

ROW CROP PLANTERS

ULTRAFLEX POPCORN - FRAME 5745 - MTH

Code: 0501092942

Series: S-0116

Revision: 00

Date Revision: ABRIL/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111190331	ULTRA FLEX SUP 5745/12E500 MTH PIP S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.



MARCHESAN

INDEX


0909095699	ASSY FRAME	1
0511051960	FRAME WITH WHEEL ARTICULATED AXIS	2
0521058396	TRACTION SPRING WHEEL ASSY WITH TRANSMISSION	3
0521058395	WHEEL SUPPORT ASSY WITH TRANSMISSION	4
0501058240	WHELL FASTENER WITH STRETCHER	5
0511054344	HYDRAULIC CYLINDER ASSEMBLY WITH 2	6
0511058406	HYDRAULIC CYLINDER	7
0511054538	MOTOR SHAFT ASSEMBLY - 5745	8
0501052560	AXLE MOTOR SLOW-MOVING ASSY	9
0511051434	TRANSMISSION DRIVING ASSY	10
0511047069	SIDE TRANSMISSION DRIVING	11
0511047070	LH SIDE TRANSMISSION DRIVING	12
0511054537	HEX AXLE ASSEMBLY - 5745	13
0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	14
0511054539	PLATFORM SET	15
0511054425	ASSY LADDER	16
0511054346	OIL CONDUCTOR ASSY - 5745	17
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	18
0511054540	HANDRAIL ASSY - 5745	19
0511054423	TRANSMISSION ASSY	20
0511048066	ASSY RIGHT EXCHANGE	21
0511048067	ASSY LEFT EXCHANGE	22
0501058241	TENSIONER CHAIN SUPPORT	23
0501053846	MIDDLE BEARING OF THE TRANSMISSION	24
0501055112	MICRO GRANULATED CHAIN TENSIONER	25
0511054541	FERTILIZER BOX ASSEMBLY	26
0511054350	HEADER	27
0511059299	SET LABEL ADHESIVE	28
0511056733	ASSY PORT MANUAL INSTRUCCION	29
0511054971	RESTING ASSEMBLY	30
0501054258	DRAWBAR ESTABILIZER ASSY	31
0511054601	FULL ARTICULATED TRACTOR HITCH	32
0511053179	TRACTOR HITCH AXLE	33
0511057257	HYDRAULIC TURBINE ASSEMBLY	34
0511057700	HYDRAULIC TURBINE	35
0511057785	VACUUM DISTRIBUTOR	36
0511057840	ASSY TURBINE HOSE REAR	37
0511059127	DUTY ASSEMBLY UPPER SEED RIGHT	38
0511059224	DUIT SET	39
0511053377	COVER ASSY	40
0909095700	SEED ROW ASSY	41
0511057244	RIGTH SHORT SEED ROW FRONT	42
0511057247	LEFT LONG SEED ROW FRONT	43
0511054635	BEARING AXLE BODY	44
0511057159	TRANSMISSION BOX SEED LINE	45
0511050609	BEARING WITH 17Z GEAR ASSY	46
0511050617	FRONT SEED ROW BEARING	47
0511055260	SEED ROW CHAIN TENSIONER	48
0511052426	TRANSMISSION CARDAN ASSY	49
0511052389	BEARING DOUBLE FRONT ROW SEED	50
0511056623	RIGHT REAR LINE SEED	51
0511056624	LEFT REAR LINE SEED	52
0511057249	PNEUMATIC SEAL DISTRIBUTOR WITH AXIS STATION	53
0511055633	PNEUMATIC DISTRIBUTOR 2014 USAP G2 APOS 05/15	54
0511055631	SUPPORT PNEUMATIC	55

INDEX

0511055624	COVER SYTEM PNEUMATIC		56
0511057153	DDD LEFT SUPREMA PRECISION PLANTING		57
0511053172	LEFT LOW CUBE WITH DISC 15		58
0511053173	CUBE LOW RIGHT WITH DISC 15		59
0511044549	18" COULTER BLADE ASSY FOR SHORT ROW		60
0511044573	18" COULTER BLADE ASSY FOR LONG ROW		61
0521045471	WHEEL SYSTEM DEPTH / CPF		62
0511053550	DEPTH CONTROL ASSY		63
0501056769	DEPTH WHEELS REGULATOR ASSY		64
0511050077	WHEEL STRIPED		65
0511052287	DEPTH WHEEL HUB ASSY		66
0501052957	IRON V PRESS WHEELS		67
0511057471	RECEIVER OF SEEDS PNEUMATIC		68
0511058212	ASSY LINE SUPPORT FERTILIZER		69

ASSY FRAME

0909095699




Item	Code	Description	See page	QT
01	0511051960	FRAME WITH WHEEL ARTICULATED AXIS	2	01
02	0521058396	TRACTION SPRING WHEEL ASSY WITH TRANSMISSION	3	04
03	0511054344	HYDRAULIC CYLINDER ASSEMBLY WITH 2	6	01
04	0511054538	MOTOR SHAFT ASSEMBLY - 5745	8	01
05	0511054537	HEX AXLE ASSEMBLY - 5745	13	01
06	0511054539	PLATFORM SET	15	01
07	0511054425	ASSY LADDER	16	01
08	0511054346	OIL CONDUCTOR ASSY - 5745	17	01
09	0511054540	HANDRAIL ASSY - 5745	19	01
10	0511054423	TRANSMISSION ASSY	20	01
11	0511054541	FERTILIZER BOX ASSEMBLY	26	01
12	0511054350	HEADER	27	01
13	0511059299	SET LABEL ADHESIVE	28	01
14	0511056733	ASSY PORT MANUAL INSTRUCCION	29	01
15	0511054971	RESTING ASSEMBLY	30	02
16	0503034003	SERIAL NUMBER TAG 61 X 118		01
17	0503010001	3.2 X 5.5 RIVET		01
18	0501054258	DRAWBAR ESTABILIZER ASSY	31	01
19	0503031436	AIR DITRIBUTOR PUMP		08
20	0511054601	FULL ARTICULATED TRACTOR HITCH	32	01
21	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
22	0511053179	TRACTOR HITCH AXLE	33	01
23	0502012702	BODY SUPPORT CLAMP		01
24	0531011180	UPPER BODY CLIP		01
25	0501047895	ROD STOP		02
26	0501047885	ROD STOP		02
27	0501047886	ROD STOP		02
28	0501047887	ROD STOP		02
29	0501065677	STRUT		02
30	0521013022	TRANSPORT LOCK		02
31	0541011767	HOSE FIXATION		01


ASSY FRAME

0909095699


Item	Code	Description	See page	QT
32	0503030168	HAIR PIN		02
33	0503010246	CLAMP		32
34	0503011750	AMENDMENT WITH LOCK		06
35	0503011751	REDUCTION		06
36	0503010543	AMENDMENT WITH LOCK		02
37	0503010780	N-2050 AMENDMENT		04
38	0511057257	HYDRAULIC TURBINE ASSEMBLY	34	01
39	0511059127	DUTY ASSEMBLY UPPER SEED RIGHT	38	06
40	0511059224	DUIT SET	39	06
41	0511053377	COVER ASSY	40	02
42	0501068994	0.3" X 3.1" LOCK PIN		02
43	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		01
44	0503010019	1/2" SPRING WASHER		01
45	0531018227	2" X 200 HOSE ASSY		12
46	0511058550	HOSE SUPPORT		01
47	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		14
48	0503010025	3/8" SPRING WASHER		14
49	0503010026	3/8" NUT		14
50	0909095700	SEED ROW ASSY	41	12




Item	Code	Description	See page	QT
01	0521063219	FRAME		01
02	0521063222	WHEELED ARTICULATED AXLE		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8" X 2-1/4" BOLT		12
05	0531013922	0.6" X 0.8" X 1" SLEEVE		12
06	0503010013	5/8" NUT		12
07	0503011445	SPRING WASHER		12
08	0501012140	FLAT WASHER		24




Item	Code	Description	See page	QT
01	0521058395	WHEEL SUPPORT ASSY WITH TRANSMISSION	4	01
02	0501058240	WHELL FASTENER WITH STRETCHER	5	01
03	1902010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503013257	2050 CHAIN X 89 LINK + MENDING		01
07	0503011254	7/8" HEX SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0521061565	WHEEL SUPPORT ARM		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0501058241	TENSIONER CHAIN SUPPORT	23	01
11	0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH TRANSMISSION		01
12	0521069983	WHEEL COVER		01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8" SPRING WASHER		04
15	0503018981	BOLT		02




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	STRETCHER INTERMEDIATE RODE CURRENT		01
07	0501058244	STRETCHER FIXED CURRENT		01
08	0501058242	MOVIL CHAIN TENSIONER		01




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	7	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521012536	COUPLING SHAFT		02
04	0503010523	1/4" X 2" COTTERPIN		04
05	0503010003	1845 GREASE FITTING		08




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01




Item	Code	Description	See page	QT
01	0511064914	MOTOR CHOCK BEARING SUPPORT		04
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
03	0511017302	FLAT WASHER		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0501110639	BEARING		08
07	0503010300	5/32" X 1" COTTERPIN		08
08	0503011099	GREASE FITTING		08
09	0531017204	CHOCK BEARING		04
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		08
11	0503010025	3/8" SPRING WASHER		08
12	0503010026	3/8" NUT		08
13	0571011442	MOTOR SHAFT		02
14	0501018466	FLAT WASHER		04
15	0511015961	LOCK BUSHING		04
16	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
17	0503010060	1/2" NUT		04
18	0501052560	AXLE MOTOR SLOW-MOVING ASSY	9	02
19	0511051434	TRANSMISSION DRIVING ASSY	10	04
20	0511047069	SIDE TRANSMISSION DRIVING	11	01
21	0511047070	LH SIDE TRANSMISSION DRIVING	12	01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	5/16" X 3/4" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0561018502	SHAFT AXIS 5/8 X 3000		01
02	0531016947	LEFT 5/8" X 108" AXLE HEX		01
03	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	14	02
04	0561014215	BEARING COVER LOWER ROW FRAME		02
05	0502040534	SPRING GUIDE BUSHING LOCK		04
06	0503010237	3/8" X 1" BOLT		04




Item	Code	Description	See page	QT
01	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8		01
02	0511063106	20Z AXLE BEARING DOBLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0503010365	NUT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0503010920	1/2" X 1.1/2" BOLT		08
02	0511017302	FLAT WASHER		08
03	0503010019	1/2" SPRING WASHER		08
04	0503010060	1/2" NUT		08
05	0521063232			02
06	0571011661			04
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		08
08	0501010984	FLAT WASHER		08
09	0503010025	3/8" SPRING WASHER		08
10	0503010026	3/8" NUT		08
11	0551019056	SIDE PLATFORM SUPPORT		02

ASSY LADDER


0511054425




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		04
02	0503010237	3/8" X 1" BOLT		08
03	0503010025	3/8" SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0511069819	SIDE LADDER		02
06	0501010096	3/8" X 2" BOLT		04
07	0501010984	FLAT WASHER		04
08	0503013357	3/8" SELF-ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0511064465	OIL CONDUCTOR		01
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
03	0503010025	3/8" SPRING WASHER		02
04	0501010984	FLAT WASHER		02
05	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	18	02
06	0511057064	HOSE KIT SYSTEM HYDRAULIC		01
06A	0501080402	HOSE 3/8 X 1700 TR-TC		04
06B	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
06BA	0501080185	HOSE 1/2 X 4000 TR-TM		01
06BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
06BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
06BD	0503018952	PLASTIC BOLT		06
06C	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
06CA	0501080185	HOSE 1/2 X 4000 TR-TM		01
06CB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
06CC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
06CD	0503018952	PLASTIC BOLT		06
07	0581010729	SPRING PROTECTION PLASTIC HOSE 3/4 X 3800MM		01
08	0502012702	BODY SUPPORT CLAMP		04
09	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
10	0503010180	7/16" SPRING WASHER		04




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01



Item	Code	Description	See page	QT
01	0521063235	LEFT HANDRAIL		01
02	0521063236	RIGHT HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		12
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12




Item	Code	Description	See page	QT
01	0511048066	ASSY RIGHT EXCHANGE	21	01
02	0511048067	ASSY LEFT EXCHANGE	22	01
03	0501010243	1/2" X 1-1/2" BOLT		06
04	0503010920	1/2" X 1.1/2" BOLT		04
05	0511017302	FLAT WASHER		08
06	0503010019	1/2" SPRING WASHER		10
07	0503012682	1/2" BSW NUT		06
08	0503010060	1/2" NUT		04
09	0501058241	TENSIONER CHAIN SUPPORT	23	02
10	0501053846	MIDDLE BEARING OF THE TRANSMISSION	24	02
11	0501055112	MICRO GRANULATED CHAIN TENSIONER	25	02
12	0561014215	BEARING COVER LOWER ROW FRAME		02
13	0503013114	40-1 CHAIN X 89 LINK + MENDING		02
14	0503013073	40-1 CHAIN X 75 LINK + MENDING		02
15	0503013167	40-1 CURRENT X 126 LINK + MENDING		02



Item	Code	Description	See page	QT
01	0503010292	0.2" X 1.6" SPRING PIN	02	
02	0503031366	RIGHT TWISTED SPRING RECAMBIO	01	
03	0511061794	CHAIN TENSIONER	01	
04	0521060977	SUPPORT RIGHT GEAR	01	
05	0502011758	REAR TENSIONER LEVER	02	
06	0503010002	1800 GREASE FITTING	01	
07	0501056271	BEARING CLOSED	05	
08	0503011953	5/16" X 1" BOLT	10	
09	0501010694	8.5 X 18 X 1.5 FLAT WASHER	10	
10	0503010179	5/16" ZN SPRING WASHER	10	
11	0503010337	5/16" NUT	10	
12	0501056443	BEARING ASSY GEAR BOX	01	
13	0503030303	SUPPORT WASHER	07	
14	0521018630	1.4" X SQUARE 0.8" WASHER	06	
15	0561014060	LEFT RIGHT DRIVE MOTOR AXLE	01	
16	0561014061	LEFT RIGHT EXCHANGE SHAFT	01	
17	0561014062	LEFT RIGHT INTERMEDIATE AXIS	01	
18	0503010292	0.2" X 1.6" SPRING PIN	06	
19	0511064680	FERTILIZER SIST AXLE CONE	02	
20	0503012389	1/2 BALL	02	
21	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING	02	
22	0511067501	26Z GEAR	01	
23	0511061830	17Z P 0.5" GEAR SQUARE HOL	02	
24	0511064536	28Z GEAR	01	
25	0501010984	FLAT WASHER	01	
26	0503010025	3/8" SPRING WASHER	01	
27	0503010237	3/8" X 1" BOLT	01	
28	0503031805	11Z 1/2" GEAR	03	
29	0503010302	501019 SEAL RING	02	
30	0531019479	AXLE CHAIN GEAR	01	
31	0511017302	FLAT WASHER	01	



Item	Code	Description	See page	QT
32	0503010019	1/2" SPRING WASHER		01
33	0503010060	1/2" NUT		01
34	0501048790	AXLE WITH LINK ASSY		01
35	0503012204	40-1 CHAIN X 82 LINK + RED		01
36	0503012713	40-1 CHAIN X 45 LINK + MEN		01




Item	Code	Description	See page	QT
01	0503010292	0.2" X 1.6" SPRING PIN	02	
02	0503031367	SPRING	01	
03	0511061794	CHAIN TENSIONER	01	
04	0521060978		01	
05	0502011758	REAR TENSIONER LEVER	02	
06	0503010002	1800 GREASE FITTING	01	
07	0501056271	BEARING CLOSED	05	
08	0503011953	5/16" X 1" BOLT	10	
09	0501010694	8.5 X 18 X 1.5 FLAT WASHER	10	
10	0503010179	5/16" ZN SPRING WASHER	10	
11	0503010337	5/16" NUT	10	
12	0501056443	BEARING ASSY GEAR BOX	01	
13	0503030303	SUPPORT WASHER	07	
14	0521018630	1.4" X SQUARE 0.8" WASHER	07	
15	0561014060	LEFT RIGHT DRIVE MOTOR AXLE	01	
16	0561014061	LEFT RIGHT EXCHANGE SHAFT	01	
17	0561014062	LEFT RIGHT INTERMEDIATE AXIS	01	
18	0503010292	0.2" X 1.6" SPRING PIN	06	
19	0502040868	GEAR CONE REPLACEMENT	02	
20	0503012389	1/2 BALL	02	
21	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING	02	
22	0511067501	26Z GEAR	01	
23	0511061830	17Z P 0.5" GEAR SQUARE HOL	02	
24	0511064536	28Z GEAR	01	
25	0501010984	FLAT WASHER	01	
26	0503010025	3/8" SPRING WASHER	01	
27	0503010237	3/8" X 1" BOLT	01	
28	0503031805	11Z 1/2" GEAR	03	
29	0503010302	501019 SEAL RING	02	
30	0531019479	AXLE CHAIN GEAR	01	
31	0511017302	FLAT WASHER	01	


**ASSY LEFT EXCHANGE**

0511048067


Item	Code	Description	See page	QT
32	0503010019	1/2" SPRING WASHER		01
33	0503010060	1/2" NUT		01
34	0501048790	AXLE WITH LINK ASSY		01
35	0503012204	40-1 CHAIN X 82 LINK + RED		01
36	0503012713	40-1 CHAIN X 45 LINK + MEN		01



Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page
01	0501053846	MIDDLE BEARING OF THE TRANSMISSION	24
01A	0511063266	INTERMEDIARY BEARING SUPPORT	
01B	0501052775	ROW SEED BEARING	
01Ba	0502011697	BEARING OF THE GEAR BOX	
01C	0531013674	INTERMEDIATE AXLE	
01D	0541011184	1.1" X 2" X 0.7" SLEEVE	
01E	0503010292	0.2" X 1.6" SPRING PIN	
01F	0511063268	20Z P1/2" GEAR FOR HEX AXLE, 1"	
01G	0511063267	26Z P1/2" GEAR FOR HEX AXLE, 1"	
01H	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	
01I	0501010984	FLAT WASHER	
01J	0503010025	3/8" SPRING WASHER	
01K	0503010026	3/8" NUT	
01L	0503011410	ROLLER BEARING	
01M	0503011105	SEAL RING	
01N	0503010371	5/16" X 1" BOLT	
01O	0501010694	8.5 X 18 X 1.5 FLAT WASHER	
01P	0503010179	5/16" ZN SPRING WASHER	
01Q	0503010337	5/16" NUT	
01R	0503012717	40-1 CHAIN X 101 LINK + MENDING	
01S	0503012718	40-1 CHAIN X 111 LINK + MENDING	



Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01

FERTILIZER BOX ASSEMBLY

0511054541




Item	Code	Description	See page	QT
01	0521063234	SUPPORT RIGHT SILO SEED		01
02	0521063233	LEFT SUPPORT SILO SEED		01
03	0571019379	INTERMEDIATE TURNBUCKLE		02
04	0571019380	TURNBUCKLE SUPPORT SILO		04
05	0521063221	INTERMEDIARY SUPPORT LEVER SILO LEFT		01
06	0521063220	INTERMEDIARY SUPPORT LEVER SILO RIGHT		01
07	0503010920	1/2" X 1.1/2" BOLT		46
08	0511017302	FLAT WASHER		92
09	0503010019	1/2" SPRING WASHER		46
10	0503010060	1/2" NUT		46
11	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		02
12	0503062018	FERTILIZER SILO SUPORT ASSY		02
13	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		08
14	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		16
15	0501010984	FLAT WASHER		32
16	0503010025	3/8" SPRING WASHER		16
17	0503010026	3/8" NUT		16
18	0503011957	NYLON LUG		02
19	0503010371	5/16" X 1" BOLT		04
20	0503010179	5/16" ZN SPRING WASHER		04
21	0503010337	5/16" NUT		04
22	0571019381	GEAR BOX LEVER LOCK		02
23	0503011953	5/16" X 1" BOLT		04
24	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
25	0503010179	5/16" ZN SPRING WASHER		04
26	0503010337	5/16" NUT		04
27	0571019383	LEVER ARM DISARMING		02
28	0503011312	ROTATIVE CABLE		02
29	0503010479	BOLT		02
30	0511017302	FLAT WASHER		06
31	0551019168	SLEEVE		02




FERTILIZER BOX ASSEMBLY

0511054541


Item	Code	Description	See page	QT
32	0561016797	SLEEVE UNION LEVER ARM/DESARM		02
33	0521063357	SMALLER LEVER RIGHT		01
34	0521063356	SMALLER LEVER LEFT		01
35	0503011082	C1/2" X 1.3/4" SCREW		02
36	0503011336	1/2" HEX SELF ADJUSTING NUT		02
37	0503010140	1/8" X 3/4" COTTERPIN		06
38	0521061742	RH LOWER LEVER		01
39	0521061743	LH LOWER LEVER		01
40	0511069679	RH UPPER LEVER		02
41	0561016468	FASTENER		02
42	0503011336	1/2" HEX SELF ADJUSTING NUT		04
43	0503010019	1/2" SPRING WASHER		06
44	0503010060	1/2" NUT		06



Item	Code	Description	See page	QT
01	0502012328	DRAWBAR SUPPORT FRONT FIXATION		04
02	0502012330	SUPPORT FIXER PIVOT		04
03	0503011084	3/4" X 5" BOLT		08
04	0503010023	3/4" SPRING WASHER		08
05	0503010014	3/4" NUT		08
06	0502012329	DRAWBAR FIXATION REAR SUPPORT		04
07	0502012330	SUPPORT FIXER PIVOT		04
08	0503011084	3/4" X 5" BOLT		08
09	0503010023	3/4" SPRING WASHER		08
10	0503010014	3/4" NUT		08
11	0561014393	COUPLING SHAFT		04
12	0503010523	1/4" X 2" COTTERPIN		04
13	0503030119	LOCK PIN		04
14	0511062824	DRAWBAR		00
15	0561019087	DRAWBAR TRANSPORT LOCK		01
16	0521010578	COUPLING SHAFT		01
17	0521010582	COUPLING SHAFT		01
18	0503030085	LOCK PIN		02
19	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503033872	ADHESIVE LABEL		04
02	0503033854	ADHESIVE LABEL		04
03	0503033853	ADHESIVE LABEL		02
04	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		04
06	0503033421	ADHESIVE LABEL 7 NUMBER FOR PLANTING		02
07	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
08	0503033008	ADHESIVE LABEL		02
09	0503031087	ADHESIVE LABEL		01
10	0503032930	ADHESIVE LABEL DANGER		06
11	0503031942	ADHESIVE LABEL		01
12	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
13	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
14	0503031425	ADHESIVE LABEL ATTENTION		02
15	0503031428	READ MANUAL DECAL		01
16	0503031566	ADHESIVE LABEL		02
17	0503031565	ADHESIVE LABEL CARE		02
18	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
19	0503032979	ADHESIVE LABEL LETTERS A B C D		02
20	0503034500	ADHESIVE LABEL		01
21	0503034078	LIFTING POINTS DECAL		03




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0511031620	BAG WITH MANUAL / CATALOG		01
03	0503010267	NYLON CLAMP		01
04	0503010363	5/16" X 1" BOLT		01
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
06	0503010179	5/16" ZN SPRING WASHER		01
07	0503010337	5/16" NUT		01

RESTING ASSEMBLY


0511054971




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0571012612	PIVOT SHAFT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HAIR PIN		01




Item	Code	Description	See page	QT
01	0571019979	SHAFT FIXER BODY		01
02	0571019978	LEFT BODY		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2" NUT		04
06	0511057700	HYDRAULIC TURBINE	35	01
07	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
08	0501012140	FLAT WASHER		02
09	0503012412	5/8 UNC SELF LOCKING NUT		02
10	0571012663	VACUUM GAUGE SUPPORT		01
11	0571016669	CONECTOR CAPE		01
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		02
15	0503010026	3/8" NUT		02
16	0503013584	VACUUM GAUGE		01
17	0571019963	AIR DISTRIBUTOR SUPPORT		04
18	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
19	0501013519	FLAT WASHER		08
20	0503010019	1/2" SPRING WASHER		08
21	0503010060	1/2" NUT		08
22	0511057785	VACUUM DISTRIBUTOR	36	02
23	0521014442	LOWER AIR DISTRIBUTOR SUPPORT		04
24	0503010363	5/16" X 1" BOLT		04
25	0503010179	5/16" ZN SPRING WASHER		04
26	0503010337	5/16" NUT		04
27	0503031576	ELBOW		04
28	0521018615	HOSE 4 X 1300		02
29	0503011372	102 TO 121 CLAMP		04
30	0503015062	TUBE		03
31	0511057840	ASSY TURBINE HOSE REAR	37	02




Item	Code	Description	See page	QT
01	0501054983	NIPPLE HIDRAULIC MOTOR	01	
02	0503010025	3/8" SPRING WASHER	10	
03	0503010026	3/8" NUT	08	
04	0521044613	FAN 480X50 (HIDRAULIC)	01	
05	0503010143	1/4" SPRING WASHER	01	
06	0503010849	3/8" X 1-1/2" BOLT	02	
07	0531018764	FLAT WASHER	01	
08	0503011104	M6 X 1" BOLT	01	
09	0503012722	0.16" X 0.4" BLIND RIVET	20	
10	0521065858	TURBIN SUPPORT	01	
11	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE	01	
12	0561010634	VALVE SUPPORT ASSY	01	
13	0503010237	3/8" X 1" BOLT	06	
14	0503010206	3/8" X 1/2" BOLT	02	
15	0571018577	COVER SNAIL TURBINE	01	
16	0521066237	SNAIL MECHANICAL TURBINE HIDRAULIC	01	
17	0503010358	5/16" X 5/8" BOLT	02	
18	0503010179	5/16" ZN SPRING WASHER	02	
19	0503010337	5/16" NUT	02	
20	0501080125	HOSE 1/2 X 500 TR TR	02	
21	0501080635	3/8" X 19" TR-TR HOSE	01	
22	0521018517	FLAT WASHER	02	
23	0503031649	CONECTOR CENTER	01	



Item	Code	Description	See page	QT
01	0571019982	BODY DISTRIBUTOR VACUUM		01
02	0503012566	COVER KAP 110 YELLOW		01
03	0571017215	SOCKET DISTRIBUTOR AR		01
04	0503012856	REBITE POP		14
05	0503031943	SOCKET		07




Item	Code	Description	See page	QT
01	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
01A	0501081247	HOSE 1/2 X 7012 TC-TM		01
01B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01D	0503018952	PLASTIC BOLT		06
02	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01
02A	0501081247	HOSE 1/2 X 7012 TC-TM		01
02B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
02C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
02D	0503018952	PLASTIC BOLT		06
03	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
03A	0501080477	HOSE 3/8 X 7012 TC-TM		01
03B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
03C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
03D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0521067310	DUCT UPPER SEED RIGHT		01
02	0501010942	3/8" X 1-1/4" BOLT		04
03	0501010984	FLAT WASHER		04
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0551016144	3" X 1500 AIR CONDUCTOR		01
07	0561014231	TUBE CAP UPPER		01
08	0501010942	3/8" X 1-1/4" BOLT		01
09	0503010025	3/8" SPRING WASHER		01
10	0503010209	3/8" UNC BUTTERFLY NUT		01

DUIT SET


0511059224




Item	Code	Description	See page	QT
01	0521067309	SUPPORT DUCT SEED LEFT		01
02	0501010942	3/8" X 1-1/4" BOLT		04
03	0501010984	FLAT WASHER		04
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0551016144	3" X 1500 AIR CONDUCTOR		01
07	0561014231	TUBE CAP UPPER		01
08	0501010942	3/8" X 1-1/4" BOLT		01
09	0503010025	3/8" SPRING WASHER		01
10	0503010209	3/8" UNC BUTTERFLY NUT		01



Item	Code	Description	See page	QT
01	0502012732	DUCT BODY	01	
02	0501010942	3/8" X 1-1/4" BOLT	04	
03	0501010984	FLAT WASHER	04	
04	0503010025	3/8" SPRING WASHER	04	
05	0503010026	3/8" NUT	04	
06	0571013983	SEED CONDUCTOR COVER	01	
07	0503011087	3/8" X 1" BOLT	02	
08	0501013518	FLAT WASHER	02	
09	0503010025	3/8" SPRING WASHER	02	
10	0503010026	3/8" NUT	02	




Item	Code	Description	See page	QT
01	0511057244	RIGTH SHORT SEED ROW FRONT	42	06
02	0511057247	LEFT LONG SEED ROW FRONT	43	06
03	0511056623	RIGHT REAR LINE SEED	51	04
04	0511056624	LEFT REAR LINE SEED	52	04
05	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	60	06
06	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	61	06
07	0511058621	CORN DISC PNEUMATIC		12
07A	0571016221	CORN DISC PNEUMATIC		01
07B	0503031863	ADHESIVE LABEL		01
08	0521045471	WHEEL SYSTEM DEPTH / CPF	62	12
09	0503010905	1/2" X 2-1/4" BOLT		24
10	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		32
11	0503010019	1/2" SPRING WASHER		56
12	0503010060	1/2" NUT		56
13	0511057471	RECEIVER OF SEEDS PNEUMATIC	68	12
14	0511058212	ASSY LINE SUPPORT FERTILIZER	69	12
15	0501011543	5/8" X 4" BOLT		24
16	0503012412	5/8 UNC SELF LOCKING NUT		24



Item	Code	Description	See page	QT
01	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8 UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	44	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
08	0503010179	5/16" ZN SPRING WASHER		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION BOX SEED LINE	45	01
12	0561014904	TRANSMISSION AXLE FRAME LINE		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	46	01
14	0511055260	SEED ROW CHAIN TENSIONER	48	01
15	0502012666	SEDD ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521065847	SHORT TIRE SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" COTTERPIN		01
27	0503030168	HAIR PIN		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" COTTERPIN		01
31	0503034580	TRACTION SPRING		02




Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY	49	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064650	LEFT SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8 UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	44	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
08	0503010179	5/16" ZN SPRING WASHER		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION BOX SEED LINE	45	01
12	0561014904	TRANSMISSION AXLE FRAME LINE		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	46	01
14	0511055260	SEED ROW CHAIN TENSIONER	48	01
15	0502012666	SEDD ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521065847	SHORT TIRE SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" COTTERPIN		01
27	0503030168	HAIR PIN		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" COTTERPIN		01
31	0503034580	TRACTION SPRING		02




Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY	49	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0502012718	BEARIN BODY		01
02	0503012882	BEARING		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511050617	FRONT SEED ROW BEARING	47	01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0502012819	17Z GEAR WITH HEX HOLE		01

FRONT SEED ROW BEARING


0511050617




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511052389	BEARING DOUBLE FRONT ROW SEED	50	01
02	0551017559	BEARING AXLE BODY		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0551017540	5/8" X 73 AXLE HEX		01
05	0501056296	UNIVERSAL JOINT		01
06	0503011855	0.2" X 1.8" SPRING PIN		03
07	0571012412	HEX AXLE		01
08	0561014778	HEX UNIVERSAL JOINT		01
09	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0511057249	PNEUMATIC SEAL DISTRIBUTOR WITH AXIS 53 STATION		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062390	SEED CONDUCTOR		01
06	0511057154	DDD RITGH SUPREMA PRECISION PLANTING		01




Item	Code	Description	See page	QT
01	0511057249	PNEUMATIC SEAL DISTRIBUTOR WITH AXIS 53 STATION		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062390	SEED CONDUCTOR		01
06	0511057153	DDD LEFT SUPREMA PRECISION PLANTING	57	01




Item	Code	Description	See page	QT
01	0511055633	PNEUMATIC DISTRIBUTOR 2014 USAP G2 APOS 54 05/15	54	01
02	0501056296	UNIVERSAL JOINT		01
03	0571018555	170 HEX AXLE SEED		01
04	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0511055631	SUPPORT PNEUMATIC	55	01
02	0511055624	COVER SYTEM PNEUMATIC	56	01
03	0511058626	SOYBEAN DISC 7040		01
04	0503033839	STIRRER SEED PNEUMATIC DISTRIBUTOR		01
05	0503017375	1/2" X 1-1/4" BOLT		01




Item	Code	Description	See page	QT
01	0503011183	6007 ROLLER BEARING		01
02	0503010246	CLAMP		01
03	0503017374	M6 X 1" BOLT		03
04	0502012761	SUPPORT PNEUMATIC		01
05	0503033978	FASTENER JOINT RUBBER		02
06	0503033977	GASKET PNEUMATIC		01
07	0503033958	PROTECTION COVER SOCKET PNEUMATIC		01
08	0502050020	SUPPORT DISC PNEUMATIC		01
09	0503033974	ELBOW SUCTION PNEUMATIC		01
10	0503017372	BOLT M6 X 1 X 65		03
11	0511055632	BOX TRANSMISSION PNEUMATIC		01
12	0503017373	BOLT		01
13	0521065278	STRAW SHIELD PNEUMATIC		01
14	0503017868	BOLT		01
15	0503012722	0.16" X 0.4" BLIND RIVET		02
16	0503010179	5/16" ZN SPRING WASHER		04
17	0571014024	FAST BOLT GUIDE AXLE		02
18	0502012744	SPEED LOCK LEVER ASSY		01
19	0571011804	FAST BOLT ADJUSTMENT		01
20	0571011803	PRISONER CLOSE FAST		01
21	0503010140	1/8" X 3/4" COTTERPIN		04
22	0503010025	3/8" SPRING WASHER		01
23	0503010849	3/8" X 1-1/2" BOLT		01
24	0571018506	SLEEVE SUPPORT		01
25	0571018508	SEED BOX BASE AXLE		01
26	0571018507	FIXER OF PROTECTION		01




Item	Code	Description	See page	QT
01	0501110311	LOWER SELECTOR ASSY	01	
02	0502050051	COVER KIT PNEUMATIC	01	
03	0503033959	SELECTOR PNEUMATIC	01	
04	0503033957	DISPLAY	01	
05	0503033960	DRAINER PNEUMATIC	01	
06	0571016191	SLUICE DOSER PNEUMATIC	01	
07	0571016189	REGULATOR PNEUMATIC	01	
08	0571016188	ADJUSTMENT AXLE SELECTOR PNEUMATIC	01	
09	0503010846	0.31" X 0.55" 701179 SPRING PIN	02	
10	0503011776	M6 SELF ADJUSTINGNUT	01	
11	0571016520	FIXER SLUICE VALVE PNEUMATIC	01	
12	0571016202	DISPLAY REGULATOR	01	
13	0503015536	M6 X 1" SELF ADJUSTING NUT	02	
14	0571017273	REGULATOR SELECTOR PNEUMATIC	01	
15	0571017267	POSITIONER RADIUS PNEUMATIC	01	
16	0503012722	0.16" X 0.4" BLIND RIVET	04	
17	0571018556	DISPLAY REGULATOR	01	
18	0503017868	BOLT	01	
19	0503017869	M6 X 1" BOLT	01	
20	0503017374	M6 X 1" BOLT	03	




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	58	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15	59	01
04	0503010026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511015098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02



Item	Code	Description	See page	QT
01	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01



Item	Code	Description	See page	QT
01	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01	
02	0502012368	BLADE DISC SUPPORT AXLE	01	
03	0503010756	0.2" X 2.4" SPRING PIN	01	
04	0503010361	SPRING PIN	01	
05	0541018684	FLAT WASHER	01	
06	0521014137	RIGHT ARM OF THE BLADE DISC	01	
07	0521014138	SUPPORT ARM LEFT BALDE DISC	01	
08	0501067323	SPRING REGULATOR	01	
09	0521010452	SLEEVE	01	
10	0503013185	3/4" X 5-1/2" BOLT	01	
11	0503011255	3/4" LOCK NUT	01	
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
13	0503011411	1/2" X 5-1/2" BOLT	01	
14	0503011440	SPRING WASHER	01	
15	0503010060	1/2" NUT	01	
16	1902020393	SPRING UPPER SUPPORT	01	
17	0502020394	SPRING SUPPORT	01	
18	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
19	0503010014	3/4" NUT	02	
20	0521015376	DUST CLOAK	02	
21	0502011562	DC BOX	01	
22	0503010276	6206 BALL BEARING	02	
23	0521013610	BLADE DISC HUB AXLE	01	
24	0503030832	FLAT WASHER	02	
25	0503012417	SEAL	02	
26	0503011800	SEAL RING	02	
27	0503010691	1/4" GREASE FITTING	01	
28	0603026013	PLAIN COULTER BLADE	01	
29	0502020641	BLADE DISC FLANGE	01	
30	0503010371	5/16" X 1" BOLT	06	
31	0503011444	SPRING WASHER	06	



ULTRAFLEX POPCORN - FRAME 5745 - MTH
18" COULTER BLADE ASSY FOR SHORT ROW

Page 60
0511044549

Item	Code	Description	See page	QT
32	0503010337	5/16" NUT		06
33	0511815346	FLAT WASHER		02
34	0503011442	3/4" SPRING WASHER		02
35	0521813510	R3/4UNC NUT		02
36	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE		01
02	0502012368	BLADE DISC SUPPORT AXLE		01
03	0503010756	0.2" X 2.4" SPRING PIN		01
04	0503010361	SPRING PIN		01
05	0541018684	FLAT WASHER		01
06	0521014137	RIGHT ARM OF THE BLADE DISC		01
07	0521014138	SUPPORT ARM LEFT BALDE DISC		01
08	0501067323	SPRING REGULATOR		01
09	0521010452	SLEEVE		01
10	0503013185	3/4" X 5-1/2" BOLT		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	0503011411	1/2" X 5-1/2" BOLT		01
14	0503011440	SPRING WASHER		01
15	0503010060	1/2" NUT		01
16	0502020393	SPRING UPPER SUPPORT		01
17	0502020394	SPRING SUPPORT		01
18	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
19	0503010014	3/4" NUT		02
20	0521015376	DUST CLOAK		02
21	0502011562	DC BOX		01
22	0503010276	6206 BALL BEARING		02
23	0521013610	BLADE DISC HUB AXLE		01
24	0503030832	FLAT WASHER		02
25	0503012417	SEAL		02
26	0503011800	SEAL RING		02
27	0503010691	1/4" GREASE FITTING		01
28	0603026013	PLAIN COULTER BLADE		01
29	0502020641	BLADE DISC FLANGE		01
30	0503010371	5/16" X 1" BOLT		06
31	0503010179	5/16" ZN SPRING WASHER		06




ULTRAFLEX POPCORN - FRAME 5745 - MTH
18" COULTER BLADE ASSY FOR LONG ROW

Page 61
0511044573


Item	Code	Description	See page	QT
32	0503010337	5/16" NUT		06
33	0511015346	FLAT WASHER		02
34	0503010023	3/4" SPRING WASHER		02
35	0521013510	3/4" NUT		02
36	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511053550	DEPTH CONTROL ASSY	63	01
02	0511050077	WHEEL STRIPED	65	02
03	0501052957	IRON V PRESS WHEELS	67	02
04	0503010547	1/2" X 4" BOLT		02
05	0521014508	FLAT WASHER		10
06	0503011336	1/2" HEX SELF ADJUSTING NUT		02
07	0503010905	1/2" X 2-1/4" BOLT		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2" NUT		02
10	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521064073	REGULACION WHEEL COMPACTOR		01
03	0521019093	0.6" X 2.7" PIVOT SHAFT		01
04	0503010581	RING		01
05	0571013054	DEPTH CONTROL WHEEL AXLE		01
06	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
07	0511015346	FLAT WASHER		04
08	0501110720	ARM LEFT		01
08A	0502012726	LEFT DEPTH WHEEL ARM		01
08B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL		02
09	0501110719	DEPTH CONTROL RIGHT ARM		01
09A	0502012725	DEPTH WHEEL RIGHT ARM		01
09B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL		02
10	0511017302	FLAT WASHER		02
11	0503011440	SPRING WASHER		04
12	1902012116	PRESS WHEEL ADJUSTER		01
13	0503010849	3/8" X 1-1/2" BOLT		02
14	0503011443	3/8" SPRING WASHER		02
15	0503010026	3/8" NUT		02
16	0521010539	0.3" X 1.2" COUPLING SHAFT		01
17	0503010140	1/8" X 3/4" COTTERPIN		01
18	0502012663	EXTENSION		01
19	0503010002	1800 GREASE FITTING		02
20	0503010060	1/2" NUT		02
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
22	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
23	0541016906	PRESS WHEELS REGULATOR BODY		01
24	0501056769	DEPTH WHEELS REGULATOR ASSY	64	01
25	0503010311	1/2" X 1-1/4" BOLT		02
26	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
01	0503010257	1/8" X 1" COTTERPIN		01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0502011689	1/8" DEPTH CONTROL LEVER		01
04	0502011688	SEED SIST CONTROL DEPTH LEVER		01
05	0511065582	DEPTH WHEEL STOP		01
06	0503030975	0.9" X 1.5" X 0.1" SPRING		01
07	0511015976	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	66	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	5/16" ZN SPRING WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEELS BOX		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0502011932	IRON PRESS WHEELS		01
02	0503010269	6204 BALL BEARING		02
03	0503011105	SEAL RING		01
04	0503013848	5072-BR SEAL		02
05	0521019147	V COMPACT WHEELS AXLE		02
06	0511011927	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01



Item	Code	Description	See page	QT
01	0521065830	SUPPORT BASE SYSTEM PNEUMATIC	01	
02	0571018512	GUIDE SLUICE PNEUMATIC	01	
03	0571018513	SLUICE PNEUMATIC	01	
04	0501011643	3/8 X 1" BOLT	01	
05	0503010209	3/8" UNC BUTTERFLY NUT	01	
06	0503010025	3/8" SPRING WASHER	01	
07	0503010026	3/8" NUT	03	
08	0503011953	5/16" X 1" BOLT	04	
09	0503010179	5/16" ZN SPRING WASHER	04	
10	0503010337	5/16" NUT	01	
11	0521066185	CONDUCTOR BOTTOM OFFSET	01	



Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02



MARCHESAN

Technical Publications | Elaboration and Revision

LORENA ROCHA ALVES

www.marchesan.com.br

