

ROW CROP PLANTERS

USAP TITANIUM - FRAME 12050 - CSU/FERTILIZER/SEED/CM/TCE/TMC/MS

Code: 0501092955
Series: S-0419
Revision: 00
Date Revision: ABRIL/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111140442	USAP 12050/24E500 CSU CM TIT DT ESPECIAL S-0419

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.



MARCHESAN

INDEX

0909095726	FRAME ASSY	1
0909095727	FRAME RIGHT SIDE ASSY	2
0909095728	ASSY CENTRAL FRAME	3
0909095729	LEFT SIDE FRAME ASSY	4
0909095730	SEED LINE/ASSY FERTILIZER	5
0521058670	TELESCOPIC ASSY 760/3225 INTERNAL TUBE	6
0521057792	PANTOGRAPHY HEADER	7
0521057786	HYDRAULIC CYLINDER HEAD PANTOGRAPH	8
0521058633	FRENCH HAND 1725X1800X4737 ASSY LEFT	9
0521058632	FRENCH HAND	10
0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	11
0521058088	ROTULA WITH EXTENSOR AXIS 2	12
0521051438	HEADER 3 POINTS ASSY	13
0511052052	SUPPORT WITH FIXATION	14
0521057773	SEMI-ASSEMBLED REST	15
0511053121	GREATER TOOL BOX ASSY	16
0521058344	WATER RESERVOIR WITH SOAP	17
0521058636	ASSY SIDE HEX AXLE	18
0521055326	RIGHT WHEEL WITH TRANSMISSION	19
0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	20
0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	21
0511054491	WHEEL WITHOUT TIRE WITH 27Z GEAR	22
0511054463	WHEEL TENSIONER SUPORT CENTRAL	23
0511054464	WHEEL FORK TENSIONER	24
0511054500	TRANSMISSION EXCHANGE RIGHT	25
0511054461	STRETCHER TOP TRANSMISSION SWIRLED	26
0521055325	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	27
0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	28
0521059910	CENTRAL STRETCHER	29
0501056573	17Z GEAR ASSY	30
0521054260	SIDE GEAR BOX ASSY	31
0501052778	CHAIN TENSIONER ASSY	32
0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	33
0511059854	STRETCHER OFFSET HIGHER FRONT	34
0521054313	CLOSED BEARING	35
0511053050	CHAIN TENSIONER	36
0501047300	DRIVE SHAFT	37
0521054289	CHAIN DEVIATION	38
0511053045	TENSIONER REAR OFFSET HIGHER	39
0511054476	RIGHT TENSIONER CENTRAL EXCHANGE	40
0521055368	SUPPORT SIDE BAEM	41
0521050525	FIXER FERTILIZER CONDUCTOR	42
0521055365	SEED CONDUCTOR	43
0521055370	SEED CONDUCTOR	44
0521055385	PRESS SUPPORT UPPER RIGHT	45
0521055361	SIDE SILO SUPPORT	46
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	47
0521054282	BEARING	48
0501056444	BEARING WITH ROLLING	49
0501053788	Q3/4" FASTENER AXLE ASSY	50
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	51
0521051407	FIXER SILO FERTILIZER	52
0521054262	RIGHT FERTILIZER CONDUCTOR	53
0521056474	RIGHT FERTILIZER CONDUCTOR WITH ASSY FIXATION	54
0521054290	ASSY SIDE SUPPORT	55



MARCHESAN

INDEX


0521053054	ASSY SIDE HANDLE	56
0521055381	PLATFORM SIDE	57
0521054279	PLATLFORM FIXER	58
0521054272	LADDER ASSY	59
0521055382	SIDE CHUTE ASSEMBLY	60
0521058637	SIDE DUCT ASSEMBLY	61
0511059943	SUPPORT FASTENER ASSY	62
0511059928	SIDE DUTY SUPPORT	63
0521055384	ADHESIVE LABELS SET	64
0521058534	FRONT LINE SEED LONG TCE/CM	65
0521058533	FRONT SEED SHORT LINE TCE/CM	66
0521058536	INTERNAL FRONT LONG SEED LINE	67
0521058535	INTERNAL FRONT SHORT SEED LINE	68
0521059045	BEARING WITH CURRENT ENCAPSULATED	69
0521050096	SEED DEPOSIT SYSTEM (CSU)	70
0521050118	DEPOSIT SEED BOCAL	71
0511052058	SEED SYSTEM TITANIUM	72
0521055349	ASSY DPL20 CUTTING DISC	73
0521055348	LOWER SUPPORT WITH DPL 20 WITHOUT LUBRICATION	74
0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	75
0521053697	CUTTING DISK BOX	76
0521055053	DEEP WHEEL / COMPACTOR SYSTEM	77
0521055065	ASSY DEPTH / COMPACTOR	78
0501056769	DEPTH WHEELS REGULATOR ASSY	79
0521055033	COMPACTADOR BODY	80
0521055054	LEFT ARM WITH SLEEVE	81
0521055066	RIGHT ARM WITH GLOVE	82
0521055068	RAYED WHEEL CENTER CLOSED	83
0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	84
0521054990	LEFT COMPACTOR WHEEL	85
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	86
0521055017	RIGHT COMPACTOR WHEEL	87
0503062066	DISC SET WITH CORN RING	88
0503062067	DISC SET / RING SOY 90F TITANIUM	89
0511052024	FAST CLOSING SET	90
0521055388	CENTER FRAME	91
0521050019	TIGHTENING PLATE WITH FIXING INTERNAL	92
0511059814	TELESCOPIC LOCK ASSY	93
0521052189	38,10X63,50X386X148 HYDRAULIC CYLINDER	94
0521058648	CENTRAL SHAFT AXLE	95
0521055329	CENTRAL WHEEL WITH TRANSMISSION	96
0511054492	STUB SHAFT HUB	97
0511054499	TRANSMISSION OF LARGER CENTRAL EXCHANGE	98
0521055328	CENTRAL WHEEL WITHOUT TRANSMISSION	99
0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE	100
0521054286	GEAR BOX CENTRAL ASSY	101
0501056443	BEARING ASSY GEAR BOX	102
0511054489	LEFT TENSIONER CENTRAL EXCHANGE	103
0511052432	DOUBLE BEARING WITH ASSY FLANGE	104
0511056179	CLUTCH WITH CARDAN CENTRAL	105
0501052776	CHAIN TENSIONER RIGHT ASSY GREATEST	106
0521054280	DEVIATION GREATER ASSY	107
0521054288	DEVIATION ASSY	108
0521054717	CURRENT GUIDE	109
0521055366	RIGHT SEED BOX ASSY	110




MARCHESAN

INDEX


0521055367	ASSY LEFT CENTRAL SEED BOX	111
0521054263	LEFT FERTILIZER CONDUCTOR ASSY	112
0521054339	CENTRAL PLATFORM ASSY	113
0521055357	CENTRAL HANDRAIL	114
0511059383	INTERNAL FIXER ASSY HANDLE	115
0521052149	ARTICULATION ARM LEFT ASSY	116
0521052147	ARTICULATION ARM RIGHT ASSY	117
0521052353	ASSEMBLY CYLINDER ARTICULATED ARM	118
0511058241	HYDRAULIC CYLINDER	119
0521058649	SET HIDRAULICO	120
0521058650	CENTRAL DUCT ASSEMBLY	121
0521053537	CENTRAL REAR DUCT SUPPORT	122
0521057013	TRIPLE DIVISER VALVE BRP00079 WITH NIPLES	123
0531050058	SUPPORT ASSY BLOCK/VALVES	124
0531050098	HOSE ASSY ARTICULATION FERTILIZER/SEED	125
0521055274	HEAD HOSE ASSY	126
0531050097	ASSY HOSE LIFTING FERTILIZER/SEED	127
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	128
0521055387	CENTRAL GUTTER ASSEMBLY	129
0511057011	SUPPORT GUTTER ASSY	130
0521055476	FIXER GUTTER	131
0521058651	ELECTRICAL ASSY 15MT / 3F MECHANICAL LED	132
0521054283	HEADLIGHT WITH SUPPORT	133
0521059393	LED FLASHLIGHT WITH FIXATION SUPPORT	134
0521055395	PLANTING MONITORING SET	135
0521055394	ADHESIVE LABEL ASSY	136
0521055426	ASSY ELECTRICAL BOX SUPPORT	137
0521052143	CLUTCH INDUCTIVE SENSOR ASSEMBLY	138
0521057203	ELECTRIC ASSEMBLY BCE (PACKED) MECHANICAL	139
0521055386	CENTRAL SUPPORT SILO 10 MOUTH	140
0521055324	SUPPORT CENTER	141
0521055323	CENTRAL LEFT SUPPORT	142
0511059491	AXLE HOLDER	143
0521055327	LEFT WHEEL WITH TRANSMISSION	144
0511054501	TRANSMISSION CAMBIO LEFT	145
0521055369	SUPPORT SIDE BAEM	146
0521055380	LEFT SIDE SUPPORT SILO FERTILIZER 8 MOUTH	147
0521055362	SUPPORT SILO SIDE FERTILIZER 08 MOUTH LEFT	148
0521056475	LEFT FERTILIZER CONDUCTOR WITH ASSY FIXATION	149



Item	Code	Description	See page	QT
01	0909095727	FRAME RIGHT SIDE ASSY	2	01
02	0909095728	ASSY CENTRAL FRAME	3	01
03	0909095729	LEFT SIDE FRAME ASSY	4	01
04	0521058670	TELESCOPIC ASSY 760/3225 INTERNAL TUBE	6	01
05	0521057792	PANTOGRAPHY HEADER	7	01
06	0521058633	FRENCH HAND 1725X1800X4737 ASSY LEFT	9	01
07	0521058632	FRENCH HAND	10	01
08	0521051438	HEADER 3 POINTS ASSY	13	01
09	0511052052	SUPPORT WITH FIXATION	14	01
10	0521069072	TRANSPORT LOCK		01
11	0521057773	SEMI-ASSEMBLED REST	15	01
12	0511053121	GREATER TOOL BOX ASSY	16	01
13	0521058345	SAFETY CHAIN WITH SHACKLE		01
13A	0503014120	CHAIN		01
13B	0503014321	CABLE STEEL SHACKLE		02
14	0521058344	WATER RESERVOIR WITH SOAP	17	01
15	0521057815	HYDRAULIC HOSE SUPPORT WITH FIXATION		01
16	0503018829	NYLON CLAMP		12




Item	Code	Description	See page	QT
01	0521069695	RH SIDE FRAME		01
02	0581012179	SLEEVE		02
03	0503010002	1800 GREASE FITTING		01
04	0521058636	ASSY SIDE HEX AXLE	18	01
05	0521055326	RIGHT WHEEL WITH TRANSMISSION	19	01
06	0521055325	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	27	01
07	0521059910	CENTRAL STRETCHER	29	01
08	0521054260	SIDE GEAR BOX ASSY	31	01
09	0501047300	DRIVE SHAFT	37	01
10	0521054289	CHAIN DEVIATION	38	01
11	0521055368	SUPPORT SIDE BAEM	41	01
12	0521055385	PRESS SUPPORT UPPER RIGHT	45	01
13	0521054262	RIGHT FERTILIZER CONDUCTOR	53	06
14	0521056474	RIGHT FERTILIZER CONDUCTOR WITH ASSY FIXATION	54	01
15	0503019222	BRACELET TYPE WIRE 3.2MM X 48 X 63 MM		14
16	0521054290	ASSY SIDE SUPPORT	55	02
17	0521053054	ASSY SIDE HANDLE	56	02
18	0521055381	PLATFORM SIDE	57	01
19	0521054272	LADDER ASSY	59	01
20	0521055382	SIDE CHUTE ASSEMBLY	60	01
21	0521058637	SIDE DUCT ASSEMBLY	61	01
22	0521055384	ADHESIVE LABELS SET	64	01
23	0909095730	SEED LINE/ASSY FERTILIZER	5	07




Item	Code	Description	See page	QT
01	0521055388	CENTER FRAME	91	01
02	0521058648	CENTRAL SHAFT AXLE	95	01
03	0521055329	CENTRAL WHEEL WITH TRANSMISSION	96	01
04	0521055328	CENTRAL WHEEL WITHOUT TRANSMISSION	99	03
05	0521059910	CENTRAL STRETCHER	29	01
06	0521054286	GEAR BOX CENTRAL ASSY	101	01
07	0521054280	DEVIATION GREATER ASSY	107	01
08	0521054288	DEVIATION ASSY	108	01
09	0521054717	CURRENT GUIDE	109	01
10	0503014917	40-1 X 2.87 CHAIN LINK + MENDING		01
11	0521055366	RIGHT SEED BOX ASSY	110	01
12	0521055367	ASSY LEFT CENTRAL SEED BOX	111	01
13	0521054262	RIGHT FERTILIZER CONDUCTOR	53	05
14	0521054263	LEFT FERTILIZER CONDUCTOR ASSY	112	05
15	0503019222	BRACELET TYPE WIRE 3.2MM X 48 X 63 MM		30
16	0521054339	CENTRAL PLATFORM ASSY	113	01
17	0521055357	CENTRAL HANDRAIL	114	02
18	0521052149	ARTICULATION ARM LEFT ASSY	116	01
19	0521052147	ARTICULATION ARM RIGHT ASSY	117	01
20	0521052353	ASSEMBLY CYLINDER ARTICULATED ARM	118	01
21	0521058649	SET HIDRAULICO	120	01
22	0521055387	CENTRAL GUTTER ASSEMBLY	129	01
23	0521058651	ELECTRICAL ASSY 15MT / 3F MECHANICAL LED	132	01
24	0581018202	SUPPORT AIR CONDUCTION		02
25	0521055395	PLANTING MONITORING SET	135	01
26	0521055394	ADHESIVE LABEL ASSY	136	01
27	1164920013	FLEX HOSE SPIRAL		29mts
28	1164920006	BLACK LIGHT SUCTION HOSE		22mts
29	0521055426	ASSY ELECTRICAL BOX SUPPORT	137	01
30	0521052143	CLUTCH INDUCTIVE SENSOR ASSEMBLY	138	01
31	0511059814	TELESCOPIC LOCK ASSY	93	01


Item	Code	Description	See page	QT
32	0521055637	ASSY TRANSPORT LOCK		04
32A	0551018312	TRANSPORT LOCK		01
32B	0501068994	0.3" X 3.1"LOCK PIN		01
32C	0503030168	HAIR PIN		01
33	0561016793	FIXED WRENCH		01
34	0501047885	ROD STOP		08
35	0561017063	HOLDER TUBE		02
36	0521053296	AXIS ARTICULATOR		01
37	0581019559	AXIS		01
38	0521057203	ELECTRIC ASSEMBLY BCE (PACKED) 139 MECHANICAL		01
39	0503011883	QUICK CONNECTION COVER		01
40	0503011628	FEMALE QUICK COUPLER		01
41	0521055386	CENTRAL SUPPORT SILO 10 MOUTH	140	01
42	0909095730	SEED LINE/ASSY FERTILIZER	5	10




Item	Code	Description	See page	QT
01	0521069696	LEFT SIDE CHASSIS		01
02	0581012179	SLEEVE		02
03	0503010002	1800 GREASE FITTING		01
04	0521058636	ASSY SIDE HEX AXLE	18	01
05	0521055327	LEFT WHEEL WITH TRANSMISSION	144	01
06	0521055325	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	27	01
07	0521059910	CENTRAL STRETCHER	29	01
08	0521054260	SIDE GEAR BOX ASSY	31	01
09	0501047300	DRIVE SHAFT	37	01
10	0521054289	CHAIN DEVIATION	38	01
11	0521055369	SUPPORT SIDE BAEM	146	01
12	0521055380	LEFT SIDE SUPPORT SILO FERTILIZER 8 MOUTH	147	01
13	0521054263	LEFT FERTILIZER CONDUCTOR ASSY	112	06
14	0521056475	LEFT FERTILIZER CONDUCTOR WITH ASSY FIXATION	149	01
15	0503019222	BRACELET TYPE WIRE 3.2MM X 48 X 63 MM		14
16	0521054290	ASSY SIDE SUPPORT	55	02
17	0521053054	ASSY SIDE HANDLE	56	02
18	0521055381	PLATFORM SIDE	57	01
19	0521054272	LADDER ASSY	59	01
20	0521055382	SIDE CHUTE ASSEMBLY	60	01
21	0521058637	SIDE DUCT ASSEMBLY	61	01
22	0521055384	ADHESIVE LABELS SET	64	01
23	0909095730	SEED LINE/ASSY FERTILIZER	5	07




Item	Code	Description	See page	QT
01	0521058534	FRONT LINE SEED LONG TCE/CM	65	01
02	0521058533	FRONT SEED SHORT LINE TCE/CM	66	01
03	0521058536	INTERNAL FRONT LONG SEED LINE	67	01
04	0521058535	INTERNAL FRONT SHORT SEED LINE	68	01
05	0521050096	SEED DEPOSIT SYSTEM (CSU)	70	01
06	0521055349	ASSY DPL20 CUTTING DISC	73	01
07	0521055053	DEEP WHEEL / COMPACTOR SYSTEM	77	01
08	0521058571	RIGHT REAR TITANIUM/TATU		01
09	0521058572	LEFT REAR TITANIUM/TATU		01
10	0591011691	TOP GLOVE CONDUCTOR FERTILIZER		01
11	0503031050	CURVED CONDUCTOR		01
12	0503062066	DISC SET WITH CORN RING	88	01
13	0503062067	DISC SET / RING SOY 90F TITANIUM	89	01
14	0531013600	PRESS ADJUSTMENT LEVER		01
15	0521068982	KEY CASH DISC CUTTING		01
16	0511052024	FAST CLOSING SET	90	01
17	0521050525	FIXER FERTILIZER CONDUCTOR	42	01
18	0503014234	BOLT 1/2 UNF X 1.3/4 CS G.5 ZN		01
19	0503012136	NUT 1/2 NF		01
20	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
21	0503010019	1/2" SPRING WASHER		01
22	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503015764	BOLT 7/8		01
02	0501010076	FLAT WASHER		01
03	0503010408	7/8" SPRING WASHER		01
04	0503010417	7/8" NUT		01
05	0501012140	FLAT WASHER		08
06	0503010233	5/8" X 2-1/2" BOLT		04
07	0503010027	5/8" SPRING WASHER		04
08	0503010013	5/8" NUT		04
09	0521051433	FRENCH HAND FRONT AXLE ASSY		02
09A	0511069442	FRENCH HAND FRONT AXLE		01
09B	0501017779	32 X 60 X 4.75 FLAT WASHER		01
09C	0503011052	1.1/4" X 0.77" CASTLE NUT		01
09D	0503010038	3/16 X 2 COTTERPIN		01
09E	0581014420	SLEVE GUIDE		02
10	0531061167	TELESCOPIC HEADER 760/3225		01
11	0531060746	AXIS 278 TELESCOPIC HEADER		03
12	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		01
13	0521069860	INTERNAL CANUDE HEADER TELESCOPE 4986		01
14	0503011052	1.1/4" X 0.77" CASTLE NUT		03
15	0503010038	3/16 X 2 COTTERPIN		03
16	0503010002	1800 GREASE FITTING		03
17	0531060747	TELESCOPIC HOSE GUIDE		01
18	0531060748	REST SUPPORT		01




Item	Code	Description	See page	QT
01	0531060744	UPPER ARM PANTOGRAPHIC HEADER		01
02	0531060743	LOWER ARM PANTOGRAPHIC HEADER		01
03	0531060745	PANTOGRAPHIC ARM EAR		02
04	0502040864	GEAR BOX WITH REGULATOR		01
05	0521068007	TRACTOR HITCH		01
06	1902040327	LOCK SLEEVE		01
07	0503010523	1/4" X 2" COTTERPIN		01
08	0503010002	1800 GREASE FITTING		04
09	0521063432	LOCK AXLE		02
10	0503031035	HAIR PIN		02
11	0531060746	AXIS 278 TELESCOPIC HEADER		02
12	0531060792	AXIS 200 TELESCOPIC HEADER		01
13	0531060776	HYDRAULIC HOSE SUPPORT FIXER		01
14	0503011052	1.1/4" X 0.77" CASTLE NUT		02
15	0503010038	3/16 X 2 COTTERPIN		03
16	0521010578	COUPLING SHAFT		01
17	0521057786	HYDRAULIC CYLINDER HEAD PANTOGRAPH	8	01
18	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		02




Item	Code	Description	See page	QT
01	0531060769	PANTOGRAPHIC HEAD CYLINDER CASE		01
02	0531060770	PANTOGRAPHIC HEAD CYLINDER ROD		01
03	0503010817	1.1/4" SELF LOCKING NUT		01
04	0503010345	2-218 N 3006-9B O'RING		01
05	0502010382	5" END CAP		01
06	0581010353	RING SUPPORT		01
07	0503018026	1870-2000-375 B GASKET		01
08	0503011453	O'RING		02
09	0503018152	O'RING		02
10	0503018024	RING BS		01
11	0503018025	RING GUIDE		01
12	0581010354	PISTON		01
13	0503018150	RING GUIDE		01
14	0503018151	RING BS		02
15	0503010039	D-2000 SCRAPER RING		01
16	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	11	01
03	0521058088	ROTULA WITH EXTENSOR AXIS 2	12	01
04	0531061168	FRENCH HAND 1725 X 1800 X 4737		01
05	0521069638	OIL TUBE		02
06	1902010477	UPPER CLAMP BODY		03
07	0502012907	FRENCH HAND DUCTS SUPPORT		06
08	0501010984	FLAT WASHER		03
09	0503010025	3/8" SPRING WASHER		03
10	0503010964	BOLT		06
11	0503010589	1/2" UNC SELF ADJUSTING NUT		06
12	0503011404	BOLT		03
13	0591010238	FRENCH HAND TRACK 20 X 38 X 1745		02
14	0521053050	ASSY RAIL GUIDE		01
14A	0571011891	GUIDE RAIL		01
14B	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
14C	0503010179	5/16" ZN SPRING WASHER		02
14D	0503010337	5/16" NUT		02
14E	0503011952	5/16" X 3/4" BOLT		02



Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	11	01
03	0521058088	ROTULA WITH EXTENSOR AXIS 2	12	01
04	0531061168	FRENCH HAND 1725 X 1800 X 4737		01
05	0521069640	OIL TUBE		02
06	0502010477	HOSE CLAMP		03
07	0502012907	FRENCH HAND DUCTS SUPPORT		06
08	0503010964	BOLT		06
09	0503010589	1/2" UNC SELF ADJUSTING NUT		06
10	0501010984	FLAT WASHER		03
11	0503010025	3/8" SPRING WASHER		03
12	0503011404	BOLT		03
13	0591010238	FRENCH HAND TRACK 20 X 38 X 1745		02
14	0521053050	ASSY RAIL GUIDE		01
14A	0571011891	GUIDE RAIL		01
14B	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
14C	0503010179	5/16" ZN SPRING WASHER		02
14D	0503010337	5/16" NUT		02
14E	0503011952	5/16" X 3/4" BOLT		02




Item	Code	Description	See page	QT
01	0521062244	PIVOT SHAFT		01
02	0551019529	FLAT WASHER		01
03	0503010027	5/8" SPRING WASHER		01
04	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0531061046	ROTULA WITH R2 LEFT NUT		01
02	0503010002	1800 GREASE FITTING		02
03	0501078990	TURNBUCLE AXLE		01
04	0561019879	LOCK ATTACHMENT BAR		01

HEADER 3 POINTS ASSY


0521051438




Item	Code	Description	See page	QT
01	0561013456	GUIDE DRAWBAR ASSY		02
02	0501010276	BOLT		04
03	0503010012	1" SPRING WASHER		04
04	0501010059	1.5/8 NUT		04
05	0503030119	LOCK PIN		02
06	0511069471	PLOUGH SUPPORT		02
07	0501011075	PIN		02
08	0503030285	HAIR PIN		02
09	0521068020	DRAWBAR ASSY		01
10	0503030085	LOCK PIN		04
11	0521068018	UPPER AXLE		01
12	0521068015	UPPER AXLE		01
13	0521068013	UPPER AXLE		01
14	0521068011	AXLE LOWER		02
15	0521068010	HITCH AXLE		01
16	0521068009	UPPER AXLE		01
17	0503031035	HAIR PIN		01




Item	Code	Description	See page	QT
01	0521063339	HIGHER		06
02	0571011070	5/8" UNC FASTENER		06
03	0503010027	5/8" SPRING WASHER		12
04	0503010013	5/8" NUT		12




Item	Code	Description	See page	QT
01	0531060668	REST SUPPORT		01
02	0503010571	1/4" X 1.1/2 COTTERPIN		02
03	0521010784	COUPLING SHAFT		01
04	0531060758	AXLE JUNCTION 25.4 X 150 WITH HANDLE		01
05	0503030085	LOCK PIN		02
06	0531060667	REST		01
07	0591013219	INTERNAL TUBE REST		01
08	0521010580	COUPLING SHAFT		01
09	0521012533	COUPLING SHAFT		01




Item	Code	Description	See page	QT
01	0521063662	BOX OF TOOLS		01
02	0551018356	BOX OF TOOLS COVER ASSY		01
03	0521010528	0.3" X 1.6" COUPLING SHAFT		02
04	0503010140	1/8" X 3/4" COTTERPIN		02
05	0503011907	PMC 594-S NYLON LUG		01
06	0503010358	5/16" X 5/8" BOLT		02
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0503014820	COROTE BLACK WATER		01
02	0503019262	SOAP DISH VACUUM		01




Item	Code	Description	See page	QT
01	0551019647	3/4 X 3280 HEX AXLE		01
02	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		04
02A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
02B	0503010256	3/8" X 3/4" BOLT		01
03	0521069326	20Z CONICAL GEAR		01




Item	Code	Description	See page	QT
01	0521064543	WHEEL SUPPORT		01
02	0561019929	FLAT WASHER		01
03	0503010523	1/4" X 2" COTTERPIN		03
04	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
05	0551014508	FLAT WASHER		01
06	0503010571	1/4" X 1.1/2 COTTERPIN		02
07	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
08	0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	20	01
09	0503010920	1/2" X 1.1/2" BOLT		04
10	0503010019	1/2" SPRING WASHER		04
11	0503010060	1/2" NUT		04
12	0502012731	WHEEL HOLDER		02
13	0581017245	AXLE BODY		01
14	0503011075	3/4" UNC NUT		04
15	0503012334	3/4" UNC X 3.1/2" BOLT		04
16	0503010002	1800 GREASE FITTING		04
17	0521064550	CARRYING-WHEELS FORK		01
18	0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	21	01
19	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
20	0511054491	WHEEL WITHOUT TIRE WITH 27Z GEAR	22	01
21	0531012874	FLAT WASHER		02
22	0511068422	WHEEL GEAR DOBLE		01
23	0551018571	FLAT WASHER		02
24	0511054463	WHEEL TENSIONER SUPORT CENTRAL	23	01
25	0511054464	WHEEL FORK TENSIONER	24	02
26	0561019941	RIGHT PROTECTIVE CAP WHEELS		01
27	0503010849	3/8" X 1-1/2" BOLT		02
28	0501013518	FLAT WASHER		02
29	0503010025	3/8" SPRING WASHER		02
30	0503010209	3/8" UNC BUTTERFLY NUT		02
31	0503016419	50-1 CHAIN X 128 LINK + REDUCION		01


Item	Code	Description	See page	QT
32	0501010630	1.1/2" CASTLE NUT		01
33	0501017779	32 X 60 X 4.75 FLAT WASHER		02
34	0503011052	1.1/4" X 0.77" CASTLE NUT		02
35	0503014857	50-1 X CHAIN X 122 LINK + REDUCION		01
36	0511054500	TRANSMISSION EXCHANGE RIGHT	25	01
37	0503033335	CURRENT 6 X 21 ELOS		01
38	0503010882	BOLT		01
39	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
40	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0521069562	5" X 17" CYLINDER CASE		01
02	0503010345	2-218 N 3006-9B O'RING		01
03	0503010817	1.1/4" SELF LOCKING NUT		01
04	0581010353	RING SUPPORT		01
05	0581010354	PISTON		01
06	0503018150	RING GUIDE		01
07	0503018151	RING BS		02
08	0503018026	1870-2000-375 B GASKET		01
09	0503011453	O'RING		02
10	0503018152	O'RING		02
11	0503018024	RING BS		01
12	0503018025	RING GUIDE		01
13	0581019464	TURNBUCLE BODY		01
14	0571015629	CILINDER SPINDLE FORK		01
15	0503011094	3/8" X 2" BOLT		01
16	0503010026	3/8" NUT		01
17	0503010025	3/8" SPRING WASHER		01
18	0503010039	D-2000 SCRAPER RING		01
19	0502040876	COVER		01
20	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
01	0503033713	TIRE 12 X 16,5/12L TR SK 900		01
02	0503015029	WHEEL		01
03	0503015355	INNER TIRE		01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503013633	BEARING 33287/33462		01
04	0503010009	RETAINER 00573-B		01
05	0503010086	SEAL 0009B-B		01
06	0551014473	GLOVE		01
07	0503012702	KM-12 NUT		02
08	0503012703	LOCK WASHER		01
09	0503010002	1800 GREASE FITTING		01
10	0503011444	SPRING WASHER		08
11	0503014048	22 X 1.5 HEX NUT		08
12	0503010363	5/16" X 1" BOLT		08
13	0521064563	27Z GEAR		01
14	0503014050	22 X 1.5 BOLT		08
15	0503013496	3982/3920 ROLLER BEARING		01
16	1882970002	GREASE SOAP		01




Item	Code	Description	See page	QT
01	0511054462	17Z GEAR		01
01A	0511061836	17Z GEAR		01
01B	0503011410	ROLLER BEARING		01
01C	0503011105	SEAL RING		01
02	0571015149	TIGHTENER AXLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0501010163	5/8" X 4-1/2" BOLT		01
05	0503010027	5/8" SPRING WASHER		01
06	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0511054462	17Z GEAR		01
01A	0511061836	17Z GEAR		01
01B	0503011410	ROLLER BEARING		01
01C	0503011105	SEAL RING		01
02	0571015150	SLEEVE TENSIONER WHEEL		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0503010027	5/8" SPRING WASHER		01
05	0503010013	5/8" NUT		01
06	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
07	0501012140	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521064556	SUPPORT ASSY TRANSMISSION WHEEL SIDE		01
02	0503010025	3/8" SPRING WASHER		13
03	0503010026	3/8" NUT		11
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03
06	0503010741	1/2" X 2-3/4" BOLT		03
07	0521064555	27Z GEAR		01
08	0503062231	CLUTCH		01
09	0571015139	FIXER PLATE		01
10	0571015138	CHOCK FRICÇÃO		01
11	0571015141	FIXER CENTRAL TRANSMISSION		04
12	0511054461	STRETCHER TOP TRANSMISSION SWIRLED	26	02
13	0503011268	3/8" X 2-1/2" BOLT		01
14	0571015142	FIXER		02
15	0571015143	RIGHT PROTECTION SUPPORT WHEEL		01
16	0503010209	3/8" UNC BUTTERFLY NUT		02
17	0503013542	M10 SPRING WASHER		04
18	0503010188	M10 X 1,5 X 30 BOLT		04




Item	Code	Description	See page	QT
01	0521055499	GEAR WITH NATIONAL BEARING		01
01A	0511061836	17Z GEAR		01
01B	0503019356	BEARING 6005 2RS1		01
01C	0503011105	SEAL RING		01
02	0571015146	TIGHTENER AXLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0501011541	5/8" X 3" BOLT		01
05	0501012140	FLAT WASHER		01
06	0503010027	5/8" SPRING WASHER		01
07	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0521064543	WHEEL SUPPORT		01
02	0561019929	FLAT WASHER		01
03	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
04	0551014508	FLAT WASHER		01
05	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
06	0503010920	1/2" X 1.1/2" BOLT		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0502012731	WHEEL HOLDER		02
10	0503010002	1800 GREASE FITTING		03
11	0521064550	CARRYING-WHEELS FORK		01
12	0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	21	01
13	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
14	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	28	01
15	0501010630	1.1/2" CASTLE NUT		01
16	0501017779	32 X 60 X 4.75 FLAT WASHER		02
17	0503011052	1.1/4" X 0.77" CASTLE NUT		02
18	0503010882	BOLT		01
19	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
20	0503010337	5/16" NUT		01
21	0503033335	CURRENT 6 X 21 ELOS		01
22	0581017245	AXLE BODY		01
23	0531012874	FLAT WASHER		02
24	0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	20	01
25	0503010523	1/4" X 2" COTTERPIN		03
26	0503010571	1/4" X 1.1/2 COTTERPIN		02
27	0503012334	3/4" UNC X 3.1/2" BOLT		04
28	0503011075	3/4" UNC NUT		04




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010059	33287/33462 ROLLER BEARING		01
05	0503010009	RETAINER 00573-B		01
06	0503010086	SEAL 0009B-B		01
07	0551014473	GLOVE		01
08	0503012702	KM-12 NUT		02
09	0503012703	LOCK WASHER		01
10	0503010002	1800 GREASE FITTING		01
11	0503011444	SPRING WASHER		04
12	0503011339	M22 X 1,5 X 72 BOLT		08
13	0503014048	22 X 1.5 HEX NUT		08
14	0503010363	5/16" X 1" BOLT		04
15	0511068415	PFFP-3770 SEAL GUIDE		01



Item	Code	Description	See page	QT
01	0501056573	17Z GEAR ASSY	30	01
02	0591016137	GLOVE 21 X 31.75 X 24.90		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503012882	BEARING		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0521069327	SUPPORT BEARING		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503030303	SUPPORT WASHER		08
04	0511064536	28Z GEAR		01
05	0503010292	0.2" X 1.6" SPRING PIN		10
06	0503010002	1800 GREASE FITTING		02
07	0503010395	1/2" X 1-1/4" BOLT		04
08	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
09	0503012389	1/2 BALL		04
10	0503010060	1/2" NUT		04
11	0503010179	5/16" ZN SPRING WASHER		03
12	0503010337	5/16" NUT		03
13	0501052778	CHAIN TENSIONER ASSY	32	01
14	0501048790	AXLE WITH LINK ASSY		02
15	0503012204	40-1 CHAIN X 82 LINK + RED		02
16	0511060396	DRIVE/DRIVEN AXLE CONE		04
17	0581018549	COVER BODY		01
18	0551015037	5/8" UNC X 210 X 198 FASTENER		03
19	0503012412	5/8 UNC SELF LOCKING NUT		06
20	0501012140	FLAT WASHER		06
21	0551018630	CARDAN SHAFT GUIDES SLEEVE		01
22	0503011268	3/8" X 2-1/2" BOLT		01
23	0503013357	3/8" SELF-ADJUSTING NUT		01
24	0503010386	CABLE		01
25	0503032986	ADHESIVE LABEL		01
26	0503034417	LETTER ADHESIVE LABEL		01
27	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	33	06
28	0581018628	DRIVEN AXLE		01
29	0581018547	DRIVEN AXLE		01
30	0501010984	FLAT WASHER		03
31	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		01


Item	Code	Description	See page	QT
32	0503010025	3/8" SPRING WASHER		01
33	0511059854	STRETCHER OFFSET HIGHER FRONT	34	02
34	0521018630	1.4" X SQUARE 0.8" WASHER		04
35	0501052776	CHAIN TENSIONER RIGHT ASSY GREATEST	106	01
36	0503010371	5/16" X 1" BOLT		02
37	0551018585	CENTRAL GEAR BOX COVER SLEEVE		02
38	0581018577	RIGHT GEAR BOX DRIVER AXLE		01
39	0521054313	CLOSED BEARING	35	03
40	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
41	0503019313	40-1 X CHAIN LINK + MENDING		01
42	0511053050	CHAIN TENSIONER	36	01
43	0581018570	CENTRAL GEAR BOX DRIVER AXLE		01
44	0503014917	40-1 X 2.87 CHAIN LINK + MENDING		01
45	0503019312	40-1 X 51 CHAIN LINK + MENDING		01
46	0511067501	26Z GEAR		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503010302	501019 SEAL RING		02
03	0503031805	11Z 1/2" GEAR		02
04	0503031367	SPRING		01
05	0511061794	CHAIN TENSIONER		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0501056573	17Z GEAR ASSY	30	01
02	0503010019	1/2" SPRING WASHER		01
03	0503010060	1/2" NUT		01
04	0511017302	FLAT WASHER		01
05	0551018562	21 X 31,75 X 26,5 SLEEVE		01
06	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED		01
01A	0502012310	GEAR BOX CLOSE BEARING		01
01B	0503013462	BEARING WITH BALL BEARING		01
01C	0503011105	SEAL RING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0571013442	TIGHTENER AXLE		01
02	0503010019	1/2" SPRING WASHER		01
03	0503010060	1/2" NUT		01
04	0503031805	11Z 1/2" GEAR		01
05	0503010004	1890 GREASE FITTING		01

DRIVE SHAFT


0501047300




Item	Code	Description	See page	QT
01	0501051721	UNIVERSAL JOINT		01
02	0501051717	UNIVERSAL JOINT		01
03	0503012087	PROTECTION FOR UNIV JOINT AND SLEEVE		01
04	0501051722	PROTECTION FOR UNIV JOINT AND AXLE		01
05	0501051719	UNIVERSAL JOINT		01
06	0503012088	PROTECTION FOR UNIV JOINT AND AXLE		01
07	0501051718	UNIVERSAL JOINT		01
08	0511012101	0.9" X 15.75" SQUARE SLEEVE		01
09	0503010839	03"X 0.6" SPRING PIN		01
10	0501051720	UNIVERSAL JOINT		01
11	0511012100	0.9" X 15.75" SQUARE SHAFT		01
12	0503010301	0.3" X 1.8" SPRING PIN		01
13	0502010558	4-20 TERMINAL WITH ROLES		01
14	0503010835	CARDAN CROSSPICE		01
15	0502011426	2-20 TERMINAL		01
16	0502011427	3-20 TERMINAL		01




Item	Code	Description	See page	QT
01	0511053045	TENSIONER REAR OFFSET HIGHER	39	01
02	0511054476	RIGHT TENSIONER CENTRAL EXCHANGE	40	01
03	0503033709	CATCH HEAD LINSEED SEEDS		01
04	0503010878	5/8" SELF ALIGNING NUT		02
05	0521069331	CHAIN DEVIATION		01




Item	Code	Description	See page	QT
01	0501056573	17Z GEAR ASSY	30	01
01A	0502012367	17Z X P 1/2" GEAR INTERM		01
01B	0503012882	BEARING		01
01C	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02	0521010454	0.83" X 1.25" X 0.79" SLEEVE		01
03	0503010905	1/2" X 2-1/4" BOLT		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501056573	17Z GEAR ASSY	30	01
01A	0502012367	17Z X P 1/2" GEAR INTERM		01
01B	0503012882	BEARING		01
01C	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02	0571015168	SLEEVE NYLON Ø21 X Ø31,75 X 20		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521069721	SUPPORT SIDE BAEM		01
02	0503062961	FERTILIZER BEAM ASSY		02
03	0521050525	FIXER FERTILIZER CONDUCTOR	42	07
04	0521051407	FIXER SILO FERTILIZER	52	12
05	0521055365	SEED CONDUCTOR	43	07
06	0521055370	SEED CONDUCTOR	44	01




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010365	NUT		02




Item	Code	Description	See page	QT
01	0521069705	CONDUCTOR FIXER		01
02	0503010358	5/16" X 5/8" BOLT		02
03	0503010337	5/16" NUT		02
04	0503010179	5/16" ZN SPRING WASHER		03
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
06	0503010499	5/16" UNC BUTTERFLY NUT		01
07	0503011953	5/16" X 1" BOLT		01
08	0503013759	NUT		04
09	0581019780	COVER		01
10	0502012899	DUCT BODY		01
11	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		04
12	0503034859	JOIN		01




Item	Code	Description	See page	QT
01	0503010179	5/16" ZN SPRING WASHER		01
02	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
03	0503010499	5/16" UNC BUTTERFLY NUT		01
04	0503011953	5/16" X 1" BOLT		01
05	0503012880	1/4" UNC SELF ADJUSTING NUT		04
06	0581019780	COVER		01
07	0502012899	DUCT BODY		01
08	0503034859	JOIN		01
09	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		04




Item	Code	Description	See page	QT
01	0503062362	SILO FERTILIZER 04 MOUTH		02
02	0521055361	SIDE SILO SUPPORT	46	01
03	0503034396	FERTILIZER SIDE COVER		07
04	0503010362	1/8" X 1.1/4" COTTERPIN		07
05	0521051407	FIXER SILO FERTILIZER	52	12




Item	Code	Description	See page	QT
01	0521069714	SUPPORT SIDE BAEM		01
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	47	05
03	0503030275	AGRICULTURAL BEARING		07
04	0501010942	3/8" X 1-1/4" BOLT		28
05	0503010026	3/8" NUT		32
06	0503010025	3/8" SPRING WASHER		32
07	0581019817	SQUARE SHAFT		01
08	0521054313	CLOSED BEARING	35	01
09	0503030303	SUPPORT WASHER		04
10	0521054282	BEARING	48	02
11	0501053788	Q3/4" FASTENER AXLE ASSY	50	03
12	0511061759	22Z P12,70 FQ 3/4" GEAR		01
13	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	51	02
14	0511062163	FERTILIZER BEAM LOWER COVER		01
15	0501010984	FLAT WASHER		04
16	0501011643	3/8 X 1"BOLT		04
17	0502012990	CONICA 14Z SQUARE GEAR		07




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	49	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511817303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0503012531	3/8" INOX NUT		01
02	0503012535	3/8" SPRING WASHER		01
03	0571019051	FIXER BOX WASHER		01
04	0503013751	3/8 UNC X 1.1/4 BOLT		01




Item	Code	Description	See page	QT
01	0521069328	RIGHT FERTILIZER CONDUCTOR		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0521069328	RIGHT FERTILIZER CONDUCTOR		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0581019990	TRACK FIXING BASE		01




Item	Code	Description	See page	QT
01	0521069333	DEPTH SUPPORT		01
02	0551015037	5/8" UNC X 210 X 198 FASTENER		02
03	0541012939	5/8 UNC X 141 X 120 FASTENER		02
04	0501012140	FLAT WASHER		08
05	0503013389	5/8" SELF LOCKING NUT		08
06	0503010920	1/2" X 1.1/2" BOLT		06
07	0503010060	1/2" NUT		06
08	0511017302	FLAT WASHER		12
09	0503010019	1/2" SPRING WASHER		06




Item	Code	Description	See page	QT
01	0521068962	HANDLE		01
02	0503013357	3/8" SELF-ADJUSTING NUT		02
03	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0581018252	PLATFORM		01
02	0521054279	PLATLFORM FIXER	58	02




Item	Code	Description	See page	QT
01	0581018560	PLATFORM SUPPORT		01
02	0503010395	1/2" X 1-1/4" BOLT		02
03	0503010589	1/2" UNC SELF ADJUSTING NUT		03
04	0511017302	FLAT WASHER		01
05	0501010063	1/2" X 1-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0521069329	ASSY SIDE LADDER		01
02	0502012742	FIXER SUPPORT LADDER		02
03	0503013357	3/8" SELF-ADJUSTING NUT		02
04	0501010984	FLAT WASHER		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0503010237	3/8" X 1" BOLT		04
07	0503010025	3/8" SPRING WASHER		04
08	0503010026	3/8" NUT		04
09	0503030403	1.85" X 2.87" BEATER		02




Item	Code	Description	See page	QT
01	0581017889	RAIL 30 X 55 X 1500		01
02	0581017952	GUTTER 30 X 55 X 1660		01
03	0521055102	BIGGEST FULL GUTTER SUPPORT		04




Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY	62	01
02	0511059928	SIDE DUTY SUPPORT	63	01
03	0581018407	BODY FASTENER 2 DUCTS		04
04	0521069713	OIL TUBE		02
05	0503011268	3/8" X 2-1/2" BOLT		02
06	0503010025	3/8" SPRING WASHER		02
07	0503010026	3/8" NUT		02



Item	Code	Description	See page	QT
01	0581011417	DUTO HOLDER SUPPORT		01
02	0503010237	3/8" X 1" BOLT		02
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0581013094	DUTO HOLDER SUPPORT		01
02	0571019756	FASTENER 1/2 UNC X 220 X 198 ZN		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02



01

0503034679



02

0503032986



03

0503033621

PLANTIO DIRETO

04

0503033424

2

05

0503033416

4

06

0503033418

LUBRIFICAR E REAPERTAR DIARIAMENTE
LUBRICATE AND TIGHTEN DAILY
LUBRICAR Y REAPRETAR DIARIAMENTE

07


0503031827




08

0503031565


Item	Code	Description	See page	QT
01	0503034679	ADHESIVE LABEL		01
02	0503032986	ADHESIVE LABEL		01
03	0503033621	ADHESIVE LABEL		01
04	0503033424	DIRECT PLANTIO ADHESIVE LABEL		01
05	0503033416	ADHESIVE LABEL		01
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		01
07	0503031827	LUBRICATE AND RETIGHTEN DAILY DECAL		01
08	0503031565	ADHESIVE LABEL CARE		01




Item	Code	Description	See page	QT
01	0531060948	SEED LINE FRAME		01
02	0571012310	ROW LOCK BODY		01
03	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
04	0503010232	5/8" X 1.3/4" BOLT		01
05	0503030168	HAIR PIN		04
06	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
07	0503033728	FIXED SPRING PIN		02
08	0571014704	UPPER AXLE		01
09	0502012768	LINE SUPPORT CLAMP		02
10	0581018676	SLEEVE ARM LINE SEED		08
11	0503010811	5/8" UNF SELF ADJUSTING NUT		04
12	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
13	0581019795	SEED ARM SUPPORT ROW		01
14	0581019796	LOWER ARM LARGER		01
15	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
16	0521068452	UP SUPPORT		01
17	0503010878	5/8" SELF ALIGNING NUT		04
18	0503019273	SLEEVE		06
19	0503010045	O-RING		08
20	0502012568	UPPER ROCKER ARM		01
21	0591014726	ENCAPSULATED CURRENT GUIDE		01
22	0503013357	3/8" SELF-ADJUSTING NUT		01
23	0503010237	3/8" X 1" BOLT		01
24	0503013389	5/8" SELF LOCKING NUT		01
25	0501012140	FLAT WASHER		01
26	0521059045	BEARING WITH CURRENT ENCAPSULATED	69	01
27	0503063190	ENCAPSULATED CURRENT MAHM LONG 1060		01
28	0503018829	NYLON CLAMP		01
29	0503010179	5/16" ZN SPRING WASHER		02
30	0503011295	M 8 X 1,25 X 25 BOLT		02




Item	Code	Description	See page	QT
01	0531060948	SEED LINE FRAME		01
02	0571012310	ROW LOCK BODY		01
03	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
04	0503010232	5/8" X 1.3/4" BOLT		01
05	0503030168	HAIR PIN		04
06	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
07	0503033728	FIXED SPRING PIN		02
08	0571014704	UPPER AXLE		01
09	0502012768	LINE SUPPORT CLAMP		02
10	0503010811	5/8" UNF SELF ADJUSTING NUT		04
11	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
12	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION		01
13	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION		01
14	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
15	0521068448	FRONT SUPPORT SHORT SEED LINE		01
16	0503010878	5/8" SELF ALIGNING NUT		04
17	0503019273	SLEEVE		08
18	0581018676	SLEEVE ARM LINE SEED		08
19	0503010045	O'RING		08
20	0502012568	UPPER ROCKER ARM		01
21	0503013389	5/8" SELF LOCKING NUT		01
22	0501012140	FLAT WASHER		01
23	0591014726	ENCAPSULATED CURRENT GUIDE		01
24	0503013357	3/8" SELF-ADJUSTING NUT		01
25	0503010237	3/8" X 1" BOLT		01
26	0521059045	BEARING WITH CURRENT ENCAPSULATED	69	01
27	0503063191	ENCAPSULATED CURRENT MAHM SHORT 895		01
28	0503018829	NYLON CLAMP		01
29	0503010179	5/16" ZN SPRING WASHER		02
30	0503011295	M 8 X 1,25 X 25 BOLT		02




Item	Code	Description	See page	QT
01	0531060948	SEED LINE FRAME		01
02	0571012310	ROW LOCK BODY		01
03	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
04	0503010232	5/8" X 1.3/4" BOLT		01
05	0503030168	HAIR PIN		04
06	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
07	0503033728	FIXED SPRING PIN		02
08	0571014704	UPPER AXLE		01
09	0502012768	LINE SUPPORT CLAMP		02
10	0581018676	SLEEVE ARM LINE SEED		08
11	0503010811	5/8" UNF SELF ADJUSTING NUT		04
12	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
13	0581019795	SEED ARM SUPPORT ROW		01
14	0581019796	LOWER ARM LARGER		01
15	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
16	0521068453	LONG FRONT SEED ROW		01
17	0503010878	5/8" SELF ALIGNING NUT		04
18	0503019273	SLEEVE		06
19	0503010045	O'RING		08
20	0502012568	UPPER ROCKER ARM		01
21	0503011295	M 8 X 1,25 X 25 BOLT		02
22	0503010179	5/16" ZN SPRING WASHER		02
23	0591014726	ENCAPSULATED CURRENT GUIDE		01
24	0503013357	3/8" SELF-ADJUSTING NUT		01
25	0503010237	3/8" X 1" BOLT		01
26	0503013389	5/8" SELF LOCKING NUT		01
27	0501012140	FLAT WASHER		01
28	0521059045	BEARING WITH CURRENT ENCAPSULATED	69	01
29	0503063190	ENCAPSULATED CURRENT MAHM LONG 1060		01
30	0503018829	NYLON CLAMP		01




Item	Code	Description	See page	QT
01	0531060948	SEED LINE FRAME		01
02	0571012310	ROW LOCK BODY		01
03	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
04	0503010232	5/8" X 1.3/4" BOLT		01
05	0503030168	HAIR PIN		04
06	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
07	0503033728	FIXED SPRING PIN		02
08	0571014704	UPPER AXLE		01
09	0502012768	LINE SUPPORT CLAMP		02
10	0581018676	SLEEVE ARM LINE SEED		08
11	0503010811	5/8" UNF SELF ADJUSTING NUT		04
12	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
13	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION		01
14	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION		01
15	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
16	0521068449	SHORT SEED ROW FRONT		01
17	0503010878	5/8" SELF ALIGNING NUT		04
18	0503019273	SLEEVE		06
19	0503010045	O'RING		08
20	0502012568	UPPER ROCKER ARM		01
21	0503011295	M 8 X 1,25 X 25 BOLT		02
22	0503010179	5/16" ZN SPRING WASHER		02
23	0591014726	ENCAPSULATED CURRENT GUIDE		01
24	0503013357	3/8" SELF-ADJUSTING NUT		01
25	0503010237	3/8" X 1" BOLT		01
26	0503013389	5/8" SELF LOCKING NUT		01
27	0501012140	FLAT WASHER		01
28	0521059045	BEARING WITH CURRENT ENCAPSULATED	69	01
29	0503063191	ENCAPSULATED CURRENT MAHM SHORT 895		01
30	0503018829	NYLON CLAMP		01




Item	Code	Description	See page	QT
01	0531061301	ENCAPSULATED CURRENT BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0511017303	FLAT WASHER		04
04	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02
06	0503013759	NUT		02
07	0503019373	6006 2RS1 NATIONAL BEARING		01
08	0503012858	502075 CLAMPING RING (FOR HOLE)		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01
10	0581019823	BEARING AXLE BODY WITHOUT LUBRICATION		01




Item	Code	Description	See page	QT
01	0521050118	DEPOSIT SEED BOCAL	71	01
02	0581014295	FIXING GLOVE		01
03	0511052058	SEED SYSTEM TITANIUM	72	01
04	0503010358	5/16" X 5/8" BOLT		05
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		05
06	0503010179	5/16" ZN SPRING WASHER		05
07	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0503062397	DEPOSIT SEED ASSY		01




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01



Item	Code	Description	See page	QT
01	0502012470	UPPER SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
03	0521055348	LOWER SUPPORT WITH DPL 20 WITHOUT 74 LUBRICATION		01
04	0503012798	5/8" X 2" BOLT		04
05	0503010878	5/8" SELF ALIGNING NUT		04




Item	Code	Description	See page	QT
01	0503019277	SLEEVE LUBRICATION SYSTEM		03
02	0503019278	LUBRICANT GLOVE		02
03	0581018679	SLEEVE		01
04	0581018677	SUPPORT DISC AXLE		01
05	0503010361	SPRING PIN		01
06	0551015883	SPRING GUIDES SLEVE		02
07	0503031575	2.5"X 12" X 0.5" COMPRESSION SPRING		02
08	0521068189	SPRING REGULACION		02
09	0501012140	FLAT WASHER		02
10	0503010152	3/4" SELF LOCKING NUT		01
11	0503010806	5/8" X 3" BOLT		02
12	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT		01
13	0503011075	3/4" UNC NUT		02
14	0503010878	5/8" SELF ALIGNING NUT		02
15	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	75	01
16	0521069351	RIGHT ARM		01
17	0521069350	LEFT ARM		01
18	0503010410	RING		02
19	0502012898	BOTTOM BRACKET		01
20	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
21	0503010179	5/16" ZN SPRING WASHER		02
22	0571012370	PROTECTION FRONT		01
23	0581018678	FLANGE WASHER		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	CUTTING DISK BOX	76	01

CUTTING DISK BOX


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	CUTTING DISK BOX		01
09	0502040873	CUTTING DISC AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	78	01
02	0521055068	RAYED WHEEL CENTER CLOSED	83	02
03	0521054990	LEFT COMPACTOR WHEEL	85	01
04	0521055017	RIGHT COMPACTOR WHEEL	87	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY	79	01
06	0503010581	RING		01
07	0521055033	COMPACTADOR BODY	80	01
08	0521055054	LEFT ARM WITH SLEEVE	81	01
09	0521055066	RIGHT ARM WITH GLOVE	82	01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED GLOVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0503010257	1/8" X 1" COTTERPIN		01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0502011689	1/8" DEPTH CONTROL LEVER		01
04	0502011688	SEED SIST CONTROL DEPTH LEVER		01
05	0511065582	DEPTH WHEEL STOP		01
06	0503030975	0.9" X 1.5" X 0.1" SPRING		01
07	0511015976	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT GLOVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0581019523	LEFT ARM WHEEL DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019524	RIGHT ARM DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	84	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	5/16" ZN SPRING WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0581019522	CASE WHEEL DEPTH WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0503010143	1/4" SPRING WASHER		03
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019529	DEPTH REGULATOR SHAFT		01
11	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	86	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	86	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0503016204	CORN DISK 12 ORANGE		01
02	0503016398	TITANIUM RING CORN / SOY (YELLOW FLAT)		01
03	0503016399	TITANIUM RING CORN (GREEN)		01
04	0503016400	TITANIUM RING CORN (GREY)		01
05	0503016401	TITANIUM RING CORN (BLUE)		01




Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016218	DISC OF SOYBEAN		01
03	0503016403	TITANIUM RING FOR SOYBEAN (LILAC)		01
04	0503016404	TITANIUM RING FOR SOYBEAN (PURPLE)		01
05	0503016406	TITANIUM RING FOR SOYBEAN (ORANGE)		01
06	0503016407	TITANIUM RING FOR SOYBEAN		01




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0521069694	CENTRAL FRAME		01
02	0521050019	TIGHTENING PLATE WITH FIXING INTERNAL	92	02
03	0511059814	TELESCOPIC LOCK ASSY	93	01
04	0503010131	3/16" X 1-1/2" COTTERPIN		01
05	0521011132	FLAT WASHER		01
06	0521052189	38,10X63,50X386X148 HYDRAULIC CYLINDER	94	01
07	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0571015217	TUBE ADJUSTMENT PLATE		01
02	0503010027	5/8" SPRING WASHER		08
03	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		08




Item	Code	Description	See page	QT
01	0571015072	LOCK AXLE		01
02	0503010765	3/8" X 3" BOLT		01
03	0521064540	TELESCOPIC LOCK		01
04	0503013357	3/8" SELF-ADJUSTING NUT		01
05	0521011132	FLAT WASHER		01
06	0503010131	3/16" X 1-1/2" COTTERPIN		01
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
08	0511054270	TENSIONER SPRING		01
08A	0511069520	TELESC LOCK SPRING TENSIONER		01
08B	0503010013	5/8" NUT		02



Item	Code	Description	See page	QT
01	0521068383	CYLINDER CASE		01
02	0581010670	CORPO HASTE 38,10 X 345		01
03	0511070058	GUIDE HIDRAULIC		01
04	0503010163	D-1500 SCRAPER RING		01
05	0502010471	MOBILE COVER		01
06	0581010668	RING SUPPORT		01
07	0503018004	RING		01
08	0503018003	GASKET		01
09	0503018163	BACK-UP RING		02
10	0503018162	O'RING		02
11	0503030385	CYLINDER PLUG N-002		02
12	0502012837	PISTON		01
13	0503018005	RING		01
14	0503011109	2-119 N 3006-9B O'RING		01
15	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01



Item	Code	Description	See page	QT
01	0561016762	3/4 X 2390 HEX AXLE		02
02	0561015837	SLEEVE 31,75		01
03	0503010523	1/4" X 2" COTTERPIN		01
04	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		06
04A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
04B	0503010256	3/8" X 3/4" BOLT		01
05	0521069326	20Z CONICAL GEAR		01




Item	Code	Description	See page	QT
01	0521064554	LEFT WHEEL FORK		01
02	0521064543	WHEEL SUPPORT		01
03	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
04	0561019929	FLAT WASHER		01
05	0503010523	1/4" X 2" COTTERPIN		02
06	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
07	0551014508	FLAT WASHER		01
08	0503010010	1/4" X 2.1/2" COTTERPIN		01
09	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
10	0503010920	1/2" X 1.1/2" BOLT		04
11	0503010019	1/2" SPRING WASHER		04
12	0503010060	1/2" NUT		04
13	0502012731	WHEEL HOLDER		02
14	0503010571	1/4" X 1.1/2 COTTERPIN		02
15	0503011075	3/4" UNC NUT		04
16	0503012334	3/4" UNC X 3.1/2" BOLT		04
17	0511054492	STUB SHAFT HUB	97	01
18	0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE	100	01
19	0503011052	1.1/4" X 0.77" CASTLE NUT		02
20	0501017779	32 X 60 X 4.75 FLAT WASHER		02
21	0501010630	1.1/2" CASTLE NUT		01
22	0503010003	1845 GREASE FITTING		03
23	0503010882	BOLT		01
24	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
25	0503033458	CURRENT 6 X 17 ELOS		01
26	0503010337	5/16" NUT		01
27	0511068422	WHEEL GEAR DOBLE		01
28	0551018571	FLAT WASHER		02
29	0503010002	1800 GREASE FITTING		01
30	0571015153	COVER PROTECTION WHEELED LARGER		01
31	0503010849	3/8" X 1-1/2" BOLT		02


Item	Code	Description	See page	QT
32	0503010209	3/8" UNC BUTTERFLY NUT		02
33	0503010025	3/8" SPRING WASHER		02
34	0501010984	FLAT WASHER		02
35	0511054463	WHEEL TENSIONER SUPORT CENTRAL	23	01
36	0511054464	WHEEL FORK TENSIONER	24	02
37	0511054499	TRANSMISSION OF LARGER CENTRAL EXCHANGE	98	01
38	0503016419	50-1 CHAIN X 128 LINK + REDUCION		01
39	0503014507	CHAIN LINK + MENDING		01
40	0581017245	AXLE BODY		01
41	0531012874	FLAT WASHER		02
42	0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	20	01

STUB SHAFT HUB


0511054492




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010059	33287/33462 ROLLER BEARING		01
05	0503010009	RETAINER 00573-B		01
06	0503010086	SEAL 0009B-B		01
07	0551014473	GLOVE		01
08	0503012702	KM-12 NUT		02
09	0503012703	LOCK WASHER		01
10	0503010002	1800 GREASE FITTING		01
11	0503011444	SPRING WASHER		08
12	0503011339	M22 X 1,5 X 72 BOLT		08
13	0503014048	22 X 1.5 HEX NUT		08
14	0503010363	5/16" X 1" BOLT		08
15	0521064564	30Z GEAR		01



Item	Code	Description	See page	QT
01	0521064557	SUPPORT SET TRANSMISSION WHEEL SIDE		01
02	0571015141	FIXER CENTRAL TRANSMISSION		04
03	0571015151	SUPPORT BEARING		01
04	0521061795	27Z GEAR		01
05	0501053654	DOUBLE BEARING TRANSMISSION SEED 3/4		01
06	0503010025	3/8" SPRING WASHER		08
07	0503010026	3/8" NUT		08
08	0503010019	1/2" SPRING WASHER		03
09	0503010060	1/2" NUT		03
10	0503010337	5/16" NUT		02
11	0503011953	5/16" X 1" BOLT		02
12	0503010179	5/16" ZN SPRING WASHER		02
13	0503010707	501030 CLAMPING RING (FOR AXLE)		02
14	0503010741	1/2" X 2-3/4" BOLT		03
15	0511054461	STRETCHER TOP TRANSMISSION SWIRLED	26	02




Item	Code	Description	See page	QT
01	0521064554	LEFT WHEEL FORK		01
02	0521064543	WHEEL SUPPORT		01
03	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
04	0561019929	FLAT WASHER		01
05	0551014511	CARRYING WHEELS AXLE SLEEVE GUIDES		02
06	0551014508	FLAT WASHER		01
07	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
08	0503010920	1/2" X 1.1/2" BOLT		04
09	0503010019	1/2" SPRING WASHER		04
10	0503010060	1/2" NUT		04
11	0502012731	WHEEL HOLDER		02
12	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	28	01
13	0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE	100	01
14	0503011052	1.1/4" X 0.77" CASTLE NUT		02
15	0501017779	32 X 60 X 4.75 FLAT WASHER		02
16	0501010630	1.1/2" CASTLE NUT		01
17	0503010003	1845 GREASE FITTING		03
18	0503010882	BOLT		01
19	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
20	0503033458	CURRENT 6 X 17 ELOS		01
21	0503010337	5/16" NUT		01
22	0581017245	AXLE BODY		01
23	0531012874	FLAT WASHER		02
24	0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	20	01
25	0503010571	1/4" X 1.1/2 COTTERPIN		02
26	0503010523	1/4" X 2" COTTERPIN		03
27	0503012334	3/4" UNC X 3.1/2" BOLT		04
28	0503011075	3/4" UNC NUT		04



Item	Code	Description	See page	QT
01	0511065331	11.75 X 17.5 HOOP WHEEL		01
02	0503015355	INNER TIRE		01
03	0503013247	PLY TIRE		01


GEAR BOX CENTRAL ASSY

0521054286




Item	Code	Description	See page	QT
01	0511060396	DRIVE/DRIVEN AXLE CONE		04
02	0511064536	28Z GEAR		01
03	0511067501	26Z GEAR		01
04	0521018630	1.4" X SQUARE 0.8" WASHER		06
05	0511065209	20Z GEAR		03
06	0501056443	BEARING ASSY GEAR BOX	102	01
07	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	33	01
08	0551011728	3770 PULLER AXLE SEED ROW		01
09	0551018585	CENTRAL GEAR BOX COVER SLEEVE		02
10	0511069512	20Z GEAR		01
11	0503030303	SUPPORT WASHER		07
12	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
13	0502011758	REAR TENSIONER LEVER		02
14	0521018259	DRIVEN AXLE		01
15	0511054476	RIGHT TENSIONER CENTRAL EXCHANGE	40	01
16	0511054489	LEFT TENSIONER CENTRAL EXCHANGE	103	01
17	0511052432	DOUBLE BEARING WITH ASSY FLANGE	104	01
18	0501048790	AXLE WITH LINK ASSY		02
19	0503012204	40-1 CHAIN X 82 LINK + RED		02
20	0503014852	40-1 CHAIN X 90 LINK + REDUCTION		01
21	0501052778	CHAIN TENSIONER ASSY	32	01
22	0511056179	CLUTCH WITH CARDAN CENTRAL	105	01
23	0501052776	CHAIN TENSIONER RIGHT ASSY GREATEST	106	01
24	0521054313	CLOSED BEARING	35	04
25	0581018572	DRIVER AXLE		01
26	0581018583	AXLE CM		01
27	0521069330	GEAR BOX CENTRAL ASSY		01
28	0581018564	CENTRAL GEAR BOX COVER		01
29	0503013352	86 CHAIN X 40-1 LINK + REDUCTION		01
30	0503012698	2050 CHAIN X 53 LINK + MENDING		01
31	0503011321	40-1 CHAIN X 94 LINK + REDUCTION		01


Item	Code	Description	See page	QT
32	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
33	0501010984	FLAT WASHER		04
34	0503010002	1800 GREASE FITTING		02
35	0503010019	1/2" SPRING WASHER		04
36	0503010025	3/8" SPRING WASHER		02
37	0503010060	1/2" NUT		08
38	0503010179	5/16" ZN SPRING WASHER		05
39	0503010292	0.2" X 1.6" SPRING PIN		07
40	0503010337	5/16" NUT		05
41	0503010365	NUT		02
42	0503010371	5/16" X 1" BOLT		02
43	0503010386	CABLE		01
44	0503010395	1/2" X 1-1/4" BOLT		04
45	0503010683	0,2" X 1,2" SPRING PIN		02
46	0503011082	C1/2" X 1.3/4" SCREW		04
47	0503011268	3/8" X 2-1/2" BOLT		01
48	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		02
49	0503012389	1/2 BALL		04
50	0503013357	3/8" SELF-ADJUSTING NUT		01
51	0511017302	FLAT WASHER		08




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	49	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056573	17Z GEAR ASSY	30	01
01A	0502012367	17Z X P 1/2" GEAR INTERM		01
01B	0503012882	BEARING		01
01C	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02	0503010019	1/2" SPRING WASHER		01
03	0503010060	1/2" NUT		01
04	0571015167	SLEEVE NYLON Ø21 X Ø31,75 X 36,50		01
05	0503010479	BOLT		01
06	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521063461	BEARING DOUBLE WITH FLANGE		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011105	SEAL RING		02




Item	Code	Description	See page	QT
01	0503062231	CLUTCH		01
02	0503062272	CARDAN WITHOUT PROTECTION		01
03	0503013357	3/8" SELF-ADJUSTING NUT		02
04	0503011268	3/8" X 2-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0511061794	CHAIN TENSIONER		01
02	0503031367	SPRING		01
03	0503031805	11Z 1/2" GEAR		02
04	0503010302	501019 SEAL RING		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521069325	DEVIATION GREATER CENTRAL CHAIN		01
02	0581018569	DRIVEN AXLE		01
03	0503030303	SUPPORT WASHER		04
04	0511065209	20Z GEAR		03
05	0503010292	0.2" X 1.6" SPRING PIN		03
06	0551015037	5/8" UNC X 210 X 198 FASTENER		02
07	0501012140	FLAT WASHER		01
08	0521054313	CLOSED BEARING	35	01
09	0511054476	RIGHT TENSIONER CENTRAL EXCHANGE	40	01
10	0521018630	1.4" X SQUARE 0.8" WASHER		03
11	0503010878	5/8" SELF ALIGNING NUT		04
12	0501056443	BEARING ASSY GEAR BOX	102	01
13	0501010984	FLAT WASHER		01
14	0503010025	3/8" SPRING WASHER		01
15	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		01




Item	Code	Description	See page	QT
01	0521069324	DEVIATION CHAIN LOWER REAR		01
02	0511053045	TENSIONER REAR OFFSET HIGHER	39	01
03	0511054476	RIGHT TENSIONER CENTRAL EXCHANGE	40	01
04	0511053050	CHAIN TENSIONER	36	01
05	0503033709	CATCH HEAD LINSEED SEEDS		01
06	0503010878	5/8" SELF ALIGNING NUT		02




Item	Code	Description	See page	QT
01	0521069460	CURRENT GUIDE		01
02	0511053050	CHAIN TENSIONER	36	01
02A	0571013442	TIGHTENER AXLE		01
02B	0503010019	1/2" SPRING WASHER		01
02C	0503010060	1/2" NUT		01
02D	0503031805	11Z 1/2" GEAR		01
02E	0503010004	1890 GREASE FITTING		01
03	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0521069723	RH SEED SILO CENTRAL SUPPORT		01
02	0503062962	SILO SEED 05 ASSY MOUTH		01
03	0521051407	FIXER SILO FERTILIZER	52	08
04	0511017302	FLAT WASHER		06
05	0503010920	1/2" X 1.1/2" BOLT		06
06	0521050525	FIXER FERTILIZER CONDUCTOR	42	05
07	0521055365	SEED CONDUCTOR	43	05
08	0503010589	1/2" UNC SELF ADJUSTING NUT		06




Item	Code	Description	See page	QT
01	0521069724	SUPPORT CENTER		01
02	0503062962	SILO SEED 05 ASSY MOUTH		01
03	0521055365	SEED CONDUCTOR	43	05
04	0511017302	FLAT WASHER		06
05	0503010920	1/2" X 1.1/2" BOLT		06
06	0521051407	FIXER SILO FERTILIZER	52	08
07	0521050525	FIXER FERTILIZER CONDUCTOR	42	05
08	0503010589	1/2" UNC SELF ADJUSTING NUT		06




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
02	0503010019	1/2" SPRING WASHER		02
03	0503010060	1/2" NUT		02
04	0521069319	LEFT FERTILIZER CONDUCTOR		01




Item	Code	Description	See page	QT
01	0581017801	PLATFORM ASSY		02
02	0521054279	PLATLFORM FIXER	58	04




Item	Code	Description	See page	QT
01	0521069356	HANDRAIL BODY		02
02	0511059383	INTERNAL FIXER ASSY HANDLE	115	04
03	0581019811	TUBE		02
04	0581012718	HANDRAIL		02
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0503010237	3/8" X 1" BOLT		04




Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01




Item	Code	Description	See page	QT
01	0521068342	ARM PIVOT		01
02	0571017893	HORIZONTAL ARTICULATION SHAFT		01
03	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
04	0571011767	LISA WASHER 125 X 88 X 4.76		01
05	0503010002	1800 GREASE FITTING		01
06	0503010408	7/8" SPRING WASHER		01
07	0503015322	BOLT 7/8		01
08	0503032042	SHEET POLYETHYLENE		01
09	0503010814	5/16 BOLT		14
10	0503010023	3/4" SPRING WASHER		01
11	0503010014	3/4" NUT		01
12	0503011198	C3/4" X 6" SCREW		01
13	0571011825	BUSHING		02
14	0503010004	1890 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521063778	RELATION AVEC AXE VERTICAL LATCH	01	
02	0571011767	LISA WASHER 125 X 88 X 4.76	01	
03	0503010408	7/8" SPRING WASHER	01	
04	0503015322	BOLT 7/8	01	
05	0571017893	HORIZONTAL ARTICULATION SHAFT	01	
06	0503011198	C3/4" X 6" SCREW	01	
07	0503010023	3/4" SPRING WASHER	01	
08	0503010014	3/4" NUT	01	
09	0503032042	SHEET POLYETHYLENE	01	
10	0503010814	5/16 BOLT	14	
11	0503010002	1800 GREASE FITTING	01	
12	0521068343	ARM PIVOT	01	
13	0571011825	BUSHING	02	
14	0503010004	1890 GREASE FITTING	01	




Item	Code	Description	See page	QT
01	0511058241	HYDRAULIC CYLINDER	119	02
02	0521017351	1-1/4" X 8" BOLT		02
03	0503013321	SCREW 1.1/4 UNF X 7 C S G.8 ZN		02
04	0503010817	1.1/4" SELF LOCKING NUT		04
05	0501010617	3/4" NIPPLE		04
06	0503010190	2-114 N 3006-9B O'RING		04




Item	Code	Description	See page	QT
01	0521066625	SHIRT 114.30 X 851		01
02	0521066559	EXTENSOR 876 X 50.80 (2)		01
03	0503010002	1800 GREASE FITTING		03
04	0503030384	CON PLUG N-001		02
05	0581010658	EMBOLO 50,80 X 114,30 USAP		01
06	0503018164	GAXETA 2500-4000-375 B (1150 AGEL)		02
07	0503018165	GUIDE RING W2-4500-590		01
08	0503010290	SELF ADJUSTING 1.1/2" UNF NUT		01
09	0503010141	2-226 N 3006-9B O'RING		01
10	0502011222	0.56" END CAP		01
11	0503010952	W2-2250-500 RING		01
12	0581010659	2" X 4" RING SUPPORT		01
13	0503010039	D-2000 SCRAPER RING		01
14	0503018026	1870-2000-375 B GASKET		01
15	0503018024	RING BS		01
16	0503011892	O' RING, 2-346 N 3006-9B		02
17	0503011893	BACK-UP RING, 8-346		02




Item	Code	Description	See page	QT
01	0521058650	CENTRAL DUCT ASSEMBLY	121	01
02	0503063242	COMMAND BLOCK		01
03	0521057013	TRIPLE DIVISER VALVE BRP00079 WITH NIPLES	123	01
04	0531050058	SUPPORT ASSY BLOCK/VALVES	124	01
05	0531050098	HOSE ASSY ARTICULATION FERTILIZER/SEED	125	01
06	0521055274	HEAD HOSE ASSY	126	01
07	0531050097	ASSY HOSE LIFTING FERTILIZER/SEED	127	01
08	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	128	02
09	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0521069163	OIL TUBE		02
02	0521069164	OIL PIPE R.7/8		06
03	0521069009	OIL DUCT		01
04	0521069275	OIL TUBE		02
05	0581018409	FASTENER BODY		08
06	0521053537	CENTRAL REAR DUCT SUPPORT	122	04
07	0503010237	3/8" X 1" BOLT		12
08	0503011268	3/8" X 2-1/2" BOLT		08
09	0503010025	3/8" SPRING WASHER		20
10	0503010026	3/8" NUT		20
11	0591010127	SUPPORT LEFT DISTRIBUTOR		02
12	0581014867	SIDE DUTY SUPPORT		02




Item	Code	Description	See page	QT
01	0571019615	FITTING 1/2 UNC 130 X 198 ZN		01
02	0511017302	FLAT WASHER		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0503010025	3/8" SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581017885	SUPPORT BODY		01
08	0503011141	3/8" X 2-3/4" BOLT		01
09	0581018407	BODY FASTENER 2 DUCTS		01




Item	Code	Description	See page	QT
01	0503019426	TRIPLE FLOW DIVISING VALVE		01
02	0581013111	NIPLE R 1.1/6 UN X 1.5/16 12 WIRES		01
03	0503014724	2-215 N 3006-9B O'RING		01
04	0501010984	FLAT WASHER		04
05	0503010045	O'RING		03
06	0511010111	7/8" NIPPLE		02
07	0503013357	3/8" SELF-ADJUSTING NUT		04
08	0503010237	3/8" X 1" BOLT		04
09	0501012520	1-1/16" X 7/8" NIPPLE		01




Item	Code	Description	See page	QT
01	0591016376	VALVE SUPPORT		01
02	0503010172	M10 X 1,5 X 25 BOLT		03
03	0503010025	3/8" SPRING WASHER		03
04	0511017302	FLAT WASHER		02
05	0591016360	BLOCK SUPPORT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		02
07	0503011082	C1/2" X 1.3/4" SCREW		02




Item	Code	Description	See page	QT
01	0501080437	3/8 X 1900 TC-TC HOSE		01
02	0501080968	3/8 X 1800 TC-TC HOSE		01
03	0501080514	3/8" X 67" TC-TC HOSE ASSY		02
04	0501080931	3/8" X 39" TC-TC HOSE ASSY		01
05	0501080370	TC-TC HOSE ASSY		01




Item	Code	Description	See page	QT
01	0501080461	TR-TC HOSE ASSY		02
02	0501080297	3/8" X 2800 TR-TR HOSE		02
03	0501080526	3/8" X 114" TR-TC HOSE ASSY		01
04	0501080527	HOSE 3/8 X 3300 TR-TC		01




Item	Code	Description	See page	QT
01	0501081837	HOSE 3/8 X 700 TR-TC		04
02	0501080700	3/8 X 650 TC-TC HOSE		02
03	0501080599	3/8 X 650 TC-TR HOSE		02
04	0501081838	HOSE		04
05	0501080065	3/8 X 1200 TC-TC HOSE ASSY		01
06	0501080675	HOSE 3/8 X 1000 TC-TC 180G		03
07	0501080105	TR-TR HOSE ASSY		04
08	0501080302	TR-TC HOSE ASSY		01
09	0501080714	HOSE 3/8 X 1600 TR-TC		01
10	0501082204	3/4 X 2750 TR-TR HOSE		02
11	0501081288	3/4 X 500 TR-TC HOSE		01
12	0521053712	HOSE 3/4 X 5900 TR-TM BLACK / RED		01
12A	0501082205	HOSE 1/2 X 5900 TR-TM		01
12B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
12C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
12D	0503018952	PLASTIC BOLT		06
13	0521053707	HOSE 3/4 X 5900 TR-TM BLACK / BLUE		01
13A	0501082205	HOSE 1/2 X 5900 TR-TM		01
13B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
13C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
13D	0503018952	PLASTIC BOLT		06
14	0501080485	3/8" X 1100 TR-TC HOSE		02
15	0501080200	3/4 X 1600 TR-TC HOSE		01
16	0501080150	HOSE ASSY		02
17	0501080023	3/4 X 1700 TR-TC HOSE		02
18	0501081160	HOSE 3/4 X 1350 TR-TC		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0581017967	GUTTER 24 X 46 X 1200		02
02	0581017950	GUTTER		02
03	0503013029	3/8" X 3/4" BOLT		04
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0511057011	SUPPORT GUTTER ASSY	130	05
07	0521055476	FIXER GUTTER	131	04




Item	Code	Description	See page	QT
01	0571013956	CENTRAL TRACK SUPPORT		01
02	0503010025	3/8" SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0503013029	3/8" X 3/4" BOLT		01
05	0501011643	3/8 X 1" BOLT		01




Item	Code	Description	See page	QT
01	0521069785	FIXER GUTTER		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0503010589	1/2" UNC SELF ADJUSTING NUT		02
04	0503010025	3/8" SPRING WASHER		01
05	0503010026	3/8" NUT		01
06	0503013029	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
01	0521054283	HEADLIGHT WITH SUPPORT	133	03
02	0521059393	LED FLASHLIGHT WITH FIXATION SUPPORT	134	02
03	0521057879	ECB ELECTRIC ASSEMBLY (ASSEMBLED)		01
03A	0503019329	COMMAND PANEL		01
03B	0503019061	WHIP		01
03C	0503019060	WHIP		01
03D	0503019390	WHIP BLOCK COMMAND IMPLEMENT		01
03E	0503019572	WHIP 3 HEADLIGHTS		01
03F	0503019694	LED LANTERN EXTENSOR WHIP 15M 4320.8 BCE		01
04	0503018829	NYLON CLAMP		20
05	0503019902	NYLON CLAMP 7,8X1,8X225 MM		80
06	0521055426	ASSY ELECTRICAL BOX SUPPORT	137	01
07	0521052143	CLUTCH INDUCTIVE SENSOR ASSEMBLY	138	01




Item	Code	Description	See page	QT
01	0581018571	REAR HEADLIGHT SUPPORT		01
02	0503018738	LIGHTHOUSE		01
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010358	5/16" X 5/8" BOLT		02
05	0503013759	NUT		02
06	0503010025	3/8" SPRING WASHER		02
07	0503010026	3/8" NUT		02
08	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0591013259	LED FLASHLIGHT SUPPORT		01
02	0503019579	LED LANTERN		01
03	0503013357	3/8" SELF-ADJUSTING NUT		02
04	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0503062967	24LINES SEED MONITORING KIT		01
01A	0503017602	MONITOR PLANT PM400		01
01B	0503017578	SINGLE CABLE PM400		01
01C	0503062698	MONITORING CABLE PM400 26 LINES		01
01D	0503017443	ANTENNA GPS PM 400		01
01E	0503015218	SENSOR FOTOELE PM 400		24
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010669	FLAT WASHER		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010667	3/16" NUT		02
09	0503013100	NYLON CLAMP		99
10	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		99




Item	Code	Description	See page	QT
01	0503034003	SERIAL NUMBER TAG 61 X 118		01
02	0503010001	3.2 X 5.5 RIVET		04
03	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 MOUTH)		08
04	0503034563	ADHESIVE LABEL		04
05	0503034114	ADHESIVE LABEL LOGO TATU BOX 190 X 530		04
06	0503034566	ADHESIVE LABEL		04
07	0503033853	ADHESIVE LABEL		02
08	0503031425	ADHESIVE LABEL ATTENTION		02
09	0503034679	ADHESIVE LABEL		01
10	0503033597	ADHESIVE		02
11	0503031087	ADHESIVE LABEL		01
12	0503032986	ADHESIVE LABEL		01
13	0503034471	ADHESIVE LABEL		01
14	0503034651	ADHESIVE LABEL		02
15	0503034683	ADHESIVE LABEL		02
16	0503034534	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0581014432	ELECTRIC BOX SUPPORT		01
02	0503010019	1/2" SPRING WASHER		02
03	0503010060	1/2" NUT		02
04	0503014007	1/2" X 1-1/4" BOLT		02




Item	Code	Description	See page	QT
01	0581016487	SENSOR SUPPORT		01
02	0501010063	1/2" X 1-1/2" BOLT		02
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0503019085	INDUCTIVE SENSOR		01
06	0571015148	PLATE SENSIBLES		01
07	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02




Item	Code	Description	See page	QT
01	0503019327	CONTROL PANEL		01
02	0503019054	WHIP		01
03	0503019059	WHIP		01
04	0503019052	WHIP		01
05	0503019328	WHIP		01
06	0503019057	WHIP		01




Item	Code	Description	See page	QT
01	0503062391	SILO FERTILIZER 05 MOUTHS		02
02	0521055324	SUPPORT CENTER	141	01
03	0521055323	CENTRAL LEFT SUPPORT	142	01
04	0511017302	FLAT WASHER		12
05	0503010019	1/2" SPRING WASHER		12
06	0503010060	1/2" NUT		12
07	0503010920	1/2" X 1.1/2" BOLT		12
08	0521051407	FIXER SILO FERTILIZER	52	16
09	0503010010	1/4" X 2.1/2" COTTERPIN		01
10	0502012007	SQUARE SLEEVE		01
11	0503034396	FERTILIZER SIDE COVER		10
12	0503010362	1/8" X 1.1/4" COTTERPIN		10




Item	Code	Description	See page	QT
01	0521069707	SUPPORT CENTER		01
02	0521054282	BEARING	48	03
03	0503030303	SUPPORT WASHER		03
04	0511061759	22Z P12,70 FQ 3/4" GEAR		01
05	0511059491	AXLE HOLDER	143	02
06	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	51	04
07	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	47	01
08	0503030275	AGRICULTURAL BEARING		05
09	1902010685	18Z CONICAL GEAR		05
10	0581019786	SQUARE SHAFT		01
11	0503010025	3/8" SPRING WASHER		20
12	0501010942	3/8" X 1-1/4" BOLT		20
13	0503010026	3/8" NUT		20



Item	Code	Description	See page	QT
01	0521054282	BEARING	48	02
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	51	01
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	47	04
04	0581019781	AXE CARRÉ		01
05	0503030275	AGRICULTURAL BEARING		05
06	1902010685	18Z CONICAL GEAR		05
07	0503030303	SUPPORT WASHER		02
08	0511059491	AXLE HOLDER	143	02
09	0521069706	SUPPORT CENTER		01
10	0503010025	3/8" SPRING WASHER		20
11	0501010942	3/8" X 1-1/4" BOLT		20
12	0503010026	3/8" NUT		20




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
03	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
04	0503011441	SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0521064543	WHEEL SUPPORT		01
02	0561019929	FLAT WASHER		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		02
04	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
05	0551014508	FLAT WASHER		01
06	0503010523	1/4" X 2" COTTERPIN		03
07	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
08	0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	20	01
09	0503010920	1/2" X 1.1/2" BOLT		04
10	0503010019	1/2" SPRING WASHER		04
11	0503010060	1/2" NUT		04
12	0502012731	WHEEL HOLDER		02
13	0581017245	AXLE BODY		01
14	0503011075	3/4" UNC NUT		04
15	0503012334	3/4" UNC X 3.1/2" BOLT		04
16	0503010002	1800 GREASE FITTING		04
17	0521064550	CARRYING-WHEELS FORK		01
18	0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	21	01
19	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
20	0511054491	WHEEL WITHOUT TIRE WITH 27Z GEAR	22	01
21	0531012874	FLAT WASHER		02
22	0511068422	WHEEL GEAR DOBLE		01
23	0551018571	FLAT WASHER		02
24	0511054463	WHEEL TENSIONER SUPORT CENTRAL	23	01
25	0511054464	WHEEL FORK TENSIONER	24	02
26	0561019941	RIGHT PROTECTIVE CAP WHEELS		01
27	0503010849	3/8" X 1-1/2" BOLT		02
28	0501013518	FLAT WASHER		02
29	0503010025	3/8" SPRING WASHER		02
30	0503010209	3/8" UNC BUTTERFLY NUT		02
31	0503016419	50-1 CHAIN X 128 LINK + REDUCION		01


Item	Code	Description	See page	QT
32	0501010630	1.1/2" CASTLE NUT		01
33	0501017779	32 X 60 X 4.75 FLAT WASHER		02
34	0503011052	1.1/4" X 0.77" CASTLE NUT		02
35	0511054501	TRANSMISSION CAMBIO LEFT	145	01
36	0503014857	50-1 X CHAIN X 122 LINK + REDUCION		01
37	0503033335	CURRENT 6 X 21 ELOS		01
38	0503010882	BOLT		01
39	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
40	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0521064556	SUPPORT ASSY TRANSMISSION WHEEL SIDE		01
02	0503010025	3/8" SPRING WASHER		13
03	0503010026	3/8" NUT		11
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03
06	0503010741	1/2" X 2-3/4" BOLT		03
07	0503062231	CLUTCH		01
08	0571015139	FIXER PLATE		01
09	0571015138	CHOCK FRICÇÃO		01
10	0511054461	STRETCHER TOP TRANSMISSION SWIRLED	26	02
11	0503011268	3/8" X 2-1/2" BOLT		01
12	0503013542	M10 SPRING WASHER		04
13	0503010188	M10 X 1,5 X 30 BOLT		01
14	0511069511	27Z GEAR		02
15	0571015152	FIXER TRANSMISSION SIDE LEFT		04
16	0571015154	PROTECTION TRANSMISSION LEFT		04




Item	Code	Description	See page	QT
01	0521069722	SUPPORT SIDE BAEM		01
02	0503062961	FERTILIZER BEAM ASSY		02
03	0521050525	FIXER FERTILIZER CONDUCTOR	42	07
04	0521051407	FIXER SILO FERTILIZER	52	12
05	0521055365	SEED CONDUCTOR	43	07
06	0521055370	SEED CONDUCTOR	44	01




Item	Code	Description	See page	QT
01	0503062362	SILO FERTILIZER 04 MOUTH		02
02	0521055362	SUPPORT SILO SIDE FERTILIZER 08 MOUTH LEFT	148	01
03	0503034396	FERTILIZER SIDE COVER		07
04	0503010362	1/8" X 1.1/4" COTTERPIN		07
05	0521051407	FIXER SILO FERTILIZER	52	12



Item	Code	Description	See page	QT
01	0521069715	SUPPORT SIDE BAEM		01
02	0503030275	AGRICULTURAL BEARING		07
03	0502012990	CONICA 14Z SQUARE GEAR		07
04	0501010942	3/8" X 1-1/4" BOLT		28
05	0503010026	3/8" NUT		32
06	0503010025	3/8" SPRING WASHER		32
07	0581019817	SQUARE SHAFT		01
08	0521054313	CLOSED BEARING	35	01
09	0503030303	SUPPORT WASHER		04
10	0521054282	BEARING	48	02
11	0501053788	Q3/4" FASTENER AXLE ASSY	50	03
12	0511061759	22Z P12,70 FQ 3/4" GEAR		01
13	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	51	05
14	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	47	02
15	0511062163	FERTILIZER BEAM LOWER COVER		01
16	0501010984	FLAT WASHER		04
17	0501011643	3/8 X 1"BOLT		04



Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
02	0503010019	1/2" SPRING WASHER		02
03	0503010060	1/2" NUT		02
04	0521069319	LEFT FERTILIZER CONDUCTOR		01
05	0581019990	TRACK FIXING BASE		01



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

