

ROW CROP PLANTERS

USAP 24E500 - MH/MS

Code: 0501092958

Series: S-0114

Revision: 00

Date Revision: ABRIL/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description	
0111140220	USAP 24E500 MH MS	S-0114

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909095714	FRAME ASSY	1
0909095715	FRAME RIGHT SIDE ASSY	2
0909095716	ASSY CENTRAL FRAME	3
0909095717	LEFT SIDE FRAME ASSY	4
0909095718	SEED LINE ASSY	5
0511053645	TELESCOPIC WITH STRAW INTERNAL 12910/15890	6
0511048176	HITCH ASSY	7
0511053630	PANTOGRAPHY HEADER	8
0511058228	HYDRAULIC CYLINDER DRAWBAR HYDRAULIC	9
0511055335	RIGHT FRENCH HAND	10
0511055336	LEFT FRENCH HAND	11
0511052388	REST GREATER ASSY	12
0511054256	COROT WATER	13
0511053122	TOOLS BOX ASSY	14
0501058486	TRANSPORT SUPPORT ASSY	15
0511052507	FRONT SUPPORT ASSY HOSES	16
0501058806	RIGHT SEED SILO SUPPORT	17
0511053321	RH PLATFORM SUPPORT	18
0511053323	NYLON LUG ASSY	19
0511053320	ASSY SIDE LADDER	20
0531050872	RIGHT WHEEL WITH TRANSMISSION	21
0531050873	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	22
0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	23
0511054491	WHEEL WITHOUT TIRE WITH 27Z GEAR	24
0511054500	TRANSMISSION EXCHANGE RIGHT	25
0511054501	TRANSMISSION CAMBIO LEFT	26
0501059729	RIGHT GEAR BOX ASSY	27
0501052776	CHAIN TENSIONER RIGHT ASSY GREATEST	28
0511053337	DRIVE SHAFT	29
0511053338	ASSY HIDRAULICO	30
0521050502	SIDE DUCT FIXER	31
0521050503	DUCT MARKER FIXER	32
0511053728	FRONTAL SUPPORT HOSE	33
0511054514	ROW MARKER ASSY	34
0511058227	HYDRAULIC CYLINDER 38,10 X 63,50 X 608 X 290	35
0511042494	ROW MARKER DISC ASSY	36
0511058903	SHORT SEED ROW FRONT	37
0511058904	LONG FRONT SEED ROW	38
0511054884	TRANSMISSION BOX	39
0501052769	BEARING WITH 17Z GEAR	40
0501055112	MICRO GRANULATED CHAIN TENSIONER	41
0501053826	BEARING WITH 17Z GEAR	42
0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	43
0501052775	ROW SEED BEARING	44
0511052300	CONDUCTOR SUPPORT ASSY SEED	45
0501058107	5/8" AXLE	46
0501058108	5/8" AXLE	47
0521042728	RIGHT REAR LINE SEED WITH SENSOR	48
0521042729	LEFT REAR LINE SEED WITH SENSOR	49
0501058972	ASSEMBLY SENSOR ELECTRONIC	50
0511051693	BASE FIXING SYSTEM	51
0501059631	DDD SEED 15 X 15 RIGHT	52
0501059632	DDD SEED 15X15 LEFT	53
0501054167	15" RIGHT OPENING DISC HUB	54
0501054168	15" LEFT OPENING DISC HUB	55



MARCHESAN

INDEX


0511047164	DISC BLADE ASSY	56
0511052299	BLADE DISC	57
0511054329	ASSY SYSTEM SEED	58
0511053715	SEED SYSTEM ASSY	59
0501051094	ASSY SEED DISTRIBUTOR	60
0501051119	DOUBLE PULLEY ROCKER'S	61
0521042327	DEPTH CONTROL & PRESS WHEEL ASSY	62
0511050077	WHEEL STRIPED	63
0511052287	DEPTH WHEEL HUB ASSY	64
0511054333	COMPACT WHEEL RIGHT WITH BEARING	65
0511054334	COMPACT WHEEL LEFT WITH BEARING	66
0501052908	COMPACTOR WHEEL WITH BEARING	67
0511053857	FAST CLOSING SET	68
0501050120	LARGER WALKING BEAM ASSY	69
0511057530	TRANSMISSION AXLE	70
0511054515	ASSY LEFT ARTICULATION ARM	71
0511054516	ASSY RIGHT ARTICULATION ARM	72
0511058226	HYDRAULIC CYLINDER 50,80 X 114,30 X 810 X 1300	73
0511058239	HYDRAULIC CYLINDER	74
0501058351	RIGHT CENTRAL BOX FERTILIZER	75
0501058352	LEFT BOX FERTILIZER ASSY	76
0511053377	COVER ASSY	77
0511052544	DUCT TOP SEED ASSY	78
0521043440	WHEELS CENTER AND TRANSMISSION	79
0521043436	CENTRAL WHEEL WITHOUT TRANSMISSION	80
0511054492	STUB SHAFT HUB	81
0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	82
0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE	83
0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	84
0511054463	WHEEL TENSIONER SUPORT CENTRAL	85
0511054464	WHEEL FORK TENSIONER	86
0511054499	TRANSMISSION OF LARGER CENTRAL EXCHANGE	87
0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	88
0511054461	STRETCHER TOP TRANSMISSION SWIRLED	89
0511054502	ASSY CENTRAL EXCHANGE	90
0511054319	CURRENT DEVIATION 8RD (8940-15890)	91
0511053043	DEVIATION GREATER ASSY	92
0511054252	DEVIATION LOWER REAR	93
0501056271	GEARBOX CLOSED BEARING	94
0501056444	BEARING WITH ROLLING	95
0511053045	TENSIONER REAR OFFSET HIGHER	96
0511053050	CHAIN TENSIONER	97
0511059854	STRETCHER OFFSET HIGHER FRONT	98
0511054476	RIGHT TENSIONER CENTRAL EXCHANGE	99
0501056573	17Z GEAR ASSY	100
0511054604	HYDRAULIC ASSEMBLY	101
0511053310	WHEEL HOSE ASSY	102
0511051368	ARTICULATION HOSE GAME	103
0511053307	LIFT HOSE GAME	104
0511051369	HYDRAULIC HOSE MARKER GAME	105
0511053313	BLOCK COMMAND	106
0501054649	HBM SEQUENTIAL VALVE	107
0511053343	ELECTRIC ASSEMBLY	108
0511053346	MINI MOUNTED ELECTRONIC SYSTEM KIT	109
0511056436	PLANTING MONITORING ASSY 29L PM400 SEED	110




MARCHESAN

INDEX

0511053349	ELECTRICAL SYSTEM KIT		111
0501058805	LEFT SEED SILO SUPPORT		112
0511053322	LEFT PLATFORM SUPPORT		113
0531050871	LEFT WHEEL WITH TRANSMISSION		114
0501059728	ASSY LEFT EXCHANGE		115
0501052778	CHAIN TENSIONER ASSY		116
0501048790	AXLE WITH RING		117




Item	Code	Description	See page	QT
01	0909095715	FRAME RIGHT SIDE ASSY	2	01
02	0909095716	ASSY CENTRAL FRAME	3	01
03	0909095717	LEFT SIDE FRAME ASSY	4	01
04	0511053645	TELESCOPIC WITH STRAW INTERNAL 12910/15890	6	01
05	0521064812	SMALLER TRANSPORT LOCK		01
06	0511048176	HITCH ASSY	7	01
07	0511053630	PANTOGRAPHY HEADER	8	01
08	0511055335	RIGHT FRENCH HAND	10	01
09	0511055336	LEFT FRENCH HAND	11	01
10	0511052388	REST GREATER ASSY	12	01
11	0511054256	COROT WATER	13	01
12	0511053122	TOOLS BOX ASSY	14	01
13	0503014120	CHAIN		01
14	0503014321	CABLE STEEL SHACKLE		01
15	0521064540	TELESCOPIC LOCK		01
16	0501058486	TRANSPORT SUPPORT ASSY	15	01
17	0511052507	FRONT SUPPORT ASSY HOSES	16	01
18	0503015764	BOLT 7/8		02
19	0501010076	FLAT WASHER		04
20	0503010408	7/8" SPRING WASHER		02
21	0503010417	7/8" NUT		02




Item	Code	Description	See page	QT
01	0521064363	RIGHT SIDE FRAME		01
02	0521060930	FERTILIZER BEAM SUPPORT FIXER		04
03	0551015037	5/8" UNC X 210 X 198 FASTENER		08
04	0503010027	5/8" SPRING WASHER		16
05	0503010013	5/8" NUT		16
06	0501058806	RIGHT SEED SILO SUPPORT	17	01
07	0501010161	1/2" X 1.1/4" BOLT		18
08	0503010920	1/2" X 1.1/2" BOLT		18
09	0501013518	FLAT WASHER		18
10	0503010019	1/2" SPRING WASHER		22
11	0503010060	1/2" NUT		22
12	0511053377	COVER ASSY	77	06
13	0511069800	SIDE HANDRAIL		02
14	0511053321	RH PLATFORM SUPPORT	18	01
15	0501010161	1/2" X 1.1/4" BOLT		04
16	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
17	0503010019	1/2" SPRING WASHER		08
18	0503010060	1/2" NUT		08
19	0511053323	NYLON LUG ASSY	19	02
20	0511053320	ASSY SIDE LADDER	20	01
21	0511069802	PLATFORM 1880		01
22	0501010942	3/8" X 1-1/4" BOLT		04
23	0501013518	FLAT WASHER		04
24	0503010025	3/8" SPRING WASHER		04
25	0503010026	3/8" NUT		04
26	0551019056	SIDE PLATFORM SUPPORT		02
27	0501010161	1/2" X 1.1/4" BOLT		08
28	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		08
29	0501010160	BOLT 1/2 UNC X 3 C S G.2 ZN		06
30	0501013519	FLAT WASHER		12
31	0503010019	1/2" SPRING WASHER		22

Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		22
33	0501012140	FLAT WASHER		04
34	0531050872	RIGHT WHEEL WITH TRANSMISSION	21	01
35	0531050873	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	22	01
36	0501059729	RIGHT GEAR BOX ASSY	27	01
37	0511053337	DRIVE SHAFT	29	01
38	0561016761	3/4 X 1900 HEX AXLE		02
39	0521060142	17Z GEAR		01
40	0561015837	SLEEVE 31,75		01
41	0503010523	1/4" X 2" COTTERPIN		01
42	0511054314	TRANSMISSION AXLE LOCK SLEEVE		20
42B	0503010256	3/8" X 3/4" BOLT		01
42C	0502012699	TRANSMISSION HUB LOCK SLEEVE		01
43	0511053338	ASSY HIDRAULICO	30	01
44	0503033621	ADHESIVE LABEL		01
45	0503033424	DIRECT PLANTIO ADHESIVE LABEL		01
46	0503033416	ADHESIVE LABEL		01
47	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		01
48	0503031425	ADHESIVE LABEL ATTENTION		01
49	0503032986	ADHESIVE LABEL		01
50	0503032988	ADHESIVE LABEL		01
51	0503031827	LUBRICATE AND RETIGHTEN DAILY DECAL		01
52	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		01
53	0503031565	ADHESIVE LABEL CARE		01
54	0511054514	ROW MARKER ASSY	34	01
55	0909095718	SEED LINE ASSY	5	07




Item	Code	Description	See page	QT
01	0521064537	CENTRAL FRAME		01
02	0571015217	TUBE ADJUSTMENT PLATE		02
03	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		16
04	0503010027	5/8" SPRING WASHER		16
05	0571015072	LOCK AXLE		01
06	0503010765	3/8" X 3" BOLT		01
07	0503010026	3/8" NUT		01
08	0503010002	1800 GREASE FITTING		01
09	0511054515	ASSY LEFT ARTICULATION ARM	71	01
10	0511054516	ASSY RIGHT ARTICULATION ARM	72	01
11	0511058226	HYDRAULIC CYLINDER 50,80 X 114,30 X 810 X 1300	73	02
12	0521012538	1.2" X 3.5" COUPLING SHAFT		04
13	0503010523	1/4" X 2" COTTERPIN		04
14	0511058239	HYDRAULIC CYLINDER	74	01
15	0521011132	FLAT WASHER		02
16	0503010523	1/4" X 2" COTTERPIN		01
17	0501058351	RIGHT CENTRAL BOX FERTILIZER	75	01
18	0501058352	LEFT BOX FERTILIZER ASSY	76	01
19	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		08
20	0511017302	FLAT WASHER		12
21	0503010019	1/2" SPRING WASHER		19
22	0503011336	1/2" HEX SELF ADJUSTING NUT		12
23	0503010905	1/2" X 2-1/4" BOLT		04
24	0511053377	COVER ASSY	77	02
25	0511052544	DUCT TOP SEED ASSY	78	10
26	0511069817	2315 CENTRAL HANDRAIL		02
27	0503010920	1/2" X 1.1/2" BOLT		04
28	0503010395	1/2" X 1-1/4" BOLT		04
29	0503010019	1/2" SPRING WASHER		08
30	0503010060	1/2" NUT		08
31	0521062334	PLATFORM CENTER		02

Item	Code	Description	See page	QT
32	0551019056	SIDE PLATFORM SUPPORT		04
33	0503010395	1/2" X 1-1/4" BOLT		14
34	0503010019	1/2" SPRING WASHER		16
35	0503010060	1/2" NUT		16
36	0551019397	CENTRAL HANDRAIL CHOCK		01
37	0503010920	1/2" X 1.1/2" BOLT		02
38	0571012531	BOX SUPPORT RELE		01
39	0551019557	FLASHLIGHT SUPPORT		02
40	0501010160	BOLT 1/2 UNC X 3 C S G.2 ZN		04
41	0511017302	FLAT WASHER		04
42	0503010019	1/2" SPRING WASHER		04
43	0503010060	1/2" NUT		02
44	0521043440	WHEELS CENTER AND TRANSMISSION	79	01
45	0521043436	CENTRAL WHEEL WITHOUT TRANSMISSION	80	03
46	0511054502	ASSY CENTRAL EXCHANGE	90	01
47	0511054319	CURRENT DEVIATION 8RD (8940-15890)	91	01
48	0511054604	HYDRAULIC ASSEMBLY	101	01
49	0511053343	ELECTRIC ASSEMBLY	108	01
50	0571013313	GUTTER 25 X 58 X 2150		02
51	0561016761	3/4 X 1900 HEX AXLE		01
52	0531013215	3/4" X 113" HEX AXLE		01
53	0521060142	17Z GEAR		01
54	0561015837	SLEEVE 31,75		01
55	0503010523	1/4" X 2" COTTERPIN		01
56	0511054314	TRANSMISSION AXLE LOCK SLEEVE		26
56A	0502012699	TRANSMISSION HUB LOCK SLEEVE		01
56B	0503010256	3/8" X 3/4" BOLT		01
57	0503034003	SERIAL NUMBER TAG 61 X 118		01
58	0503010001	3.2 X 5.5 RIVET		04
59	0503033854	ADHESIVE LABEL		06
60	0503033873	ADHESIVE LABEL		06
61	0503033853	ADHESIVE LABEL		02
62	0503031425	ADHESIVE LABEL ATTENTION		02
63	0503032988	ADHESIVE LABEL		01
64	0503033597	ADHESIVE		02
65	0503031087	ADHESIVE LABEL		01
66	0503032986	ADHESIVE LABEL		01
67	0503034471	ADHESIVE LABEL		01
68	0503034534	ADHESIVE LABEL		01
69	0511056436	PLANTING MONITORING ASSY 29L PM400 SEED	110	01
70	0511053349	ELECTRICAL SYSTEM KIT	111	01
71	0561016793	FIXED WRENCH		01
72	0521055637	ASSY TRANSPORT LOCK		04
72A	0551018312	TRANSPORT LOCK		01
72B	0501068994	8,30 X 78 LOCK PIN		01
72C	0503030168	HITCH PIN CLIP		01
73	0501047885	ROD STOP		08
74	0561017063	HOLDER TUBE		02
75	0511069471	PLOUGH SUPPORT		02
76	0501011075	PIN		02
77	0503030012	HITCH PIN CLIP		02
78	0503010002	1800 GREASE FITTING		30
79	0511018012	HIDRAULIC ADAPTER		02
80	0909095718	SEED LINE ASSY	5	10




Item	Code	Description	See page	QT
01	0521064364	LEFT SIDE FRAME		01
02	0521060930	FERTILIZER BEAM SUPPORT FIXER		03
03	0551015037	5/8" UNC X 210 X 198 FASTENER		06
04	0503010027	5/8" SPRING WASHER		12
05	0503010013	5/8" NUT		12
06	0501058805	LEFT SEED SILO SUPPORT	112	01
07	0501010161	1/2" X 1.1/4" BOLT		18
08	0503010920	1/2" X 1.1/2" BOLT		18
09	0501013518	FLAT WASHER		18
10	0503010019	1/2" SPRING WASHER		22
11	0503010060	1/2" NUT		22
12	0511053377	COVER ASSY	77	06
13	0511069800	SIDE HANDRAIL		01
14	0511053322	LEFT PLATFORM SUPPORT	113	01
15	0501010161	1/2" X 1.1/4" BOLT		04
16	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
17	0503010019	1/2" SPRING WASHER		08
18	0503010060	1/2" NUT		08
19	0511053323	NYLON LUG ASSY	19	02
20	0511053320	ASSY SIDE LADDER	20	01
21	0511069802	PLATFORM 1880		01
22	0501010942	3/8" X 1-1/4" BOLT		04
23	0501013518	FLAT WASHER		04
24	0503010025	3/8" SPRING WASHER		04
25	0503010026	3/8" NUT		04
26	0551019056	SIDE PLATFORM SUPPORT		02
27	0501010161	1/2" X 1.1/4" BOLT		08
28	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		08
29	0501010160	BOLT 1/2 UNC X 3 C S G.2 ZN		06
30	0501013519	FLAT WASHER		12
31	0503010019	1/2" SPRING WASHER		22

Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		22
33	0501012140	FLAT WASHER		04
34	0531050871	LEFT WHEEL WITH TRANSMISSION	114	01
35	0531050873	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	22	01
36	0501059728	ASSY LEFT EXCHANGE	115	01
37	0511053337	DRIVE SHAFT	29	01
38	0561016761	3/4 X 1900 HEX AXLE		02
39	0521060142	17Z GEAR		01
40	0561015837	SLEEVE 31,75		01
41	0503010523	1/4" X 2" COTTERPIN		01
42	0511054314	TRANSMISSION AXLE LOCK SLEEVE		20
42A	0502012699	TRANSMISSION HUB LOCK SLEEVE		20
42B	0503010256	3/8" X 3/4" BOLT		20
43	0511053338	ASSY HIDRAULICO	30	01
44	0503033621	ADHESIVE LABEL		01
45	0503033424	DIRECT PLANTIO ADHESIVE LABEL		01
46	0503033416	ADHESIVE LABEL		01
47	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		01
48	0503031425	ADHESIVE LABEL ATTENTION		01
49	0503032987	ADHESIVE LABEL		01
50	0503032988	ADHESIVE LABEL		01
51	0503031827	LUBRICATE AND RETIGHTEN DAILY DECAL		01
52	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		01
53	0503031565	ADHESIVE LABEL CARE		01
54	0511054514	ROW MARKER ASSY	34	01
55	0909095718	SEED LINE ASSY	5	07




Item	Code	Description	See page	QT
01	0511058903	SHORT SEED ROW FRONT	37	01
02	0511058904	LONG FRONT SEED ROW	38	01
03	0501013352	FLAT WASHER		01
04	0503010246	CLAMP		01
05	0521042728	RIGHT REAR LINE SEED WITH SENSOR	48	01
06	0521042729	LEFT REAR LINE SEED WITH SENSOR	49	01
07	0511047164	DISC BLADE ASSY	56	01
08	0511054329	ASSY SYSTEM SEED	58	01
09	0521042327	DEPTH CONTROL & PRESS WHEEL ASSY	62	01
10	0511053857	FAST CLOSING SET	68	01
11	0531013600	PRESS ADJUSTMENT LEVER		01
12	0503016204	CORN DISK 12 ORANGE		01
13	0503016214	RING CORN (APOLLO740)		01
14	0503016218	DISC OF SOYBEAN		01
15	0503016220	RING TO SOYBEANS (APOLLO 745)		01
16	0503016221	RING TO SOYBEANS (APOLLO 571)		01
17	0503030558	PULLEY 4Z CORN PLASTIC		01
18	0501050120	LARGER WALKING BEAM ASSY	69	01
19	0503010905	1/2" X 2-1/4" BOLT		01
20	0503010019	1/2" SPRING WASHER		01
21	0503010060	1/2" NUT		01
22	0571012013	TRANSPORT LOCK		01
23	0571012014	TRANSPORT LOCK		01
24	0511057530	TRANSMISSION AXLE	70	01




Item	Code	Description	See page	QT
01	0521061429	FRONT ARM INTERNAL TUBE		01
02	0521061424	TELESCOPIC DRAWBAR		01

HITCH ASSY


0511048176




Item	Code	Description	See page	QT
01	0511069472	DRAWBAR		01
02	0551018417	AXLE HITCH		02
03	0503030012	HITCH PIN CLIP		02
04	0561013456	GUIDE DRAWBAR ASSY		02
05	0501010276	BOLT		04
06	0501010059	1.5/8 NUT		04
07	0503010012	1" SPRING WASHER		04
08	0521012533	COUPLING SHAFT		01
09	0561017306	COUPLING SHAFT		01
10	0503030119	LOCK PIN		02




Item	Code	Description	See page	QT
001	0521062955	SEED ARM SUPPORT ROW		01
002	0501079585	ARM USAP		01
003	0521063433	EAR ARM PANTOGRAPH WITH LOOK		01
004	0521063434	EAR ARM PANTOGRAPH		01
005	0502040864	GEAR BOX WITH REGULATOR		01
006	0521063514	TRACTOR HITCH		01
007	1902040327	LOCK SLEEVE		01
008	0521010578	COUPLING SHAFT		01
009	0503010523	1/4" X 2" COTTERPIN		01
010	0521063432	LOCK AXLE		02
011	0521063022	AXLE LOWER		04
012	0571011013	AXLE ARM		01
013	0503012198	3/16" X 2" COTTERPIN		07
014	0503010002	1800 GREASE FITTING		04
015	0501019435	32 X 50 X 1.5 FLAT WASHER		12
016	0503031035	HITCH PIN CLIP		02
017	0511058228	HYDRAULIC CYLINDER DRAWBAR HYDRAULIC	9	01
018	0511052507	FRONT SUPPORT ASSY HOSES	16	01
018A	0521066319	FRONT SUPPORT HYDRAULIC HOSE		01
018B	0503014007	1/2" X 1-1/4" BOLT		01
018C	0503010019	1/2" SPRING WASHER		01
019	0501081848	HOSE 3/8 X 3200 TR-TM		02
020	0503011052	1.1/4" X 0.77" CASTLE NUT		02
021	0501010307	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521062362	CYLINDER CASE		01
02	0521062361	ROD CILINDER DRAWBAR HYDRAULIC		01
03	0503010002	1800 GREASE FITTING		02
04	0503030384	CON PLUG N-001		02
05	0503010817	1.1/4" SELF LOCKING NUT		01
06	0503010345	2-218 N 3006-9B O'RING		01
07	0502010382	5" END CAP		01
08	0581010353	RING SUPPORT		01
09	0503018026	1870-2000-375 B GASKET		01
10	0503011453	O'RING		02
11	0503018152	O'RING		02
12	0503018024	RING BS		01
13	0503018025	RING GUIDE		01
14	0581010354	PISTON		01
15	0503018150	RING GUIDE		01
16	0503018151	RING BS		02
17	0503010039	D-2000 SCRAPER RING		01
18	0511032524	ASSY CYLINDER REPAIR KIT 50,8X127 USAP (0511058228)		01




Item	Code	Description	See page	QT
001	0521063864	FRENCH HAND		01
002	0502012702	BODY SUPPORT CLAMP		08
003	0503011135	BOLT		08
004	0503010180	7/16" SPRING WASHER		08




Item	Code	Description	See page	QT
001	0521063864	FRENCH HAND		01
002	0571010361	20 X 38 X 2075 GUTTER		02
003	0571011891	GUIDE RAIL		01
004	0503011952	5/16" X 3/4" BOLT		02
005	0501010694	FLAT WASHER		02
006	0503010179	LOCK WASHER		02
007	0503010337	5/16" NUT		02
008	0502012702	BODY SUPPORT CLAMP		04
009	0503010355	7/16" X 1" BOLT		04
010	0503011135	BOLT		04
011	0501012803	FLAT WASHER		04
012	0503010180	7/16" SPRING WASHER		08




Item	Code	Description	See page	QT
01	0521063510	PLOUGH SUPPORT		01
02	0521063509	FRAME BRACKET		01
03	0571012421	FIXER ARM		01
04	0501014063	25 X 55 COUPLING SHAFT		01
05	0521010596	COUPLING SHAFT		03
06	0521010585	0.9" X 5.9" COUPLING SHAFT		01
07	0521010574	C0.9" X 3.3" COUPLING SHAFT		01
08	0503030085	LOCK PIN		06
09	0571013317	INNER TUBE		01




Item	Code	Description	See page	QT
01	0503014820	BLACK WATER RESERVOIR		01
02	0571014702	COROTE SUPPORT GLOVE		02




Item	Code	Description	See page	QT
01	0521063661	BOX OF TOOLS		01
02	0551018356	BOX OF TOOLS COVER ASSY		01
03	0521010528	0.3" X 1.6" COUPLING SHAFT		02
04	0503010140	1/8" X 3/4" COTTERPIN		02
05	0503011907	PMC 594-S NYLON LUG		01
06	0503010358	5/16" X 5/8" BOLT		02
07	0503010179	LOCK WASHER		02
08	0503010337	5/16" NUT		02
09	0511017302	FLAT WASHER		04
10	0503010019	1/2" SPRING WASHER		02
11	0503010060	1/2" NUT		02
12	0503011411	1/2" X 5-1/2" BOLT		02




Item	Code	Description	See page	QT
00	0501058486	TRANSPORT SUPPORT ASSY	15	01
01	0521060025	TRANSPORT SUPPORT		03
02	0521062623	STAND		01
03	0521062624	STAND		02
04	0561019801	LOCK PIN		02
05	0561010272	L 76,20 X 1300 WITH HOLE		06
06	0501018652	CORN STABILIZER BAR		12
07	0501010098	3/4" UNC BOLT		24
08	0503010023	3/4" SPRING WASHER		24
09	0503010014	3/4" NUT		24
10	0503012410	5/8" X 7.1/2" BOLT		02
11	0551015037	5/8" UNC X 210 X 198 FASTENER		06
12	0503010027	5/8" SPRING WASHER		12
13	0503010013	5/8" NUT		12
14	0521063556	EASEL HIGHER		02




Item	Code	Description	See page	QT
01	0521066319	FRONT SUPPORT HYDRAULIC HOSE		01
02	0503010019	1/2" SPRING WASHER		01
03	0503010395	1/2" X 1-1/4" BOLT		01




Item	Code	Description	See page	QT
01	0511069823	RH SEED BOX SIDE SUPPORT		01
02	0503060640	COVER BOX RIGHT FERTILIZER		01
03	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02
04	0503010849	3/8" X 1-1/2" BOLT		04
05	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
06	0503010025	3/8" SPRING WASHER		04
07	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0561014688	RH PLATFORM SUPPORT		01
02	0503010239	BOLT 1/2 UNC X 1.1/2 C S G.2 ZN		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02



Item	Code	Description	See page	QT
01	0503011957	NYLON LUG		01
02	0503010365	NUT		02
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0511069819	SIDE LADDER		01
02	0502012742	FIXER SUPPORT LADDER		02
03	0503013357	3/8" SELF-ADJUSTING NUT		02
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0503010237	3/8" X 1" BOLT		04
07	0503010025	3/8" SPRING WASHER		04
08	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521064543	WHEEL SUPPORT		01
02	0561019929	FLAT WASHER		01
03	0503010523	1/4" X 2" COTTERPIN		03
04	0551014511	CARRYING WHEELS AXLE SLEVE GUIDES		02
05	0551014508	FLAT WASHER		01
06	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
07	0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	84	01
08	0503010920	1/2" X 1.1/2" BOLT		04
09	0503010019	1/2" SPRING WASHER		04
10	0503010060	1/2" NUT		04
11	0502012731	WHEEL HOLDER		02
12	0503010002	1800 GREASE FITTING		04
13	0521064550	CARRYING-WHEELS FORK		01
14	0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	23	01
15	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
16	0511054491	WHEEL WITHOUT TIRE WITH 27Z GEAR	24	01
17	0511068422	WHEEL GEAR DOBLE		01
18	0551018571	FLAT WASHER		02
19	0511054463	WHEEL TENSIONER SUPORT CENTRAL	85	01
20	0511054464	WHEEL FORK TENSIONER	86	02
21	0561019941	RIGHT PROTECTIVE CAP WHEELS		01
22	0503010849	3/8" X 1-1/2" BOLT		02
23	0501013518	FLAT WASHER		02
24	0503010025	3/8" SPRING WASHER		02
25	0503010209	3/8" UNC BUTTERFLY NUT		02
26	0503016419	50-1 CHAIN X 128 LINK + REDUCION		01
27	0501010630	1.1/2" CASTLE NUT		01
28	0501017779	32 X 60 X 4.75 FLAT WASHER		02
29	0503011052	1.1/4" X 0.77" CASTLE NUT		02
30	0503014857	50-1 X CHAIN X 122 LINK + REDUCION		01
31	0511054500	TRANSMISSION EXCHANGE RIGHT	25	01


Item	Code	Description	See page	QT
32	0503033335	CURRENT 6 X 21 ELOS		01
33	0503010882	BOLT		01
34	0501010694	FLAT WASHER		02
35	0503010337	5/16" NUT		01
36	0581017245	AXLE BODY		01
37	0531012874	FLAT WASHER		02
38	0503012334	3/4" UNC X 3.1/2" BOLT		04
39	0503011075	3/4" UNC NUT		04
40	0503010571	1/4" X 1.1/2 COTTERPIN		02

SIDE CENTRAL WHEEL WITHOUT TRANSMISSION


0531050873




Item	Code	Description	See page	QT
01	0521064543	WHEEL SUPPORT		01
02	0561019929	FLAT WASHER		01
03	0551014511	CARRYING WHEELS AXLE SLEVE GUIDES		02
04	0551014508	FLAT WASHER		01
05	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
06	0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	84	01
07	0503010920	1/2" X 1.1/2" BOLT		04
08	0503010019	1/2" SPRING WASHER		04
09	0503010060	1/2" NUT		04
10	0502012731	WHEEL HOLDER		02
11	0503010002	1800 GREASE FITTING		03
12	0521064550	CARRYING-WHEELS FORK		01
13	0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	23	01
14	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
15	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	82	01
16	0501010630	1.1/2" CASTLE NUT		01
17	0501017779	32 X 60 X 4.75 FLAT WASHER		02
18	0503011052	1.1/4" X 0.77" CASTLE NUT		02
19	0503010882	BOLT		01
20	0501010694	FLAT WASHER		02
21	0503010337	5/16" NUT		01
22	0503033335	CURRENT 6 X 21 ELOS		01
23	0581017245	AXLE BODY		01
24	0531012874	FLAT WASHER		02
25	0503012334	3/4" UNC X 3.1/2" BOLT		04
26	0503011075	3/4" UNC NUT		04
27	0503010523	1/4" X 2" COTTERPIN		03
28	0503010571	1/4" X 1.1/2 COTTERPIN		02




Item	Code	Description	See page	QT
01	0503033713	TIRE 12 X 16,5/12L TR SK 900		01
02	0503015029	WHEEL		01
03	0503015355	INNER TIRE		01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503013633	BEARING 33287/33462		01
04	0503010009	RETAINER 00573-B		01
05	0503010086	SEAL 0009B-B		01
06	0551014473	GLOVE		01
07	0503012702	KM-12 NUT		02
08	0503012703	LOCK WASHER		01
09	0503010002	1800 GREASE FITTING		01
10	0503011444	SPRING WASHER		08
11	0503014048	22 X 1.5 HEX NUT		08
12	0503010363	5/16" X 1" BOLT		08
13	0521064563	27Z GEAR		01
14	0503014050	22 X 1.5 BOLT		08
15	0503013496	3982/3920 ROLLER BEARING		01
16	1882970002	GREASE SOAP		01



Item	Code	Description	See page	QT
01	0521064556	SUPPORT ASSY TRANSMISSION WHEEL SIDE		01
02	0503010025	3/8" SPRING WASHER		13
03	0503010026	3/8" NUT		11
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03
06	0503010741	1/2" X 2-3/4" BOLT		03
07	0521064555	27Z GEAR		01
08	0503062231	CLUTCH		01
09	0571015139	FIXER PLATE		01
10	0571015138	SIDE CLUTCH CHOCK		01
11	0571015141	FIXER CENTRAL TRANSMISSION		04
12	0511054461	STRETCHER TOP TRANSMISSION SWIRLED	89	02
13	0503011268	3/8" X 2-1/2" BOLT		01
14	0571015142	FIXER		02
15	0571015143	RIGHT PROTECTION SUPPORT WHEEL		01
16	0503010209	3/8" UNC BUTTERFLY NUT		02
17	0503013542	M10 SPRING WASHER		04
18	0503010188	M10 X 1,5 X 30 BOLT		04




Item	Code	Description	See page	QT
01	0521064556	SUPPORT ASSY TRANSMISSION WHEEL SIDE		01
02	0503010025	3/8" SPRING WASHER		13
03	0503010026	3/8" NUT		11
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03
06	0503010741	1/2" X 2-3/4" BOLT		03
07	0503062231	CLUTCH		01
08	0571015139	FIXER PLATE		01
09	0571015138	SIDE CLUTCH CHOCK		01
10	0511054461	STRETCHER TOP TRANSMISSION SWIRLED	89	02
11	0503011268	3/8" X 2-1/2" BOLT		01
12	0503013542	M10 SPRING WASHER		04
13	0503010188	M10 X 1,5 X 30 BOLT		01
14	0511069511	27Z GEAR		02
15	0571015152	FIXER TRANSMISSION SIDE LEFT		04
16	0571015154	PROTECTION TRANSMISSION LEFT		04




Item	Code	Description	See page	QT
01	0521061420	SIDE GEAR BOX SUPPORT		01
02	0551015037	5/8" UNC X 210 X 198 FASTENER		02
03	0503010027	5/8" SPRING WASHER		04
04	0503010013	5/8" NUT		04
05	0501056271	GEARBOX CLOSED BEARING	94	03
06	0551018627	SIDE GEAR BOX DRIVER AXLE		01
07	0551018581	CENTRAL GEAR BOX DRIVEN AXLE		01
08	0503010292	0.2" X 1.6" SPRING PIN		05
09	0501056444	BEARING WITH ROLLING	95	01
10	0502011758	REAR TENSIONER LEVER		01
11	0501052776	CHAIN TENSIONER RIGHT ASSY GREATEST	28	01
12	0503010002	1800 GREASE FITTING		01
13	0503012204	40-1 CHAIN X 82 LINK + RED		01
14	0503030303	SUPPORT WASHER		04
15	0502040868	GEAR CONE REPLACEMENT		02
16	0503010395	1/2" X 1-1/4" BOLT		02
17	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		02
18	0503012389	1/2 BALL		02
19	0503010060	1/2" NUT		02
20	0511064536	28Z GEAR		01
21	0503014854	40-1 CHAIN X 135 LINK + MENDING		01
22	0521014167	CONE LOCK		01
23	0501054221	SEED BEARING INTERM LINE		02
24	0551018630	CARDAN SHAFT GUIDES SLEEVE		01
25	0551011625	PROTECTION COVER		01
26	0503010386	CABLE		01
27	0503010179	LOCK WASHER		01
28	0503010337	5/16" NUT		01
29	0551018629	GEAR BOX COVER FIXER ROD		01
30	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
31	0503010257	1/8" X 1" COTTERPIN		02


Item	Code	Description	See page	QT
32	0501048790	AXLE WITH RING	117	01
33	0503011953	5/16" X 1" BOLT		08
34	0501010694	FLAT WASHER		08
35	0503010179	LOCK WASHER		08
36	0503010337	5/16" NUT		08
37	0503011268	3/8" X 2-1/2" BOLT		01
38	0503013357	3/8" SELF-ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0511061794	CHAIN TENSIONER		01
02	0503031367	SPRING		01
03	0503031805	11Z 1/2" GEAR		02
04	0503010302	501019 SEAL RING		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501048409	DRIVE SHAFT		01
02	0503011141	3/8" X 2-3/4" BOLT		02
03	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
001	0521050502	SIDE DUCT FIXER	31	03
001A	0511069526	TUBE FIXER LARGER SUPPORT		01
001B	0581010230	LOWER BODY CENTRAL DUCT FASTENER		01
001C	0503010025	3/8" SPRING WASHER		02
001D	0503010026	3/8" NUT		02
001E	0503011179	3/8" X 2-1/4" BOLT		02
001F	0571019756	FASTENER 1/2 UNC X 220 X 198 ZN		01
001G	0511017302	FLAT WASHER		02
001H	0503010019	1/2" SPRING WASHER		02
001I	0503010060	1/2" NUT		02
002	0521050503	DUCT MARKER FIXER	32	01
002A	0521062666	FIXER SUPPORT TUBE MARK		01
002B	0571019756	FASTENER 1/2 UNC X 220 X 198 ZN		01
002C	0511017302	FLAT WASHER		02
002D	0503010019	1/2" SPRING WASHER		02
002E	0503010060	1/2" NUT		02
002F	0551018637	SMALEE FASTENER TUBE UPPER		01
002G	0503010025	3/8" SPRING WASHER		01
002H	0503010026	3/8" NUT		01
002I	0503011179	3/8" X 2-1/4" BOLT		01
003	0571014383	GUTTER		02
004	0511069525	2622 OIL TUBE		02
005	0511053728	FRONTAL SUPPORT HOSE	33	01
005A	0521064196	FRONTAL SUPPORT HOSE		01
005B	0551015037	5/8" UNC X 210 X 198 FASTENER		01
005C	0503010027	5/8" SPRING WASHER		02
005D	0503010013	5/8" NUT		02
005E	0501012140	FLAT WASHER		02
006	0503013171	SEALING		02




Item	Code	Description	See page	QT
001	0511069526	TUBE FIXER LARGER SUPPORT		01
002	0581010230	LOWER BODY CENTRAL DUCT FASTENER		01
003	0503010025	3/8" SPRING WASHER		02
004	0503010026	3/8" NUT		02
005	0503011179	3/8" X 2-1/4" BOLT		02
006	0571019756	FASTENER 1/2 UNC X 220 X 198 ZN		01
007	0511017302	FLAT WASHER		02
008	0503010019	1/2" SPRING WASHER		02
009	0503010060	1/2" NUT		02



Item	Code	Description	See page	QT
001	0521062666	FIXER SUPPORT TUBE MARK		01
002	0571019756	FASTENER 1/2 UNC X 220 X 198 ZN		01
003	0511017302	FLAT WASHER		02
004	0503010019	1/2" SPRING WASHER		02
005	0503010060	1/2" NUT		02
006	0551018637	SMALLEE FASTENER TUBE UPPER		01
007	0503010025	3/8" SPRING WASHER		01
008	0503010026	3/8" NUT		01
009	0503011179	3/8" X 2-1/4" BOLT		01




Item	Code	Description	See page	QT
001	0521064196	FRONTAL SUPPORT HOSE		01
002	0551015037	5/8" UNC X 210 X 198 FASTENER		01
003	0503010027	5/8" SPRING WASHER		02
004	0503010013	5/8" NUT		02
005	0501012140	FLAT WASHER		02





Item	Code	Description	See page	QT
01	0541012195	ARM BEFORE ARTICULICION AXLE		02
02	0521062492	RIGHT SUPPORT SMALLER		01
03	0521062493	LEFT SUPPORT		01
04	0503010038	3/16 X 2 COTTERPIN		06
05	0503010523	1/4" X 2" COTTERPIN		04
06	0511065479	BEFORE ARM (ROW MARKER)		02
07	0511058227	HYDRAULIC CYLINDER 38,10 X 63,50 X 608 X 290	35	02
08	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
09	0541015714	CYLINDER ARTICULACCION ALXE		02
10	0551016251	PIVOT SHAFT		02
11	0511065476	LARGER LEVER		02
12	0511065480	RIGHT INTERMEDIATE ARM		01
13	0511065481	LEFT INTERMEDIATE ARM		01
14	0541012194	INTERMEDIATE ARM ARTIC ALXE		02
15	0521064440	MARKER ARM LINE 1000		02
16	0541012193	MARK ARM ARTICULACCION ALXE		02
17	0503011052	1.1/4" X 0.77" CASTLE NUT		06
18	0511065487	REGULATOR SPINDLE		02
19	0511065475	ADJUSTMENT ROD		02
20	0541012196	SMALLER LEVER		02
21	0521064441	EXTENSOR 1025		02
22	0541015917	MARK ARM GUIDE		02
23	0511042494	ROW MARKER DISC ASSY	36	02
24	0511057350	ASSY BATSMAN		02
24A	0503011070	BEATER		01
24B	0503010233	5/8" X 2-1/2" BOLT		01
24C	0503010027	5/8" SPRING WASHER		01
24D	0501012140	FLAT WASHER		02
25	0501019435	32 X 50 X 1.5 FLAT WASHER		08
26	0501068994	8,30 X 78 LOCK PIN		02
27	0503030168	HITCH PIN CLIP		02

Item	Code	Description	See page	QT
28	0503010002	1800 GREASE FITTING		06
29	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		08
30	0503010027	5/8" SPRING WASHER		08
31	0503010013	5/8" NUT		08
32	0501014063	25 X 55 COUPLING SHAFT		10
33	0503030085	LOCK PIN		10
34	0501011445	FLAT WASHER		10
35	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04




Item	Code	Description	See page	QT
01	0521066554	SHIRT 72.85 X 522		01
02	0521066555	ROD 38,10 X 480		01
03	0503010002	1800 GREASE FITTING		02
04	0551016274	HYDRAULIC CYLINDER ADAPTER		02
05	0581010669	EMBOLUS 63.50 X 40 USAP		01
06	0503018005	RING		01
07	0503010558	7/8" NUT		01
08	0503010605	O'RING		01
09	0503010163	D-1500 SCRAPER RING		01
10	0502010471	63,50 MOBILE CAP		01
11	0581010668	RING SUPPORT		01
12	0503018004	RING		01
13	0503018003	GASKET		01
14	0503018163	BACK-UP RING		02
15	0503018162	O'RING		02
16	0503030385	CYLINDER PLUG N-002		02






Item	Code	Description	See page	QT
001	0511065881	SEED ROW SUPPORT FRONT		01
002	0502012710	SMALLER LOWER ARM		01
003	0531016194	0.6" X 1" X 2.6" SLEEVE		08
004	0502012749	SEED ARM SUPPORT ROW		01
005	0503010027	5/8" SPRING WASHER		05
006	0503010003	1845 GREASE FITTING		04
007	0503013077	5/8" X 8" BOLT		04
008	0521066168	FRAME SEED LINE		01
009	0571012310	ROW LOCK BODY		01
010	0551015826	SEED ROW LOCK GUIDE SLEEV		01
011	0503010232	5/8" X 1.3/4" BOLT		01
012	0503010013	5/8" NUT		01
013	0503030285	HITCH PIN CLIP		01
014	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
015	0503033728	FIXED SPRING PIN		02
016	1902012568	UPPER ROCKER ARM		01
017	0503030168	HITCH PIN CLIP		03
018	0511054884	TRANSMISSION BOX	39	01
019	0501052769	BEARING WITH 17Z GEAR	40	01
020	0503010071	3/16" X 1" COTTERPIN		01
021	0501055112	MICRO GRANULATED CHAIN TENSIONER	41	01
022	0501053826	BEARING WITH 17Z GEAR	42	01
023	0561014215	BEARING COVER LOWER ROW FRAME		01
024	0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	43	01
025	0503013369	40-1 X 62 CHAIN LINK + REDUCTION		01
026	0561015801	COVER PROTECTION FRAME		01
027	0561015802	13 X 10 X 14 SLEEVE		01
028	0503010179	LOCK WASHER		02
029	0503010337	5/16" NUT		02
030	0503010178	5/16" X 7/8" BOLT		01
031	0503010421	5/16" X 1-1/2" BOLT		01

Item	Code	Description	See page	QT
032	0511052300	CONDUCTOR SUPPORT ASSY SEED	45	01
033	0501058107	5/8" AXLE	46	01
034	0531015184	FLAT WASHER		04
035	0501013352	FLAT WASHER		02
036	0503012412	5/8 UNC SELF LOCKING NUT		08
037	0503033709	CATCH HEAD LINSEED SEEDS		02
038	0571014704	UPPER AXLE		01
039	0501012140	FLAT WASHER		01




Item	Code	Description	See page	QT
001	0521061015	SEED ROW SUPPORT FRONT		01
002	0502012709	LARGER LOWER ARM		01
003	0531016194	0.6" X 1" X 2.6" SLEEVE		08
004	0502012750	SEED ARM SUPPORT ROW		01
005	0503010027	5/8" SPRING WASHER		05
006	0503010003	1845 GREASE FITTING		04
007	0503013077	5/8" X 8" BOLT		04
008	0521066168	FRAME SEED LINE		01
009	0571012310	ROW LOCK BODY		01
010	0551015826	SEED ROW LOCK GUIDE SLEEV		01
011	0503010232	5/8" X 1.3/4" BOLT		01
012	0503010013	5/8" NUT		01
013	0503030285	HITCH PIN CLIP		01
014	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
015	0503033728	FIXED SPRING PIN		02
016	1902012568	UPPER ROCKER ARM		01
017	0503030168	HITCH PIN CLIP		03
018	0511054884	TRANSMISSION BOX	39	01
019	0501052769	BEARING WITH 17Z GEAR	40	01
020	0503010071	3/16" X 1" COTTERPIN		01
021	0501055112	MICRO GRANULATED CHAIN TENSIONER	41	01
022	0501053826	BEARING WITH 17Z GEAR	42	01
023	0561014215	BEARING COVER LOWER ROW FRAME		01
024	0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	43	01
025	0503013369	40-1 X 62 CHAIN LINK + REDUCTION		01
026	0561015801	COVER PROTECTION FRAME		01
027	0561015802	13 X 10 X 14 SLEEVE		01
028	0503010179	LOCK WASHER		02
029	0503010337	5/16" NUT		02
030	0503010178	5/16" X 7/8" BOLT		01
031	0503010421	5/16" X 1-1/2" BOLT		01


Item	Code	Description	See page	QT
032	0511052300	CONDUCTOR SUPPORT ASSY SEED	45	01
033	0501058108	5/8"AXLE	47	01
034	0531015184	FLAT WASHER		04
035	0501013352	FLAT WASHER		02
036	0503012412	5/8 UNC SELF LOCKING NUT		08
037	0503033709	CATCH HEAD LINSEED SEEDS		02
038	0571014704	UPPER AXLE		01
039	0501012140	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB	01	
02	0502012464	HOPPER TRANSMISSION LID	01	
03	0503016995	6006 BALL BEARING	02	
04	0503015895	6005 Z BALL BEARING	01	
05	0503010143	1/4" SPRING WASHER	03	
06	0503011378	M6X1X16 C S 8.8 ZN BOLT	03	
07	0503010406	501025 CLAMPING RING (FOR AXLE)	01	
08	0503010707	501030 CLAMPING RING (FOR AXLE)	02	
09	0502040856	CONICAL GEAR	01	
10	0502040857	CONICAL GEAR	01	
11	0503011105	SEAL RING	01	
12	0503010003	1845 GREASE FITTING	01	
13	0503011409	6005 Z BALL BEARING	01	
14	0503017008	SEAL RING	01	
15	0503017007	SEAL RING	02	
16	0511017907	1/8" BSPT X 6 PLUG	01	




Item	Code	Description	See page	QT
01	0503010406	501025 CLAMPING RING (FOR AXLE)		01
02	0502011697	BEARING OF THE GEAR BOX		01
03	0503011410	ROLLER BEARING		01
04	0503011105	SEAL RING		01
05	0503011953	5/16" X 1" BOLT		02
06	0501010694	FLAT WASHER		02
07	0503010179	LOCK WASHER		02
08	0503010337	5/16" NUT		02
09	0502012819	17Z GEAR WITH HEX HOLE		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501052775	ROW SEED BEARING	44	01
02	0502012028	17Z GEAR WITH HEX HOLE AXLE, 0.5"		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503010371	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521063444	CONDUCTOR SUPPORT SEED		01
02	0501011643	3/8 X 1" BOLT		02
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0551018357	5/8" X 290 BODY HEX AXLE SHORT		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		01
04	0551018358	5/8" X 74 AXLE BODY		01
05	0503011855	0.2" X 1.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0551018359	5/8" X 440 AXLE BODY		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		01
04	0551018358	5/8" X 74 AXLE BODY		01
05	0503011855	0.2" X 1.8" SPRING PIN		01




Item	Code	Description	See page	QT
001	0521065999	FRONT SHIELD		01
002	0503033672	NOZZLE WITHOUT TITANIUM		01
003	0501058972	ASSEMBLY SENSOR ELECTRONIC	50	01
004	0511051693	BASE FIXING SYSTEM	51	01
005	0503015920	3/8" UNC X 1.3/4" BOLT		04
006	0503011443	3/8" SPRING WASHER		04
007	0503010026	3/8" NUT		04
008	0501059631	DDD SEED 15 X 15 RIGHT	52	01




Item	Code	Description	See page	QT
001	0521065999	FRONT SHIELD		01
002	0503033672	NOZZLE WITHOUT TITANIUM		01
003	0501058972	ASSEMBLY SENSOR ELECTRONIC	50	01
004	0511051693	BASE FIXING SYSTEM	51	01
005	0503015920	3/8" UNC X 1.3/4" BOLT		04
006	0503011443	3/8" SPRING WASHER		04
007	0503010026	3/8" NUT		04
008	0501059632	DDD SEED 15X15 LEFT	53	01




Item	Code	Description	See page	QT
01	0503015218	SENSOR FOTOELE PM 400		01
02	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		03




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502011411	10Z CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	15" RIGHT OPENING DISC HUB	54	01
04	0501054168	15" LEFT OPENING DISC HUB	55	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	PROTECTION LID		02
07	0503014729	1/4" UNF X 1/2" BOLT		06
08	0503011441	SPRING WASHER		06
09	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13	0503011443	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511052301	SUPPORT DDD 15 RIGHT		01
15A	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
15B	0571012491	SOCKET SEED GUIDE		01
15C	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	15" RIGHT OPENING DISC HUB	54	01
04	0501054168	15" LEFT OPENING DISC HUB	55	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	PROTECTION LID		02
07	0503014729	1/4" UNF X 1/2" BOLT		06
08	0503011441	SPRING WASHER		06
09	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13	0503011443	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511052302	LH SUPPORT DDD GUIDE		01
15A	0561015592	LEFT DOUBLE DISC SUPPORT		01
15B	0571012491	SOCKET SEED GUIDE		01
15C	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502011930	OPENING DISCS HUB		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT DOUB DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011930	OPENING DISCS HUB		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
00	0511047164	DISC BLADE ASSY	56	01
01	0502012470	UPPER SUPPORT		01
02	0503010232	5/8" X 1.3/4" BOLT		04
03	0503012412	5/8 UNC SELF LOCKING NUT		04
04	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		01
05	0501058374	BOTTOM BRACKET		01
05A	0502012713	BOTTOM BRACKET		01
06	0503010002	1800 GREASE FITTING		02
07	0561014164	SUPPORT DISC AXLE		01
08	0503010361	SPRING PIN		01
09	0571012371	SLEEVE 20 X 34,93 X 130		01
10	0521063500	RIGHT ARM OF THE BLADE DISC		01
11	0521063499	LH ARM BLADE DISC		01
12	0501013475	3/4 UNC X 7.1/2 C S G.5 ZN BOLT		01
13	0503011442	3/4" SPRING WASHER		02
14	0503010014	3/4" NUT		01
15	0501011541	5/8" X 3" BOLT		02
16	0511068751	SPRING REGULACION		02
17	0501010301	FLAT WASHER		02
18	0503011445	SPRING WASHER		02
19	0503010013	5/8" NUT		02
20	0503031575	2.5"X 12" X 0.5" COMPRESSION SPRING		02
21	0551015883	SPRING GUIDES SLEVE		02
22	0503010014	3/4" NUT		04
23	0571012370	PROTECTION FRONT		01
24	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
25	0503011444	SPRING WASHER		02
26	0511052299	BLADE DISC	57	01
27	0571012224	DUST CLOAK		02
28	0503016485	BOLT 3/4		01
29	0503010335	3/4"NUT		01




Item	Code	Description	See page	QT
01	0502011562	DISC HUB		01
02	0503010276	6206 BALL BEARING		02
03	0571012223	BEARING CUBE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603027851	20" X 0.2" FLAT PLAIN DISC		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503011444	SPRING WASHER		06
12	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0511053715	SEED SYSTEM ASSY	59	01
02	0521018577	2 X 1300 AIR CONDUCTOR		01




Item	Code	Description	See page	QT
01	0511053715	SEED SYSTEM ASSY	59	01
01A	0503033009	SEED BOX WITH COVER		01
02	0501051094	ASSY SEED DISTRIBUTOR	60	01
03	0511013494	DEFLECTOR		01
04	0511013590	HEX STUD 3/8" X 3/8"		01
05	0501010694	FLAT WASHER		04
06	0503010337	5/16" NUT		01
07	0503010179	LOCK WASHER		05
08	0503010675	5/16" X 2.1/4" BOLT		01
09	0503010240	BOLT		04
10	0503016282	ALLEN BOLT		01
11	0503030083	3/8" X 3/8" X 1.6" STUD		02
12	0502012721	SEED DISC LOWER TRAIL		01
13	0502020693	SUPPORT SEED BOX		01
14	0503016283	M8 NUT HEX		01
15	0503010209	3/8" UNC BUTTERFLY NUT		03
16	0503010025	3/8" SPRING WASHER		04
17	0503016219	RING TO SOYBEANS		01
18	0503016217	SOYBEAN SEED DISC 34 OBLONG		01




Item	Code	Description	See page	QT
01	0503030381	SEED DISTRIBUTOR BOX		01
02	0502010447	TRIGGER		02
03	0501013467	KEY AXLE		01
04	0503030378	0.4" X 1.1" X 0.03" SPRING		03
05	0501013466	KEY LIMITER AXLE		01
06	0501051119	DOUBLE PULLEY ROCKER'S	61	01
07	0501013468	ROCKER ARM AXLE, OF THE PULLEY		01
08	0503030377	SCRAPER		01




Item	Code	Description	See page	QT
01	0503031129	DOUBLE PULLEY ROCKER ARM		01
02	0503031128	5Z PLASTIC DOUB PULLEY FOR SOYBEAN		02
03	0521010649	TOOTH PULLEY COUPLING SHAFT		01
04	0503011853	503050 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0511053550	DEPTH CONTROL ASSY		01
02	0511050077	WHEEL STRIPED	63	02
03	0511054333	COMPACT WHEEL RIGHT WITH BEARING	65	01
04	0511054334	COMPACT WHEEL LEFT WITH BEARING	66	01
05	0503033942	COMPACTOR WHEEL REGULATOR LID		01




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	64	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	LOCK WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEEL HUB		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	67	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	67	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0502012744	SPEED LOCK LEVER ASSY		01
02	0502012743	FAST BOLT ASSY		01
03	0571014534	FAST BOLT ADJUSTMENT		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010257	1/8" X 1" COTTERPIN		02




Item	Code	Description	See page	QT
01	0503030379	LARGER ROCKER ARM		01
02	0502060001	PLASTIC PULLEY FOR MAIZE		01
03	0503010669	FLAT WASHER		01
04	0503010667	3/16" NUT		02
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01




Item	Code	Description	See page	QT
01	0503062173	UNIVERSAL JOINT		01
02	0571019616	TRANSMISSION AXLE		01
03	0571013689	TRANSMISSION AXLE		01
04	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0521064536	LH PIVOT ARM		01
02	0561015688	PIVOT SMALLE AXLE		01
03	0501010452	5/8" X 5" BOLT		01
04	0503012412	5/8 UNC SELF LOCKING NUT		01
05	0503010002	1800 GREASE FITTING		02
06	0503032042	SHEET POLYETHYLENE		01
07	0503010814	5/16 BOLT		14
08	0521063779	PIVOT SHAFT		01
09	0503015322	BOLT 7/8		01
10	0503010408	7/8" SPRING WASHER		01




Item	Code	Description	See page	QT
01	0521064551	RH PIVOT ARM		01
02	0503032042	SHEET POLYETHYLENE		01
03	0503010814	5/16 BOLT		14
04	0561015688	PIVOT SMALLE AXLE		01
05	0503010002	1800 GREASE FITTING		02
06	0501010452	5/8" X 5" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01
08	0521063779	PIVOT SHAFT		01
09	0503010408	7/8" SPRING WASHER		01
10	0503015322	BOLT 7/8		01




Item	Code	Description	See page	QT
01	0521066553	SHIRT 114.30 X 679 USAP		01
02	0581010657	ROD 50.80 X 695 USAP		01
03	0502040747	32.54 CLEVIS CLAMP		01
04	0502011222	0.56" END CAP		01
05	0503010952	W2-2250-500 RING		01
06	0503011094	3/8" X 2" BOLT		01
07	0503010025	3/8" SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503030384	CON PLUG N-001		02
10	0581010659	2" X 4" RING SUPPORT		01
11	0503010039	D-2000 SCRAPER RING		01
12	0503018026	1870-2000-375 B GASKET		01
13	0503018024	RING BS		01
14	0503011892	O' RING, 2-346 N 3006-9B		02
15	0503011893	BACK-UP RING, 8-346		02
16	0581010658	PISTON 50,80 X 114,30		01
17	0503018164	GASKET 2500-4000-375 B (1150 AGEL)		02
18	0503010290	SELF ADJUSTING 1.1/2" UNF NUT		01
19	0503010141	2-226 N 3006-9B O'RING		01
20	0503018165	GUIDE RING W2-4500-590		01
21	0511032868	ASSY CYLINDER REPAIR KIT 50,8 X 114,3 (0511058401)		01




Item	Code	Description	See page	QT
001	0521066556	CYLINDER CASE 63,50 X 318 USAP		01
002	0581010670	CORPO HASTE 38,10 X 345		01
003	0511070058	GUIDE HIDRAULIC		01
004	0503010163	D-1500 SCRAPER RING		01
005	0502010471	63,50 MOBILE CAP		01
006	0581010668	RING SUPPORT		01
007	0503018004	RING		01
008	0503018003	GASKET		01
009	0503018163	BACK-UP RING		02
010	0503018162	O'RING		02
011	0503030385	CYLINDER PLUG N-002		02
012	0502012837	PISTON		01
013	0503018005	RING		01
014	0503011109	2-119 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0511069816	RH SEED SILO CENTRAL SUPPORT		01
02	0503060642	COVER BOX RIGHT FERTILIZER		01
03	0511061886	FERTILIZER BEAM LOCK		02
04	0511062099	FERTILIZER BEAM CLAMP		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0511069815	LR SEED SILO CENTRAL SUPPORT		01
02	0503060643	COVER BOX LEFT FERTILIZER		01
03	0511061886	FERTILIZER BEAM LOCK		02
04	0511062099	FERTILIZER BEAM CLAMP		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2" NUT		02



Item	Code	Description	See page	QT
01	0502012732	DUCT BODY		01
02	0501010942	3/8" X 1-1/4" BOLT		04
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0571013983	SEED CONDUCTOR COVER		01
07	0503011087	3/8" X 1" BOLT		02
08	0501013518	FLAT WASHER		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0502012732	DUCT BODY		01
02	0501010942	3/8" X 1-1/4" BOLT		04
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0551017635	UPPER TUBE COVER		01
07	0503013029	3/8" X 3/4" BOLT		01
08	0503010209	3/8" UNC BUTTERFLY NUT		01
09	0521064045	CONDUCTOR WITH FLANGED		01
10	0503011087	3/8" X 1" BOLT		02
11	0501013518	FLAT WASHER		02
12	0503010025	3/8" SPRING WASHER		02
13	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0521064554	LEFT WHEEL FORK		01
02	0521064543	WHEEL SUPPORT		01
03	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
04	0561019929	FLAT WASHER		01
05	0503011345	1/4" X 3-1/2" COTTERPIN		01
06	0551014511	CARRYING WEELS AXLE SLEEVE GUIDES		02
07	0551014508	FLAT WASHER		01
08	0503010010	1/4" X 2.1/2" COTTERPIN		02
09	0571015147	PIVOT SHAFT		01
10	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
11	0503010920	1/2" X 1.1/2" BOLT		04
12	0503010019	1/2" SPRING WASHER		08
13	0503010060	1/2" NUT		08
14	0551014565	CILINDER FORK SLEEVE GUIDES		01
15	0503010067	3/16" X 2.1/2" COTTER PIN		01
16	0502012731	WHEEL HOLDER		02
17	0501010322	FLAT WASHER		04
18	0503010014	3/4" NUT		04
19	0501010195	3/4" X 3-1/2" BOLT		04
20	0511054492	STUB SHAFT HUB	81	01
21	0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE	83	01
22	0503011052	1.1/4" X 0.77" CASTLE NUT		02
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	84	01
25	0501010630	1.1/2" CASTLE NUT		01
26	0503010003	1845 GREASE FITTING		03
27	0503010882	BOLT		01
28	0501010694	FLAT WASHER		02
29	0503033458	CURRENT 6 X 17 ELOS		01
30	0503010337	5/16" NUT		01
31	0511068422	WHEEL GEAR DOBLE		01


Item	Code	Description	See page	QT
32	0551018571	FLAT WASHER		02
33	0503010002	1800 GREASE FITTING		01
34	0571015153	COVER PROTECTION WHEELED LARGER		01
35	0503010849	3/8" X 1-1/2" BOLT		02
36	0503010209	3/8" UNC BUTTERFLY NUT		02
37	0503010025	3/8" SPRING WASHER		02
38	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
39	0571012483	FIXER SENSOR WHEEL		01
40	0571015148	PLATE SENSIBLES		01
41	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
42	0501010063	1/2" X 1-1/2" BOLT		02
43	0511054463	WHEEL TENSIONER SUPORT CENTRAL	85	01
44	0511054464	WHEEL FORK TENSIONER	86	02
45	0511054499	TRANSMISSION OF LARGER CENTRAL EXCHANGE	87	01
46	0503016419	50-1 CHAIN X 128 LINK + REDUCION		01
47	0503014507	CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521064554	LEFT WHEEL FORK		01
02	0521064543	WHEEL SUPPORT		01
03	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
04	0561019929	FLAT WASHER		01
05	0503011345	1/4" X 3-1/2" COTTERPIN		01
06	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
07	0551014508	FLAT WASHER		01
08	0503010010	1/4" X 2.1/2" COTTERPIN		04
09	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
10	0503010920	1/2" X 1.1/2" BOLT		04
11	0503010019	1/2" SPRING WASHER		04
12	0503010060	1/2" NUT		04
13	0502012731	WHEEL HOLDER		02
14	0503010337	5/16" NUT		01
15	0581017245	AXLE BODY		01
16	0531012874	FLAT WASHER		02
17	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	82	01
18	0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE	83	01
19	0503011052	1.1/4" X 0.77" CASTLE NUT		02
20	0501017779	32 X 60 X 4.75 FLAT WASHER		02
21	0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	84	01
22	0501010630	1.1/2" CASTLE NUT		01
23	0503010003	1845 GREASE FITTING		03
24	0503010882	BOLT		01
25	0501010694	FLAT WASHER		02
26	0503033458	CURRENT 6 X 17 ELOS		01
27	0503012334	3/4" UNC X 3.1/2" BOLT		04
28	0503011075	3/4" UNC NUT		04




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010059	33287/33462 ROLLER BEARING		01
05	0503010009	RETAINER 00573-B		01
06	0503010086	SEAL 0009B-B		01
07	0551014473	GLOVE		01
08	0503012702	KM-12 NUT		02
09	0503012703	LOCK WASHER		01
10	0503010002	1800 GREASE FITTING		01
11	0503011444	SPRING WASHER		08
12	0503011339	M22 X 1,5 X 72 BOLT		08
13	0503014048	22 X 1.5 HEX NUT		08
14	0503010363	5/16" X 1" BOLT		08
15	0521064564	30Z GEAR		01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010059	33287/33462 ROLLER BEARING		01
05	0503010009	RETAINER 00573-B		01
06	0503010086	SEAL 0009B-B		01
07	0551014473	GLOVE		01
08	0503012702	KM-12 NUT		02
09	0503012703	LOCK WASHER		01
10	0503010002	1800 GREASE FITTING		01
11	0503011444	SPRING WASHER		04
12	0503010363	5/16" X 1" BOLT		04
13	0503014048	22 X 1.5 HEX NUT		08
14	0503014050	22 X 1.5 BOLT		08
15	0511068415	PFFP-3770 SEAL GUIDE		01




Item	Code	Description	See page	QT
01	0511065331	11.75 X 17.5 HOOP WHEEL		01
02	0503015355	INNER TIRE		01
03	0503013247	PLY TIRE		01




Item	Code	Description	See page	QT
01	0521066557	CYLINDER CASE 101,60 X 352		01
02	0581010680	TURNBUCKLE 50,80 X 386		01
03	0571015629	CILINDER SPINDLE FORK		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010345	2-218 N 3006-9B O'RING		01
06	0503011094	3/8" X 2" BOLT		01
07	0503010026	3/8" NUT		01
08	0503010025	3/8" SPRING WASHER		01
09	0503030385	CYLINDER PLUG N-002		02
10	0503015633	SELEMASTER SEALING		01
11	0581010678	50,80 X 101 RING SUPPORT		01
12	0503015636	SCRAPER SEAL		01
13	0503018025	RING GUIDE		01
14	0503018026	1870-2000-375 B GASKET		01
15	0503010338	2-342 N 3006-9B O'RING		02
16	0503011061	8-342 BACK-UP RING		02
17	0502012822	101.60 END CAP		01
18	0502012820	50.80 X 101.60 PISTON		01
19	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0511054462	17Z GEAR		01
01A	0511061836	17Z GEAR		01
01B	0503011410	ROLLER BEARING		01
01C	0503011105	SEAL RING		01
02	0571015149	TIGHTENER AXLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0501010163	5/8" X 4-1/2" BOLT		01
05	0503010027	5/8" SPRING WASHER		01
06	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0511054462	17Z GEAR		01
01A	0511061836	17Z GEAR		01
01B	0503011410	ROLLER BEARING		01
01C	0503011105	SEAL RING		01
02	0571015150	SLEEVE TENSIONER WHEEL		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0503010027	5/8" SPRING WASHER		01
05	0503010013	5/8" NUT		01
06	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
07	0501012140	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521064557	SUPPORT SET TRANSMISSION WHEEL SIDE		01
02	0571015141	FIXER CENTRAL TRANSMISSION		04
03	0571015151	SUPPORT BEARING		01
04	0521061795	27Z GEAR		01
05	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	88	01
06	0503010025	3/8" SPRING WASHER		08
07	0503010026	3/8" NUT		08
08	0503010019	1/2" SPRING WASHER		03
09	0503010060	1/2" NUT		03
10	0503010337	5/16" NUT		02
11	0503011953	5/16" X 1" BOLT		02
12	0503010179	LOCK WASHER		02
13	0503010707	501030 CLAMPING RING (FOR AXLE)		02
14	0503010741	1/2" X 2-3/4" BOLT		03
15	0511054461	STRETCHER TOP TRANSMISSION SWIRLED	89	02



Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		02
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0521055499	GEAR WITH NATIONAL BEARING		01
01A	0511061836	17Z GEAR		01
01B	0503019356	BEARING 6005 2RS1		01
01C	0503011105	SEAL RING		01
02	0571015146	TIGHTENER AXLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0501011541	5/8" X 3" BOLT		01
05	0501012140	FLAT WASHER		01
06	0503010027	5/8" SPRING WASHER		01
07	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0521064562	CENTRAL GEAR BOX SUPPORT		01
02	0511056179	CLUTCH WITH CARDAN CENTRAL		01
03	0511069512	20Z GEAR		01
04	0501056271	GEARBOX CLOSED BEARING	94	04
05	0571015170	CENTRAL GEAR BOX DRIVER AXLE		01
06	0521063460	20Z GEAR		03
07	0503030303	SUPPORT WASHER		04
08	0571015169	FLANGE WASHER		02
09	0511052432	DOUBLE BEARING WITH ASSY FLANGE		01
09A	0521063461	BEARING DOUBLE WITH FLANGE		01
09B	0503013462	BEARING WITH BALL BEARING		02
09C	0503011105	SEAL RING		01
10	0571015171	CENTRAL GEAR BOX DRIVEN AXLE		01
11	0511054476	RIGHT TENSIONER CENTRAL EXCHANGE	99	01
11A	0501056573	17Z GEAR ASSY	100	01
11AA	0502012367	17Z X P 1/2" GEAR INTERM		01
11AB	0503012882	BEARING		01
11AC	0503011945	503050 CLAMPING RING (FOR AXLE)		01
11B	0571015168	SLEEVE NYLON Ø21 X Ø31,75 X 20		01
11C	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01
11D	0503010019	1/2" SPRING WASHER		01
11E	0503010060	1/2" NUT		01
11F	0511017302	FLAT WASHER		01
12	0511054489	LEFT TENSIONER CENTRAL EXCHANGE		01
12A	0501056573	17Z GEAR ASSY	100	01
12AA	0502012367	17Z X P 1/2" GEAR INTERM		01
12AB	0503012882	BEARING		01
12AC	0503011945	503050 CLAMPING RING (FOR AXLE)		01
12B	0503010019	1/2" SPRING WASHER		01
12C	0503010060	1/2" NUT		01
12D	0571015167	SLEEVE NYLON Ø21 X Ø31,75 X 36,50		01


Item	Code	Description	See page	QT
12E	0503010479	BOLT		01
12F	0511017302	FLAT WASHER		01
13	0551018585	CENTRAL GEAR BOX COVER SLEEVE		02
14	0571015172	CENTRAL GEAR BOX COVER		01
15	0503010179	LOCK WASHER		13
16	0503010337	5/16" NUT		13
17	0503010371	5/16" X 1" BOLT		02
18	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
19	0503013542	M10 SPRING WASHER		04
20	0503011953	5/16" X 1" BOLT		08
21	0501010694	FLAT WASHER		12
22	0503010292	0.2" X 1.6" SPRING PIN		05
23	0503010395	1/2" X 1-1/4" BOLT		02
24	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		02
25	0503012389	1/2 BALL		02
26	0503010060	1/2" NUT		06
27	0501052778	CHAIN TENSIONER ASSY	116	01
27A	0511061794	CHAIN TENSIONER		01
27B	0503031805	11Z 1/2" GEAR		02
27C	0503010302	501019 SEAL RING		02
27D	0503031367	SPRING		01
28	0502011758	REAR TENSIONER LEVER		01
29	0503010002	1800 GREASE FITTING		01
30	0503010172	M10 X 1,5 X 25 BOLT		04
31	0503010365	NUT		02
32	0503010025	3/8" SPRING WASHER		03
33	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		02
34	0503011268	3/8" X 2-1/2" BOLT		01
35	0503010026	3/8" NUT		01
36	0501048790	AXLE WITH RING	117	01
36A	0521012476	GEAR BOX LEVER AXLE		01
36B	0503031369	LINK		01
37	0503010683	0,2" X 1,2" SPRING PIN		01
38	0503010019	1/2" SPRING WASHER		04
39	0511017302	FLAT WASHER		08
40	0503011082	C1/2" X 1.3/4" SCREW		04
41	0503012390	40-1 CHAIN X 93 LINK + MENDING		01
42	0503012204	40-1 CHAIN X 82 LINK + RED		01
43	0511064536	28Z GEAR		01
44	0521014167	CONE LOCK		01
45	0551011728	3770 PULLER AXLE SEED ROW		01
46	0503010386	CABLE		01
47	0502040868	GEAR CONE REPLACEMENT		02




Item	Code	Description	See page	QT
01	0511053043	DEVIATION GREATER ASSY	92	01
02	0511054252	DEVIATION LOWER REAR	93	01
03	0503013254	40-1X CHAINX 138 LINK + MENDING + REDUCION		01
04	0503013369	40-1 X 62 CHAIN LINK + REDUCTION		01




Item	Code	Description	See page	QT
01	0521063899	DEVIATION GREATER CENTRAL CHAIN		01
02	0501056271	GEARBOX CLOSED BEARING	94	01
03	0551018612	3/4" SQUARE SHAFT		01
04	0501056444	BEARING WITH ROLLING	95	01
05	0503030303	SUPPORT WASHER		03
06	0511065209	20Z GEAR		02
07	0511053050	CHAIN TENSIONER	97	01
08	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
09	0503010025	3/8" SPRING WASHER		01
10	0503010237	3/8" X 1" BOLT		01
11	0503010292	0.2" X 1.6" SPRING PIN		02
12	0551015037	5/8" UNC X 210 X 198 FASTENER		02
13	0503012412	5/8 UNC SELF LOCKING NUT		04
14	0503011953	5/16" X 1" BOLT		04
15	0501010694	FLAT WASHER		04
16	0503010179	LOCK WASHER		04
17	0503010337	5/16" NUT		04
18	0511059854	STRETCHER OFFSET HIGHER FRONT	98	01
19	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
001	0521062840	DEVIATION CHAIN LOWER REAR		01
002	0511053045	TENSIONER REAR OFFSET HIGHER	96	02
003	0511053050	CHAIN TENSIONER	97	01
004	0503033709	CATCH HEAD LINSEED SEEDS		01
005	0503012412	5/8 UNC SELF LOCKING NUT		02
006	0511054476	RIGHT TENSIONER CENTRAL EXCHANGE	99	01
007	0501012140	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056573	17Z GEAR ASSY	100	01
01A	0502012367	17Z X P 1/2" GEAR INTERM		01
01B	0503012882	BEARING		01
01C	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02	0521010454	0.83" X 1.25" X 0.79" SLEEVE		01
03	0503010905	1/2" X 2-1/4" BOLT		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0571013442	TIGHTENER AXLE		01
02	0503010019	1/2" SPRING WASHER		01
03	0503010060	1/2" NUT		01
04	0503031805	1 1/2" GEAR		01
05	0503010004	1890 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501056573	17Z GEAR ASSY	100	01
02	0503010019	1/2" SPRING WASHER		01
03	0503010060	1/2" NUT		01
04	0511017302	FLAT WASHER		01
05	0551018562	21 X 31,75 X 26,5 SLEEVE		01
06	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01



Item	Code	Description	See page	QT
01	0501056573	17Z GEAR ASSY	100	01
01A	0502012367	17Z X P 1/2" GEAR INTERM		01
01B	0503012882	BEARING		01
01C	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02	0571015168	SLEEVE NYLON Ø21 X Ø31,75 X 20		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0511053310	WHEEL HOSE ASSY	102	01
02	0511051368	ARTICULATION HOSE GAME	103	01
03	0511053307	LIFT HOSE GAME	104	01
04	0511051369	HYDRAULIC HOSE MARKER GAME	105	01
05	0501058101	DOUBLE MOTOR ASSY		01
06	0501058100	ARTICULATE VALVE		02
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		04
08	0501010694	FLAT WASHER		04
09	0503010143	1/4" SPRING WASHER		04
10	0503010144	1/4" NUT		04
11	0503010848	5/16" X 3.1/2" BOLT		04
12	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		08
13	0511017303	FLAT WASHER		08
14	0503010179	LOCK WASHER		04
15	0503010143	1/4" SPRING WASHER		08
16	0503010337	5/16" NUT		04
17	0503010144	1/4" NUT		08
18	0511053313	BLOCK COMMAND	106	01
19	0571013760	SUPPORT BLOCK HYDRAULIC		01
20	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
21	0503010025	3/8" SPRING WASHER		02
22	0503010026	3/8" NUT		02
23	0501054649	HBM SEQUENTIAL VALVE	107	01
24	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
25	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
26	0503010025	3/8" SPRING WASHER		02
27	0551018640	TUBE FIXER UPPER SUPPORT		04
28	0503010237	3/8" X 1" BOLT		08
29	0503010025	3/8" SPRING WASHER		08
30	0503010026	3/8" NUT		08
31	0521062359	FASTENER LOWER DUCT CENTRAL		04


Item	Code	Description	See page	QT
32	0551018635	TUBE UPPER FASTENER		04
33	0503011268	3/8" X 2-1/2" BOLT		08
34	0503010025	3/8" SPRING WASHER		08
35	0503010026	3/8" NUT		08
36	0511068881	1000 OIL TUBE		08
37	0561019643	25 X 58 X 1000 GUTTER		02
38	0503011268	3/8" X 2-1/2" BOLT		04
39	0503010025	3/8" SPRING WASHER		04
40	0503010026	3/8" NUT		04
41	0511069523	1360 OIL TUBE		02
42	0511069524	3052 OIL TUBE		01
43	0503012412	5/8 UNC SELF LOCKING NUT		08
44	0503033709	CATCH HEAD LINSEED SEEDS		04
45	0551018637	SMALEE FASTENER TUBE UPPER		04
46	0511069527	FIXER SMALLE SUPPORT		04




Item	Code	Description	See page	QT
01	0501081816	HOSE 3/8 X 800 TR-TR	05	
02	0501081823	HOSE 3/8 X 700 TR-TR	02	
03	0501081836	HOSE 3/8 X 700 TC-TC	02	
04	0501081837	3/8 X 700 TR-TC HOSE	02	
05	0501081838	3/8 X 1000 TR-TC HOSE	03	
06	0501081839	HOSE 3/8 X 1200 TR-TC	01	
07	0501081830	HOSE 3/8 X 1000 TC-TC	03	
08	0521052556	HOSE 1/2 X 14500 TR-TM BLACK / BLUE	01	
08A	0501081854	HOSE 1/2 X 14500 TR-TM	01	
08B	0503034492	HYDRAULIC HOSE GRIP (BLACK)	01	
08C	0503034494	HYDRAULIC HOSE GRIP (BLUE)	01	
08D	0503018952	PLASTIC BOLT	06	
09	0521052555	HOSE 1/2 X 14500 TC-TM BLACK / RED	01	
09A	0501081872	HOSE 1/2 X 14500 TC-TM	01	
09B	0503034492	HYDRAULIC HOSE GRIP (BLACK)	01	
09C	0503034495	HYDRAULIC HOSE GRIP (RED)	01	
09D	0503018952	PLASTIC BOLT	06	
10	0501081843	HOSE 3/8 X 750 TR-TC	02	
11	0501081820	3/8 X 1700 TR-TC HOSE	02	
12	0501081840	HOSE 3/8 X 1200 TC-TC	01	




Item	Code	Description	See page	QT
01	0521052579	3/8 X 14500 TR-TM HOSE BROWN / RED		01
01A	0501081855	HOSE 3/8 X 14500 TR-TM		01
01B	0503034490	HYDRAULIC HOSE GRIP (BROWN)		01
01C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01D	0503018952	PLASTIC BOLT		06
02	0521052578	1/2 X 14500 TR-TM HOSE		01
02A	0501081855	HOSE 3/8 X 14500 TR-TM		01
02B	0503034490	HYDRAULIC HOSE GRIP (BROWN)		01
02C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
02D	0503018952	PLASTIC BOLT		06
03	0501081813	HOSE 1/2 X 1400 TC-TC		01
04	0501081814	HOSE 1/2 X 900 TC-TC		03
05	0501081815	HOSE 3/8 X 1500 TC-TC		01
06	0501081812	HOSE 3/8 X 1370 TC-TC		01
07	0521052583	3/8 X 3200 TR-TM HOSE BROWN / RED		01
07A	0501081848	HOSE 3/8 X 3200 TR-TM		01
07B	0503034490	HYDRAULIC HOSE GRIP (BROWN)		01
07C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
07D	0503018952	PLASTIC BOLT		06
08	0521052582	3/8 X 3200 TR-TM HOSE BROWN / BLUE		01
08A	0501081848	HOSE 3/8 X 3200 TR-TM		01
08B	0503034490	HYDRAULIC HOSE GRIP (BROWN)		01
08C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
08D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0501081874	HOSE		02
02	0501081843	HOSE 3/8 X 750 TR-TC		02
03	0501080123	1/2 X 800 TR-TC HOSE ASSY		01




Item	Code	Description	See page	QT
01	0501081851	3/8 X 1400 TR-TC HOSE		02
02	0501081816	HOSE 3/8 X 800 TR-TR		04
03	0501081820	3/8 X 1700 TR-TC HOSE		02
04	0501081856	HOSE 3/8 X 14500 TC-TM		02
04A	0521052576	HOSE 3/8 X 14500 TC-TM PURPLE / BLUE		02
04AA	0501081856	HOSE 3/8 X 14500 TC-TM		01
04AB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
04AC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
04AD	0503018952	PLASTIC BOLT		06
04B	0521052577	HOSE 3/8 X 14500 TC-TM PURPLE / RED		02
04BA	0501081856	HOSE 3/8 X 14500 TC-TM		01
04BB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
04BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
04BD	0503018952	PLASTIC BOLT		06
05	0501081853	HOSE 3/8 X 1400 TR-TR		04




Item	Code	Description	See page	QT
00	0511053313	BLOCK COMMAND	106	01
01	0503016332	BLOCK COMMAND		01
02	0503010190	2-114 N 3006-9B O'RING		04
03	0501010617	3/4" NIPPLE		04
04	0503010045	O'RING		03
05	0501010590	NIPPLE		01
06	0511010111	7/8" NIPPLE		02
07	0503010371	5/16" X 1" BOLT		03
08	0503010179	LOCK WASHER		03




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0511053346	MINI MOUNTED ELECTRONIC SYSTEM KIT	109	01
02	0511052471	ELECTRICAL COMPONENTS KIT (MINOR)		01




Item	Code	Description	See page	QT
001	0503016466	WHIP FEEDING MACHINE		01
002	0503016469	WHIP COMMAND MACHINE 14M		01
003	0503016474	CONTROL PANEL		01
004	0503062308	WHIP ASSEMBLY WITH OUTLET CLUTCH VALVE		01
005	0503016477	SENSOR CAPACITIVE SPIRALED		01




Item	Code	Description	See page	QT
01	0503017602	MONITOR PLANT PM400		01
02	0503017578	SINGLE CABLE PM400		01
03	0503062322	MONITOR CABLE PM400 29 LINES		01
04	0503016234	TRIMBLE FIXING WINDOW		01
05	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
06	0571012196	MOUNTING BRACKET PM 400		01
07	0503017443	ANTENNA GPS PM 400		01
08	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		435
09	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
10	0503010669	FLAT WASHER		02
11	0503010668	3/16" SPRING WASHER		02
12	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0503016472	WHIP FEEDING TRACTOR		01
02	0503016473	WHIP COMMAND TRACTOR		01
03	0503016475	CONTROL PANEL		01
04	0561016352	ELECTRICAL BOX PLATE FIXING		01
05	3114820001	BOLT PLASTIC COIL		02



Item	Code	Description	See page	QT
01	0511069824	LH SEED BOX SIDE SUPPORT		01
02	0503060641	LEFT FERTILIZER HOPPER WITH LID		01
03	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02
04	0503010849	3/8" X 1-1/2" BOLT		04
05	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
06	0503010025	3/8" SPRING WASHER		04
07	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0561014687	LH PLATFORM SUPPORT		01
02	0503010239	BOLT 1/2 UNC X 1.1/2 C S G.2 ZN		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0521064543	WHEEL SUPPORT		01
02	0561019929	FLAT WASHER		01
03	0503010523	1/4" X 2" COTTERPIN		03
04	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
05	0551014508	FLAT WASHER		01
06	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
07	0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	84	01
08	0503010920	1/2" X 1.1/2" BOLT		04
09	0503010019	1/2" SPRING WASHER		04
10	0503010060	1/2" NUT		04
11	0502012731	WHEEL HOLDER		02
12	0503010002	1800 GREASE FITTING		04
13	0521064550	CARRYING-WHEELS FORK		01
14	0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	23	01
15	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
16	0511054491	WHEEL WITHOUT TIRE WITH 27Z GEAR	24	01
17	0511068422	WHEEL GEAR DOBLE		01
18	0551018571	FLAT WASHER		02
19	0511054463	WHEEL TENSIONER SUPORT CENTRAL	85	01
20	0511054464	WHEEL FORK TENSIONER	86	02
21	0561019941	RIGHT PROTECTIVE CAP WHEELS		01
22	0503010849	3/8" X 1-1/2" BOLT		02
23	0501013518	FLAT WASHER		02
24	0503010025	3/8" SPRING WASHER		02
25	0503010209	3/8" UNC BUTTERFLY NUT		02
26	0503016419	50-1 CHAIN X 128 LINK + REDUCION		01
27	0501010630	1.1/2" CASTLE NUT		01
28	0501017779	32 X 60 X 4.75 FLAT WASHER		02
29	0503011052	1.1/4" X 0.77" CASTLE NUT		02
30	0503014857	50-1 X CHAIN X 122 LINK + REDUCION		01
31	0511054501	TRANSMISSION CAMBIO LEFT	26	01

Item	Code	Description	See page	QT
32	0503033335	CURRENT 6 X 21 ELOS		01
32.	0503014857	50-1 X CHAIN X 122 LINK + REDUCION		01
33	0503010882	BOLT		01
34	0501010694	FLAT WASHER		02
35	0503010337	5/16" NUT		01
36	0581017245	AXLE BODY		01
37	0531012874	FLAT WASHER		02
38	0503012334	3/4" UNC X 3.1/2" BOLT		04
39	0503011075	3/4" UNC NUT		04
40	0503010571	1/4" X 1.1/2 COTTERPIN		02




Item	Code	Description	See page	QT
01	0521061419	LEFT GEAR BOX SUPPORT		01
02	0551015037	5/8" UNC X 210 X 198 FASTENER		02
03	0503010027	5/8" SPRING WASHER		04
04	0503010013	5/8" NUT		04
05	0501056271	GEARBOX CLOSED BEARING	94	03
06	0551018627	SIDE GEAR BOX DRIVER AXLE		01
07	0551018581	CENTRAL GEAR BOX DRIVEN AXLE		01
08	0503010292	0.2" X 1.6" SPRING PIN		05
09	0501056444	BEARING WITH ROLLING	95	01
10	0502011758	REAR TENSIONER LEVER		01
11	0501052778	CHAIN TENSIONER ASSY	116	01
12	0503010002	1800 GREASE FITTING		01
13	0503012204	40-1 CHAIN X 82 LINK + RED		01
14	0503030303	SUPPORT WASHER		04
15	0502040868	GEAR CONE REPLACEMENT		02
16	0503010395	1/2" X 1-1/4" BOLT		02
17	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		02
18	0503012389	1/2 BALL		02
19	0503010060	1/2" NUT		02
20	0511064536	28Z GEAR		01
21	0503014854	40-1 CHAIN X 135 LINK + MENDING		01
22	0521014167	CONE LOCK		01
23	0501054221	SEED BEARING INTERM LINE		02
24	0551018630	CARDAN SHAFT GUIDES SLEEVE		01
25	0551011625	PROTECTION COVER		01
26	0503010386	CABLE		01
27	0503010179	LOCK WASHER		01
28	0503010337	5/16" NUT		01
29	0551018629	GEAR BOX COVER FIXER ROD		01
30	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
31	0503010257	1/8" X 1" COTTERPIN		02


Item	Code	Description	See page	QT
32	0501048790	AXLE WITH RING	117	01
33	0503011953	5/16" X 1" BOLT		08
34	0501010694	FLAT WASHER		08
35	0503010179	LOCK WASHER		08
36	0503010337	5/16" NUT		08
37	0503011268	3/8" X 2-1/2" BOLT		01
38	0503013357	3/8" SELF-ADJUSTING NUT		01



Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503010302	501019 SEAL RING		02
03	0503031805	11Z 1/2" GEAR		02
04	0503031367	SPRING		01
05	0511061794	CHAIN TENSIONER		01



Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

