

ROW CROP PLANTERS

**PST DUO FLEX SUPREMA P.P - FRAME 5950 -
CSU - CBA - APT ISOBUS - SEED -
FERTILIZER - MS**

Code: 0501092970

Series: S-0119

Revision: 00

Date Revision: MAIO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111250093	PST DUO FLEX SUP PP 5950/12E500 ESPECIAL S-0119

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.

INDEX

0909095755	ASSY FRAME	1
0521054578	FRAME WITH ARTICULATION 5950	2
0521054572	RIGHT FRAME WITH WHEELED AXLE 5950	3
0521054573	FRAME LEFT WITH SHAFT WHEELED 5950	4
0511058667	SPRING FLOW ENSEMBLY	5
0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	6
0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	7
0521058394	WHEEL WITH PNEUME	8
0521055244	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	9
0521054561	CYLINDER ASSEMBLY	10
0511058406	HYDRAULIC CYLINDER	11
0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	12
0501054694	FLOW DIVIDING VALVE ASSY	13
0909095186	HEADER ASSY	14
0511055096	TRACTOR HITCH	15
0511053179	TRACTOR HITCH AXLE	16
0521053310	LEFT EXTENSION HEADER 36.00 - 4880/5720/5950	17
0521053313	LEFT EXTENSION HEADER 36.00 - 5340	18
0521053320	LEFT EXTENSION HEADER 36.00 - 6350	19
0521053318	LEFT EXTENSION HEADER 36.00 - 6850	20
0521053311	RIGHT EXTENSOR HEAD 36,00 - 4880/5720/5950	21
0521053312	RIGHT EXTENSOR HEAD 36,00 - 5340	22
0521053321	RIGHT EXTENSOR HEAD 36,00 - 6350	23
0521053319	RIGHT EXTENSOR HEAD 36,00 - 6850	24
0511052311	3 POINT TURNBUCKLE	25
0511057817	SUPPORT HOSE	26
0521055528	SILO FERTILIZER ASSY 5950 - APT	27
0521055526	SUPPORT RIGHT FERTILIZER WITH DISTRIBUTOR - 5950 APT	28
0521055527	SUPPORT SILO LEFT FERTILIZER WITH DISTRIBUTOR - 5950 APT	29
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	30
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	31
0521054564	PLATFORM ASSEMBLY 5950	32
0521054568	HANDRAIL ASSY 5950	33
0511054971	RESTING ASSEMBLY	34
0511056536	ASSEMBLY LADDER	35
0531050855	LABEL ASSY FOR CSU / APT	36
0521054582	REAR LIGHTING ASSEMBLY 5720/5950	37
0521052792	MOUNTED REAR LIGHT	38
0909095190	ASSY HEX AXLE	39
0521055214	BEARING GEAR WITH	40
0521055215	DOUBLE TRANSMISSION BEARING	41
0521054676	TURBINE ASSEMBLY	42
0521050262	RIGHT AIR DISTRIBUTOR	43
0521050263	LEFT AIR DISTRIBUTOR	44
0511059319	AIR FIXING SUPPORT	45
0511059406	TURBINE P.P MOUNTED	46
0521050154	TURBINE P.P WITH HOLE	47
0521052549	CLAMP	48
0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	49
0511058723	ASSEMBLY CSU C3 SEMI MOUNTED 5950	50
0511058724	ASSEMBLY CSU C3 2BOXES 7/6 12E500	51
0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	52
0521051931	LH SUPPORT TOWER SILO	53




MARCHESAN

INDEX

0521051927	TOWER SUPPORT HOPPER	54
0521054586	ASSY MANUAL DOOR	55
0531050277	ASSY ISO 4C/12L 45/50 MS - EE	56
0511056972	FILTER HYDAC	57
0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	58
0531050854	MECHANICAL ASSEMBLY APT ISO 4C SEED / FERTILIZER	59
0511059348	APT ASSY MODULE BOX	60
0521054181	TOOL BOX ASSEMBLY	61
0521054525	CONTAINER WATER TANK	62
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	63
0909095756	ASSY SEED/FERTILIZER LINE	64
0521059770	FRONT SEED LINE SHORT WITH ELLIOTT CABLE	65
0521059769	LONG SEED LINE FRONT WITH ELLIOTT CABLE	66
0521059771	FRONT SM LONG SEED LINE WITH ELLIOTT CABLE	67
0521053577	BEARING BOX	68
0521058028	LEFT REAR LINE SEED PP CBA/CSU 3 NAC	69
0521058027	RIGHT REAR LINE SEED PP CBA/CSU 3 NAC	70
0521055872	RIGHT DOUBLE DISK FAST EXCHANGE SEED 15X15	71
0521055873	LEFT DOUBLE DISK FAST EXCHANGE SEED 15X15	72
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	73
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	74
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	75
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	76
0521052015	ASSY P.P V-SET2 SUPREME STEEL CABLE CSU	77
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	78
0531050978	DEPTH CONTROL WITH FAST ANGLE REGULATING AXIS	79
0531050980	SEM SEMI-ASSEMBLED CONTROL WITHOUT LUBRICATION	80
0501052297	DEPTH WHEELS REGULATOR ASSY	81
0531050975	LEFT ARM WHEELS DEPTH WITH CUBE WITHOUT LUBRICATION	82
0531050973	RIGHT ARM DEPTH WHEEL WITH HUB WITHOUT LUBRICATION	83
0531050974	CUBE CONTROL DEPTH WITHOUT LUBRICATION	84
0521055033	COMPACTADOR BODY	85
0521055017	RIGHT COMPACTOR WHEEL	86
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	87
0521054990	LEFT COMPACTOR WHEEL	88
0511055819	DEPTH WHIT AROS BAND	89
0521054811	FERTILIZER SHORT LINE	90
0521054812	LONG FERTILIZER LINE	91
0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION CONICAL BEARING	92
0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION CONICAL BEARING	93
0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	94
0521053697	CUTTING DISK BOX	95
0521054906	SPRING ASSY FERTILIZER	96
0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	97
0521054769	LEFT FERTILIZER WITH SUPPORT	98
0521054764	DDD RIGHT FERTILIZER	99
0521054765	DDD LEFT FERTILIZER	100
0521054761	LEFT LOW CUBE	101
0521054760	DOWN LOW CUBE	102
0521050525	FIXER FERTILIZER CONDUCTOR	103

ASSY FRAME

0909095755




Item	Code	Description	See page	QT
01	0521054578	FRAME WITH ARTICULATION 5950	2	01
02	0521064285	LOCK LOWER FRAME		01
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		01
04	0503010002	1800 GREASE FITTING		01
05	0503010003	1845 GREASE FITTING		05
06	0503010004	1890 GREASE FITTING		02
07	0511058667	SPRING FLOW ENSEMBLY	5	01
08	0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	6	06
09	0521054561	CYLINDER ASSEMBLY	10	01
10	0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	12	01
11	0909095186	HEADER ASSY	14	01
12	0511057817	SUPPORT HOSE	26	01
13	0521055528	SILO FERTILIZER ASSY 5950 - APT	27	01
14	0521054564	PLATFORM ASSEMBLY 5950	32	01
15	0521054568	HANDRAIL ASSY 5950	33	01
16	0511054971	RESTING ASSEMBLY	34	04
17	0511056536	ASSEMBLY LADDER	35	02
18	0531050855	LABEL ASSY FOR CSU / APT	36	01
19	0521054582	REAR LIGHTING ASSEMBLY 5720/5950	37	01
20	0909095190	ASSY HEX AXLE	39	01
21	0503010246	CLAMP		12
22	0521054676	TURBINE ASSEMBLY	42	01
23	0511058723	ASSEMBLY CSU C3 SEMI MOUNTED 5950	50	01
24	0521054586	ASSY MANUAL DOOR	55	01
25	0531050277	ASSY ISO 4C/12L 45/50 MS - EE	56	01
26	0531050854	MECHANICAL ASSEMBLY APT ISO 4C SEED / FERTILIZER	59	01
27	0501065677	STRUT		02
28	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
29	0501047895	ROD STOP		02
30	0501047885	ROD STOP		02


ASSY FRAME

0909095755


Item	Code	Description	See page	QT
31	0501047886	ROD STOP		02
32	0501047887	ROD STOP		02
33	0503032624	SILO FERTILIZER GUTTER		07
34	0521065613	HOSE HOLDER		01
35	0503011953	5/16" X 1" BOLT		02
36	0503013816	5/16" LOCKNUT		02
37	0521013022	TRANSPORT LOCK		02
38	0501068994	0.3" X 3.1" LOCK PIN		02
39	0503030168	HAIR PIN		02
40	0521054181	TOOL BOX ASSEMBLY	61	01
41	0521054525	CONTAINER WATER TANK	62	01
42	0503019262	SOAP DISH VACUUM		01
43	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	63	01
44	0503010045	O'RING		01
45	0541010080	TERMINAL R.1 / 2 NPT		01
46	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
47	0581013729	NIPLE 1 / 2NPT		01
48	0909098944	ASSY SEED/FERTILIZER LINE		13




Item	Code	Description	See page	QT
01	0521054572	RIGHT FRAME WITH WHEELED AXLE 5950	3	01
02	0521054573	FRAME LEFT WITH SHAFT WHEELED 5950	4	01
03	0501110791	DRIVER WHEEL HUB		01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	NUT		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581018960	TROUGH 24 X 50 X 1855		02
20	0581018961	TROUGH 24 X 50 X 945		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8" SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
01	0521068946	RIGHT FRAME 5950		01
02	0521069430	RIGHT SIDE RIGHT ARTICULATED AXLE 5950		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521068947	LEFT FRAME 5950		01
02	0521069431	LEFT ARTICULATED AXLE 5950		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		06
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		12
03	0501012140	FLAT WASHER		24




Item	Code	Description	See page	QT
01	0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	7	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8" SPRING WASHER		02
08	0591010589	BODY LOCK WHEEL		02
09	0521058394	WHEEL WITH PNEUME	8	01




Item	Code	Description	See page	QT
01	0503063172	WHEEL		01
02	0521055244	WHEELED WITHOUT TRANSMISSION WITHOUT 9 TIRE	9	01




Item	Code	Description	See page	QT
01	0521012185	TRANSM AXLE CARRYING-WHEEL		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	11	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521015501	COUPLING SHAFT		02
04	0503010523	1/4" X 2" COTTERPIN		04
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
06	0531012565	SLEEVE 16,3X 30 X 88		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01



Item	Code	Description	See page	QT
01	0571017027	SOPORTE VALV		01
02	0503010920	1/2" X 1.1/2" BOLT		02
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0501054694	FLOW DIVIDING VALVE ASSY	13	01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	63	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		02
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057089	HOSE KIT SYSTEM HYDRAULIC		01
19A	0501080045	3/8" X 850 TR-TR HOSE		01
19B	0501080999	3/8" X 39" TC-TC HOSE		01
19C	0501081987	HOSE 3/8 X 1550 TR-TC		01
19D	0501081986	HOSE 3/8 X 1550 TC-TC		01
20	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
20A	0501080185	HOSE 1/2 X 4000 TR-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
20C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20D	0503018952	PLASTIC BOLT		06
21	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
21A	0501080185	HOSE 1/2 X 4000 TR-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01


Item	Code	Description	See page	QT
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503030923	3/4" UNF X 13/16UN OFS X 40 NIPPLE		03
03	0503010190	2-114 N 3006-9B O'RING		03

HEADER ASSY

0909095186



Item	Code	Description	See page	4880	5340	5950	6350	6850
01	0521068561	LONG COUPLING HEADER		001	001	001	001	001
02	0511055096	TRACTOR HITCH	15	001	001	001	001	001
03	0511053179	TRACTOR HITCH AXLE	16	001	001	001	001	001
03A	0521064036	TRACTOR HITCH AXLE		001	001	001	001	001
03B	0503030012	HAIR PIN		001	001	001	001	001
04	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		001	001	001	001	001
05	0503014120	CHAIN		001	001	001	001	001
06	0503014321	CABLE STEEL SHACKLE		002	002	002	002	002
07	0571010661	PIVOT SHAFT		001	001	001	001	001
08	0503010010	1/4" X 2.1/2" COTTERPIN		002	002	002	002	002
09	0521064203	EAR PIVOT DRAWBAR		001	001	001	001	001
10	0521053310	LEFT EXTENSION HEADER 36.00 - 4880/5720/5950	17	001	000	001	000	000
10.	0521053313	LEFT EXTENSION HEADER 36.00 - 5340	18	000	001	000	000	000
10..	0521053320	LEFT EXTENSION HEADER 36.00 - 6350	19	000	000	000	001	000
10...	0521053318	LEFT EXTENSION HEADER 36.00 - 6850	20	000	000	000	000	001
11	0501010500	3/4"X3"BOLT		002	002	002	002	002
12	0503010023	3/4" SPRING WASHER		002	002	002	002	002
13	0503010014	3/4" NUT		002	002	002	002	002
14	0571019949	JUNCTION SHAFT		002	002	002	002	002
15	0503030119	LOCK PIN		002	002	002	002	002
16	0521053311	RIGHT EXTENSOR HEAD 36.00 - 4880/5720/5950	21	001	000	001	000	000
16.	0521053312	RIGHT EXTENSOR HEAD 36.00 - 5340	22	000	001	000	000	000
16..	0521053321	RIGHT EXTENSOR HEAD 36.00 - 6350	23	000	000	000	001	000
16...	0521053319	RIGHT EXTENSOR HEAD 36.00 - 6850	24	000	000	000	000	001
17	0521010572	0.9" X 2.9" COUPLING SHAFT		001	001	001	001	001
18	0503030085	LOCK PIN		004	004	004	004	004
19	0521063528	EXTENDING FIXER		001	001	001	001	001
20	0501010171	BOLT 1 UNC X 3.1/2 C S G.5		003	003	003	003	003
21	0503010012	1" SPRING WASHER		003	003	003	003	003
22	0501010059	1.5/8 NUT		003	003	003	003	003
23	0521062916	LEFT FRENCH HAND		001	001	001	001	001




HEADER ASSY

0909095186


Item	Code	Description	See page	4880	5340	5950	6350	6850
24	0521010585	0.9" X 5.9" COUPLING SHAFT		001	001	001	001	001
25	0511052311	3 POINT TURNBUCKLE	25	001	001	001	001	001
26	0521012532	0.9" X 3.9" COUPLING SHAFT		001	001	001	001	001
27	0521010582	COUPLING SHAFT		001	001	001	001	001
28	0521063529	LOCK AXLE		001	001	001	001	001
29	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		001	001	001	001	001

TRACTOR HITCH


0511055096




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HAIR PIN		01




Item	Code	Description	See page	QT
01	0521064426	POINT FIXER EXTENDING LEFT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064426	POINT FIXER EXTENDING LEFT		01
02	0521065193	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064238	POINT FIXER EXTENDING LEFT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064238	POINT FIXER EXTENDING LEFT		01
02	0521065193	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064425	POINT FIXER EXTENDING RIGHT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0521064425	POINT FIXER EXTENDING RIGHT		01
02	0521065193	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064237	POINT FIXER EXTENDING RIGHT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064237	POINT FIXER EXTENDING RIGHT		01
02	0521065193	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02

3 POINT TURNBUCKLE


0511052311




Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0571012279	JACK RIGHT		01
03	0571012280	JACK LEFT		01
04	0531010264	SIDE RATCHET		02
05	0521018500	SHAFT LEVER EXTENSOR		01
06	0511061881	RATCHET FOLLOWER		01
07	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
08	0503011179	3/8" X 2-1/4" BOLT		05
09	0503011443	3/8" SPRING WASHER		05
10	0503010026	3/8" NUT		05
11	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0521055526	SUPPORT RIGHT FERTILIZER WITH DISTRIBUTOR - 5950 APT	28	01
02	0521055527	SUPPORT SILO LEFT FERTILIZER WITH DISTRIBUTOR - 5950 APT	29	01
03	0503062362	SILO FERTILIZER 04 MOUTH		02
04	0503062927	SILO FERTILIZER 3 MOUTHS		02
05	0501010984	FLAT WASHER		24
06	0503010025	3/8" SPRING WASHER		12
07	0503010026	3/8" NUT		12
08	0503010849	3/8" X 1-1/2" BOLT		12
09	0571019051	FIXER BOX WASHER		20
10	0503013751	3/8 UNC X 1.1/4 BOLT		20
11	0503012535	3/8" SPRING WASHER		20
12	0503012531	3/8" INOX NUT		20
13	0503011957	NYLON LUG		02
14	0503010371	5/16" X 1" BOLT		04
15	0503010179	5/16" ZN SPRING WASHER		04
16	0503010337	5/16" NUT		04
17	0503034396	FERTILIZER SIDE COVER		12
18	0503010362	1/8" X 1.1/4" COTTERPIN		12




Item	Code	Description	See page	QT
01	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	30	02
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	31	05
03	0501010942	3/8" X 1-1/4" BOLT		28
04	0503011443	3/8" SPRING WASHER		28
05	0503010026	3/8" NUT		28
06	0571019828	LOCK AXLE		01
07	0503010365	NUT		02
08	0501110392	SILO SUPPORT BEARING		01
09	0521012485	GEAR BOX BEARING AGRICUTURAL		01
10	0503011953	5/16" X 1" BOLT		02
11	0521011039	FLAT WASHER		02
12	0503011444	SPRING WASHER		02
13	0503010337	5/16" NUT		02
14	0503010003	1845 GREASE FITTING		01
15	0503030275	AGRICULTURAL BEARING		07
16	0581018930	SQUARE AXLE 3/4 X 2788 - 5950		01
17	0521069410	SUPPORT RIGHT SILO FERTILIZER 5950		01
18	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	30	02
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	31	05
03	0501010942	3/8" X 1-1/4" BOLT		28
04	0503011443	3/8" SPRING WASHER		28
05	0503010026	3/8" NUT		28
06	0571019828	LOCK AXLE		01
07	0503010365	NUT		02
08	0501110392	SILO SUPPORT BEARING		01
09	0521012485	GEAR BOX BEARING AGRICUTURAL		01
10	0503011953	5/16" X 1" BOLT		02
11	0521011039	FLAT WASHER		02
12	0503011444	SPRING WASHER		02
13	0503010337	5/16" NUT		02
14	0503010003	1845 GREASE FITTING		01
15	0503030275	AGRICULTURAL BEARING		07
16	0581018930	SQUARE AXLE 3/4 X 2788 - 5950		01
17	0521069411	LEFT SILO FERTILIZER 5950 SUPPORT		01
18	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01



Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521069418	RIGHT PLATFORM 5950		01
02	0521069423	LEFT PLATFORM 5950		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	FLAT WASHER		18
06	0503010025	3/8" SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	HAIR PIN		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521063175	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		08

RESTING ASSEMBLY


0511054971




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	



Item	Code	Description	See page	QT
01	0503034788	ADHESIVE LABEL		01
02	0503034787	ADHESIVE LABEL		01
03	0503034782	LABEL ADHESIVE LOGO SMALLER TATU (03 MOUTHS)		01
04	0503034114	ADHESIVE LABEL LOGO TATU BOX 190 X 530		01
05	0503033858	ADHESIVE LABEL		01
06	0503033854	ADHESIVE LABEL		01
07	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
08	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		04
09	0503033423	LABEL ADHESIVE NUMBER 9		02
10	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
11	0503031428	READ MANUAL DECAL		01
12	0503031942	ADHESIVE LABEL		01
13	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		01
14	0503031565	ADHESIVE LABEL CARE		02
15	0503031566	ADHESIVE LABEL		02
16	0503031425	ADHESIVE LABEL ATTENTION		02
17	0503031669	ADHESIVE LABEL		01
18	0503032930	ADHESIVE LABEL DANGER		08
19	0503031087	ADHESIVE LABEL		01
20	0503034078	LIFTING POINTS DECAL		03
21	0503034003	SERIAL NUMBER TAG 61 X 118		01
22	0503010001	3.2 X 5.5 RIVET		04
23	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		17mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		02
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	38	02
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		14




Item	Code	Description	See page	QT
01	0503018738	LIGHTHOUSE		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	5/16" ZN SPRING WASHER		04
08	0503010337	5/16" NUT		04

ASSY HEX AXLE


0909095190



Item	Code	Description	See page	4880	5340	5950	6350	6850
01	0531016944	RIGHT 5/8" X 96" HEX AXLE		001	000	000	000	000
01.	0561019199	5/8" X 2275 AXLE HEX		001	000	000	000	000
02	0571017427	5/8" X 2700 HEX AXLE		000	001	000	000	000
02.	0571017425	5/8" X 2530 HEX AXLE		000	001	000	000	000
03	0561018502	SHAFT AXIS 5/8 X 3000		000	000	001	001	000
03.	0571011980	HEX AXLE		000	000	001	000	000
04	0531016949	LEFT 5/8" X 125" AXLE HEX		000	000	000	001	000
04.	0561018502	SHAFT AXIS 5/8 X 3000		000	000	000	001	000
05	0571017030	SHAFT AXLE 5 / 8X3450 14E500		000	000	000	000	001
05.	0571017029	AXLE HEX		000	000	000	000	001
05..	0571017030	SHAFT AXLE 5 / 8X3450 14E500		000	000	000	000	001
05...	0571017029	AXLE HEX		000	000	000	000	001
06	0561014215	BEARING COVER LOWER ROW FRAME		002	002	002	002	002
07	0521055214	BEARING GEAR WITH	40	002	002	002	002	002
08	0502040534	SPRING GUIDE BUSHING LOCK		004	004	004	004	004
09	0501018535	1/2 X 1 BOLT		004	004	004	004	004




Item	Code	Description	See page	QT
01	0511063106	20Z AXLE BEARING DOBLE		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521055215	DOUBLE TRANSMISSION BEARING	41	01
04	0503010365	NUT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503019356	BEARING 6005 2RS1		02
03	0503011105	SEAL RING		01

TURBINE ASSEMBLY

0521054676




Item	Code	Description	See page	QT
01	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
02	0501012140	FLAT WASHER		02
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0521066426	TURBINE SUPPORT		01
05	0503011082	C1/2" X 1.3/4" SCREW		01
06	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
07	0503010019	1/2" SPRING WASHER		03
08	0503010060	1/2" NUT		03
09	0561011377	HOSE 4 X 2200		02
10	0503011372	102 TO 121 CLAMP		04
11	0521050262	RIGHT AIR DISTRIBUTOR	43	01
12	0521050263	LEFT AIR DISTRIBUTOR	44	01
13	0511059319	AIR FIXING SUPPORT	45	04
14	0571013731	VACUUM GAUGE SUPPORT		01
15	0503013584	VACUUM GAUGE		01
16	0571019716	ADAPTER		12
17	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		12
18	0503031436	AIR DITRIBUTOR PUMP		02
19	0503010246	CLAMP		02
20	0511059406	TURBINE P.P MOUNTED	46	01
21	0521052549	CLAMP	48	24
22	0511057906	HOSE ASSY		01
22A	0511057840	ASSY TURBINE HOSE REAR		01
22AA	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
22AAA	0501081247	HOSE 1/2 X 7012 TC-TM		01
22AAB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
22AAC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
22AAD	0503018952	PLASTIC BOLT		06
23	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01
23A	0501081247	HOSE 1/2 X 7012 TC-TM		01
23B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01


TURBINE ASSEMBLY

0521054676


Item	Code	Description	See page	QT
23C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
23D	0503018952	PLASTIC BOLT		06
24	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
24A	0501080477	HOSE 3/8 X 7012 TC-TM		01
24B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
24C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
24D	0503018952	PLASTIC BOLT		06
25	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	63	02
26	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
27	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	49	01




Item	Code	Description	See page	QT
01	0503012566	COVER KAP 110 YELLOW		01
02	0503012856	REBITE POP		14
03	0503031943	SOCKET		07
04	0503017845	PVC KNEE 90 SOLD AVEL		01
05	0571018559	WHITE PVC TUBE		01
06	0581011923	BODY DISTRIBUTOR VACUUM COP		01
07	0521015543	DUTO 110 X 55		01




Item	Code	Description	See page	QT
01	0503012566	COVER KAP 110 YELLOW		01
02	0503012856	REBITE POP		14
03	0503031943	SOCKET		07
04	0503017845	PVC KNEE 90 SOLD AVEL		01
05	0571018559	WHITE PVC TUBE		01
06	0581011923	BODY DISTRIBUTOR VACUUM COP		01
07	0521015543	DUTO 110 X 55		01



Item	Code	Description	See page	QT
01	0571019403	STAPLE FIXER		01
02	0503010025	3/8" SPRING WASHER		04
03	0503010026	3/8" NUT		04
04	0501013518	FLAT WASHER		02
05	0571019921	AIR SUPPORT FIXATION		01
06	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		04
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0581012096	ROUND SLEEVE		02
06	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
07	0521050154	TURBINE P.P WITH HOLE	47	01
08	0503011372	102 TO 121 CLAMP		02
09	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
10	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
11	0503010143	1/4" SPRING WASHER		02
12	0503010144	1/4" NUT		02
13	0503010190	2-114 N 3006-9B O'RING		04
14	0501081235	1/2 X 650 TR- TC HOSE		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01

CLAMP


0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0503018799	QUICK COUPLING		01
02	0503011883	QUICK CONNECTION COVER		01




Item	Code	Description	See page	QT
01	0511058724	ASSEMBLY CSU C3 2BOXES 7/6 12E500	51	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521051931	LH SUPPORT TOWER SILO	53	02
07	0521051927	TOWER SUPPORT HOPPER	54	02




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		04
02	0501010984	FLAT WASHER		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	52	12
06	0571015773	SUPPORT SEED CSU		02
07	0501011643	3/8 X 1" BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		48
09	0521064874	07 MOUTHS SUPPORT BOX SEED ONLY		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
09	0503010179	5/16" ZN SPRING WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01




Item	Code	Description	See page	QT
01	0521066207	LH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066208	SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
05	0503010179	5/16" ZN SPRING WASHER		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0503063315	KIT INTELLIAG ISO 4C/12L 45/50 MS - EE		01
01A	0503015065	MASTER CONTROL MODULE		01
01B	0503015066	CABLE CONTROL MASTER MODULE		01
01C	0503017445	ELECTRICAL UNIT		02
01D	0503017444	MODEL-OFF / GENERAL COMMUNICATION CABLE		02
01E	0503019576	KEY CONNECTION CABLE		01
01F	0503017448	LINES ACTIVATION KEY MODULE 030010084		01
01G	0503017447	MANUAL CLOSING CONTROL KEY MODULE 467984264S1		01
01H	0503019097	WHIP ADAPTER		01
01I	0503015071	CONCTOR		01
01J	0503019992	CABLE ISO 4C 12L 45/50 MS - EE		01
01K	0503017443	ANTENNA GPS PM 400		01
01L	0503017031	CLEANING BRUSH		01
01M	0503015218	SENSOR FOTOELE PM 400		12
01N	0503019685	CABLE ISO CONNECTION TRACTOR 8,0 MT 020011353		01
02	0511056972	FILTER HYDAC	57	01
03	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	58	04
04	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		180
05	0503013100	NYLON CLAMP		60
06	0503019291	SUPPORT SENSOR		01



Item	Code	Description	See page	QT
01	0503016376	FILTER SPRING		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	T 7/8" ADAPOR GIRAT NUT		01
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0503018768	MOTOR OMP 80		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02




Item	Code	Description	See page	QT
01	0521064816	SUPPORT HIDRAULIC MOTOR	02	
02	0503031805	11Z 1/2" GEAR	02	
03	0511017302	FLAT WASHER	02	
04	0503010019	1/2" SPRING WASHER	06	
05	0503010060	1/2" NUT	06	
06	0531019479	AXLE CHAIN GEAR	02	
07	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
08	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN	04	
09	0503062754	GEAR 34Z P.1/2 APT	02	
10	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN	04	
11	0503013073	40-1 CHAIN X 75 LINK + MENDING	02	
12	0531060544	15Z GEAR P	02	
13	0503010282	1/4" X 3/4" BOLT	02	
14	0503010143	1/4" SPRING WASHER	02	
15	0561011665	FLAT WASHER	02	
16	0521067490	HYDRAULIC MOTOR SUPPORT APT	02	
17	0503010060	1/2" NUT	06	
18	0503010019	1/2" SPRING WASHER	06	
19	0503011082	C1/2" X 1.3/4" SCREW	04	
20	0502010175	HITCH CLAMP	02	
21	0503010013	5/8" NUT	04	
22	0503010027	5/8" SPRING WASHER	04	
23	0501011027	5/8" X 3-3/4" BOLT	04	
24	0501011299	FLAT WASHER	04	
25	0503031805	11Z 1/2" GEAR	02	
26	0511017302	FLAT WASHER	02	
27	0531019479	AXLE CHAIN GEAR	02	
28	0521065328	20Z GEAR WITH HOLE SHAFT HEX 16.5	02	
29	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN	04	
30	0521069832	15Z GEAR	02	
31	0503016462	40-1 X 50 LINKS + REDUCTION CHAIN	02	


Item	Code	Description	See page	QT
32	0503010025	3/8" SPRING WASHER		02
33	0591010757	FIXED SHEET FILTER SUPPORT		01
34	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
35	0503010208	HEX NUT 3/8 UNF G.5 ZN		02
36	0581011347	SUPPORT FILTER		01
37	0591015027	SENSOR DRIVER		01
38	0503010143	1/4" SPRING WASHER		01
39	0591015026	LIFTING SENSOR DRIVING BODY		01
40	0503010282	1/4" X 3/4" BOLT		01
41	0503010144	1/4" NUT		01
42	0503011336	1/2" HEX SELF ADJUSTING NUT		02
43	0561016468	FASTENER		01
44	0591015101	LIFT SENSOR SUPPORT		01
45	0503013356	RIVET POP 3,2 X 10,0		01
46	0511017302	FLAT WASHER		04
47	0503010019	1/2" SPRING WASHER		04
48	0511059348	APT ASSY MODULE BOX	60	01
49	0503010060	1/2" NUT		04
50	0571016237	1/2"UNC X2.1" X1.6" FASTENER ASSY		02
51	0521064978	BOX SUPPORT		02
52	0502012702	BODY SUPPORT CLAMP		10
53	0503010850	BOLT 7/16 UNC X 3 CS G.5 ZN		05
54	0503010180	7/16" SPRING WASHER		05
55	0503018033	37 X R.7/8 UNF 90° JIC MALE CONNECTOR WITH ROTATING NUT		01
56	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	63	02
57	0571015808	SUPPORT FIXER		02
58	0521052519	HOSE 1/2 X 4200 TC-TM GRAY / RED		01
58A	0501081073	HOSE 1/2 X 4200 TC-TM		01
58B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
58C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
58D	0503018952	PLASTIC BOLT		06
59	0521056808	HOSE 1/2 X 5000 TC-TM GRAY / BLUE		01
59A	0501080711	HOSE 1/2 X 5000 TC-TM		01
59B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
59C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
59D	0503018952	PLASTIC BOLT		06
60	0501080239	HOSE 1/2 X 350 TR-TC		01
61	0501080618	1/2" X 2200 TR-TC HOSE		01
62	0501080495	1/2 X 2500 TR-TC HOSE		01
63	0501081768	HOSE 1/2 X 6700 TR-TR		01




Item	Code	Description	See page	QT
01	0521066834	CAIXA MODULO		01
02	0503018171	FAST LOCK ASSY		02
03	0521066833	BOX COVER		01
04	0571012006	COVER PIVOT SHAFT		01
05	0571012005	SUPPORT GUIDE ASSY		01
06	0501010694	8.5 X 18 X 1.5 FLAT WASHER		03
07	0503010257	1/8" X 1" COTTERPIN		02
08	0511017303	FLAT WASHER		10
09	0503010298	1/4" X 1/2" BOLT		04
10	0503010143	1/4" SPRING WASHER		10
11	0503010294	1/4" X 7/8" BOLT		06
12	0503010144	1/4" NUT		06
13	0501011643	3/8 X 1" BOLT		04
14	0503010025	3/8" SPRING WASHER		04
15	0501010984	FLAT WASHER		04
16	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
02	0511017302	FLAT WASHER		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0521069295	SUPPORT TOOL CHEST		01
06	0581017000	PLATE INTERMEDIARY		02
07	0503034772	BOX		01
08	0501011643	3/8 X 1"BOLT		04
09	0503010025	3/8" SPRING WASHER		04
10	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
02	0511017302	FLAT WASHER		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0521069405	WATER TANK SUPPORT		01
06	0503014820	COROTE BLACK WATER		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521059770	FRONT SEED LINE SHORT WITH ELLIOTT CABLE	65	01
02	0521059769	LONG SEED LINE FRONT WITH ELLIOTT CABLE	66	01
03	0521059771	FRONT SM LONG SEED LINE WITH ELLIOTT CABLE	67	01
04	0521069028	CENTRAL SEED LINE FRAME CBA/SPA		01
05	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0581010593	HEX AXLE 5/8 X 600		01
08.	0581012756	HEX AXLE 5/8 X 360		01
09	0521058028	LEFT REAR LINE SEED PP CBA/CSU 3 NAC	69	01
10	0521058027	RIGHT REAR LINE SEED PP CBA/CSU 3 NAC	70	01
11	0531050978	DEPTH CONTROL WITH FAST REGULATING AXIS	79	01
12	0521054811	FERTILIZER SHORT LINE	90	01
13	0521054812	LONG FERTILIZER LINE	91	01
14	0521054768	DDD RIGHT FERTILIZER WITH SUPPORT	97	01
15	0521054769	LEFT FERTILIZER WITH SUPPORT	98	01
16	0503030391	RIGHT FERTILIZER NOZZLE		01
17	0503030392	LEFT FERTILIZER NOZZLE		01
18	0503031050	CURVED CONDUCTOR		01
19	0503010246	CLAMP		01
20	0503031145	2" X 2" X 20" HOSE		01
21	0503031076	2" HOSE CLAMP		01
22	0571011730	SEED CONDUCTOR 3X1500		01
23	0521050525	FIXER FERTILIZER CONDUCTOR	103	01
24	0531013600	PRESS ADJUSTMENT LEVER		01
25	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
26	0521068982	KEY CASH DISC CUTTING		01
27	0503010905	1/2" X 2-1/4" BOLT		01



Item	Code	Description	See page	QT
001	0502012910	LOWER ARM LINE WITHOUT LUBRICATION		01
002	0521069029	FRAME		01
003	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		03
004	0561019032	SEED FERTIL ROW LOCK		01
005	0503010071	3/16" X 1" COTTERPIN		01
006	0503030168	HAIR PIN		01
007	0521010773	0.37" X 1.18" COUPLING SHAFT		01
008	0503010140	1/8" X 3/4" COTTERPIN		01
009	0503012412	5/8 UNC SELF LOCKING NUT		04
010	0502012568	UPPER ROCKER ARM		01
011	0501011388	COUPLING SHAFT		02
012	0502012789	FIXER SUPPORT FERTILIZER ROW		01
013	0503017857	BOLT 5/8 UNF 4		04
014	0503010811	5/8" UNF SELF ADJUSTING NUT		04
015	0503034580	TRACTION SPRING		02
016	0502012911	TOP ARM SEED LINE		01
017	0503019273	SLEEVE		08
018	0581017624	SPACING SLEEVE		06
019	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		02
020	0503010045	O'RING		08
021	0581018487	FIXER UPPER SPRING		01
022	0521069031	SEED ROW SUPPORT FRONT		01
023	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		01
024	0521053577	BEARING BOX	68	01
025	0503062858	SHORT CBA TRANSMISSION SET		01
026	0581017955	CABLE GUIDE		01
027	0503011953	5/16" X 1" BOLT		02
028	0503010179	5/16" ZN SPRING WASHER		02
029	0503010337	5/16" NUT		02
030	0521068285	PROTECTION SUPPORT		01




Item	Code	Description	See page	QT
001	0502012910	LOWER ARM LINE WITHOUT LUBRICATION		01
002	0521069029	FRAME		01
003	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		03
004	0561019032	SEED FERTIL ROW LOCK		01
005	0503010071	3/16" X 1" COTTERPIN		01
006	0503030168	HAIR PIN		01
007	0521010773	0.37" X 1.18" COUPLING SHAFT		01
008	0503010140	1/8" X 3/4" COTTERPIN		01
009	0503012412	5/8 UNC SELF LOCKING NUT		04
010	0502012568	UPPER ROCKER ARM		01
011	0501011388	COUPLING SHAFT		02
012	0502012789	FIXER SUPPORT FERTILIZER ROW		01
013	0503017857	BOLT 5/8 UNF 4		04
014	0503010811	5/8" UNF SELF ADJUSTING NUT		04
015	0503034580	TRACTION SPRING		02
016	0502012911	TOP ARM SEED LINE		01
017	0503019273	SLEEVE		08
018	0581017624	SPACING SLEEVE		06
019	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		02
020	0503010045	O'RING		08
021	0581018487	FIXER UPPER SPRING		01
022	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		01
023	0521053577	BEARING BOX	68	01
024	0503062859	CBA TRANSMISSION ASSY WITH LONG EE ISO		01
025	0581017955	CABLE GUIDE		01
026	0503011953	5/16" X 1" BOLT		02
027	0503010179	5/16" ZN SPRING WASHER		02
028	0503010337	5/16" NUT		02
029	0521068285	PROTECTION SUPPORT		01
030	0521069030	SUPPORT FRONT		01




Item	Code	Description	See page	QT
01	0502012910	LOWER ARM LINE WITHOUT LUBRICATION		01
02	0521069030	SUPPORT FRONT		01
03	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		03
04	0561019032	SEED FERTIL ROW LOCK		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0503030168	HAIR PIN		01
07	0521010773	0.37" X 1.18" COUPLING SHAFT		01
08	0503010140	1/8" X 3/4" COTTERPIN		01
09	0503012412	5/8 UNC SELF LOCKING NUT		04
10	0502012568	UPPER ROCKER ARM		01
11	0501011388	COUPLING SHAFT		02
12	0502012789	FIXER SUPPORT FERTILIZER ROW		01
13	0503017857	BOLT 5/8 UNF 4		04
14	0503010811	5/8" UNF SELF ADJUSTING NUT		04
15	0503034580	TRACTION SPRING		02
16	0502012911	TOP ARM SEED LINE		01
17	0503019273	SLEEVE		08
18	0581017624	SPACING SLEEVE		06
19	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		02
20	0503010045	O'RING		08
21	0581018487	FIXER UPPER SPRING		01
22	0521068285	PROTECTION SUPPORT		01
23	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		01
24	0521053577	BEARING BOX	68	01
25	0503062860	CBA ULTRA TRANSMISSION SET		01
26	0581017955	CABLE GUIDE		01
27	0503011953	5/16" X 1" BOLT		02
28	0503010179	5/16" ZN SPRING WASHER		02
29	0503010337	5/16" NUT		02

BEARING BOX


0521053577




Item	Code	Description	See page	QT
01	0581014692	BEARING		01
02	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
03	0503011953	5/16" X 1" BOLT		02
04	0503010337	5/16" NUT		02
05	0503011410	ROLLER BEARING		01
06	0503011105	SEAL RING		01
07	0503010406	501025 CLAMPING RING (FOR AXLE)		02
08	0581017960	SLEEVE HEX SEXTAVADA		01
09	0503010179	5/16" ZN SPRING WASHER		02
10	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521055873	LEFT DOUBLE DISK FAST EXCHANGE SEED 15X15	72	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0521052015	ASSY P.P V-SET2 SUPREME STEEL CABLE CSU	77	01




Item	Code	Description	See page	QT
01	0521055872	RIGHT DOUBLE DISK FAST EXCHANGE SEED 71 15X15		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0521052015	ASSY P.P V-SET2 SUPREME STEEL CABLE CSU	77	01




Item	Code	Description	See page	QT
01	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0502012780	SUPPORT DDD RIGHT		01
04	0503011402	0.2" X 0.8" SPRING PIN		01
05	0503013129	ELASTIC PIN		01
06	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
07	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 73 FERTILIZER / SEED		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 74 FERTILIZER / SEED		01
09	0501010984	FLAT WASHER		02
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
11	0503010025	3/8" SPRING WASHER		01
12	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0502012781	SUPPORT DDD LEFT		01
04	0503011402	0.2" X 0.8" SPRING PIN		01
05	0503013129	ELASTIC PIN		01
06	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
07	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 73 FERTILIZER / SEED		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 74 FERTILIZER / SEED		01
09	0501010984	FLAT WASHER		02
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
11	0503010025	3/8" SPRING WASHER		01
12	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	75	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	76	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	LOW CUBE FERTILIZER / SEED BOX		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	5/16" ZN SPRING WASHER		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01



Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUB DISC - HUB		01
02	0502012896	LOW CUBE FERTILIZER / SEED BOX		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	5/16" ZN SPRING WASHER		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571017895	PIN FIXER CONDUCTOR P.P		01
02	0503010293	BAQUELITE MANIPULACION		01
03	0503010140	1/8" X 3/4" COTTERPIN		02
04	0503010025	3/8" SPRING WASHER		02
05	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
06	0501011643	3/8 X 1"BOLT		01
07	0503010209	3/8" UNC BUTTERFLY NUT		01
08	0502012807	SUPPORT BOX PRECISION PLANTING		01
09	0571019489	CLAMP PRECISION PLANTING		01
10	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 78 DISC		01
11	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
12	0503015110	M06 SPRING WASHER		02
13	0503012721	1/4" X 4" BOLT		01
14	0503012880	1/4" UNC SELF ADJUSTING NUT		01
15	0503018139	PARAF M6 X 10 CAB CIL C/FENDA		03
16	0571014024	FAST BOLT GUIDE AXLE		01
17	0503037390	PACKING FOR PLANTING		01
18	0503011953	5/16" X 1" BOLT		03
19	0503010337	5/16" NUT		04
20	0503010179	5/16" ZN SPRING WASHER		04
21	0503012163	5/16" X 1-1/2" BOLT		01
22	0581011226	FIXER CLOSING P PLANTING CONTR CPRA		01
23	0503034824	FIXATIVE		01
24	0521066707	FEEDER		01
25	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01
26	0503010589	1/2" UNC SELF ADJUSTING NUT		01
27	0502012909	BASE SUPPORT PRECISION PLANTING		01




Item	Code	Description	See page	QT
01	0503062405	SEED DISTRIBUTOR		01
01A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
01AA	0503018908	BODY FIXED BASE DISTRIBUTOR SEED		01
01AB	0503018909	COVER CONDUCTOR DISTRIBUTOR SEED		01
01AC	0503062652	SEED INPUT DEFLECTOR		01
01AD	0503062653	FULL COVER		01
01AE	0503018910	RIVETS LARGEST		01
01AF	0503018911	SPACING BUSHING		01
01AG	0503018912	BOLT		03
01AH	0503018476	SPRING		01
01AI	0503018474	LOWER BRUSH		01
01AJ	0503018475	TOP BRUSH		01
01AK	0503018157	RUBBER		01
01AL	0503018477	LOCK SPRING		01
01B	0503062568	FIXER MOBILE		01
01BA	0503018919	BASE		01
01BB	0503018913	RIVET		01
01BC	0503018914	WASHER		01
01BD	0503018915	BEARING		02
01BE	0503062654	BEARING		01
01BF	0503018916	ADJUSTMENT CHOCK		03
01BG	0503018917	RING		01
01BH	0503018918	CHOCK		02
01BI	0503019288	RUBBER SEAL PP 730518		01
01BJ	0503018478	SPRING		01
01BK	0503018920	SEALING		01
01BL	0503018479	TUBE		01
01BM	0503018735	PROTECTIVE COVER		01
01BN	0503018921	BOLT		06
01BO	0503018922	BOLT		02
01BP	0503018480	REGULATOR PIN		01


Item	Code	Description	See page	QT
01BQ	0503018923	ADAPTER		01
01BR	0503018924	SPRING PIN		01
02	0503062417	KIT CORN DISTRIBUTION		01
02A	0503018160	CORN PLASTIC DISC		01
02B	0503062472	SELECTOR SEED CORN		01
02C	0503062474	EJECTOR CORN SEED SET		01
03	0571019613	STRAW PRECISION PLANTING SHIELD		01
03A	0503017957	PROTECTIVE COVER AIR INPUT		01




Item	Code	Description	See page	QT
01	0531050980	SEM SEMI-ASSEMBLED CONTROL WITHOUT LUBRICATION	80	01
02	0503010358	5/16" X 5/8" BOLT		08
03	0503013816	5/16" LOCKNUT		08
04	0521055017	RIGHT COMPACTOR WHEEL	86	01
05	0521054990	LEFT COMPACTOR WHEEL	88	01
06	0511055819	DEPTH WHIT AROS BAND	89	02




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	81	01
02	0531050975	LEFT ARM WHEELS DEPTH WITH CUBE WITHOUT LUBRICATION	82	01
03	0531050973	RIGHT ARM DEPTH WHEEL WITH HUB WITHOUT LUBRICATION	83	01
04	0521055033	COMPACTADOR BODY	85	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	SCREEW 3/8 UNC X 3/4		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED GLOVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0511015976	FLAT WASHER		01
05	0503010257	1/8" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503010071	3/16" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0531050974	CUBE CONTROL DEPTH WITHOUT LUBRICATION	84	01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0531050974	CUBE CONTROL DEPTH WITHOUT LUBRICATION	84	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503010060	1/2" NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0581019514	LUBRICANT GLOVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL BOX		01
02	0503019342	ROLLER BEARING		01
03	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
04	0503034055	CLAMPING RING		01
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0521019178	COVER DEPTH		01
08	0503010143	1/4" SPRING WASHER		03
09	0503011105	SEAL RING		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0591018029	DEPTH REGULATING AXLE WITH ANGLE		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT GLOVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	87	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	87	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0521066231	SHORT FERTILIZER LINE ARM		01
02	0502012873	SUPPORT DC LINE FERTILIZER		01
03	0502012876	CLAMP		01
04	0503016110	BOLT 5/8 UNC X 4 C S G.7 ZN		02
05	0503012412	5/8 UNC SELF LOCKING NUT		03
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0503019116	BOLT		02
08	0503010013	5/8" NUT		02
09	0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION 92 CONICAL BEARING		01
10	0521054906	SPRING ASSY FERTILIZER	96	01
11	0501010066	3/4" X 9" BOLT		01
12	0511017232	FLAT WASHER		02
13	0581019195	SIDE GUIDE GLOVE		02
14	0503010410	RING		02
15	0503019278	LUBRICANT GLOVE		02
16	0581019196	CENTRAL GUIDE GLOVE		01
17	0503011255	3/4" LOCK NUT		01




Item	Code	Description	See page	QT
01	0521066230	LONG FERTILIZER LINE ARM		01
02	0502012873	SUPPORT DC LINE FERTILIZER		01
03	0502012876	CLAMP		01
04	0503016110	BOLT 5/8 UNC X 4 C S G.7 ZN		02
05	0503012412	5/8 UNC SELF LOCKING NUT		03
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0503019116	BOLT		02
08	0503010013	5/8" NUT		02
09	0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION 93 CONICAL BEARING		01
10	0521054906	SPRING ASSY FERTILIZER	96	01
11	0501010066	3/4" X 9" BOLT		01
12	0511017232	FLAT WASHER		02
13	0581019195	SIDE GUIDE GLOVE		02
14	0503010410	RING		02
15	0503019278	LUBRICANT GLOVE		02
16	0581019196	CENTRAL GUIDE GLOVE		01
17	0503011255	3/4" LOCK NUT		01



Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	94	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	94	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	FIXING SHAFT DISC CUT LINE		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	CUTTING DISK BOX	95	01

CUTTING DISK BOX


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	CUTTING DISK BOX		01
09	0502040873	CUTTING DISC AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0521067619	TUBE LINE FERTILIZER		01
02	0502012510	SPRING ROD SUPPORT		01
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502040534	SPRING GUIDE BUSHING LOCK		02
06	0501018535	1/2 X 1 BOLT		02
07	0503010014	3/4" NUT		01
08	0502010891	SPRING CHOCK SUPPORT VARON		01
09	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
10	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		02
12	0581013793	PIN LOCK		01
13	0503010577	3/16" X 1-1/4" COTTERPIN		01




Item	Code	Description	See page	QT
01	0521054764	DDD RIGHT FERTILIZER	99	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521054765	DDD LEFT FERTILIZER	100	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	101	01
03	0521054760	DOWN LOW CUBE	102	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	101	01
03	0521054760	DOWN LOW CUBE	102	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511015098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502012736	HUB LOWR DDD		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06



Item	Code	Description	See page	QT
01	0502012736	HUB LOWR DDD		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06



Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010365	NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

