

ROW CROP PLANTERS

**USAP SUPREMA P.P - FRAME 15900/17900 -
CSU/APT VDRIVE/MS
USAP SUPREMA P.P - CHASSI 15900/17900 -
CSU/APT VDRIVE/MS**

Code: 0501093033
Series: S-0419
Revision: 00
Revision Date: MAY/2024

PARTS CATALOGUE



MARCHESAN



PRODUCTS

Code	Working Width	Description
0111440203		USAP SUP 15900/32E500 CSU CM PP DP80 ESP S-0419
0111440220		USAP SUP 17900/36E500 CSU CA PP ESPECIAL S-0419
0111440221		USAP SUP 17900/36E500 CSU CA PP ESPECIAL S-0419
0111440179		USAP SUP 17900/36E500 CSU CA PP ESPECIAL S-0419

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909095823	FRAME ASSY	1
0909095824	FRAME RIGHT SIDE ASSY	2
0909095825	ASSY CENTRAL FRAME	3
0909095826	LEFT SIDE FRAME ASSY	4
0909095827	SEED LINE/ASSY FERTILIZER	5
0521058343	TELESCOPIC ASSY	6
0521059412	TELESCOPE WITH INTERNAL TUBE 3220/4250 ASSY	7
0521057792	PANTOGRAPHY HEADER	8
0521057786	HYDRAULIC CYLINDER HEAD PANTOGRAPH	9
0521058334	RIGHT HAND	10
0531051307	FRENCH HAND 5805 ASSY RIGHT	11
0521059413	FRENCH MAO 5805 COMPLETE RIGHT	12
0521058089	FRENCH HAND 4855 ASSY LEFT	13
0531051306	FRENCH HAND 5805 LEFT ASSY	14
0521059414	FRENCH MAO 5805 LEFT COMPLETE	15
0511054713	ASSY TRANSMISSION SHAFT	16
0521058088	BALLET WITH EXTENSION AXLE 2	17
0511052052	SUPPORT WITH FIXATION	18
0521057773	SEMI-ASSEMBLED REST	19
0531052688	SEMI ASSEMBLED REST	20
0511053121	GREATER TOOL BOX ASSY	21
0521058344	WATER RESERVOIR WITH SOAP	22
0521057815	HYDRAULIC HOSE SUPPORT WITH FIXATION	23
0521059540	ASSY TRACTOR HITCH AXLE	24
0521053054	ASSY SIDE HANDLE	25
0521055325	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	26
0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	27
0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	28
0521056764	RIGHT SUPPORT 5 MOUTH 2128 X 1410 ASSY	29
0521058895	FERTILIZER SUPORT RIGHT BOX	30
0521058896	BLADE DISC SIDE SUPPORT	31
0521056785	RIGHT SIDE SUPPORT 4 MOUTH 1633 X 1274 ASSY	32
0521051407	FERTILIZER HOPPER FIXER	33
0521058329	SEED CONDUCTOR	34
0503062767	SCRUFFY ARTICULATED SEED CONDUCTOR	35
0503062766	ARTICULATED SEED DRIVER ALIGNED	36
0521055364	ARTICULATED SEED CONDUCTOR SUPPORT	37
0521050525	FIXER FERTILIZER CONDUCTOR	38
0531050753	ASSY SILO SUPPORT FIXER 410	39
0531050752	ASSY SILO SUPPORT FIXER 400	40
0531051338	COMPLETE SILO 312 SUPPORT FIXER	41
0531051181	SIDE SILO SUPPORT SHOE WITH FIXATIONS	42
0521058964	SIDE PLATFORM	43
0521056356	SIDE PLATFORM ASSY	44
0521053066	PLATFORM SUPPORT ASSY	45
0521058905	PLATFORM ASSY	46
0521058386	FRONT SIDE CORRIMAO	47
0521059557	RIGHT SIDE HANDRAIL 6567	48
0521058385	RIGHT SIDE HANDRAIL 2549 X 2223	49
0511059383	INTERNAL HANDRAILING FIXER	50
0521056310	RIGHT SIDE HANDRAIL	51
0521056309	RIGHT SIDE HANDRAIL	52
0521055750	SIDE HANDRAIL	53
0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	54
0521058341	FRONT SIDE CORRIMAO	55
0521058135	LEFT INTERNAL HANDRAIL LARGER	56
0521058891	LADDER ASSY	57
0511053320	ASSY SIDE LADDER	58
0521051406	TURBINE P.P SIDE FRAME WITH FIXATION	59



MARCHESAN

INDEX

0511059406	TURBINE PP MOUNTED	60
0521050154	PRECISION PLANTING TURBINE WITH HOLE	61
0531051564	SUPREME RIGHT LATERAL DUCT ASSEMBLY	62
0531054732	RIGHT SIDE DUCT ASSEMBLY 36E500 APT	63
0531050584	RIGHT SIDE DUCT P.P 36E500 SET	64
0511059943	SUPPORT FASTENER ASSY	65
0511059928	SIDE DUTY SUPPORT	66
0521056358	SIDE CHANNEL SET 36E50	67
0521058381	SIDE SHAFT ASSEMBLY	68
0531051298	SIDE GUTTER ASSY	69
0521059612	RIGHT SIDE AIR DUCT ASSEMBLY	70
0531054731	RIGHT SIDE AIR DUCT ASSEMBLY	71
0521056374	RIGHT SIDE AIR DUCT SET 36E500	72
0521056262	CBA ASSY AIR DUCT FIXER SUPPORT	73
0521056311	RIGHT SIDE AIR CONDUCTOR 13 MOUTH 6280	74
0521058336	DRIVER AIR	75
0521055100	SUPPORT CONDUCTOR AIR ASSY GREATER	76
0521055102	BIGGEST FULL GUTTER SUPPORT	77
0521052549	CLAMP	78
0521058383	SET LABEL ADHESIVE	79
0521056361	SIDE ADHESIVE LABEL ASSY	80
0521050332	VACUOMETER WITH ASSY SUPPORT	81
0521056360	SIDE HEXAGONAL AXLE 36E500 COMPLETE	82
0521051442	MOTOR SUPPORT ASSY	83
0521051293	16Z/32Z GEAR BEARING	84
0501054655	CHAIN TENSIONER ASSY	85
0511059969	CHAIN TENSIONER	86
0521058739	LONG FRONT SEED ROW	87
0531054675	FRONT INTERNAL LONG SEED LINE VDRIVE	88
0521058583	LONG SEED LINE FRONT CBA/CA WITHOUT LUBRICATION	89
0521058076	FRONT LINE BEARING	90
0521058738	AVANT LIGNE SEMENCE COURTE	91
0531054677	FRONT INTERNAL SHORT SEED LINE VDRIVE	92
0521058584	FRONT LINE SEED SHORT CBA/CA WITHOUT LUBRICATION	93
0521058736	AVANT LIGNE SEMENCE LONGUE	94
0531054676	FRONT LONG SEED LINE VDRIVE	95
0521058592	INTERNAL FRONT LONG SEED LINE CBA / CA WITHOUT LUBRICATION	96
0521058737	SHORT SEED ROW FRONT	97
0531054678	FRONT SHORT SEED LINE VDRIVE	98
0521058591	INTERNAL FRONT SHORT SEED LINE CBA / CA WITHOUT LUBRICATION	99
0521058074	ARTICULATED DRIVING SUPPORT WITH FIXATION	100
0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	101
0521055065	ASSY DEPTH / COMPACTOR	102
0521055033	SEMI-ASSEMBLED COMPACTOR BODY	103
0521055054	LEFT ARM WITH SLEEVE	104
0521055066	RIGHT ARM WITH SLEEVE	105
0521055068	RAYED WHEEL CENTER CLOSED	106
0521055055	HUB WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	107
0521054990	LEFT COMPACTOR WHEEL	108
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	109
0521055017	RIGHT COMPACTOR WHEEL	110
0521058904	REAR LEFT VDRIVE CSU	111
0521058888	REAR WITH LEFT DDD SPICRR P.P V-DRIVE	112
0521058903	RIGHT REAR VDRIVE CSU	113
0521058887	REAR WITH RIGHT DDD SPICRR PP V-DRIVE	114
0521058085	REAR WITH DDD LEFT SPICRR	115
0521058084	REAR WITH RIGHT DDD SPICRR	116



MARCHESAN

INDEX

0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	117
0521056632	DEPTH CONTROL	118
0521056633	MOUNTED RIGHT ARM	119
0521056631	MOUNTED LEFT ARM	120
0521055059	WHEEL RAYED ASSY SPA WITHOUT LUBRICATION	121
0521055073	ASSEMBLY DEPTH WHEEL HUB	122
0521055093	BODY COMPACTOR	123
0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	124
0521054470	CONDUCTOR 3 LOWER LONG ASSY	125
0521054471	CONDUCTOR 3 LOWER SHORT ASSY	126
0521055346	20 BLADE DISC ASSY	127
0521055349	ASSY DPL20 CUTTING DISC	128
0521055344	LOWER SUPPORT	129
0521054844	20" WAVY COULTER BLADE HUB	130
0521053697	DISC BLADE HUB	131
0521055348	LOWER SUPPORT WITH DPL 20 WITHOUT LUBRICATION	132
0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	133
0521058758	ASSY P.P CSU V-DRIVE	134
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	135
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	136
0521055865	FERTILIZER/SEED LEFT HUB ASSY	137
0521055864	FERTILIZER/SEED RIGHT HUB ASSY	138
0521056955	RIGHT DDD ASSY	139
0531050596	FENDER ASSY	140
0521055603	FRAME CENTRAL 4686 FIXING / LATCH TELESCOPICA	141
0521050019	TIGHTENING PLATE WITH FIXING INTERNAL	142
0521052189	38,10 X 63,50 X 386 X 148 HYDRAULIC CYLINDER	143
0521053514	ASSY ASSEMBLY ASSEMBLED PDM 729185 VDRIVE	144
0531054734	SUPREME USAP HYDRAULIC ASSEMBLY	145
0531054733	SUPREME USAP CENTRAL DUCT ASSEMBLY	146
0521054018	ASSY HEAD HOSE CSC FRAME 20226	147
0531054728	SUPREME USAP LIFTING HOSE SET	148
0531054729	SUPREME USAP TURBINE HOSE SET	149
0521055006	ASSY ALTERNATOR SUPPORT P.P	150
0521055328	CENTRAL WHEEL WITHOUT TRANSMISSION	151
0521059368	SUPPORT/SENSOR ASSY PSS-X1005B 87780-000 TE	152
0521058330	SENSOR SUPPORT	153
0521058331	DRIVE HYDRAULIC ASSEMBLY	154
0521058902	SUPPORT	155
0521056784	RIGHT CENTRAL SUPPORT 5B 2033 X 1480 ASSY	156
0521056783	LEFT CENTRAL SUPPORT 5B 2033 X 1480 ASSY	157
0521058669	KIT CABINE SEEDSENSE GEN3 - VDRIVE	158
0531050727	ASSY SUPPORT FIXER SILO 510	159
0521057513	CENTRAL HANDRAIL ASSY 30E500	160
0521059552	SET HANDRAIL	161
0521056303	CENTRAL HANDRAIL 2422 X 1424	162
0521057493	INTERNAL HANDRAIL 463/483 CENTRAL HOPPER SUPPORT	163
0521053222	PLATFORM ASSY CENTER FRAME 4686	164
0521052149	ARTICULATION ARM LEFT ASSY	165
0521052147	ARTICULATION ARM RIGHT ASSY	166
0521052353	ASSEMBLY CYLINDER ARTICULATED ARM	167
0511058241	HYDRAULIC CYLINDER 50,80 X 114,30 X 964 X 638	168
0521058390	SET HIDRAULICO	169
0521059553	SUPREME USAP HYDRAULIC ASSEMBLY	170
0521059554	CENTRAL DUCT ASSEMBLY	171
0521053537	CENTRAL REAR DUCT SUPPORT	172
0521058391	CENTRAL DUTY CONNECTOR	173
0521051537	CENTRAL REAR DUCT SUPPORT	174
0521057013	TRIPLE DIVISER VALVE BRP00079 WITH NIPLES	175




MARCHESAN

INDEX


0521057495	SUPPORT BLOCK	176
0521058570	RELIEF VALVE BLFP 3208 WITH SUPPORT	177
0521055275	ASSY HOSE ARTICULATION	178
0521055274	HEAD HOSE ASSY	179
0521059583	HOSE SET CABECALHO	180
0521059227	GAME OF LEVANTE HOSES	181
0521059584	LIFTING HOSE SET	182
0521058634	HOSE KIT	183
0521057885	VALVE ASSEMBLY	184
0521059226	TURBINE HOSES SET	185
0521059782	HOSE SET 3 TURBINE P.P 36LINES 500	186
0501053834	MALE QUICK COUPLER	187
0521058181	ELECTRIC ASSEMBLY 15MT / 5 HEADLIGHTS LED/APT	188
0521058744	ELECTRICAL ASSY 19 MT/5F LED APT	189
0521057760	LED FLASHLIGHT WITH SUPPORT	190
0521053672	LIGHTHOUSE ASSY	191
0521058182	CENTRAL AIR DUCT ASSY 30E500 CSU	192
0521059556	CENTRAL AIR DUCT ASSY 36E500	193
0521054185	OF THE AIR CENTRAL TUBE	194
0521051096	REAR CENTRAL AIR CONDUCTOR 1120 CSCP	195
0521052924	SUPPORT CONDUCTOR AIR CENTRAL ASSY	196
0521058388	CENTRAL TRACK ASSEMBLY	197
0531054735	36E500 CENTRAL CHUTE ASSEMBLY	198
0521059555	CENTER CHANNEL SET	199
0521058890	32 LINES VDRIVE SET	200
0531054699	ASSY VDRIVE 36L 45/50 MS/WV	201
0521059564	SET ISOBUS 36L 45/50 WITH SEED MONITORING	202
0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	203
0511056972	FILTER HYDAC	204
0521058389	SET LABEL ADHESIVE	205
0521056380	ADHESIVE LABEL ASSY	206
0511059814	TELESCOPIC LOCK ASSY	207
0521057207	ELECTRIC ASSEMBLY BCE (EMB) APT	208
0521051707	ASSY PANEL FIXER PLATE	209
0521055353	SUPPORT WITH BLOCK DIVIDER FOR 2 TURBINES	210
0521055354	SUPPORT WITH FLOW DIVIDER BLOCK FOR 3 TURBINES	211
0521055356	FLUX DIVIDER BLOCK FOR 03 TURBINES	212
0521058893	LH SUPPORT	213
0521058894	SIDE SUPPORT	214
0521056782	LEFT SUPPORT 5 MOUTH 2033 X 1224 ASSY	215
0521056781	LEFT SIDE SUPPORT 4 MOUTH 1633 X 1274 ASSY	216
0521059563	LEFT SIDE HANDRAIL 6567	217
0521056320	LEFT SIDE HANDRAIL 2375 X 1237	218
0521056319	LEFT HANDRAIL 2238 X 1336	219
0521056562	RIGHT INTERNAL HANDRAIL	220
0531054730	LEFT SIDE AIR DUCT ASSEMBLY	221
0521056364	LEFT SIDE AIR DUCT ASSEMBLY	222
0521056318	LEFT SIDE AIR CONDUCTOR 13 BUTTONS 6280	223
0521058384	LEFT SIDE CORRIMAO	224
0521058340	LEFT SIDE HANDRAIL 2549 X 2223	225
0521058339	LEFT SIDE HANDRAIL	226
0521058134	RIGHT INTERNAL HANDRAIL LARGER	227
0521058380	RIGHT SIDE AIR DUTY ASSEMBLY	228
0521058335	SIDE AIR CONDUCTOR 11 MOUTH	229
0521058382	LEFT SIDE DUTY ASSEMBLY	230
0521059582	SUPREME USAP SIDE DUCT ASSEMBLY	231
0521058426	ASSY FILTER SUPPORT	232

FRAME ASSY

0909095823



Item	Code	Description	See page	15900	17900
01		FRAME RIGHT SIDE ASSY	2		
02		ASSY CENTRAL FRAME	3		
03		LEFT SIDE FRAME ASSY	4		
04	0521058343	TELESCOPIC ASSY	6	01	00
04.	0521059412	TELESCOPE WITH INTERNAL TUBE 3220/4250 ASSY	7	00	01
05	0521069072	TRANSPORT LOCK		01	01
06	0521057792	PANTOGRAPHY HEADER	8	01	01
07	0521058334	RIGHT HAND	10	01	00
07.	0531051307	FRENCH HAND 5805 ASSY RIGHT	11	00	01
07..	0521059413	FRENCH MAO 5805 COMPLETE RIGHT	12	00	01
08	0521058089	FRENCH HAND 4855 ASSY LEFT	13	01	00
08.	0531051306	FRENCH HAND 5805 LEFT ASSY	14	00	01
08..	0521059414	FRENCH MAO 5805 LEFT COMPLETE	15	00	01
09	0511052052	SUPPORT WITH FIXATION	18	04	04
10	0521057773	SEMI-ASSEMBLED REST	19	01	00
10.	0531052688	SEMI ASSEMBLED REST	20	00	01
11	0511053121	GREATER TOOL BOX ASSY	21	01	01
12	0521058345	SAFETY CHAIN WITH SHACKLE		01	01
12A	0503014120	CHAIN		01	01
12B	0503014321	CABLE STEEL SHACKLE		02	02
13	0521058344	WATER RESERVOIR WITH SOAP	22	01	01
14	0521057815	HYDRAULIC HOSE SUPPORT WITH FIXATION	23	01	01
15	0503018829	NYLON CLAMP 7,8 X 1,8 X 390 MM		20	24
16	0511059814	TELESCOPIC LOCK ASSY	207	00	01
17	0521059540	ASSY TRACTOR HITCH AXLE	24	00	01




Item	Code	Description	See page	15900	17900
01	0501110948	RIGHT FRAME WITH GLOVE 5567		01	00
01.	0501110982	RIGHT CHASSIS WITH GLOVE 6567		00	01
01A	0521069759	RIGHT SIDE FRAME 5567 X 5235		01	00
01A.	0531060115	RIGHT SIDE CHASSIS 6567		00	01
01B	0581012179	BUSHING		02	02
02	0503015062	TUBE		03	04 mts
03	0503010002	1800 GREASE FITTING		01	01
04	0521053054	ASSY SIDE HANDLE	25	01	01
05	0521055325	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	26	02	02
06	0521058895	FERTILIZER SUPORT RIGHT BOX	30	01	00
06.	0521056764	RIGHT SUPPORT 5 MOUTH 2128 X 1410 ASSY	29	00	01
07	0521058896	BLADE DISC SIDE SUPPORT	31	01	00
07.	0521056786	RIGHT SIDE SUPPORT 4 MOUTH 1633 X 1274 ASSY		00	01
07..	0521056785	RIGHT SIDE SUPPORT 4 MOUTH 1633 X 1274 ASSY	32	00	01
08	0521062769	SILO SUPPORT FIXER		02	00
08.	0531050753	ASSY SILO SUPPORT FIXER 410	39	00	01
08..	0531050752	ASSY SILO SUPPORT FIXER 400	40	00	01
08...	0531051338	COMPLETE SILO 312 SUPPORT FIXER	41	00	01
09	0531051181	SIDE SILO SUPPORT SHOE WITH FIXATIONS	42	04	06
10	0521058964	SIDE PLATFORM	43	01	00
10.	0521056356	SIDE PLATFORM ASSY	44	00	01
11	0521058386	FRONT SIDE CORRIMAO	47	01	00
11.	0521059557	RIGHT SIDE HANDRAIL 6567	48	00	01
12	0521058891	LADDER ASSY	57	01	00
12.	0511053320	ASSY SIDE LADDER	58	00	01
13	0521051406	TURBINE P.P SIDE FRAME WITH FIXATION	59	01	01
14	0531051564	SUPREME RIGHT LATERAL DUCT ASSEMBLY	62	01	00
14.	0531054732	RIGHT SIDE DUCT ASSEMBLY 36E500 APT	63	00	01
14..	0531050584	RIGHT SIDE DUCT P.P 36E500 SET	64	00	01
15	0503011372	102 TO 121 CLAMP		03	04

Item	Code	Description	See page	15900	17900
16	0521058381	SIDE SHAFT ASSEMBLY	68	01	00
16.	0531051298	SIDE GUTTER ASSY	69	00	01
16..	0521056358	SIDE CHANNEL SET 36E50	67	00	01
17	0521059612	RIGHT SIDE AIR DUCT ASSEMBLY	70	01	00
17.	0531054731	RIGHT SIDE AIR DUCT ASSEMBLY	71	00	01
17..	0521056374	RIGHT SIDE AIR DUCT SET 36E500	72	00	01
18	0521058383	SET LABEL ADHESIVE	79	01	00
18.	0521056361	SIDE ADHESIVE LABEL ASSY	80	00	01
19	0521050332	VACUOMETER WITH ASSY SUPPORT	81	01	01
20	0521056360	SIDE HEXAGONAL AXLE 36E500 COMPLETE	82	00	01
21	0521051442	MOTOR SUPPORT ASSY	83	00	01
22		SEED LINE/ASSY FERTILIZER	5		

ASSY CENTRAL FRAME

0909095825



Item	Code	Description	See page	15900	17900
01	0521055603	FRAME CENTRAL 4686 FIXING / LATCH TELESCOPICA	141	01	01
02	0521053514	ASSY ASSEMBLY ASSEMBLED PDM VDRIVE	144	01	00
03	0521055328	CENTRAL WHEEL WITHOUT TRANSMISSION	151	04	04
04	0521059368	SUPPORT/SENSOR ASSY PSS-X1005B TE	152	01	01
05	0521058902	SUPPORT	155	02	00
05.	0521056784	RIGHT CENTRAL SUPPORT 5B 2033 X 1480 ASSY	156	00	01
05..	0521056783	LEFT CENTRAL SUPPORT 5B 2033 X 1480 ASSY	157	00	01
06	0521058669	KIT CABINE SEEDSENSE GEN3 - VDRIVE	158	01	00
07	0531050727	ASSY SUPPORT FIXER SILO 510	159	02	02
08	0521057513	CENTRAL HANDRAIL ASSY 30E500	160	01	00
08.	0521059552	SET HANDRAIL	161	00	01
09	0521053222	PLATFORM ASSY CENTER FRAME 4686	164	01	01
10	0521052149	ARTICULATION ARM LEFT ASSY	165	01	01
11	0521052147	ARTICULATION ARM RIGHT ASSY	166	01	01
12	0521052353	ASSEMBLY CYLINDER ARTICULATED ARM	167	01	01
13	0521058390	SET HIDRAULICO	169	01	00
13.	0531054734	SUPREME USAP HYDRAULIC ASSEMBLY	145	00	01
13..	0521059553	SUPREME USAP HYDRAULIC ASSEMBLY	170	00	01
14	0521058181	ELECTRIC ASSEMBLY 15MT / 5 HEADLIGHTS LED/APT	188	01	00
14.	0521058744	ELECTRICAL ASSY 19 MT/5F LED APT	189	00	01
15	0521058182	CENTRAL AIR DUCT ASSY 30E500 CSU	192	01	00
15.	0521059556	CENTRAL AIR DUCT ASSY 36E500	193	00	01
16	0521058388	CENTRAL TRACK ASSEMBLY	197	01	00
16.	0531054735	36E500 CENTRAL CHUTE ASSEMBLY	198	00	01
16..	0521059555	CENTER CHANNEL SET	199	00	01
17	0521058890	32 LINES VDRIVE SET	200	01	00
17.	0531054699	ASSY VDRIVE 36L 45/50 MS/WV	201	00	01
17..	0521059564	SET ISOBUS 36L 45/50 WITH SEED MONITORING	202	00	01


ASSY CENTRAL FRAME

0909095825

Item	Code	Description	See page	15900	17900
18	0521058389	SET LABEL ADHESIVE	205	01	00
18.	0521056380	ADHESIVE LABEL ASSY	206	00	01
19	0503011628	FEMALE QUICK COUPLER		01	01
20	1164920013	SPIRAL HOSE		49	52
21	1163920004	BLACK LIGHT SUCTION HOSE		09	09
22	1164920014	BLACK LIGHT SUCTION HOSE		42	50
23	0511059814	TELESCOPIC LOCK ASSY	207	01	01
24	0521055637	ASSY TRANSPORT LOCK		04	04
24A	0551018312	TRANSPORT LOCK		04	04
24B	0501068994	8,30 X 78 LOCK PIN		04	04
24C	0503030168	HITCH PIN CLIP		04	04
25	0561016793	FIXED WRENCH		01	01
26	0501047885	30 ROD STOP		08	08
27	0561017063	HOLDER TUBE		02	02
28	0521053296	AXIS ARTICULATOR		01	01
29	0581019559	AXIS		01	01
30	0521052549	CLAMP	78	32	36
31	0521057207	ELECTRIC ASSEMBLY BCE (EMB) APT	208	01	01
31.	0521058744	ELECTRICAL ASSY 19 MT/5F LED APT	189	00	01
32	0521055353	SUPPORT WITH BLOCK DIVIDER FOR 2 TURBINES	210	01	00
32.	0521055354	SUPPORT WITH FLOW DIVIDER BLOCK FOR 3 TURBINES	211	00	01
33	0521059540	ASSY TRACTOR HITCH AXLE	24	01	01
34	0503010045	O'RING		01	01
35	0541010080	TERMINAL R.1 / 2 NPT		01	01
36	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01	01
37	0581013729	NIPLE 1/2 NPT		01	01
38	0503011883	PLASTIC COVER		01	01
39	0511059406	TURBINE PP MOUNTED	60	00	01
40	0581018653	LESSER PROTECTION		00	02
41	0521051437	BOX ECU APT TVT NO EXCHANGE		00	01
42	0521059551	CENTRAL SHAFT AXLE		00	01
43	0521051442	MOTOR SUPPORT ASSY	83	00	01
44	0511033763	PLASTIC COVER WITH INSTRUCTIONS MANUAL		01	01
45	0521055006	ASSY ALTERNATOR SUPPORT P.P	150	00	01
46		SEED LINE/ASSY FERTILIZER	5		

LEFT SIDE FRAME ASSY

0909095826




Item	Code	Description	See page	15900	17900
01	0501110947	LEFT FRAME WITH GLOVE 5567		01	00
01.	0501110983	LEFT CHASSIS WITH GLOVE 6567		00	01
01A	0521069758	LEFT FRAME 5567 X 5325		01	00
01A.	0531060117	LEFT CHASSIS 6567 X 6235		00	01
01B	0581012179	BUSHING		02	02
02	0503015062	TUBE		03	04mts
03	0503010002	1800 GREASE FITTING		01	01
04	0521053054	ASSY SIDE HANDLE	25	01	01
05	0521055325	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	26	02	02
06	0521058893	LH SUPPORT	213	01	00
06.	0521056782	LEFT SUPPORT 5 MOUTH 2033 X 1224 ASSY	215	00	01
07	0521058894	SIDE SUPPORT	214	01	00
07.	0521056781	LEFT SIDE SUPPORT 4 MOUTH 1633 X 1274 ASSY	216	00	02
08	0521062769	SILO SUPPORT FIXER		02	00
08.	0531050753	ASSY SILO SUPPORT FIXER 410	39	00	02
08..	0531050752	ASSY SILO SUPPORT FIXER 400	40	00	02
09	0531051181	SIDE SILO SUPPORT SHOE WITH FIXATIONS	42	04	06
10	0521058964	SIDE PLATFORM	43	01	00
10.	0521056356	SIDE PLATFORM ASSY	44	00	01
11	0521058384	LEFT SIDE CORRIMAO	224	01	00
11.	0521059563	LEFT SIDE HANDRAIL 6567	217	00	01
12	0521058891	LADDER ASSY	57	01	00
12.	0511053320	ASSY SIDE LADDER	58	00	01
13	0521051406	TURBINE P.P SIDE FRAME WITH FIXATION	59	01	01
14	0521058380	RIGHT SIDE AIR DUTY ASSEMBLY	228	01	00
14.	0531054730	LEFT SIDE AIR DUCT ASSEMBLY	221	00	01
14..	0521056364	LEFT SIDE AIR DUCT ASSEMBLY	222	00	01
15	0503011372	102 TO 121 CLAMP		03	04
16	0521058381	SIDE SHAFT ASSEMBLY	68	01	00
16.	0531051298	SIDE GUTTER ASSY	69	00	01
16..	0521056358	SIDE CHANNEL SET 36E50	67	00	01
17	0521058382	LEFT SIDE DUTY ASSEMBLY	230	01	00

LEFT SIDE FRAME ASSY

0909095826

Item	Code	Description	See page	15900	17900
17.	0521059582	SUPREME USAP SIDE DUCT ASSEMBLY	231	00	01
18	0521058383	SET LABEL ADHESIVE	79	01	00
18.	0521056361	SIDE ADHESIVE LABEL ASSY	80	00	01
19	0521050332	VACUOMETER WITH ASSY SUPPORT	81	01	01
20	0521056360	SIDE HEXAGONAL AXLE 36E500 COMPLETE	82	00	01
21	0521051442	MOTOR SUPPORT ASSY	83	00	01
22	0521058426	ASSY FILTER SUPPORT	232	00	01
23	0503011968	NUT 3/4" 8R6X-S T ADAPTER WITH SWIVEL		00	01
24		SEED LINE/ASSY FERTILIZER	5		




Item	Code	Description	See page	15900	17900
01	0521058739	LONG FRONT SEED ROW	87	01	00
01.	0531054675	FRONT INTERNAL LONG SEED LINE VDRIVE	88	00	01
01..	0521058583	LONG SEED LINE FRONT CBA/CA WITHOUT LUBRICATION	89	01	01
02	0521058738	AVANT LIGNE SEMENCE COURTE	91	01	00
02.	0531054677	FRONT INTERNAL SHORT SEED LINE VDRIVE	92	00	01
02..	0521058584	FRONT LINE SEED SHORT CBA/CA WITHOUT LUBRICATION	93	01	01
03	0521058736	AVANT LIGNE SEMENCE LONGUE	94	01	00
03.	0531054676	FRONT LONG SEED LINE VDRIVE	95	00	01
03..	0521058592	INTERNAL FRONT LONG SEED LINE CBA / CA WITHOUT LUBRICATION	96	01	01
04	0521058737	SHORT SEED ROW FRONT	97	01	00
04.	0531054678	FRONT SHORT SEED LINE VDRIVE	98	00	01
04..	0521058591	INTERNAL FRONT SHORT SEED LINE CBA / CA WITHOUT LUBRICATION	99	01	01
05	0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	101	01	00
06	0521058904	REAR LEFT VDRIVE CSU	111	01	00
06.	0521058888	REAR WITH LEFT DDD SPICRR P.P V-DRIVE	112	00	01
07	0521058903	RIGHT REAR VDRIVE CSU	113	01	00
07.	0521058887	REAR WITH RIGHT DDD SPICRR PP V-DRIVE	114	00	01
08	0521050525	FIXER FERTILIZER CONDUCTOR	38	01	00
09	0503062407	SET SOYBEAN DISTRIBUTION		01	00
09.	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		00	01
10	0503011372	102 TO 121 CLAMP		01	01
11	0503010184	CLAMP		01	01
12	0503018829	NYLON CLAMP 7,8 X 1,8 X 390 MM		01	01
13	0503062433	SEED TUBE WITH SENSOR		01	00
14	0521052549	CLAMP	78	01	01
15	0531013600	PRESS ADJUSTMENT LEVER		01	01
16	0521068982	DISC BLADE HUB KEY		01	01
17	0561016889	STRIPED CAP WHEEL DEPTH		00	01


Item	Code	Description	See page	15900	17900
18	0521054470	CONDUCTOR 3 LOWER LONG ASSY	125	00	05
19	0521054471	CONDUCTOR 3 LOWER SHORT ASSY	126	00	05
20	0521055346	20 BLADE DISC ASSY	127	01	00
21	0521055349	ASSY DPL20 CUTTING DISC	128	00	01
22	0503063060	TRANSMISSION ASSY P.P LONG LINE 1253MM		00	01
23	0503063061	TRANSMISSION ASSY P.P SHORT LINE 1076MM		00	01

TELESCOPIC ASSY

0521058343




Item	Code	Description	See page	QT
01	0503015764	BOLT 7/8		01
02	0501010076	FLAT WASHER		01
03	0503010408	7/8" SPRING WASHER		01
04	0503010417	7/8" NUT		01
05	0503011052	1.1/4" X 0.77" CASTLE NUT		03
06	0503010038	3/16" X 2" SPLIT PIN		03
07	0503010002	1800 GREASE FITTING		03
08	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		08
09	0503010233	5/8 UNC X 2.1/2 CS G.5 ZN BOLT		04
10	0503010027	5/8 SPRING WASHER		04
11	0503010013	5/8 UNC G.5 ZN HEX NUT		04
12	0521051433	FRENCH HAND FRONT AXLE ASSY		02
12A	0511069442	FRENCH HAND FRONT AXLE		01
12B	0501017779	FLAT WASHER 32 X 60 X 4,75		01
12C	0503011052	1.1/4" X 0.77" CASTLE NUT		01
12D	0503010038	3/16" X 2" SPLIT PIN		01
12E	0581014420	GUIDE SLEEVE		02
13	0531061064	TELESCOPIC DRAWBAR		01
14	0531060748	REST SUPPORT		01
15	0531060747	TELESCOPIC HOSE GUIDE		01
16	0531060746	AXIS 278 TELESCOPIC HEADER		03
17	0521069860	INTERNAL CANUDE HEADER TELESCOPE 4986		01
18	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		01



Item	Code	Description	See page	QT
01	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		08
02	0503010027	5/8 SPRING WASHER		04
03	0503010013	5/8 UNC G.5 ZN HEX NUT		04
04	0503011052	1.1/4" X 0.77" CASTLE NUT		03
05	0503010038	3/16" X 2" SPLIT PIN		03
06	0531060747	TELESCOPIC HOSE GUIDE		01
07	0531060746	AXIS 278 TELESCOPIC HEADER		03
08	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		01
09	0503015764	BOLT 7/8		01
10	0501010076	FLAT WASHER		01
11	0503010408	7/8" SPRING WASHER		01
12	0503010417	7/8" NUT		01
13	0503010002	1800 GREASE FITTING		03
14	0521069861	INTERNAL STRAW CAB TEDESC 6000		01
15	0503010233	5/8 UNC X 2.1/2 CS G.5 ZN BOLT		04
16	0521051433	FRENCH HAND FRONT AXLE ASSY		02
16A	0511069442	FRENCH HAND FRONT AXLE		01
16B	0501017779	FLAT WASHER 32 X 60 X 4,75		01
16C	0503011052	1.1/4" X 0.77" CASTLE NUT		01
16D	0503010038	3/16" X 2" SPLIT PIN		01
16E	0581014420	GUIDE SLEEVE		02
17	0531061408	TELESCOPIC HEADERS 3220/4250		01
18	0531060748	REST SUPPORT		01

PANTOGRAPHY HEADER


0521057792




Item	Code	Description	See page	QT
01	0531060744	UPPER ARM PANTOGRAPHIC HEADER		01
02	0531060743	LOWER ARM PANTOGRAPHIC HEADER		01
03	0531060745	PANTOGRAPHIC ARM EAR		02
04	0502040864	GEAR BOX WITH REGULATOR		01
05	0521068007	TRACTOR HITCH		01
06	1902040327	LOCK SLEEVE		01
07	0503010523	1/4 X 2 SPLIT PIN		01
08	0503010002	1800 GREASE FITTING		04
09	0521063432	LOCK AXLE		02
10	0503031035	HITCH PIN CLIP		02
11	0531060746	AXIS 278 TELESCOPIC HEADER		02
12	0531060792	AXIS 200 TELESCOPIC HEADER		01
13	0531060776	HYDRAULIC HOSE SUPPORT FIXER		01
14	0503011052	1.1/4" X 0.77" CASTLE NUT		02
15	0503010038	3/16" X 2" SPLIT PIN		03
16	0521010578	COUPLING SHAFT		01
17	0521057786	HYDRAULIC CYLINDER HEAD PANTOGRAPH	9	01
18	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		02

HYDRAULIC CYLINDER HEAD PANTOGRAPH


0521057786




Item	Code	Description	See page	QT
01	0531060769	PANTOGRAPHIC HEAD CYLINDER CASE		01
02	0531060770	PANTOGRAPHIC HEAD CYLINDER ROD		01
03	0503010817	1.1/4" SELF LOCKING NUT		01
04	0503010345	2-218 N 3006-9B O'RING		01
05	0502010382	5" END CAP		01
06	0581010353	RING SUPPORT		01
07	0503018026	GASKET 1870-2000-375 B POLYMAX		01
08	0503011453	O'RING		02
09	0503018152	O'RING		02
10	0503018024	RING BS OD050805200171D-BR		01
11	0503018025	RING GUIDE W2-2250-750		01
12	0581010354	PISTON		01
13	0503018150	RING GUIDE W2-5000-984 (4528)		01
14	0503018151	RING BS		02
15	0503010039	D-2000 SCRAPER RING		01
16	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
001	0503010002	1800 GREASE FITTING		01
002	1902010477	UPPER CLAMP BODY		09
003	0511054713	ASSY TRANSMISSION SHAFT	16	01
004	0521058088	BALLET WITH EXTENSION AXLE 2	17	01
005	0501010984	10,50 X 27 X 3,00 FLAT WASHER		09
006	0503010025	3/8" SPRING WASHER		09
007	0503010964	BOLT		06
008	0503010589	1/2" UNC SELF ADJUSTING NUT		06
009	0503011404	BOLT		09
010	0591010925	FRENCH HAND RAIL		02
011	0521069494	DUCT OIL		02
012	0521069492	DUCT OIL		01
013	0531060085	FRENCH HAND 4855		01
014	0502012907	FRENCH HAND DUCTS SUPPORT		06
015	0521069493	DUCT OIL		02
016	0521053050	ASSY RAIL GUIDE		01
016A	0571011891	GUIDE RAIL		01
016B	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
016C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
016D	0503010337	NUT 5/16 UNC G.5 ZN		02
016E	0503011952	5/16" X 3/4" BOLT		02
017	0581018419	SUPPORT		03




Item	Code	Description	See page	QT
01	0521069853	FRENCH HAND 5805		01
02	0502010477	HOSE CLAMP		16
03	0503010002	1800 GREASE FITTING		01
04	0511054713	ASSY TRANSMISSION SHAFT	16	01
05	0521058088	BALLET WITH EXTENSION AXLE 2	17	01
06	0501082208	HOSE 3/4 X 180 TR-TR		02
07	0521069852	R.1.1/16 X 2260 OIL DUCT		04
08	0503010964	BOLT		08
09	0503010589	1/2" UNC SELF ADJUSTING NUT		08
10	0502012907	FRENCH HAND DUCTS SUPPORT		08
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
12	0503010025	3/8" SPRING WASHER		16
13	0503010849	3/8" X 1-1/2" BOLT		16
14	0521069851	R.7/8 X 2260 OIL DUCT		08
15	0591010983	CHUTE FRENCH HAND 20 X 38 X 2285		02
16	0501082189	HOSE 1/2 X 160 TR-TR		04
17	0521069850	R.3/4 X 2260 OIL DUCT		02
18	0501082190	HOSE 3/8 X 160 TR-TR		01
19	0581018419	SUPPORT		04




Item	Code	Description	See page	QT
01	0521069853	FRENCH HAND 5805		01
02	0502010477	HOSE CLAMP		12
03	0503010002	1800 GREASE FITTING		01
04	0511054713	ASSY TRANSMISSION SHAFT	16	01
05	0521058088	BALLET WITH EXTENSION AXLE 2	17	01
06	0501082208	HOSE 3/4 X 180 TR-TR		02
07	0521069852	R.1.1/16 X 2260 OIL DUCT		04
08	0503010964	BOLT		08
09	0503010589	1/2" UNC SELF ADJUSTING NUT		08
10	0502012907	FRENCH HAND DUCTS SUPPORT		08
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		12
12	0503010025	3/8" SPRING WASHER		12
13	0503010849	3/8" X 1-1/2" BOLT		12
14	0521069851	R.7/8 X 2260 OIL DUCT		06
15	0591010983	CHUTE FRENCH HAND 20 X 38 X 2285		02
16	0501082189	HOSE 1/2 X 160 TR-TR		03
17	0521069850	R.3/4 X 2260 OIL DUCT		02
18	0501082190	HOSE 3/8 X 160 TR-TR		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	1902010477	UPPER CLAMP BODY		12
03	0511054713	ASSY TRANSMISSION SHAFT	16	01
04	0503010025	3/8" SPRING WASHER		12
05	0591010925	FRENCH HAND RAIL		02
06	0521069492	DUCT OIL		03
07	0521069493	DUCT OIL		04
08	0521053050	ASSY RAIL GUIDE		01
08A	0571011891	GUIDE RAIL		01
08B	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
08C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
08D	0503010337	NUT 5/16 UNC G.5 ZN		02
08E	0503011952	5/16" X 3/4" BOLT		02
09	0531060085	FRENCH HAND 4855		01
10	0521058088	BALLET WITH EXTENSION AXLE 2	17	01
11	0502012907	FRENCH HAND DUCTS SUPPORT		06
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		12
13	0503010964	BOLT		06
14	0503010589	1/2" UNC SELF ADJUSTING NUT		06
15	0503011404	BOLT		12
16	0581018419	SUPPORT		03




Item	Code	Description	See page	QT
01	0521069853	FRENCH HAND 5805		01
02	0503010002	1800 GREASE FITTING		01
03	0502010477	HOSE CLAMP		24
04	0511054713	ASSY TRANSMISSION SHAFT	16	01
05	0521058088	BALLET WITH EXTENSION AXLE 2	17	01
06	0501082189	HOSE 1/2 X 160 TR-TR		06
07	0501082190	HOSE 3/8 X 160 TR-TR		04
08	0503010589	1/2" UNC SELF ADJUSTING NUT		08
09	0503010964	BOLT		08
10	0502012907	FRENCH HAND DUCTS SUPPORT		08
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
12	0503010025	3/8" SPRING WASHER		16
13	0503010849	3/8" X 1-1/2" BOLT		12
14	0521069850	R.3/4 X 2260 OIL DUCT		08
15	0521069851	R.7/8 X 2260 OIL DUCT		12
16	0591010983	CHUTE FRENCH HAND 20 X 38 X 2285		02
17	0503013665	SCREW 3/8 UNC X 3.1/4 C S RP G.2 ZN		04




Item	Code	Description	See page	QT
01	0521069853	FRENCH HAND 5805		01
02	0503010002	1800 GREASE FITTING		01
03	0502010477	HOSE CLAMP		16
04	0511054713	ASSY TRANSMISSION SHAFT	16	01
05	0521058088	BALLET WITH EXTENSION AXLE 2	17	01
06	0501082189	HOSE 1/2 X 160 TR-TR		05
07	0501082190	HOSE 3/8 X 160 TR-TR		03
08	0503010589	1/2" UNC SELF ADJUSTING NUT		08
09	0503010964	BOLT		08
10	0502012907	FRENCH HAND DUCTS SUPPORT		08
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
12	0503010025	3/8" SPRING WASHER		16
13	0503010849	3/8" X 1-1/2" BOLT		16
14	0521069850	R.3/4 X 2260 OIL DUCT		06
15	0521069851	R.7/8 X 2260 OIL DUCT		10
16	0591010983	CHUTE FRENCH HAND 20 X 38 X 2285		02




Item	Code	Description	See page	QT
01	0521062244	PIVOT SHAFT		01
02	0551019529	FLAT WASHER		01
03	0503010027	5/8 SPRING WASHER		01
04	0503011267	BOLT 5/8" UNC X 1.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0531061046	LABEL WITH NUT R2 LEFT		01
02	0503010002	1800 GREASE FITTING		02
03	0501078990	TURNBUCKLE AXLE		01
04	0561019879	LOCK ATTACHMENT BAR		01



Item	Code	Description	See page	QT
01	0521063339	EASEL		06
02	0571011070	5/8" UNC FASTENER		06
03	0503010027	5/8 SPRING WASHER		12
04	0503010013	5/8 UNC G.5 ZN HEX NUT		12







Item	Code	Description	See page	QT
01	0503010571	1/4" X 1.1/2" SPLIT PIN		01
02	0521010784	COUPLING SHAFT		01
03	0531060758	AXLE JUNCTION 25.4 X 150 WITH HANDLE		01
04	0503030085	LOCK PIN		02
05	0531060667	REST		01
06	0521012533	COUPLING SHAFT		01
07	0531062876	INTERNAL TUBE WITH SHOE REST		01

GREATER TOOL BOX ASSY


0511053121




Item	Code	Description	See page	QT
01	0521063662	BOX OF TOOLS		01
02	0551018356	BOX OF TOOLS COVER ASSY		01
03	0521010528	0.3" X 1.6" COUPLING SHAFT		02
04	0503010140	1/8" X 3/4" SPLIT PIN		02
05	0503011907	NYLON HANDLE		01
06	0503010358	5/16" X 5/8" BOLT		02
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
08	0503010337	NUT 5/16 UNC G.5 ZN		02
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
10	0503010964	BOLT		02
11	0503010589	1/2" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0503014820	WATER JUG 25/26 LITERS		01
02	0503019262	SOAP DISH VACUUM		01




Item	Code	Description	See page	QT
01	0531060794	HYDRAULIC HOSE SUPPORT		01
02	0503015490	SELF-LOCKING NUT 7/16		02
03	0503011173	7/16" X 2" BOLT		02
04	0501010937	13,50 X 28 X 3,00 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521068010	HITCH AXLE		01
02	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0521068962	MANGO LATERAL		01
02	0503013357	3/8 SELF-ADJUSTING NUT		02
03	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0521064543	WHEEL SUPPORT		01
02	0561019929	FLAT WASHER		01
03	0551014511	CARRYING WHEEL AXIS GUIDE SLEEVE		02
04	0551014508	FLAT WASHER		01
05	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
06	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0502012731	WHEEL HOLDER		02
10	0503010002	1800 GREASE FITTING		03
11	0521064550	CARRYING-WHEELS FORK		01
12	0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)		01
13	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
14	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	27	01
15	0501010630	1.1/2" CASTLE NUT		01
16	0501017779	FLAT WASHER 32 X 60 X 4,75		02
17	0503011052	1.1/4" X 0.77" CASTLE NUT		02
18	0503010882	BOLT		01
19	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
20	0503010337	NUT 5/16 UNC G.5 ZN		01
21	0503033335	CURRENT 6 X 21 ELOS		01
22	0581017245	AXLE BODY		01
23	0531012874	FLAT WASHER		02
24	0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	28	01
25	0503010523	1/4 X 2 SPLIT PIN		03
26	0503010571	1/4" X 1.1/2" SPLIT PIN		02
27	0503012334	3/4" UNC X 3.1/2" BOLT		04
28	0503011075	3/4 UNC LOCK NUT		04




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010059	33287/33462 ROLLER BEARING		01
05	0503010009	RETAINER 00573-B		01
06	0503010086	SEAL 0009B-B		01
07	0551014473	SLEEVE		01
08	0503012702	KM-12 NUT		02
09	0503012703	LOCK WASHER		01
10	0503010002	1800 GREASE FITTING		01
11	0503011444	SPRING WASHER 5/16"		04
12	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
13	0503014048	HEX NUT M22 X 1,5" CH 32 X 33,5		08
14	0503014050	BOLT M22 X 1,5 X 77/87 188RT		08
15	0511068415	SEAL GUIDE		01




Item	Code	Description	See page	QT
01	0521069562	5" X 17" CYLINDER CASE		01
02	0503010345	2-218 N 3006-9B O'RING		01
03	0503010817	1.1/4" SELF LOCKING NUT		01
04	0581010353	RING SUPPORT		01
05	0581010354	PISTON		01
06	0503018150	RING GUIDE W2-5000-984 (4528)		01
07	0503018151	RING BS		02
08	0503018026	GASKET 1870-2000-375 B POLYMAX		01
09	0503011453	O'RING		02
10	0503018152	O'RING		02
11	0503018024	RING BS OD050805200171D-BR		01
12	0503018025	RING GUIDE W2-2250-750		01
13	0581019464	TURNBUCLE BODY		01
14	0571015629	CILINDER SPINDLE FORK		01
15	0503011094	BOLT 3/8" UNC X 2" C C S I 12.9		01
16	0503010026	3/8" NUT		01
17	0503010025	3/8" SPRING WASHER		01
18	0503010039	D-2000 SCRAPER RING		01
19	0502040876	COVER		01
20	0503030385	CYLINDER PLUG N-002		02
21	0511034219	CYLINDER REPAIR KIT 50,80 X 127 (0521054953)		01




Item	Code	Description	See page	QT
01	0503062962	SEED HOPPER 05 NOZZLES ASSY		01
02	0531060304	RIGHT SUPPORT 5 MOUTH 2128 X 1410		01
03	0521051407	FERTILIZER HOPPER FIXER	33	08
04	0503062767	SCRUFFY ARTICULATED SEED CONDUCTOR	35	03
05	0503062766	ARTICULATED SEED DRIVER ALIGNED	36	02
06	0521055364	ARTICULATED SEED CONDUCTOR SUPPORT	37	05




Item	Code	Description	See page	QT
01	0521051407	FERTILIZER HOPPER FIXER	33	08
02	0531060583	RH SUPPORT		01
03	0503062962	SEED HOPPER 05 NOZZLES ASSY		01
04	0521058329	SEED CONDUCTOR	34	05
05	0521050525	FIXER FERTILIZER CONDUCTOR	38	05



Item	Code	Description	See page	QT
01	0503062963	FERTILIZER HOPPER 06 NOZZLES		01
02	0521051407	FERTILIZER HOPPER FIXER	33	10
03	0531061062	SIDE SUPPORT		01
04	0521058329	SEED CONDUCTOR	34	06
05	0521050525	FIXER FERTILIZER CONDUCTOR	38	06




Item	Code	Description	See page	QT
01	0531060308	RIGHT SUPPORT 4 MOUTH 1633 X 1274		01
02	0503062961	FERTILIZER HOPPER ASSY		01
03	0503062766	ARTICULATED SEED DRIVER ALIGNED	36	02
04	0503062767	SCRUFFY ARTICULATED SEED CONDUCTOR	35	02
05	0521051407	FERTILIZER HOPPER FIXER	33	06
06	0521055364	ARTICULATED SEED CONDUCTOR SUPPORT	37	04




Item	Code	Description	See page	QT
01	0503012531	3/8" INOX NUT		01
02	0503012535	3/8" SPRING WASHER		01
03	0571019051	FIXER HOPPER WASHER		01
04	0503013751	3/8 UNC X 1.1/4 BOLT		01

SEED CONDUCTOR


0521058329




Item	Code	Description	See page	QT
01	0531061059	CONDUCTOR WITH FLANGED		01
02	0503010358	5/16" X 5/8" BOLT		02
03	0503010337	NUT 5/16 UNC G.5 ZN		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		03
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		06
06	0503010499	5/16 UNC BUTTERFLY NUT		01
07	0503011953	5/16" X 1" BOLT		01
08	0503013759	NUT		04
09	0581019780	COVER		01
10	0502012899	DUCT BODY		01
11	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		04
12	0503034859	BOX SEALING GASKET		01




Item	Code	Description	See page	QT
01	0503062294	CONDUCTOR ARTICULATOR		04
02	0503034037	CLAMP LOWER CONDUCTOR		02
03	0503034034	CLAMP UPPER CONDUCTOR		02
04	0503034677	OUTPUT NOZZLE		01
05	0503010305	6,50 X 17 X 1,50 ZN FLAT WASHER		08
06	0503014876	NUT PARLOCK 1/4"		08
07	0503010733	1/4" X 1-3/4" BOLT		08
08	0503019575	HEX NUT		12
09	0503019574	SCREW M 3 X 0,50 X 20		12




Item	Code	Description	See page	QT
01	0503062294	CONDUCTOR ARTICULATOR		04
02	0503034037	CLAMP LOWER CONDUCTOR		02
03	0503034034	CLAMP UPPER CONDUCTOR		02
04	0503034677	OUTPUT NOZZLE		01
05	0503010305	6,50 X 17 X 1,50 ZN FLAT WASHER		08
06	0503014876	NUT PARLOCK 1/4"		08
07	0503010733	1/4" X 1-3/4" BOLT		08
08	0503019575	HEX NUT		12
09	0503019574	SCREW M 3 X 0,50 X 20		12




Item	Code	Description	See page	QT
01	0581019780	COVER		01
02	0503011953	5/16" X 1" BOLT		01
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
04	0503012880	1/4" UNC SELF ADJUSTING NUT		04
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
07	0503010499	5/16 UNC BUTTERFLY NUT		01
08	0503013759	NUT		02
09	0502012900	UPPER DUCT BODY ARTICULATED		01
10	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		04
11	0503034859	BOX SEALING GASKET		01




Item	Code	Description	See page	QT
01	0502012864	CLAMP 3 CSU		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0531062073	SILO SUPPORT FIXER 410		01
02	0503010019	1/2" SPRING WASHER		02
03	0503011082	C1/2" X 1.3/4" SCREW		02
04	0561013871	FLAT WASHER 13,50 X 50 X 4,75 ZN		02




Item	Code	Description	See page	QT
01	0531062072	SILO SUPPORT FIXER 400		01
02	0503010019	1/2" SPRING WASHER		02
03	0503011082	C1/2" X 1.3/4" SCREW		02
07	0561013871	FLAT WASHER 13,50 X 50 X 4,75 ZN		02




Item	Code	Description	See page	QT
01	0531062346	SILO SUPPORT FIXER 312		01
02	0503010019	1/2" SPRING WASHER		02
03	0503011082	C1/2" X 1.3/4" SCREW		02
04	0561013871	FLAT WASHER 13,50 X 50 X 4,75 ZN		02




Item	Code	Description	See page	QT
01	0531062299	SIDE SILO SUPPORT SHOE		01
02	0551015037	5/8" UNC X 210 X 198 FASTENER		02
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
04	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		03
05	0503013389	5/8" SELF LOCKING NUT		04
06	0503010589	1/2" UNC SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
001	0581017737	PLATFORM 2570		01
002	0581017801	PLATFORM ASSY		01
003	0521053066	PLATFORM SUPPORT ASSY	45	03
004	0521058905	PLATFORM ASSY	46	01




Item	Code	Description	See page	QT
01	0591010990	PLATFORM 2700		01
02	0581018239	PLATFORM 1720		02
03	0521053066	PLATFORM SUPPORT ASSY	45	06




Item	Code	Description	See page	QT
01	0551019056	SIDE PLATFORM SUPPORT		01
02	0503010019	1/2" SPRING WASHER		07
03	0503010060	1/2 UNC G.5 ZN HEX NUT		07
04	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		07
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
001	0503010019	1/2" SPRING WASHER		07
002	0503010060	1/2 UNC G.5 ZN HEX NUT		07
003	0503010395	1/2" X 1-1/4" BOLT		07
004	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
005	0511072070	ASSY SIDE PLATFORM SUPPORT		01




Item	Code	Description	See page	QT
01	0521058385	RIGHT SIDE HANDRAIL 2549 X 2223	49	01
02	0521058341	FRONT SIDE CORRIMAO	55	01
03	0521058135	LEFT INTERNAL HANDRAIL LARGER	56	02



Item	Code	Description	See page	QT
01	0521056310	RIGHT SIDE HANDRAIL	51	01
02	0521056309	RIGHT SIDE HANDRAIL	52	01
03	0521055750	SIDE HANDRAIL	53	01
04	0521058135	LEFT INTERNAL HANDRAIL LARGER	56	02
05	0521056563	LEFT INTERNAL HANDRAIL		01




Item	Code	Description	See page	QT
01	0521067991	SIDE HANDRAIL		02
02	0511059383	INTERNAL HANDRAILING FIXER	50	10
03	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	54	05
04	0581012718	HANDRAIL		03
05	0591014392	TUBE		03
06	0581014825	TUBE 33,70 X 27 X 924		01
07	0581019622	TUBE 33,70 X 27 X 250		03
08	0581015992	33,70 X 27 X 354 TUBE		04



Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01

RIGHT SIDE HANDRAIL


0521056310



Item	Code	Description	See page	QT
001	0511059383	INTERNAL HANDRAILING FIXER	50	08
002	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	54	07
003	0521067991	SIDE HANDRAIL		02
004	0581012718	HANDRAIL		04
005	0581015992	33,70 X 27 X 354 TUBE		02
006	0581014825	TUBE 33,70 X 27 X 924		02
007	0591010989	TUBE 33.70 X 27 X 730		03
008	0591010985	TUBE 33.70 X 27 X 1339		03
009	0591010178	TUBE 33,70 X 27 X 150		03

RIGHT SIDE HANDRAIL


0521056309




Item	Code	Description	See page	QT
001	0521067991	SIDE HANDRAIL		02
002	0581014825	TUBE 33,70 X 27 X 924		02
003	0581015992	33,70 X 27 X 354 TUBE		02
004	0591010177	TUBE 33,70 X 27 X 1248		03
005	0511059383	INTERNAL HANDRAILING FIXER	50	08
006	0581012718	HANDRAIL		03
007	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	54	07
008	0581017332	TUBE		03
009	0591010178	TUBE 33,70 X 27 X 150		03

SIDE HANDRAIL


0521055750



Item	Code	Description	See page	QT
001	0511059383	INTERNAL HANDRAILING FIXER	50	08
002	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	54	01
003	0581012718	HANDRAIL		02
004	0521067991	SIDE HANDRAIL		02
005	0581015992	33,70 X 27 X 354 TUBE		02
006	0591010177	TUBE 33,70 X 27 X 1248		03




Item	Code	Description	See page	QT
01	0502012855	CENTRAL FIXER		01
02	0502012856	CENTRAL FIXER		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		02
04	0503015490	SELF-LOCKING NUT 7/16		02



Item	Code	Description	See page	QT
01	0591013447	TUBE 33,70 X 27 X 1652		03
02	0521067991	SIDE HANDRAIL		02
03	0511059383	INTERNAL HANDRAILING FIXER	50	08
04	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	54	07
05	0581014825	TUBE 33,70 X 27 X 924		03
06	0581015992	33,70 X 27 X 354 TUBE		04
07	0581012718	HANDRAIL		04
08	0581017391	TUBE		01
09	0581019622	TUBE 33,70 X 27 X 250		03

LEFT INTERNAL HANDRAIL LARGER


0521058135



Item	Code	Description	See page	QT
01	0591014006	LEFT BODY BIGGER INTERNAL HANDRAIL		01
02	0503013357	3/8 SELF-ADJUSTING NUT		02
03	0591011198	50MM HANDRAIL SUPPORT		02
04	0511059383	INTERNAL HANDRAILING FIXER	50	02
05	0581012718	HANDRAIL		01
06	0591014008	BODY L INTERNAL HANDRAIL 250 X 727		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503011268	3/8" X 2-1/2" BOLT		02

LADDER ASSY


0521058891




Item	Code	Description	See page	QT
001	0531061260	ASSY SIDE LADDER		01
002	0502012742	FIXER SUPPORT LADDER		02
003	0503013357	3/8 SELF-ADJUSTING NUT		02
004	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
005	0503011179	3/8" X 2-1/4" BOLT		02
006	0503010237	3/8" X 1" BOLT		04
007	0503010025	3/8" SPRING WASHER		04
008	0503010026	3/8" NUT		04

ASSY SIDE LADDER


0511053320




Item	Code	Description	See page	QT
01	0511069819	SIDE LADDER		01
02	0502012742	FIXER SUPPORT LADDER		02
03	0503013357	3/8 SELF-ADJUSTING NUT		02
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0503010237	3/8" X 1" BOLT		04
07	0503010025	3/8" SPRING WASHER		04
08	0503010026	3/8" NUT		04



Item	Code	Description	See page	QT
01	0581014830	FIXER MOVEL TURBINE		01
02	0511059406	TURBINE PP MOUNTED	60	01
03	0551015037	5/8" UNC X 210 X 198 FASTENER		02
04	0503010027	5/8 SPRING WASHER		08
05	0503010013	5/8 UNC G.5 ZN HEX NUT		08
06	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
07	0503010232	5/8" X 1.3/4" BOLT		04




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		04
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0581012096	ROUND SLEEVE		02
06	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
07	0521050154	PRECISION PLANTING TURBINE WITH HOLE	61	01
08	0503031087	AUTO CONTROL APPROVED DECAL		01
09	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
10	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
11	0503010143	1/4" SPRING WASHER		02
12	0503010144	1/4" NUT		02
13	0503010190	2-114 N 3006-9B O'RING		04
14	0501081235	1/2 X 650 TR- TC HOSE		01
15	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01

SUPREME RIGHT LATERAL DUCT ASSEMBLY


0531051564




Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY	65	03
02	0581018415	PROTECTION BODY		04
03	0511059928	SIDE DUTY SUPPORT	66	02
04	0581018407	BODY FASTENER 2 DUCTS		06
05	0503011268	3/8" X 2-1/2" BOLT		07
06	0503010025	3/8" SPRING WASHER		07
07	0503010026	3/8" NUT		07
08	0521069757	DUCT OIL		02
09	0521069107	OIL DUCT 03 EXIT R.3/4 X 2040		02
10	0521069299	RIGHT SIDE DUTY ASSEMBLY		01
11	0521069209	OIL DUCT R.7/8 X 1350		02
12	0501082190	HOSE 3/8 X 160 TR-TR		02




Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY	65	02
02	0581018407	BODY FASTENER 2 DUCTS		08
03	0581018415	PROTECTION BODY		08
04	0521068953	OIL PIPE R.7/8 X 829		02
05	0521069497	OIL PIPE R.3/4 X 829		01
06	0521069157	OIL TUBE		02
07	0521069355	OIL TUBE		02
08	0531060118	OIL DUCT 3 OUTPUTS R.3/4 X 1800		02
09	0531061178	OIL PIPE R1.1/16 X 829		02
10	0503011123	BOLT		02
11	0521069164	OIL PIPE R.7/8		01
12	0511059928	SIDE DUTY SUPPORT	66	04
13	0501082190	HOSE 3/8 X 160 TR-TR		02
14	0503011268	3/8\" X 2-1/2\" BOLT		08
15	0503010025	3/8\" SPRING WASHER		10
16	0503010026	3/8\" NUT		10




Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY	65	02
02	0581018407	BODY FASTENER 2 DUCTS		04
03	0521069157	OIL TUBE		02
04	0521069355	OIL TUBE		02
05	0581018415	PROTECTION BODY		04
06	0581018409	FASTENER BODY		04
07	0531060118	OIL DUCT 3 OUTPUTS R.3/4 X 1800		02
08	0531061178	OIL PIPE R1.1/16 X 829		02
09	0521069164	OIL PIPE R.7/8		01
10	0511059928	SIDE DUTY SUPPORT	66	04
11	0501082190	HOSE 3/8 X 160 TR-TR		02
12	0503011268	3/8" X 2-1/2" BOLT		10
13	0503010025	3/8" SPRING WASHER		10
14	0503010026	3/8" NUT		10




Item	Code	Description	See page	QT
01	0581011417	SUPPORT		01
02	0503010237	3/8" X 1" BOLT		02
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0581013094	DUTO HOLDER SUPPORT		01
02	0571019756	FASTENER 1/2 UNC X 220 X 198 ZN		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0581018295	GUTTER		02
02	0521055102	BIGGEST FULL GUTTER SUPPORT	77	04




Item	Code	Description	See page	QT
001	0591014390	GUTTER		01
002	0581017950	GUTTER 30 X 55 X 2330		01
003	0521055102	BIGGEST FULL GUTTER SUPPORT	77	04
003A	0581019560	SUPPORT CONDUCTOR		01
003B	0503010025	3/8" SPRING WASHER		02
003C	0503010026	3/8" NUT		02
003D	0503013029	3/8" X 3/4" BOLT		01
003E	0501011643	3/8 X 1" BOLT		01




Item	Code	Description	See page	QT
01	0591018389	CHANNEL 30 X 55 X 3320		01
02	0581018295	GUTTER		01
03	0521055102	BIGGEST FULL GUTTER SUPPORT	77	04




Item	Code	Description	See page	QT
001	0521058336	DRIVER AIR	75	01
002	0521055100	SUPPORT CONDUCTOR AIR ASSY GREATER	76	04
003	0521052549	CLAMP	78	22




Item	Code	Description	See page	QT
01	0521056311	RIGHT SIDE AIR CONDUCTOR 13 MOUTH 6280	74	01
02	0521055100	SUPPORT CONDUCTOR AIR ASSY GREATER	76	04
03	0521052549	CLAMP	78	13




Item	Code	Description	See page	QT
01	0521056262	CBA ASSY AIR DUCT FIXER SUPPORT	73	01
02	0521056311	RIGHT SIDE AIR CONDUCTOR 13 MOUTH 6280	74	01
03	0521055100	SUPPORT CONDUCTOR AIR ASSY GREATER	76	04
04	0521052549	CLAMP	78	13




Item	Code	Description	See page	QT
01	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
02	0503010337	NUT 5/16 UNC G.5 ZN		02
03	0503010371	5/16" X 1" BOLT		02
04	0503010025	3/8" SPRING WASHER		02
05	0503010026	3/8" NUT		02
06	0503010237	3/8" X 1" BOLT		02
07	0521018402	AIR CONDUCTOR CLAMP		01
08	0591010923	AIR DUCT SUPPORT		01




Item	Code	Description	See page	QT
01	0511057036	AIR DISTRIBUTOR BOARD	02	
01A	0503012567	T-JOIN FOR TUBE 110	01	
01B	0581013890	AIR DISTRIBUTOR SOCKET	01	
02	0581019594	CONDUCTOR BODY AIR 03 MOUTH 1400 04 HOLES	01	
03	0591010986	CONDUCTOR BODY	01	
04	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET	13	
04A	0503034812	SOCKET DISTRIBUTOR AR	01	
04B	0503012856	POP RIVET	04	
05	0521056049	AIR DISTRIBUTOR CAP WITH RIVET	02	
05A	0503034763	AIR DITRIBUTOR PUMP	01	
05B	0503015341	POP RIVET	02	
06	0581018832	AIR CONDUCTOR BODY 6 MOUTH 2860	01	



Item	Code	Description	See page	QT
001	0511057036	AIR DISTRIBUTOR BOARD		03
001A	0503012567	T-JOIN FOR TUBE 110		01
001B	0581013890	AIR DISTRIBUTOR SOCKET		01
002	0581019586	AIR CONDUCTOR BODY 1 MOUTH 268 04 HOLES		01
003	0581018874	CONDUCTOR BODY AIR 03 MOUTH 1360 04 HOLES		01
004	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		02
004A	0503034763	AIR DITRIBUTOR PUMP		01
004B	0503015341	POP RIVET		02
005	0591010986	CONDUCTOR BODY		01
006	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		11
006A	0503034812	SOCKET DISTRIBUTOR AR		01
006B	0503012856	POP RIVET		04
007	0591014391	CONDUCTOR BODY		01




Item	Code	Description	See page	QT
01	0521018402	AIR CONDUCTOR CLAMP		01
02	0571019615	CLAMP 1/2 UNC 130		01
03	0521069601	SUPPORT CONDUCTOR AIR		01
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	NUT 5/16 UNC G.5 ZN		02
08	0503010371	5/16" X 1" BOLT		02
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02




Item	Code	Description	See page	QT
01	0581019560	SUPPORT CONDUCTOR		01
02	0503010025	3/8" SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0503013029	3/8" X 3/4" BOLT		01
05	0501011643	3/8 X 1"BOLT		01

CLAMP

0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	SELF-LOCKING HEX NUT		01
05	0503011813	M6 X 1.2" BOLT		01




0503032988

PLANTIO DIRETO

0503033424



0503031565



0503032986

2

0503033416



0503033621


3

0503033417

LUBRIFICAR E REAPERTAR DIARIAMENTE
LUBRICATE AND TIGHTEN DAILY
LUBRICAR Y REAPRETAR DIARIAMENTE

0503031827

Item	Code	Description	See page	QT
01	0503032988	SEED DISTRIBUTOR CHART DECAL		01
02	0503032986	ADHESIVE LABEL		01
03	0503033621	WARNING DO NOT TRANSIT DECAL		01
04	0503033424	DIRECT PLANTING DECAL		01
05	0503033417	NUMBER 3 DECAL		01
06	0503033416	NUMBER 2 DECAL		01
07	0503031827	DAILY LUBRICATION AND RETIGHTENING DECAL		01
08	0503031565	CAUTION TRANSPORTATION DECAL		01



01


0503034682

3⁰⁴

0503033417

6⁰⁵

0503033420



02

0503032986

LUBRIFICAR E REAPERTAR DIARIAMENTE
LUBRICATE AND TIGHTEN DAILY
LUBRICAR Y REAPRETAR DIARIAMENTE

06

0503031827



03


0503033621




07

0503031565

Item	Code	Description	See page	QT
01	0503034682	ADHESIVE LABEL SEED TABLE		01
02	0503032986	ADHESIVE LABEL		01
03	0503033621	WARNING DO NOT TRANSIT DECAL		01
04	0503033417	NUMBER 3 DECAL		01
05	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING		01
06	0503031827	DAILY LUBRICATION AND RETIGHTENING DECAL		01
07	0503031565	CAUTION TRANSPORTATION DECAL		01




Item	Code	Description	See page	QT
01	0571019137	SWITCH FIXER		01
02	0503013584	VACUUM GAUGE		01
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0581014411	BREATHE		01




Item	Code	Description	See page	QT
01	0551019787	3/4 X 2750 HEX AXLE		01
02	0561010268	3/4 X 3390 HEX AXLE		01
03	0561015837	SLEEVE 31,75		01
04	0503010523	1/4 X 2 SPLIT PIN		01
05	0511054314	TRANSMISSION AXLE LOCK BUSHING		04
05A	0502012699	TRANSMISSION CASE LOCK BUSHING		01
05B	0503010256	3/8" X 3/4" BOLT		01

MOTOR SUPPORT ASSY


0521051442




Item	Code	Description	See page	QT
01	0521067940	SUPPORT HIDRAULIC MOTOR		01
02	0521051293	16Z/32Z GEAR BEARING	84	01
03	0521067333	DRIVER GEAR		01
04	0502012768	ROW SUPPORT CLAMP		01
05	0581014672	SUPPORT ENCODER		01
06	0503010337	NUT 5/16 UNC G.5 ZN		02
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
08	0503011953	5/16" X 1" BOLT		02
09	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
10	0503010019	1/2" SPRING WASHER		02
11	0503010060	1/2 UNC G.5 ZN HEX NUT		02
12	0503011807	SCREW M8 X 1,25X10		02
13	0503010811	5/8" UNF SELF ADJUSTING NUT		02
14	0501054655	CHAIN TENSIONER ASSY	85	01
15	0511059969	CHAIN TENSIONER	86	01
16	0503014626	40-1 CHAIN X 55 LINK + MENDING		01
17	0503012391	40-1 CHAIN X 83 LINK + MENDING		01
18	0521067982	36Z P1/2 SH GEAR		01
19	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		02
20	0511054314	TRANSMISSION AXLE LOCK BUSHING		02
20A	0502012699	TRANSMISSION CASE LOCK BUSHING		01
20B	0503010256	3/8" X 3/4" BOLT		01



Item	Code	Description	See page	QT
01	0581014670	DOUBLE GEAR AXLE		01
02	0521067941	DOUBLE GEAR AXLE		01
03	0503012882	BEARING		02
04	0503011945	503050 CLAMPING RING (FOR AXLE)		02
05	0581014671	DOUBLE GEAR SLEEVE		01
06	0501013519	FLAT WASHER		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0581012970	TIGHTENER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01

LONG FRONT SEED ROW


0521058739




Item	Code	Description	See page	QT
01	0581018676	SLEEVE ARM SEED ROW	08	
02	0531061203	SEED LINE FRAME VDRIVE	01	
03	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
04	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN	04	
05	0571012310	ROW LOCK BODY	01	
06	0551015826	SEED ROW LOCK GUIDE SLEEVE	01	
07	0503010232	5/8" X 1.3/4" BOLT	01	
08	0503030168	HITCH PIN CLIP	04	
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN	01	
10	0503033728	FIXED SPRING PIN	02	
11	0571014704	UPPER AXLE	01	
12	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	01	
13	0502012768	ROW SUPPORT CLAMP	02	
14	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN	04	
15	0521068452	UP SUPPORT	01	
16	0581019795	SEED ARM SUPPORT ROW	01	
17	0581019796	LOWER ARM LARGER	01	
18	0503010878	5/8" SELF ALIGNING NUT	04	
19	0521068188	HOSE GUIDE	01	
20	0503010025	3/8" SPRING WASHER	01	
21	0503010026	3/8" NUT	01	
22	0501011643	3/8 X 1" BOLT	01	
23	0503019273	AUTO LUBRICANT SLEEVE	08	
24	0503010045	O'RING	08	
25	0503013389	5/8" SELF LOCKING NUT	01	
26	0503010421	5/16" X 1-1/2" BOLT	01	
27	0503010179	LOCK WASHER 5/16 ZN 1K01528	01	
28	0502012568	UPPER ROCKER ARM	01	

FRONT INTERNAL LONG SEED LINE VDRIVE

0531054675




Item	Code	Description	See page	QT
01	0581018676	SLEEVE ARM SEED ROW	08	
02	0531061203	SEED LINE FRAME VDRIVE	01	
03	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
04	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN	04	
05	0571012310	ROW LOCK BODY	01	
06	0551015826	SEED ROW LOCK GUIDE SLEEVE	01	
07	0503010232	5/8" X 1.3/4" BOLT	01	
08	0503030168	HITCH PIN CLIP	04	
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN	01	
10	0503033728	FIXED SPRING PIN	02	
11	0571014704	UPPER AXLE	01	
12	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	01	
13	0502012768	ROW SUPPORT CLAMP	02	
14	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN	04	
15	0521068453	LONG FRONT SEED ROW	01	
16	0581019795	SEED ARM SUPPORT ROW	01	
17	0581019796	LOWER ARM LARGER	01	
18	0503010878	5/8" SELF ALIGNING NUT	04	
19	0521068188	HOSE GUIDE	01	
20	0503010025	3/8" SPRING WASHER	01	
21	0503010026	3/8" NUT	01	
22	0501011643	3/8 X 1" BOLT	01	
23	0503019273	AUTO LUBRICANT SLEEVE	08	
24	0503010045	O'RING	08	
25	0503013389	5/8" SELF LOCKING NUT	01	
26	0503010421	5/16" X 1-1/2" BOLT	01	
27	0503010179	LOCK WASHER 5/16 ZN 1K01528	01	
28	0502012568	UPPER ROCKER ARM	01	
29	0521058074	ARTICULATED DRIVING SUPPORT WITH FIXATION	100	01




Item	Code	Description	See page	QT
01	0581018676	SLEEVE ARM SEED ROW		08
02	0531060948	SEED ROW FRAME		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
05	0571012310	ROW LOCK BODY		01
06	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
07	0503010232	5/8" X 1.3/4" BOLT		01
08	0503030168	HITCH PIN CLIP		04
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		01
10	0503033728	FIXED SPRING PIN		02
11	0571014704	UPPER AXLE		01
12	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
13	0502012768	ROW SUPPORT CLAMP		02
14	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
15	0521068452	UP SUPPORT		01
16	0581019795	SEED ARM SUPPORT ROW		01
17	0581019796	LOWER ARM LARGER		01
18	0503013759	NUT		01
19	0503010878	5/8" SELF ALIGNING NUT		04
20	0521068188	HOSE GUIDE		01
21	0503010025	3/8" SPRING WASHER		01
22	0503010026	3/8" NUT		01
23	0501011643	3/8 X 1" BOLT		01
24	0503019273	AUTO LUBRICANT SLEEVE		08
25	0503010045	O'RING		08
26	0502012568	UPPER ROCKER ARM		01
27	0521068024	STELL CABLE GUIDE		01
28	0503011953	5/16" X 1" BOLT		01
29	0521058076	FRONT LINE BEARING	90	01
30	0503013389	5/8" SELF LOCKING NUT		01
31	0521058074	ARTICULATED DRIVING SUPPORT WITH FIXATION	100	01

FRONT LINE BEARING


0521058076




Item	Code	Description	See page	QT
01	0581014691	BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0503019373	6006 2RS1 NATIONAL BEARING		01
04	0503012858	502075 CLAMPING RING (FOR HOLE)		01
05	0581019823	BEARING AXLE BODY WITHOUT LUBRICATION		01
06	0503010707	501030 CLAMPING RING (FOR AXLE)		01
07	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
08	0503014876	NUT PARLOCK 1/4"		02
09	0503013759	NUT		02




Item	Code	Description	See page	QT
01	0521068448	SHORT SEED ROW FRONT SUPPORT		01
02	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION		01
03	0581018676	SLEEVE ARM SEED ROW		08
04	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION		01
05	0531061203	SEED LINE FRAME VDRIVE		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
08	0571012310	ROW LOCK BODY		01
09	0503030168	HITCH PIN CLIP		04
10	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		01
11	0503033728	FIXED SPRING PIN		02
12	0571014704	UPPER AXLE		01
13	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
14	0502012768	ROW SUPPORT CLAMP		02
15	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
16	0503010878	5/8" SELF ALIGNING NUT		04
17	0521068188	HOSE GUIDE		01
18	0503010025	3/8" SPRING WASHER		01
19	0503010026	3/8" NUT		01
20	0501011643	3/8 X 1" BOLT		01
21	0503019273	AUTO LUBRICANT SLEEVE		08
22	0503010045	O'RING		08
23	0503013389	5/8" SELF LOCKING NUT		01
24	0503010232	5/8" X 1.3/4" BOLT		01
25	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
26	0502012568	UPPER ROCKER ARM		01
27	0503010421	5/16" X 1-1/2" BOLT		01
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		01




Item	Code	Description	See page	QT
01	0581018676	SLEEVE ARM SEED ROW	08	
02	0531061203	SEED LINE FRAME VDRIVE	01	
03	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
04	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN	04	
05	0571012310	ROW LOCK BODY	01	
06	0551015826	SEED ROW LOCK GUIDE SLEEVE	01	
07	0503010232	5/8" X 1.3/4" BOLT	01	
08	0503030168	HITCH PIN CLIP	04	
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN	01	
10	0503033728	FIXED SPRING PIN	02	
11	0571014704	UPPER AXLE	01	
12	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	01	
13	0502012768	ROW SUPPORT CLAMP	02	
14	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN	04	
15	0521068449	SHORT SEED ROW FRONT	01	
16	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION	01	
17	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION	01	
18	0503010878	5/8" SELF ALIGNING NUT	04	
19	0521068188	HOSE GUIDE	01	
20	0503010025	3/8" SPRING WASHER	01	
21	0503010026	3/8" NUT	01	
22	0501011643	3/8 X 1" BOLT	01	
23	0503019273	AUTO LUBRICANT SLEEVE	08	
24	0503010045	O'RING	08	
25	0503013389	5/8" SELF LOCKING NUT	01	
26	0503010421	5/16" X 1-1/2" BOLT	01	
27	0503010179	LOCK WASHER 5/16 ZN 1K01528	01	
28	0502012568	UPPER ROCKER ARM	01	
29	0521058074	ARTICULATED DRIVING SUPPORT WITH FIXATION	100	01




Item	Code	Description	See page	QT
01	0581018676	SLEEVE ARM SEED ROW		08
02	0531060948	SEED ROW FRAME		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
05	0571012310	ROW LOCK BODY		01
06	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
07	0503010232	5/8" X 1.3/4" BOLT		01
08	0503030168	HITCH PIN CLIP		04
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		01
10	0503033728	FIXED SPRING PIN		02
11	0571014704	UPPER AXLE		01
12	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
13	0502012768	ROW SUPPORT CLAMP		02
14	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
15	0521068448	SHORT SEED ROW FRONT SUPPORT		01
16	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION		01
17	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION		01
18	0503013759	NUT		01
19	0503010878	5/8" SELF ALIGNING NUT		04
20	0521068188	HOSE GUIDE		01
21	0503010025	3/8" SPRING WASHER		01
22	0503010026	3/8" NUT		01
23	0501011643	3/8 X 1" BOLT		01
24	0503019273	AUTO LUBRICANT SLEEVE		08
25	0503010045	O'RING		08
26	0502012568	UPPER ROCKER ARM		01
27	0521068024	STELL CABLE GUIDE		01
28	0503011953	5/16" X 1" BOLT		01
29	0521058076	FRONT LINE BEARING	90	01
30	0503013389	5/8" SELF LOCKING NUT		01
31	0521058074	ARTICULATED DRIVING SUPPORT WITH FIXATION	100	01



Item	Code	Description	See page	QT
01	0581018676	SLEEVE ARM SEED ROW		08
02	0531061203	SEED LINE FRAME VDRIVE		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
05	0571012310	ROW LOCK BODY		01
06	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
07	0503010232	5/8" X 1.3/4" BOLT		01
08	0503030168	HITCH PIN CLIP		04
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		01
10	0503033728	FIXED SPRING PIN		02
11	0571014704	UPPER AXLE		01
12	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
13	0502012768	ROW SUPPORT CLAMP		02
14	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
15	0521068453	LONG FRONT SEED ROW		01
16	0581019795	SEED ARM SUPPORT ROW		01
17	0581019796	LOWER ARM LARGER		01
18	0503010878	5/8" SELF ALIGNING NUT		04
19	0521068188	HOSE GUIDE		01
20	0503010025	3/8" SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0501011643	3/8 X 1" BOLT		01
23	0503019273	AUTO LUBRICANT SLEEVE		08
24	0503010045	O'RING		08
25	0503013389	5/8" SELF LOCKING NUT		01
26	0503010421	5/16" X 1-1/2" BOLT		01
27	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
28	0502012568	UPPER ROCKER ARM		01




Item	Code	Description	See page	QT
01	0581018676	SLEEVE ARM SEED ROW	08	
02	0531061203	SEED LINE FRAME VDRIVE	01	
03	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
04	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN	04	
05	0571012310	ROW LOCK BODY	01	
06	0551015826	SEED ROW LOCK GUIDE SLEEVE	01	
07	0503010232	5/8" X 1.3/4" BOLT	01	
08	0503030168	HITCH PIN CLIP	04	
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN	01	
10	0503033728	FIXED SPRING PIN	02	
11	0571014704	UPPER AXLE	01	
12	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	01	
13	0502012768	ROW SUPPORT CLAMP	02	
14	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN	04	
15	0521068452	UP SUPPORT	01	
16	0581019795	SEED ARM SUPPORT ROW	01	
17	0581019796	LOWER ARM LARGER	01	
18	0503010878	5/8" SELF ALIGNING NUT	04	
19	0521068188	HOSE GUIDE	01	
20	0503010025	3/8" SPRING WASHER	01	
21	0503010026	3/8" NUT	01	
22	0501011643	3/8 X 1"BOLT	01	
23	0503019273	AUTO LUBRICANT SLEEVE	08	
24	0503010045	O'RING	08	
25	0503013389	5/8" SELF LOCKING NUT	01	
26	0503010421	5/16" X 1-1/2" BOLT	01	
27	0503010179	LOCK WASHER 5/16 ZN 1K01528	01	
28	0502012568	UPPER ROCKER ARM	01	
29	0521058074	ARTICULATED DRIVING SUPPORT WITH FIXATION	100	01




Item	Code	Description	See page	QT
01	0521068453	LONG FRONT SEED ROW		01
02	0581019795	SEED ARM SUPPORT ROW		01
03	0581018676	SLEEVE ARM SEED ROW		08
04	0581019796	LOWER ARM LARGER		01
05	0531060948	SEED ROW FRAME		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
08	0571012310	ROW LOCK BODY		01
09	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
10	0503010232	5/8" X 1.3/4" BOLT		01
11	0503030168	HITCH PIN CLIP		04
12	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		01
13	0503033728	FIXED SPRING PIN		02
14	0571014704	UPPER AXLE		01
15	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
16	0502012768	ROW SUPPORT CLAMP		02
17	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
18	0503010878	5/8" SELF ALIGNING NUT		04
19	0521068188	HOSE GUIDE		01
20	0503010025	3/8" SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0501011643	3/8 X 1" BOLT		01
23	0503019273	AUTO LUBRICANT SLEEVE		08
24	0503010045	O'RING		08
25	0502012568	UPPER ROCKER ARM		01
26	0521068024	STELL CABLE GUIDE		01
27	0503011953	5/16" X 1" BOLT		01
28	0521058076	FRONT LINE BEARING	90	01
29	0503013759	NUT		01
30	0503013389	5/8" SELF LOCKING NUT		01
31	0521058074	ARTICULATED DRIVING SUPPORT WITH FIXATION	100	01

SHORT SEED ROW FRONT


0521058737




Item	Code	Description	See page	QT
01	0521068449	SHORT SEED ROW FRONT		01
02	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION		01
03	0581018676	SLEEVE ARM SEED ROW		08
04	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION		01
05	0531061203	SEED LINE FRAME VDRIVE		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
08	0571012310	ROW LOCK BODY		01
09	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
10	0503010232	5/8" X 1.3/4" BOLT		01
11	0503030168	HITCH PIN CLIP		04
12	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		01
13	0503033728	FIXED SPRING PIN		02
14	0571014704	UPPER AXLE		01
15	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
16	0502012768	ROW SUPPORT CLAMP		02
17	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
18	0503010878	5/8" SELF ALIGNING NUT		04
19	0521068188	HOSE GUIDE		01
20	0503010025	3/8" SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0501011643	3/8 X 1" BOLT		01
23	0503019273	AUTO LUBRICANT SLEEVE		08
24	0503010045	O-RING		08
25	0503013389	5/8" SELF LOCKING NUT		01
26	0502012568	UPPER ROCKER ARM		01
27	0503010421	5/16" X 1-1/2" BOLT		01
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		01




Item	Code	Description	See page	QT
01	0581018676	SLEEVE ARM SEED ROW	08	
02	0531061203	SEED LINE FRAME VDRIVE	01	
03	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
04	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN	04	
05	0571012310	ROW LOCK BODY	01	
06	0551015826	SEED ROW LOCK GUIDE SLEEVE	01	
07	0503010232	5/8" X 1.3/4" BOLT	01	
08	0503030168	HITCH PIN CLIP	04	
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN	01	
10	0503033728	FIXED SPRING PIN	02	
11	0571014704	UPPER AXLE	01	
12	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	01	
13	0502012768	ROW SUPPORT CLAMP	02	
14	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN	04	
15	0521068448	SHORT SEED ROW FRONT SUPPORT	01	
16	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION	01	
17	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION	01	
18	0503010878	5/8" SELF ALIGNING NUT	04	
19	0521068188	HOSE GUIDE	01	
20	0503010025	3/8" SPRING WASHER	01	
21	0503010026	3/8" NUT	01	
22	0501011643	3/8 X 1" BOLT	01	
23	0503019273	AUTO LUBRICANT SLEEVE	08	
24	0503010045	O'RING	08	
25	0503013389	5/8" SELF LOCKING NUT	01	
26	0503010421	5/16" X 1-1/2" BOLT	01	
27	0503010179	LOCK WASHER 5/16 ZN 1K01528	01	
28	0502012568	UPPER ROCKER ARM	01	
29	0521058074	ARTICULATED DRIVING SUPPORT WITH FIXATION	100	01




Item	Code	Description	See page	QT
01	0521068449	SHORT SEED ROW FRONT		01
02	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION		01
03	0581018676	SLEEVE ARM SEED ROW		08
04	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION		01
05	0531060948	SEED ROW FRAME		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
08	0571012310	ROW LOCK BODY		01
09	0551015826	SEED ROW LOCK GUIDE SLEEVE		01
10	0503010232	5/8" X 1.3/4" BOLT		01
11	0503030168	HITCH PIN CLIP		04
12	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		01
13	0503033728	FIXED SPRING PIN		02
14	0571014704	UPPER AXLE		01
15	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
16	0502012768	ROW SUPPORT CLAMP		02
17	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
18	0503010878	5/8" SELF ALIGNING NUT		04
19	0521068188	HOSE GUIDE		01
20	0503010025	3/8" SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0501011643	3/8 X 1" BOLT		01
23	0503019273	AUTO LUBRICANT SLEEVE		08
24	0503010045	O'RING		08
25	0502012568	UPPER ROCKER ARM		01
26	0521068024	STELL CABLE GUIDE		01
27	0503011953	5/16" X 1" BOLT		01
28	0521058076	FRONT LINE BEARING	90	01
29	0503013759	NUT		01
30	0503013389	5/8" SELF LOCKING NUT		01
31	0521058074	ARTICULATED DRIVING SUPPORT WITH FIXATION	100	01




Item	Code	Description	See page	QT
01	0571018436	TUBE CAP UPPER		01
02	0501011643	3/8 X 1" BOLT		02
03	0503013357	3/8 SELF-ADJUSTING NUT		02



Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	102	01
02	0521055068	RAYED WHEEL CENTER CLOSED	106	02
03	0521054990	LEFT COMPACTOR WHEEL	108	01
04	0521055017	RIGHT COMPACTOR WHEEL	110	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY		01
06	0503019398	AXLE RETAINER RING		01
07	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	103	01
08	0521055054	LEFT ARM WITH SLEEVE	104	01
09	0521055066	RIGHT ARM WITH SLEEVE	105	01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2 UNC G.5 ZN HEX NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED SLEEVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT SLEEVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" SPLIT PIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02

LEFT ARM WITH SLEEVE


0521055054




Item	Code	Description	See page	QT
01	0581019523	LEFT ARM WHEEL DEPTH		01
02	0581019514	LUBRICANT SLEEVE		02
03	0503011109	O'RING 2-119 N 3006 9B		02




Item	Code	Description	See page	QT
01	0581019524	RIGHT ARM DEPTH		01
02	0581019514	LUBRICANT SLEEVE		02
03	0503011109	O'RING 2-119 N 3006 9B		02




Item	Code	Description	See page	QT
01	0521055055	HUB WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	107	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	NUT 5/16 UNC G.5 ZN		06




Item	Code	Description	See page	QT
01	0581019522	CASE WHEEL DEPTH WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0503010143	1/4" SPRING WASHER		03
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019529	DEPTH REGULATOR SHAFT		01
11	0581019168	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	109	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	WHEEL HUB		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	109	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521056954	LEFT DDD ASSY		01
02	0521058758	ASSY P.P CSU V-DRIVE	134	01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" SPLIT PIN		01
05	0531050596	FENDER ASSY	140	01
06	0591017565	SEED CONDUCTOR GUIDE		01
07	0503015341	POP RIVET		02




Item	Code	Description	See page	QT
01	0521058085	REAR WITH DDD LEFT SPICRR	115	01
02	0521058758	ASSY P.P CSU V-DRIVE	134	01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" SPLIT PIN		01
05	0591017565	SEED CONDUCTOR GUIDE		01
06	0503015341	POP RIVET		02




Item	Code	Description	See page	QT
01	0521058758	ASSY P.P CSU V-DRIVE	134	01
02	0571017895	PIN FIXER CONDUCTOR P.P		01
03	0503010140	1/8" X 3/4" SPLIT PIN		01
04	0521056955	RIGHT DDD ASSY	139	01
05	0531050596	FENDER ASSY	140	01
06	0591017565	SEED CONDUCTOR GUIDE		01
07	0503015341	POP RIVET		02




Item	Code	Description	See page	QT
01	0521058084	REAR WITH RIGHT DDD SPICRR	116	01
02	0521058758	ASSY P.P CSU V-DRIVE	134	01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" SPLIT PIN		01
05	0591017565	SEED CONDUCTOR GUIDE		01
06	0503015341	POP RIVET		02



Item	Code	Description	See page	QT
01	0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	117	01
02	0502012923	BEATER		01
03	0521056632	DEPTH CONTROL	118	01
04	0591011323	AXLE ARTICULATION WHEEL DEPTH		02
05	0502012920	SUPPORT ADJUSTING		01
06	0502012611	DEPTH CONTROL AXLE		01
07	0591011309	ADJUSTMENT BUSHING		02
08	0591011310	ADJUSTMENT BAR		02
09	0503019275	SLEEVE LUBRICATION SYSTEM		01
10	0581019473	ARTICULATED SLEEVE		02
11	0503010045	O'RING		02
12	0503013357	3/8 SELF-ADJUSTING NUT		02
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
14	0591011326	LOCK PIN		01
15	0571015326	ARTICULATION SLEEVE HANDLE		01
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2 UNC G.5 ZN HEX NUT		02
18	0503010019	1/2" SPRING WASHER		04
19	0591011324	SMALLER AXLE		01
20	0591011325	LARGER AXLE		01
21	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
22	0503030012	HITCH PIN CLIP		02
23	0501011445	FLAT WASHER		04
24	0521056633	MOUNTED RIGHT ARM	119	01
25	0521056631	MOUNTED LEFT ARM	120	01
26	0503012556	1/2" X 1" BOLT		02
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
28	0591011306	ADJUSTMENT LOCK		02
29	0521055093	BODY COMPACTOR	123	01
30	0521054990	LEFT COMPACTOR WHEEL	108	01
31	0521055017	RIGHT COMPACTOR WHEEL	110	01




Item	Code	Description	See page	QT
01	0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	124	01
02	0502012923	BEATER		01
03	0521056632	DEPTH CONTROL	118	01
04	0591011323	AXLE ARTICULATION WHEEL DEPTH		02
05	0502012920	SUPPORT ADJUSTING		01
06	0502012611	DEPTH CONTROL AXLE		01
07	0591011309	ADJUSTMENT BUSHING		02
08	0591011310	ADJUSTMENT BAR		02
09	0503019275	SLEEVE LUBRICATION SYSTEM		01
10	0581019473	ARTICULATED SLEEVE		02
11	0503010045	O'RING		02
12	0503013357	3/8 SELF-ADJUSTING NUT		02
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
14	0591011326	LOCK PIN		01
15	0571015326	ARTICULATION SLEEVE HANDLE		01
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2 UNC G.5 ZN HEX NUT		02
18	0503010019	1/2" SPRING WASHER		04
19	0591011324	SMALLER AXLE		01
20	0591011325	LARGER AXLE		01
21	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
22	0503030012	HITCH PIN CLIP		02
23	0501011445	FLAT WASHER		04
24	0521056633	MOUNTED RIGHT ARM	119	01
25	0521056631	MOUNTED LEFT ARM	120	01
26	0503012556	1/2" X 1" BOLT		02
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
28	0591011306	ADJUSTMENT LOCK		02
29	0521055093	BODY COMPACTOR	123	01
30	0521054990	LEFT COMPACTOR WHEEL	108	01
31	0521055017	RIGHT COMPACTOR WHEEL	110	01



Item	Code	Description	See page	QT
01	0502012928	LEFT EXTENSOR		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 135 FERTILIZER / SEED		01
11	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 136 FERTILIZER / SEED		01

DEPTH CONTROL


0521056632



Item	Code	Description	See page	QT
01	0502012925	ADJUSTMENT BODY		01
02	0511015976	FLAT WASHER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0503010581	RING		01
05	0502012892	DEPTH CONTROL HANDLE		01
06	0581019526	ARTICULATED AXLE LEVER DEPTH		01
07	0503010302	501019 SEAL RING		01

MOUNTED RIGHT ARM


0521056633




Item	Code	Description	See page	QT
01	0502012926	RIGHT ARM		01
02	0503011109	O'RING 2-119 N 3006 9B		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 121 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01

MOUNTED LEFT ARM

0521056631




Item	Code	Description	See page	QT
01	0502012927	LEFT ARM		01
02	0503011109	O'RING 2-119 N 3006 9B		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 121 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503030891	RUBBER BAND		01
03	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
05	0503010337	NUT 5/16 UNC G.5 ZN		06
06	0521055073	ASSEMBLY DEPTH WHEEL HUB	122	01

ASSEMBLY DEPTH WHEEL HUB


0521055073




Item	Code	Description	See page	QT
01	0581019528	WHEEL DEPTH SPA HUB WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	DUST CLOAK		01
11	0581019529	DEPTH REGULATOR SHAFT		01




Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT		02
02	0503013816	5/16" LOCKNUT		04
03	0581015855	SLEEVE		02
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
05	0521068661	LEVER		01
06	0503030878	LEVER CRANK		01
07	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING		01
08	0581019520	AXIS		01
09	0571812442	COUPLING SHAFT		01
10	0503010257	1/8" X 1" SPLIT PIN		01
11	0581019511	COVER		01
12	0503010848	5/16" X 3.1/2" BOLT		02
13	0503010752	1/2" X 3.1/2" BOLT		01
14	0503011336	1/2" HEX SELF ADJUSTING NUT		01
15	0503030190	0.5" X 1.6" X 0.05" SPRING		01
16	0581019510	AXIS		01
17	0581019512	PLATE TOP		01
18	0503019351	LUBRICANT SLEEVE		02
19	0521069591	LEFT SIDE		01
20	0581019548	RIGHT SIDE BODY		01




Item	Code	Description	See page	QT
01	0502012929	BODY RIGHT		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 136 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 135 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0581019218	SEED CONDUCTOR		01
02	0521065815	GUIDE SUPPORT		01
03	0503010071	3/16" X 1" SPLIT PIN		01
04	0501011643	3/8 X 1"BOLT		01
05	0581018858	SEED CONDUCTOR		01
06	0521050525	FIXER FERTILIZER CONDUCTOR	38	02
07	0503013759	NUT		01
08	0503034678	COUPLING SET		01
09	0503017823	THREAD CLAMP WITHOUT END 14MM WIDTH		02
10	0521068727	FERTILIZER CONDUCTOR FIXER		01
11	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		01
12	0503013357	3/8 SELF-ADJUSTING NUT		01



Item	Code	Description	See page	QT
01	0503034678	COUPLING SET		01
02	0581019217	TUBE PVC		01
03	0521065815	GUIDE SUPPORT		01
04	0503010071	3/16" X 1" SPLIT PIN		01
05	0501011643	3/8 X 1"BOLT		01
06	0503017823	THREAD CLAMP WITHOUT END 14MM WIDTH		02
07	0521068727	FERTILIZER CONDUCTOR FIXER		01
08	0503013759	NUT		01
09	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		01
10	0581018858	SEED CONDUCTOR		01
11	0521050525	FIXER FERTILIZER CONDUCTOR	38	02
12	0503013357	3/8 SELF-ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0502012470	UPPER SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
03	0503012798	5/8" X 2" BOLT		04
04	0503010878	5/8" SELF ALIGNING NUT		04
05	0521055344	LOWER SUPPORT	129	01




Item	Code	Description	See page	QT
01	0502012470	UPPER SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
03	0521055348	LOWER SUPPORT WITH DPL 20 WITHOUT 132 LUBRICATION		01
04	0503012798	5/8" X 2" BOLT		04
05	0503010878	5/8" SELF ALIGNING NUT		04

LOWER SUPPORT

0521055344




Item	Code	Description	See page	QT
01	0503019277	SLEEVE LUBRICATION SYSTEM		03
02	0503019278	LUBRICANT SLEEVE		02
03	0581018679	SLEEVE		01
04	0581018677	SUPPORT DISC AXLE		01
05	0503010361	SPRING PIN		01
06	0551015883	SPRING GUIDES SLEEVE		02
07	0503031575	COMPRESSION SPRING		02
08	0521068189	SPRING REGULACION		02
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		02
10	0503010152	3/4\" SELF LOCKING NUT		01
11	0503010806	5/8\" X 3\" BOLT		02
12	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT		01
13	0503011075	3/4 UNC LOCK NUT		02
14	0503010878	5/8\" SELF ALIGNING NUT		02
15	0521054844	20\" WAVY COULTER BLADE HUB	130	01
16	0521069351	RIGHT ARM		01
17	0521069350	LEFT ARM		01
18	0503010410	RING		02
19	0502012898	BOTTOM BRACKET		01
20	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
21	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
22	0571012370	PROTECTION FRONT		01
23	0581018678	FLANGE WASHER		01




Item	Code	Description	See page	QT
01	0521053697	DISC BLADE HUB	131	01
02	0607026025	DPLO20X4,5		01

DISC BLADE HUB


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	DISC BLADE HUB		01
09	0502040873	DISC BLADE AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	FLAT WASHER 32,50 X 75 X 4,75		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0503019277	SLEEVE LUBRICATION SYSTEM		03
02	0503019278	LUBRICANT SLEEVE		02
03	0581018679	SLEEVE		01
04	0581018677	SUPPORT DISC AXLE		01
05	0503010361	SPRING PIN		01
06	0551015883	SPRING GUIDES SLEEVE		02
07	0503031575	COMPRESSION SPRING		02
08	0521068189	SPRING REGULACION		02
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		02
10	0503010152	3/4" SELF LOCKING NUT		01
11	0503010806	5/8" X 3" BOLT		02
12	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT		01
13	0503011075	3/4 UNC LOCK NUT		02
14	0503010878	5/8" SELF ALIGNING NUT		02
15	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	133	01
16	0521069351	RIGHT ARM		01
17	0521069350	LEFT ARM		01
18	0503010410	RING		02
19	0502012898	BOTTOM BRACKET		01
20	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
21	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
22	0571012370	PROTECTION FRONT		01
23	0581018678	FLANGE WASHER		01
24	0503010756	0.2" X 2.4" SPRING PIN		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	DISC BLADE HUB	131	01




Item	Code	Description	See page	QT
01	0502012924	PRECISION PLANTING SUPPORT		01
02	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
03	0503010589	1/2" UNC SELF ADJUSTING NUT		01
04	0503010140	1/8" X 3/4" SPLIT PIN		01
05	0571014024	FAST BOLT GUIDE AXLE		01
06	0503034824	FIXATIVE		01
07	0503010293	CLAMP KNOB		01
08	0503010025	3/8" SPRING WASHER		02
09	0502012922	FIXING SUPPORT		01
10	0503011404	BOLT		01
11	0503013357	3/8 SELF-ADJUSTING NUT		05
12	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04
13	0571019491	SLUICE PNEUMATIC		01
14	0501011643	3/8 X 1" BOLT		01
15	0503010209	3/8" UNC BUTTERFLY NUT		01
16	0502012807	SUPPORT HOPPER PRECISION PLANTING		01
17	0571019489	CLAMP PRECISION PLANTING		01
18	0503012721	1/4" X 4" BOLT		01
19	0503012880	1/4" UNC SELF ADJUSTING NUT		01
20	0503018139	BOLT M6 X 10 CYLINDRICAL HEAD WITH SLOT		03
21	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
22	0503015110	M06 SPRING WASHER		02
23	0503037390	PACKING FOR PLANTING		01
24	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
25	0503011953	5/16" X 1" BOLT		03
26	0503010337	NUT 5/16 UNC G.5 ZN		04
27	0503012163	5/16" X 1-1/2" BOLT		01
28	0581011226	FIXER CLOSING P. PLANTING CONTROL CPRA		01
29	0521052130	VSET2 DISTRIBUTOR WITH SOY VDRIVE DISK		01
30	0571019613	STRAW PRECISION PLANTING SHIELD		01
31	0521068012	FIXER LEVER LOWER		01




Item	Code	Description	See page	QT
01	0521055865	FERTILIZER/SEED LEFT HUB ASSY	137	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055864	FERTILIZER/SEED RIGHT HUB ASSY	138	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01



Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUBLE DISC AXLE		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0591011773	RIGHT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 135 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 136 FERTILIZER / SEED		01

FENDER ASSY


0531050596




Item	Code	Description	See page	QT
01	0591016908	FENDER		01
02	0503010589	1/2" UNC SELF ADJUSTING NUT		01
03	0503010479	BOLT		01




Item	Code	Description	See page	QT
01	0521069762	CENTRAL FRAME 4686		01
02	0521050019	TIGHTENING PLATE WITH FIXING INTERNAL	142	02
03	0503010131	3/16" X 1.1/2" SPLIT PIN		01
04	0521011132	FLAT WASHER		01
05	0521052189	38,10 X 63,50 X 386 X 148 HYDRAULIC CYLINDER	143	01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0571015217	TUBE ADJUSTMENT PLATE		01
02	0503010027	5/8 SPRING WASHER		08
03	0503011267	BOLT 5/8" UNC X 1.1/2 C S G.5 ZN		08




Item	Code	Description	See page	QT
01	0521068383	CYLINDER CASE		01
02	0581010670	CORPO HASTE 38,10 X 345		01
03	0511070058	GUIDE HIDRAULIC		01
04	0503010163	D-1500 SCRAPER RING		01
05	0502010471	63,50 MOBILE CAP		01
06	0581010668	RING SUPPORT		01
07	0503018004	RING		01
08	0503018003	GASKET		01
09	0503018163	BACK-UP RING		02
10	0503018162	O'RING		02
11	0503030385	CYLINDER PLUG N-002		02
12	0502012837	PISTON		01
13	0503018005	RING		01
14	0503011109	O'RING 2-119 N 3006 9B		01
15	0511032280	REPAIR KIT ASSY (0511058413)		01




Item	Code	Description	See page	QT
01	0581017863	ALTERNATOR SUPPORT BODY		01
02	0503011776	SELF-LOCKING HEX NUT		04
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
06	0503014734	BOLT		02




Item	Code	Description	See page	QT
01	0531054733	SUPREME USAP CENTRAL DUCT ASSEMBLY	146	01
02	0503063242	COMMAND BLOCK		01
03	0521057013	TRIPLE DIVISER VALVE BRP00079 WITH NIPLES	175	01
04	0521057495	SUPPORT BLOCK	176	01
05	0521055275	ASSY HOSE ARTICULATION	178	01
06	0521054018	ASSY HEAD HOSE CSC FRAME 20226	147	01
07	0531054728	SUPREME USAP LIFTING HOSE SET	148	01
08	0531054729	SUPREME USAP TURBINE HOSE SET	149	01
09	0501053834	MALE QUICK COUPLER	187	06
10	0581017815	MALE ADAPTER		01




Item	Code	Description	See page	QT
01	0521069009	OIL DUCT		01
02	0521069164	OIL PIPE R.7/8		08
03	0521069275	OIL TUBE		02
04	0521069163	OIL TUBE		02
05	0521069157	OIL TUBE		04
06	0581018409	FASTENER BODY		16
07	0521053537	CENTRAL REAR DUCT SUPPORT	172	04
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		08
09	0503011123	BOLT		08
10	0503010025	3/8" SPRING WASHER		16
11	0503010026	3/8" NUT		16
12	0591010127	SUPPORT LEFT DISTRIBUTOR		02
13	0581014867	SIDE DUTY SUPPORT		02



Item	Code	Description	See page	QT
01	0501080714	3/8 X 1600 TR-TC HOSE		02
02	0501080105	3/8 X 700 TR-TR HOSE		02
03	0501080128	3/8" X 71" TR-TR HOSE ASSY		02
04	0501081046	3/8" X 161.4" TC-TM HOSE ASSY		01
05	0501080390	3/8" X 150" TR-TC HOSE ASSY		01




Item	Code	Description	See page	QT
01	0501080105	3/8 X 700 TR-TR HOSE		04
02	0501080232	3/4" X 1100 TR-TR HOSE		02
03	0501080012	3/4 X 700 TR-TR HOSE		02
04	0501080599	3/8 X 650 TR-TC HOSE		02
05	0501080065	3/8" X 47" TC-TC HOSE		01
06	0501080175	3/4 X 900 TR-TC HOSE		01
07	0501080055	3/8" X 39" TR-TC HOSE		02
08	0501080302	3/8" X 55" TR-TC HOSE		01
09	0501080714	3/8 X 1600 TR-TC HOSE		01
10	0501081288	3/4 X 500 TR-TC HOSE		01
11	0501080019	3/4 X 1000 TR-TC HOSE		01
12	0501080675	3/8 X 1000 TC-TC 180G HOSE		03
13	0501080700	3/8 X 650 TC-TC HOSE		02
14	0501081254	3/8" X 900 TR-TC HOSE		02
15	0501082204	3/4 X 2750 TR-TR HOSE		02
16	0501081837	3/8 X 700 TR-TC HOSE		04
17	0501081838	3/8 X 1000 TR-TC HOSE		04
18	0521053712	3/4 X 5900 TR-TM BLACK/RED HOSE		01
18A	0501082205	3/4 X 5900 TR-TM HOSE		01
18B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
18C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
18D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
19	0521053707	3/4 X 5900 TR-TM BLACK/BLUE HOSE		01
19A	0501082205	3/4 X 5900 TR-TM HOSE		01
19B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
19C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
19D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0501080024	1/2" X 700 TR-TR HOSE		04
02	0501080048	3/8" X 78" TR-TR HOSE ASSY		03
03	0501080056	3/8" X 1700 TR-TC HOSE ASSY		01
04	0501080061	1/2" X 66.93" TR-TC HOSE		01
05	0501080091	1/2" X 550 TR-TR HOSE		02
06	0501080102	1/2" X 2200 TR-TR HOSE		02
07	0501080105	3/8 X 700 TR-TR HOSE		02
08	0501080346	1/2" X 2000 TR-TR HOSE ASSY		04
09	0501080348	3/8" X 47,24" TR-TC HOSE		02
10	0501080526	3/8" X 114.17" TR-TC HOSE		01
11	0501080618	1/2" X 86" TR-TC HOSE		04
12	0501080840	1/2" X 1400 TC-TC HOSE		01
13	0501081235	1/2 X 650 TR- TC HOSE		02
14	0501081415	3/8" X 2300 TR-TC HOSE ASSY		02
15	0501081510	1/2 X 1700 TR-TC HOSE		03
16	0501082025	HOSE 1/2 X 2900 TR-TR		04
17	0521052564	HOSE 1/2 X 5900 TR-TM YELLOW / BLUE		01
17A	0501081841	1/2 X 5900 TR-TM HOSE		01
17B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
17C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
17D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
18	0521052565	1/2 X 5900 TR-TM HOSE YELLOW / RED		01
18A	0501081841	1/2 X 5900 TR-TM HOSE		01
18B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
18C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
18D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
19	0521056426	HOSE 3/8 X 3200 TR-TM YELLOW/GREEN		01
19A	0501081848	HOSE 3/8 X 3200 TR-TM		01
19B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
19C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
19D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
20	0521056427	HOSE 3/4 X 3300 TR-TM YELLOW/RED		01


Item	Code	Description	See page	QT
20A	0501080887	HOSE 3/4 X 3300 TM-TR		01
20B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
20C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
21	0521056429	HOSE 3/4 X 3300 TR-TM YELLOW/BLUE		01
21A	0501080887	HOSE 3/4 X 3300 TM-TR		01
21B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
21C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
21D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0581013486	PP ALTERNATOR SUPPORT		01
02	0503010019	1/2" SPRING WASHER		08
03	0503010060	1/2 UNC G.5 ZN HEX NUT		08
04	0503010834	1/2 X 1 BOLT		04
05	0503014734	BOLT		04

CENTRAL WHEEL WITHOUT TRANSMISSION

0521055328




Item	Code	Description	See page	QT
01	0521064554	LEFT WHEEL FORK		01
02	0521064543	WHEEL SUPPORT		01
03	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
04	0561019929	FLAT WASHER		01
05	0551014511	CARRYING WHEEL AXIS GUIDE SLEEVE		02
06	0551014508	FLAT WASHER		01
07	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
08	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
09	0503010019	1/2" SPRING WASHER		04
10	0503010060	1/2 UNC G.5 ZN HEX NUT		04
11	0502012731	WHEEL HOLDER		02
12	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	27	01
13	0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE		01
14	0503011052	1.1/4" X 0.77" CASTLE NUT		02
15	0501017779	FLAT WASHER 32 X 60 X 4,75		02
16	0501010630	1.1/2" CASTLE NUT		01
17	0503010003	1845 GREASE FITTING		03
18	0503010882	BOLT		01
19	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
20	0503033458	CURRENT 6 X 17 ELOS		01
21	0503010337	NUT 5/16 UNC G.5 ZN		01
22	0581017245	AXLE BODY		01
23	0531012874	FLAT WASHER		02
24	0521054953	HYDRAULIC CYLINDER 50,80 X 127,00 X 205	28	01
25	0503010571	1/4" X 1.1/2" SPLIT PIN		02
26	0503010523	1/4 X 2 SPLIT PIN		03
27	0503012334	3/4" UNC X 3.1/2" BOLT		04
28	0503011075	3/4 UNC LOCK NUT		04




Item	Code	Description	See page	QT
01	0521058330	SENSOR SUPPORT	153	01
02	0521058331	DRIVE HYDRAULIC ASSEMBLY	154	01

SENSOR SUPPORT


0521058330




Item	Code	Description	See page	QT
01	0591014387	SENSOR SUPPORT		01
02	0501010942	3/8" X 1-1/4" BOLT		03
03	0503010026	3/8" NUT		03
04	0503010025	3/8" SPRING WASHER		03
05	0503013356	RIVET POP 3,2 X 10,0		01




Item	Code	Description	See page	QT
01	0591014389	LIFTING SENSOR DRIVING BODY		01
02	0521058332	FIXER BODY CONTROL		01
02A	0591014388	LIFT ACTUATOR FIXER		01
02B	0503019412	RIVET SCREW INTERNAL		02
03	0503010143	1/4" SPRING WASHER		02
04	0503010420	BOLT		02




Item	Code	Description	See page	QT
01	0531060317	CENTRAL SUPPORT		01
02	0503062962	SEED HOPPER 05 NOZZLES ASSY		01
03	0521051407	FERTILIZER HOPPER FIXER	33	08
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
05	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		06
06	0503010589	1/2" UNC SELF ADJUSTING NUT		06
07	0521058329	SEED CONDUCTOR	34	05
08	0521050525	FIXER FERTILIZER CONDUCTOR	38	05




Item	Code	Description	See page	QT
01	0531060317	CENTRAL SUPPORT		01
02	0503062962	SEED HOPPER 05 NOZZLES ASSY		01
03	0521051407	FERTILIZER HOPPER FIXER	33	08
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
05	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		06
06	0503010589	1/2" UNC SELF ADJUSTING NUT		06
07	0503062767	SCRUFFY ARTICULATED SEED CONDUCTOR	35	02
08	0503062766	ARTICULATED SEED DRIVER ALIGNED	36	03
09	0521055364	ARTICULATED SEED CONDUCTOR SUPPORT	37	05




Item	Code	Description	See page	QT
01	0531060317	CENTRAL SUPPORT		01
02	0503062962	SEED HOPPER 05 NOZZLES ASSY		01
03	0521051407	FERTILIZER HOPPER FIXER	33	08
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
05	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		06
06	0503010589	1/2" UNC SELF ADJUSTING NUT		06
07	0503062767	SCRUFFY ARTICULATED SEED CONDUCTOR	35	02
08	0503062766	ARTICULATED SEED DRIVER ALIGNED	36	03
09	0521055364	ARTICULATED SEED CONDUCTOR SUPPORT	37	05




Item	Code	Description	See page	QT
01	0503063047	MONITOR KIT		01
02	0503019536	MODULE		01
03	0503063204	KIT BASE		01
04	0503062449	ANTENNA ASSY		01
05	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
06	0503016234	FIXING VACUUM TRIMBLE 91357-AG		01
07	0503019759	WHIP		01
08	0503019852	SPEED WHIP		01




Item	Code	Description	See page	QT
01	0531062051	HOPPER SUPPORT FIXER		01
02	0503010019	1/2" SPRING WASHER		02
03	0503011082	C1/2" X 1.3/4" SCREW		02
04	0561013871	FLAT WASHER 13,50 X 50 X 4,75 ZN		02




Item	Code	Description	See page	QT
01	0521056303	CENTRAL HANDRAIL 2422 X 1424	162	02
02	0521057493	INTERNAL HANDRAIL 463/483 CENTRAL HOPPER SUPPORT	163	01




Item	Code	Description	See page	QT
01	0521056303	CENTRAL HANDRAIL 2422 X 1424	162	02
02	0521057493	INTERNAL HANDRAIL 463/483 CENTRAL HOPPER SUPPORT	163	01




Item	Code	Description	See page	QT
01	0581018304	TUBE 33,70 X 27 X 1336		03
02	0521067991	SIDE HANDRAIL		02
03	0511059383	INTERNAL HANDRAILING FIXER	50	10
04	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	54	08
05	0581019599	TUBE 33,70 X 27 X 420		06
06	0581014825	TUBE 33,70 X 27 X 924		02
07	0581015992	33,70 X 27 X 354 TUBE		04
08	0581012718	HANDRAIL		04



Item	Code	Description	See page	QT
01	0511059383	INTERNAL HANDRAILING FIXER	50	06
02	0503013357	3/8 SELF-ADJUSTING NUT		04
03	0591011198	50MM HANDRAIL SUPPORT		04
04	0581012718	HANDRAIL		02
05	0591012480	SIDE L INTERNAL HANDRAIL		02
06	0591012479	TUBE 33,70 X 27 X 384/386		03
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
08	0503011268	3/8" X 2-1/2" BOLT		04




Item	Code	Description	See page	QT
01	0581017397	PLATFORM		02
02	0521053066	PLATFORM SUPPORT ASSY	45	04




Item	Code	Description	See page	QT
01	0521068342	ARM PIVOT		01
02	0571017893	HORIZONTAL ARTICULATION SHAFT		01
03	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
04	0571011767	125 X 88 X 4,76 FLAT WASHER		01
05	0503010002	1800 GREASE FITTING		01
06	0503010408	7/8" SPRING WASHER		01
07	0503015322	BOLT 7/8		01
08	0503032042	SHEET POLYETHYLENE		01
09	0503010814	5/16 BOLT		14
10	0503011198	BOLT 3/4" UNC X 6" CS G.5		01
11	0571011825	BUSHING		02
12	0503010004	1890 GREASE FITTING		01
13	0503011255	3/4" LOCK NUT		01

ARTICULATION ARM RIGHT ASSY


0521052147




Item	Code	Description	See page	QT
01	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
02	0571011767	125 X 88 X 4,76 FLAT WASHER		01
03	0503010408	7/8" SPRING WASHER		01
04	0503015322	BOLT 7/8		01
05	0571017893	HORIZONTAL ARTICULATION SHAFT		01
06	0503011198	BOLT 3/4" UNC X 6" CS G.5		01
07	0503011255	3/4" LOCK NUT		01
08	0503010004	1890 GREASE FITTING		01
09	0503032042	SHEET POLYETHYLENE		01
10	0503010814	5/16 BOLT		14
11	0503010002	1800 GREASE FITTING		01
12	0521068343	ARM PIVOT		01
13	0571011825	BUSHING		02




Item	Code	Description	See page	QT
01	0511058241	HYDRAULIC CYLINDER 50,80 X 114,30 X 964 X 638	168	02
02	0521017351	1-1/4" X 8" BOLT		02
03	0503013321	SCREW 1.1/4 UNF X 7 C S G.8 ZN		02
04	0503010817	1.1/4" SELF LOCKING NUT		04



Item	Code	Description	See page	QT
01	0521066625	114.30 X 851 CYLINDER CASE		01
02	0521066559	EXTENSOR 876 X 50.80 (2)		01
03	0503010002	1800 GREASE FITTING		03
04	0503030385	CYLINDER PLUG N-002		02
05	0581010658	PISTON 50,80 X 114,30		01
06	0503018164	GASKET 2500-4000-375 B (1150 AGEL)		02
07	0503018165	GUIDE RING W2-4500-590		01
08	0503010290	SELF ADJUSTING 1.1/2" UNF NUT		01
09	0503010141	2-226 N 3006-9B O'RING		01
10	0502011222	END CAP 4 . 1/2"		01
11	0503010952	W2-2250-500 RING		01
12	0581010659	2" X 4" RING SUPPORT		01
13	0503010039	D-2000 SCRAPER RING		01
14	0503018026	GASKET 1870-2000-375 B POLYMAX		01
15	0503018024	RING BS OD050805200171D-BR		01
16	0503011892	O' RING, 2-346 N 3006-9B		02
17	0503011893	BACK-UP RING, 8-346		02




Item	Code	Description	See page	QT
01	0521058391	CENTRAL DUTY CONNECTOR	173	01
02	0503063242	COMMAND BLOCK		01
03	0521057013	TRIPLE DIVISER VALVE BRP00079 WITH NIPLES	175	01
04	0521057495	SUPPORT BLOCK	176	01
05	0521058570	RELIEF VALVE BLFP 3208 WITH SUPPORT	177	01
06	0503013534	ADAPTER T TEE		04
07	0501080175	3/4 X 900 TR-TC HOSE		04
08	0521055275	ASSY HOSE ARTICULATION	178	01
09	0521055274	HEAD HOSE ASSY	179	01
10	0521059227	GAME OF LEVANTE HOSES	181	01
11	0521059226	TURBINE HOSES SET	185	01
12	0503011968	NUT 3/4" 8R6X-S T ADAPTER WITH SWIVEL		01
13	0501053834	MALE QUICK COUPLER	187	06
14	0581017815	MALE ADAPTER		01
15	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0521059554	CENTRAL DUCT ASSEMBLY	171	01
02	0503063242	COMMAND BLOCK		01
03	0521057013	TRIPLE DIVISER VALVE BRP00079 WITH NIPLES	175	01
04	0521057495	SUPPORT BLOCK	176	01
05	0521055275	ASSY HOSE ARTICULATION	178	01
06	0521059583	HOSE SET CABECALHO	180	01
07	0521059584	LIFTING HOSE SET	182	01
08	0521058634	HOSE KIT	183	01
09	0521059782	HOSE SET 3 TURBINE P.P 36LINES 500	186	01
10	0501053834	MALE QUICK COUPLER	187	06
11	0581017815	MALE ADAPTER		01

CENTRAL DUCT ASSEMBLY


0521059554



Item	Code	Description	See page	QT
01	0521069009	OIL DUCT		01
02	0521069164	OIL PIPE R.7/8		07
03	0521069275	OIL TUBE		02
04	0521069163	OIL TUBE		02
05	0521069157	OIL TUBE		04
06	0581018409	FASTENER BODY		08
07	0581018415	PROTECTION BODY		04
08	0521053537	CENTRAL REAR DUCT SUPPORT	172	04
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		08
10	0503011123	BOLT		04
11	0503011268	3/8" X 2-1/2" BOLT		04
12	0503010025	3/8" SPRING WASHER		16
13	0503010026	3/8" NUT		16
14	0591010127	SUPPORT LEFT DISTRIBUTOR		02
15	0581014867	SIDE DUTY SUPPORT		02




Item	Code	Description	See page	QT
01	0571019615	CLAMP 1/2 UNC 130		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0503010025	3/8" SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581017885	SUPPORT BODY		01
08	0503011141	3/8" X 2-3/4" BOLT		01
09	0581018407	BODY FASTENER 2 DUCTS		01




Item	Code	Description	See page	QT
01	0521069163	OIL TUBE		02
02	0521069009	OIL DUCT		01
03	0521069164	OIL PIPE R.7/8		06
04	0521069275	OIL TUBE		02
05	0521051537	CENTRAL REAR DUCT SUPPORT	174	04
06	0581018409	FASTENER BODY		08
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		08
08	0503011141	3/8" X 2-3/4" BOLT		08
09	0503010025	3/8" SPRING WASHER		16
10	0503010026	3/8" NUT		16
11	0591010127	SUPPORT LEFT DISTRIBUTOR		02
12	0581014867	SIDE DUTY SUPPORT		02

CENTRAL REAR DUCT SUPPORT


0521051537




Item	Code	Description	See page	QT
01	0571019615	CLAMP 1/2 UNC 130		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0503010025	3/8" SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581014997	BODY SUPPORT DUCT REAR		01
08	0503011141	3/8" X 2-3/4" BOLT		01
09	0581014987	LOWER BODY FASTENER		01



Item	Code	Description	See page	QT
01	0503019426	TRIPLE FLOW DIVISING VALVE		01
02	0581013111	NIPLE R 1.1/6 UN X 1.5/16 12 WIRES		01
03	0503014724	2-215 N 3006-9B O'RING		01
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010045	O'RING		03
06	0511010111	7/8" NIPPLE		02
07	0503013357	3/8 SELF-ADJUSTING NUT		04
08	0503010237	3/8" X 1" BOLT		04
09	0501012520	1-1/16" X 7/8" NIPPLE		01




Item	Code	Description	See page	QT
01	0591012482	SUPPORT BLOCK VALVE CASAPPA CSU		01
02	0503010172	M10 X 1,5 X 25 BOLT		03
03	0503010025	3/8" SPRING WASHER		03
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
05	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2 UNC G.5 ZN HEX NUT		02



Item	Code	Description	See page	QT
01	0591013861	RELIEF VALVE SUPPORT BLFP 3208		01
02	0503019807	COMMAND BLOCK BLFP3208		01
03	0503011141	3/8" X 2-3/4" BOLT		02
04	0503013357	3/8 SELF-ADJUSTING NUT		02

ASSY HOSE ARTICULATION


0521055275




Item	Code	Description	See page	QT
01	0501080516	3/8" X 63" TR-TC HOSE ASSY		01
02	0501080449	3/8" X 1500 TC-TC HOSE		01
03	0501081108	3/8 X 1400 TC-TC HOSE		02
04	0501080522	3/8 X 700 TC-TC HOSE ASSY		01
05	0501082184	HOSE 1/2 X 2100 TC-TC		01

HEAD HOSE ASSY


0521055274



Item	Code	Description	See page	QT
01	0501080461	3/8" X 70" TR-TC HOSE		02
02	0501080297	3/8 X 2800 TR-TR HOSE		02
03	0501080526	3/8" X 114.17" TR-TC HOSE		01
04	0501080527	3/8 X 3300 TR-TC HOSE		01




Item	Code	Description	See page	QT
01	0501080461	3/8" X 70" TR-TC HOSE		02
02	0501080128	3/8" X 71" TR-TR HOSE ASSY		02
03	0501080105	3/8 X 700 TR-TR HOSE		02
04	0501080526	3/8" X 114.17" TR-TC HOSE		01
05	0501080527	3/8 X 3300 TR-TC HOSE		01




Item	Code	Description	See page	QT
01	0501080105	3/8 X 700 TR-TR HOSE		04
02	0501080164	3/4 X 1250 TR-TC HOSE		02
03	0501080599	3/8 X 650 TR-TC HOSE		02
04	0501080065	3/8" X 47" TC-TC HOSE		01
05	0501080175	3/4 X 900 TR-TC HOSE		01
06	0501080055	3/8" X 39" TR-TC HOSE		02
07	0501080302	3/8" X 55" TR-TC HOSE		01
08	0501080714	3/8 X 1600 TR-TC HOSE		01
09	0501081288	3/4 X 500 TR-TC HOSE		01
10	0501080019	3/4 X 1000 TR-TC HOSE		01
11	0501080675	3/8 X 1000 TC-TC 180G HOSE		03
12	0501080700	3/8 X 650 TC-TC HOSE		02
13	0501081254	3/8" X 900 TR-TC HOSE		02
14	0501082204	3/4 X 2750 TR-TR HOSE		02
15	0501081837	3/8 X 700 TR-TC HOSE		04
16	0501081838	3/8 X 1000 TR-TC HOSE		04
17	0521053712	3/4 X 5900 TR-TM BLACK/RED HOSE		01
17A	0501082205	3/4 X 5900 TR-TM HOSE		01
17B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
17C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
17D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
18	0521053707	3/4 X 5900 TR-TM BLACK/BLUE HOSE		01
18A	0501082205	3/4 X 5900 TR-TM HOSE		01
18B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
18C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
18D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
19	0521057885	VALVE ASSEMBLY	184	01

LIFTING HOSE SET


0521059584



Item	Code	Description	See page	QT
01	0501080105	3/8 X 700 TR-TR HOSE		04
02	0501080232	3/4" X 1100 TR-TR HOSE		02
03	0501080599	3/8 X 650 TR-TC HOSE		02
04	0501080065	3/8" X 47" TC-TC HOSE		01
05	0501080175	3/4 X 900 TR-TC HOSE		01
06	0501080055	3/8" X 39" TR-TC HOSE		02
07	0501080025	3/8" X 55,11" TR-TC HOSE		01
08	0501080714	3/8 X 1600 TR-TC HOSE		01
09	0501081288	3/4 X 500 TR-TC HOSE		01
10	0501080159	HOSE 3/4 X 1100 TR-TC 1G138645		01
11	0501080675	3/8 X 1000 TC-TC 180G HOSE		03
12	0501080700	3/8 X 650 TC-TC HOSE		02
13	0501081254	3/8" X 900 TR-TC HOSE		02
14	0501080347	HOSE 3/4 X 1800 TR-TR		02
15	0501080012	3/4 X 700 TR-TR HOSE		02
16	0501081837	3/8 X 700 TR-TC HOSE		04
17	0501081838	3/8 X 1000 TR-TC HOSE		04
18	0521053712	3/4 X 5900 TR-TM BLACK/RED HOSE		01
18A	0501082205	3/4 X 5900 TR-TM HOSE		01
18B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
18C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
18D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
19	0521053707	3/4 X 5900 TR-TM BLACK/BLUE HOSE		01
19A	0501082205	3/4 X 5900 TR-TM HOSE		01
19B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
19C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
19D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0501080094	1/2 X 1800 TR-TC HOSE		01
02	0501081834	1/2 X 1500 TR-TC HOSE		02
03	0501080272	1/2" X 106" TR-TC HOSE		01
04	0501081041	1/2" X 94.48" TR-TC HOSE		02
05	0501081349	1/2 X 1050 TC-TC 180G 1G138646 HOSE		01
06	0521052567	1/2 X 5900 TR-TM GRAY/RED HOSE		01
06A	0501081841	1/2 X 5900 TR-TM HOSE		01
06B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
06C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
06D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
07	0521052566	1/2 X 5900 TR-TM GRAY/BLUE HOSE		01
07A	0501081841	1/2 X 5900 TR-TM HOSE		01
07B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
07C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
07D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0521057877	RELIEF VALVE		01
02	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
03	0503013534	ADAPTER T TEE		04
04	0501080175	3/4 X 900 TR-TC HOSE		04


TURBINE HOSES SET

0521059226




Item	Code	Description	See page	QT
01	0501080091	1/2" X 550 TR-TR HOSE		01
02	0501080400	HOSE ASSY		02
03	0501080413	3/8" X 27" TR-TC HOSE		02
04	0521053713	3/8 X 3200 TR-TM HOSE YELLOW / GREEN		01
04A	0501080441	HOSE ASSY		01
04B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
04C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
04D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
05	0501081235	1/2 X 650 TR- TC HOSE		02
06	0501081326	HOSE		04
07	0521053714	3/4 X 3200 TR-TM HOSE YELLOW / BLUE		01
07A	0501082206	HOSE 3/8 X 3200 TR-TM		01
07B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
07C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
07D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
08	0521053716	3/4 X 3200 TR-TM HOSE YELLOW / RED		01
08A	0501082206	HOSE 3/8 X 3200 TR-TM		01
08B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
08C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
08D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
09	0501080048	3/8" X 78" TR-TR HOSE ASSY		02
10	0501080346	1/2" X 2000 TR-TR HOSE ASSY		04
11	0501080166	1/2" X 22" TR-TR HOSE ASSY		01
12	0521055655	BOYAU		01
12A	0501081841	1/2 X 5900 TR-TM HOSE		01
12B	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
12C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
12D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
13	0521055657	HOSE 1/2 X 5900 TR-TM BLUE/BLUE		01
13A	0501081841	1/2 X 5900 TR-TM HOSE		01
13B	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02
13C	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06


Item	Code	Description	See page	QT
14	0501080570	HOSE		01
15	0501082025	HOSE 1/2 X 2900 TR-TR		02
16	0501081985	HOSE		02
17	0501080506	3/8" X 75" TR-TR HOSE ASSY		01




Item	Code	Description	See page	QT
01	0501080091	1/2" X 550 TR-TR HOSE		02
02	0501080105	3/8 X 700 TR-TR HOSE		01
03	0501080413	3/8" X 27" TR-TC HOSE		02
04	0521056427	HOSE 3/4 X 3300 TR-TM YELLOW/RED		01
04A	0501080887	HOSE 3/4 X 3300 TM-TR		01
04B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
04C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
04D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
05	0521056429	HOSE 3/4 X 3300 TR-TM YELLOW/BLUE		01
05A	0501080887	HOSE 3/4 X 3300 TM-TR		01
05B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
05C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
05D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
06	0501081235	1/2 X 650 TR- TC HOSE		02
07	0521056426	HOSE 3/8 X 3200 TR-TM YELLOW/GREEN		01
07A	0501081848	HOSE 3/8 X 3200 TR-TM		01
07B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
07C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
07D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
08	0501080135	HOSE 1/2 X 1800 TR-TR		06
09	0501080024	1/2" X 700 TR-TR HOSE		02
10	0501080461	3/8" X 70" TR-TC HOSE		02
11	0501080094	1/2 X 1800 TR-TC HOSE		02
12	0501080495	1/2" X 98" TR-TC HOSE		06
13	0501080469	3/8" X 98.42" TR-TR HOSE ASSY		02
14	0501080105	3/8 X 700 TR-TR HOSE		01
15	0501080128	3/8" X 71" TR-TR HOSE ASSY		02




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521057760	LED FLASHLIGHT WITH SUPPORT	190	02
02	0521053672	LIGHTHOUSE ASSY	191	05
03	0521057883	ELECTRIC ASSEMBLY BCE (ASSEMBLED) APT 15MT/5F-L		01
03A	0503019692	WHIP LIGHTHOUSE / LANTERN LED APT15M / 5F 4318.2 ECB		01
03B	0503019337	COMMAND BLOCK WHIP		01




Item	Code	Description	See page	QT
01	0521057760	LED FLASHLIGHT WITH SUPPORT	190	02
02	0521053672	LIGHTHOUSE ASSY	191	05
03	0521057884	ELECTRICAL ASSY BCE (ASSEMBLED) APT 19MT/5F-L		01
03A	0503019693	HEADLIGHT WHIP/LED LANTERN IMPLEMENT APT19M/5F 4319.0 BCE		01
03B	0503019036	CABLE BLOCK WITH IMPLEMENT		01
04	0503018829	NYLON CLAMP 7,8 X 1,8 X 390 MM		20
05	0503019902	NYLON CLAMP 7,8X1,8X225 MM		100




Item	Code	Description	See page	QT
01	0591013259	LED FLASHLIGHT SUPPORT		01
02	0503019579	LED LANTERN		01




Item	Code	Description	See page	QT
01	0581015856	REDLIGHT SUPPORT		01
02	0503018738	HEADLIGHT		01
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
04	0503010358	5/16" X 5/8" BOLT		02
05	0551019884	45 X 50 X 3/8 FASTENER		02
06	0503013357	3/8 SELF-ADJUSTING NUT		04
07	0503010337	NUT 5/16 UNC G.5 ZN		02
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		02




Item	Code	Description	See page	QT
01	0521054185	OF THE AIR CENTRAL TUBE	194	01
02	0521051096	REAR CENTRAL AIR CONDUCTOR 1120 CSCP	195	02
03	0521055100	SUPPORT CONDUCTOR AIR ASSY GREATER	76	03
04	0521052924	SUPPORT CONDUCTOR AIR CENTRAL ASSY	196	04
05	0503011372	102 TO 121 CLAMP		04
06	0521052549	CLAMP	78	10
07	0581018653	LESSER PROTECTION		02




Item	Code	Description	See page	QT
01	0521054185	OF THE AIR CENTRAL TUBE	194	01
02	0521055100	SUPPORT CONDUCTOR AIR ASSY GREATER	76	03
03	0503011372	102 TO 121 CLAMP		04
04	0521052549	CLAMP	78	10




Item	Code	Description	See page	QT
01	0511057036	AIR DISTRIBUTOR BOARD		02
01A	0503012567	T-JOIN FOR TUBE 110		02
01B	0581013890	AIR DISTRIBUTOR SOCKET		02
02	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		10
02A	0503034812	SOCKET DISTRIBUTOR AR		10
02B	0503012856	POP RIVET		20
03	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		02
03A	0503034763	AIR DISTRIBUTOR PUMP		02
03B	0503015341	POP RIVET		04
04	0581017864	AIR DISTRIBUTOR BODY		01
05	0581013477	AIR DISTRIBUTOR BODY		01
06	0581018500	AIR DISTRIBUTOR BODY		01




Item	Code	Description	See page	QT
01	0581015132	BODY DISTRIBUTOR AR		01
02	0581013633	AIR DISTRIBUTOR NOZZLE		01
03	0521050393	ASSY KNEE		01
03A	0503017845	90 PVC KNEE		01
03B	0581013890	AIR DISTRIBUTOR SOCKET		01




Item	Code	Description	See page	QT
01	0581017122	CENTRAL AIR CONDUCTOR SUPPORT		01
02	0521018402	AIR CONDUCTOR CLAMP		01
03	0503010371	5/16" X 1" BOLT		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0581017950	GUTTER 30 X 55 X 2330		02
02	0581017967	24 X 46 X 1200 GUTTER		02
03	0521055102	BIGGEST FULL GUTTER SUPPORT	77	04
03A	0581019560	SUPPORT CONDUCTOR		01
03B	0503010025	3/8" SPRING WASHER		02
03C	0503010026	3/8" NUT		02
03D	0503013029	3/8" X 3/4" BOLT		01
06E	0501011643	3/8 X 1"BOLT		01




Item	Code	Description	See page	QT
01	0581017950	GUTTER 30 X 55 X 2330		02
02	0521055102	BIGGEST FULL GUTTER SUPPORT	77	04
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
04	0581017967	24 X 46 X 1200 GUTTER		02




Item	Code	Description	See page	QT
01	0581017683	GUTTER 30 X 55 X 2660		01
02	0521055102	BIGGEST FULL GUTTER SUPPORT	77	04
03	0581017952	GUTTER 30 X 55 X 1660		01
04	0581017967	24 X 46 X 1200 GUTTER		02
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521058669	KIT CABINE SEEDSENSE GEN3 - VDRIVE	158	01
02	0503018063	SRM MAIN WHIP - 10 ROWS		01
03	0503017977	SRM MAIN WHIP - 11 LINES		02
04	0503018080	EXTENSION CABLE		01
05	0503062457	TRACTOR CONNECTION ASSY		01
06	0503017980	APEX EXTENSION CABLE		01
07	0503018085	APEX EXTENSION CABLE		02
08	0503019291	SUPPORT SENSOR		01
09	0503019618	EXTENSION CABLE		01
10	0503017988	VACUUM SENSOR		03
11	0503017993	EXTENSION CABLE		01
12	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		20
13	0503018081	CAN EXTENSION CABLE SRM		02
14	0503062461	160 AMP ALTERNATOR SET		01
15	0503017975	WHIP		32
16	0503019755	UNIT MODULE		32
17	0503062433	SEED TUBE WITH SENSOR		32
18	0503062431	ELECTRIC MOTOR		32



Item	Code	Description	See page	QT
01	0521058669	KIT CABINE SEEDSENSE GEN3 - VDRIVE	158	01
02	0503018063	SRM MAIN WHIP - 10 ROWS		01
03	0503017991	MAIN HARNESS SRM - 6 LINES 45/55 729466		02
04	0503018061	SRM MAIN WHIP - 7 LINES		02
05	0503018081	CAN EXTENSION CABLE SRM		03
06	0503062457	TRACTOR CONNECTION ASSY		01
07	0503017980	APEX EXTENSION CABLE		01
08	0503018085	APEX EXTENSION CABLE		02
09	0503018086	APEX EXTENSION CABLE 729153 - 10.60MTS		02
10	0503019291	SUPPORT SENSOR		01
11	0513010031	EXTERNAL LIFTING CABLE PSS-X1005B CAN-5M		01
12	0513010275	PP725905 VACUUM SENSOR		03
13	0503017993	EXTENSION CABLE		01
14	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		480
15	0503062461	160 AMP ALTERNATOR SET		01
16	0503017975	WHIP		36
17	0503019755	UNIT MODULE		36
18	0503062433	SEED TUBE WITH SENSOR		36
19	0503062431	ELECTRIC MOTOR		36




Item	Code	Description	See page	QT
01	0503063241	INTELLIAG KIT 36 LINES 45/50 USAP WITH MONITORING AND 010081562		01
01A	0503015065	MASTER CONTROL MODULE		01
01B	0503015066	CABLE CONTROL MASTER MODULE		01
01C	0503015209	MODULES WSMB 18L ISOBUS 4679811100S1		02
01D	0503015210	WSMB ISOBUS 467981200 MODULE CABLE		02
01E	0503016323	CABLE ASSY		01
01F	0503015071	CONNECTOR		01
01G	0503062697	CABLE CABLE MONITORING CABLE EMB ISOBUS 36 LINES50		01
01H	0503017443	ANTENNA GPS PM 400		01
01I	0503017031	CLEAN BRUSH		01
01J	0503015218	SENSOR FOTOELE PM 400		36
02	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	203	03
03	0511056972	FILTER HYDAC	204	01
04	0503019291	SUPPORT SENSOR		01
05	0503013100	NYLON CLAMP 4,8 X 1,3 X 200 MM		180
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		540




Item	Code	Description	See page	QT
01	0513010049	MOTOR OMP X 80 EMD - 11185907		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02

FILTER HYDAC


0511056972




Item	Code	Description	See page	QT
01	0503063151	PRESSURE FILTER MFM HYDAC 1319024BR		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	7/8" T ADAPTER		01
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0503034003	61 X 118 SERIAL NUMBER TAG		01
02	0503010001	RIVET 3,2 X 5,5		04
03	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		04
04	0503034563	ADHESIVE LABEL		04
05	0503034114	TATU LOGO DECAL		02
06	0503034566	ADHESIVE LABEL		02
07	0503033853	SIDE TATU LOGO DECAL		02
08	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL		02
09	0503032988	SEED DISTRIBUTOR CHART DECAL		01
10	0503033597	LIFTING PROHIBITED DECAL		02
11	0503031087	AUTO CONTROL APPROVED DECAL		01
12	0503032986	ADHESIVE LABEL		01
13	0503034471	ADHESIVE LABEL		01
14	0503034651	ADHESIVE LABEL		02
15	0503034683	ADHESIVE LABEL		02
16	0503034534	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0521056998	ALUMINUM IDENTIFICATION LABEL WITH RIVET		01
01A	0503034003	61 X 118 SERIAL NUMBER TAG		01
01B	0503010001	RIVET 3,2 X 5,5		04
02	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		04
03	0503034563	ADHESIVE LABEL		04
04	0503034114	TATU LOGO DECAL		04
05	0503034566	ADHESIVE LABEL		04
06	0503033853	SIDE TATU LOGO DECAL		02
07	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL		02
08	0503034682	ADHESIVE LABEL SEED TABLE		01
09	0503033597	LIFTING PROHIBITED DECAL		02
10	0503031087	AUTO CONTROL APPROVED DECAL		01
11	0503032986	ADHESIVE LABEL		01
12	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		02
13	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02
14	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		04
15	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		01
16	0503034471	ADHESIVE LABEL		01
17	0503034651	ADHESIVE LABEL		02
18	0503034683	ADHESIVE LABEL		02
19	0503034534	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0571015072	LOCK AXLE		01
02	0503010765	3/8" X 3" BOLT		01
03	0521064540	TELESCOPIC LOCK		01
04	0503013357	3/8 SELF-ADJUSTING NUT		01
05	0521011132	FLAT WASHER		01
06	0503010131	3/16" X 1.1/2" SPLIT PIN		01
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
08	0511054270	TENSIONER SPRING		01
08A	0511069520	TELESC LOCK SPRING TENSIONER		01
08B	0503010013	5/8 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0503019303	CONTROL PANEL		01
02	0503019305	WHIP		01
03	0503019307	CABLE TRACTOR HEADLIGHT		01
04	0503019304	WIRES BLOCK COMMAND TRACTOR		01
05	0521051707	ASSY PANEL FIXER PLATE	209	01
06	0503016234	FIXING VACUUM TRIMBLE 91357-AG		01
07	0503016452	FIXING SUPPORT AG500 TRIMBLE		01




Item	Code	Description	See page	QT
01	0581015186	ELECTRIC PANEL FIXING PLATE		01
02	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
03	0503010669	FLAT WASHER 5 X 11 X 1,00 ZN		02
04	0503010667	3/16" NUT		02
05	0503010668	3/16" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0581018714	HYDRAULIC HOSE SUPPORT		01
02	0503010395	1/2" X 1-1/4" BOLT		02
03	0503010589	1/2" UNC SELF ADJUSTING NUT		02
04	0503010237	3/8" X 1" BOLT		02
05	0503013357	3/8 SELF-ADJUSTING NUT		02
06	0503010025	3/8" SPRING WASHER		02
07	0503010172	M10 X 1,5 X 25 BOLT		02
08	0581019743	FLOW DIVISOR BLOCK SUPPORT		01
09	0503034719	FLOW DIVIDER BLOCK		01



Item	Code	Description	See page	QT
01	0581018714	HYDRAULIC HOSE SUPPORT		01
02	0503010395	1/2" X 1-1/4" BOLT		02
03	0503010589	1/2" UNC SELF ADJUSTING NUT		02
04	0503010237	3/8" X 1" BOLT		02
05	0503013357	3/8 SELF-ADJUSTING NUT		02
06	0503010025	3/8" SPRING WASHER		02
07	0503010172	M10 X 1,5 X 25 BOLT		02
08	0581019743	FLOW DIVISOR BLOCK SUPPORT		01
09	0521055356	FLUX DIVIDER BLOCK FOR 03 TURBINES	212	01




Item	Code	Description	See page	QT
01	0503034719	FLOW DIVIDER BLOCK		01
02	0501010590	NIPPLE		02
03	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0521051407	FERTILIZER HOPPER FIXER	33	08
02	0531060582	SUPPORT LEFT 5 MOUTH 2033 X 1674		01
03	0503062962	SEED HOPPER 05 NOZZLES ASSY		01
04	0521058329	SEED CONDUCTOR	34	05
05	0521050525	FIXER FERTILIZER CONDUCTOR	38	05

SIDE SUPPORT


0521058894




Item	Code	Description	See page	QT
01	0531061063	LEFT SIDE SUPPORT 6 MOUTH		01
02	0503062963	FERTILIZER HOPPER 06 NOZZLES		01
03	0521051407	FERTILIZER HOPPER FIXER	33	10
04	0521058329	SEED CONDUCTOR	34	06
05	0521050525	FIXER FERTILIZER CONDUCTOR	38	06




Item	Code	Description	See page	QT
01	0531060316	RIGHT CENTRAL SUPPORT 5 MOUTH 2033X1224		01
02	0503062962	SEED HOPPER 05 NOZZLES ASSY		01
03	0503062766	ARTICULATED SEED DRIVER ALIGNED	36	02
04	0503062767	SCRUFFY ARTICULATED SEED CONDUCTOR	35	03
05	0521051407	FERTILIZER HOPPER FIXER	33	08
06	0521055364	ARTICULATED SEED CONDUCTOR SUPPORT	37	05




Item	Code	Description	See page	QT
01	0531060307	LEFT SIDE SUPPORT 4 MOUTH 1633X1274		01
02	0503062961	FERTILIZER HOPPER ASSY		01
03	0503062766	ARTICULATED SEED DRIVER ALIGNED	36	02
04	0503062767	SCRUFFY ARTICULATED SEED CONDUCTOR	35	02
05	0521051407	FERTILIZER HOPPER FIXER	33	06
06	0521055364	ARTICULATED SEED CONDUCTOR SUPPORT	37	04



Item	Code	Description	See page	QT
01	0521056320	LEFT SIDE HANDRAIL 2375 X 1237	218	01
02	0521056319	LEFT HANDRAIL 2238 X 1336	219	01
03	0521055750	SIDE HANDRAIL	53	01
04	0521056562	RIGHT INTERNAL HANDRAIL	220	01
05	0521058134	RIGHT INTERNAL HANDRAIL LARGER	227	02




Item	Code	Description	See page	QT
01	0581019610	TUBE 33,70 X 27 X 1149		03
02	0511059383	INTERNAL HANDRAILING FIXER	50	10
03	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	54	08
04	0521067991	SIDE HANDRAIL		02
05	0581012718	HANDRAIL		04
06	0581015992	33,70 X 27 X 354 TUBE		04
07	0581014825	TUBE 33,70 X 27 X 924		02
08	0581019622	TUBE 33,70 X 27 X 250		03
09	0591010989	TUBE 33.70 X 27 X 730		03




Item	Code	Description	See page	QT
01	0521067991	SIDE HANDRAIL		02
02	0581014825	TUBE 33,70 X 27 X 924		02
03	0581015992	33,70 X 27 X 354 TUBE		02
04	0591010177	TUBE 33,70 X 27 X 1248		03
05	0511059383	INTERNAL HANDRAILING FIXER	50	08
06	0581012718	HANDRAIL		04
07	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	54	07
08	0581017332	TUBE		03
09	0581019622	TUBE 33,70 X 27 X 250		03

RIGHT INTERNAL HANDRAIL


0521056562




Item	Code	Description	See page	QT
01	0591011196	BODY L INTERNAL HANDRAIL		01
02	0511059383	INTERNAL HANDRAILING FIXER	50	02
03	0591011197	RIGHT BODY INTERNAL HANDRAIL		01
04	0503013357	3/8 SELF-ADJUSTING NUT		02
05	0591011198	50MM HANDRAIL SUPPORT		02
06	0581012718	HANDRAIL		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503011268	3/8" X 2-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0521056318	LEFT SIDE AIR CONDUCTOR 13 BUTTONS 6280	223	01
02	0521055100	SUPPORT CONDUCTOR AIR ASSY GREATER	76	04
03	0521052549	CLAMP	78	13




Item	Code	Description	See page	QT
01	0521056262	CBA ASSY AIR DUCT FIXER SUPPORT	73	01
02	0521056318	LEFT SIDE AIR CONDUCTOR 13 BUTTONS 6280	223	01
03	0521055100	SUPPORT CONDUCTOR AIR ASSY GREATER	76	04
04	0521052549	CLAMP	78	13



Item	Code	Description	See page	QT
01	0511057036	AIR DISTRIBUTOR BOARD		02
01A	0503012567	T-JOIN FOR TUBE 110		01
01B	0581013890	AIR DISTRIBUTOR SOCKET		01
02	0581019594	CONDUCTOR BODY AIR 03 MOUTH 1400 04 HOLES		01
03	0591010986	CONDUCTOR BODY		01
04	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		13
04A	0503034812	SOCKET DISTRIBUTOR AR		01
04B	0503012856	POP RIVET		04
05	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		02
05A	0503034763	AIR DITRIBUTOR PUMP		01
05B	0503015341	POP RIVET		02
06	0581018832	AIR CONDUCTOR BODY 6 MOUTH 2860		01




Item	Code	Description	See page	QT
01	0521058340	LEFT SIDE HANDRAIL 2549 X 2223	225	01
02	0521058339	LEFT SIDE HANDRAIL	226	01
03	0521058134	RIGHT INTERNAL HANDRAIL LARGER	227	02




Item	Code	Description	See page	QT
01	0521067991	SIDE HANDRAIL		02
02	0511059383	INTERNAL HANDRAILING FIXER	50	10
03	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	54	05
04	0581019622	TUBE 33,70 X 27 X 250		03
05	0581014825	TUBE 33,70 X 27 X 924		01
06	0581015992	33,70 X 27 X 354 TUBE		04
07	0581012718	HANDRAIL		03
08	0591014392	TUBE		03

LEFT SIDE HANDRAIL


0521058339




Item	Code	Description	See page	QT
01	0591013447	TUBE 33,70 X 27 X 1652		03
02	0521067991	SIDE HANDRAIL		02
03	0511059383	INTERNAL HANDRAILING FIXER	50	10
04	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	54	08
05	0581019622	TUBE 33,70 X 27 X 250		03
06	0581014825	TUBE 33,70 X 27 X 924		02
07	0581015992	33,70 X 27 X 354 TUBE		04
08	0581012718	HANDRAIL		04
09	0581017391	TUBE		03



Item	Code	Description	See page	QT
01	0591014007	RIGHT BODY HIGHER INTERNAL HANDRAIL		01
02	0591014008	BODY L INTERNAL HANDRAIL 250 X 727		01
03	0511059383	INTERNAL HANDRAILING FIXER	50	02
04	0581012718	HANDRAIL		01
05	0503013357	3/8 SELF-ADJUSTING NUT		02
06	0591011198	50MM HANDRAIL SUPPORT		02
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503011268	3/8" X 2-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0521058335	SIDE AIR CONDUCTOR 11 MOUTH	229	01
02	0521055100	SUPPORT CONDUCTOR AIR ASSY GREATER	76	03
03	0521052549	CLAMP	78	22




Item	Code	Description	See page	QT
01	0511057036	AIR DISTRIBUTOR BOARD		02
01A	0503012567	T-JOIN FOR TUBE 110		01
01B	0581013890	AIR DISTRIBUTOR SOCKET		01
02	0521050393	ASSY KNEE		01
02A	0503017845	90 PVC KNEE		01
02B	0581013890	AIR DISTRIBUTOR SOCKET		01
03	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		11
03A	0503034812	SOCKET DISTRIBUTOR AR		01
03B	0503012856	POP RIVET		04
04	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
04A	0503034763	AIR DITRIBUTOR PUMP		01
05	0581019613	CONDUCTOR BODY		01
054B	0503015341	POP RIVET		02
06	0591014394	BODY DISTRIBUTOR AR		01
07	0581018874	CONDUCTOR BODY AIR 03 MOUTH 1360 04 HOLES		01

LEFT SIDE DUTY ASSEMBLY

0521058382




Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY	65	04
01A	0581011417	SUPPORT		01
01B	0503010237	3/8" X 1" BOLT		02
01C	0503010025	3/8" SPRING WASHER		02
01D	0503010026	3/8" NUT		02
02	0581018415	PROTECTION BODY		04
03	0511059928	SIDE DUTY SUPPORT	66	02
03A	0581013094	DUTO HOLDER SUPPORT		01
03B	0571019756	FASTENER 1/2 UNC X 220 X 198 ZN		01
03C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
03D	0503010019	1/2" SPRING WASHER		02
03E	0503010060	1/2 UNC G.5 ZN HEX NUT		02
04	0581018407	BODY FASTENER 2 DUCTS		06
05	0503011268	3/8" X 2-1/2" BOLT		07
06	0503010025	3/8" SPRING WASHER		07
07	0503010026	3/8" NUT		07
08	0521069757	DUCT OIL		02
09	0521069107	OIL DUCT 03 EXIT R.3/4 X 2040		02
10	0521069299	RIGHT SIDE DUTY ASSEMBLY		01
11	0521069209	OIL DUCT R.7/8 X 1350		02
12	0501082190	HOSE 3/8 X 160 TR-TR		02




Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY	65	02
02	0521069157	OIL TUBE		02
03	0521069355	OIL TUBE		02
04	0531060118	OIL DUCT 3 OUTPUTS R.3/4 X 1800		02
05	0521068953	OIL PIPE R.7/8 X 829		02
06	0521069497	OIL PIPE R.3/4 X 829		03
07	0521069164	OIL PIPE R.7/8		01
08	0511059928	SIDE DUTY SUPPORT	66	04
09	0581018407	BODY FASTENER 2 DUCTS		08
10	0581018415	PROTECTION BODY		08
11	0501082190	HOSE 3/8 X 160 TR-TR		02
12	0503011268	3/8" X 2-1/2" BOLT		08
13	0503011123	BOLT		02
14	0503010025	3/8" SPRING WASHER		10
15	0503010026	3/8" NUT		10

ASSY FILTER SUPPORT

0521058426



Item	Code	Description	See page	QT
01	0571016995	FIXER SUPPORT		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0571018437	PRISONER 1/2 X		02
06	0571014216	FRONT HOSE SUPPORT FIXER		01



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

