

ROW CROP PLANTERS

PST TRIO FLEX SUPREMA P.P - FRAME - 7450/8460 - CSU

Code: 0501093066
Series: S-0119
Revision: 00
Date Revision: AGOSTO/2022

PARTS CATALOGUE



MARCHESAN



PRODUCTS

Code	Description
0111360130	PST TRIO FLEX SUP PP 7450/15E500 ESPECIAL S-0119
0111360132	PST TRIO FLEX SUP PP 7450/15E500 ESPECIAL S-0119
0111360115	PST TRIO FLEX SUP PP 7450/15E500 ESPECIAL S-0119
0111360137	PST TRIO FLEX SUP PP 8460/17E500 ESPECIAL S-0119
0111360141	PST TRIO FLEX SUP PP 8460/18E450 ESPECIAL S-0119

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909095865	FRAME ASSY	1
0511053196	PST JOINT FRAME	2
0511056311	ARTICULATION FRAME 8460	3
0511053188	RIGHT FRAME WITH WHEELED AXLE 7450	4
0511056312	RIGHT FRAME WITH WHEELED AXLE 8460	5
0511053189	LEFT FRAME WITH WHEELED AXLE 7450	6
0511056313	LEFT FRAME WITH WHEELED AXLE 8460	7
0511053190	CENTRAL FRAME WITH WHEELED AXLE 6450/7285/7450/8460	8
0511059232	ASSEMBLY SPRING TRACTION	9
0521058402	WHEELED WITH 655 DRIFT SPRING WITH TRANSMISSION	10
0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	11
0521058401	655 WHEELED SUPPORT WITH TRANSMISSION	12
0501058241	WHEEL SUPPORT CHAIN TENSIONER	13
0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH TRANSMISSION	14
0503063172	WHEEL	15
0521055233	WHEELED TRANSMISSION WITHOUT TIRE	16
0521055234	WHEELED FASTENER	17
0521055236	INTERMEDIARY CURRENT STRETCHER	18
0521055237	WHEEL FIXED CURRENT STRETCHER	19
0521055235	WHEEL MOBILE CURRENT STRETCHER	20
0521055238	BEARING TENSIONER CHAIN	21
0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	22
0521058394	WHEEL WITH PNEUME	23
0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	24
0909098905	HEADER FULL ASSEMBLY - FRAME 5750/5850/6850/7450	25
0511055096	TRACTOR HITCH	26
0511053179	TRACTOR COUPLING SHAFT	27
0521051614	TURNBUCKLE SIDE UPPER	28
0521050133	TURNBUCKLE SIDE 755/480	29
0511059237	3 POINT TURNBUCKLE	30
0521045756	HYDRAULIC CYLINDER	31
0511057653	HYDRAULIC CYLINDER	32
0501053835	FEMALE QUICK COUPLER	33
0521052796	CYLINDER ASSEMBLY 5750/6850/7860/7960/8460	34
0511058406	HYDRAULIC CYLINDER	35
0511059419	HYDRAULIC SYSTEM ASSEMBLY 6850/7285/7450/7860/7960	36
0521052860	HYDRAULIC SYSTEM ASSEMBLY 8160/8460	37
0511059290	VALVE ASSEMBLY	38
0521052622	ASSY SILO FERTILIZER 7450	39
0521052744	ASSY SILO FERTILIZER 8460	40
0521052709	SUPPORT SILO RIGHT FERTILIZER WITH DISTRIBUTOR 8460/8960/9460	41
0521052718	SILO SUPPORT LEFT FERTILIZER WITH DISTRIBUTOR 8460/8960/9460	42
0521052620	SUPPORT SILO RIGHT FERTILIZER WITH DISTRIBUTOR 7450	43
0521052621	SILO SUPPORT LEFT FERTILIZER WITH DISTRIBUTOR 7450	44
0521051607	SUPPORT SILO CENTRAL FERTILIZER 6450/7285/7450/8460	45
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	46
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	47
0501053788	3/4 SQUARE AXLE FASTENER	48
0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	49
0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	50
0521050195	SILO FERTILIZER LEFT SQUARE AXLE	51
0501056444	BEARING WITH ROLLING	52



MARCHESAN

INDEX

0521050283	TRANSMISSION ASSEMBLY 7450	53
0531050946	TRANSMISSION SET 7450	54
0521050024	ASSEMBLY TRANSMISSION 7960	55
0501052560	MOTOR AXLE SIGNAL	56
0511051434	TRANSMISSION ACTUATOR	57
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	58
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	59
0521050183	RIGHT GEAR BOX ASSY	60
0531050914	COMPLETE RIGHT EXCHANGE PP CBA SORETO	61
0521050184	EXCHANGE LEFT ASSY	62
0531050916	COMPLETE LEFT EXCHANGE PP CBA SORETO	63
0501058212	SEMI MOUNTED RIGHT CHANGE	64
0501058213	LH GEAR BOX	65
0511059266	CLOSED BEARING	66
0501056271	GEARBOX CLOSED BEARING	67
0501056443	GEAR HOUSING BEARING	68
0501048790	AXLE WITH RING	69
0501054655	CHAIN TENSIONER ASSY	70
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	71
0511059261	CHAIN TENSIONER	72
0521055217	LOWER CURRENT STRETCH	73
0501058254	UPPER SEED CHAIN TENSIONER	74
0521055216	BEARING WITH GEAR	75
0521055218	BEARING GEAR WITH DOUBLE	76
0521055214	BEARING GEAR WITH	77
0521055215	DOUBLE TRANSMISSION BEARING	78
0521052672	PLATFORM ASSEMBLY 7450	79
0521052676	PLATFORM ASSEMBLY 8460	80
0511058252	HANDLE ASSEMBLY 7450	81
0511058282	HANDLE ASSEMBLY 8460	82
0521052698	ASSEMBLY CSU C3 SEMI MOUNTED 7285/7450	83
0511058398	ASSEMBLY CSU C3 SEMI MOUNTED 7860/8460	84
0511058397	ASSEMBLY CSU C3 3BOX 7B WITH 17 C 7860	85
0521052699	ASSEMBLY CSU C3 2BOX 6/5 - 1BOX 7/5 7285/7450	86
0521052687	RH SUPPORT TOWER SILO	87
0511057690	3" ARTICULATED SEED CONDUCTOR	88
0521051931	LH SUPPORT TOWER SILO	89
0521051927	TOWER SUPPORT HOPPER	90
0511054971	JACK ASSEMBLY	91
0511056536	LADDER ASSEMBLY	92
0511057512	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE	93
0511057889	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE 8460	94
0501054649	HBM SEQUENTIAL VALVE	95
0511058431	HYDRAULIC CYLINDER	96
0521053076	LABEL ASSY FOR MH/CSU	97
0521053085	SUPREME LABEL SET	98
0521052827	AXIS TRANSMISSION SEED ASSY 7450	99
0521052863	AXIS TRANSMISSION SEED ASSY 8460	100
0511059233	INTERMEDIATE TRANSMISSION	101
0521052803	REAR LIGHT ASSEMBLY	102
0521052844	REAR LIGHT ASSEMBLY 7860/7960/8160/8460	103
0521052792	MOUNTED REAR LIGHT	104
0521050282	TURBINE ASSEMBLY MTH PP CSU	105
0521053016	TURBINE ASSEMBLY MTH PP CSU PST TRIO FLEX SUP PP 7860/8460 17	106



MARCHESAN

INDEX

0521050260	SUPPORT ASSEMBLY P.P MTH	107
0521050016	DISTRIBUTOR AIR RIGHT 06 MOUTHS - 17 E500	108
0521050017	DISTRIBUTOR AIR LEFT 06 MOUTHS - 17 E500	109
0521052999	DISTRIBUTOR AIR CENTRAL 7 MOUTHS - 17	110
0511057292	ASSY FLOW REGULATION VALVE	111
0511057906	HOSE ASSY	112
0511059504	RIGHT AIR CONDUCTOR - 6850	113
0511059505	LEFT AIR CONDUCTOR - 6850	114
0511059503	6 MOUTH AIR CONDUCTOR X 2150 - 6850	115
0511059319	AIR FIXING SUPPORT	116
0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	117
0511059406	TURBINE P.P MOUNTED	118
0521050154	TURBINE P.P WITH HOLE	119
0521052549	CLAMP	120
0521052814	ASSY MANUAL DOOR	121
0501053834	MALE QUICK COUPLER	122
0521053426	MONITORING ASSEMBLY PLANTING SEEDS 15L PM400	123
0511057817	SUPPORT HOSE	124
0521025447	BOX WITH HYDRAULIC MARKER COMPONENTS	125
0521055204	ROW MARKER DISC	126
0909095866	SEED LINE/FERTILIZER ASSEMBLY	127
0521054739	FRONT LINE SHORT LEFT SEED WITH CARDAN WITHOUT LUBRICATION	128
0521057998	FRONT SHORT SEED LINE WITH SORETO CABLE WITHOUT LUBRICATION	129
0521054738	FRONT LINE SHORT RIGHT SEED WITH CARDAN WITHOUT LUBRICATION	130
0521054741	FRONT LINE SEED LONG LEFT WITH CARDAN WITHOUT LUBRICATION	131
0521054740	FRONT LINE LONG RIGHT SEED WITH CARDAN WITHOUT LUBRICATION	132
0521057999	FRONT LONG SEED LINE WITH SORETO CABLE WITHOUT LUBRICATION	133
0521058000	FRONT SEMI ASSEMBLED LONG SEED LINE WITH SORETO CABLE WITHOUT LUBRICATION	134
0521053577	BEARING BOX	135
0521054737	FRONT SEMI-ASSEMBLED LONG LEFT SEED ROW	136
0521054736	FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED LINE	137
0521055213	LINE BEARING SEED	138
0521055223	SEED LINE TRANSMISSION BOX	139
0511055260	SEED ROW CHAIN TENSIONER	140
0521055224	TRANSMISSION CARDAN ASSY	141
0521055225	BEARING DOUBLE FRONT LINE SEED	142
0521055219	BEARING WITH GEAR 17Z HEX 5/8	143
0521055220	BEARING FRONT LINE SEED	144
0521052270	SEMI MOUNTED FRAME PRECISION PLANTING SPA	145
0521054811	FERTILIZER SHORT LINE	146
0521054900	FERTILIZER LINE SHORT ASSY DOC20	147
0521054812	LONG FERTILIZER LINE	148
0521054901	LONG FERTILIZER DOC20 ASSY LINE	149
0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION CONICAL BEARING	150
0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION CONICAL BEARING	151
0521054845	DPLO 20 LOW LINE WITHOUT LUBRICATION	152
0521054846	DPLO 20 LONG LINE WITHOUT LUBRICATION CONICAL BEARING	153




MARCHESAN

INDEX

0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	154
0521053697	CUTTING DISK BOX	155
0521054844	DPLO 20 CUTTING DISK BOX	156
0521054906	SPRING ASSY FERTILIZER	157
0521054769	LEFT DDD FERTILIZER WITH SUPPORT	158
0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	159
0521054765	DDD LEFT FERTILIZER	160
0521054764	DDD RIGHT FERTILIZER	161
0521054761	LEFT LOW CUBE	162
0521054760	DOWN LOW CUBE	163
0521054794	REAR RIGHT SEAL LINE P.P CSU 3 NAC	164
0521054795	REAR LEFT LINE SEED P.P CSU 3 NAC	165
0521054786	DDD RIGHT SEED SUPREME 15 X 15 NAC	166
0521054787	DDD LEFT SUPREME SEED 15 X 15 NAC	167
0521055208	ASSEMBLY PRECISION PLANTING V-SET2 CSU 3 CSU SUPREMA P.P	168
0521055210	LEFT P.P TRANSMISSION BOX	169
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	170
0521055397	DEEP WHEEL / COMPACTOR SYSTEM	171
0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	172
0521055065	ASSY DEPTH / COMPACTOR	173
0501056769	DEPTH WHEELS REGULATOR ASSY	174
0521055033	SEMI-ASSEMBLED COMPACTOR BODY	175
0521055054	LEFT ARM WITH SLEEVE	176
0521055066	RIGHT ARM WITH GLOVE	177
0521055068	RAYED WHEEL CENTER CLOSED	178
0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	179
0521055398	DEPTH WHEEL	180
0501059228	ADJUSTMENT LEVER	181
0521055399	LEFT ARM WITH WHEEL	182
0521055400	RIGHT ARM WITH WHEEL	183
0521055058	LEFT ARM	184
0521055401	ASSY WHEEL	185
0521055073	ASSEMBLY DEPTH WHEEL BOX	186
0521055074	RIGHT ARM WITH O-RING	187
0521055093	BODY COMPACTOR	188
0521055017	RIGHT COMPACTOR WHEEL	189
0521054990	LEFT COMPACTOR WHEEL	190
0521055064	WHEEL SYSTEM DEPTH/ASSY COMPACTOR	191
0521055018	WHEEL DRIVE WHEEL LEFT IN V	192
0521055019	IRON IN RIGHT WHEEL COMPACTOR V	193
0521054991	WHEEL DRIVE WHEEL RIGHT	194
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	195
0521053946	SCARING ROD	196
0521057957	FIXED ROD EXTENSION WITH FIXATION	197
0521050525	FIXER FERTILIZER CONDUCTOR	198

FRAME ASSY

0909095865



Item	Code	Description	See page	7450	8460
01	0511053196	PST JOINT FRAME	2	01	00
01.	0511056311	ARTICULATION FRAME 8460	3	00	01
02	0521064285	LOCK LOWER FRAME		02	02
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		02	02
04	0503010002	1800 GREASE FITTING		02	02
05	0503010003	1845 GREASE FITTING		08	08
06	0503010004	1890 GREASE FITTING		02	02
07	0511059232	ASSEMBLY SPRING TRACTION	9	02	02
08	0521058402	WHEELED WITH 655 DRIFT SPRING WITH 10 TRANSMISSION		04	04
09	0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT 11 TRANSMISSION		02	04
10	0909098905	HEADER FULL ASSEMBLY - FRAME 25		01	01
11	0521052796	CYLINDER ASSEMBLY 5750/6850/7860/7960/8460	34	01	01
12	0511059419	HYDRAULIC SYSTEM ASSEMBLY 6850/7285/7450/7860/7960	36	01	00
12.	0521052860	HYDRAULIC SYSTEM ASSEMBLY 8160/8460	37	00	01
13	0521052622	ASSY SILO FERTILIZER 7450	39	01	00
13.	0521052744	ASSY SILO FERTILIZER 8460	40	00	01
14	0521050283	TRANSMISSION ASSEMBLY 7450	53	01	00
14.	0531050946	TRANSMISSION SET 7450	54	01	00
14..	0521050024	ASSEMBLY TRANSMISSION 7960	55	00	01
15	0521052672	PLATFORM ASSEMBLY 7450	79	01	00
15.	0521052676	PLATFORM ASSEMBLY 8460	80	00	01
16	0511058252	HANDLE ASSEMBLY 7450	81	01	00
16.	0511058282	HANDLE ASSEMBLY 8460	82	00	01
17	0521052698	ASSEMBLY CSU C3 SEMI MOUNTED 7285/7450	83	01	00
17.	0511058398	ASSEMBLY CSU C3 SEMI MOUNTED 7860/8460	84	00	01
18	0511054971	JACK ASSEMBLY	91	02	02
19	0511056536	LADDER ASSEMBLY	92	02	02


FRAME ASSY

0909095865

Item	Code	Description	See page	7450	8460
20	0511057512	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE	93	01	00
20.	0511057889	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE 8460	94	00	01
21	0501065677	STRUT		02	02
22	0521053076	LABEL ASSY FOR MH/CSU	97	01	00
22.	0521053085	SUPREME LABEL SET	98	00	01
23	0521052827	AXIS TRANSMISSION SEED ASSY 7450	99	01	00
23.	0521052863	AXIS TRANSMISSION SEED ASSY 8460	100	00	01
24	0521052803	REAR LIGHT ASSEMBLY	102	01	00
24.	0521052844	REAR LIGHT ASSEMBLY 7860/7960/8160/8460	103	00	01
25	0503010246	CLAMP		15	15
26	0521050282	TURBINE ASSEMBLY MTH PP CSU	105	01	00
26.	0521053016	TURBINE ASSEMBLY MTH PP CSU PST TRIO FLEX SUP PP 7860/8460 17	106	00	01
27	0521052814	ASSY MANUAL DOOR	121	01	01
28	0541015451	FIXED KEY 2.3/8 X 2.3/4		01	01
29	0521013022	TRANSPORT LOCK		03	03
30	0501068994	8,30 X 78 LOCK PIN		03	03
31	0503030168	HITCH PIN CLIP		03	03
32	0501047895	ROD STOP		03	03
33	0501047885	ROD STOP		03	03
34	0501047886	ROD STOP		03	03
35	0501047887	ROD STOP		03	03
36	0521066304	HOSE GUIDE		01	01
37	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02	02
38	0503013816	5/16" LOCKNUT		02	02
39	0503019262	SOAP DISH VACUUM		01	01
40	0503010780	N-2050 AMENDMENT		02	02
41	0503010951	REDUCTION		04	04
42	0503011750	AMENDMENT WITH LOCK		06	06
43	0503011751	REDUCTION		06	06
44	0501053834	MALE QUICK COUPLER	122	01	01
45	0503010045	O'RING		01	01
46	0541010080	TERMINAL R.1 / 2 NPT		01	01
47	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01	01
48	0581013729	NIPLE 1/2 NPT		01	01
49	0521053426	MONITORING ASSEMBLY PLANTING SEEDS PM400	15L 123	01	00
50	0511057817	SUPPORT HOSE	124	01	01
51	0521025447	BOX WITH HYDRAULIC MARKER COMPONENTS	125	01	01
52	0909095866	SEED LINE/FERTILIZER ASSEMBLY	127	15	17

PST JOINT FRAME


0511053196




Item	Code	Description	See page	QT
01	0511053188	RIGHT FRAME WITH WHEELED AXLE 7450	4	01
02	0511053189	LEFT FRAME WITH WHEELED AXLE 7450	6	01
03	0511053190	CENTRAL FRAME WITH WHEELED AXLE 6450/7285/7450/8460	8	01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	3/4" UNC BOLT		18
07	0571010094	SLEEVE FLANGE		06
08	0521063912	PIVOT SHAFT		02
09	0571013510	LOCK AXLE		02
10	0503030085	LOCK PIN		02
11	0571010095	FLAT WASHER		02
12	0503010365	NUT		04
13	0503011444	SPRING WASHER		04
14	0502012698	CLAMP		04
15	0501011643	3/8 X 1" BOLT		14
16	0503010025	3/8" SPRING WASHER		14
17	0503010026	3/8" NUT		14
18	0521063003	LOCK PIN		02
19	0571010969	LOCK SLEEVE FRAME		02
20	0503013627	1.1/2 SPRING WASHER		02
21	0501010110	1.1/2" NUT		02
22	0581018018	TROUGH 24 X 50 X 1255		02
23	0581018019	TROUGH 24 X 50 X 1070		02
24	0581015857	GUTTER 24 X 50 X 1080		02

ARTICULATION FRAME 8460


0511056311




Item	Code	Description	See page	QT
01	0511056312	RIGHT FRAME WITH WHEELED AXLE 8460	5	01
02	0511056313	LEFT FRAME WITH WHEELED AXLE 8460	7	01
03	0511053190	CENTRAL FRAME WITH WHEELED AXLE 8450/7285/7450/8460	8	01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER		16
06	0501010098	3/4" UNC BOLT		16
07	0571010094	SLEEVE FLANGE		06
08	0521063912	PIVOT SHAFT		02
09	0571013510	LOCK AXLE		02
10	0503030085	LOCK PIN		02
11	0571010095	FLAT WASHER		02
12	0503011442	3/4" SPRING WASHER		02
13	0501010098	3/4" UNC BOLT		02
14	0521063003	LOCK PIN		02
15	0571010969	LOCK SLEEVE FRAME		02
16	0503013627	1.1/2 SPRING WASHER		02
17	0502012698	CLAMP		04
18	0503010365	NUT		04
19	0503011444	SPRING WASHER		04
20	0501010110	1.1/2" NUT		02
21	0581017979	GUTTER		02
22	0581017935	GUTTER		02
23	0581018018	TROUGH 24 X 50 X 1255		02
24	0501011643	3/8 X 1" BOLT		12
25	0503010025	3/8" SPRING WASHER		12
26	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
01	0521064009	RIGHT FRAME PST TRIO 15		01
02	0521064023	ARTICLES AXLE RIGHT ROLLED		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521065394	RIGHT CHASSIS		01
02	0521065222	SIDE ROD JOINT AXLE		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521064010	LEFT FRAME PST TRIO 15		01
02	0521064021	ARTICLES AXLE LEFT ROLLED		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521065395	LEFT CHASSIS		01
02	0521065223	SHAFT SHAFT SHAFT SIDE SHAFT		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521064011	CENTRAL FRAME PST TRIO 15		01
02	0521064022	CENTRAL ARTICLES AXLE ROLLED		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		05
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		10
03	0501012140	FLAT WASHER		10




Item	Code	Description	See page	QT
01	0521058401	655 WHEELED SUPPORT WITH TRANSMISSION	12	01
02	0521055234	WHEELED FASTENER	17	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	22	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	WHEEL SUPPORT CHAIN TENSIONER	13	01
07	0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH 14 TRANSMISSION		01
08	0503018981	BOLT		02
09	0503010027	5/8" SPRING WASHER		04
10	0591010589	BODY LOCK WHEEL		01
11	0521069983	WHEEL COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0503063172	WHEEL	15	01
02	0521055233	WHEELED TRANSMISSION WITHOUT TIRE	16	01




Item	Code	Description	See page	QT
01	0503019458	TIRE 7.00X16 14PR		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0502011339	15Z GEAR P 1.25"		01
09	0503012550	5/16" X 3/4" BOLT		06
10	0503010002	1800 GREASE FITTING		01

WHEELED FASTENER


0521055234




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0521055236	INTERMEDIARY CURRENT STRETCHER	18	01
07	0521055237	WHEEL FIXED CURRENT STRETCHER	19	01
08	0521055235	WHEEL MOBILE CURRENT STRETCHER	20	01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN	21	01
02	0551018245	CHAIN TENSIONER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0551018239	SLEEVE 19 X 13,50 X 45		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN	21	01
02	0551018252	CHAIN TIGHTENER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN	21	01
02	0551018244	CHAIN UPPER AXLE		01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503019355	BEARING 6202 2RS1		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8" SPRING WASHER		02
08	0591010589	BODY LOCK WHEEL		02
09	0521058394	WHEEL WITH PNEUME	23	01



Item	Code	Description	See page	QT
01	0503063172	WHEEL	15	01
02	0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	24	01



Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	5750	5850	6850	7450
01	0521066289	FRONT HEADER 5750/6350/6850		001	001	001	001
02	0521066290	INTERMEDIATE HEAD 5750/6850/7860/8160		001	000	001	000
02.	0521067151	INTERMEDIATE HEAD 5850/7960		000	001	000	000
02...	0521067075	INTERMEDIATE HEAD 6450/7285/7350/7450/8460		000	000	000	001
03	0571019949	JUNCTION SHAFT		006	006	006	006
04	0503030119	LOCK PIN		010	010	010	010
05	0511055096	TRACTOR HITCH	26	001	001	001	001
06	0511053179	TRACTOR COUPLING SHAFT	27	001	001	001	001
07	0503014120	CHAIN		001	001	001	001
08	0521051614	TURNBUCKLE SIDE UPPER	28	002	002	002	002
09	0521010571	COUPLING SHAFT		004	004	004	004
10	0503030085	LOCK PIN		006	006	006	006
11	0521052754	LATERAL EXTENSOR 505/316		002	000	000	000
11.	0521051616	TURNBUCKLE SIDE 505/480		000	002	000	000
11..	0521050133	TURNBUCKLE SIDE 755/480	29	000	000	002	002
12	0571019951	JUNCTION SHAFT		003	003	003	003
13	0503010523	1/4" X 2" COTTERPIN		004	004	004	004
14	0503034772	BOX		001	001	001	001
15	0521068652	TOOLS BOX SUPPORT		001	001	001	001
16	0501011643	3/8 X 1"BOLT		004	004	004	004
17	0503010025	3/8" SPRING WASHER		004	004	004	004
18	0503010026	3/8" NUT		004	004	004	004
19	0581017000	PLATE INTERMEDIARY		002	002	002	002
20	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		004	004	004	004
21	0503010025	3/8" SPRING WASHER		004	004	004	004
22	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		004	004	004	004
23	0503014321	CABLE STEEL SHACKLE		002	002	002	002
24	0502010584	CARRYING-WHEELS SUPPORT FIXER		008	008	008	008
25	0503016485	BOLT 3/4		016	016	016	016
26	0501010322	FLAT WASHER		032	032	032	032
27	0503010152	3/4" SELF LOCKING NUT		016	016	016	016


Item	Code	Description	See page	5750	5850	6850	7450
28	0521067716	FIXER TUBE		004	004	004	004
29	0511059237	3 POINT TURNBUCKLE	30	001	001	001	001
30	0571019950	COUPLING SHAFT		001	001	001	001
31	0521045756	HYDRAULIC CYLINDER	31	001	001	001	001
32	0521010779	31.75 X 95 COUPLING SHAFT		001	001	001	001
33	0521010581	0.9" X 4.9" COUPLING SHAFT		001	001	001	001
34	0531016049	FLAT WASHER		002	002	002	002
35	0503014820	BLACK WATER RESERVOIR		001	001	001	001
36	0521068651	SUPPORT BOX		001	001	001	001
37	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		000	000	001	001
38	0501212237	HITCH GLOVE ARTICULATED 85 X 35 MM		001	001	001	001

TRACTOR HITCH


0511055096




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0502011195	ADJUSTMENT NUT BODY		01
02	0521068096	EXTENSOR R.1.1 / 2 UNC RIGHT		01
03	0521068095	EXTENSOR R.1.1/2 UNC LEFT		01
04	0541018672	COUNTERNUT		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521065193	TURNBUCKLE AXLE		01
02	0521067392	FIXED BRACKET		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03




Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0511061880	SIDE RIGHT RATCHET		01
03	0511061881	RATCHET FOLLOWER		01
04	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
05	0503011179	3/8" X 2-1/4" BOLT		05
06	0503010025	3/8" SPRING WASHER		05
07	0503010026	3/8" NUT		05
08	0503010002	1800 GREASE FITTING		02
09	0531010264	SIDE RATCHET		01
10	0521066919	3-POINT EXTENSOR RIGHT FUSE		01
11	0521066337	LEFT EXTENSOR 3 SPIKE		01




Item	Code	Description	See page	QT
01	0511057653	HYDRAULIC CYLINDER	32	01
02	0501053835	FEMALE QUICK COUPLER	33	02




Item	Code	Description	See page	QT
01	0521066550	CASE		01
02	0521066551	EXTENSION DRAWBAR		01
03	0503010002	1800 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010669	EMBOLUS 63.50 X 40 USAP		01
06	0503018005	RING		01
07	0503010558	7/8" NUT		01
08	0502010471	MOBILE COVER		01
09	0503011058	8-330 BACK-UP RING		01
10	0571019866	RING SUPPORT		01
11	0503010163	D-1500 SCRAPER RING		01
12	0503018004	RING		01
13	0503010161	2-330 N 3006 9B O'RING		01
14	0503018003	GASKET		01
15	0503010605	O'RING		01
16	0581010652	JIC ADAPTER		01




Item	Code	Description	See page	QT
01	0503011883	QUICK CONNECTION COVER		01
02	0503011628	FEMALE QUICK COUPLER		01



Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	35	03
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521015501	COUPLING SHAFT		03
04	0503010523	1/4" X 2" COTTERPIN		06
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		03
06	0531012565	SLEEVE 16,3X 30 X 88		03
07	0503010027	5/8" SPRING WASHER		03
08	0503010013	5/8" NUT		03
09	0551014099	COUPLING SHAFT 31,75 X 185		01




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O'RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O'RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0591019605	FLUXO DIVIDER VALVE SUPPORT		01
01.	0591019604	VALVE SUPPORT		01
02	0511059290	VALVE ASSEMBLY	38	01
03	0501053835	FEMALE QUICK COUPLER	33	02
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
05	0531011180	UPPER BODY CLIP		04
06	0521066564	DUCT SEAL OIL		01
07	0531013922	0.6" X 0.8" X 1" SLEEVE		02
08	0503011179	3/8" X 2-1/4" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0502012702	BODY SUPPORT CLAMP		12
12	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
13	0501053834	MALE QUICK COUPLER	122	04
14	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
15	0503010244	7/16" NUT		04
16	0503010180	7/16" SPRING WASHER		08
17	0503010920	1/2" X 1.1/2" BOLT		02
18	0511017302	FLAT WASHER		02
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2" NUT		02
21	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
22	0571017774	SPRING PROTECTION QUICK HOSE		01
23	0511059418	HYDRAULIC SYSTEM HOSE ASSEMBLY		01
23A	0501080406	3/8" X 23" TR-TC HOSE		01
23B	0501080150	3/8 X 800 TR-TC HOSE		01
23C	0501081930	HOSE		01
23D	0501081646	TC-TC HOSE ASSY		03
24	0521052484	HOSE 1/2 X 4122 TM-TM BLACK / RED		01
24A	0501080881	HOSE		01
24B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02

Item	Code	Description	See page	QT
24C	0503034495	HYDRAULIC HOSE GRIP (RED)		02
24D	0503018952	PLASTIC BOLT		12
25	0521052485	HOSE 1/2 X 4122 TM-TM BLACK / BLUE		01
25A	0501080881	HOSE		01
25B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
25C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02
25D	0503018952	PLASTIC BOLT		12




Item	Code	Description	See page	QT
01	0571013472	FIXER BODY VALVE		01
02	0511059290	VALVE ASSEMBLY	38	01
03	0501053835	FEMALE QUICK COUPLER	33	02
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
05	0531011180	UPPER BODY CLIP		04
06	0521066564	DUCT SEAL OIL		01
07	0531013922	0.6" X 0.8" X 1" SLEEVE		02
08	0503011179	3/8" X 2-1/4" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0502012702	BODY SUPPORT CLAMP		12
12	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
13	0501053834	MALE QUICK COUPLER	122	04
14	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
15	0503010244	7/16" NUT		04
16	0503010180	7/16" SPRING WASHER		08
17	0503010920	1/2" X 1.1/2" BOLT		02
18	0511017302	FLAT WASHER		02
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2" NUT		02
21	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
22	0571017774	SPRING PROTECTION QUICK HOSE		01
23	0511059418	HYDRAULIC SYSTEM HOSE ASSEMBLY		01
23A	0501080406	3/8" X 23" TR-TC HOSE		01
23B	0501080150	3/8 X 800 TR-TC HOSE		01
23C	0501080392	3/8 X 3300 TR-TC HOSE		01
23D	0501080442	3/8" X 130" TC-TC HOSE ASSY		03
24	0521052484	HOSE 1/2 X 4122 TM-TM BLACK / RED		01
24A	0501080881	HOSE		01
24B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
24C	0503034495	HYDRAULIC HOSE GRIP (RED)		02

Item	Code	Description	See page	QT
24D	0503018952	PLASTIC BOLT		12
25	0521052485	HOSE 1/2 X 4122 TM-TM BLACK / BLUE		01
25A	0501080881	HOSE		01
25B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
25C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02
25D	0503018952	PLASTIC BOLT		12




Item	Code	Description	See page	QT
01	0503016524	DIVIDER VALVE		01
02	0581011593	NIPPLE R.1.1/16 UN		01
03	0511010111	7/8" NIPPLE		03
04	0503011109	2-119 N 3006-9B O'RING		01
05	0503010045	O'RING		03




Item	Code	Description	See page	QT
01	0521052620	SUPPORT SILO RIGHT FERTILIZER WITH DISTRIBUTOR 7450	43	01
02	0521052621	SILO SUPPORT LEFT FERTILIZER WITH DISTRIBUTOR 7450	44	01
03	0521051607	SUPPORT SILO CENTRAL FERTILIZER 6450/7285/7450/8460	45	01
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		40
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0503062391	FERTILIZER BOX		02
09	0571019051	FIXER BOX WASHER		26
10	0503013751	3/8 UNC X 1.1/4 BOLT		26
11	0503012535	3/8" SPRING WASHER		26
12	0503012531	3/8" INOX NUT		26
13	0503011957	NYLON LUG		02
14	0503010371	5/16" X 1" BOLT		04
15	0503010179	LOCK WASHER		08
16	0503010337	5/16" NUT		08
17	0501010694	FLAT WASHER		04
18	0503011953	5/16" X 1" BOLT		04
19	0551019168	SLEEVE		02
20	0551019160	LEVER		02
21	0551019167	SLEEVE UNION		02
22	0511017302	FLAT WASHER		06
23	0503010479	BOLT		02
24	0503011336	1/2" HEX SELF ADJUSTING NUT		06
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
26	0503010019	1/2" SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0501013518	FLAT WASHER		06
29	0503010140	1/8" X 3/4" COTTERPIN		06

Item	Code	Description	See page	QT
30	0511069678	LH LOWER LEVER		02
31	0561016468	FASTENER		02
32	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	49	02
33	0581012605	GEAR BOX LEVER LOCK		02
34	0521061741	INNTER LEVER		02
35	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	50	01
36	0551019159	LEVER FIXER BODY		02
37	0503034396	FERTILIZER SIDE COVER		15
38	0503010362	1/8 X 1.1/4 COTTERPIN		15
39	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		01
40	0521050195	SILO FERTILIZER LEFT SQUARE AXLE	51	01




Item	Code	Description	See page	QT
01	0521052709	SUPPORT SILO RIGHT FERTILIZER WITH 41 DISTRIBUTOR 8460/8960/9460	01	01
02	0521052718	SILO SUPPORT LEFT FERTILIZER WITH 42 DISTRIBUTOR 8460/8960/9460	01	01
03	0521051607	SUPPORT SILO CENTRAL FERTILIZER 45 6450/7285/7450/8460	01	01
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		40
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0571019051	FIXER BOX WASHER		28
09	0503013751	3/8 UNC X 1.1/4 BOLT		28
10	0503012535	3/8" SPRING WASHER		28
11	0503012531	3/8" INOX NUT		28
12	0503011957	NYLON LUG		02
13	0503010371	5/16" X 1" BOLT		04
14	0503010179	LOCK WASHER		08
15	0503010337	5/16" NUT		08
16	0501010694	FLAT WASHER		04
17	0503011953	5/16" X 1" BOLT		04
18	0551019168	SLEEVE		02
19	0551019160	LEVER		02
20	0551019167	SLEEVE UNION		02
21	0511017302	FLAT WASHER		06
22	0503010479	BOLT		02
23	0503011336	1/2" HEX SELF ADJUSTING NUT		06
24	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
25	0503010019	1/2" SPRING WASHER		02
26	0503010060	1/2" NUT		02
27	0501013518	FLAT WASHER		06
28	0503010140	1/8" X 3/4" COTTERPIN		06
29	0511069678	LH LOWER LEVER		02


Item	Code	Description	See page	QT
30	0561016468	FASTENER		02
31	0581012605	GEAR BOX LEVER LOCK		02
32	0521061741	INNTER LEVER		02
33	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	50	01
34	0551019159	LEVER FIXER BODY		02
35	0503034396	FERTILIZER SIDE COVER		17
36	0503010362	1/8 X 1.1/4 COTTERPIN		17
37	0503062589	SILO FERTILIZER 6 MOUTHS MOUNTED		03
38	0521050195	SILO FERTILIZER LEFT SQUARE AXLE	51	01
39	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	49	02




Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	46	01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	47	05
03	0501010942	3/8" X 1-1/4" BOLT		24
04	0503010025	3/8" SPRING WASHER		24
05	0503010026	3/8" NUT		24
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0503013816	5/16" LOCKNUT		02
11	0581016967	SQUARE SHAFT		01
12	1902010685	18Z CONICAL GEAR		06
13	0503030275	AGRICULTURAL BEARING		06
14	0501053788	3/4 SQUARE AXLE FASTENER	48	01
15	0501110392	BOX SUPPORT BEARING		01
16	0503010003	1845 GREASE FITTING		01
17	0521068602	SUPPORT RIGHT SILO FERTILIZER WITH DISTRIBUTOR		01
18	0503011953	5/16" X 1" BOLT		02
19	0521011039	FLAT WASHER		02
20	0503010179	LOCK WASHER		02
21	0503010337	5/16" NUT		02
22	0521012485	GEAR BOX BEARING AGRICUTURAL		01




Item	Code	Description	See page	QT
01	0521068612	SILO FERTILIZER SUPPORT WITH DISTRIBUTOR		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	46	05
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	47	01
04	0501010942	3/8" X 1-1/4" BOLT		24
05	0503010025	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0503010337	5/16" NUT		02
12	0581016967	SQUARE SHAFT		01
13	0503030275	AGRICULTURAL BEARING		06
14	1902010685	18Z CONICAL GEAR		06
15	0503010003	1845 GREASE FITTING		01
16	0501053788	3/4 SQUARE AXLE FASTENER	48	01
17	0521012485	GEAR BOX BEARING AGRICUTURAL		01
18	0501110392	BOX SUPPORT BEARING		01
19	0503011953	5/16" X 1" BOLT		02
20	0521011039	FLAT WASHER		02
21	0503010179	LOCK WASHER		02
22	0503013816	5/16" LOCKNUT		02



Item	Code	Description	See page	QT
01	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	46	02
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	47	03
03	0501010942	3/8" X 1-1/4" BOLT		20
04	0503011443	3/8" SPRING WASHER		20
05	0503010026	3/8" NUT		20
06	0521014167	CONE LOCK		01
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0571019828	LOCK AXLE		01
09	0503010365	NUT		02
10	0501053788	3/4 SQUARE AXLE FASTENER	48	01
11	0501110392	BOX SUPPORT BEARING		01
12	0503030275	AGRICULTURAL BEARING		05
13	0503011953	5/16" X 1" BOLT		02
14	0521011039	FLAT WASHER		02
15	0503011444	SPRING WASHER		02
16	0503010337	5/16" NUT		02
17	0503010003	1845 GREASE FITTING		01
18	1902010685	18Z CONICAL GEAR		05
19	0521012485	GEAR BOX BEARING AGRICUTURAL		01
20	0581018078	SQUARE AXLE 3/4 X 1944.5		01
21	0521069062	SILO FERTILIZER RIGHT SUPPORT		01
22	0503013816	5/16" LOCKNUT		02




Item	Code	Description	See page	QT
01	0521068563	LEFT SILO FERTILIZER SUPPORT		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	46	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	47	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0521014167	CONE LOCK		01
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01
09	0571019828	LOCK AXLE		01
10	0503010365	NUT		02
11	0501053788	3/4 SQUARE AXLE FASTENER	48	01
12	0501110392	BOX SUPPORT BEARING		01
13	0521012485	GEAR BOX BEARING AGRICUTURAL		01
14	0503011953	5/16" X 1" BOLT		02
15	0521011039	FLAT WASHER		02
16	0503011444	SPRING WASHER		02
17	0503010337	5/16" NUT		02
18	0503010003	1845 GREASE FITTING		01
19	1902010685	18Z CONICAL GEAR		05
20	0503030275	AGRICULTURAL BEARING		05
21	0581016776	SQUARE AXLE 3/4 X 2028		01
22	0503013816	5/16" LOCKNUT		02



Item	Code	Description	See page	QT
01	0521068089	SUPPORT CENTRAL SILO FERTILIZER		01
02	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	46	03
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	47	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0581016973	SQUARE AXLE 3/4 X 790		01
08	0571019828	LOCK AXLE		02
09	0503010365	NUT		04
10	1902010685	18Z CONICAL GEAR		05
11	0503030275	AGRICULTURAL BEARING		05
12	0503013816	5/16" LOCKNUT		04
13	0511062163	FERTILIZER BEAM LOWER COVER		01
14	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
15	0501011643	3/8 X 1" BOLT		04
16	0581016950	SQUARE AXLE 3/4 X 1115		01

RIGHT SIDE FERTILIZER DISTRIBUTOR


0511051535




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01

LEFT SIDE FERTILIZER DISTRIBUTOR


0511051558




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0503030331	1.2" X 1.2" X 12.2" HOSE		01
02	0503010243	CLAMP		02
03	0503062755	TRANSMISSION AXLE		01
04	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0581013322	BEARING RIGHT SUPPORT		01
02	0503011953	5/16" X 1" BOLT		04
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
04	0501010694	FLAT WASHER		04
05	0503013816	5/16" LOCKNUT		04
06	0501056444	BEARING WITH ROLLING	52	01



Item	Code	Description	See page	QT
01	0581013324	BEARING LEFT SUPPORT		01
02	0503011953	5/16" X 1" BOLT		04
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
04	0501010694	FLAT WASHER		04
05	0503013816	5/16" LOCKNUT		04
06	0501056444	BEARING WITH ROLLING	52	01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571014439	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	MOTOR AXLE SIGNAL	56	02
15	0511051434	TRANSMISSION ACTUATOR	57	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	58	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	59	01
18	0521050183	RIGHT GEAR BOX ASSY	60	01
19	0521050184	EXCHANGE LEFT ASSY	62	01
20	0503014734	BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064449	36Z P1/2 SH 3/4 GEAR		02
26	0511059261	CHAIN TENSIONER	72	04
27	0521055217	LOWER CURRENT STRETCH	73	02
28	0501058254	UPPER SEED CHAIN TENSIONER	74	02
29	0521055216	BEARING WITH GEAR	75	02
30	0521055218	BEARING GEAR WITH DOUBLE	76	02
31	0521055214	BEARING GEAR WITH	77	02

Item	Code	Description	See page	QT
32	0503012522	40-1 CHAIN X 85 LINK + MENDING		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571014439	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	MOTOR AXLE SIGNAL	56	02
15	0511051434	TRANSMISSION ACTUATOR	57	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	58	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	59	01
18	0531050914	COMPLETE RIGHT EXCHANGE PP CBA SORETTO	61	01
19	0531050916	COMPLETE LEFT EXCHANGE PP CBA SORETTO	63	01
20	0501011600	1/2" X 1-1/4" BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064449	36Z P1/2 SH 3/4 GEAR		02
26	0511059261	CHAIN TENSIONER	72	04
27	0521055217	LOWER CURRENT STRETCH	73	02
28	0501058254	UPPER SEED CHAIN TENSIONER	74	02
29	0521055216	BEARING WITH GEAR	75	02
30	0521055218	BEARING GEAR WITH DOUBLE	76	02
31	0521055214	BEARING GEAR WITH	77	02

Item	Code	Description	See page	QT
32	0503012522	40-1 CHAIN X 85 LINK + MENDING		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571014442	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	MOTOR AXLE SIGNAL	56	02
15	0511051434	TRANSMISSION ACTUATOR	57	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	58	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	59	01
18	0521050183	RIGHT GEAR BOX ASSY	60	01
19	0521050184	EXCHANGE LEFT ASSY	62	01
20	0501011600	1/2" X 1-1/4" BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064449	36Z P1/2 SH 3/4 GEAR		02
26	0511059261	CHAIN TENSIONER	72	04
27	0521055217	LOWER CURRENT STRETCH	73	02
28	0501058254	UPPER SEED CHAIN TENSIONER	74	02
29	0521055216	BEARING WITH GEAR	75	02
30	0521055218	BEARING GEAR WITH DOUBLE	76	02
31	0521055214	BEARING GEAR WITH	77	02


Item	Code	Description	See page	QT
32	0503012522	40-1 CHAIN X 85 LINK + MENDING		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02



Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

LEFT SIDE TRANSMISSION ACTUATOR


0511047070




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY

0521050183




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	64	01
02	0511059266	CLOSED BEARING	66	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	68	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	69	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	70	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	71	01
23	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01
30	0511065209	20Z GEAR		01




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	64	01
02	0511059266	CLOSED BEARING	66	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	68	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	69	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	70	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	71	01
23	0503017397	CHAIN 40-1 X 60 ELOS + RED		01
24	0511061757	18Z GEAR		01
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01
30	0521061010	GEAR 32Z STEP 1/2 "CF 3/4"		01

EXCHANGE LEFT ASSY


0521050184




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	65	01
02	0511059266	CLOSED BEARING	66	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	68	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	69	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	70	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	71	01
23	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01
30	0511065209	20Z GEAR		01




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	65	01
02	0511059266	CLOSED BEARING	66	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	68	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	69	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	70	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	71	01
23	0503017397	CHAIN 40-1 X 60 ELOS + RED		01
24	0511061759	22Z P12,70 FQ 3/4" GEAR		01
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01
30	0521061010	GEAR 32Z STEP 1/2 "CF 3/4"		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	67	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	52	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0503031805	1 1/2" GEAR		01
02	0511017302	FLAT WASHER		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0521018933	FERT CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501011234	5/8" X 3" BOLT		01
02	0531017086	50 AXLETIGHTENER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0503019356	BEARING 6005 2RS1		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0503016460	5/8" X 4.1/2" BOLT		01
02	0551019175	DOUBLE GEAR AXLE		01
03	0503019356	BEARING 6005 2RS1		02
04	0511069680	20Z X 28Z DOBLE GEAR		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511063106	20Z AXLE BEARING DOBLE		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521055215	DOUBLE TRANSMISSION BEARING	78	01
04	0503010365	NUT		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503019356	BEARING 6005 2RS1		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521068580	RIGHT PLATFORM	01	
02	0521068596	CENTRAL PLATFORM	01	
03	0521068588	LEFT PLATFORM	01	
04	0581015863	PLATFORM ENHANCEMENT PROTECTION	02	
05	0501010942	3/8" X 1-1/4" BOLT	04	
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN	28	
07	0503010025	3/8" SPRING WASHER	16	
08	0503010026	3/8" NUT	16	
09	0521068316	JOINT SUPPORT	06	
10	0503010849	3/8" X 1-1/2" BOLT	12	
11	0521010549	COUPLING SHAFT	06	
12	0503030168	HITCH PIN CLIP	06	
13	0503010741	1/2" X 2-3/4" BOLT	06	
14	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
15	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
16	0502012739	PLATFORM LEFT FIXER SUPPORT	02	
17	0503011333	COVER FIXER	03	
18	0503010274	5/32"X 2" COTTERPIN	03	




Item	Code	Description	See page	QT
01	0521068579	RIGHT PLATFORM		01
02	0521068596	CENTRAL PLATFORM		01
03	0521068587	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		28
07	0503010025	3/8" SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	HITCH PIN CLIP		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32"X 2" COTTERPIN		03




Item	Code	Description	See page	QT
01	0521064019	SIDE HANDRAIL		02
02	0521064018	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0521064280	SIDE HANDRAIL		02
02	0521064018	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2" NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8" SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0521052699	ASSEMBLY CSU C3 2BOX 6/5 - 1BOX 7/5 7285/7450	86	01
02	0501010942	3/8" X 1-1/4" BOLT		12
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		12
04	0503010025	3/8" SPRING WASHER		12
05	0503010026	3/8" NUT		12
06	0521052687	RH SUPPORT TOWER SILO	87	02
07	0521051931	LH SUPPORT TOWER SILO	89	02
08	0521051927	TOWER SUPPORT HOPPER	90	02




Item	Code	Description	See page	QT
01	0511058397	ASSEMBLY CSU C3 3BOX 7B WITH 17 C 7860	85	01
02	0501010942	3/8" X 1-1/4" BOLT		12
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		12
04	0503010025	3/8" SPRING WASHER		12
05	0503010026	3/8" NUT		12
06	0521051931	LH SUPPORT TOWER SILO	89	01
07	0521052687	RH SUPPORT TOWER SILO	87	01
08	0521051927	TOWER SUPPORT HOPPER	90	04




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		06
02	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
03	0503010025	3/8" SPRING WASHER		90
04	0503010026	3/8" NUT		90
05	0511057690	3" ARTICULATED SEED CONDUCTOR	88	17
06	0501010942	3/8" X 1-1/4" BOLT		68
07	0571015773	SUPPORT SEED		04
08	0501011643	3/8 X 1"BOLT		16
09	0521064874	07 NOZZLES SUPPORT BOX SEED ONLY		03
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		03




Item	Code	Description	See page	QT
01	0521063401	SEED BOX ONLY FIXING LOCK		06
02	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
03	0503010025	3/8" SPRING WASHER		82
04	0503010026	3/8" NUT		82
05	0511057690	3" ARTICULATED SEED CONDUCTOR	88	15
06	0501010942	3/8" X 1-1/4" BOLT		60
07	0571015773	SUPPORT SEED		04
08	0501011643	3/8 X 1"BOLT		16
09	0521064813	SINGLE SEED BOX SUPPORT - 06 NOZZLES		02
10	0503061899	REAR BEAN FERTILIZER ASSY		02
11	0521064874	07 NOZZLES SUPPORT BOX SEED ONLY		01
12	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		01




Item	Code	Description	See page	QT
01	0521066206	RH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01




Item	Code	Description	See page	QT
01	0521066207	LH SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066208	SUPPORT TOWER SILO		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501054649	HBM SEQUENTIAL VALVE	95	01
02	0511058431	HYDRAULIC CYLINDER	96	01
03	0511058431	HYDRAULIC CYLINDER	96	01
04	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
05	0501068994	8,30 X 78 LOCK PIN		02
06	0503030168	HITCH PIN CLIP		02
07	0511057094	HYDRAULIC HOSE MARKER ASSY 6450		01
07A	0501080783	HOSE 3/8 X 5000 TR-TR		02
07B	0501081659	HOSE 3/8 X 5300 TR-TR 2T		02
07C	0521052512	HOSE 3/8 X 5200 TC-TM PURPLE / RED		01
07CA	0501081980	HOSE 3/8 X 5200 TC-TM		01
07CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
07CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
07CD	0503018952	PLASTIC BOLT		06
07D	0521052513	HOSE 3/8 X 5200 TC-TM PURPLE / BLUE		01
07DA	0501081980	HOSE 3/8 X 5200 TC-TM		01
07DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
07DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
07DE	0503018952	PLASTIC BOLT		06
08	0501053834	MALE QUICK COUPLER	122	02
09	0511018012	HIDRAULIC ADAPTER		04




Item	Code	Description	See page	QT
01	0501054649	HBM SEQUENTIAL VALVE	95	01
02	0511058431	HYDRAULIC CYLINDER	96	01
03	0511058431	HYDRAULIC CYLINDER	96	01
04	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
05	0501068994	8,30 X 78 LOCK PIN		02
06	0503030168	HITCH PIN CLIP		02
07	0511057890	17 E 500 HYDRAULIC MARKER HOSE ASSEMBLY		01
07A	0501080383	3/8" X 197" TC-TM HOSE		02
07B	0501081748	HOSE		02
07C	0501081981	HOSES		02
08	0501053834	MALE QUICK COUPLER	122	02
08A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
08B	0503011882	MALE QUICK COUPLER CAP		01
09	0511018012	HIDRAULIC ADAPTER		04



Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0501067700	2.5" X 25" CYLINDER CASE		01
02	0521066632	EXTENDER		01
03	0503030384	CON PLUG N-001		02
04	0502012837	PISTON		01
05	0503018005	RING		01
06	0503011109	2-119 N 3006-9B O'RING		01
07	0503010163	D-1500 SCRAPER RING		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503018004	RING		01
11	0503018003	GASKET		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503010002	1800 GREASE FITTING		02
15	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503034420	ADHESIVE LABEL	01	
02	0503034419	ADHESIVE LABEL PST TRIO FLEX SUPREME MINOR (05 MOUTH)	02	
03	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)	02	
04	0503033854	ADHESIVE LABEL	01	
05	0503034056	ADHESIVE LABEL PST TRIO FLEX SUPREMA	02	
06	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING	02	
07	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	02	
08	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
09	0503033421	ADHESIVE LABEL 7 NUMBER FOR PLANTING	02	
10	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
11	0503033008	ADHESIVE LABEL	02	
12	0503031428	READ MANUAL DECAL	01	
13	0503031942	ADHESIVE LABEL	01	
14	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS	02	
15	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
16	0503031565	ADHESIVE LABEL CARE	02	
17	0503031566	ADHESIVE LABEL	02	
18	0503034249	ADHESIVE LABEL TABLE PLANTS	02	
19	0503031425	ADHESIVE LABEL ATTENTION	02	
20	0503031669	ADHESIVE LABEL	01	
21	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
22	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
23	0503032930	ADHESIVE LABEL DANGER	08	
24	0503031087	ADHESIVE LABEL	01	
25	0503034078	LIFTING POINTS DECAL	03	
26	0503034003	SERIAL NUMBER TAG 61 X 118	01	
27	0503010001	3.2 X 5.5 RIVET	04	




Item	Code	Description	See page	QT
28	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
29	0503032979	ADHESIVE LABEL LETTERS A B C D		02
30	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503034420	ADHESIVE LABEL	01	
02	0503034114	ADHESIVE LABEL LOGO TATU BOX 190 X 530	02	
03	0503033854	ADHESIVE LABEL	01	
04	0503034056	ADHESIVE LABEL PST TRIO FLEX SUPREMA	02	
05	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING	02	
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	02	
07	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING	02	
08	0503033422	ADHESIVE LABEL	02	
09	0503033008	ADHESIVE LABEL	02	
10	0503031428	READ MANUAL DECAL	01	
11	0503031942	ADHESIVE LABEL	01	
12	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS	02	
13	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
14	0503031565	ADHESIVE LABEL CARE	02	
15	0503031566	ADHESIVE LABEL	02	
16	0503034249	ADHESIVE LABEL TABLE PLANTS	02	
17	0503031425	ADHESIVE LABEL ATTENTION	02	
18	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
19	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
20	0503032930	ADHESIVE LABEL DANGER	09	
21	0503031087	ADHESIVE LABEL	01	
22	0503034078	LIFTING POINTS DECAL	03	
23	0503034003	SERIAL NUMBER TAG 61 X 118	01	
24	0503010001	3.2 X 5.5 RIVET	04	
25	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO	02	
26	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
27	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0571013726	5/8 X 800 HEX AXLE		01
02	0571013724	5/8 X 1250 HEX AXLE		01
03	0571013725	5/8 X 2190 HEX AXLE		02
04	0503062206	CARDAN TERMINAL		02
05	0561014215	BEARING COVER LOWER ROW FRAME		02
06	0502040534	SPRING GUIDE BUSHING LOCK		08
07	0501018535	1/2 X 1 BOLT		08




Item	Code	Description	See page	QT
01	0571013470	5/8 X 1100 HEX AXLE		01
02	0581015232	2735 - 17 E 500 5/8" X 60.4" HEX AXLE		02
03	0581012154	HEX 5/8 X AXIS 755		01
04	0561014215	BEARING COVER LOWER ROW FRAME		02
05	0502040534	SPRING GUIDE BUSHING LOCK		08
06	0501018535	1/2 X 1 BOLT		08
07	0511059233	INTERMEDIATE TRANSMISSION	101	02




Item	Code	Description	See page	QT
01	0503062206	CARDAN TERMINAL		01
02	0503030331	1.2" X 1.2" X 12.2" HOSE		01
03	0503010243	CLAMP		02
04	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		16
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		03
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	104	03
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		15



Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		17
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		03
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	104	03
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		15




Item	Code	Description	See page	QT
01	0503018738	LIGHTHOUSE		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	LOCK WASHER		04
08	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		02
02	0501012140	FLAT WASHER		02
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0581011414	BODY RIGHT SUPPORT TURBINE		01
05	0581011413	SOPORTE IZQUIERDO CUERPO DE LA TURBINA		01
06	0581011415	SUPPORTER FIXING BAR		01
07	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
08	0503011239	1/2" X 2" BOLT		04
09	0511017302	FLAT WASHER		08
10	0503010019	1/2" SPRING WASHER		08
11	0503010060	1/2" NUT		08
12	0581012166	HOSE		04
13	0503011372	102 TO 121 CLAMP		06
14	0511059504	RIGHT AIR CONDUCTOR - 6850	113	01
15	0511059505	LEFT AIR CONDUCTOR - 6850	114	01
16	0511059503	6 MOUTH AIR CONDUCTOR X 2150 - 6850	115	01
17	0511059319	AIR FIXING SUPPORT	116	06
18	0581010952	VACUUM GAUGE SUPPORT		01
19	0503013584	VACUUM GAUGE		01
20	0571019716	ADAPTER		15
21	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		15
22	0503031436	AIR DITRIBUTOR PUMP		01
23	0503010246	CLAMP		01
24	0511057906	HOSE ASSY	112	01
24A	0511057840	ASSY TURBINE HOSE REAR		01
24AA	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
24AAA	0501081247	HOSE 1/2 X 7012 TC-TM		01
24AAB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
24AAC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
24AAD	0503018952	PLASTIC BOLT		06
25	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01

Item	Code	Description	See page	QT
25A	0501081247	HOSE 1/2 X 7012 TC-TM		01
25B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
25C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
26A	0501080477	HOSE 3/8 X 7012 TC-TM		01
26B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
26C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	122	02
28	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
29	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	117	01
30	0511059406	TURBINE P.P MOUNTED	118	01
31	0521052549	CLAMP	120	30




Item	Code	Description	See page	QT
01	0581012166	HOSE		02
02	0551015245	4 X 1150 HOSE		02
03	0503011372	102 TO 121 CLAMP		08
04	0521050260	SUPPORT ASSEMBLY P.P MTH	107	02
05	0521050016	DISTRIBUTOR AIR RIGHT 06 MOUTHS - 17 E500	108	01
06	0521050017	DISTRIBUTOR AIR LEFT 06 MOUTHS - 17 E500	109	01
07	0521052999	DISTRIBUTOR AIR CENTRAL 7 MOUTHS - 17	110	01
08	0503031436	AIR DITRIBUTOR PUMP		02
09	0503010246	CLAMP		02
10	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		17
11	0571019716	ADAPTER		17
12	0511059319	AIR FIXING SUPPORT	116	04
13	0521068698	AIR CONDUCTOR FIXING SUPPORT		04
14	0581013454	VALVE SUPPORT		01
15	0511057292	ASSY FLOW REGULATION VALVE	111	01
16	0521060118	"T" TERMINAL		01
17	0503033787	NUT 3/4 UNF		01
18	0502012702	BODY SUPPORT CLAMP		02
19	0503010674	7/16" X 3-1/4" BOLT		01
20	0503015490	SELF-LOCKING NUT 7/16		01
21	0501080714	3/8 X 1600 TR-TC HOSE		02
22	0501080060	1/2 X 1600 TR-TC HOSE		04
23	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0503012456	3/8" X 7/8" BOLT		02
27	0503010025	3/8" SPRING WASHER		02
28	0581010952	VACUUM GAUGE SUPPORT		01
29	0503013584	VACUUM GAUGE		01
30	0511057906	HOSE ASSY	112	01
31	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01


Item	Code	Description	See page	QT
31A	0501081247	HOSE 1/2 X 7012 TC-TM		01
31B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
31C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
31D	0503018952	PLASTIC BOLT		06
32	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
32A	0501080477	HOSE 3/8 X 7012 TC-TM		01
32B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
32C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
32D	0503018952	PLASTIC BOLT		06
33	0501053834	MALE QUICK COUPLER	122	02
34	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
35	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	117	01
36	0521052549	CLAMP	120	34
37	0511059887	TURBINE PRECISION PLANTING		02




Item	Code	Description	See page	QT
01	0502010175	HITCH CLAMP		01
02	0501011543	5/8" X 4" BOLT		02
03	0501012140	FLAT WASHER		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0571019403	STAPLE FIXER		01
06	0503010025	3/8" SPRING WASHER		03
07	0503010026	3/8" NUT		03
08	0521067492	SUPPORT		01
09	0501013518	FLAT WASHER		02
10	0521067491	SUPPORT MTH P.P		01
11	0501010694	FLAT WASHER		02
12	0503010143	1/4" SPRING WASHER		02
13	0503010144	1/4" NUT		02
14	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02




Item	Code	Description	See page	QT
01	0581013131	ENG RAP FEMEA C DRENO TURB HIDR		01
02	0503017845	PVC KNEE 90 SOLD AVEL		01
03	0571018559	WHITE PVC TUBE		01
04	0503031943	SOCKET		06
05	0503012856	POP RIVET		12
06	0503012566	COVER KAP 110 YELLOW		01
07	0521015543	DUTO 110 X 55		01



Item	Code	Description	See page	QT
01	0581013131	ENG RAP FEMEA C DRENO TURB HIDR		01
02	0503017845	PVC KNEE 90 SOLD AVEL		01
03	0571018559	WHITE PVC TUBE		01
04	0503031943	SOCKET		06
05	0503012856	POP RIVET		12
06	0503012566	COVER KAP 110 YELLOW		01
07	0521015543	DUTO 110 X 55		01




Item	Code	Description	See page	QT
01	0571019573	AR 1000 CONDUCTOR BODY		01
02	0503031943	SOCKET		07
03	0503012856	POP RIVET		14
04	0581012167	AR 600 CONDUCTOR BODY		02
05	0511057036	AIR DISTRIBUTOR BOARD		02
06	0503012566	COVER KAP 110 YELLOW		02




Item	Code	Description	See page	QT
01	0503014774	HFB0709111 CONTROL VALVE		01
02	0501010590	NIPPLE		06
03	0503010045	O'RING		06

HOSE ASSY


0511057906




Item	Code	Description	See page	QT
01	0511057840	ASSY TURBINE HOSE REAR		01
01A	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
01AA	0501081247	HOSE 1/2 X 7012 TC-TM		01
01AB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01
01BA	0501081247	HOSE 1/2 X 7012 TC-TM		01
01BB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PLASTIC BOLT		06
01C	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
01CA	0501080477	HOSE 3/8 X 7012 TC-TM		01
01CB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01CC	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
01CD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	122	02
03	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
04	0503033981	ADHESIVE LABEL		01
05	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	117	01




Item	Code	Description	See page	QT
01	0503017845	PVC KNEE 90 SOLD AVEL		01
02	0571019405	BODY DISTRIBUTOR VACUUM 4845/5345		01
03	0503012566	COVER KAP 110 YELLOW		01
04	0503031943	SOCKET		05
05	0503012856	POP RIVET		10
06	0571018559	WHITE PVC TUBE		01




Item	Code	Description	See page	QT
01	0503017845	PVC KNEE 90 SOLD AVEL		01
02	0571019405	BODY DISTRIBUTOR VACUUM 4845/5345		01
03	0503012566	COVER KAP 110 YELLOW		01
04	0503031943	SOCKET		05
05	0503012856	POP RIVET		10
06	0571018559	WHITE PVC TUBE		01




Item	Code	Description	See page	QT
01	0503017845	PVC KNEE 90 SOLD AVEL		02
02	0571018559	WHITE PVC TUBE		04
03	0503031943	SOCKET		06
04	0503012856	POP RIVET		12
05	0503012567	T-JOIN FOR TUBE 110		02
06	0581012167	AR 600 CONDUCTOR BODY		03




Item	Code	Description	See page	QT
01	0571019403	STAPLE FIXER		01
02	0503010025	3/8" SPRING WASHER		04
03	0503010026	3/8" NUT		04
04	0501013518	FLAT WASHER		02
05	0571019921	AIR SUPPORT FIXATION		01
06	0503010237	3/8" X 1" BOLT		02



Item	Code	Description	See page	QT
01	0503018799	QUICK COUPLING		01
02	0503011883	QUICK CONNECTION COVER		01




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		04
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0581012096	ROUND SLEEVE		02
06	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
07	0521050154	TURBINE P.P WITH HOLE	119	01
08	0503031087	ADHESIVE LABEL		01
09	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
10	0501010694	FLAT WASHER		02
11	0503010143	1/4" SPRING WASHER		02
12	0503010144	1/4" NUT		02
13	0503010190	2-114 N 3006-9B O'RING		04
14	0501081235	1/2 X 650 TR- TC HOSE		01
15	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01

CLAMP


0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01



Item	Code	Description	See page	QT
01	0503062808	KIT MONITOR SEED 15L 45/50 PM400		01
01A	0503016561	15 ROW SIMPLE MONITOR CABLE		01
01B	0503019100	SENSOR		15
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		75
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		225
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0501100045	WOODEN BOX		01
02	0511061022	ROW MARKER SUPPORT		02
03	0511066119	MARKER SUPP FIXER FASTENER		04
04	0502010175	HITCH CLAMP		08
05	0501010216	3/4" X 4-1/2" BOLT		16
06	0503010023	3/4" SPRING WASHER		16
07	0503010014	3/4" NUT		16
08	0511060013	ROW MARKER ARM		02
09	0521013347	1.1/4" X 8.4" AXLE		02
10	0501019435	32 X 50 X 1.5 FLAT WASHER		16
11	0503010523	1/4" X 2" COTTERPIN		16
12	0511060014	ROW MARKER ARM		02
13	0521011142	1.1/4" X 7.5" AXLE		04
14	0521011141	1.1/4" X 6.5" AXLE		02
15	0521061790	1750 TURNBUCKLE		02
16	0521055204	ROW MARKER DISC	126	02
17	0521012324	1/2" X 3.2" X 2.54" FASTENER		04
18	0511017302	FLAT WASHER		08
19	0503010019	1/2" SPRING WASHER		08
20	0503010060	1/2" NUT		08
21	0503010004	1890 GREASE FITTING		02
22	0503010003	1845 GREASE FITTING		02

ROW MARKER DISC

0521055204



Item	Code	Description	See page	QT
01	0521069643	DISC AXLE MARKER LINE		01
02	0602023094	DR16X3 C36AFPAFR73+4FR+4FR D474 10R		01
03	0581019513	DEPTH WHEEL BOX		01
04	0503019342	ROLLER BEARING		01
05	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503013758	1/4" X 1-1/2" BOLT		03
11	0503010143	1/4" SPRING WASHER		03
12	0503010358	5/16" X 5/8" BOLT		04
13	0503010179	LOCK WASHER		04
14	0503010337	5/16" NUT		04
15	0503034055	CLAMPING RING		01




Item	Code	Description	See page	QT
01	0521054739	FRONT LINE SHORT LEFT SEED WITH CARDAN WITHOUT LUBRICATION	128	01
01.	0521057998	FRONT SHORT SEED LINE WITH SORETO CABLE WITHOUT LUBRICATION	129	01
02	0521054738	FRONT LINE SHORT RIGHT SEED WITH CARDAN WITHOUT LUBRICATION	130	01
03	0521054741	FRONT LINE SEED LONG LEFT WITH CARDAN WITHOUT LUBRICATION	131	01
03.	0521054740	FRONT LINE LONG RIGHT SEED WITH CARDAN WITHOUT LUBRICATION	132	01
03..	0521057999	FRONT LONG SEED LINE WITH SORETO CABLE WITHOUT LUBRICATION	133	01
03...	0521058000	FRONT SEMI ASSEMBLED LONG SEED LINE WITH SORETO CABLE WITHOUT LUBRICATION	134	01
04	0521054737	FRONT SEMI-ASSEMBLED LONG LEFT SEED ROW	136	01
05	0521054736	FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED LINE	137	01
06	0521052270	SEMI MOUNTED FRAME PRECISION PLANTING SPA	145	01
06.	0521066539	CENTRAL SEED LINE FRAME		01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
08	0503010019	1/2" SPRING WASHER		01
09	0503010060	1/2" NUT		01
10	0521054811	FERTILIZER SHORT LINE	146	01
10.	0521054900	FERTILIZER LINE SHORT ASSY DOC20	147	01
11	0521054812	LONG FERTILIZER LINE	148	01
11.	0521054901	LONG FERTILIZER DOC20 ASSY LINE	149	01
12	0521054769	LEFT DDD FERTILIZER WITH SUPPORT	158	01
13	0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	159	01
14	0521054794	REAR RIGHT SEAL LINE P.P CSU 3 NAC	164	01
15	0521054795	REAR LEFT LINE SEED P.P CSU 3 NAC	165	01
16	0521055397	DEEP WHEEL / COMPACTOR SYSTEM	171	01
16.	0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	172	01

SEED LINE/FERTILIZER ASSEMBLY

0909095866

Item	Code	Description	See page	QT
16..	0521055064	WHEEL SYSTEM DEPTH/ASSY COMPACTOR	191	01
17	0503010905	1/2" X 2-1/4" BOLT		01
18	0503010019	1/2" SPRING WASHER		01
19	0503010060	1/2" NUT		01
20	0521053946	SCARING ROD	196	01
21	0521069127	BOTTOM NOZZLE FERTILIZER		01
22	0511017969	0.1" SPACING PLATE		01
23	0511018662	SPACING PLATE		01
24	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
25	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
26	0503010025	3/8" SPRING WASHER		01
27	0503010026	3/8" NUT		01
28	0521057957	FIXED ROD EXTENSION WITH FIXATION	197	01
29	0521068982	KEY CASH DISC CUTTING		01
30	0531013600	PRESS ADJUSTMENT LEVER		01
31	0503030483	FERTILIZER SOCKET		01
32	0503031050	CURVED CONDUCTOR		01
33	0503010246	CLAMP		01
34	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
35	0521018501	TURNBUCKLE LEVER		01
36	0581012756	HEX AXLE 5/8 X 360		01
37	0581010593	HEX AXLE 5/8 X 600		01
38	0503030391	RIGHT FERTILIZER NOZZLE		01
39	0503030392	LEFT FERTILIZER NOZZLE		01
40	0503031145	2" X 2" X 20" HOSE		01
41	0503031076	2" HOSE CLAMP		01
42	0571011730	SEED CONDUCTOR 3" X 1500		01
43	0521050525	FIXER FERTILIZER CONDUCTOR	198	01




Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0521065847	SHORT TIRE SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	138	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	139	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	140	01
17	0581018487	FIXER UPPER SPRING		01
18	0521055224	TRANSMISSION CARDAN ASSY	141	01
19	0502012782	17Z GEAR WITH HEX HOLE		01
20	0521064651	LEFT SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	143	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06




PST TRIO FLEX SUPREMA P.P - FRAME - 7450/8460 - CSU
FRONT LINE SHORT LEFT SEED WITH CARDAN WITHOUT

Page 128
0521054739

Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT GLOVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08



Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0521069029	FRAME		01
03	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		03
04	0561019032	SEED FERTIL ROW LOCK		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0503030168	HITCH PIN CLIP		01
07	0521010773	0.37" X 1.18" COUPLING SHAFT		01
08	0503010140	1/8" X 3/4" COTTERPIN		01
09	0503012412	5/8 UNC SELF LOCKING NUT		04
10	0502012568	UPPER ROCKER ARM		01
11	0501011388	COUPLING SHAFT		02
12	0502012789	FIXER SUPPORT FERTILIZER ROW		01
13	0503017857	BOLT 5/8 UNF 4		04
14	0503010811	5/8" UNF SELF ADJUSTING NUT		04
15	0503034580	TRACTION SPRING		02
16	0502012911	TOP ARM SEED LINE		01
17	0503019273	AUTO LUBRICANT GLOVE		08
18	0581017624	SPACING SLEEVE		06
19	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		02
20	0503010045	O'RING		08
21	0581018487	FIXER UPPER SPRING		01
22	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		01
23	0521053577	BEARING BOX	135	01
24	0503062983	SET TRANSMISSION P.P LC 1310MM S/E SORETTTO		01
25	0581017955	CABLE GUIDE		01
26	0503011953	5/16" X 1" BOLT		02
27	0503010179	LOCK WASHER		02
28	0503010337	5/16" NUT		02
29	0521068285	PROTECTION SUPPORT		01
30	0521069031	SEED ROW SUPPORT FRONT		01




Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0521065847	SHORT TIRE SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	138	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	139	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	140	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055224	TRANSMISSION CARDAN ASSY	141	01
20	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	143	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06



PST TRIO FLEX SUPREMA P.P - FRAME - 7450/8460 - CSU
FRONT LINE SHORT RIGHT SEED WITH CARDAN WITHOUT

Page 130
0521054738

Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT GLOVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0521065847	SHORT TIRE SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	138	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	139	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	140	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055224	TRANSMISSION CARDAN ASSY	141	01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	143	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06



PST TRIO FLEX SUPREMA P.P - FRAME - 7450/8460 - CSU
FRONT LINE SEED LONG LEFT WITH CARDAN WITHOUT

Page 131
0521054741

Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT GLOVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0521065847	SHORT TIRE SEED ROW FRAME		01
03	0521055213	LINE BEARING SEED	138	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	139	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	140	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055224	TRANSMISSION CARDAN ASSY	141	01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	143	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06




PST TRIO FLEX SUPREMA P.P - FRAME - 7450/8460 - CSU
FRONT LINE LONG RIGHT SEED WITH CARDAN WITHOUT

Page 132
0521054740

Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT GLOVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0521069029	FRAME		01
03	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		03
04	0561019032	SEED FERTIL ROW LOCK		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0503030168	HITCH PIN CLIP		01
07	0521010773	0.37" X 1.18" COUPLING SHAFT		01
08	0503010140	1/8" X 3/4" COTTERPIN		01
09	0503012412	5/8 UNC SELF LOCKING NUT		04
10	0502012568	UPPER ROCKER ARM		01
11	0501011388	COUPLING SHAFT		02
12	0502012789	FIXER SUPPORT FERTILIZER ROW		01
13	0503017857	BOLT 5/8 UNF 4		04
14	0503010811	5/8" UNF SELF ADJUSTING NUT		04
15	0503034580	TRACTION SPRING		02
16	0502012911	TOP ARM SEED LINE		01
17	0503019273	AUTO LUBRICANT GLOVE		08
18	0581017624	SPACING SLEEVE		06
19	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		02
20	0503010045	O'RING		08
21	0581018487	FIXER UPPER SPRING		01
22	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		01
23	0521053577	BEARING BOX	135	01
24	0503062984	TRANSMISSION ASSY P.P SUPER LONG LINE 1410MM		01
25	0581017955	CABLE GUIDE		01
26	0503011953	5/16" X 1" BOLT		02
27	0503010179	LOCK WASHER		02
28	0503010337	5/16" NUT		02
29	0521068285	PROTECTION SUPPORT		01
30	0521069030	SUPPORT FRONT		01




Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		03
03	0561019032	SEED FERTIL ROW LOCK		01
04	0503010071	3/16" X 1" COTTERPIN		01
05	0503030168	HITCH PIN CLIP		01
06	0521010773	0.37" X 1.18" COUPLING SHAFT		01
07	0503010140	1/8" X 3/4" COTTERPIN		01
08	0503012412	5/8 UNC SELF LOCKING NUT		04
09	0502012568	UPPER ROCKER ARM		01
10	0501011388	COUPLING SHAFT		02
11	0502012789	FIXER SUPPORT FERTILIZER ROW		01
12	0503017857	BOLT 5/8 UNF 4		04
13	0503010811	5/8" UNF SELF ADJUSTING NUT		04
14	0503034580	TRACTION SPRING		02
15	0502012911	TOP ARM SEED LINE		01
16	0503019273	AUTO LUBRICANT GLOVE		08
17	0581017624	SPACING SLEEVE		06
18	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		02
19	0503010045	O'RING		08
20	0581018487	FIXER UPPER SPRING		01
21	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		01
22	0521053577	BEARING BOX	135	01
23	0503062986	SET TRANSMISSION P.P S/LG SPA 1850MM S/E SORETO		01
24	0581017955	CABLE GUIDE		01
25	0503011953	5/16" X 1" BOLT		01
26	0503010179	LOCK WASHER		01
27	0503010337	5/16" NUT		01
28	0521069030	SUPPORT FRONT		01

BEARING BOX

0521053577




Item	Code	Description	See page	QT
01	0581014692	BEARING		01
02	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
03	0503011953	5/16" X 1" BOLT		02
04	0503010337	5/16" NUT		02
05	0503011410	ROLLER BEARING		01
06	0503011105	SEAL RING		01
07	0503010406	501025 CLAMPING RING (FOR AXLE)		02
08	0581017960	SLEEVE HEX SEXTAVADA		01
09	0503010179	LOCK WASHER		02
10	0503012880	1/4" UNC SELF ADJUSTING NUT		02



Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	LINE BEARING SEED	138	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	139	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	140	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	143	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06



Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT GLOVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0502012910	SEED LINE LOWER ARM WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	LINE BEARING SEED	138	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED LINE TRANSMISSION BOX	139	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8 UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	140	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE GLOVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME LINE		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	143	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED LINE		01
31	0581017624	SPACING SLEEVE		06




PST TRIO FLEX SUPREMA P.P - FRAME - 7450/8460 - CSU
FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED LINE

Page 137
0521054736


Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT GLOVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0502012718	BEARIN BODY		01
02	0503019355	BEARING 6202 2RS1		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503019361	BEARING 6006 RS1		02
04	0503019363	BEARING 6005		01
05	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503019362	BEARING 6005 RS1		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551017540	5/8" X 73 AXLE HEX		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0503011855	0.2" X 1.8" SPRING PIN		03
04	0503013958	1/4" X 1" BOLT		02
05	0551017559	BEARING AXLE BODY		01
06	0561014778	HEX UNIVERSAL JOINT		01
07	0571012412	HEX AXLE		01
08	0521055225	BEARING DOUBLE FRONT LINE SEED	142	01
09	0501056296	UNIVERSAL JOINT		01




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503019356	BEARING 6005 2RS1		02
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012819	17Z GEAR WITH HEX HOLE		01
02	0521055220	BEARING FRONT LINE SEED	144	01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503019356	BEARING 6005 2RS1		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521068457	FRAME CENTRAL SEED LINE		01
02	0521055224	TRANSMISSION CARDAN ASSY	141	01




Item	Code	Description	See page	QT
01	0501010066	3/4" X 9" BOLT		01
02	0511017232	FLAT WASHER		02
03	0503011255	3/4" LOCK NUT		01
04	0502012873	SUPPORT DC LINE FERTILIZER		01
05	0503019278	LUBRICANT SLEEVE		02
06	0581019195	SIDE GUIDE GLOVE		02
07	0581019196	CENTRAL GUIDE GLOVE		01
08	0503010410	RING		02
09	0502012876	CLAMP		01
10	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
11	0503010013	5/8" NUT		02
12	0521054906	SPRING ASSY FERTILIZER	157	01
13	0521053231	DPL 20 SHORT LINE WITHOUT LUBRICATION CONICAL BEARING	150	01
14	0521066231	SHORT FERTILIZER LINE ARM		01
15	0503017857	BOLT 5/8 UNF 4		03
16	0503010811	5/8" UNF SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0521066231	SHORT FERTILIZER LINE ARM		01
02	0502012873	SUPPORT DC LINE FERTILIZER		01
03	0502012876	CLAMP		01
04	0503017857	BOLT 5/8 UNF 4		03
05	0503010811	5/8\" UNF SELF ADJUSTING NUT		03
06	0503011255	3/4\" LOCK NUT		01
07	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
08	0503010013	5/8\" NUT		02
09	0521054845	DPLO 20 LOW LINE WITHOUT LUBRICATION	152	01
10	0521054906	SPRING ASSY FERTILIZER	157	01
11	0501010066	3/4\" X 9\" BOLT		01
12	0511017232	FLAT WASHER		02
13	0581019195	SIDE GUIDE GLOVE		02
14	0503010410	RING		02
15	0503019278	LUBRICANT SLEEVE		02
16	0581019196	CENTRAL GUIDE GLOVE		01




Item	Code	Description	See page	QT
01	0501010066	3/4" X 9" BOLT		01
02	0511017232	FLAT WASHER		02
03	0503011255	3/4" LOCK NUT		01
04	0502012873	SUPPORT DC LINE FERTILIZER		01
05	0503019278	LUBRICANT SLEEVE		02
06	0581019195	SIDE GUIDE GLOVE		02
07	0581019196	CENTRAL GUIDE GLOVE		01
08	0503010410	RING		02
09	0502012876	CLAMP		01
10	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
11	0503010013	5/8" NUT		02
12	0521054906	SPRING ASSY FERTILIZER	157	01
13	0521053232	DPL 20 LONG LINE WITHOUT LUBRICATION CONICAL BEARING	151	01
14	0521066230	LONG FERTILIZER LINE ARM		01
15	0503017857	BOLT 5/8 UNF 4		03
16	0503010811	5/8" UNF SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0521066230	LONG FERTILIZER LINE ARM		01
02	0502012873	SUPPORT DC LINE FERTILIZER		01
03	0502012876	CLAMP		01
04	0503017857	BOLT 5/8 UNF 4		03
05	0503010811	5/8\" UNF SELF ADJUSTING NUT		03
06	0503011255	3/4\" LOCK NUT		01
07	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
08	0503010013	5/8\" NUT		02
09	0521054846	DPLO 20 LONG LINE WITHOUT LUBRICATION 153 CONICAL BEARING		01
10	0521054906	SPRING ASSY FERTILIZER	157	01
11	0501010066	3/4\" X 9\" BOLT		01
12	0511017232	FLAT WASHER		02
13	0581019195	SIDE GUIDE GLOVE		02
14	0503010410	RING		02
15	0503019278	LUBRICANT SLEEVE		02
16	0581019196	CENTRAL GUIDE GLOVE		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	154	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	154	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	FIXING SHAFT DISC CUT LINE		01



Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521054844	DPLO 20 CUTTING DISK BOX	156	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521054844	DPLO 20 CUTTING DISK BOX	156	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	WASHER BRACKET AXIS DC PST		01
08	0521068887	DC RIGHT ARM WITH GLOVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2" NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH GLOVE		01
17	0503019272	LUBRICANT GLOVE		02
18	0503010390	SEAL RING		02
19	0581017628	COVER		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	FIXING SHAFT DISC CUT LINE		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	CUTTING DISK BOX	155	01

CUTTING DISK BOX


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4	01	
02	0502040872	REGULATORY NUT	01	
03	0503010370	502072 CLAMPING RING (FOR AXLE)	02	
04	0503010590	00674-B SEAL	02	
05	0503019285	RING	02	
06	0503012170	30207 ROLLER BEARING	02	
07	0502020641	BLADE DISC FLANGE	01	
08	0502012862	CUTTING DISK BOX	01	
09	0502040873	CUTTING DISC AXLE	01	
10	0503017755	NUT	01	
11	0503018825	5/16 UNC UNC BOLT	06	
12	0501010694	FLAT WASHER	06	
13	0503013816	5/16" LOCKNUT	06	
14	0511017907	1/8" BSPT X 6 PLUG	02	




Item	Code	Description	See page	QT
01	0521053697	CUTTING DISK BOX	155	01
02	0607026025	DPLO20X4,5		01




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK		02
02	0502012184	FERTILIZER SPRING GUIDE		02
03	0503031910	1.7" X 22.8" X 0.3" SPRING		01
04	0502012510	SPRING ROD SUPPORT		01
05	0591018219	JUNCTION SHAFT 12.70 X 109 ZN		01
06	0501018535	1/2 X 1 BOLT		02
07	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		02
08	0503010060	1/2" NUT		02
09	0502010891	SPRING CHOCK SUPPORT VARON		01
10	0503010014	3/4" NUT		01
11	0521067619	TUBE LINE FERTILIZER		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0501010937	13,50 X 28 X 3,00 FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	162	01
03	0521054760	DOWN LOW CUBE	163	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511815098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	162	01
03	0521054760	DOWN LOW CUBE	163	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511815098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502012736	HUB LOWER		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012736	HUB LOWER		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0521055872	RIGHT DOUBLE DISK FAST EXCHANGE SEED 15X15		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0521055208	ASSEMBLY PRECISION PLANTING V-SET2 CSU 3 168 CSU SUPREMA P.P		01




Item	Code	Description	See page	QT
01	0521054787	DDD LEFT SUPREME SEED 15 X 15 NAC	167	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0521055208	ASSEMBLY PRECISION PLANTING V-SET2 CSU 3 168 CSU SUPREMA P.P		01



Item	Code	Description	See page	QT
01	0521054761	LEFT LOW CUBE	162	01
02	0521054760	DOWN LOW CUBE	163	01
03	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0502012780	SUPPORT DDD RIGHT		01
06	0511815098	FLAT WASHER		04
07	0503011402	0.2" X 0.8" SPRING PIN		01
08	0503013129	ELASTIC PIN		01
09	0503015081	502052 CLAMPING RING (FOR AXLE)		02
10	0511011927	DUST CLOAK		02
11	0571011152	DOUBLE DISC CAP		02
12	0502012779	PNEUMATIC DRIVING PROTECTOR		01
13	0503014679	2-134 O'RING		02
14	0503034055	CLAMPING RING		02
15	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
16	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
17	0503010025	3/8" SPRING WASHER		01
18	0503010026	3/8" NUT		01
19	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521054761	LEFT LOW CUBE	162	01
02	0521054760	DOWN LOW CUBE	163	01
03	0503013129	ELASTIC PIN		01
04	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0502012781	SUPPORT DDD LEFT		01
07	0511815098	FLAT WASHER		04
08	0503011402	0.2" X 0.8" SPRING PIN		01
09	0571011152	DOUBLE DISC CAP		02
10	0511011927	DUST CLOAK		02
11	0503015081	502052 CLAMPING RING (FOR AXLE)		02
12	0502012779	PNEUMATIC DRIVING PROTECTOR		01
13	0503014679	2-134 O'RING		02
14	0503034055	CLAMPING RING		02
15	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
16	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
17	0503010026	3/8" NUT		01
18	0503010025	3/8" SPRING WASHER		01
19	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
02	0571017899	PIN LOCK PP		01
03	0503030190	0.5" X 1.6" X 0.05" SPRING		01
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
05	0521055210	LEFT P.P TRANSMISSION BOX	169	01
06	0571017894	PIN DRAG PRECISION PLANTING		01
07	0503013357	3/8" SELF-ADJUSTING NUT		01
08	0501013518	FLAT WASHER		02
09	0503015356	SPRING PIN		01
10	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
11	0571017895	PIN FIXER CONDUCTOR P.P		01
12	0503010589	1/2" UNC SELF ADJUSTING NUT		01
13	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
14	0503010293	BAQUELITE MANIPULACION		02
15	0503010140	1/8" X 3/4" COTTERPIN		02
16	0521066707	FEEDER		01
17	0503010025	3/8" SPRING WASHER		02
18	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
19	0501011643	3/8 X 1"BOLT		01
20	0503010209	3/8" UNC BUTTERFLY NUT		01
21	0502012807	SUPPORT BOX PRECISION PLANTING		01
22	0571019489	CLAMP PRECISION PLANTING		01
23	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
24	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 170 DISC		01
25	0561014778	HEX UNIVERSAL JOINT		01
26	0503013958	1/4" X 1" BOLT		02
27	0503011855	0.2" X 1.8" SPRING PIN		01
28	0503012721	1/4" X 4" BOLT		01
29	0503012880	1/4" UNC SELF ADJUSTING NUT		04
30	0571014024	FAST BOLT GUIDE AXLE		01


Item	Code	Description	See page	QT
31	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
32	0503015110	M06 SPRING WASHER		02
33	0503818139	BOLT		03
34	0503037390	PACKING FOR PLANTING		01
35	0503015752	3/8" X 2" BOLT		01
36	0503034824	FIXATIVE		01
37	0581011226	FIXER CLOSING P PLANTING CONTR CPRA		01
38	0503010337	5/16" NUT		04
39	0503010179	LOCK WASHER		04
40	0503011953	5/16" X 1" BOLT		03
41	0503012163	5/16" X 1-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION BOX PP		01
02	0502050053	RIGHT SIDE TRANSMISSION BOX PP		01
03	0503019356	BEARING 6005 2RS1		02
04	0503019367	BEARING 6203 2RS1 NAC		02
05	0503011184	502040 CLAMPING RING (FOR AXLE)		01
06	0571017655	SLEVE FIXER HITCH PNEUMATIC		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
08	0503010144	1/4" NUT		03
09	0511057504	JOIN GEAR		01
09A	0571017898	BODY GEAR TRANSMISSION		01
09B	0503033975	24Z GEAR PNEUMATIC		01
09C	0503011769	M8 X 0.5" BOLT		01
10	0581011222	PINION AXLE 6Z PNEUMATIC		01
11	0503034340	PINION AXLE 6Z PNEUMATIC		01
12	3402510052	GRAXA SHELL STAMINA/RL-2		0,07Kg




Item	Code	Description	See page	QT
01	0571019613	STRAW PRECISION PLANTING SHIELD		01
02	0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT PROTECTION		01




Item	Code	Description	See page	QT
01	0521055398	DEPTH WHEEL	180	01
02	0521055093	BODY COMPACTOR	188	01
03	0521055017	RIGHT COMPACTOR WHEEL	189	01
04	0521054990	LEFT COMPACTOR WHEEL	190	01




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	173	01
02	0521055068	RAYED WHEEL CENTER CLOSED	178	02
03	0521054990	LEFT COMPACTOR WHEEL	190	01
04	0521055017	RIGHT COMPACTOR WHEEL	189	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY	174	01
06	0503019398	AXLE RETAINER RING		01
07	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	175	01
08	0521055054	LEFT ARM WITH SLEEVE	176	01
09	0521055066	RIGHT ARM WITH GLOVE	177	01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED SLEEVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT SLEEVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0581019523	LEFT ARM WHEEL DEPTH		01
02	0581019514	LUBRICANT SLEEVE		02
03	0503011109	2-119 N 3006-9B O'RING		02



Item	Code	Description	See page	QT
01	0581019524	RIGHT ARM DEPTH		01
02	0581019514	LUBRICANT SLEEVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	179	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	LOCK WASHER		06
07	0503010337	5/16" NUT		06



Item	Code	Description	See page	QT
01	0581019522	CASE WHEEL DEPTH WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0503010143	1/4" SPRING WASHER		03
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019529	DEPTH REGULATOR SHAFT		01
11	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01

DEPTH WHEEL


0521055398




Item	Code	Description	See page	QT
01	0581019532	DEPTH CONTROL SUPPORT		01
02	0581019531	ARTICULATED AXLE WHEEL DEPTH		02
03	0501059228	ADJUSTMENT LEVER	181	01
04	0502012611	DEPTH CONTROL AXLE		01
05	0571015326	ARTICULATION SLEEVE HANDLE		01
06	0581017075	LARGER AXLE		01
07	0581017076	SMALLER AXLE		01
08	0501011445	FLAT WASHER		04
09	0511017302	FLAT WASHER		02
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0503030012	HITCH PIN CLIP		04
12	0503011402	0.2" X 0.8" SPRING PIN		02
13	0503012795	5/8" HEX SELF ADJUSTING NUT		02
14	0503010237	3/8" X 1" BOLT		01
15	0503010025	3/8" SPRING WASHER		01
16	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
17	0581019526	ARTICULATED AXLE LEVER DEPTH		01
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0503010302	501019 SEAL RING		01
20	0581019473	ARTICULATED SLEEVE		02
21	0503010045	O'RING		02
22	0521055399	LEFT ARM WITH WHEEL	182	01
23	0521055400	RIGHT ARM WITH WHEEL	183	01

ADJUSTMENT LEVER


0501059228




Item	Code	Description	See page	QT
01	0502012603	ADJUSTMENT LEVER		01
02	0502011689	1/8" DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0511015976	FLAT WASHER		01
05	0503010140	1/8" X 3/4" COTTERPIN		01




Item	Code	Description	See page	QT
01	0521055058	LEFT ARM	184	01
02	0521055401	ASSY WHEEL	185	01
03	0581018815	SET DEVIATION		01
04	0503010741	1/2" X 2-3/4" BOLT		01
05	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0521055074	RIGHT ARM WITH O-RING	187	01
02	0521055401	ASSY WHEEL	185	01
03	0581018815	SET DEVIATION		01
04	0503010741	1/2" X 2-3/4" BOLT		01
05	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0581019525	LEFT ARM WHEEL DEPTH		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503030891	RUBBER BAND		01
03	0503010365	NUT		06
04	0503010179	LOCK WASHER		06
05	0503010337	5/16" NUT		06
06	0521055073	ASSEMBLY DEPTH WHEEL BOX	186	01
07	0561016889	STRIPED CAP WHEEL DEPTH		01




Item	Code	Description	See page	QT
01	0581019528	BOX WHEEL DEPTH SPA WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
11	0581019529	DEPTH REGULATOR SHAFT		01




Item	Code	Description	See page	QT
01	0581019530	RIGHT ARM ROD DEPTH SPA NO LUBRICATION		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02




Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT	02	
02	0503013816	5/16" LOCKNUT	04	
03	0581015855	SLEEVE	02	
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER	01	
05	0521068661	LEVER	01	
06	0503030878	LEVER CRANK	01	
07	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING	01	
08	0581019520	AXIS	01	
09	0571812442	COUPLING SHAFT	01	
10	0503010257	1/8" X 1" COTTERPIN	01	
11	0581019511	COVER	01	
12	0503010848	5/16" X 3.1/2" BOLT	02	
13	0503010752	1/2" X 3.1/2" BOLT	01	
14	0503011336	1/2" HEX SELF ADJUSTING NUT	01	
15	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
16	0581019510	AXIS	01	
17	0581019512	PLATE TOP	01	
18	0503019351	LUBRICANT SLEEVE	02	
19	0521069591	LEFT SIDE	01	
20	0581019548	RIGHT SIDE BODY	01	




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	195	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	195	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	173	01
02	0521055068	RAYED WHEEL CENTER CLOSED	178	02
03	0521055018	WHEEL DRIVE WHEEL LEFT IN V	192	01
04	0521055019	IRON IN RIGHT WHEEL COMPACTOR V	193	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0503013739	1/2" X 1" BOLT		01
02	0521014508	FLAT WASHER		04
03	0521054991	WHEEL DRIVE WHEEL RIGHT	194	01



Item	Code	Description	See page	QT
01	0503010752	1/2" X 3.1/2" BOLT		01
02	0521014508	FLAT WASHER		04
03	0521054991	WHEEL DRIVE WHEEL RIGHT	194	01




Item	Code	Description	See page	QT
01	0581019509	IRON WHEEL COMPACTOR		01
02	0503011105	SEAL RING		01
03	0503013848	5072-BR SEAL		02
04	0511011927	DUST CLOAK		02
05	0503019342	ROLLER BEARING		01
06	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02

SCARING ROD


0521053946




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070085	FIXED ROD BEARING		01
03	0513010288	ELASTIC PIN 701211 10 X 24		02
04	0513010289	ELASTIC PIN 701211 10 X 24		02



Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02



Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

