

ROW CROP PLANTERS

USAP 3200 SUPREMA - FRAME 8470 - CSC/TCE/APT

Code: 0501093068
Series: S-0120
Revision: 00
Date Revision: FEVEREIRO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111500009	USAP 3200 MEC 8470/16E500 CSC TIT DT ESP S-0120

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909095893	FRAME ASSY	1
0909095894	ASSY RIGHT FRAME	2
0909095895	ASSY CENTRAL FRAME	3
0909095896	ASSY LEFT FRAME	4
0909095897	SEED LINE/ASSY FERTILIZER	5
0531051275	COMPLETE HYDRAULIC ASSY	6
0531051924	HEADING 16/17 LINES WITH INOCULANT SUPPORT	7
0521059454	SIDE ARM LOCK ASSY	8
0531050017	HYDRAULIC CYLINDER 44,45 X 85,7 X 397 X 93MM	9
0531050962	SEMI-ASSEMBLED FRONT HEADER	10
0521059465	MOUNTED PANTOGRAPHIC HEADER	11
0531040499	HYDRAULIC CYLINDER 50.8 X 127 X 682 X 285	12
0521057815	HYDRAULIC HOSE SUPPORT WITH FIXATION	13
0521057739	HYDRAULIC CYLINDER 38,10 X 63,50 X 397 X 126	14
0521059886	SEMI-ASSEMBLED REST	15
0531051182	TRACK ASSEMBLY	16
0531051334	PANEL NIPLES	17
0531051887	VALVE FRONT SUPPORT	18
0531051646	REGISTRATION ASSEMBLY	19
0531051397	INOCULATING DIREITO SUPPORT	20
0531051398	INOCULATING ESQUERDO SUPPORT	21
0531051206	ASSY FRENCH HAND	22
0521057793	KNEECAP WITH RIGHT EXTENSION AXLE	23
0531050966	2150 MOUNTED SIDE HANDRAIL	24
0531050908	ASSY RIGHT LADDER	25
0531051177	SIL0 05 MOUTH RIGHT ASSEMBLED	26
0521051407	FERTILIZER HOPPER FIXER	27
0531051178	RIGHT SIDE SUPPORT 5B WITH DISTRIBUTORS	28
0531050918	TOP SUPPORT MOUNTED LIFT EXTENSOR	29
0521054282	BEARING	30
0501056444	BEARING WITH ROLLER	31
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	32
0501053788	3/4 SQUARE AXLE FASTENER	33
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	34
0531050940	RIGHT MONO ARM WHEEL	35
0531050023	HYDRAULIC CYLINDER 2 X 5 X 599 X 336	36
0531050941	MONO WHEEL	37
0521059946	WHEEL ASSY WITH TIRE	38
0521059728	WHEEL WITH TIRE	39
0521059947	MOUNTED CUBE	40
0531050902	MOUNTED SIDE SUPPORT	41
0531050903	SIDE ARTICULATED CYLINDER 44.45X85.70X291X657	42
0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	43
0531050901	ASSY STABILIZER	44
0531051179	RIGHT SUPPORT WITH FERTILIZER GUTTER 16/17 LINES	45
0531050968	RIGHT PLUMBING ASSY	46
0521059839	ASSY REAR HEADLIGHT	47
0521059838	LOCK PIN ASSY	48
0531051002	VALVE	49
0531050002	HYDRAULIC CYLINDER 101,55X466,5X312 COURSE WITHOUT LUBRICATION	50
0521059948	ASSY LOCK AXLE	51
0531051900	DOC20 SHORT FERTILIZER LINE WITHOUT ROD LUBRICATION	52
0531051899	LONG FERTILIZER LINE DOC20 WITH ROD	53



MARCHESAN

INDEX


0531051901	FERTILIZER LINE SUPER LONG DOC20 SHORT	54
0521053946	SCARING ROD	55
0521053673	SCARIFIER ROD WITH NOZZLE	56
0531051902	CURVED WAVY CUTTING DISC 20 COMPLETE	57
0531051903	CURVED CURVED CUTTING DISC	58
0521057680	DISC CUTTING BOX	59
0531050376	TITANIUM SHORT LINE	60
0531050377	LONG LEFT TITANIUM SPI	61
0531050378	TITANIUM SPI SUPER LONG LEFT LINE	62
0521059626	FRONT LINE	63
0521059466	TITANIUM SEED DISTRIBUTOR	64
0511052058	SEED SYSTEM TITANIUM	65
0521059627	UNIVERSAL CURRENT / CABLE BEARING	66
0531051094	MOUNTED HOSE GUIDE ASSEMBLY	67
0521056636	REAR RIGHT SPI TITANIUM/TATU	68
0521056637	REAR LEFT SPI TITANIUM/TATU	69
0531050193	DOSING ASSY TITANIUM/TATU	70
0521056639	SEED ROW TRANSMISSION	71
0511052024	FAST CLOSING SET	72
0521056645	RIGHT SPI TRANSMISSION	73
0521056632	DEPTH CONTROL	74
0521056633	MOUNTED RIGHT ARM	75
0521055059	WHEEL RAYED ASSY SPA WITHOUT LUBRICATION	76
0521055073	ASSEMBLY DEPTH WHEEL HUB	77
0521056631	MOUNTED LEFT ARM	78
0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	79
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	80
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	81
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	82
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	83
0521054990	LEFT COMPACTOR WHEEL	84
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	85
0521055093	BODY COMPACTOR	86
0521055017	RIGHT COMPACTOR WHEEL	87
0503062066	DISC SET WITH CORN RING	88
0503062067	DISC SET / RING SOY 90F TITANIUM	89
0521055868	RIGHT DUAL FERTILIZER DISC	90
0531051118	SINGLE CABLE 12 METERS	91
0521053173	CENTRAL SEED HOPPER 15 OUTPUTS	92
0521053175	BASE CSC HOPPER 15 OUTPUTS	93
0531051092	ASSY HOSE SUPPORT	94
0521045392	HYDRAULIC TURBINE WITH SCREEN	95
0501054983	NIPPLE HIDRAULIC MOTOR	96
0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE	97
0531051119	PRECISION PLANTING ASSEMBLED TURBINE	98
0531051120	PLANTING TURBINE WITH HOLE	99
0531050964	MOUNTED CENTRAL SUPPORT	100
0531051280	WHEEL WITHOUT TRANSMISSION	101
0521059737	CENTRAL FORK RODEIRO	102
0521059723	WHEEL ASSY WITH TIRE	103
0521059724	ASSEMBLED CUBE WITHOUT TRANSMISSION	104
0531051783	SILO 07 CENTRAL MOUTH MOUNTED (APT)	105
0531051782	07 MOUTH CENTRAL SUPPORT	106
0531051200	FERTILIZER CENTRAL SUPPORT	107
0531050168	ASSY CENTRAL PLATFORM 2797	108



MARCHESAN

INDEX


0531050950	ASSY RIGHT ARTICULATION ARM	109
0531050935	ASSY LEFT ARTICULATION ARM	110
0531050963	HYDRAULIC CYLINDER 50.8X127X760X464	111
0531051455	LABEL SET	112
0531050329	MOUNTED SINGLE VACUOMETER ASSY	113
0531052114	ASSY PORT MANUAL INSTRUCCION	114
0531051768	MOUNTED HYDRAULIC SUPPORT	115
0521059704	CASAPPA TRIPLE VALVE WITH FIXING NIPLES	116
0501054694	FLOW DIVIDING VALVE ASSY	117
0531051769	MOUNTED DUCT SUPPORT	118
0531051599	LED FLASHLIGHT WITH SUPPORT	119
0531051470	GUTTER ASSEMBLY 16E500	120
0531051342	RAIL SUPPORT WITH FIXER	121
0531052107	16L E500 MECHANICAL SET	122
0531050396	SEED ENGINE SUPPORT WITH COVER	123
0531051558	SIDE BODY BEARING APT	124
0531051575	FULL FERTILIZER ENGINE PLATE RIGHT LEFT	125
0531051974	MONTAGE CAIXA MODULE ECU	126
0531052048	HYDRAULIC HOSE SET 17 LINES	127
0501053834	MALE QUICK COUPLER	128
0531051353	LIFTING DRIVE ASSEMBLY	129
0531050811	APT FILTER SUPPORT	130
0531052108	ISO6 6C SET	131
0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	132
0521054490	FLOW DIVIDING VALVE ASSY	133
0531050909	ASSEMBLY LADDER LEFT	134
0531051167	SILO 5 MOUTHS LEFT MOUNTED	135
0503062391	FERTILIZER HOPPER	136
0531051168	LEFT SIDE SUPPORT 05 MOUTH WITH DISTRIBUTOR	137
0531050896	LEFT ARM MONO WHEEL WHEEL	138
0531050897	MONO WHEEL LEFT	139
0531051169	RIGHT SUPPORT WITH FERTILIZER GUTTER	140
0531050943	LEFT PLUMBING ASSY	141



Item	Code	Description	See page	QT
01	0909095894	ASSY RIGHT FRAME	2	01
02	0909095895	ASSY CENTRAL FRAME	3	01
03	0909095896	ASSY LEFT FRAME	4	01
04	0531051924	HEADING 16/17 LINES WITH INOCULANT SUPPORT	7	01
05	0531051206	ASSY FRENCH HAND	22	02
06	0531061069	FRONT HAND FRENCH AXLE		02
07	0531061650	FRONT HAND FRENCH AXLE		02
08	0501017779	32 X 60 X 4.75 FLAT WASHER		04
09	0503011052	1.1/4" X 0.77" CASTLE NUT		04
10	0503010038	3/16 X 2 COTTERPIN		04
11	0531051275	COMPLETE HYDRAULIC ASSY	6	01

ASSY RIGHT FRAME

0909095894



Item	Code	Description	See page	QT
01	0531062298	RIGHT SIDE FRAME 2485		01
02	0531061865	SIDE PLATFORM 2180		01
03	0531050966	2150 MOUNTED SIDE HANDRAIL	24	01
04	0531050908	ASSY RIGHT LADDER	25	01
05	0531051177	SILO 05 MOUTH RIGHT ASSEMBLED	26	01
06	0531050940	RIGHT MONO ARM WHEEL	35	01
07	0591016192	GLOVE 102 X 85.50 X 111		02
08	0591018042	FRICTION PLATE		02
09	0591015962	SEPARATOR GLOVE		04
10	0501010453	FLAT WASHER		06
11	0503010027	5/8 SPRING WASHER		07
12	0503010962	5/8" X 1-1/4" BOLT		06
13	0591018049	RIGHT COVER AXLE DEPOSIT		04
14	0503010237	3/8" X 1" BOLT		02
15	0501013518	FLAT WASHER		07
16	0503010025	3/8 SPRING WASHER		07
17	0503010026	3/8" NUT		07
18	0531050902	MOUNTED SIDE SUPPORT	41	02
19	0531050901	ASSY STABILIZER	44	02
20	0531061654	SEED LINES / FERTILIZER TUBE 2200		02
21	0591018043	BODY SUPPORT		02
22	0591016282	HEX SHAFT 3/4 X 2200 SIDE TRANSMISSION		01
23	0511063123	BUSHING WITH NUT		04
24	0501018535	1/2 X 1 BOLT		04
25	0531051179	RIGHT SUPPORT WITH FERTILIZER GUTTER 16/17 45 LINES		01
26	0503014007	1/2" X 1-1/4" BOLT		06
27	0503010019	1/2" SPRING WASHER		06
28	0503010060	1/2 UNC G.5 ZN HEX NUT		06
29	0503030195	2" X 2" X 12.2" HOSE		08mts
30	0503010246	CLAMP		22
31	0591015332	AXLE JUNCTION LOCK		01


ASSY RIGHT FRAME

0909095894

Item	Code	Description	See page	QT
32	0531050968	RIGHT PLUMBING ASSY	46	01
33	0521059839	ASSY REAR HEADLIGHT	47	01
34	1164920015	BLACK SUCTION HOSE		25mts
35	0501010942	3/8" X 1-1/4" BOLT		04
36	0503010880	501032 CLAMPING RING (FOR AXLE)		01
37	0591018044	WASHER 65 X 130 X 20		01
38	0503019271	SELF LUBRICATING BUSHING		02
39	0591018050	EXTERNAL RIGHT COVER		01
40	0503010371	5/16" X 1" BOLT		02
41	0501010694	FLAT WASHER		04
42	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
43	0503010337	5/16" NUT		04
44	0521059838	LOCK PIN ASSY	48	01
45	0531051002	VALVE	49	01
46	0503011141	3/8" X 2-3/4" BOLT		01
47	0591018045	FRICTION TRACK		02
48	0531050002	HYDRAULIC CYLINDER 101,55X466,5X312 COURSE WITHOUT LUBRICATION	50	01
49	0501111058	ASSY FIXING GLOVE		02
50	0503011336	1/2" HEX SELF ADJUSTING NUT		06
51	0503011082	C1/2" X 1.3/4" SCREW		06
52	0591015374	HITCH AXIS		01
53	0503010232	5/8" X 1.3/4" BOLT		01
54	0511010721	FLAT WASHER		01
55	0591018541	SWIVEL CYLINDER COVER		02
56	0521059948	ASSY LOCK AXLE	51	01
57	1164920014	BLACK LIGHT SUCTION HOSE		5,5mts
58	0909095897	SEED LINE/ASSY FERTILIZER	5	04

ASSY CENTRAL FRAME

0909095895



Item	Code	Description	See page	QT
01	0531062146	CENTRAL FRAME 7 LINES 450		01
02	0531051118	SINGLE CABLE 12 METERS	91	01
03	0531050964	MOUNTED CENTRAL SUPPORT	100	02
04	0531051280	WHEEL WITHOUT TRANSMISSION	101	02
05	0503032624	FERTILIZER HOPPER GUTTER		06
06	0531051783	SILO 07 CENTRAL MOUTH MOUNTED (APT)	105	01
07	0531062221	CENTRAL SUPPORT SILO		01
08	0531062223	RIGHT CENTRAL SILO SUPPORT		01
09	0531062222	RIGHT CENTRAL SILO SUPPORT		01
10	0581012482	TRANSPORT LATCH		04
11	0503030168	HITCH PIN CLIP		04
12	0501068994	8,30 X 78 LOCK PIN		04
13	0501047895	25 ROD STOP		04
14	0501047885	30 ROD STOP		08
15	0531051200	FERTILIZER CENTRAL SUPPORT	107	01
16	0501047886	35 ROD STOP		04
17	0531050168	ASSY CENTRAL PLATFORM 2797	108	01
18	0531050950	ASSY RIGHT ARTICULATION ARM	109	01
19	0531050935	ASSY LEFT ARTICULATION ARM	110	01
20	0501047887	40 ROD STOP		08
21	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
22	0531050963	HYDRAULIC CYLINDER 50.8X127X760X464	111	02
23	0521011100	FLAT WASHER		04
24	0531062245	233 CYLINDER JOINT AXIS		02
25	0503010834	1/2 X 1 BOLT		02
26	0503010019	1/2" SPRING WASHER		06
27	0531051002	VALVE	49	02
28	0503019222	BRACELET TYPE WIRE 3.2MM X 48 X 63 MM		05
29	0531051455	LABEL SET	112	01
30	0503010060	1/2 UNC G.5 ZN HEX NUT		04
31	0503014007	1/2" X 1-1/4" BOLT		04


ASSY CENTRAL FRAME

0909095895

Item	Code	Description	See page	QT
32	0503010246	CLAMP		24
33	0503010027	5/8 SPRING WASHER		12
34	0503010013	5/8 NUT		12
35	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		06
36	0503010023	3/4" SPRING WASHER		02
37	0503010014	3/4" HEX NUT		02
38	0501010098	3/4" UNC BOLT		02
39	0503010233	5/8" X 2-1/2" BOLT		06
40	0511063123	BUSHING WITH NUT		02
41	0501018535	1/2 X 1 BOLT		02
42	0531050329	MOUNTED SINGLE VACUOMETER ASSY	113	01
43	0581018254	HEX AXLE 3/4 X 2700 STM 29 USG		01
44	0531052114	ASSY PORT MANUAL INSTRUCCION	114	01
45	0503010027	5/8 SPRING WASHER		02
46	0503010026	3/8" NUT		02
47	0503011179	3/8" X 2-1/4" BOLT		02
48	0531051768	MOUNTED HYDRAULIC SUPPORT	115	01
49	0531051769	MOUNTED DUCT SUPPORT	118	01
50	0521059839	ASSY REAR HEADLIGHT	47	01
51	0531051599	LED FLASHLIGHT WITH SUPPORT	119	02
52	0503030195	2" X 2" X 12.2" HOSE		12
53	0501013519	FLAT WASHER		04
54	0503010589	1/2" UNC SELF ADJUSTING NUT		04
55	0503014378	1/2" X 1-1/2" BOLT		04
56	0531061847	FIXING TUBE SEED/FERTILIZER LINES		02
57	0503010019	1/2" SPRING WASHER		04
58	1164920015	BLACK SUCTION HOSE		25 mts
59	1163920004	BLACK LIGHT SUCTION HOSE		9,5 mts
60	0503019869	CLAMP		05
61	0503011750	AMENDMENT WITH LOCK		06
62	0503011751	REDUCTION		06
63	0531051470	GUTTER ASSEMBLY 16E500	120	01
64	0531052107	16L E500 MECHANICAL SET	122	01
65	0513010044	CORD LIGHTHOUSE LANTERN		01
66	0531052108	ISO6 6C SET	131	01
67	0909095897	SEED LINE/ASSY FERTILIZER	5	06

ASSY LEFT FRAME

0909095896




Item	Code	Description	See page	QT
01	0531061862	LEFT SIDE FRAME		01
02	0531061865	SIDE PLATFORM 2180		01
03	0531050966	2150 MOUNTED SIDE HANDRAIL	24	01
04	0531050909	ASSEMBLY LADDER LEFT	134	01
05	0531051167	SILO 5 MOUTHS LEFT MOUNTED	135	01
06	0531050896	LEFT ARM MONO WHEEL WHEEL	138	01
07	0591016192	GLOVE 102 X 85.50 X 111		02
08	0591018042	FRICTION PLATE		02
09	0591015962	SEPARATOR GLOVE		04
10	0501010453	FLAT WASHER		06
11	0503010027	5/8 SPRING WASHER		07
12	0503010962	5/8" X 1-1/4" BOLT		06
13	0591018051	LEFT COVER AXLE DEPOSIT		01
14	0503010237	3/8" X 1" BOLT		02
15	0501013518	FLAT WASHER		07
16	0503010025	3/8 SPRING WASHER		07
17	0503010026	3/8" NUT		07
18	0531050902	MOUNTED SIDE SUPPORT	41	02
19	0531050901	ASSY STABILIZER	44	02
20	0531061654	SEED LINES / FERTILIZER TUBE 2200		02
21	0591016282	HEX SHAFT 3/4 X 2200 SIDE TRANSMISSION		01
22	0511063123	BUSHING WITH NUT		04
23	0501018535	1/2 X 1 BOLT		04
24	0531051169	RIGHT SUPPORT WITH FERTILIZER GUTTER	140	01
25	0503014007	1/2" X 1-1/4" BOLT		06
26	0503010019	1/2" SPRING WASHER		06
27	0503010060	1/2 UNC G.5 ZN HEX NUT		06
28	0503030195	2" X 2" X 12.2" HOSE		10
29	0503010246	CLAMP		24
30	0531050943	LEFT PLUMBING ASSY	141	01
31	0521059839	ASSY REAR HEADLIGHT	47	01


ASSY LEFT FRAME

0909095896

Item	Code	Description	See page	QT
32	1164920015	BLACK SUCTION HOSE		31 mts
33	0503019271	SELF LUBRICATING BUSHING		02
34	0591018052	EXTERNAL LEFT COVER		01
35	0503010371	5/16" X 1" BOLT		02
36	0501010694	FLAT WASHER		04
37	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
38	0503010337	5/16" NUT		04
39	0521059838	LOCK PIN ASSY	48	01
40	0531051002	VALVE	49	01
41	0503011141	3/8" X 2-3/4" BOLT		01
42	0531050002	HYDRAULIC CYLINDER 101,55X466,5X312 COURSE WITHOUT LUBRICATION	50	01
43	0501111058	ASSY FIXING GLOVE		02
44	0503011336	1/2" HEX SELF ADJUSTING NUT		06
45	0503011082	C1/2" X 1.3/4" SCREW		06
46	0591015374	HITCH AXIS		01
47	0503010232	5/8" X 1.3/4" BOLT		01
48	0511010721	FLAT WASHER		01
49	0521059948	ASSY LOCK AXLE	51	01
50	0591018045	FRICTION TRACK		02
51	0591018044	WASHER 65 X 130 X 20		01
52	0591018043	BODY SUPPORT		02
53	0591015332	AXLE JUNCTION LOCK		01
54	0503010880	501032 CLAMPING RING (FOR AXLE)		01
55	0591018541	SWIVEL CYLINDER COVER		02
56	1164920014	BLACK LIGHT SUCTION HOSE		7,0 mts
57	0501010942	3/8" X 1-1/4" BOLT		04
58	0909095897	SEED LINE/ASSY FERTILIZER	5	06




Item	Code	Description	See page	QT
01	0531051900	DOC20 SHORT FERTILIZER LINE WITHOUT ROD LUBRICATION	52	01
02	0531051899	LONG FERTILIZER LINE DOC20 WITH ROD	53	01
03	0531051901	FERTILIZER LINE SUPER LONG DOC20 SHORT	54	01
04	0531050376	TITANIUM SHORT LINE	60	01
05	0531050377	LONG LEFT TITANIUM SPI	61	01
06	0531050378	TITANIUM SPI SUPER LONG LEFT LINE	62	01
07	0531013600	PRESS ADJUSTMENT LEVER		01
08	0503062066	DISC SET WITH CORN RING	88	16
09	0503062067	DISC SET / RING SOY 90F TITANIUM	89	16
10	0502012815	DOUBLE-DISC SPACING PLATE		16
11	0521055868	RIGHT DUAL FERTILIZER DISC	90	08
12	0511018662	SPACING PLATE		16
13	0502070085	FIXED ROD BEARING		06
14	0503011402	0.2" X 0.8" SPRING PIN		32
15	0503016853	SPRING PIN		32
16	0503030391	RIGHT FERTILIZER NOZZLE		08
17	0503030392	LEFT FERTILIZER NOZZLE		08
18	0503031050	CURVED CONDUCTOR		16
19	0503031826	CURVED CONDUCTOR		10
20	0503031145	2" X 2" X 20" HOSE		16
21	0503031076	2" HOSE CLAMP		32
22	0503010246	CLAMP		32
23	0503019869	CLAMP		05
24	0503019222	BRACELET TYPE WIRE 3.2MM X 48 X 63 MM		05
25	0521068982	DISC BLADE HUB KEY		02
26	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		32
27	0503011440	SPRING WASHER		32
28	0503010060	1/2 UNC G.5 ZN HEX NUT		33



Item	Code	Description	See page	QT
01	0531051800	FULL LIFT HOSE ASSY		01
01A	0501080451	3/8" X 94.5" TR-TC HOSE ASSY		02
01B	0501080453	3/8" X 102" TR-TR HOSE ASSY		02
01C	0501080445	TR-TM HOSE ASSY		01
01D	0501080321	3/8" X 47" TR-TR HOSE ASSY		02
01E	0501080150	3/8 X 800 TR-TC HOSE		02
01F	0501080359	3/8" X 78.7" TR-TC HOSE ASSY		02
01G	0501080427	3/8" X 60" TR-TR HOSE ASSY		02
01H	0501080413	3/8" X 27" TR-TC HOSE		02
01I	0501080507	3/8" X 21.6" TR-TC HOSE ASSY		02
01J	0501080700	3/8 X 650 TC-TC HOSE		04
01K	0501080842	HOSE 1/2 X 4500 TR-TC		02
01L	0501080016	1/2 X 2800 TR-TC HOSE		01
01M	0501081041	1/2 X 2400 TR-TC HOSE		01
01N	0501080740	1/2" X 12" TC-TM HOSE ASSY		02
02	0531051801	HOSE JOINT FULL CLOSURE SET		01
02A	0501080413	3/8" X 27" TR-TC HOSE		02
02B	0501080150	3/8 X 800 TR-TC HOSE		02
02C	0501080388	3/8 X 4300 TR-TC HOSE ASSY		02
02D	0501080720	HOSE 3/8 X 3500 TR-TC		02
02E	0501080473	3/8" X 120" TC-TM HOSE		02
03	0531051802	FULL SWING HOSE ASSY		01
03A	0501080451	3/8" X 94.5" TR-TC HOSE ASSY		04
03B	0501080413	3/8" X 27" TR-TC HOSE		02
03C	0501080348	3/8 X 1200 TR-TC HOSE		02
03D	0501080715	3/8" X 177" TR-TC HOSE ASSY		02
03E	0501080453	3/8" X 102" TR-TR HOSE ASSY		02
03F	0501080473	3/8" X 120" TC-TM HOSE		02
04	0531051803	FULL HOSE LOCKS ASSY		01
04A	0501080720	HOSE 3/8 X 3500 TR-TC		02
04B	0501080301	3/8 X 1300 TC-TC HOSE		02


Item	Code	Description	See page	QT
04C	0501080465	3/8 X 400 TR-TC HOSE ASSY		01
04D	0501080445	TR-TM HOSE ASSY		01
04E	0501080150	3/8 X 800 TR-TC HOSE		01
05	0531051804	HOSE LINES ASSY KIT		01
05A	0501080451	3/8" X 94.5" TR-TC HOSE ASSY		04
05B	0501080055	3/8 X 1000 TR-TC HOSE		04
05C	0501080302	3/8 X 1400 TR-TC HOSE		02
05D	0501080485	3/8 X 1100 TR-TC HOSE		04
05E	0501080065	3/8 X 1200 TC-TC HOSE		04
05F	0501080715	3/8" X 177" TR-TC HOSE ASSY		02
05G	0501080469	3/8" X 98.42" TR-TR HOSE ASSY		02
06	0531052024	HOSE SET 01 TURBINE COMPLETE		01
06A	0501080633	1/2 X 3500 TR-TC HOSE		02
06B	0501080720	HOSE 3/8 X 3500 TR-TC		01
06C	0501080286	HOSE 1/2 X 6200 TR-TM		02
06D	0501080733	HOSE 3/8 X 6200 TR-TM		01
07	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		06
08	0503034494	HYDRAULIC HOSE GRIP (BLUE)		04
09	0503034495	HYDRAULIC HOSE GRIP (RED)		04
10	0503034492	HYDRAULIC HOSE GRIP (BLACK)		04
11	0503018952	PLASTIC BOLT		54




Item	Code	Description	See page	QT
01	0531051207	REAR HEADER 2770		01
02	0531050962	SEMI-ASSEMBLED FRONT HEADER	10	01
03	0503062180	T ADAPTER WITH ROTATING NUT		01
04	0531051182	TRACK ASSEMBLY	16	01
05	0531051334	PANEL NIPLES	17	01
06	0503010019	1/2" SPRING WASHER		10
07	0503010060	1/2 UNC G.5 ZN HEX NUT		10
08	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		06
09	0591018967	CALHA FIXA 16/17		01
10	0591018952	SUPPORT MAIOR CALHA		01
11	0591018951	SUPPORT CALHA		01
12	0501013519	FLAT WASHER		10
13	0503010395	1/2" X 1-1/4" BOLT		04
14	0531061487	NIPLE 3/4 UNF X 3/8 BSPT		01
15	0503016612	VALVE		01
16	0571013798	3/4" UNF X 3/8 NPT NIPPLE		02
17	0531051887	VALVE FRONT SUPPORT	18	01
18	0531051397	INOCULATING DIREITO SUPPORT	20	01
19	0531051398	INOCULATING ESQUERDO SUPPORT	21	01
20	0521059886	SEMI-ASSEMBLED REST	15	01

SIDE ARM LOCK ASSY


0521059454



Item	Code	Description	See page	QT
01	0591015326	LATERAL FRAME LOCK	02	
02	0531061411	STABILIZER ASSY LOCK ARM	01	
03	0591015327	AXLE JUNCTION	02	
04	0591015328	SPACING GLOVE	04	
05	0591015329	CYLINDER GUIDE AXLE	01	
06	0591015330	WASHER SUPPORT	02	
07	0591015332	AXLE JUNCTION LOCK	03	
08	0591015333	SUPPORT GLOVE	02	
09	0503019522	HEX NUT	04	
10	0501010164	3/4" X 7 BOLT	02	
11	0501010322	FLAT WASHER	10	
12	0503010880	501032 CLAMPING RING (FOR AXLE)	05	
13	0531061445	TOP PLATE WITH GLOVE	02	
14	0503014007	1/2" X 1-1/4" BOLT	02	
15	0503010019	1/2" SPRING WASHER	02	
16	0591015341	GLOVE SUPPORT	04	
17	0591015340	WASHER SUPPORT GUIDE AXIS	01	
18	0511016281	3/4" X 8" BOLT	02	
19	0531050017	HYDRAULIC CYLINDER 44,45 X 85,7 X 397 X 93MM	9	01



Item	Code	Description	See page	QT
01	0531061421	CASE 85,7 X 272		01
02	0591015343	EXTENSOR 44,45 X 280MM		01
03	0503010063	1" SELF-ALIGNING NUT		01
04	0502010843	1.8" X 3.4" PISTON		01
05	0503010042	2-214 N 3006-9B O'RING		01
06	0503010170	PACKING 3120 2750		02
07	0503010948	W4-3346-590 PK RING G.E		01
08	0502040747	32.54 CLEVIS CLAMP		01
09	0503011094	3/8" X 2" BOLT		01
10	0503010025	3/8 SPRING WASHER		01
11	0503010026	3/8" NUT		01
12	0502010781	RING SUPPORT		01
13	0503010949	W2-2000-500 PK RING G.E		01
14	0503010990	GASKET		01
15	0503010761	D-1750 SCRAPER RING		01
16	0503010976	2-336 N 3006-9B O'RING		01
17	0503011060	8-336 BACK-UP RING		01
18	0502010993	DETACHABLE COVER		01
19	0503030385	CYLINDER PLUG N-002		02



Item	Code	Description	See page	QT
01	0521059470	ROLLER HEADER		01
01A	0591015445	HEAD ROLLER BODY		01
01B	0551014862	NYLON PULLEY		02
02	0521059471	INTERNAL PULLEY HEADER		02
02A	0591015446	INTERNAL PULLEY BODY HEADER		01
02B	0551014862	NYLON PULLEY		02
03	0551014871	FLAT WASHER		06
04	0503010002	1800 GREASE FITTING		06
05	0591015447	INTERNAL PULLEY AXIS		01
06	0503011105	SEAL RING		03
07	0531061443	FRONT TELESCOPIC HEADER		01
08	0591015448	SIDE ROLLER AXLE HEADER		02
09	0591015449	AXLE LOCK HEADER		01
10	0503018754	1-8 UNC NUT		02
11	0591015450	LOCK BODY GLOVE		02
12	0591015451	BODY LOCK		02
13	0501010888	1.3/4" 2.5/16" CASTLE NUT		01
14	0591015452	BODY AXLE LOCK		01
15	0591015453	BACK WASHER		02
16	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
17	0511054270	TENSIONER SPRING		01
17A	0511069520	TELESC LOCK SPRING TENSIONER		01
17B	0503010013	5/8 NUT		02
18	0591015454	SPRING HITCH LOCK		01
19	0591015455	CYLINDER GUIDE AXLE		01
20	0591015456	CYLINDER GUIDE AXLE		01
21	0521011132	FLAT WASHER		02
22	0503010131	3/16" X 1-1/2" COTTERPIN		02
23	0521059465	MOUNTED PANTOGRAPHIC HEADER	11	01
24	0521057815	HYDRAULIC HOSE SUPPORT WITH FIXATION	13	01
25	0521058345	SAFETY CHAIN WITH SHACKLE		01


SEMI-ASSEMBLED FRONT HEADER

0531050962


Item	Code	Description	See page	QT
25A	0503014120	CHAIN		01
25B	0503014321	CABLE STEEL SHACKLE		02
26	0503011052	1.1/4" X 0.77" CASTLE NUT		03
27	0503010038	3/16 X 2 COTTERPIN		03
28	0531060748	REST SUPPORT		01
29	0531060746	AXIS 278 TELESCOPIC HEADER		03
30	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		02
31	0531060747	TELESCOPIC HOSE GUIDE		01
32	0521057739	HYDRAULIC CYLINDER 38,10 X 63,50 X 397 X 126	14	01
33	0591015457	CYLINDER GUIDE AXLE		01
34	0503010019	1/2" SPRING WASHER		04
35	0503010060	1/2 UNC G.5 ZN HEX NUT		04
36	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		04
37	0521059886	SEMI-ASSEMBLED REST	15	01

MOUNTED PANTOGRAPHIC HEADER


0521059465




Item	Code	Description	See page	QT
01	0531061422	SUPERIOR ARM PANTOGRAPHIC HEADER		01
02	0531061759	LOWER ARM PANTOGRAPHIC HEADER		01
03	0531060745	PANTOGRAPHIC ARM EAR		02
04	0502040864	GEAR BOX WITH REGULATOR		01
05	1902040327	LOCK SLEEVE		01
06	0503010523	1/4" X 2" COTTERPIN		01
07	0503010002	1800 GREASE FITTING		03
08	0521063432	LOCK AXLE		02
09	0503031035	HITCH PIN CLIP		02
10	0531060746	AXIS 278 TELESCOPIC HEADER		02
11	0531060792	AXIS 200 TELESCOPIC HEADER		01
12	0531060776	HYDRAULIC HOSE SUPPORT FIXER		01
13	0503011052	1.1/4" X 0.77" CASTLE NUT		02
14	0503010038	3/16 X 2 COTTERPIN		03
15	0521010578	COUPLING SHAFT		01
16	0531040499	HYDRAULIC CYLINDER 50.8 X 127 X 682 X 285	12	01
17	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		02
18	0502040223	DRAWBOLT		01
19	1902040733	U COUPLING HOOK		01
20	0521012545	COUPLING SHAFT		01
21	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
22	0503010010	1/4" X 2.1/2" COTTERPIN		01




Item	Code	Description	See page	QT
01	0531061425	PANTOGRAPHIC HEAD CYLINDER CASE		01
02	0531061424	PANTOGRAPHIC HEAD CYLINDER ROD		01
03	0503010817	1.1/4" SELF LOCKING NUT		01
04	0503010345	2-218 N 3006-9B O'RING		01
05	0502010382	5" END CAP		01
06	0581010353	RING SUPPORT		01
07	0503018026	1870-2000-375 B GASKET		01
08	0503011453	O'RING		02
09	0503018152	O'RING		02
10	0503018024	RING BS		01
11	0503018025	RING GUIDE		01
12	0581010354	PISTON		01
13	0503018150	RING GUIDE		01
14	0503018151	RING BS		02
15	0503010039	D-2000 SCRAPER RING		01
16	0503030385	CYLINDER PLUG N-002		02



Item	Code	Description	See page	QT
01	0531060794	HYDRAULIC HOSE SUPPORT		01
02	0503015490	SELF-LOCKING NUT 7/16		02
03	0503011173	7/16" X 2" BOLT		02
04	0501010937	13,50 X 28 X 3,00 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0531060718	CASE 63,50 X 285MM		01
02	0531060719	GUIA CILINDRO		01
03	0591013120	BODY STEM 38.10 X 280		01
04	0502012837	PISTON		01
05	0581010668	RING SUPPORT		01
06	0502010471	63,50 MOBILE CAP		01
07	0503018005	RING		01
08	0503011109	2-119 N 3006-9B O'RING		01
09	0503018004	RING		01
10	0503018003	GASKET		01
11	0503010163	D-1500 SCRAPER RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503030385	CYLINDER PLUG N-002		02



Item	Code	Description	See page	QT
01	0503010571	1/4" X 1.1/2 COTTERPIN		02
02	0521010784	COUPLING SHAFT		01
03	0531060758	AXLE JUNCTION 25.4 X 150 WITH HANDLE		01
04	0503030085	LOCK PIN		02
05	0531060667	REST		01
06	0521010580	COUPLING SHAFT		01
07	0521012533	COUPLING SHAFT		01
08	0591016111	TUBE 80 X 80 X 9,52 X 600MM		01
09	0531061640	REST		01

TRACK ASSEMBLY


0531051182




Item	Code	Description	See page	QT
01	0591018020	RIGHT SIDE SUPPORT		01
02	0591018021	LEFT SIDE SUPPORT		01
03	0531062201	REAR RAIL		01
04	0531062202	FRONT GUTTER		01
05	0591018022	GUTTER SUPPORT		01
06	0591018018	ARTICULATOR AXIS		02
07	0591018019	ARTICULATOR AXIS		01
08	0503014007	1/2" X 1-1/4" BOLT		06
09	0503010019	1/2" SPRING WASHER		06
10	0501013519	FLAT WASHER		06
11	0501012140	FLAT WASHER		04
12	0503010027	5/8 SPRING WASHER		04
13	0503010013	5/8 NUT		04
14	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		04

PANEL NIPLES


0531051334




Item	Code	Description	See page	QT
01	0501011643	3/8 X 1" BOLT		04
02	0503013357	3/8 SELF-ADJUSTING NUT		04
03	0591018515	NIPLES PLATE		01
04	0591018028	NIPPLES 7/8 UNF X 7/8 UNF X 65 HEXAGONAL 1.1/8		06
05	0591018027	NIPPLE FIXING NUT R.7 / 8 UNF X 14		06
06	0541012165	3/4" NIPPLE		03
07	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		03
08	0591018026	GUTTER SUPPORT		01



Item	Code	Description	See page	QT
01	0531062572	SUPPORT		01
02	0531051646	REGISTRATION ASSEMBLY	19	03
03	0503035468	HOSE PROTECTION		01




Item	Code	Description	See page	QT
01	0503016612	VALVE		02
02	0551019884	45 X 50 X 3/8 FASTENER		04
03	0503013357	3/8 SELF-ADJUSTING NUT		08
04	0581015287	3/8 BSPT X 7/8 UNF JIC X 45 NIPLE		02
05	0571013798	3/4" UNF X 3/8 NPT NIPPLE		04
06	0591018536	REGISTRATION SUPPORT		01




Item	Code	Description	See page	QT
01	0531062373	TOP SUPPORT BASE	01	
02	0531062372	FRENCH HAND	01	
03	0591018594	RIGHT SUPPORT	01	
04	0591019066	MOUNTED FIXING PLATE	01	
05	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN	04	
06	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT	04	
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN	04	
08	0503010013	5/8 NUT	04	
09	0503010019	1/2" SPRING WASHER	08	
10	0503010027	5/8 SPRING WASHER	04	
11	0503010060	1/2 UNC G.5 ZN HEX NUT	08	

INOCULATING ESQUERDO SUPPORT


0531051398




Item	Code	Description	See page	QT
01	0531062374	LEFT SUPPORT BASE		01
02	0531062373	TOP SUPPORT BASE		01
03	0531062372	FRENCH HAND		01
04	0591019066	MOUNTED FIXING PLATE		01
05	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		04
06	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		04
08	0503010013	5/8 NUT		04
09	0503010019	1/2" SPRING WASHER		08
10	0503010027	5/8 SPRING WASHER		04
11	0503010060	1/2 UNC G.5 ZN HEX NUT		08



Item	Code	Description	See page	QT
01	0521057793	KNEECAP WITH RIGHT EXTENSION AXLE	23	01
02	0531062309	FRENCH HAND 3267		01
03	0531061434	SIDE EXTENSOR EAR		01
04	0571019949	JUNCTION SHAFT		01
05	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0521062617	NUT FIXER		01
02	0531060778	EXTENSION AXLE 466 WITH DRAG		01
03	0561019879	LOCK ATTACHMENT BAR		01
04	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0531061863	SIDE HANDRAIL 2150		01
02	0503014007	1/2" X 1-1/4" BOLT		04
03	0501010937	13,50 X 28 X 3,00 FLAT WASHER		08
04	0503011336	1/2" HEX SELF ADJUSTING NUT		04
05	0503011957	NYLON LUG		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
08	0503010337	5/16" NUT		04

ASSY RIGHT LADDER


0531050908




Item	Code	Description	See page	QT
01	0531061615	MOBILE LADDER		01
02	0531062142	LOWER RIGHT LADDER SUPPORT		01
03	0531062143	HIGHER LEFT STAIRCASE SUPPORT		01
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
08	0503010589	1/2" UNC SELF ADJUSTING NUT		02
09	0503010752	1/2" X 3.1/2" BOLT		02
10	0511065678	STAIR RIGHT LOCK		01
11	0591016037	SENSOR LOCK ROD		02
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
13	0503010337	5/16" NUT		01
14	0503010397	5/16" X 1-3/4" BOLT		01




Item	Code	Description	See page	QT
01	0503062391	FERTILIZER HOPPER	136	01
02	0521051407	FERTILIZER HOPPER FIXER	27	08
03	0531051178	RIGHT SIDE SUPPORT 5B WITH DISTRIBUTORS	28	01
04	0531050918	TOP SUPPORT MOUNTED LIFT EXTENSOR	29	02



Item	Code	Description	See page	QT
01	0503012531	3/8" INOX NUT		01
02	0503012535	3/8" SPRING WASHER		01
03	0571019051	FIXER HOPPER WASHER		01
04	0503013751	3/8 UNC X 1.1/4 BOLT		01




Item	Code	Description	See page	QT
01	0521054282	BEARING	30	01
02	0503030275	AGRICULTURAL BEARING		05
03	0591018303	SQUARE SHAFT 3/4 X 1740		01
04	0503011953	5/16" X 1" BOLT		20
05	0501010694	FLAT WASHER		18
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		18
07	0503010337	5/16" NUT		18
08	0531061864	SUPPORT SILO 05 MOUTH		01
09	0503010329	LOCK WASHER		02
10	0503010330	KM 9 LOCKNUT		04
11	0591015365	RING		04
12	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	32	03
13	0503030303	SUPPORT WASHER		02
14	0511065209	20Z GEAR		01
15	0501053788	3/4 SQUARE AXLE FASTENER	33	01
16	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	34	02
17	0591017775	ARTICULATION AXIS		02
18	0503010589	1/2" UNC SELF ADJUSTING NUT		02
19	0503011140	1/2" X 3-3/4" BOLT		02
20	0502012990	CONICA 14Z SQUARE GEAR		05




Item	Code	Description	See page	QT
01	0501012140	FLAT WASHER		08
02	0503010811	5/8" UNF SELF ADJUSTING NUT		04
03	0503018814	SCREW 5/8 UNF X 5" G.5 CS ZN		04
04	0531062173	LIFT EXTENSOR TOP SUPPORT		01
05	1902011170	FIXER		02

BEARING


0521054282



Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	31	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01



Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01

3/4 SQUARE AXLE FASTENER


0501053788



Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01

LEFT SIDE FERTILIZER DISTRIBUTOR


0511051558




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01

RIGHT MONO ARM WHEEL

0531050940




Item	Code	Description	See page	QT
01	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
02	0503010019	1/2" SPRING WASHER		08
03	0503010060	1/2 UNC G.5 ZN HEX NUT		04
04	0531061431	REAR MONO WHEEL SUPPORT		01
05	0591015907	LARGER JUNCTION AXIS		02
06	0501111051	ARTICULATOR ARM		01
07	0591016194	AXLE JUNCTION		02
08	0503010007	3982/3920 ROLLER BEARING		01
09	0503010059	33287/33462 ROLLER BEARING		01
10	0503013106	SEAL 00085-B		01
11	0502040080	FLANGE NUT R.2.1/2 UN		01
12	0541013225	WHEEL BOX COVER		01
13	0503011444	SPRING WASHER		06
14	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
15	0503010002	1800 GREASE FITTING		01
16	0503017874	BOLT 1/2 UNC		04
17	0591016198	PIN 37,8 X 186		01
18	0501111050	REAR LIFT ARM		01
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
20	0531050023	HYDRAULIC CYLINDER 2 X 5 X 599 X 336	36	01
21	0531050941	MONO WHEEL	37	01
22	0591017921	BRONZE GLOVE 90.5 X 115 X 91		02
23	0531062180	RIGHT SIDE FRAME		01
24	0551016274	HYDRAULIC CYLINDER ADAPTER		01




Item	Code	Description	See page	QT
01	0531061565	CASE WITH TERMINAL 127 X 490		01
02	0581010353	RING SUPPORT		01
03	0503018026	1870-2000-375 B GASKET		01
04	0503011453	O'RING		02
05	0503018152	O'RING		02
06	0503018024	RING BS		01
07	0503018025	RING GUIDE		01
08	0503010039	D-2000 SCRAPER RING		01
09	0502040876	COVER		01
10	0503010817	1.1/4" SELF LOCKING NUT		01
11	0581010354	PISTON		01
12	0503018150	RING GUIDE		01
13	0503018151	RING BS		02
14	0531061566	HYDRAULIC CYLINDER ROD 50.8 X 570.5		01
15	0503010002	1800 GREASE FITTING		01

MONO WHEEL

0531050941




Item	Code	Description	See page	QT
01	0531062179	RIGHT MONO WHEEL		01
02	0521059946	WHEEL ASSY WITH TIRE	38	01
03	0503019246	BOLT		01
04	0503011075	3/4" UNC NUT		01




Item	Code	Description	See page	QT
01	0521059728	WHEEL WITH TIRE	39	01
02	0521059947	MOUNTED CUBE	40	01

WHEEL WITH TIRE


0521059728




Item	Code	Description	See page	QT
01	0503019598	TIRE 11.5 / 80 -15.3 16PR REINF IM-04 TT MI		01
02	0503019599	AIR CAMERA 11.5 / 80 -15.3 TR 15		01
03	0503035060	WHEEL 9.00 X 15.3		01




Item	Code	Description	See page	QT
01	0502011389	BOX		01
02	0503010006	32210 ROLLER BEARING		01
03	0503010005	32212 ROLLER BEARING		01
04	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
05	0503010002	1800 GREASE FITTING		01
06	0503010064	5/8 UNF CONIC NUT		06
07	0503011866	SEAL 00573-B WITH HOLE		01
08	0501010888	1.3/4" 2.5/16" CASTLE NUT		01
09	0503010010	1/4" X 2.1/2" COTTERPIN		01
10	0502020593	COVER		01
11	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		01
12	0591016195	WHEEL AXIS		01




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		02
02	0503017857	BOLT 5/8 UNF 4		08
03	0503010811	5/8" UNF SELF ADJUSTING NUT		08
04	0551019514	3/8 FASTENER		02
05	0531050903	SIDE ARTICULATED CYLINDER 42		01
06	0591017796	ARTICULATION AXIS 222 R.1.1 / 4 UNF		01
07	0531062134	UNIVERSAL SUPPORT		01
08	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
09	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
10	0503010019	1/2" SPRING WASHER		04
11	0501111070	SIDE SUPPORT ARTICULATOR		01
12	0503011075	3/4" UNC NUT		06
13	0501010125	3/4" X 2-1/2" BOLT		06
14	0591013172	31.75 X126 AXLE WITH 8 HOLE		02
15	0591013173	CYLINDER INTERMEDIATE BUSHING		02
16	0503012231	1/4" X 3" COTTERPIN		02
17	0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	43	02
18	0503010026	3/8" NUT		04
19	0503010025	3/8 SPRING WASHER		04
20	0501011544	3/4" X 1-1/2" BOLT		01
21	0503010023	3/4" SPRING WASHER		01
22	0511017232	FLAT WASHER		01
23	0591018408	PIN LOCK LINES		01
24	0503030085	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531062138	CASE 85,7 X 486 WITH COVER		01
02	0503010761	D-1750 SCRAPER RING		01
03	0571019711	RING SUPPORT		01
04	0571019709	DETACHABLE COVER		01
05	0503017936	RING		01
06	0503017938	RING GUIDE		01
07	0503017937	GASKET		01
08	0503017940	8-337 BACK-UP RING		02
09	0503017939	2-337 N 3006-9B O' RING		02
10	0503018045	2-130 (AGEL) O'RING		04
11	0511064408	FORK		01
12	0503010025	3/8 SPRING WASHER		01
13	0503011094	3/8" X 2" BOLT		01
14	0503010026	3/8" NUT		01
15	0503010042	2-214 N 3006-9B O'RING		01
16	0503010063	1" SELF-ALIGNING NUT		01
17	0571019710	1.7" X 3.4" PISTON		01
18	0503017935	RING		01
19	0503018144	RING		01
20	0591017818	EXTENSOR 44,45 X 550		01




Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011195	ADJUSTMENT NUT BODY		01
02	0503010002	1800 GREASE FITTING		02
03	0551013654	SPINDLE R.1.1 / 4 X R.1.1 / 2 RIGHT X 165		01
04	0502040747	32.54 CLEVIS CLAMP		01
05	0551013653	SPINDLE R.1.1 / 4 X LEFT X.1.1 / 2 X 165		01
06	0503011094	3/8" X 2" BOLT		01
07	0503010026	3/8" NUT		01
08	0503011443	3/8" SPRING WASHER		01
09	0501061056	RH LOCKNUT WITH HANDLER		01
10	0531062137	SIDE FERTILIZER BOX EXTENSOR		01
11	0521010779	31.75 X 95 COUPLING SHAFT		01
12	0503010571	1/4" X 1.1/2 COTTERPIN		01



Item	Code	Description	See page	QT
01	0591018304	FERTILIZER CONDUCTOR GUTTER	01	
02	0591015578	CLAMP	05	
03	0591015577	CONDUCTING TUBE	03	
04	0501010942	3/8" X 1-1/4" BOLT	07	
05	0503013357	3/8 SELF-ADJUSTING NUT	07	
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER	07	
07	0591018014	LEFT SUPPORT	01	
08	0591016338	CONDUCTING TUBE	02	
09	0591017994	SUPPORT RIGHT	01	




Item	Code	Description	See page	QT
01	0581018408	SUPPORT SCALE		08
02	0591016226	SHORT SUPPORT		02
03	0503011123	BOLT		04
04	0503013357	3/8 SELF-ADJUSTING NUT		04
05	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		02
06	0503013389	5/8" SELF LOCKING NUT		02
07	0501012140	FLAT WASHER		02
08	0531062186	SIDE FRAME DUCT		02
09	0531062185	SIDE FRAME DUCT		04




Item	Code	Description	See page	QT
01	0591016055	REAR HEADLIGHT SUPPORT		01
02	0503018738	HEADLIGHT		01
03	0503010337	5/16" NUT		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		02

LOCK PIN ASSY


0521059838



Item	Code	Description	See page	QT
01	0591016056	LOCK AXLE SUPPORT		01
02	0531061626	38 X 308 JUNCTION AXLE WITH HANDLE		02
03	0503030119	LOCK PIN		02
04	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
05	0503013389	5/8" SELF LOCKING NUT		01
06	0501010453	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0503013622	VALVE ASSY		01
02	0511010111	7/8" NIPPLE		02
03	0503011030	2-014 N 3006-9B O'RING		01
04	0503010045	O'RING		02
05	0501012109	3/4" X 9/16" NIPPLE FITTING		01




Item	Code	Description	See page	QT
01	0581010302	RING OF SUPPORT		01
02	0502012822	101.60 END CAP		01
03	0503011061	8-342 BACK-UP RING		02
04	0503010338	2-342 N 3006-9B O'RING		02
05	0503017936	RING		01
06	0503017938	RING GUIDE		01
07	0503017937	GASKET		01
08	0503010761	D-1750 SCRAPER RING		01
09	0503018045	2-130 (AGEL) O'RING		04
10	0503030387	PLUG		02
11	0531061461	CASE 101.6 X 466.5 WITHOUT LUBRICATION		01
12	0531061460	ROTATING CYLINDER ROD		01
13	0581010837	PISTON		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503015633	SELEMASTER SEALING		01
16	0503018029	2-217 O'RING		01

ASSY LOCK AXLE


0521059948




Item	Code	Description	See page	QT
01	0502040080	FLANGE NUT R.2.1/2 UN		01
02	0503010002	1800 GREASE FITTING		01
03	0531061664	LOCK AXIS		01



Item	Code	Description	See page	QT
01	0503011255	3/4" LOCK NUT		02
02	0571019062	SLEEVE		01
03	0571019059	SUPPORT WASHER		01
04	0503034320	COMPRESSION SPRING		01
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503011854	5/8" X 1-1/4" BOLT		02
07	0521010066	3/4" X 8.12" BOLT		02
08	0503017960	5/8" X 3-12" BOLT		04
09	0502012813	FLANGE WASHER SPRING		01
10	0531062203	REGULATOR SPRING LINE FERTILIZER		01
11	0503010417	7/8" NUT		02
12	0502012789	FIXER SUPPORT FERTILIZER ROW		01
13	0591011145	FERTILIZER ROW SUPPORT		01
14	0503019278	LUBRICANT SLEEVE		02
15	0591011147	SLEEVE ARM ROW		02
16	0503011109	2-119 N 3006-9B O'RING		02
17	0581014070	FERTILIZER NOZZLE		01
18	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
19	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
20	0503010025	3/8 SPRING WASHER		02
21	0521053946	SCARING ROD	55	01
22	0521065972	LH SHORT ARM ROW FERTILIZER		01
23	0503011254	7/8" HEX SELF ADJUSTING NUT		01
24	0531051902	CURVED WAVY CUTTING DISC 20 COMPLETE	57	01
25	0503010026	3/8" NUT		02
26	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
27	0503010019	1/2" SPRING WASHER		02
28	0503010060	1/2 UNC G.5 ZN HEX NUT		02
29	0511018662	SPACING PLATE		02




Item	Code	Description	See page	QT
01	0503011255	3/4" LOCK NUT		02
02	0571019062	SLEEVE		01
03	0571019059	SUPPORT WASHER		01
04	0503034320	COMPRESSION SPRING		01
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503011854	5/8" X 1-1/4" BOLT		02
07	0521010066	3/4" X 8.12" BOLT		02
08	0503017960	5/8" X 3-12" BOLT		04
09	0502012813	FLANGE WASHER SPRING		01
10	0531062203	REGULATOR SPRING LINE FERTILIZER		01
11	0503010417	7/8" NUT		02
12	0502012789	FIXER SUPPORT FERTILIZER ROW		01
13	0591011146	SUPPORT LONG		01
14	0531061648	LONG ARM LOWER FERTILIZER LINE		01
15	0591011147	SLEEVE ARM ROW		02
16	0503019278	LUBRICANT SLEEVE		02
17	0503011109	2-119 N 3006-9B O'RING		02
18	0503011254	7/8" HEX SELF ADJUSTING NUT		01
19	0531051902	CURVED WAVY CUTTING DISC 20 COMPLETE	57	01
20	0581014070	FERTILIZER NOZZLE		01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
23	0503010025	3/8 SPRING WASHER		02
24	0503010026	3/8" NUT		02
25	0591016141	LONG LINE COMPLEMENT		02
26	0521053673	SCARIFIER ROD WITH NOZZLE	56	01
27	0503010019	1/2" SPRING WASHER		04
28	0503010060	1/2 UNC G.5 ZN HEX NUT		04
29	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
30	0503010479	BOLT		02
31	0511018662	SPACING PLATE		04




Item	Code	Description	See page	QT
01	0503011255	3/4" LOCK NUT		02
02	0571019062	SLEEVE		01
03	0571019059	SUPPORT WASHER		01
04	0503034320	COMPRESSION SPRING		01
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503011854	5/8" X 1-1/4" BOLT		02
07	0521010066	3/4" X 8.12" BOLT		02
08	0503017960	5/8" X 3-12" BOLT		04
09	0502012813	FLANGE WASHER SPRING		01
10	0531062203	REGULATOR SPRING LINE FERTILIZER		01
11	0503010417	7/8" NUT		02
12	0502012789	FIXER SUPPORT FERTILIZER ROW		01
13	0591011146	SUPPORT LONG		01
14	0503019278	LUBRICANT SLEEVE		02
15	0591011147	SLEEVE ARM ROW		02
16	0503011109	2-119 N 3006-9B O'RING		02
17	0581014070	FERTILIZER NOZZLE		01
18	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
19	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
20	0503010025	3/8 SPRING WASHER		02
21	0521053946	SCARING ROD	55	01
22	0531061648	LONG ARM LOWER FERTILIZER LINE		01
23	0503011254	7/8" HEX SELF ADJUSTING NUT		01
24	0531051902	CURVED WAVY CUTTING DISC 20 COMPLETE	57	01
25	0503010026	3/8" NUT		02
26	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
27	0503010019	1/2" SPRING WASHER		02
28	0503010060	1/2 UNC G.5 ZN HEX NUT		02
29	0511018662	SPACING PLATE		02

SCARING ROD


0521053946




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070085	FIXED ROD BEARING		01
03	0513010288	ELASTIC PIN 701211 10 X 24		02
04	0513010289	ELASTIC PIN 701211 10 X 24		02



Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER ROD		01
02	0503011402	0.2" X 0.8" SPRING PIN		02
03	0503016853	SPRING PIN		02
04	0502040869	FIXED ROD BEARING		01




Item	Code	Description	See page	QT
01	0531060662	MONO ARM DISC CUTTING		01
02	0531060661	ARM SUPPORT		01
03	0571019034	FLANGE WASHER AXLE		01
04	0571019032	SUPPORT WASHER		01
05	0502012813	FLANGE WASHER SPRING		01
06	0591010619	DC SPRING SUPPORT		01
07	0503019274	WASHER		02
08	0581017628	LID		02
09	0503034320	COMPRESSION SPRING		01
10	0591010625	19,50 X 25 X 91,50/91,30 SLEEVE		01
11	0503010417	7/8" NUT		02
12	0503010390	SEAL RING		02
13	0503011198	C3/4" X 6" SCREW		01
14	0503011255	3/4" LOCK NUT		01
15	0503030430	7/16 X 2" PIN LOCK		01
16	0503019271	SELF LUBRICATING BUSHING		01
17	0503011254	7/8" HEX SELF ADJUSTING NUT		01
18	0531061481	MONO SPRING DISC CUTTING REGULATOR		01
19	0591011144	FIXATION AXLE		01
20	0591010628	DC AXIS BACKREST WASHER		01
21	0503019272	LUBRICANT SLEEVE		02
22	0531051903	CURVED CURVED CUTTING DISC	58	01
23	0503012412	5/8 UNC SELF LOCKING NUT		01
24	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01




Item	Code	Description	See page	QT
001	0521057680	DISC CUTTING BOX	59	01
002	0607026025	DPLO20X4,5		01

DISC CUTTING BOX


0521057680




Item	Code	Description	See page	QT
01	0503010370	502072 CLAMPING RING (FOR AXLE)	02	
02	0502020641	BLADE DISC FLANGE	01	
03	0503018825	5/16 UNC UNC BOLT	06	
04	0503013816	5/16" LOCKNUT	06	
05	0501010694	FLAT WASHER	06	
06	0502012862	DISC BLADE HUB	01	
07	0511017907	1/8" BSPT X 6 PLUG	02	
08	0503019285	RING	02	
09	0503010590	00674-B SEAL	02	
10	0591012836	CUTTING DISC AXLE	01	
11	0502040872	REGULATORY NUT	01	
12	0503012170	30207 ROLLER BEARING	02	
13	0503010812	7/8" UNF SELF LOCKING NUT	01	
14	0501010067	22.5 X 56 X 4.75 FLAT WASHER	01	
15	0503019283	SCREW 7/8 UNF X 6.1/4	01	




Item	Code	Description	See page	QT
01	0521059626	FRONT LINE	63	01
02	0521059466	TITANIUM SEED DISTRIBUTOR	64	01
03	0521059627	UNIVERSAL CURRENT / CABLE BEARING	66	01
04	0503063178	SHORT LINE ENCAPSULATED CHAIN		01
05	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	67	01
06	0521056636	REAR RIGHT SPI TITANIUM/TATU	68	01
07	0503011295	M 8 X 1,25 X 25 BOLT		02



Item	Code	Description	See page	QT
01	0521059626	FRONT LINE	63	01
02	0531061136	EXTENSION		01
03	0503012136	NUT 1/2 NF		04
04	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
05	0521059466	TITANIUM SEED DISTRIBUTOR	64	01
06	0521059627	UNIVERSAL CURRENT / CABLE BEARING	66	01
07	0503063179	LONG LINE ENCAPSULATED CHAIN		01
08	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	67	01
09	0521056637	REAR LEFT SPI TITANIUM/TATU	69	01
10	0503011295	M 8 X 1,25 X 25 BOLT		02




Item	Code	Description	See page	QT
01	0521059626	FRONT LINE	63	01
02	0521059466	TITANIUM SEED DISTRIBUTOR	64	01
03	0531060405	EXTENSION		01
04	0503012136	NUT 1/2 NF		04
05	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
06	0521059627	UNIVERSAL CURRENT / CABLE BEARING	66	01
07	0503063180	SUPER / LONG 1200 ENCAPSULATED CHAIN		01
08	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	67	01
09	0521056637	REAR LEFT SPI TITANIUM/TATU	69	01
10	0503011295	M 8 X 1,25 X 25 BOLT		02




Item	Code	Description	See page	QT
01	0531060663	FRONT FRAME SEED LINE	01	
02	0531061428	REAR LINE	01	
03	0503030168	HITCH PIN CLIP	05	
04	0571018883	PIN FIXER SPRING	02	
05	0503034198	SPRING TRACTION 40 X 198 X 5,5	01	
06	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
07	0502012812	SEED ROW ADJUSTMENT LEVER ASSY	01	
08	0591011156	PIVOT ARM SEED ROW	02	
09	0503017857	BOLT 5/8 UNF 4	04	
10	0501012140	FLAT WASHER	04	
11	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
12	0503019273	AUTO LUBRICANT SLEEVE	08	
13	0503010045	O'RING	08	
14	0591012829	SPACER LOWER SLEEVE	08	
15	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
16	0503012412	5/8 UNC SELF LOCKING NUT	04	
17	0591012827	FRONT PENDULUM LINE	01	
18	0591012828	LOCK PIN ROW ARTICULAT	01	
19	0501219536	LINE GUTTER	01	
20	0501310623	SPRING FIXING PIN	02	

TITANIUM SEED DISTRIBUTOR


0521059466




Item	Code	Description	See page	QT
01	0511052058	SEED SYSTEM TITANIUM	65	01
02	0503033771	SILO SEED AIR POSITIVE		01
03	0531061432	SEED SIEVE		01
04	0591014774	TERMINAL COUPLING HOSE		01
05	0503010025	3/8 SPRING WASHER		01
06	0503019222	BRACELET TYPE WIRE 3.2MM X 48 X 63 MM		01
07	0503035257	KNOB 3 POINTS K3 60 A 3/8 UNC X 20		01
08	0503019869	CLAMP		01




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
09.	0503016279	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01
14	0503062044	ASSEMBLY SEED HOPPER SET		01
14A	0503016285	BOLT		05
14B	0503016286	HEX NUT		05
14C	0503016287	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0531061496	BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503019373	6006 2RS1 NATIONAL BEARING		01
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0581019823	BEARING AXLE BODY WITHOUT LUBRICATION		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		01
09	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
10	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0531062260	GUIDE HOSE L / TRANSMISSION		01
02	0571018883	PIN FIXER SPRING		01
03	0503010257	1/8" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0531050193	DOSING ASSY TITANIUM/TATU	70	01
02	0521056645	RIGHT SPI TRANSMISSION	73	01
03	0591017564	TITANIUM SEED DRIVER GUIDE		01
04	0503015341	POP RIVET		02
05	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04
06	0503010025	3/8 SPRING WASHER		04
07	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0531050193	DOSING ASSY TITANIUM/TATU	70	01
02	0521056646	LEFT REAR FRAME		01
03	0591017564	TITANIUM SEED DRIVER GUIDE		01
04	0503015341	POP RIVET		02
05	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04
06	0503010025	3/8 SPRING WASHER		04
07	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521056639	SEED ROW TRANSMISSION	71	01
02	0503035402	HIGHER LINE HIGH SEED		01
03	0502012921	BASE FIXING SYSTEM		01
04	0591014600	ENCAPSULATED CURRENT FIXER		01
05	0503014876	NUT PARLOCK 1/4"		02
06	0503010461	1/4" X 1" BOLT		02
07	0511052024	FAST CLOSING SET	72	01



Item	Code	Description	See page	QT
01	0502012932	MINOR SIDE	01	
02	0503017046	BEARING	02	
03	0503011410	ROLLER BEARING	02	
04	0591011321	AXLE GEAR	01	
05	0591011322	SPACER	01	
06	0581019168	DUST CLOAK	01	
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
08	0503010025	3/8 SPRING WASHER	01	
09	0503010179	LOCK WASHER 5/16 ZN 1K01528	04	
10	0503011945	503050 CLAMPING RING (FOR AXLE)	01	
11	0503010420	BOLT	02	
12	0503011053	5/16" X 3" C S 6.5 ZN BOLT	04	
13	0502012919	GRAGGER	01	
14	0502012933	LARGER SIDE	01	
15	0502012930	CONICAL GEAR	01	
16	0502012931	CONICAL GEAR	01	
17	0503010585	0,24" X 1.18" SPRING PIN	01	



Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0521056632	DEPTH CONTROL	74	01
03	0591011323	AXLE ARTICULATION WHEEL DEPTH		02
04	0502012920	SUPPORT ADJUSTING		01
05	0502012611	DEPTH CONTROL AXLE		01
06	0591011309	ADJUSTMENT BUSHING		02
07	0591011310	ADJUSTMENT BAR		02
08	0503019275	SLEEVE LUBRICATION SYSTEM		01
09	0581019473	ARTICULATED SLEEVE		02
10	0503010045	O'RING		02
11	0503013357	3/8 SELF-ADJUSTING NUT		02
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
13	0591011326	LOCK PIN		01
14	0571015326	ARTICULATION SLEEVE HANDLE		01
15	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
16	0503010060	1/2 UNC G.5 ZN HEX NUT		02
17	0503010019	1/2" SPRING WASHER		04
18	0591011324	SMALLER AXLE		01
19	0591011325	LARGER AXLE		01
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
21	0503030012	HITCH PIN CLIP		02
22	0501011445	FLAT WASHER		04
23	0521056633	MOUNTED RIGHT ARM	75	01
24	0521056631	MOUNTED LEFT ARM	78	01
25	0503010025	3/8 SPRING WASHER		02
26	0503012556	1/2" X 1" BOLT		02
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
28	0591011306	ADJUSTMENT LOCK		02
29	0503012136	NUT 1/2 NF		04
30	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
31	0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	79	01

RIGHT SPI TRANSMISSION

0521056645


Item	Code	Description	See page	QT
32	0521055093	BODY COMPACTOR	86	01
33	0521054990	LEFT COMPACTOR WHEEL	84	01
34	0521055017	RIGHT COMPACTOR WHEEL	87	01




Item	Code	Description	See page	QT
01	0502012925	ADJUSTMENT BODY		01
02	0511015976	FLAT WASHER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0503010581	RING		01
05	0502012892	DEPTH CONTROL HANDLE		01
06	0581019526	ARTICULATED AXLE LEVER DEPTH		01
07	0503010302	501019 SEAL RING		01

MOUNTED RIGHT ARM


0521056633



Item	Code	Description	See page	QT
01	0502012926	RIGHT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 76 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503030891	RUBBER BAND		01
03	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
05	0503010337	5/16" NUT		06
06	0521055073	ASSEMBLY DEPTH WHEEL HUB	77	01




Item	Code	Description	See page	QT
01	0581019528	WHEEL DEPTH SPA HUB WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	DUST CLOAK		01
11	0581019529	DEPTH REGULATOR SHAFT		01

MOUNTED LEFT ARM


0521056631




Item	Code	Description	See page	QT
01	0502012927	LEFT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 76 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0502012929	BODY RIGHT		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 81 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 80 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	82	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	83	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUB DISC - HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	85	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT	02	
02	0503013816	5/16" LOCKNUT	04	
03	0581015855	SLEEVE	02	
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER	01	
05	0521068661	LEVER	01	
06	0503030878	LEVER CRANK	01	
07	0503031393	1.57" X 5.98" X 0.2"TRACTION SPRING	01	
08	0581019520	AXIS	01	
09	0571812442	COUPLING SHAFT	01	
10	0503010257	1/8" X 1" COTTERPIN	01	
11	0581019511	COVER	01	
12	0503010848	5/16" X 3.1/2" BOLT	02	
13	0503010752	1/2" X 3.1/2" BOLT	01	
14	0503011336	1/2" HEX SELF ADJUSTING NUT	01	
15	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
16	0581019510	AXIS	01	
17	0581019512	PLATE TOP	01	
18	0503019351	LUBRICANT SLEEVE	02	
19	0521069591	LEFT SIDE	01	
20	0581019548	RIGHT SIDE BODY	01	



Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	85	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0503016204	CORN DISC 12 ORANGE		01
02	0503016398	TITANIUM RING CORN / SOY (YELLOW FLAT)		01
03	0503016399	TITANIUM RING CORN (GREEN)		01
04	0503016400	TITANIUM RING CORN (GREY)		01
05	0503016401	TITANIUM RING CORN (BLUE)		01




Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016218	DISC OF SOYBEAN		01
03	0503016403	TITANIUM RING FOR SOYBEAN (LILAC)		01
04	0503016404	TITANIUM RING FOR SOYBEAN (PURPLE)		01
05	0503016406	TITANIUM RING FOR SOYBEAN (ORANGE)		01
06	0503016407	TITANIUM RING FOR SOYBEAN		01

RIGHT DUAL FERTILIZER DISC


0521055868




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 81 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 80 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0581012238	SEED HOPPER SUPPORT		04
02	0531061644	CENTRAL SEED SILO FIXATION BASE		01
03	0501011643	3/8 X 1" BOLT		16
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
05	0503013357	3/8 SELF-ADJUSTING NUT		24
06	0503010025	3/8 SPRING WASHER		04
07	0503010026	3/8" NUT		04
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
09	0521053176	COVER KAP		01
09A	0503011372	102 TO 121 CLAMP		01
09B	0581017528	15 OUTPUT TUBE COVER		01
10	0521053173	CENTRAL SEED HOPPER 15 OUTPUTS	92	01
11	0531060166	LEFT LOCKING SUPPORT		01
12	0503011372	102 TO 121 CLAMP		01
13	0531060165	RIGHT LOCKING SUPPORT		01
14	0531060781	BOX FIXING CLAMP		02
15	0501012140	FLAT WASHER		20
16	0503010811	5/8" UNF SELF ADJUSTING NUT		20
17	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
18	0503010232	5/8" X 1.3/4" BOLT		12
19	0531051092	ASSY HOSE SUPPORT	94	01
20	0531060723	RIGHT CENTRAL HANDRAIL		01
21	0531060724	LEFT CENTRAL HANDRAIL		01
22	0501010942	3/8" X 1-1/4" BOLT		08
23	0521045392	HYDRAULIC TURBINE WITH SCREEN	95	01
24	0503010233	5/8" X 2-1/2" BOLT		04
25	0531051119	PRECISION PLANTING ASSEMBLED TURBINE	98	01
26	0503019221	WIRE TYPE CLAMP 3,2MM X 35 X 41 MM AWAARC041		19
27	0531061755	NOZZLE Y SEED		02




Item	Code	Description	See page	QT
01	0521068977	15 OUTPUTS AIR TUBE		01
02	0521053175	BASE CSC HOPPER 15 OUTPUTS	93	01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		26
04	0503015075	M10 SPRING WASHER		26
05	0503010025	3/8 SPRING WASHER		08
06	0503010172	M10 X 1,5 X 25 BOLT		26
07	0503062687	SEED HOPPER		01
08	0503019284	M8 X BOLT		04
09	0503010849	3/8" X 1-1/2" BOLT		08
10	0581017922	WASHER		04



Item	Code	Description	See page	QT
01	0521068978	CASH FUND COVER		03
02	0503015135	FLAT WASHER 10 X 18 X 2		06
03	0503011823	0.1" X 0.6" SPRING PIN		06
04	0521068851	SYSTEM ASSY		01
05	0503034571	SEALING		01
06	0503034573	SEALING		03
07	0581017529	ROD 9,53		03
08	0503062759	SEALING		03
09	0503034692	FAST LOCK ASSY		06
10	0503030085	LOCK PIN		06
11	0503019290	BOLT		24




Item	Code	Description	See page	QT
01	0531062259	HOSE SUPPORT		01
02	1902011170	FIXER		02
03	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		04
04	0501013519	FLAT WASHER		04
05	0503010589	1/2" UNC SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0501054983	NIPPLE HIDRAULIC MOTOR	96	01
02	0503010025	3/8 SPRING WASHER		12
03	0503010026	3/8" NUT		10
04	0521044613	FAN 480X50 (HIDRAULIC)		01
05	0503010143	1/4" SPRING WASHER		01
06	0503010849	3/8" X 1-1/2" BOLT		02
07	0531018764	FLAT WASHER		01
08	0503011104	M6 X 1" BOLT		01
09	0503012722	0.16" X 0.4" BLIND RIVET		24
10	0521065857	CARACOL MECHANICAL TURBINE S MEC		01
11	0521065858	TURBIN SUPPORT		01
12	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC 97 TURBINE		01
13	0561010634	VALVE SUPPORT ASSY		01
14	0503010237	3/8" X 1" BOLT		08
15	0503010206	3/8 X 1/2 BOLT		02
16	0571018577	COVER SNAIL TURBINE		01
17	0571018578	TURBINE PROTECTIVE SCREEN		01
18	0541013274	LISA WASHER 10 X 38 X 4.75		02
19	0521069167	FRONT PROTECTION		01
20	0501080709	3/8" X 21.6" TR-TR HOSE		01
21	0501080091	1/2" X 550 TR-TR HOSE		02
22	0503031087	ADHESIVE LABEL		01
23	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
24	0503033981	ADHESIVE LABEL		01

NIPPLE HIDRAULIC MOTOR


0501054983




Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW		01
03	0561016941	3/4" NUT		01
04	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
05	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE		01
06	3914103037	TEFLON		0,001RI



Item	Code	Description	See page	QT
01	0503012291	BLOCK COMMAND		01
02	0501010590	NIPPLE		04
03	0503010045	O'RING		04
04	0541011066	3/4" UNF X 43.5 NIPPLE		01
05	0503010190	2-114 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		04
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O-RING		01
05	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
06	0531051120	PLANTING TURBINE WITH HOLE	99	01
07	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
08	0501010694	FLAT WASHER		02
09	0503010143	1/4" SPRING WASHER		02
10	0503010144	1/4" NUT		02
11	0503010190	2-114 N 3006-9B O-RING		04
12	0501081235	1/2 X 650 TR- TC HOSE		01
13	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
14	0503031087	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0531062288	TURBINE FLANGE		01
02	0521050154	PRECISION PLANTING TURBINE WITH HOLE		01

MOUNTED CENTRAL SUPPORT


0531050964




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		02
02	0503017857	BOLT 5/8 UNF 4		08
03	0503010811	5/8" UNF SELF ADJUSTING NUT		08
04	0551019514	3/8 FASTENER		02
05	0591017796	ARTICULATION AXIS 222 R.1.1 / 4 UNF		01
06	0531062134	UNIVERSAL SUPPORT		01
07	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
08	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
09	0503010019	1/2" SPRING WASHER		04
10	0503011075	3/4" UNC NUT		06
11	0501010125	3/4" X 2-1/2" BOLT		06
12	0591013172	31.75 X126 AXLE WITH 8 HOLE		02
13	0591013173	CYLINDER INTERMEDIATE BUSHING		02
14	0503012231	1/4" X 3" COTTERPIN		02
15	0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	43	02
16	0503010026	3/8" NUT		04
17	0503010025	3/8 SPRING WASHER		04
18	0501111072	SIDE SUPPORT ARTICULATOR		01
19	0501011544	3/4" X 1-1/2" BOLT		01
20	0503010023	3/4" SPRING WASHER		01
21	0511017232	FLAT WASHER		01
22	0531050903	SIDE ARTICULATED CYLINDER 44.45X85.70X291X657	42	01
23	0591018408	PIN LOCK LINES		01
24	0503030085	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531061579	CENTRAL WHEEL SUPPORT		01
02	0531050023	HYDRAULIC CYLINDER 2 X 5 X 599 X 336	36	01
03	0503010019	1/2" SPRING WASHER		05
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503017874	BOLT 1/2 UNC		01
06	0591015907	LARGER JUNCTION AXIS		01
07	0521059737	CENTRAL FORK RODEIRO	102	01
08	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
09	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
10	0502012731	WHEEL HOLDER		03
11	0503014441	BOLT 3/4		06
12	0501010322	FLAT WASHER		06
13	0503010152	3/4" SELF LOCKING NUT		06
14	0521059723	WHEEL ASSY WITH TIRE	103	02
15	0551016274	HYDRAULIC CYLINDER ADAPTER		01




Item	Code	Description	See page	QT
01	0531061573	WHEEL BODY	01	
02	0521018575	REGULATOR SPINDLE 100	02	
03	0591015950	SUPPORT	04	
04	0501010087	1.1/4" NUT	02	
05	0521059738	CROSSHEAD MOUNTED	01	
06	0591016434	PLASTIPRENE	02	
07	0503019246	BOLT	02	
08	0503011075	3/4" UNC NUT	02	
09	0531061575	BEARING	02	
10	0503010019	1/2" SPRING WASHER	13	
11	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT	12	
12	0503019271	SELF LUBRICATING BUSHING	02	
13	0591015935	CENTRAL WHEEL CYLINDER AXLE	01	
14	0503010060	1/2 UNC G.5 ZN HEX NUT	01	
15	0503010752	1/2" X 3.1/2" BOLT	01	




Item	Code	Description	See page	QT
01	0521059728	WHEEL WITH TIRE	39	01
02	0521059724	ASSEMBLED CUBE WITHOUT TRANSMISSION	104	01




Item	Code	Description	See page	QT
01	0502011389	BOX		01
02	0503010006	32210 ROLLER BEARING		01
03	0503010005	32212 ROLLER BEARING		01
04	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
05	0503010002	1800 GREASE FITTING		01
06	0503010064	5/8 UNF CONIC NUT		06
07	0503011866	SEAL 00573-B WITH HOLE		01
08	0501010888	1.3/4" 2.5/16" CASTLE NUT		01
09	0503010010	1/4" X 2.1/2" COTTERPIN		01
10	0502020593	COVER		01
11	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		01
12	0591015895	WHEEL AXIS		01




Item	Code	Description	See page	QT
01	0503062362	FERTILIZER HOPPER		01
02	0531051782	07 MOUTH CENTRAL SUPPORT	106	01
03	0521051407	FERTILIZER HOPPER FIXER	27	10
04	0501013519	FLAT WASHER		06
05	0503010589	1/2" UNC SELF ADJUSTING NUT		06
06	0503014378	1/2" X 1-1/2" BOLT		06
07	0503062927	FERTILIZER HOPPER		01




Item	Code	Description	See page	QT
01	0531062465	07 MOUTH SILO SUPPORT		01
02	0521054282	BEARING	30	02
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	34	04
04	0503030275	AGRICULTURAL BEARING		07
05	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	32	03
06	0501053788	3/4 SQUARE AXLE FASTENER	33	02
07	0551018055	22,65 X 60 SLEEVE		02
08	0503011953	5/16" X 1" BOLT		28
09	0501010694	FLAT WASHER		28
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		28
11	0503010337	5/16" NUT		28
12	0502012990	CONICA 14Z SQUARE GEAR		07
13	0503010362	1/8 X 1.1/4 COTTERPIN		07
14	0503034396	FERTILIZER SIDE COVER		07
15	0581016498	SQUARE AXLE 3/4 X 2700 - 3200		01



Item	Code	Description	See page	QT
01	0591017995	FERTILIZER CONDUCTOR GUTTER		02
02	0501010942	3/8" X 1-1/4" BOLT		02
03	0503013357	3/8 SELF-ADJUSTING NUT		08
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		14
05	0591018014	LEFT SUPPORT		01
06	0531061465	GUIDE		06
07	0591017994	SUPPORT RIGHT		01
08	0531051736	SHORT LINE FERTILIZER CONDUCTOR ARTICULATOR		06




Item	Code	Description	See page	QT
01	0531061658	CENTRAL PLATFORM 2797		01
02	0501013519	FLAT WASHER		04
03	0503010589	1/2" UNC SELF ADJUSTING NUT		04
04	0503014378	1/2" X 1-1/2" BOLT		04




Item	Code	Description	See page	QT
01	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
02	0571011767	LISA WASHER 125 X 88 X 4.76		01
03	0503010408	7/8" SPRING WASHER		01
04	0503015322	BOLT 7/8		01
05	0591012527	HORIZONTAL JOINT AXIS		01
06	0503011198	C3/4" X 6" SCREW		01
07	0503010023	3/4" SPRING WASHER		01
08	0503010014	3/4" HEX NUT		01
09	0503010814	5/16 BOLT		10
10	0503010002	1800 GREASE FITTING		01
11	0571011825	BUSHING		02
12	0503010004	1890 GREASE FITTING		01
13	0531062167	RIGHT HOSE SUPPORT		01
14	0531062168	CYLINDER JOINT AXIS		01
15	0503010834	1/2 X 1 BOLT		01
16	0503010019	1/2" SPRING WASHER		05
17	0503010060	1/2 UNC G.5 ZN HEX NUT		04
18	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
19	0501013519	FLAT WASHER		04
20	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
21	0591012948	700 X 130 X 10 PLATE		01
22	0531062196	LEFT ARTICULATION ARM		01
23	0531062166	LEFT SUPPORT HOSES		01
24	0503035505	HOSE PROTECTOR		01

ASSY LEFT ARTICULATION ARM


0531050935




Item	Code	Description	See page	QT
01	0521063778	RELATION AVEC AXE VERTICAL LATCH	01	
02	0571011767	LISA WASHER 125 X 88 X 4.76	01	
03	0503010408	7/8" SPRING WASHER	01	
04	0503015322	BOLT 7/8	01	
05	0591012527	HORIZONTAL JOINT AXIS	01	
06	0503011198	C3/4" X 6" SCREW	01	
07	0503010023	3/4" SPRING WASHER	01	
08	0503010014	3/4" HEX NUT	01	
09	0503010814	5/16 BOLT	10	
10	0503010002	1800 GREASE FITTING	01	
11	0571011825	BUSHING	02	
12	0503010004	1890 GREASE FITTING	01	
13	0591012948	700 X 130 X 10 PLATE	01	
14	0531062149	RIGHT ARTICULATION ARM	01	
15	0531062167	RIGHT HOSE SUPPORT	01	
16	0531062166	LEFT SUPPORT HOSES	01	
17	0531062168	CYLINDER JOINT AXIS	01	
18	0503010834	1/2 X 1 BOLT	01	
19	0503010019	1/2" SPRING WASHER	05	
20	0501013519	FLAT WASHER	04	
21	0503010060	1/2 UNC G.5 ZN HEX NUT	04	
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT	02	
23	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	02	
24	0503035505	HOSE PROTECTOR	01	




Item	Code	Description	See page	QT
01	0581010353	RING SUPPORT		01
02	0502010382	5" END CAP		01
03	0581013698	PISTON		01
04	0531062199	CASE 127 X 662		01
05	0531062198	EXTENSOR 50,80 X 692		01
06	0503010003	1845 GREASE FITTING		02
07	0503010817	1.1/4" SELF LOCKING NUT		01
08	0503018439	WIPER SEAL		01
09	0503018150	RING GUIDE		01
10	0503010173	2-220 N 3006-9B O'RING		01
11	0503018024	RING BS		01
12	0503018026	1870-2000-375 B GASKET		01
13	0503010039	D-2000 SCRAPER RING		01
14	0503018152	O'RING		02
15	0503018025	RING GUIDE		01
16	0503011453	O'RING		02




Item	Code	Description	See page	QT
01	0503035133	ADHESIVE LABEL USAP 3200 (192 X 437)		08
02	0503034782	LABEL ADHESIVE LOGO SMALLER TATU (03 MOUTHS)		08
03	0503035135	ADHESIVE LABEL USAP 3200 (185 X 320)		04
04	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		04
05	0503035134	ADHESIVE LABEL USAP 3200 (190 X 613)		02
06	0503034983	LOGO TATU MARCHESAN ADHESIVE LABEL 190 X 613		08
07	0503035136	ADHESIVE LABEL USAP 3200 (170 X 820)		03
08	0503035137	ADHESIVE LABEL USAP 3200 (165 X 850)		03
09	0503034970	LOGO TATU MARCHESAN (CSC) 155 X 1120		03
10	0503034971	ADHESIVE LABEL LOGO TATU MARCHESAN (CSC) 150 X 1130		03
11	0503034338	ADHESIVE LABEL		02
12	0503035445	ADHESIVE LABEL LEVER BLUE HANDLE		01
13	0503035443	ADHESIVE LABEL LEVER RED HANDLE		01
14	0503035442	ADHESIVE LABEL FLOATING LEVER		01
15	0503033415	ADHESIVE LABEL		02
16	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING		02
17	0503031565	ADHESIVE LABEL CARE		02
18	0503031428	READ MANUAL DECAL		01
19	0503031425	ADHESIVE LABEL ATTENTION		02
20	0503034078	LIFTING POINTS DECAL		02
21	0503031087	ADHESIVE LABEL		01
22	0503035316	LUBRICATED POINTS ADHESIVE LABEL		04
23	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
24	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
25	0503035494	ADHESIVE LABEL LEVER BLACK HANDLE		01
26	0503035498	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0591016660	UNIQUE VACUOMETER SUPPORT		01
02	0503013584	VACUUM GAUGE		01
03	0501011643	3/8 X 1" BOLT		02
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
05	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
02	0503010267	NYLON CLAMP		01
03	0503010337	5/16" NUT		01
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
05	0503060100	INSTRUCTIONS MANUAL CANISTER		01
06	0511034152	BAG WITH INSTRUCTION MANUAL		01




Item	Code	Description	See page	QT
01	0531062350	VALVE SUPPORT		01
02	0521059704	CASAPPA TRIPLE VALVE WITH FIXING NIPLES	116	01
03	0501068706	DOUBLE CONNECTION		02
04	0531062352	SIMPLE OIL DISTRIBUTOR		01
05	0503010026	3/8" NUT		06
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
07	0503010025	3/8 SPRING WASHER		06
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		06
09	0501054694	FLOW DIVIDING VALVE ASSY	117	01
10	0503010882	BOLT		02
11	0503013759	NUT		02
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		04
13	0503013389	5/8" SELF LOCKING NUT		04
14	0501012140	FLAT WASHER		04
15	0511017303	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503019571	DIVIDER VALVE TRI-DIREC PLD20 CASAPPA BRP00095		01
02	0503010026	3/8" NUT		04
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
04	0503010025	3/8 SPRING WASHER		04
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
06	0511018014	7/8"NF X 1.1/16 UN NIPPLE		01
07	0503011109	2-119 N 3006-9B O'RING		01
08	0511010111	7/8" NIPPLE		03
09	0503010045	O'RING		03




Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503030923	3/4" UNF X 13/16UN OFS X 40 NIPPLE		03
03	0503010190	2-114 N 3006-9B O'RING		03




Item	Code	Description	See page	QT
01	0591018537	DOUBLE CONNECTION SUPPORT		01
02	0501068706	DOUBLE CONNECTION		02
03	0503010026	3/8" NUT		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0503010589	1/2" UNC SELF ADJUSTING NUT		02
08	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02




Item	Code	Description	See page	QT
01	0503019579	LED LANTERN		01
02	0591018797	LED LANTERN SUPPORT		01
03	0503011828	FLAT WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0503010019	1/2" SPRING WASHER		02
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
07	0591018872	LANTERN COVER		01
08	0503019412	RIVET SCREW INTERNAL		02
09	0503013813	1/4" UNC X 7/8" BOLT		02
10	0503010143	1/4" SPRING WASHER		02
11	0503010305	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0531051342	RAIL SUPPORT WITH FIXER	121	08
02	0591018563	RIGHT 3S TROUGH 50 X 50 X 1330		01
03	0591018565	GUTTER 3S LEFT 50 X 50 X 1330		01
04	0591018623	5S GUTTER 50 X 50 X 2200		02




Item	Code	Description	See page	QT
01	0591018525	GUTTER SUPPORT		01
02	0503011828	FLAT WASHER		02
03	0503010060	1/2 UNC G.5 ZN HEX NUT		02
04	0503010019	1/2" SPRING WASHER		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
06	0501011643	3/8 X 1"BOLT		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0531050396	SEED ENGINE SUPPORT WITH COVER	123	03
02	0531051575	FULL FERTILIZER ENGINE PLATE RIGHT LEFT	125	03
03	0531051974	MONTAGE CAIXA MODULE ECU	126	01
04	0531052048	HYDRAULIC HOSE SET 17 LINES	127	01
05	0501053834	MALE QUICK COUPLER	128	02
06	0531051353	LIFTING DRIVE ASSEMBLY	129	01
07	0503030303	SUPPORT WASHER		02
08	0501013518	FLAT WASHER		02
09	0503010237	3/8" X 1" BOLT		02
10	0511017406	FLAT WASHER Q20 X 33 X 3.00		04
11	0503013759	NUT		02
12	0503010357	8 X 20 X 1 FLAT WASHER		02
13	0503011332	5/16" X 2-3/4" BOLT		02
14	0531062331	SIDE CHASSI DUCT		04
15	0581018407	BODY FASTENER 2 DUCTS		08
16	0501011517	FLAT WASHER		04
17	0503010025	3/8 SPRING WASHER		04
18	0503010026	3/8" NUT		04
19	0503011141	3/8" X 2-3/4" BOLT		04
20	0503013493	T CONNECTION MALE		01
21	0591019675	LEFT SECONDARY GUTTER		01
22	0591019676	RIGHT SECONDARY GUTTER		01
23	0503010019	1/2" SPRING WASHER		04
24	0503010060	1/2 UNC G.5 ZN HEX NUT		04
25	0503014007	1/2" X 1-1/4" BOLT		04
26	0531050811	APT FILTER SUPPORT	130	01




Item	Code	Description	See page	QT
01	0531060543	25Z GEAR WITH		01
02	0591013338	SIDE PLATE HYDRAULIC MOTOR SEED		01
03	0503010019	1/2" SPRING WASHER		03
04	0503010060	1/2 UNC G.5 ZN HEX NUT		03
05	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
07	0503030402	PULLEY		01
08	0531019479	AXLE CHAIN GEAR		01
09	0503010237	3/8" X 1" BOLT		03
10	0503010025	3/8 SPRING WASHER		03
11	0503010026	3/8" NUT		03
12	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
13	0503012713	40-1 CHAIN X 45 LINK + MEN		01
14	0531060590	HYDRAULIC MOTOR SUPPORT		01
15	0502010175	HITCH CLAMP		01
16	0503017857	BOLT 5/8 UNF 4		02
17	0501012140	FLAT WASHER		02
18	0503010811	5/8" UNF SELF ADJUSTING NUT		02
19	0531050397	COMPLETE PROTECTION		01
19A	0531050398	ENGINE PROTECTION COVER WITH RIVET		01
19B	0503013849	1/4" UNC X 3/4" BOLT		03
19C	0503010305	FLAT WASHER		03
19D	0503010143	1/4" SPRING WASHER		03




Item	Code	Description	See page	QT
01	0591018034	SHAFT BEARING GUIDE HITCH		01
02	0503010845	501035 CLAMPING RING (FOR AXLE)		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		01
04	0591018780	SIDE TRANSMISSION SHAFT		01
05	0503010849	3/8" X 1-1/2" BOLT		04
06	0503013357	3/8 SELF-ADJUSTING NUT		04
07	0503016061	BEARING		02




Item	Code	Description	See page	QT
01	0531051558	SIDE BODY BEARING APT	124	01
02	0591018653	FERTILIZER MOTOR FIXING PLATE		01
03	0503062754	GEAR 34Z P.1/2 APT		01
04	0521069832	15Z GEAR		01
05	0503010282	1/4" X 3/4" BOLT		01
06	0503010143	1/4" SPRING WASHER		04
07	0561011665	FLAT WASHER		01
08	0503010019	1/2" SPRING WASHER		03
09	0503010060	1/2 UNC G.5 ZN HEX NUT		03
10	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
11	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
12	0561013049	CHAIN TIGHTENER AXLE		01
13	0503010302	501019 SEAL RING		01
14	0503030402	PULLEY		01
15	0531051574	ASSY FERTILIZER ENGINE COVER		01
16	0503017392	40-1 X 67 CHAIN LINK + MENDING		01
17	0591018779	AGAINST FERTILIZER MOTOR COVER		01
18	0503013849	1/4" UNC X 3/4" BOLT		01
19	0503010305	FLAT WASHER		03
20	0503013813	1/4" UNC X 7/8" BOLT		02




Item	Code	Description	See page	QT
01	0591019589	ECU MODULE BOX		01
02	0591015310	ECU MODULES BOX COVER		01
03	0591015311	MODEL BOX FIXER		02
04	0503019901	INTERNAL THREAD RIVET RM 1/4 P30S		06
05	0501011643	3/8 X 1" BOLT		04
06	0503011773	FLAT WASHER		06
07	0503010143	1/4" SPRING WASHER		06
08	0503018171	FAST LOCK ASSY		02
09	0501013518	FLAT WASHER		04
10	0503010025	3/8 SPRING WASHER		04
11	0503010026	3/8" NUT		04
12	0503010743	1/4" X 1-1/4" BOLT		06




Item	Code	Description	See page	QT
01	0521052519	HOSE 1/2 X 4200 TC-TM GRAY / RED		01
01A	0501081073	HOSE 1/2 X 4200 TC-TM		01
01B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
01C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01D	0503018952	PLASTIC BOLT		06
02	0501081862	HOSE 1/2 X 5500 TC-TR		01
03	0501080269	1/2 X 3000 TR-TC HOSE ASSY		03
04	0501080092	1/2 X 700 TR-TC HOSE		02
05	0501080062	1/2 X 2000 TR-TC HOSE		05
06	0501080157	HOSE 1/2 X 1300 TC-TC		02
07	0501082304	1/2 X 1000 TR-TC HOSE		02
08	0501080618	1/2" X 2200 TR-TC HOSE		01
09	0501080511	HOSE		01
10	0521057429	HOSE 1/2 X 6700 TR-M GRAY/BLUE		01
10A	0501080265	TR-TM HOSE ASSY		01
10B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
10C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
10D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0591018521	LIFT SENSOR DRIVER		01
02	0591018520	SENSOR SUPPORT		01
03	0503010019	1/2" SPRING WASHER		03
04	0541012143	FLAT WASHER		03
05	0501011194	1/2" X 1-3/4" BOLT		01
06	0503012682	1/2" BSW NUT		01
07	0503013356	RIVET POP 3,2 X 10,0		01
08	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0591017488	APT FILTER SUPPORT		01
02	0581019503	3/8" FASTENER		02
03	0503015135	FLAT WASHER 10 X 18 X 2		04
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04



Item	Code	Description	See page	QT
01	0503063450	INTELLIAG ISO6 KIT		01
01A	0503019526	CONTROL MODULE ISO6 6CH ADV		01
01B	0503019384	CABLE CTRL MASTER MODULE		01
01C	0503019298	MODULATE BODY		01
01D	0503015210	CABLE MODULO WSMB ISOBUS 467981200		01
01E	0503016320	ISO CONEX TRACTOR 13M CABLE		01
01F	0503015071	CONCTOR		01
01G	0503017443	ANTENNA GPS PM 400		01
01H	0503019386	MODULES "C"		01
01I	0503019385	WHIP ELETTRIC		01
01J	0503063449	CABLE 16L 45/50		01
01K	0503019616	EXTENSION CABLE		06
01L	0503019617	EXTENSION CABLE		06
01M	0513010023	EXTERNAL LIFTING CABLE		01
01N	0503018932	FLOW FERTILIZER SENSOR		16
01O	0503015218	SENSOR FOTOELE PM 400		16
01P	0503017031	CLEANING BRUSH		01
02	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	132	06
03	0511056972	FILTER HYDAC		01
04	0503019291	SUPPORT SENSOR		01
05	0521054490	FLOW DIVIDING VALVE ASSY	133	01
06	0503013100	NYLON CLAMP		85
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		**




Item	Code	Description	See page	QT
01	0503018768	MOTOR OMP 80		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02




Item	Code	Description	See page	QT
01	0503016227	FLOW DIVIDING VALVE		01
02	0503013917	O'RING 2-224		03
03	0571013917	7/8\"NF X 1.1/16 UNF NIPPLE		03

ASSEMBLY LADDER LEFT

0531050909




Item	Code	Description	See page	QT
01	0531061615	MOBILE LADDER		01
02	0531062145	LADDER GREATER RIGHT SUPPORT		01
03	0531062144	LADDER LARGER SUPPORT LEFT		01
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
08	0503010589	1/2" UNC SELF ADJUSTING NUT		02
09	0503010752	1/2" X 3.1/2" BOLT		02
10	0511065679	STAIR RIGHT LOCK		01
11	0591016037	SENSOR LOCK ROD		02
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
13	0503010337	5/16" NUT		01
14	0503010397	5/16" X 1-3/4" BOLT		01




Item	Code	Description	See page	QT
01	0503062391	FERTILIZER HOPPER	136	01
02	0521051407	FERTILIZER HOPPER FIXER	27	08
03	0531051168	LEFT SIDE SUPPORT 05 MOUTH WITH DISTRIBUTOR	137	01
04	0531050918	TOP SUPPORT MOUNTED LIFT EXTENSOR	29	02

FERTILIZER HOPPER

0503062391




Item	Code	Description	See page	QT
01	0503034127	FERTILIZER HOPPER		01
02	0503034129	LOWER HOPPER LID		01
03	0503034128	UPPER HOPPER LID		01
04	0503034130	PLATE		01
05	0503032053	BOLT C.A.S.I		04
06	0503034220	FLAT WASHER		04
07	0503034087	LID ARTICULATING TUBE		04
08	0503034088	WASHER		08
09	0503010131	3/16" X 1-1/2" COTTERPIN		08




Item	Code	Description	See page	QT
01	0521054282	BEARING	30	01
02	0503030275	AGRICULTURAL BEARING		05
03	0502012990	CONICA 14Z SQUARE GEAR		05
04	0591018303	SQUARE SHAFT 3/4 X 1740		01
05	0503011953	5/16" X 1" BOLT		20
06	0501010694	FLAT WASHER		20
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		20
08	0503010337	5/16" NUT		20
09	0531061864	SUPPORT SILO 05 MOUTH		01
10	0503010329	LOCK WASHER		02
11	0503010330	KM 9 LOCKNUT		04
12	0591015365	RING		04
13	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	34	03
14	0501053788	3/4 SQUARE AXLE FASTENER	33	02
15	0511065209	20Z GEAR		01
16	0503030303	SUPPORT WASHER		02
17	0551018055	22,65 X 60 SLEEVE		01
18	0501013519	FLAT WASHER		01
19	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	32	02
20	0591017775	ARTICULATION AXIS		02
21	0503010589	1/2" UNC SELF ADJUSTING NUT		02
22	0503011140	1/2" X 3-3/4" BOLT		02

LEFT ARM MONO WHEEL WHEEL


0531050896




Item	Code	Description	See page	QT
01	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
02	0503010019	1/2" SPRING WASHER		08
03	0503010060	1/2 UNC G.5 ZN HEX NUT		04
04	0531061431	REAR MONO WHEEL SUPPORT		01
05	0591015907	LARGER JUNCTION AXIS		02
06	0501111051	ARTICULATOR ARM		01
07	0591016194	AXLE JUNCTION		02
08	0503010007	3982/3920 ROLLER BEARING		01
09	0503010059	33287/33462 ROLLER BEARING		01
10	0503013106	SEAL 00085-B		01
11	0502040080	FLANGE NUT R.2.1/2 UN		01
12	0541013225	WHEEL BOX COVER		01
13	0503011444	SPRING WASHER		01
14	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		01
15	0503010002	1800 GREASE FITTING		01
16	0503017874	BOLT 1/2 UNC		04
17	0591016198	PIN 37,8 X 186		01
18	0501111050	REAR LIFT ARM		01
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
20	0531050023	HYDRAULIC CYLINDER 2 X 5 X 599 X 336	36	01
21	0531050897	MONO WHEEL LEFT	139	01
22	0531062131	LEFT SIDE FRAME		01
23	0591017921	BRONZE GLOVE 90.5 X 115 X 91		02
24	0551016274	HYDRAULIC CYLINDER ADAPTER		01




Item	Code	Description	See page	QT
01	0531062130	LEFT MONO WHEEL		01
02	0521059946	WHEEL ASSY WITH TIRE	38	01
03	0503019246	BOLT		01
04	0503011075	3/4" UNC NUT		01



Item	Code	Description	See page	QT
01	0591018304	FERTILIZER CONDUCTOR GUTTER		01
02	0591015578	CLAMP		05
03	0591015577	CONDUCTING TUBE		03
04	0501010942	3/8" X 1-1/4" BOLT		07
05	0503013357	3/8 SELF-ADJUSTING NUT		07
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		07
07	0591017994	SUPPORT RIGHT		01
08	0591018014	LEFT SUPPORT		01
09	0591016338	CONDUCTING TUBE		02



Item	Code	Description	See page	QT
01	0581018408	SUPPORT SCALE		08
02	0591016226	SHORT SUPPORT		02
03	0503011123	BOLT		04
04	0503013357	3/8 SELF-ADJUSTING NUT		04
05	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		02
06	0503013389	5/8" SELF LOCKING NUT		02
07	0501012140	FLAT WASHER		02
08	0531062186	SIDE FRAME DUCT		02
09	0531062185	SIDE FRAME DUCT		04



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

