

ROW CROP PLANTERS

USAP 3200 SUPREMA - FRAME 8470 - CSC/TCE/APT

Code: 0501093069
Series: S-0120
Revision: 00
Date Revision: FEVEREIRO/2023

PARTS CATALOGUE



MARCHESAN



PRODUCTS

Code	Description
0111510017	USAP 3200 SUP 8470/17E450 CSC PPH DT ESP S-0120
0111510018	USAP 3200 SUP 8470/17E450 CSC PPH DT ESP S-0120

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909095882	FRAME ASSY	1
0909095879	CHÂSSIS DROIT COMPLÈTE	2
0909095881	ASSY CENTRAL FRAME	3
0909095880	ASSY LEFT FRAME	4
0909095883	SEED LINE/ASSY FERTILIZER	5
0531051234	COMPLETE HYDRAULIC ASSEMBLY	6
0531051207	REAR HEADER 2770	7
0521059454	SIDE ARM LOCK ASSY	8
0531050017	HYDRAULIC CYLINDER 44,45 X 85,7 X 397 X 93MM	9
0531050962	SEMI-ASSEMBLED FRONT HEADER	10
0521059465	MOUNTED PANTOGRAPHIC HEADER	11
0531040499	HYDRAULIC CYLINDER 50.8 X 127 X 682 X 285	12
0521057815	HYDRAULIC HOSE SUPPORT WITH FIXATION	13
0521057739	HYDRAULIC CYLINDER 38,10 X 63,50 X 397 X 126	14
0521059886	SEMI-ASSEMBLED REST	15
0531051182	TRACK ASSEMBLY	16
0531050970	PANEL NIPLES	17
0531051206	ASSY FRENCH HAND	18
0521057793	KNEECAP WITH RIGHT EXTENSION AXLE	19
0531050966	2150 MOUNTED SIDE HANDRAIL	20
0531050908	ASSY RIGHT LADDER	21
0531051177	SILO 05 MOUTH RIGHT ASSEMBLED	21
0521051407	FERTILIZER HOPPER FIXER	22
0531051178	RIGHT SIDE SUPPORT 5B WITH DISTRIBUTORS	23
0521054282	BEARING	24
0501056444	BEARING WITH ROLLER	25
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	26
0501053788	3/4 SQUARE AXLE FASTENER	27
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	28
0531050918	TOP SUPPORT MOUNTED LIFT EXTENSOR	29
0531050940	RIGHT MONO ARM WHEEL	30
0531050023	HYDRAULIC CYLINDER 2 X 5 X 599 X 336	31
0531050941	MONO WHEEL	32
0521059946	WHEEL ASSY WITH TIRE	33
0521059728	WHEEL WITH TIRE	34
0521059947	MOUNTED CUBE	35
0531050902	MOUNTED SIDE SUPPORT	36
0531050903	SIDE ARTICULATED CYLINDER 44.45X85.70X291X657	37
0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	38
0501053566	ROW SEED BEARING	39
0531050901	ASSY STABILIZER	40
0531052026	CHAIN/ENCAPSULATED LEFT MOUNTED TRANSMISSION BOX	41
0511057159	TRANSMISSION HOPPER SEED ROW	42
0531052020	28Z CHAIN/ENCAPSULATED TRANSMISSION GEAR	43
0531052019	17Z TRANSMISSION GEAR	44
0531052021	DOUBLE GEAR 17Z X 24Z P 1/2 ASSY	45
0511055260	SEED ROW CHAIN TENSIONER	46
0521052368	STRETCHER SIMPLE SEED	47
0531051179	RIGHT SUPPORT WITH FERTILIZER GUTTER 16/17 LINES	48
0531050968	RIGHT PLUMBING ASSY	49
0521059839	ASSY REAR HEADLIGHT	50
0531051517	RIGHT ARM TRANSMISSION ASSY	51
0531050982	SIDE BODY BEARING	52
0521059838	LOCK PIN ASSY	53
0531051002	VALVE	54



MARCHESAN

INDEX

0531050002	HYDRAULIC CYLINDER 101,55X466,5X312 COURSE WITHOUT LUBRICATION	55
0521059948	ASSY LOCK AXLE	56
0531051109	FULL SIDE AIR DISTRIBUTOR	57
0521052549	CLAMP	58
0521059920	LONGER FERTILIZER LINE SMALLER DC20 ROD	59
0531052306	LINHA ADUBO LONGA MENOR	60
0521059919	SHORT FERTILIZER LINE DC20 WITHOUT ROD LUBRICATION	61
0531052307	SHORT FERTILIZER LINE WITHOUT LUBRICATION	62
0531051414	SUPER LONG LINE SPI TIRE WITHOUT FLAP CURRENT TRANSMISSION	63
0531052308	SUPER LONG LINE SPI TIRE WITHOUT FLAP CURRENT TRANSMISSION	64
0531051412	SHORT LINE SPI TIRE WITHOUT FLAP CURRENT TRANSMISSION	65
0531052287	SHORT LINE SPI TIRE WITHOUT FLAP CURRENT TRANSMISSION	66
0531051413	LONG LINE SPI TIRE WITHOUT FLAP CURRENT TRANSMISSION	67
0531052286	LONG LINE SPI TIRE WITHOUT FLAP CURRENT TRANSMISSION	68
0521057679	ASSY CUTTING DISK 20	69
0521054913	LEFT SUPPORT WITH DOC 18	70
0521054912	RIGHT SUPPORT WITH DOC 18	71
0521054915	HUB WITH DOC 18 LEFT	72
0521054914	HUB WITH DOC 18 RIGHT	73
0521054907	ASSEMBLED CENTRAL ADUBO DRIVER	74
0531052288	REAR WITH LEFT DDD SPICRR CLOSED	75
0531052301	REAR WITH RIGHT DDD SPICRR CLOSED	76
0531052302	TRASEIRA COM DDD DIREITA SPICRR DATED	77
0531052300	TRASEIRA COM DDD ESQUERDO SPICRR DATED	78
0531052304	BRACO ESQUERDO MOUNTED DATED	79
0531052303	BRACO DIREITO MOUNTED DATED	80
0521055059	WHEEL RAYED ASSY SPA WITHOUT LUBRICATION	81
0521057681	BOX WITH DISC CUTTING 20 BEARING CONICO	82
0521057680	DISC CUTTING BOX	83
0521053673	SCARIFIER ROD WITH NOZZLE	84
0521053946	SCARING ROD	85
0521059626	FRONT LINE	86
0521059627	UNIVERSAL CURRENT / CABLE BEARING	87
0531051411	REAR LEFT TIRE SPI SEM / ABA TRANSMISSION / CURRENT	88
0531050537	REAR SPI LEFT TIRE WITHOUT TAB	89
0521056632	DEPTH CONTROL	90
0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	91
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	92
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	93
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	94
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	95
0521055093	BODY COMPACTOR	96
0521055017	RIGHT COMPACTOR WHEEL	97
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	98
0521054990	LEFT COMPACTOR WHEEL	99
0531050538	MOUNTED LEFT ARM	100
0531050539	MOUNTED LEFT ARM	101
0521055056	WHEEL RAYED ASSY BAND	102
0521055073	ASSEMBLY DEPTH WHEEL HUB	103



MARCHESAN

INDEX


0521056640	PRECISION PLANTING CSC CABLE / TRANSMISSION ASSY	104
0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT PROTECTION	105
0531051264	FULL SUPPORT FOR ENCAPSULATED CURRENT FIXATION	106
0531051094	MOUNTED HOSE GUIDE ASSEMBLY	107
0531051410	REAR RIGHT TIRE SPI SEM / ABA TRANSMISSION / CURRENT	108
0531050536	REAR RIGHT SPI TIRE WITHOUT FLAP	109
0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	110
0521055869	LEFT DUAL FERTILIZER DISC	111
0521055868	RIGHT DUAL FERTILIZER DISC	112
0531051118	SINGLE CABLE 12 METERS	113
0521053173	CENTRAL SEED HOPPER 15 OUTPUTS	114
0521053175	BASE CSC HOPPER 15 OUTPUTS	115
0531051092	ASSY HOSE SUPPORT	116
0521045392	HYDRAULIC TURBINE WITH SCREEN	117
0501054983	NIPPLE HIDRAULIC MOTOR	119
0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE	120
0531051119	PRECISION PLANTING ASSEMBLED TURBINE	121
0531051120	PLANTING TURBINE WITH HOLE	122
0531050964	MOUNTED CENTRAL SUPPORT	123
0531051360	FULL LEFT WHEEL	124
0521059737	CENTRAL FORK RODEIRO	125
0521056085	PLATE BEARING ASSY	126
0521059727	WHEEL ASSY WITH TIRE	127
0521059729	MOUNTED CUBE	128
0521059723	WHEEL ASSY WITH TIRE	129
0521059599	WHEEL TRANSMISSION BOX	130
0521059736	RIGHT SIDE TRANSMISSION DRIVER	131
0531051355	LEFT WHEEL TRANSMISSION ASSY	132
0531051358	WHEEL TRANSMISSION STRETCHER	133
0531051356	STARTER TRANSMISSION ASSY LEFT 29Z	134
0531051372	RIGHT / LEFT WHEEL TRANSMISSION BOX	135
0531051359	COMPLETE RIGHT ROADWAY	136
0521059735	LEFT SIDE TRANSMISSION DRIVER	137
0531051354	RIGHT WHEEL TRANSMISSION ASSY	138
0531051357	FULL RIGHT TRANSMISSION ACTUATOR 29Z	139
0521057782	SILO 8 MOUTH CENTRAL MOUNTED	140
0521057783	CENTRAL SUPPORT 8 MOUTH	141
0531051054	RIGHT TRANSMISSION SUPPORT	142
0531051055	HUB GREATER TRANSMISSION	143
0531051063	LEFT TRANSMISSION SUPPORT	144
0531052028	LEFT SEED/FERTILIZER CHAIN/ENCAPSULATED PNEUMATIC DISTRIBUTOR EXCHANGE	145
0531052027	RIGHT SEED/FERTILIZER CHAIN/ENCAPSULATED PNEUMATIC DISTRIBUTOR EXCHANGE	146
0501048790	AXLE WITH RING	147
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	148
0501056443	GEAR HOUSING BEARING	149
0511059266	CLOSED BEARING	150
0501056271	GEARBOX CLOSED BEARING	151
0521059533	MOUNTED 21Z P 1/2 GEAR	152
0531051050	CENTRAL FERTILIZER SUPPORT	153
0531050168	ASSY CENTRAL PLATFORM 2797	154
0531050950	ASSY RIGHT ARTICULATION ARM	155
0531050935	ASSY LEFT ARTICULATION ARM	156




MARCHESAN

INDEX

0531051056	HITCH ASSY	157
0531051057	HITCH MOUNTED TRANSMISSION	158
0531051062	LEFT HITCH ASSEMBLY	159
0531050963	HYDRAULIC CYLINDER 50.8X127X760X464	160
0521059759	MOUNTED VACUOMETER ASSEMBLY	161
0531051114	ASSY AIR DISTRIBUTOR	162
0531050879	CENTRAL AIR DISTRIBUTOR	163
0531052025	CHAIN/ENCAPSULATED RIGHT MOUNTED TRANSMISSION BOX	164
0531051515	CENTRAL LEFT TRANSMISSION	165
0531051861	BEARING/TRANSMISSION SUPPORT WITH LOCK	166
0531051516	CENTRAL RIGHT TRANSMISSION	167
0531051768	MOUNTED HYDRAULIC SUPPORT	168
0521059704	CASAPPA TRIPLE VALVE WITH FIXING NIPLES	169
0501054694	FLOW DIVIDING VALVE ASSY	170
0531051769	MOUNTED DUCT SUPPORT	171
0531051788	BLOCK SUPPORT	172
0511059542	BLOCK COMMAND TURBINES	173
0531051599	LED FLASHLIGHT WITH SUPPORT	174
0531052114	ASSY PORT MANUAL INSTRUCCION	175
0531051989	ASSY ISO 6CHANNEL 17 LINHA	176
0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	177
0511056972	FILTER HYDAC	178
0521054490	FLOW DIVIDING VALVE ASSY	179
0531052050	MECHANICAL ASSEMBLY	180
0531050396	SEED ENGINE SUPPORT WITH COVER	181
0531051575	FULL FERTILIZER ENGINE PLATE RIGHT LEFT	182
0531051558	SIDE BODY BEARING APT	183
0531051974	MONTAGE CAIXA MODULE ECU	184
0531052048	HYDRAULIC HOSE SET 17 LINES	185
0501053834	MALE QUICK COUPLER	186
0531051353	LIFTING DRIVE ASSEMBLY	187
0531051464	LABEL ASSY 8470/17L	188
0531051475	GUTTER ASSEMBLY 17E450	189
0531051342	RAIL SUPPORT WITH FIXER	190
0531050909	ASSEMBLY LADDER LEFT	191
0531051167	SILLO 5 MOUTHS LEFT MOUNTED	192
0531051168	LEFT SIDE SUPPORT 05 MOUTH WITH DISTRIBUTOR	193
0531050896	LEFT ARM MONO WHEEL WHEEL	194
0531050897	MONO WHEEL LEFT	195
0531051169	RIGHT SUPPORT WITH FERTILIZER GUTTER	196
0531050943	LEFT PLUMBING ASSY	197
0531051518	LEFT ARM ENCAPSULATED CURRENT TRANSMISSION ASSY	198



Item	Code	Description	See page	QT
01	0909095879	CHÂSSIS DROIT COMPLÈTE	2	01
02	0909095881	ASSY CENTRAL FRAME	3	01
03	0909095880	ASSY LEFT FRAME	4	01
04	0531041074	ASSY HEADER		01
05	0531051206	ASSY FRENCH HAND	18	02
06	0531061069	FRONT HAND FRENCH AXLE		02
07	0531061650	FRONT HAND FRENCH AXLE		02
08	0501017779	32 X 60 X 4.75 FLAT WASHER		04
09	0503011052	1.1/4" X 0.77" CASTLE NUT		04
10	0503010038	3/16 X 2 COTTERPIN		04
11	0531051234	COMPLETE HYDRAULIC ASSEMBLY	6	01




Item	Code	Description	See page	QT
01	0531062298	RIGHT SIDE FRAME 2485		01
02	0531061865	SIDE PLATFORM 2180		01
03	0531050966	2150 MOUNTED SIDE HANDRAIL	20	01
04	0531050908	ASSY RIGHT LADDER	21	01
05	0531051177	SILO 05 MOUTH RIGHT ASSEMBLED	21	01
06	0531050940	RIGHT MONO ARM WHEEL	30	01
07	0591016192	GLOVE 102 X 85.50 X 111		02
08	0591018042	FRICTION PLATE		02
09	0591015962	SEPARATOR GLOVE		04
10	0501010453	FLAT WASHER		06
11	0503010027	5/8 SPRING WASHER		07
12	0503010962	5/8" X 1-1/4" BOLT		06
13	0591018049	RIGHT COVER AXLE DEPOSIT		01
14	0503010237	3/8" X 1" BOLT		02
15	0501013518	FLAT WASHER		07
16	0503010025	3/8 SPRING WASHER		07
17	0503010026	3/8" NUT		07
18	0531050902	MOUNTED SIDE SUPPORT	36	02
19	0531050901	ASSY STABILIZER	40	02
20	0531062317	SEED LINES / FERTILIZER 2000 FIXING TUBE		02
21	0531052026	CHAIN/ENCAPSULATED LEFT MOUNTED 41 TRANSMISSION BOX	41	01
22	0591014453	HEX AXLE 3/4 X 2000		01
23	0511063123	BUSHING WITH NUT		04
24	0501018535	1/2 X 1 BOLT		04
25	0531051179	RIGHT SUPPORT WITH FERTILIZER GUTTER 16/17 48 LINES	48	01
26	0503014007	1/2" X 1-1/4" BOLT		06
27	0503010019	1/2" SPRING WASHER		06
28	0503010060	1/2 UNC G.5 ZN HEX NUT		06
29	0503030195	2" X 2" X 12.2" HOSE		10mts
30	0503010246	CLAMP		22

Item	Code	Description	See page	QT
31	0531061866	SIDE AIR SUPPORT EXTENDER		01
32	0531050968	RIGHT PLUMBING ASSY	49	01
33	0521059839	ASSY REAR HEADLIGHT	50	01
34	1164920015	BLACK SUCTION HOSE		31mts
35	0531051517	RIGHT ARM TRANSMISSION ASSY	51	01
36	0503032984	HOOD HEX AXLE ROW		02
37	0503010071	3/16" X 1" COTTERPIN		02
38	0503019271	SELF LUBRICATING BUSHING		02
39	0591018050	EXTERNAL RIGHT COVER		01
40	0503010371	5/16" X 1" BOLT		02
41	0501010694	FLAT WASHER		04
42	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
43	0503010337	5/16" NUT		04
44	0521059838	LOCK PIN ASSY	53	01
45	0531051002	VALVE	54	01
46	0503011141	3/8" X 2-3/4" BOLT		01
47	0591018046	HEX SHAFT BODY TR SEED 5/8 X 585		01
48	0531050002	HYDRAULIC CYLINDER 101,55X466,5X312 COURSE WITHOUT LUBRICATION	55	01
49	0501111058	ASSY FIXING GLOVE		02
50	0503011336	1/2" HEX SELF ADJUSTING NUT		06
51	0503011082	C1/2" X 1.3/4" SCREW		06
52	0591015374	HITCH AXIS		01
53	0503010232	5/8" X 1.3/4" BOLT		01
54	0511010721	FLAT WASHER		01
55	0511057159	TRANSMISSION HOPPER SEED ROW	42	01
56	0521059948	ASSY LOCK AXLE	56	01
57	0591018045	FRICTION TRACK		01
58	0591018044	WASHER 65 X 130 X 20		01
59	0591018043	BODY SUPPORT		02
60	0531051109	FULL SIDE AIR DISTRIBUTOR	57	01
61	0521052549	CLAMP	58	12
62	0591015332	AXLE JUNCTION LOCK		01
63	0503010880	501032 CLAMPING RING (FOR AXLE)		01
64	0503011372	102 TO 121 CLAMP		01
65	0503034867	AIR DISTRIBUTOR PUMP		01
66	0591018541	SWIVEL CYLINDER COVER		02
67	0591018540	CABLE SUPPORT		01
68	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		02
69	1164920014	BLACK LIGHT SUCTION HOSE		7.0mts
70	0501010942	3/8" X 1-1/4" BOLT		04
71	0909095851	SEED LINE/ASSY FERTILIZER		06

ASSY CENTRAL FRAME

0909095881



Item	Code	Description	See page	QT
001	0531062146	CENTRAL FRAME 7 LINES 450		01
002	0531051118	SINGLE CABLE 12 METERS	113	01
003	0531050964	MOUNTED CENTRAL SUPPORT	123	02
004	0531051360	FULL LEFT WHEEL	124	01
005	0531051359	COMPLETE RIGHT ROADWAY	136	01
006	0521057782	SILO 8 MOUTH CENTRAL MOUNTED	140	01
007	0531062221	CENTRAL SUPPORT SILO		01
008	0531062223	RIGHT CENTRAL SILO SUPPORT		01
009	0531062222	RIGHT CENTRAL SILO SUPPORT		01
010	0531051054	RIGHT TRANSMISSION SUPPORT	142	01
011	0531051063	LEFT TRANSMISSION SUPPORT	144	01
012	0531052028	LEFT SEED/FERTILIZER CHAIN/ENCAPSULATED PNEUMATIC DISTRIBUTOR EXCHANGE	145	01
013	0531052027	RIGHT SEED/FERTILIZER CHAIN/ENCAPSULATED PNEUMATIC DISTRIBUTOR EXCHANGE	146	01
014	0591018046	HEX SHAFT BODY TR SEED 5/8 X 585		02
015	0531051050	CENTRAL FERTILIZER SUPPORT	153	01
016	0511057159	TRANSMISSION HOPPER SEED ROW	42	02
017	0531050168	ASSY CENTRAL PLATFORM 2797	154	01
018	0531050950	ASSY RIGHT ARTICULATION ARM	155	01
019	0531050935	ASSY LEFT ARTICULATION ARM	156	01
020	0531051056	HITCH ASSY	157	01
021	0531051062	LEFT HITCH ASSEMBLY	159	01
022	0531050963	HYDRAULIC CYLINDER 50.8X127X760X464	160	02
023	0521011100	FLAT WASHER		04
024	0531062245	233 CYLINDER JOINT AXIS		02
025	0503010834	1/2 X 1 BOLT		02
026	0503010019	1/2" SPRING WASHER		06
027	0531051002	VALVE	54	02
028	0591015906	MOTOR AXLE		01
029	0591018162	GLOVE 17 X 28 X 24		06
030	0503010060	1/2 UNC G.5 ZN HEX NUT		04

ASSY CENTRAL FRAME

0909095881

Item	Code	Description	See page	QT
031	0503014007	1/2" X 1-1/4" BOLT		04
032	0503010246	CLAMP		28
033	0503010027	5/8 SPRING WASHER		12
034	0503010013	5/8 NUT		12
035	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		06
036	0503010023	3/4" SPRING WASHER		02
037	0503010014	3/4" HEX NUT		02
038	0501010098	3/4" UNC BOLT		02
039	0503010233	5/8" X 2-1/2" BOLT		06
040	0511063123	BUSHING WITH NUT		12
041	0501018535	1/2 X 1 BOLT		12
042	0521059759	MOUNTED VACUOMETER ASSEMBLY	161	01
043	0591016307	HEX SHAFT 3/4 X 1100		01
043.	0571018910	3/4 X 1505 AXLE HEX		01
044	0503010237	3/8" X 1" BOLT		02
045	0503010025	3/8 SPRING WASHER		02
046	0503010026	3/8" NUT		02
047	0503011179	3/8" X 2-1/4" BOLT		02
048	0503010071	3/16" X 1" COTTERPIN		04
049	0503032984	HOOD HEX AXLE ROW		04
050	0521059839	ASSY REAR HEADLIGHT	50	01
051	0503063384	SEED / FERTILIZER TRANSMISSION SHAFT		04
052	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		08
053	0503014876	NUT PARLOCK 1/4"		08
054	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		02
055	0531062289	PLATFORM SUPPORT		02
056	0501013519	FLAT WASHER		04
057	0503010589	1/2" UNC SELF ADJUSTING NUT		04
058	0503014378	1/2" X 1-1/2" BOLT		04
059	0531051114	ASSY AIR DISTRIBUTOR	162	01
060	0531050879	CENTRAL AIR DISTRIBUTOR	163	01
061	0521052549	CLAMP	58	14
062	0503011372	102 TO 121 CLAMP		04
063	0503012724	121 TO 140 CLAMP		02
064	0531060782	REAR CENTRAL TUBE FIXING SEED LINES		02
065	0531052026	CHAIN/ENCAPSULATED LEFT MOUNTED 41		01
066	0531052025	CHAIN/ENCAPSULATED RIGHT MOUNTED 164		01
067	0503019222	BRACELET TYPE WIRE 3.2MM X 48 X 63 MM		05
068	0531051515	CENTRAL LEFT TRANSMISSION	165	01
069	0501013518	FLAT WASHER		02
070	0531051516	CENTRAL RIGHT TRANSMISSION	167	01
071	0531051768	MOUNTED HYDRAULIC SUPPORT	168	01
072	0531051769	MOUNTED DUCT SUPPORT	171	01
073	0531051788	BLOCK SUPPORT	172	01
074	0531051599	LED FLASHLIGHT WITH SUPPORT	174	02
075	0591018540	CABLE SUPPORT		01
076	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
077	0503010337	5/16" NUT		02
078	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		02
079	0503030195	2" X 2" X 12.2" HOSE		14
080	1164920014	BLACK LIGHT SUCTION HOSE		10 mts
081	1164920015	BLACK SUCTION HOSE		25 mts
082	1163920004	BLACK LIGHT SUCTION HOSE		9,5 mts
083	1163920006	SPIRAL MANG		02 mts
084	1164920017	BLUE PVC FLAT HOSE		02 mts
085	0531052114	ASSY PORT MANUAL INSTRUCCION	175	01
086	0503010019	1/2" SPRING WASHER		04


ASSY CENTRAL FRAME

0909095881

Item	Code	Description	See page	QT
087	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
088	0501047895	25 ROD STOP		04
089	0501047885	30 ROD STOP		08
090	0501047886	35 ROD STOP		04
091	0501047887	40 ROD STOP		08
092	0581012482	TRANSPORT LATCH		04
093	0501068994	8,30 X 78 LOCK PIN		04
094	0503030168	HITCH PIN CLIP		04
095	0503032624	FERTILIZER HOPPER GUTTER		06
096	0503011750	AMENDMENT WITH LOCK		06
097	0503011751	REDUCTION		06
098	0503019869	CLAMP		05
099	0531051989	ASSY ISO 6CHANNEL 17 LINHA	176	01
100	0531052050	MECHANICAL ASSEMBLY	180	01
101	0531051464	LABEL ASSY 8470/17L	188	01
102	0513010044	CORD LIGHTHOUSE LANTERN		01
103	0531051475	GUTTER ASSEMBLY 17E450	189	01
104	0909095851	SEED LINE/ASSY FERTILIZER		16

ASSY LEFT FRAME

0909095880




Item	Code	Description	See page	QT
01	0531061862	LEFT SIDE FRAME		01
02	0531061865	SIDE PLATFORM 2180		01
03	0531050966	2150 MOUNTED SIDE HANDRAIL	20	01
04	0531050909	ASSEMBLY LADDER LEFT	191	01
05	0531051167	SILO 5 MOUTHS LEFT MOUNTED	192	01
06	0531050896	LEFT ARM MONO WHEEL WHEEL	194	01
07	0591016192	GLOVE 102 X 85.50 X 111		02
08	0591018042	FRICTION PLATE		02
09	0591015962	SEPARATOR GLOVE		04
10	0501010453	FLAT WASHER		06
11	0503010027	5/8 SPRING WASHER		07
12	0503010962	5/8" X 1-1/4" BOLT		06
13	0591018051	LEFT COVER AXLE DEPOSIT		01
14	0503010237	3/8" X 1" BOLT		02
15	0501013518	FLAT WASHER		07
16	0503010025	3/8 SPRING WASHER		07
17	0503010026	3/8" NUT		07
18	0531050902	MOUNTED SIDE SUPPORT	36	02
19	0531050901	ASSY STABILIZER	40	02
20	0531062317	SEED LINES / FERTILIZER 2000 FIXING TUBE		02
21	0531052025	CHAIN/ENCAPSULATED RIGHT MOUNTED 164 TRANSMISSION BOX		01
22	0591014453	HEX AXLE 3/4 X 2000		01
23	0511063123	BUSHING WITH NUT		04
24	0501018535	1/2 X 1 BOLT		04
25	0531051169	RIGHT SUPPORT WITH FERTILIZER GUTTER	196	01
26	0503014007	1/2" X 1-1/4" BOLT		06
27	0503010019	1/2" SPRING WASHER		06
28	0503010060	1/2 UNC G.5 ZN HEX NUT		06
29	0503030195	2" X 2" X 12.2" HOSE		10
30	0503010246	CLAMP		24
31	0531061866	SIDE AIR SUPPORT EXTENDER		01

ASSY LEFT FRAME


0909095880

Item	Code	Description	See page	QT
32	0531050943	LEFT PLUMBING ASSY	197	01
33	0521059839	ASSY REAR HEADLIGHT	50	01
34	1164920015	BLACK SUCTION HOSE		31 mts
35	0531051518	LEFT ARM ENCAPSULATED TRANSMISSION ASSY	CURRENT 198	01
36	0503032984	HOOD HEX AXLE ROW		02
37	0503010071	3/16" X 1" COTTERPIN		02
38	0503019271	SELF LUBRICATING BUSHING		02
39	0591018052	EXTERNAL LEFT COVER		01
40	0503010371	5/16" X 1" BOLT		02
41	0501010694	FLAT WASHER		04
42	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
43	0503010337	5/16" NUT		04
44	0521059838	LOCK PIN ASSY	53	01
45	0531051002	VALVE	54	01
46	0503011141	3/8" X 2-3/4" BOLT		01
47	0591018046	HEX SHAFT BODY TR SEED 5/8 X 585		01
48	0531050002	HYDRAULIC CYLINDER 101,55X466,5X312 COURSE WITHOUT LUBRICATION	55	01
49	0501111058	ASSY FIXING GLOVE		02
50	0503011336	1/2" HEX SELF ADJUSTING NUT		06
51	0503011082	C1/2" X 1.3/4" SCREW		06
52	0591015374	HITCH AXIS		01
53	0503010232	5/8" X 1.3/4" BOLT		01
54	0511010721	FLAT WASHER		01
55	0511057159	TRANSMISSION HOPPER SEED ROW	42	01
56	0521059948	ASSY LOCK AXLE	56	01
57	0591018045	FRICTION TRACK		02
58	0591018044	WASHER 65 X 130 X 20		01
59	0591018043	BODY SUPPORT		02
60	0531051109	FULL SIDE AIR DISTRIBUTOR	57	01
61	0521052549	CLAMP	58	11
62	0591015332	AXLE JUNCTION LOCK		01
63	0503010880	501032 CLAMPING RING (FOR AXLE)		01
64	0503011372	102 TO 121 CLAMP		01
65	0503034867	AIR DITRIBUTOR PUMP		01
66	0591018541	SWIVEL CYLINDER COVER		02
67	0591018540	CABLE SUPPORT		01
68	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		02
69	1164920014	BLACK LIGHT SUCTION HOSE		7,0 mts
70	0501010942	3/8" X 1-1/4" BOLT		04
71	0909095851	SEED LINE/ASSY FERTILIZER		06



Item	Code	Description	See page	QT
01	0521059920	LONGER FERTILIZER LINE SMALLER DC20 ROD	59	01
02	0521059919	SHORT FERTILIZER LINE DC20 WITHOUT ROD LUBRICATION	61	01
03	0531052306	LINHA ADUBO LONGA MENOR	60	01
04	0531052307	SHORT FERTILIZER LINE WITHOUT LUBRICATION	62	01
05	0531051414	SUPER LONG LINE SPI TIRE WITHOUT FLAP CURRENT TRANSMISSION	63	01
06	0531051412	SHORT LINE SPI TIRE WITHOUT FLAP CURRENT TRANSMISSION	65	01
07	0531051413	LONG LINE SPI TIRE WITHOUT FLAP CURRENT TRANSMISSION	67	01
08	0531052308	SUPER LONG LINE SPI TIRE WITHOUT FLAP CURRENT TRANSMISSION	64	01
09	0531052287	SHORT LINE SPI TIRE WITHOUT FLAP CURRENT TRANSMISSION	66	01
10	0531052286	LONG LINE SPI TIRE WITHOUT FLAP CURRENT TRANSMISSION	68	01
11	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
12	0521055869	LEFT DUAL FERTILIZER DISC	111	01
13	0521055868	RIGHT DUAL FERTILIZER DISC	112	01
14	0502012815	DOUBLE-DISC SPACING PLATE		01
15	0511018662	SPACING PLATE		01
16	0502070085	FIXED ROD BEARING		01
17	0503030391	RIGHT FERTILIZER NOZZLE		01
18	0503030392	LEFT FERTILIZER NOZZLE		01
19	0581014070	FERTILIZER NOZZLE		01
20	0503031050	CURVED CONDUCTOR		01
21	0503031826	CURVED CONDUCTOR		01
22	0503031145	2" X 2" X 20" HOSE		01
23	0521068982	DISC BLADE HUB KEY		01
24	0503010246	CLAMP		01
25	0503031076	2" HOSE CLAMP		01

Item	Code	Description	See page	QT
26	0503011402	0.2" X 0.8" SPRING PIN		01
27	0503016853	SPRING PIN		01
28	0503010479	BOLT		01
29	0503010019	1/2" SPRING WASHER		01
30	0503010060	1/2 UNC G.5 ZN HEX NUT		01
31	0531013600	PRESS ADJUSTMENT LEVER		01
32	0521053946	SCARING ROD	85	01
33	0521053673	SCARIFIER ROD WITH NOZZLE	84	01
34	0591016141	LONG LINE COMPLEMENT		01
35	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
36	0503010479	BOLT		02
37	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
38	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
39	0503010025	3/8 SPRING WASHER		02
40	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0531051800	FULL LIFT HOSE ASSY		01
01A	0501080451	3/8" X 94.5" TR-TC HOSE ASSY		02
01B	0501080453	3/8" X 102" TR-TR HOSE ASSY		02
01C	0501080445	TR-TM HOSE ASSY		01
01D	0501080321	3/8" X 47" TR-TR HOSE ASSY		02
01E	0501080150	3/8 X 800 TR-TC HOSE		02
01F	0501080359	3/8" X 78.7" TR-TC HOSE ASSY		02
01G	0501080427	3/8" X 60" TR-TR HOSE ASSY		02
01H	0501080413	3/8" X 27" TR-TC HOSE		02
01I	0501080507	3/8" X 21.6" TR-TC HOSE ASSY		02
01J	0501080700	3/8 X 650 TC-TC HOSE		04
01K	0501080842	HOSE 1/2 X 4500 TR-TC		02
01L	0501080016	1/2 X 2800 TR-TC HOSE		01
01M	0501081041	1/2 X 2400 TR-TC HOSE		01
01N	0501080740	1/2" X 12" TC-TM HOSE ASSY		02
02	0531051801	HOSE JOINT FULL CLOSURE SET		01
02A	0501080413	3/8" X 27" TR-TC HOSE		02
02B	0501080150	3/8 X 800 TR-TC HOSE		02
02C	0501080388	3/8 X 4300 TR-TC HOSE ASSY		02
02D	0501080720	HOSE 3/8 X 3500 TR-TC		02
02E	0501080473	3/8" X 120" TC-TM HOSE		02
03	0531051802	FULL SWING HOSE ASSY		01
03A	0501080451	3/8" X 94.5" TR-TC HOSE ASSY		04
03B	0501080413	3/8" X 27" TR-TC HOSE		02
03C	0501080348	3/8 X 1200 TR-TC HOSE		02
03D	0501080715	3/8" X 177" TR-TC HOSE ASSY		02
03E	0501080453	3/8" X 102" TR-TR HOSE ASSY		02
03F	0501080473	3/8" X 120" TC-TM HOSE		02
04	0531051803	FULL HOSE LOCKS ASSY		01
04A	0501080720	HOSE 3/8 X 3500 TR-TC		02
04B	0501080301	3/8 X 1300 TC-TC HOSE		02

COMPLETE HYDRAULIC ASSEMBLY

0531051234


Item	Code	Description	See page	QT
04C	0501080465	3/8 X 400 TR-TC HOSE ASSY		01
04D	0501080445	TR-TM HOSE ASSY		01
04E	0501080150	3/8 X 800 TR-TC HOSE		01
05	0531051804	HOSE LINES ASSY KIT		01
05A	0501080451	3/8" X 94.5" TR-TC HOSE ASSY		04
05B	0501080055	3/8 X 1000 TR-TC HOSE		04
05C	0501080302	3/8 X 1400 TR-TC HOSE		02
05D	0501080485	3/8 X 1100 TR-TC HOSE		04
05E	0501080065	3/8 X 1200 TC-TC HOSE		04
05F	0501080715	3/8" X 177" TR-TC HOSE ASSY		02
05G	0501080469	3/8" X 98.42" TR-TR HOSE ASSY		02
06	0531051805	ASSY HOSE 2 TURBINES KIT		01
06A	0501080314	HOSE 1/2 X 3300 TR-TR		02
06B	0501080016	1/2 X 2800 TR-TC HOSE		02
06C	0501080286	HOSE 1/2 X 6200 TR-TM		02
06D	0501080447	3/8" X 122" TR-TC HOSE ASSY		01
06E	0501080414	3/8" X 110.2" TR-TC HOSE ASSY		01
06F	0501080825	1/2" X 1100 TR-TC HOSE		02
06G	0501080733	HOSE 3/8 X 6200 TR-TM		01
06H	0501081407	1/2 X 3100 TR-TC HOSE		02
07	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		06
08	0503034494	HYDRAULIC HOSE GRIP (BLUE)		04
09	0503034495	HYDRAULIC HOSE GRIP (RED)		04
10	0503034492	HYDRAULIC HOSE GRIP (BLACK)		04
11	0503018952	PLASTIC BOLT		54




Item	Code	Description	See page	QT
01	0531062310	REAR HEAD BODY		01
02	0591015434	NYLON ADJUSTABLE BACK HEAD		04
03	0591015433	HEADER SUPPORT		04
04	0591015533	ADJUSTMENT SUPPORT		04
05	0503014007	1/2" X 1-1/4" BOLT		24
06	0503010019	1/2" SPRING WASHER		48
07	0503010002	1800 GREASE FITTING		08
08	0501010276	BOLT		14
09	0503010012	1" SPRING WASHER		14
10	0503012182	1" NUT		14
11	0591015435	NYLON ADJUSTMENT REGULATOR GUIDE		04
12	0591015432	HEAD ADJUSTMENT SUPPORT PLATE		04
13	0521059454	SIDE ARM LOCK ASSY	8	01
14	0591015431	HEADER ADJUSTMENT SUPPORT		04
15	0503011401	1/2" X 3/4" BOLT		24

SIDE ARM LOCK ASSY

0521059454




Item	Code	Description	See page	QT
01	0591015326	LATERAL FRAME LOCK	02	
02	0531061411	STABILIZER ASSY LOCK ARM	01	
03	0591015327	AXLE JUNCTION	02	
04	0591015328	SPACING GLOVE	04	
05	0591015329	CYLINDER GUIDE AXLE	01	
06	0591015330	WASHER SUPPORT	02	
07	0591015332	AXLE JUNCTION LOCK	03	
08	0591015333	SUPPORT GLOVE	02	
09	0503019522	HEX NUT	04	
10	0501010164	3/4" X 7 BOLT	02	
11	0501010322	FLAT WASHER	10	
12	0503010880	501032 CLAMPING RING (FOR AXLE)	05	
13	0531061445	TOP PLATE WITH GLOVE	02	
14	0503014007	1/2" X 1-1/4" BOLT	02	
15	0503010019	1/2" SPRING WASHER	02	
16	0591015341	GLOVE SUPPORT	04	
17	0591015340	WASHER SUPPORT GUIDE AXIS	01	
18	0511016281	3/4" X 8" BOLT	02	
19	0531050017	HYDRAULIC CYLINDER 44,45 X 85,7 X 397 X 93MM	9	01



Item	Code	Description	See page	QT
01	0531061421	CASE 85,7 X 272		01
02	0591015343	EXTENSOR 44,45 X 280MM		01
03	0503010063	1" SELF-ALIGNING NUT		01
04	0502010843	1.8" X 3.4" PISTON		01
05	0503010042	2-214 N 3006-9B O'RING		01
06	0503010170	PACKING 3120 2750		02
07	0503010948	W4-3346-590 PK RING G.E		01
08	0502040747	32.54 CLEVIS CLAMP		01
09	0503011094	3/8" X 2" BOLT		01
10	0503010025	3/8 SPRING WASHER		01
11	0503010026	3/8" NUT		01
12	0502010781	RING SUPPORT		01
13	0503010949	W2-2000-500 PK RING G.E		01
14	0503010990	GASKET		01
15	0503010761	D-1750 SCRAPER RING		01
16	0503010976	2-336 N 3006-9B O'RING		01
17	0503011060	8-336 BACK-UP RING		01
18	0502010993	DETACHABLE COVER		01
19	0503030385	CYLINDER PLUG N-002		02

SEMI-ASSEMBLED FRONT HEADER

0531050962



Item	Code	Description	See page	QT
01	0521059470	ROLLER HEADER		01
01A	0591015445	HEAD ROLLER BODY		01
01B	0551014862	NYLON PULLEY		02
02	0521059471	INTERNAL PULLEY HEADER		02
02A	0591015446	INTERNAL PULLEY BODY HEADER		01
02B	0551014862	NYLON PULLEY		02
03	0551014871	FLAT WASHER		06
04	0503010002	1800 GREASE FITTING		06
05	0591015447	INTERNAL PULLEY AXIS		01
06	0503011105	SEAL RING		03
07	0531061443	FRONT TELESCOPIC HEADER		01
08	0591015448	SIDE ROLLER AXLE HEADER		02
09	0591015449	AXLE LOCK HEADER		01
10	0503018754	1-8 UNC NUT		02
11	0591015450	LOCK BODY GLOVE		02
12	0591015451	BODY LOCK		02
13	0501010888	1.3/4" 2.5/16" CASTLE NUT		01
14	0591015452	BODY AXLE LOCK		01
15	0591015453	BACK WASHER		02
16	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
17	0511054270	TENSIONER SPRING		01
17A	0511069520	TELESC LOCK SPRING TENSIONER		01
17B	0503010013	5/8 NUT		02
18	0591015454	SPRING HITCH LOCK		01
19	0591015455	CYLINDER GUIDE AXLE		01
20	0591015456	CYLINDER GUIDE AXLE		01
21	0521011132	FLAT WASHER		02
22	0503010131	3/16" X 1-1/2" COTTERPIN		02
23	0521059465	MOUNTED PANTOGRAPHIC HEADER	11	01
24	0521057815	HYDRAULIC HOSE SUPPORT WITH FIXATION	13	01
25	0521058345	SAFETY CHAIN WITH SHACKLE		01


SEMI-ASSEMBLED FRONT HEADER

0531050962


Item	Code	Description	See page	QT
25A	0503014120	CHAIN		01
25B	0503014321	CABLE STEEL SHACKLE		02
26	0503011052	1.1/4" X 0.77" CASTLE NUT		03
27	0503010038	3/16 X 2 COTTERPIN		03
28	0531060748	REST SUPPORT		01
29	0531060746	AXIS 278 TELESCOPIC HEADER		03
30	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		02
31	0531060747	TELESCOPIC HOSE GUIDE		01
32	0521057739	HYDRAULIC CYLINDER 38,10 X 63,50 X 397 X 126	14	01
33	0591015457	CYLINDER GUIDE AXLE		01
34	0503010019	1/2" SPRING WASHER		04
35	0503010060	1/2 UNC G.5 ZN HEX NUT		04
36	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		04
37	0521059886	SEMI-ASSEMBLED REST	15	01

MOUNTED PANTOGRAPHIC HEADER


0521059465




Item	Code	Description	See page	QT
01	0531061422	SUPERIOR ARM PANTOGRAPHIC HEADER		01
02	0531061759	LOWER ARM PANTOGRAPHIC HEADER		01
03	0531060745	PANTOGRAPHIC ARM EAR		02
04	0502040864	GEAR BOX WITH REGULATOR		01
05	1902040327	LOCK SLEEVE		01
06	0503010523	1/4" X 2" COTTERPIN		01
07	0503010002	1800 GREASE FITTING		03
08	0521063432	LOCK AXLE		02
09	0503031035	HITCH PIN CLIP		02
10	0531060746	AXIS 278 TELESCOPIC HEADER		02
11	0531060792	AXIS 200 TELESCOPIC HEADER		01
12	0531060776	HYDRAULIC HOSE SUPPORT FIXER		01
13	0503011052	1.1/4" X 0.77" CASTLE NUT		02
14	0503010038	3/16 X 2 COTTERPIN		03
15	0521010578	COUPLING SHAFT		01
16	0531040499	HYDRAULIC CYLINDER 50.8 X 127 X 682 X 285	12	01
17	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		02
18	0502040223	DRAWBOLT		01
19	1902040733	U COUPLING HOOK		01
20	0521012545	COUPLING SHAFT		01
21	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
22	0503010010	1/4" X 2.1/2" COTTERPIN		01




Item	Code	Description	See page	QT
01	0531061425	PANTOGRAPHIC HEAD CYLINDER CASE		01
02	0531061424	PANTOGRAPHIC HEAD CYLINDER ROD		01
03	0503010817	1.1/4" SELF LOCKING NUT		01
04	0503010345	2-218 N 3006-9B O'RING		01
05	0502010382	5" END CAP		01
06	0581010353	RING SUPPORT		01
07	0503018026	1870-2000-375 B GASKET		01
08	0503011453	O'RING		02
09	0503018152	O'RING		02
10	0503018024	RING BS		01
11	0503018025	RING GUIDE		01
12	0581010354	PISTON		01
13	0503018150	RING GUIDE		01
14	0503018151	RING BS		02
15	0503010039	D-2000 SCRAPER RING		01
16	0503030385	CYLINDER PLUG N-002		02



Item	Code	Description	See page	QT
01	0531060794	HYDRAULIC HOSE SUPPORT		01
02	0503015490	SELF-LOCKING NUT 7/16		02
03	0503011173	7/16" X 2" BOLT		02
04	0501010937	13,50 X 28 X 3,00 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0531060718	CASE 63,50 X 285MM		01
02	0531060719	GUIA CILINDRO		01
03	0591013120	BODY STEM 38.10 X 280		01
04	0502012837	PISTON		01
05	0581010668	RING SUPPORT		01
06	0502010471	63,50 MOBILE CAP		01
07	0503018005	RING		01
08	0503011109	2-119 N 3006-9B O'RING		01
09	0503018004	RING		01
10	0503018003	GASKET		01
11	0503010163	D-1500 SCRAPER RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
01	0503010571	1/4" X 1.1/2 COTTERPIN		02
02	0521010784	COUPLING SHAFT		01
03	0531060758	AXLE JUNCTION 25.4 X 150 WITH HANDLE		01
04	0503030085	LOCK PIN		02
05	0531060667	REST		01
06	0521010580	COUPLING SHAFT		01
07	0521012533	COUPLING SHAFT		01
08	0591016111	TUBE 80 X 80 X 9,52 X 600MM		01
09	0531061640	REST		01

TRACK ASSEMBLY


0531051182




Item	Code	Description	See page	QT
01	0591018020	RIGHT SIDE SUPPORT		01
02	0591018021	LEFT SIDE SUPPORT		01
03	0531062201	REAR RAIL		01
04	0531062202	FRONT GUTTER		01
05	0591018022	GUTTER SUPPORT		01
06	0591018018	ARTICULATOR AXIS		02
07	0591018019	ARTICULATOR AXIS		01
08	0503014007	1/2" X 1-1/4" BOLT		06
09	0503010019	1/2" SPRING WASHER		06
10	0501013519	FLAT WASHER		06
11	0501012140	FLAT WASHER		04
12	0503010027	5/8 SPRING WASHER		04
13	0503010013	5/8 NUT		04
14	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		04




Item	Code	Description	See page	QT
01	0501011643	3/8 X 1" BOLT		04
02	0503013357	3/8 SELF-ADJUSTING NUT		04
03	0591015908	NIPLES PLATE		01
04	0591018028	NIPPLES 7/8 UNF X 7/8 UNF X 65 HEXAGONAL 1.1/8		04
05	0591018027	NIPPLE FIXING NUT R.7 / 8 UNF X 14		04
06	0541012165	3/4" NIPPLE		03
07	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		03
08	0591018026	GUTTER SUPPORT		01



Item	Code	Description	See page	QT
01	0521057793	KNEECAP WITH RIGHT EXTENSION AXLE	19	01
02	0531062309	FRENCH HAND 3267		01
03	0531061434	SIDE EXTENSOR EAR		01
04	0571019949	JUNCTION SHAFT		01
05	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0521062617	NUT FIXER		01
02	0531060778	EXTENSION AXLE 466 WITH DRAG		01
03	0561019879	LOCK ATTACHMENT BAR		01
04	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0531061863	SIDE HANDRAIL 2150		01
02	0503014007	1/2" X 1-1/4" BOLT		04
03	0501010937	13,50 X 28 X 3,00 FLAT WASHER		08
04	0503011336	1/2" HEX SELF ADJUSTING NUT		04
05	0503011957	NYLON LUG		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
08	0503010337	5/16" NUT		04

ASSY RIGHT LADDER


0531050908




Item	Code	Description	See page	QT
01	0531061615	MOBILE LADDER		01
02	0531062142	LOWER RIGHT LADDER SUPPORT		01
03	0531062143	HIGHER LEFT STAIRCASE SUPPORT		01
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8\" NUT		04
06	0503010751	C3/8\" X 1.1/4\" HEX BOLT G.5		04
07	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
08	0503010589	1/2\" UNC SELF ADJUSTING NUT		02
09	0503010752	1/2\" X 3.1/2\" BOLT		02
10	0511065678	STAIR RIGHT LOCK		01
11	0591016037	SENSOR LOCK ROD		02
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
13	0503010337	5/16\" NUT		01
14	0503010397	5/16\" X 1-3/4\" BOLT		01



Item	Code	Description	See page	QT
01	0503062391	FERTILIZER HOPPER		01
02	0521051407	FERTILIZER HOPPER FIXER	22	08
03	0531051178	RIGHT SIDE SUPPORT 5B WITH DISTRIBUTORS	23	01
04	0531050918	TOP SUPPORT MOUNTED LIFT EXTENSOR	29	02




Item	Code	Description	See page	QT
01	0503012531	3/8" INOX NUT		01
02	0503012535	3/8" SPRING WASHER		01
03	0571019051	FIXER HOPPER WASHER		01
04	0503013751	3/8 UNC X 1.1/4 BOLT		01




Item	Code	Description	See page	QT
01	0521054282	BEARING	24	01
02	0503030275	AGRICULTURAL BEARING		05
03	0591018303	SQUARE SHAFT 3/4 X 1740		01
04	0503011953	5/16" X 1" BOLT		20
05	0501010694	FLAT WASHER		18
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		18
07	0503010337	5/16" NUT		18
08	0531061864	SUPPORT SILO 05 MOUTH		01
09	0503010329	LOCK WASHER		02
10	0503010330	KM 9 LOCKNUT		04
11	0591015365	RING		04
12	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	26	03
13	0503030303	SUPPORT WASHER		02
14	0511065209	20Z GEAR		01
15	0501053788	3/4 SQUARE AXLE FASTENER	27	01
16	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	28	02
17	0591017775	ARTICULATION AXIS		02
18	0503010589	1/2" UNC SELF ADJUSTING NUT		02
19	0503011140	1/2" X 3-3/4" BOLT		02
20	0502012990	CONICA 14Z SQUARE GEAR		05

BEARING

0521054282




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	25	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01

RIGHT SIDE FERTILIZER DISTRIBUTOR


0511051535



Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01

3/4 SQUARE AXLE FASTENER


0501053788




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01

LEFT SIDE FERTILIZER DISTRIBUTOR

0511051558




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501012140	FLAT WASHER		08
02	0503010811	5/8" UNF SELF ADJUSTING NUT		04
03	0503018814	SCREW 5/8 UNF X 5" G.5 CS ZN		04
04	0531062173	LIFT EXTENSOR TOP SUPPORT		01
05	1902011170	FIXER		02

RIGHT MONO ARM WHEEL

0531050940




Item	Code	Description	See page	QT
01	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
02	0503010019	1/2" SPRING WASHER		08
03	0503010060	1/2 UNC G.5 ZN HEX NUT		04
04	0531061431	REAR MONO WHEEL SUPPORT		01
05	0591015907	LARGER JUNCTION AXIS		02
06	0501111051	ARTICULATOR ARM		01
07	0591016194	AXLE JUNCTION		02
08	0503010007	3982/3920 ROLLER BEARING		01
09	0503010059	33287/33462 ROLLER BEARING		01
10	0503013106	SEAL 00085-B		01
11	0502040080	FLANGE NUT R.2.1/2 UN		01
12	0541013225	WHEEL BOX COVER		01
13	0503011444	SPRING WASHER		06
14	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
15	0503010002	1800 GREASE FITTING		01
16	0503017874	BOLT 1/2 UNC		04
17	0591016198	PIN 37,8 X 186		01
18	0501111050	REAR LIFT ARM		01
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
20	0531050023	HYDRAULIC CYLINDER 2 X 5 X 599 X 336	31	01
21	0531050941	MONO WHEEL	32	01
22	0591017921	BRONZE GLOVE 90.5 X 115 X 91		02
23	0531062180	RIGHT SIDE FRAME		01
24	0551016274	HYDRAULIC CYLINDER ADAPTER		01




Item	Code	Description	See page	QT
01	0531061565	CASE WITH TERMINAL 127 X 490		01
02	0581010353	RING SUPPORT		01
03	0503018026	1870-2000-375 B GASKET		01
04	0503011453	O'RING		02
05	0503018152	O'RING		02
06	0503018024	RING BS		01
07	0503018025	RING GUIDE		01
08	0503010039	D-2000 SCRAPER RING		01
09	0502040876	COVER		01
10	0503010817	1.1/4" SELF LOCKING NUT		01
11	0581010354	PISTON		01
12	0503018150	RING GUIDE		01
13	0503018151	RING BS		02
14	0531061566	HYDRAULIC CYLINDER ROD 50.8 X 570.5		01
15	0503010002	1800 GREASE FITTING		01

MONO WHEEL

0531050941




Item	Code	Description	See page	QT
01	0531062179	RIGHT MONO WHEEL		01
02	0521059946	WHEEL ASSY WITH TIRE	33	01
03	0503019246	BOLT		01
04	0503011075	3/4" UNC NUT		01



Item	Code	Description	See page	QT
01	0521059728	WHEEL WITH TIRE	34	01
02	0521059947	MOUNTED CUBE	35	01

WHEEL WITH TIRE


0521059728



Item	Code	Description	See page	QT
01	0503019598	TIRE 11.5 / 80 -15.3 16PR REINF IM-04 TT MI		01
02	0503019599	AIR CAMERA 11.5 / 80 -15.3 TR 15		01
03	0503035060	WHEEL 9.00 X 15.3		01

MOUNTED CUBE


0521059947




Item	Code	Description	See page	QT
01	0502011389	BOX		01
02	0503010006	32210 ROLLER BEARING		01
03	0503010005	32212 ROLLER BEARING		01
04	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
05	0503010002	1800 GREASE FITTING		01
06	0503010064	5/8 UNF CONIC NUT		06
07	0503011866	SEAL 00573-B WITH HOLE		01
08	0501010888	1.3/4" 2.5/16" CASTLE NUT		01
09	0503010010	1/4" X 2.1/2" COTTERPIN		01
10	0502020593	COVER		01
11	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		01
12	0591016195	WHEEL AXIS		01

MOUNTED SIDE SUPPORT


0531050902




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		02
02	0503017857	BOLT 5/8 UNF 4		08
03	0503010811	5/8" UNF SELF ADJUSTING NUT		08
04	0551019514	3/8 FASTENER		02
05	0531050903	SIDE ARTICULATED CYLINDER 37 44.45X85.70X291X657		01
06	0591017796	ARTICULATION AXIS 222 R.1.1 / 4 UNF		01
07	0531062134	UNIVERSAL SUPPORT		01
08	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
09	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
10	0503010019	1/2" SPRING WASHER		04
11	0501111070	SIDE SUPPORT ARTICULATOR		01
12	0503011075	3/4" UNC NUT		06
13	0501010125	3/4" X 2-1/2" BOLT		06
14	0591013172	31.75 X126 AXLE WITH 8 HOLE		02
15	0591013173	CYLINDER INTERMEDIATE BUSHING		02
16	0503012231	1/4" X 3" COTTERPIN		02
17	0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	38	02
18	0503010026	3/8" NUT		04
19	0503010025	3/8 SPRING WASHER		04
20	0501011544	3/4" X 1-1/2" BOLT		01
21	0503010023	3/4" SPRING WASHER		01
22	0511017232	FLAT WASHER		01
23	0591018408	PIN LOCK LINES		01
24	0503030085	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531062138	CASE 85,7 X 486 WITH COVER		01
02	0503010761	D-1750 SCRAPER RING		01
03	0571019711	RING SUPPORT		01
04	0571019709	DETACHABLE COVER		01
05	0503017936	RING		01
06	0503017938	RING GUIDE		01
07	0503017937	GASKET		01
08	0503017940	8-337 BACK-UP RING		02
09	0503017939	2-337 N 3006-9B O' RING		02
10	0503018045	2-130 (AGEL) O'RING		04
11	0511064408	FORK		01
12	0503010025	3/8 SPRING WASHER		01
13	0503011094	3/8" X 2" BOLT		01
14	0503010026	3/8" NUT		01
15	0503010042	2-214 N 3006-9B O'RING		01
16	0503010063	1" SELF-ALIGNING NUT		01
17	0571019710	1.7" X 3.4" PISTON		01
18	0503017935	RING		01
19	0503018144	RING		01
20	0591017818	EXTENSOR 44,45 X 550		01




Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING	39	01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012030	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		01
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0502011195	ADJUSTMENT NUT BODY		01
02	0503010002	1800 GREASE FITTING		02
03	0551013654	SPINDLE R.1.1 / 4 X R.1.1 / 2 RIGHT X 165		01
04	0502040747	32.54 CLEVIS CLAMP		01
05	0551013653	SPINDLE R.1.1 / 4 X LEFT X.1.1 / 2 X 165		01
06	0503011094	3/8" X 2" BOLT		01
07	0503010026	3/8" NUT		01
08	0503011443	3/8" SPRING WASHER		01
09	0501061056	RH LOCKNUT WITH HANDLER		01
10	0531062137	SIDE FERTILIZER BOX EXTENSOR		01
11	0521010779	31.75 X 95 COUPLING SHAFT		01
12	0503010571	1/4" X 1.1/2 COTTERPIN		01




Item	Code	Description	See page	QT
01	0531062633	RIGHT SIDE CURRENT/ENCAPSULATED TRANSMISSION		01
02	0531062634	LEFT SIDE CURRENT/ENCAPSULATED TRANSMISSION		01
03	0591019647	TRANSMISSION AXIS GREATER		01
04	0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	38	01
05	0511057159	TRANSMISSION HOPPER SEED ROW	42	01
06	0531052020	28Z CHAIN/ENCAPSULATED TRANSMISSION GEAR	43	01
07	0591015357	HEX SHAFTED GUIDE 3/4 X 195		01
08	0503010237	3/8" X 1" BOLT		04
09	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
10	0503010025	3/8 SPRING WASHER		04
11	0591016053	SUPPORT PLATE		01
12	0531052019	17Z TRANSMISSION GEAR	44	01
13	0531052021	DOUBLE GEAR 17Z X 24Z P 1/2 ASSY	45	01
14	0511055260	SEED ROW CHAIN TENSIONER	46	01
15	0521052368	STRETCHER SIMPLE SEED	47	01
16	0503012391	40-1 CHAIN X 83 LINK + MENDING		01
17	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		01
18	0591019650	LEFT CHAIN COVER CHAIN/ENCAPSULATED		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503010707	501030 CLAMPING RING (FOR AXLE)		01
02	0531062632	GEAR 25Z X 45 HEXAGONAL HOLE 19,80 / 20		01
03	0503012861	6006 2RS BALL BEARING		01
04	0502012030	HOUSING BEARING		01
05	0503011953	5/16" X 1" BOLT		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0503010707	501030 CLAMPING RING (FOR AXLE)		01
02	0531062631	GEAR 17Z HEX HOLE 19,80 / 20		01
03	0503012861	6006 2RS BALL BEARING		01
04	0502012030	HOUSING BEARING		01
05	0503011953	5/16" X 1" BOLT		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531062635	DOUBLE GEAR 17Z X 24Z P1/2		01
02	0503019355	BEARING 6202 2RS1		02
03	0591019653	AXIS GEAR DOUBLE		01
04	0503010237	3/8" X 1" BOLT		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
06	0503010025	3/8 SPRING WASHER		01
07	0503012104	501015 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0581016479	CURRENT STRETCH SHAFT 81		01
02	0503030402	PULLEY		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0591018304	FERTILIZER CONDUCTOR GUTTER	01	
02	0591015578	CLAMP	05	
03	0591015577	CONDUCTING TUBE	03	
04	0501010942	3/8" X 1-1/4" BOLT	07	
05	0503013357	3/8 SELF-ADJUSTING NUT	07	
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER	07	
07	0591018014	LEFT SUPPORT	01	
08	0591016338	CONDUCTING TUBE	02	
09	0591017994	SUPPORT RIGHT	01	




Item	Code	Description	See page	QT
01	0581018408	SUPPORT SCALE		08
02	0591016226	SHORT SUPPORT		02
03	0503011123	BOLT		04
04	0503013357	3/8 SELF-ADJUSTING NUT		04
05	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		02
06	0503013389	5/8" SELF LOCKING NUT		02
07	0501012140	FLAT WASHER		02
08	0531062186	SIDE FRAME DUCT		02
09	0531062185	SIDE FRAME DUCT		04



Item	Code	Description	See page	QT
01	0591016055	REAR HEADLIGHT SUPPORT		01
02	0503018738	HEADLIGHT		01
03	0503010337	5/16" NUT		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		02




Item	Code	Description	See page	QT
01	0531062208	TRANSMISSION RIGHT SUPPORT		01
02	0591018040	SEPARATING GLOVE 16.5 X 32 X 70		03
03	0503013389	5/8" SELF LOCKING NUT		03
04	0531050982	SIDE BODY BEARING	52	02
05	0501010163	5/8" X 4-1/2" BOLT		03
06	0591018038	DRAGGLE GLOVE		01
07	0591018039	HEX SHAFT 3/4 X 750 CENTRAL AND SIDE		01
08	0503063380	SIDE ENCAPSULATED CHAIN		01
09	0503030303	SUPPORT WASHER		01
10	0501013518	FLAT WASHER		01
11	0503010237	3/8" X 1" BOLT		01
12	0511017406	FLAT WASHER Q20 X 33 X 3.00		02
13	0503010882	BOLT		02
14	0503013759	NUT		02




Item	Code	Description	See page	QT
01	0503011081	6207 2RS BEARING		02
02	0591018034	SHAFT BEARING GUIDE HITCH		01
03	0503010845	501035 CLAMPING RING (FOR AXLE)		01
04	0503010370	502072 CLAMPING RING (FOR AXLE)		01
05	0591018033	SIDE TRANSMISSION AXIS		01
06	0503010849	3/8" X 1-1/2" BOLT		04
07	0503013357	3/8 SELF-ADJUSTING NUT		04

LOCK PIN ASSY


0521059838




Item	Code	Description	See page	QT
01	0591016056	LOCK AXLE SUPPORT		01
02	0531061626	38 X 308 JUNCTION AXLE WITH HANDLE		02
03	0503030119	LOCK PIN		02
04	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
05	0503013389	5/8" SELF LOCKING NUT		01
06	0501010453	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0503013622	VALVE ASSY		01
02	0511010111	7/8" NIPPLE		02
03	0503011030	2-014 N 3006-9B O'RING		01
04	0503010045	O'RING		02
05	0501012109	3/4" X 9/16" NIPPLE FITTING		01



Item	Code	Description	See page	QT
01	0581010302	RING OF SUPPORT		01
02	0502012822	101.60 END CAP		01
03	0503011061	8-342 BACK-UP RING		02
04	0503010338	2-342 N 3006-9B O'RING		02
05	0503017936	RING		01
06	0503017938	RING GUIDE		01
07	0503017937	GASKET		01
08	0503010761	D-1750 SCRAPER RING		01
09	0503018045	2-130 (AGEL) O'RING		04
10	0503030387	PLUG		02
11	0531061461	CASE 101.6 X 466.5 WITHOUT LUBRICATION		01
12	0531061460	ROTATING CYLINDER ROD		01
13	0581010837	PISTON		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503015633	SELEMASTER SEALING		01
16	0503018029	2-217 O'RING		01




Item	Code	Description	See page	QT
01	0502040080	FLANGE NUT R.2.1/2 UN		01
02	0503010002	1800 GREASE FITTING		01
03	0531061664	LOCK AXIS		01




Item	Code	Description	See page	QT
01	0531062275	SIDE DISTRIBUTOR FIXER		01
02	0531062274	SIDE AIR DISTRIBUTOR		01
03	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
04	0503010589	1/2" UNC SELF ADJUSTING NUT		04

CLAMP


0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0503011255	3/4" LOCK NUT		02
02	0571019062	SLEEVE		01
03	0571019059	SUPPORT WASHER		01
04	0503034320	COMPRESSSSION SPRING		01
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503011854	5/8" X 1-1/4" BOLT		02
07	0521010066	3/4" X 8.12" BOLT		02
08	0503017960	5/8" X 3-12" BOLT		04
09	0502012813	FLANGE WASHER SPRING		01
10	0531062203	REGULATOR SPRING LINE FERTILIZER		01
11	0503010417	7/8" NUT		02
12	0502012789	FIXER SUPPORT FERTILIZER ROW		01
13	0591011146	SUPPORT LONG		01
14	0531061648	LONG ARM LOWER FERTILIZER LINE		01
15	0591011147	SLEEVE ARM ROW		02
16	0503019278	LUBRICANT SLEEVE		02
17	0503011109	2-119 N 3006-9B O'RING		02
18	0503011254	7/8" HEX SELF ADJUSTING NUT		01
19	0521057679	ASSY CUTTING DISK 20	69	01
20	0581014070	FERTILIZER NOZZLE		01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
23	0503010025	3/8 SPRING WASHER		02
24	0503010026	3/8" NUT		02
25	0591016141	LONG LINE COMPLEMENT		02
26	0521053673	SCARIFIER ROD WITH NOZZLE	84	01
27	0503010019	1/2" SPRING WASHER		04
28	0503010060	1/2 UNC G.5 ZN HEX NUT		04
29	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
30	0503010479	BOLT		02
31	0511018662	SPACING PLATE		04




Item	Code	Description	See page	QT
01	0503011255	3/4" LOCK NUT		02
02	0571019062	SLEEVE		01
03	0571019059	SUPPORT WASHER		01
04	0503034320	COMPRESSION SPRING		01
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503011854	5/8" X 1-1/4" BOLT		02
07	0521010066	3/4" X 8.12" BOLT		02
08	0503017960	5/8" X 3-12" BOLT		04
09	0502012813	FLANGE WASHER SPRING		01
10	0531062203	REGULATOR SPRING LINE FERTILIZER		01
11	0503010417	7/8" NUT		02
12	0502012789	FIXER SUPPORT FERTILIZER ROW		01
13	0591011146	SUPPORT LONG		01
14	0531061648	LONG ARM LOWER FERTILIZER LINE		01
15	0591011147	SLEEVE ARM ROW		02
16	0503019278	LUBRICANT SLEEVE		02
17	0503011109	2-119 N 3006-9B O'RING		02
18	0503011254	7/8" HEX SELF ADJUSTING NUT		01
19	0521057679	ASSY CUTTING DISK 20	69	01
20	0521054913	LEFT SUPPORT WITH DOC 18	70	01
21	0521054907	ASSEMBLED CENTRAL ADUBO DRIVER	74	01




Item	Code	Description	See page	QT
01	0503011255	3/4" LOCK NUT		02
02	0571019062	SLEEVE		01
03	0571019059	SUPPORT WASHER		01
04	0503034320	COMPRESSSION SPRING		01
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503011854	5/8" X 1-1/4" BOLT		02
07	0521010066	3/4" X 8.12" BOLT		02
08	0503017960	5/8" X 3-12" BOLT		04
09	0502012813	FLANGE WASHER SPRING		01
10	0531062203	REGULATOR SPRING LINE FERTILIZER		01
11	0503010417	7/8" NUT		02
12	0502012789	FIXER SUPPORT FERTILIZER ROW		01
13	0591011145	FERTILIZER ROW SUPPORT		01
14	0503019278	LUBRICANT SLEEVE		02
15	0591011147	SLEEVE ARM ROW		02
16	0503011109	2-119 N 3006-9B O'RING		02
17	0581014070	FERTILIZER NOZZLE		01
18	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
19	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
20	0503010026	3/8" NUT		02
21	0521053946	SCARING ROD	85	01
22	0521065972	LH SHORT ARM ROW FERTILIZER		01
23	0503011254	7/8" HEX SELF ADJUSTING NUT		01
24	0521057679	ASSY CUTTING DISK 20	69	01
25	0503010025	3/8 SPRING WASHER		02
26	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
27	0503010019	1/2" SPRING WASHER		02
28	0503010060	1/2 UNC G.5 ZN HEX NUT		02
29	0511018662	SPACING PLATE		02




Item	Code	Description	See page	QT
01	0503011255	3/4" LOCK NUT		02
02	0571019062	SLEEVE		01
03	0571019059	SUPPORT WASHER		01
04	0503034320	COMPRESSSION SPRING		01
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503011854	5/8" X 1-1/4" BOLT		02
07	0521010066	3/4" X 8.12" BOLT		02
08	0503017960	5/8" X 3-12" BOLT		04
09	0502012813	FLANGE WASHER SPRING		01
10	0531062203	REGULATOR SPRING LINE FERTILIZER		01
11	0503010417	7/8" NUT		02
12	0502012789	FIXER SUPPORT FERTILIZER ROW		01
13	0591011145	FERTILIZER ROW SUPPORT		01
14	0503019278	LUBRICANT SLEEVE		02
15	0591011147	SLEEVE ARM ROW		02
16	0503011109	2-119 N 3006-9B O'RING		02
17	0521065972	LH SHORT ARM ROW FERTILIZER		01
18	0521054907	ASSEMBLED CENTRAL ADUBO DRIVER	74	01
19	0521054912	RIGHT SUPPORT WITH DOC 18	71	01
20	0521057679	ASSY CUTTING DISK 20	69	01




Item	Code	Description	See page	QT
01	0521059626	FRONT LINE	86	01
02	0521059627	UNIVERSAL CURRENT / CABLE BEARING	87	01
03	0531051411	REAR LEFT TIRE SPI SEM / ABA TRANSMISSION / CURRENT	88	01
04	0531060405	EXTENSION		01
05	0503012136	NUT 1/2 NF		04
06	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
07	0503063397	SUPER LONG ENCAPSULATED CHAIN		01
08	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	107	01
09	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
10	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521059626	FRONT LINE	86	01
02	0521059627	UNIVERSAL CURRENT / CABLE BEARING	87	01
03	0531052288	REAR WITH LEFT DDD SPICRR CLOSED	75	01
04	0531060405	EXTENSION		01
05	0503012136	NUT 1/2 NF		04
06	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
07	0503063398	SUPREME LONG SUPREME ENCAPSULATED CHAIN		01
08	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	107	01
09	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
10	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521059626	FRONT LINE	86	01
02	0521059627	UNIVERSAL CURRENT / CABLE BEARING	87	01
03	0531051410	REAR RIGHT TIRE SPI SEM / ABA TRANSMISSION / CURRENT	108	01
04	0503063399	SHORT ENCAPSULATED CHAIN		01
05	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	107	01
06	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
07	0503012880	1/4" UNC SELF ADJUSTING NUT		02



Item	Code	Description	See page	QT
01	0521059626	FRONT LINE	86	01
02	0521059627	UNIVERSAL CURRENT / CABLE BEARING	87	01
03	0531052301	REAR WITH RIGHT DDD SPICRR CLOSED	76	01
04	0503063399	SHORT ENCAPSULATED CHAIN		01
05	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	107	01
06	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
07	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521059626	FRONT LINE	86	01
02	0521059627	UNIVERSAL CURRENT / CABLE BEARING	87	01
03	0531051411	REAR LEFT TIRE SPI SEM / ABA TRANSMISSION / CURRENT	88	01
04	0531061136	EXTENSION		01
05	0503012136	NUT 1/2 NF		04
06	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
07	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	107	01
08	0503063400	LONG ENCAPSULATED CHAIN		01
09	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
10	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521059626	FRONT LINE	86	01
02	0521059627	UNIVERSAL CURRENT / CABLE BEARING	87	01
03	0531052288	REAR WITH LEFT DDD SPICRR CLOSED	75	01
04	0531061136	EXTENSION		01
05	0503012136	NUT 1/2 NF		04
06	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
07	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	107	01
08	0503063400	LONG ENCAPSULATED CHAIN		01
09	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
10	0503012880	1/4" UNC SELF ADJUSTING NUT		02

ASSY CUTTING DISK 20


0521057679




Item	Code	Description	See page	QT
01	0531060662	MONO ARM DISC CUTTING		01
02	0531060661	ARM SUPPORT		01
03	0571019034	FLANGE WASHER AXLE		01
04	0571019032	SUPPORT WASHER		01
05	0502012813	FLANGE WASHER SPRING		01
06	0591010619	DC SPRING SUPPORT		01
07	0503019274	WASHER		02
08	0581017628	LID		02
09	0503034320	COMPRESSION SPRING		01
10	0591010625	19,50 X 25 X 91,50/91,30 SLEEVE		01
11	0503010417	7/8" NUT		02
12	0503010390	SEAL RING		02
13	0503011198	C3/4" X 6" SCREW		01
14	0503011255	3/4" LOCK NUT		01
15	0503030430	7/16 X 2" PIN LOCK		01
16	0503019271	SELF LUBRICATING BUSHING		01
17	0503011254	7/8" HEX SELF ADJUSTING NUT		01
18	0531061481	MONO SPRING DISC CUTTING REGULATOR		01
19	0591011144	FIXATION AXLE		01
20	0591010628	DC AXIS BACKREST WASHER		01
21	0503019272	LUBRICANT SLEEVE		02
22	0521057681	BOX WITH DISC CUTTING 20 BEARING CONICO	82	01
23	0503012412	5/8 UNC SELF LOCKING NUT		01
24	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01




Item	Code	Description	See page	QT
01	0521069504	DOC DISC ARM		01
02	0581011838	SLEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2 UNC G.5 ZN HEX NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503016063	ROLLER BEARING		01
10	0503030832	FLAT WASHER		01
11	0521054915	HUB WITH DOC 18 LEFT	72	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0521069504	DOC DISC ARM		01
02	0581011838	SLEEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2 UNC G.5 ZN HEX NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503016063	ROLLER BEARING		01
10	0503030832	FLAT WASHER		01
11	0521054914	HUB WITH DOC 18 RIGHT	73	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0503011800	SEAL RING		01
02	0503012417	SEAL		01
03	0503016063	ROLLER BEARING		01
04	0503030832	FLAT WASHER		01
05	0502020641	BLADE DISC FLANGE		01
06	0607025032	PLAIN COULTER BLADE		01
07	0503010371	5/16" X 1" BOLT		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0503010337	5/16" NUT		06
10	0581019304	DISC HUB		01




Item	Code	Description	See page	QT
01	0503011800	SEAL RING		01
02	0503012417	SEAL		01
03	0503016063	ROLLER BEARING		01
04	0503030832	FLAT WASHER		01
05	0502020641	BLADE DISC FLANGE		01
06	0607025032	PLAIN COULTER BLADE		01
07	0503010371	5/16" X 1" BOLT		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0503010337	5/16" NUT		06
10	0581019304	DISC HUB		01




Item	Code	Description	See page	QT
01	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
02	0503010060	1/2 UNC G.5 ZN HEX NUT		01
03	0503010019	1/2" SPRING WASHER		01
04	0503030483	FERTILIZER SOCKET		01
05	0503031050	CURVED CONDUCTOR		01
06	0503010246	CLAMP		01
07	0571019645	CONDUCTOR SUPPORT		01
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01



Item	Code	Description	See page	QT
01	0531052300	TRASEIRA COM DDD ESQUERDO SPICRR DATED	78	01
02	0521056640	PRECISION PLANTING CSC CABLE / 104		01
03	0503062403	TUBE SEED P.P		01
04	0571017895	PIN FIXER CONDUCTOR P.P		01
05	0503010140	1/8" X 3/4" COTTERPIN		01
06	0591017565	SEED CONDUCTOR GUIDE		01
07	0503015341	POP RIVET		02
08	0531051264	FULL SUPPORT FOR ENCAPSULATED CURRENT 106		01
		FIXATION		




Item	Code	Description	See page	QT
01	0531052302	TRASEIRA COM DDD DIREITA SPICRR DATED	77	01
02	0521056640	PRECISION PLANTING CSC CABLE / 104		01
03	0503062403	TUBE SEED P.P		01
04	0571017895	PIN FIXER CONDUCTOR P.P		01
05	0503010140	1/8" X 3/4" COTTERPIN		01
06	0591017565	SEED CONDUCTOR GUIDE		01
07	0503015341	POP RIVET		02
08	0531051264	FULL SUPPORT FOR ENCAPSULATED CURRENT 106 FIXATION		01



Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0521056632	DEPTH CONTROL	90	01
03	0502012920	SUPPORT ADJUSTING		01
04	0502012611	DEPTH CONTROL AXLE		01
05	0591011309	ADJUSTMENT BUSHING		02
06	0591011310	ADJUSTMENT BAR		02
07	0503019275	SLEEVE LUBRICATION SYSTEM		01
08	0581019473	ARTICULATED SLEEVE		02
09	0503010045	O'RING		02
10	0503013357	3/8 SELF-ADJUSTING NUT		02
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
12	0591011326	LOCK PIN		01
13	0571015326	ARTICULATION SLEEVE HANDLE		01
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503010060	1/2 UNC G.5 ZN HEX NUT		02
16	0503010019	1/2" SPRING WASHER		04
17	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
18	0501011445	FLAT WASHER		04
19	0503012556	1/2" X 1" BOLT		02
20	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
21	0591011306	ADJUSTMENT LOCK		02
22	0503012136	NUT 1/2 NF		04
23	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
24	0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	110	01
25	0521055093	BODY COMPACTOR	96	01
26	0521055017	RIGHT COMPACTOR WHEEL	97	01
27	0521054990	LEFT COMPACTOR WHEEL	99	01
28	0531052304	BRACO ESQUERDO MOUNTED DATED	79	01
29	0531052303	BRACO DIREITO MOUNTED DATED	80	01
30	0503010131	3/16" X 1-1/2" COTTERPIN		02
31	0591016900	BEATING AXLE		01




Item	Code	Description	See page	QT
32	0591011323	AXLE ARTICULATION WHEEL DEPTH		02
33	0591016907	SPACER GLOVE 14MM		06
34	0591016988	SPICER PROTECTOR		01
35	0503030012	HITCH PIN CLIP		02




Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0521056632	DEPTH CONTROL	90	01
03	0502012920	SUPPORT ADJUSTING		01
04	0502012611	DEPTH CONTROL AXLE		01
05	0591011309	ADJUSTMENT BUSHING		02
06	0591011310	ADJUSTMENT BAR		02
07	0503019275	SLEEVE LUBRICATION SYSTEM		01
08	0581019473	ARTICULATED SLEEVE		02
09	0503010045	O'RING		02
10	0503013357	3/8 SELF-ADJUSTING NUT		02
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
12	0591011326	LOCK PIN		01
13	0571015326	ARTICULATION SLEEVE HANDLE		01
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503010060	1/2 UNC G.5 ZN HEX NUT		02
16	0503010019	1/2" SPRING WASHER		04
17	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
18	0501011445	FLAT WASHER		04
19	0503012556	1/2" X 1" BOLT		02
20	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
21	0591011306	ADJUSTMENT LOCK		02
22	0503012136	NUT 1/2 NF		04
23	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
24	0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	91	01
25	0521055093	BODY COMPACTOR	96	01
26	0521055017	RIGHT COMPACTOR WHEEL	97	01
27	0521054990	LEFT COMPACTOR WHEEL	99	01
28	0531052304	BRACO ESQUERDO MOUNTED DATED	79	01
29	0531052303	BRACO DIREITO MOUNTED DATED	80	01
30	0503010131	3/16" X 1-1/2" COTTERPIN		02
31	0591016900	BEATING AXLE		01




Item	Code	Description	See page	QT
32	0591016905	DEPTH WHEEL JOINT AXLE		02
33	0591016907	SPACER GLOVE 14MM		06
34	0591016988	SPICER PROTECTOR		01
35	0503030012	HITCH PIN CLIP		02




Item	Code	Description	See page	QT
01	0502012927	LEFT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 81 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01
07	0561016889	STRIPED CAP WHEEL DEPTH		01



Item	Code	Description	See page	QT
01	0502012926	RIGHT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 81 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01
07	0561016889	STRIPED CAP WHEEL DEPTH		01




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503030891	RUBBER BAND		01
03	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
05	0503010337	5/16" NUT		06
06	0521055073	ASSEMBLY DEPTH WHEEL HUB	103	01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521057680	DISC CUTTING BOX	83	01

DISC CUTTING BOX

0521057680




Item	Code	Description	See page	QT
01	0503010370	502072 CLAMPING RING (FOR AXLE)	02	
02	0502020641	BLADE DISC FLANGE	01	
03	0503018825	5/16 UNC UNC BOLT	06	
04	0503013816	5/16" LOCKNUT	06	
05	0501010694	FLAT WASHER	06	
06	0502012862	DISC BLADE HUB	01	
07	0511017907	1/8" BSPT X 6 PLUG	02	
08	0503019285	RING	02	
09	0503010590	00674-B SEAL	02	
10	0591012836	CUTTING DISC AXLE	01	
11	0502040872	REGULATORY NUT	01	
12	0503012170	30207 ROLLER BEARING	02	
13	0503010812	7/8" UNF SELF LOCKING NUT	01	
14	0501010067	22.5 X 56 X 4.75 FLAT WASHER	01	
15	0503019283	SCREW 7/8 UNF X 6.1/4	01	




Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER ROD		01
02	0503011402	0.2" X 0.8" SPRING PIN		02
03	0503016853	SPRING PIN		02
04	0502040869	FIXED ROD BEARING		01

SCARING ROD


0521053946




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070085	FIXED ROD BEARING		01
03	0513010288	ELASTIC PIN 701211 10 X 24		02
04	0513010289	ELASTIC PIN 701211 10 X 24		02




Item	Code	Description	See page	QT
01	0531060663	FRONT FRAME SEED LINE	01	
02	0531061428	REAR LINE	01	
03	0503030168	HITCH PIN CLIP	05	
04	0571018883	PIN FIXER SPRING	02	
05	0503034198	SPRING TRACTION 40 X 198 X 5,5	01	
06	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
07	0502012812	SEED ROW ADJUSTMENT LEVER ASSY	01	
08	0591011156	PIVOT ARM SEED ROW	02	
09	0503017857	BOLT 5/8 UNF 4	04	
10	0501012140	FLAT WASHER	04	
11	0503010811	5/8\" UNF SELF ADJUSTING NUT	04	
12	0503019273	AUTO LUBRICANT SLEEVE	08	
13	0503010045	O'RING	08	
14	0591012829	SPACER LOWER SLEEVE	08	
15	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
16	0503012412	5/8 UNC SELF LOCKING NUT	04	
17	0591012827	FRONT PENDULUM LINE	01	
18	0591012828	LOCK PIN ROW ARTICULAT	01	
19	0501219536	LINE GUTTER	01	
20	0501310623	SPRING FIXING PIN	02	



Item	Code	Description	See page	QT
01	0531061496	BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503019373	6006 2RS1 NATIONAL BEARING		01
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0581019823	BEARING AXLE BODY WITHOUT LUBRICATION		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		01
09	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
10	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0531050537	REAR SPI LEFT TIRE WITHOUT TAB	89	01
02	0521056640	PRECISION PLANTING CSC CABLE / 104	104	01
03	0503062403	TUBE SEED P.P		01
04	0571017895	PIN FIXER CONDUCTOR P.P		01
05	0503010140	1/8" X 3/4" COTTERPIN		01
06	0591017565	SEED CONDUCTOR GUIDE		01
07	0503015341	POP RIVET		02
08	0531051264	FULL SUPPORT FOR ENCAPSULATED CURRENT 106	106	01
		FIXATION		




Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0521056632	DEPTH CONTROL	90	01
03	0502012920	SUPPORT ADJUSTING		01
04	0502012611	DEPTH CONTROL AXLE		01
05	0591011309	ADJUSTMENT BUSHING		02
06	0591011310	ADJUSTMENT BAR		02
07	0503019275	SLEEVE LUBRICATION SYSTEM		01
08	0581019473	ARTICULATED SLEEVE		02
09	0503010045	O'RING		02
10	0503013357	3/8 SELF-ADJUSTING NUT		02
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
12	0591011326	LOCK PIN		01
13	0571015326	ARTICULATION SLEEVE HANDLE		01
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503010060	1/2 UNC G.5 ZN HEX NUT		02
16	0503010019	1/2" SPRING WASHER		04
17	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
18	0501011445	FLAT WASHER		04
19	0503012556	1/2" X 1" BOLT		02
20	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
21	0591011306	ADJUSTMENT LOCK		02
22	0503012136	NUT 1/2 NF		04
23	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
24	0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	91	01
25	0521055093	BODY COMPACTOR	96	01
26	0521055017	RIGHT COMPACTOR WHEEL	97	01
27	0521054990	LEFT COMPACTOR WHEEL	99	01
28	0531050538	MOUNTED LEFT ARM	100	01
29	0531050539	MOUNTED LEFT ARM	101	01
30	0503010131	3/16" X 1-1/2" COTTERPIN		02
31	0591016900	BEATING AXLE		01


Item	Code	Description	See page	QT
32	0591016905	DEPTH WHEEL JOINT AXLE		02
33	0591016907	SPACER GLOVE 14MM		06
34	0591016988	SPICER PROTECTOR		01




Item	Code	Description	See page	QT
01	0502012925	ADJUSTMENT BODY		01
02	0511015976	FLAT WASHER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0503010581	RING		01
05	0502012892	DEPTH CONTROL HANDLE		01
06	0581019526	ARTICULATED AXLE LEVER DEPTH		01
07	0503010302	501019 SEAL RING		01




Item	Code	Description	See page	QT
01	0502012928	LEFT EXTENSOR		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 92 FERTILIZER / SEED		01
11	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 93 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	95	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	94	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUB DISC - HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01



Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT	02	
02	0503013816	5/16" LOCKNUT	04	
03	0581015855	SLEEVE	02	
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER	01	
05	0521068661	LEVER	01	
06	0503030878	LEVER CRANK	01	
07	0503031393	1.57" X 5.98" X 0.2"TRACTION SPRING	01	
08	0581019520	AXIS	01	
09	0571812442	COUPLING SHAFT	01	
10	0503010257	1/8" X 1" COTTERPIN	01	
11	0581019511	COVER	01	
12	0503010848	5/16" X 3.1/2" BOLT	02	
13	0503010752	1/2" X 3.1/2" BOLT	01	
14	0503011336	1/2" HEX SELF ADJUSTING NUT	01	
15	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
16	0581019510	AXIS	01	
17	0581019512	PLATE TOP	01	
18	0503019351	LUBRICANT SLEEVE	02	
19	0521069591	LEFT SIDE	01	
20	0581019548	RIGHT SIDE BODY	01	




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	98	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05



Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02

LEFT COMPACTOR WHEEL


0521054990




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	98	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05

MOUNTED LEFT ARM


0531050538



Item	Code	Description	See page	QT
01	0502012927	LEFT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055056	WHEEL RAYED ASSY BAND	102	01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0502012926	RIGHT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055056	WHEEL RAYED ASSY BAND	102	01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
04	0503010337	5/16" NUT		06
05	0503032970	RUBBER BAND		01
06	0521055073	ASSEMBLY DEPTH WHEEL HUB	103	01

ASSEMBLY DEPTH WHEEL HUB


0521055073




Item	Code	Description	See page	QT
01	0581019528	WHEEL DEPTH SPA HUB WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	DUST CLOAK		01
11	0581019529	DEPTH REGULATOR SHAFT		01




Item	Code	Description	See page	QT
01	0502012924	PRECISION PLANTING SUPPORT		01
02	0502012800	SUPPORT ARTICULATION PNEUMATIC		01
03	0503062406	SEED HOPPER		01
04	0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT 105 PROTECTION		01
05	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01
07	0503810009	BOLT		02
08	0571018649	SUPPORT FIXER		02
09	0503010243	CLAMP		01
10	0581017816	TERMINAL		01
11	0503034204	SEALING		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0571014024	FAST BOLT GUIDE AXLE		01
14	0503034824	FIXATIVE		01
15	0503010293	CLAMP KNOB		01
16	0503010025	3/8 SPRING WASHER		05
17	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
18	0501110894	FIXER		01
19	0502012922	FIXING SUPPORT		01
20	0503011404	BOLT		01
21	0503013357	3/8 SELF-ADJUSTING NUT		01
22	0503010026	3/8" NUT		04
23	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04




Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01




Item	Code	Description	See page	QT
01	0521068129	ENCAPSULATED CHAIN FIXATION SUPPORT		01
02	0591015755	CHAIN SUPPORT SLEEVE		02
03	0591016332	SUPPORT REAR SLEEVE		01
04	0501011753	5/16" X 1-3/4" BOLT		03
05	0501010694	FLAT WASHER		01
06	0503019657	HEX LOCK NUT WITH NYLON 5/16		03
07	0591016334	FLAT WASHER 8,50 X 23 X 4,00		02



Item	Code	Description	See page	QT
01	0531062260	GUIDE HOSE L / TRANSMISSION		01
02	0571018883	PIN FIXER SPRING		01
03	0503010257	1/8" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0531050536	REAR RIGHT SPI TIRE WITHOUT FLAP	109	01
02	0521056640	PRECISION PLANTING CSC CABLE / TRANSMISSION ASSY	104	01
03	0503062403	TUBE SEED P.P		01
04	0571017895	PIN FIXER CONDUCTOR P.P		01
05	0503010140	1/8" X 3/4" COTTERPIN		01
06	0591017565	SEED CONDUCTOR GUIDE		01
07	0503015341	POP RIVET		02
08	0531051264	FULL SUPPORT FOR ENCAPSULATED CURRENT FIXATION	106	01



Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0521056632	DEPTH CONTROL	90	01
03	0502012920	SUPPORT ADJUSTING		01
04	0502012611	DEPTH CONTROL AXLE		01
05	0591011309	ADJUSTMENT BUSHING		02
06	0591011310	ADJUSTMENT BAR		02
07	0503019275	SLEEVE LUBRICATION SYSTEM		01
08	0581019473	ARTICULATED SLEEVE		02
09	0503010045	O'RING		02
10	0503013357	3/8 SELF-ADJUSTING NUT		02
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
12	0591011326	LOCK PIN		01
13	0571015326	ARTICULATION SLEEVE HANDLE		01
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503010060	1/2 UNC G.5 ZN HEX NUT		02
16	0503010019	1/2" SPRING WASHER		04
17	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
18	0501011445	FLAT WASHER		04
19	0503012556	1/2" X 1" BOLT		02
20	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
21	0591011306	ADJUSTMENT LOCK		02
22	0503012136	NUT 1/2 NF		04
23	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
24	0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	110	01
25	0521055093	BODY COMPACTOR	96	01
26	0521055017	RIGHT COMPACTOR WHEEL	97	01
27	0521054990	LEFT COMPACTOR WHEEL	99	01
28	0531050538	MOUNTED LEFT ARM	100	01
29	0531050539	MOUNTED LEFT ARM	101	01
30	0503010131	3/16" X 1-1/2" COTTERPIN		02
31	0591016900	BEATING AXLE		01


Item	Code	Description	See page	QT
32	0591016905	DEPTH WHEEL JOINT AXLE		02
33	0591016907	SPACER GLOVE 14MM		06
34	0591016988	SPICER PROTECTOR		01



Item	Code	Description	See page	QT
01	0502012929	BODY RIGHT		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 93 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 92 FERTILIZER / SEED		01

LEFT DUAL FERTILIZER DISC


0521055869




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 93 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 92 FERTILIZER / SEED		01

RIGHT DUAL FERTILIZER DISC


0521055868




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 93 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 92 FERTILIZER / SEED		01



Item	Code	Description	See page	QT
01	0581012238	SEED HOPPER SUPPORT		04
02	0531061644	CENTRAL SEED SILO FIXATION BASE		01
03	0501011643	3/8 X 1" BOLT		16
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
05	0503013357	3/8 SELF-ADJUSTING NUT		24
06	0503010025	3/8 SPRING WASHER		04
07	0503010026	3/8" NUT		04
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
09	0521053176	COVER KAP		01
09A	0503011372	102 TO 121 CLAMP		01
09B	0581017528	15 OUTPUT TUBE COVER		01
10	0521053173	CENTRAL SEED HOPPER 15 OUTPUTS	114	01
11	0531060166	LEFT LOCKING SUPPORT		01
12	0503011372	102 TO 121 CLAMP		01
13	0531060165	RIGHT LOCKING SUPPORT		01
14	0531060781	BOX FIXING CLAMP		02
15	0501012140	FLAT WASHER		20
16	0503010811	5/8" UNF SELF ADJUSTING NUT		20
17	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
18	0503010232	5/8" X 1.3/4" BOLT		12
19	0531051092	ASSY HOSE SUPPORT	116	01
20	0531060723	RIGHT CENTRAL HANDRAIL		01
21	0531060724	LEFT CENTRAL HANDRAIL		01
22	0501010942	3/8" X 1-1/4" BOLT		08
23	0521045392	HYDRAULIC TURBINE WITH SCREEN	117	01
24	0503010233	5/8" X 2-1/2" BOLT		04
25	0531051119	PRECISION PLANTING ASSEMBLED TURBINE	121	01
26	0503019221	WIRE TYPE CLAMP 3,2MM X 35 X 41 MM AWAARC041		19
27	0531061755	NOZZLE Y SEED		02




Item	Code	Description	See page	QT
01	0521068977	15 OUTPUTS AIR TUBE		01
02	0521053175	BASE CSC HOPPER 15 OUTPUTS	115	01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		26
04	0503015075	M10 SPRING WASHER		26
05	0503010025	3/8 SPRING WASHER		08
06	0503010172	M10 X 1,5 X 25 BOLT		26
07	0503062687	SEED HOPPER		01
08	0503019284	M8 X BOLT		04
09	0503010849	3/8" X 1-1/2" BOLT		08
10	0581017922	WASHER		04




Item	Code	Description	See page	QT
01	0521068978	CASH FUND COVER		03
02	0503015135	FLAT WASHER 10 X 18 X 2		06
03	0503011823	0.1" X 0.6" SPRING PIN		06
04	0521068851	SYSTEM ASSY		01
05	0503034571	SEALING		01
06	0503034573	SEALING		03
07	0581017529	ROD 9,53		03
08	0503062759	SEALING		03
09	0503034692	FAST LOCK ASSY		06
10	0503030085	LOCK PIN		06
11	0503019290	BOLT		24

ASSY HOSE SUPPORT

0531051092




Item	Code	Description	See page	QT
01	0531062259	HOSE SUPPORT		01
02	1902011170	FIXER		02
03	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		04
04	0501013519	FLAT WASHER		04
05	0503010589	1/2" UNC SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0501054983	NIPPLE HIDRAULIC MOTOR	119	01
02	0503010025	3/8 SPRING WASHER		12
03	0503010026	3/8" NUT		10
04	0521044613	FAN 480X50 (HIDRAULIC)		01
05	0503010143	1/4" SPRING WASHER		01
06	0503010849	3/8" X 1-1/2" BOLT		02
07	0531018764	FLAT WASHER		01
08	0503011104	M6 X 1" BOLT		01
09	0503012722	0.16" X 0.4" BLIND RIVET		24
10	0521065857	CARACOL MECHANICAL TURBINE S MEC		01
11	0521065858	TURBIN SUPPORT		01
12	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC 120 TURBINE		01
13	0561010634	VALVE SUPPORT ASSY		01
14	0503010237	3/8" X 1" BOLT		08
15	0503010206	3/8 X 1/2 BOLT		02
16	0571018577	COVER SNAIL TURBINE		01
17	0571018578	TURBINE PROTECTIVE SCREEN		01
18	0541013274	LISA WASHER 10 X 38 X 4.75		02
19	0521069167	FRONT PROTECTION		01
20	0501080709	3/8" X 21.6" TR-TR HOSE		01
21	0501080091	1/2" X 550 TR-TR HOSE		02
22	0503031087	ADHESIVE LABEL		01
23	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
24	0503033981	ADHESIVE LABEL		01

NIPPLE HIDRAULIC MOTOR


0501054983




Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW		01
03	0561016941	3/4" NUT		01
04	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
05	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE		01
06	3914103037	TEFLON		0,001RI




Item	Code	Description	See page	QT
01	0503012291	BLOCK COMMAND		01
02	0501010590	NIPPLE		04
03	0503010045	O'RING		04
04	0541011066	3/4" UNF X 43.5 NIPPLE		01
05	0503010190	2-114 N 3006-9B O'RING		01



Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		04
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
06	0531051120	PLANTING TURBINE WITH HOLE	122	01
07	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
08	0501010694	FLAT WASHER		02
09	0503010143	1/4" SPRING WASHER		02
10	0503010144	1/4" NUT		02
11	0503010190	2-114 N 3006-9B O'RING		04
12	0501081235	1/2 X 650 TR- TC HOSE		01
13	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
14	0503031087	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0531062288	TURBINE FLANGE		01
02	0521050154	PRECISION PLANTING TURBINE WITH HOLE		01



Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		02
02	0503017857	BOLT 5/8 UNF 4		08
03	0503010811	5/8" UNF SELF ADJUSTING NUT		08
04	0551019514	3/8 FASTENER		02
05	0591017796	ARTICULATION AXIS 222 R.1.1 / 4 UNF		01
06	0531062134	UNIVERSAL SUPPORT		01
07	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
08	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
09	0503010019	1/2" SPRING WASHER		04
10	0503011075	3/4" UNC NUT		06
11	0501010125	3/4" X 2-1/2" BOLT		06
12	0591013172	31.75 X126 AXLE WITH 8 HOLE		02
13	0591013173	CYLINDER INTERMEDIATE BUSHING		02
14	0503012231	1/4" X 3" COTTERPIN		02
15	0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	38	02
16	0503010026	3/8" NUT		04
17	0503010025	3/8 SPRING WASHER		04
18	0501111072	SIDE SUPPORT ARTICULATOR		01
19	0501011544	3/4" X 1-1/2" BOLT		01
20	0503010023	3/4" SPRING WASHER		01
21	0511017232	FLAT WASHER		01
22	0531050903	SIDE ARTICULATED CYLINDER 44.45X85.70X291X657	37	01
23	0591018408	PIN LOCK LINES		01
24	0503030085	LOCK PIN		01

FULL LEFT WHEEL

0531051360



Item	Code	Description	See page	QT
01	0531061579	CENTRAL WHEEL SUPPORT		01
02	0531050023	HYDRAULIC CYLINDER 2 X 5 X 599 X 336	31	01
03	0503010019	1/2" SPRING WASHER		05
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503017874	BOLT 1/2 UNC		01
06	0591015907	LARGER JUNCTION AXIS		01
07	0521059737	CENTRAL FORK RODEIRO	125	01
08	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
09	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
10	0502012731	WHEEL HOLDER		03
11	0503014441	BOLT 3/4		06
12	0501010322	FLAT WASHER		06
13	0503010152	3/4" SELF LOCKING NUT		06
14	0521056085	PLATE BEARING ASSY	126	01
15	0501010937	13,50 X 28 X 3,00 FLAT WASHER		02
16	0503010589	1/2" UNC SELF ADJUSTING NUT		03
17	0591016136	GLOVE 13.5 X 18.5 X 18		01
18	0503011082	C1/2" X 1.3/4" SCREW		03
19	0531061577	FIXING SUPPORT LEFT		01
20	0521059727	WHEEL ASSY WITH TIRE	127	01
21	0521059723	WHEEL ASSY WITH TIRE	129	01
22	0503011404	BOLT		01
23	0591016044	FIXING GLOVE 11 X 35 X 20		01
24	0503010025	3/8 SPRING WASHER		01
25	0521059599	WHEEL TRANSMISSION BOX	130	01
26	0503030179	TRACTION SPRING 26 X 3.5 X 105		01
27	0502012768	LINE SUPPORT CLAMP		01
28	0503013389	5/8" SELF LOCKING NUT		04
29	0501017334	5/8"X 5/8" X 10.24" STUD		02
30	0521059736	RIGHT SIDE TRANSMISSION DRIVER	131	01
31	0591015920	DISARMING LEVER		01


FULL LEFT WHEEL

0531051360


Item	Code	Description	See page	QT
32	0503011312	ROTATIVE CABLE		01
33	0591015996	LEFT PLATE ACTIVATION		01
34	0521010773	0.37" X 1.18" COUPLING SHAFT		02
35	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
36	0591016621	LEFT PLATE SUPPORT LEVER		01
37	0591016620	RATCHET LEVER		01
38	0531051355	LEFT WHEEL TRANSMISSION ASSY	132	01
39	0503063177	5/8 WHEEL ENCAPSULATED CHAIN		01
40	0503010257	1/8" X 1" COTTERPIN		02
41	0551016274	HYDRAULIC CYLINDER ADAPTER		01

CENTRAL FORK RODEIRO


0521059737



Item	Code	Description	See page	QT
01	0531061573	WHEEL BODY		01
02	0521018575	REGULATOR SPINDLE 100		02
03	0591015950	SUPPORT		04
04	0501010087	1.1/4" NUT		02
05	0521059738	CROSSHEAD MOUNTED		01
06	0591016434	PLASTIPRENE		02
07	0503019246	BOLT		02
08	0503011075	3/4" UNC NUT		02
09	0531061575	BEARING		02
10	0503010019	1/2" SPRING WASHER		13
11	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		12
12	0503019271	SELF LUBRICATING BUSHING		02
13	0591015935	CENTRAL WHEEL CYLINDER AXLE		01
14	0503010060	1/2 UNC G.5 ZN HEX NUT		01
15	0503010752	1/2" X 3.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0503019402	BEARING B207-22 V22 FRM		01
02	0503019403	PFL 207 FRM BEARING PLATE		02
03	0503010026	3/8" NUT		02
04	0503010025	3/8 SPRING WASHER		02
05	0501011643	3/8 X 1"BOLT		02




Item	Code	Description	See page	QT
01	0521059728	WHEEL WITH TIRE	34	01
02	0521059729	MOUNTED CUBE	128	01

MOUNTED CUBE


0521059729




Item	Code	Description	See page	QT
01	0591016025	BOX MM		01
02	0503010006	32210 ROLLER BEARING		01
03	0503010005	32212 ROLLER BEARING		01
04	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
05	0503010002	1800 GREASE FITTING		01
06	0503010064	5/8 UNF CONIC NUT		06
07	0503011866	SEAL 00573-B WITH HOLE		01
08	0501010888	1.3/4" 2.5/16" CASTLE NUT		01
09	0503010010	1/4" X 2.1/2" COTTERPIN		01
10	0502020593	COVER		01
11	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		01
12	0591015896	WHEEL AXIS		01



Item	Code	Description	See page	QT
01	0521059728	WHEEL WITH TIRE	34	01
02	0521059724	ASSEMBLED CUBE WITHOUT TRANSMISSION		01




Item	Code	Description	See page	QT
01	0503010237	3/8" X 1" BOLT		06
02	0503010025	3/8 SPRING WASHER		06
03	0531061478	TRANSMISSION BOX		01
04	0531061479	CUBE WITH GEAR 20Z		01
05	0503011100	502080 CLAMPING RING (FOR AXLE)		01
06	0503010217	501040 CLAMPING RING (FOR AXLE)		01
07	0591015634	NYLON GLOVE		01
08	0591015635	WASHER		01
09	0503019922	BEARING 6208		02
10	0531061480	10Z GEAR AXLE		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
05	0501019734	FLAT WASHER		02
06	0503010003	1845 GREASE FITTING		02
07	0502012539	26Z P12,7 GEAR		01
08	0501019735	FLAT WASHER		01
09	0521017593	FLAT WASHER		01
10	0503010542	501045 CLAMPING RING (FOR AXLE)		01
11	0503030678	BOLT 1/2 UNC X 1.1/2 C50 G.5 ZN		01
12	0503010060	1/2 UNC G.5 ZN HEX NUT		01
13	0502010720	RIGHT CAM, SMALLER		02

LEFT WHEEL TRANSMISSION ASSY


0531051355




Item	Code	Description	See page	QT
01	0503014007	1/2" X 1-1/4" BOLT		04
02	0503010019	1/2" SPRING WASHER		04
03	0503010905	1/2" X 2-1/4" BOLT		02
04	0503010589	1/2" UNC SELF ADJUSTING NUT		03
05	0521056085	PLATE BEARING ASSY	126	01
06	0531051358	WHEEL TRANSMISSION STRETCHER	133	01
07	0531062355	MOTOR GEAR 20Z P5/8		01
08	0531062354	LEFT WHEEL TRANSMISSION SUPPORT		01
09	0531051356	STARTER TRANSMISSION ASSY LEFT 29Z	134	01
10	0531051372	RIGHT / LEFT WHEEL TRANSMISSION BOX	135	01
11	0501013233	5/8" X 2-3/4" BOLT		02
12	0503012412	5/8 UNC SELF LOCKING NUT		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01
14	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
15	0503012463	CHAIN		01
16	0503011404	BOLT		01
17	0591016044	FIXING GLOVE 11 X 35 X 20		01
18	0503010025	3/8 SPRING WASHER		01
19	0591018543	LEFT PROTECTIVE COVER		01
20	0503016023	1/2 X 6 BOLT		01




Item	Code	Description	See page	QT
01	0503011410	ROLLER BEARING		01
02	0503011105	SEAL RING		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0503012412	5/8 UNC SELF LOCKING NUT		01
05	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		01
06	0591015905	STRETCHER AXIS		01
07	0501010453	FLAT WASHER		01
08	0511061836	17Z GEAR		01



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY	01	
02	0571010151	GRAGGER RATCHET BODY	01	
03	0551019100	LOCK RATCHET	02	
04	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING	02	
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN	04	
06	0503013816	5/16" LOCKNUT	04	
07	0571010164	SEAT SIDE OF RATCHET	01	
08	0503010060	1/2 UNC G.5 ZN HEX NUT	01	
09	0571010763	FLANGE WASHER	02	
10	0503010004	1890 GREASE FITTING	01	
11	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
12	0591018545	GEAR BODY	01	




Item	Code	Description	See page	QT
01	0531061493	20Z GEAR AXLE		01
02	0531061494	SMALLER GEAR		01
03	0503010019	1/2" SPRING WASHER		03
04	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		03
05	0531062356	FRONT BEARING		01
06	0591018554	SEPARATOR		03
07	0591018555	TRANSMISSION BOX BODY		01
08	0503019922	BEARING 6208		04
09	0503011100	502080 CLAMPING RING (FOR AXLE)		02
10	0503010217	501040 CLAMPING RING (FOR AXLE)		02



Item	Code	Description	See page	QT
01	0531061579	CENTRAL WHEEL SUPPORT		01
02	0531050023	HYDRAULIC CYLINDER 2 X 5 X 599 X 336	31	01
03	0503010019	1/2" SPRING WASHER		05
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503017874	BOLT 1/2 UNC		01
06	0591015907	LARGER JUNCTION AXIS		01
07	0521059737	CENTRAL FORK RODEIRO	125	01
08	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
09	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
10	0502012731	WHEEL HOLDER		03
11	0503014441	BOLT 3/4		06
12	0501010322	FLAT WASHER		06
13	0503010152	3/4" SELF LOCKING NUT		06
14	0521056085	PLATE BEARING ASSY	126	01
15	0501010937	13,50 X 28 X 3,00 FLAT WASHER		02
16	0503010589	1/2" UNC SELF ADJUSTING NUT		03
17	0591016136	GLOVE 13.5 X 18.5 X 18		01
18	0503011082	C1/2" X 1.3/4" SCREW		03
19	0531061576	RIGHT FIXING SUPPORT		01
20	0521059727	WHEEL ASSY WITH TIRE	127	01
21	0521059723	WHEEL ASSY WITH TIRE	129	01
22	0503011404	BOLT		01
23	0591016044	FIXING GLOVE 11 X 35 X 20		01
24	0503010025	3/8 SPRING WASHER		01
25	0521059599	WHEEL TRANSMISSION BOX	130	01
26	0503030179	TRACTION SPRING 26 X 3.5 X 105		01
27	0502012768	LINE SUPPORT CLAMP		01
28	0503013389	5/8" SELF LOCKING NUT		04
29	0501017334	5/8"X 5/8" X 10.24" STUD		02
30	0521059735	LEFT SIDE TRANSMISSION DRIVER	137	01
31	0591015920	DISARMING LEVER		01


Item	Code	Description	See page	QT
32	0503011312	ROTATIVE CABLE		01
33	0591015996	LEFT PLATE ACTIVATION		01
34	0521010773	0.37" X 1.18" COUPLING SHAFT		02
35	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
36	0591016621	LEFT PLATE SUPPORT LEVER		01
37	0591016620	RATCHET LEVER		01
38	0531051354	RIGHT WHEEL TRANSMISSION ASSY	138	01
39	0503063177	5/8 WHEEL ENCAPSULATED CHAIN		01
40	0503010257	1/8" X 1" COTTERPIN		02
41	0551016274	HYDRAULIC CYLINDER ADAPTER		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0501019734	FLAT WASHER		02
05	0503010003	1845 GREASE FITTING		02
06	0501019735	FLAT WASHER		01
07	0521017593	FLAT WASHER		01
08	0503010542	501045 CLAMPING RING (FOR AXLE)		01
09	0502011995	LH DRIVING AXLE FOLLOWER		01
10	0502012540	26Z P12,7 GEAR		01
11	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
12	0503010060	1/2 UNC G.5 ZN HEX NUT		01
13	0502010710	RIGHT CAM, SMALLER		02

RIGHT WHEEL TRANSMISSION ASSY


0531051354




Item	Code	Description	See page	QT
01	0503014007	1/2" X 1-1/4" BOLT		04
02	0503010019	1/2" SPRING WASHER		04
03	0503010905	1/2" X 2-1/4" BOLT		02
04	0503010589	1/2" UNC SELF ADJUSTING NUT		03
05	0521056085	PLATE BEARING ASSY	126	01
06	0531051358	WHEEL TRANSMISSION STRETCHER	133	01
07	0531062355	MOTOR GEAR 20Z P5/8		01
08	0531062353	RIGHT WHEEL TRANSMISSION SUPPORT		01
09	0531051357	FULL RIGHT TRANSMISSION ACTUATOR 29Z	139	01
10	0531051372	RIGHT / LEFT WHEEL TRANSMISSION BOX	135	01
11	0501013233	5/8" X 2-3/4" BOLT		02
12	0503012412	5/8 UNC SELF LOCKING NUT		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01
14	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
15	0503012463	CHAIN		01
16	0503011404	BOLT		01
17	0591016044	FIXING GLOVE 11 X 35 X 20		01
18	0503010025	3/8 SPRING WASHER		01
19	0591018542	PROTECTIVE RIGHT COVER		01
20	0503016023	1/2 X 6 BOLT		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY	01	
02	0571010151	GRAGGER RATCHET BODY	01	
03	0551019100	LOCK RATCHET	02	
04	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING	02	
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN	04	
06	0503013816	5/16" LOCKNUT	04	
07	0571010164	SEAT SIDE OF RATCHET	01	
08	0503010060	1/2 UNC G.5 ZN HEX NUT	01	
09	0571010763	FLANGE WASHER	02	
10	0503010004	1890 GREASE FITTING	01	
11	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
12	0591018545	GEAR BODY	01	




Item	Code	Description	See page	QT
01	0503062362	FERTILIZER HOPPER		02
02	0521057783	CENTRAL SUPPORT 8 MOUTH	141	01
03	0521051407	FERTILIZER HOPPER FIXER	22	12
04	0501013519	FLAT WASHER		06
05	0503010589	1/2" UNC SELF ADJUSTING NUT		06
06	0503014378	1/2" X 1-1/2" BOLT		06



Item	Code	Description	See page	QT
01	0531060766	SUPPORT SILO 08 MOUTH		01
02	0521054282	BEARING	24	04
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	28	04
04	0503030275	AGRICULTURAL BEARING		08
05	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	26	04
06	0561018362	SQUARE SHAFT		02
07	0501053788	3/4 SQUARE AXLE FASTENER	27	08
08	0551018055	22,65 X 60 SLEEVE		04
09	0503011953	5/16" X 1" BOLT		32
10	0501010694	FLAT WASHER		32
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		32
12	0503010337	5/16" NUT		32
13	0502012990	CONICA 14Z SQUARE GEAR		08
14	0511065209	20Z GEAR		02
15	0503030303	SUPPORT WASHER		06
16	0503010362	1/8 X 1.1/4 COTTERPIN		08
17	0503034396	FERTILIZER SIDE COVER		08




Item	Code	Description	See page	QT
01	0591018114	RIGHT PLATE BEARING		01
02	0531051055	HUB GREATER TRANSMISSION	143	01
03	0503011081	6207 2RS BEARING		02
04	0591018034	SHAFT BEARING GUIDE HITCH		01
05	0503010845	501035 CLAMPING RING (FOR AXLE)		01
06	0503010370	502072 CLAMPING RING (FOR AXLE)		01
07	0591018115	SMALLER TRANSMISSION AXIS		01
08	0503010849	3/8" X 1-1/2" BOLT		04
09	0503013357	3/8 SELF-ADJUSTING NUT		04
10	0591018038	DRAGGLE GLOVE		01
11	0591018039	HEX SHAFT 3/4 X 750 CENTRAL AND SIDE		01
12	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
13	0503014876	NUT PARLOCK 1/4"		02
14	0531062224	TRANSMISSION COUPLING WITH PLATE		02
15	0503010019	1/2" SPRING WASHER		02
16	0591018113	WASHER SUPPORT AXLE 13.50 X 34 X 4.00		02
17	0503012556	1/2" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0591018112	HIGHER TRANSMISSION BEARING		01
02	0503011081	6207 2RS BEARING		02
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0591018111	LARGER TRANSMISSION AXIS		01
05	0503010849	3/8" X 1-1/2" BOLT		04
06	0503013357	3/8 SELF-ADJUSTING NUT		04

LEFT TRANSMISSION SUPPORT


0531051063




Item	Code	Description	See page	QT
01	0591018114	RIGHT PLATE BEARING		01
02	0531051055	HUB GREATER TRANSMISSION	143	01
03	0503011081	6207 2RS BEARING		02
04	0591018034	SHAFT BEARING GUIDE HITCH		01
05	0503010845	501035 CLAMPING RING (FOR AXLE)		01
06	0503010370	502072 CLAMPING RING (FOR AXLE)		01
07	0591018115	SMALLER TRANSMISSION AXIS		01
08	0503010849	3/8" X 1-1/2" BOLT		04
09	0503013357	3/8 SELF-ADJUSTING NUT		04
10	0591018038	DRAGGLE GLOVE		01
11	0591018039	HEX SHAFT 3/4 X 750 CENTRAL AND SIDE		01
12	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
13	0503014876	NUT PARLOCK 1/4"		02
14	0531062224	TRANSMISSION COUPLING WITH PLATE		02
15	0503010019	1/2" SPRING WASHER		02
16	0591018113	WASHER SUPPORT AXLE 13.50 X 34 X 4.00		02
17	0503012556	1/2" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0531062226	EXCHANGE BOX		01
02	0503031805	11Z 1/2" GEAR		04
03	0511061795	CHAIN TENSIONER		02
04	0503010302	501019 SEAL RING		04
05	0501048790	AXLE WITH RING	147	02
06	0503010292	701164 6 X 40 SPRING PIN		10
07	0502012669	LEVER TENSIONER REAR		02
08	0511060396	DRIVE/DRIVEN SHAFT		04
09	0591015347	EXCHANGE MOTOR AXLE		01
10	0503012204	40-1 CHAIN X 82 LINK + RED		02
11	0591015346	LOWER MOVED AXLE		01
12	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	148	01
13	0501056443	GEAR HOUSING BEARING	149	04
14	0503030303	SUPPORT WASHER		03
15	0511059266	CLOSED BEARING	150	03
16	0521018630	1.4" X SQUARE 0.8" WASHER		05
17	0511067501	26Z GEAR		01
18	0521059533	MOUNTED 21Z P 1/2 GEAR	152	01
19	0591015345	TOP SIDE AXLE		01
20	0591015344	LOWER SIDE AXLE		01
21	0503010589	1/2" UNC SELF ADJUSTING NUT		04
22	0503012110	1/2" X 3-3/4" BOLT		04
23	0511055260	SEED ROW CHAIN TENSIONER	46	01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
25	0503012389	1/2 BALL		04
26	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
27	0503010834	1/2 X 1 BOLT		04
28	0503010060	1/2 UNC G.5 ZN HEX NUT		04
29	0503016178	40-1 CHAIN X 38 LINK + MENDING		01
30	0511066098	23Z GEAR		01




Item	Code	Description	See page	QT
01	0531062226	EXCHANGE BOX		01
02	0503031805	11Z 1/2" GEAR		04
03	0511061795	CHAIN TENSIONER		02
04	0503010302	501019 SEAL RING		04
05	0501048790	AXLE WITH RING	147	02
06	0503010292	701164 6 X 40 SPRING PIN		10
07	0502012669	LEVER TENSIONER REAR		02
08	0511060396	DRIVE/DRIVEN SHAFT		04
09	0591015347	EXCHANGE MOTOR AXLE		01
10	0503012204	40-1 CHAIN X 82 LINK + RED		02
11	0591015346	LOWER MOVED AXLE		01
12	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	148	01
13	0501056443	GEAR HOUSING BEARING	149	04
14	0503030303	SUPPORT WASHER		03
15	0511059266	CLOSED BEARING	150	03
16	0521018630	1.4" X SQUARE 0.8" WASHER		07
17	0511067501	26Z GEAR		01
18	0521059533	MOUNTED 21Z P 1/2 GEAR	152	01
19	0591015345	TOP SIDE AXLE		01
20	0591015344	LOWER SIDE AXLE		01
21	0503010589	1/2" UNC SELF ADJUSTING NUT		04
22	0503012110	1/2" X 3-3/4" BOLT		04
23	0511055260	SEED ROW CHAIN TENSIONER	46	01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
25	0503012389	1/2 BALL		04
26	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
27	0503010834	1/2 X 1 BOLT		04
28	0503010060	1/2 UNC G.5 ZN HEX NUT		04
29	0503016178	40-1 CHAIN X 38 LINK + MENDING		01
30	0511066098	23Z GEAR		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	25	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	151	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0503011410	ROLLER BEARING		01
02	0503011105	SEAL RING		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0571019207	DEVIATION AXLE GEAR BOX		01
05	0503010899	5/8 UNC X 2.1/4 BOLT		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01
07	0521069698	GEAR 21Z P 1/2		01




Item	Code	Description	See page	QT
01	0591017995	FERTILIZER CONDUCTOR GUTTER		02
02	0531051736	SHORT LINE FERTILIZER CONDUCTOR ARTICULATOR		07
03	0501010942	3/8" X 1-1/4" BOLT		09
04	0503013357	3/8 SELF-ADJUSTING NUT		16
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		23
06	0591018014	LEFT SUPPORT		02
07	0531061465	GUIDE		07



Item	Code	Description	See page	QT
01	0531061658	CENTRAL PLATFORM 2797		01
02	0501013519	FLAT WASHER		04
03	0503010589	1/2" UNC SELF ADJUSTING NUT		04
04	0503014378	1/2" X 1-1/2" BOLT		04




Item	Code	Description	See page	QT
01	0521063778	RELATION AVEC AXE VERTICAL LATCH	01	
02	0571011767	LISA WASHER 125 X 88 X 4.76	01	
03	0503010408	7/8" SPRING WASHER	01	
04	0503015322	BOLT 7/8	01	
05	0591012527	HORIZONTAL JOINT AXIS	01	
06	0503011198	C3/4" X 6" SCREW	01	
07	0503010023	3/4" SPRING WASHER	01	
08	0503010014	3/4" HEX NUT	01	
09	0503010814	5/16 BOLT	10	
10	0503010002	1800 GREASE FITTING	01	
11	0571011825	BUSHING	02	
12	0503010004	1890 GREASE FITTING	01	
13	0531062167	RIGHT HOSE SUPPORT	01	
14	0531062168	CYLINDER JOINT AXIS	01	
15	0503010834	1/2 X 1 BOLT	01	
16	0503010019	1/2" SPRING WASHER	05	
17	0503010060	1/2 UNC G.5 ZN HEX NUT	04	
18	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	02	
19	0501013519	FLAT WASHER	04	
20	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT	02	
21	0591012948	700 X 130 X 10 PLATE	01	
22	0531062196	LEFT ARTICULATION ARM	01	
23	0531062166	LEFT SUPPORT HOSES	01	
24	0503035505	HOSE PROTECTOR	01	




Item	Code	Description	See page	QT
01	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
02	0571011767	LISA WASHER 125 X 88 X 4.76		01
03	0503010408	7/8" SPRING WASHER		01
04	0503015322	BOLT 7/8		01
05	0591012527	HORIZONTAL JOINT AXIS		01
06	0503011198	C3/4" X 6" SCREW		01
07	0503010023	3/4" SPRING WASHER		01
08	0503010014	3/4" HEX NUT		01
09	0503010814	5/16 BOLT		10
10	0503010002	1800 GREASE FITTING		01
11	0571011825	BUSHING		02
12	0503010004	1890 GREASE FITTING		01
13	0591012948	700 X 130 X 10 PLATE		01
14	0531062149	RIGHT ARTICULATION ARM		01
15	0531062167	RIGHT HOSE SUPPORT		01
16	0531062166	LEFT SUPPORT HOSES		01
17	0531062168	CYLINDER JOINT AXIS		01
18	0503010834	1/2 X 1 BOLT		01
19	0503010019	1/2" SPRING WASHER		05
20	0501013519	FLAT WASHER		04
21	0503010060	1/2 UNC G.5 ZN HEX NUT		04
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
24	0503035505	HOSE PROTECTOR		01

HITCH ASSY

0531051056




Item	Code	Description	See page	QT
01	0591018116	BODY FIXING HITCH TRANSMISSION		01
02	0531051057	HITCH MOUNTED TRANSMISSION	158	02
03	0503013389	5/8" SELF LOCKING NUT		03
04	0503010233	5/8" X 2-1/2" BOLT		03




Item	Code	Description	See page	QT
01	0503011081	6207 2RS BEARING		02
02	0503010019	1/2" SPRING WASHER		01
03	0591018113	WASHER SUPPORT AXLE 13.50 X 34 X 4.00		01
04	0591018115	SMALLER TRANSMISSION AXIS		01
05	0591018034	SHAFT BEARING GUIDE HITCH		01
06	0503012556	1/2" X 1" BOLT		01
07	0503010845	501035 CLAMPING RING (FOR AXLE)		01
08	0503010370	502072 CLAMPING RING (FOR AXLE)		01
09	0503010849	3/8" X 1-1/2" BOLT		04
10	0503013357	3/8 SELF-ADJUSTING NUT		04
11	0531062225	TRANSMISSION COUPLING WITH POINTER		01

LEFT HITCH ASSEMBLY


0531051062




Item	Code	Description	See page	QT
01	0591018116	BODY FIXING HITCH TRANSMISSION		01
02	0531051057	HITCH MOUNTED TRANSMISSION	158	02
03	0503013389	5/8" SELF LOCKING NUT		03
04	0503010233	5/8" X 2-1/2" BOLT		03




Item	Code	Description	See page	QT
01	0581010353	RING SUPPORT		01
02	0502010382	5" END CAP		01
03	0581013698	PISTON		01
04	0531062199	CASE 127 X 662		01
05	0531062198	EXTENSOR 50,80 X 692		01
06	0503010003	1845 GREASE FITTING		02
07	0503010817	1.1/4" SELF LOCKING NUT		01
08	0503018439	WIPER SEAL		01
09	0503018150	RING GUIDE		01
10	0503010173	2-220 N 3006-9B O'RING		01
11	0503018024	RING BS		01
12	0503018026	1870-2000-375 B GASKET		01
13	0503010039	D-2000 SCRAPER RING		01
14	0503018152	O'RING		02
15	0503018025	RING GUIDE		01
16	0503011453	O'RING		02




Item	Code	Description	See page	QT
01	0591015993	VACUOMETER SUPPORT		01
02	0503013584	VACUUM GAUGE		02
03	0501011643	3/8 X 1" BOLT		02
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
05	0503013357	3/8 SELF-ADJUSTING NUT		02



Item	Code	Description	See page	QT
01	0591018250	AIR FIXING DISTRIBUTOR		02
02	0503010481	BOLT		04
03	0503013357	3/8 SELF-ADJUSTING NUT		04
04	0531062286	AIR DISTRIBUTOR		01




Item	Code	Description	See page	QT
01	0531062268	CENTRAL AIR DISTRIBUTOR		01
02	0531062270	RIGHT FIXER SUPPORT		01
03	0531062269	PLATFORM LEFT FIXER		01
04	1902010175	HITCH CLAMP		02
05	0501011543	5/8" X 4" BOLT		04
06	0503010027	5/8 SPRING WASHER		04
07	0503010013	5/8 NUT		04
08	0503010025	3/8 SPRING WASHER		04
09	0503010026	3/8" NUT		04
10	0503010237	3/8" X 1" BOLT		04




Item	Code	Description	See page	QT
01	0531062633	RIGHT SIDE CURRENT/ENCAPSULATED TRANSMISSION		01
02	0531062634	LEFT SIDE CURRENT/ENCAPSULATED TRANSMISSION		01
03	0591019647	TRANSMISSION AXIS GREATER		01
04	0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	38	01
05	0511057159	TRANSMISSION HOPPER SEED ROW	42	01
06	0531052020	28Z CHAIN/ENCAPSULATED TRANSMISSION GEAR	43	01
07	0591015357	HEX SHAFTED GUIDE 3/4 X 195		01
08	0503010237	3/8" X 1" BOLT		04
09	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
10	0503010025	3/8 SPRING WASHER		04
11	0591016053	SUPPORT PLATE		01
12	0531052019	17Z TRANSMISSION GEAR	44	01
13	0531052021	DOUBLE GEAR 17Z X 24Z P 1/2 ASSY	45	01
14	0511055260	SEED ROW CHAIN TENSIONER	46	01
15	0521052368	STRETCHER SIMPLE SEED	47	01
16	0503012391	40-1 CHAIN X 83 LINK + MENDING		01
17	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		01
18	0591019651	CHAIN/ENCAPSULATED RIGHT CHAIN COVER		01

CENTRAL LEFT TRANSMISSION


0531051515




Item	Code	Description	See page	QT
01	0511057159	TRANSMISSION HOPPER SEED ROW	42	02
02	0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	38	02
03	0502012768	LINE SUPPORT CLAMP		02
04	0503014636	5/8" UNC X 9 BOLT		04
05	0503013389	5/8" SELF LOCKING NUT		04
06	0591018103	HEX AXLE BODY SEED TRANSMISSION 5/8 X 565		01
07	0521011859	FLAT WASHER		02
08	0503010257	1/8" X 1" COTTERPIN		02
09	0521054282	BEARING	24	02
10	0591018038	DRAGGLE GLOVE		02
11	0591018102	HEX SHAFT 3/4 X 250		01
12	0591018101	SQUARE SHAFT 3/4 X 250 CENTRAL		01
13	0501053788	3/4 SQUARE AXLE FASTENER	27	02
14	0503063381	ENCAPSULATED CHAIN		01
15	0503063382	CENTRAL ENCAPSULATED CHAIN		01
16	0503030303	SUPPORT WASHER		04
17	0503010882	BOLT		04
18	0503013759	NUT		04
19	0531051861	BEARING/TRANSMISSION SUPPORT WITH LOCK	166	01




Item	Code	Description	See page	QT
01	0531062220	BEARING SUPPORT / TRANSMISSION		01
02	0591019298	LOCK GLOVE 13,5 X 25,40 X 134		03
03	0503010019	1/2" SPRING WASHER		03
04	0503010060	1/2 UNC G.5 ZN HEX NUT		03
05	0503010964	BOLT		03




Item	Code	Description	See page	QT
01	0511057159	TRANSMISSION HOPPER SEED ROW	42	02
02	0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	38	02
03	0502012768	LINE SUPPORT CLAMP		02
04	0503014636	5/8" UNC X 9 BOLT		04
05	0503013389	5/8" SELF LOCKING NUT		04
06	0591018103	HEX AXLE BODY SEED TRANSMISSION 5/8 X 565		01
07	0521011859	FLAT WASHER		02
08	0503010257	1/8" X 1" COTTERPIN		02
09	0521054282	BEARING	24	02
10	0591018038	DRAGGLE GLOVE		02
11	0591018102	HEX SHAFT 3/4 X 250		01
12	0591018101	SQUARE SHAFT 3/4 X 250 CENTRAL		01
13	0501053788	3/4 SQUARE AXLE FASTENER	27	02
14	0503063381	ENCAPSULATED CHAIN		01
15	0503063382	CENTRAL ENCAPSULATED CHAIN		01
16	0503030303	SUPPORT WASHER		04
17	0503010882	BOLT		04
18	0503013759	NUT		04
19	0531051861	BEARING/TRANSMISSION SUPPORT WITH LOCK	166	01




Item	Code	Description	See page	QT
01	0531062350	VALVE SUPPORT		01
02	0521059704	CASAPPA TRIPLE VALVE WITH FIXING NIPLES	169	01
03	0501068706	DOUBLE CONNECTION		02
04	0531062352	SIMPLE OIL DISTRIBUTOR		01
05	0503010026	3/8" NUT		06
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
07	0503010025	3/8 SPRING WASHER		06
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		06
09	0501054694	FLOW DIVIDING VALVE ASSY	170	01
10	0503010882	BOLT		02
11	0503013759	NUT		02
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		04
13	0503013389	5/8" SELF LOCKING NUT		04
14	0501012140	FLAT WASHER		04
15	0511017303	FLAT WASHER		02



Item	Code	Description	See page	QT
01	0503019571	DIVIDER VALVE TRI-DIREC PLD20 CASAPPA BRP00095		01
02	0503010026	3/8" NUT		04
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
04	0503010025	3/8 SPRING WASHER		04
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
06	0511018014	7/8"NF X 1.1/16 UN NIPPLE		01
07	0503011109	2-119 N 3006-9B O'RING		01
08	0511010111	7/8" NIPPLE		03
09	0503010045	O'RING		03




Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503030923	3/4" UNF X 13/16UN OFS X 40 NIPPLE		03
03	0503010190	2-114 N 3006-9B O'RING		03




Item	Code	Description	See page	QT
01	0591018537	DOUBLE CONNECTION SUPPORT		01
02	0501068706	DOUBLE CONNECTION		02
03	0503010026	3/8" NUT		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0503010589	1/2" UNC SELF ADJUSTING NUT		02
08	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02

BLOCK SUPPORT


0531051788




Item	Code	Description	See page	QT
01	0581012199	COMMAND BLOCK SUPPORT		01
02	0511059542	BLOCK COMMAND TURBINES	173	01
03	0501013518	FLAT WASHER		04
04	0503010025	3/8 SPRING WASHER		02
05	0503010026	3/8" NUT		02
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
07	0503015115	M8 X 1,25 X 12 BOLT		04
08	0503014371	M8 SPRING WASHER		04




Item	Code	Description	See page	QT
01	0503018597	BLOCK COMMAND		01
02	0503010190	2-114 N 3006-9B O'RING		02
03	0501011460	7/8 NF REDUCTION NIPPLE		02
04	0503011109	2-119 N 3006-9B O'RING		04
05	0571013917	7/8"NF X 1.1/16 UNF NIPPLE		04




Item	Code	Description	See page	QT
01	0503019579	LED LANTERN		01
02	0591018797	LED LANTERN SUPPORT		01
03	0503011828	FLAT WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0503010019	1/2" SPRING WASHER		02
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
07	0591018872	LANTERN COVER		01
08	0503019412	RIVET SCREW INTERNAL		02
09	0503013813	1/4" UNC X 7/8" BOLT		02
10	0503010143	1/4" SPRING WASHER		02
11	0503010305	FLAT WASHER		02



Item	Code	Description	See page	QT
01	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
02	0503010267	NYLON CLAMP		01
03	0503010337	5/16" NUT		01
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
05	0503060100	INSTRUCTIONS MANUAL CANISTER		01
06	0511034152	BAG WITH INSTRUCTION MANUAL		01




Item	Code	Description	See page	QT
01	0503063446	KIT INTELLIAG ISO6 6C 17LINES 45/50		01
01A	0503019526	CONTROL MODULE ISO6 6CH ADV		01
01B	0503015066	CABLE CONTROL MASTER MODULE		01
01C	0503019298	MODULATE BODY		01
01D	0503015210	CABLE MODULO WSMB ISOBUS 467981200		01
01E	0503016320	ISO CONEX TRACTOR 13M CABLE		01
01F	0503015071	CONCTOR		01
01G	0503017443	ANTENNA GPS PM 400		01
01H	0503019386	MODULES "C"		01
01I	0503019385	WHIP ELETTRIC		01
01J	0503063396	CABLE S M 17L MS PM400 18X18		01
01K	0503019616	EXTENSION CABLE		06
01L	0503019617	EXTENSION CABLE		06
01M	0513010023	EXTERNAL LIFTING CABLE		01
01N	0503015218	SENSOR FOTOELE PM 400		17
01O	0503017031	CLEANING BRUSH		01
02	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	177	06
03	0511056972	FILTER HYDAC	178	01
04	0503019291	SUPPORT SENSOR		01
05	0521054490	FLOW DIVIDING VALVE ASSY	179	01
06	0503013100	NYLON CLAMP		85
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		**




Item	Code	Description	See page	QT
01	0503018768	MOTOR OMP 80		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02

FILTER HYDAC


0511056972



Item	Code	Description	See page	QT
01	0503016376	FILTER SPRING		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8\"NF UNF NIPPLE		02
04	0503012341	T 7/8\" ADAPOR GIRAT NUT		01
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02



Item	Code	Description	See page	QT
01	0503016227	FLOW DIVIDING VALVE		01
02	0503013917	O'RING 2-224		03
03	0571013917	7/8\"NF X 1.1/16 UNF NIPPLE		03




Item	Code	Description	See page	QT
01	0531050396	SEED ENGINE SUPPORT WITH COVER	181	03
02	0531051575	FULL FERTILIZER ENGINE PLATE RIGHT LEFT	182	03
03	0531051974	MONTAGE CAIXA MODULE ECU	184	01
04	0531052048	HYDRAULIC HOSE SET 17 LINES	185	01
05	0501053834	MALE QUICK COUPLER	186	02
06	0591018507	BODY SUPPORT FILTER		01
07	0531051353	LIFTING DRIVE ASSEMBLY	187	01
08	0503030303	SUPPORT WASHER		02
09	0501013518	FLAT WASHER		02
10	0503010237	3/8" X 1" BOLT		02
11	0511017406	FLAT WASHER Q20 X 33 X 3.00		04
12	0503011196	3/4" X 2-1/4" BOLT		02
13	0503010023	3/4" SPRING WASHER		02
14	0511017305	FLAT WASHER		02
15	0503012183	SNC 3/4" ZIN 1K03097 NUT		02
16	0503013759	NUT		02
17	0503010357	8 X 20 X 1 FLAT WASHER		02
18	0503011332	5/16" X 2-3/4" BOLT		02
19	0531062331	SIDE CHASSI DUCT		04
20	0581018407	BODY FASTENER 2 DUCTS		08
21	0501011517	FLAT WASHER		04
22	0503010025	3/8 SPRING WASHER		04
23	0503010026	3/8" NUT		04
24	0503011141	3/8" X 2-3/4" BOLT		04
25	0503013493	T CONNECTION MALE		01
26	0591019675	LEFT SECONDARY GUTTER		01
27	0591019676	RIGHT SECONDARY GUTTER		01
28	0503010019	1/2" SPRING WASHER		04
29	0503010060	1/2 UNC G.5 ZN HEX NUT		04
30	0503014007	1/2" X 1-1/4" BOLT		04
31	0581015291	Q AXIS 3/4 X 3050		01




USAP 3200 SUPREMA - FRAME 8470 - CSC/TCE/APT
MECHANICAL ASSEMBLY

Page 180
0531052050


Item	Code	Description	See page	QT
32	0591015006	3/4 X 2900HEX AXLE		01




Item	Code	Description	See page	QT
01	0531060543	25Z GEAR WITH		01
02	0591013338	SIDE PLATE HYDRAULIC MOTOR SEED		01
03	0503010019	1/2" SPRING WASHER		03
04	0503010060	1/2 UNC G.5 ZN HEX NUT		03
05	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
07	0503030402	PULLEY		01
08	0531019479	AXLE CHAIN GEAR		01
09	0503010237	3/8" X 1" BOLT		03
10	0503010025	3/8 SPRING WASHER		03
11	0503010026	3/8" NUT		03
12	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
13	0503012713	40-1 CHAIN X 45 LINK + MEN		01
14	0531060590	HYDRAULIC MOTOR SUPPORT		01
15	0502010175	HITCH CLAMP		01
16	0503017857	BOLT 5/8 UNF 4		02
17	0501012140	FLAT WASHER		02
18	0503010811	5/8" UNF SELF ADJUSTING NUT		02
19	0531050397	COMPLETE PROTECTION		01
19A	0531050398	ENGINE PROTECTION COVER WITH RIVET		01
19B	0503013849	1/4" UNC X 3/4" BOLT		03
19C	0503010305	FLAT WASHER		03
19D	0503010143	1/4" SPRING WASHER		03




Item	Code	Description	See page	QT
01	0531051558	SIDE BODY BEARING APT	183	01
02	0591018653	FERTILIZER MOTOR FIXING PLATE		01
03	0503062754	GEAR 34Z P.1/2 APT		01
04	0521069832	15Z GEAR		01
05	0503010282	1/4" X 3/4" BOLT		01
06	0503010143	1/4" SPRING WASHER		04
07	0561011665	FLAT WASHER		01
08	0503010019	1/2" SPRING WASHER		03
09	0503010060	1/2 UNC G.5 ZN HEX NUT		03
10	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
11	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
12	0561013049	CHAIN TIGHTENER AXLE		01
13	0503010302	501019 SEAL RING		01
14	0503030402	PULLEY		01
15	0531051574	ASSY FERTILIZER ENGINE COVER		01
16	0503017392	40-1 X 67 CHAIN LINK + MENDING		01
17	0591018779	AGAINST FERTILIZER MOTOR COVER		01
18	0503013849	1/4" UNC X 3/4" BOLT		01
19	0503010305	FLAT WASHER		03
20	0503013813	1/4" UNC X 7/8" BOLT		02




Item	Code	Description	See page	QT
01	0591018034	SHAFT BEARING GUIDE HITCH		01
02	0503010845	501035 CLAMPING RING (FOR AXLE)		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		01
04	0591018780	SIDE TRANSMISSION SHAFT		01
05	0503010849	3/8" X 1-1/2" BOLT		04
06	0503013357	3/8 SELF-ADJUSTING NUT		04
07	0503016061	BEARING		02




Item	Code	Description	See page	QT
01	0591019589	ECU MODULE BOX		01
02	0591015310	ECU MODULES BOX COVER		01
03	0591015311	MODEL BOX FIXER		02
04	0503019901	INTERNAL THREAD RIVET RM 1/4 P30S		06
05	0501011643	3/8 X 1" BOLT		04
06	0503011773	FLAT WASHER		06
07	0503010143	1/4" SPRING WASHER		06
08	0503018171	FAST LOCK ASSY		02
09	0501013518	FLAT WASHER		04
10	0503010025	3/8 SPRING WASHER		04
11	0503010026	3/8" NUT		04
12	0503010743	1/4" X 1-1/4" BOLT		06




Item	Code	Description	See page	QT
01	0521052519	HOSE 1/2 X 4200 TC-TM GRAY / RED		01
01A	0501081073	HOSE 1/2 X 4200 TC-TM		01
01B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
01C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01D	0503018952	PLASTIC BOLT		06
02	0501081862	HOSE 1/2 X 5500 TC-TR		01
03	0501080269	1/2 X 3000 TR-TC HOSE ASSY		03
04	0501080092	1/2 X 700 TR-TC HOSE		02
05	0501080062	1/2 X 2000 TR-TC HOSE		05
06	0501080157	HOSE 1/2 X 1300 TC-TC		02
07	0501082304	1/2 X 1000 TR-TC HOSE		02
08	0501080618	1/2" X 2200 TR-TC HOSE		01
09	0501080511	HOSE		01
10	0521057429	HOSE 1/2 X 6700 TR-M GRAY/BLUE		01
10A	0501080265	TR-TM HOSE ASSY		01
10B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
10C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
10D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0591018521	LIFT SENSOR DRIVER		01
02	0591018520	SENSOR SUPPORT		01
03	0503010019	1/2" SPRING WASHER		03
04	0541012143	FLAT WASHER		03
05	0501011194	1/2" X 1-3/4" BOLT		01
06	0503012682	1/2" BSW NUT		01
07	0503013356	RIVET POP 3,2 X 10,0		01
08	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02



Item	Code	Description	See page	QT
01	0503035133	ADHESIVE LABEL USAP 3200 (192 X 437)		08
02	0503034782	LABEL ADHESIVE LOGO SMALLER TATU (03 MOUTHS)		08
03	0503035135	ADHESIVE LABEL USAP 3200 (185 X 320)		04
04	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		04
05	0503035134	ADHESIVE LABEL USAP 3200 (190 X 613)		02
06	0503034983	LOGO TATU MARCHESAN ADHESIVE LABEL 190 X 613		08
07	0503035136	ADHESIVE LABEL USAP 3200 (170 X 820)		03
08	0503035137	ADHESIVE LABEL USAP 3200 (165 X 850)		03
09	0503034970	LOGO TATU MARCHESAN (CSC) 155 X 1120		03
10	0503034971	ADHESIVE LABEL LOGO TATU MARCHESAN (CSC) 150 X 1130		03
11	0503034338	ADHESIVE LABEL		02
12	0503035445	ADHESIVE LABEL LEVER BLUE HANDLE		01
13	0503035443	ADHESIVE LABEL LEVER RED HANDLE		01
14	0503035442	ADHESIVE LABEL FLOATING LEVER		01
15	0503033415	ADHESIVE LABEL		02
16	0503033421	ADHESIVE LABEL 7 NUMBER FOR PLANTING		02
17	0503031565	ADHESIVE LABEL CARE		02
18	0503031428	READ MANUAL DECAL		01
19	0503031425	ADHESIVE LABEL ATTENTION		02
20	0503034078	LIFTING POINTS DECAL		02
21	0503031087	ADHESIVE LABEL		01
22	0503035316	LUBRICATED POINTS ADHESIVE LABEL		04
23	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
24	0503034249	ADHESIVE LABEL TABLE PLANTS		02
25	0503035494	ADHESIVE LABEL LEVER BLACK HANDLE		01




Item	Code	Description	See page	QT
01	0531051342	RAIL SUPPORT WITH FIXER	190	08
02	0591018643	5S TROUGH 50 X 50 X 2000		02
03	0501210021	GUTTER 7S 50 X 50 X 2900		01




Item	Code	Description	See page	QT
01	0591018525	GUTTER SUPPORT		01
02	0503011828	FLAT WASHER		02
03	0503010060	1/2 UNC G.5 ZN HEX NUT		02
04	0503010019	1/2" SPRING WASHER		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
06	0501011643	3/8 X 1"BOLT		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01

ASSEMBLY LADDER LEFT


0531050909



Item	Code	Description	See page	QT
01	0531061615	MOBILE LADDER		01
02	0531062145	LADDER GREATER RIGHT SUPPORT		01
03	0531062144	LADDER LARGER SUPPORT LEFT		01
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
08	0503010589	1/2" UNC SELF ADJUSTING NUT		02
09	0503010752	1/2" X 3.1/2" BOLT		02
10	0511065679	STAIR RIGHT LOCK		01
11	0591016037	SENSOR LOCK ROD		02
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
13	0503010337	5/16" NUT		01
14	0503010397	5/16" X 1-3/4" BOLT		01




Item	Code	Description	See page	QT
01	0503062391	FERTILIZER HOPPER		01
02	0521051407	FERTILIZER HOPPER FIXER	22	08
03	0531051168	LEFT SIDE SUPPORT 05 MOUTH WITH DISTRIBUTOR	193	01
04	0531050918	TOP SUPPORT MOUNTED LIFT EXTENSOR	29	02




Item	Code	Description	See page	QT
01	0521054282	BEARING	24	01
02	0503030275	AGRICULTURAL BEARING		05
03	0502012990	CONICA 14Z SQUARE GEAR		05
04	0591018303	SQUARE SHAFT 3/4 X 1740		01
05	0503011953	5/16" X 1" BOLT		20
06	0501010694	FLAT WASHER		20
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		20
08	0503010337	5/16" NUT		20
09	0531061864	SUPPORT SILO 05 MOUTH		01
10	0503010329	LOCK WASHER		02
11	0503010330	KM 9 LOCKNUT		04
12	0591015365	RING		04
13	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	28	03
14	0501053788	3/4 SQUARE AXLE FASTENER	27	02
15	0511065209	20Z GEAR		01
16	0503030303	SUPPORT WASHER		02
17	0551018055	22,65 X 60 SLEEVE		01
18	0501013519	FLAT WASHER		01
19	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	26	02
20	0591017775	ARTICULATION AXIS		02
21	0503010589	1/2" UNC SELF ADJUSTING NUT		02
22	0503011140	1/2" X 3-3/4" BOLT		02

LEFT ARM MONO WHEEL WHEEL


0531050896




Item	Code	Description	See page	QT
01	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
02	0503010019	1/2" SPRING WASHER		08
03	0503010060	1/2 UNC G.5 ZN HEX NUT		04
04	0531061431	REAR MONO WHEEL SUPPORT		01
05	0591015907	LARGER JUNCTION AXIS		02
06	0501111051	ARTICULATOR ARM		01
07	0591016194	AXLE JUNCTION		02
08	0503010007	3982/3920 ROLLER BEARING		01
09	0503010059	33287/33462 ROLLER BEARING		01
10	0503013106	SEAL 00085-B		01
11	0502040080	FLANGE NUT R.2.1/2 UN		01
12	0541013225	WHEEL BOX COVER		01
13	0503011444	SPRING WASHER		01
14	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		01
15	0503010002	1800 GREASE FITTING		01
16	0503017874	BOLT 1/2 UNC		04
17	0591016198	PIN 37,8 X 186		01
18	0501111050	REAR LIFT ARM		01
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
20	0531050023	HYDRAULIC CYLINDER 2 X 5 X 599 X 336	31	01
21	0531050897	MONO WHEEL LEFT	195	01
22	0531062131	LEFT SIDE FRAME		01
23	0591017921	BRONZE GLOVE 90.5 X 115 X 91		02
24	0551016274	HYDRAULIC CYLINDER ADAPTER		01




Item	Code	Description	See page	QT
01	0531062130	LEFT MONO WHEEL		01
02	0521059946	WHEEL ASSY WITH TIRE	33	01
03	0503019246	BOLT		01
04	0503011075	3/4" UNC NUT		01




Item	Code	Description	See page	QT
01	0591018304	FERTILIZER CONDUCTOR GUTTER		01
02	0591015578	CLAMP		05
03	0591015577	CONDUCTING TUBE		03
04	0501010942	3/8" X 1-1/4" BOLT		07
05	0503013357	3/8 SELF-ADJUSTING NUT		07
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		07
07	0591017994	SUPPORT RIGHT		01
08	0591018014	LEFT SUPPORT		01
09	0591016338	CONDUCTING TUBE		02



Item	Code	Description	See page	QT
01	0581018408	SUPPORT SCALE		08
02	0591016226	SHORT SUPPORT		02
03	0503011123	BOLT		04
04	0503013357	3/8 SELF-ADJUSTING NUT		04
05	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		02
06	0503013389	5/8\" SELF LOCKING NUT		02
07	0501012140	FLAT WASHER		02
08	0531062186	SIDE FRAME DUCT		02
09	0531062185	SIDE FRAME DUCT		04



Item	Code	Description	See page	QT
01	0531062207	TRANSMISSION LEFT SUPPORT		01
02	0591018040	SEPARATING GLOVE 16.5 X 32 X 70		03
03	0503013389	5/8" SELF LOCKING NUT		03
04	0531050982	SIDE BODY BEARING	52	02
05	0591018038	DRAGGLE GLOVE		01
06	0591018039	HEX SHAFT 3/4 X 750 CENTRAL AND SIDE		01
07	0503063380	SIDE ENCAPSULATED CHAIN		01
08	0501010163	5/8" X 4-1/2" BOLT		03
09	0503030303	SUPPORT WASHER		01
10	0501013518	FLAT WASHER		01
11	0503010237	3/8" X 1" BOLT		01
12	0511017406	FLAT WASHER Q20 X 33 X 3.00		02
13	0503010882	BOLT		02
14	0503013759	NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

