

ROW CROP PLANTERS

PST TRIO FLEX - FRAME 7450 - MH

Code: 0501093083
Series: S-0116
Revision: 00
Date Revision: AGOSTO/2021

PARTS CATALOGUE



MARCHESAN



PRODUCTS

Code	Description
0111260137	PST TRIO FLEX 7450/15E500 ESPECIAL S-0116
0111260138	PST TRIO FLEX 7450/15E500 ESPECIAL S-0116
0111260072	PST TRIO FLEX 7450/15E500 MH 2T DC20 S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.

INDEX

0909095931	FRAME ASSY	1
0511053196	PST JOINT FRAME	2
0511053188	RIGHT FRAME WITH WHEELED AXLE 7450	3
0511053189	LEFT FRAME WITH WHEELED AXLE 7450	4
0511053190	CENTRAL FRAME WITH WHEELED AXLE 6450/7285/7450/8460	5
0511059232	ASSEMBLY SPRING TRACTION	6
0511059265	WHEELED WITH SPRING TRACTION WITH TRANSMISSION	7
0511059262	WHEEL SUPPORT ASSY	8
0501058240	WHELL FASTENER WITH STRETCHER	9
0501058243	STRETCHER INTERMEDIATE RODE CURRENT	10
0501058244	STRETCHER FIXED CURRENT	11
0501058242	MOVIL CHAIN TENSIONER	12
0521043313	WHEELED WITH SPRING TRACTION WITHOUT TRANSMISSION	13
0511054336	SUPPORT WHEELED WITHOUT TRANSMISSION	14
0521051801	WHEEL WITH TIRE 7.00X16 WHEELED BOX WITHOUT TRANSMISSION	15
0503062159	WHEEL	16
0521051800	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	17
0909095199	HEADER FULL ASSEMBLY	18
0511055096	TRACTOR HITCH	19
0521051614	TURNBUCKLE SIDE UPPER	20
0521050133	TURNBUCKLE SIDE 755/480	21
0511059237	3 POINT TURNBUCKLE	22
0511058231	HYDRAULIC SYSTEM ASSEMBLY	23
0511053065	TRIPLE VALVE	24
0511058250	SET FERTILIZER SILO	25
0511053191	RIGHTH BEAM SUPPORT WITH DISTRIBUTOR	26
0511053192	LEFT BEAM SUPPORT WITH DISTRIBUTOR	27
0511053193	SUPPORT CENTER BEAM WITH DISTRIBUTOR	28
0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS	29
0503062169	SILO FERTILIZER 6 MOUTHS MOUNTED	30
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	31
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	32
0511058249	ASSEMBLY TRANSMISSION 7450	33
0501052560	AXLE MOTOR SLOW-MOVING ASSY	34
0511051434	TRANSMISSION DRIVING ASSY	35
0511047069	SIDE TRANSMISSION DRIVING	36
0511047070	LH SIDE TRANSMISSION DRIVING	37
0521043316	RIGHT GEAR BOX ASSY	38
0521043317	LEFT GEAR BOX ASSY	39
0501058212	SEMI MOUNTED RIGHT CHANGE	40
0501058213	LH GEAR BOX	41
0511059266	CLOSED BEARING	42
0501056443	BEARING ASSY GEAR BOX	43
0501048790	AXLE WITH LINK ASSY	44
0501054655	CHAIN TENSIONER ASSY	45
0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	46
0511059261	CHAIN TENSIONER	47
0521055217	LOWER CURRENT STRETCH	48
0501058254	UPPER SEED CHAIN TENSIONER	49
0521055216	BEARING WITH GEAR	50
0521055218	BEARING GEAR WITH DOUBLE	51
0521055214	BEARING GEAR WITH	52
0511058251	PLATFORM ASSEMBLY	53



MARCHESAN

INDEX


0511058252	HANDLE ASSEMBLY 7450	54
0511056536	ASSEMBLY LADDER	55
0511057512	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE	56
0501054649	SEQUENTIAL VALVE ASSY	57
0511058431	HYDRAULIC CYLINDER	58
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	59
0511053194	HYDRAULIC MARKER	60
0511058449	HYDRAULIC CYLINDER	61
0521052827	AXIS TRANSMISSION SEED ASSY 7450	62
0503062206	CARDAN TERMINAL	63
0521052803	REAR LIGHT ASSEMBLY	64
0521052792	MOUNTED REAR LIGHT	65
0511058229	CYLINDER ASSEMBLY	66
0511058406	HYDRAULIC CYLINDER	67
0511058235	MANUAL DOOR ASSEMBLY	68
0511058253	LABEL SET	69
0501050633	MARKER DISC ASSY LINE	70
0511053904	DISC LINE MARKER	71
0511056736	HOSE SUPPORT	72
0909092513	FERTILZER SEED ROW ASSY	73
0501059834	FRONT LINE SEED SHORT LEFT CARDAN	74
0501059833	FRONT LINE SEED SHORT RIGHT CARDAN	75
0501059835	FRONT LINE SEED LONG RIGHT CARDAN	76
0501059836	FRONT LINE SEED LONG LEFT CARDAN	77
0511054635	BEARING AXLE BODY	78
0511057159	TRANSMISSION BOX SEED LINE	79
0511050609	BEARING WITH 17Z GEAR ASSY	80
0511055260	SEED ROW CHAIN TENSIONER	81
0511059264	BEARING WITH AXLE	82
0501052769	BEARING WITH 17Z GEAR	83
0511050617	FRONT SEED ROW BEARING	84
0501059326	UNIVERSAL JOINT AXLE	85
0511050611	5/8" HEX AXLE BEARING	86
0501059363	5/8" HEX AXLE BEARING	87
0511056621	REAR RIGHT SEED LINE	88
0511056622	LEFT REAR LINE SEED	89
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	90
0511056586	15 X 15 SEED DDD LEFT	91
0511052301	SUPPORT DDD 15 RIGHT	92
0511053173	CUBE LOW RIGHT WITH DISC 15	93
0511053172	LEFT LOW CUBE WITH DISC 15	94
0511052302	LH SUPPORT DDD GUIDE	95
0511057017	SEED SYSTEM ASSY	96
0501051094	SEED DISTRIB ASSY WITH DOUB PULLEY	97
0501051119	DOUBLE PULLEY ROCKER'S	98
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	99
0511058650	SEMI-MOUNTED DEPTH CONTROL	100
0501052538	DEPTH BAND WITH ARMS	101
0511054333	COMPACT WHEEL RIGHT WITH BEARING	102
0511054334	COMPACT WHEEL LEFT WITH BEARING	103
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	104
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	105
0501052297	DEPTH WHEELS REGULATOR ASSY	106
0501052908	COMPACTOR WHEEL WITH BEARING	107
0501052627	ASSY DEPTH WHEEL BOX	108



MARCHESAN

INDEX

0521044269	PRESS WHEELS/DEPTH ASSY	109
0511055326	DEPTH CONTROL PRESS WHEEL ASSY	110
0511055327	COMPACTING WHEEL V ASSY RUBBER	111
0501059228	ADJUSTMENT LEVER	112
0511055328	DEPTH WHEEL SYSTEM	113
0511055329	LEFT DEPTH WHEEL	114
0511055627	WHEEL ASSY RAYED	115
0521044460	SYSTEM DEPTH / COMPACTOR	116
0511055690	WHEEL SISTEM	117
0511055628	DEPTH WHEEL SYSTEM	118
0511055629	DEPTH WHEEL SYSTEM	119
0521046501	DEPTH CONTROL AND PRESS WHEEL WITH FAST ADJUSTING	120
0511059462	DEPTH CONTROL WITH FAST ADJUSTMENT	121
0511050077	WHEEL STRIPED	122
0501056769	DEPTH WHEELS REGULATOR ASSY	123
0511059463	COMFORT WHEEL WITH FAST ADJUSTMENT	124
0511052287	DEPTH WHEEL HUB ASSY	125
0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	126
0511053250	SHORT ARM FERTILIZER LINE WITH DDD LEFT	127
0511053251	ARM LONG FERTILIZER LINE WITH DDD RIGHT	128
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	129
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	130
0501058423	FERTILIZER ROD SPRING ROW	131
0511058619	DISC CUT 20 SHORT LINE	132
0511058648	BOX WITH DISC BLADE 20"	133
0511058617	DISC CUT 18 SHORT LINE	134
0511056909	DISC BOX CUT WITHOUT THE DISC	135
0511058620	DISC CUT 20 LONG LINE	136
0511058618	DISC CUT 18 LONG LINE	137
0511057542	HDA	138
0511057533	ROD WITH POINT FLANGE WASHER SPRING	139
0501110231	SCARIFIER HEAD WITH SPIKE 0061	140
0501050120	LARGER WALKING BEAM ASSY	141
0511052024	FAST CLOSING SET	142




Item	Code	Description	See page	QT
01	0511053196	PST JOINT FRAME	2	01
02	0521064285	LOCK LOWER FRAME		02
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		02
04	0503010002	1800 GREASE FITTING		02
05	0503010003	1845 GREASE FITTING		08
06	0503010004	1890 GREASE FITTING		02
07	0511059232	ASSEMBLY SPRING TRACTION	6	02
08	0511059265	WHEELED WITH SPRING TRACTION WITH 7 TRANSMISSION		04
09	0521043313	WHEELED WITH SPRING TRACTION WITHOUT TRANSMISSION	13	02
10	0909095199	HEADER FULL ASSEMBLY	18	01
11	0511058231	HYDRAULIC SYSTEM ASSEMBLY	23	01
12	0511058250	SET FERTILIZER SILO	25	01
13	0511058249	ASSEMBLY TRANSMISSION 7450	33	01
14	0511058251	PLATFORM ASSEMBLY	53	01
15	0511058252	HANDLE ASSEMBLY 7450	54	01
16	0511054971	RESTING ASSEMBLY		02
17	0511056536	ASSEMBLY LADDER	55	02
18	0511057512	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE	56	01
18.	0511053194	HYDRAULIC MARKER	60	01
19	0521052827	AXIS TRANSMISSION SEED ASSY 7450	62	01
20	0521052803	REAR LIGHT ASSEMBLY	64	01
21	0511058229	CYLINDER ASSEMBLY	66	01
22	0511058235	MANUAL DOOR ASSEMBLY	68	01
23	0511058253	LABEL SET	69	01
24	0501050633	MARKER DISC ASSY LINE	70	02
25	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
26	0501065677	STRUT		02
27	0501047895	ROD STOP		03
28	0501047885	ROD STOP		03




FRAME ASSY

0909095931


Item	Code	Description	See page	QT
29	0501047886	ROD STOP		03
30	0501047887	ROD STOP		03
31	0511056736	HOSE SUPPORT	72	01
32	0521013022	TRANSPORT LOCK		03
33	0503030168	HAIR PIN		03
34	0501068994	0.3" X 3.1" LOCK PIN		03
35	0521066304	HOSE GUIDE		01
36	0503019262	SOAP DISH VACUUM		01
37	0503010780	N-2050 AMENDMENT		02
38	0503011750	AMENDMENT WITH LOCK		06
39	0503011751	REDUCTION		06
40	0503010951	REDUCTION		04
41	0503010246	CLAMP		15
42	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02
43	0503013816	5/16" LOCKNUT		02
44	0909092513	FERTILZER SEED ROW ASSY	73	15




Item	Code	Description	See page	QT
01	0511053188	RIGHT FRAME WITH WHEELED AXLE 7450	3	01
02	0511053189	LEFT FRAME WITH WHEELED AXLE 7450	4	01
03	0511053190	CENTRAL FRAME WITH WHEELED AXLE 5 6450/7285/7450/8460	5	01
04	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	3/4" UNC BOLT		18
07	0571010094	SLEEVE FLANGE		06
08	0521063912	PIVOT SHAFT		02
09	0571013510	LOCK AXLE		02
10	0503030085	LOCK PIN		02
11	0571010095	FLAT WASHER		02
12	0503010365	NUT		04
13	0503011444	SPRING WASHER		04
14	0502012698	CLAMP		04
15	0501011643	3/8 X 1" BOLT		14
16	0503010025	3/8" SPRING WASHER		14
17	0503010026	3/8" NUT		14
18	0521063003	LOCK PIN		02
19	0571010969	LOCK SLEEVE FRAME		02
20	0503013627	1.1/2 SPRING WASHER		02
21	0501010110	1.1/2" NUT		02
22	0581018018	TROUGH 24 X 50 X 1255		02
23	0581018019	TROUGH 24 X 50 X 1070		02
24	0581015857	GUTTER 24 X 50 X 1080		02




Item	Code	Description	See page	QT
01	0521064009	RIGHT FRAME PST TRIO 15		01
02	0521064023	ARTICLES AXLE RIGHT ROLLED		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521064010	LEFT FRAME PST TRIO 15		01
02	0521064021	ARTICLES AXLE LEFT ROLLED		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521064011	CENTRAL FRAME PST TRIO 15		01
02	0521064022	CENTRAL ARTICLES AXLE ROLLED		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		05
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		10
03	0501012140	FLAT WASHER		10




Item	Code	Description	See page	QT
01	0511059262	WHEEL SUPPORT ASSY	8	01
02	0501058240	WHELL FASTENER WITH STRETCHER	9	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION	01	
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT	01	
03	0531016887	CARRYING WHEEL AXLE ARM	01	
04	0503010523	1/4" X 2" COTTERPIN	01	
05	0503010003	1845 GREASE FITTING	01	
06	0501058241	TENSIONER CHAIN SUPPORT	01	
07	0511052770	WHEEL WITH TIRE 7.00X16 ASSY WHEELED BOX	01	
08	0503018981	BOLT	02	
09	0503010027	5/8" SPRING WASHER	04	
10	0521012190	AXLE LOCK	01	
11	0581011124	WHEELED COVER	01	
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN	01	
13	0551017715	FLAT WASHER	02	
14	0503013030	5/8" X 3.1/4" BOLT	01	
15	0511050681	TRACTION SPRING	01	
15A	0503031681	2.1" X 7.78" EXTENSION SPRING	01	
15B	0561016062	SPRING HITCH	02	




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	STRETCHER INTERMEDIATE RODE CURRENT	10	01
07	0501058244	STRETCHER FIXED CURRENT	11	01
08	0501058242	MOVIL CHAIN TENSIONER	12	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING		01
02A	0503012882	BEARING		01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02C	0502012853	GEAR		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TIGHTENER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING		01
02A	0503012882	BEARING		01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02C	0502012853	GEAR		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN UPPER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING		01
02A	0503012882	BEARING		01
02B	0503011945	503050 CLAMPING RING (FOR AXLE)		01
02C	0502012853	GEAR		01
03	0551018240	SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511054336	SUPPORT WHEELED WITHOUT TRANSMISSION	14	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0521061566	CARRYING WHEEL ARM TRACTION	01	
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT	01	
03	0531016887	CARRYING WHEEL AXLE ARM	01	
04	0503010523	1/4" X 2" COTTERPIN	01	
05	0503010003	1845 GREASE FITTING	01	
06	0503018981	BOLT	02	
07	0503010027	5/8" SPRING WASHER	02	
08	0521012190	AXLE LOCK	02	
09	0521051801	WHEEL WITH TIRE 7.00X16 WHEELED BOX 15 WITHOUT TRANSMISSION	01	




Item	Code	Description	See page	QT
01	0503062159	WHEEL	16	01
02	0521051800	WHEELED WITHOUT TRANSMISSION WITHOUT TIRE	17	01



Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503012114	7.00 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0503010328	25590/25523 ROLLER BEARING		02
02	0503010804	00547-B SEAL		02
03	0521012185	TRANSM AXLE CARRYING-WHEEL		01
04	0503010330	KM 9 LOCKNUT		01
05	0511015949	LOCK NUT		01
06	0503010329	LOCK WASHER		01
07	0503010002	1800 GREASE FITTING		01
08	0501110721	WHEEL HUB WITH SCREW / NUTS		01
08A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
08B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
08C	0503016516	5/8 UNF CONIC NUT		06




Item	Code	Description	See page	6850	7450	7860	7960	8160	8460
01	0521066289	FRONT HEADER 5750/6350/6850		001	001	001	001	001	001
02	0521066290	INTERMEDIATE HEAD 5750/6850/7860/8160		001	000	001	000	001	000
02..	0521067075	INTERMEDIATE HEAD 6450/7285/7350/7450/8460		000	001	000	000	000	001
02..	0521067151	INTERMEDIATE HEAD 5850/7960		000	000	000	001	000	000
03	0571019949	JUNCTION SHAFT		006	006	006	006	006	006
04	0503030119	LOCK PIN		010	010	010	010	010	010
05	0511055096	TRACTOR HITCH	19	001	001	001	001	001	001
06	0511053179	TRACTOR HITCH AXLE		001	001	001	001	001	001
06A	0521064036	TRACTOR HITCH AXLE		001	001	001	001	001	001
06B	0503030012	HAIR PIN		001	001	001	001	001	001
07	0503014120	CHAIN		001	001	001	001	001	001
08	0521051614	TURNBUCKLE SIDE UPPER	20	002	002	002	002	002	002
09	0521010571	COUPLING SHAFT		004	004	004	004	004	004
10	0503030085	LOCK PIN		006	006	006	006	006	006
11	0521050133	TURNBUCKLE SIDE 755/480	21	002	002	002	002	002	002
12	0571019951	JUNCTION SHAFT		003	003	003	003	003	003
13	0503010523	1/4" X 2" COTTERPIN		004	004	004	004	004	004
14	0503034772	BOX		001	001	001	001	001	001
15	0521068652	TOOLS BOX SUPPORT		001	001	001	001	001	001
16	0501011643	3/8 X 1" BOLT		004	004	004	004	004	004
17	0503010025	3/8" SPRING WASHER		004	004	004	004	004	004
18	0503010026	3/8" NUT		004	004	004	004	004	004
19	0581017000	PLATE INTERMEDIARY		002	002	002	002	002	002
20	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		004	004	004	004	004	004
21	0503010025	3/8" SPRING WASHER		004	004	004	004	004	004
22	0501010984	FLAT WASHER		004	004	004	004	004	004
23	0503014321	CABLE STEEL SHACKLE		002	002	002	002	002	002
24	0502010584	CARRYING-WHEELS SUPPORT FIXER		008	008	008	008	008	008
25	0503016485	BOLT 3/4		016	016	016	016	016	016
26	0501010322	FLAT WASHER		032	032	032	032	032	032
27	0503010152	3/4" SELF LOCKING NUT		016	016	016	016	016	016


Item	Code	Description	See page	6850	7450	7860	7960	8160	8460
28	0521067716	FIXER TUBE		004	004	004	004	004	004
29	0511059237	3 POINT TURNBUCKLE	22	001	001	001	001	001	001
30	0571019950	COUPLING SHAFT		001	001	001	001	001	001
31	0521045756	HYDRAULIC CYLINDER		001	001	001	001	001	001
32	0521010779	31.75 X 95 COUPLING SHAFT		001	001	001	001	001	001
33	0521010581	0.9" X 4.9" COUPLING SHAFT		001	001	001	001	001	001
34	0531016049	FLAT WASHER		002	002	002	002	002	002
35	0503014820	COROTE BLACK WATER		001	001	001	001	001	001
36	0521068651	SUPPORT BOX		001	001	001	001	001	001




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0502011195	ADJUSTMENT NUT BODY		01
02	0521068096	EXTENSOR R.1.1 / 2 UNC RIGHT		01
03	0521068095	EXTENSOR R.1.1/2 UNC LEFT		01
04	0541018672	COUNTERNUT		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521065193	TURNBUCKLE AXLE		01
02	0521067392	FIXED BRACKET		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03




Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0511061880	SIDE RIGHT RATCHET		01
03	0511061881	RATCHET FOLLOWER		01
04	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
05	0503011179	3/8" X 2-1/4" BOLT		05
06	0503010025	3/8" SPRING WASHER		05
07	0503010026	3/8" NUT		05
08	0503010002	1800 GREASE FITTING		02
09	0531010264	SIDE RATCHET		01
10	0521066919	3-POINT EXTENSOR RIGHT FUSE		01
11	0521066337	LEFT EXTENSOR 3 SPIKE		01



Item	Code	Description	See page	QT
001	0571013472	FIXER BODY VALVE		01
002	0511053065	TRIPLE VALVE	24	01
003	0503010237	3/8" X 1" BOLT		02
004	0503011179	3/8" X 2-1/4" BOLT		02
005	0501010984	FLAT WASHER		04
006	0503010025	3/8" SPRING WASHER		02
007	0503010026	3/8" NUT		02
008	0531011180	UPPER BODY CLIP		02
009	0521063909	DUCT SEAL OIL		01
010	0531013922	0.6" X 0.8" X 1" SLEEVE		02
011	0531011180	UPPER BODY CLIP		02
012	0511057092	HOSE KIT SYSTEM HYDRAULIC		01
012A	0501080406	3/8" X 23" TR-TC HOSE		01
012B	0501080150	HOSE ASSY		01
012C	0501081930	HOSE		01
012D	0501081646	TC-TC HOSE ASSY		03
012E	0501081073	HOSE 1/2 X 4200 TC-TM		02
013	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	59	02
013A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
013B	0503011882	MALE QUICK COUPLER CAP		01
014	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
015	0571017774	SPRING PROTECTION QUICK HOSE		01
016	0502012702	BODY SUPPORT CLAMP		12
017	0503010244	7/16" NUT		04
018	0503010180	7/16" SPRING WASHER		08
019	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
020	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
021	0503013100	NYLON CLAMP		02




Item	Code	Description	See page	QT
01	0503016524	DIVIDER VALVE		01
02	0551012400	7/8" UNF NIPPLE		01
03	0501011460	7/8 NF REDUCTION NIPPLE		03
04	0503010190	2-114 N 3006-9B O'RING		04




Item	Code	Description	See page	QT
01	0511053191	RIGH BEAM SUPPORT WITH DISTRIBUITOR	26	01
02	0511053192	LEFT BEAM SUPPORT WITH DISTRIBUITOR	27	01
03	0511053193	SUPPORT CENTER BEAM WITH DISTRIBUITOR	28	01
04	0503010849	3/8" X 1-1/2" BOLT		16
05	0501010984	FLAT WASHER		32
06	0503010025	3/8" SPRING WASHER		16
07	0503010026	3/8" NUT		16
08	0503034396	FERTILIZER SIDE COVER		15
09	0503010362	1/8" X 1.1/4" COTTERPIN		15
10	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS	29	02
11	0503062169	SILO FERTILIZER 6 MOUTHS MOUNTED	30	01
12	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		06
13	0503010849	3/8" X 1-1/2" BOLT		12
14	0501010984	FLAT WASHER		24
15	0503010025	3/8" SPRING WASHER		12
16	0503010026	3/8" NUT		12
17	0503011957	NYLON LUG		02
18	0503010371	5/16" X 1" BOLT		04
19	0503010179	5/16" ZN SPRING WASHER		04
20	0503010337	5/16" NUT		04
21	0503062208	CARDAN TERMINAL		02
22	0503011855	0.2" X 1.8" SPRING PIN		04
23	0503030331	1.2" X 1.2" X 12.2" HOSE		02
24	0503010243	CLAMP		04
25	0551018055	22,65 X 60 SLEEVE		02
26	0521014167	CONE LOCK		02
27	0551019156	GEAR BOX LEVER LOCK		02
28	0503011953	5/16" X 1" BOLT		04
29	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
30	0503010179	5/16" ZN SPRING WASHER		04
31	0503010337	5/16" NUT		04


Item	Code	Description	See page	QT
32	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
33	0561016797	SLEEVE UNION LEVER		02
34	0561016800	ARM/DISARMENT LEVER		02
35	0511017302	FLAT WASHER		02
36	0503010019	1/2" SPRING WASHER		02
37	0503010060	1/2" NUT		02
38	0581011541	ARTICULAT SLEEVE		02
39	0511069676	INNER LEVER		02
40	0511017302	FLAT WASHER		02
41	0503011082	C1/2" X 1.3/4" SCREW		02
42	0511017302	FLAT WASHER		02
43	0503010019	1/2" SPRING WASHER		02
44	0503010060	1/2" NUT		02
45	0501013518	FLAT WASHER		02
46	0503010140	1/8" X 3/4" COTTERPIN		02
47	0511069678	LH LOWER LEVER		02
48	0501013518	FLAT WASHER		02
49	0503010140	1/8" X 3/4" COTTERPIN		04
50	0551019159	LEVER FIXER BODY		02
51	0561016468	FASTENER		02
52	0503011336	1/2" HEX SELF ADJUSTING NUT		04
53	0571013471	PLATFORM FIXER LOCK		03
54	0501010096	3/8" X 2" BOLT		03
55	0501010984	FLAT WASHER		03
56	0503013357	3/8" SELF-ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0521066219	FERTILIZER BEAN RIGHT SUPPORT		01
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	31	01
03	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	32	04
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		05
10	0502012990	CONICA 14Z SQUARE GEAR		05
11	0571019663	SQUARE SHAFT		01
12	0571015966	LOCK AXLE		01
13	0503010421	5/16" X 1-1/2" BOLT		02
14	0503011444	SPRING WASHER		02
15	0503010337	5/16" NUT		02
16	0501110392	SILO SUPPORT BEARING		01
17	0521012485	GEAR BOX BEARING AGRICUTURAL		01
18	0503010003	1845 GREASE FITTING		01
19	0503011953	5/16" X 1" BOLT		02
20	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
21	0521011039	FLAT WASHER		02
22	0503011444	SPRING WASHER		02
23	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521066220	FERTILIZER BEAN LEFT SUPPORT		01
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	31	04
03	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	32	01
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		05
10	0502012990	CONICA 14Z SQUARE GEAR		05
11	0571019663	SQUARE SHAFT		01
12	0571015966	LOCK AXLE		01
13	0503010421	5/16" X 1-1/2" BOLT		02
14	0503011444	SPRING WASHER		02
15	0503010337	5/16" NUT		02
16	0501110392	SILO SUPPORT BEARING		01
17	0521012485	GEAR BOX BEARING AGRICUTURAL		01
18	0503010003	1845 GREASE FITTING		01
19	0503011953	5/16" X 1" BOLT		02
20	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
21	0521011039	FLAT WASHER		02
22	0503011444	SPRING WASHER		02
23	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521065393	CENTER FERTILIZER BEAM SUPPORT		01
02	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	31	03
03	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	32	02
04	0511062163	FERTILIZER BEAM LOWER COVER		01
05	0501010942	3/8" X 1-1/4" BOLT		24
06	0503011443	3/8" SPRING WASHER		24
07	0503010026	3/8" NUT		24
08	0521014167	CONE LOCK		04
09	0503030275	AGRICULTURAL BEARING		05
10	0502012990	CONICA 14Z SQUARE GEAR		05
11	0581010699	SQUARE SHAFT		01
12	0581010700	SQUARE SHAFT		01
13	0571015966	LOCK AXLE		02
14	0503010421	5/16" X 1-1/2" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0503033577	BEAN FERTILIZ 5 MOUTHS		01
02	0503033578	FERTILIZER BEAM LOCK		01
03	0503032136	FERTILIZER BEAM COVER		02
04	0503032052	COVER PIVOT SHAFT		04
05	0503032051	COVER PIVOT SHAFT		08
06	0503032054	FLAT WASHER (INOX)		02
07	0503032053	BOLT C.A.S.I		02
08	0503032055	COVER		02




Item	Code	Description	See page	QT
01	0503033801	BEAM FERTILIZER		01
02	0503033578	FERTILIZER BEAM LOCK		02
03	0503032134	FERTILIZER BEAM COVER		03
04	0503032052	COVER PIVOT SHAFT		06
05	0503032051	COVER PIVOT SHAFT		12
06	0503032054	FLAT WASHER (INOX)		04
07	0503032053	BOLT C.A.S.I		04
08	0503032055	COVER		04



Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" COTTERPIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2" NUT		08
09	0571014439	MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2" NUT		04
14	0501052560	AXLE MOTOR SLOW-MOVING ASSY	34	02
15	0511051434	TRANSMISSION DRIVING ASSY	35	04
16	0511047069	SIDE TRANSMISSION DRIVING	36	01
17	0511047070	LH SIDE TRANSMISSION DRIVING	37	01
18	0521043316	RIGHT GEAR BOX ASSY	38	01
19	0521043317	LEFT GEAR BOX ASSY	39	01
20	0503014734	BOLT		06
21	0503010920	1/2" X 1.1/2" BOLT		04
22	0511017302	FLAT WASHER		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2" NUT		10
25	0521064448	GEAR		02
26	0511059261	CHAIN TENSIONER	47	04
27	0521055217	LOWER CURRENT STRETCH	48	02
28	0501058254	UPPER SEED CHAIN TENSIONER	49	02
29	0521055216	BEARING WITH GEAR	50	02
30	0521055218	BEARING GEAR WITH DOUBLE	51	02
31	0521055214	BEARING GEAR WITH	52	02


Item	Code	Description	See page	QT
32	0503012204	40-1 CHAIN X 82 LINK + RED		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	5/16" X 3/4" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02



Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLLEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	40	01
02	0511059266	CLOSED BEARING	42	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	BEARING ASSY GEAR BOX	43	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH LINK ASSY	44	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	45	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	46	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	41	01
02	0511059266	CLOSED BEARING	42	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	BEARING ASSY GEAR BOX	43	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH LINK ASSY	44	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	45	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	46	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	1 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0503031805	1 1/2" GEAR		01
02	0511017302	FLAT WASHER		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0511062169	21Z P 1/2" GEAR		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0521018933	FERT CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501011234	5/8" X 3" BOLT		01
02	0531017086	50 AXLETIGHTENER		01
03	0511062169	21Z P 1/2" GEAR		01
04	0503019356	BEARING 6005 2RS1		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0503016460	5/8" X 4.1/2" BOLT		01
02	0551019175	DOUBLE GEAR AXLE		01
03	0503019356	BEARING 6005 2RS1		02
04	0511069680	20Z X 28Z DOBLE GEAR		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511063106	20Z AXLE BEARING DOBLE		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521055215	DOUBLE TRANSMISSION BEARING		01
04	0503010365	NUT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	06	
02	0503010849	3/8" X 1-1/2" BOLT	10	
03	0501010984	FLAT WASHER	20	
04	0503010025	3/8" SPRING WASHER	10	
05	0503010026	3/8" NUT	10	
06	0521064015	PLATFORM RIGHT SIDE	01	
07	0521064016	PLATFORM LEFT SIDE	01	
08	0521064017	PLATFORM CENTER	01	
09	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	06	
10	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
11	0503011333	COVER FIXER	03	
12	0503010274	5/32"X 2" COTTERPIN	03	
13	0502012740	PLATFORM RIGHT FIXER SUPPORT	02	
14	0502012739	PLATFORM LEFT FIXER SUPPORT	01	
15	0571017990	PLATFORM ENHANCEMENT PROTECTION	02	
16	0501010942	3/8" X 1-1/4" BOLT	04	
17	0501010984	FLAT WASHER	04	
18	0503010025	3/8" SPRING WASHER	04	
19	0503010026	3/8" NUT	04	




Item	Code	Description	See page	QT
01	0521064019	SIDE HANDRAIL	02	
02	0521064018	CENTRAL HANDRAIL	01	
03	0503010395	1/2" X 1-1/4" BOLT	04	
04	0503010019	1/2" SPRING WASHER	12	
05	0503010060	1/2" NUT	12	
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	06	
07	0503011082	C1/2" X 1.3/4" SCREW	02	
08	0551019884	45 X 50 X 3/8 FASTENER	08	
09	0571017991	CHAIN FIXER HANDRAIL	08	
10	0503013357	3/8" SELF-ADJUSTING NUT	16	
11	0503034094	22 TWISTED CHAIN	04	




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501054649	SEQUENTIAL VALVE ASSY	57	01
02	0511058431	HYDRAULIC CYLINDER	58	01
03	0511058431	HYDRAULIC CYLINDER	58	01
04	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
05	0501068994	0.3" X 3.1" LOCK PIN		02
06	0503030168	HAIR PIN		02
07	0511057094	HYDRAULIC HOSE MARKER ASSY 6450		01
07A	0501080783	HOSE 3/8 X 5000 TR-TR		02
07B	0501081659	HOSE 3/8 X 5300 TR-TR 2T		02
07C	0521052512	HOSE 3/8 X 5200 TC-TM PURPLE / RED		01
07CA	0501081980	HOSE 3/8 X 5200 TC-TM		01
07CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
07CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
07CD	0503018952	PLASTIC BOLT		06
07D	0521052513	HOSE 3/8 X 5200 TC-TM PURPLE / BLUE		01
07DA	0501081980	HOSE 3/8 X 5200 TC-TM		01
07DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
07DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
07DE	0503018952	PLASTIC BOLT		06
08	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	59	02
09	0511018012	HIDRAULIC ADAPTER		04




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02



Item	Code	Description	See page	QT
01	0501067700	2.5" X 25" CYLINDER CASE		01
02	0521066632	EXTENDER		01
03	0503030384	CON PLUG N-001		02
04	0502012837	PISTON		01
05	0503018005	RING		01
06	0503011109	2-119 N 3006-9B O'RING		01
07	0503010163	D-1500 SCRAPER RING		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503018004	RING		01
11	0503018003	GASKET		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503011336	1/2" HEX SELF ADJUSTING NUT		02
05	0511061811	ROW MARKER ARM		02
06	0521061655	BOLT 5/8 UNC X 320 MM		02
07	0521010479	SLEEVE ARTICULATION		04
08	0511058449	HYDRAULIC CYLINDER	61	02
09	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
10	0503010523	1/4" X 2" COTTERPIN		02
11	0511015779	1" X 4.2" AXLE		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
14	0501068994	0.3" X 3.1" LOCK PIN		02
15	0503030168	HAIR PIN		02
16	0501066949	1235 TURNBUCKLE		02
17	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
18	0501054649	SEQUENTIAL VALVE ASSY	57	01
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
20	0501010984	FLAT WASHER		02
21	0503010025	3/8" SPRING WASHER		02
22	0511057094	HYDRAULIC HOSE MARKER ASSY 6450		01
22A	0501081804	HOSE ASSY		02
22B	0501081093	3/8" X 188.9" TR-TC HOSE ASSY		02
22C	0501080878	3/8 X 4200 TC-TM HOSE ASSY		02
23	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	59	02
23A	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
23B	0503011882	MALE QUICK COUPLER CAP		01
24	0502012702	BODY SUPPORT CLAMP		02
25	0531011180	UPPER BODY CLIP		08
26	0503010180	7/16" SPRING WASHER		02




PST TRIO FLEX - FRAME 7450 - MH
HYDRAULIC MARKER

Page 60
0511053194


Item	Code	Description	See page	QT
27	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
28	0503012412	5/8 UNC SELF LOCKING NUT		08
29	0501012140	FLAT WASHER		04
30	0503010920	1/2" X 1.1/2" BOLT		02
31	0503010019	1/2" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02




Item	Code	Description	See page	QT
01	0571013726	5/8 X 800 HEX AXLE		01
02	0571013724	5/8 X 1250 HEX AXLE		01
03	0571013725	5/8 X 2190 HEX AXLE		02
04	0503062206	CARDAN TERMINAL	63	02
05	0561014215	BEARING COVER LOWER ROW FRAME		02
06	0502040534	SPRING GUIDE BUSHING LOCK		08
07	0501018535	1/2 X 1 BOLT		08




Item	Code	Description	See page	QT
01	0503062206	CARDAN TERMINAL	63	01




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		16
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		03
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	65	03
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		15




Item	Code	Description	See page	QT
01	0503018738	LIGHTHOUSE		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	5/16" ZN SPRING WASHER		04
08	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	67	03
02	0521012538	1.2" X 3.5" COUPLING SHAFT		03
03	0521012536	COUPLING SHAFT		03
04	0503010523	1/4" X 2" COTTERPIN		06
05	0531012565	SLEEVE 16,3X 30 X 88		03
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		03
07	0503010027	5/8" SPRING WASHER		03
08	0503010013	5/8" NUT		03




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
05	0503010179	5/16" ZN SPRING WASHER		01
07	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0503033900	ADHESIVE LABEL	03	
02	0503033854	ADHESIVE LABEL	03	
03	0503033853	ADHESIVE LABEL	02	
04	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING	02	
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	02	
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
07	0503033421	ADHESIVE LABEL 7 NUMBER FOR PLANTING	02	
08	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
09	0503033008	ADHESIVE LABEL	02	
10	0503031428	READ MANUAL DECAL	01	
11	0503031942	ADHESIVE LABEL	01	
12	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS	02	
13	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
14	0503031565	ADHESIVE LABEL CARE	02	
15	0503031566	ADHESIVE LABEL	02	
16	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
17	0503031425	ADHESIVE LABEL ATTENTION	02	
18	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO	02	
19	0503031669	ADHESIVE LABEL	01	
20	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
21	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
22	0503032930	ADHESIVE LABEL DANGER	08	
23	0503031087	ADHESIVE LABEL	01	
24	0503034078	LIFTING POINTS DECAL	03	
25	0503034003	SERIAL NUMBER TAG 61 X 118	01	
26	0503010001	3.2 X 5.5 RIVET	04	
27	0503032979	ADHESIVE LABEL LETTERS A B C D	02	




Item	Code	Description	See page	QT
01	0511053904	DISC LINE MARKER	71	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01



Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9\" X 2\" X 0.02\" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4\" UNF X 1/2\" BOLT		03
12	0503010878	5/8\" SELF ALIGNING NUT		01
13	0503010691	1/4\" GREASE FITTING		01
14	0503010358	5/16\" X 5/8\" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16\" NUT		04




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01



Item	Code	Description	See page	QT
01	0501059834	FRONT LINE SEED SHORT LEFT CARDAN	74	01
02	0501059833	FRONT LINE SEED SHORT RIGHT CARDAN	75	01
03	0501059835	FRONT LINE SEED LONG RIGHT CARDAN	76	01
04	0501059836	FRONT LINE SEED LONG LEFT CARDAN	77	01
05	0511056621	REAR RIGHT SEED LINE	88	01
06	0511056622	LEFT REAR LINE SEED	89	01
07	0511057017	SEED SYSTEM ASSY	96	01
08	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	99	01
09	0521044269	PRESS WHEELS/DEPTH ASSY	109	01
10	0521044460	SYSTEM DEPTH / COMPACTOR	116	01
11	0521046501	DEPTH CONTROL AND PRESS WHEEL WITH FAST ADJUSTING	120	01
12	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	126	01
13	0511053250	SHORT ARM FERTILIZER LINE WITH DDD LEFT	127	01
14	0511053251	ARM LONG FERTILIZER LINE WITH DDD RIGHT	128	01
15	0501058423	FERTILIZER ROD SPRING ROW	131	01
16	0511058619	DISC CUT 20 SHORT LINE	132	01
17	0511058617	DISC CUT 18 SHORT LINE	134	01
18	0511058620	DISC CUT 20 LONG LINE	136	01
19	0511058618	DISC CUT 18 LONG LINE	137	01
20	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	129	01
21	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	130	01
22	0503030331	1.2" X 1.2" X 12.2" HOSE		01
23	0503010243	CLAMP		02
24	0501010066	3/4" X 9" BOLT		01
25	0521017831	SUPPORT SLEEVE SPACER		01
26	0511017232	FLAT WASHER		01
27	0503011255	3/4" LOCK NUT		01
28	0503030391	RIGHT FERTILIZER NOZZLE		01
29	0503030392	LEFT FERTILIZER NOZZLE		01
30	0503031050	CURVED CONDUCTOR		01
31	0503010246	CLAMP		01

Item	Code	Description	See page	QT
32	0503031145	2" X 2" X 20" HOSE		01
33	0503031076	2" HOSE CLAMP		01
34	0503010905	1/2" X 2-1/4" BOLT		02
35	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
36	0503010019	1/2" SPRING WASHER		04
37	0503010060	1/2" NUT		04
38	0531013600	PRESS ADJUSTMENT LEVER		01
39	0511057542	HDA	138	01
40	0581010082	FERTILIZER SOCKET RIGHT		01
41	0581010083	FERTILIZER SOCKET LEFT		01
42	0521018501	TURNBUCKLE LEVER		01
43	0501110231	SCARIFIER HEAD WITH SPIKE 0061	140	01
44	0511017969	0.1" SPACING PLATE		01
45	0511061852	ADJUSTAMENT CONDUCTOR FERTILIZER		01
46	0503016204	CORN DISK 12 ORANGE		01
47	0503016214	RING CORN (APOLLO740)		01
48	0503016218	DISC OF SOYBEAN		01
49	0503016220	RING TO SOYBEANS (APOLLO 745)		01
50	0503016221	RING TO SOYBEANS (APOLLO 571)		01
51	0501050120	LARGER WALKING BEAM ASSY	141	01
52	0503030558	PULLEY 4Z CORN PLASTIC		01
53	0511052024	FAST CLOSING SET	142	01
54	0503033672	NOZZLE WITHOUT TITANIUM		01
55	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
56	0501010984	FLAT WASHER		01
57	0503010025	3/8" SPRING WASHER		01
58	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0521064651	LEFT SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		02
04	0503012412	5/8 UNC SELF LOCKING NUT		06
05	0511054635	BEARING AXLE BODY	78	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
08	0503010179	5/16" ZN SPRING WASHER		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION BOX SEED LINE	79	01
12	0561014904	TRANSMISSION AXLE FRAME LINE		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	80	01
14	0511055260	SEED ROW CHAIN TENSIONER	81	01
15	0502012666	SEDD ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521061427	SHORT SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" COTTERPIN		01
27	0503030168	HAIR PIN		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" COTTERPIN		01
31	0503034580	TRACTION SPRING		02



PST TRIO FLEX - FRAME 7450 - MH
FRONT LINE SEED SHORT LEFT CARDAN

Page 74
0501059834

Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	82	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064653	RIGH SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		02
04	0503012412	5/8 UNC SELF LOCKING NUT		06
05	0511054635	BEARING AXLE BODY	78	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
08	0503010179	5/16" ZN SPRING WASHER		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION BOX SEED LINE	79	01
12	0561014904	TRANSMISSION AXLE FRAME LINE		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	80	01
14	0511055260	SEED ROW CHAIN TENSIONER	81	01
15	0502012666	SEDD ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521061427	SHORT SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" COTTERPIN		01
27	0503030168	HAIR PIN		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" COTTERPIN		01
31	0503034580	TRACTION SPRING		02



PST TRIO FLEX - FRAME 7450 - MH
FRONT LINE SEED SHORT RIGHT CARDAN

Page 75
0501059833

Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	82	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064652	RH SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		02
04	0503012412	5/8 UNC SELF LOCKING NUT		06
05	0511054635	BEARING AXLE BODY	78	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
08	0503010179	5/16" ZN SPRING WASHER		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION BOX SEED LINE	79	01
12	0561014904	TRANSMISSION AXLE FRAME LINE		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	80	01
14	0511055260	SEED ROW CHAIN TENSIONER	81	01
15	0502012666	SEDD ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521061427	SHORT SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" COTTERPIN		01
27	0503030168	HAIR PIN		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" COTTERPIN		01
31	0503034580	TRACTION SPRING		02



PST TRIO FLEX - FRAME 7450 - MH
FRONT LINE SEED LONG RIGHT CARDAN

Page 76
0501059835

Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	82	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064650	LEFT SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		02
04	0503012412	5/8 UNC SELF LOCKING NUT		06
05	0511054635	BEARING AXLE BODY	78	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
08	0503010179	5/16" ZN SPRING WASHER		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION BOX SEED LINE	79	01
12	0561014904	TRANSMISSION AXLE FRAME LINE		01
13	0501052769	BEARING WITH 17Z GEAR	83	01
14	0511055260	SEED ROW CHAIN TENSIONER	81	01
15	0502012666	SEDD ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521061427	SHORT SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" COTTERPIN		01
27	0503030168	HAIR PIN		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" COTTERPIN		01
31	0503034580	TRACTION SPRING		02




PST TRIO FLEX - FRAME 7450 - MH
FRONT LINE SEED LONG LEFT CARDAN

Page 77
0501059836


Item	Code	Description	See page	QT
32	0511059264	BEARING WITH AXLE	82	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0502012718	BEARIN BODY		01
02	0503012882	BEARING		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	BOX TRANSMISSION COVER		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511050617	FRONT SEED ROW BEARING	84	01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0502012819	17Z GEAR WITH HEX HOLE		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501059326	UNIVERSAL JOINT AXLE	85	01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0511050611	5/8" HEX AXLE BEARING	86	01




Item	Code	Description	See page	QT
01	0503010406	501025 CLAMPING RING (FOR AXLE)		01
02	0502011697	BEARING OF THE GEAR BOX		01
03	0503011410	ROLLER BEARING		01
04	0503011105	SEAL RING		01
05	0503011953	5/16" X 1" BOLT		02
06	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503010337	5/16" NUT		02
09	0502012819	17Z GEAR WITH HEX HOLE		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0561016322	5/8" HEX AXLE		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		02
04	0561014794	350 AXLE HEX		01




Item	Code	Description	See page	QT
01	0501059363	5/8" HEX AXLE BEARING	87	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0561014911	AXLE SLEEVE GUIDES HEX		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		02




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8		01
01A	0502012704	BASE FIXING SYSTEM		01
01B	0501013354	FLAT WASHER		01
01C	0502012639	12Z LOWER CONICAL GEAR		01
01D	0502011418	40Z CONICAL GEAR		01
01E	0511018700	AXLE		01
01F	0503010002	1800 GREASE FITTING		02
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	90	01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8		01
01A	0502012704	BASE FIXING SYSTEM		01
01B	0501013354	FLAT WASHER		01
01C	0502012639	12Z LOWER CONICAL GEAR		01
01D	0502011418	40Z CONICAL GEAR		01
01E	0511018700	AXLE		01
01F	0503010002	1800 GREASE FITTING		02
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511056586	15 X 15 SEED DDD LEFT	91	01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	92	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	93	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	94	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	95	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	93	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	94	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503011443	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0503062300	EVA-F8 ESF2CARR BALL BEARING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016219	RING TO SOYBEANS		01
03	0503010025	3/8" SPRING WASHER		04
04	0503010209	3/8" UNC BUTTERFLY NUT		03
05	0503016283	M8 NUT HEX		01
06	0502020693	SUPPORT SEED BOX		01
07	0502012721	SEED DISC LOWER TRAIL		01
08	0503030083	3/8" X 3/8" X 1.6" STUD		02
09	0503016282	ALLEN BOLT		01
10	0503010675	5/16" X 2.1/4" BOLT		01
11	0503010179	5/16" ZN SPRING WASHER		05
12	0503010337	5/16" NUT		01
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
14	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
15	0501051094	SEED DISTRIB ASSY WITH DOUB PULLEY	97	01
16	0503031508	COVER GREEN BEAM SEED YELLOW		01
17	0571018536	HEX PRISONER		01
18	0501013518	FLAT WASHER		02
19	0503034131	DEFLECTOR		01




Item	Code	Description	See page	QT
01	0503030381	SEED DISTRIBUTOR BOX		01
02	0502010447	TRIGGER		02
03	0501013467	KEY AXLE		01
04	0503030378	0.4" X 1.1" X 0.03" SPRING		03
05	0501013466	KEY LIMITER AXLE		01
06	0501051119	DOUBLE PULLEY ROCKER'S	98	01
07	0501013468	ROCKER ARM AXLE, OF THE PULLEY		01
08	0503030377	SCRAPER		01




Item	Code	Description	See page	QT
01	0503031129	DOUBLE PULLEY ROCKER ARM		01
02	0503031128	5Z PLASTIC DOUB PULLEY FOR SOYBEAN		02
03	0521010649	TOOTH PULLEY COUPLING SHAFT		01
04	0503011853	503050 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	100	01
02	0501052538	DEPTH BAND WITH ARMS	101	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	102	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	103	01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	104	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	105	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	106	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	107	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	107	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX	108	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX	108	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0511015976	FLAT WASHER		01
05	0503010257	1/8" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503010071	3/16" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511055326	DEPTH CONTROL PRESS WHEEL ASSY	110	01
02	0551019650	SLEEVE 13,20 X 25 X 74		01
03	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511055327	COMPACTING WHEEL V ASSY RUBBER	111	01




Item	Code	Description	See page	QT
01	0502012758	DEPTH CONTROL SUPPORT		01
02	0503010585	0,24" X 1.18" SPRING PIN		02
03	0503010002	1800 GREASE FITTING		01
04	0501059228	ADJUSTMENT LEVER	112	01
05	0502012611	DEPTH CONTROL AXLE		01
06	0571015326	ARTICULATION SLEEVE HANDLE		01
07	0501010984	FLAT WASHER		01
08	0503011443	3/8" SPRING WASHER		01
09	0503010237	3/8" X 1" BOLT		01
10	0571016132	PIVOT SHAFT		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0561014336	PIVOT SHAFT		01
13	0503010071	3/16" X 1" COTTERPIN		02
14	0511055328	DEPTH WHEEL SYSTEM	113	01
15	0511055329	LEFT DEPTH WHEEL	114	01



Item	Code	Description	See page	QT
01	0571015324	COMPACT WHEEL RIGHT ARM		01
02	0571015325	LH ARM PRESS WHEELS		01
03	0541012145	SLEEV 13,5 X 25 X 18		02
04	0501058362	LARGER HANDLE ASSY		01
04A	0502011689	1/8" DEPTH CONTROL LEVER		01
04B	0521064892	REGULACION SPRING COMPACTOR		01
04C	0541012146	0.53" X 0.74" X 0.33" SLEEVE		01
04D	0503030174	COMPRESSION SPRING		01
04E	0541012143	FLAT WASHER		01
04F	0503010257	1/8" X 1" COTTERPIN		01
05	0503010479	BOLT		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING		01
09	0501055289	HANDLE SMALLER ASSY		01
09A	0511065451	PRESS WHEEL ADJUSTER		01
09B	0511065496	PRESS WHEEL FIXER		01
09C	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
09D	0541012143	FLAT WASHER		01
09E	0503010257	1/8" X 1" COTTERPIN		01
10	0503010397	5/16" X 1-3/4" BOLT		02
11	0541012144	8,50 X 16 X 21 SLEEVE		02
12	0503011444	SPRING WASHER		02
13	0503010337	5/16" NUT		02
14	0501052908	COMPACTOR WHEEL WITH BEARING	107	02
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503013739	1/2" X 1" BOLT		01
17	0503011440	SPRING WASHER		02




Item	Code	Description	See page	QT
01	0502012603	ADJUSTMENT LEVER		01
02	0502011689	1/8" DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0511015976	FLAT WASHER		01
05	0503010140	1/8" X 3/4" COTTERPIN		01




Item	Code	Description	See page	QT
01	0561014385	CARRYING-WHEELS PIVOT SHAFT		01
02	0501110777	RIGHT WHEEL ARM		01
03	0503010019	1/2" SPRING WASHER		01
04	0511055627	WHEEL ASSY RAYED	115	01
05	0503016453	1/2" X 2.1/2 BOLT		01
06	0503010060	1/2" NUT		01
07	0503010002	1800 GREASE FITTING		01
08	0503030012	HAIR PIN		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER		01
11	0501011445	FLAT WASHER		03
12	0571015974	WASHER		01
13	0503012412	5/8 UNC SELF LOCKING NUT		01
14	0503011440	SPRING WASHER		01

LEFT DEPTH WHEEL


0511055329




Item	Code	Description	See page	QT
01	0571015973	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED	115	01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HAIR PIN		01
08	0501110776	ARM, LEFT		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER		01
11	0501011445	FLAT WASHER		03
12	0571015974	WASHER		01
13	0503012412	5/8 UNC SELF LOCKING NUT		01
14	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0511055626	BOX ROUND DEPTH ROYAL WITH SPA		01
02	0551019904	PRESS WHEEL RIM		02
03	0503030891	RUBBER BAND		01
04	0503010365	NUT		06
05	0503010179	5/16" ZN SPRING WASHER		06
06	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0511055690	WHEEL SISTEM	117	01
02	0551019650	SLEEVE 13,20 X 25 X 74		01
03	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511055327	COMPACTING WHEEL V ASSY RUBBER	111	01




Item	Code	Description	See page	QT
01	0502012758	DEPTH CONTROL SUPPORT		01
02	0503010585	0,24" X 1.18" SPRING PIN		02
03	0503010002	1800 GREASE FITTING		01
04	0501059228	ADJUSTMENT LEVER	112	01
05	0502012611	DEPTH CONTROL AXLE		01
06	0571015326	ARTICULATION SLEEVE HANDLE		01
07	0501010984	FLAT WASHER		01
08	0503011443	3/8" SPRING WASHER		01
09	0503010237	3/8" X 1" BOLT		01
10	0571016132	PIVOT SHAFT		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0561014336	PIVOT SHAFT		01
13	0503010071	3/16" X 1" COTTERPIN		02
14	0511055628	DEPTH WHEEL SYSTEM	118	01
15	0511055629	DEPTH WHEEL SYSTEM	119	01




Item	Code	Description	See page	QT
01	0561014385	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED	115	01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HAIR PIN		01
08	0501110777	RIGHT WHEEL ARM		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER		01
11	0501011445	FLAT WASHER		03
12	0503012412	5/8 UNC SELF LOCKING NUT		01
13	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0571015973	CARRYING-WHEELS PIVOT SHAFT		01
02	0503010019	1/2" SPRING WASHER		01
03	0511055627	WHEEL ASSY RAYED	115	01
04	0503016453	1/2" X 2.1/2 BOLT		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01
07	0503030012	HAIR PIN		01
08	0501110776	ARM,LEFT		01
09	0503014007	1/2" X 1-1/4" BOLT		01
10	0511017302	FLAT WASHER		01
11	0501011445	FLAT WASHER		03
12	0503012412	5/8 UNC SELF LOCKING NUT		01
13	0503011440	SPRING WASHER		01




Item	Code	Description	See page	QT
01	0511059462	DEPTH CONTROL WITH FAST ADJUSTMENT	121	01
02	0511050077	WHEEL STRIPED	122	02
03	0503016453	1/2" X 2.1/2 BOLT		02
04	0503010019	1/2" SPRING WASHER		04
05	0503010028	1/2" NUT		02
06	0501052908	COMPACTOR WHEEL WITH BEARING	107	02
07	0503010752	1/2" X 3.1/2" BOLT		01
08	0503013739	1/2" X 1" BOLT		01




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0503010257	1/8" X 1" COTTERPIN		01
04	0571013054	DEPTH CONTROL WHEEL AXLE		01
05	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
06	0511015346	FLAT WASHER		04
07	0501110720	ARM LEFT		01
07A	0502012726	LEFT DEPTH WHEEL ARM		01
07B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL		02
08	0501110719	DEPTH CONTROL RIGHT ARM		01
08A	0501110720	ARM LEFT		01
08B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL		02
09	0511017302	FLAT WASHER		02
10	0503011440	SPRING WASHER		04
11	0502012663	EXTENSION		01
12	0503010002	1800 GREASE FITTING		02
13	0503010060	1/2" NUT		02
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503031393	1.57" X 5.98" X 0.2"TRACTION SPRING		01
16	0501056769	DEPTH WHEELS REGULATOR ASSY	123	01
17	0503010311	1/2" X 1-1/4" BOLT		02
18	0503010256	3/8" X 3/4" BOLT		01
19	0511059463	COMFORT WHEEL WITH FAST ADJUSTMENT	124	01




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	125	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	5/16" ZN SPRING WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0503010257	1/8" X 1" COTTERPIN		01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0502011689	1/8" DEPTH CONTROL LEVER		01
04	0502011688	SEED SIST CONTROL DEPTH LEVER		01
05	0511065582	DEPTH WHEEL STOP		01
06	0503030975	0.9" X 1.5" X 0.1" SPRING		01
07	0511015976	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521067072	COMPACT WHEEL RIGHT ARM		01
02	0521067071	COMPACT RUEDA LEFT ARM		01
03	0541012144	8,50 X 16 X 21 SLEEVE		02
04	0501055289	HANDLE SMALLER ASSY		01
04A	0511065451	PRESS WHEEL ADJUSTER		01
04B	0511065496	PRESS WHEEL FIXER		01
04C	0503031719	0.7" X 1" X 1,1" COMPRESSION SPRING		01
04D	0541012143	FLAT WASHER		01
04E	0503010257	1/8" X 1" COTTERPIN		01
05	0511059461	COMPLETE REGULATOR		01
05A	0503030174	COMPRESSION SPRING		01
05B	0502011689	1/8" DEPTH CONTROL LEVER		01
05C	0503010257	1/8" X 1" COTTERPIN		01
05D	0521067070	PRESS WHEEL ADJUSTER		01
05E	0511015976	FLAT WASHER		01
05F	0541012146	0.53" X 0.74" X 0.33" SLEEVE		01
06	0541012145	SLEEV 13,5 X 25 X 18		02
07	0503010479	BOLT		01
08	0503010060	1/2" NUT		01
09	0503011440	SPRING WASHER		01
10	0503010397	5/16" X 1-3/4" BOLT		02
11	0503011444	SPRING WASHER		02
12	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEELS BOX		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0502012823	CUTTING DISC SUPPORT		01
02	0503034318	5/8 UNC X 2 BOLT		02
03	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503011440	SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	129	01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503011440	SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521061153	LONG ARM FERTILIZER LINE		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	130	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	94	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	93	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503011443	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	93	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	94	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O-RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
09	0503010060	1/2" NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER		01
14	0503010257	1/8" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	WASHER BRACKET AXIS DC PST		01
17	0503034319	LOCK PIN		01
18	0511058648	BOX WITH DISC BLADE 20"	133	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511056909	DISC BOX CUT WITHOUT THE DISC	135	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0503010003	1845 GREASE FITTING		01
03	0571019976	LEFT BRACELET CUTTING DISC		01
04	0503011411	1/2" X 5-1/2" BOLT		01
05	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
06	0503011440	SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0502020394	SPRING SUPPORT		01
09	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
10	0502020393	SPRING UPPER SUPPORT		01
11	0521010452	SLEEVE		01
12	0503013185	3/4" X 5-1/2" BOLT		01
13	0501067323	SPRING REGULATOR		01
14	0511056910	BOX WITH DISC CUT 18		01
15	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01
16	0503011255	3/4" LOCK NUT		02
17	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
18	0581011111	WASHER BRACKET AXIS DC PST		01
19	0503034319	LOCK PIN		01
20	0511056909	DISC BOX CUT WITHOUT THE DISC	135	01




Item	Code	Description	See page	QT
01	0502012793	DC PST		01
02	0571018049	DOOR DUST		02
03	0571018047	AXLE DISC		01
04	0503017755	NUT		01
05	0502020641	BLADE DISC FLANGE		01
06	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
07	0503018441	5/16" X 1-1/4" BOLT		06
08	0503013816	5/16" LOCKNUT		06
09	0503010691	1/4" GREASE FITTING		01
10	0571018048	WASHER		02
11	0521065882	SEAL RING		02
12	0503010816	6207 RS ROLLER BEARING		02
13	0581010575	7/8" X 145 BOLT		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012824	FIXING SHAFT DISC CUT LINE		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	WASHER BRACKET AXIS DC PST		01
17	0503034319	LOCK PIN		01
18	0511058648	BOX WITH DISC BLADE 20"	133	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0503010003	1845 GREASE FITTING		01
03	0571019976	LEFT BRACELET CUTTING DISC		01
04	0503011411	1/2" X 5-1/2" BOLT		01
05	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
06	0503011440	SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0502020394	SPRING SUPPORT		01
09	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
10	0502020393	SPRING UPPER SUPPORT		01
11	0521010452	SLEEVE		01
12	0503013185	3/4" X 5-1/2" BOLT		01
13	0501067323	SPRING REGULATOR		01
14	0511056910	BOX WITH DISC CUT 18		01
15	0502012824	FIXING SHAFT DISC CUT LINE		01
16	0503011255	3/4" LOCK NUT		02
17	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
18	0581011111	WASHER BRACKET AXIS DC PST		01
19	0503034319	LOCK PIN		01




Item	Code	Description	See page	QT
01	0521066202	SUPPORT FIXER ROD		01
02	0511057533	ROD WITH POINT FLANGE WASHER SPRING	139	01
03	0571015538	SLEEVE 37 X 28,3 X 16,70		01
04	0503012795	5/8" HEX SELF ADJUSTING NUT		01
05	0571015552	BOLT FIXER		01
06	0503010417	7/8" NUT		01
07	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
08	0503034106	80 X 230 X 16,50 HDA COMPRESSION SPRING		01
09	0503010691	1/4" GREASE FITTING		01
10	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
11	0571019531	BODY SOCKET FERTILIZER		01
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
13	0501010984	FLAT WASHER		04
14	0503010026	3/8" NUT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010384	1/2" X 5" BOLT		02
17	0511017302	FLAT WASHER		04
18	0503010547	1/2" X 4" BOLT		02
19	0503011336	1/2" HEX SELF ADJUSTING NUT		04
20	0571019462	SUPPORT GUIDE PRING		01




Item	Code	Description	See page	QT
01	0501110810	ROD WITH POINT ARM/DISARMENT		01
02	0521066123	FLANGE WASHER SPRING		01
03	0571015521	PIN LOCK STEM		01
04	0571017723	FLAT WASHER		01
05	0503012104	501015 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER SPINDLE		01
02	1902070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01



Item	Code	Description	See page	QT
01	0503030379	LARGER ROCKER ARM		01
02	0502060001	PLASTIC PULLEY FOR MAIZE		01
03	0503010669	FLAT WASHER		01
04	0503010667	3/16" NUT		02
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01



Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

