

ROW CROP PLANTERS

COP TRIO 650 SUPREMA P.P MINI HOPPER - FRAME 6850 - CSU/CBA/MH/TMC

Code: 0501093128
Series: S-0419
Revision: 00
Date Revision: FEVEREIRO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111420065	COP TRIO 650 SUP 6850/15E450 ESPECIAL S-0419

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909095988	ASSY FRAME	1
0521056065	FRAME SHAFT	2
0521056088	WHEEL ASSY RIGHT FIXING EXTENSOR	3
0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH TRANSMISSION	4
0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY	5
0521056100	WHEEL BOX ASSY WITH TRANSMISSION	6
0521056160	SIDE TRANSMISSION CURRENT STRETCHER	7
0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	8
0521056299	MOUNTED RIGHT STRETCHER	9
0521055238	BEARING TENSIONER CHAIN	10
0521056095	ARTICULATED BEARING WHEELED WITHOUT LUBRICATION	11
0501058239	CHAIN TENSIONER BEARING	12
0521056089	WHEEL ASSY LEFT FIXING EXTENSOR	13
0521056300	MOUNTED LEFT STRETCHER	14
0521056090	RIGHT WHEEL ASSY	15
0521056091	LEFT WHEEL ASSY	16
0521056093	RIGHT WHEEL ASSEMBLY WITHOUT TRANSMISSION	17
0521056092	LEFT WHEEL ASSEMBLY WITHOUT TRANSMISSION	18
0521056101	EE WHEEL WITH TIRE 7.00X16 ASSY WITHOUT TRANSMISSION	19
0521056102	ASSY WHEEL BOX WITHOUT TRANSMISSION	20
0521056119	SQUARE AXIS ASSEMBLY 730	21
0501056271	BEARING CLOSED	22
0501056444	BEARING WITH ROLLING	23
0501053788	Q3/4" FASTENER AXLE ASSY	24
0521056084	MOTOR SHAFT ASSEMBLY - 6850	25
0511047069	SIDE TRANSMISSION DRIVING	26
0511047070	LH SIDE TRANSMISSION DRIVING	27
0511051434	TRANSMISSION DRIVING ASSY	28
0521056085	PLATE BEARING ASSY	29
0521056121	HEX AXLE ASSEMBLY	30
0521056103	BEARING WITH GEAR 20Z HEX SHAFT 3/4	31
0521055498	SEED TRANSMISSION DOUBLE BEARING	32
0521056144	INTERMEDIATE SEED TRANSMISSION	33
0521056118	TRANSMISSION ASSY	34
0521056135	BEARING GEAR WITH DOUBLE	35
0521055217	LOWER CURRENT STRETCH	36
0521056134	STRETCHER FERTILIZER CURRENT 17Z	37
0521054446	LOWER CURRENT STRETCHER 21Z	38
0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	39
0511052333	ASSEMBLY SUPPORT LEFT FIXER CHANGE	40
0521056086	ASSY RIGHT EXCHANGE	41
0521056087	ASSY LEFT EXCHANGE	42
0501056443	BEARING ASSY GEAR BOX	43
0511059266	CLOSED BEARING	44
0501054655	CHAIN TENSIONER ASSY	45
0511059261	CHAIN TENSIONER	46
0521056071	SET FERTILIZER SILO	47
0521056073	FERTILIZER BEAM SUPPORT	48
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	49
0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	50
0521056072	CENTER FERTILIZER SILO SUPPORT	51
0521056074	LFT FERTILIZER BEAM SUPPORT	52
0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	53

INDEX


0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	54
0521050195	SILO FERTILIZER LEFT SQUARE AXLE	55
0521057078	HANDRAIL ASSY - 6850	56
0531051907	PLATFORM ASSEMBLY - 6850	57
0521057199	SET HIDRAULICO	58
0521057899	SUPPORT VALVE BLOCK VACUOMETER ASSY 5750/7350	59
0521057855	CASAPPA DIVIDER VALVE WITH FIXING NIPLES	60
0521057886	HOSE CLAMP ASSEMBLY	61
0521057259	OIL CONDUCTOR FIXATION	62
0521057704	SLIDING SUPPORT HYDRAULIC HOSE	63
0521057306	HYDRAULIC MARKER	64
0511053356	ASSY LADDER	65
0511058191	REST ASSY	66
0511057803	ASSY PORT MANUAL INSTRUCCION	67
0909099261	COMPLETE HEADER ASSY	68
0511055096	TRACTOR HITCH	69
0521050574	EXTENSOR	70
0521057452	ASSY INTERMEDIATE HEADER FIXATION SUPPORT	71
0521057928	REAR HEADLIGHT ASSY 6850 A 7350	72
0521057140	TURBINE ASSEMBLY - 6850	73
0521057131	CENTRAL TURBINE MOUNTED WITH CSU SUPPORT	74
0521056143	RIGHT SIDE AIR DISTRIBUTOR	75
0521056112	LEFT SIDE AIR DISTRIBUTOR	76
0521057135	CENTRAL AIR DISTRIBUTOR 1978	77
0521052549	CLAMP	78
0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	79
0521057289	VACUOMETER FIXING SUPPORT CSU	80
0521057018	CSU CONDUCTOR 3 SEMI-ASSEMBLED ASSY - 6850	81
0521051730	ASSY FIXING SUPPORT	82
0511057755	ASSEMBLY CSU 6850	83
0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	84
0521057149	ASSY RIGHT FIXING SUPPORT	85
0521057151	FIXING SUPPORT LEFT ASSY	86
0521057094	ASSY STICKER - 6850	87
0511059494	TRACTION SPRING ASSY	88
0521055204	LIGNE DE DISQUE MARKER	89
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	90
0521056993	COROT D' WATER ASSY	91
0521056994	ASSY TOOL CHEST	92
0909095989	SEED/FERTILIZER ROW ASSY	93
0521056240	FRONT SHORT LINE	94
0521056241	FRONT LONG LINE	95
0531052956	ASSEMBLY SEED LINE TRANSMISSION FIXING BEARING	96
0521056941	RIGHT REAR P.P CSU TRANSMISSION/CABLE	97
0521056955	RIGHT DDD ASSY	98
0521056956	PRECISION PLANTING CSU CABLE/TRANSMISSION ASSY	99
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	100
0521056940	LEFT REAR P.P CSU TRANSMISSION CABLE	101
0521056954	LEFT DDD ASSY	102
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	103
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	104
0521055053	DEEP WHEEL/COMPACTOR SYSTEM	105
0521055065	ASSY DEPTH / COMPACTOR	106
0501056769	DEPTH WHEELS REGULATOR ASSY	107
0521055033	COMPACTADOR BODY	108

INDEX

0521055054	LEFT ARM WITH SLEEVE	109
0521055066	RIGHT ARM WITH GLOVE	110
0521055068	RAYED WHEEL CENTER CLOSED	111
0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	112
0521054990	LEFT COMPACTOR WHEEL	113
0521055017	RIGHT COMPACTOR WHEEL	114
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	115
0521056069	SEMI-ASSEMBLED SHORT FERTILIZER LINE	116
0521056066	SEMI-ASSEMBLED LONG FERTILIZER LINE	117
0521056070	DC 20 ASSY	118
0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	119
0521053697	CUTTING DISK BOX	120
0521053987	SCARIFIER SPINDLE WITH SOCKET RIGHT	121
0521053956	SCARIFIER SPINDLE WITH SOCKET LEFT	122
0521053957	ROD WITH ARM/DISARMMENT	123
0521053958	STEM WITH NOZZLE HDA	124
0521053959	ROD WITH AUTOMATIC DISARM TIP	125
0511059454	ADJUSTMENT BAR	126
0521050525	FIXER FERTILIZER CONDUCTOR	127
0521051447	FRONT ASSY ROW BEARING	128
0531053036	SHORT SEED LINE HOSE GUIDE STEEL CABLE	129
0531053037	LONG SEED LINE HOSE GUIDE STEEL CABLE	130
0531052349	CURRENT GUIDE ASSEMBLY	131
0531052347	HOSE SUPPORT ASSEMBLY	132

ASSY FRAME

0909095988



Item	Code	Description	See page	QT
01	0521056065	FRAME SHAFT	2	01
02	0521056088	WHEEL ASSY RIGHT FIXING EXTENSOR	3	01
03	0521056089	WHEEL ASSY LEFT FIXING EXTENSOR	13	01
04	0521056090	RIGHT WHEEL ASSY	15	01
05	0521056091	LEFT WHEEL ASSY	16	01
06	0521056092	LEFT WHEEL ASSEMBLY WITHOUT TRANSMISSION	18	01
07	0521056093	RIGHT WHEEL ASSEMBLY WITHOUT TRANSMISSION	17	01
08	0521056119	SQUARE AXIS ASSEMBLY 730	21	01
09	0521056084	MOTOR SHAFT ASSEMBLY - 6850	25	01
10	0521056121	HEX AXLE ASSEMBLY	30	01
11	0521056118	TRANSMISSION ASSY	34	01
12	0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	39	01
13	0511052333	ASSEMBLY SUPPORT LEFT FIXER CHANGE	40	01
14	0521056086	ASSY RIGHT EXCHANGE	41	01
15	0521056087	ASSY LEFT EXCHANGE	42	01
16	0521056071	SET FERTILIZER SILO	47	01
17	0521057078	HANDRAIL ASSY - 6850	56	01
18	0531051907	PLATFORM ASSEMBLY - 6850	57	01
19	0521057199	SET HIDRAULICO	58	01
20	0521057306	HYDRAULIC MARKER	64	01
21	0511053356	ASSY LADDER	65	01
22	0511058191	REST ASSY	66	01
23	0511057803	ASSY PORT MANUAL INSTRUCCION	67	01
24	090909261	COMPLETE HEADER ASSY	68	01
25	0521057928	REAR HEADLIGHT ASSY 6850 A 7350	72	02
26	0521057140	TURBINE ASSEMBLY - 6850	73	01
27	0521057018	CSU CONDUCTOR 3 SEMI-ASSEMBLED ASSY - 6850	81	01
28	0521057094	ASSY STICKER - 6850	87	01
29	0503011750	AMENDMENT WITH LOCK		06


ASSY FRAME

0909095988

Item	Code	Description	See page	QT
30	0503011751	REDUCTION		06
31	0503010780	N-2050 AMENDMENT		06
32	0521064285	LOCK LOWER FRAME		04
33	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		04
34	0511059494	TRACTION SPRING ASSY	88	10
35	0503034867	AIR DITRIBUTOR PUMP		07
36	0503010002	1800 GREASE FITTING		01
37	0501068994	0.3" X 3.1"LOCK PIN		08
38	0503032624	SILO FERTILIZER GUTTER		07
39	0521013022	TRANSPORT LOCK		08
40	0501047895	ROD STOP		08
41	0501047885	ROD STOP		08
42	0501047886	ROD STOP		08
43	0501047887	ROD STOP		08
44	0521055204	LIGNE DE DISQUE MARKER	89	02
45	0521013164	EXTENSOR		02
46	0501011310	FIXER LOCK		08
47	0521066303	HOSE GUIDE		01
48	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
49	0503030168	HAIR PIN		08
50	0503010246	CLAMP		22
51	0503010019	1/2" SPRING WASHER		08
52	0503010060	1/2" NUT		08
53	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	90	01
54	0503014321	CABLE STEEL SHACKLE		02
55	0503014120	CHAIN		01
56	0521056993	COROT D' WATER ASSY	91	01
57	0521056994	ASSY TOOL CHEST	92	01
58	0503019262	SOAP DISH VACUUM		01
59	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02
60	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		08
61	0503013816	5/16" LOCKNUT		02
62	0909095989	SEED/FERTILIZER ROW ASSY	93	15

FRAME SHAFT


0521056065



Item	Code	Description	See page	QT
01	0521069990	RIGHT SIDE FRAME 6850		01
02	0521069989	LEFT SIDE FRAME 6850		01
03	0521063003	LOCK PIN		02
04	0571010969	LOCK SLEEVE FRAME		02
05	0503013627	1.1/2 SPRING WASHER		02
06	0501010110	1.1/2" NUT		02
07	0521069988	CENTRAL FRAME		01
08	0501110683	REAR HUB OF ARTICULATOR WITH GLOVES		04
09	0503011442	3/4" SPRING WASHER		20
10	0501010098	3/4" UNC BOLT		20
11	0571010094	SLEEVE FLANGE		12
12	0521066298	ARTICULATOR		04
13	0571013510	LOCK AXLE		04
14	0503030085	LOCK PIN		04
15	0571010095	FLAT WASHER		04
16	0521064285	LOCK LOWER FRAME		04
17	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		04
18	0591012308	SIDE GUTTER 24 X 50 X 1950		02
19	0591012303	CENTRAL TRACK		02
20	0503013029	3/8" X 3/4" BOLT		08
21	0501013518	FLAT WASHER		08
22	0503010025	3/8" SPRING WASHER		08
23	0503010026	3/8" NUT		08

WHEEL ASSY RIGHT FIXING EXTENSOR

0521056088




Item	Code	Description	See page	QT
01	0521066480	RH WHEELS SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 4 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	7	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	8	01
15	0501047888	ROD STOP		02
16	0511064744	WHEEL FORK		01
17	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8" SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056299	MOUNTED RIGHT STRETCHER	9	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8" NUT		02


WHEEL ASSY RIGHT FIXING EXTENSOR

0521056088

Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 11 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TIGHTENER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	CHAIN TENSIONER BEARING	12	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY	5	01
02	0521056100	WHEEL BOX ASSY WITH TRANSMISSION	6	01




Item	Code	Description	See page	QT
01	0503016518	RUEDA		01
02	0503010033	7.50 X 16 INNER TIRE		01
03	0503019458	TIRE 7.00X16 14PR		01

WHEEL BOX ASSY WITH TRANSMISSION


0521056100




Item	Code	Description	See page	QT
01	0503010804	00547-B SEAL		02
02	0503010330	KM 9 LOCKNUT		01
03	0511015949	LOCK NUT		01
04	0503010329	LOCK WASHER		01
05	0503010002	1800 GREASE FITTING		01
06	0501110721	WHEEL HUB WITH SCREW / NUTS		01
06A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
06B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
06C	0503016516	5/8 UNF CONIC NUT		06
07	0503019364	BEARING 25590/25523		02
08	0521018363	00547-B SEAL		01
09	0511062015	14Z GEAR WITH FLANGE		01
10	0503010421	5/16" X 1-1/2" BOLT		06
11	0503011444	SPRING WASHER		06




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		01
02	0591010747	CURRENT STRETCHER AXIS		01
03	0503010302	501019 SEAL RING		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0511017302	FLAT WASHER		01
07	0541016454	PULLEY		01




Item	Code	Description	See page	QT
01	0531060012	CASE 101.6 X 324.5 WITHOUT LUBRICATION		01
02	0541017674	TURNBUCLE BODY		01
03	0511064408	FORK		01
04	0503011094	3/8" X 2" BOLT		01
05	0503010025	3/8" SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581010302	RING OF SUPPORT		01
08	0502012822	101.60 END CAP		01
09	0503011061	8-342 BACK-UP RING		02
10	0503010338	2-342 N 3006-9B O'RING		02
11	0503017936	RING		01
12	0503017938	RING GUIDE		01
13	0503017937	GASKET		01
14	0503010761	D-1750 SCRAPER RING		01
15	0581010837	PISTON		01
16	0503010817	1.1/4" SELF LOCKING NUT		01
17	0503015633	SELEMASTER SEALING		01
18	0503018029	2-217 O'RING		01
19	0503018045	2-130 (AGEL) O'RING		04
20	0503030387	PLUG		02
21	0511033019	CYLINDER REPAIR KIT 44.45 X 101.60		01




Item	Code	Description	See page	QT
01	0503010027	5/8" SPRING WASHER		01
02	0503010013	5/8" NUT		01
03	0521055238	BEARING TENSIONER CHAIN	10	01
04	0551018241	SLEEVE 16,30 X 30 X 8		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0551018252	CHAIN TIGHTENER AXLE		01
08	0511017302	FLAT WASHER		01
09	0503010232	5/8" X 1.3/4" BOLT		01
10	0531016916	SLEEVE BEARING SUPPORT		01
11	0531018654	CHAIN TIGHTENER SUPPORT		01



Item	Code	Description	See page	QT
01	0503019355	BEARING 6202 2RS1		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0591010097	ARTICULATED BEARING WHEELED WITHOUT LUBRICATION		01
02	0503019409	SELF LUBRICATING BUSHING		01



Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01

WHEEL ASSY LEFT FIXING EXTENSOR

0521056089




Item	Code	Description	See page	QT
01	0521066479	RH WHEELS SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 4 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	7	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	8	01
15	0501047888	ROD STOP		01
16	0511065842	LEFT WHEEL FORK		01
17	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8" SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056300	MOUNTED LEFT STRETCHER	14	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8" NUT		02

WHEEL ASSY LEFT FIXING EXTENSOR

0521056089


Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 11 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TIGHTENER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	CHAIN TENSIONER BEARING	12	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01



Item	Code	Description	See page	QT
01	0503010027	5/8" SPRING WASHER		01
02	0503010013	5/8" NUT		01
03	0521055238	BEARING TENSIONER CHAIN	10	01
04	0551018241	SLEEVE 16,30 X 30 X 8		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0551018252	CHAIN TIGHTENER AXLE		01
08	0511017302	FLAT WASHER		01
09	0503010232	5/8" X 1.3/4" BOLT		01
10	0531016916	SLEEVE BEARING SUPPORT		01
11	0541012098	LEFT CHAIN TIGHTENER LARGER SUPPORT		01

RIGHT WHEEL ASSY

0521056090



Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 4 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	7	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	8	01
15	0501047888	ROD STOP		01
16	0511064744	WHEEL FORK		01
17	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8" SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056299	MOUNTED RIGHT STRETCHER	9	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8" NUT		02


RIGHT WHEEL ASSY

0521056090

Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 11 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TIGHTENER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	CHAIN TENSIONER BEARING	12	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01

LEFT WHEEL ASSY

0521056091



Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 4 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	7	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	8	01
15	0501047888	ROD STOP		01
16	0511065842	LEFT WHEEL FORK		01
17	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8" SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" COTTERPIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056300	MOUNTED LEFT STRETCHER	14	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8" NUT		02


LEFT WHEEL ASSY

0521056091

Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 11 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TIGHTENER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	CHAIN TENSIONER BEARING	12	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01

RIGHT WHEEL ASSEMBLY WITHOUT TRANSMISSION


0521056093




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0503010019	1/2" SPRING WASHER		12
03	0503013232	1/2" BOLT		08
04	0561013021	BEARING INNER LOK		02
05	0561013022	BEARING EXTERNAL LOCK		02
06	0503010398	501082 CLAMPING RING (FOR AXLE)		02
07	0561013020	KM 12 NUT		02
08	0503010027	5/8" SPRING WASHER		02
09	0503011167	M16 X 2 X 30 BOLT		02
10	0501047888	ROD STOP		01
11	0521056101	EE WHEEL WITH TIRE 7.00X16 ASSY WITHOUT 19 TRANSMISSION		01
12	0503016485	BOLT 3/4		04
13	0503010152	3/4" SELF LOCKING NUT		04
14	0541010763	FLAT WASHER		04
15	0503017857	BOLT 5/8 UNF 4		04
16	0503010811	5/8" UNF SELF ADJUSTING NUT		04
17	0501012140	FLAT WASHER		04
18	0503010834	1/2 X 1 BOLT		04
19	0501017779	32 X 60 X 4.75 FLAT WASHER		02
20	0503010523	1/4" X 2" COTTERPIN		01
21	0521010546	1.2" X 5.7" COUPLING SHAFT		01
22	0511064744	WHEEL FORK		01
23	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
24	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 8 WITHOUT LUBRICATION		01
25	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
26	0591010098	ARTICULATED BEARING WHEELED WITHOUT TRANSMISSION WITHOUT LUBRICATION		02
27	0502012720	WHEEL SUPPORT FIXER		01

LEFT WHEEL ASSEMBLY WITHOUT TRANSMISSION


0521056092



Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0503010019	1/2" SPRING WASHER		12
03	0503013232	1/2" BOLT		08
04	0561013021	BEARING INNER LOK		02
05	0561013022	BEARING EXTERNAL LOCK		02
06	0503010398	501082 CLAMPING RING (FOR AXLE)		02
07	0561013020	KM 12 NUT		02
08	0503010027	5/8" SPRING WASHER		02
09	0503011167	M16 X 2 X 30 BOLT		02
10	0501047888	ROD STOP		01
11	0521056101	EE WHEEL WITH TIRE 7.00X16 ASSY WITHOUT 19 TRANSMISSION		01
12	0503016485	BOLT 3/4		04
13	0503010152	3/4" SELF LOCKING NUT		04
14	0541010763	FLAT WASHER		04
15	0503017857	BOLT 5/8 UNF 4		04
16	0503010811	5/8" UNF SELF ADJUSTING NUT		04
17	0501012140	FLAT WASHER		04
18	0503010834	1/2 X 1 BOLT		04
19	0501017779	32 X 60 X 4.75 FLAT WASHER		02
20	0503010523	1/4" X 2" COTTERPIN		01
21	0521010546	1.2" X 5.7" COUPLING SHAFT		01
22	0511065842	LEFT WHEEL FORK		01
23	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
24	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 8 WITHOUT LUBRICATION		01
25	0502012720	WHEEL SUPPORT FIXER		01
26	0591010098	ARTICULATED BEARING WHEELED WITHOUT TRANSMISSION WITHOUT LUBRICATION		02
27	0502010584	CARRYING-WHEELS SUPPORT FIXER		02




Item	Code	Description	See page	QT
01	0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY	5	01
02	0521056102	ASSY WHEEL BOX WITHOUT TRANSMISSION	20	01




Item	Code	Description	See page	QT
01	0503010804	00547-B SEAL		02
02	0503010330	KM 9 LOCKNUT		01
03	0511015949	LOCK NUT		01
04	0503010329	LOCK WASHER		01
05	0503010002	1800 GREASE FITTING		01
06	0501110721	WHEEL HUB WITH SCREW / NUTS		01
06A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
06B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
06C	0503016516	5/8 UNF CONIC NUT		06
07	0503019364	BEARING 25590/25523		02
08	0521018363	00547-B SEAL		01

SQUARE AXIS ASSEMBLY 730


0521056119




Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED	22	02
02	0501056444	BEARING WITH ROLLING	23	02
03	0503011953	5/16" X 1" BOLT		08
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		08
05	0503010179	5/16" ZN SPRING WASHER		08
06	0503010337	5/16" NUT		08
07	0511014218	3/4" X 28.7"SQUARE SHAFT		02
08	0501053788	Q3/4" FASTENER AXLE ASSY	24	04
09	0503030275	AGRICULTURAL BEARING		04
10	0521061852	LEVER RATCHET		02
11	0521061847	AXLE ADRIVING ASSY		02
12	0521061849	DISASSEMBLE LEVER		02
13	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
14	0501010984	FLAT WASHER		08
15	0503010140	1/8" X 3/4" COTTERPIN		04
16	0571012792	LOWER LEVER		02
17	0503011082	C1/2" X 1.3/4" SCREW		02
18	0511017302	FLAT WASHER		04
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2" NUT		02
21	0561016797	SLEEVE UNION LEVER		02
22	0503010026	3/8" NUT		02
23	0503010025	3/8" SPRING WASHER		02
24	0503010849	3/8" X 1-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0503011082	C1/2" X 1.3/4" SCREW		08
02	0511017302	FLAT WASHER		16
03	0503010019	1/2" SPRING WASHER		08
04	0503010060	1/2" NUT		08
05	0511047069	SIDE TRANSMISSION DRIVING	26	01
06	0511047070	LH SIDE TRANSMISSION DRIVING	27	01
07	0511051434	TRANSMISSION DRIVING ASSY	28	04
08	0591010711	MOTOR AXLE BEARING SUPPORT		04
09	0521056085	PLATE BEARING ASSY	29	08
10	0571014441	MOTOR SHAFT		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0503019402	BEARING B207-22 V22 FRM		01
02	0503019403	PFL 207 FRM BEARING PLATE		02
03	0503010026	3/8" NUT		02
04	0503010025	3/8" SPRING WASHER		02
05	0501011643	3/8 X 1"BOLT		02

HEX AXLE ASSEMBLY


0521056121




Item	Code	Description	See page	QT
01	0521056103	BEARING WITH GEAR 20Z HEX SHAFT 3/4	31	02
02	0591011101	HEX AXLE 3/4 X 1727		01
03	0591011100	HEX AXLE 3/4 X 1847		01
04	0591010702	HEX SHAFT 3/4 X 750		01
05	0591010701	HEX SHAFT 3/4 X 1270		01
06	0521056144	INTERMEDIATE SEED TRANSMISSION	33	02
07	0511063123	BUSHING WITH NUT		08
08	0501018535	1/2 X 1 BOLT		08
09	0581015056	SLEEVE		08




Item	Code	Description	See page	QT
01	0521055498	SEED TRANSMISSION DOUBLE BEARING	32	01
02	0531060014	GEAR 20Z X 48.50 HEX HOLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02
06	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
07	0503018441	5/16" X 1-1/4" BOLT		02




Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012858	502075 CLAMPING RING (FOR HOLE)		01
03	0503019373	6006 2RS1 NATIONAL BEARING		02




Item	Code	Description	See page	QT
01	0503010243	CLAMP		02
02	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
03	0503012880	1/4" UNC SELF ADJUSTING NUT		02
04	0503063012	SEED TRANSMISSION SHAFT HEX 3/4		01
05	0503034773	HOSE 1.1/2 X 1.1/2 X 120		01




Item	Code	Description	See page	QT
01	0511017302	FLAT WASHER		06
02	0503010019	1/2" SPRING WASHER		02
03	0503010060	1/2" NUT		02
04	0561017281	ARTICULACION ARM		02
05	0521056135	BEARING GEAR WITH DOUBLE	35	02
06	0521055217	LOWER CURRENT STRETCH	36	04
07	0521056134	STRETCHER FERTILIZER CURRENT 17Z	37	02
08	0521054446	LOWER CURRENT STRETCHER 21Z	38	02
09	0571019829	LEVER FIXER		02
10	0503010237	3/8" X 1" BOLT		06
11	0503010025	3/8" SPRING WASHER		06
12	0503010026	3/8" NUT		06
13	0571019830	LEVER FIXER		02
14	0503011312	ROTATIVE CABLE		02
15	0503030093	TRACTION SPRING		02
16	0561017273	FIXER SPRING		02
17	0561017282	LOWER LEVER		02
18	0561016797	SLEEVE UNION LEVER		02
19	0591010705	ARTICULATION GLOVE		02
20	0503011082	C1/2" X 1.3/4" SCREW		02
21	0521010773	0.37" X 1.18" COUPLING SHAFT		02
22	0501010984	FLAT WASHER		06
23	0541014973	COUPLING SHAFT		02
24	0503010140	1/8" X 3/4" COTTERPIN		04
25	0503017874	BOLT 1/2 UNC		02
26	0503011336	1/2" HEX SELF ADJUSTING NUT		02
27	0503013065	40-1 X 159 CHAIN LINK + MENDING		02
28	0503016737	40-1 X 114 CHAIN LINK + REDUCION		02




Item	Code	Description	See page	QT
01	0503019356	BEARING 6005 2RS1		02
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0503012412	5/8 UNC SELF LOCKING NUT		01
04	0521061843	20Z DOBLE GEAR		01
05	0551019175	DOUBLE GEAR AXLE		01
06	0501010163	5/8" X 4-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0591010693	CURRENT DEVIATION GLOVE		01
08	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503019356	BEARING 6005 2RS1		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0501012140	FLAT WASHER		01
06	0581015136	40MM STRETCHING SHAFT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01
08	0501011541	5/8" X 3" BOLT		01



Item	Code	Description	See page	QT
01	0561019899	RIGHT SUPPORT FIXER RECAMBIO		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02



Item	Code	Description	See page	QT
01	0561019898	LEFT SUPPORT FIXER RECAMBIO		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02



Item	Code	Description	See page	QT
01	0501048790	AXLE WITH LINK ASSY		02
02	0551018209	DRIVING AXLE		01
03	0521018259	DRIVEN AXLE		01
04	0551018210	DRIVEN AXLE		01
05	0551018211	INTERM SHAFT		01
06	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE		01
07	0503030303	SUPPORT WASHER		06
08	0501056443	BEARING ASSY GEAR BOX	43	02
09	0511059266	CLOSED BEARING	44	05
10	0503012389	1/2 BALL		04
11	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
12	0503010834	1/2 X 1 BOLT		04
13	0503010060	1/2" NUT		06
14	0503031805	11Z 1/2" GEAR		04
15	0503010302	501019 SEAL RING		04
16	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
17	0511067501	26Z GEAR		01
18	0521018630	1.4" X SQUARE 0.8" WASHER		05
19	0503010292	0.2" X 1.6" SPRING PIN		10
20	0501054655	CHAIN TENSIONER ASSY	45	02
21	0591010679	AGRICOLA BEARING SQUARE HOLE 19.4 / 19.6X26		01
22	0501010984	FLAT WASHER		01
23	0503010256	3/8" X 3/4" BOLT		01
24	0503012204	40-1 CHAIN X 82 LINK + RED		02
25	0503019573	CHAIN		01
26	0511060396	DRIVE/DRIVEN AXLE CONE		04
27	0511061822	25Z P0.5" GEAR SQUARE HOL		01
28	0502011758	REAR TENSIONER LEVER		02
29	0531060029	LONGER CURRENT STRETCHER WITHOUT LUBRICATION		01
30	0503031367	SPRING		01
31	0503031366	RIGHT TWISTED SPRING RECAMBIO		01


ASSY RIGHT EXCHANGE

0521056086

Item	Code	Description	See page	QT
32	0531060009	RIGHT EXCHANGE BODY WITHOUT LUBRICATION		01
33	0503019418	GLOVE		04
34	0503011034	RING		04
35	0531060025	MINOR CHAIN STRETCHER WITHOUT LUBRICATION		01
36	0511059261	CHAIN TENSIONER	46	01
37	0503014734	BOLT		02
38	0503010019	1/2" SPRING WASHER		02
39	0521060879	38Z GEAR		01
40	0511061759	22Z P12,70 FQ 3/4" GEAR		01

ASSY LEFT EXCHANGE

0521056087




Item	Code	Description	See page	QT
01	0501048790	AXLE WITH LINK ASSY		02
02	0551018209	DRIVING AXLE		01
03	0521018259	DRIVEN AXLE		01
04	0551018210	DRIVEN AXLE		01
05	0551018211	INTERM SHAFT		01
06	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE		01
07	0503030303	SUPPORT WASHER		06
08	0501056443	BEARING ASSY GEAR BOX	43	02
09	0511059266	CLOSED BEARING	44	05
10	0503012389	1/2 BALL		04
11	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
12	0503010834	1/2 X 1 BOLT		04
13	0503010060	1/2" NUT		06
14	0503031805	11Z 1/2" GEAR		04
15	0503010302	501019 SEAL RING		04
16	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
17	0511067501	26Z GEAR		01
18	0521018630	1.4" X SQUARE 0.8" WASHER		05
19	0503010292	0.2" X 1.6" SPRING PIN		10
20	0501054655	CHAIN TENSIONER ASSY	45	02
21	0501010984	FLAT WASHER		01
22	0503010256	3/8" X 3/4" BOLT		01
23	0503012204	40-1 CHAIN X 82 LINK + RED		02
24	0503019573	CHAIN		01
25	0511060396	DRIVE/DRIVEN AXLE CONE		04
26	0511061822	25Z P0.5" GEAR SQUARE HOL		01
27	0502011758	REAR TENSIONER LEVER		02
28	0531060029	LONGER CURRENT STRETCHER WITHOUT LUBRICATION		01
29	0503031367	SPRING		01
30	0503031366	RIGHT TWISTED SPRING RECAMBIO		01
31	0531060008	LEFT EXCHANGE BODY WITHOUT LUBRICATION		01


ASSY LEFT EXCHANGE

0521056087


Item	Code	Description	See page	QT
32	0531060025	MINOR CHAIN STRETCHER WITHOUT LUBRICATION		01
33	0503019418	GLOVE		04
34	0503011034	RING		04
35	0511059261	CHAIN TENSIONER	46	01
36	0591010679	AGRICOLA BEARING SQUARE HOLE 19.4 / 19.6X26		01
37	0503014734	BOLT		02
38	0503010019	1/2" SPRING WASHER		02
39	0521060879	38Z GEAR		01
40	0511061759	22Z P12,70 FQ 3/4" GEAR		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	23	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056271	BEARING CLOSED	22	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503031805	1 1/2" GEAR		01
02	0511017302	FLAT WASHER		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0521056073	FERTILIZER BEAM SUPPORT	48	01
02	0521056072	CENTER FERTILIZER SILO SUPPORT	51	01
03	0521056074	LFT FERTILIZER BEAM SUPPORT	52	01
04	0571019051	FIXER BOX WASHER		28
05	0503013751	3/8 UNC X 1.1/4 BOLT		28
06	0503012535	3/8" SPRING WASHER		28
07	0503012531	3/8" INOX NUT		28
08	0501010984	FLAT WASHER		32
09	0503010026	3/8" NUT		16
10	0503010849	3/8" X 1-1/2" BOLT		16
11	0503010025	3/8" SPRING WASHER		16
12	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	53	02
13	0503034396	FERTILIZER SIDE COVER		17
14	0503010362	1/8" X 1.1/4" COTTERPIN		17
15	0503011957	NYLON LUG		02
16	0503010371	5/16" X 1" BOLT		04
17	0503010179	5/16" ZN SPRING WASHER		04
18	0503010337	5/16" NUT		04
19	0503062391	SILO FERTILIZER 05 MOUTHS		03
20	0521050194	SUPPORT RIGHT SQUARE AXLE SILO FERTILIZER	54	01
21	0521050195	SILO FERTILIZER LEFT SQUARE AXLE	55	01
22	0521010572	0.9" X 2.9" COUPLING SHAFT		02
23	0503030085	LOCK PIN		02

FERTILIZER BEAM SUPPORT


0521056073




Item	Code	Description	See page	QT
01	0521066295	FERTILIZER BEAM RIGHT SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	49	03
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	50	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0501056271	BEARING CLOSED	22	01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	5/16" ZN SPRING WASHER		02
11	0503010337	5/16" NUT		02
12	0581016972	AXIS Q 3/4 X 1953		01
13	0571019828	LOCK AXLE		01
14	0503010365	NUT		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521018630	1.4" X SQUARE 0.8" WASHER		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	Q3/4" FASTENER AXLE ASSY	24	01
20	0503030275	AGRICULTURAL BEARING		05
21	1902010685	18Z CONICAL GEAR		05




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0521066296	SEED SILO CENTRAL SUPPORT		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	49	03
03	1902010685	18Z CONICAL GEAR		05
04	0581016971	AXIS Q 3/4 X 1063		01
05	0571019828	LOCK AXLE		02
06	0503013816	5/16" LOCKNUT		04
07	0581016970	AXIS Q 3/4 X 763		01
08	0501010942	3/8" X 1-1/4" BOLT		20
09	0503010025	3/8" SPRING WASHER		20
10	0503010026	3/8" NUT		20
11	0503010365	NUT		04
12	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	50	02
13	0503030275	AGRICULTURAL BEARING		05




Item	Code	Description	See page	QT
01	0521066297	FERTILIZER SUPPORT LEFT BEAM		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	49	02
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	50	03
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503010025	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0501056271	BEARING CLOSED	22	01
08	0503011953	5/16" X 1" BOLT		02
09	0521011039	FLAT WASHER		02
10	0503010179	5/16" ZN SPRING WASHER		02
11	0503010337	5/16" NUT		02
12	0581016972	AXIS Q 3/4 X 1953		01
13	0571019828	LOCK AXLE		01
14	0503010365	NUT		02
15	0503013816	5/16" LOCKNUT		02
16	0503030303	SUPPORT WASHER		01
17	0521018630	1.4" X SQUARE 0.8" WASHER		03
18	0511061759	22Z P12,70 FQ 3/4" GEAR		01
19	0501053788	Q3/4" FASTENER AXLE ASSY	24	01
20	0503030275	AGRICULTURAL BEARING		05
21	1902010685	18Z CONICAL GEAR		05




Item	Code	Description	See page	QT
01	0503030331	1.2" X 1.2" X 12.2" HOSE		01
02	0503010243	CLAMP		02
03	0503062755	TRANSMISSION AXLE		01
04	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0581013322	BEARING RIGHT SUPPORT		01
02	0503011953	5/16" X 1" BOLT		04
03	0501010984	FLAT WASHER		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
05	0503013816	5/16" LOCKNUT		04
06	0501056444	BEARING WITH ROLLING	23	01




Item	Code	Description	See page	QT
01	0581013324	BEARING LEFT SUPPORT		01
02	0503011953	5/16" X 1" BOLT		04
03	0501010984	FLAT WASHER		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
05	0503013816	5/16" LOCKNUT		04
06	0501056444	BEARING WITH ROLLING	23	01



Item	Code	Description	See page	QT
01	0531060446	HANDRAIL		01
02	0551019884	45 X 50 X 3/8 FASTENER		04
03	0503013357	3/8" SELF-ADJUSTING NUT		08
04	0503011082	C1/2" X 1.3/4" SCREW		08
05	0503010019	1/2" SPRING WASHER		12
06	0503010060	1/2" NUT		12
07	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
08	0531060448	HANDRAIL		02
09	0571017991	CHAIN FIXER HANDRAIL		04
10	0503034094	22 TWISTED CHAIN		02




Item	Code	Description	See page	QT
01	0521067102	ARTICULATION CENTRAL PLATFORM	04	
02	0531062585	CENTRAL PLATFORM	01	
03	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
04	0503010741	1/2" X 2-3/4" BOLT	06	
05	0521067100	LEFT PLATAFORM	01	
06	0521067104	LEFT SIDE ARTICULATION PLATFORM	01	
07	0521067101	RIGHT PLATAFORM	01	
08	0521067103	RIGHT SIDE ARTICULATION PLATFORM	01	
09	0581012193	PLATFORM AMENDMENT PROTECTION	02	
10	0551019115	LOCKING PLATFORM FIXATION	03	
11	0571019831	X 0.2" SLEEVE	03	
12	0501010096	3/8" X 2" BOLT	03	
13	0501010984	FLAT WASHER	31	
14	0503013357	3/8" SELF-ADJUSTING NUT	03	
15	0503011333	COVER FIXER	04	
16	0503010274	5/32"X 2" COTTERPIN	04	
17	1902012740	PLATFORM RIGHT FIXER SUPPORT	02	
18	1902012739	PLATFORM LEFT FIXER SUPPORT	02	
19	0503010849	3/8" X 1-1/2" BOLT	12	
20	0503010025	3/8" SPRING WASHER	16	
21	0503010026	3/8" NUT	16	
22	0501010942	3/8" X 1-1/4" BOLT	04	




Item	Code	Description	See page	QT
01	0521057899	SUPPORT VALVE BLOCK VACUOMETER ASSY 5750/7350	59	01
02	0521057886	HOSE CLAMP ASSEMBLY	61	02
03	0581010324	HOSE PROTECTOR		01
04	0503010358	5/16" X 5/8" BOLT		04
05	0503010179	5/16" ZN SPRING WASHER		04
06	0503010337	5/16" NUT		04
07	0503013493	T CONNECTION MALE		02
08	0521057259	OIL CONDUCTOR FIXATION	62	08
09	0531060538	OIL CONDUCTOR		04
10	0531060537	OIL CONDUCTOR		02
11	0531060540	OIL TUBE		02
12	0531060545	OIL DUCT 275 6350		02
13	0521057915	HOSE KIT HYDRAULIC SYSTEM 6 WHEEL		01
13A	0501082269	HOSE 1/2 X 300 TR-TR		04
13B	0501080087	1/2" X 450 HOSE		03
13C	0501080096	1/2 X 500 TC-TC HOSE		08
13D	0501081235	1/2 X 650 TR- TC HOSE		02
13E	0501080024	1/2" X 700 TR-TR HOSE		04
13F	0501080218	1/2 X 750 HOSE		02
13G	0501080093	1/2 X 1300 HOSE TR-TC		01
13H	0501080058	HOSE 1/2 X 1400 TR-TC		01
13I	0501081834	1/2 X 1500 TR-TC HOSE		02
13J	0521057243	1/2 X 4350 TC-TM HOSE BLACK / RED		01
13JA	0501082259	HOSE 1/2 X 4350 TC-TM		01
13JB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
13JC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
13JD	0503018952	PLASTIC BOLT		06
13K	0521057244	HOSE 1/2 X 4900 TC-TM BLACK / BLUE		01
13KA	0501082260	HOSE 1/2 X 4900 TC-TM		01
13KB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
13KC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01


Item	Code	Description	See page	QT
13KD	0503018952	PLASTIC BOLT		06
14	0521057704	SLIDING SUPPORT HYDRAULIC HOSE	63	04
15	0581010091	SPRING PROTECTION PLASTIC HOSE		01
16	0581012991	SPRING PROTECTION PLASTIC HOSE		01
17	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	90	02
18	0581010090	SPRING PROTECTION PLASTIC HOSE		02
19	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		01




Item	Code	Description	See page	QT
01	0503062960	COMMAND BLOCK		01
02	0591013473	VACUOMETER GUIDE SCREW BOLT		02
03	0501010984	FLAT WASHER		02
04	0503010026	3/8" NUT		02
05	0503010025	3/8" SPRING WASHER		02
06	0502011170	FIXER		02
07	0503010384	1/2" X 5" BOLT		04
08	0511017302	FLAT WASHER		08
09	0503010589	1/2" UNC SELF ADJUSTING NUT		04
10	0503010179	5/16" ZN SPRING WASHER		04
11	0503015114	BOLT		04
12	0531060808	SUPPORT FIXING VALVE TRIPLE BLOCK		01
13	0521057855	CASAPPA DIVIDER VALVE WITH FIXING NIPLES	60	01
14	0591014208	GLOVE SUPPORT HYDRAULIC BLOCK		02




Item	Code	Description	See page	QT
01	0503019548	FLOW DIVIDER VALVE		01
02	0501010590	NIPPLE		03
03	0503010026	3/8" NUT		04
04	0501010984	FLAT WASHER		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0511018014	7/8"NF X 1.1/16 UN NIPPLE		01
08	0503010045	O'RING		03
09	0503011109	2-119 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0502010477	HOSE CLAMP		02
02	0502012702	BODY SUPPORT CLAMP		01
03	0503010718	3/8" X 3-1/2" BOLT		01
04	0503010026	3/8" NUT		01
05	0503010025	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0591012302	LOWER CLAMP FIXING OIL CONDUCTOR		01
02	0591012301	TOP CLAMP FIXING OIL CONDUCTOR		01
03	0503010025	3/8" SPRING WASHER		03
04	0503010026	3/8" NUT		03
05	0561017277	OIL CONDUCTOR FIXER PLATE		01
06	0521010718	5/8" U BOLT		01
07	0501012140	FLAT WASHER		02
08	0503010027	5/8" SPRING WASHER		02
09	0503010013	5/8" NUT		02
10	0501011755	3/8" X 3" BOLT		02
11	0502010477	HOSE CLAMP		02
12	0501010096	3/8" X 2" BOLT		01




Item	Code	Description	See page	QT
01	0591012962	SLIDING SUPPORT BODY HYDRAULIC HOSE		01
02	0591012961	GLOVE 16,30 X 30 X 230		01
03	0591012963	AXLE FIXING HOSE GLOVE		01
04	0503010013	5/8" NUT		02
05	0501012140	FLAT WASHER		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010071	3/16" X 1" COTTERPIN		02




Item	Code	Description	See page	QT
01	0511065449	ROW MARKER ARM SUPPORT	02	
02	0501010098	3/4" UNC BOLT	08	
03	0503011255	3/4" LOCK NUT	08	
04	0511061811	ROW MARKER ARM	02	
05	0503011067	5/8" X 2-1/2" BOLT	04	
06	0521010479	SLEEVE ARTICULATION	04	
07	0501012140	FLAT WASHER	04	
08	0503012795	5/8" HEX SELF ADJUSTING NUT	04	
09	0511058449	HYDRAULIC CYLINDER	02	
10	0521010575	C0.9" X 3.3" COUPLING SHAFT	02	
11	0503010571	1/4" X 1.1/2 COTTERPIN	02	
12	0511015779	1" X 4.2" AXLE	02	
13	0503010523	1/4" X 2" COTTERPIN	02	
14	0511017592	11.8" X 1.6" TRANSPORT LOCK	02	
15	0501068994	0.3" X 3.1" LOCK PIN	02	
16	0503030168	HAIR PIN	02	
17	0501066949	1235 TURNBUCKLE	02	
18	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	04	
19	0909098940	ROW MARKER HYDRAULIC CIRCUIT	01	
20	0503011070	BEATER	02	
21	0503010019	1/2" SPRING WASHER	02	
22	0503011082	C1/2" X 1.3/4" SCREW	02	



Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		04
02	0503010237	3/8" X 1" BOLT		08
03	0503010025	3/8" SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0511069636	LADDER		02
06	0503011179	3/8" X 2-1/4" BOLT		04
07	0501010984	FLAT WASHER		04
08	0503013357	3/8" SELF-ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0502011530	SUPPORT		02
02	0502010175	HITCH CLAMP		02
03	0501011543	5/8" X 4" BOLT		04
04	0503012412	5/8 UNC SELF LOCKING NUT		04
05	0501069951	PLOUGH SUPPORT		04
06	0501011075	PIN		02
07	0503030012	HAIR PIN		02



Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
05	0503010179	5/16" ZN SPRING WASHER		01
06	0503010337	5/16" NUT		01

COMPLETE HEADER ASSY

0909099261



Item	Code	Description	See page	QT
01	0521066289	FRONT HEADER 5750/6350/6850		01
02	0531060570	INTERMEDIATE HEADER 5750/6850		01
03	0571019949	JUNCTION SHAFT		06
04	0503030119	LOCK PIN		10
05	0521045756	HYDRAULIC CYLINDER		01
06	0521010779	31.75 X 95 COUPLING SHAFT		01
07	0521010581	0.9" X 4.9" COUPLING SHAFT		01
08	0503030085	LOCK PIN		06
09	0531016049	FLAT WASHER		02
10	0521050573	EXTENSOR 3RD POINT		01
11	0521018532	1.4" X 12" COUPLING SHAFT		01
12	0571019951	JUNCTION SHAFT		02
13	0503010523	1/4" X 2" COTTERPIN		04
14	0511055096	TRACTOR HITCH	69	01
15	0511053179	TRACTOR HITCH AXLE		01
16	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
17	0521050133	TURNBUCKLE SIDE 755/480		02
18	0521050574	EXTENSOR	70	02
19	0521010571	COUPLING SHAFT		04
20	0521057452	ASSY INTERMEDIATE HEADER FIXATION SUPPORT	71	04
21	0521050693	ASSEMBLY SET HOSE CYLINDER FRONT HEAD		01
21A	0521050692	HOSE KIT CYLINDER HEAD FRONT		01
21AA	0521052310	HOSE 1/2 X 4500 TM-TM GREEN / RED		01
21AAA	0501081929	HOSE 1/2 X 4500 TM-TM		01
21AAB	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
21AAC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
21AAD	0503018952	PLASTIC BOLT		06
21AB	0521052309	HOSE 1/2 X 4500 TM-TM GREEN / BLUE		01
21ABA	0501081929	HOSE 1/2 X 4500 TM-TM		01
21ABB	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
21ABC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01


COMPLETE HEADER ASSY

0909099261


Item	Code	Description	See page	QT
21ABD	0503018952	PLASTIC BOLT		06
21C	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	90	04
22	0571019950	COUPLING SHAFT		01
23	0581013729	NIPLE 1/2 NPT		01
24	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
25	0541010080	TERMINAL R.1 / 2 NPT		01
26	0503010045	O'RING		01

TRACTOR HITCH


0511055096




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0521066300	RIGHT TURNBUCKLE		01
02	0503010002	1800 GREASE FITTING		02
03	0521066301	LEFT TURNBUCKLE		01
04	0541018672	COUNTERNUT		01
05	0502011195	ADJUSTMENT NUT BODY		01



Item	Code	Description	See page	QT
01	0521067716	FIXER TUBE		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0503010152	3/4" SELF LOCKING NUT		04
05	0501010322	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE	17	
02	0503013151	ELECTRIC CONNECTION	01	
03	0503015482	CONNECTOR	03	
04	0503012903	T-80M CRAMP NYLON	50	
05	0521053672	LIGHTHOUSE ASSY	02	
06	0521052792	MOUNTED REAR LIGHT	01	
07	0503015907	MALE TERMINAL	02	
08	0503015908	FEMALE TERMINAL	02	
09	0503015906	TWO-WAY MALE CONNECTOR	01	
10	0503015905	TWO-WAY FEMALE MALE CONNECTOR	01	
11	0503015911	CABLE SEAL	04	
12	3505151602	TUBE	01	
13	0503017702	FIXER	03	




Item	Code	Description	See page	QT
01	0521057131	CENTRAL TURBINE MOUNTED WITH CSU	74	01
02	0521056143	RIGHT SIDE AIR DISTRIBUTOR	75	01
03	0521056112	LEFT SIDE AIR DISTRIBUTOR	76	01
04	0521057135	CENTRAL AIR DISTRIBUTOR 1978	77	01
05	0581012184	HOSE 4 X 250		02
06	0511015569	HOSE		02
07	0501082282	SEED CONDUCTOR 1.1/2 X 2000		15
08	0521052549	CLAMP	78	30
09	0503011372	102 TO 121 CLAMP		08
10	0591012114	SUPPORT WITH FOLDING FIXATION AIR DUCT CSU		02
11	0503010026	3/8" NUT		24
12	0503010025	3/8" SPRING WASHER		24
13	0503010237	3/8" X 1" BOLT		04
14	0571019403	STAPLE FIXER		06
15	0501013518	FLAT WASHER		12
16	0591012113	STRAIGHT SUPPORT FIXING AIR DUCT		04
17	0501010942	3/8" X 1-1/4" BOLT		08
18	0501010984	FLAT WASHER		08
19	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	90	02
20	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	79	01
21	0521057109	1/2 X 7000 TR-TM HOSE YELLOW / BLUE		01
21A	0501082007	HOSE 1/2 X 7000 TR-TM		01
21B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06
22	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
22A	0501080477	HOSE 3/8 X 7012 TC-TM		01
22B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
22C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01


Item	Code	Description	See page	QT
22D	0503018952	PLASTIC BOLT		06
23	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
23A	0501081247	HOSE 1/2 X 7012 TC-TM		01
23B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
23C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
23D	0503018952	PLASTIC BOLT		06
24	0581012991	SPRING PROTECTION PLASTIC HOSE		01
25	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
26	0581011173	SPRING PROTECTION PLASTIC HOSE		02
27	0503033981	ADHESIVE LABEL		01
28	0521057289	VACUOMETER FIXING SUPPORT CSU	80	01




Item	Code	Description	See page	QT
01	0521056673	TURBINE P.P CSC		01
02	0503010179	5/16" ZN SPRING WASHER		02
03	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
04	0503010190	2-114 N 3006-9B O'RING		02
05	0501011460	7/8 NF REDUCTION NIPPLE		02
06	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
07	0503010143	1/4" SPRING WASHER		02
08	0503010144	1/4" NUT		02
09	0503010305	FLAT WASHER		02
10	0501082254	HOSE 1/2 X 210 TC-TC		01
11	0503015114	BOLT		02
12	0591012425	CENTRAL SUPPORT FIXING TURBINE		01
13	0511017302	FLAT WASHER		08
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0503010920	1/2" X 1.1/2" BOLT		04



Item	Code	Description	See page	QT
01	0591010690	CONDUCTOR BODY AIR 5 MOUTH 1650 5 HOLES		01
02	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		05
02A	0503034812	SOCKET DISTRIBUTOR AR		01
02B	0503012856	POP RIVET		04
03	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
03A	0503034763	AIR DITRIBUTOR PUMP		01
03B	0503015341	POP RIVET		02
04	0503017845	PVC KNEE 90 SOLD AVEL		01
05	0581013890	SOCKET DISTRIBUTOR AR		01




Item	Code	Description	See page	QT
01	0591010690	CONDUCTOR BODY AIR 5 MOUTH 1650 5 HOLES		01
02	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		05
02A	0503034812	SOCKET DISTRIBUTOR AR		01
02B	0503012856	POP RIVET		04
03	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
03A	0503034763	AIR DITRIBUTOR PUMP		01
03B	0503015341	POP RIVET		02
04	0503017845	PVC KNEE 90 SOLD AVEL		01
05	0581013890	SOCKET DISTRIBUTOR AR		01




Item	Code	Description	See page	QT
01	0503012567	T-JOIN FOR TUBE 110		02
02	0581013890	SOCKET DISTRIBUTOR AR		04
03	0503017845	PVC KNEE 90 SOLD AVEL		04
04	0571019146	110 X 130 GLOVE		02
05	0591012118	AIR CONDUCTOR BODY		01
06	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		05
06A	0503034812	SOCKET DISTRIBUTOR AR		01
06B	0503012856	POP RIVET		04
07	0581019586	AIR CONDUCTOR BODY 1 MOUTH 268 04 HOLES		02

CLAMP


0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0503018799	QUICK COUPLING		01
02	0503011883	QUICK CONNECTION COVER		01




Item	Code	Description	See page	QT
01	0591012157	VACUOMETER FIXATION		01
02	0503013584	VACUUM GAUGE		01




Item	Code	Description	See page	QT
01	0521051730	ASSY FIXING SUPPORT	82	02
02	0511057755	ASSEMBLY CSU 6850	83	01
03	0521057149	ASSY RIGHT FIXING SUPPORT	85	02
04	0521057151	FIXING SUPPORT LEFT ASSY	86	02



Item	Code	Description	See page	QT
01	0531060573	FIXING SUPPORT CSU		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		04
07	0503010025	3/8" SPRING WASHER		04
08	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0503061899	REAR BEAN FERTILIZER ASSY		03
02	0521064813	SUPPORT SEED BOX ONLY 06 MOUTHS		03
03	0521063401	SEED BOX ONLY FIXING LOCK		06
04	0501010984	FLAT WASHER		06
05	0503010025	3/8" SPRING WASHER		78
06	0503010026	3/8" NUT		78
07	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	84	15
08	0501010942	3/8" X 1-1/4" BOLT		60
09	0501011643	3/8 X 1" BOLT		12
10	0571015773	SUPPORT SEED CSU		03



Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
09	0503010179	5/16" ZN SPRING WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01

ASSY RIGHT FIXING SUPPORT


0521057149



Item	Code	Description	See page	QT
01	0531060480	RIGHT FIXING SUPPORT CSU		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		04
07	0503010025	3/8" SPRING WASHER		04
08	0503010026	3/8" NUT		04

FIXING SUPPORT LEFT ASSY


0521057151




Item	Code	Description	See page	QT
01	0531060485	FIXING SUPPORT LEFT CSU		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	FLAT WASHER		04
07	0503010025	3/8" SPRING WASHER		04
08	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0503034963	ADHESIVE LABEL		01
02	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 MOUTH)		03
03	0503031565	ADHESIVE LABEL CARE		02
04	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
05	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
06	0503032930	ADHESIVE LABEL DANGER		04
07	0503031425	ADHESIVE LABEL ATTENTION		02
08	0503031087	ADHESIVE LABEL		01
09	0503031942	ADHESIVE LABEL		01
10	0503031669	ADHESIVE LABEL		01
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
12	0503034249	ADHESIVE LABEL TABLE PLANTS		02
13	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
14	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
15	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
16	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING		02
17	0503033422	ADHESIVE LABEL		02
18	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		04
19	0503034078	LIFTING POINTS DECAL		03
20	0503032979	ADHESIVE LABEL LETTERS A B C D		02
21	0503032949	ADHESIVE LABEL		01
22	0503031428	READ MANUAL DECAL		01
23	0503034500	ADHESIVE LABEL		01
24	0521056998	ALUMINUM IDENTIFICATION LABEL WITH RIVET		01
24A	0503034003	SERIAL NUMBER TAG 61 X 118		01
24B	0503010001	3.2 X 5.5 RIVET		04
25	0503034967	ADHESIVE LABEL (190 X 720)		04
26	0503034966	ADHESIVE LABEL (185 X 320)		03




Item	Code	Description	See page	QT
01	0503013030	5/8" X 3.1/4" BOLT		02
02	0511050681	TRACTION SPRING		01
02A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
02B	0561016062	SPRING HITCH		02
03	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521069643	DISC AXLE MARKER LINE		01
02	0602023094	DR16X3 C36AFPAFR73+4FR+4FR D474 10R		01
03	0581019513	DEPTH WHEEL BOX		01
04	0503019342	ROLLER BEARING		01
05	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503013758	1/4" X 1-1/2" BOLT		03
11	0503010143	1/4" SPRING WASHER		03
12	0503010358	5/16" X 5/8" BOLT		04
13	0503010179	5/16" ZN SPRING WASHER		04
14	0503010337	5/16" NUT		04
15	0503034055	CLAMPING RING		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01



Item	Code	Description	See page	QT
01	0503014820	COROTE BLACK WATER		01
02	0521068651	SUPPORT BOX		01
03	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		02
04	0503010025	3/8" SPRING WASHER		02
05	0501010984	FLAT WASHER		02



Item	Code	Description	See page	QT
01	0521068652	TOOLS BOX SUPPORT		01
02	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		02
03	0503010025	3/8" SPRING WASHER		06
04	0501010984	FLAT WASHER		02
05	0501011643	3/8 X 1"BOLT		04
06	0503010026	3/8" NUT		04
07	0503034772	BOX		01
08	0581017000	PLATE INTERMEDIARY		02



Item	Code	Description	See page	QT
01	0521056240	FRONT SHORT LINE	94	01
02	0521056241	FRONT LONG LINE	95	01
03	0521056941	RIGHT REAR P.P CSU TRANSMISSION/CABLE	97	01
04	0521056940	LEFT REAR P.P CSU TRANSMISSION CABLE	101	01
05	0521055053	DEEP WHEEL/COMPACTOR SYSTEM	105	01
06	0503063031	TRANSMISSION ASSY PRECISION PLANTING SHORT LINE		01
07	0503063033	TRANSMISSION ASSY PRECISION PLANTING LONG LINE		01
08	0503063035	TRANSMISSION ASSY PRECISION PLANTING SUPER LONG LINE		01
09	0521056069	SEMI-ASSEMBLED SHORT FERTILIZER LINE	116	01
10	0521056066	SEMI-ASSEMBLED LONG FERTILIZER LINE	117	01
11	0521053987	SCARIFIER SPINDLE WITH SOCKET RIGHT	121	01
12	0521053956	SCARIFIER SPINDLE WITH SOCKET LEFT	122	01
13	0503031145	2" X 2" X 20" HOSE		01
14	0503031076	2" HOSE CLAMP		01
15	0571011730	SEED CONDUCTOR 3X1500		01
16	0521050525	FIXER FERTILIZER CONDUCTOR	127	01
17	0503031050	CURVED CONDUCTOR		01
18	0503010246	CLAMP		01
19	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
20	0531061786	LEVER REGULATING PRESSURE LINE SEED		01
21	0521018501	TURNBUCKLE LEVER		01
22	0521068982	KEY CASH DISC CUTTING		01
23	0503010905	1/2" X 2-1/4" BOLT		01
24	0503010019	1/2" SPRING WASHER		01
25	0503010060	1/2" NUT		01
26	0521051447	FRONT ASSY ROW BEARING	128	01
27	0503010243	CLAMP		01
28	0531060405	EXTENSION		01




**COP TRIO 650 SUPREMA P.P MINI HOPPER - FRAME 6850 -
SEED/FERTILIZER ROW ASSY**

Page 93
0909095989


Item	Code	Description	See page	QT
29	0531053036	SHORT SEED LINE HOSE GUIDE STEEL CABLE	129	01
30	0531053037	LONG SEED LINE HOSE GUIDE STEEL CABLE	130	01

FRONT SHORT LINE


0521056240




Item	Code	Description	See page	QT
01	0503019273	SLEEVE	08	
02	0591011316	SEED LINE SUPPORT GLOVE	08	
03	0531060069	TOP ARM	01	
04	0531062744	FRONT LOWER ARM OF THE SHORT SEED LINE	01	
05	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
06	0531060077	PRESSURE REGULATOR	01	
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	02	
08	0591010915	SPRING REGULATOR	01	
09	0591010914	LOWER AXLE	01	
10	0591011315	SPRING AXLE	01	
11	0503010045	O'RING	08	
12	0503010131	3/16" X 1-1/2" COTTERPIN	01	
13	0503030168	HAIR PIN	01	
14	0531060068	REAR LINE	01	
15	0503019295	SCREW 5/8 UNF X 7 CS RP G.5 ZN	04	
16	0502010175	HITCH CLAMP	02	
17	0503017857	BOLT 5/8 UNF 4	04	
18	0501012140	FLAT WASHER	04	
19	0531060073	FRONT LINE SUPPORT	01	
20	0521010542	COUPLING SHAFT	01	
21	0503010300	5/32" X 1" COTTERPIN	01	
22	0591010913	TRANSPORT BUMPER	01	
23	0501010301	FLAT WASHER	04	
24	0503010878	5/8" SELF ALIGNING NUT	04	
25	0503030012	HAIR PIN	01	
26	0571016296	FLAT WASHER	04	
27	0531052956	ASSEMBLY SEED LINE TRANSMISSION FIXING 96 BEARING	01	




Item	Code	Description	See page	QT
01	0503019273	SLEEVE	08	
02	0591011316	SEED LINE SUPPORT GLOVE	08	
03	0531060069	TOP ARM	01	
04	0531060070	LOWER ARM	01	
05	0503010811	5/8" UNF SELF ADJUSTING NUT	08	
06	0531060077	PRESSURE REGULATOR	01	
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	02	
08	0591010915	SPRING REGULATOR	01	
09	0591010914	LOWER AXLE	01	
10	0591011315	SPRING AXLE	01	
11	0503010045	O'RING	08	
12	0503010131	3/16" X 1-1/2" COTTERPIN	01	
13	0503030168	HAIR PIN	01	
14	0531060068	REAR LINE	01	
15	0503019295	SCREW 5/8 UNF X 7 CS RP G.5 ZN	04	
16	0531060073	FRONT LINE SUPPORT	01	
17	0521010542	COUPLING SHAFT	01	
18	0503010300	5/32" X 1" COTTERPIN	01	
19	0591010913	TRANSPORT BUMPER	01	
20	0501010301	FLAT WASHER	04	
21	0531060072	EXTENDER	01	
22	0502010175	HITCH CLAMP	02	
23	0503017857	BOLT 5/8 UNF 4	04	
24	0501012140	FLAT WASHER	08	
25	0503012798	5/8" X 2" BOLT	04	
26	0503010878	5/8" SELF ALIGNING NUT	04	
27	0503030012	HAIR PIN	01	
28	0571016296	FLAT WASHER	04	
29	0531052956	ASSEMBLY SEED LINE TRANSMISSION FIXING 96 BEARING	01	




Item	Code	Description	See page	QT
01	0531060071	BEARING		01
02	0551015804	BEARING AXLE BODY		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02
07	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
08	0503012880	1/4" UNC SELF ADJUSTING NUT		02
09	0503019373	6006 2RS1 NATIONAL BEARING		01
10	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0521056955	RIGHT DDD ASSY	98	01
02	0503062403	TUBE SEED P.P		01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0521056956	PRECISION PLANTING CABLE/TRANSMISSION ASSY	CSU 99	01
06	0503012136	NUT 1/2 NF		04
07	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04




Item	Code	Description	See page	QT
01	0591011773	RIGHT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	FLAT WASHER		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 103 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 104 FERTILIZER / SEED		01



Item	Code	Description	See page	QT
01	0502012924	PRECISION PLANTING SUPPORT	01	01
02	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN	01	01
03	0503010589	1/2" UNC SELF ADJUSTING NUT	01	01
04	0503010140	1/8" X 3/4" COTTERPIN	01	01
05	0571014024	FAST BOLT GUIDE AXLE	01	01
06	0503034824	FIXATIVE	01	01
07	0503010293	BAQUELITE MANIPULACION	01	01
08	0503010025	3/8" SPRING WASHER	06	06
09	0502012922	FIXING SUPPORT	01	01
10	0503011404	BOLT	01	01
11	0503013357	3/8" SELF-ADJUSTING NUT	01	01
12	0503010026	3/8" NUT	04	04
13	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN	04	04
14	0571019491	SLUICE PNEUMATIC PRECISION PLANTING	01	01
15	0501011643	3/8 X 1" BOLT	01	01
16	0503010209	3/8" UNC BUTTERFLY NUT	01	01
17	0502012807	SUPPORT BOX PRECISION PLANTING	01	01
18	0571019489	CLAMP PRECISION PLANTING	01	01
19	0503012721	1/4" X 4" BOLT	01	01
20	0503012880	1/4" UNC SELF ADJUSTING NUT	01	01
21	0503818139	BOLT	03	03
22	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN	02	02
23	0503015110	M06 SPRING WASHER	02	02
24	0503037390	PACKING FOR PLANTING	01	01
25	0503010179	5/16" ZN SPRING WASHER	04	04
26	0503011953	5/16" X 1" BOLT	03	03
27	0503010337	5/16" NUT	04	04
28	0503012163	5/16" X 1-1/2" BOLT	01	01
29	0581011226	FIXER CLOSING P PLANTING CONTR CPRA	01	01
30	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 100 DISC	01	01
31	0521066707	FEEDER	01	01




Item	Code	Description	See page	QT
01	0571019613	STRAW PRECISION PLANTING SHIELD		01
02	0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT PROTECTION		01




Item	Code	Description	See page	QT
01	0521056954	LEFT DDD ASSY	102	01
02	0503062403	TUBE SEED P.P		01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0521056956	PRECISION PLANTING CABLE/TRANSMISSION ASSY	CSU 99	01
06	0503012136	NUT 1/2 NF		04
07	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04

LEFT DDD ASSY


0521056954




Item	Code	Description	See page	QT
01	0591011772	LEFT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	FLAT WASHER		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 103 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 104 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED		01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED		01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	106	01
02	0521055068	RAYED WHEEL CENTER CLOSED	111	02
03	0521054990	LEFT COMPACTOR WHEEL	113	01
04	0521055017	RIGHT COMPACTOR WHEEL	114	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY	107	01
06	0503019398	AXLE RETAINER RING		01
07	0521055033	COMPACTADOR BODY	108	01
08	0521055054	LEFT ARM WITH SLEEVE	109	01
09	0521055066	RIGHT ARM WITH GLOVE	110	01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2" NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED GLOVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	SEED SIST CONTROL DEPTH LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT GLOVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0581019523	LEFT ARM WHEEL DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019524	RIGHT ARM DEPTH		01
02	0581019514	LUBRICANT GLOVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521055055	BOX WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	112	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	5/16" ZN SPRING WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0581019522	CASE WHEEL DEPTH WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0503010143	1/4" SPRING WASHER		03
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019529	DEPTH REGULATOR SHAFT		01
11	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	115	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	115	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05



Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0531060002	REAR SUPPORT LINE FERTILIZER		01
02	0503019405	GLOVE		08
03	0591010640	SPACER GLOVE ARM WITHOUT LUBRICATION		08
04	0503010045	O'RING		04
05	0531060001	TOP SUPPORT FERTILIZER LINE		01
06	0521069998	LOWER SUPPORT LINE FERTILIZER		01
07	0591010629	SHORT FERTILIZER LINE SUPPORT		01
08	0503010233	5/8" X 2-1/2" BOLT		02
09	0503012412	5/8 UNC SELF LOCKING NUT		05
10	0501010452	5/8" X 5" BOLT		03
11	0502012727	BLADE DISC SUPPORT		01
12	0503011255	3/4" LOCK NUT		02
13	0503011328	3/4" X 4" BOLT		02
14	0501010322	FLAT WASHER		02
15	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
16	0503010013	5/8" NUT		02
17	0521056070	DC 20 ASSY	118	01
18	0521011158	SPRING LOCKNUT		01
19	0521062073	SPRING GUIDE		01
20	0521018575	REGULATOR SPINDLE 100		01
21	0503031450	2.7" X 9.2" X 0.03" SPRING		01
22	0521016057	COUP SHA OF THE CARRY-W SPRING GUI		01
23	0503030168	HAIR PIN		01
24	0502020393	SPRING UPPER SUPPORT		02




Item	Code	Description	See page	QT
01	0531060002	REAR SUPPORT LINE FERTILIZER		01
02	0503019405	GLOVE		08
03	0591010640	SPACER GLOVE ARM WITHOUT LUBRICATION		08
04	0503010045	O'RING		04
05	0531060001	TOP SUPPORT FERTILIZER LINE		01
06	0521069998	LOWER SUPPORT LINE FERTILIZER		01
07	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		04
08	0503010233	5/8" X 2-1/2" BOLT		02
09	0503012412	5/8 UNC SELF LOCKING NUT		09
10	0501010452	5/8" X 5" BOLT		02
11	0502012727	BLADE DISC SUPPORT		01
12	0503011255	3/4" LOCK NUT		02
13	0521069993	LONG FERTILIZER LINE SUPPORT		01
14	0501010125	3/4" X 2-1/2" BOLT		02
15	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
16	0503010013	5/8" NUT		02
17	0521056070	DC 20 ASSY	118	01
18	0521011158	SPRING LOCKNUT		01
19	0521062073	SPRING GUIDE		01
20	0521018575	REGULATOR SPINDLE 100		01
21	0503031450	2.7" X 9.2" X 0.03" SPRING		01
22	0521016057	COUP SHA OF THE CARRY-W SPRING GUI		01
23	0503030168	HAIR PIN		01
24	0502020393	SPRING UPPER SUPPORT		02
25	0502012724	FERTILIZER ROW FIXER		01
26	0501010163	5/8" X 4-1/2" BOLT		01

DC 20 ASSY

0521056070




Item	Code	Description	See page	QT
01	0571019034	FLANGE WASHER AXLE		02
02	0571019032	SUPPORT WASHER		01
03	0502012813	FLANGE WASHER SPRING		01
04	0591010619	DC SPRING SUPPORT		01
05	0503019274	WASHER		02
06	0581017628	COVER		02
07	0503019277	SLEEVE LUBRICATION SYSTEM		01
08	0501110964	RIGHT ARM WITH GLOVE		01
09	0501110965	LEFT ARM WITH GLOVE		01
10	0503034709	COMPRESSION SPRING 100 X 315 X 15.87		01
11	0521069996	ROD SPRING FERTILIZER		01
12	0591010624	GLOVE SUPPORT ARM DC		01
13	0591010625	GLOVE 19,50 X 25 X 91,50 / 91,30		01
14	0503010417	7/8" NUT		02
15	0503010390	SEAL RING		02
16	0503011198	C3/4" X 6" SCREW		01
17	0501010322	FLAT WASHER		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503010060	1/2" NUT		01
20	0503010019	1/2" SPRING WASHER		01
21	0503011255	3/4" LOCK NUT		01
22	0503030430	7/16 X 2" PIN LOCK		01
23	0503019271	SELF LUBRICATING BUSHING		01
24	0521069997	DC FIXING AXIS WITH LIMITER		01
25	0591010628	DC AXIS BACKREST WASHER		01
26	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	119	01
27	0503011254	7/8" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	CUTTING DISK BOX	120	01

CUTTING DISK BOX


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4	01	
02	0502040872	REGULATORY NUT	01	
03	0503010370	502072 CLAMPING RING (FOR AXLE)	02	
04	0503010590	00674-B SEAL	02	
05	0503019285	RING	02	
06	0503012170	30207 ROLLER BEARING	02	
07	0502020641	BLADE DISC FLANGE	01	
08	0502012862	CUTTING DISK BOX	01	
09	0502040873	CUTTING DISC AXLE	01	
10	0503017755	NUT	01	
11	0503018825	5/16 UNC UNC BOLT	06	
12	0501010694	8.5 X 18 X 1.5 FLAT WASHER	06	
13	0503013816	5/16" LOCKNUT	06	
14	0511017907	1/8" BSPT X 6 PLUG	02	




Item	Code	Description	See page	QT
01	0581010082	FERTILIZER SOCKET RIGHT		01
02	0511059454	ADJUSTMENT BAR	126	01
03	0521053957	ROD WITH ARM/DISARMENT	123	01




Item	Code	Description	See page	QT
01	0521053957	ROD WITH ARM/DISARMENT	123	01
02	0581010083	FERTILIZER SOCKET LEFT		01
03	0511059454	ADJUSTMENT BAR	126	01




Item	Code	Description	See page	QT
01	0503012795	5/8" HEX SELF ADJUSTING NUT		01
02	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
03	0503010691	1/4" GREASE FITTING		01
04	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
06	0503011336	1/2" HEX SELF ADJUSTING NUT		04
07	0521067063	SPRING BOX HDA		01
08	0571018541	BODY SOCKET FERTILIZER		01
09	0521053958	STEM WITH NOZZLE HDA	124	01
10	0581012108	SPRING SUPPORT WASHER HDA		01
11	0503034107	71,50 X 230 X 16,50 SPRING COMPRESSION		01
12	0571018053	GUIDE SPRING SUPPORT		01
13	0503010384	1/2" X 5" BOLT		02
14	0511017302	FLAT WASHER		04
15	0503010547	1/2" X 4" BOLT		02
16	0503010026	3/8" NUT		02
17	0501010984	FLAT WASHER		04
18	0503010025	3/8" SPRING WASHER		02
19	0581012084	ARTICULATED GLOVE		01
20	0581012081	GLOVE		01
21	0581012082	SCREW		01
22	0503010417	7/8" NUT		01




Item	Code	Description	See page	QT
01	0521053959	ROD WITH AUTOMATIC DISARM TIP	125	01
02	0521067067	WASHER SPRING WASHER 71.50 HDA		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0581012092	AXLE FIXER		01
05	0521015818	FLAT WASHER		02



Item	Code	Description	See page	QT
01	0521067066	ROD WITHOUT NOZZLE AUTOMATIC DISARM		01
02	0502040901	FIXED ROD NOZZLE		01
03	0503016853	SPRING PIN		02
04	0503011402	0.2" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0571016532	ADJUSTMENT BAR		02
02	0511017969	0.1" SPACING PLATE		02




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010365	NUT		02

FRONT ASSY ROW BEARING


0521051447




Item	Code	Description	See page	QT
01	0581014691	BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02
05	0503012861	6006 2RS BALL BEARING		01
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0581015056	SLEEVE		01
08	0551015804	BEARING AXLE BODY		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
001	0531052349	CURRENT GUIDE ASSEMBLY	131	01
002	0531052347	HOSE SUPPORT ASSEMBLY	132	01




Item	Code	Description	See page	QT
01	0531052349	CURRENT GUIDE ASSEMBLY	131	01
02	0531052347	HOSE SUPPORT ASSEMBLY	132	01
03	0531052953	TRANSMISSION CABLE GUIDE		01
03A	0531062742	CABLE GUIDE		01
03B	0503010071	3/16" X 1" COTTERPIN		01



Item	Code	Description	See page	QT
01	0501011778	3/8" X 2-1/2" BOLT		02
02	0503010025	3/8" SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0591016329	ENCAPSULATED CHAIN CLOSING		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010669	FLAT WASHER		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010667	3/16" NUT		02
09	0531062745	CHAIN GUIDE		01



Item	Code	Description	See page	QT
01	0501210006	ASSY ARTICULATED CONDUCTOR SUPPORT		01
02	0501011643	3/8 X 1"BOLT		03
03	0503013357	3/8" SELF-ADJUSTING NUT		03
04	0531062741	SEED HOSE GUIDE		01
05	0501010984	FLAT WASHER		01
06	0503010071	3/16" X 1" COTTERPIN		01
07	0521065815	GUIDE SUPPORT		01



MARCHESAN

Technical Publications | Elaboration and Revision

LORENA ROCHA ALVES

www.marchesan.com.br

