

ROW CROP PLANTERS

USAP SUPREMA P.P MINI HOPPER - 24 LINES/SPACING 500 - CSC

Code: 0501093149
Series: S-0118
Revision: 00
Date Revision: DEZEMBRO/2021

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111440107	USAP SUP PP 24E500 CSC ESPECIAL S-0118

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and / or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer.



MARCHESAN

INDEX

0909096093	ASSY FRAME	1
0909096094	ASSY RIGHT SIDE FRAME	2
0909096095	ASSY CENTRAL FRAME	3
0909096096	ASSY LEFT SIDE FRAME	4
0521051435	PANTOGRAPHY HEADER	5
0511058228	HYDRAULIC CYLINDER DRAWBAR HYDRAULIC	6
0511052507	FRONT SUPPORT ASSY HOSES	7
0521051438	HEADER 3 POINTS ASSY	8
0521053721	FRENCH HAND ASSY RIGHT 3865	9
0521053724	FRENCH HAND 3865 ASSY LEFT	10
0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	11
0511051299	ROTATING RIGHT AXIS EXTENSOR	12
0501059876	ROTATING LEFT AXIS EXTENSOR	13
0521052137	TELESCOPIC ASSY 788	14
0511052388	REST GREATER ASSY	15
0511053121	GREATER TOOL BOX ASSY	16
0511054256	COROT WATER	17
0531050873	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	18
0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	19
0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	20
0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	21
0521052872	SEED BOX 15/7 RIGHT SIDE OUTLETS	22
0511059553	SIDE STAND WITH FIXING	23
0521053174	CENTRAL SEED BOX 15 OUTPUTS WITH LID	24
0521053173	CENTRAL SEED BOX 15 EXITS	25
0521053175	BASE CSC BOX 15 OUTPUTS	26
0521052398	SIDE PLATFORM	27
0511059822	ASSY SIDE PLATFORM SUPPORT	28
0521052175	SUPPORT PLATFORM ASSY	29
0521052397	RIGHT SIDE HANDRAIL	30
0521052136	FRONT SIDE HANDRAIL 2235	31
0521052139	FRONT SIDE HANDRAIL 565	32
0511059383	INTERNAL FIXER ASSY HANDLE	33
0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	34
0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	35
0511053320	ASSY SIDE LADDER	36
0521052884	RIGHT SIDE AIR DUCT ASSEMBLY	37
0521052170	RIGHT CENTRAL AIR CONDUCTOR	38
0521053183	SIDE AIR CONDUCTOR 5 INPUT 2334	39
0511057646	ASSY AIR CONDUCTOR SUPPORT	40
0521052549	CLAMP	41
0521052168	SEED HOSE GUIDE	42
0521052392	SIDE GUTTER ASSY	43
0511057011	SUPPORT GUTTER ASSY	44
0521052891	RIGHT SIDE DUCT ASSEMBLY	45
0511059943	SUPPORT FASTENER ASSY	46
0511059928	SIDE DUTY SUPPORT	47
0511059929	TURBINE PRECISION PLANTING WITH SUPPORT CSCP	48
0521050154	TURBINE P.P WITH HOLE	49
0521050332	VACUOMETER WITH ASSY SUPPORT	50
0909096097	ASSY SEED/FERTILIZER LINE	51
0521053691	LONG/LEFT LINE VDRIVE	52
0521053690	SHORT/RIGHT LINE VDRIVE	53
0521053705	LONG/LEFT LINE (INTERNAL) VDRIVE	54
0521053704	SHORT/RIGHT LINE (INTERNAL) VDRIVE	55



MARCHESAN

INDEX


0521053180	FRONT LONG SEED LINE VDRIVE/MINI HOPPER	56
0521053179	FRONT SHORT SEED LINE VDRIVE/MINI HOPPER	57
0521053178	INTERNAL FRONT LONG SEED LINE VDRIVE/MINI HOPPER	58
0521053177	INTERNAL FRONT SHORT SEED LINE VDRIVE/MINI HOPPER	59
0511052300	CONDUCTOR SUPPORT ASSY SEED	60
0521053345	LEFT REAR PRECISION PLANTING	61
0521053343	REAR RIGHT PRECISION PLANTING	62
0521053356	DOUBLE DISC LEFT HIGH CUBE	63
0521053344	DOUBLE DISC RIGHT HIGH CUBE	64
0501054167	BOX DDD ASSY DPL 15 RIGHT	65
0501054168	BOX DDD ASSY DPL 15 LEFT	66
0521052142	DISC CUT DPL 20 ASSY	67
0521052141	ASSY LOWER SUPPORT DPL 20	68
0511058648	BOX WITH DISC BLADE 20"	69
0511056909	DISC BOX CUT WITHOUT THE DISC	70
0521053482	ASSY PP MINI HOPPER VDRIVE CSC	71
0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT PROTECTION	72
0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	73
0501056769	DEPTH WHEELS REGULATOR ASSY	74
0521051423	COMPACTOR SUPPORT	75
0501052908	COMPACTOR WHEEL WITH BEARING	76
0511050077	WHEEL STRIPED	77
0511052287	DEPTH WHEEL HUB ASSY	78
0521053700	CENTRAL FRAME 4686 TELESCOPIC FIXATION/LOCK	79
0521043436	CENTRAL WHEEL WITHOUT TRANSMISSION	80
0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE	81
0521052354	SEED BOX 15 CENTRAL OUTLETS CSCP	82
0521052156	ASSY CENTRAL SUPPORT	83
0521052351	ASSY LADDER	84
0521052154	ASSY REAR LADDER PLATFORM	85
0521052140	HANDRAIL SIDE FRAME CENTRAL	86
0521052138	LADDER REAR	87
0511052457	REAR SIDE HANDRAIL LADDER	88
0511052499	HANDRAIL LADDER BACK RIGHT CENTRAL FRAME	89
0521052149	ARTICULATION ARM LEFT ASSY	90
0521052147	ARTICULATION ARM RIGHT ASSY	91
0521052353	ASSEMBLY CYLINDER ARTICULATED ARM	92
0511058241	HYDRAULIC CYLINDER 50,80 X 114,30 X 964 X 638	93
0521053706	ENSEMBLE HYDRAULIQUE CSC/VDRIVE	94
0521053702	CENTRAL DUCT ASSEMBLY	95
0521053537	CENTRAL REAR DUCT SUPPORT	96
0521053098	ASSY BLFP2604 BLOCK	97
0521052155	SEQUENTIAL VALVE ASSY	98
0521052377	HOSE ARTICULATION KIT	99
0521052376	HEADER HOSE ASSY	100
0521052378	LIFTING HOSE GAME	101
0521052379	HOSE KIT TURBINE	102
0521052153	ASSY HOSE GUIDE	103
0521052134	SUPPORT BLOCK COMMAND	104
0521053703	ISOBUS ELECTRICAL ASSEMBLY	105
0521052174	LANTERN WITH SUPPORT	106
0521053672	LIGHTHOUSE ASSY	107
0521052374	CENTRAL AIR DUCT ASSEMBLY	108
0521051659	10 MOUTH CENTRAL AIR CONDUCTOR	109

INDEX

0521052152	REAR CENTRAL AIR CONDUCTOR 1520	110
0521051096	REAR CENTRAL AIR CONDUCTOR 1120 CSCP	111
0521051092	AIR CONDUCTOR ASSY SUPPORT CSCP	112
0521050785	SUPPORT CONDUCTOR AIR ASSY	113
0521052882	CENTRAL GUTTER ASSEMBLY	114
0521053726	ASSEMBLY VDRIVE 24E500	115
0521052876	ADHESIVE LABEL ASSY 24LINHAS CSC	116
0521053296	AXIS ARTICULATOR	117
0521050413	MONITOR/VDRIVE COMPONENT ASSEMBLY	118
0521051523	ASSY SYSTEM ELECTRONIC	119
0521052453	SUPPORT WITH FLOW DIVISOR BLOCK FOR 02 TURBINES	120
0521053481	FLOW DIVIDER BLOCK FOR 02 TURBINES	121
0521052875	SEED BOX 15/7 LEFT SIDE OUTLETS	122
0521052393	LEFT SIDE HANDRAIL 3640 CSCP	123
0521052135	LEFT SIDE HANDRAIL 2235	124
0511059951	ASSY HYDRAULIC TURBINE	125
0511059823	ASSY POSITIVE AIR TURBINE SUPPORT	126
0521045392	HYDRAULIC TURBINE WITH SCREEN	127
0501054983	NIPPLE HIDRAULIC MOTOR	128
0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE	129
0521052890	LEFT SIDE AIR DUCT ASSEMBLY	130
0521052171	LEFT CENTRAL AIR CONDUCTOR	131
0521052892	LEFT SIDE DUCT ASSEMBLY	132

ASSY FRAME


0909096093




Item	Code	Description	See page	QT
01	0909096094	ASSY RIGHT SIDE FRAME	2	01
02	0909096095	ASSY CENTRAL FRAME	3	01
03	0909096096	ASSY LEFT SIDE FRAME	4	01
04	0521051435	PANTOGRAPHY HEADER	5	01
05	0521051438	HEADER 3 POINTS ASSY	8	01
06	0521053721	FRENCH HAND ASSY RIGHT 3865	9	01
07	0521053724	FRENCH HAND 3865 ASSY LEFT	10	01
08	0521052137	TELESCOPIC ASSY 788	14	01
09	0521064812	SMALLER TRANSPORT LOCK		01
10	0511052388	REST GREATER ASSY	15	01
11	0511053121	GREATER TOOL BOX ASSY	16	01
12	0511054256	COROT WATER	17	01
13	0503014120	CHAIN		01
14	0503014321	CABLE STEEL SHACKLE		02

ASSY RIGHT SIDE FRAME

0909096094



Item	Code	Description	See page	QT
00	0521053684	RIGHT SIDE FRAME		01
01	0501110882	RIGHT FRAME WITH GLOVE 3640		01
01A	0581012179	SLEEVE		02
01B	0521068350	RIGHT FRAME 3640		01
02	0531050873	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	18	02
03	0521052872	SEED BOX 15/7 RIGHT SIDE OUTLETS	22	01
04	0521052398	SIDE PLATFORM	27	01
05	0521052397	RIGHT SIDE HANDRAIL	30	01
06	0511053320	ASSY SIDE LADDER	36	01
07	0521052884	RIGHT SIDE AIR DUCT ASSEMBLY	37	01
08	0521052392	SIDE GUTTER ASSY	43	01
09	0521052891	RIGHT SIDE DUCT ASSEMBLY	45	01
10	0511059929	TURBINE PRECISION PLANTING WITH SUPPORT CSCP	48	01
11	0521050332	VACUOMETER WITH ASSY SUPPORT	50	01
12	0503015062	TUBE		1,5mts
13	0909096097	ASSY SEED/FERTILIZER LINE	51	07



Item	Code	Description	See page	QT
00	0521053699	CENTRAL FRAME		01
01	0521053700	CENTRAL FRAME 4686 TELESCOPIC 79 FIXATION/LOCK		01
02	0521043436	CENTRAL WHEEL WITHOUT TRANSMISSION	80	04
03	0521052354	SEED BOX 15 CENTRAL OUTLETS CSCP	82	01
04	0521052351	ASSY LADDER	84	01
05	0521052149	ARTICULATION ARM LEFT ASSY	90	01
06	0521052147	ARTICULATION ARM RIGHT ASSY	91	01
07	0521052353	ASSEMBLY CYLINDER ARTICULATED ARM	92	01
08	0521053706	ENSEMBLE HYDRAULIQUE CSC/VDRIVE	94	01
09	0521053703	ISOBUS ELECTRICAL ASSEMBLY	105	01
10	0521052374	CENTRAL AIR DUCT ASSEMBLY	108	01
11	0521052882	CENTRAL GUTTER ASSEMBLY	114	01
12	0521053726	ASSEMBLY VDRIVE 24E500	115	01
13	0521052876	ADHESIVE LABEL ASSY 24LINHAS CSC	116	01
14	0521055637	ASSY TRANSPORT LOCK		04
14A	0551018312	TRANSPORT LOCK		01
14B	0501068994	0.3" X 3.1" LOCK PIN		01
14C	0503030168	HAIR PIN		01
15	0561016793	FIXED WRENCH		01
16	0501047885	ROD STOP		08
17	0561017063	HOLDER TUBE		02
18	0503011372	102 TO 121 CLAMP		08
19	0521053296	AXIS ARTICULATOR	117	01
20	0521050413	MONITOR/VDRIVE COMPONENT ASSEMBLY	118	01
21	0521051523	ASSY SYSTEM ELECTRONIC	119	01
22	0521052453	SUPPORT WITH FLOW DIVISOR BLOCK FOR 02 TURBINES	120	01
23	0503010045	O'RING		01
24	0541010080	TERMINAL R.1 / 2 NPT		01
25	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
26	0581013729	NIPLE 1/2 NPT		01




ASSY CENTRAL FRAME

0909096095


Item	Code	Description	See page	QT
27	0503011883	QUICK CONNECTION COVER		01
28	0503011628	FEMALE QUICK COUPLER		01
29	0909096097	ASSY SEED/FERTILIZER LINE	51	10

ASSY LEFT SIDE FRAME


0909096096




Item	Code	Description	See page	QT
00	0521053689	LEFT SIDE FRAME		01
01	0501110883	LEFT FRAME WITH GLOVE 3640		01
01A	0521068352	LEFT FRAME 3640		01
01B	0581012179	SLEEVE		02
02	0531050873	SIDE CENTRAL WHEEL WITHOUT TRANSMISSION	18	02
03	0521052875	SEED BOX 15/7 LEFT SIDE OUTLETS	122	01
04	0521052398	SIDE PLATFORM	27	01
05	0521052393	LEFT SIDE HANDRAIL 3640 CSCP	123	01
06	0511053320	ASSY SIDE LADDER	36	01
07	0511059951	ASSY HYDRAULIC TURBINE	125	01
08	0521052890	LEFT SIDE AIR DUCT ASSEMBLY	130	01
09	0521052392	SIDE GUTTER ASSY	43	01
10	0521052892	LEFT SIDE DUCT ASSEMBLY	132	01
11	0511059929	TURBINE PRECISION PLANTING WITH SUPPORT CSCP	48	01
12	0521050332	VACUOMETER WITH ASSY SUPPORT	50	01
13	0503015062	TUBE		1,5mts
14	0909096097	ASSY SEED/FERTILIZER LINE	51	07



Item	Code	Description	See page	QT
01	0521062955	SEED ARM SUPPORT ROW		01
02	0501079585	ARM USAP		01
03	0521063433	EAR ARM PANTOGRAPH WITH LOOK		01
04	0521063434	EAR ARM PANTOGRAPH		01
05	0502040864	GEAR BOX WITH REGULATOR		01
06	0521068007	TRACTOR HITCH		01
07	1902040327	LOCK SLEEVE		01
08	0521010578	COUPLING SHAFT		01
09	0503010523	1/4" X 2" COTTERPIN		01
10	0521063432	LOCK AXLE		02
11	0521063022	AXLE LOWER		02
12	0571011013	AXLE ARM		01
13	0503012198	3/16" X 2" COTTERPIN		04
14	0503010002	1800 GREASE FITTING		03
15	0501019435	32 X 50 X 1.5 FLAT WASHER		02
16	0503031035	HAIR PIN		02
17	0511058228	HYDRAULIC CYLINDER DRAWBAR HYDRAULIC	6	01
18	0511052507	FRONT SUPPORT ASSY HOSES	7	01
19	0501081848	HOSE 3/8 X 3200 TR-TM		02
20	0503011052	1.1/4" X 0.77" CASTLE NUT		02
21	0501010307	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521062362	CYLINDER CASE		01
02	0521062361	ROD CILINDER DRAWBAR HYDRAULIC		01
03	0503010002	1800 GREASE FITTING		02
04	0503030384	CON PLUG N-001		02
05	0503010817	1.1/4" SELF LOCKING NUT		01
06	0503010345	2-218 N 3006-9B O'RING		01
07	0502010382	5" END CAP		01
08	0581010353	RING SUPPORT		01
09	0503018026	1870-2000-375 B GASKET		01
10	0503011453	O'RING		02
11	0503018152	O'RING		02
12	0503018024	RING BS		01
13	0503018025	RING GUIDE		01
14	0581010354	PISTON		01
15	0503018150	RING GUIDE		01
16	0503018151	RING BS		02
17	0503010039	D-2000 SCRAPER RING		01
18	0511032524	ASSY CYLINDER REPAIR KIT 50,8X127 USAP (0511058228)		01




Item	Code	Description	See page	QT
01	0521066319	FRONT SUPPORT HYDRAULIC HOSE		01
02	0503010019	1/2" SPRING WASHER		01
03	0503010395	1/2" X 1-1/4" BOLT		01

HEADER 3 POINTS ASSY


0521051438




Item	Code	Description	See page	QT
01	0561013456	GUIDE DRAWBAR ASSY		02
02	0501010276	BOLT		04
03	0503010012	1" SPRING WASHER		04
04	0501010059	1.5/8 NUT		04
05	0503030119	LOCK PIN		02
06	0511069471	PLOUGH SUPPORT		02
07	0501011075	PIN		02
08	0503030285	HAIR PIN		02
09	0521068020	DRAWBAR ASSY		01
10	0503030085	LOCK PIN		04
11	0521068018	UPPER AXLE		01
12	0521068015	UPPER AXLE		01
13	0521068013	UPPER AXLE		01
14	0521068011	AXLE LOWER		02
15	0521068010	HITCH AXLE		01
16	0521068009	UPPER AXLE		01
17	0503031035	HAIR PIN		01




Item	Code	Description	See page	QT
01	0503010180	7/16" SPRING WASHER		06
02	0503010002	1800 GREASE FITTING		01
03	1902010477	UPPER CLAMP BODY		06
04	0503011135	BOLT		06
05	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	11	01
06	0521069045	OIL DUCT 2578 R.3/4 UNF 16FPP		01
07	0581012711	CLIP DUCT SUPPORT		02
08	0511051299	ROTATING RIGHT AXIS EXTENSOR	12	01
09	0521069034	OIL DUCT 2600 (R.1.1/16 UN 12FPP)		02
10	0521069046	OIL DUCT 2578 R.7/8 UNF 14FPP		02
11	0521069048	FRENCH HAND 3865		01




Item	Code	Description	See page	QT
01	0501012803	FLAT WASHER		02
02	0503010180	7/16" SPRING WASHER		08
03	0503010002	1800 GREASE FITTING		01
04	1902010477	UPPER CLAMP BODY		08
05	0503011135	BOLT		08
06	0511054713	ASSY FRENCH HAND TRANSMISSION SHAFT	11	01
07	0581013502	FRENCH HAND GUTTER 20 X 38 X 2300		01
08	0581012711	CLIP DUCT SUPPORT		02
09	0521069045	OIL DUCT 2578 R.3/4 UNF 16FPP		03
10	0521069046	OIL DUCT 2578 R.7/8 UNF 14FPP		04
11	0521069048	FRENCH HAND 3865		01
12	0501059876	ROTATING LEFT AXIS EXTENSOR	13	01




Item	Code	Description	See page	QT
01	0521062244	PIVOT SHAFT		01
02	0551019529	FLAT WASHER		01
03	0503010027	5/8" SPRING WASHER		01
04	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0521062617	NUT FIXER		01
02	0503010002	1800 GREASE FITTING		02
03	0501078990	TURNBUCLE AXLE		01
04	0561019879	LOCK ATTACHMENT BAR		01




Item	Code	Description	See page	QT
01	0501078991	NUT FIXER		01
02	0503010002	1800 GREASE FITTING		02
03	0501078990	TURNBUCLE AXLE		01
04	0561019879	LOCK ATTACHMENT BAR		01




Item	Code	Description	See page	QT
01	0503015764	BOLT 7/8		01
02	0501010076	FLAT WASHER		01
03	0503010408	7/8" SPRING WASHER		01
04	0503010417	7/8" NUT		01
05	0521061436	LOCK AXLE		01
06	0521063022	AXLE LOWER		02
07	0501017779	32 X 60 X 4.75 FLAT WASHER		03
08	0503011052	1.1/4" X 0.77" CASTLE NUT		03
09	0503010038	3/16 X 2 COTTERPIN		03
10	0503010002	1800 GREASE FITTING		02
11	0501012140	FLAT WASHER		08
12	0503010233	5/8" X 2-1/2" BOLT		04
13	0503010027	5/8" SPRING WASHER		04
14	0503010013	5/8" NUT		04
15	0521051433	FRENCH HAND FRONT AXLE ASSY		02
15A	0511069442	FRENCH HAND FRONT AXLE		01
15B	0501017779	32 X 60 X 4.75 FLAT WASHER		01
15C	0503011052	1.1/4" X 0.77" CASTLE NUT		01
15D	0503010038	3/16 X 2 COTTERPIN		01
15E	0581014420	SLEEVE GUIDE		02
16	0521068340	788 TELESCOPIC HEADER		01
17	0521068337	TUBE		01




Item	Code	Description	See page	QT
01	0521063510	PLOUGH SUPPORT		01
02	0521063509	FRAME BRACKET		01
03	0571012421	FIXER ARM		01
04	0501014063	25 X 55 COUPLING SHAFT		01
05	0521010596	COUPLING SHAFT		03
06	0521010585	0.9" X 5.9" COUPLING SHAFT		01
07	0521010574	C0.9" X 3.3" COUPLING SHAFT		01
08	0503030085	LOCK PIN		06
09	0571013317	INNER TUBE		01




Item	Code	Description	See page	QT
01	0521063662	BOX OF TOOLS		01
02	0551018356	BOX OF TOOLS COVER ASSY		01
03	0521010528	0.3" X 1.6" COUPLING SHAFT		02
04	0503010140	1/8" X 3/4" COTTERPIN		02
05	0503011907	PMC 594-S NYLON LUG		01
06	0503010358	5/16" X 5/8" BOLT		02
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503010337	5/16" NUT		02
09	0511017302	FLAT WASHER		04
10	0503010964	BOLT		02
11	0503010589	1/2" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0503014820	COROTE BLACK WATER		01
02	0571014702	COROTE SUPPORT GLOVE		02




Item	Code	Description	See page	QT
01	0521064543	WHEEL SUPPORT		01
02	0561019929	FLAT WASHER		01
03	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
04	0551014508	FLAT WASHER		01
05	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
06	0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	19	01
07	0503010920	1/2" X 1.1/2" BOLT		04
08	0503010019	1/2" SPRING WASHER		04
09	0503010060	1/2" NUT		04
10	0502012731	WHEEL HOLDER		02
11	0503010002	1800 GREASE FITTING		03
12	0521064550	CARRYING-WHEELS FORK		01
13	0521054068	WHEEL WITH TIRE 12 X 16.5 - 12 CANVAS (RIGHT)	20	01
14	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
15	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	21	01
16	0501010630	1.1/2" CASTLE NUT		01
17	0501017779	32 X 60 X 4.75 FLAT WASHER		02
18	0503011052	1.1/4" X 0.77" CASTLE NUT		02
19	0503010882	BOLT		01
20	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
21	0503010337	5/16" NUT		01
22	0503033335	CURRENT 6 X 21 ELOS		01
23	0581017245	AXLE BODY		01
24	0531012874	FLAT WASHER		02
25	0503012334	3/4" UNC X 3.1/2" BOLT		04
26	0503011075	3/4" UNC NUT		04
27	0503010523	1/4" X 2" COTTERPIN		03
28	0503010571	1/4" X 1.1/2 COTTERPIN		02




Item	Code	Description	See page	QT
01	0521066557	CYLINDER CASE 101,60 X 352		01
02	0581010680	TURNBUCKLE 50,80 X 386		01
03	0571015629	CILINDER SPINDLE FORK		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010345	2-218 N 3006-9B O'RING		01
06	0503011094	3/8" X 2" BOLT		01
07	0503010026	3/8" NUT		01
08	0503010025	3/8" SPRING WASHER		01
09	0503030385	CYLINDER PLUG N-002		02
10	0503015633	SELEMASTER SEALING		01
11	0581010678	50,80 X 101 RING SUPPORT		01
12	0503015636	SCRAPER SEAL		01
13	0503018025	RING GUIDE		01
14	0503018026	1870-2000-375 B GASKET		01
15	0503010338	2-342 N 3006-9B O'RING		02
16	0503011061	8-342 BACK-UP RING		02
17	0502012822	101.60 END CAP		01
18	0502012820	50.80 X 101.60 PISTON		01
19	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0503033713	TIRE 12 X 16,5/12L TR SK 900		01
02	0503015029	WHEEL		01
03	0503015355	INNER TIRE		01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0571015180	WHEEL AXLE		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010059	33287/33462 ROLLER BEARING		01
05	0503010009	RETAINER 00573-B		01
06	0503010086	SEAL 0009B-B		01
07	0551014473	GLOVE		01
08	0503012702	KM-12 NUT		02
09	0503012703	LOCK WASHER		01
10	0503010002	1800 GREASE FITTING		01
11	0503011444	SPRING WASHER		04
12	0503010363	5/16" X 1" BOLT		04
13	0503014048	22 X 1.5 HEX NUT		08
14	0503014050	22 X 1.5 BOLT		08
15	0511068415	PFFP-3770 SEAL GUIDE		01




Item	Code	Description	See page	QT
01	0511059553	SIDE STAND WITH FIXING	23	01
02	0521053174	CENTRAL SEED BOX 15 OUTPUTS WITH LID	24	01
03	0501082104	AIR CONDUCTOR 1.1 / 4 X 1700		02
04	0501082105	AIR CONDUCTOR 1.1 / 4 X 1500		03
05	0501082102	AIR CONDUCTOR 1.1/4 X 1900 CSCP		01
06	0503034345	AIR DISPENSER COVER		08
07	0503010184	CLAMP		15
08	0503011372	102 TO 121 CLAMP		02




Item	Code	Description	See page	QT
01	0581016040	LOWER SUPPORT CASH SEED		04
02	0501011643	3/8 X 1"BOLT		16
03	0501010984	FLAT WASHER		24
04	0503013357	3/8" SELF-ADJUSTING NUT		16
05	0581012237	SEAL BOX FIXER		02
06	0581012245	SEAL BOX SHOULDER		02
07	0503010025	3/8" SPRING WASHER		04
08	0503010026	3/8" NUT		04
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
10	0521067113	SEED BOX SIDE SUPPORT		01
11	0551015037	5/8" UNC X 210 X 198 FASTENER		04
12	0503010027	5/8" SPRING WASHER		08
13	0501012140	FLAT WASHER		08
14	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0521053173	CENTRAL SEED BOX 15 EXITS	25	01
02	0521053176	COVER KAP		01
02A	0581017528	15 OUTPUT TUBE COVER		01
02B	0503011372	102 TO 121 CLAMP		01



Item	Code	Description	See page	QT
01	0521068977	TUBE AR 15 OUTPUTS		01
02	0521053175	BASE CSC BOX 15 OUTPUTS	26	01
03	0501010984	FLAT WASHER		26
04	0503015075	M10 SPRING WASHER		26
05	0503010025	3/8" SPRING WASHER		08
06	0503010172	M10 X 1,5 X 25 BOLT		26
07	0503062687	BOX SEED		01
08	0503019284	M8 X BOLT		04
09	0503010849	3/8" X 1-1/2" BOLT		08
10	0581017922	WASHER		04




Item	Code	Description	See page	QT
01	0521068978	CASH FUND COVER		03
02	0503015135	FLAT WASHER 10 X 18 X 2		06
03	0503011823	0.1" X 0.6" SPRING PIN		06
04	0521068851	SYSTEM ASSY		01
05	0503034571	SEALING		01
06	0503034573	SEALING		03
07	0581017529	VARAO 9.53		03
08	0503062759	SEALING		03
09	0503034692	FAST LOCK ASSY		06
10	0503030085	LOCK PIN		06
11	0503019290	BOLT		24




Item	Code	Description	See page	QT
01	0581016057	PLATFORM 2220		01
02	0511059822	ASSY SIDE PLATFORM SUPPORT	28	01
03	0521052175	SUPPORT PLATFORM ASSY	29	02

ASSY SIDE PLATFORM SUPPORT


0511059822




Item	Code	Description	See page	QT
01	0521067275	SIDE FRAME PLATFORM SUPPORT		01
02	0551015037	5/8" UNC X 210 X 198 FASTENER		02
03	0501012140	FLAT WASHER		04
04	0503010027	5/8" SPRING WASHER		04
05	0503010013	5/8" NUT		04
06	0511017302	FLAT WASHER		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2" NUT		01
09	0503010920	1/2" X 1.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0581016058	PLATFORM SUPPORT		01
02	0511017302	FLAT WASHER		01
03	0503010060	1/2" NUT		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010920	1/2" X 1.1/2" BOLT		01
06	0503010395	1/2" X 1-1/4" BOLT		05
07	0503010589	1/2" UNC SELF ADJUSTING NUT		05




Item	Code	Description	See page	QT
01	0521052136	FRONT SIDE HANDRAIL 2235	31	01
02	0521052139	FRONT SIDE HANDRAIL 565	32	01
03	0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	35	01




Item	Code	Description	See page	QT
01	0581015996	TUBE 33,7 X 27 X 1131		01
02	0511059383	INTERNAL FIXER ASSY HANDLE	33	10
03	0581015995	TUBE 33,7 X 27 X 925		01
04	0581012718	HANDRAIL		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0581014429	SHIM HANDRAIL		01
07	0521068338	FIXING HANDRAIL RIGHT		01
08	0581012708	HANDRAIL REAR SIDE BODY		02
09	0581015992	TUBE 33,70 X 27 X 354		04
10	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	34	02
11	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0581012724	SIDE HANDRAIL REINFORCEMENT (486)		03
02	0511059383	INTERNAL FIXER ASSY HANDLE	33	06
03	0581012718	HANDRAIL		02
04	0581014429	SHIM HANDRAIL		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0581015996	TUBE 33,7 X 27 X 1131		02
07	0503013357	3/8" SELF-ADJUSTING NUT		02



Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01




Item	Code	Description	See page	QT
01	0502012855	CENTRAL FIXER		01
02	0502012856	CENTRAL FIXER		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		02
04	0503015490	SELF-LOCKING NUT 7/16		02




Item	Code	Description	See page	QT
01	0581012698	FRONT SIDE HANDRAIL FIXER		01
02	0503010237	3/8" X 1" BOLT		02
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503011179	3/8" X 2-1/4" BOLT		02

ASSY SIDE LADDER


0511053320




Item	Code	Description	See page	QT
01	0511069819	SIDE LADDER		01
02	0502012742	FIXER SUPPORT LADDER		02
03	0503013357	3/8" SELF-ADJUSTING NUT		02
04	0501010984	FLAT WASHER		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0503010237	3/8" X 1" BOLT		04
07	0503010025	3/8" SPRING WASHER		04
08	0503010026	3/8" NUT		04



Item	Code	Description	See page	QT
01	0521052170	RIGHT CENTRAL AIR CONDUCTOR	38	01
02	0521053183	SIDE AIR CONDUCTOR 5 INPUT 2334	39	01
03	0511057646	ASSY AIR CONDUCTOR SUPPORT	40	03
04	0581016488	AIR CONDUCTOR		07
05	0521052549	CLAMP	41	07
06	0521052168	SEED HOSE GUIDE	42	01




Item	Code	Description	See page	QT
01	0581012427	AIR DISTRIBUTOR NOZZLE		01
02	0511057036	AIR DISTRIBUTOR BOARD		01
02A	0503012567	T-JOIN FOR TUBE 110		01
02B	0581013890	SOCKET DISTRIBUTOR AR		01
03	0581016056	CENTRAL AIR DISTRIBUTOR BODY 315		02
04	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
04A	0503034763	AIR DITRIBUTOR PUMP		01
04B	0503015341	RIVET POP		02
05	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		02
05A	0503034812	SOCKET DISTRIBUTOR AR		01
05B	0503012856	REBITE POP		04



Item	Code	Description	See page	QT
01	0581017531	DISTRIBUTOR BODY 05 ENTRIES 2280		01
02	0581012427	AIR DISTRIBUTOR NOZZLE		01
03	0503012566	COVER KAP 110 YELLOW		01
04	0503031943	SOCKET		05
05	0503012856	REBITE POP		10
06	0571019716	ADAPTER		05

ASSY AIR CONDUCTOR SUPPORT


0511057646




Item	Code	Description	See page	QT
01	0521066281	AIR CONDUCTOR SUPPORT		01
02	0511017302	FLAT WASHER		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521018402	AIR CONDUCTOR CLAMP		01
06	0503010371	5/16" X 1" BOLT		02
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503010337	5/16" NUT		02
09	0571019615	FITTING 1/2 UNC 130 X 198 ZN		01

CLAMP


0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0521068360	SEED HOSE GUIDE		01
02	0521018402	AIR CONDUCTOR CLAMP		01
03	0503010371	5/16" X 1" BOLT		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0581017952	GUTTER 30 X 55 X 1660		01
02	0581017953	GUTTER 30 X 55 X 1650		01
03	0511057011	SUPPORT GUTTER ASSY	44	04




Item	Code	Description	See page	QT
01	0571013956	CENTRAL TRACK SUPPORT		01
02	0503010025	3/8" SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0503013029	3/8" X 3/4" BOLT		01
05	0501011643	3/8 X 1"BOLT		01




Item	Code	Description	See page	QT
01	0521069266	OIL DUCT 3 OUTLETS R/34 X 2340		02
02	0511059943	SUPPORT FASTENER ASSY	46	01
03	0581018407	BODY FASTENER 2 DUCTS		04
04	0511059928	SIDE DUTY SUPPORT	47	01
05	0503011268	3/8" X 2-1/2" BOLT		02
06	0503010025	3/8" SPRING WASHER		02
07	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0581011417	DUTO HOLDER SUPPORT		01
02	0503010237	3/8" X 1" BOLT		02
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0581013094	DUTO HOLDER SUPPORT		01
02	0571019756	FASTENER 1/2 UNC X 220 X 198 ZN		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0581013095	TURBIN SUPPORT		01
02	0503010190	2-114 N 3006-9B O'RING		04
03	0503010392	2-046 N 3006 9B O'RING		01
04	0501011460	7/8 NF REDUCTION NIPPLE		04
05	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
06	0501080788	1/2" X 570 HOSE ASSY		01
07	0521050154	TURBINE P.P WITH HOLE	49	01
08	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
09	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
10	0503010143	1/4" SPRING WASHER		02
11	0503010144	1/4" NUT		02
12	0503010305	FLAT WASHER		02
13	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
14	0503031087	ADHESIVE LABEL		01
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0502012768	LINE SUPPORT CLAMP		02
17	0501017334	5/8"X 5/8" X 10.24" STUD		04
18	0503010013	5/8" NUT		08
19	0501012140	FLAT WASHER		04
20	0503010027	5/8" SPRING WASHER		04




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01




Item	Code	Description	See page	QT
01	0571019137	SWITCH FIXER		01
02	0503013584	VACUUM GAUGE		01
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0581014411	BREATHE		01




Item	Code	Description	See page	QT
01	0521053691	LONG/LEFT LINE VDRIVE	52	01
02	0521053690	SHORT/RIGHT LINE VDRIVE	53	01
03	0521053705	LONG/LEFT LINE (INTERNAL) VDRIVE	54	01
04	0521053704	SHORT/RIGHT LINE (INTERNAL) VDRIVE	55	01
05	0521052142	DISC CUT DPL 20 ASSY	67	01
06	0521053482	ASSY PP MINI HOPPER VDRIVE CSC	71	01
07	0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	73	01
08	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
09	0531013600	PRESS ADJUSTMENT LEVER		01
10	0503062403	TUBE SEED P.P		01
11	0503010184	CLAMP		01
12	0503010905	1/2" X 2-1/4" BOLT		01
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521053180	FRONT LONG SEED LINE VDRIVE/MINI HOPPER	56	01
02	0521053345	LEFT REAR PRECISION PLANTING	61	01




Item	Code	Description	See page	QT
01	0521053179	FRONT SHORT SEED LINE VDRIVE/MINI HOPPER	57	01
02	0521053343	REAR RIGHT PRECISION PLANTING	62	01



Item	Code	Description	See page	QT
01	0521053178	INTERNAL FRONT LONG SEED LINE VDRIVE/MINI HOPPER	58	01
02	0521053345	LEFT REAR PRECISION PLANTING	61	01




Item	Code	Description	See page	QT
01	0521053177	INTERNAL FRONT SHORT SEED LINE VDRIVE/MINI HOPPER	59	01
02	0521053343	REAR RIGHT PRECISION PLANTING	62	01



Item	Code	Description	See page	QT
01	0581014932	SLEEVE ARM LINE SEED		08
02	0521066168	FRAME SEED LINE		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
05	0511052300	CONDUCTOR SUPPORT ASSY SEED	60	01
06	0561014215	BEARING COVER LOWER ROW FRAME		01
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503011952	5/16" X 3/4" BOLT		02
09	0503010337	5/16" NUT		02
10	0571012310	ROW LOCK BODY		01
11	0551015826	SEED ROW LOCK GUIDE SLEEV		01
12	0503010232	5/8" X 1.3/4" BOLT		01
13	0503010027	5/8" SPRING WASHER		01
14	0503010013	5/8" NUT		01
15	0503030168	HAIR PIN		04
16	0501012140	FLAT WASHER		01
17	0503010019	1/2" SPRING WASHER		01
18	0503010060	1/2" NUT		01
19	0571012014	TRANSPORT LOCK		01
20	0503010479	BOLT		01
21	1902012568	UPPER ROCKER ARM		01
22	0503033728	FIXED SPRING PIN		02
23	0571014704	UPPER AXLE		01
24	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
25	0503010003	1845 GREASE FITTING		04
26	0502012768	LINE SUPPORT CLAMP		02
27	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
28	0521068452	UP SUPPORT		01
29	0581014926	UPPER ARM BIGGER		01
30	0581014927	LOWER BOTTOM ARM (123,7)		01
31	0581016350	SUPPORT UNIT MODULE		01




Item	Code	Description	See page	QT
32	0581015903	SPACER WASHER		01
33	0503011953	5/16" X 1" BOLT		01
34	0503013759	NUT		01
35	0503010878	5/8" SELF ALIGNING NUT		04
36	0521068188	HOSE GUIDE		01
37	0503010025	3/8" SPRING WASHER		01
38	0503010026	3/8" NUT		01
39	0501011643	3/8 X 1"BOLT		01



Item	Code	Description	See page	QT
01	0581014932	SLEEVE ARM LINE SEED		08
02	0521066168	FRAME SEED LINE		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
05	0511052300	CONDUCTOR SUPPORT ASSY SEED	60	01
06	0561014215	BEARING COVER LOWER ROW FRAME		01
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503011952	5/16" X 3/4" BOLT		02
09	0503010337	5/16" NUT		02
10	0571012310	ROW LOCK BODY		01
11	0551015826	SEED ROW LOCK GUIDE SLEEV		01
12	0503010232	5/8" X 1.3/4" BOLT		01
13	0503010027	5/8" SPRING WASHER		01
14	0503010013	5/8" NUT		01
15	0503030168	HAIR PIN		04
16	0501012140	FLAT WASHER		01
17	0503010019	1/2" SPRING WASHER		01
18	0503010060	1/2" NUT		01
19	0571012014	TRANSPORT LOCK		01
20	0503010479	BOLT		01
21	1902012568	UPPER ROCKER ARM		01
22	0503033728	FIXED SPRING PIN		02
23	0571014704	UPPER AXLE		01
24	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
25	0503010003	1845 GREASE FITTING		04
26	0502012768	LINE SUPPORT CLAMP		02
27	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
28	0521068448	FRONT SUPPORT SHORT SEED LINE		01
29	0581014929	SMALL UPPER ARM		01
30	0581014930	LOWER BOW ARM		01
31	0581016350	SUPPORT UNIT MODULE		01



Item	Code	Description	See page	QT
32	0581015903	SPACER WASHER		01
33	0503011953	5/16" X 1" BOLT		01
34	0503013759	NUT		01
35	0503010878	5/8" SELF ALIGNING NUT		04
36	0521068188	HOSE GUIDE		01
37	0503010025	3/8" SPRING WASHER		01
38	0503010026	3/8" NUT		01
39	0501011643	3/8 X 1"BOLT		01




Item	Code	Description	See page	QT
01	0581014932	SLEEVE ARM LINE SEED		08
02	0521066168	FRAME SEED LINE		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
05	0511052300	CONDUCTOR SUPPORT ASSY SEED	60	01
06	0561014215	BEARING COVER LOWER ROW FRAME		01
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503011952	5/16" X 3/4" BOLT		02
09	0503010337	5/16" NUT		02
10	0571012310	ROW LOCK BODY		01
11	0551015826	SEED ROW LOCK GUIDE SLEEV		01
12	0503010232	5/8" X 1.3/4" BOLT		01
13	0503010027	5/8" SPRING WASHER		01
14	0503010013	5/8" NUT		01
15	0503030168	HAIR PIN		04
16	0501012140	FLAT WASHER		01
17	0503010019	1/2" SPRING WASHER		01
18	0503010060	1/2" NUT		01
19	0571012014	TRANSPORT LOCK		01
20	0503010479	BOLT		01
21	1902012568	UPPER ROCKER ARM		01
22	0503033728	FIXED SPRING PIN		02
23	0571014704	UPPER AXLE		01
24	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
25	0503010003	1845 GREASE FITTING		04
26	0502012768	LINE SUPPORT CLAMP		02
27	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
28	0521068453	LONG FRONT SEED ROW		01
29	0581014926	UPPER ARM BIGGER		01
30	0581014927	LOWER BOTTOM ARM (123,7)		01
31	0581016350	SUPPORT UNIT MODULE		01



**USAP SUPREMA P.P MINI HOPPER - 24 LINES/SPACING 500 -
INTERNAL FRONT LONG SEED LINE VDRIVE/MINI HOPPER**

Page 58
0521053178

Item	Code	Description	See page	QT
32	0581015903	SPACER WASHER		01
33	0503011953	5/16" X 1" BOLT		01
34	0503013759	NUT		01
35	0503010878	5/8" SELF ALIGNING NUT		04
36	0521068188	HOSE GUIDE		01
37	0503010025	3/8" SPRING WASHER		01
38	0503010026	3/8" NUT		01
39	0501011643	3/8 X 1"BOLT		01




Item	Code	Description	See page	QT
01	0581014932	SLEEVE ARM LINE SEED		08
02	0521066168	FRAME SEED LINE		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
05	0511052300	CONDUCTOR SUPPORT ASSY SEED	60	01
06	0561014215	BEARING COVER LOWER ROW FRAME		01
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503011952	5/16" X 3/4" BOLT		02
09	0503010337	5/16" NUT		02
10	0571012310	ROW LOCK BODY		01
11	0551015826	SEED ROW LOCK GUIDE SLEEV		01
12	0503010232	5/8" X 1.3/4" BOLT		01
13	0503010027	5/8" SPRING WASHER		01
14	0503010013	5/8" NUT		01
15	0503030168	HAIR PIN		04
16	0501012140	FLAT WASHER		01
17	0503010019	1/2" SPRING WASHER		01
18	0503010060	1/2" NUT		01
19	0571012014	TRANSPORT LOCK		01
20	0503010479	BOLT		01
21	1902012568	UPPER ROCKER ARM		01
22	0503033728	FIXED SPRING PIN		02
23	0571014704	UPPER AXLE		01
24	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
25	0503010003	1845 GREASE FITTING		04
26	0502012768	LINE SUPPORT CLAMP		02
27	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
28	0521068449	SHORT SEED ROW FRONT		01
29	0581014929	SMALL UPPER ARM		01
30	0581014930	LOWER BOW ARM		01
31	0581016350	SUPPORT UNIT MODULE		01




**USAP SUPREMA P.P MINI HOPPER - 24 LINES/SPACING 500 -
INTERNAL FRONT SHORT SEED LINE VDRIVE/MINI HOPPER**

Page 59
0521053177


Item	Code	Description	See page	QT
32	0581015903	SPACER WASHER		01
33	0503011953	5/16" X 1" BOLT		01
34	0503013759	NUT		01
35	0503010878	5/8" SELF ALIGNING NUT		04
36	0521068188	HOSE GUIDE		01
37	0503010025	3/8" SPRING WASHER		01
38	0503010026	3/8" NUT		01
39	0501011643	3/8 X 1"BOLT		01




Item	Code	Description	See page	QT
01	0521063444	CONDUCTOR SUPPORT SEED		01
02	0501011643	3/8 X 1"BOLT		02
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0521053356	DOUBLE DISC LEFT HIGH CUBE	63	01
02	0521065999	FRONT SHIELD		01
03	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		03
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03




Item	Code	Description	See page	QT
01	0521053344	DOUBLE DISC RIGHT HIGH CUBE	64	01
02	0521065999	FRONT SHIELD		01
03	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		03
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2" NUT		03




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	BOX DDD ASSY DPL 15 RIGHT	65	01
04	0501054168	BOX DDD ASSY DPL 15 LEFT	66	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	COVER DEPTH		02
07	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
08	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0502012781	SUPPORT DDD LEFT		01
10	0503014729	1/4" UNF X 1/2" BOLT		04
11	0503010143	1/4" SPRING WASHER		04
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	BOX DDD ASSY DPL 15 RIGHT	65	01
04	0501054168	BOX DDD ASSY DPL 15 LEFT	66	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	COVER DEPTH		02
07	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
08	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0502012780	SUPPORT DDD RIGHT		01
10	0503014729	1/4" UNF X 1/2" BOLT		04
11	0503010143	1/4" SPRING WASHER		04
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
17	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502011930	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT DOUB DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011930	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012470	UPPER SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
03	0521052141	ASSY LOWER SUPPORT DPL 20	68	01
04	0503012798	5/8" X 2" BOLT		04
05	0503010878	5/8" SELF ALIGNING NUT		04




Item	Code	Description	See page	QT
01	0503031575	2.5"X 12" X 0.5" COMPRESSION SPRING		02
02	0551015883	SPRING GUIDES SLEVE		02
03	0503010002	1800 GREASE FITTING		02
04	0561014164	SUPPORT DISC AXLE		01
05	0571012370	PROTECTION FRONT		01
06	0502012713	BOTTOM BRACKET		01
07	0571012371	SLEEVE 20 X 34,93 X 130		01
08	0503010361	SPRING PIN		01
09	0521068323	LEFT ARM		01
10	0521068322	RIGHT ARM		01
11	0511058648	BOX WITH DISC BLADE 20"	69	01
12	0521068189	SPRING REGULACION		02
13	0501012140	FLAT WASHER		02
14	0503010179	5/16" ZN SPRING WASHER		02
15	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
16	0503010152	3/4" SELF LOCKING NUT		01
17	0503010806	5/8" X 3" BOLT		02
18	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT		01
19	0503011075	3/4" UNC NUT		02
20	0503010878	5/8" SELF ALIGNING NUT		02




Item	Code	Description	See page	QT
01	0511056909	DISC BOX CUT WITHOUT THE DISC	70	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0502012793	DC PST		01
02	0571018047	CUTTING DISC BOX SHAFT		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DOOR DUST		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0571017895	PIN FIXER CONDUCTOR P.P	01	
02	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING	01	
03	0503010293	BAQUELITE MANIPULACION	01	
04	0503010140	1/8" X 3/4" COTTERPIN	02	
05	0503010025	3/8" SPRING WASHER	04	
06	0571014024	FAST BOLT GUIDE AXLE	01	
07	0503034824	FIXATIVE	01	
08	0503015920	3/8" UNC X 1.3/4" BOLT	04	
09	0503010026	3/8" NUT	04	
10	0502012800	SUPPORT ARTICULATION PNEUMATIC	01	
11	0503810009	BOLT	02	
12	0571018649	SUPPORT FIXER	02	
13	0501110894	FIXER	01	
14	0503062406	SEED BOX	01	
15	0503034204	SEALING	01	
16	0503019869	CLAMP	01	
17	0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT 72 PROTECTION	01	
18	0581017816	TERMINAL	01	
19	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN	01	
20	0503010589	1/2" UNC SELF ADJUSTING NUT	01	
21	0502012909	BASE SUPPORT PRECISION PLANTING	01	
22	0501210173	FIXATION RING	01	



Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0581014858	DEPTH WHEEL AXLE		01
04	0501110720	ARM LEFT		01
05	0501110719	DEPTH CONTROL RIGHT ARM		01
06	0502012663	EXTENSION		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	74	01
09	0503034793	ARTICULATION SLEEVE		02
10	0521051423	COMPACTOR SUPPORT	75	01
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503016453	1/2" X 2.1/2 BOLT		02
14	0503034817	SPRING		01
15	0503010581	RING		01
16	0503034377	SCREEW 3/8 UNC X 3/4		01
17	0503010019	1/2" SPRING WASHER		08
18	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
19	0503010060	1/2" NUT		04
20	0501052908	COMPACTOR WHEEL WITH BEARING	76	02
21	0503013739	1/2" X 1" BOLT		01
22	0511050077	WHEEL STRIPED	77	02
23	0503010752	1/2" X 3.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	SEED SIST CONTROL DEPTH LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01

COMPACTOR SUPPORT


0521051423




Item	Code	Description	See page	QT
01	0521068003	RIGHT SIDE		01
02	0521068002	LEFT SIDE		01
03	0581014847	PLATE UPPER		01
04	0581015855	SLEEVE		02
05	0521068004	HANDLE BODY		01
06	0581014969	SLEEVE GUIDE		01
07	0581014968	SLEEVE FLANGE		01
08	0503010937	5/16" X 3" BOLT		02
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0521068005	LEVER		01
11	0503010179	5/16" ZN SPRING WASHER		04
12	0503010337	5/16" NUT		04
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2" NUT		01
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010882	BOLT		02
17	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
18	0503030878	LEVER CRANK		01
19	0581015854	RIGHT PROTECTION COVER		01
20	0581015853	LEFT PROTECTION COVER		01
21	0581015903	SPACER WASHER		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03



Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	78	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	NUT		06
06	0503010179	5/16" ZN SPRING WASHER		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEELS BOX		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	COVER DEPTH		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0521068022	CENTRAL CHASSIS		01
02	0521050019	TIGHTENING PLATE WITH FIXING INTERNAL		02
03	0503010131	3/16" X 1-1/2" COTTERPIN		01
04	0521011132	FLAT WASHER		01
05	0521052189	38,10X63,50X386X148 HYDRAULIC CYLINDER		01
06	0503010002	1800 GREASE FITTING		01

CENTRAL WHEEL WITHOUT TRANSMISSION


0521043436



Item	Code	Description	See page	QT
01	0521064554	LEFT WHEEL FORK		01
02	0521064543	WHEEL SUPPORT		01
03	0521064558	CARRYING-WHEELS PIVOT SHAFT		01
04	0561019929	FLAT WASHER		01
05	0503011345	1/4" X 3-1/2" COTTERPIN		01
06	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
07	0551014508	FLAT WASHER		01
08	0503010010	1/4" X 2.1/2" COTTERPIN		04
09	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
10	0503010920	1/2" X 1.1/2" BOLT		04
11	0503010019	1/2" SPRING WASHER		04
12	0503010060	1/2" NUT		04
13	0502012731	WHEEL HOLDER		02
14	0503010337	5/16" NUT		01
15	0581017245	AXLE BODY		01
16	0531012874	FLAT WASHER		02
17	0511054495	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION	21	01
18	0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE	81	01
19	0503011052	1.1/4" X 0.77" CASTLE NUT		02
20	0501017779	32 X 60 X 4.75 FLAT WASHER		02
21	0511058240	HYDRAULIC CYLINDER 50,80 X 101,60 X 483 X 276	19	01
22	0501010630	1.1/2" CASTLE NUT		01
23	0503010003	1845 GREASE FITTING		03
24	0503010882	BOLT		01
25	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
26	0503033458	CURRENT 6 X 17 ELOS		01
27	0503012334	3/4" UNC X 3.1/2" BOLT		04
28	0503011075	3/4" UNC NUT		04




Item	Code	Description	See page	QT
01	0511065331	11.75 X 17.5 HOOP WHEEL		01
02	0503015355	INNER TIRE		01
03	0503013247	PLY TIRE		01



Item	Code	Description	See page	QT
01	0521053173	CENTRAL SEED BOX 15 EXITS	25	01
02	0521052156	ASSY CENTRAL SUPPORT	83	01
03	1164920015	BLACK SUCTION HOSE		20mts
04	0503034345	AIR DISPENSER COVER		05
05	0503010184	CLAMP		15

ASSY CENTRAL SUPPORT


0521052156




Item	Code	Description	See page	QT
01	0521068348	CENTRAL SUPPORT SEED BOX		01
02	0581016040	LOWER SUPPORT CASH SEED		04
03	0501011643	3/8 X 1"BOLT		16
04	0503013357	3/8" SELF-ADJUSTING NUT		16
05	0501010984	FLAT WASHER		24
06	0581012237	SEAL BOX FIXER		02
07	0581012245	SEAL BOX SHOULDER		02
08	0503010025	3/8" SPRING WASHER		04
09	0503010026	3/8" NUT		04
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
11	0511017302	FLAT WASHER		06
12	0503010589	1/2" UNC SELF ADJUSTING NUT		06
13	0503010920	1/2" X 1.1/2" BOLT		06

ASSY LADDER


0521052351



Item	Code	Description	See page	QT
01	0521068345	REAR PLATFORM BASE		01
02	0521052154	ASSY REAR LADDER PLATFORM	85	02
03	0503010019	1/2" SPRING WASHER		08
04	0503010060	1/2" NUT		08
05	0503014734	BOLT		08
06	0521052140	HANDRAIL SIDE FRAME CENTRAL	86	02
07	0521052138	LADDER REAR	87	01




Item	Code	Description	See page	QT
01	0521068347	PLATFORM 430 X 980		01
02	0501010984	FLAT WASHER		08
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04



Item	Code	Description	See page	QT
01	0581012750	SIDE HANDRAIL BODY (1085)		02
02	0511059383	INTERNAL FIXER ASSY HANDLE	33	06
03	0581016002	REAR HANDRAIL REINFORCEMENT 468		03
04	0581012718	HANDRAIL		02
05	0581014429	SHIM HANDRAIL		03
06	0503011179	3/8" X 2-1/4" BOLT		04
07	0503010025	3/8" SPRING WASHER		04
08	0503013357	3/8" SELF-ADJUSTING NUT		04

LADDER REAR


0521052138




Item	Code	Description	See page	QT
01	0581015998	CSCP REAR SIDE STAIR		02
02	0521064790	DEGRAU 600 USAP CXC		04
03	0503010025	3/8" SPRING WASHER		16
04	0503010026	3/8" NUT		16
05	0503010237	3/8" X 1" BOLT		16
06	0511052457	REAR SIDE HANDRAIL LADDER	88	01
07	0511052499	HANDRAIL LADDER BACK RIGHT CENTRAL FRAME	89	01
08	0503010395	1/2" X 1-1/4" BOLT		04
09	0503010589	1/2" UNC SELF ADJUSTING NUT		04

REAR SIDE HANDRAIL LADDER


0511052457




Item	Code	Description	See page	QT
01	0581012741	SIDE HANDRAIL BODY (1113) CSCP		01
02	0511059383	INTERNAL FIXER ASSY HANDLE	33	06
03	0581012748	BODY LARGER LADDER REAR		02
04	0581012742	SIDE HANDRAIL BODY		01
05	0581012744	REINFORCEMENT REAR SIDE HANDRAIL		01
06	0581012718	HANDRAIL		02
07	0581014429	SHIM HANDRAIL		02
08	0503011179	3/8" X 2-1/4" BOLT		04
09	0503013357	3/8" SELF-ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0581012741	SIDE HANDRAIL BODY (1113) CSCP		01
02	0511059383	INTERNAL FIXER ASSY HANDLE	33	06
03	0581012748	BODY LARGER LADDER REAR		02
04	0581012742	SIDE HANDRAIL BODY		01
05	0581012744	REINFORCEMENT REAR SIDE HANDRAIL		01
06	0581012718	HANDRAIL		02
07	0581014429	SHIM HANDRAIL		02
08	0503010025	3/8" SPRING WASHER		04
09	0503010026	3/8" NUT		04
10	0503011179	3/8" X 2-1/4" BOLT		04




Item	Code	Description	See page	QT
01	0521068342	ARM PIVOT		01
02	0571017893	HORIZONTAL ARTICULATION SHAFT		01
03	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
04	0571011767	LISA WASHER 125 X 88 X 4.76		01
05	0503010002	1800 GREASE FITTING		01
06	0503010408	7/8" SPRING WASHER		01
07	0503015322	BOLT 7/8		01
08	0503032042	SHEET POLYETHYLENE		01
09	0503010814	5/16 BOLT		14
10	0503011198	C3/4" X 6" SCREW		01
11	0571011825	BUSHING		02
12	0503010004	1890 GREASE FITTING		01
13	0503011255	3/4" LOCK NUT		01




Item	Code	Description	See page	QT
01	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
02	0571011767	LISA WASHER 125 X 88 X 4.76		01
03	0503010408	7/8" SPRING WASHER		01
04	0503015322	BOLT 7/8		01
05	0571017893	HORIZONTAL ARTICULATION SHAFT		01
06	0503011198	C3/4" X 6" SCREW		01
07	0503011255	3/4" LOCK NUT		01
08	0503010004	1890 GREASE FITTING		01
09	0503032042	SHEET POLYETHYLENE		01
10	0503010814	5/16 BOLT		14
11	0503010002	1800 GREASE FITTING		01
12	0521068343	ARM PIVOT		01
13	0571011825	BUSHING		02



Item	Code	Description	See page	QT
01	0511058241	HYDRAULIC CYLINDER 50,80 X 114,30 X 964 X 638	93	02
02	0521017351	1-1/4" X 8" BOLT		02
03	0503013321	SCREW 1.1/4 UNF X 7 C S G.8 ZN		02
04	0503010817	1.1/4" SELF LOCKING NUT		04




Item	Code	Description	See page	QT
01	0521066625	SHIRT 114.30 X 851		01
02	0521066559	EXTENSOR 876 X 50.80 (2)		01
03	0503010002	1800 GREASE FITTING		03
04	0503030385	CYLINDER PLUG N-002		02
05	0581010658	EMBOLO 50,80 X 114,30 USAP		01
06	0503018164	GAXETA 2500-4000-375 B (1150 AGEL)		02
07	0503018165	GUIDE RING W2-4500-590		01
08	0503010290	SELF ADJUSTING 1.1/2" UNF NUT		01
09	0503010141	2-226 N 3006-9B O'RING		01
10	0502011222	0.56" END CAP		01
11	0503010952	W2-2250-500 RING		01
12	0581010659	2" X 4" RING SUPPORT		01
13	0503010039	D-2000 SCRAPER RING		01
14	0503018026	1870-2000-375 B GASKET		01
15	0503018024	RING BS		01
16	0503011892	O' RING, 2-346 N 3006-9B		02
17	0503011893	BACK-UP RING, 8-346		02



Item	Code	Description	See page	QT
01	0521053702	CENTRAL DUCT ASSEMBLY	95	01
02	0521053098	ASSY BLFP2604 BLOCK	97	01
03	0521052155	SEQUENTIAL VALVE ASSY	98	01
04	0521052377	HOSE ARTICULATION KIT	99	01
05	0521052376	HEADER HOSE ASSY	100	01
06	0521052378	LIFTING HOSE GAME	101	01
07	0521052379	HOSE KIT TURBINE	102	01
08	0521052153	ASSY HOSE GUIDE	103	02
09	0521052134	SUPPORT BLOCK COMMAND	104	01

CENTRAL DUCT ASSEMBLY


0521053702




Item	Code	Description	See page	QT
01	0521063890	OIL DUCT (1250)		06
02	0521068998	OIL DUCT 1.1/16 X 1274		02
03	0581010230	LOWER BODY CENTRAL DUCT FASTENER		08
04	0521069009	OIL DUCT		01
05	0511069523	1360 OIL TUBE		02
06	0521053537	CENTRAL REAR DUCT SUPPORT	96	04
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		08
08	0503011268	3/8" X 2-1/2" BOLT		08
09	0503010025	3/8" SPRING WASHER		16
10	0503010026	3/8" NUT		16
11	0591010127	SUPPORT LEFT DISTRIBUTOR		02
12	0581014867	SIDE DUTY SUPPORT		02

CENTRAL REAR DUCT SUPPORT


0521053537




Item	Code	Description	See page	QT
01	0571019615	FITTING 1/2 UNC 130 X 198 ZN		01
02	0511017302	FLAT WASHER		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0503010025	3/8" SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581017885	SUPPORT BODY		01
08	0503011141	3/8" X 2-3/4" BOLT		01
09	0581018407	BODY FASTENER 2 DUCTS		01




Item	Code	Description	See page	QT
01	0503062728	BLOCK COMMAND		01
02	0503010190	2-114 N 3006-9B O'RING		11
03	0501010617	3/4" NIPPLE		11
04	0503015075	M10 SPRING WASHER		03
05	0503010172	M10 X 1,5 X 25 BOLT		03
06	0503011109	2-119 N 3006-9B O'RING		03
07	0501010589	R. 1.1/16UN SEXT 1.1/4 X 52 NIPPLE		03




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501012109	3/4" X 9/16" NIPPLE		04
03	0501010617	3/4" NIPPLE		02
04	0503010190	2-114 N 3006-9B O'RING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02
07	0501010984	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		02
09	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0501080449	3/8" X 1500 TC-TC HOSE		01
02	0501080301	HOSE 3/8 X 1300 TC-TC		01
03	0501080065	3/8 X 1200 TC-TC HOSE ASSY		01
04	0501081108	TC-TC HOSE ASSY		01
05	0501080359	3/8" X 78.7" TR-TC HOSE ASSY		01
06	0501080968	3/8 X 1800 TC-TC HOSE		01



Item	Code	Description	See page	QT
001	0501080714	HOSE 3/8 X 1600 TR-TC		02
002	0501080297	3/8" X 2800 TR-TR HOSE		02
003	0501080526	3/8" X 114" TR-TC HOSE ASSY		01
004	0501080408	HOSE 3/8 X 3200 TR-TC		01



Item	Code	Description	See page	QT
01	0521053712	HOSE 3/4 X 5900 TR-TM BLACK / RED		01
01A	0501082205	HOSE 1/2 X 5900 TR-TM		01
01B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01D	0503018952	PLASTIC BOLT		06
02	0521053707	HOSE 3/4 X 5900 TR-TM BLACK / BLUE		01
02A	0501082205	HOSE 1/2 X 5900 TR-TM		01
02B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
02C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
02D	0503018952	PLASTIC BOLT		06
03	0501082204	3/4 X 2750 TR-TR HOSE		02
04	0501080105	TR-TR HOSE ASSY		04
05	0501081837	HOSE 3/8 X 700 TR-TC		04
06	0501082005	3/8 X 750 TC-TC 90G HOSE		01
07	0501080930	3/8" X 35" TC-TC HOSE ASSY		01
08	0501081838	HOSE		01
09	0501080402	HOSE 3/8 X 1700 TR-TC		01
10	0501080202	HOSE 1/2 X 1250 TR-TR		02
11	0501080485	3/8" X 1100 TR-TC HOSE		04
12	0501080675	HOSE 3/8 X 1000 TC-TC 180G		02
13	0501081254	3/8" X 900 TR-TC HOSE		04
14	0501082203	3/4 X 950 TR-TC HOSE		01
15	0501080700	3/8 X 650 TC-TC HOSE		04
16	0501080461	TR-TC HOSE ASSY		01




Item	Code	Description	See page	QT
01	0521053716	3/4 X 3200 TR-TM HOSE YELLOW / RED		01
01A	0501082206	HOSE 3/8 X 3200 TR-TM		01
01B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01D	0503018952	PLASTIC BOLT		06
02	0521053714	3/4 X 3200 TR-TM HOSE YELLOW / BLUE		01
02A	0501082206	HOSE 3/8 X 3200 TR-TM		01
02B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
02C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
02D	0503018952	PLASTIC BOLT		06
03	0521052564	HOSE 1/2 X 5900 TR-TM YELLOW / BLUE		01
03A	0501081841	HOSE 1/2 X 5900 TR-TM		01
03B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
03C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
03D	0503018952	PLASTIC BOLT		06
04	0521052565	1/2 X 5900 TR-TM HOSE YELLOW / RED		01
04A	0501081841	HOSE 1/2 X 5900 TR-TM		01
04B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
04C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
04D	0503018952	PLASTIC BOLT		06
05	0521053713	3/8 X 3200 TR-TM HOSE YELLOW / GREEN		01
05A	0501080441	HOSE ASSY		01
05B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
05C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
05D	0503018952	PLASTIC BOLT		06
06	0501080400	HOSE ASSY		02
07	0501081326	HOSE		04
08	0501080359	3/8" X 78.7" TR-TC HOSE ASSY		01
09	0501080618	1/2" X 2200 TR-TC HOSE		02
10	0501080346	1/2" X 2000 TR-TR HOSE ASSY		02
11	0501080128	3/8" X 71" TR-TR HOSE ASSY		01


**HOSE KIT TURBINE**

0521052379


Item	Code	Description	See page	QT
12	0501080135	HOSE 1/2 X 1800 TR-TR		02
13	0501080413	3/8" X 27" TR-TC HOSE		01
14	0501081296	3/8" X 800 TC-TC HOSE		01
15	0501082159	HOSE 1/2 X 1000 TC-TC 90G LEFT		02




Item	Code	Description	See page	QT
01	0521068346	HOSE GUIDE		01
02	0503010025	3/8" SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0501011643	3/8 X 1"BOLT		02




Item	Code	Description	See page	QT
001	0581015993	SUPPORT BLOCK HYDRAULIC		01
002	0511017302	FLAT WASHER		02
003	0503010395	1/2" X 1-1/4" BOLT		02
004	0503010019	1/2" SPRING WASHER		02
005	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0521052174	LANTERN WITH SUPPORT	106	02
02	0503032812	1141 12V LAMP		04
03	0503032813	67 12V 5W LAMP		02
04	0521053672	LIGHTHOUSE ASSY	107	03




Item	Code	Description	See page	QT
01	0571019753	SIDE SUPPORT		01
02	0503032811	FLASHLIGHT		01
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0503010395	1/2" X 1-1/4" BOLT		02




Item	Code	Description	See page	QT
01	0581015856	REDLIGHT SUPPORT		01
02	0503018738	LIGHTHOUSE		01
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010358	5/16" X 5/8" BOLT		02
05	0551019884	45 X 50 X 3/8 FASTENER		02
06	0503013357	3/8" SELF-ADJUSTING NUT		04
07	0503010337	5/16" NUT		02
08	0503010179	5/16" ZN SPRING WASHER		02




Item	Code	Description	See page	QT
01	0521051659	10 MOUTH CENTRAL AIR CONDUCTOR	109	01
02	0521052152	REAR CENTRAL AIR CONDUCTOR 1520	110	02
03	0521051096	REAR CENTRAL AIR CONDUCTOR 1120 CSCP	111	02
04	0521051092	AIR CONDUCTOR ASSY SUPPORT CSCP	112	04
05	0521050785	SUPPORT CONDUCTOR AIR ASSY	113	03
06	0521052168	SEED HOSE GUIDE	42	04
07	0503011372	102 TO 121 CLAMP		12
08	0581016488	AIR CONDUCTOR		10
09	0521052549	CLAMP	41	10
10	1164920009	FIXER SUPPORT SUCTION		06




Item	Code	Description	See page	QT
01	0511057036	AIR DISTRIBUTOR BOARD		02
01A	0503012567	T-JOIN FOR TUBE 110		01
01B	0581013890	SOCKET DISTRIBUTOR AR		01
02	0503031943	SOCKET		10
03	0503012856	REBITE POP		20
04	0571019716	ADAPTER		10
05	0503012566	COVER KAP 110 YELLOW		02
06	0581015157	AIR CONDUCTOR BODY 3 MOUTH 1140		02
07	0581015156	4 MOUTH AIR CONDUCTOR BODY 1750		01




Item	Code	Description	See page	QT
01	0581016018	AIR CONDUCTOR BODY 1400		01
02	0581013633	SOCKET DISTRIBUTOR AR		02




Item	Code	Description	See page	QT
01	0581015132	BODY DISTRIBUTOR AR		01
02	0581013633	SOCKET DISTRIBUTOR AR		01
03	0521050393	ASSY KNEE		01
03A	0503017845	PVC KNEE 90 SOLD AVEL		01
03B	0581013890	SOCKET DISTRIBUTOR AR		01




Item	Code	Description	See page	QT
01	0581014434	DOUBLE BODY SUPPORT AIR CONDUCTOR		01
02	0521018402	AIR CONDUCTOR CLAMP		02
03	0503010179	5/16" ZN SPRING WASHER		04
04	0503010337	5/16" NUT		04
05	0503010371	5/16" X 1" BOLT		04




Item	Code	Description	See page	QT
01	0521067690	BODY DISTRIBUTEUR AR		01
02	0511017302	FLAT WASHER		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521018402	AIR CONDUCTOR CLAMP		01
06	0503010371	5/16" X 1" BOLT		02
07	0503010179	5/16" ZN SPRING WASHER		02
08	0503010337	5/16" NUT		02
09	0571019615	FITTING 1/2 UNC 130 X 198 ZN		01




Item	Code	Description	See page	QT
01	0581017951	GUTTER 30 X 55 X 1200		01
02	0581017950	GUTTER		01
03	0511057011	SUPPORT GUTTER ASSY	44	04




Item	Code	Description	See page	QT
01	0503018063	SRM MAIN WHIP - 10 LINES		01
02	0503018061	SRM MAIN WHIP - 7 LINES		02
03	0503018074	CAN TERMINATOR		01
04	0503018080	EXTENSION CABLE		01
05	0503062430	SRM LINE ASSEMBLY		24
06	0503062456	TRACTOR CONNECTION ASSEMBLY 729414 - 13,7MTS		01
07	0503017980	APEX EXTENSION CABLE		01
08	0503018085	APEX EXTENSION CABLE		02
09	0503017984	LIFT SENSOR		02
10	0503017987	SENSOR LEVANTE EXTENDED WHIP		01
11	0503017988	VACUUM SENSOR		04
12	0503015218	SENSOR FOTOELE PM 400		24
13	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		432




Item	Code	Description	See page	QT
01	0503034334	ADHESIVE LABEL CSC (REAR)		03
02	0503034335	ADHESIVE LABEL		03
03	0503034336	ADHESIVE LABEL CSC (FRONT)		03
04	0503034337	ADHESIVE LABEL		03
05	0503034338	ADHESIVE LABEL		06
06	0503034339	ADHESIVE LABEL		06
07	0503031565	ADHESIVE LABEL CARE		02
08	0503031827	LUBRICATE AND RETIGHTEN DAILY DECAL		03
09	0503033621	ADHESIVE LABEL		02
10	0503031425	ADHESIVE LABEL ATTENTION		04
11	0503033597	ADHESIVE		02
12	0503031428	READ MANUAL DECAL		01
13	0503033416	ADHESIVE LABEL		02
14	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
15	0503034534	ADHESIVE LABEL		01
16	0503034680	LABEL ADHESIVE TABLE SEED		01




Item	Code	Description	See page	QT
01	0521068930	SACADOR AXLE		01
02	0521068931	SLEEVE SACADOR		01




Item	Code	Description	See page	QT
01	0503062427	CONTROL / MONITOR ASSEMBLY		01
01A	0503018046	MONITOR		01
01B	0503018047	MONITOR SUPPORT		01
02	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
03	0503016234	TRIMBLE FIXING WINDOW		01
04	0503018052	VDRIVE INSTRUCTIONS MANUAL		01
05	0503062428	CONTROL CABIN		01
06	0503017969	WHIP CABIN TRACTOR		01
07	0503018653	ADAPTER WHIP		01
08	0503018097	WHIP BATTERY		01
09	0503018053	GPS RECEIVER		01
10	0503062429	SRM ASSY		01
11	0503017994	EXTENSION CABLE		02




Item	Code	Description	See page	QT
01	0503019035	CONTROL PANEL		01
02	0503019040	CABLE BLOCK WITH IMPLEMENT		01
03	0503019037	WHIP		01
04	0503019038	BATTERY CABLE		01




Item	Code	Description	See page	QT
01	0561016781	SEQUENTIAL VALVE SUPPORT ASSY		01
02	0571011596	FIXER HOSE		01
03	0521060118	"T" TERMINAL		01
04	0503033787	NUT 3/4 UNF		01
05	0503014007	1/2" X 1-1/4" BOLT		02
06	0503010589	1/2" UNC SELF ADJUSTING NUT		02
07	0503010237	3/8" X 1" BOLT		02
08	0503013357	3/8" SELF-ADJUSTING NUT		02
09	0503010025	3/8" SPRING WASHER		02
10	0501010984	FLAT WASHER		02
11	0521053481	FLOW DIVIDER BLOCK FOR 02 TURBINES	121	01
12	0503010172	M10 X 1,5 X 25 BOLT		02




Item	Code	Description	See page	QT
01	0503034719	FLOW DIVIDER BLOCK		01
02	0501010590	NIPPLE		04
03	0503010045	O'RING		04



Item	Code	Description	See page	QT
01	0511059553	SIDE STAND WITH FIXING	23	01
02	0521053173	CENTRAL SEED BOX 15 EXITS	25	01
03	0501082104	AIR CONDUCTOR 1.1 / 4 X 1700		02
04	0501082105	AIR CONDUCTOR 1.1 / 4 X 1500		03
05	0501082102	AIR CONDUCTOR 1.1/4 X 1900 CSCP		01
06	0503034345	AIR DISPENSER COVER		08
07	0503010184	CLAMP		15
08	0503011372	102 TO 121 CLAMP		02




Item	Code	Description	See page	QT
01	0521052135	LEFT SIDE HANDRAIL 2235	124	01
02	0521052139	FRONT SIDE HANDRAIL 565	32	01
03	0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	35	01



Item	Code	Description	See page	QT
01	0581015996	TUBE 33,7 X 27 X 1131		01
02	0511059383	INTERNAL FIXER ASSY HANDLE	33	10
03	0581015995	TUBE 33,7 X 27 X 925		01
04	0581012718	HANDRAIL		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0581014429	SHIM HANDRAIL		01
07	0521068339	LEFT HANDRAIL FIXER		01
08	0581012708	HANDRAIL REAR SIDE BODY		02
09	0581015992	TUBE 33,70 X 27 X 354		04
10	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE CSCP	34	02
11	0503013357	3/8" SELF-ADJUSTING NUT		02

ASSY HYDRAULIC TURBINE


0511059951




Item	Code	Description	See page	QT
01	0511059823	ASSY POSITIVE AIR TURBINE SUPPORT	126	01
02	0521045392	HYDRAULIC TURBINE WITH SCREEN	127	01
03	0581014075	HOSE 4 X 500		01
04	0503011372	102 TO 121 CLAMP		02

ASSY POSITIVE AIR TURBINE SUPPORT

0511059823




Item	Code	Description	See page	QT
01	0521067276	AR POSITIVE TURBINE SUPPORT		01
02	0551015037	5/8" UNC X 210 X 198 FASTENER		02
03	0501012140	FLAT WASHER		04
04	0503010027	5/8" SPRING WASHER		06
05	0503010013	5/8" NUT		06
06	0503010232	5/8" X 1.3/4" BOLT		02




Item	Code	Description	See page	QT
01	0501054983	NIPPLE HIDRAULIC MOTOR	128	01
02	0503010025	3/8" SPRING WASHER		12
03	0503010026	3/8" NUT		10
04	0521044613	FAN 480X50 (HIDRAULIC)		01
05	0503010143	1/4" SPRING WASHER		01
06	0503010849	3/8" X 1-1/2" BOLT		02
07	0531018764	FLAT WASHER		01
08	0503011104	M6 X 1" BOLT		01
09	0503012722	0.16" X 0.4" BLIND RIVET		24
10	0521065857	CARACOL MECHANICAL TURBINE S MEC		01
11	0521065858	TURBIN SUPPORT		01
12	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC 129 TURBINE		01
13	0561010634	VALVE SUPPORT ASSY		01
14	0503010237	3/8" X 1" BOLT		08
15	0503010206	3/8" X 1/2" BOLT		02
16	0571018577	COVER SNAIL TURBINE		01
17	0571018578	TURBINE PROTECTIVE SCREEN		01
18	0541013274	LISA WASHER 10 X 38 X 4.75		02
19	0521069167	FRONT PROTECTION		01
20	0501080709	3/8" X 21.6" TR-TR HOSE		01
21	0501080091	1/2" X 550 TR-TR HOSE		02
22	0503031087	ADHESIVE LABEL		01
23	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
24	0503033981	ADHESIVE LABEL		01

NIPPLE HIDRAULIC MOTOR


0501054983



Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW		01
03	0561016941	3/4" NUT		01
04	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
05	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE		01
06	3914103037	TEFLON 50M/M BRANCO		0,001RI




Item	Code	Description	See page	QT
01	0503012291	BLOCK COMMAND		01
02	0501010590	NIPPLE		04
03	0503010045	O'RING		04
04	0541011066	3/4" UNF X 43.5 NIPPLE		01
05	0503010190	2-114 N 3006-9B O'RING		01



Item	Code	Description	See page	QT
01	0521052171	LEFT CENTRAL AIR CONDUCTOR	131	01
02	0521053183	SIDE AIR CONDUCTOR 5 INPUT 2334	39	01
03	0511057646	ASSY AIR CONDUCTOR SUPPORT	40	03
04	0581016488	AIR CONDUCTOR		07
05	0521052549	CLAMP	41	07
06	0521052168	SEED HOSE GUIDE	42	02

LEFT CENTRAL AIR CONDUCTOR


0521052171




Item	Code	Description	See page	QT
01	0581012427	AIR DISTRIBUTOR NOZZLE		01
02	0511057036	AIR DISTRIBUTOR BOARD		01
02A	0503012567	T-JOIN FOR TUBE 110		01
02B	0581013890	SOCKET DISTRIBUTOR AR		01
03	0581016056	CENTRAL AIR DISTRIBUTOR BODY 315		02
04	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		02
04A	0503034812	SOCKET DISTRIBUTOR AR		01
04B	0503012856	REBITE POP		04
05	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
05A	0503034763	AIR DITRIBUTOR PUMP		01
05B	0503015341	RIVET POP		02

LEFT SIDE DUCT ASSEMBLY

0521052892



Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY	46	02
02	0581018408	SUPPORT SCALE		02
03	0581018415	PROTECTION BODY		04
04	0511059928	SIDE DUTY SUPPORT	47	01
05	0503011268	3/8" X 2-1/2" BOLT		06
06	0503010025	3/8" SPRING WASHER		06
07	0503010026	3/8" NUT		06
08	0521069290	OIL DUCT R7/8 X 2500		02
09	0521069265	OIL DUCT R3/4 X 2500		01
10	0521069266	OIL DUCT 3 OUTLETS R/34 X 2340		02
11	0503062180	T ADAPTER WITH ROTATING NUT		01



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

