

ROW CROP PLANTERS

PHT4 - CHASSI 3185 - CSI

Code: 0501093206
Series: S-0615
Revision: 00
Date Revision: JULHO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111450008	PHT4 3185/4E900 CI MH AMENDOIM / MILHO S-0615

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX


0909096415	ASSY FRAME	1
0521050859	RIGHT CARRYING-WHEELS	2
0511052484	WHEELS RIGHT	3
0503060105	WELL AND TIRE ASSY	4
0511052486	WHEEL ARM RIGTH	5
0511052487	TURNBUCKLE	6
0501056444	BEARING WITH ROLLING	7
0521050860	LEFT CARRYING-WHEELS	8
0511052483	LEFT CARRYING-WHEELS	9
0909096416	FERTILIZER SPROCKET	10
0511059266	CLOSED BEARING	11
0501056443	GEAR HOUSING BEARING	12
0501048790	AXLE WITH RING	13
0521050312	LOWER HITCH ASSY	14
0521050861	SEED/FERTILIZER TRANSMISSION	15
0521050521	UPPER HITCH	16
0501052586	ESTABILIZER DRAWBAR ASSY	17
0521040712	FERTILIZER RIGHT BOX ASSY	18
0511051712	RH BEAM SUPPORT	19
0511051714	SIDE FERTILIZER DISTRIBUTOR	20
0511051715	SIDE FERTILIZER DISTRIBUTOR	21
0501056451	BEARING	22
0501053788	3/4 SQUARE AXLE FASTENER	23
0521040718	LH FERTILIZER BOX COVER ASSY	24
0511051717	LH BEAM SUPPORT	25
0511057604	HYDRAULIC MARKER ASSY	26
0521040155	HYDRAULIC CYLINDER 31,75 X 50,8 X 365 X 595	27
0501054649	HBM SEQUENTIAL VALVE	28
0501053834	MALE QUICK COUPLER	29
0501050633	ROW MARKER DISK ASSEMBLY	30
0511053904	ROW MARKER DISC	31
0909093956	TRANSMISSION SEED	32
0909093957	SEED/FERTILIZER ROW ASSY	33
0531054169	LINE SEED RIGHT SIGMA	34
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	35
0501052538	DEPTH BAND WITH ARMS	36
0511054333	COMPACT WHEEL RIGHT WITH BEARING	37
0511054334	COMPACT WHEEL LEFT WITH BEARING	38
0501052908	COMPACTOR WHEEL WITH BEARING	39
0511058650	SEMI-MOUNTED DEPTH CONTROL	40
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	41
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	42
0501052627	ASSY DEPTH WHEEL BOX	43
0501052297	DEPTH WHEELS REGULATOR ASSY	44
0511052024	FAST CLOSING SET	45
0531054131	PEANUT SEED SYSTEM IBEZZI	46
0503063602	SEMI-ASSEMBLED SIGMA INDIVIDUAL SEED BOX	47
0531054132	PEANUT SEED SYSTEM IBEZZI	48
0511057694	LH SEED ROW ARM	49
0511051693	BASE FIXING SYSTEM	50
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	51
0511052301	SUPPORT DDD 15 RIGHT	52
0511053173	CUBE LOW RIGHT WITH DISC 15	53
0511053172	LEFT LOW CUBE WITH DISC 15	54
0531054168	LINE SEED LEFT SIGMA	55

INDEX

0511057695	LH SEED ROW ARM		56
0511058212	ASSY LINE SUPPORT FERTILIZER		57
0511057589	RIGHT ARM FERTILIZER ROW ASSY		58
0511057590	RH FERTILIZER ROW ARM		59
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR		60
0511057591	LH FERTILIZER ROW ASSY		61
0511057592	LH FERTILIZER ROW ARM		62
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR		63
0511058164	16" COULTER BLADE ASSY		64
0501056428	16" CUTTING DISC SEMI-ASSEMBLED		65

ASSY FRAME

0909096415




Item	Code	Description	See page	QT
01	0521062567	FRAME		01
02	0521050859	RIGHT CARRYING-WHEELS	2	01
03	0521050860	LEFT CARRYING-WHEELS	8	01
04	0909096416	FERTILIZER SPROCKET	10	01
05	0521050312	LOWER HITCH ASSY	14	02
06	0521050861	SEED/FERTILIZER TRANSMISSION	15	02
07	0521050521	UPPER HITCH	16	01
08	0501052586	ESTABILIZER DRAWBAR ASSY	17	01
09	0521010580	COUPLING SHAFT		01
10	0501011445	FLAT WASHER		01
11	0503030085	LOCK PIN		04
12	0511064353	FASTENER		02
13	0501013233	5/8" X 2-3/4" BOLT		08
14	0501012140	FLAT WASHER		08
15	0503012412	5/8 UNC SELF LOCKING NUT		08
16	0521040712	FERTILIZER RIGHT BOX ASSY	18	01
17	0521040718	LH FERTILIZER BOX COVER ASSY	24	01
18	0511057604	HYDRAULIC MARKER ASSY	26	01
19	0501050633	ROW MARKER DISK ASSEMBLY	30	01
20	0501065337	PLOUGH SUPPORT		02
21	0521010809	11,11 X 64 COUPLING SHAFT		02
22	0503030168	HITCH PIN CLIP		02
23	0521010530	COUPLING SHAFT		02
24	0503010140	1/8" X 3/4" COTTERPIN		02
25	0909093956	TRANSMISSION SEED	32	01
26	0503034003	SERIAL NUMBER TAG 61 X 118		01
27	0503034245	ADHESIVE LABEL		02
28	0503033874	ADHESIVE LABEL LOGO TATU BOX 180X545		02
29	0503033853	ADHESIVE LABEL		02
30	0503033421	ADHESIVE LABEL 7 NUMBER FOR PLANTING		02
31	0503031428	READ MANUAL DECAL		01

ASSY FRAME


0909096415

Item	Code	Description	See page	QT
32	0503031942	ADHESIVE LABEL		01
33	0503031565	ADHESIVE LABEL CARE		02
34	0503031424	ADHESIVE LABEL ATTENTION MARCADOR LÍNEA HIDRAULICO		02
35	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
36	0503010001	3.2 X 5.5 RIVET		04
37	0511062251	12.80" RIGTH TURNBUCKLE		01
38	0521012533	COUPLING SHAFT		02
39	0503010780	N-2050 AMENDMENT		02
40	0503010951	REDUCTION		04
41	0503010010	1/4" X 2.1/2" COTTERPIN		04
42	0909093957	SEED/FERTILIZER ROW ASSY	33	01




Item	Code	Description	See page	QT
01	0521063583	WHEEL SUPPORT		02
02	0502010175	HITCH CLAMP		02
03	0501011543	5/8" X 4" BOLT		04
04	0503012412	5/8 UNC SELF LOCKING NUT		08
05	0511052484	WHEELS RIGHT	3	01
06	0521062809	BEARING		04
07	0571010967	CHAIN TENSIONER		02
08	0561016501	GLOVE 30,50		02
09	0511067501	26Z GEAR		02
10	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
11	0571010830	RIGHT CHAIN COVER		01
12	0561016503	PRISONER 3/8 UNC		06
13	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
14	0503010025	3/8" SPRING WASHER		08
15	0503010209	3/8" UNC BUTTERFLY NUT		06
16	0571010341	SQUARE SHAFT		02
17	0581014148	AXLE		02
18	0521060880	GEAR 22 TEETH		02
19	0511061757	18Z GEAR		02
20	0503018182	40-1 X 39 CHAIN LINK + MENDING		02
21	0561019679	CHAIN CAP		01
22	0501056444	BEARING WITH ROLLING	7	04
23	0521018630	1.4" X SQUARE 0.8" WASHER		08
24	0503030303	SUPPORT WASHER		08
25	0503010577	3/16" X 1-1/4" COTTERPIN		12
26	0511057192	EXTENSION SPRING		02
26A	0503031681	2.1" X 7.78" EXTENSION SPRING		04
26B	0502011031	SPRING UPPER HITCH		02
27	0503013618	BOLT		04
28	0501011299	FLAT WASHER		04
29	0571010541	BEATER SLEEVE		02

Item	Code	Description	See page	QT
30	0571010964	TENSIONER CHAIN		02
31	0503031805	11Z 1/2" GEAR		02
32	0503010302	501019 SEAL RING		04
33	0511052487	TURNBUCKLE	6	02
34	0521010784	COUPLING SHAFT		02
35	0501011445	FLAT WASHER		04
36	0503010571	1/4" X 1.1/2 COTTERPIN		02
37	0521017623	0.5" X 1.5" COUPLING SHAFT		02
38	0503010257	1/8" X 1" COTTERPIN		02
39	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01
40	0503010302	501019 SEAL RING		02
41	0503010002	1800 GREASE FITTING		02
42	0521012529	CHAIN TIGHTENER AXLE		01
43	0503010019	1/2" SPRING WASHER		01
44	0503030402	PULLEY		01
45	0511017302	FLAT WASHER		03
46	0503010060	1/2" NUT		01
47	0503013462	BEARING WITH BALL BEARING		02
48	0503011105	SEAL RING		02
49	0503011953	5/16" X 1" BOLT		08
50	0501010694	FLAT WASHER		08
51	0503010179	LOCK WASHER		08
52	0503010337	5/16" NUT		08




Item	Code	Description	See page	QT
01	0503060105	WELL AND TIRE ASSY	4	01
02	0511052486	WHEEL ARM RIGTH	5	01
03	0501010127	9/16" X 1-7/8" LUG BOLT		04
04	0503010035	9/16" CONIC NUT		04



Item	Code	Description	See page	QT
01	0503011010	CANVAS TIRE		01
02	0503010791	AR F 15 INNER TIRE		01
03	0503010789	0.2"J X 15H2" X0.2"F X0.6"X6" WHEEL		01

WHEEL ARM RIGTH


0511052486




Item	Code	Description	See page	QT
01	0521061662	WHEELED AXLE		01
02	0521063588	RH WHEEL ARM		01
03	0571010311	SLEEVE INTERMEDIARY		02
04	0503010002	1800 GREASE FITTING		02
05	0503013170	ROLLER BEARING		02
06	0561016502	GUARD POWDER		02
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01

TURNBUCKLE


0511052487



Item	Code	Description	See page	QT
01	0521063584	BODY RIGHT TURNBUCLE		01
02	0521063585	LEFT EXTENSOR BODY		01
03	0541010618	STABILIZER BODY		01
04	0541010087	LOOK NUT		01
05	0503010691	1/4" GREASE FITTING		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521063583	WHEEL SUPPORT		02
02	0502010175	HITCH CLAMP		02
03	0501011543	5/8" X 4" BOLT		04
04	0503012412	5/8 UNC SELF LOCKING NUT		08
05	0511052483	LEFT CARRYING-WHEELS	9	01
06	0521062809	BEARING		04
07	0571010967	CHAIN TENSIONER		02
08	0561016501	GLOVE 30,50		02
09	0511067501	26Z GEAR		02
10	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
11	0561019680	LEFT CHAIN COVER		01
12	0561016503	PRISONER 3/8 UNC		06
13	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
14	0503010025	3/8" SPRING WASHER		08
15	0503010209	3/8" UNC BUTTERFLY NUT		06
16	0571010341	SQUARE SHAFT		02
17	0581014148	AXLE		02
18	0521060880	GEAR 22 TEETH		02
19	0511061757	18Z GEAR		02
20	0503018182	40-1 X 39 CHAIN LINK + MENDING		02
21	0561019679	CHAIN CAP		01
22	0501056444	BEARING WITH ROLLING	7	04
23	0521018630	1.4" X SQUARE 0.8" WASHER		08
24	0503030303	SUPPORT WASHER		08
25	0503010577	3/16" X 1-1/4" COTTERPIN		12
26	0511057192	EXTENSION SPRING		02
26A	0503031681	2.1" X 7.78" EXTENSION SPRING		04
26B	0502011031	SPRING UPPER HITCH		02
27	0503013618	BOLT		04
28	0501011299	FLAT WASHER		04
29	0571010541	BEATER SLEEVE		02

Item	Code	Description	See page	QT
30	0571010964	TENSIONER CHAIN		02
31	0503031805	11Z 1/2" GEAR		02
32	0503010302	501019 SEAL RING		04
33	0511052487	TURNBUCKLE	6	02
34	0521010784	COUPLING SHAFT		02
35	0501011445	FLAT WASHER		04
36	0503010571	1/4" X 1.1/2 COTTERPIN		02
37	0521017623	0.5" X 1.5" COUPLING SHAFT		02
38	0503010257	1/8" X 1" COTTERPIN		02
39	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01
40	0503010302	501019 SEAL RING		02
41	0503010002	1800 GREASE FITTING		02
42	0521012529	CHAIN TIGHTENER AXLE		01
43	0503010019	1/2" SPRING WASHER		01
44	0503030402	PULLEY		01
45	0511017302	FLAT WASHER		03
46	0503010060	1/2" NUT		01
47	0503013462	BEARING WITH BALL BEARING		02
48	0503011105	SEAL RING		02
49	0503011953	5/16" X 1" BOLT		08
50	0501010694	FLAT WASHER		08
51	0503010179	LOCK WASHER		08
52	0503010337	5/16" NUT		08



Item	Code	Description	See page	QT
01	0503060105	WELL AND TIRE ASSY	4	01
02	0511052485	LH WHELLS ARM		01
03	0501010127	9/16" X 1-7/8" LUG BOLT		04
04	0503010035	9/16" CONIC NUT		04




Item	Code	Description	See page	QT
01	0571010425	JACK		04
02	0521062568	SIDE		01
03	0561019671	BODY		01
04	0503011336	1/2" HEX SELF ADJUSTING NUT		08
05	0511059266	CLOSED BEARING	11	03
06	0511060392	CHAIN TENSIONER		01
07	0503010302	501019 SEAL RING		02
08	0501056443	GEAR HOUSING BEARING	12	01
09	0581014147	MOTOR SHAFT		01
10	0503010292	0.2" X 1.6" SPRING PIN		04
11	0561017353	MOTOR SHAFT		01
12	0503030303	SUPPORT WASHER		01
13	0503011907	PMC 594-S NYLON LUG		01
14	0521018630	1.4" X SQUARE 0.8" WASHER		09
15	0511060396	DRIVE/DRIVEN AXLE CONE		02
16	0503031366	RIGHT TWISTED SPRING RECAMBIO		01
17	0503012204	40-1 CHAIN X 82 LINK + RED		01
18	0503031805	11Z 1/2" GEAR		02
19	0503010002	1800 GREASE FITTING		03
20	0502011758	REAR TENSIONER LEVER		01
21	0501048790	AXLE WITH RING	13	01
22	0501013518	FLAT WASHER		03
23	0503010025	3/8" SPRING WASHER		02
24	0571010426	SLEEVE SUPPORT		04
25	0503010256	3/8" X 3/4" BOLT		03
26	0581012581	TOP RIGHT COVER		01
27	0521067247	RIGHT PROTECTION COVER		01
28	0581012580	REAR COVER		01
29	0503010363	5/16" X 1" BOLT		02
30	0503010179	LOCK WASHER		02
31	0503010337	5/16" NUT		02




PHT4 - CHASSI 3185 - CSI
FERTILIZER SPROCKET

Page 10
0909096416


Item	Code	Description	See page	QT
32	0503013357	3/8" SELF-ADJUSTING NUT		02
33	0503014528	40-1 CHAIN X 72 LINK + REDECTION		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	7	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0521067511	LOWER HITCH		01
02	0502010175	HITCH CLAMP		02
03	0521010596	COUPLING SHAFT		01
04	0503012412	5/8 UNC SELF LOCKING NUT		04
05	0501012140	FLAT WASHER		04
06	0503016460	5/8" X 4.1/2" BOLT		04
07	0503030085	LOCK PIN		01




Item	Code	Description	See page	QT
01	0503011855	0.2" X 1.8" SPRING PIN		02
02	0503030331	1.2" X 1.2" X 12.2" HOSE		01
03	0503010243	CLAMP		02
04	0503062657	DRIVE SHAFT		01

UPPER HITCH


0521050521




Item	Code	Description	See page	QT
01	0521067571	UPPER HITCH		01
02	0501010392	1" X 5" BOLT		02
03	0501010059	1.5/8 NUT		02
04	0503010012	1" SPRING WASHER		02
05	0503030085	LOCK PIN		01
06	0521010581	0.9" X 4.9" COUPLING SHAFT		01




Item	Code	Description	See page	QT
01	0501110096	165 ADJUSTMENT NUT		01
02	0511061503	8.86" RIGTH TURNBUCKLE		01
03	0511061504	8.86" LH TURNBUCKLE		01
04	0501064974	LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511051712	RH BEAM SUPPORT	19	01
02	0503060693	BOX FERTILIZER ASSY		01
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0503034396	FERTILIZER SIDE COVER		02
08	0503010362	1/8 X 1.1/4 COTTERPIN		02
09	0581018852	GLOVE Ø13,5 X Ø35 X 10		04
10	0581018853	SEED BOX FIXATION		02
11	0501010937	13,50 X 28 X 3,00 FLAT WASHER		08
12	0503010019	1/2" SPRING WASHER		04
13	0503010060	1/2" NUT		04
14	0501019219	1/2" X 1-3/4" BOLT		04




Item	Code	Description	See page	QT
01	0521062960	SUPPORT BIN FERTILIZER BOX PLASTIC		01
02	0511051714	SIDE FERTILIZER DISTRIBUTOR	20	01
03	0511051715	SIDE FERTILIZER DISTRIBUTOR	21	01
04	0501811643	SCREW 3/8 UNC X 1 CAPQ G.2		08
05	0503011443	3/8" SPRING WASHER		12
06	0503810026	3/8" NUT		12
07	0501056451	BEARING	22	01
08	0501056444	BEARING WITH ROLLING	7	01
09	0503810237	3/8 UNC X 1 C S G.5 SA BOLT		04
10	0561018362	SQUARE SHAFT		01
11	0501053788	3/4 SQUARE AXLE FASTENER	23	04
12	0511066098	23Z GEAR		01
13	0503030275	AGRICULTURAL BEARING		02
14	1902010685	18Z CONICAL GEAR		02
15	0551018055	22,65 X 60 SLEEVE		02




Item	Code	Description	See page	QT
01	0501110690	DISTRIBUTOR FERTILIZER		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		02
12	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110691	DISTRIBUTOR FERTILIZER WITH SIDE OUTPUT		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		02
12	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01



Item	Code	Description	See page	QT
01	0511051717	LH BEAM SUPPORT	25	01
02	0503060693	BOX FERTILIZER ASSY		01
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0503034396	FERTILIZER SIDE COVER		02
08	0503010362	1/8 X 1.1/4 COTTERPIN		02
09	0581018852	GLOVE Ø13,5 X Ø35 X 10		04
10	0581018853	SEED BOX FIXATION		02
11	0501010937	13,50 X 28 X 3,00 FLAT WASHER		08
12	0503010019	1/2" SPRING WASHER		04
13	0503010060	1/2" NUT		04
14	0501019219	1/2" X 1-3/4" BOLT		04




Item	Code	Description	See page	QT
01	0521062960	SUPPORT BIN FERTILIZER BOX PLASTIC		01
02	0511051714	SIDE FERTILIZER DISTRIBUTOR	20	01
03	0511051715	SIDE FERTILIZER DISTRIBUTOR	21	01
04	0501811643	SCREW 3/8 UNC X 1 CAPQ G.2		08
05	0503011443	3/8" SPRING WASHER		12
06	0503810026	3/8" NUT		12
07	0501056444	BEARING WITH ROLLING	7	01
08	0501056451	BEARING	22	01
09	0503810237	3/8 UNC X 1 C S G.5 SA BOLT		04
10	0561018362	SQUARE SHAFT		01
11	0501053788	3/4 SQUARE AXLE FASTENER	23	02
12	0503030275	AGRICULTURAL BEARING		02
13	1902010685	18Z CONICAL GEAR		02
14	0551018055	22,65 X 60 SLEEVE		02




Item	Code	Description	See page	QT
01	0521062818	BRACO LEFT MARKER LINE		01
02	0521062819	RIGHT ARM MARKER LINE		01
03	0531012400	COUPLING SHAFT		02
04	0503010577	3/16" X 1-1/4" COTTERPIN		02
05	0501069307	ROW MARKER ARM		02
06	0503010834	1/2 X 1 BOLT		04
07	0503011070	BEATER		02
08	0503010019	1/2" SPRING WASHER		02
09	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
10	0521040155	HYDRAULIC CYLINDER 31,75 X 50,8 X 365 X 595	27	02
11	0521010571	COUPLING SHAFT		02
12	0503010571	1/4" X 1.1/2 COTTERPIN		02
13	0561019695	TRANSPORT LOCK		02
14	0501068994	8,30 X 78 LOCK PIN		02
15	0503030168	HITCH PIN CLIP		02
16	0571010413	VALVE SUPPORT		01
17	0503010371	5/16" X 1" BOLT		02
18	0501010694	FLAT WASHER		02
19	0503010179	LOCK WASHER		02
20	0503010337	5/16" NUT		02
21	0501054649	HBM SEQUENTIAL VALVE	28	01
22	0503010237	3/8" X 1" BOLT		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057603	HOSE KIT		01
24A	0501080469	3/8" X 98.42" TR-TR HOSE ASSY		02
24B	0501080412	3/8" X 90.55" TR-TC HOSE		02
24C	0521052312	HOSE 3/8 X 1500 TR-TM PURPLE / RED		01
24CA	0501080852	3/8" X 1500 TR-TM HOSE		01
24CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
24CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
24CD	0503018952	PLASTIC BOLT		06


Item	Code	Description	See page	QT
24D	0521052313	HOSE 3/8 X 1500 TR-TM PURPLE / BLUE		01
24DA	0501080852	3/8" X 1500 TR-TM HOSE		01
24DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
24DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
24DD	0503018952	PLASTIC BOLT		06
25	0501053834	MALE QUICK COUPLER	29	02
26	0502012702	BODY SUPPORT CLAMP		06
27	0503010180	7/16" SPRING WASHER		06
28	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		06




Item	Code	Description	See page	QT
01	0521062810	CYLINDER CASE		01
02	0571010344	31,75 X 456 ROD		01
03	0551019990	31,75 X 50,80 X 39,40 PISTON		01
04	0503010812	7/8" UNF SELF LOCKING NUT		01
05	0503010949	W2-2000-500 PK RING G.E		01
06	0503013920	GASKET 1870-1625		02
07	0503014677	2-118 O'RING		01
08	0503013917	O'RING 2-224		01
09	0503013914	1870-1250-312B GASKET		01
10	0503013915	D-1250 SCRAPER RING		01
11	0503013918	8-224 BACK-UP RING		01
12	0503014683	W1-1400-500 RING GUIDE		01
13	0501012140	FLAT WASHER		01
14	0503012412	5/8 UNC SELF LOCKING NUT		01
15	0571010576	SUPPORT WASHER		01
16	0571011410	SUPPORT RING CYLINDER LINE PHT4		01
17	0571011411	MOBILE COVER		01
18	0503033686	SLEEVE 22 X 38 X 12,50 RUBBER		02
19	0501038643	ASSEMBLY		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01



Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	31	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0511060396	DRIVE/DRIVEN AXLE CONE		02
02	0571010426	SLEEVE SUPPORT		04
03	0511060392	CHAIN TENSIONER		01
04	0521018630	1.4" X SQUARE 0.8" WASHER		09
05	0503031805	11Z 1/2" GEAR		03
06	0501056443	GEAR HOUSING BEARING	12	01
07	0503030303	SUPPORT WASHER		02
08	0503031367	SPRING		01
09	0511061822	25Z P0.5" GEAR SQUARE HOL		01
10	0502011758	REAR TENSIONER LEVER		01
11	0561014215	BEARING COVER LOWER ROW FRAME		01
12	0561016554	CURRENT STRETCH AXIS WHEELED SUPPORT		01
13	0561017353	MOTOR SHAFT		01
14	0561019671	BODY		01
15	0521062568	SIDE		01
16	0571010425	JACK		04
17	0501048790	AXLE WITH RING	13	01
18	0511059266	CLOSED BEARING	11	03
19	0503012204	40-1 CHAIN X 82 LINK + RED		01
20	0581012582	LEFT UPPER COVER		01
21	0581012580	REAR COVER		01
22	0521067248	LEFT PROTECTION COVER		01
23	0581014147	MOTOR SHAFT		01
24	0571011451	HEX AXLE		01
25	0511057698	BEARING GEAR 20Z LINE SEED		01
26	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
27	0501010694	FLAT WASHER		02
28	0501013518	FLAT WASHER		03
29	0503010002	1800 GREASE FITTING		01
30	0503010019	1/2" SPRING WASHER		01
31	0503010025	3/8" SPRING WASHER		02


Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		01
33	0503010179	LOCK WASHER		04
34	0503010256	3/8" X 3/4" BOLT		03
35	0503010292	0.2" X 1.6" SPRING PIN		04
36	0503010302	501019 SEAL RING		01
37	0503010337	5/16" NUT		04
38	0503010363	5/16" X 1" BOLT		02
39	0511017302	FLAT WASHER		01
40	0503011336	1/2" HEX SELF ADJUSTING NUT		08
41	0503011907	PMC 594-S NYLON LUG		01
42	0503011953	5/16" X 1" BOLT		02
43	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0531054169	LINE SEED RIGHT SIGMA	34	01
02	0531054168	LINE SEED LEFT SIGMA	55	01
03	0511058212	ASSY LINE SUPPORT FERTILIZER	57	01
04	0511057589	RIGHT ARM FERTILIZER ROW ASSY	58	01
05	0511057591	LH FERTILIZER ROW ASSY	61	01
06	0571011443	ROD GUIDE SUPPORT		01
07	0502010891	SPRING CHOCK SUPPORT VARON		01
08	0501010163	5/8" X 4-1/2" BOLT		01
09	0503012412	5/8 UNC SELF LOCKING NUT		01
10	0503010920	1/2" X 1.1/2" BOLT		01
11	0503010395	1/2" X 1-1/4" BOLT		01
12	0503010060	1/2" NUT		01
13	0511058164	16" COULTER BLADE ASSY	64	01
14	0501018652	CORN STABILIZER BAR		01
15	0503063647	SIGMA CORN DISC SET		01
16	0503034131	DEFLECTOR		01
17	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
18	0521069124	BOCAL FILLED LINE PIVOTED WITH LINGUET		01
19	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
20	0503010019	1/2" SPRING WASHER		01
21	0503010060	1/2" NUT		01
22	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
23	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
24	0503010025	3/8" SPRING WASHER		01
25	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0521062824	SPINDLE GUIDE		01
02	0521010542	COUPLING SHAFT		01
03	0503010257	1/8" X 1" COTTERPIN		01
04	0521062825	LOCK VARON GUIDE		01
05	0503010834	1/2 X 1 BOLT		02
06	0531019915	FLAT WASHER		01
07	0503031359	1"X15.75"X0.15" COMPRESSION SPRING		01
08	0503031360	1.68"X17.75"X0.3" COMPRESS SPRING		01
09	0502040534	SPRING GUIDE BUSHING LOCK		01
10	0501018535	1/2 X 1 BOLT		01
11	0503010335	3/4"NUT		01
12	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	35	01
13	0503010905	1/2" X 2-1/4" BOLT		02
14	0503010019	1/2" SPRING WASHER		02
15	0503010060	1/2" NUT		02
16	0511052024	FAST CLOSING SET	45	01
17	0531054131	PEANUT SEED SYSTEM IBEZZI	46	01
18	0503033672	NOZZLE WITHOUT TITANIUM		01
19	0571019911	AXLE PROTECTION COVER		01
20	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
21	0511017302	FLAT WASHER		01
22	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
23	0503010019	1/2" SPRING WASHER		01
24	0503010060	1/2" NUT		01
25	0511057694	LH SEED ROW ARM	49	01




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	40	01
02	0501052538	DEPTH BAND WITH ARMS	36	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	37	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	38	01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	39	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	39	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	41	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	42	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	44	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX	43	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX	43	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0503063602	SEMI-ASSEMBLED SIGMA INDIVIDUAL SEED BOX	47	01
02	0503010179	LOCK WASHER		04
03	0501010694	FLAT WASHER		04
04	0503010240	BOLT		04
05	0503035691	ADHESIVE LABEL		02
06	0531054132	PEANUT SEED SYSTEM IBEZZI	48	01




Item	Code	Description	See page	QT
01	0503035628	SIGMA YELLOW SEED BOX		01
02	0503035629	SIGMA SEED BOX LID		01
03	0503035298	BAKELITE HANDLE WITH THREAD		01
04	0503015536	M6 X 1" SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0503030083	3/8" X 3/8" X 1.6" STUD		02
02	0503010675	5/16" X 2.1/4" BOLT		01
03	0503010337	5/16" NUT		01
04	0591016431			01
05	0501013518	FLAT WASHER		03
06	0503010025	3/8" SPRING WASHER		03
07	0503010209	3/8" UNC BUTTERFLY NUT		03
08	0503016282	ALLEN BOLT		01
09	0503019913	SELF-LOCKING NUT W/ NYLON M8 X 1.25 C.8 ZN		01
10	0503035299	PLATE SPRING 16 X 8.2 X 0.90		02
11	0591018706	SEED BOX SUPPORT		01
12	0503063415	PEANUT SEED DISTRIBUTOR BOX		01
13	0591016430	PEANUT DEFLECTOR		01
14	0571018536	HEX PRISONER		01
15	0503019965	11 SLOTS 8,50 PEANUT DISC		01




Item	Code	Description	See page	QT
001	0502011561	BEARING SEMI		01
002	0571010152	ROW SEED SUPPORT ARTICULACION		01
003	0521018079	SEEP ROW DRAWBAR COVER		01
004	0503014729	1/4" UNF X 1/2" BOLT		02
005	0503011441	SPRING WASHER		02
006	0502010426	UPPER BEARING SEMI		02
007	0503010479	BOLT		04
008	0503011440	SPRING WASHER		04
009	0503010060	1/2" NUT		04
010	0521066077	SEED ROW ARM		01
011	0503010752	1/2" X 3.1/2" BOLT		02
012	0503011440	SPRING WASHER		02
013	0503010060	1/2" NUT		02
014	0502011400	18Z CONICAL GEAR		01
015	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
016	0501013354	FLAT WASHER		02
017	0502011505	18Z CONICAL GEAR		01
018	0571019912	1/2 X 925 AXLE HEX		01
019	0501013352	FLAT WASHER		01
020	0503010060	1/2" NUT		02
021	0571019911	AXLE PROTECTION COVER		01
022	0511051693	BASE FIXING SYSTEM	50	01
023	0571019424	SUPPORT		01
024	0503015920	3/8" UNC X 1.3/4" BOLT		02
025	0503017813	3/8" X 2" BOLT		02
026	0503011443	3/8" SPRING WASHER		04
027	0503010026	3/8" NUT		04
028	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	51	01
029	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
030	0503011440	SPRING WASHER		02




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502011411	10Z CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	52	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	53	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	54	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0511057695	LH SEED ROW ARM	56	01
02	0521062824	SPINDLE GUIDE		01
03	0521010542	COUPLING SHAFT		01
04	0503010257	1/8" X 1" COTTERPIN		01
05	0521062825	LOCK VARON GUIDE		01
06	0503010834	1/2 X 1 BOLT		02
07	0531019915	FLAT WASHER		01
08	0503031359	1"X15.75"X0.15" COMPRESSION SPRING		01
09	0503031360	1.68"X17.75"X0.3" COMPRESS SPRING		01
10	0502040534	SPRING GUIDE BUSHING LOCK		01
11	0501018535	1/2 X 1 BOLT		01
12	0503010335	3/4"NUT		01
13	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	35	01
14	0503010905	1/2" X 2-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		02
16	0503010060	1/2" NUT		02
17	0511052024	FAST CLOSING SET	45	01
18	0531054131	PEANUT SEED SYSTEM IBEZZI	46	01
19	0503033672	NOZZLE WITHOUT TITANIUM		01
20	0571019911	AXLE PROTECTION COVER		01
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
22	0511017302	FLAT WASHER		01
23	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
24	0503010019	1/2" SPRING WASHER		01
25	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011561	BEARING SEMI		01
02	0571010152	ROW SEED SUPPORT ARTICULACION		01
03	0521018079	SEEP ROW DRAWBAR COVER		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0502010426	UPPER BEARING SEMI		02
07	0503010479	BOLT		04
08	0503011440	SPRING WASHER		04
09	0503010060	1/2" NUT		04
10	0521066077	SEED ROW ARM		01
11	0503010752	1/2" X 3.1/2" BOLT		02
12	0503011440	SPRING WASHER		02
13	0503010060	1/2" NUT		02
14	0502011400	18Z CONICAL GEAR		01
15	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
16	0501013354	FLAT WASHER		02
17	0502011505	18Z CONICAL GEAR		01
18	0571019912	1/2 X 925 AXLE HEX		01
19	0501013352	FLAT WASHER		01
20	0503010060	1/2" NUT		02
21	0571019911	AXLE PROTECTION COVER		01
22	0511051693	BASE FIXING SYSTEM	50	01
23	0571019424	SUPPORT		01
24	0503015920	3/8" UNC X 1.3/4" BOLT		02
25	0503017813	3/8" X 2" BOLT		02
26	0503011443	3/8" SPRING WASHER		04
27	0503010026	3/8" NUT		04
28	0511056586	15 X 15 SEED DDD LEFT		01
29	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
30	0503011440	SPRING WASHER		02




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0511057590	RH FERTILIZER ROW ARM	59	01
02	0521066715	VARAO SPRING ADB PHT4		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0511017302	FLAT WASHER		02
05	0521010445	0.53" X 0.75" X 0.45" SLEEVE		02
06	0503011336	1/2" HEX SELF ADJUSTING NUT		01
07	0501013753	FLAT WASHER		01
08	0502040534	SPRING GUIDE BUSHING LOCK		01
09	0501018535	1/2 X 1 BOLT		01
10	0503030609	1"X11.81"X 0.16" COMPRESSION SPRING		01
11	0503030917	1.6"X11.8"X 0.2" COMPRESSION SPRING		01
12	0502011538	SPRING GUIDE		01
13	0503010013	5/8" NUT		01
14	0511016281	3/4" X 8" BOLT		01
15	0521018797	0.7" X 1" X .55" SLEEVE		02
16	0511017232	FLAT WASHER		02
17	0503011255	3/4" LOCK NUT		01
18	0503030391	RIGHT FERTILIZER NOZZLE		01
19	0503030408	2X2X390 HOSE		01
20	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521063737	FERTILIZER ROW ARM		01
02	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	60	01
03	0511018662	SPACING PLATE		06
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	53	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	54	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511057592	LH FERTILIZER ROW ARM	62	01
02	0521066715	VARAO SPRING ADB PHT4		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0511017302	FLAT WASHER		02
05	0521010445	0.53" X 0.75" X 0.45" SLEEVE		02
06	0503011336	1/2" HEX SELF ADJUSTING NUT		01
07	0501013753	FLAT WASHER		01
08	0502040534	SPRING GUIDE BUSHING LOCK		01
09	0501018535	1/2 X 1 BOLT		01
10	0503030609	1"X11.81"X 0.16" COMPRESSION SPRING		01
11	0503030917	1.6"X11.8"X 0.2" COMPRESSION SPRING		01
12	0502011538	SPRING GUIDE		01
13	0503010013	5/8" NUT		01
14	0511016281	3/4" X 8" BOLT		01
15	0521018797	0.7" X 1" X .55" SLEEVE		02
16	0511017232	FLAT WASHER		02
17	0503011255	3/4" LOCK NUT		01
18	0503030392	LEFT FERTILIZER NOZZLE		01
19	0503030408	2X2X390 HOSE		01
20	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521063737	FERTILIZER ROW ARM		01
02	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	63	01
03	0511018662	SPACING PLATE		06
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	54	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	53	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02



Item	Code	Description	See page	QT
01	0501056428	16" CUTTING DISC SEMI-ASSEMBLED	65	01
02	0503013329	1/2" UNC X 4-3/4" BOLT		01
03	0511017302	FLAT WASHER		03
04	0503010060	1/2" NUT		01
05	0511057192	EXTENSION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0502011031	SPRING UPPER HITCH		02
06	0531012869	SUPPORT SPRING		01
07	0503011264	1/2" X 2-1/2" BOLT		01
08	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02



Item	Code	Description	See page	QT
01	0511063081	DISC BLADE SUPPORT		01
02	0502011279	DISC HUB		01
03	0503010215	30205 BEARING		02
04	0503010213	SEAL 30205		02
05	0511061647	BLADE DISC AXLE ASSY		01
06	0501068582	7/8" UNF WITH DUST CLOAK NUT		01
07	0603023013	DPL16X4,5 AFDJR80+6FR D224 TATU		01
08	0501013839	WASHER		01
09	0503010365	NUT		06
10	0503010179	LOCK WASHER		06
11	0503010337	5/16" NUT		06
12	0503010691	1/4" GREASE FITTING		01
13	0503010012	1" SPRING WASHER		02
14	0521013510	3/4" NUT		02
15	0511063073	DISC BLADE FIXER		01
16	0531012999	DISC BLADE FIXER AXLE		01
17	0503010361	SPRING PIN		01
18	0503010756	0.2" X 2.4" SPRING PIN		01
19	0503013185	3/4" X 5-1/2" BOLT		01
20	0521014321	ARTICULATION ARM REEL		01
21	0503010046	2-216 N 3006-9B O'RING		02
22	0511015346	FLAT WASHER		02
23	0503011255	3/4" LOCK NUT		01
24	0501010322	FLAT WASHER		01



MARCHESAN

Technical Publications | Elaboration and Revision

LORENA ROCHA ALVES

www.marchesan.com.br

