

ROW CROP PLANTERS

PST PLUS FLEX SUPREMA P.P - FRAME 3895 - CSU - DOUBLE HEADER

Code: 0501093217
Series: S-0116
Revision: 00
Date Revision: FEVEREIRO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0531041832	CABECALHO DUPLO 3895
0111390072	PST PLUS FLEX SUPREMA P.P - CHASSI 3895 - MESTRA
0111390073	PST PLUS FLEX SUPREMA P.P - CHASSI 3895 ESCRAVA

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909096147	PST PLUS FLEX SUPREMA P.P WITH DOUBLE HEADER	1
0531041832	DOUBLE HEAD OFFICE 3895	2
0909096148	PST PLUS FLEX SUPREMA P.P - FRAME 3895 - MASTER	3
0909096149	PST PLUS FLEX SUPREMA P.P - FREME 3895 - ESLAVE	4
0909096150	ASSY SEED/FERTILIZER ROW	5
0511059398	SEMI-ASSEMBLED DOUBLE HEADER	6
0909093876	FIXER SUPPORT BOLT HOSE	7
0909093873	HYDRAULIC CIRCUIT	8
0909093877	HYDRAULIC CIRCUIT TURBINE	9
0909093878	LIFTING HYDRAULIC CIRCUIT	10
0909093879	HYDRAULIC CIRCUIT ROW MARKER	11
0501053835	FEMALE QUICK COUPLER	12
0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	13
0511052464	FLOW DIVIDING VALVE	14
0501054694	FLOW DIVIDING VALVE ASSY	15
0501054061	SEQUENCE VALVE WITH NIPPLES	16
0501054862	AXIS LOCK RODE ASSY	17
0501054863	WELL AND TIRE ASSY	18
0503060414	WHEEL AND TIRE	19
0501051799	STUB SHAFT & HUB ASSY	20
0521027227	BOX WITH DOUBLE HEADING COMPONENTS 3895	21
0501040364	HOSE SUPPORT 3/4X640 ASSY	22
0511053179	TRACTOR HITCH AXLE	23
0501051160	TRACTOR HITCH PIN	24
0511056409	TRACTOR HITCH	25
0511034235	PACKED PIECES DOUBLE HEAD PACKAGE 3895	26
0531053573	CHASSIS WITH WHEEL AXLE 3895	27
0511058655	3245/3495/4045/4395 - CYLINDER ASSY	28
0521045510	HYDRAULIC CYLINDER 50,8 X 127 X 868,5 X 507,5	29
0511058653	ASSY TRACTION SPRING WHEEL	30
0511058654	WHEEL SUPPORT ASSY	31
0501058241	TENSIONER CHAIN SUPPORT	32
0511052770	WHEEL WITH TIRE 7.00X16 ASSY WHEELED BOX	33
0503062159	WHEEL	34
0511052769	WHEEL TRANSMISSION WITHOUT TIRE	35
0501058240	WHELL FASTENER WITH STRETCHER	36
0501058243	STRETCHER INTERMEDIATE RODE CURRENT	37
0501058239	CHAIN TENSIONER BEARING	38
0501058244	STRETCHER FIXED CURRENT	39
0501058242	MOVIL CHAIN TENSIONER	40
0531053586	TRANSMISSION SET FOR TIRE 7.00 - 3895	41
0501052560	AXLE MOTOR SLOW-MOVING ASSY	42
0511051434	TRANSMISSION DRIVING ASSY	43
0511047069	SIDE TRANSMISSION DRIVING	44
0511047070	LH SIDE TRANSMISSION DRIVING	45
0521055335	ASSY RECAMBIO RIGHT	46
0511058381	RIGHT RECAMBIO	47
0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	48
0501056271	BEARING CLOSED	49
0501048790	AXLE WITH LINK ASSY	50
0501056443	BEARING ASSY GEAR BOX	51
0501056444	BEARING WITH ROLLING	52
0531053561	FERTILIZER SILO SET - 3895	53
0531053563	SILO SUPPORT WITH DISTRIBUTOR - 3895	54
0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	55



MARCHESAN

INDEX


0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	56
0521055337	ASSY RECAMBIO LEFT	57
0511057258	GEAR WITH ADJUSTER	58
0511054363	CHAIN TENSIONER	59
0501053788	Q3/4" FASTENER AXLE ASSY	60
0511057265	TIGHTENER TRANSMISSION	61
0511050652	CHAIN TENSIONER	62
0501052810	TRANSMISSION CHAIN TENSIONER ASSY	63
0501053653	BEARING WITH 20Z GEAR	64
0511057266	ASSY SYSTEM HYDRAULIC	65
0531053571	PLATFORM SET - 3895	66
0511056536	ASSEMBLY LADDER	67
0511054971	RESTING ASSEMBLY	68
0511057333	ASSY HEADER 3495/4045/4395/4845/5345/5745	69
0531053585	LABEL SET - 3895	70
0511059322	SUPPORT ASSY	71
0531053581	HANDRAIL SET - 3895	72
0511059383	INTERNAL FIXER ASSY HANDLE	73
0511059323	SUPPORT PLATFORM	74
0511058827	ASSEMBLY CSU	75
0511058828	CSU ASSY	76
0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	77
0531053576	SUPREME MTH PP TURBINE SET - 3895	78
0511059887	TURBINE PRECISION PLANTING	79
0521050154	TURBINE P.P WITH HOLE	80
0531053559	RIGHT AIR CONDUCTOR 05 MOUTH 3895	81
0531053558	LEFT AIR CONDUCTOR 05 MOUTH 3895	82
0521052549	CLAMP	83
0909096151	ASSY HEX AXLE	84
0521055338	ROW SEED BEARING	85
0521057356	ROW SEED MONITOR	86
0511057270	DRAWBAR TURNBUCKLE	87
0511054601	FULL ARTICULATED TRACTOR HITCH	88
0521056505	MANUAL CANISTER ASSY	89
0511057817	SUPPORT HOSE	90
0531053593	TRANSMISSION SET 7.00 3895	91
0531053580	FULL CENTER LINE CHAIN STRETCH	92
0531053579	BEARING WITH GEAR 20Z CENTER LINE HEXAGONAL AXIS	93
0501053654	DOUBLE BEARING TRANSMISSION SEED 3/4	94
0531053560	SILO SET ADUBO LINHA CENTRAL 3895	95
0531053562	SUPT SILO WITH CENTRAL LINE DISTRIBUTOR 3895	96
0531053596	ASSEMBLY CSU 3895	97
0531053595	CSU 2CHANNEL SET	98
0531053577	TURBINE ASSEMBLY MTH SUPREME PP	99
0531053584	CENTRAL LINE FIXACAO SET	100
0531053582	ROLO BATTER COMPLETE LINE CENTRAL	101
0511057505	SEED ROW FRONT PNEUM PP SHORT WITH RIGHT REAR	102
0511057506	SEED ROW FRONT PNEUM PP LONG WITH RIGHT REAR	103
0511057276	TRANSMISSION SUPPORT RIGHT ASSY	104
0511057273	ASSEMBLY TRANSMISSION	105
0511058766	BEARING	106
0511057159	TRANSMISSION BOX SEED LINE	107
0511057269	CHAIN TENSIONER LINE	108
0511059190	BEARING DOBLE	109
0511059191	FRONT BEARING DOBLE	110




MARCHESAN

INDEX


0511058512	PROTECTION COVER	111
0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	112
0511052971	CONTROL DEPTH WITH SEMI MOUNTED THREAD	113
0511059325	LEFT ARM WHEELS	114
0511059324	RIGHT ARM COATING WHEEL MOUNTED	115
0511051546	CUBE RIGHT CONTROL DEPTH	116
0511051583	DEPTH WHEEL HUB SEMIFINISHED	117
0511051547	LEFT CUBE CONTROL DEPTH	118
0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	119
0501052908	COMPACTOR WHEEL WITH BEARING	120
0511055819	DEPTH WHIT AROS BAND	121
0521050064	SHORT FERTILIZER ROW	122
0521050065	LONG FERTILIZER ROW	123
0511058633	SHORT SUPPORT FIXED LINE FERTILIZER	124
0521050062	ARM SHORT LINE FERTILIZER	125
0521050061	18" WAVY COULTER BLADE ASSY	126
0511057544	ASSY TURBO CUTTING DISC (18)	127
0511057537	COULTER BLADE ASSY	128
0511058630	20 DISC CUT	129
0511058648	BOX WITH DISC BLADE 20	130
0511056909	DISC BOX CUT WITHOUT THE DISC	131
0511058634	SUPPORT LONG	132
0511057271	RH LONG ARM ROW FERTILIZER	133
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	134
0511053173	CUBE LOW RIGHT WITH DISC 15	135
0511053172	LEFT LOW CUBE WITH DISC 15	136
0521050063	RH LONG ARM ROW FERTILIZER	137
0511057115	REAR LEFT SEED LINE PRECISION PLANTING CSU 3	138
0511057108	RIGHT REAR SEED ROW PRECISION PLANTING CSU 3	139
0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	140
0511057155	PRECISION PLANTING LEFT TRANSMISSION BOX	141
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	142
0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT PROTECTION	143
0511057154	DDD RITGH SUPREMA PRECISION PLANTING	144
0501110804	ROD SCARIFIER SPINDLE WIHT POINT	145
0521057957	FIXED ROD EXTENSION WITH FIXATION	146
0521050525	FIXER FERTILIZER CONDUCTOR	147



Item	Code	Description	See page	QT
01	0531041832	DOUBLE HEAD OFFICE 3895	2	01
02	0909096148	PST PLUS FLEX SUPREMA P.P - FRAME 3895 - 3 MASTER		01
03	0909096149	PST PLUS FLEX SUPREMA P.P - FREME 3895 - 4 ESLAVE		01




Item	Code	Description	See page	QT
01	0511059398	SEMI-ASSEMBLED DOUBLE HEADER	6	01
02	0501054863	WELL AND TIRE ASSY	18	02
03	0521027227	BOX WITH DOUBLE HEADING COMPONENTS 3895	21	01




Item	Code	Description	See page	QT
01	0531053573	CHASSIS WITH WHEEL AXLE 3895	27	01
02	0503010003	1845 GREASE FITTING		06
03	0511058655	3245/3495/4045/4395 - CYLINDER ASSY	28	01
04	0511058653	ASSY TRACTION SPRING WHEEL	30	04
05	0531053586	TRANSMISSION SET FOR TIRE 7.00 - 3895	41	01
06	0531053561	FERTILIZER SILO SET - 3895	53	01
07	0511057266	ASSY SYSTEM HYDRAULIC	65	01
08	0581013729	NIPLE 1/2 NPT		01
09	0531053571	PLATFORM SET - 3895	66	01
10	0511056536	ASSEMBLY LADDER	67	02
11	0511054971	RESTING ASSEMBLY	68	02
12	0511057333	ASSY HEADER 3495/4045/4395/4845/5345/5745	69	01
13	0531053585	LABEL SET - 3895	70	01
14	0511059322	SUPPORT ASSY	71	02
15	0531053581	HANDRAIL SET - 3895	72	04
16	0511059323	SUPPORT PLATFORM	74	04
17	0511058827	ASSEMBLY CSU	75	01
18	0531053576	SUPREME MTH PP TURBINE SET - 3895	78	01
19	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		04
20	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
21	0511017302	FLAT WASHER		08
22	0503010019	1/2" SPRING WASHER		08
23	0503010060	1/2" NUT		08
24	0909096151	ASSY HEX AXLE	84	01
25	0521057356	ROW SEED MONITOR	86	01
26	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	13	01
27	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		02
28	0501065677	STRUT		02
29	0511057270	DRAWBAR TURNBUCKLE	87	01
30	0511054601	FULL ARTICULATED TRACTOR HITCH	88	01
31	0503034867	AIR DITRIBUTOR PUMP		04

Item	Code	Description	See page	QT
32	0503014120	CHAIN		01
33	0503014321	CABLE STEEL SHACKLE		02
34	0521056505	MANUAL CANISTER ASSY	89	01
35	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
36	0511053179	TRACTOR HITCH AXLE	23	01
37	0521013022	TRANSPORT LOCK		02
38	0501068994	0.3" X 3.1"LOCK PIN		02
39	0503030168	HAIR PIN		02
40	0511057817	SUPPORT HOSE	90	01
41	0501047895	ROD STOP		02
42	0501047885	ROD STOP		02
43	0501047886	ROD STOP		02
44	0501047886	ROD STOP		02
45	0503032624	SILO FERTILIZER GUTTER		06
46	0503010246	CLAMP		09
47	0503010780	N-2050 AMENDMENT		02
48	0503010951	REDUCTION		04
49	0503011751	REDUCTION		06
50	0503011750	AMENDMENT WITH LOCK		06
51	0503010045	O'RING		01
52	0541010080	TERMINAL R.1 / 2 NPT		01
53	0571017368	SUPPORT GUTTER		06
54	0571014383	GUTTER		01
55	0501011643	3/8 X 1"BOLT		06
56	0501010984	FLAT WASHER		06
57	0503010025	3/8" SPRING WASHER		06
58	0503010026	3/8" NUT		06
59	0909096150	ASSY SEED/FERTILIZER ROW	5	01




Item	Code	Description	See page	QT
01	0531053573	CHASSIS WITH WHEEL AXLE 3895	27	01
02	0503010003	1845 GREASE FITTING		06
03	0511058655	3245/3495/4045/4395 - CYLINDER ASSY	28	01
04	0511058653	ASSY TRACTION SPRING WHEEL	30	04
05	0531053593	TRANSMISSION SET 7.00 3895	91	01
06	0531053560	SILO SET ADUBO LINHA CENTRAL 3895	95	01
07	0511057266	ASSY SYSTEM HYDRAULIC	65	01
08	0581013729	NIPLE 1/2 NPT		01
09	0531053571	PLATFORM SET - 3895	66	01
10	0511056536	ASSEMBLY LADDER	67	02
11	0511054971	RESTING ASSEMBLY	68	02
12	0511057333	ASSY HEADER 3495/4045/4395/4845/5345/5745	69	01
13	0531053585	LABEL SET - 3895	70	01
14	0511059322	SUPPORT ASSY	71	02
15	0531053581	HANDRAIL SET - 3895	72	04
16	0511059323	SUPPORT PLATFORM	74	04
17	0531053596	ASSEMBLY CSU 3895	97	01
18	0531053577	TURBINE ASSEMBLY MTH SUPREME PP	99	01
19	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		04
20	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
21	0511017302	FLAT WASHER		08
22	0503010019	1/2" SPRING WASHER		08
23	0503010060	1/2" NUT		08
24	0909096151	ASSY HEX AXLE	84	01
25	0521057356	ROW SEED MONITOR	86	01
26	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	13	01
27	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		02
28	0501065677	STRUT		02
29	0511057270	DRAWBAR TURNBUCKLE	87	01
30	0511054601	FULL ARTICULATED TRACTOR HITCH	88	01
31	0503034867	AIR DITRIBUTOR PUMP		04

Item	Code	Description	See page	QT
32	0503014120	CHAIN		01
33	0503014321	CABLE STEEL SHACKLE		02
34	0521056505	MANUAL CANISTER ASSY	89	01
35	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
36	0511053179	TRACTOR HITCH AXLE	23	01
37	0521013022	TRANSPORT LOCK		02
38	0501068994	0.3" X 3.1"LOCK PIN		02
39	0503030168	HAIR PIN		02
40	0511057817	SUPPORT HOSE	90	01
41	0501047895	ROD STOP		02
42	0501047885	ROD STOP		02
43	0501047886	ROD STOP		02
44	0501047886	ROD STOP		02
45	0503032624	SILO FERTILIZER GUTTER		06
46	0503010246	CLAMP		09
47	0503010780	N-2050 AMENDMENT		02
48	0503010951	REDUCTION		04
49	0503011751	REDUCTION		06
50	0503011750	AMENDMENT WITH LOCK		06
51	0503010045	O'RING		01
52	0541010080	TERMINAL R.1 / 2 NPT		01
53	0531053584	CENTRAL LINE FIXACAO SET	100	01
54	0531053582	ROLO BATTER COMPLETE LINE CENTRAL	101	01
55	0571014383	GUTTER		01
56	0571017368	SUPPORT GUTTER		06
57	0501011643	3/8 X 1"BOLT		06
58	0501010984	FLAT WASHER		06
59	0503010025	3/8" SPRING WASHER		06
60	0503010026	3/8" NUT		06
61	0909096150	ASSY SEED/FERTILIZER ROW	5	01



Item	Code	Description	See page	QT
01	0511057505	SEED ROW FRONT PNEUM PP SHORT WITH RIGHT REAR	102	05
02	0511057506	SEED ROW FRONT PNEUM PP LONG WITH RIGHT REAR	103	04
03	0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	112	10
04	0521050064	SHORT FERTILIZER ROW	122	05
05	0521050065	LONG FERTILIZER ROW	123	05
06	0511057115	REAR LEFT SEED LINE PRECISION PLANTING CSU 3	138	06
07	0511057108	RIGHT REAR SEED ROW PRECISION PLANTING CSU 3	139	06
08	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
09	0503010905	1/2" X 2-1/4" BOLT		02
10	0503010019	1/2" SPRING WASHER		02
11	0503010060	1/2" NUT		02
12	0503031145	2" X 2" X 20" HOSE		10
13	0503031076	2" HOSE CLAMP		20
14	0531013600	PRESS ADJUSTMENT LEVER		01
15	0501110804	ROD SCARIFIER SPINDLE WIHT POINT	145	09
16	0521069127	BOTTOM NOZZLE FERTILIZER		09
17	0503031050	CURVED CONDUCTOR		09
18	0511017969	0.1" SPACING PLATE		18
19	0511018662	SPACING PLATE		18
20	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		09
21	0501010984	FLAT WASHER		18
22	0503010025	3/8" SPRING WASHER		09
23	0503010026	3/8" NUT		09
24	0521067360	PROTRACTOR CPRA		09
25	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		09
26	0511058877	REGULATORY KEY		01
26A	0521066800	BODY REGULATORY KEY		01

Item	Code	Description	See page	QT
26B	0503030878	LEVER CRANK		01
27	0521057957	FIXED ROD EXTENSION WITH FIXATION	146	04
28	0503030520	SEED SOCKET		09
29	0571011730	SEED CONDUCTOR 3X1500		09
30	0521050525	FIXER FERTILIZER CONDUCTOR	147	18




Item	Code	Description	See page	QT
01	0511064305	FRAME HEADER DOUBLE		01
02	0511064219	FORK WHEEL DRAWBAR DOUBLE		02
03	0503010007	3982/3920 ROLLER BEARING		02
04	0503010059	33287/33462 ROLLER BEARING		02
05	0503013106	SEAL 00085-B		02
06	0502040080	FLANGE NUT R.2.1/2 UN		02
07	0503011345	1/4" X 3-1/2" COTTERPIN		02
08	0541013225	WHEEL BOX COVER		02
09	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		12
10	0503011444	SPRING WASHER		12
11	0503010002	1800 GREASE FITTING		03
12	0909093876	FIXER SUPPORT BOLT HOSE	7	04
13	0909093873	HYDRAULIC CIRCUIT	8	01
14	0531017560	DISPLAYED IDENTIFICATION		08
15	0502012702	BODY SUPPORT CLAMP		09
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		09
17	0503010180	7/16" SPRING WASHER		09
18	0501053835	FEMALE QUICK COUPLER	12	08
19	0503010217	501040 CLAMPING RING (FOR AXLE)		16
20	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	13	04
21	0501054061	SEQUENCE VALVE WITH NIPPLES	16	01
22	0503010237	3/8" X 1" BOLT		02
23	0503010025	3/8" SPRING WASHER		02
24	0503010026	3/8" NUT		02
25	0501054862	AXIS LOCK RODE ASSY	17	02
26	0511066114	CONDUCTOR VALVE SUPPORT DOUBLE HEADER		01
26.	0521063568	SUPPORT VALVE		01
27	0501054694	FLOW DIVIDING VALVE ASSY	15	01
28	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
29	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
30	0503010143	1/4" SPRING WASHER		02




PST PLUS FLEX SUPREMA P.P - FRAME 3895 - CSU - DOUBLE
SEMI-ASSEMBLED DOUBLE HEADER

Page 6
0511059398


Item	Code	Description	See page	QT
31	0503010144	1/4" NUT		02
32	0503062157	HEADER JACK		01
33	0521010549	COUPLING SHAFT		01
34	0503030168	HAIR PIN		01
35	0511052464	FLOW DIVIDING VALVE	14	01
36	0503010001	3.2 X 5.5 RIVET		04




Item	Code	Description	See page	QT
01	0511064222	FIXER SUPPORT BOLT HOSE		02
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2" NUT		04
05	0502012702	BODY SUPPORT CLAMP		06
06	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
07	0503010180	7/16" SPRING WASHER		04




Item	Code	Description	See page	QT
01	0909093877	HYDRAULIC CIRCUIT TURBINE	9	01
02	0909093878	LIFTING HYDRAULIC CIRCUIT	10	01
03	0909093879	HYDRAULIC CIRCUIT ROW MARKER	11	01
04	0521065376	HEADER DOUBLE		01
05	0909093876	FIXER SUPPORT BOLT HOSE	7	02
06	0511066114	CONDUCTOR VALVE SUPPORT DOUBLE HEADER		01
07	0501053835	FEMALE QUICK COUPLER	12	08
08	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	13	04




Item	Code	Description	See page	QT
01	0521063568	SUPPORT VALVE		01
02	0511052464	FLOW DIVIDING VALVE	14	01
03	0501080512	1/2" X 1400 TR-TM HOSE		06
03.	0501080072	1/2" X 63" TR-TM HOSE ASSY		06
04	0501080185	HOSE 1/2 X 4000 TR-TM		03
05	0909093876	FIXER SUPPORT BOLT HOSE	7	02
06	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	13	03
07	0501053835	FEMALE QUICK COUPLER	12	06




Item	Code	Description	See page	QT
01	0521063568	SUPPORT VALVE		01
02	0501054694	FLOW DIVIDING VALVE ASSY	15	01
03	0501080796	1/2" X 1400 TC-TM HOSE		04
03.	0501080335	1/2" X 63" TC-TM HOSE ASSY		04
04	0501080185	HOSE 1/2 X 4000 TR-TM		02
05	0909093876	FIXER SUPPORT BOLT HOSE	7	02
06	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	13	02
07	0501053835	FEMALE QUICK COUPLER	12	04




Item	Code	Description	See page	QT
01	0521063568	SUPPORT VALVE		01
02	0501054061	SEQUENCE VALVE WITH NIPPLES	16	01
03	0501080440	HOSE 3/8 X 1350 TR-TM		04
04	0501080678	HOSE 1/2 X 3800 TC-TM		02
05	0909093876	FIXER SUPPORT BOLT HOSE	7	02
06	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	13	02
07	0501053835	FEMALE QUICK COUPLER	12	04




Item	Code	Description	See page	QT
01	0503011883	QUICK CONNECTION COVER		01
02	0503011628	FEMALE QUICK COUPLER		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0503013791	DOUBLE MOTOR		01
02	0541018940	7/8 NF X R 1 BSPT X 55 NIPPLE		01
03	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
04	0503010025	3/8" SPRING WASHER		04
05	0503011051	M10 X 0.6" NUT		04




Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503030923	3/4" UNF X 13/16UN OFS X 40 NIPPLE		03
03	0503010190	2-114 N 3006-9B O'RING		03




Item	Code	Description	See page	QT
01	0501011460	7/8 NF REDUCTION NIPPLE		02
02	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0511064229	LOCK PIN		01
02	0503030978	COMPRES SPRING		01
03	0503010131	3/16" X 1-1/2" COTTERPIN		01
04	0503010292	0.2" X 1.6" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503060414	WHEEL AND TIRE	19	01
02	0501051799	STUB SHAFT & HUB ASSY	20	01
03	0531015109	WHEEL AXLE LOCK		02




Item	Code	Description	See page	QT
01	0503012108	WHEEL 10 LB X 15 X 8F X 203		01
02	0503010860	AIR CHAMBER 11L 15		01
03	0503011469	RIB TIRE BL - 12L		01




Item	Code	Description	See page	QT
01	0502010908	CARRYING WHEEL HUB	01	
02	0503012159	4.0" X 2.5" X 0.5" SEAL 5144	01	
03	0503010008	3780/3720 ROLLER BEARING	01	
04	0503010328	25590/25523 ROLLER BEARING	01	
05	0503012162	5046 BAG SEAL RING	01	
06	0521011209	425 TRANSP WHEEL AXLE	01	
07	0511015949	LOCK NUT	01	
08	0503010329	LOCK WASHER	01	
09	0503010330	KM 9 LOCKNUT	01	
10	0501010086	FLAT WASHER	01	
11	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR	08	
12	0503010064	5/8 UNF CONIC NUT	08	
13	0503011052	1.1/4" X 0.77" CASTLE NUT	02	
14	0503010067	3/16" X 2.1/2" COTTER PIN	02	




Item	Code	Description	See page	QT
01	0501100160	WOODEN BOX 2450X1050X920		01
02	0521014754	FIXING BASE ESTABILIZER		02
03	0521067307	STABILITY FIXER		02
04	0501110262	245 ADJUSTMENT NUT		01
05	0511064217	TURNBUCKLE WITH EAR		02
06	0521066236	EXTENDER WITH SLEEVE R.1.1/2 X 490 LEFT		01
07	0501061056	RH LOCKNUT WITH HANDLER		02
08	0501068300	TURNBUCKLE WITH EAR		02
09	0521066235	EXTENDER WITH SLEEVE R.1.1/2 X 490 RIGHT		01
10	0501069529	653 TURNBUCKLE		02
11	0501066284	SUPPORT FRONT TURNBUCKLE FIXER		02
12	0521012329	3/4 UNC X 130 X 173 FASTENER		02
13	0501040364	HOSE SUPPORT 3/4X640 ASSY	22	01
14	0501080779	1/2 X 1500 TM-TM HOSE		02
15	0501054862	AXIS LOCK RODE ASSY	17	02
16	0511053179	TRACTOR HITCH AXLE	23	01
17	0501051160	TRACTOR HITCH PIN	24	02
18	0511056409	TRACTOR HITCH	25	01
19	0571017510	GLOVE ARTICULATED HITCH		01
20	0511064220	COUPLING SUPPORT DOUBLE DRAWBAR		02
21	0511034235	PACKED PIECES DOUBLE HEAD PACKAGE 3895	26	01
22	0511031535	BAG WITH INSTRUCTION MANUAL		01
23	0503014120	CHAIN		01
24	0503014321	CABLE STEEL SHACKLE		02
25	0521067935	FIXER PLATE		02



Item	Code	Description	See page	QT
01	0501060409	HOSE SOPPORT ASSY		01
02	0503011442	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HAIR PIN		01




Item	Code	Description	See page	QT
01	0521010681	BUSHING COUPLING BODY		01
02	0502040556	HITCH TURNER		01
03	0521010639	COUPLING SHAFT		01
04	0503010571	1/4" X 1.1/2 COTTERPIN		01

TRACTOR HITCH


0511056409




Item	Code	Description	See page	QT
01	0571017512	HITCH JOINT		01
02	0571017511	SLEEVE HITCH ARTICULATION		01
03	0502040850	U TRACTOR COUPLING		01
04	0571012612	PIVOT SHAFT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503016482	BOLT		02
11	0503033731	COMPRESSION SPRING LEFT		02
12	0503011331	3/8 BALL		02
13	0503010002	1800 GREASE FITTING		01
14	1882970002	GREASE SOAP		01
15	0503010378	CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0501014172	1" X 8" BOLT		08
02	0503010797	3/4" X 4" BOLT		08
03	0503010023	3/4" SPRING WASHER		08
04	0503010012	1" SPRING WASHER		08
05	0503010027	5/8" SPRING WASHER		04
06	0503010014	3/4" NUT		08
07	0503010013	5/8" NUT		04
08	0501010059	1.5/8 NUT		08
09	0521010594	1.1" X 4.1" COUPLING SHAFT		06
10	0503031035	HAIR PIN		06
11	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	13	02
12	0501053835	FEMALE QUICK COUPLER	12	02




Item	Code	Description	See page	QT
01	0531063240	CHASSIS - 3895		01
02	0531063242	ARTICULATOR WHEEL AXLE 3895		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0501012140	FLAT WASHER		16
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08



Item	Code	Description	See page	QT
01	0521045510	HYDRAULIC CYLINDER 50,8 X 127 X 868,5 X 507,5	29	01
02	0551014099	COUPLING SHAFT 31,75 X 185		01
03	0521010547	1.2" X 6.5" COUPLING SHAFT		01
04	0503010523	1/4" X 2" COTTERPIN		02
05	0501047888	ROD STOP		01




Item	Code	Description	See page	QT
01	0521065976	SHIRT 127 X 438,5		01
02	0581013698	PISTON		01
03	0521067585	EXTENDER 50.80 X 371.5 WITH BUSHING		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010003	1845 GREASE FITTING		01
06	0503030385	CYLINDER PLUG N-002		02
07	0503018439	WIPER SEAL		01
08	0503018150	RING GUIDE		01
09	0502010382	5" END CAP		01
10	0581010353	RING SUPPORT		01
11	0503018026	1870-2000-375 B GASKET		01
12	0503011453	O'RING		02
13	0503018152	O'RING		02
14	0503018024	RING BS		01
15	0503018025	RING GUIDE		01
16	0503010039	D-2000 SCRAPER RING		01
17	0503010173	2-220 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0511058654	WHEEL SUPPORT ASSY	31	01
02	0501058240	WHELL FASTENER WITH STRETCHER	36	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01

WHEEL SUPPORT ASSY


0511058654




Item	Code	Description	See page	QT
01	0521066716	WHEEL ARM ASSY		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
08	0503010027	5/8" SPRING WASHER		01
09	0501058241	TENSIONER CHAIN SUPPORT	32	01
10	0503013030	5/8" X 3.1/4" BOLT		01
11	0551017715	FLAT WASHER		02
12	0511052770	WHEEL WITH TIRE 7.00X16 ASSY WHEELED BOX	33	01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8" SPRING WASHER		02
15	0503011167	M16 X 2 X 30 BOLT		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL	34	01
02	0511052769	WHEEL TRANSMISSION WITHOUT TIRE	35	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSM AXLE CARRYING-WHEEL		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	STRETCHER INTERMEDIATE RODE CURRENT	37	01
07	0501058244	STRETCHER FIXED CURRENT	39	01
08	0501058242	MOVIL CHAIN TENSIONER	40	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING	38	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01



Item	Code	Description	See page	QT
01	0551018252	CHAIN TIGHTENER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING	38	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN UPPER AXLE		01
02	0501058239	CHAIN TENSIONER BEARING	38	01
03	0591017923	GLOVE 15.30 X 30 X 32		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2" NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2" NUT		16
12	0501058241	TENSIONER CHAIN SUPPORT	32	04
13	0501211933	ENGINE AXLE - 1875		02
14	0501018466	FLAT WASHER		02
15	0501052560	AXLE MOTOR SLOW-MOVING ASSY	42	02
16	0511051434	TRANSMISSION DRIVING ASSY	43	04
17	0511047069	SIDE TRANSMISSION DRIVING	44	01
18	0511047070	LH SIDE TRANSMISSION DRIVING	45	01
19	0521055335	ASSY RECAMBIO RIGHT	46	01
20	0521055337	ASSY RECAMBIO LEFT	57	01
21	0511061759	22Z P12,70 FQ 3/4" GEAR		02
22	0501053788	Q3/4" FASTENER AXLE ASSY	60	02
23	0503030303	SUPPORT WASHER		04
24	0501056271	BEARING CLOSED	49	02
25	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
26	0501010984	FLAT WASHER		08
27	0503010025	3/8" SPRING WASHER		04
28	0503010026	3/8" NUT		04
29	0511057265	TIGHTENER TRANSMISSION	61	02
30	0521010773	0.37" X 1.18" COUPLING SHAFT		02
31	0501010984	FLAT WASHER		06


Item	Code	Description	See page	QT
32	0503010140	1/8" X 3/4" COTTERPIN		02
33	0571018846	DISASSEMBLE LEVER		02
34	0503033942	COVER REGULATORY WHEEL		02
35	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
36	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
37	0503030093	TRACTION SPRING		02
38	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
39	0503012412	5/8 UNC SELF LOCKING NUT		04
40	0511061759	22Z P12,70 FQ 3/4" GEAR		02
41	0503030275	AGRICULTURAL BEARING		02
42	0503010292	0.2" X 1.6" SPRING PIN		02
43	0521018630	1.4" X SQUARE 0.8" WASHER		02
44	0501052810	TRANSMISSION CHAIN TENSIONER ASSY	63	02
45	0511050652	CHAIN TENSIONER	62	04
46	0501053653	BEARING WITH 20Z GEAR	64	02
47	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
48	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
49	0503013149	40-1 CHAIN X 157 LINK + MENDING + RED		02
50	0531062318	LEFT/RIGHT LOWER LEVER		02
51	0551019159	LEVER FIXER BODY		02
52	0561016468	FASTENER		02
53	0503011336	1/2" HEX SELF ADJUSTING NUT		04
54	0503010140	1/8" X 3/4" COTTERPIN		04
55	0511064536	28Z GEAR		02




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	5/16" X 3/4" BOLT		02
03	0503010179	5/16" ZN SPRING WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ETIQUETA ADHESIVA		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0511058381	RIGHT RECAMBIO	47	01
02	0521065955	RH GEAR BOX COVER		01
03	0503010240	5/16" X 3/4" BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0503010019	1/2" SPRING WASHER		01
07	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
08	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521065939	RH GEAR BOX		01
02	0511060396	DRIVE/DRIVEN AXLE CONE		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2" NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	BEARING DOUBLE CENTRAL ASSY EXCHANGE	48	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	BEARING CLOSED	49	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
14	0503010179	5/16" ZN SPRING WASHER		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TENSIONER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH LINK ASSY	50	02
20	0503031366	RIGHT TWISTED SPRING RECAMBIO		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	BEARING ASSY GEAR BOX	51	01
31	0503010292	0.2" X 1.6" SPRING PIN		08




Item	Code	Description	See page	QT
32	0511057258	GEAR WITH ADJUSTER	58	01
33	0511054363	CHAIN TENSIONER	59	01
34	0571018901	DRIVEN AXLE		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	52	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531053563	SILO SUPPORT WITH DISTRIBUTOR - 3895	54	01
02	0503062391	SILO FERTILIZER 05 MOUTHS		02
03	0571019051	FIXER BOX WASHER		16
04	0503013751	3/8 UNC X 1.1/4 BOLT		16
05	0503012535	3/8" SPRING WASHER		16
06	0503012531	3/8" INOX NUT		16
07	0503011957	NYLON LUG		02
08	0503010371	5/16" X 1" BOLT		04
09	0503010179	5/16" ZN SPRING WASHER		04
10	0503010337	5/16" NUT		04
11	0503034396	FERTILIZER SIDE COVER		10
12	0503010362	1/8" X 1.1/4" COTTERPIN		10
13	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
14	0501010984	FLAT WASHER		20
15	0503010025	3/8" SPRING WASHER		10
16	0503010026	3/8" NUT		10




Item	Code	Description	See page	QT
01	0531063232	FERTILIZER SILOS SUPPORT - 3895		01
02	0511051535	FERTILIZER DISTRIBUTOR RIGHT SIDE STEP 2	55	05
03	0511051558	DISTRIBUTOR FERTILIZER SIDE LEFT STEP 2	56	05
04	0501010942	3/8" X 1-1/4" BOLT		40
05	0503011443	3/8" SPRING WASHER		40
06	0503010026	3/8" NUT		40
07	0503030275	AGRICULTURAL BEARING		10
08	0551018055	22,65 X 60 SLEEVE		04
09	0501053788	Q3/4" FASTENER AXLE ASSY	60	06
10	0511061759	22Z P12,70 FQ 3/4" GEAR		02
11	0503030303	SUPPORT WASHER		04
12	0501056271	BEARING CLOSED	49	02
13	0571018896	SQUARE SHAFT		02
14	1902010685	18Z CONICAL GEAR		10
15	0503011953	5/16" X 1" BOLT		04
16	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
17	0503011444	SPRING WASHER		04
18	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICAL CONDUTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0511058382	LEFT RECAMBIO		01
02	0521065956	LH GEAR BOX COVER		01
03	0503010240	5/16" X 3/4" BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0511017302	FLAT WASHER		01
07	0503010019	1/2" SPRING WASHER		01
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0571019207	DEVIATION AXLE GEAR BOX		01
06	0503010899	5/8" X 2-1/4" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		03
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551019171	CHAIN TIGHTENER AXLE		01
02	0503011410	ROLLER BEARING		01
03	0511062169	21Z P 1/2" GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503011105	SEAL RING		01
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0571010265	16.5 X 40 X 3 FLAT WASHER		01
08	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0541011713	TENSIONER CHAIN LOWER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501053654	DOUBLE BEARING TRANSMISSION SEED 3/4	94	01
02	0511063185	20Z GEAR WITH HEX HOLE AXLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010365	NUT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0511057267	HOSE KIT HYDRAULIC		01
01A	0501080722	3/8 X 3300 TC-TM HOSE ASSY		01
01B	0501082023	HOSE 3/8 X 3600 TC-TM		01
02	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	13	02
03	0503013100	NYLON CLAMP		02
04	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0501211900	PLATFORM - 3895		02
02	0503010237	3/8" X 1" BOLT		06
03	0501010984	FLAT WASHER		12
04	0503010025	3/8" SPRING WASHER		06
05	0503010026	3/8" NUT		06




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012806	SUPPORT REAR FIXER DRAWBAR		04
02	0502012789	FIXER SUPPORT FERTILIZER ROW		04
03	0503017960	5/8" X 3-12" BOLT		16
04	0503010811	5/8" UNF SELF ADJUSTING NUT		16
05	0501010191	1" X 6" BOLT		04
06	0503010012	1" SPRING WASHER		04
07	0501010059	1.5/8 NUT		04
08	0502012805	SUPPORT FRONT FIXER DRAWBAR		04
09	0502012789	FIXER SUPPORT FERTILIZER ROW		04
10	0503017960	5/8" X 3-12" BOLT		16
11	0503010811	5/8" UNF SELF ADJUSTING NUT		16
12	0521065958	DRAWBAR		01
13	0561019087	DRAWBAR TRANSPORT LOCK		01
14	0551014099	COUPLING SHAFT 31,75 X 185		01
15	0521010544	1.2" X 4.9" COUPLING SHAFT		01
16	0503030085	LOCK PIN		02
17	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503033892	ADHESIVE LABEL LOGO TATU BOX 190 X 720	01	
02	0503034226	LABEL ADHESIVE	02	
03	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 MOUTH)	02	
04	0503034257	ADHESIVE LABEL	01	
05	0503033417	ADHESIVE LABEL	02	
06	0503033422	ADHESIVE LABEL	02	
07	0503033423	LABEL ADHESIVE NUMBER 9	02	
08	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
09	0503031428	READ MANUAL DECAL	01	
10	0503031942	ADHESIVE LABEL	01	
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
12	0503031565	ADHESIVE LABEL CARE	02	
13	0503031566	ADHESIVE LABEL	02	
14	0503034249	ADHESIVE LABEL TABLE PLANTS	02	
15	0503031425	ADHESIVE LABEL ATTENTION	02	
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503032930	ADHESIVE LABEL DANGER	05	
19	0503031087	ADHESIVE LABEL	01	
20	0503034003	SERIAL NUMBER TAG 61 X 118	01	
21	0503010001	3.2 X 5.5 RIVET	04	
22	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
23	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521067033	CONJ SUPT		01
03	0503017960	5/8" X 3-12" BOLT		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
02	0511017302	FLAT WASHER		08
03	0503010019	1/2" SPRING WASHER		08
04	0503010060	1/2" NUT		08
05	0511059383	INTERNAL FIXER ASSY HANDLE	73	04
06	0531063244	HANDRAIL WITH DEGREE - 3895		02
07	0581012642	REAR HANDRAIL REFERENCE		02




Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01




Item	Code	Description	See page	QT
01	0581011989	SIDE BODY FIXER PLATFORM		01
02	0551019884	45 X 50 X 3/8 FASTENER		01
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0501010984	FLAT WASHER		02
07	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0511058828	CSU ASSY	76	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0571019393	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16
15	0521066211	PROTECTOR CENTRAL		01
16	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
17	0501013519	FLAT WASHER		04
18	0503010019	1/2" SPRING WASHER		04
19	0503010060	1/2" NUT		04



Item	Code	Description	See page	QT
01	0521064748	05 MOUTHS CSU SUPPORT		02
02	0503061987	SILO FERTILIZER 05 MOUTHS FRONT MOUNTED		02
03	0521063401	SEED BOX ONLY FIXING LOCK		04
04	0501010984	FLAT WASHER		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	77	09
08	0501010942	3/8" X 1-1/4" BOLT		36
09	0503010025	3/8" SPRING WASHER		36
10	0503010026	3/8" NUT		36
11	0571015773	SUPPORT SEED CSU		01
12	0501011643	3/8 X 1"BOLT		04
13	0503010025	3/8" SPRING WASHER		04
14	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
09	0503010179	5/16" ZN SPRING WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01




Item	Code	Description	See page	QT
01	0571019403	STAPLE FIXER		04
02	0503010019	1/2" SPRING WASHER		04
03	0503010060	1/2" NUT		04
04	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
05	0581012111	RIGHT SUPPORT		01
06	0581012112	LEFT SUPPORT		01
07	0511059887	TURBINE PRECISION PLANTING	79	01
08	0503011372	102 TO 121 CLAMP		06
09	0503010025	3/8" SPRING WASHER		08
10	0503010026	3/8" NUT		08
11	0503013584	VACUUM GAUGE		01
12	0531053559	RIGHT AIR CONDUCTOR 05 MOUTH 3895	81	01
13	0531053558	LEFT AIR CONDUCTOR 05 MOUTH 3895	82	01
14	0521052549	CLAMP	83	18
15	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		09
16	0503034867	AIR DITRIBUTOR PUMP		01
17	0503010243	CLAMP		01
18	0571013731	VACUUM GAUGE SUPPORT		01
19	0581012166	HOSE		02
20	0511057846	ASSY HOSE KIT		01
20A	0511057847	ASSY HOSE TURBINE		01
20AA	0521052531	3/8 X 6108 TC-TM HOSE YELLOW / GREEN		01
20AAA	0501080850	3/8" X 6100 TC-TM HOSE		01
20AAB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
20AAC	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
20AAD	0503018952	PLASTIC BOLT		06
20AB	0521052528	1/2 X 6200 TC-TM HOSE YELLOW / RED		01
20ABA	0501081810	HOSE 1/2 X 6200 TC-TM		01
20ABB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
20ABC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20ABD	0503018952	PLASTIC BOLT		06


Item	Code	Description	See page	QT
20AC	0521052529	1/2 X 6200 TC-TM HOSE YELLOW / BLUE		01
20ACA	0501081810	HOSE 1/2 X 6200 TC-TM		01
20ACB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
20ACC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
20ACD	0503018952	PLASTIC BOLT		06
20B	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	13	02
20C	0581012991	SPRING PROTECTION PLASTIC HOSE		01
20D	0503033981	ADHESIVE LABEL		01
20E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01




Item	Code	Description	See page	QT
01	0521050154	TURBINE P.P WITH HOLE	80	01
02	0503015420	VALVE ANTI-CAVITACAO CV10208TN5		01
03	0501011460	7/8 NF REDUCTION NIPPLE		04
04	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
05	0503010392	2-046 N 3006 9B O'RING		01
06	0503010190	2-114 N 3006-9B O'RING		04
07	0501080218	1/2 X 750 HOSE		01
08	0581012096	ROUND SLEEVE		02
09	0503031087	ADHESIVE LABEL		01
10	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01




Item	Code	Description	See page	QT
01	0511057036	AIR DISTRIBUTOR BOARD		01
01A	0503012567	T-JOIN FOR TUBE 110		01
01B	0581013890	SOCKET DISTRIBUTOR AR		01
02	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		02
02A	0503034763	AIR DITRIBUTOR PUMP		01
02B	0503015341	POP RIVET		02
03	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		05
03A	0503034812	SOCKET DISTRIBUTOR AR		01
03B	0503012856	POP RIVET		04
04	0591016994	AIR CONDUCTOR BODY 02 MOUTH		01
05	0591014350	AIR CONDUCTOR BODY 3 MOUTH		01




Item	Code	Description	See page	QT
01	0511057036	AIR DISTRIBUTOR BOARD		01
01A	0503012567	T-JOIN FOR TUBE 110		01
01B	0581013890	SOCKET DISTRIBUTOR AR		01
02	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		02
02A	0503034763	AIR DITRIBUTOR PUMP		01
02B	0503015341	POP RIVET		02
03	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		05
03A	0503034812	SOCKET DISTRIBUTOR AR		01
03B	0503012856	POP RIVET		04
04	0591016994	AIR CONDUCTOR BODY 02 MOUTH		01
05	0591014350	AIR CONDUCTOR BODY 3 MOUTH		01




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0521055338	ROW SEED BEARING	85	06
02	0511054314	TRANSMISSION AXLE ASSY TRANSMISSION GLOVE		24
02A	0502012699	LATCH GLOVE BOX TRANSMISSION		01
02B	0503010256	3/8" X 3/4" BOLT		01
03	0561018832	3/4" X 1830 HEX AXLE		01
04	0531013213	3/4" X 79" HEX AXLE		01




Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	BEARING SEED LINE		01
03A	0502012030	HOUSING BEARING		01
03B	0503012861	6006 2RS BALL BEARING		01
03C	0503012858	502075 CLAMPING RING (FOR HOLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	5/16" ZN SPRING WASHER		02
06	0503010337	5/16" NUT		02
07	0501013518	FLAT WASHER		02
08	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503063097	KIT MONITORING SEED		01
01A	0503017602	MONITOR PLANT PM400		01
01B	0503017606	APEX EXTENSION CABLE		01
01C	0503016556	10 ROW SIMPLE MONITOR CABLE		01
01D	0503017443	ANTENNA GPS PM 400		01
01E	0503019100	SENSOR		10
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		30
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		**
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521065959	JACK R.1.1/2 UNC RIGHT X 240		01
03	0521065960	JACK R.1.1/2 UNC LEFT X 240		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01



Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	8.5 X 18 X 1.5 FLAT WASHER		01
05	0503010179	5/16" ZN SPRING WASHER		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2" NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2" NUT		16
12	0501058241	TENSIONER CHAIN SUPPORT	32	04
13	0501211933	ENGINE AXLE - 1875		02
14	0501018466	FLAT WASHER		02
15	0501052560	AXLE MOTOR SLOW-MOVING ASSY	42	02
16	0511051434	TRANSMISSION DRIVING ASSY	43	04
17	0511047069	SIDE TRANSMISSION DRIVING	44	01
18	0511047070	LH SIDE TRANSMISSION DRIVING	45	01
19	0521055335	ASSY RECAMBIO RIGHT	46	01
20	0521055337	ASSY RECAMBIO LEFT	57	01
21	0511061759	22Z P12,70 FQ 3/4" GEAR		02
22	0501053788	Q3/4" FASTENER AXLE ASSY	60	02
23	0503030303	SUPPORT WASHER		04
24	0501056271	BEARING CLOSED	49	02
25	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
26	0501010984	FLAT WASHER		08
27	0503010025	3/8" SPRING WASHER		04
28	0503010026	3/8" NUT		04
29	0511057265	TIGHTENER TRANSMISSION	61	02
30	0521010773	0.37" X 1.18" COUPLING SHAFT		02
31	0501010984	FLAT WASHER		06


Item	Code	Description	See page	QT
32	0503010140	1/8" X 3/4" COTTERPIN		02
33	0571018846	DISASSEMBLE LEVER		02
34	0503033942	COVER REGULATORY WHEEL		02
35	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
36	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
37	0503030093	TRACTION SPRING		02
38	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
39	0503012412	5/8 UNC SELF LOCKING NUT		04
40	0511061759	22Z P12,70 FQ 3/4" GEAR		02
41	0503030275	AGRICULTURAL BEARING		02
42	0503010292	0.2" X 1.6" SPRING PIN		02
43	0521018630	1.4" X SQUARE 0.8" WASHER		02
44	0501052810	TRANSMISSION CHAIN TENSIONER ASSY	63	02
45	0531053580	FULL CENTER LINE CHAIN STRETCH	92	04
46	0531053579	BEARING WITH GEAR 20Z CENTER LINE HEXAGONAL AXIS	93	02
47	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
48	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
49	0503013149	40-1 CHAIN X 157 LINK + MENDING + RED		02
50	0531062318	LEFT/RIGHT LOWER LEVER		02
51	0551019159	LEVER FIXER BODY		02
52	0561016468	FASTENER		02
53	0503011336	1/2" HEX SELF ADJUSTING NUT		04
54	0503010140	1/8" X 3/4" COTTERPIN		04
55	0511064536	28Z GEAR		02




Item	Code	Description	See page	QT
01	0551019171	CHAIN TIGHTENER AXLE		01
02	0503011410	ROLLER BEARING		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0503011105	SEAL RING		01
05	0501012140	FLAT WASHER		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01
07	0501010163	5/8" X 4-1/2" BOLT		01
08	0521069698	GEAR 21Z P 1/2		01




Item	Code	Description	See page	QT
01	0501053654	DOUBLE BEARING TRANSMISSION SEED 3/4	94	01
02	0511063185	20Z GEAR WITH HEX HOLE AXLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010179	5/16" ZN SPRING WASHER		02
05	0503010337	5/16" NUT		02
06	0501010694	8.5 X 18 X 1.5 FLAT WASHER		04
07	0501013518	FLAT WASHER		02
08	0503010421	5/16" X 1-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		02
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0531053562	SUPT SILO WITH CENTRAL LINE DISTRIBUTOR 96 3895		01
02	0503062391	SILO FERTILIZER 05 MOUTHS		02
03	0571019051	FIXER BOX WASHER		16
04	0503013751	3/8 UNC X 1.1/4 BOLT		16
05	0503012535	3/8" SPRING WASHER		16
06	0503012531	3/8" INOX NUT		16
07	0503011957	NYLON LUG		02
08	0503010371	5/16" X 1" BOLT		04
09	0503010179	5/16" ZN SPRING WASHER		04
10	0503010337	5/16" NUT		04
11	0503034396	FERTILIZER SIDE COVER		10
12	0503010362	1/8" X 1.1/4" COTTERPIN		10
13	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
14	0501010984	FLAT WASHER		20
15	0503010025	3/8" SPRING WASHER		10
16	0503010026	3/8" NUT		10






Item	Code	Description	See page	QT
01	0531053595	CSU 2CHANNEL SET	98	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0571019393	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16
15	0521066211	PROTECTOR CENTRAL		01
16	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
17	0501013519	FLAT WASHER		04
18	0503010019	1/2" SPRING WASHER		04
19	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521064748	05 MOUTHS CSU SUPPORT		02
02	0503061987	SILO FERTILIZER 05 MOUTHS FRONT MOUNTED		02
03	0521063401	SEED BOX ONLY FIXING LOCK		04
04	0501010984	FLAT WASHER		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	SEED CONDUCTOR 3 ARTICULATED ASSY CSU	77	10
08	0501010942	3/8" X 1-1/4" BOLT		40
09	0503010025	3/8" SPRING WASHER		40
10	0503010026	3/8" NUT		40




Item	Code	Description	See page	QT
01	0571019403	STAPLE FIXER		04
02	0503010019	1/2" SPRING WASHER		04
03	0503010060	1/2" NUT		04
04	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
05	0581012111	RIGHT SUPPORT		01
06	0581012112	LEFT SUPPORT		01
07	0511059887	TURBINE PRECISION PLANTING	79	01
08	0503011372	102 TO 121 CLAMP		06
09	0503010025	3/8" SPRING WASHER		08
10	0503010026	3/8" NUT		08
11	0503013584	VACUUM GAUGE		01
12	0531053559	RIGHT AIR CONDUCTOR 05 MOUTH 3895	81	01
13	0531053558	LEFT AIR CONDUCTOR 05 MOUTH 3895	82	01
14	0521052549	CLAMP	83	20
15	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		10
16	0571013731	VACUUM GAUGE SUPPORT		01
17	0581012166	HOSE		02
18	0511057846	ASSY HOSE KIT		01
18A	0511057847	ASSY HOSE TURBINE		01
18AA	0521052531	3/8 X 6108 TC-TM HOSE YELLOW / GREEN		01
18AAA	0501080850	3/8" X 6100 TC-TM HOSE		01
18AAB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
18AAC	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
18AAD	0503018952	PLASTIC BOLT		06
18AC	0521052528	1/2 X 6200 TC-TM HOSE YELLOW / RED		01
18ACA	0501081810	HOSE 1/2 X 6200 TC-TM		01
18ACB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
18ACC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
18ACD	0503018952	PLASTIC BOLT		06
18AD	0521052529	1/2 X 6200 TC-TM HOSE YELLOW / BLUE		01
18ADA	0501081810	HOSE 1/2 X 6200 TC-TM		01


Item	Code	Description	See page	QT
18ADB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
18ADC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
18ADD	0503018952	PLASTIC BOLT		06
18B	0501053834	MALE QUICK COUPLER WITH CAP - 1/2 NPT	13	02
18C	0581012991	SPRING PROTECTION PLASTIC HOSE		01
18D	0503033981	ADHESIVE LABEL		01
18E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01



Item	Code	Description	See page	QT
01	0581012644	CENTRAL LINE PLATFORM		01
02	0581012643	HANDRAIL BODY WITH DEGREE - 3495		02
03	0581012718	HANDRAIL		02
04	0511059383	INTERNAL FIXER ASSY HANDLE	73	04
05	0581012642	REAR HANDRAIL REFERENCE		02
06	0521067259	SIDE FERTILIZER LINE SUPPORT		01
07	0521067258	SIDE SEED LINE SUPPORT		01
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
09	0511017302	FLAT WASHER		04
10	0503010019	1/2" SPRING WASHER		04
11	0503010060	1/2" NUT		04
12	0503010237	3/8" X 1" BOLT		04
13	0501010984	FLAT WASHER		04
14	0503010025	3/8" SPRING WASHER		06
15	0503010026	3/8" NUT		06
16	0503012412	5/8 UNC SELF LOCKING NUT		07
17	0503013736	SCREW 5/8 UNF X 1.1/2 CS G.5 ZN		03
18	0503010849	3/8" X 1-1/2" BOLT		02
19	0501013518	FLAT WASHER		04
20	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
21	0501012140	FLAT WASHER		04
22	0521055338	ROW SEED BEARING	85	01



Item	Code	Description	See page	QT
01	0521067609	ROLLER FIXING SUPPORT	01	
02	0581013750	JOINT GLOVE	01	
03	0521067608	ROLLER GUIDE AXIS	01	
04	0581013747	ROLLING GLOVE	02	
05	0503010002	1800 GREASE FITTING	01	
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN	04	
07	0501012140	FLAT WASHER	08	
08	0503012412	5/8 UNC SELF LOCKING NUT	08	
09	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548	04	
10	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN	01	
11	0503010027	5/8" SPRING WASHER	01	
12	0581013749	SQUARE WASHER	01	
13	0531063247	CENTER LINE SLIDING PLATE	01	




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		02
03	0503017857	BOLT 5/8 UNF 4		04
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8 UNC SELF LOCKING NUT		04
08	0502012804	PIVOT ARM SEED ROW		02
09	0571018882	SLEEVE ARM LINE SEED		08
10	0503010002	1800 GREASE FITTING		04
11	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
12	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
13	0571018883	PIN FIXER SPRING		03
14	0571018884	LOCK PIN ROW ARTICULAT		01
15	0503030168	HAIR PIN		04
16	0511057276	TRANSMISSION SUPPORT RIGHT ASSY	104	01
17	0521065943	REAR FRAME LONG ROW SEED		01
18	0511057269	CHAIN TENSIONER LINE	108	01
19	0511057507	TRANSMISSION LOWER FRONT		01
19A	0511059190	BEARING DOBLE	109	01
19B	0581010976	5/8" HEX AXLE		01
19C	0503010300	5/32" X 1" COTTERPIN		01
19D	0501056296	UNIVERSAL JOINT		01
19E	0503011855	0.2" X 1.8" SPRING PIN		02
19F	0561014794	350 AXLE HEX		01
20	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
21	0581011694	PROTECTION REAR COVER SEED ROW		01
22	0503010765	3/8" X 3" BOLT		01
23	0503010025	3/8" SPRING WASHER		01
24	0503010026	3/8" NUT		01
25	0511058512	PROTECTION COVER	111	01
26	0581011430	DRAWBAR ASSY		01



PST PLUS FLEX SUPREMA P.P - FRAME 3895 - CSU - DOUBLE
SEED ROW FRONT PNEUM PP SHORT WITH RIGHT REAR

Page 102
0511057505

Item	Code	Description	See page	QT
27	0521064369	HOSE HOLDER		01
28	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		02
03	0503017960	5/8" X 3-12" BOLT		04
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8 UNC SELF LOCKING NUT		04
08	0502012804	PIVOT ARM SEED ROW		02
09	0571018882	SLEEVE ARM LINE SEED		08
10	0503010002	1800 GREASE FITTING		04
11	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
12	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
13	0571018883	PIN FIXER SPRING		03
14	0571018884	LOCK PIN ROW ARTICULAT		01
15	0503030168	HAIR PIN		04
16	0511057276	TRANSMISSION SUPPORT RIGHT ASSY	104	01
17	0521066158	FRAME REAR LONG ROW SEED		01
18	0511057269	CHAIN TENSIONER LINE	108	01
19	0511057508	TRANSMISSION LOWER FRONT		01
19A	0511059190	BEARING DOBLE	109	01
19B	0581010976	5/8" HEX AXLE		01
19C	0503010300	5/32" X 1" COTTERPIN		02
19D	0501056296	UNIVERSAL JOINT		01
19E	0503011855	0.2" X 1.8" SPRING PIN		02
19F	0561014794	350 AXLE HEX		01
20	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
21	0581011694	PROTECTION REAR COVER SEED ROW		01
22	0503010765	3/8" X 3" BOLT		01
23	0503010025	3/8" SPRING WASHER		01
24	0503010026	3/8" NUT		01
25	0511058512	PROTECTION COVER	111	01
26	0581011430	DRAWBAR ASSY		01




PST PLUS FLEX SUPREMA P.P - FRAME 3895 - CSU - DOUBLE
SEED ROW FRONT PNEUM PP LONG WITH RIGHT REAR


Page 103
0511057506

Item	Code	Description	See page	QT
27	0521064369	HOSE HOLDER		01
28	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511058766	BEARING	106	01
02	0511057273	ASSEMBLY TRANSMISSION	105	01
03	0503010300	5/32" X 1" COTTERPIN		01







Item	Code	Description	See page	QT
01	0502012852	ROW SEED UPPER BEARING		01
02	0503011105	SEAL RING		01
03	0502012851	17Z GEAR WITH HEX HOLE		01
04	0503011410	ROLLER BEARING		02
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010237	3/8" X 1" BOLT		02
07	0503010025	3/8" SPRING WASHER		02
08	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB	01	
02	0502012464	BOX TRANSMISSION COVER	01	
03	0503016995	6006 BALL BEARING	02	
04	0503015895	6005 Z BALL BEARING	01	
05	0503010143	1/4" SPRING WASHER	03	
06	0503011378	M6X1X16 C S 8.8 ZN BOLT	03	
07	0503010406	501025 CLAMPING RING (FOR AXLE)	01	
08	0503010707	501030 CLAMPING RING (FOR AXLE)	02	
09	0502040856	CONICAL GEAR	01	
10	0571018870	14Z CONICAL GEAR	01	
11	0503011105	SEAL RING	01	
12	0503011409	6005 Z BALL BEARING	01	
13	0503017008	SEAL RING	01	
14	0503017007	SEAL RING	02	
15	0511017907	1/8" BSPT X 6 PLUG	01	
16	0503010003	1845 GREASE FITTING	01	
17	0503035316	LUBRICATED POINTS ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503031805	11Z 1/2" GEAR		01
02	0511017302	FLAT WASHER		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0511059191	FRONT BEARING DOBLE	110	01
02	0502012851	17Z GEAR WITH HEX HOLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
06	0503010179	5/16" ZN SPRING WASHER		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521066693	CAP BEARING		01
02	0503010834	1/2 X 1 BOLT		02
03	0503010019	1/2" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0511052971	CONTROL DEPTH WITH SEMI MOUNTED THREAD	113	01
02	0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	119	01
03	0501052908	COMPACTOR WHEEL WITH BEARING	120	02
04	0503010019	1/2" SPRING WASHER		06
05	0503010752	1/2" X 3.1/2" BOLT		01
06	0503013739	1/2" X 1" BOLT		01
07	0503010479	BOLT		02
08	0503010060	1/2" NUT		04
09	0503030012	HAIR PIN		01
10	0571013222	FIXING CHOCK		01
11	0503010741	1/2" X 2-3/4" BOLT		02
12	0511055819	DEPTH WHIT AROS BAND	121	02
13	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
14	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0521063808	DEPTH CONTROL INNER COLUMN CONTROL WITH SCREW		01
02	0521063809	DEPTH CONTROL EXTERNAL COLUMN CONTROL WITH SCREW		01
03	0571013194	REGULATOR SPINDLE		01
04	0551010616	ROD HEX		01
05	0503010683	0,2" X 1,2" SPRING PIN		01
06	0571013202	REGULATOR AXLE WHEELS COBRIDORA		01
07	0521063812	REGULATOR LEVER ALXE		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		01
09	0511065308	LOCK REGULATOR		01
10	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
11	0541011627	FLAT WASHER		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0511059325	LEFT ARM WHEELS	114	01
14	0511059324	RIGHT ARM COATING WHEEL MOUNTED	115	01
15	0571014709	SLEEVE LOCK CONTROL ARM		02
16	0503011440	SPRING WASHER		03
17	0503819099	BOLT		02
18	0511051546	CUBE RIGHT CONTROL DEPTH	116	01
19	0511051547	LEFT CUBE CONTROL DEPTH	118	01
20	0503011442	3/4" SPRING WASHER		02
21	0571013189	SLEEVE SUPPORT BEATER		01
22	0521063813	WHEEL PRESS BEATER		01
23	0501010937	13.5 X 28 X 3 FLAT WASHER		01
24	0503010920	1/2" X 1.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502012844	LEFT ARM WHEELS		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	GLOVE SUPPORT ARM WHEEL COBRIDORA		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012843	RIGHT WHEEL ARM		01
02	0581011340	ARM COVER		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	GLOVE SUPPORT ARM WHEEL COBRIDORA		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051583	DEPTH WHEEL HUB SEMIFINISHED	117	01
02	0511066638	AXLE WHEEL RIGHT DEPTH WITH DOOR DUST		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	COVER DEPTH		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0502011907	DEPTH CONTROL WHEEL HUB		01
02	0503010269	6204 BALL BEARING		02
03	0501013636	SPACING SLEEVE		01
04	0503010689	SEAL 00763-BR		01
05	0503011105	SEAL RING		01
06	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051583	DEPTH WHEEL HUB SEMIFINISHED	117	01
02	0511066637	AXLE WHEEL LEFT DEPTH WITH DOOR DUST		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	COVER DEPTH		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0502012850	PRESS WHEELS ARM		01
02	0503030883	RIGHT TORSION SPRING		01
03	0502011066	PRESS WHEELS ARM SUPPORT		01
04	0531017415	1" X 4.72" AXLE JOINT		01
05	0503010839	03"X 0.6" SPRING PIN		01
06	0521063841	REGULATOR RIGHT COMPACTOR		01
07	0521063842	REGULATOR LEFT COMPACTOR		01
08	0503811404	BOLT		02
09	0503011443	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0571013295	ALXE REGULATOR COMPACTOR		01
12	0521063812	REGULATOR LEVER ALXE		01
13	0503011336	1/2" HEX SELF ADJUSTING NUT		02
14	0511065308	LOCK REGULATOR		01
15	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
16	0541011627	FLAT WASHER		01
17	0503010140	1/8" X 3/4" COTTERPIN		01
18	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW		01
19	0503811172	BOLT		01
20	0503010002	1800 GREASE FITTING		01
21	0581013744	PROTECTION COVER - CPRA		01
22	0503813096	BOLT		01
23	0503013816	5/16" LOCKNUT		0




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05




Item	Code	Description	See page	QT
01	0511058633	SHORT SUPPORT FIXED LINE FERTILIZER	124	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	SLEEVE ARM LINE		02
04	0503011255	3/4" LOCK NUT		02
05	0521050062	ARM SHORT LINE FERTILIZER	125	01
06	0511058630	20 DISC CUT	129	01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	132	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	SLEEVE ARM LINE		02
04	0503011255	3/4" LOCK NUT		02
05	0521050063	RH LONG ARM ROW FERTILIZER	137	01
06	0511058630	20 DISC CUT	129	01




Item	Code	Description	See page	QT
01	0502012794	SHORT SUPPORT FERTILIZER ROW	01	
02	0503011854	5/8" X 1-1/4" BOLT	02	
03	0503010002	1800 GREASE FITTING	01	
04	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
05	0503017960	5/8" X 3-12" BOLT	04	
06	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
07	0521066744	FERTILIZER ROW ADJUSTMENT SPRING	01	
08	0571019062	SLEEVE	01	
09	0571019059	SUPPORT WASHER	01	
10	0503010417	7/8" NUT	04	
11	0503034320	COMPRESSION SPRING	01	
12	0502012813	FLANGE WASHER SPRING	01	




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0521050061	18" WAVY COULTER BLADE ASSY	126	01
03	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0511057544	ASSY TURBO CUTTING DISC (18)	127	01
02	0571019645	CONDUCTOR SUPPORT		01
03	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
04	0521018517	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	0503030483	FERTILIZER SOCKET		01




Item	Code	Description	See page	QT
01	0571019636	UPPER SLEEVE		02
02	0571019637	RIGHT ARM		01
03	0571019638	LEFT ARM		01
04	0511057537	COULTER BLADE ASSY	128	01
05	0521015376	DUST CLOAK		02
06	0511015346	FLAT WASHER		02
07	0503011438	SPRING WASHER		02
08	0521013510	3/4" NUT		02




Item	Code	Description	See page	QT
01	0521013610	BLADE DISC HUB AXLE		01
02	0502011562	DC BOX		01
03	0503011800	SEAL RING		02
04	0503012417	SEAL		02
05	0503010276	6206 BALL BEARING		02
06	0503030832	FLAT WASHER		02
07	0503011444	SPRING WASHER		06
08	0503010691	1/4" GREASE FITTING		01
09	0503010337	5/16" NUT		06
10	0502020641	BLADE DISC FLANGE		01
11	0503010371	5/16" X 1" BOLT		06
12	0607025032	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0571018989	LH BLADE DISC ARM		01
02	0502012790	LOCK NUT		01
03	0511058648	BOX WITH DISC BLADE 20	130	01
04	0521065978	RIGHT ARM WITH WASHER LOCK		01
05	0571019035	SLEEVE SUPPORT ARM		01
06	0521010452	SLEEVE		01
07	0521066743	REGULACION SPRING		01
08	0503010417	7/8" NUT		04
09	0571019033	FIXATION AXLE		01
10	0503034319	LOCK PIN		01
11	0502012813	FLANGE WASHER SPRING		01
12	0503034320	COMPRESSSION SPRING		01
13	0571019032	SUPPORT WASHER		01
14	0571019034	FLANGE WASHER AXLE		02
15	0503010002	1800 GREASE FITTING		01
16	0503013185	3/4" X 5-1/2" BOLT		01
17	0503011255	3/4" LOCK NUT		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503011440	SPRING WASHER		01
20	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511056909	DISC BOX CUT WITHOUT THE DISC	131	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0502012793	DC PST		01
02	0571018047	CUTTING DISC BOX SHAFT		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DOOR DUST		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	8.5 X 18 X 1.5 FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	132	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	SLEEVE ARM LINE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057271	RH LONG ARM ROW FERTILIZER	133	01
06	0511058629	18" COULTER BLADE ASSY FOR SHORT ROW		01




Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	134	01
07	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	135	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	136	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWR DDD		01




Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
02	0521050061	18" WAVY COULTER BLADE ASSY	126	01
03	0503010706	SCREW 1/2 UNC X 4.1/2 C S G.5 ZN		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2" NUT		02



Item	Code	Description	See page	QT
01	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA 140 CSU 3		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT SUPREMA PRECISION PLANTING		01




Item	Code	Description	See page	QT
01	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	140	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	DDD RITGH SUPREMA PRECISION PLANTING	144	01




Item	Code	Description	See page	QT
01	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
02	0571017899	PIN LOCK PP		01
03	0503030190	0.5" X 1.6" X 0.05" SPRING		01
04	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
05	0511057155	PRECISION PLANTING LEFT TRANSMISSION BOX	141	01
06	0571017894	PIN DRAG PRECISION PLANTING		01
07	0503013357	3/8" SELF-ADJUSTING NUT		01
08	0501013518	FLAT WASHER		02
09	0503015356	SPRING PIN		01
10	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
11	0571017895	PIN FIXER CONDUCTOR P.P		01
12	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
13	0503010293	BAQUELITE MANIPULACION		02
14	0503010140	1/8" X 3/4" COTTERPIN		02
15	0503010131	3/16" X 1-1/2" COTTERPIN		01
16	0503010025	3/8" SPRING WASHER		02
17	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
18	0501011643	3/8 X 1"BOLT		01
19	0503010209	3/8" UNC BUTTERFLY NUT		01
20	0502012807	SUPPORT BOX PRECISION PLANTING		01
21	0571019489	CLAMP PRECISION PLANTING		01
22	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
23	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	142	01
24	0561014778	HEX UNIVERSAL JOINT		01
25	0503013958	1/4" X 1" BOLT		02
26	0503011855	0.2" X 1.8" SPRING PIN		01
27	0503012721	1/4" X 4" BOLT		01
28	0503012880	1/4" UNC SELF ADJUSTING NUT		04
29	0571014024	FAST BOLT GUIDE AXLE		01
30	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02


Item	Code	Description	See page	QT
31	0503015110	M06 SPRING WASHER		02
32	0503818139	BOLT		03
33	0503037390	PACKING FOR PLANTING		01
34	0503015752	3/8" X 2" BOLT		01
35	0503034824	FIXATIVE		01
36	0581011226	FIXER CLOSING P PLANTING CONTR CPRA		01
37	0503010337	5/16" NUT		04
38	0503010179	5/16" ZN SPRING WASHER		04
39	0503011953	5/16" X 1" BOLT		03
40	0503012163	5/16" X 1-1/2" BOLT		01
41	0521066707	FEEDER		01




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION BOX PP		01
02	0502050053	RIGHT SIDE TRANSMISSION BOX PP		01
03	0503011410	ROLLER BEARING		02
04	0503011182	6203 ROLLER BEARING		02
05	0503011184	502040 CLAMPING RING (FOR AXLE)		01
06	0571017655	SLEEVE FIXER HITCH PNEUMATIC		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
08	0503010144	1/4" NUT		03
09	0511057504	JOIN GEAR		01
09A	0571017898	BODY GEAR TRANSMISSION		01
09B	0503011769	M8 X 0.5" BOLT		01
10	0581011222	PINION AXLE 6Z PNEUMATIC		01
11	0503034340	PINION AXLE 6Z PNEUMATIC		01




Item	Code	Description	See page	QT
01	0571019613	STRAW PRECISION PLANTING SHIELD		01
02	0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT PROTECTION	143	01




Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	136	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	CUBE LOW RIGHT WITH DISC 15	135	01
04	0503010026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501010984	FLAT WASHER		02
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012780	SUPPORT DDD RIGHT		01
11	0511015098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01



Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02



Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	8.5 X 18 X 1.5 FLAT WASHER		02
04	0503010365	NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

