

ROW CROP PLANTERS

**PST4 - FRAME 4045/4495 - WITH ELEVATION
(FROM 04/2022)**

Code: 0501093285
Series: S-0116
Revision: 00
Date Revision: MAIO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111151259	PST4 4045/9E450 ELEV CI MH DC20 S-0116
0111151251	PST4 4495/9E500 ELEV CI S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909096266	ASSY FRAME	1
0501058195	FRAME WITH AXLE WHEEL - 4045	2
0511050836	WHEEL AXLE FRAME - 4495	3
0511057124	CYLINDER ASSY	4
0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	5
0521043934	CARRYING WHEELS SPRING TRACTION	6
0501058240	WHEEL FASTENER WITH TENSIONER	7
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	8
0501058244	WHEEL FIXED CHAIN TENSIONER	9
0501058242	WHEEL MOBILE CHAIN TENSIONER	10
0501059909	CARRYING WHEELS SUPPORT	11
0511052770	WHEEL WITH TIRE	12
0503062159	WHEEL WITH TIRE	13
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	14
0501058241	WHEEL SUPPORT CHAIN TENSIONER	15
0511058597	RIGHT TRANSMISSION ASSY - 4045	16
0511058970	RIGHT TRANSMISSION ASSY - 4495	17
0511058598	LEFT TRANSMISSION ASSY - 4045	18
0511058971	LEFT TRANSMISSION ASSY - 4495	19
0501052560	MOTOR AXLE SIGNAL	20
0511051434	TRANSMISSION ACTUATOR	21
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	22
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	23
0521043316	RIGHT GEAR BOX ASSY	24
0521043317	LEFT GEAR BOX ASSY	25
0501058212	SEMI MOUNTED RIGHT CHANGE	26
0501058213	LH GEAR BOX	27
0511059266	CLOSED BEARING	28
0501056271	GEARBOX CLOSED BEARING	29
0501056443	GEAR HOUSING BEARING	30
0501056444	BEARING WITH ROLLING	31
0501048790	AXLE WITH RING	32
0501054655	CHAIN TENSIONER ASSY	33
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	34
0511054363	CHAIN TENSIONER	35
0501058234	LOWER CHAIN TENSIONER	36
0501058235	STRETCHER CURRENT TOP SEED 17Z	37
0501058236	BEARING WITH 21Z GEAR	38
0501058237	16Z GEAR BEARING	39
0501055112	MICRO GRANULATED CHAIN TENSIONER	40
0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	41
0501053834	MALE QUICK COUPLER	42
0511057128	SET SUPPORT RIGHT LEFT	43
0511057564	SET SUPPORT RIGHT LEFT	44
0511053240	RIGHT SILO SUPPORT WITH DISTRIBUTOR 10	45
0511053241	LEFT SILO SUPPORT WITH DISTRIBUTOR 10	46
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	47
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	48
0511057129	PLATFORM ASSY - 4045	49
0511057565	PLATFORM ASSY - 4495	50
0511057130	HANDRAIL ASSY - 4045	51
0511057566	HANDRAIL ASSY - 4495	52
0511056536	LADDER ASSEMBLY	53
0511054971	JACK ASSEMBLY	54
0511057142	ASSY HEADER - 3245/3695/4045/4495	55




MARCHESAN

INDEX

0511057131	MANUAL CANISTER ASSY	56
0909099234	HEX AXLE ASSEMBLY	57
0909098921	ASSY HEX AXLE	58
0511057133	LABEL ASSY FOR HYDRAULIC MARKER - 4045	59
0511058969	LABEL ASSY - 4495	60
0501054258	DRAWBAR ESTABILIZER ASSY	61
0511054601	HITCH ARTICULATED TRACTOR	62
0511053179	TRACTOR COUPLING SHAFT	63
0511056736	HOSE SUPPORT	64
0511058368	EAR MOVABLE	65
0501058170	SEMI-ASSEMBLED HYDRAULIC MARKER 4045/9	66
0511058449	HYDRAULIC CYLINDER	67
0501054649	HBM SEQUENTIAL VALVE	68
0511057095	HYDRAULIC MARKER HOSE KIT	69
0501050633	ROW MARKER DISK ASSEMBLY	70
0511053904	ROW MARKER DISC	71
0909096267	ASSY SEED/FERTILIZER ROW	72
0531054196	HIGH SHORT SEED ROW	73
0531054195	HIGH LONG SEED ROW	74
0521052840	SHORT PIVOTING HIGH LINE	75
0511059244	ROD SPRING LINE SEED	76
0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	77
0511052024	FAST CLOSING SET	78
0511051693	BASE FIXING SYSTEM	79
0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	80
0531053925	SIGMA SOY INDIVIDUAL SEED SYSTEM	81
0531051514	SIGMA SOY SEED SYSTEM	82
0511057289	ASSY SEED DEFLECTOR	83
0503063602	SEMI-ASSEMBLED SIGMA INDIVIDUAL SEED BOX	84
0521052841	LONG PIVOTANT HIGH LINE	85
0511056586	15 X 15 SEED DDD LEFT	86
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	87
0511052301	SUPPORT DDD 15 RIGHT	88
0511052302	LH SUPPORT DDD GUIDE	89
0511053173	CUBE LOW RIGHT WITH DISC 15	90
0511053172	LEFT LOW CUBE WITH DISC 15	91
0521053154	FERTILIZER SHORT HIGH ROW WITH LEFT DDD/18" DC	92
0521053153	FERTILIZER LONG HIGH ROW WITH RIGHT DDD/18" DC	93
0521052636	FERTILIZER SHORT HIGH ROW WITH LEFT DDD/20" DC	94
0521052637	FERTILIZER LONG HIGH ROW WITH RIGHT DDD/20" DC	95
0521053152	ARM SHORT LINE FERTILIZER WITH DDD LEFT	96
0521053151	ARM LONG FERTILIZER LINE WITH DDD RIGHT	97
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	98
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	99
0511058617	DISC CUT 18 SHORT LINE	100
0511058618	DISC CUT 18 LONG LINE	101
0511058619	DISC CUT 20 SHORT LINE	102
0511058620	DISC CUT 20 LONG LINE	103
0511056909	DISC BOX CUT WITHOUT THE DISC	104
0511056910	BOX WITH DISC CUT 18	105
0511058648	BOX WITH DISC BLADE 20	106
0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	107
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	108
0511058650	SEMI-MOUNTED DEPTH CONTROL	109
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	110


INDEX

0501052627	ASSY DEPTH WHEEL BOX		111
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE		112
0501052297	DEPTH WHEELS REGULATOR ASSY		113
0501052538	DEPTH BAND WITH ARMS		114
0511054333	COMPACT WHEEL RIGHT WITH BEARING		115
0511054334	COMPACT WHEEL LEFT WITH BEARING		116
0501052908	COMPACTOR WHEEL WITH BEARING		117
0501110804	SCARIFIER ROD WITH POINT		118
0503063647	SIGMA CORN DISC SET		119
0503063648	SIGMA SOY DISC SET		120




Item	Code	Description	See page	4045	4495
01	0501058195	FRAME WITH AXLE WHEEL - 4045	2	01	00
01.	0511050836	WHEEL AXLE FRAME - 4495	3	00	01
02	0503010003	1845 GREASE FITTING		04	04
03	0511057124	CYLINDER ASSY	4	01	01
04	0521043934	CARRYING WHEELS SPRING TRACTION	6	04	04
05	0511058597	RIGHT TRANSMISSION ASSY - 4045	16	01	00
05.	0511058970	RIGHT TRANSMISSION ASSY - 4495	17	00	01
06	0511058598	LEFT TRANSMISSION ASSY - 4045	18	01	00
06.	0511058971	LEFT TRANSMISSION ASSY - 4495	19	00	01
07	0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	41	01	01
08	0511057128	SET SUPPORT RIGHT LEFT	43	01	00
08.	0511057564	SET SUPPORT RIGHT LEFT	44	00	01
09	0511057129	PLATFORM ASSY - 4045	49	01	00
09.	0511057565	PLATFORM ASSY - 4495	50	00	01
10	0511057130	HANDRAIL ASSY - 4045	51	01	00
10.	0511057566	HANDRAIL ASSY - 4495	52	00	01
11	0511056536	LADDER ASSEMBLY	53	02	02
12	0511054971	JACK ASSEMBLY	54	02	02
13	0511057142	ASSY HEADER - 3245/3695/4045/4495	55	01	01
14	0511057131	MANUAL CANISTER ASSY	56	01	01
15	0909099234	HEX AXLE ASSEMBLY	57	01	00
15.	0909098921	ASSY HEX AXLE	58	00	01
16	0501065677	STRUT		02	02
17	0501054258	DRAWBAR ESTABILIZER ASSY	61	01	01
18	0511054601	HITCH ARTICULATED TRACTOR	62	01	01
19	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01
20	0511053179	TRACTOR COUPLING SHAFT	63	01	01
21	0521013022	TRANSPORT LOCK		01	01
22	0501068994	0.3" X 3.1" LOCK PIN		01	01
23	0503030168	CUPILLA		01	01
24	0503014120	CHAIN		01	01


Item	Code	Description	See page	4045	4495
25	0503014321	CABLE STEEL SHACKLE		02	02
26	0511056736	HOSE SUPPORT	64	01	01
27	0501047895	ROD STOP		01	01
28	0501047885	ROD STOP		01	01
29	0501047886	ROD STOP		01	01
30	0501047887	ROD STOP		01	01
31	0503032624	SILO FERTILIZER GUTTER		05	05
32	0503010780	N-2050 AMENDMENT		02	02
33	0503011750	AMENDMENT WITH LOCK		06	06
34	0503010951	REDUCTION		04	04
35	0503011751	REDUCTION		06	06
36	0503010246	CLAMP		09	09
37	0511058368	EAR MOVABLE	65	02	02
38	0501058170	SEMI-ASSEMBLED HYDRAULIC MARKER 4045/9	66	01	00
39	0501050633	ROW MARKER DISK ASSEMBLY	70	02	00
40	0511066652	400 TURNBUCKLE		02	00
41	0503013185	3/4" X 5-1/2" BOLT		02	00
42	0511017305	FLAT WASHER		02	00
43	0503010023	3/4" SPRING WASHER		02	00
44	0503011255	3/4" LOCK NUT		02	00
45	0511057133	LABEL ASSY FOR HYDRAULIC MARKER - 4045	59	01	00
45.	0511058969	LABEL ASSY - 4495	60	00	01
46	0909096267	ASSY SEED/FERTILIZER ROW	72	01	01




Item	Code	Description	See page	QT
01	0511069529	FRAME		01
02	0511069682	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0521062243	FRAME		01
02	0521062242	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	5	01
02	0531019171	1.25" X 7" COUPLING SHAFT		01
03	0521012536	COUPLING SHAFT		01
04	0503010523	1/4" X 2" COTTERPIN		02
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511064055	5" X 15" CYLINDER CASE		01
02	0511064056	BUSHING 2" X 14" TURNBUCLE		01
03	0502010382	5" END CAP		01
04	0502012227	50.80 X 127 RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	1870-2000-375-B GASKET		01
07	0503010952	W2-2250-500 RING		01
08	0503010351	2-425 N 3006-9B O'RING		01
09	0503011062	8-425 BACK-UP RING		01
10	0502010963	2.0" X 5.0" PISTON		01
11	0503010552	PACKING 3750-4250-625-B		02
12	0503010345	2-218 N 3006-9B O'RING		01
13	0503010974	W2-5000-500 RING		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503010003	1845 GREASE FITTING		01
16	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
01	0501058240	WHEEL FASTENER WITH TENSIONER	7	01
02	0503011119	7/8" X 6" BOLT		04
03	0501014251	FLAT WASHER		04
04	0503011254	7/8" HEX SELF ADJUSTING NUT		04
05	0501059909	CARRYING WHEELS SUPPORT	11	01
06	0503014887	2050 CHAIN X 80 LINK + REDUCTION		01
07	0502010584	CARRYING-WHEELS SUPPORT FIXER		01







Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TIGHTENER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN UPPER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0591017923	GLOVE 15.30 X 30 X 32		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0531016887	CARRYING WHEEL AXLE ARM		01
03	0503010523	1/4" X 2" COTTERPIN		01
04	0503010003	1845 GREASE FITTING		01
05	0511050681	TRACTION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0561016062	SPRING HITCH		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		04
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0511052770	WHEEL WITH TIRE	12	01
11	0501058241	WHEEL SUPPORT CHAIN TENSIONER	15	01
12	0521061565	WHEEL SUPPORT ARM		01
13	0503018981	BOLT		02
14	0521069983	WHEEL COVER		01
15	0591010589	BODY LOCK WHEEL		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	13	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	14	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01



Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSM AXLE CARRYING-WHEEL		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	20	01
15	0511051434	TRANSMISSION ACTUATOR	21	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	22	01
17	0521043316	RIGHT GEAR BOX ASSY	24	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	35	01
26	0501058234	LOWER CHAIN TENSIONER	36	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	37	01
28	0501058236	BEARING WITH 21Z GEAR	38	01
29	0501058237	16Z GEAR BEARING	39	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	40	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01



PST4 - FRAME 4045/4495 - WITH ELEVATION (FROM
RIGHT TRANSMISSION ASSY - 4045

Page 16
0511058597

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561018351	2155 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	20	01
15	0511051434	TRANSMISSION ACTUATOR	21	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	22	01
17	0521043316	RIGHT GEAR BOX ASSY	24	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	35	01
26	0501058234	LOWER CHAIN TENSIONER	36	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	37	01
28	0501058236	BEARING WITH 21Z GEAR	38	01
29	0501058237	16Z GEAR BEARING	39	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	40	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01



PST4 - FRAME 4045/4495 - WITH ELEVATION (FROM
RIGHT TRANSMISSION ASSY - 4495

Page 17
0511058970

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	20	01
15	0511051434	TRANSMISSION ACTUATOR	21	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	23	01
17	0521043317	LEFT GEAR BOX ASSY	25	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	35	01
26	0501058234	LOWER CHAIN TENSIONER	36	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	37	01
28	0501058236	BEARING WITH 21Z GEAR	38	01
29	0501058237	16Z GEAR BEARING	39	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	40	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01



PST4 - FRAME 4045/4495 - WITH ELEVATION (FROM
LEFT TRANSMISSION ASSY - 4045

Page 18
0511058598

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561018351	2155 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	20	01
15	0511051434	TRANSMISSION ACTUATOR	21	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	23	01
17	0521043317	LEFT GEAR BOX ASSY	25	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	35	01
26	0501058234	LOWER CHAIN TENSIONER	36	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	37	01
28	0501058236	BEARING WITH 21Z GEAR	38	01
29	0501058237	16Z GEAR BEARING	39	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	40	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01




PST4 - FRAME 4045/4495 - WITH ELEVATION (FROM
LEFT TRANSMISSION ASSY - 4495

Page 19
0511058971


Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER	01	
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
03	0503010060	1/2" NUT	01	
04	0521017590	GUIDE AXLE	01	
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING	01	
06	0502012009	DRIVING AXLE RIGHT FOLLOWER	01	
07	0501019734	FLAT WASHER	02	
08	0502010710	RIGHT CAM, SMALLER	02	
09	0503010003	1845 GREASE FITTING	02	
10	0502012539	26Z P12,7 GEAR	01	
11	0501019735	FLAT WASHER	01	
12	0521017593	FLAT WASHER	01	
13	0503010542	501045 CLAMPING RING (FOR AXLE)	01	




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	26	01
02	0511059266	CLOSED BEARING	28	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	30	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	32	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	33	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	34	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	27	01
02	0511059266	CLOSED BEARING	28	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	30	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	32	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	33	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	34	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	29	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	31	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503012882	BEARING		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0551019173	CHAIN SLEEVE TENSIONER		01
05	0511017302	FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019174	DOBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0511057070	HOSE KIT HYDRAULIC		01
01A	0521052285	TC-TM HOSE ASSY		01
01AA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01AB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052287	TC-TM HOSE ASSY		01
01BA	0501080446	3/8 X" 169" TC-TM HOSE ASSY		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	42	02
03	0503013100	NYLON CLAMP		02
04	0581010091	SPRING PROTECTION PLASTIC HOSE		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01



Item	Code	Description	See page	DIR	ESQ
01	0511052253	RH BEAM SUPPORT & METERING		01	00
01A	0521063436	FERTILIZER BEAN RIGHT SUPPORT		01	00
02	0511052254	LH BEAM SUPPORT & METERING		00	01
02A	0521063437	FERTILIZER BEAN LEFT SUPPORT		00	01
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	47	00	05
04	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	48	05	00
05	0501010942	3/8" X 1-1/4" BOLT		20	20
06	0503011443	3/8" SPRING WASHER		20	20
07	0503010026	3/8" NUT		20	20
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01	01
09	0521014167	CONE LOCK		01	01
10	0503030275	AGRICULTURAL BEARING		05	05
11	0502010685	18Z CONICAL GEAR		05	05
12	0551018213	3/4" X 1830 SQUARE SHAFT		01	01
13	0521010691	AXLE FASTENER		02	02
14	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02	02
15	0501010694	FLAT WASHER		02	02
16	0503011441	SPRING WASHER		02	02
17	0503010144	1/4" NUT		02	02
18	0501110392	SILO SUPPORT BEARING		01	01
19	0521012485	GEAR BOX BEARING AGRICUTURAL		01	01
20	0503011953	5/16" X 1" BOLT		02	02
21	0501010694	FLAT WASHER		02	02
22	0521011039	FLAT WASHER		02	02
23	0503011444	SPRING WASHER		02	02
24	0503010337	5/16" NUT		02	02
25	0551018055	22,65 X 60 SLEEVE		01	01
26	0503010003	1845 GREASE FITTING		01	01
27	0503010849	3/8" X 1-1/2" BOLT		08	08
28	0501010984	FLAT WASHER		17	17
29	0503010025	3/8" SPRING WASHER		08	08

Item	Code	Description	See page	DIR	ESQ
30	0503010026	3/8" NUT		08	08
31	0503034396	FERTILIZER SIDE COVER		05	05
32	0503010362	1/8" X 1.1/4" COTTERPIN		05	05
33	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		01	01
34	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
35	0551019156	GEAR BOX LEVER LOCK		01	01
36	0503011953	5/16" X 1" BOLT		02	02
37	0501010694	FLAT WASHER		02	02
38	0503010179	LOCK WASHER		02	02
39	0503010337	5/16" NUT		02	02
40	0503010847	1/2" X 3.1/4" BOLT		01	01
41	0551019168	SLEEVE		01	01
42	0511069678	LH LOWER LEVER		01	01
43	0511017302	FLAT WASHER		03	03
44	0503010019	1/2" SPRING WASHER		02	02
45	0503010060	1/2" NUT		02	02
46	0551019167	SLEEVE UNION		01	01
47	0511069678	LH LOWER LEVER		01	01
48	0501013518	FLAT WASHER		02	02
49	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
50	0503010140	1/8" X 3/4" COTTERPIN		03	03
51	0511069678	LH LOWER LEVER		02	02
52	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
53	0551019115	LOCKING PLATFORM FIXATION		01	01
54	0501010096	3/8" X 2" BOLT		01	01
55	0503013357	3/8" SELF-ADJUSTING NUT		01	01
56	0551019159	LEVER FIXER BODY		01	01
57	0561016468	FASTENER		01	01




Item	Code	Description	See page	DIR	ESQ
01	0511053240	RIGHT SILO SUPPORT WITH DISTRIBUTOR 10	45	01	00
02	0511053241	LEFT SILO SUPPORT WITH DISTRIBUTOR 10	46	00	01
03	0503010849	3/8" X 1-1/2" BOLT		08	08
04	0501010984	FLAT WASHER		17	17
05	0503010025	3/8" SPRING WASHER		08	08
06	0503010026	3/8" NUT		08	08
07	0571010590	FERTILIZER SIDE COVER		05	05
08	0503010362	1/8" X 1.1/4" COTTERPIN		05	05
09	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		01	01
10	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
11	0551019156	GEAR BOX LEVER LOCK		01	01
12	0503011953	5/16" X 1" BOLT		02	02
13	0501010694	FLAT WASHER		02	02
14	0503010179	LOCK WASHER		02	02
15	0503010337	5/16" NUT		02	02
16	0503010847	1/2" X 3.1/4" BOLT		01	01
17	0551019168	SLEEVE		01	01
18	0551019160	LEVER		01	01
19	0511017302	FLAT WASHER		03	03
20	0503010019	1/2" SPRING WASHER		02	02
21	0503010060	1/2" NUT		02	02
22	0551019167	SLEEVE UNION		01	01
23	0511069676	INNER LEVER		01	01
24	0501013518	FLAT WASHER		02	02
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
26	0503010140	1/8" X 3/4" COTTERPIN		03	03
27	0511069678	LH LOWER LEVER		02	02
28	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
29	0551019115	LOCKING PLATFORM FIXATION		01	01
30	0501010096	3/8" X 2" BOLT		01	01
31	0503013357	3/8" SELF-ADJUSTING NUT		01	01




**PST4 - FRAME 4045/4495 - WITH ELEVATION (FROM
SET SUPPORT RIGHT LEFT**

Page 44
0511057564


Item	Code	Description	See page	DIR	ESQ
32	0551019159	LEVER FIXER BODY		01	01
33	0561016468	FASTENER		01	01




Item	Code	Description	See page	QT
01	0521064058	FERTILIZER BEAN RIGHT SUPPORT		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	47	03
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	48	02
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		05
10	1902010685	18Z CONICAL GEAR		05
11	0571013830	SQUARE SHAFT		01
12	0521010691	AXLE FASTENER		02
13	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
14	0501010694	FLAT WASHER		02
15	0503011441	SPRING WASHER		02
16	0503010144	1/4" NUT		02
17	0501110392	SILO SUPPORT BEARING		01
18	0521012485	GEAR BOX BEARING AGRICUTURAL		01
19	0503011953	5/16" X 1" BOLT		02
20	0501010694	FLAT WASHER		02
21	0521011039	FLAT WASHER		02
22	0503011444	SPRING WASHER		02
23	0503010337	5/16" NUT		02
24	0551018055	22,65 X 60 SLEEVE		01
25	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521064059	FERTILIZER BEAN LEFT SUPPORT		01
02	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	47	02
03	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	48	03
04	0501010942	3/8" X 1-1/4" BOLT		20
05	0503011443	3/8" SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0511061759	22Z P12,70 FQ 3/4" GEAR		01
08	0521014167	CONE LOCK		01
09	0503030275	AGRICULTURAL BEARING		05
10	1902010685	18Z CONICAL GEAR		05
11	0571013830	SQUARE SHAFT		01
12	0521010691	AXLE FASTENER		02
13	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
14	0501010694	FLAT WASHER		02
15	0503011441	SPRING WASHER		02
16	0503010144	1/4" NUT		02
17	0501110392	SILO SUPPORT BEARING		01
18	0521012485	GEAR BOX BEARING AGRICUTURAL		01
19	0503011953	5/16" X 1" BOLT		02
20	0501010694	FLAT WASHER		02
21	0521011039	FLAT WASHER		02
22	0503011444	SPRING WASHER		02
23	0503010337	5/16" NUT		02
24	0551018055	22,65 X 60 SLEEVE		01
25	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	FLAT WASHER	16	
04	0503010025	3/8" SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0511069665	PLATFORM RIGHT	01	
07	0521062323	PLATFORM LEFT	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	FLAT WASHER	16	
04	0503010025	3/8" SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521062237	RIGHT PLATAFORM	01	
07	0521062238	LEFT PLATAFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069656	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0521062239	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012329	DRAWBAR FIXATION REAR SUPPORT		02
02	0502012330	SUPPORT FIXER PIVOT		04
03	0503011084	3/4" X 5" BOLT		08
04	0501010322	FLAT WASHER		08
05	0503010023	3/4" SPRING WASHER		08
06	0503010014	3/4" NUT		08
07	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02
08	0561014393	COUPLING SHAFT		02
09	0503030119	LOCK PIN		04
10	0531063130	HEADER		01
11	0561019087	DRAWBAR TRANSPORT LOCK		01
12	0521010578	COUPLING SHAFT		01
13	0521010588	0.9" X 7.0" COUPLING SHAFT		01
14	0503030085	LOCK PIN		02
15	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	3245	3695	4045	4445	4845	5345
01	0531016940	5/8 X 1650 RIGHT HEX AXLE		001	000	000	000	000	000
02	0531016941	LEFT 5/8" X 59" AXLE HEX		001	000	000	000	000	000
03	0571011624	RIGHT HEX AXLE 5/8 X 1875		000	001	000	000	000	000
04	0571011625	LEFT HEX AXLE 5/8 X 1725		000	001	000	000	000	000
05	0531016942	RIGHT HEX AXLE 5/8 X 2050		000	000	001	000	000	000
06	0531016943	LEFT HEX AXLE 5/8 X 1900		000	000	001	000	000	000
07	0561019199	5/8" X 2275 AXLE HEX		000	000	000	001	000	000
08	0561019200	5/8" X 2125 AXLE HEX		000	000	000	001	000	000
09	0531016944	RIGHT 5/8" X 96" HEX AXLE		000	000	000	000	001	000
10	0531016945	LEFT 5/8" X 90" HEX AXLE		000	000	000	000	001	000
11	0561019202	HEX AXLE RIGHT		000	000	000	000	000	001
12	0561019203	HEX AXLE 5/8 X 2525 LEFT		000	000	000	000	000	001
13	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE		002	002	002	002	002	002
14	0561014215	BEARING COVER LOWER ROW FRAME		002	002	002	002	002	002
15	0502040534	SPRING GUIDE BUSHING LOCK		004	004	004	004	004	004
16	0501018535	1/2 X 1 BOLT		004	004	004	004	004	004




Item	Code	Description	See page	3695	4045	4495	4845	5345
01	0571011601	SEXT AXIS 5/8 X 2005 PST4 8 S-0812	01	00	00	00	00	00
01.	0521013429	AXLE HEX 5/8 X 2180	00	01	00	00	00	00
01..	0561018352	RIGHT HEX SHAFT 5/8 X 2375	00	00	01	00	00	00
01...	0521013430	HEX AXLE 5/8 X 2580	00	00	00	01	00	00
01....	0561019214	HEX AXLE 5/8 X 2805 RIGHT	00	00	00	00	01	00
02	0571011600	SIXTH AXIS 5/8 X 1725	01	00	00	00	00	00
02.	0521013433	5/8" X 75" AXLE HEX	00	01	00	00	00	00
02..	0561018353	5/8 X 2150 LEFT HEX AXLE	00	00	01	00	00	00
02...	0521013434	HEX AXLE 5/8 X 2300	00	00	00	01	00	00
02....	0561019215	HEX AXLE 5/8 X 2555 LEFT	00	00	00	00	01	00
03	0503010571	1/4" X 1.1/2 COTTERPIN	02	02	02	02	02	02
04	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"	02	02	02	02	02	02
05	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8	02	02	02	02	02	02
06	0503010003	1845 GREASE FITTING	02	02	02	02	02	02
07	0503010365	NUT	04	04	04	04	04	04
08	0501010984	FLAT WASHER	04	04	04	04	04	04
09	0501010694	FLAT WASHER	08	08	08	08	08	08
10	0503010179	LOCK WASHER	04	04	04	04	04	04
11	0503010337	5/16" NUT	04	04	04	04	04	04
12	0511015098	FLAT WASHER	02	02	02	02	02	02
13	0511017305	FLAT WASHER	04	04	04	04	04	04
14	0511065562	20Z GEAR	02	02	02	02	02	02
15	0502011299	BUSHING GEAR	02	02	02	02	02	02
16	0503010010	1/4" X 2.1/2" COTTERPIN	02	02	02	02	02	02







Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
06	0503033423	LABEL ADHESIVE NUMBER 9		02
07	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
08	0503033008	ADHESIVE LABEL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	ADHESIVE LABEL		01
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
12	0503031565	ADHESIVE LABEL CARE		02
13	0503031566	ADHESIVE LABEL		02
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
15	0503031425	ADHESIVE LABEL ATTENTION		02
16	0503031669	ADHESIVE LABEL		01
17	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
19	0503032930	ADHESIVE LABEL DANGER		05
20	0503031087	ADHESIVE LABEL		01
21	0503034078	LIFTING POINTS DECAL		03
22	0503034003	SERIAL NUMBER TAG 61 X 118		01
23	0503010001	3.2 X 5.5 RIVET		04
24	0503032979	ADHESIVE LABEL LETTERS A B C D		02
25	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HAIR PIN		01



Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01



Item	Code	Description	See page	QT
01	0521066608	LIFTING HOOK		01
02	0581019707	FIXATION SUPPORT SUPPORT		01
03	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
04	0501012140	FLAT WASHER		04
05	0503012412	5/8 UNC SELF LOCKING NUT		04




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8 UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0503012412	5/8 UNC SELF LOCKING NUT		02
13	0511058449	HYDRAULIC CYLINDER	67	02
14	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
15	0503010523	1/4" X 2" COTTERPIN		02
16	0511015779	1" X 4.2" AXLE		02
17	0503010523	1/4" X 2" COTTERPIN		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	0.3" X 3.1" LOCK PIN		02
20	0503030168	CUPILLA		02
21	0501069643	890 TURNBUCKLE		02
22	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
23	0511011311	VALVE SUPPORT		01
24	0503010232	5/8" X 1.3/4" BOLT		02
25	0503010027	5/8" SPRING WASHER		02
26	0503010013	5/8" NUT		02
27	0501054649	HBM SEQUENTIAL VALVE	68	01
28	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
29	0501010984	FLAT WASHER		02
30	0503010025	3/8" SPRING WASHER		02
31	0511057095	HYDRAULIC MARKER HOSE KIT	69	01




PST4 - FRAME 4045/4495 - WITH ELEVATION (FROM
SEMI-ASSEMBLED HYDRAULIC MARKER 4045/9

Page 66
0501058170


Item	Code	Description	See page	QT
32	0501053834	MALE QUICK COUPLER	42	02
33	0502012702	BODY SUPPORT CLAMP		06
34	0503011103	7/16" X 2-1/2" BOLT		06
35	0501012803	FLAT WASHER		02
36	0503010180	7/16" SPRING WASHER		06
37	0503010244	7/16" NUT		06




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCIAL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0501081727	TR-TR HOSE ASSY		02
02	0501080447	3/8" X 122" TR-TC HOSE ASSY		02
03	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
03A	0501080422	HOSE 3/8 X 4000 TC-TM		01
03B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
03C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
03D	0503018952	PLASTIC BOLT		06
04	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
04A	0501080422	HOSE 3/8 X 4000 TC-TM		01
04B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
04C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
04D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	71	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01



Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0531054196	HIGH SHORT SEED ROW	73	01
02	0531054195	HIGH LONG SEED ROW	74	01
03	0521053154	FERTILIZER SHORT HIGH ROW WITH LEFT 92		01
		DDD/18" DC		
03.	0521052636	FERTILIZER SHORT HIGH ROW WITH LEFT 94		01
		DDD/20" DC		
04	0521053153	FERTILIZER LONG HIGH ROW WITH RIGHT 93		01
		DDD/18" DC		
04.	0521052637	FERTILIZER LONG HIGH ROW WITH RIGHT 95		01
		DDD/20" DC		
05	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	108	01
06	0501013714	STABILIZER BAR		01
06.	0501018652	CORN STABILIZER BAR		01
07	0581015213	STABILIZER BAR E450		01
07.	0581015215	STABILIZER BAR E500 PIVOTED HIGH LINE		01
08	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
09	0503010479	BOLT		01
10	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
11	0511017302	FLAT WASHER		01
12	0503010019	1/2" SPRING WASHER		03
13	0503010060	1/2" NUT		03
14	0503031050	CURVED CONDUCTOR		01
15	0503010246	CLAMP		01
16	0501110804	SCARIFIER ROD WITH POINT	118	01
17	0511017969	0.1" SPACING PLATE		01
18	0511018662	SPACING PLATE		01
19	0521069124	BOCAL FILLED LINE PIVOTED WITH LINGUET		01
20	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
21	0501010984	FLAT WASHER		01
22	0503010025	3/8" SPRING WASHER		01
23	0503010026	3/8" NUT		01
24	0503010905	1/2" X 2-1/4" BOLT		01




PST4 - FRAME 4045/4495 - WITH ELEVATION (FROM
ASSY SEED/FERTILIZER ROW

Page 72
0909096267


Item	Code	Description	See page	QT
25	0503063647	SIGMA CORN DISC SET	119	01
26	0503063648	SIGMA SOY DISC SET	120	01




Item	Code	Description	See page	QT
01	0521052840	SHORT PIVOTING HIGH LINE	75	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	80	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0531053925	SIGMA SOY INDIVIDUAL SEED SYSTEM	81	01




Item	Code	Description	See page	QT
01	0521052841	LONG PIVOTANT HIGH LINE	85	01
02	0511059350	SUPPORT LINE SUPPORT LINE WITH SCREW NUT	80	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0531053925	SIGMA SOY INDIVIDUAL SEED SYSTEM	81	01




Item	Code	Description	See page	QT
01	0521068663	SHORT SEED LINE ARM		01
02	0511059244	ROD SPRING LINE SEED	76	01
03	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	77	01
04	0511052024	FAST CLOSING SET	78	01
05	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
06	0521018077	1/2" X 58.6" HEX AXLE		01
07	0521018079	SEEP ROW DRAWBAR COVER		01
08	0502011830	ARTICULACCION SUPPORT		01
09	1902010426	UPPER BEARING SEMI		02
10	0511051693	BASE FIXING SYSTEM	79	01
11	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	87	01
12	0503010752	1/2" X 3.1/2" BOLT		02
13	0503011440	SPRING WASHER		08
14	0503010060	1/2" NUT		08
15	1902011561	BEARING SEMI		01
16	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
17	0503014729	1/4" UNF X 1/2" BOLT		02
18	0503011441	SPRING WASHER		02
19	0503010479	BOLT		04
20	0501013352	FLAT WASHER		01
21	0502011505	18Z CONICAL GEAR		01
22	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
23	0501013354	FLAT WASHER		02
24	0502011400	18Z CONICAL GEAR		01
25	0581014526	ELEVATION PLATE 3/8		01
26	0581014527	ELEVATION PLATE 12,5		03
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
28	0503010025	3/8" SPRING WASHER		04
29	0503010026	3/8" NUT		04
30	0503011099	GREASE FITTING		02
31	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511060376	SEEP SPRING GUIDE		01
02	0503010834	1/2 X 1 BOLT		02
03	0502040534	SPRING GUIDE BUSHING LOCK		02
04	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
05	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
06	0501013753	FLAT WASHER		01
07	0521010542	COUPLING SHAFT		01
08	0503010257	1/8" X 1" COTTERPIN		01
09	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0502012538	SPRING VARON SUPPORT		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0511017302	FLAT WASHER		02
04	0503011336	1/2" HEX SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502011411	10Z CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0502012823	CUTTING DISC SUPPORT		01
02	0503034318	5/8 UNC X 2 BOLT		02
03	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0531051514	SIGMA SOY SEED SYSTEM	82	01
02	0503063602	SEMI-ASSEMBLED SIGMA INDIVIDUAL SEED BOX	84	01
03	0503010179	LOCK WASHER		04
04	0501010694	FLAT WASHER		04
05	0503010240	BOLT		04
06	0503035691	ADHESIVE LABEL		02




Item	Code	Description	See page	QT
01	0511057289	ASSY SEED DEFLECTOR	83	01
02	0503030083	3/8" X 3/8" X 1.6" STUD		02
03	0503010675	5/16" X 2.1/4" BOLT		01
04	0503010179	LOCK WASHER		01
05	0503010337	5/16" NUT		01
06	0502012974	LOWER SEED DISK TRACK		01
07	0501013518	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		02
09	0503010209	3/8" UNC BUTTERFLY NUT		02
10	0503016282	ALLEN BOLT		01
11	0503019913	SELF-LOCKING NUT W/ NYLON M8 X 1.25 C.8 ZN		01
12	0503035299	PLATE SPRING 16 X 8.2 X 0.90		02
13	0591018706	SEED BOX SUPPORT		01
14	0513010140	SOYA DISK SOCIDISC 90 HOLES		01
15	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461		01
16	0503063405	SOY SEED DISTRIBUTOR BOX		01




Item	Code	Description	See page	QT
01	0503010025	3/8" SPRING WASHER		01
02	0503010209	3/8" UNC BUTTERFLY NUT		01
03	0571018536	HEX PRISONER		01
04	0501013518	FLAT WASHER		02
05	0503034131	DEFLECTOR		01




Item	Code	Description	See page	QT
01	0503035628	SIGMA YELLOW SEED BOX		01
02	0503035629	SIGMA SEED BOX LID		01
03	0503035298	BAKELITE HANDLE WITH THREAD		01
04	0503015536	M6 X 1" SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0521068664	LONG SEED LINE ARM		01
02	0511059244	ROD SPRING LINE SEED	76	01
03	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	77	01
04	0511052024	FAST CLOSING SET	78	01
05	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
06	0521018078	1/2" X 66.5" HEX AXLE		01
07	0521018079	SEEP ROW DRAWBAR COVER		01
08	0502011830	ARTICULACION SUPPORT		01
09	1902010426	UPPER BEARING SEMI		02
10	0511051693	BASE FIXING SYSTEM	79	01
11	0511056586	15 X 15 SEED DDD LEFT	86	01
12	0503010752	1/2" X 3.1/2" BOLT		02
13	0503011440	SPRING WASHER		08
14	0503010060	1/2" NUT		08
15	1902011561	BEARING SEMI		01
16	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
17	0503014729	1/4" UNF X 1/2" BOLT		02
18	0503011441	SPRING WASHER		02
19	0503010479	BOLT		04
20	0501013352	FLAT WASHER		01
21	0502011505	18Z CONICAL GEAR		01
22	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
23	0501013354	FLAT WASHER		02
24	0502011400	18Z CONICAL GEAR		01
25	0581014526	ELEVATION PLATE 3/8		01
26	0581014527	ELEVATION PLATE 12,5		03
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
28	0503010025	3/8" SPRING WASHER		04
29	0503010026	3/8" NUT		04
30	0503011099	GREASE FITTING		02
31	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	89	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	90	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	91	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	88	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	90	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	91	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0521053152	ARM SHORT LINE FERTILIZER WITH DDD LEFT	96	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058617	DISC CUT 18 SHORT LINE	100	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	107	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521053151	ARM LONG FERTILIZER LINE WITH DDD RIGHT	97	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058618	DISC CUT 18 LONG LINE	101	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	107	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521053152	ARM SHORT LINE FERTILIZER WITH DDD LEFT	96	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058619	DISC CUT 20 SHORT LINE	102	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	107	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521053151	ARM LONG FERTILIZER LINE WITH DDD RIGHT	97	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058620	DISC CUT 20 LONG LINE	103	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	107	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521068566	SHORT FERTILIZER LINE ARM		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	98	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0521068565	LONG FERTILIZER LINE ARM		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2" NUT		02
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	99	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	91	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	90	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	90	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	91	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0503010003	1845 GREASE FITTING		01
03	0571019976	LEFT BRACELET CUTTING DISC		01
04	0503011411	1/2" X 5-1/2" BOLT		01
05	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
06	0503011440	SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0502020394	SPRING SUPPORT		01
09	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
10	0502020393	SPRING UPPER SUPPORT		01
11	0521010452	SLEEVE		01
12	0503013185	3/4" X 5-1/2" BOLT		01
13	0501067323	SPRING REGULATOR		01
14	0511056910	BOX WITH DISC CUT 18	105	01
15	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01
16	0503011255	3/4" LOCK NUT		02
17	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
18	0581011111	WASHER BRACKET AXIS DC PST		01
19	0503034319	LOCK PIN		01
20	0511056909	DISC BOX CUT WITHOUT THE DISC	104	01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0503010003	1845 GREASE FITTING		01
03	0571019976	LEFT BRACELET CUTTING DISC		01
04	0503011411	1/2" X 5-1/2" BOLT		01
05	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
06	0503011440	SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0502020394	SPRING SUPPORT		01
09	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
10	0502020393	SPRING UPPER SUPPORT		01
11	0521010452	SLEEVE		01
12	0503013185	3/4" X 5-1/2" BOLT		01
13	0501067323	SPRING REGULATOR		01
14	0511056910	BOX WITH DISC CUT 18	105	01
15	0502012824	FIXING SHAFT DISC CUT LINE		01
16	0503011255	3/4" LOCK NUT		02
17	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
18	0581011111	WASHER BRACKET AXIS DC PST		01
19	0503034319	LOCK PIN		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012825	SHAFT FIXING SHAFT CUT LINE SHORT		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	WASHER BRACKET AXIS DC PST		01
17	0503034319	LOCK PIN		01
18	0511058648	BOX WITH DISC BLADE 20	106	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2" NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012824	FIXING SHAFT DISC CUT LINE		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	WASHER BRACKET AXIS DC PST		01
17	0503034319	LOCK PIN		01
18	0511058648	BOX WITH DISC BLADE 20	106	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012793	DC PST		01
02	0571018047	CUTTING DISC BOX SHAFT		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DOOR DUST		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0511056909	DISC BOX CUT WITHOUT THE DISC	104	01
02	0603026013	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0511056909	DISC BOX CUT WITHOUT THE DISC	104	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK	02	
02	0502012184	FERTILIZER SPRING GUIDE	02	
03	0503031910	1.7" X 22.8" X 0.3" SPRING	01	
04	0502012510	SPRING ROD SUPPORT	01	
05	0521068568	LARGE ELEVATION SPRING FERTILIZER	01	
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN	01	
07	0501018535	1/2 X 1 BOLT	02	
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
09	0503010060	1/2" NUT	02	
10	0502010891	SPRING CHOCK SUPPORT VARON	01	
11	0503010014	3/4" NUT	01	
12	0561014471	COUPLING SHAFT	01	
13	0511017302	FLAT WASHER	01	
14	0503010257	1/8" X 1" COTTERPIN	01	




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	109	01
02	0501052538	DEPTH BAND WITH ARMS	114	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	115	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	116	01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	110	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	112	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	113	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX	111	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX	111	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	117	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	117	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01



Item	Code	Description	See page	QT
01	0513010117	SOCIDISCO CORN DISC 28 HOLES 9,0 AMC9R-002130	01	01
02	0513010118	SOCIDISCO CORN DISC 28 HOLES 9,5 VLD9.5R-002115	01	01
03	0513010119	SOCIDISCO CORN DISC 28 HOLES 10 SAL10R-002619	01	01
04	0513010120	SOCIDISCO CORN DISC 28 HOLES 10,5 RSP10.5R-002133	01	01
05	0513010121	SOCIDISCO CORN DISC 28 HOLES 11 LRA11R-002134	01	01
06	0513010122	SOCIDISCO CORN DISC 28 HOLES 11,5 MAG11.5R-002620	01	01
07	0513010123	SOCIDISCO CORN DISC 28 HOLES 12 VDA12R-002621	01	01
08	0513010124	SOCIDISCO CORN DISC 28 HOLES 12,5 AMP12.5R-002131	01	01
09	0513010125	SOCIDISCO CORN DISC 28 HOLES 13 VMV13R-002132	01	01
10	0513010126	SOCIDISCO CORN DISC 28 HOLES 13,5 RXR13.5R-002136	01	01
11	0513010187	SOCIDISCO CORN DISC 28 HOLES 14,8 X 10 VM4-002581	01	01
12	0513010188	SOCIDISCO CORN DISC 28 HOLES 11 X 8 BR8.1-002589	01	01
13	0513010189	SOCIDISCO CORN DISC 28 HOLES 12,5 X 8,5 AZ8.2-002587	01	01
14	0513010164	SOCIDISCO FLAT RING FOR CORN AMFOSLISO-002127	01	01
15	0513010159	SOCIDISCO RING FOR CORN 0,8MM LRFOSSR08-002120	01	01
16	0513010160	SOCIDISCO RING FOR CORN 1,4MM VMFOSR1.4-002245	01	01
17	0513010163	SOCIDISCO RING FOR CORN 2,0MM VDFOSR2-002116	01	01
18	0503063413	CORN SEED DISTRIBUTOR BOX 4Z - 001798	01	01



Item	Code	Description	See page	QT
01	0513010136	SOCIDISCO SOY DISC 62 HOLES 7,5 LRA62.75-002357	01	01
02	0513010137	SOCIDISCO SOY DISC 62 HOLES 8,0 RSP62.80-002358	01	01
03	0513010138	SOCIDISCO SOY DISC 62 HOLES 8,5 RXR62.85-002359	01	01
04	0513010139	SOCIDISCO SOY DISC 62 HOLES 9,0 AZM62.90-002360	01	01
05	0513010141	SOCIDISCO SOY DISC 90 HOLES 8,0 RSP90.80-002287	01	01
06	0513010142	SOCIDISCO SOY DISC 90 HOLES 8,5 RXR90.85-002317	01	01
07	0513010143	SOCIDISCO SOY DISC 90 HOLES 9,0 AZM90.90-002288	01	01
08	0513010158	SOCIDISCO FLAT RING FOR SOY AZMSOJALISO-002243	01	01
09	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461	01	01
10	0513010162	SOCIDISCO RING FOR SOY 1,5MM RSPSOJASR1,5-002244	01	01
11	0503063412	4Z SOY/BEAN SEED DISTRIBUTOR BOX - 001804	01	01



MARCHESAN

Technical Publications | Elaboration and Revision

LEONARDO JOSÉ DA SILVA SOUZA

www.marchesan.com.br

