

ROW CROP PLANTERS

PST4 - FRAME 4045 - RIGHT - LEFT - DOUBLE HEADER (FROM 04/2022)

Code: 0501093286
Series: S-0116
Revision: 00
Date Revision: MAIO/2022

PARTS CATALOGUE



MARCHESAN



PRODUCTS

Code	Description
0521046401	CABECALHO DUPLO SEM MARCADOR HIDRAULICO
0111151191	PST4 4045/9E450 CI 5LG/4CT S-0116
0111151190	PST4 4045/9E450 CI S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909096268	PST4 - FRAME 4045 - RIGHT/LEFT WITH DOUBLE HEADER	1
0909096269	PST4 - FRAME 4045 - RIGHT	2
0909096270	PST4 - FRAME 4045 - LEFT	3
0521046401	DOUBLE HEADER WITHOUT HYDRAULIC MARKER	4
0511057626	SEMI MOUNTED DOUBLE HEADER	5
0511057627	DOUBLE HEADER HYDRAULIC SYSTEM HOSE ASSY	6
0501053835	FEMALE QUICK COUPLER	7
0501053834	MALE QUICK COUPLER	8
0501054694	FLOW DIVIDING VALVE ASSY	9
0503062157	HEADER JACK	10
0501054863	WELL AND TIRE ASSY	11
0503060414	WHEEL AND TIRE	12
0501051799	STUB SHAFT & HUB ASSY	13
0521022453	BOX WITH DOUBLE HEADER COMPONENTS	14
0501054258	DRAWBAR ESTABILIZER ASSY	15
0501040364	HOSE SUPPORT ASSEMBLY	16
0501054862	AXIS LOCK RODE ASSY	17
0511053179	TRACTOR COUPLING SHAFT	18
0501051160	TRACTOR HITCH PIN	19
0511056409	TRACTOR HITCH	20
0501058195	FRAME WITH AXLE WHEEL - 4045	21
0511057124	CYLINDER ASSY	22
0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	23
0521043934	CARRYING WHEELS SPRING TRACTION	24
0501058240	WHEEL FASTENER WITH TENSIONER	25
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	26
0501058239	WHEEL CHAIN TENSIONER BEARING	27
0501058244	WHEEL FIXED CHAIN TENSIONER	28
0501058242	WHEEL MOBILE CHAIN TENSIONER	29
0501059909	CARRYING WHEELS SUPPORT	30
0511052770	WHEEL WITH TIRE	31
0503062159	WHEEL WITH TIRE	32
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	33
0501058241	WHEEL SUPPORT CHAIN TENSIONER	34
0511058597	RIGHT TRANSMISSION ASSY - 4045	35
0511058598	LEFT TRANSMISSION ASSY - 4045	36
0501052560	MOTOR AXLE SIGNAL	37
0511051434	TRANSMISSION ACTUATOR	38
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	39
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	40
0521043316	RIGHT GEAR BOX ASSY	41
0521043317	LEFT GEAR BOX ASSY	42
0501058212	SEMI MOUNTED RIGHT CHANGE	43
0501058213	LH GEAR BOX	44
0511059266	CLOSED BEARING	45
0501056271	GEARBOX CLOSED BEARING	46
0501056443	GEAR HOUSING BEARING	47
0501056444	BEARING WITH ROLLING	48
0501048790	AXLE WITH RING	49
0501054655	CHAIN TENSIONER ASSY	50
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	51
0511054363	CHAIN TENSIONER	52
0501058234	LOWER CHAIN TENSIONER	53
0501058235	STRETCHER CURRENT TOP SEED 17Z	54
0501058236	BEARING WITH 21Z GEAR	55



MARCHESAN

INDEX


0501058237	16Z GEAR BEARING	56
0501055112	MICRO GRANULATED CHAIN TENSIONER	57
0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	58
0511057128	SET SUPPORT RIGHT LEFT	59
0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	60
0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	61
0511057129	PLATFORM ASSY - 4045	62
0511057130	HANDRAIL ASSY - 4045	63
0511056536	LADDER ASSEMBLY	64
0511054971	JACK ASSEMBLY	65
0511057142	ASSY HEADER - 3245/3695/4045/4495	66
0511057131	MANUAL CANISTER ASSY	67
0511057541	LABEL ASSY - 4045	68
0909098921	ASSY HEX AXLE	69
0511058368	EAR MOVABLE	70
0511054601	HITCH ARTICULATED TRACTOR	71
0511056736	HOSE SUPPORT	72
0909096271	ASSY SEED/FERTILIZER LINE	73
0531054249	INDIVIDUAL SHORT SEED ROW	74
0511056600	FRONT LINE SEED SHORT DDD RIGHT	75
0511051693	BASE FIXING SYSTEM	76
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	77
0511052301	SUPPORT DDD 15 RIGHT	78
0511053173	CUBE LOW RIGHT WITH DISC 15	79
0511053172	LEFT LOW CUBE WITH DISC 15	80
0511058212	ASSY LINE SUPPORT FERTILIZER	81
0511052024	FAST CLOSING SET	82
0531053925	SIGMA SOY INDIVIDUAL SEED SYSTEM	83
0531051514	SIGMA SOY SEED SYSTEM	84
0511057289	ASSY SEED DEFLECTOR	85
0531054248	INDIVIDUAL LONG SEED ROW	86
0511056601	LONG SEED ROW FRONT DDD LEFT	87
0511056586	15 X 15 SEED DDD LEFT	88
0511052302	LH SUPPORT DDD GUIDE	89
0511053252	FERTILIZER SHORT ROW WITH LEFT DDD/18" DC	90
0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	91
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	92
0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	93
0521054686	CUTTING DISC BOX 18	94
0521054679	DISC CUTTING BOX WITHOUT DISC	95
0501058423	FERTILIZER ROD SPRING ROW	96
0511053253	FERTILIZER LONG ROW WITH RIGHT DDD/18" DC	97
0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	98
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	99
0511044573	18" COULTER BLADE ASSY FOR LONG ROW	100
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	101
0511058650	SEMI-MOUNTED DEPTH CONTROL	102
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	103
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	104
0501052627	ASSY DEPTH WHEEL BOX	105
0501052297	DEPTH WHEELS REGULATOR ASSY	106
0501052538	DEPTH BAND WITH ARMS	107
0511054333	COMPACT WHEEL RIGHT WITH BEARING	108
0511054334	COMPACT WHEEL LEFT WITH BEARING	109
0501052908	COMPACTOR WHEEL WITH BEARING	110




MARCHESAN

INDEX

0503063647	SIGMA CORN DISC SET		111
0503063648	SIGMA SOY DISC SET		112




Item	Code	Description	See page	QT
01	0521046401	DOUBLE HEADER WITHOUT HYDRAULIC MARKER	4	01
02	0909096269	PST4 - FRAME 4045 - RIGHT	2	01
03	0909096270	PST4 - FRAME 4045 - LEFT	3	01



Item	Code	Description	See page	QT
01	0501058195	FRAME WITH AXLE WHEEL - 4045	21	01
02	0503010003	1845 GREASE FITTING		04
03	0511057124	CYLINDER ASSY	22	01
04	0521043934	CARRYING WHEELS SPRING TRACTION	24	04
05	0511058597	RIGHT TRANSMISSION ASSY - 4045	35	01
06	0511058598	LEFT TRANSMISSION ASSY - 4045	36	01
07	0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	58	01
08	0511057128	SET SUPPORT RIGHT LEFT	59	01
09	0511057129	PLATFORM ASSY - 4045	62	01
10	0511057130	HANDRAIL ASSY - 4045	63	01
11	0511056536	LADDER ASSEMBLY	64	02
12	0511054971	JACK ASSEMBLY	65	02
13	0511057142	ASSY HEADER - 3245/3695/4045/4495	66	01
14	0511057131	MANUAL CANISTER ASSY	67	01
15	0511057541	LABEL ASSY - 4045	68	01
16	0909098921	ASSY HEX AXLE	69	01
17	0511058368	EAR MOVABLE	70	02
18	0501065677	STRUT		02
19	0501054258	DRAWBAR ESTABILIZER ASSY	15	01
20	0511054601	HITCH ARTICULATED TRACTOR	71	01
21	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
22	0511053179	TRACTOR COUPLING SHAFT	18	01
23	0521013022	TRANSPORT LOCK		01
24	0501068994	0.3" X 3.1" LOCK PIN		01
25	0503030168	CUPILLA		01
26	0511056736	HOSE SUPPORT	72	01
27	0501047895	ROD STOP		01
28	0501047885	ROD STOP		01
29	0501047886	ROD STOP		01
30	0501047887	ROD STOP		01
31	0503032624	SILLO FERTILIZER GUTTER		05




Item	Code	Description	See page	QT
32	0503014120	CHAIN		01
33	0503014321	CABLE STEEL SHACKLE		02
34	0503010780	N-2050 AMENDMENT		02
35	0503010951	REDUCTION		04
36	0503011750	AMENDMENT WITH LOCK		06
37	0503011751	REDUCTION		06
38	0909096271	ASSY SEED/FERTILIZER LINE	73	09




Item	Code	Description	See page	QT
01	0501058195	FRAME WITH AXLE WHEEL - 4045	21	01
02	0503010003	1845 GREASE FITTING		04
03	0511057124	CYLINDER ASSY	22	01
04	0521043934	CARRYING WHEELS SPRING TRACTION	24	04
05	0511058597	RIGHT TRANSMISSION ASSY - 4045	35	01
06	0511058598	LEFT TRANSMISSION ASSY - 4045	36	01
07	0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	58	01
08	0511057128	SET SUPPORT RIGHT LEFT	59	01
09	0511057129	PLATFORM ASSY - 4045	62	01
10	0511057130	HANDRAIL ASSY - 4045	63	01
11	0511056536	LADDER ASSEMBLY	64	02
12	0511054971	JACK ASSEMBLY	65	02
13	0511057142	ASSY HEADER - 3245/3695/4045/4495	66	01
14	0511057131	MANUAL CANISTER ASSY	67	01
15	0511057541	LABEL ASSY - 4045	68	01
16	0909098921	ASSY HEX AXLE	69	01
17	0511058368	EAR MOVABLE	70	02
18	0501065677	STRUT		02
19	0501054258	DRAWBAR ESTABILIZER ASSY	15	01
20	0511054601	HITCH ARTICULATED TRACTOR	71	01
21	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
22	0511053179	TRACTOR COUPLING SHAFT	18	01
23	0521013022	TRANSPORT LOCK		01
24	0501068994	0.3" X 3.1" LOCK PIN		01
25	0503030168	CUPILLA		01
26	0511056736	HOSE SUPPORT	72	01
27	0501047895	ROD STOP		01
28	0501047885	ROD STOP		01
29	0501047886	ROD STOP		01
30	0501047887	ROD STOP		01
31	0503032624	SILLO FERTILIZER GUTTER		05



Item	Code	Description	See page	QT
32	0503014120	CHAIN		01
33	0503014321	CABLE STEEL SHACKLE		02
34	0503010780	N-2050 AMENDMENT		02
35	0503010951	REDUCTION		04
36	0503011750	AMENDMENT WITH LOCK		06
37	0503011751	REDUCTION		06
38	0909096271	ASSY SEED/FERTILIZER LINE	73	09



Item	Code	Description	See page	QT
01	0511057626	SEMI MOUNTED DOUBLE HEADER	5	01
02	0501054863	WELL AND TIRE ASSY	11	02
03	0521022453	BOX WITH DOUBLE HEADER COMPONENTS	14	01




Item	Code	Description	See page	QT
01	0511064304	FRAME HEADER DOUBLE		01
02	0511064219	FORK WHEEL DRAWBAR DOUBLE		02
03	0503010007	3982/3920 ROLLER BEARING		02
04	0503010059	33287/33462 ROLLER BEARING		02
05	0503013106	SEAL 00085-B		02
06	0502040080	FLANGE NUT R.2.1/2 UN		02
07	0503011345	1/4" X 3-1/2" COTTERPIN		02
08	0541013225	WHEEL BOX COVER		02
09	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		12
10	0503011444	SPRING WASHER		12
11	1882970002	GREASE SOAP		00
12	0503010002	1800 GREASE FITTING		03
13	0511064222	FIXER SUPPORT BOLT HOSE		04
14	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
15	0503010019	1/2" SPRING WASHER		08
16	0503010060	1/2" NUT		08
17	0511057627	DOUBLE HEADER HYDRAULIC SYSTEM HOSE 6 ASSY		01
18	0531017560	DISPLAYED IDENTIFICATION		04
19	0502012702	BODY SUPPORT CLAMP		05
20	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		05
21	0503010180	7/16" SPRING WASHER		05
22	0501053835	FEMALE QUICK COUPLER	7	04
23	0503010217	501040 CLAMPING RING (FOR AXLE)		04
24	0501053834	MALE QUICK COUPLER	8	02
25	0503010237	3/8" X 1" BOLT		02
26	0503010025	3/8" SPRING WASHER		02
27	0503010026	3/8" NUT		02
28	0511066114	CONDUCTOR VALVE SUPPORT DOUBLE HEADER		01
29	0501054694	FLOW DIVIDING VALVE ASSY	9	01
30	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
31	0501010694	FLAT WASHER		04




PST4 - FRAME 4045 - RIGHT - LEFT - DOUBLE HEADER
SEMI MOUNTED DOUBLE HEADER

Page 5
0511057626


Item	Code	Description	See page	QT
32	0503010143	1/4" SPRING WASHER		02
33	0503010144	1/4" NUT		02
34	0503062157	HEADER JACK	10	01
35	0521010549	COUPLING SHAFT		01
36	0503030168	CUPILLA		01
37	0503034003	SERIAL NUMBER TAG 61 X 118		01
38	0503010001	3.2 X 5.5 RIVET		04




Item	Code	Description	See page	QT
01	0501080512	1/2" X 1400 TR-TM HOSE		02
02	0501080796	1/2" X 1400 TC-TM HOSE		02
03	0501080004	HOSE 1/2 X 3500 TR-TM		02




Item	Code	Description	See page	QT
01	0503011883	QUICK CONNECTION COVER		01
02	0503011628	FEMALE QUICK COUPLER		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503030923	3/4" UNF X 13/16UN OFS X 40 NIPPLE		03
03	0503010190	2-114 N 3006-9B O'RING		03




Item	Code	Description	See page	QT
01	0503062157	HEADER JACK	10	01




Item	Code	Description	See page	QT
01	0503060414	WHEEL AND TIRE	12	01
02	0501051799	STUB SHAFT & HUB ASSY	13	01
03	0531015109	WHEEL AXLE LOCK		02



Item	Code	Description	See page	QT
01	0503012108	WHEEL 10 LB X 15 X 8F X 203		01
02	0503010860	AIR CHAMBER 11L 15		01
03	0503011469	RIB TIRE BL - 12L		01




Item	Code	Description	See page	QT
01	0502010908	CARRYING WHEEL HUB	01	
02	0503012159	4.0" X 2.5" X 0.5" SEAL 5144	01	
03	0503010008	3780/3720 ROLLER BEARING	01	
04	0503010328	25590/25523 ROLLER BEARING	01	
05	0503012162	5046 BAG SEAL RING	01	
06	0521011209	425 TRANSP WHEEL AXLE	01	
07	0511015949	LOCK NUT	01	
08	0503010329	LOCK WASHER	01	
09	0503010330	KM 9 LOCKNUT	01	
10	0501010086	FLAT WASHER	01	
11	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR	08	
12	0503010064	5/8 UNF CONIC NUT	08	
13	0503011052	1.1/4" X 0.77" CASTLE NUT	02	
14	0503010067	3/16" X 2.1/2" COTTER PIN	02	




Item	Code	Description	See page	QT
01	0501100045	WOODEN BOX		01
02	0501069807	FIXER SUPPORT ESTABILIZER		02
03	0521014754	FIXING BASE ESTABILIZER		02
04	0501110262	245 ADJUSTMENT NUT		01
05	0501069529	653 TURNBUCKLE		02
06	0501054258	DRAWBAR ESTABILIZER ASSY	15	01
07	0511064217	TURNBUCKLE WITH EAR		02
08	0501068300	TURNBUCKLE WITH EAR		02
09	0501061056	RH LOCKNUT WITH HANDLER		04
10	0511060916	TURNBUCKLE WITH GLOVE		01
11	0511061029	TURNBUCKLE WITH GLOVE		01
12	0511060919	TURNBUCKLE WITH GLOVE		01
13	0501066284	SUPPORT FRONT TURNBUCKLE FIXER		02
14	0521012329	3/4 UNC X 130 X 173 FASTENER		02
15	0511064310	FIXER PLATE FASTENER		02
16	0521014021	1/2" X 4.5" X 5.4" FASTENER		06
17	0501040364	HOSE SUPPORT ASSEMBLY	16	03
18	0521062077	SUPPORT STABILIZER REAR RIGHT DRAWBAR		02
19	0511064353	FASTENER		02
20	0511057628	HOSE ASSY HYDRAULIC SYSTEM		01
20A	0501080779	1/2 X 1500 TM-TM HOSE		02
21	0501054862	AXIS LOCK RODE ASSY	17	02
22	0511053179	TRACTOR COUPLING SHAFT	18	01
23	0501051160	TRACTOR HITCH PIN	19	02
24	0511056409	TRACTOR HITCH	20	01
25	0571017510	GLOVE ARTICULATED HITCH		01
26	0511064220	COUPLING SUPPORT DOUBLE DRAWBAR		02
27	0531017551	COUPLING SUPPORT FIXING BASE		02
28	0511031535	BAG WITH INSTRUCTION MANUAL		01
29	0503014120	CHAIN		01
30	0503014321	CABLE STEEL SHACKLE		02


Item	Code	Description	See page	QT
31	0501014172	1" X 8" BOLT		08
32	0503010012	1" SPRING WASHER		08
33	0501010059	1.5/8 NUT		08
34	0503011135	BOLT		04
35	0503010180	7/16" SPRING WASHER		04
36	0503010797	3/4" X 4" BOLT		08
37	0503010023	3/4" SPRING WASHER		12
38	0503010014	3/4" NUT		12
39	0501053834	MALE QUICK COUPLER	8	02
40	0501053835	FEMALE QUICK COUPLER	7	02
41	0503010002	1800 GREASE FITTING		11
42	0501013233	5/8" X 2-3/4" BOLT		08
43	0503012412	5/8 UNC SELF LOCKING NUT		08
44	0521010572	0.9" X 2.9" COUPLING SHAFT		02
45	0503030085	LOCK PIN		02
46	0521010594	1.1" X 4.1" COUPLING SHAFT		06
47	0503031035	HAIR PIN		07
48	0503010019	1/2" SPRING WASHER		12
49	0503010060	1/2" NUT		12




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0501060409	HOSE SOPPORT ASSY		01
02	0503011442	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0511064229	LOCK PIN		01
02	0503030978	COMPRES SPRING		01
03	0503010131	3/16" X 1-1/2" COTTERPIN		01
04	0503010292	0.2" X 1.6" SPRING PIN		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HAIR PIN		01




Item	Code	Description	See page	QT
01	0521010681	BUSHING COUPLING BODY		01
02	0502040556	HITCH TURNER		01
03	0521010639	COUPLING SHAFT		01
04	0503010571	1/4" X 1.1/2 COTTERPIN		01




Item	Code	Description	See page	QT
01	0571017512	HITCH JOINT		01
02	0571017511	SLEEVE HITCH ARTICULATION		01
03	0502040850	U TRACTOR COUPLING		01
04	0571012612	PIVOT SHAFT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503016482	BOLT		02
11	0503033731	COMPRESSION SPRING LEFT		02
12	0503011331	3/8 BALL		02
13	0503010002	1800 GREASE FITTING		01
14	1882970002	GREASE SOAP		01
15	0503010378	CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0511069529	FRAME		01
02	0511069682	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8" X 2-1/4" BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8" NUT		08




Item	Code	Description	See page	QT
01	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	23	01
02	0531019171	1.25" X 7" COUPLING SHAFT		01
03	0521012536	COUPLING SHAFT		01
04	0503010523	1/4" X 2" COTTERPIN		02
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511064055	5" X 15" CYLINDER CASE		01
02	0511064056	BUSHING 2" X 14" TURNBUCLE		01
03	0502010382	5" END CAP		01
04	0502012227	50.80 X 127 RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	1870-2000-375-B GASKET		01
07	0503010952	W2-2250-500 RING		01
08	0503010351	2-425 N 3006-9B O'RING		01
09	0503011062	8-425 BACK-UP RING		01
10	0502010963	2.0" X 5.0" PISTON		01
11	0503010552	PACKING 3750-4250-625-B		02
12	0503010345	2-218 N 3006-9B O'RING		01
13	0503010974	W2-5000-500 RING		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503010003	1845 GREASE FITTING		01
16	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
01	0501058240	WHEEL FASTENER WITH TENSIONER	25	01
02	0503011119	7/8" X 6" BOLT		04
03	0501014251	FLAT WASHER		04
04	0503011254	7/8" HEX SELF ADJUSTING NUT		04
05	0501059909	CARRYING WHEELS SUPPORT	30	01
06	0503014887	2050 CHAIN X 80 LINK + REDUCTION		01
07	0502010584	CARRYING-WHEELS SUPPORT FIXER		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	26	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	28	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	29	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	27	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TIGHTENER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	27	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN UPPER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	27	01
03	0591017923	GLOVE 15.30 X 30 X 32		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0531016887	CARRYING WHEEL AXLE ARM		01
03	0503010523	1/4" X 2" COTTERPIN		01
04	0503010003	1845 GREASE FITTING		01
05	0511050681	TRACTION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0561016062	SPRING HITCH		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		04
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0511052770	WHEEL WITH TIRE	31	01
11	0501058241	WHEEL SUPPORT CHAIN TENSIONER	34	01
12	0521061565	WHEEL SUPPORT ARM		01
13	0503018981	BOLT		02
14	0521069983	WHEEL COVER		01
15	0591010589	BODY LOCK WHEEL		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	32	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	33	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01



Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSM AXLE CARRYING-WHEEL		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	37	01
15	0511051434	TRANSMISSION ACTUATOR	38	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	39	01
17	0521043316	RIGHT GEAR BOX ASSY	41	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	52	01
26	0501058234	LOWER CHAIN TENSIONER	53	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	54	01
28	0501058236	BEARING WITH 21Z GEAR	55	01
29	0501058237	16Z GEAR BEARING	56	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	57	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2" NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2" NUT		02
14	0501052560	MOTOR AXLE SIGNAL	37	01
15	0511051434	TRANSMISSION ACTUATOR	38	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	40	01
17	0521043317	LEFT GEAR BOX ASSY	42	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2" X 1.1/2" BOLT		02
23	0503010060	1/2" NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	52	01
26	0501058234	LOWER CHAIN TENSIONER	53	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	54	01
28	0501058236	BEARING WITH 21Z GEAR	55	01
29	0501058237	16Z GEAR BEARING	56	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	57	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01


Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8" SPRING WASHER		01
36	0501010984	FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	43	01
02	0511059266	CLOSED BEARING	45	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	47	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	49	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	50	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	51	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	44	01
02	0511059266	CLOSED BEARING	45	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN AXLE CONE		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2" NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	47	02
13	0503010292	0.2" X 1.6" SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	49	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	50	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	51	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TENSIONER LEVER		02
03	0503010292	0.2" X 1.6" SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING RECAMBIO		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	46	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	48	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503012882	BEARING		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0551019173	CHAIN SLEEVE TENSIONER		01
05	0511017302	FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019174	DOBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511057070	HOSE KIT HYDRAULIC		01
01A	0521052285	TC-TM HOSE ASSY		01
01AA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01AB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052287	TC-TM HOSE ASSY		01
01BA	0501080446	3/8 X" 169" TC-TM HOSE ASSY		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	8	02
03	0503013100	NYLON CLAMP		02
04	0581010091	SPRING PROTECTION PLASTIC HOSE		01




Item	Code	Description	See page	DIR	ESQ
01	0511052253	RH BEAM SUPPORT & METERING		01	00
01A	0521063436	FERTILIZER BEAN RIGHT SUPPORT		01	00
02	0511052254	LH BEAM SUPPORT & METERING		00	01
02A	0521063437	FERTILIZER BEAN LEFT SUPPORT		00	01
03	0511051558	LEFT SIDE FERTILIZER DISTRIBUTOR	60	00	05
04	0511051535	RIGHT SIDE FERTILIZER DISTRIBUTOR	61	05	00
05	0501010942	3/8" X 1-1/4" BOLT		20	20
06	0503011443	3/8" SPRING WASHER		20	20
07	0503010026	3/8" NUT		20	20
08	0511061759	22Z P12,70 FQ 3/4" GEAR		01	01
09	0521014167	CONE LOCK		01	01
10	0503030275	AGRICULTURAL BEARING		05	05
11	0502010685	18Z CONICAL GEAR		05	05
12	0551018213	3/4" X 1830 SQUARE SHAFT		01	01
13	0521010691	AXLE FASTENER		02	02
14	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02	02
15	0501010694	FLAT WASHER		02	02
16	0503011441	SPRING WASHER		02	02
17	0503010144	1/4" NUT		02	02
18	0501110392	SILO SUPPORT BEARING		01	01
19	0521012485	GEAR BOX BEARING AGRICUTURAL		01	01
20	0503011953	5/16" X 1" BOLT		02	02
21	0501010694	FLAT WASHER		02	02
22	0521011039	FLAT WASHER		02	02
23	0503011444	SPRING WASHER		02	02
24	0503010337	5/16" NUT		02	02
25	0551018055	22,65 X 60 SLEEVE		01	01
26	0503010003	1845 GREASE FITTING		01	01
27	0503010849	3/8" X 1-1/2" BOLT		08	08
28	0501010984	FLAT WASHER		17	17
29	0503010025	3/8" SPRING WASHER		08	08


Item	Code	Description	See page	DIR	ESQ
30	0503010026	3/8" NUT		08	08
31	0503034396	FERTILIZER SIDE COVER		05	05
32	0503010362	1/8" X 1.1/4" COTTERPIN		05	05
33	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		01	01
34	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02	02
35	0551019156	GEAR BOX LEVER LOCK		01	01
36	0503011953	5/16" X 1" BOLT		02	02
37	0501010694	FLAT WASHER		02	02
38	0503010179	LOCK WASHER		02	02
39	0503010337	5/16" NUT		02	02
40	0503010847	1/2" X 3.1/4" BOLT		01	01
41	0551019168	SLEEVE		01	01
42	0511069678	LH LOWER LEVER		01	01
43	0511017302	FLAT WASHER		03	03
44	0503010019	1/2" SPRING WASHER		02	02
45	0503010060	1/2" NUT		02	02
46	0551019167	SLEEVE UNION		01	01
47	0511069678	LH LOWER LEVER		01	01
48	0501013518	FLAT WASHER		02	02
49	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		01	01
50	0503010140	1/8" X 3/4" COTTERPIN		03	03
51	0511069678	LH LOWER LEVER		02	02
52	0503011336	1/2" HEX SELF ADJUSTING NUT		02	02
53	0551019115	LOCKING PLATFORM FIXATION		01	01
54	0501010096	3/8" X 2" BOLT		01	01
55	0503013357	3/8" SELF-ADJUSTING NUT		01	01
56	0551019159	LEVER FIXER BODY		01	01
57	0561016468	FASTENER		01	01




Item	Code	Description	See page	QT
01	0501110682	DISTRIBUTOR FERTILIZER WITH LEFT SIDE OUTLET		01
01A	0502012700	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010560	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031164	RIGHT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110676	SIDE FERTILIZER DISTRIBUTOR		01
01A	0502012688	SIDE FERTILIZER DISTRIBUTOR		01
01B	0571010542	FERTILIZER DISTRIBUTOR TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031165	LEFT HELICOID CONDUCTOR		01
06	0501010637	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0591017505	GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503011962	GREASE FITTING		01
12	0503010003	1845 GREASE FITTING		01
13	0503012826	CREASE FITTING		01




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	FLAT WASHER	16	
04	0503010025	3/8" SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0511069665	PLATFORM RIGHT	01	
07	0521062323	PLATFORM LEFT	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069656	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HAIR PIN		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01



Item	Code	Description	See page	QT
01	0502012329	DRAWBAR FIXATION REAR SUPPORT		02
02	0502012330	SUPPORT FIXER PIVOT		04
03	0503011084	3/4" X 5" BOLT		08
04	0501010322	FLAT WASHER		08
05	0503010023	3/4" SPRING WASHER		08
06	0503010014	3/4" NUT		08
07	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02
08	0561014393	COUPLING SHAFT		02
09	0503030119	LOCK PIN		04
10	0531063130	HEADER		01
11	0561019087	DRAWBAR TRANSPORT LOCK		01
12	0521010578	COUPLING SHAFT		01
13	0521010588	0.9" X 7.0" COUPLING SHAFT		01
14	0503030085	LOCK PIN		02
15	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING	02	
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
07	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
08	0503033008	ADHESIVE LABEL	02	
09	0503031428	READ MANUAL DECAL	01	
10	0503031942	ADHESIVE LABEL	01	
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
12	0503031565	ADHESIVE LABEL CARE	02	
13	0503031566	ADHESIVE LABEL	02	
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
15	0503031425	ADHESIVE LABEL ATTENTION	02	
16	0503031669	ADHESIVE LABEL	01	
17	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
19	0503032930	ADHESIVE LABEL DANGER	05	
20	0503031087	ADHESIVE LABEL	01	
21	0503034003	SERIAL NUMBER TAG 61 X 118	01	
22	0503010001	3.2 X 5.5 RIVET	04	
23	0503034078	LIFTING POINTS DECAL	03	
24	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
25	0503034500	ADHESIVE LABEL	01	

ASSY HEX AXLE


0909098921




Item	Code	Description	See page	3695	4045	4495	4845	5345
01	0571011601	SEXT AXIS 5/8 X 2005 PST4 8 S-0812	01	00	00	00	00	00
01.	0521013429	AXLE HEX 5/8 X 2180	00	01	00	00	00	00
01..	0561018352	RIGHT HEX SHAFT 5/8 X 2375	00	00	01	00	00	00
01...	0521013430	HEX AXLE 5/8 X 2580	00	00	00	01	00	00
01....	0561019214	HEX AXLE 5/8 X 2805 RIGHT	00	00	00	00	00	01
02	0571011600	SIXTH AXIS 5/8 X 1725	01	00	00	00	00	00
02.	0521013433	5/8" X 75" AXLE HEX	00	01	00	00	00	00
02..	0561018353	5/8 X 2150 LEFT HEX AXLE	00	00	01	00	00	00
02...	0521013434	HEX AXLE 5/8 X 2300	00	00	00	01	00	00
02....	0561019215	HEX AXLE 5/8 X 2555 LEFT	00	00	00	00	00	01
03	0503010571	1/4" X 1.1/2 COTTERPIN	02	02	02	02	02	02
04	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"	02	02	02	02	02	02
05	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8	02	02	02	02	02	02
06	0503010003	1845 GREASE FITTING	02	02	02	02	02	02
07	0503010365	NUT	04	04	04	04	04	04
08	0501010984	FLAT WASHER	04	04	04	04	04	04
09	0501010694	FLAT WASHER	08	08	08	08	08	08
10	0503010179	LOCK WASHER	04	04	04	04	04	04
11	0503010337	5/16" NUT	04	04	04	04	04	04
12	0511015098	FLAT WASHER	02	02	02	02	02	02
13	0511017305	FLAT WASHER	04	04	04	04	04	04
14	0511065562	20Z GEAR	02	02	02	02	02	02
15	0502011299	BUSHING GEAR	02	02	02	02	02	02
16	0503010010	1/4" X 2.1/2" COTTERPIN	02	02	02	02	02	02




Item	Code	Description	See page	QT
01	0521066608	LIFTING HOOK		01
02	0581019707	FIXATION SUPPORT SUPPORT		01
03	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
04	0501012140	FLAT WASHER		04
05	0503012412	5/8 UNC SELF LOCKING NUT		04




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0531054249	INDIVIDUAL SHORT SEED ROW	74	01
02	0531054248	INDIVIDUAL LONG SEED ROW	86	01
03	0511053252	FERTILIZER SHORT ROW WITH LEFT DDD/18" DC	90	01
04	0511053253	FERTILIZER LONG ROW WITH RIGHT DDD/18" DC	97	01
05	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	101	01
06	0503031050	CURVED CONDUCTOR		01
07	0503010246	CLAMP		01
08	0501013714	STABILIZER BAR		01
09	0501018652	CORN STABILIZER BAR		01
10	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
11	0511017969	0.1" SPACING PLATE		01
12	0503010905	1/2" X 2-1/4" BOLT		01
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2" NUT		01
15	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
16	0501010984	FLAT WASHER		01
17	0503010025	3/8" SPRING WASHER		01
18	0503010026	3/8" NUT		01
19	0521069124	BOCAL FILLED LINE PIVOTED WITH LINGUET		01
20	0503063647	SIGMA CORN DISC SET	111	01
21	0503063648	SIGMA SOY DISC SET	112	01




Item	Code	Description	See page	QT
01	0511056600	FRONT LINE SEED SHORT DDD RIGHT	75	01
02	0511058212	ASSY LINE SUPPORT FERTILIZER	81	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0511060376	SEEP SPRING GUIDE		01
06	1902012538	SPRING ROD SUPPORT		01
07	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
08	0511017302	FLAT WASHER		03
09	0503011336	1/2" HEX SELF ADJUSTING NUT		02
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8" X 1" COTTERPIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		02
13	0501018535	1/2 X 1 BOLT		02
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
16	0501013753	FLAT WASHER		01
17	0503010013	5/8" NUT		01
18	0511052024	FAST CLOSING SET	82	01
19	0531053925	SIGMA SOY INDIVIDUAL SEED SYSTEM	83	01
20	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
22	0503010019	1/2" SPRING WASHER		01
23	0503010060	1/2" NUT		01
24	0503011099	GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521062183	SHORT SEED ROW ARM		01
02	0502011830	ARTICULACCION SUPPORT		01
03	0521018079	SEEP ROW DRAWBAR COVER		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		02
08	0503010060	1/2" NUT		02
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0503011440	SPRING WASHER		04
13	0503010060	1/2" NUT		04
14	0501013354	FLAT WASHER		02
15	0502011400	18Z CONICAL GEAR		01
16	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
17	0502011505	18Z CONICAL GEAR		01
18	0521018077	1/2" X 58.6" HEX AXLE		01
19	0501013352	FLAT WASHER		04
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	76	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04
25	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
26	0503011440	SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	77	01




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502011411	10Z CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	78	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	79	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	80	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O-RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0531051514	SIGMA SOY SEED SYSTEM	84	01
02	0503063602	SEMI-ASSEMBLED SIGMA INDIVIDUAL SEED BOX		01
03	0503010179	LOCK WASHER		04
04	0501010694	FLAT WASHER		04
05	0503010240	BOLT		04
06	0503035691	ADHESIVE LABEL		02




Item	Code	Description	See page	QT
01	0511057289	ASSY SEED DEFLECTOR	85	01
02	0503030083	3/8" X 3/8" X 1.6" STUD		02
03	0503010675	5/16" X 2.1/4" BOLT		01
04	0503010179	LOCK WASHER		01
05	0503010337	5/16" NUT		01
06	0502012974	LOWER SEED DISK TRACK		01
07	0501013518	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		02
09	0503010209	3/8" UNC BUTTERFLY NUT		02
10	0503016282	ALLEN BOLT		01
11	0503019913	SELF-LOCKING NUT W/ NYLON M8 X 1.25 C.8 ZN		01
12	0503035299	PLATE SPRING 16 X 8.2 X 0.90		02
13	0591018706	SEED BOX SUPPORT		01
14	0513010140	SOYA DISK SOCIDISC 90 HOLES		01
15	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461		01
16	0503063405	SOY SEED DISTRIBUTOR BOX		01




Item	Code	Description	See page	QT
01	0503010025	3/8" SPRING WASHER		01
02	0503010209	3/8" UNC BUTTERFLY NUT		01
03	0571018536	HEX PRISONER		01
04	0501013518	FLAT WASHER		02
05	0503034131	DEFLECTOR		01




Item	Code	Description	See page	QT
01	0511056601	LONG SEED ROW FRONT DDD LEFT	87	01
02	0511058212	ASSY LINE SUPPORT FERTILIZER	81	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0511060376	SEEP SPRING GUIDE		01
06	1902012538	SPRING ROD SUPPORT		01
07	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
08	0511017302	FLAT WASHER		03
09	0503011336	1/2" HEX SELF ADJUSTING NUT		02
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8" X 1" COTTERPIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		02
13	0501018535	1/2 X 1 BOLT		02
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
16	0501013753	FLAT WASHER		01
17	0503010013	5/8" NUT		01
18	0511052024	FAST CLOSING SET	82	01
19	0531053925	SIGMA SOY INDIVIDUAL SEED SYSTEM	83	01
20	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
22	0503010019	1/2" SPRING WASHER		01
23	0503010060	1/2" NUT		01
24	0503011099	GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521062184	LONG SEED ROW ARM		01
02	0502011830	ARTICULACION SUPPORT		01
03	0521018079	SEEP ROW DRAWBAR COVER		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		02
08	0503010060	1/2" NUT		02
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0503011440	SPRING WASHER		04
13	0503010060	1/2" NUT		04
14	0501013354	FLAT WASHER		02
15	0502011400	18Z CONICAL GEAR		01
16	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
17	0502011505	18Z CONICAL GEAR		01
18	0521018078	1/2" X 66.5" HEX AXLE		01
19	0501013352	FLAT WASHER		04
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	76	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04
25	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
26	0503011440	SPRING WASHER		02
27	0503010060	1/2" NUT		02
28	0511056586	15 X 15 SEED DDD LEFT	88	01




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	89	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	79	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	80	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511015098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT 91 DOUBLE DISC		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	93	01
07	0501058423	FERTILIZER ROD SPRING ROW	96	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	92	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	80	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	79	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0503010003	1845 GREASE FITTING		01
03	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
04	0521014137	RIGHT ARM OF THE BLADE DISC		01
05	0521014138	SUPPORT ARM LEFT BALDE DISC		01
06	0521054686	CUTTING DISC BOX 18	94	01
07	0503010756	0.2" X 2.4" SPRING PIN		01
08	0503010361	SPRING PIN		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	1902020394	SPRING SUPPORT		01
14	1902020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0503010014	3/4" NUT		02
17	0541018684	FLAT WASHER		01
18	0503013185	3/4" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2" NUT		01
21	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
001	0521054679	DISC CUTTING BOX WITHOUT DISC	95	01
002	0603026013	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0502011562	DC BOX		01
02	0502020641	BLADE DISC FLANGE		01
03	0503010276	6206 BALL BEARING		02
04	0521013610	BLADE DISC HUB AXLE		01
05	0503010179	LOCK WASHER		06
06	0503012417	SEAL		02
07	0503011800	SEAL RING		02
08	0503010691	1/4" GREASE FITTING		01
09	0521015376	DUST CLOAK		02
10	0503030832	FLAT WASHER		02
11	0511015346	FLAT WASHER		02
12	0521013510	3/4" NUT		02
13	0503010012	1" SPRING WASHER		02
14	0503010371	5/16" X 1" BOLT		06
15	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		02
09	0503010060	1/2" NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	98	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	100	01
07	0501058423	FERTILIZER ROD SPRING ROW	96	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02
05	0521061153	LONG ARM FERTILIZER LINE		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	99	01




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	79	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	80	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511015098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0503010003	1845 GREASE FITTING		01
03	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE		01
04	0521014137	RIGHT ARM OF THE BLADE DISC		01
05	0521014138	SUPPORT ARM LEFT BALDE DISC		01
06	0521054686	CUTTING DISC BOX 18	94	01
07	0503010756	0.2" X 2.4" SPRING PIN		01
08	0503010361	SPRING PIN		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	1902020394	SPRING SUPPORT		01
14	1902020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0503010014	3/4" NUT		02
17	0541018684	FLAT WASHER		01
18	0503013185	3/4" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2" NUT		01
21	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	102	01
02	0501052538	DEPTH BAND WITH ARMS	107	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	108	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	109	01
07	0503033942	COVER REGULATORY WHEEL		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	103	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	104	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	106	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	SCREWEW 3/8 UNC X 3/4		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL BOX	105	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL BOX	105	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	COVER DEPTH		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	SEED SIST CONTROL DEPTH LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	110	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	110	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03



Item	Code	Description	See page	QT
01	0513010117	SOCIDISCO CORN DISC 28 HOLES 9,0 AMC9R-002130	01	01
02	0513010118	SOCIDISCO CORN DISC 28 HOLES 9,5 VLD9.5R-002115	01	01
03	0513010119	SOCIDISCO CORN DISC 28 HOLES 10 SAL10R-002619	01	01
04	0513010120	SOCIDISCO CORN DISC 28 HOLES 10,5 RSP10.5R-002133	01	01
05	0513010121	SOCIDISCO CORN DISC 28 HOLES 11 LRA11R-002134	01	01
06	0513010122	SOCIDISCO CORN DISC 28 HOLES 11,5 MAG11.5R-002620	01	01
07	0513010123	SOCIDISCO CORN DISC 28 HOLES 12 VDA12R-002621	01	01
08	0513010124	SOCIDISCO CORN DISC 28 HOLES 12,5 AMP12.5R-002131	01	01
09	0513010125	SOCIDISCO CORN DISC 28 HOLES 13 VMV13R-002132	01	01
10	0513010126	SOCIDISCO CORN DISC 28 HOLES 13,5 RXR13.5R-002136	01	01
11	0513010187	SOCIDISCO CORN DISC 28 HOLES 14,8 X 10 VM4-002581	01	01
12	0513010188	SOCIDISCO CORN DISC 28 HOLES 11 X 8 BR8.1-002589	01	01
13	0513010189	SOCIDISCO CORN DISC 28 HOLES 12,5 X 8,5 AZ8.2-002587	01	01
14	0513010164	SOCIDISCO FLAT RING FOR CORN AMFOSLISO-002127	01	01
15	0513010159	SOCIDISCO RING FOR CORN 0,8MM LRFOSSR08-002120	01	01
16	0513010160	SOCIDISCO RING FOR CORN 1,4MM VMFOSR1.4-002245	01	01
17	0513010163	SOCIDISCO RING FOR CORN 2,0MM VDFOSR2-002116	01	01
18	0503063413	CORN SEED DISTRIBUTOR BOX 4Z - 001798	01	01



Item	Code	Description	See page	QT
01	0513010136	SOCIDISCO SOY DISC 62 HOLES 7,5 LRA62.75-002357		01
02	0513010137	SOCIDISCO SOY DISC 62 HOLES 8,0 RSP62.80-002358		01
03	0513010138	SOCIDISCO SOY DISC 62 HOLES 8,5 RXR62.85-002359		01
04	0513010139	SOCIDISCO SOY DISC 62 HOLES 9,0 AZM62.90-002360		01
05	0513010141	SOCIDISCO SOY DISC 90 HOLES 8,0 RSP90.80-002287		01
06	0513010142	SOCIDISCO SOY DISC 90 HOLES 8,5 RXR90.85-002317		01
07	0513010143	SOCIDISCO SOY DISC 90 HOLES 9,0 AZM90.90-002288		01
08	0513010158	SOCIDISCO FLAT RING FOR SOY AZMSOJALISO-002243		01
09	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461		01
10	0513010162	SOCIDISCO RING FOR SOY 1,5MM RSPSOJASR1,5-002244		01
11	0503063412	4Z SOY/BEAN SEED DISTRIBUTOR BOX - 001804		01



MARCHESAN

Technical Publications | Elaboration and Revision

LORENA ROCHA ALVES

www.marchesan.com.br

