

ROW CROP PLANTERS

PDCP 2400/3150 (FROM 04/2022)

Code: 0501093307
Series: S-1117
Revision: 00
Date Revision: MAIO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS

Code	Description
0111130056	PDCP 2400/11F-E200 S/DC P.1 S-1117
0111130064	PDCP 2400/13F-E170 DPLE P.1 S-1117
0111130080	PDCP 2400/13F-E170 DPLE P.3/4 S-1117
0111130057	PDCP 2400/13F-E170 S/DC P.1 S-1117
0111130062	PDCP 2400/13F-E170/5G ESPECIAL S-1117
0111130063	PDCP 2400/13F-E170/6G ESPECIAL S-1117
0111130054	PDCP 2400/3G-E900 DC CPF P.2 S-1117
0111130055	PDCP 2400/4G-E700 CPF DC P.2 S-1117
0111130060	PDCP 2400/7F-E300 DC P.1 S-1117
0111130059	PDCP 2400/7F-E300 S/DC P.1 S-1117
0111130058	PDCP 2400/9F-E250 S/DC P.1 S-1117
0111130067	PDCP 2400/9F/3G ESPECIAL S-1117
0111130061	PDCP 2400/9F/3G ESPECIAL S-1117
0111130065	PDCP 2400/9F/5G ESPECIAL S-1117
0111130066	PDCP 2400/9F/5G ESPECIAL S-1117
0111130069	PDCP 3150/11F-E250 S/DC P.1 S-1117
0111130073	PDCP 3150/12F/4G ESPECIAL S-1117
0111130070	PDCP 3150/13F ESPECIAL S/DC P.1 S-1117
0111130075	PDCP 3150/15F/7G ESPECIAL S-1117
0111130072	PDCP 3150/17F-E170 DC P.1 ENGR 60Z S-1117
0111130071	PDCP 3150/17F-E170 DPLE P.1 S-1117
0111130081	PDCP 3150/17F-E170 DPLE P.3/4 S-1117
0111130068	PDCP 3150/17F-E170 S/DC P.1 S-1117
0111130078	PDCP 3150/17F/4G ESPECIAL S-1117
0111130079	PDCP 3150/17F/4G ESPECIAL S-1117
0111130077	PDCP 3150/17F/5G ESPECIAL S-1117
0111130076	PDCP 3150/17F/7G ESPECIAL S-1117
0111130074	PDCP 3150/4G-E900 CPV BORR P.2 S-1117

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909096303	ASSY FRAME - 2400/3150	1
0521051468	FRONT LOCK	2
0521051469	LOCK NUT	3
0521051953	RODE RIGHT	4
0521051936	LEFT WHEEL	5
0521054104	LEFT WHEEL	6
0511058443	HYDRAULIC CYLINDER	7
0501058239	WHEEL CHAIN TENSIONER BEARING	8
0511040424	RH TRANSMISSION DRIVING ASSY	9
0501049265	LH TRANSMISSION DRIVING ASSY	10
0501056450	5/8 DOUB BEARING SEED TRANSMISSION	11
0501048790	AXLE WITH RING	12
0501056444	BEARING WITH ROLLING	13
0501056271	GEARBOX CLOSED BEARING	14
0501054284	STRETCHER CURRENT TRANSMISSION SIDE	15
0521054094	SEED/FERTILIZER BOX ASSY	16
0511047567	SEED/FERTILIZER BOX ASSY	17
0521054106	SEED/FERTILIZER BOX ASSY	18
0511057576	SEED/FERTILIZER BOX ASSY	19
0521054095	SEED/FERTILIZER BOX ASSY	20
0511040931	SEED/FERTILIZER BOX ASSY	21
0521054107	SEED/FERTILIZER BOX ASSY	22
0511057578	SEED/FERTILIZER BOX ASSY	23
0521054096	SEED/FERTILIZER BOX ASSY	24
0501058661	SEED/FERTILIZER BOX ASSY	25
0521054108	SEED/FERTILIZER BOX ASSY	26
0511057577	SEED/FERTILIZER BOX ASSY	27
0521054097	SEED/FERTILIZER BOX ASSY	28
0501053953	SEED/FERTILIZER BOX ASSY	29
0521054109	SEED/FERTILIZER BOX ASSY	30
0511057579	SEED/FERTILIZER BOX ASSY	31
0501053303	KIT DISTRIBUTOR	32
0501052990	AGRICULTURAL BEARING	33
0501053788	3/4 SQUARE AXLE FASTENER	34
0511047568	DISTRIBUTOR FERTILIZER	35
0521054098	DISTRIBUTOR FERTILIZER	36
0503050060	SEED DISTRIBUTOR BOX SWITCH	37
0511056736	HOSE SUPPORT	38
0511050129	SUPPORT ASSEMBLE	39
0521051945	STIRRUP	40
0521051946	FRONT PLATFORM	41
0521051983	FRONT PLATFORM SET	42
0521051954	TRANSMISSION ASSY	43
0909098593	TRANSMISSION ASSY	44
0501052973	LEFT RATCHET CHAIN TENSIONER	45
0501052972	RIGHT RATCHET CHAIN TENSIONER	46
0501053296	BEARING WITH 17Z GEAR	47
0501054355	LARGE SEED CHAIN TENSIONER	48
0501053952	SEED DOUBLE BEARING INTERM	49
0501053950	FINE SEED ASSY INTERMEDIATE BEARING	50
0501053951	FERTILIZER MIDDLEMAN BEARING ASSY	51
0501053935	SEED BEARING INTERM ASSY	52
0521051948	HANDRAIL ASSEMBLE	53
0521051949	SET HIDRAULICO	54
0521051984	SET HIDRAULICO	55



MARCHESAN

INDEX


0501053834	MALE QUICK COUPLER	56
0511057534	FLOW DIVIDING VALVE	57
0521051950	HEADER ASSY	58
0521051985	HEADER ASSY	59
0501051160	TRACTOR HITCH PIN	60
0521051951	MANUAL CANISTER ASSY	61
0521051955	SET LABEL ADHESIVE	62
0521054101	SET LABEL ADHESIVE	63
0521054111	SET LABEL ADHESIVE	64
0521051986	SET LABEL ADHESIVE	65
0511051394	DRAWBAR TURNBUCKLE	66
0501047881	AXIS JOINT ASSY	67
0909096304	ASSY SEED/FERTILIZER ROW	68
0511046443	RIGHT FERTILIZER/FINE SEED ROW WITH 16" RIBBED DISC	69
0511046442	LEFT FERTILIZER/FINE SEED ROW WITH 16" RIBBED DISC	70
0511040905	RIGHT FERTILIZER/FINE SEED ROW WITH 16" SMOOTH DISC	71
0511041019	LEFT FERTILIZER/FINE SEED ROW WITH 16" SMOOTH DISC	72
0511041103	RIGHT FERTILIZER/FINE SEED ROW WITHOUT DISC	73
0511041104	LEFT FERTILIZER/FINE SEED ROW WITHOUT DISC	74
0511045468	RIGHT FERTILIZER/FINE SEED ROW WITH 16" SMOOTH DISC	75
0511045469	LEFT FERTILIZER/FINE SEED ROW WITH 16" SMOOTH DISC	76
0531054172	RIGHT LARGE SEED ROW WITH RUBBER V-COMPACTOR	77
0531054171	LEFT LARGE SEED ROW WITH RUBBER V-COMPACTOR	78
0531054174	RIGHT LARGE SEED ROW WITH IRON V-COMPACTOR	79
0531054173	LEFT LARGE SEED ROW WITH IRON V-COMPACTOR	80
0511040908	FERTILIZER ROW WITH RIGHT NOZZLE/16" SMOOTH DISC	81
0511040925	FERTILIZER ROW WITH LEFT NOZZLE/16" SMOOTH DISC	82
0511040938	FERTILIZER ROW WITH RIGHT NOZZLE	83
0511040939	FERTILIZER ROW WITH LEFT NOZZLE	84
0511055820	FERTILIZER ROW WITH RIGHT NOZZLE/16" RIBBED DISC	85
0511055821	FERTILIZER ROW WITH LEFT NOZZLE/16" RIBBED DISC	86
0511058212	ASSY LINE SUPPORT FERTILIZER	87
0511046441	SHORT BLADE DISC STRIATED	88
0501058030	ESTR DISC BLADE DISC ASSY	89
0501054473	RIGHT 15 X 15 UNAL DOUBLE-DISC	90
0501054151	RIGHT DOUBLE DISC COULTER BOX	91
0501056200	RIGHT ROD STOP SCRAPER	92
0501046839	RIGHT IRON PRESS WHEEL	93
0501053187	LEFT IRON PRESS WHEEL ASSY	94
0501054474	LEFT 15 X 15 UNAL DOUBLE-DISC	95
0501046844	LEFT IRON PRESS WHEEL ASSY	96
0501053186	RIGHT IRON PRESS WHEEL ASSY	97
0511044553	BLADE DISC ASSY	98
0501053938	16 DPL BLADE DISC	99
0531054348	FRONT LARGE SEED ROW	100
0501053826	BEARING WITH 17Z GEAR	101
0501053552	UPPER SIDE BEARING	102
0501053553	UPPER CENTER BEARING	103
0511059247	BEARING WITH GEAR LINE PIVOTED PRECISION PLANTING	104
0501053949	SEED AXLE TENSIONER CHAIN LINE	105
0501055112	MICRO GRANULATED CHAIN TENSIONER	106
0531054346	RIGHT REAR SEED ROW	107
0501052978	RIGHT 15" X 15" DOUBLE DISC	108
0531054347	LEFT REAR SEED ROW	109
0501052979	LEFT 15" X 15" DOUBLE DISC	110



MARCHESAN

INDEX

0501054167	BOX DDD ASSY DPL 15 RIGHT		111
0501054168	BOX DDD ASSY DPL 15 LEFT		112
0511040703	DEPTH WHEEL ASSY		113
0501053714	DEPTH REGULATOR W/ BOX		114
0501056749	DEPTH CONTROL WHEEL RUBBER BAND		115
0531054345	IRON-V COMPACTOR WHEEL		116
0501052957	IRON V PRESS WHEELS		117
0511053857	FAST CLOSING SET		118
0531053929	SIGMA SEED SYSTEM WITH INDIVIDUAL BOX (SOY)		119
0503063602	SEMI-ASSEMBLED SIGMA INDIVIDUAL SEED BOX		120
0531052814	SIGMA SEED SYSTEM (SOY)		121
0511057289	ASSY SEED DEFLECTOR		122
0501054145	PRESS WHEELS ASSY		123
0501052908	COMPACTOR WHEEL WITH BEARING		124
0503063647	SIGMA CORN DISC SET		125
0503063648	SIGMA SOY DISC SET		126




Item	Code	Description	See page	2400	3150
01	0511063577	FRAME 2400		01	00
02	0511063870	FRAME 3150		00	01
03	0521051468	FRONT LOCK	2	02	02
04	0521051469	LOCK NUT	3	02	02
05	0521051953	RODE RIGHT	4	01	01
06	0521051936	LEFT WHEEL	5	01	01
07	0521054104	LEFT WHEEL	6	01	01
08	0521054094	SEED/FERTILIZER BOX ASSY	16	01	00
09	0511047567	SEED/FERTILIZER BOX ASSY	17	01	00
10	0521054106	SEED/FERTILIZER BOX ASSY	18	00	01
11	0511057576	SEED/FERTILIZER BOX ASSY	19	00	01
12	0521054095	SEED/FERTILIZER BOX ASSY	20	01	00
13	0511040931	SEED/FERTILIZER BOX ASSY	21	01	00
14	0521054107	SEED/FERTILIZER BOX ASSY	22	00	01
15	0511057578	SEED/FERTILIZER BOX ASSY	23	00	01
16	0511056736	HOSE SUPPORT	38	01	01
17	0511050129	SUPPORT ASSEMBLE	39	01	01
18	0521051945	STIRRUP	40	01	01
19	0521051946	FRONT PLATFORM	41	01	00
20	0521051983	FRONT PLATFORM SET	42	00	01
21	0521051954	TRANSMISSION ASSY	43	01	00
22	0909098593	TRANSMISSION ASSY	44	00	01
23	0521051948	HANDRAIL ASSEMBLE	53	01	01
24	0521051949	SET HIDRAULICO	54	01	00
25	0521051984	SET HIDRAULICO	55	00	01
26	0521051950	HEADER ASSY	58	01	00
27	0521051985	HEADER ASSY	59	00	01
28	0521051951	MANUAL CANISTER ASSY	61	01	01
29	0521051955	SET LABEL ADHESIVE	62	01	00
30	0521054101	SET LABEL ADHESIVE	63	01	00
31	0521054111	SET LABEL ADHESIVE	64	00	01

Item	Code	Description	See page	2400	3150
32	0521051986	SET LABEL ADHESIVE	65	00	01
33	0503034003	SERIAL NUMBER TAG 61 X 118		01	01
34	0503010001	3.2 X 5.5 RIVET		04	04
35	0511051394	DRAWBAR TURNBUCKLE	66	01	01
36	0503032624	SILO FERTILIZER GUTTER		06	06
37	0501047881	AXIS JOINT ASSY	67	01	01
38	0503011750	AMENDMENT WITH LOCK		04	04
39	0503011751	REDUCTION		04	04
40	0503010543	AMENDMENT WITH LOCK		02	02
41	0503010780	N-2050 AMENDMENT		02	02
42	0521013022	TRANSPORT LOCK		02	02
43	0501068994	0.3" X 3.1" LOCK PIN		02	02
44	0503030168	CUPILLA		02	02
45	0501047885	ROD STOP		02	02
46	0501047886	ROD STOP		02	02
47	0501047887	ROD STOP		02	02
48	0521010578	COUPLING SHAFT		01	01
49	0503030085	LOCK PIN		02	02
50	0511015511	WRENCH		02	02
51	0511015423	WRENCH SUPPORT		01	01
52	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01	01
53	0503010025	3/8" SPRING WASHER		01	01
54	0503010026	3/8" NUT		01	01
55	0503014120	CHAIN		01	01
56	0503014321	CABLE STEEL SHACKLE		02	02
57	0909096304	ASSY SEED/FERTILIZER ROW	68	01	01

FRONT LOCK


0521051468




Item	Code	Description	See page	QT
001	0521068041	ROW FRONT		01
002	0501011543	5/8" X 4" BOLT		02
003	0503012412	5/8 UNC SELF LOCKING NUT		04
004	0502010175	HITCH CLAMP		01
005	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		02
006	0581014982	LOCK FIXATION SUPPORT		01

LOCK NUT

0521051469



Item	Code	Description	See page	QT
001	0521068042	SPEED LOCK		01
002	0501011543	5/8" X 4" BOLT		02
003	0503012412	5/8 UNC SELF LOCKING NUT		04
004	0502010175	HITCH CLAMP		01
005	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		02
006	0581014980	FIXD TRAVA		01




Item	Code	Description	See page	QT
001	0503010179	LOCK WASHER		10
002	0503010337	5/16" NUT		10
003	0503010002	1800 GREASE FITTING		01
004	0503011953	5/16" X 1" BOLT		06
005	0521010530	COUPLING SHAFT		01
006	0503010140	1/8" X 3/4" COTTERPIN		04
007	0503010365	NUT		02
008	0503011907	PMC 594-S NYLON LUG		01
009	0503010363	5/16" X 1" BOLT		02
010	1902010175	HITCH CLAMP		02
011	0501010216	3/4" X 4-1/2" BOLT		04
012	0503010023	3/4" SPRING WASHER		04
013	0503010014	3/4" NUT		04
014	0511017302	FLAT WASHER		01
015	0503010060	1/2" NUT		04
016	0503010019	1/2" SPRING WASHER		17
017	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		04
018	0531014897	GEAR BOX COVER		01
019	0501110627	WHEEL PIVOT BEARING		02
020	0531014895	MOTOR SHAFT 427		01
021	0503010004	1890 GREASE FITTING		02
022	0561013022	BEARING EXTERNAL LOCK		02
023	0503010398	501082 CLAMPING RING (FOR AXLE)		02
024	0561013020	KM 12 NUT		02
025	0501018466	FLAT WASHER		08
026	0511063619	DISARM/ARM PIVOT ARM		01
027	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX		01
027A	0511052766	CARRYING WHEEL HUB ASSY		01
027B	0503062158	EEE WHEEL WITH TIRE 700 X 16-10L ASSY		01
028	0551018252	CHAIN TIGHTENER AXLE		01
029	0501058239	WHEEL CHAIN TENSIONER BEARING	8	01

Item	Code	Description	See page	QT
030	0521010479	SLEEVE ARTICULATION		01
031	0503011336	1/2" HEX SELF ADJUSTING NUT		01
032	0503013034	2050 CHAIN X 64 LINK + REDUCTION		01
033	0561013021	BEARING INNER LOK		02
034	0503011167	M16 X 2 X 30 BOLT		02
035	0503010027	5/8" SPRING WASHER		02
036	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
037	0503010834	1/2 X 1 BOLT		04
038	0511063568	RIGHT GANG CARRYING-WHEEL SUPPORT		01
039	0511058443	HYDRAULIC CYLINDER	7	01
040	0521068148	RIGHT ARM		01
041	0531015192	COVER ARTICULAT SLEEVE		02
042	0501010694	FLAT WASHER		02
043	0501069585	17Z P5/8" GEAR ROUND HOLE 1.4"		01
044	0511060719	DISARMMENT/ARM PIVOT ARM		01
045	0501010984	FLAT WASHER		03
046	0501017779	32 X 60 X 4.75 FLAT WASHER		02
047	0503010523	1/4" X 2" COTTERPIN		01
048	0503010257	1/8" X 1" COTTERPIN		01
049	0502040534	SPRING GUIDE BUSHING LOCK		01
049A	1902012196	SPRING GUIDE LOCK SLEEVE		01
050	0501018535	1/2 X 1 BOLT		01
051	0521010546	1.2" X 5.7" COUPLING SHAFT		01
052	0501013753	FLAT WASHER		01
053	0511063920	SPRING GUIDE		01
054	0503031823	1" X 250 X 3,8 COMPRESSION SPRING		01
055	0521017623	0.5" X 1.5" COUPLING SHAFT		01
056	0503013232	1/2' BOLT		09
057	0511040424	RH TRANSMISSION DRIVING ASSY	9	01
058	0581015541	RH CHAIN PROTECTION CAP		01
059	0511063583	TRANSMISSION AXLE GEAR		01
060	0503011136	BOLT 1/2 UNC X 1/2 S C S I 12.9		01
061	0561014215	BEARING COVER LOWER ROW FRAME		03

LEFT WHEEL

0521051936



Item	Code	Description	See page	QT
001	0503010179	LOCK WASHER		10
002	0503010337	5/16" NUT		10
003	0503010002	1800 GREASE FITTING		01
004	0503011953	5/16" X 1" BOLT		06
005	0521010530	COUPLING SHAFT		01
006	0503010140	1/8" X 3/4" COTTERPIN		04
007	0503010365	NUT		02
008	0503011907	PMC 594-S NYLON LUG		01
009	0503010363	5/16" X 1" BOLT		02
010	1902010175	HITCH CLAMP		02
011	0501010216	3/4" X 4-1/2" BOLT		04
012	0503010023	3/4" SPRING WASHER		04
013	0503010014	3/4" NUT		04
014	0511017302	FLAT WASHER		01
015	0503010060	1/2" NUT		04
016	0503010019	1/2" SPRING WASHER		17
017	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		04
018	0531014897	GEAR BOX COVER		01
019	0501110627	WHEEL PIVOT BEARING		02
020	0531014895	MOTOR SHAFT 427		01
021	0503010004	1890 GREASE FITTING		02
022	0561013022	BEARING EXTERNAL LOCK		02
023	0503010398	501082 CLAMPING RING (FOR AXLE)		02
024	0561013020	KM 12 NUT		02
025	0501018466	FLAT WASHER		08
026	0511063619	DISARM/ARM PIVOT ARM		01
027	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX		01
027A	0511052766	CARRYING WHEEL HUB ASSY		01
027B	0503062158	EEE WHEEL WITH TIRE 700 X 16-10L ASSY		01
028	0551018252	CHAIN TIGHTENER AXLE		01
029	0501058239	WHEEL CHAIN TENSIONER BEARING	8	01


LEFT WHEEL

0521051936

Item	Code	Description	See page	QT
030	0521010479	SLEEVE ARTICULATION		01
031	0503011336	1/2" HEX SELF ADJUSTING NUT		01
032	0503013034	2050 CHAIN X 64 LINK + REDUCTION		01
033	0561013021	BEARING INNER LOK		02
034	0503011167	M16 X 2 X 30 BOLT		02
035	0503010027	5/8" SPRING WASHER		02
036	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
037	0503010834	1/2 X 1 BOLT		04
038	0511063615	LEFT GANG CARRYING-WHEEL SUPPORT		01
039	0511058443	HYDRAULIC CYLINDER	7	01
040	0521068147	LEFT ARM		01
041	0531015192	COVER ARTICULAT SLEEVE		02
042	0501010694	FLAT WASHER		02
043	0501069585	17Z P5/8" GEAR ROUND HOLE 1.4"		01
044	0511060719	DISARMMENT/ARM PIVOT ARM		01
045	0501010984	FLAT WASHER		03
046	0501017779	32 X 60 X 4.75 FLAT WASHER		02
047	0503010523	1/4" X 2" COTTERPIN		01
048	0503010257	1/8" X 1" COTTERPIN		01
049	0502040534	SPRING GUIDE BUSHING LOCK		01
049A	1902012196	SPRING GUIDE LOCK SLEEVE		01
050	0501018535	1/2 X 1 BOLT		01
051	0521010546	1.2" X 5.7" COUPLING SHAFT		01
052	0501013753	FLAT WASHER		01
053	0511063920	SPRING GUIDE		01
054	0503031823	1" X 250 X 3,8 COMPRESSION SPRING		01
055	0521017623	0.5" X 1.5" COUPLING SHAFT		01
056	0503013232	1/2' BOLT		09
057	0501049265	LH TRANSMISSION DRIVING ASSY	10	01
058	0581015540	LEFT CHAIN PROTECTION CAP		01
059	0511063583	TRANSMISSION AXLE GEAR		01
060	0503011136	BOLT 1/2 UNC X 1/2 S C S I 12.9		01
061	0561014215	BEARING COVER LOWER ROW FRAME		03

LEFT WHEEL

0521054104




Item	Code	Description	See page	QT
001	0511063615	LEFT GANG CARRYING-WHEEL SUPPORT		01
002	0501056450	5/8 DOUB BEARING SEED TRANSMISSION	11	01
003	0503012163	5/16" X 1-1/2" BOLT		02
004	0503010179	LOCK WASHER		14
005	0503010337	5/16" NUT		14
006	0511060396	DRIVE/DRIVEN AXLE CONE		02
007	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		02
008	0503012389	1/2 BALL		02
009	0503010395	1/2" X 1-1/4" BOLT		02
010	0503030303	SUPPORT WASHER		04
011	0501069874	GEAR 17Z P 15,87 FQ 3/4		01
012	0502011758	REAR TENSIONER LEVER		01
013	0501048790	AXLE WITH RING	12	01
014	0503010292	0.2" X 1.6" SPRING PIN		06
015	0503010002	1800 GREASE FITTING		01
016	0501056444	BEARING WITH ROLLING	13	02
017	0501056271	GEARBOX CLOSED BEARING	14	02
018	0503011953	5/16" X 1" BOLT		08
019	0521068147	LEFT ARM		01
020	0502011300	BUSHING GEAR		01
021	0521010530	COUPLING SHAFT		02
022	0503010140	1/8" X 3/4" COTTERPIN		05
023	0503010365	NUT		02
024	0503011907	PMC 594-S NYLON LUG		01
025	0503010363	5/16" X 1" BOLT		02
026	1902010175	HITCH CLAMP		02
027	0501010216	3/4" X 4-1/2" BOLT		04
028	0503010023	3/4" SPRING WASHER		04
029	0503010014	3/4" NUT		04
030	0511017302	FLAT WASHER		01
031	0503010060	1/2" NUT		06


LEFT WHEEL

0521054104


Item	Code	Description	See page	QT
032	0503010019	1/2" SPRING WASHER		16
033	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		04
034	0531014897	GEAR BOX COVER		01
035	0501110627	WHEEL PIVOT BEARING		02
036	0531014895	MOTOR SHAFT 427		01
037	0503010004	1890 GREASE FITTING		02
038	0561013022	BEARING EXTERNAL LOCK		02
039	0503010398	501082 CLAMPING RING (FOR AXLE)		02
040	0561013020	KM 12 NUT		02
041	0501018466	FLAT WASHER		06
042	0511063619	DISARMENT/ARM PIVOT ARM		01
043	0501049265	LH TRANSMISSION DRIVING ASSY	10	01
044	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED BOX		01
044A	0511052766	CARRYING WHEEL HUB ASSY		01
044B	0503062158	EEE WHEEL WITH TIRE 700 X 16-10L ASSY		01
045	0551018252	CHAIN TIGHTENER AXLE		01
046	0501058239	WHEEL CHAIN TENSIONER BEARING	8	01
047	0521010479	SLEEVE ARTICULATION		01
048	0503011336	1/2" HEX SELF ADJUSTING NUT		02
049	0503013034	2050 CHAIN X 64 LINK + REDUCTION		01
050	0561013021	BEARING INNER LOK		02
051	0503011167	M16 X 2 X 30 BOLT		03
052	0503010027	5/8" SPRING WASHER		03
053	0511061810	HYDRAULIC CYLINDER FIXING FLANGE		02
054	0503010834	1/2 X 1 BOLT		04
055	0501054072	RIGHT CHAIN TENSIONER		01
056	0531014936	RIGHT GEAR BOX DRIVER AXLE		01
057	0531015974	LEFT GEAR BOX DRIVEN AXLE		01
058	0503012712	40-1 CHAIN X 81 LINK + MENDING		01
059	0521069239	14Z GEAR		01
060	0511058443	HYDRAULIC CYLINDER	7	01
061	0501052788	CHAIN TENSIONER ASSY		01
062	0531015192	COVER ARTICULAT SLEEVE		02
063	0501010694	FLAT WASHER		02
064	0501069585	17Z P5/8" GEAR ROUND HOLE 1.4"		01
065	0511060719	DISARMENT/ARM PIVOT ARM		01
066	0501010984	FLAT WASHER		03
067	0501017779	32 X 60 X 4.75 FLAT WASHER		02
068	0503010523	1/4" X 2" COTTERPIN		01
069	0503010257	1/8" X 1" COTTERPIN		01
070	0502040534	SPRING GUIDE BUSHING LOCK		01
070A	1902012196	SPRING GUIDE LOCK SLEEVE		01
071	0501018535	1/2 X 1 BOLT		01
072	0521010546	1.2" X 5.7" COUPLING SHAFT		01
073	0501013753	FLAT WASHER		01
074	0511063920	SPRING GUIDE		01
075	0503031823	1" X 250 X 3,8 COMPRESSION SPRING		01
076	0521017623	0.5" X 1.5" COUPLING SHAFT		01
077	0501054284	STRETCHER CURRENT TRANSMISSION SIDE	15	01
078	0503013033	50-1 CHAIN X 76 LINK + MENDING		01
079	0503010311	1/2" X 1-1/4" BOLT		08
080	0581015540	LEFT CHAIN PROTECTION CAP		01
081	0503011136	BOLT 1/2 UNC X 1/2 S C S I 12.9		01




Item	Code	Description	See page	QT
001	0511061839	2.4" X 10.8" CYLINDER CASE		01
002	0521018426	1.7" X 13.7" TURNBUCLE		01
003	0503010042	2-214 N 3006-9B O'RING		01
004	0503010063	1" SELF-ALIGNING NUT		01
005	0503030385	CYLINDER PLUG N-002		02
006	0503010761	D-1750 SCRAPER RING		01
007	0511064408	FORK		01
008	0503010025	3/8" SPRING WASHER		01
009	0503011094	3/8" X 2" BOLT		01
010	0503010026	3/8" NUT		01
011	0503010003	1845 GREASE FITTING		02
012	0571019710	1.7" X 3.4" PISTON		01
013	0503017935	RING		01
014	0503018144	RING		01
015	0571019711	RING SUPPORT		01
016	0571019709	DETACHABLE COVER		01
017	0503017936	RING		01
018	0503017938	RING GUIDE		01
019	0503017937	GASKET		01
020	0503017940	8-337 BACK-UP RING		02
021	0503017939	2-337 N 3006-9B O' RING		02
022	0511032784	HYDRAULIC CYLINDER REPAIR KIT		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0521017590	GUIDE AXLE		01
02	0503010542	501045 CLAMPING RING (FOR AXLE)		01
03	0521017593	FLAT WASHER		01
04	0501019734	FLAT WASHER		02
05	0502011329	14Z GEAR WITH RIGHT DRAGGER		01
06	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
07	0501019735	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		01
09	0502010711	RIGHT CAM,LARGER		01
10	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
11	0502011996	SLEEVE FIXER		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 C50 G.5 ZN		01
13	0503010060	1/2" NUT		01
14	0503010003	1845 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521017590	GUIDE AXLE		01
02	0503010542	501045 CLAMPING RING (FOR AXLE)		01
03	0521017593	FLAT WASHER		01
04	0501019735	FLAT WASHER		01
05	0502011331	LH 14Z P 1.25" GEAR WITH DRAGGER		01
06	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		01
09	0502010721	LEFT CAM,LARGER		01
10	0502011995	LH DRIVING AXLE FOLLOWER		01
11	0502011996	SLEEVE FIXER		01
12	0503010395	1/2" X 1-1/4" BOLT		01
13	0503010060	1/2" NUT		01
14	0503010003	1845 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531017202	AXLE CHAIN TIGHTENER		01
02	0503030402	PULLEY		01
03	0503010302	501019 SEAL RING		01
04	0503010004	1890 GREASE FITTING		01
05	0511017302	FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2" NUT		01
08	0511015098	FLAT WASHER		01




Item	Code	Description	See page	QT
001	0521054096	SEED/FERTILIZER BOX ASSY	24	01
002	0511063580	FINE SEED BOX CAP		01
003	0511063581	FERTILIZER BOX COVER		01
004	0503010421	5/16" X 1-1/2" BOLT		04
005	0521011116	COVER PIVOT BUSHING		04
006	0501010694	FLAT WASHER		04
007	0503010179	LOCK WASHER		04
008	0503010337	5/16" NUT		04
009	0503011907	PMC 594-S NYLON LUG		02
010	0503010363	5/16" X 1" BOLT		04
011	0503010179	LOCK WASHER		04
012	0503010337	5/16" NUT		04
013	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
014	0501010984	FLAT WASHER		08
015	0503010025	3/8" SPRING WASHER		04
016	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
001	0501058661	SEED/FERTILIZER BOX ASSY	25	01
002	0511063580	FINE SEED BOX CAP		01
003	0511063581	FERTILIZER BOX COVER		01
004	0503010421	5/16" X 1-1/2" BOLT		04
005	0521011116	COVER PIVOT BUSHING		04
006	0501010694	FLAT WASHER		04
007	0503010179	LOCK WASHER		04
008	0503010337	5/16" NUT		04
009	0503011907	PMC 594-S NYLON LUG		02
010	0503010363	5/16" X 1" BOLT		04
011	0503010179	LOCK WASHER		04
012	0503010337	5/16" NUT		04
013	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
014	0501010984	FLAT WASHER		08
015	0503010025	3/8" SPRING WASHER		04
016	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
001	0521054108	SEED/FERTILIZER BOX ASSY	26	01
002	0511063873	FINE SEED BOX CAP		01
003	0511063874	FERTILIZER BOX COVER		01
004	0503010421	5/16" X 1-1/2" BOLT		04
005	0521011116	COVER PIVOT BUSHING		04
006	0501010694	FLAT WASHER		04
007	0503010179	LOCK WASHER		04
008	0503010337	5/16" NUT		04
009	0503011907	PMC 594-S NYLON LUG		02
010	0503010363	5/16" X 1" BOLT		04
011	0503010179	LOCK WASHER		04
012	0503010337	5/16" NUT		04
013	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
014	0501010984	FLAT WASHER		08
015	0503010025	3/8" SPRING WASHER		04
016	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
001	0511057577	SEED/FERTILIZER BOX ASSY	27	01
002	0511063873	FINE SEED BOX CAP		01
003	0511063874	FERTILIZER BOX COVER		01
004	0503010421	5/16" X 1-1/2" BOLT		04
005	0521011116	COVER PIVOT BUSHING		04
006	0501010694	FLAT WASHER		04
007	0503010179	LOCK WASHER		04
008	0503010337	5/16" NUT		04
009	0503011907	PMC 594-S NYLON LUG		02
010	0503010363	5/16" X 1" BOLT		04
011	0503010179	LOCK WASHER		04
012	0503010337	5/16" NUT		04
013	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
014	0501010984	FLAT WASHER		08
015	0503010025	3/8" SPRING WASHER		04
016	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
001	0521054097	SEED/FERTILIZER BOX ASSY	28	01
002	0511063580	FINE SEED BOX CAP		01
003	0511063581	FERTILIZER BOX COVER		01
004	0503010421	5/16" X 1-1/2" BOLT		04
005	0521011116	COVER PIVOT BUSHING		04
006	0501010694	FLAT WASHER		04
007	0503010179	LOCK WASHER		04
008	0503010337	5/16" NUT		04
009	0503011907	PMC 594-S NYLON LUG		02
010	0503010363	5/16" X 1" BOLT		04
011	0503010179	LOCK WASHER		04
012	0503010337	5/16" NUT		04
013	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
014	0501010984	FLAT WASHER		08
015	0503010025	3/8" SPRING WASHER		04
016	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
001	0501053953	SEED/FERTILIZER BOX ASSY	29	01
002	0511063580	FINE SEED BOX CAP		01
003	0511063581	FERTILIZER BOX COVER		01
004	0503010421	5/16" X 1-1/2" BOLT		04
005	0521011116	COVER PIVOT BUSHING		04
006	0501010694	FLAT WASHER		04
007	0503010179	LOCK WASHER		04
008	0503010337	5/16" NUT		04
009	0503011907	PMC 594-S NYLON LUG		02
010	0503010363	5/16" X 1" BOLT		04
011	0503010179	LOCK WASHER		04
012	0503010337	5/16" NUT		04
013	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
014	0501010984	FLAT WASHER		08
015	0503010025	3/8" SPRING WASHER		04
016	0503010026	3/8" NUT		04



Item	Code	Description	See page	QT
001	0521054109	SEED/FERTILIZER BOX ASSY	30	01
002	0511063873	FINE SEED BOX CAP		01
003	0511063874	FERTILIZER BOX COVER		01
004	0503010421	5/16" X 1-1/2" BOLT		04
005	0521011116	COVER PIVOT BUSHING		04
006	0501010694	FLAT WASHER		04
007	0503010179	LOCK WASHER		04
008	0503010337	5/16" NUT		04
009	0503011907	PMC 594-S NYLON LUG		02
010	0503010363	5/16" X 1" BOLT		04
011	0503010179	LOCK WASHER		04
012	0503010337	5/16" NUT		04
013	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
014	0501010984	FLAT WASHER		08
015	0503010025	3/8" SPRING WASHER		04
016	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
001	0511057579	SEED/FERTILIZER BOX ASSY	31	01
002	0511063873	FINE SEED BOX CAP		01
003	0511063874	FERTILIZER BOX COVER		01
004	0503010421	5/16" X 1-1/2" BOLT		04
005	0521011116	COVER PIVOT BUSHING		04
006	0501010694	FLAT WASHER		04
007	0503010179	LOCK WASHER		04
008	0503010337	5/16" NUT		04
009	0503011907	PMC 594-S NYLON LUG		02
010	0503010363	5/16" X 1" BOLT		04
011	0503010179	LOCK WASHER		04
012	0503010337	5/16" NUT		04
013	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
014	0501010984	FLAT WASHER		08
015	0503010025	3/8" SPRING WASHER		04
016	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0511063579	REAR CONJUGATED BOX FERTILIZER SEED		01
02	0531014894	SEED BOX AXLE		01
03	0501053303	KIT DISTRIBUTOR	32	06
04	0501012370	SEED EXIT COVER		02
05	0503010256	3/8" X 3/4" BOLT		08
06	0503010025	3/8" SPRING WASHER		08
07	0503010026	3/8" NUT		08
08	0503010778	1/8" X 1.1/2" COTTERPIN		12
09	0531014907	SCALE SUPPORT		01
10	0503030886	SCALE DOSER		01
11	0503010001	3.2 X 5.5 RIVET		02
12	0503032077	LARGE DOSER		01
13	0503010292	0.2" X 1.6" SPRING PIN		01
14	0521054098	DISTRIBUTOR FERTILIZER	36	06
15	0501011643	3/8 X 1" BOLT		24
16	0503010025	3/8" SPRING WASHER		24
17	0503010026	3/8" NUT		24
18	0531015175	FERTILIZER BEAM LOWER COVER		01
19	0503010256	3/8" X 3/4" BOLT		04
20	0503010025	3/8" SPRING WASHER		04
21	0503010026	3/8" NUT		04
22	0501052990	AGRICULTURAL BEARING	33	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	FLAT WASHER		02
25	0503010025	3/8" SPRING WASHER		02
26	0503010026	3/8" NUT		02
27	0511014265	3/4" X 86" SQUARE SHAFT		01
28	0503030275	AGRICULTURAL BEARING		06
29	1902010685	18Z CONICAL GEAR		06
30	0503032078	SPACING SLEEVE		06
31	0501053788	3/4 SQUARE AXLE FASTENER	34	03

Item	Code	Description	See page	QT
32	0503010002	1800 GREASE FITTING		07
33	0503010004	1890 GREASE FITTING		01
34	0503050060	SEED DISTRIBUTOR BOX SWITCH	37	06
35	0503030189	COMPRES SPRING		06
36	0501053939	RH BEARING SEED BOX		01
37	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01




Item	Code	Description	See page	QT
01	0511063579	REAR CONJUGATED BOX FERTILIZER SEED		01
02	0531014894	SEED BOX AXLE		01
03	0501053303	KIT DISTRIBUTOR	32	06
04	0501012370	SEED EXIT COVER		02
05	0503010256	3/8" X 3/4" BOLT		08
06	0503010025	3/8" SPRING WASHER		08
07	0503010026	3/8" NUT		08
08	0503010778	1/8" X 1.1/2" COTTERPIN		12
09	0531014907	SCALE SUPPORT		01
10	0503030886	SCALE DOSER		01
11	0503010001	3.2 X 5.5 RIVET		02
12	0503032077	LARGE DOSER		01
13	0503010292	0.2" X 1.6" SPRING PIN		01
14	0521054098	DISTRIBUTOR FERTILIZER	36	06
15	0501011643	3/8 X 1" BOLT		24
16	0503010025	3/8" SPRING WASHER		24
17	0503010026	3/8" NUT		24
18	0531015175	FERTILIZER BEAM LOWER COVER		01
19	0503010256	3/8" X 3/4" BOLT		04
20	0503010025	3/8" SPRING WASHER		04
21	0503010026	3/8" NUT		04
22	0501052990	AGRICULTURAL BEARING	33	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	FLAT WASHER		02
25	0503010025	3/8" SPRING WASHER		02
26	0503010026	3/8" NUT		02
27	0511014265	3/4" X 86" SQUARE SHAFT		01
28	0503030275	AGRICULTURAL BEARING		06
29	1902010685	18Z CONICAL GEAR		06
30	0503032078	SPACING SLEEVE		06
31	0501053788	3/4 SQUARE AXLE FASTENER	34	03

Item	Code	Description	See page	QT
32	0503010002	1800 GREASE FITTING		07
33	0503010004	1890 GREASE FITTING		01
34	0503050060	SEED DISTRIBUTOR BOX SWITCH	37	06
35	0503030189	COMPRES SPRING		06
36	0501053939	RH BEARING SEED BOX		01
37	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01




Item	Code	Description	See page	QT
01	0511063872	REAR CONJUGATED BOX FERTILIZER SEED		01
02	0531016218	SEED BOX AXLE		01
03	0501053303	KIT DISTRIBUTOR	32	06
04	0501012370	SEED EXIT COVER		02
05	0503010256	3/8" X 3/4" BOLT		08
06	0503010025	3/8" SPRING WASHER		08
07	0503010026	3/8" NUT		08
08	0503010778	1/8" X 1.1/2" COTTERPIN		12
09	0531014907	SCALE SUPPORT		01
10	0503030886	SCALE DOSER		01
11	0503010001	3.2 X 5.5 RIVET		02
12	0503032077	LARGE DOSER		01
13	0503010292	0.2" X 1.6" SPRING PIN		01
14	0521054098	DISTRIBUTOR FERTILIZER	36	06
15	0501011643	3/8 X 1" BOLT		24
16	0503010025	3/8" SPRING WASHER		24
17	0503010026	3/8" NUT		24
18	0531015175	FERTILIZER BEAM LOWER COVER		01
19	0503010256	3/8" X 3/4" BOLT		04
20	0503010025	3/8" SPRING WASHER		04
21	0503010026	3/8" NUT		04
22	0501052990	AGRICULTURAL BEARING	33	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	FLAT WASHER		02
25	0503010025	3/8" SPRING WASHER		02
26	0503010026	3/8" NUT		02
27	0511014265	3/4" X 86" SQUARE SHAFT		01
28	0503030275	AGRICULTURAL BEARING		06
29	1902010685	18Z CONICAL GEAR		06
30	0503032078	SPACING SLEEVE		06
31	0501053788	3/4 SQUARE AXLE FASTENER	34	03

Item	Code	Description	See page	QT
32	0503010002	1800 GREASE FITTING		07
33	0503010004	1890 GREASE FITTING		01
34	0503050060	SEED DISTRIBUTOR BOX SWITCH	37	06
35	0503030189	COMPRES SPRING		06
36	0501053939	RH BEARING SEED BOX		01
37	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01




Item	Code	Description	See page	QT
01	0511063872	REAR CONJUGATED BOX FERTILIZER SEED		01
02	0531016218	SEED BOX AXLE		01
03	0501053303	KIT DISTRIBUTOR	32	06
04	0501012370	SEED EXIT COVER		02
05	0503010256	3/8" X 3/4" BOLT		08
06	0503010025	3/8" SPRING WASHER		08
07	0503010026	3/8" NUT		08
08	0503010778	1/8" X 1.1/2" COTTERPIN		12
09	0531014907	SCALE SUPPORT		01
10	0503030886	SCALE DOSER		01
11	0503010001	3.2 X 5.5 RIVET		02
12	0503032077	LARGE DOSER		01
13	0503010292	0.2" X 1.6" SPRING PIN		01
14	0521054098	DISTRIBUTOR FERTILIZER	36	06
15	0501011643	3/8 X 1" BOLT		24
16	0503010025	3/8" SPRING WASHER		24
17	0503010026	3/8" NUT		24
18	0531015175	FERTILIZER BEAM LOWER COVER		01
19	0503010256	3/8" X 3/4" BOLT		04
20	0503010025	3/8" SPRING WASHER		04
21	0503010026	3/8" NUT		04
22	0501052990	AGRICULTURAL BEARING	33	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	FLAT WASHER		02
25	0503010025	3/8" SPRING WASHER		02
26	0503010026	3/8" NUT		02
27	0511014265	3/4" X 86" SQUARE SHAFT		01
28	0503030275	AGRICULTURAL BEARING		06
29	1902010685	18Z CONICAL GEAR		06
30	0503032078	SPACING SLEEVE		06
31	0501053788	3/4 SQUARE AXLE FASTENER	34	03

Item	Code	Description	See page	QT
32	0503010002	1800 GREASE FITTING		07
33	0503010004	1890 GREASE FITTING		01
34	0503050060	SEED DISTRIBUTOR BOX SWITCH	37	06
35	0503030189	COMPRES SPRING		06
36	0501053939	RH BEARING SEED BOX		01
37	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01




Item	Code	Description	See page	QT
01	0511063612	BOX FERTILIZER SEED		01
02	0531014894	SEED BOX AXLE		01
03	0501053303	KIT DISTRIBUTOR	32	06
04	0501012370	SEED EXIT COVER		02
05	0503010256	3/8" X 3/4" BOLT		08
06	0503010025	3/8" SPRING WASHER		08
07	0503010026	3/8" NUT		08
08	0503010778	1/8" X 1.1/2" COTTERPIN		12
09	0531014907	SCALE SUPPORT		01
10	0503030886	SCALE DOSER		01
11	0503010001	3.2 X 5.5 RIVET		02
12	0503032077	LARGE DOSER		01
13	0503010292	0.2" X 1.6" SPRING PIN		01
14	0521054098	DISTRIBUTOR FERTILIZER	36	06
15	0501011643	3/8 X 1" BOLT		24
16	0503010025	3/8" SPRING WASHER		24
17	0503010026	3/8" NUT		24
18	0531015175	FERTILIZER BEAM LOWER COVER		01
19	0503010256	3/8" X 3/4" BOLT		04
20	0503010025	3/8" SPRING WASHER		04
21	0503010026	3/8" NUT		04
22	0501052990	AGRICULTURAL BEARING	33	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	FLAT WASHER		02
25	0503010025	3/8" SPRING WASHER		02
26	0503010026	3/8" NUT		02
27	0511014265	3/4" X 86" SQUARE SHAFT		01
28	0503030275	AGRICULTURAL BEARING		06
29	1902010685	18Z CONICAL GEAR		06
30	0503032078	SPACING SLEEVE		06
31	0501053788	3/4 SQUARE AXLE FASTENER	34	03

Item	Code	Description	See page	QT
32	0503010002	1800 GREASE FITTING		07
33	0503010004	1890 GREASE FITTING		01
34	0503050060	SEED DISTRIBUTOR BOX SWITCH	37	06
35	0503030189	COMPRES SPRING		06
36	0501053939	RH BEARING SEED BOX		01
37	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01




Item	Code	Description	See page	QT
01	0511063612	BOX FERTILIZER SEED		01
02	0531014894	SEED BOX AXLE		01
03	0501053303	KIT DISTRIBUTOR	32	06
04	0501012370	SEED EXIT COVER		02
05	0503010256	3/8" X 3/4" BOLT		08
06	0503010025	3/8" SPRING WASHER		08
07	0503010026	3/8" NUT		08
08	0503010778	1/8" X 1.1/2" COTTERPIN		12
09	0531014907	SCALE SUPPORT		01
10	0503030886	SCALE DOSER		01
11	0503010001	3.2 X 5.5 RIVET		02
12	0503032077	LARGE DOSER		01
13	0503010292	0.2" X 1.6" SPRING PIN		01
14	0521054098	DISTRIBUTOR FERTILIZER	36	06
15	0501011643	3/8 X 1" BOLT		24
16	0503010025	3/8" SPRING WASHER		24
17	0503010026	3/8" NUT		24
18	0531015175	FERTILIZER BEAM LOWER COVER		01
19	0503010256	3/8" X 3/4" BOLT		04
20	0503010025	3/8" SPRING WASHER		04
21	0503010026	3/8" NUT		04
22	0501052990	AGRICULTURAL BEARING	33	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	FLAT WASHER		02
25	0503010025	3/8" SPRING WASHER		02
26	0503010026	3/8" NUT		02
27	0511014265	3/4" X 86" SQUARE SHAFT		01
28	0503030275	AGRICULTURAL BEARING		06
29	1902010685	18Z CONICAL GEAR		06
30	0503032078	SPACING SLEEVE		06
31	0501053788	3/4 SQUARE AXLE FASTENER	34	03

Item	Code	Description	See page	QT
32	0503010002	1800 GREASE FITTING		07
33	0503010004	1890 GREASE FITTING		01
34	0503050060	SEED DISTRIBUTOR BOX SWITCH	37	06
35	0503030189	COMPRES SPRING		06
36	0501053939	RH BEARING SEED BOX		01
37	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01




Item	Code	Description	See page	QT
01	0511063871	BOX FERTILIZER SEED		01
02	0531016218	SEED BOX AXLE		01
03	0501053303	KIT DISTRIBUTOR	32	06
04	0501012370	SEED EXIT COVER		02
05	0503010256	3/8" X 3/4" BOLT		08
06	0503010025	3/8" SPRING WASHER		08
07	0503010026	3/8" NUT		08
08	0503010778	1/8" X 1.1/2" COTTERPIN		12
09	0531014907	SCALE SUPPORT		01
10	0503030886	SCALE DOSER		01
11	0503010001	3.2 X 5.5 RIVET		02
12	0503032077	LARGE DOSER		01
13	0503010292	0.2" X 1.6" SPRING PIN		01
14	0521054098	DISTRIBUTOR FERTILIZER	36	06
15	0501011643	3/8 X 1" BOLT		24
16	0503010025	3/8" SPRING WASHER		24
17	0503010026	3/8" NUT		24
18	0531015175	FERTILIZER BEAM LOWER COVER		01
19	0503010256	3/8" X 3/4" BOLT		04
20	0503010025	3/8" SPRING WASHER		04
21	0503010026	3/8" NUT		04
22	0501052990	AGRICULTURAL BEARING	33	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	FLAT WASHER		02
25	0503010025	3/8" SPRING WASHER		02
26	0503010026	3/8" NUT		02
27	0531016219	3/4 X 2950 SQUARE SHAFT		01
28	0503030275	AGRICULTURAL BEARING		06
29	1902010685	18Z CONICAL GEAR		06
30	0503032078	SPACING SLEEVE		06
31	0501053788	3/4 SQUARE AXLE FASTENER	34	03

Item	Code	Description	See page	QT
32	0503010002	1800 GREASE FITTING		07
33	0503010004	1890 GREASE FITTING		01
34	0503050060	SEED DISTRIBUTOR BOX SWITCH	37	06
35	0503030189	COMPRES SPRING		06
36	0501053939	RH BEARING SEED BOX		01
37	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01




Item	Code	Description	See page	QT
01	0511063871	BOX FERTILIZER SEED		01
02	0531016218	SEED BOX AXLE		01
03	0501053303	KIT DISTRIBUTOR	32	10
04	0501012370	SEED EXIT COVER		02
05	0503010256	3/8" X 3/4" BOLT		08
06	0503010025	3/8" SPRING WASHER		08
07	0503010026	3/8" NUT		08
08	0503010778	1/8" X 1.1/2" COTTERPIN		16
09	0531014907	SCALE SUPPORT		01
10	0503030886	SCALE DOSER		01
11	0503010001	3.2 X 5.5 RIVET		02
12	0503032077	LARGE DOSER		01
13	0503010292	0.2" X 1.6" SPRING PIN		01
14	0511047568	DISTRIBUTOR FERTILIZER	35	08
15	0501011643	3/8 X 1" BOLT		32
16	0503010025	3/8" SPRING WASHER		32
17	0503010026	3/8" NUT		02
18	0501052990	AGRICULTURAL BEARING	33	01
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
20	0501010984	FLAT WASHER		02
21	0503010025	3/8" SPRING WASHER		02
22	0503010026	3/8" NUT		02
23	0531016219	3/4 X 2950 SQUARE SHAFT		01
24	0503030275	AGRICULTURAL BEARING		08
25	1902010685	18Z CONICAL GEAR		08
26	0503032078	SPACING SLEEVE		08
27	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01
28	0521010691	AXLE FASTENER		03
29	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
30	0501010694	FLAT WASHER		03
31	0503010143	1/4" SPRING WASHER		03


Item	Code	Description	See page	QT
32	0503010144	1/4" NUT		03
33	0503010002	1800 GREASE FITTING		08
34	0503010004	1890 GREASE FITTING		01
35	0503010691	1/4" GREASE FITTING		01
36	0501053939	RH BEARING SEED BOX		01




Item	Code	Description	See page	QT
01	0503030180	SEED DISTRIBUTOR BOX		01
02	0502010950	ROTOR		01
03	0503010366	ROTOR GUIDE		01
04	0501040236	SEED LIMETER		01
05	0503010370	502072 CLAMPING RING (FOR AXLE)		01
06	0501011064	ROTOR WHASHER		01
07	0503030189	COMPRES SPRING		01
08	0503050060	SEED DISTRIBUTOR BOX SWITCH	37	01
09	0503030756	SOCKET FASTENER		01
10	0503010369	SEED SOCKET		01
11	0501010637	FLAT WASHER		02
12	0503013813	1/4\" UNC X 7/8\" BOLT		04
13	0511017303	FLAT WASHER		08
14	0503011441	SPRING WASHER		04
15	0503010144	1/4\" NUT		04




Item	Code	Description	See page	QT
01	0501110250	BEARING BOX		01
02	0502040154	BEARING REEL		01
03	0503010372	501050 CLAMPING RING (FOR AXLE)		01
04	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01



Item	Code	Description	See page	QT
001	0501110143	TUBE FERTILIZER METERING BODY		01
001A	1902020469	DISTRIBUTOR FERTILIZER		01
001B	0541016687	268 FERTILIZER TUBE		01
002	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
003	0521010309	SLEEVE INTER		01
004	0503030275	AGRICULTURAL BEARING		02
005	0503031166	LEFT CONDUTOR		01
006	0511017137	FLAT WASHER		01
007	0503030303	SUPPORT WASHER		01
008	0501013774	GREASE SEAL		01
009	0502011412	18Z CONICAL GEAR		01
010	0503010523	1/4" X 2" COTTERPIN		01
011	0503012826	CREASE FITTING		02
012	0503011962	GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110143	TUBE FERTILIZER METERING BODY		01
01A	1902020469	DISTRIBUTOR FERTILIZER		01
01B	0541016687	268 FERTILIZER TUBE		01
02	0501019851	DISTRIBUTOR FERTILIZER AXLE		01
03	0521010309	SLEEVE INTER		01
04	0503030275	AGRICULTURAL BEARING		02
05	0503031163	LEFT CONDUTOR		01
06	0511017137	FLAT WASHER		01
07	0503030303	SUPPORT WASHER		01
08	0501013774	GREASE SEAL		01
09	0502011412	18Z CONICAL GEAR		01
10	0503010523	1/4" X 2" COTTERPIN		01
11	0503012826	CREASE FITTING		02
12	0503011962	GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511015728	DISTRIBUTOR BOX SEED SWITCH BODY		01

HOSE SUPPORT

0511056736




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
001	0502011530	SUPPORT		02
002	0502010175	HITCH CLAMP		02
003	0501011543	5/8" X 4" BOLT		04
004	0503010027	5/8" SPRING WASHER		04
005	0503010013	5/8" NUT		04
006	0521069978	PLOUGH SUPPORT 815		02
007	0501011075	PIN		02
008	0503030012	HAIR PIN		02

STIRRUP


0521051945




Item	Code	Description	See page	QT
001	0511064817	STIRRUP		02
002	0501011532	3/8" X 1-3/4" BOLT		08
003	0503010025	3/8" SPRING WASHER		08
004	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
001	0531014955	PLATFORM		01
002	0531015185	PLATFORM FIXATION SUPPORT		02
003	0501010080	3/8" BOLT		02
004	0503010025	3/8" SPRING WASHER		02
005	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
001	0531016217	PLATFORM 4000 X 400		01
002	0531015185	PLATFORM FIXATION SUPPORT		02
003	0501010080	3/8" BOLT		02
004	0503010025	3/8" SPRING WASHER		02
005	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
001	0501052972	RIGHT RATCHET CHAIN TENSIONER	46	01
002	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
003	0503012962	282 CHAIN X 40-1 LINK + REDUCTION		01
004	0501052973	LEFT RATCHET CHAIN TENSIONER	45	01
005	0503012960	40-1 CHAIN X 266 LINK + REDUCTION		01
006	0531014956	BOX TRANSMISSION PROTECTION CAP		01
007	0531014957	BOX TRANSMISSION PROTECTION CAP		01
008	0503010282	1/4" X 3/4" BOLT		04
009	0503010305	FLAT WASHER		04
010	0503010143	1/4" SPRING WASHER		04
011	0503010144	1/4" NUT		04
012	0501053952	SEED DOUBLE BEARING INTERM	49	01
013	0501053950	FINE SEED ASSY INTERMEDIATE BEARING	50	03
014	0501053951	FERTILIZER MIDDLEMAN BEARING ASSY	51	03




Item	Code	Description	See page	QT
001	0501052973	LEFT RATCHET CHAIN TENSIONER	45	01
002	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
003	0503012962	282 CHAIN X 40-1 LINK + REDUCTION		01
004	0503012963	198 CHAIN X 40-1 LINK + REDUCTION		01
005	0501052972	RIGHT RATCHET CHAIN TENSIONER	46	01
006	0503012960	40-1 CHAIN X 266 LINK + REDUCTION		01
007	0501053296	BEARING WITH 17Z GEAR	47	01
008	0531016224	5/8" X 3170 AXLE HEX		01
009	0502040534	SPRING GUIDE BUSHING LOCK		02
010	0503010026	3/8" NUT		02
011	0503010237	3/8" X 1" BOLT		02
012	0531014956	BOX TRANSMISSION PROTECTION CAP		01
013	0531014957	BOX TRANSMISSION PROTECTION CAP		01
014	0503010282	1/4" X 3/4" BOLT		04
015	0503010305	FLAT WASHER		04
016	0503010143	1/4" SPRING WASHER		04
017	0503010144	1/4" NUT		04
018	0501054355	LARGE SEED CHAIN TENSIONER	48	01
019	0501053952	SEED DOUBLE BEARING INTERM	49	01
020	0501053950	FINE SEED ASSY INTERMEDIATE BEARING	50	03
021	0501053951	FERTILIZER MIDDLEMAN BEARING ASSY	51	03
022	0501053935	SEED BEARING INTERM ASSY	52	02




Item	Code	Description	See page	QT
01	0511062128	CHAIN TENSIONER		01
02	0503031804	5Z GEAR P31,75		01
03	0503010302	501019 SEAL RING		01
04	0521019253	3.6" PIVOT SHAFT		01
05	0503010292	0.2" X 1.6" SPRING PIN		01
06	0503030394	1.7"X 1.4"X 0.14" LH TORSION SPRING		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511062128	CHAIN TENSIONER		01
02	0503031804	5Z GEAR P31,75		01
03	0503010302	501019 SEAL RING		01
04	0521019253	3.6" PIVOT SHAFT		01
05	0503010292	0.2" X 1.6" SPRING PIN		01
06	0503030417	1.7"X 1.4"X 0.14" RH TORSION SPRING		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0501010694	FLAT WASHER		02
02	0501053297	BEARING WITH DOUBLE BALL BEARING		01
02A	0502011971	HOUSING WITH DOUBLE BEARING		001
02B	0503011105	SEAL RING		001
02C	0503011410	ROLLER BEARING		002
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02
05	0503010371	5/16" X 1" BOLT		02
06	0503010406	501025 CLAMPING RING (FOR AXLE)		02
07	0511062625	BERING AXLE		01




Item	Code	Description	See page	QT
001	0511064208	LARGE SEED CHAIN TENSIONER		01
002	0503030402	PULLEY		01
003	0503010302	501019 SEAL RING		01
004	0521019253	3.6" PIVOT SHAFT		01
005	0503030417	1.7"X 1.4"X 0.14" RH TORSION SPRING		01
006	0503010019	1/2" SPRING WASHER		01
007	0503010060	1/2" NUT		01
008	0503010292	0.2" X 1.6" SPRING PIN		01




Item	Code	Description	See page	QT
001	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING		01
001A	0502012031	HOUSING BEARING		01
001B	0503012861	6006 2RS BALL BEARING		02
001C	0503012858	502075 CLAMPING RING (FOR HOLE)		01
002	0531015206	INNER AXLE		01
003	0503010707	501030 CLAMPING RING (FOR AXLE)		01
004	0511063565	25Z X 38Z DOBLE GEAR		01
005	0521010530	COUPLING SHAFT		01
006	0503010140	1/8" X 3/4" COTTERPIN		01
007	0503011953	5/16" X 1" BOLT		02
008	0503010337	5/16" NUT		02
009	0503010179	LOCK WASHER		02




Item	Code	Description	See page	QT
001	0531015204	MIDDLE BEARING AXLE		01
002	0501011543	5/8" X 4" BOLT		01
003	0503011105	SEAL RING		01
004	0503010406	501025 CLAMPING RING (FOR AXLE)		01
005	0503010027	5/8" SPRING WASHER		01
006	0503012412	5/8 UNC SELF LOCKING NUT		01
007	0503011410	ROLLER BEARING		01
008	0521069698	GEAR 21Z P 1/2		01




Item	Code	Description	See page	QT
001	0531015205	MIDDLE BEARING AXLE		01
002	0521069698	GEAR 21Z P 1/2		01
003	0501011543	5/8" X 4" BOLT		01
004	0503011105	SEAL RING		01
005	0503010406	501025 CLAMPING RING (FOR AXLE)		01
006	0503010027	5/8" SPRING WASHER		01
007	0503012412	5/8 UNC SELF LOCKING NUT		01
008	0503011410	ROLLER BEARING		01




Item	Code	Description	See page	QT
001	0531015973	MIDDLE BEARING AXLE		01
002	0501011541	5/8" X 3" BOLT		01
003	0503011410	ROLLER BEARING		01
004	0503011105	SEAL RING		01
005	0503010027	5/8" SPRING WASHER		01
006	0503012412	5/8 UNC SELF LOCKING NUT		01
007	0503010406	501025 CLAMPING RING (FOR AXLE)		01
008	0521069698	GEAR 21Z P 1/2		01




Item	Code	Description	See page	QT
001	0511063563	HANDRAIL		04
002	0503010237	3/8" X 1" BOLT		08
003	0503010025	3/8" SPRING WASHER		08
004	0503010026	3/8" NUT		08
005	0503010371	5/16" X 1" BOLT		08
006	0503010179	LOCK WASHER		08
007	0503010337	5/16" NUT		08



Item	Code	Description	See page	QT
01	0511058892	HOSE KIT		01
01A	0501080398	3/8" X 76.8" TC-TC HOSE ASSY		02
01B	0501080393	3/8 X 2200 TC-TC HOSE		02
01C	0521052594	3/8 X 3500 TC-TM HOSE BLACK / RED		01
01CA	0501080365	HOSE 3/8 X 3500 TC-TM		01
01CB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01CD	0503018952	PLASTIC BOLT		06
01D	0521052595	3/8 X 3500 TC-TM HOSE BLACK / BLUE		01
01DA	0501080365	HOSE 3/8 X 3500 TC-TM		01
01DB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01DD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	56	02
03	0511057534	FLOW DIVIDING VALVE	57	01
04	0503010421	5/16" X 1-1/2" BOLT		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02
07	0502012702	BODY SUPPORT CLAMP		05
08	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		05
09	0503010180	7/16" SPRING WASHER		05




Item	Code	Description	See page	QT
001	0511058493	HOSE KIT		01
001A	0501080525	3/8 X 2300 TC-TC HOSE ASSY		02
001B	0501080432	3/8 X 2600 TC-TC HOSE ASSY		02
001C	0521052594	3/8 X 3500 TC-TM HOSE BLACK / RED		01
001CA	0501080365	HOSE 3/8 X 3500 TC-TM		01
001CB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
001CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
001CD	0503018952	PLASTIC BOLT		06
001D	0521052595	3/8 X 3500 TC-TM HOSE BLACK / BLUE		01
001DA	0501080365	HOSE 3/8 X 3500 TC-TM		01
001DB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
001DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
001DD	0503018952	PLASTIC BOLT		06
002	0501053834	MALE QUICK COUPLER	56	02
003	0511057534	FLOW DIVIDING VALVE	57	01
004	0503010421	5/16" X 1-1/2" BOLT		02
005	0503010179	LOCK WASHER		02
006	0503010337	5/16" NUT		02
007	0502012702	BODY SUPPORT CLAMP		05
008	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		05
009	0503010180	7/16" SPRING WASHER		05



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01

FLOW DIVIDING VALVE


0511057534



Item	Code	Description	See page	QT
01	0511057381	FLOW DIVIDING VALVE		01
01A	0503016227	FLOW DIVIDING VALVE		01
01B	0503011109	2-119 N 3006-9B O-RING		03
01C	0521014704	HOSE NIPPLE 3/4 UNF		03
02	0521066121	OIL TUBE		01
03	0503010179	LOCK WASHER		02
04	0503011053	5/16" X 3" C S 6.5 ZN BOLT		02
05	0503010337	5/16" NUT		02
06	0503037376	3/4" T ADAPTER WITH SWIVEL NUT		01
07	0571019627	SUPPORT VALVE		01

HEADER ASSY


0521051950




Item	Code	Description	See page	QT
01	0502012329	DRAWBAR FIXATION REAR SUPPORT		02
02	0502012330	SUPPORT FIXER PIVOT		02
03	0503011084	3/4" X 5" BOLT		04
04	0503010023	3/4" SPRING WASHER		04
05	0503010014	3/4" NUT		04
06	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02
07	0502012330	SUPPORT FIXER PIVOT		02
08	0501010216	3/4" X 4-1/2" BOLT		04
09	0503010023	3/4" SPRING WASHER		04
10	0503010014	3/4" NUT		04
11	0511063573	DRAWBAR		01
12	0561014393	COUPLING SHAFT		02
13	0503030119	LOCK PIN		04
14	0521010582	COUPLING SHAFT		01
15	0503030085	LOCK PIN		01
16	0503010002	1800 GREASE FITTING		01
17	0561019087	DRAWBAR TRANSPORT LOCK		01
18	0501051160	TRACTOR HITCH PIN	60	01
19	0503010523	1/4" X 2" COTTERPIN		01

HEADER ASSY


0521051985




Item	Code	Description	See page	QT
01	0502012329	DRAWBAR FIXATION REAR SUPPORT		02
02	0502012330	SUPPORT FIXER PIVOT		02
03	0503011084	3/4" X 5" BOLT		04
04	0503010023	3/4" SPRING WASHER		04
05	0503010014	3/4" NUT		04
06	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02
07	0502012330	SUPPORT FIXER PIVOT		02
08	0501010216	3/4" X 4-1/2" BOLT		04
09	0503010023	3/4" SPRING WASHER		04
10	0503010014	3/4" NUT		04
11	0511064808	DRAWBAR		01
12	0561014393	COUPLING SHAFT		02
13	0503030119	LOCK PIN		04
14	0521010582	COUPLING SHAFT		01
15	0503030085	LOCK PIN		01
16	0503010002	1800 GREASE FITTING		01
17	0531015979	DRAWBAR LOCK		01
18	0501051160	TRACTOR HITCH PIN	60	01
19	0503010523	1/4" X 2" COTTERPIN		01




Item	Code	Description	See page	QT
01	0521010681	BUSHING COUPLING BODY		01
02	0502040556	HITCH TURNER		01
03	0521010639	COUPLING SHAFT		01
04	0503010571	1/4" X 1.1/2 COTTERPIN		01




Item	Code	Description	See page	QT
001	0541016866	CLOAK MANUAL FIXER L		01
002	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
003	0511032981	BAG WITH MANUAL AND PARTS CATALOGUE		01
004	0503010267	NYLON CLAMP		01
005	0503010363	5/16" X 1" BOLT		01
006	0501010694	FLAT WASHER		01
007	0503010179	LOCK WASHER		01
008	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
001	0503031942	ADHESIVE LABEL	01	
002	0503031797	ADHESIVE LABEL	02	
003	0503031993	ADHESIVE LABEL	01	
004	0503031565	ADHESIVE LABEL CARE	02	
005	0503031425	ADHESIVE LABEL ATTENTION	02	
006	0503031428	READ MANUAL DECAL	01	
007	0503031087	ADHESIVE LABEL	01	
008	0503031669	ADHESIVE LABEL	01	
009	0503031743	ADHESIVE LABEL	01	
010	0503031744	ADHESIVE LABEL	01	
011	0503033923	ÉTIQUETTE ADHÉSIVE	02	
012	0503033922	ADHESIVE LABEL	02	
013	0503033853	ADHESIVE LABEL	02	
014	0503033416	ADHESIVE LABEL	02	
015	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	02	
016	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING	04	
017	0503034500	ADHESIVE LABEL	01	



Item	Code	Description	See page	QT
001	0503031942	ADHESIVE LABEL	01	
002	0503034748	ADHESIVE LABEL	02	
003	0503031993	ADHESIVE LABEL	01	
004	0503031565	ADHESIVE LABEL CARE	02	
005	0503031425	ADHESIVE LABEL ATTENTION	02	
006	0503031428	READ MANUAL DECAL	01	
007	0503031087	ADHESIVE LABEL	01	
008	0503031669	ADHESIVE LABEL	01	
009	0503031743	ADHESIVE LABEL	01	
010	0503031744	ADHESIVE LABEL	01	
011	0503033923	ÉTIQUETTE ADHÉSIVE	02	
012	0503033922	ADHESIVE LABEL	02	
013	0503033853	ADHESIVE LABEL	02	
014	0503033416	ADHESIVE LABEL	02	
015	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	02	
016	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING	04	
017	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
001	0503031942	ADHESIVE LABEL		01
002	0503034748	ADHESIVE LABEL		02
003	0503031993	ADHESIVE LABEL		01
004	0503031565	ADHESIVE LABEL CARE		02
005	0503031425	ADHESIVE LABEL ATTENTION		02
006	0503031428	READ MANUAL DECAL		01
007	0503031087	ADHESIVE LABEL		01
008	0503031669	ADHESIVE LABEL		01
009	0503031743	ADHESIVE LABEL		01
010	0503031744	ADHESIVE LABEL		01
011	0503033923	ÉTIQUETTE ADHÉSIVE		02
012	0503033922	ADHESIVE LABEL		02
013	0503033853	ADHESIVE LABEL		02
014	0503033417	ADHESIVE LABEL		02
015	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
016	0503033415	ADHESIVE LABEL		02
017	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
018	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
001	0503031942	ADHESIVE LABEL		01
002	0503031797	ADHESIVE LABEL		02
003	0503031993	ADHESIVE LABEL		01
004	0503031565	ADHESIVE LABEL CARE		02
005	0503031425	ADHESIVE LABEL ATTENTION		02
006	0503031428	READ MANUAL DECAL		01
007	0503031087	ADHESIVE LABEL		01
008	0503031669	ADHESIVE LABEL		01
009	0503031743	ADHESIVE LABEL		01
010	0503031744	ADHESIVE LABEL		01
011	0503033923	ÉTIQUETTE ADHÉSIVE		02
012	0503033922	ADHESIVE LABEL		02
013	0503033853	ADHESIVE LABEL		02
014	0503033417	ADHESIVE LABEL		02
015	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
016	0503033415	ADHESIVE LABEL		02
017	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
018	0503034500	ADHESIVE LABEL		01

DRAWBAR TURNBUCKLE


0511051394



Item	Code	Description	See page	QT
001	0521062723	TURNBUCKLE		01
002	0503010002	1800 GREASE FITTING		02
003	0511060558	RIGHT TURNBUCKLE		01
004	0511060559	LEFT TURNBUCKLE		01
005	0501061056	RH LOCKNUT WITH HANDLER		01




Item	Code	Description	See page	QT
01	0501068989	COUPLING SHAFT		01
03	0503031035	HAIR PIN		01



Item	Code	Description	See page	QT
01	0511046443	RIGHT FERTILIZER/FINE SEED ROW WITH 16" RIBBED DISC	69	01
02	0511046442	LEFT FERTILIZER/FINE SEED ROW WITH 16" RIBBED DISC	70	01
03	0511040905	RIGHT FERTILIZER/FINE SEED ROW WITH 16" SMOOTH DISC	71	01
04	0511041019	LEFT FERTILIZER/FINE SEED ROW WITH 16" SMOOTH DISC	72	01
05	0511041103	RIGHT FERTILIZER/FINE SEED ROW WITHOUT DISC	73	01
06	0511041104	LEFT FERTILIZER/FINE SEED ROW WITHOUT DISC	74	01
07	0511045468	RIGHT FERTILIZER/FINE SEED ROW WITH 16" SMOOTH DISC	75	01
08	0511045469	LEFT FERTILIZER/FINE SEED ROW WITH 16" SMOOTH DISC	76	01
09	0531054172	RIGHT LARGE SEED ROW WITH RUBBER V-COMPACTOR	77	01
10	0531054171	LEFT LARGE SEED ROW WITH RUBBER V-COMPACTOR	78	01
11	0531054174	RIGHT LARGE SEED ROW WITH IRON V-COMPACTOR	79	01
12	0531054173	LEFT LARGE SEED ROW WITH IRON V-COMPACTOR	80	01
13	0511040908	FERTILIZER ROW WITH RIGHT NOZZLE/16" SMOOTH DISC	81	01
14	0511040925	FERTILIZER ROW WITH LEFT NOZZLE/16" SMOOTH DISC	82	01
15	0511040938	FERTILIZER ROW WITH RIGHT NOZZLE	83	01
16	0511040939	FERTILIZER ROW WITH LEFT NOZZLE	84	01
17	0511055820	FERTILIZER ROW WITH RIGHT NOZZLE/16" RIBBED DISC	85	01
18	0511055821	FERTILIZER ROW WITH LEFT NOZZLE/16" RIBBED DISC	86	01

Item	Code	Description	See page	QT
19	0503063647	SIGMA CORN DISC SET	125	01
20	0503063648	SIGMA SOY DISC SET	126	01
21	0531013600	PRESS ADJUSTMENT LEVER		01




Item	Code	Description	See page	QT
01	0511058212	ASSY LINE SUPPORT FERTILIZER	87	01
02	0502011814	REAR FIXER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0531015184	FLAT WASHER		02
05	0511046441	SHORT BLADE DISC STRIATED	88	01
06	0511063571	LOWER ROCKER ARM		01
07	0511016281	3/4" X 8" BOLT		01
08	0511017232	FLAT WASHER		02
09	0531018235	SUPPORT SLEEVE SPACER		02
10	0511063569	UPPER ROCKER ARM		01
11	0501010452	5/8" X 5" BOLT		02
12	0531016207	0.6" X 1" X 2.8" SLEEVE		02
13	0531015184	FLAT WASHER		02
14	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		01
15	0531015137	16,40 X 25,57 X 101 SLEEVE		01
16	0503031389	2.11" X 8.83 X 0.39" TRACTION SPRING		01
17	0502011031	SPRING UPPER HITCH		01
18	0531014953	BOLT GUIDES SLEEVE		01
19	0511017302	FLAT WASHER		01
20	0503013329	1/2" UNC X 4-3/4" BOLT		01
21	0503010060	1/2" NUT		01
22	0501054473	RIGHT 15 X 15 UNAL DOUBLE-DISC	90	01
23	0503010547	1/2" X 4" BOLT		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501056200	RIGHT ROD STOP SCRAPER	92	01
27	0503010834	1/2 X 1 BOLT		01
28	0501046839	RIGHT IRON PRESS WHEEL	93	01
29	0503010752	1/2" X 3.1/2" BOLT		02
30	0503010019	1/2" SPRING WASHER		02
31	0511017302	FLAT WASHER		01

RIGHT FERTILIZER/FINE SEED ROW WITH 16" RIBBED DISC

0511046443

Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		02
33	0503030483	FERTILIZER SOCKET		01
34	0503030520	SEED SOCKET		01
35	0561011813	SOCKET LOCK		02
36	0503031145	2" X 2" X 20" HOSE		01
37	0503030573	1-1/2" X 2" X 400 HOSE		01
38	0503030887	1-1/2" HOSE CLAMP		01
39	0503031076	2" HOSE CLAMP		03
40	0531018513	SLEEVE NYLON 51 X 41 X 33		01
41	0503010246	CLAMP		01
42	0503011255	3/4" LOCK NUT		01
43	0503012412	5/8 UNC SELF LOCKING NUT		02
44	0503012412	5/8 UNC SELF LOCKING NUT		01
45	0503012412	5/8 UNC SELF LOCKING NUT		02
46	0503011255	3/4" LOCK NUT		01
47	0511064467	SHORT FERTILIZER ROW REAR SUPPORT		01




Item	Code	Description	See page	QT
01	0511058212	ASSY LINE SUPPORT FERTILIZER	87	01
02	0502011814	REAR FIXER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0531015184	FLAT WASHER		02
05	0511046441	SHORT BLADE DISC STRIATED	88	01
06	0511063571	LOWER ROCKER ARM		01
07	0511016281	3/4" X 8" BOLT		01
08	0511017232	FLAT WASHER		02
09	0531018235	SUPPORT SLEEVE SPACER		02
10	0511063569	UPPER ROCKER ARM		01
11	0501010452	5/8" X 5" BOLT		02
12	0531016207	0.6" X 1" X 2.8" SLEEVE		02
13	0531015184	FLAT WASHER		02
14	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		01
15	0531015137	16,40 X 25,57 X 101 SLEEVE		01
16	0503031389	2.11" X 8.83 X 0.39" TRACTION SPRING		01
17	0502011031	SPRING UPPER HITCH		01
18	0531014953	BOLT GUIDES SLEEVE		01
19	0511017302	FLAT WASHER		01
20	0503013329	1/2" UNC X 4-3/4" BOLT		01
21	0503010060	1/2" NUT		01
22	0501054474	LEFT 15 X 15 UNAL DOUBLE-DISC	95	01
23	0503010547	1/2" X 4" BOLT		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501056200	RIGHT ROD STOP SCRAPER	92	01
27	0503010834	1/2 X 1 BOLT		01
28	0501046844	LEFT IRON PRESS WHEEL ASSY	96	01
29	0503010752	1/2" X 3.1/2" BOLT		02
30	0503010019	1/2" SPRING WASHER		02
31	0511017302	FLAT WASHER		01

LEFT FERTILIZER/FINE SEED ROW WITH 16" RIBBED DISC


0511046442

Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		02
33	0503030483	FERTILIZER SOCKET		01
34	0503030520	SEED SOCKET		01
35	0561011813	SOCKET LOCK		02
36	0503031145	2" X 2" X 20" HOSE		01
37	0503030573	1-1/2" X 2" X 400 HOSE		01
38	0503030887	1-1/2" HOSE CLAMP		01
39	0503031076	2" HOSE CLAMP		03
40	0531018513	SLEEVE NYLON 51 X 41 X 33		01
41	0503010246	CLAMP		01
42	0503011255	3/4" LOCK NUT		01
43	0503012412	5/8 UNC SELF LOCKING NUT		02
44	0503012412	5/8 UNC SELF LOCKING NUT		01
45	0503012412	5/8 UNC SELF LOCKING NUT		02
46	0503011255	3/4" LOCK NUT		01
47	0511064467	SHORT FERTILIZER ROW REAR SUPPORT		01




Item	Code	Description	See page	QT
01	0511058212	ASSY LINE SUPPORT FERTILIZER	87	01
02	0502011814	REAR FIXER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0531015184	FLAT WASHER		02
05	0511044553	BLADE DISC ASSY	98	01
06	0511063571	LOWER ROCKER ARM		01
07	0511016281	3/4" X 8" BOLT		01
08	0511017232	FLAT WASHER		02
09	0531018235	SUPPORT SLEEVE SPACER		02
10	0511063569	UPPER ROCKER ARM		01
11	0501010452	5/8" X 5" BOLT		02
12	0531016207	0.6" X 1" X 2.8" SLEEVE		02
13	0531015184	FLAT WASHER		02
14	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		01
15	0531015137	16,40 X 25,57 X 101 SLEEVE		01
16	0503031389	2.11" X 8.83 X 0.39"TRACTION SPRING		01
17	0502011031	SPRING UPPER HITCH		01
18	0531014953	BOLT GUIDES SLEEVE		01
19	0511017302	FLAT WASHER		01
20	0503013329	1/2" UNC X 4-3/4" BOLT		01
21	0503010060	1/2" NUT		01
22	0501054473	RIGHT 15 X 15 UNAL DOUBLE-DISC	90	01
23	0503010547	1/2" X 4" BOLT		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501056200	RIGHT ROD STOP SCRAPER	92	01
27	0503010834	1/2 X 1 BOLT		01
28	0501046839	RIGHT IRON PRESS WHEEL	93	01
29	0503010752	1/2" X 3.1/2" BOLT		02
30	0503010019	1/2" SPRING WASHER		02
31	0511017302	FLAT WASHER		01

Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		02
33	0503030483	FERTILIZER SOCKET		01
34	0503030520	SEED SOCKET		01
35	0561011813	SOCKET LOCK		02
36	0503031145	2" X 2" X 20" HOSE		01
37	0503030573	1-1/2" X 2" X 400 HOSE		01
38	0503030887	1-1/2" HOSE CLAMP		01
39	0503031076	2" HOSE CLAMP		03
40	0531018513	SLEEVE NYLON 51 X 41 X 33		01
41	0503010246	CLAMP		01
42	0503011255	3/4" LOCK NUT		01
43	0503012412	5/8 UNC SELF LOCKING NUT		02
44	0503012412	5/8 UNC SELF LOCKING NUT		01
45	0503012412	5/8 UNC SELF LOCKING NUT		02
46	0503011255	3/4" LOCK NUT		01
47	0511064467	SHORT FERTILIZER ROW REAR SUPPORT		01




Item	Code	Description	See page	QT
01	0511058212	ASSY LINE SUPPORT FERTILIZER	87	01
02	0502011814	REAR FIXER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0531015184	FLAT WASHER		02
05	0511044553	BLADE DISC ASSY	98	01
06	0511063571	LOWER ROCKER ARM		01
07	0511016281	3/4" X 8" BOLT		01
08	0511017232	FLAT WASHER		02
09	0531018235	SUPPORT SLEEVE SPACER		02
10	0511063569	UPPER ROCKER ARM		01
11	0501010452	5/8" X 5" BOLT		02
12	0531016207	0.6" X 1" X 2.8" SLEEVE		02
13	0531015184	FLAT WASHER		02
14	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		01
15	0531015137	16,40 X 25,57 X 101 SLEEVE		01
16	0503031389	2.11" X 8.83 X 0.39" TRACTION SPRING		01
17	0502011031	SPRING UPPER HITCH		01
18	0531014953	BOLT GUIDES SLEEVE		01
19	0511017302	FLAT WASHER		01
20	0503013329	1/2" UNC X 4-3/4" BOLT		01
21	0503010060	1/2" NUT		01
22	0501054474	LEFT 15 X 15 UNAL DOUBLE-DISC	95	01
23	0503010547	1/2" X 4" BOLT		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501056200	RIGHT ROD STOP SCRAPER	92	01
27	0503010834	1/2 X 1 BOLT		01
28	0501046844	LEFT IRON PRESS WHEEL ASSY	96	01
29	0503010752	1/2" X 3.1/2" BOLT		02
30	0503010019	1/2" SPRING WASHER		02
31	0511017302	FLAT WASHER		01

Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		02
33	0503030483	FERTILIZER SOCKET		01
34	0503030520	SEED SOCKET		01
35	0561011813	SOCKET LOCK		02
36	0503031145	2" X 2" X 20" HOSE		01
37	0503030573	1-1/2" X 2" X 400 HOSE		01
38	0503030887	1-1/2" HOSE CLAMP		01
39	0503031076	2" HOSE CLAMP		03
40	0531018513	SLEEVE NYLON 51 X 41 X 33		01
41	0503010246	CLAMP		01
42	0503011255	3/4" LOCK NUT		01
43	0503012412	5/8 UNC SELF LOCKING NUT		02
44	0503012412	5/8 UNC SELF LOCKING NUT		01
45	0503012412	5/8 UNC SELF LOCKING NUT		02
46	0503011255	3/4" LOCK NUT		01
47	0511064467	SHORT FERTILIZER ROW REAR SUPPORT		01



Item	Code	Description	See page	QT
01	0511058212	ASSY LINE SUPPORT FERTILIZER	87	01
02	0502011814	REAR FIXER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0531015184	FLAT WASHER		02
05	0511044553	BLADE DISC ASSY	98	01
06	0511063571	LOWER ROCKER ARM		01
07	0511016281	3/4" X 8" BOLT		01
08	0511017232	FLAT WASHER		02
09	0531018235	SUPPORT SLEEVE SPACER		02
10	0511063569	UPPER ROCKER ARM		01
11	0501010452	5/8" X 5" BOLT		02
12	0531016207	0.6" X 1" X 2.8" SLEEVE		02
13	0531015184	FLAT WASHER		02
14	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		01
15	0531015137	16,40 X 25,57 X 101 SLEEVE		01
16	0503031389	2.11" X 8.83 X 0.39" TRACTION SPRING		01
17	0502011031	SPRING UPPER HITCH		01
18	0531014953	BOLT GUIDES SLEEVE		01
19	0511017302	FLAT WASHER		01
20	0503013329	1/2" UNC X 4-3/4" BOLT		01
21	0503010060	1/2" NUT		01
22	0501054473	RIGHT 15 X 15 UNAL DOUBLE-DISC	90	01
23	0503010547	1/2" X 4" BOLT		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501056200	RIGHT ROD STOP SCRAPER	92	01
27	0503010834	1/2 X 1 BOLT		01
28	0501046839	RIGHT IRON PRESS WHEEL	93	01
29	0503010752	1/2" X 3.1/2" BOLT		02
30	0503010019	1/2" SPRING WASHER		02
31	0511017302	FLAT WASHER		01

Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		02
33	0503030483	FERTILIZER SOCKET		01
34	0503030520	SEED SOCKET		01
35	0561011813	SOCKET LOCK		02
36	0503031145	2" X 2" X 20" HOSE		01
37	0503030573	1-1/2" X 2" X 400 HOSE		01
38	0503030887	1-1/2" HOSE CLAMP		01
39	0503031076	2" HOSE CLAMP		03
40	0531018513	SLEEVE NYLON 51 X 41 X 33		01
41	0503010246	CLAMP		01
42	0503011255	3/4" LOCK NUT		01
43	0503012412	5/8 UNC SELF LOCKING NUT		02
44	0503012412	5/8 UNC SELF LOCKING NUT		01
45	0503012412	5/8 UNC SELF LOCKING NUT		02
46	0503011255	3/4" LOCK NUT		01
47	0511064467	SHORT FERTILIZER ROW REAR SUPPORT		01




Item	Code	Description	See page	QT
01	0511058212	ASSY LINE SUPPORT FERTILIZER	87	01
02	0502011814	REAR FIXER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0531015184	FLAT WASHER		02
05	0511044553	BLADE DISC ASSY	98	01
06	0511063571	LOWER ROCKER ARM		01
07	0511016281	3/4" X 8" BOLT		01
08	0511017232	FLAT WASHER		02
09	0531018235	SUPPORT SLEEVE SPACER		02
10	0511063569	UPPER ROCKER ARM		01
11	0501010452	5/8" X 5" BOLT		02
12	0531016207	0.6" X 1" X 2.8" SLEEVE		02
13	0531015184	FLAT WASHER		02
14	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		01
15	0531015137	16,40 X 25,57 X 101 SLEEVE		01
16	0503031389	2.11" X 8.83 X 0.39" TRACTION SPRING		01
17	0502011031	SPRING UPPER HITCH		01
18	0531014953	BOLT GUIDES SLEEVE		01
19	0511017302	FLAT WASHER		01
20	0503013329	1/2" UNC X 4-3/4" BOLT		01
21	0503010060	1/2" NUT		01
22	0501054474	LEFT 15 X 15 UNAL DOUBLE-DISC	95	01
23	0503010547	1/2" X 4" BOLT		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501056200	RIGHT ROD STOP SCRAPER	92	01
27	0503010834	1/2 X 1 BOLT		01
28	0501046844	LEFT IRON PRESS WHEEL ASSY	96	01
29	0503010752	1/2" X 3.1/2" BOLT		02
30	0503010019	1/2" SPRING WASHER		02
31	0511017302	FLAT WASHER		01

LEFT FERTILIZER/FINE SEED ROW WITHOUT DISC

0511041104

Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		02
33	0503030483	FERTILIZER SOCKET		01
34	0503030520	SEED SOCKET		01
35	0561011813	SOCKET LOCK		02
36	0503031145	2" X 2" X 20" HOSE		01
37	0503030573	1-1/2" X 2" X 400 HOSE		01
38	0503030887	1-1/2" HOSE CLAMP		01
39	0503031076	2" HOSE CLAMP		03
40	0531018513	SLEEVE NYLON 51 X 41 X 33		01
41	0503010246	CLAMP		01
42	0503011255	3/4" LOCK NUT		01
43	0503012412	5/8 UNC SELF LOCKING NUT		02
44	0503012412	5/8 UNC SELF LOCKING NUT		01
45	0503012412	5/8 UNC SELF LOCKING NUT		02
46	0503011255	3/4" LOCK NUT		01
47	0511064467	SHORT FERTILIZER ROW REAR SUPPORT		01




Item	Code	Description	See page	QT
01	0511058212	ASSY LINE SUPPORT FERTILIZER	87	01
02	0502011814	REAR FIXER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0531015184	FLAT WASHER		02
05	0511044553	BLADE DISC ASSY	98	01
06	0511063571	LOWER ROCKER ARM		01
07	0511016281	3/4" X 8" BOLT		01
08	0511017232	FLAT WASHER		02
09	0531018235	SUPPORT SLEEVE SPACER		02
10	0511063569	UPPER ROCKER ARM		01
11	0501010452	5/8" X 5" BOLT		02
12	0531016207	0.6" X 1" X 2.8" SLEEVE		02
13	0531015184	FLAT WASHER		02
14	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		01
15	0531015137	16,40 X 25,57 X 101 SLEEVE		01
16	0503031389	2.11" X 8.83 X 0.39"TRACTION SPRING		01
17	0502011031	SPRING UPPER HITCH		01
18	0531014953	BOLT GUIDES SLEEVE		01
19	0511017302	FLAT WASHER		01
20	0503013329	1/2" UNC X 4-3/4" BOLT		01
21	0503010060	1/2" NUT		01
22	0501054473	RIGHT 15 X 15 UNAL DOUBLE-DISC	90	01
23	0503010547	1/2" X 4" BOLT		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501056200	RIGHT ROD STOP SCRAPER	92	01
27	0503010834	1/2 X 1 BOLT		01
28	0501046839	RIGHT IRON PRESS WHEEL	93	01
29	0503010752	1/2" X 3.1/2" BOLT		02
30	0503010019	1/2" SPRING WASHER		02
31	0511017302	FLAT WASHER		01

RIGHT FERTILIZER/FINE SEED ROW WITH 16" SMOOTH DISC

0511045468

Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		02
33	0503030483	FERTILIZER SOCKET		01
34	0503030520	SEED SOCKET		01
35	0561011813	SOCKET LOCK		02
36	0503031145	2" X 2" X 20" HOSE		01
37	0503030573	1-1/2" X 2" X 400 HOSE		01
38	0503030887	1-1/2" HOSE CLAMP		01
39	0503031076	2" HOSE CLAMP		03
40	0531018513	SLEEVE NYLON 51 X 41 X 33		01
41	0503010246	CLAMP		01
42	0503011255	3/4" LOCK NUT		01
43	0503012412	5/8 UNC SELF LOCKING NUT		02
44	0503012412	5/8 UNC SELF LOCKING NUT		01
45	0503012412	5/8 UNC SELF LOCKING NUT		02
46	0503011255	3/4" LOCK NUT		01
47	0511064467	SHORT FERTILIZER ROW REAR SUPPORT		01




Item	Code	Description	See page	QT
01	0511058212	ASSY LINE SUPPORT FERTILIZER	87	01
02	0502011814	REAR FIXER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0531015184	FLAT WASHER		02
05	0511044553	BLADE DISC ASSY	98	01
06	0511063571	LOWER ROCKER ARM		01
07	0511016281	3/4" X 8" BOLT		01
08	0511017232	FLAT WASHER		02
09	0531018235	SUPPORT SLEEVE SPACER		02
10	0511063569	UPPER ROCKER ARM		01
11	0501010452	5/8" X 5" BOLT		02
12	0531016207	0.6" X 1" X 2.8" SLEEVE		02
13	0531015184	FLAT WASHER		02
14	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		01
15	0531015137	16,40 X 25,57 X 101 SLEEVE		01
16	0503031389	2.11" X 8.83 X 0.39"TRACTION SPRING		01
17	0502011031	SPRING UPPER HITCH		01
18	0531014953	BOLT GUIDES SLEEVE		01
19	0511017302	FLAT WASHER		01
20	0503013329	1/2" UNC X 4-3/4" BOLT		01
21	0503010060	1/2" NUT		01
22	0501054474	LEFT 15 X 15 UNAL DOUBLE-DISC	95	01
23	0503010547	1/2" X 4" BOLT		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2" NUT		02
26	0501056200	RIGHT ROD STOP SCRAPER	92	01
27	0503010834	1/2 X 1 BOLT		01
28	0501046844	LEFT IRON PRESS WHEEL ASSY	96	01
29	0503010752	1/2" X 3.1/2" BOLT		02
30	0503010019	1/2" SPRING WASHER		02
31	0511017302	FLAT WASHER		01


LEFT FERTILIZER/FINE SEED ROW WITH 16" SMOOTH DISC

0511045469


Item	Code	Description	See page	QT
32	0503010060	1/2" NUT		02
33	0503030483	FERTILIZER SOCKET		01
34	0503030520	SEED SOCKET		01
35	0561011813	SOCKET LOCK		02
36	0503031145	2" X 2" X 20" HOSE		01
37	0503030573	1-1/2" X 2" X 400 HOSE		01
38	0503030887	1-1/2" HOSE CLAMP		01
39	0503031076	2" HOSE CLAMP		03
40	0531018513	SLEEVE NYLON 51 X 41 X 33		01
41	0503010246	CLAMP		01
42	0503011255	3/4" LOCK NUT		01
43	0503012412	5/8 UNC SELF LOCKING NUT		02
44	0503012412	5/8 UNC SELF LOCKING NUT		01
45	0503012412	5/8 UNC SELF LOCKING NUT		02
46	0503011255	3/4" LOCK NUT		01
47	0511064467	SHORT FERTILIZER ROW REAR SUPPORT		01
48	0511017302	FLAT WASHER		01



Item	Code	Description	See page	QT
01	0531054348	FRONT LARGE SEED ROW	100	01
02	0531054346	RIGHT REAR SEED ROW	107	01
03	0531014970	SEED ROW TRANSMISSION AXLE		01
04	0511040703	DEPTH WHEEL ASSY	113	01
05	0501013352	FLAT WASHER		02
06	0501018535	1/2 X 1 BOLT		02
07	0511053857	FAST CLOSING SET	118	01
08	0503030482	SEED SOCKET		01
09	0531053929	SIGMA SEED SYSTEM WITH INDIVIDUAL BOX (SOY)	119	01
10	0501054145	PRESS WHEELS ASSY	123	01




Item	Code	Description	See page	QT
01	0531054348	FRONT LARGE SEED ROW	100	01
02	0531054347	LEFT REAR SEED ROW	109	01
03	0531014970	SEED ROW TRANSMISSION AXLE		01
04	0511040703	DEPTH WHEEL ASSY	113	01
05	0501013352	FLAT WASHER		02
06	0501018535	1/2 X 1 BOLT		02
07	0511053857	FAST CLOSING SET	118	01
08	0503030482	SEED SOCKET		01
09	0531053929	SIGMA SEED SYSTEM WITH INDIVIDUAL BOX (SOY)	119	01
10	0501054145	PRESS WHEELS ASSY	123	01




Item	Code	Description	See page	QT
01	0531054348	FRONT LARGE SEED ROW	100	01
02	0531054346	RIGHT REAR SEED ROW	107	01
03	0531014970	SEED ROW TRANSMISSION AXLE		01
04	0511040703	DEPTH WHEEL ASSY	113	01
05	0501013352	FLAT WASHER		02
06	0501018535	1/2 X 1 BOLT		02
07	0531054345	IRON-V COMPACTOR WHEEL	116	01
08	0511053857	FAST CLOSING SET	118	01
09	0503030482	SEED SOCKET		01
10	0531053929	SIGMA SEED SYSTEM WITH INDIVIDUAL BOX (SOY)	119	01

LEFT LARGE SEED ROW WITH IRON V-COMPACTOR

0531054173



Item	Code	Description	See page	QT
01	0531054348	FRONT LARGE SEED ROW	100	01
02	0531054347	LEFT REAR SEED ROW	109	01
03	0531014970	SEED ROW TRANSMISSION AXLE		01
04	0511040703	DEPTH WHEEL ASSY	113	01
05	0501013352	FLAT WASHER		02
06	0501018535	1/2 X 1 BOLT		02
07	0531054345	IRON-V COMPACTOR WHEEL	116	01
08	0511053857	FAST CLOSING SET	118	01
09	0503030482	SEED SOCKET		01
10	0531053929	SIGMA SEED SYSTEM WITH INDIVIDUAL BOX (SOY)	119	01




Item	Code	Description	See page	QT
01	0511058212	ASSY LINE SUPPORT FERTILIZER	87	01
02	0502011814	REAR FIXER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0531015184	FLAT WASHER		02
05	0503012412	5/8 UNC SELF LOCKING NUT		02
06	0511044553	BLADE DISC ASSY	98	01
07	0511063571	LOWER ROCKER ARM		01
08	0511016281	3/4" X 8" BOLT		01
09	0511017232	FLAT WASHER		02
10	0531018235	SUPPORT SLEEVE SPACER		02
11	0503011255	3/4" LOCK NUT		01
12	0511063569	UPPER ROCKER ARM		01
13	0501010452	5/8" X 5" BOLT		02
14	0531016207	0.6" X 1" X 2.8" SLEEVE		02
15	0531015184	FLAT WASHER		04
16	0503012412	5/8 UNC SELF LOCKING NUT		02
17	0511063572	SEED/FERTILIZER ROW REAR SUPPORT		01
18	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
19	0531015137	16,40 X 25,57 X 101 SLEEVE		01
20	0503012412	5/8 UNC SELF LOCKING NUT		01
21	0503031389	2.11" X 8.83 X 0.39"TRACTION SPRING		01
22	0502011031	SPRING UPPER HITCH		01
23	0531014953	BOLT GUIDES SLEEVE		01
24	0501067363	1/2" X 115 BOLT		01
25	0503010060	1/2" NUT		01
26	0503010547	1/2" X 4" BOLT		02
27	0503010019	1/2" SPRING WASHER		02
28	0503010060	1/2" NUT		02
29	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
29A	0511061768	FERTILIZER SCARIFIER ROD		01
29B	0502070061	POINT SUBSOILER		01

FERTILIZER ROW WITH RIGHT NOZZLE/16" SMOOTH DISC

0511040908

Item	Code	Description	See page	QT
29C	0503011373	0.4" X 1.1" SPRING PIN		01
30	0511018662	SPACING PLATE		02
31	0511017969	0.1" SPACING PLATE		02
32	0511061769	RIGHT FERTILIZER CONDUCTOR WITH REGULATOR		01
34	0503010849	3/8" X 1-1/2" BOLT		02
35	0501010984	FLAT WASHER		02
36	0503010025	3/8" SPRING WASHER		02
37	0503010026	3/8" NUT		02
38	0503031145	2" X 2" X 20" HOSE		01
39	0503030331	1.2" X 1.2" X 12.2" HOSE		01
40	0503030183	1.1/2" HOSE CLAMP		01
41	0503030156	2" HOSE CLAMP		02
42	0503031050	CURVED CONDUCTOR		01
43	0503010246	CLAMP		01
44	0503010243	CLAMP		01
45	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0511058212	ASSY LINE SUPPORT FERTILIZER	87	01
02	0502011814	REAR FIXER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0531015184	FLAT WASHER		02
05	0503012412	5/8 UNC SELF LOCKING NUT		02
06	0511044553	BLADE DISC ASSY	98	01
07	0511063571	LOWER ROCKER ARM		01
08	0511016281	3/4" X 8" BOLT		01
09	0511017232	FLAT WASHER		02
10	0531018235	SUPPORT SLEEVE SPACER		02
11	0503011255	3/4" LOCK NUT		01
12	0511063569	UPPER ROCKER ARM		01
13	0501010452	5/8" X 5" BOLT		02
14	0531016207	0.6" X 1" X 2.8" SLEEVE		02
15	0531015184	FLAT WASHER		04
16	0503012412	5/8 UNC SELF LOCKING NUT		02
17	0511063572	SEED/FERTILIZER ROW REAR SUPPORT		01
18	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
19	0531015137	16,40 X 25,57 X 101 SLEEVE		01
20	0503012412	5/8 UNC SELF LOCKING NUT		01
21	0503031389	2.11" X 8.83 X 0.39" TRACTION SPRING		01
22	0502011031	SPRING UPPER HITCH		01
23	0531014953	BOLT GUIDES SLEEVE		01
24	0501067363	1/2" X 115 BOLT		01
25	0503010060	1/2" NUT		01
26	0503010547	1/2" X 4" BOLT		02
27	0503010019	1/2" SPRING WASHER		02
28	0503010060	1/2" NUT		02
29	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
29A	0511061768	FERTILIZER SCARIFIER ROD		01
29B	0502070061	POINT SUBSOILER		01

FERTILIZER ROW WITH LEFT NOZZLE/16" SMOOTH DISC


0511040925

Item	Code	Description	See page	QT
29C	0503011373	0.4" X 1.1" SPRING PIN		01
30	0511018662	SPACING PLATE		02
31	0511017969	0.1" SPACING PLATE		02
32	0511061770	LEFT CONDUCTOR FERTILIZER WITH REGULATOR		01
34	0503010849	3/8" X 1-1/2" BOLT		02
35	0501010984	FLAT WASHER		02
36	0503010025	3/8" SPRING WASHER		02
37	0503010026	3/8" NUT		02
38	0503031145	2" X 2" X 20" HOSE		01
39	0503030331	1.2" X 1.2" X 12.2" HOSE		01
40	0503030183	1.1/2" HOSE CLAMP		01
41	0503030156	2" HOSE CLAMP		02
42	0503031050	CURVED CONDUCTOR		01
43	0503010246	CLAMP		01
44	0503010243	CLAMP		01
45	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0511058212	ASSY LINE SUPPORT FERTILIZER	87	01
02	0502011814	REAR FIXER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0531015184	FLAT WASHER		02
05	0503012412	5/8 UNC SELF LOCKING NUT		02
06	0511044553	BLADE DISC ASSY	98	01
07	0511063571	LOWER ROCKER ARM		01
08	0511016281	3/4" X 8" BOLT		01
09	0511017232	FLAT WASHER		02
10	0531018235	SUPPORT SLEEVE SPACER		02
11	0503011255	3/4" LOCK NUT		01
12	0511063569	UPPER ROCKER ARM		01
13	0501010452	5/8" X 5" BOLT		02
14	0531016207	0.6" X 1" X 2.8" SLEEVE		02
15	0531015184	FLAT WASHER		04
16	0503012412	5/8 UNC SELF LOCKING NUT		02
17	0511063572	SEED/FERTILIZER ROW REAR SUPPORT		01
18	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
19	0531015137	16,40 X 25,57 X 101 SLEEVE		01
20	0503012412	5/8 UNC SELF LOCKING NUT		01
21	0503031389	2.11" X 8.83 X 0.39"TRACTION SPRING		01
22	0502011031	SPRING UPPER HITCH		01
23	0531014953	BOLT GUIDES SLEEVE		01
24	0501067363	1/2" X 115 BOLT		01
25	0503010060	1/2" NUT		01
26	0503010547	1/2" X 4" BOLT		02
27	0503010019	1/2" SPRING WASHER		02
28	0503010060	1/2" NUT		02
29	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
29A	0511061768	FERTILIZER SCARIFIER ROD		01
29B	0502070061	POINT SUBSOILER		01

Item	Code	Description	See page	QT
29C	0503011373	0.4" X 1.1" SPRING PIN		01
30	0511018662	SPACING PLATE		02
31	0511017969	0.1" SPACING PLATE		02
32	0511061770	LEFT CONDUCTOR FERTILIZER WITH REGULATOR		01
34	0503010849	3/8" X 1-1/2" BOLT		02
35	0501010984	FLAT WASHER		02
36	0503010025	3/8" SPRING WASHER		02
37	0503010026	3/8" NUT		02
38	0503031145	2" X 2" X 20" HOSE		01
39	0503030331	1.2" X 1.2" X 12.2" HOSE		01
40	0503030183	1.1/2" HOSE CLAMP		01
41	0503030156	2" HOSE CLAMP		02
42	0503031050	CURVED CONDUCTOR		01
43	0503010246	CLAMP		01
44	0503010243	CLAMP		01
45	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0511058212	ASSY LINE SUPPORT FERTILIZER	87	01
02	0502011814	REAR FIXER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0531015184	FLAT WASHER		02
05	0503012412	5/8 UNC SELF LOCKING NUT		02
06	0511044553	BLADE DISC ASSY	98	01
07	0511063571	LOWER ROCKER ARM		01
08	0511016281	3/4" X 8" BOLT		01
09	0511017232	FLAT WASHER		02
10	0531018235	SUPPORT SLEEVE SPACER		02
11	0503011255	3/4" LOCK NUT		01
12	0511063569	UPPER ROCKER ARM		01
13	0501010452	5/8" X 5" BOLT		02
14	0531016207	0.6" X 1" X 2.8" SLEEVE		02
15	0531015184	FLAT WASHER		04
16	0503012412	5/8 UNC SELF LOCKING NUT		02
17	0511063572	SEED/FERTILIZER ROW REAR SUPPORT		01
18	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
19	0531015137	16,40 X 25,57 X 101 SLEEVE		01
20	0503012412	5/8 UNC SELF LOCKING NUT		01
21	0503031389	2.11" X 8.83 X 0.39" TRACTION SPRING		01
22	0502011031	SPRING UPPER HITCH		01
23	0531014953	BOLT GUIDES SLEEVE		01
24	0501067363	1/2" X 115 BOLT		01
25	0503010060	1/2" NUT		01
26	0503010547	1/2" X 4" BOLT		02
27	0503010019	1/2" SPRING WASHER		02
28	0503010060	1/2" NUT		02
29	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
29A	0511061768	FERTILIZER SCARIFIER ROD		01
29B	0502070061	POINT SUBSOILER		01

Item	Code	Description	See page	QT
29C	0503011373	0.4" X 1.1" SPRING PIN		01
30	0511018662	SPACING PLATE		02
31	0511017969	0.1" SPACING PLATE		02
32	0511061770	LEFT CONDUCTOR FERTILIZER WITH REGULATOR		01
34	0503010849	3/8" X 1-1/2" BOLT		02
35	0501010984	FLAT WASHER		02
36	0503010025	3/8" SPRING WASHER		02
37	0503010026	3/8" NUT		02
38	0503031145	2" X 2" X 20" HOSE		01
39	0503030331	1.2" X 1.2" X 12.2" HOSE		01
40	0503030183	1.1/2" HOSE CLAMP		01
41	0503030156	2" HOSE CLAMP		02
42	0503031050	CURVED CONDUCTOR		01
43	0503010246	CLAMP		01
44	0503010243	CLAMP		01
45	0511017302	FLAT WASHER		01



Item	Code	Description	See page	QT
01	0511058212	ASSY LINE SUPPORT FERTILIZER	87	01
02	0502011814	REAR FIXER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0531015184	FLAT WASHER		02
05	0503012412	5/8 UNC SELF LOCKING NUT		02
06	0511044553	BLADE DISC ASSY	98	01
07	0511063571	LOWER ROCKER ARM		01
08	0511016281	3/4" X 8" BOLT		01
09	0511017232	FLAT WASHER		02
10	0531018235	SUPPORT SLEEVE SPACER		02
11	0503011255	3/4" LOCK NUT		01
12	0511063569	UPPER ROCKER ARM		01
13	0501010452	5/8" X 5" BOLT		02
14	0531016207	0.6" X 1" X 2.8" SLEEVE		02
15	0531015184	FLAT WASHER		04
16	0503012412	5/8 UNC SELF LOCKING NUT		02
17	0511063572	SEED/FERTILIZER ROW REAR SUPPORT		01
18	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
19	0531015137	16,40 X 25,57 X 101 SLEEVE		01
20	0503012412	5/8 UNC SELF LOCKING NUT		01
21	0503031389	2.11" X 8.83 X 0.39"TRACTION SPRING		01
22	0502011031	SPRING UPPER HITCH		01
23	0531014953	BOLT GUIDES SLEEVE		01
24	0501067363	1/2" X 115 BOLT		01
25	0503010060	1/2" NUT		01
26	0503010547	1/2" X 4" BOLT		02
27	0503010019	1/2" SPRING WASHER		02
28	0503010060	1/2" NUT		02
29	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
29A	0511061768	FERTILIZER SCARIFIER ROD		01
29B	0502070061	POINT SUBSOILER		01

Item	Code	Description	See page	QT
29C	0503011373	0.4" X 1.1" SPRING PIN		01
30	0511018662	SPACING PLATE		02
31	0511017969	0.1" SPACING PLATE		02
32	0511061770	LEFT CONDUCTOR FERTILIZER WITH REGULATOR		01
34	0503010849	3/8" X 1-1/2" BOLT		02
35	0501010984	FLAT WASHER		02
36	0503010025	3/8" SPRING WASHER		02
37	0503010026	3/8" NUT		02
38	0503031145	2" X 2" X 20" HOSE		01
39	0503030331	1.2" X 1.2" X 12.2" HOSE		01
40	0503030183	1.1/2" HOSE CLAMP		01
41	0503030156	2" HOSE CLAMP		02
42	0503031050	CURVED CONDUCTOR		01
43	0503010246	CLAMP		01
44	0503010243	CLAMP		01
45	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0511058212	ASSY LINE SUPPORT FERTILIZER	87	01
02	0502011814	REAR FIXER		01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0531015184	FLAT WASHER		02
05	0503012412	5/8 UNC SELF LOCKING NUT		02
06	0511046441	SHORT BLADE DISC STRIATED	88	01
07	0511063571	LOWER ROCKER ARM		01
08	0511016281	3/4" X 8" BOLT		01
09	0511017232	FLAT WASHER		02
10	0531018235	SUPPORT SLEEVE SPACER		02
11	0503011255	3/4" LOCK NUT		01
12	0511063569	UPPER ROCKER ARM		01
13	0501010452	5/8" X 5" BOLT		02
14	0531016207	0.6" X 1" X 2.8" SLEEVE		02
15	0531015184	FLAT WASHER		04
16	0503012412	5/8 UNC SELF LOCKING NUT		02
17	0511063572	SEED/FERTILIZER ROW REAR SUPPORT		01
18	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
19	0531015137	16,40 X 25,57 X 101 SLEEVE		01
20	0503012412	5/8 UNC SELF LOCKING NUT		01
21	0503031389	2.11" X 8.83 X 0.39"TRACTION SPRING		01
22	0502011031	SPRING UPPER HITCH		01
23	0531014953	BOLT GUIDES SLEEVE		01
24	0501067363	1/2" X 115 BOLT		01
25	0503010060	1/2" NUT		01
26	0503010547	1/2" X 4" BOLT		02
27	0503010019	1/2" SPRING WASHER		02
28	0503010060	1/2" NUT		02
29	0501110231	SCARIFIER HEAD WITH SPIKE 0061		01
29A	0511061768	FERTILIZER SCARIFIER ROD		01
29B	0502070061	POINT SUBSOILER		01


FERTILIZER ROW WITH LEFT NOZZLE/16" RIBBED DISC

0511055821


Item	Code	Description	See page	QT
29C	0503011373	0.4" X 1.1" SPRING PIN		01
30	0511018662	SPACING PLATE		02
31	0511017969	0.1" SPACING PLATE		02
32	0511061770	LEFT CONDUCTOR FERTILIZER WITH REGULATOR		01
34	0503010849	3/8" X 1-1/2" BOLT		02
35	0501010984	FLAT WASHER		02
36	0503010025	3/8" SPRING WASHER		02
37	0503010026	3/8" NUT		02
38	0503031145	2" X 2" X 20" HOSE		01
39	0503030331	1.2" X 1.2" X 12.2" HOSE		01
40	0503030183	1.1/2" HOSE CLAMP		01
41	0503030156	2" HOSE CLAMP		02
42	0503031050	CURVED CONDUCTOR		01
43	0503010246	CLAMP		01
44	0503010243	CLAMP		01
45	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
001	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
002	0502012368	BLADE DISC SUPPORT AXLE		01
003	0541018684	FLAT WASHER		01
004	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
005	0503010361	SPRING PIN		01
006	0521014137	RIGHT ARM OF THE BLADE DISC		01
007	0521014138	SUPPORT ARM LEFT BALDE DISC		01
008	0501067323	SPRING REGULATOR		01
009	0521010452	SLEEVE		01
010	0503013185	3/4" X 5-1/2" BOLT		01
011	0503011255	3/4" LOCK NUT		01
012	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
013	0503011411	1/2" X 5-1/2" BOLT		01
014	0503011440	SPRING WASHER		01
015	0503010060	1/2" NUT		01
016	1902020393	SPRING UPPER SUPPORT		02
017	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
018	0503010014	3/4" NUT		02
019	0501058030	ESTR DISC BLADE DISC ASSY	89	01
020	0521015376	DUST CLOAK		02
021	0521015818	FLAT WASHER		06
022	0503011438	SPRING WASHER		02
023	0521013510	3/4" NUT		02
024	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
001	0502011562	DC BOX		01
002	0503010276	6206 BALL BEARING		02
003	0521013610	BLADE DISC HUB AXLE		01
004	0503030832	FLAT WASHER		02
005	0503012417	SEAL		02
006	0503011800	SEAL RING		02
007	0503010691	1/4" GREASE FITTING		01
008	0605023018	PLAIN COULTER BLADE		01
009	0502020641	BLADE DISC FLANGE		01
010	0503010371	5/16" X 1" BOLT		06
011	0503011444	SPRING WASHER		06
012	0503010337	5/16" NUT		06
013	1882970002	GREASE SOAP		00




Item	Code	Description	See page	QT
001	0502012114	15"X15" RIGHT DOUBLE DISC SUPPORT		01
002	0501054151	RIGHT DOUBLE DISC COULTER BOX	91	01
003	0501054168	BOX DDD ASSY DPL 15 LEFT	112	01
004	0511015098	FLAT WASHER		02
005	0511011927	DUST CLOAK		02
006	0521019178	COVER DEPTH		02
007	0503030757	2.9" X 2" X 0.02" JOINT		02
008	0503014729	1/4" UNF X 1/2" BOLT		06
009	0503011441	SPRING WASHER		06
010	0502020662	ROD STOP		01
011	0531013568	RIGHT DOUBLE DISC SCRAPER		01
012	0531013569	LEFT DOUBLE-DISC SCRAPER		01
013	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
014	0501010984	FLAT WASHER		02
015	0503011443	3/8" SPRING WASHER		01
016	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0502011933	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0521019154	RIGHT DOUB DISC HUB		01
04	0603022024	15" X 0.2" C1,2 PLAIN COULTER BLADE		01
05	0503011112	SEAL 02376-BRG		01
06	0503030282	3/4" CASTLE NUT		01
07	0503010257	1/8" X 1" COTTERPIN		01
08	0503010256	3/8" X 3/4" BOLT		03
09	0503011443	3/8" SPRING WASHER		03
10	0503010546	5/16" X 7/8" BOLT		09
11	0503010337	5/16" NUT		09




Item	Code	Description	See page	QT
01	0541016755	ROD STOP SCRAPER		01
02	0541016756	L 41,50 X 58,50 X 6,30 SDA3		01
03	0541016758	RIGHT SCRAPER SUPPORT		01
04	0541016757	LEFT SCRAPER SUPPORT		01
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
06	0501010984	FLAT WASHER		02
07	0503010025	3/8" SPRING WASHER		02
08	0503010026	3/8" NUT		02
09	0503010752	1/2" X 3.1/2" BOLT		02
10	0511017302	FLAT WASHER		02
11	0503010019	1/2" SPRING WASHER		02
12	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502011068	RIGHT ARM		01
02	0501053187	LEFT IRON PRESS WHEEL ASSY	94	01
03	0502011155	RIGHT FIXER WHEEL		01
04	0501066592	IRON PRESS WHEEL LEFT SCRAPER		01
05	0502011066	PRESS WHEELS ARM SUPPORT		01
06	0503030883	RIGHT TORSION SPRING		01
07	0521010543	1" X 5" COUPLING SHAFT		01
08	0503010839	03"X 0.6" SPRING PIN		02
09	0503011082	C1/2" X 1.3/4" SCREW		02
10	0503011440	SPRING WASHER		02
11	0501010937	13.5 X 28 X 3 FLAT WASHER		02
12	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011970	IRON PRESS WHEEL		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0511015098	FLAT WASHER		01
06	0503030282	3/4" CASTLE NUT		01
07	0503010257	1/8" X 1" COTTERPIN		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503013758	1/4" X 1-1/2" BOLT		03
12	0511016896	DUST CLOAK		01




Item	Code	Description	See page	QT
001	0502012115	15"X15" LEFT DOUBLE DISC SUPPORT		01
002	0501054151	RIGHT DOUBLE DISC COULTER BOX	91	01
003	0501054168	BOX DDD ASSY DPL 15 LEFT	112	01
004	0511015098	FLAT WASHER		02
005	0511011927	DUST CLOAK		02
006	0521019178	COVER DEPTH		02
007	0503030757	2.9" X 2" X 0.02" JOINT		02
008	0503014729	1/4" UNF X 1/2" BOLT		06
009	0503011441	SPRING WASHER		06
010	0502020662	ROD STOP		01
011	0531013568	RIGHT DOUBLE DISC SCRAPER		01
012	0531013569	LEFT DOUBLE-DISC SCRAPER		01
013	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
014	0501010984	FLAT WASHER		02
015	0503011443	3/8" SPRING WASHER		01
016	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0502011069	ARM LEFT		01
02	0501053186	RIGHT IRON PRESS WHEEL ASSY	97	01
03	0502011156	LEFT FIXER WHEEL		01
04	0501066591	IRON PRESS WHEEL RIGHT SCRAPER		01
05	0502011067	LEFT PRESS WHEELS ARM SUPPORT		01
06	0503030882	LEFT TORSION SPRING		01
07	0521010543	1" X 5" COUPLING SHAFT		01
08	0503010839	03"X 0.6" SPRING PIN		02
09	0503011082	C1/2" X 1.3/4" SCREW		02
10	0503011440	SPRING WASHER		02
11	0501010937	13.5 X 28 X 3 FLAT WASHER		02
12	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011970	IRON PRESS WHEEL		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT DOUB DISC HUB		01
05	0511015098	FLAT WASHER		01
06	0503030282	3/4" CASTLE NUT		01
07	0503010257	1/8" X 1" COTTERPIN		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503013758	1/4" X 1-1/2" BOLT		03
12	0511016896	DUST CLOAK		01



Item	Code	Description	See page	QT
01	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
02	0502012368	BLADE DISC SUPPORT AXLE		01
03	0541018684	FLAT WASHER		01
04	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
05	0503010361	SPRING PIN		01
06	0521014137	RIGHT ARM OF THE BLADE DISC		01
07	0521014138	SUPPORT ARM LEFT BALDE DISC		01
08	0503010003	1845 GREASE FITTING		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0503011255	3/4" LOCK NUT		01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
14	0503011411	1/2" X 5-1/2" BOLT		01
15	0503011440	SPRING WASHER		01
16	0503010060	1/2" NUT		01
17	1902020393	SPRING UPPER SUPPORT		02
18	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
19	0503011442	3/4" SPRING WASHER		02
20	0501053938	16 DPL BLADE DISC	99	01
21	0521015376	DUST CLOAK		02
22	0521015818	FLAT WASHER		06
23	0503011438	SPRING WASHER		02
24	0521013510	3/4" NUT		02
25	0503810014	3/4" NUT		02




Item	Code	Description	See page	QT
00	0501053938	16 DPL BLADE DISC	99	01
01	0502011562	DC BOX		01
02	0503010276	6206 BALL BEARING		02
03	0521013610	BLADE DISC HUB AXLE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603023067	PLAIN COULTER BLADE		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503010179	LOCK WASHER		06
12	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0511063586	ROW FIXER SUPPORT		01
02	0503012412	5/8 UNC SELF LOCKING NUT		04
03	0511063591	ROW LOWER PARALELOGRAMO		01
04	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
05	0531015151	0.6" X 1" X 2.4" SLEEVE		08
06	0511063590	UPPER ARM PARALELOGRAMO		01
07	0503010003	1845 GREASE FITTING		04
08	0511063592	SEED ROW REAR SUPPORT		01
09	0501053826	BEARING WITH 17Z GEAR	101	01
10	0503010577	3/16" X 1-1/4" COTTERPIN		01
11	0503030168	CUPILLA		01
12	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
13	0503010257	1/8" X 1" COTTERPIN		01
14	0503010752	1/2" X 3.1/2" BOLT		02
15	0503010019	1/2" SPRING WASHER		02
16	0503010060	1/2" NUT		02
17	0501053552	UPPER SIDE BEARING	102	01
18	0501053553	UPPER CENTER BEARING	103	01
19	0511059247	BEARING WITH GEAR LINE PIVOTED PRECISION PLANTING	104	01
20	0531015184	FLAT WASHER		08
21	0503010027	5/8" SPRING WASHER		04
22	0501053949	SEED AXLE TENSIONER CHAIN LINE	105	01
23	0503013064	40-1 X 43 CHAIN LINK + MENDING		01
24	0503012515	40-1 X CHAIN 77 LINK+ MENDING		01
25	0502012568	UPPER ROCKER ARM		01
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	106	01
27	0502010175	HITCH CLAMP		01
28	0501011388	COUPLING SHAFT		02
29	0521017623	0.5" X 1.5" COUPLING SHAFT		01
30	0503018814	SCREW 5/8 UNF X 5" G.5 CS ZN		02
31	0591011409	FLAT WASHER 16,5 X 35 X 3,00		02




Item	Code	Description	See page	QT
32	0503010811	5/8" UNF SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0501052775	ROW SEED BEARING		01
02	0502012028	17Z GEAR WITH HEX HOLE AXLE, 0.5"		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page
01	0501053297	BEARING WITH DOUBLE BALL BEARING	01
01A	0511063045	DOUBLE BERING AXLE	01
01B	0503010406	501025 CLAMPING RING (FOR AXLE)	01
01C	0503010365	NUT	02
01D	0501010694	FLAT WASHER	04
01E	0503010179	LOCK WASHER	02
01F	0503010337	5/16" NUT	02




Item	Code	Description	See page
00	0501053553	UPPER CENTER BEARING	103
01	0501053297	BEARING WITH DOUBLE BALL BEARING	01
01A	0511063045	DOUBLE BEARING AXLE	01
01B	0503010406	501025 CLAMPING RING (FOR AXLE)	01
01C	0503010365	NUT	02
01D	0501010694	FLAT WASHER	04
01E	0503010179	LOCK WASHER	02
01F	0503010337	5/16" NUT	02




Item	Code	Description	See page	QT
01	0503010406	501025 CLAMPING RING (FOR AXLE)		01
02	0502011697	BEARING OF THE GEAR BOX		01
03	0503011410	ROLLER BEARING		01
04	0503011105	SEAL RING		01
05	0503011953	5/16" X 1" BOLT		02
06	0501010694	FLAT WASHER		02
07	0503010179	LOCK WASHER		02
08	0503010337	5/16" NUT		02
09	0502012819	17Z GEAR WITH HEX HOLE		01




Item	Code	Description	See page	QT
001	0511063407	SEED AXLE TENSIONER CHAIN LINE		01
002	0531015164	CHAIN TIGHTENER FIX AXLE		01
003	0503031367	SPRING		01
004	0503010027	5/8" SPRING WASHER		01
005	0503010013	5/8" NUT		01
006	0503030402	PULLEY		01
007	0503010302	501019 SEAL RING		01
008	0503010004	1890 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502012314	SEED BOX FIXING BASE		01
02	0502011411	10Z CONICAL GEAR		01
03	0502011418	40Z CONICAL GEAR		01
04	0511018700	AXLE		01
05	0531016075	LEFT SIDE BASE		01
06	0531016074	RIGHT SIDE BASE		01
07	0501052978	RIGHT 15" X 15" DOUBLE DISC	108	01
08	0503010848	5/16" X 3.1/2" BOLT		02
09	0503010337	5/16" NUT		02
10	0503010179	LOCK WASHER		02
11	0503011135	BOLT		01
12	0503011446	SPRING WASHER		04
13	0503010244	7/16" NUT		03
14	0503010851	7/16" X 3.1/2" BOLT		01
15	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		02
16	0502012331	DEPTH WHEEL SUPPORT		01
17	0503010479	BOLT		01
18	0503010060	1/2" NUT		01
19	0503011440	SPRING WASHER		01
20	0503010002	1800 GREASE FITTING		02
21	0503013233	7/16 NUT		01




Item	Code	Description	See page	QT
01	0502011184	15" X 15" DOUBLE DISC SUPPORT		01
02	0501054167	BOX DDD ASSY DPL 15 RIGHT	111	01
03	0511011927	DUST CLOAK		02
04	0503030757	2.9" X 2" X 0.02" JOINT		02
05	0521019178	COVER DEPTH		02
06	0501054168	BOX DDD ASSY DPL 15 LEFT	112	01
07	0511015098	FLAT WASHER		06
08	0501017542	LH DOUBLE DISC SCRAPER		01
09	0501017541	RIGHT DOUBLE DISC SCRAPER		01
10	0503014729	1/4" UNF X 1/2" BOLT		06
11	0503010143	1/4" SPRING WASHER		06
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01

LEFT REAR SEED ROW


0531054347




Item	Code	Description	See page	QT
01	0502012314	SEED BOX FIXING BASE		01
02	0502011411	10Z CONICAL GEAR		01
03	0502011418	40Z CONICAL GEAR		01
04	0511018700	AXLE		01
05	0531016075	LEFT SIDE BASE		01
06	0531016074	RIGHT SIDE BASE		01
07	0501052979	LEFT 15" X 15" DOUBLE DISC	110	01
08	0503010848	5/16" X 3.1/2" BOLT		02
09	0503010337	5/16" NUT		02
10	0503010179	LOCK WASHER		02
11	0503011135	BOLT		01
12	0503011446	SPRING WASHER		04
13	0503010244	7/16" NUT		03
14	0503010851	7/16" X 3.1/2" BOLT		01
15	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		02
16	0502012331	DEPTH WHEEL SUPPORT		01
17	0503010479	BOLT		01
18	0503010060	1/2" NUT		01
19	0503011440	SPRING WASHER		01
20	0503010002	1800 GREASE FITTING		02
21	0503013233	7/16 NUT		01




Item	Code	Description	See page	QT
01	0502011183	15"X15" LW SEED UNAL DOUB-DISC SUPP		01
02	0501054167	BOX DDD ASSY DPL 15 RIGHT	111	01
03	0511011927	DUST CLOAK		02
04	0503030757	2.9" X 2" X 0.02" JOINT		02
05	0521019178	COVER DEPTH		02
06	0501054168	BOX DDD ASSY DPL 15 LEFT	112	01
07	0511015098	FLAT WASHER		06
08	0501017542	LH DOUBLE DISC SCRAPER		01
09	0501017541	RIGHT DOUBLE DISC SCRAPER		01
10	0503010143	1/4" SPRING WASHER		06
11	0503014729	1/4" UNF X 1/2" BOLT		06
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0502011930	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT DOUB DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011930	DOUBLE DISC COULTER BOX		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0501053714	DEPTH REGULATOR W/ BOX	114	01
02	0501056749	DEPTH CONTROL WHEEL RUBBER BAND	115	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503010179	LOCK WASHER		08
05	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0511063262	DEPTH REGULATOR ARM		01
02	0503010689	SEAL 00763-BR		02
03	0503010269	6204 BALL BEARING		04
04	0501013636	SPACING SLEEVE		02
05	0502011907	DEPTH CONTROL WHEEL HUB		02
06	0503010878	5/8" SELF ALIGNING NUT		02
07	0503011105	SEAL RING		02
08	0503030757	2.9" X 2" X 0.02" JOINT		02
09	0521019178	COVER DEPTH		02
10	0503014729	1/4" UNF X 1/2" BOLT		06
11	0503010691	1/4" GREASE FITTING		02
12	0503011441	SPRING WASHER		06




Item	Code	Description	See page	QT
01	0503031711	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0531013652	DEPHT WHEEL ARO FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501013799	RIGHT ARM		01
02	0501013798	LEFT ARM		01
03	0501069979	SPRING REGULATOR		01
04	0501052957	IRON V PRESS WHEELS	117	02
05	0502040534	SPRING GUIDE BUSHING LOCK		02
06	0501018535	1/2 X 1 BOLT		02
07	0502011757	PRESS REGULATOR		01
08	0503010849	3/8" X 1-1/2" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0521013310	0.5" X 3" COUPLING SHAFT		01
12	0503010300	5/32" X 1" COTTERPIN		01
13	0503010479	BOLT		01
14	0541016309	13,2 X 22,18 SLEEVE		01
15	0503010019	1/2" SPRING WASHER		01
16	0503010060	1/2" NUT		01
17	0503016449	1/2 X 4 BOLT		01
18	0503012136	NUT 1/2 NF		01
19	0521014508	FLAT WASHER		10
20	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
21	0503016864	LH 1/2" LOCK NUT		01
22	0503030399	1"X5.1"X 0.2" COMPRESSION SPRING		01




Item	Code	Description	See page	QT
01	0502011932	IRON PRESS WHEELS		01
02	0503010269	6204 BALL BEARING		02
03	0503011105	SEAL RING		01
04	0503013848	5072-BR SEAL		02
05	0521019147	V COMPACT WHEELS AXLE		02
06	0511011927	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012744	SPEED LOCK LEVER ASSY		01
02	0502012743	FAST BOLT ASSY		01
03	0571014534	FAST BOLT ADJUSTMENT		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010257	1/8" X 1" COTTERPIN		02



Item	Code	Description	See page	QT
01	0503063602	SEMI-ASSEMBLED SIGMA INDIVIDUAL SEED BOX	120	01
02	0503010179	LOCK WASHER		04
03	0501010694	FLAT WASHER		04
04	0503010240	BOLT		04
05	0531052814	SIGMA SEED SYSTEM (SOY)	121	01
06	0503035691	ADHESIVE LABEL		02




Item	Code	Description	See page	QT
01	0503035628	SIGMA YELLOW SEED BOX		01
02	0503035629	SIGMA SEED BOX LID		01
03	0503035298	BAKELITE HANDLE WITH THREAD		01
04	0503015536	M6 X 1" SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0502013007	SUPPORT BOX SEED		01
02	0502013006	LOWER SEED DISK TRACK		01
03	0511057289	ASSY SEED DEFLECTOR	122	01
04	0503010675	5/16" X 2.1/4" BOLT		01
05	0503010337	5/16" NUT		01
06	0513010140	SOYA DISK SOCIDISC 90 HOLES		01
07	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461		01
08	0503063405	SOY SEED DISTRIBUTOR BOX		01
09	0503016282	ALLEN BOLT		01
10	0503019913	SELF-LOCKING NUT W/ NYLON M8 X 1.25 C.8 ZN		01
11	0503035299	PLATE SPRING 16 X 8.2 X 0.90		02
12	0503030083	3/8" X 3/8" X 1.6" STUD		02
13	0501013518	FLAT WASHER		02
14	0503010025	3/8" SPRING WASHER		03
15	0503010209	3/8" UNC BUTTERFLY NUT		02
16	0531018622	BOLT FAST SUPPORT UPPER		01
17	0501010096	3/8" X 2" BOLT		01
18	0501010984	FLAT WASHER		01
19	0503010026	3/8" NUT		01

ASSY SEED DEFLECTOR


0511057289




Item	Code	Description	See page	QT
01	0503010025	3/8" SPRING WASHER		01
02	0503010209	3/8" UNC BUTTERFLY NUT		01
03	0571018536	HEX PRISONER		01
04	0501013518	FLAT WASHER		02
05	0503034131	DEFLECTOR		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	124	02
02	0502011757	PRESS REGULATOR		01
03	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
04	0521014508	FLAT WASHER		10
05	0503011336	1/2" HEX SELF ADJUSTING NUT		02
06	0501013798	LEFT ARM		01
07	0501013799	RIGHT ARM		01
08	0503010849	3/8" X 1-1/2" BOLT		02
09	0503010025	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0501069979	SPRING REGULATOR		01
12	0521013310	0.5" X 3" COUPLING SHAFT		01
13	0503010300	5/32" X 1" COTTERPIN		01
14	0503010479	BOLT		01
15	0541016309	13,2 X 22,18 SLEEVE		01
16	0503010019	1/2" SPRING WASHER		01
17	0503010060	1/2" NUT		01
18	0502040534	SPRING GUIDE BUSHING LOCK		02
19	0503030399	1"X5.1"X 0.2" COMPRESSION SPRING		01
20	0501018535	1/2 X 1 BOLT		02




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03



Item	Code	Description	See page	QT
01	0513010117	SOCIDISCO CORN DISC 28 HOLES 9,0 AMC9R-002130	01	01
02	0513010118	SOCIDISCO CORN DISC 28 HOLES 9,5 VLD9.5R-002115	01	01
03	0513010119	SOCIDISCO CORN DISC 28 HOLES 10 SAL10R-002619	01	01
04	0513010120	SOCIDISCO CORN DISC 28 HOLES 10,5 RSP10.5R-002133	01	01
05	0513010121	SOCIDISCO CORN DISC 28 HOLES 11 LRA11R-002134	01	01
06	0513010122	SOCIDISCO CORN DISC 28 HOLES 11,5 MAG11.5R-002620	01	01
07	0513010123	SOCIDISCO CORN DISC 28 HOLES 12 VDA12R-002621	01	01
08	0513010124	SOCIDISCO CORN DISC 28 HOLES 12,5 AMP12.5R-002131	01	01
09	0513010125	SOCIDISCO CORN DISC 28 HOLES 13 VMV13R-002132	01	01
10	0513010126	SOCIDISCO CORN DISC 28 HOLES 13,5 RXR13.5R-002136	01	01
11	0513010187	SOCIDISCO CORN DISC 28 HOLES 14,8 X 10 VM4-002581	01	01
12	0513010188	SOCIDISCO CORN DISC 28 HOLES 11 X 8 BR8.1-002589	01	01
13	0513010189	SOCIDISCO CORN DISC 28 HOLES 12,5 X 8,5 AZ8.2-002587	01	01
14	0513010164	SOCIDISCO FLAT RING FOR CORN AMFOSLISO-002127	01	01
15	0513010159	SOCIDISCO RING FOR CORN 0,8MM LRFOSSR08-002120	01	01
16	0513010160	SOCIDISCO RING FOR CORN 1,4MM VMFOSR1.4-002245	01	01
17	0513010163	SOCIDISCO RING FOR CORN 2,0MM VDFOSR2-002116	01	01
18	0503063413	CORN SEED DISTRIBUTOR BOX 4Z - 001798	01	01



Item	Code	Description	See page	QT
01	0513010136	SOCIDISCO SOY DISC 62 HOLES 7,5 LRA62.75-002357	01	01
02	0513010137	SOCIDISCO SOY DISC 62 HOLES 8,0 RSP62.80-002358	01	01
03	0513010138	SOCIDISCO SOY DISC 62 HOLES 8,5 RXR62.85-002359	01	01
04	0513010139	SOCIDISCO SOY DISC 62 HOLES 9,0 AZM62.90-002360	01	01
05	0513010141	SOCIDISCO SOY DISC 90 HOLES 8,0 RSP90.80-002287	01	01
06	0513010142	SOCIDISCO SOY DISC 90 HOLES 8,5 RXR90.85-002317	01	01
07	0513010143	SOCIDISCO SOY DISC 90 HOLES 9,0 AZM90.90-002288	01	01
08	0513010158	SOCIDISCO FLAT RING FOR SOY AZMSOJALISO-002243	01	01
09	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461	01	01
10	0513010162	SOCIDISCO RING FOR SOY 1,5MM RSPSOJASR1,5-002244	01	01
11	0503063412	4Z SOY/BEAN SEED DISTRIBUTOR BOX - 001804	01	01



MARCHESAN

Technical Publications | Elaboration and Revision

LEONARDO JOSÉ DA SILVA SOUZA

www.marchesan.com.br

