

ROW CROP PLANTERS

USAP SUPREMA P. P MINI HOPPER - FRAME 20250 - CSC/APT/VDRIVE/SEED

Code: 0501093324
Series: S-0419
Revision: 00
Date Revision: JUNHO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111440219	USAP SUP 20250/40E500 CSC CM PPH ESPECIAL S-0419

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909096352	ASSY FRAME	1
0909096353	ASSY RIGHT SIDE FRAME	2
0909096354	ASSY RIGHT FRAME	3
0909096355	ASSY CENTRAL FRAME	4
0909096356	ASSY LEFT FRAME	5
0909096357	ASSY LEFT SIDE FRAME	6
0531051076	TELESCOPIC HEAD WITH FIXING	7
0521052189	38,10 X 63,50 X 386 X 148 HYDRAULIC CYLINDER	8
0521058357	FRENCH HAND FRONT AXLE ASSY	9
0521057792	PANTOGRAPHY HEADER	10
0521057786	HYDRAULIC CYLINDER HEAD PANTOGRAPH	11
0531054446	ARTICULATED FRENCH HAND 7377 COMPLETE LEFT	12
0531054447	ARTICULATED FRENCH HAND 7377 COMPLETE RIGHT	13
0521058088	ROTULA WITH EXTENSOR AXIS 2	14
0531051811	REAR AXLE	15
0531051121	FRENCH HAND TELESCOPIC 5846X10230 COMPLETE	16
0521059390	JOINT SUPPORT	17
0521052138	LADDER REAR	18
0511052457	REAR SIDE HANDRAIL LADDER	19
0511052499	HANDRAIL LADDER BACK RIGHT CENTRAL FRAME	20
0511059383	HANDRAIL INTERNAL FIXER	21
0531052688	SEMI ASSEMBLED REST	22
0521057815	HYDRAULIC HOSE SUPPORT WITH FIXATION	23
0521055355	SUPPORT WITH FLOW DIVIDER BLOCK FOR 5 TURBINES	24
0521055356	FLUX DIVIDER BLOCK FOR 03 TURBINES	25
0521059540	ASSY TRACTOR HITCH AXLE	26
0531053278	SMALL REAR STAND FULL CENTER CHASSIS	27
0531053277	COMPLETE SIDE CHASSIS STAND	28
0531050960	WHEEL SUPPORT WITH CONTROL VALVE	29
0521058907	SIDE WHEEL WITHOUT TRANSMISSION	30
0521058137	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION 564	31
0521058783	50,80 X 127 X 381 MM 3/4 NIPPLE HYDRAULIC CYLINDER	32
0531051244	SEED BOX 17/8 LEFT SIDE OUTLETS	33
0531050114	COMPLETE SIDE BOX SUPPORT	34
0531050113	BEARING HANGER ASSEMBLY	35
0531051245	LEFT SIDE PLATFORM	36
0521052175	SUPPORT PLATFORM ASSY	37
0531050115	PLATFORM/LADDER SIDE SUPPORT	38
0531051261	RIGHT SIDE HANDRAIL	39
0531055106	1027 FRONT SIDE HANDRAIL	40
0531055107	980 FRONT SIDE HANDRAIL	41
0531055108	1745 RIGHT SIDE HANDRAIL	42
0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	43
0531055109	1789 LEFT SIDE HANDRAIL	44
0531050947	U HANDRAIL FIXER	45
0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	46
0531050140	ASSY RIGHT LADDER	47
0531051260	ASSY RIGHT HYDRAULIC TURBINE	48
0531050948	LEFT SIDE TURBINE SUPPORT	49
0521045392	HYDRAULIC TURBINE WITH SCREEN	50
0501054983	NIPPLE HIDRAULIC MOTOR	51
0521044613	480 X 50 FAN (HIDRAULIC)	52
0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE	53
0531051262	RIGHT SIDE AIR DUCT ASSEMBLY	54
0531051036	SIDE AIR CONDUCTOR 7 BUTTONS X 500 X 3258	55

INDEX

0531051035	COMPLETE MAJOR AIR CONDUCTOR SUPPORT	56
0521052549	CLAMP	57
0521052168	SEED HOSE GUIDE	58
0531051028	SIDE HOSE SUPPORT	59
0531051249	SIDE CHANNEL ASSEMBLY	60
0521055102	BIGGEST FULL GUTTER SUPPORT	61
0531051263	RIGHT SIDE DUCT ASSEMBLY	62
0511059943	SUPPORT FASTENER ASSY	63
0521053025	DUCT SUPPORT OIL	64
0531051250	SET LABELS ADHESIVE CHASSIS SIDE	65
0909096358	ASSY SEED/FERTILIZER LINE	66
0531050988	FRONT INTERNAL SHORT SEED LINE VDRIVE CSC PPH	67
0511052300	CONDUCTOR SUPPORT ASSY SEED	68
0531050991	FRONT INTERNAL LONG SEED LINE VDRIVE CSC PPH	69
0531050989	FRONT SHORT SEED LINE VDRIVE CSC PPH	70
0531050990	FRONT LONG SEED LINE VDRIVE CSC PPH	71
0521055349	ASSY DPL20 CUTTING DISC	72
0521055348	LOWER SUPPORT WITH DPL 20 WITHOUT LUBRICATION	73
0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	74
0521053697	DISC BLADE HUB	75
0531050984	REAR WITH LEFT DDD SPICRR PPH VDRIVE	76
0521058085	REAR WITH DDD LEFT SPICRR	77
0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	78
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	79
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	80
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	81
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	82
0521056632	DEPTH CONTROL	83
0521056633	MOUNTED RIGHT ARM	84
0521056631	MOUNTED LEFT ARM	85
0521055059	WHEEL RAYED ASSY SPA WITHOUT LUBRICATION	86
0521055073	ASSEMBLY DEPTH WHEEL HUB	87
0521055093	BODY COMPACTOR	88
0521054990	LEFT COMPACTOR WHEEL	89
0521055017	RIGHT COMPACTOR WHEEL	90
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	91
0521056640	PRECISION PLANTING CSC CABLE / TRANSMISSION ASSY	92
0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	93
0531050985	REAR WITH RIGHT DDD SPICRR PPH VDRIVE	94
0521058084	REAR WITH RIGHT DDD SPICRR	95
0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	96
0531051034	COMPLETE PRECISION PLANTING TURBINE	97
0531050983	PRECISION PLANTING TURBINE WITH SUPPORT	98
0521050154	PRECISION PLANTING TURBINE WITH HOLE	99
0531051266	SEED BOX 17/8 RIGHT SIDE OUTLETS	100
0531054290	CENTRAL SEED BOX	101
0531054289	CENTRAL SEED BOX	102
0531054275	LOWER BOX SEED SYSTEM	103
0531051254	SIDE PLATFORM	104
0531051267	RIGHT SIDE HANDRAIL	105
0531050952	FRONT SIDE HANDRAIL 824	106
0531050954	RIGHT HANDRAIL 2507	107
0531051265	RIGHT SIDE AIR DUCT ASSEMBLY	108
0531051031	SIDE AIR CONDUCTOR 6 BUTTONS X 2745	109



MARCHESAN

INDEX


0531051032	AIR CONDUCTOR 2 MOUTH X 512	110
0521056960	SIDE SHAFT ASSEMBLY	111
0531054463	RIGHT SIDE DUCT ASSEMBLY	112
0531054462	HYDRAULIC ASSEMBLY	113
0521059366	COMPLETE DOUBLE ROTARY VALVE SUPPORT	114
0521059419	CASAPPA DOUBLE DIVIDER BRP00102 WITH NIPLES	115
0521059520	CENTRAL FRAME 4686 WITH FIXING	116
0521053207	INTERNAL PLATE WITH FIXATION SCREW 1/2	117
0521058875	WHEEL SUPPORT WITHOUT TIRE	118
0521058864	WHEEL SUPPORT WITHOUT TIRE AND WITH ROCKER ARM	119
0521058874	HYDRAULIC CYLINDER 63,50 X 150 X 731 X 322	120
0531052442	ACTUATOR ASSEMBLY	121
0521058865	TIRE WITH WHEEL 15 X 19.50 14 LEFT CANVAS	122
0521055981	WHEEL WITH TIRE 15 X 19.50 / 14 CANVAS	123
0531051269	SEED BOX 17/8 CENTRAL OUTPUTS	124
0521052156	ASSY CENTRAL SUPPORT	125
0521058860	LARGER REAR PLATFORM BASE ASSY LANTERN LED CSC	126
0521052154	ASSY REAR LADDER PLATFORM	127
0521054881	LARGER SIDE HANDRAIL FRAME CENTRAL	128
0521057760	LED FLASHLIGHT WITH SUPPORT	129
0521053296	AXIS ARTICULATOR	130
0521050332	VACUOMETER WITH ASSY SUPPORT	131
0521057207	ELECTRIC ASSEMBLY BCE (EMB) APT	132
0521051707	ASSY PANEL FIXER PLATE	133
0521058858	LEFT ARTICULATING ARM COMPLETE 1736	134
0521058855	ASSY RIGHT ARTICULATING ARM 1736	135
0521058955	ARTICULATED ARM CYLINDER ASSY	136
0511058761	HYDRAULIC CYLINDER	137
0531054467	HYDRAULIC ASSEMBLY 40E500 CSC VDRIVE	138
0531054466	CENTRAL DUTY ASSEMBLY	139
0521053537	CENTRAL REAR DUCT SUPPORT	140
0521057526	SUPPORT BLOCK	141
0521058489	CASAPPA TRIPLE DIVIDER VALVE BRP00090 WITH NIPLES	142
0531050254	ASSY HOSE ARTICULATION	143
0531055059	HEADER HOSE ASSY	144
0531051240	HOSE KIT LIFFITING CYLINDER	145
0531052831	TURBINE HOSE KIT	146
0531055084	ALTERNATOR HOSE SET	147
0501053834	MALE QUICK COUPLER	148
0521059538	ELECTRICAL ASSEMBLY 21MT/5F LED/APT	149
0521053672	LIGHTHOUSE ASSY	150
0531051272	CENTRAL AIR DUCT ASSY 40E500 CSC	151
0521053530	REAR CENTRAL AIR CONDUCTOR 1400 CSC	152
0521059355	CENTRAL AIR CONDUCTOR	153
0521051096	REAR CENTRAL AIR CONDUCTOR 1120 CSCP	154
0521055922	DOUBLE CONDUCTOR SUPPORT ASSY CENTRAL AIR	155
0531051112	CENTRAL AIR CONDUCTOR SUPPORT	156
0521052153	ASSY HOSE GUIDE	157
0531051255	LEFT SIDE HANDRAIL	158
0531050958	LEFT HANDRAIL 2507	159
0531051256	LEFT SIDE AIR DUCT ASSEMBLY	160
0531051030	AIR CONDUCTOR 2 MOUTH X 752	161
0531051033	SIDE AIR DRIVER 06 MOUTH	162
0531054461	LEFT SIDE DUCT ASSEMBLY	163
0531055058	SUPPORT FOR ALTERNATOR 1 PDM	164

INDEX

0521058906	COMPLETE ALTERNATOR SUPPORT		165
0531051246	LEFT SIDE HANDRAIL		166
0531055104	RIGHT SIDE HANDRAIL 1789		167
0531055105	LEFT SIDE HANDRAIL 1745		168
0531050117	LEFT LADDER COMPLETE		169
0531051247	COMPLETE LEFT HYDRAULIC TURBINE		170
0531050959	COMPLETE RIGHT SIDE TURBINE SUPPORT		171
0531051248	LEFT SIDE AIR DUCT ASSEMBLY		172
0531051243	SIDE DUCT ASSEMBLY		173
0531051629	CROTETS WITH FIXING SUPPORTS		174
0521058344	WATER RESERVOIR WITH SOAP		175

ASSY FRAME


0909096352



Item	Code	Description	See page	QT
01	0909096353	ASSY RIGHT SIDE FRAME	2	01
02	0909096354	ASSY RIGHT FRAME	3	01
03	0909096355	ASSY CENTRAL FRAME	4	01
04	0909096356	ASSY LEFT FRAME	5	01
05	0909096357	ASSY LEFT SIDE FRAME	6	01
06	0531051076	TELESCOPIC HEAD WITH FIXING	7	01
07	0531061580	HOLDER TUBE		01
08	0521057792	PANTOGRAPHY HEADER	10	01
09	0531054446	ARTICULATED FRENCH HAND 7377 COMPLETE LEFT	12	01
10	0531054447	ARTICULATED FRENCH HAND 7377 COMPLETE RIGHT	13	01
11	0531051121	FRENCH HAND TELESCOPIC 5846X10230 COMPLETE	16	02
12	0521052138	LADDER REAR	18	01
13	0531061880	TRANSPORT LOCK		02
14	0531052688	SEMI ASSEMBLED REST	22	01
15	0521057815	HYDRAULIC HOSE SUPPORT WITH FIXATION	23	01
16	0521055355	SUPPORT WITH FLOW DIVIDER BLOCK FOR 5 TURBINES	24	01
17	0521059540	ASSY TRACTOR HITCH AXLE	26	01
18	0521059546	LOCK AXLE		01
18A	0531061403	COUPLING SHAFT		01
18B	0503030085	LOCK PIN		01
19	0561017063	HOLDER TUBE		01
20	0521058345	SAFETY CHAIN WITH SHACKLE		01
20A	0503014120	CHAIN		01
20B	0503014321	CABLE STEEL SHACKLE		02
21	0531063123	SMALL FRONT EASEL CHASSIS		01
22	0531053278	SMALL REAR STAND FULL CENTER CHASSIS	27	02
23	0531053277	COMPLETE SIDE CHASSIS STAND	28	08

ASSY RIGHT SIDE FRAME


0909096353



Item	Code	Description	See page	QT
01	0531062124	RIGHT SIDE CHASSIS 3500		01
02	0591015268	HORIZONTAL ARTICULATION AXLE 597		01
03	0503034318	5/8 UNC X 2 BOLT		02
04	0503010013	5/8 NUT		02
05	0503010002	1800 GREASE FITTING		03
06	0531050960	WHEEL SUPPORT WITH CONTROL VALVE	29	01
07	0521058907	SIDE WHEEL WITHOUT TRANSMISSION	30	01
08	0531051244	SEED BOX 17/8 LEFT SIDE OUTLETS	33	01
09	0531051245	LEFT SIDE PLATFORM	36	01
10	0531051261	RIGHT SIDE HANDRAIL	39	01
11	0531050140	ASSY RIGHT LADDER	47	01
12	0531051260	ASSY RIGHT HYDRAULIC TURBINE	48	01
13	0531051262	RIGHT SIDE AIR DUCT ASSEMBLY	54	01
14	0503011372	102 TO 121 CLAMP		04
15	0531051249	SIDE CHANNEL ASSEMBLY	60	01
16	0531051263	RIGHT SIDE DUCT ASSEMBLY	62	01
17	0531051250	SET LABELS ADHESIVE CHASSIS SIDE	65	01
18	0909096358	ASSY SEED/FERTILIZER LINE	66	07

ASSY RIGHT FRAME


0909096354



Item	Code	Description	See page	QT
01	0531062126	RIGHT FRAME		01
02	0591014479	GLOVE 102 X 77 X 150		02
03	0581012179	SLEEVE		02
04	0503010002	1800 GREASE FITTING		01
05	0531051034	COMPLETE PRECISION PLANTING TURBINE	97	01
06	0521058907	SIDE WHEEL WITHOUT TRANSMISSION	30	01
07	0531051266	SEED BOX 17/8 RIGHT SIDE OUTLETS	100	01
08	0531051254	SIDE PLATFORM	104	01
09	0531051267	RIGHT SIDE HANDRAIL	105	01
10	0531051265	RIGHT SIDE AIR DUCT ASSEMBLY	108	01
11	0503011372	102 TO 121 CLAMP		03
12	0521056960	SIDE SHAFT ASSEMBLY	111	01
13	0531054463	RIGHT SIDE DUCT ASSEMBLY	112	01
14	0531054462	HYDRAULIC ASSEMBLY	113	01
15	0909096358	ASSY SEED/FERTILIZER LINE	66	07

ASSY CENTRAL FRAME

0909096355




Item	Code	Description	See page	QT
01	0521059520	CENTRAL FRAME 4686 WITH FIXING	116	01
02	0521058875	WHEEL SUPPORT WITHOUT TIRE	118	01
03	0521058865	TIRE WITH WHEEL 15 X 19.50 14 LEFT CANVAS	122	02
04	0521055981	WHEEL WITH TIRE 15 X 19.50 / 14 CANVAS	123	02
05	0531051269	SEED BOX 17/8 CENTRAL OUTPUTS	124	01
06	0521058860	LARGER REAR PLATFORM BASE ASSY LANTERN LED CSC	126	01
07	0503011372	102 TO 121 CLAMP		05
08	0521052549	CLAMP	57	40
09	0561016793	FIXED WRENCH		01
10	0501047885	30 ROD STOP		04
11	0501047888	45 ROD STOP		08
12	0521053296	AXIS ARTICULATOR	130	01
13	0581019559	AXIS		01
14	0521050332	VACUOMETER WITH ASSY SUPPORT	131	05
15	0503015062	TUBE		7,5mts
16	0503011372	102 TO 121 CLAMP		10
17	0521059883	TRANSPORT LOCK 325 X 66 X 9.50 ASSY		02
17A	0591016108	TRANSPORT LOCK 325 X 66 X 9.50		01
17B	0531061649	AXLE LOCKS TRANSPORT		01
17C	0503030168	HITCH PIN CLIP		01
18	0521059884	COMPLETE SIDE CYLINDERS LOCK		04
18A	0591016107	SIDE WHEEL CYLINDER LOCK		01
18B	0501068994	8,30 X 78 LOCK PIN		01
18C	0503030168	HITCH PIN CLIP		01
19	0521057207	ELECTRIC ASSEMBLY BCE (EMB) APT	132	01
20	0511033763	PLASTIC COVER WITH INSTRUCTIONS MANUAL		01
21	0503010045	O'RING		01
22	0541010080	TERMINAL R.1 / 2 NPT		01
23	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
24	0581013729	NIPLE 1/2 NPT		01
25	0503011883	QUICK CONNECTION COVER		01


ASSY CENTRAL FRAME

0909096355


Item	Code	Description	See page	QT
26	0503011628	FEMALE QUICK COUPLER		01
27	0521058858	LEFT ARTICULATING ARM COMPLETE 1736	134	01
28	0521058855	ASSY RIGHT ARTICULATING ARM 1736	135	01
29	0521058955	ARTICULATED ARM CYLINDER ASSY	136	01
30	0531054467	HYDRAULIC ASSEMBLY 40E500 CSC VDRIVE	138	01
31	0521059538	ELECTRICAL ASSEMBLY 21MT/5F LED/APT	149	01
32	0531051272	CENTRAL AIR DUCT ASSY 40E500 CSC	151	01
33	0521059526	CENTRAL GUTTER ASSY		01
34	0531054438	ASSY VDRIVE 40L 45/50 MS-WV GEN 3		01
35	0511059406	TURBINE P.P MOUNTED		01
36	0503010232	5/8" X 1.3/4" BOLT		02
37	0503010027	5/8 SPRING WASHER		02
38	0503010013	5/8 NUT		02
39	0531054468	ADHESIVE LABEL ASSY		01
40	0531050061	SENSOR ASSEMBLY PSS-X 1005B-000 TE		01
41	1164920014	BLACK LIGHT SUCTION HOSE		53mts
42	1164920015	BLACK SUCTION HOSE		90mts
43	1163920004	BLACK LIGHT SUCTION HOSE		14,5 mts
44	0909096358	ASSY SEED/FERTILIZER LINE	66	10



Item	Code	Description	See page	QT
01	0531062123	LEFT CHASSIS 3766		01
02	0591014479	GLOVE 102 X 77 X 150		02
03	0581012179	SLEEVE		02
04	0503010002	1800 GREASE FITTING		01
05	0531051034	COMPLETE PRECISION PLANTING TURBINE	97	01
06	0521058907	SIDE WHEEL WITHOUT TRANSMISSION	30	01
07	0503011372	102 TO 121 CLAMP		04
08	0531051244	SEED BOX 17/8 LEFT SIDE OUTLETS	33	01
09	0531051254	SIDE PLATFORM	104	01
10	0531051255	LEFT SIDE HANDRAIL	158	01
11	0531051256	LEFT SIDE AIR DUCT ASSEMBLY	160	01
12	0521056960	SIDE SHAFT ASSEMBLY	111	01
13	0531054461	LEFT SIDE DUCT ASSEMBLY	163	01
14	0531054462	HYDRAULIC ASSEMBLY	113	01
15	0503062180	T ADAPTER WITH ROTATING NUT		01
16	0531055058	SUPPORT FOR ALTERNATOR 1 PDM	164	01
17	0909096358	ASSY SEED/FERTILIZER LINE	66	08



Item	Code	Description	See page	QT
01	0531062125	LEFT SIDE CHASSIS 3500		01
02	0591015268	HORIZONTAL ARTICULATION AXLE 597		01
03	0503034318	5/8 UNC X 2 BOLT		02
04	0503010013	5/8 NUT		02
05	0503010002	1800 GREASE FITTING		03
06	0531050960	WHEEL SUPPORT WITH CONTROL VALVE	29	01
07	0521058907	SIDE WHEEL WITHOUT TRANSMISSION	30	01
08	0531051244	SEED BOX 17/8 LEFT SIDE OUTLETS	33	01
09	0531051245	LEFT SIDE PLATFORM	36	01
10	0531051246	LEFT SIDE HANDRAIL	166	01
11	0531050117	LEFT LADDER COMPLETE	169	01
12	0531051247	COMPLETE LEFT HYDRAULIC TURBINE	170	01
13	0531051248	LEFT SIDE AIR DUCT ASSEMBLY	172	01
14	0503011372	102 TO 121 CLAMP		04
15	0531051249	SIDE CHANNEL ASSEMBLY	60	01
16	0531051243	SIDE DUCT ASSEMBLY	173	01
17	0531051250	SET LABELS ADHESIVE CHASSIS SIDE	65	01
18	0531051629	CROTETS WITH FIXING SUPPORTS	174	01
19	0909096358	ASSY SEED/FERTILIZER LINE	66	07




Item	Code	Description	See page	QT
01	0503010027	5/8 SPRING WASHER		08
02	0503010013	5/8 NUT		08
03	0503010002	1800 GREASE FITTING		04
04	0521051433	FRENCH HAND FRONT AXLE ASSY		02
04A	0511069442	FRENCH HAND FRONT AXLE		01
04B	0501017779	32 X 60 X 4.75 FLAT WASHER		01
04C	0503011052	1.1/4" X 0.77" CASTLE NUT		01
04D	0503010038	3/16" X 2" SPLIT PIN		01
04E	0581014420	SLEEVE GUIDE		02
05	0531062239	TELESCOPIC HEADER		01
06	0501012140	FLAT WASHER		16
07	0503010233	5/8" X 2-1/2" BOLT		08
08	0503011052	1.1/4" X 0.77" CASTLE NUT		03
09	0521011688	FLAT WASHER		02
10	0503010010	1/4" X 2.1/2" SPLIT PIN		03
11	0531060748	REST SUPPORT		01
12	0531060747	TELESCOPIC HOSE GUIDE		01
13	0531061070	AXIS 365 TELESCOPIC HEADER		03
14	0501012694	FLAT WASHER		01
15	0521011132	FLAT WASHER		04
16	0503010523	1/4" X 2" SPLIT PIN		04
17	0521052189	38,10 X 63,50 X 386 X 148 HYDRAULIC CYLINDER	8	01
18	0531061407	LOCK		01
19	0591015302	PIVOT SHAFT		01
20	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
21	0511054270	TENSIONER SPRING		01
21A	0511069520	TELESC LOCK SPRING TENSIONER		01
21B	0503010013	5/8 NUT		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		03
23	0503010025	3/8 SPRING WASHER		03
24	0503010849	3/8" X 1-1/2" BOLT		03




**USAP SUPREMA P. P MINI HOPPER - FRAME 20250 -
TELESCOPIC HEAD WITH FIXING**

Page 7
0531051076


Item	Code	Description	See page	QT
25	0521058357	FRENCH HAND FRONT AXLE ASSY	9	02
26	0521069201	OIL DUCT R.3/4 X 3230		02
27	0502010477	HOSE CLAMP		03




Item	Code	Description	See page	QT
01	0521068383	CYLINDER CASE		01
02	0581010670	CORPO HASTE 38,10 X 345		01
03	0511070058	GUIDE HIDRAULIC		01
04	0503010163	D-1500 SCRAPER RING		01
05	0502010471	63,50 MOBILE CAP		01
06	0581010668	RING SUPPORT		01
07	0503018004	RING		01
08	0503018003	GASKET		01
09	0503018163	BACK-UP RING		02
10	0503018162	O'RING		02
11	0503030385	CYLINDER PLUG N-002		02
12	0502012837	PISTON		01
13	0503018005	RING		01
14	0503011109	2-119 N 3006-9B O'RING		01
15	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0531061069	FRONT HAND FRENCH AXLE		01
02	0501017779	32 X 60 X 4.75 FLAT WASHER		01
03	0503011052	1.1/4" X 0.77" CASTLE NUT		01
04	0503010038	3/16" X 2" SPLIT PIN		01




Item	Code	Description	See page	QT
01	0531060744	UPPER ARM PANTOGRAPHIC HEADER		01
02	0531060743	LOWER ARM PANTOGRAPHIC HEADER		01
03	0531060745	PANTOGRAPHIC ARM EAR		02
04	0502040864	GEAR BOX WITH REGULATOR		01
05	0521068007	TRACTOR HITCH		01
06	1902040327	LOCK SLEEVE		01
07	0503010523	1/4" X 2" SPLIT PIN		01
08	0503010002	1800 GREASE FITTING		04
09	0521063432	LOCK AXLE		02
10	0503031035	HITCH PIN CLIP		02
11	0531060746	AXIS 278 TELESCOPIC HEADER		02
12	0531060792	AXIS 200 TELESCOPIC HEADER		01
13	0531060776	HYDRAULIC HOSE SUPPORT FIXER		01
14	0503011052	1.1/4" X 0.77" CASTLE NUT		02
15	0503010038	3/16" X 2" SPLIT PIN		03
16	0521010578	COUPLING SHAFT		01
17	0521057786	HYDRAULIC CYLINDER HEAD PANTOGRAPH	11	01
18	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		02







Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		02
02	0521058088	ROTULA WITH EXTENSOR AXIS 2	14	01
03	0501082189	HOSE 1/2 X 160 TR-TR		12
04	0521069593	OIL DUCT		12
05	0521069586	OIL DUCT		12
06	0502010477	HOSE CLAMP		32
07	0502012907	FRENCH HAND DUCTS SUPPORT		08
08	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
09	0503010025	3/8 SPRING WASHER		16
10	0503010964	BOLT		08
11	0503010589	1/2" UNC SELF ADJUSTING NUT		08
12	0503011404	BOLT		08
13	0581017859	GUTTER		02
14	0531062290	FRAME TUBE		01
15	0531051811	REAR AXLE	15	01
16	0531061900	FIXER SUPPORT		01
17	0531062527	FRENCH MAO SIDE AXIS		01
18	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
19	0503010019	1/2" SPRING WASHER		01
20	0503014007	1/2" X 1-1/4" BOLT		01
21	0503013665	SCREW 3/8 UNC X 3.1/4 C S RP G.2 ZN		08




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		02
02	0521058088	ROTULA WITH EXTENSOR AXIS 2	14	01
03	0501082208	HOSE 3/4 X 180 TR-TR		02
04	0501082189	HOSE 1/2 X 160 TR-TR		05
05	0501082190	HOSE 3/8 X 160 TR-TR		02
06	0521069586	OIL DUCT		02
07	0521069593	OIL DUCT		12
08	0521069594	OIL PIPE R.1.1/16 X 3150		04
09	0502010477	HOSE CLAMP		24
10	0502012907	FRENCH HAND DUCTS SUPPORT		08
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
12	0503010025	3/8 SPRING WASHER		16
13	0503010964	BOLT		08
14	0503010589	1/2" UNC SELF ADJUSTING NUT		08
15	0503011404	BOLT		12
16	0581017859	GUTTER		02
17	0503013665	SCREW 3/8 UNC X 3.1/4 C S RP G.2 ZN		04
18	0531062290	FRAME TUBE		01
19	0531061900	FIXER SUPPORT		01
20	0531062527	FRENCH MAO SIDE AXIS		01
21	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
22	0503010019	1/2" SPRING WASHER		01
23	0503014007	1/2" X 1-1/4" BOLT		01
24	0531051811	REAR AXLE	15	01
25	0581018419	SUPPORT		04




Item	Code	Description	See page	QT
01	0531061046	ROTULA WITH R2 LEFT NUT		01
02	0503010002	1800 GREASE FITTING		02
03	0501078990	TURNBUCKLE AXLE		01
04	0561019879	LOCK ATTACHMENT BAR		01




Item	Code	Description	See page	QT
01	0531062529	FRENCH HAND GUIDE HOSE ARTICULATION SHAFT		01
02	0551019529	FLAT WASHER		01
03	0503010027	5/8 SPRING WASHER		01
04	0503011267	5/8 UNC X 1.1/2 C S G.5 ZN BOLT		01




Item	Code	Description	See page	QT
01	0531062242	FRAME TUBE		01
02	0531062241	FRAME TUBE		01
03	0521058088	ROTULA WITH EXTENSOR AXIS 2	14	01
04	0591015304	SHIM		02
05	0531061405	TIGHTENING REGULATOR		02
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01
07	0503011411	1/2" X 5-1/2" BOLT		01
08	0521059390	JOINT SUPPORT	17	01
09	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0531061397	JOINT SUPPORT		01
02	0503012231	1/4" X 3" SPLIT PIN		02
03	0591015301	ARTICULATION AXIS		01
04	0521059592	REAR AXLE 38.10 FULL TELESCOPIC FRENCH MAO		01




Item	Code	Description	See page	QT
01	0581015998	CSCP REAR SIDE STAIR		02
02	0521064790	DEGRAU 600 USAP CXC		04
03	0503010025	3/8 SPRING WASHER		16
04	0503010026	3/8" NUT		16
05	0503010237	3/8" X 1" BOLT		16
06	0511052457	REAR SIDE HANDRAIL LADDER	19	01
07	0511052499	HANDRAIL LADDER BACK RIGHT CENTRAL FRAME	20	01
08	0503010395	1/2" X 1-1/4" BOLT		04
09	0503010589	1/2" UNC SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0581012741	SIDE HANDRAIL BODY (1113) CSCP		01
02	0511059383	HANDRAIL INTERNAL FIXER	21	06
03	0581012748	BODY LARGER LADDER REAR		02
04	0581012742	SIDE HANDRAIL BODY		01
05	0581012744	REINFORCEMENT REAR SIDE HANDRAIL		01
06	0581012718	HANDRAIL		02
07	0581014429	SHIM HANDRAIL		02
08	0503011179	3/8" X 2-1/4" BOLT		04
09	0503013357	3/8 SELF-ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0581012741	SIDE HANDRAIL BODY (1113) CSCP		01
02	0511059383	HANDRAIL INTERNAL FIXER	21	06
03	0581012748	BODY LARGER LADDER REAR		02
04	0581012742	SIDE HANDRAIL BODY		01
05	0581012744	REINFORCEMENT REAR SIDE HANDRAIL		01
06	0581012718	HANDRAIL		02
07	0581014429	SHIM HANDRAIL		02
08	0503010025	3/8 SPRING WASHER		04
09	0503010026	3/8" NUT		04
10	0503011179	3/8" X 2-1/4" BOLT		04




Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01




Item	Code	Description	See page	QT
01	0503010571	1/4" X 1.1/2" SPLIT PIN		01
02	0521010784	COUPLING SHAFT		01
03	0531060758	AXLE JUNCTION 25.4 X 150 WITH HANDLE		01
04	0503030085	LOCK PIN		02
05	0531060667	REST		01
06	0521012533	COUPLING SHAFT		01
07	0531062876	INTERNAL TUBE WITH SHOE REST		01




Item	Code	Description	See page	QT
01	0531060794	HYDRAULIC HOSE SUPPORT		01
02	0503015490	SELF-LOCKING NUT 7/16		02
03	0503011173	7/16" X 2" BOLT		02
04	0501010937	13,50 X 28 X 3,00 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0581018714	HYDRAULIC HOSE SUPPORT		01
02	0503010395	1/2" X 1-1/4" BOLT		02
03	0503010589	1/2" UNC SELF ADJUSTING NUT		02
04	0503010237	3/8" X 1" BOLT		04
05	0503013357	3/8 SELF-ADJUSTING NUT		04
06	0503010025	3/8 SPRING WASHER		04
07	0503010172	M10 X 1,5 X 25 BOLT		04
08	0581019743	FLOW DIVISOR BLOCK SUPPORT		02
09	0503034719	FLOW DIVIDER BLOCK		01
10	0521055356	FLUX DIVIDER BLOCK FOR 03 TURBINES	25	01




Item	Code	Description	See page	QT
01	0503034719	FLOW DIVIDER BLOCK		01
02	0501010590	NIPPLE		02
03	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0521068010	HITCH AXLE		01
02	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531063121	REAR EASEL		01
02	0501012140	FLAT WASHER		02
03	0503012412	5/8" UNC SELF LOCKING NUT		02
04	0531063122	U-BOLT BEAM CLAMP		01
05	0501211474	SHIM		02




Item	Code	Description	See page	QT
01	0531063119	SIDE CHASSIS STAND		01
02	0503012412	5/8" UNC SELF LOCKING NUT		04
03	0501012140	FLAT WASHER		04
04	0531063120	U-BOLT BEAM CLAMP		01
05	0571011070	5/8" UNC FASTENER		01




Item	Code	Description	See page	QT
01	0591018008	VALVE FIXING SUPPORT		01
02	0503019917	CONTROL VALVE		01
03	0503013357	3/8 SELF-ADJUSTING NUT		02
04	0503011141	3/8" X 2-3/4" BOLT		02
05	0503010849	3/8" X 1-1/2" BOLT		02
06	0503013759	NUT		02




Item	Code	Description	See page	QT
01	0531061228	SIDE WHEEL FORK		01
02	0531061055	SIDE WHEEL SUPPORT		01
03	0531060981	ARTICULATED AXIS		01
04	0561019929	FLAT WASHER		01
05	0503011345	1/4" X 3.1/2" SPLIT PIN		01
06	0551014511	CARRYING WEELS AXLE SLEVE GUIDES		02
07	0551014508	FLAT WASHER		01
08	0503010010	1/4" X 2.1/2" SPLIT PIN		04
09	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
10	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
11	0503010019	1/2" SPRING WASHER		04
12	0503010060	1/2 UNC G.5 ZN HEX NUT		04
13	0591014036	569 WHEEL LIFTING AXLE BODY		01
14	0502012731	WHEEL HOLDER		03
15	0531012874	FLAT WASHER		02
16	0521058137	WHEEL WITHOUT TIRE WITHOUT TRANSMISSION 31 564		01
17	0503060684	14 X 17.5/14L TR SK900 LEFT - WHEEL AND TIRE		01
18	0503011052	1.1/4" X 0.77" CASTLE NUT		02
19	0501017779	32 X 60 X 4.75 FLAT WASHER		02
20	0521058783	50,80 X 127 X 381 MM 3/4 NIPLE HYDRAULIC 32 CYLINDER		01
21	0501010630	1.1/2" CASTLE NUT		01
22	0503010003	1845 GREASE FITTING		02
23	0503010882	BOLT		01
24	0501010694	FLAT WASHER		02
25	0503035229	CHAIN		01
26	0503010337	5/16" NUT		01
27	0503010002	1800 GREASE FITTING		02
28	0503011075	3/4" UNC NUT		06
29	0503012334	3/4" UNC X 3.1/2" BOLT		03
30	0503016525	3/4" X 6" BOLT		03




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0591014038	LARGER WHEEL AXLE 564		01
03	0503010059	33287/33462 ROLLER BEARING		01
04	0503010009	RETAINER 00573-B		01
05	0503010086	SEAL 0009B-B		01
06	0551014473	GLOVE		01
07	0503012702	KM-12 NUT		02
08	0503012703	LOCK WASHER		01
09	0503010002	1800 GREASE FITTING		01
10	0503011444	SPRING WASHER		04
11	0503014048	22 X 1.5 HEX NUT		08
12	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
13	0503014050	22 X 1.5 BOLT		08
14	0511068415	SEAL GUIDE		01
15	0503010007	3982/3920 ROLLER BEARING		01







Item	Code	Description	See page	QT
01	0531050114	COMPLETE SIDE BOX SUPPORT	34	01
02	0531050113	BEARING HANGER ASSEMBLY	35	02
03	0531054290	CENTRAL SEED BOX	101	01
04	0503034345	DISPENSER COVER		09
05	0503010184	CLAMP		09
06	0513010405	CLAMP		08




Item	Code	Description	See page	QT
01	0531061732	CENTRAL BOX SUPPORT		01
02	0581016040	LOWER SUPPORT CASH SEED		04
03	0501011643	3/8 X 1"BOLT		16
04	0503013357	3/8 SELF-ADJUSTING NUT		16
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
06	0581012237	SEAL BOX FIXER		02
07	0581012245	SEAL BOX SHOULDER		02
08	0503010025	3/8 SPRING WASHER		04
09	0503010026	3/8" NUT		04
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04




Item	Code	Description	See page	QT
01	0531061733	SUPPORT SHOE		01
02	0571011070	5/8" UNC FASTENER		02
03	0501012140	FLAT WASHER		04
04	0503013389	5/8" SELF LOCKING NUT		04
05	0503010589	1/2" UNC SELF ADJUSTING NUT		06
06	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		06




Item	Code	Description	See page	QT
01	0581018631	PLATLFORM		02
02	0521052175	SUPPORT PLATFORM ASSY	37	02
03	0531050115	PLATFORM/LADDER SIDE SUPPORT	38	02




Item	Code	Description	See page	QT
01	0581016058	PLATFORM SUPPORT		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01
06	0503010395	1/2" X 1-1/4" BOLT		05
07	0503010589	1/2" UNC SELF ADJUSTING NUT		05




Item	Code	Description	See page	QT
01	0521068228	SIDE SUPPORT		01
02	0571011070	5/8" UNC FASTENER		02
03	0501012140	FLAT WASHER		04
04	0503010027	5/8 SPRING WASHER		04
05	0503010013	5/8 NUT		04
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2 UNC G.5 ZN HEX NUT		01
09	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01




Item	Code	Description	See page	QT
01	0531055106	1027 FRONT SIDE HANDRAIL	40	01
02	0531055107	980 FRONT SIDE HANDRAIL	41	01
03	0531055108	1745 RIGHT SIDE HANDRAIL	42	01
04	0531055109	1789 LEFT SIDE HANDRAIL	44	01
05	0531050947	U HANDRAIL FIXER	45	02
06	0591015150	L HANDRAIL FIXING		02
07	0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	46	02




Item	Code	Description	See page	QT
01	0501214026	33,70 X 27,00 X 944 TUBE		03
02	0511059383	HANDRAIL INTERNAL FIXER	21	06
03	0581012718	HANDRAIL		02
04	0581014429	SHIM HANDRAIL		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0581015996	TUBE 33,7 X 27 X 1131		02
07	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0501214027	33,70 X 27,00 X 897 TUBE		03
02	0511059383	HANDRAIL INTERNAL FIXER	21	06
03	0581012718	HANDRAIL		02
04	0581014429	SHIM HANDRAIL		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0581015996	TUBE 33,7 X 27 X 1131		02
07	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0501214025	33,70 X 27,00 X 1183 TUBE		03
02	0511059383	HANDRAIL INTERNAL FIXER	21	08
03	0581012718	HANDRAIL		03
04	0503011179	3/8" X 2-1/4" BOLT		04
05	0581015996	TUBE 33,7 X 27 X 1131		02
06	0581014429	SHIM HANDRAIL		02
07	0503013357	3/8 SELF-ADJUSTING NUT		04
08	0581015992	33,70 X 27 X 354 TUBE		02
09	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	43	04
10	0581019811	33,7 X27 X 398 TUBE		03
11	0581015995	33,7 X 27 X 925 TUBE		01




Item	Code	Description	See page	QT
01	0502012855	CENTRAL FIXER		01
02	0502012856	CENTRAL FIXER		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		02
04	0503015490	SELF-LOCKING NUT 7/16		02




Item	Code	Description	See page	QT
01	0501214024	33,70 X 27,00 X 1227 TUBE		03
02	0511059383	HANDRAIL INTERNAL FIXER	21	08
03	0581012718	HANDRAIL		03
04	0503011179	3/8" X 2-1/4" BOLT		04
05	0581015996	TUBE 33,7 X 27 X 1131		02
06	0581014429	SHIM HANDRAIL		02
07	0503013357	3/8 SELF-ADJUSTING NUT		04
08	0581015992	33,70 X 27 X 354 TUBE		02
09	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	43	04
10	0581019811	33,7 X27 X 398 TUBE		03
11	0581015995	33,7 X 27 X 925 TUBE		01




Item	Code	Description	See page	QT
01	0591017998	FIXER BODY U		01
02	0503010237	3/8" X 1" BOLT		02
03	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0581012698	FRONT SIDE HANDRAIL FIXER		01
02	0503010237	3/8" X 1" BOLT		02
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503011179	3/8" X 2-1/4" BOLT		02




Item	Code	Description	See page	QT
01	0531061754	RIGHT LADDER		01
02	0502012742	FIXER SUPPORT LADDER		02
03	0503013357	3/8 SELF-ADJUSTING NUT		02
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0503010237	3/8" X 1" BOLT		04
07	0503010025	3/8 SPRING WASHER		04
08	0503010026	3/8" NUT		04
09	0503030403	1.85" X 2.87" BEATER		01




Item	Code	Description	See page	QT
01	0531050948	LEFT SIDE TURBINE SUPPORT	49	01
02	0521045392	HYDRAULIC TURBINE WITH SCREEN	50	01




Item	Code	Description	See page	QT
01	0531062187	LEFT SIDE FRAME TURBINE SUPPORT		01
02	0501012140	FLAT WASHER		04
03	0503010027	5/8 SPRING WASHER		06
04	0503010013	5/8 NUT		06
05	0571011070	5/8" UNC FASTENER		02
06	0503010232	5/8" X 1.3/4" BOLT		02




Item	Code	Description	See page	QT
01	0501054983	NIPPLE HIDRAULIC MOTOR	51	01
02	0503010025	3/8 SPRING WASHER		12
03	0503010026	3/8" NUT		10
04	0521044613	480 X 50 FAN (HIDRAULIC)	52	01
05	0503010143	1/4" SPRING WASHER		01
06	0503010849	3/8" X 1-1/2" BOLT		02
07	0531018764	FLAT WASHER		01
08	0503011104	M6 X 1" BOLT		01
09	0503012722	0.16" X 0.4" BLIND RIVET		24
10	0521065857	CARACOL MECHANICAL TURBINE S MEC		01
11	0521065858	TURBIN SUPPORT		01
12	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC 53 TURBINE		01
13	0561010634	VALVE SUPPORT ASSY		01
14	0503010237	3/8" X 1" BOLT		08
15	0503010206	3/8 X 1/2 BOLT		02
16	0571018577	COVER SNAIL TURBINE		01
17	0571018578	TURBINE PROTECTIVE SCREEN		01
18	0541013274	LISA WASHER 10 X 38 X 4.75		02
19	0521069167	FRONT PROTECTION		01
20	0501080709	3/8" X 21.6" TR-TR HOSE		01
21	0501080091	1/2" X 550 TR-TR HOSE		02
22	0503031087	ADHESIVE LABEL		01
23	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
24	0503033981	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW		01
03	0561016941	3/4" NUT		01
04	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
05	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE		01
06	3914103037	TEFLON		0,001RI




Item	Code	Description	See page	QT
01	0571016947	DISC FRONT TURBINE		01
02	0571016949	DISC REAR TURBINE		01
03	0521065171	HUB FLANGE		01
04	0571016950	DISC STRENGTHENING TURBINE		01
05	0571016951	FLIP TURBINE		10
06	0503012651	M6 X 1" BOLT		05
07	0503010143	1/4" SPRING WASHER		05
08	0503011776	M6 SELF ADJUSTINGNUT		05




Item	Code	Description	See page	QT
01	0503012291	BLOCK COMMAND		01
02	0501010590	NIPPLE		04
03	0503010045	O'RING		04
04	0541011066	3/4" UNF X 43.5 NIPPLE		01
05	0503010190	2-114 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0531051036	SIDE AIR CONDUCTOR 7 BUTTONS X 500 X 3258	55	01
02	0531051035	COMPLETE MAJOR AIR CONDUCTOR SUPPORT	56	03
03	0521052549	CLAMP	57	07
04	0521052168	SEED HOSE GUIDE	58	02
05	0531051028	SIDE HOSE SUPPORT	59	01




Item	Code	Description	See page	QT
01	0581012427	AIR DISTRIBUTOR NOZZLE		01
02	0591018096	AIR CONDUCTOR BODY 7 BUTTONS X 500 X 3200		01
03	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
03A	0503034763	AIR DISTRIBUTOR PUMP		01
03B	0503015341	POP RIVET		02
04	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		07
04A	0503034812	SOCKET DISTRIBUTOR AR		01
04B	0503012856	POP RIVET		04




Item	Code	Description	See page	QT
01	0531062219	HIGHER AIR CONDUCTOR SUPPORT		01
02	0571019615	FITTING 1/2 UNC 130 X 198 ZN		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0521018402	AIR CONDUCTOR CLAMP		01
07	0503010371	5/16" X 1" BOLT		02
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
09	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0521068360	SEED HOSE GUIDE		01
02	0521018402	AIR CONDUCTOR CLAMP		01
03	0503010371	5/16" X 1" BOLT		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531062218	SIDE SUPPORT HOSES		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0581018240	AIR CONDUCTOR SUPPORT BODY		01
06	0571018437	PRISONER 1/2 X		02




Item	Code	Description	See page	QT
01	0591016452	CHANNEL 30 X 55 X 2700		01
02	0521055102	BIGGEST FULL GUTTER SUPPORT	61	02




Item	Code	Description	See page	QT
01	0581019560	SUPPORT CONDUCTOR		01
02	0503010025	3/8 SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0503013029	3/8" X 3/4" BOLT		01
05	0501011643	3/8 X 1" BOLT		01




Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY	63	01
02	0521053025	DUCT SUPPORT OIL	64	01
03	0581018415	PROTECTION BODY		04
04	0503011268	3/8" X 2-1/2" BOLT		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0521068926	3/4 X 2730 OIL DUCT		01
08	0521068927	7/8 X 2730 OIL DUCT		02
09	0531062279	3/4 X 2814 OIL DUCT		02



Item	Code	Description	See page	QT
01	0581011417	DUTO HOLDER SUPPORT		01
02	0503010237	3/8" X 1" BOLT		02
03	0503010025	3/8 SPRING WASHER		02
04	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0571019121	FIXER LOWER		01
02	0581013094	DUTO HOLDER SUPPORT		01
03	0571019139	PRISONER		02
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04




0503032988



0503033418




0503033414




0503032986



0503031827




0503033621




0503031565


Item	Code	Description	See page	QT
01	0503032988	ADHESIVE LABEL		01
02	0503032986	ADHESIVE LABEL		01
03	0503033621	ADHESIVE LABEL		01
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		01
05	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		01
06	0503031827	LUBRICATE AND RETIGHTEN DAILY DECAL		01
07	0503031565	ADHESIVE LABEL CARE		01




Item	Code	Description	See page	QT
01	0531050988	FRONT INTERNAL SHORT SEED LINE VDRIVE CSC PPH	67	01
02	0531050991	FRONT INTERNAL LONG SEED LINE VDRIVE CSC PPH	69	01
03	0531050989	FRONT SHORT SEED LINE VDRIVE CSC PPH	70	01
04	0531050990	FRONT LONG SEED LINE VDRIVE CSC PPH	71	01
05	0521055349	ASSY DPL20 CUTTING DISC	72	01
06	0531050984	REAR WITH LEFT DDD SPICRR PPH VDRIVE	76	01
07	0531050985	REAR WITH RIGHT DDD SPICRR PPH VDRIVE	94	01
08	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
09	0531013600	PRESS ADJUSTMENT LEVER		01
10	0521068982	DISC BLADE HUB KEY		01
11	0561016889	STRIPED CAP WHEEL DEPTH		01
12	0503018829	NYLON CLAMP		01
13	0503014234	BOLT 1/2 UNF X 1.3/4 CS G.5 ZN		01
14	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0521068449	SHORT SEED ROW FRONT		01
02	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION		01
03	0581018676	SLEEVE ARM SEED ROW		08
04	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION		01
05	0531061203	SEED LINE FRAME VDRIVE		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
08	0571012310	ROW LOCK BODY		01
09	0551015826	SEED ROW LOCK GUIDE SLEEV		01
10	0503010232	5/8" X 1.3/4" BOLT		01
11	0503030168	HITCH PIN CLIP		04
12	0501012140	FLAT WASHER		01
13	0503033728	FIXED SPRING PIN		02
14	0571014704	UPPER AXLE		01
15	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
16	0502012768	ROW SUPPORT CLAMP		02
17	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
18	0503010878	5/8" SELF ALIGNING NUT		04
19	0521068188	HOSE GUIDE		01
20	0503010025	3/8 SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0501011643	3/8 X 1" BOLT		01
23	0503019273	AUTO LUBRICANT SLEEVE		08
24	0503010045	O'RING		08
25	0502012568	UPPER ROCKER ARM		01
26	0503013389	5/8" SELF LOCKING NUT		01
27	0503010421	5/16" X 1-1/2" BOLT		01
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
29	0511052300	CONDUCTOR SUPPORT ASSY SEED	68	01




Item	Code	Description	See page	QT
01	0521063444	CONDUCTOR SUPPORT SEED		01
02	0501011643	3/8 X 1" BOLT		02
03	0503010025	3/8 SPRING WASHER		02
04	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0521068453	LONG FRONT SEED ROW		01
02	0581019795	SEED ARM SUPPORT ROW		01
03	0581018676	SLEEVE ARM SEED ROW		08
04	0581019796	LOWER ARM LARGER		01
05	0531061203	SEED LINE FRAME VDRIVE		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
08	0571012310	ROW LOCK BODY		01
09	0551015826	SEED ROW LOCK GUIDE SLEEV		01
10	0503010232	5/8" X 1.3/4" BOLT		01
11	0503030168	HITCH PIN CLIP		04
12	0501012140	FLAT WASHER		01
13	0503033728	FIXED SPRING PIN		02
14	0571014704	UPPER AXLE		01
15	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
16	0502012768	ROW SUPPORT CLAMP		02
17	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
18	0503010878	5/8" SELF ALIGNING NUT		04
19	0521068188	HOSE GUIDE		01
20	0503010025	3/8 SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0501011643	3/8 X 1" BOLT		01
23	0503019273	AUTO LUBRICANT SLEEVE		08
24	0503010045	O'RING		08
25	0502012568	UPPER ROCKER ARM		01
26	0503013389	5/8" SELF LOCKING NUT		01
27	0503010421	5/16" X 1-1/2" BOLT		01
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
29	0511052300	CONDUCTOR SUPPORT ASSY SEED	68	01




Item	Code	Description	See page	QT
01	0521068448	SHORT SEED ROW FRONT SUPPORT		01
02	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION		01
03	0581018676	SLEEVE ARM SEED ROW		08
04	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION		01
05	0531061203	SEED LINE FRAME VDRIVE		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
08	0571012310	ROW LOCK BODY		01
09	0551015826	SEED ROW LOCK GUIDE SLEEV		01
10	0503010232	5/8" X 1.3/4" BOLT		01
11	0503030168	HITCH PIN CLIP		04
12	0501012140	FLAT WASHER		01
13	0503033728	FIXED SPRING PIN		02
14	0571014704	UPPER AXLE		01
15	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
16	0502012768	ROW SUPPORT CLAMP		02
17	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
18	0503010878	5/8" SELF ALIGNING NUT		04
19	0521068188	HOSE GUIDE		01
20	0503010025	3/8 SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0501011643	3/8 X 1" BOLT		01
23	0503019273	AUTO LUBRICANT SLEEVE		08
24	0503010045	O'RING		08
25	0502012568	UPPER ROCKER ARM		01
26	0503013389	5/8" SELF LOCKING NUT		01
27	0503010421	5/16" X 1-1/2" BOLT		01
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
29	0511052300	CONDUCTOR SUPPORT ASSY SEED	68	01




Item	Code	Description	See page	QT
01	0521068452	UP SUPPORT		01
02	0581019795	SEED ARM SUPPORT ROW		01
03	0581018676	SLEEVE ARM SEED ROW		08
04	0581019796	LOWER ARM LARGER		01
05	0531061203	SEED LINE FRAME VDRIVE		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
08	0571012310	ROW LOCK BODY		01
09	0551015826	SEED ROW LOCK GUIDE SLEEV		01
10	0503010232	5/8" X 1.3/4" BOLT		01
11	0503030168	HITCH PIN CLIP		04
12	0501012140	FLAT WASHER		01
13	0503033728	FIXED SPRING PIN		02
14	0571014704	UPPER AXLE		01
15	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
16	0502012768	ROW SUPPORT CLAMP		02
17	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
18	0503010878	5/8" SELF ALIGNING NUT		04
19	0521068188	HOSE GUIDE		01
20	0503010025	3/8 SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0501011643	3/8 X 1" BOLT		01
23	0503019273	AUTO LUBRICANT SLEEVE		08
24	0503010045	O'RING		08
25	0502012568	UPPER ROCKER ARM		01
26	0503013389	5/8" SELF LOCKING NUT		01
27	0503010421	5/16" X 1-1/2" BOLT		01
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
29	0511052300	CONDUCTOR SUPPORT ASSY SEED	68	01



Item	Code	Description	See page	QT
01	0502012470	UPPER SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
03	0521055348	LOWER SUPPORT WITH DPL 20 WITHOUT 73 LUBRICATION		01
04	0503012798	5/8" X 2" BOLT		04
05	0503010878	5/8" SELF ALIGNING NUT		04




Item	Code	Description	See page	QT
01	0503019277	SLEEVE LUBRICATION SYSTEM		03
02	0503019278	LUBRICANT SLEEVE		02
03	0581018679	SLEEVE		01
04	0581018677	SUPPORT DISC AXLE		01
05	0503010361	SPRING PIN		01
06	0551015883	SPRING GUIDES SLEEVE		02
07	0503031575	COMPRESSION SPRING		02
08	0521068189	SPRING REGULACION		02
09	0501012140	FLAT WASHER		02
10	0503010152	3/4" SELF LOCKING NUT		01
11	0503010806	5/8" X 3" BOLT		02
12	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT		01
13	0503011075	3/4" UNC NUT		02
14	0503010878	5/8" SELF ALIGNING NUT		02
15	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	74	01
16	0521069351	RIGHT ARM		01
17	0521069350	LEFT ARM		01
18	0503010410	RING		02
19	0502012898	BOTTOM BRACKET		01
20	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
21	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
22	0571012370	PROTECTION FRONT		01
23	0581018678	FLANGE WASHER		01
24	0503010756	0.2" X 2.4" SPRING PIN		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	DISC BLADE HUB	75	01

DISC BLADE HUB


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	DISC BLADE HUB		01
09	0502040873	DISC BLADE AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0521058085	REAR WITH DDD LEFT SPICRR	77	01
02	0521056640	PRECISION PLANTING CSC CABLE / 92	92	01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" SPLIT PIN		01
05	0591017565	SEED CONDUCTOR GUIDE		01
06	0503015341	POP RIVET		02




Item	Code	Description	See page	QT
01	0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM 78 SPI		01
02	0502012923	BEATER		01
03	0521056632	DEPTH CONTROL	83	01
04	0591011323	AXLE ARTICULATION WHEEL DEPTH		02
05	0502012920	SUPPORT ADJUSTING		01
06	0502012611	DEPTH CONTROL AXLE		01
07	0591011309	ADJUSTMENT BUSHING		02
08	0591011310	ADJUSTMENT BAR		02
09	0503019275	SLEEVE LUBRICATION SYSTEM		01
10	0581019473	ARTICULATED SLEEVE		02
11	0503010045	O'RING		02
12	0503013357	3/8 SELF-ADJUSTING NUT		02
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
14	0591011326	LOCK PIN		01
15	0571015326	ARTICULATION SLEEVE HANDLE		01
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2 UNC G.5 ZN HEX NUT		02
18	0503010019	1/2" SPRING WASHER		04
19	0591011324	SMALLER AXLE		01
20	0591011325	LARGER AXLE		01
21	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
22	0503030012	HITCH PIN CLIP		02
23	0501011445	FLAT WASHER		04
24	0521056633	MOUNTED RIGHT ARM	84	01
25	0521056631	MOUNTED LEFT ARM	85	01
26	0503012556	1/2" X 1" BOLT		02
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
28	0591011306	ADJUSTMENT LOCK		02
29	0521055093	BODY COMPACTOR	88	01
30	0521054990	LEFT COMPACTOR WHEEL	89	01
31	0521055017	RIGHT COMPACTOR WHEEL	90	01




Item	Code	Description	See page	QT
01	0502012928	LEFT EXTENSOR		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 79 FERTILIZER / SEED		01
11	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 81 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	80	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	82	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUBLE DISC AXLE		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0502012925	ADJUSTMENT BODY		01
02	0511015976	FLAT WASHER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0503010581	RING		01
05	0502012892	DEPTH CONTROL HANDLE		01
06	0581019526	ARTICULATED AXLE LEVER DEPTH		01
07	0503010302	501019 SEAL RING		01




Item	Code	Description	See page	QT
01	0502012926	RIGHT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 86 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0502012927	LEFT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 86 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503030891	RUBBER BAND		01
03	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
05	0503010337	5/16" NUT		06
06	0521055073	ASSEMBLY DEPTH WHEEL HUB	87	01




Item	Code	Description	See page	QT
01	0581019528	WHEEL DEPTH SPA HUB WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	DUST CLOAK		01
11	0581019529	DEPTH REGULATOR SHAFT		01




Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT	02	
02	0503013816	5/16" LOCKNUT	04	
03	0581015855	SLEEVE	02	
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER	01	
05	0521068661	LEVER	01	
06	0503030878	LEVER CRANK	01	
07	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING	01	
08	0581019520	AXIS	01	
09	0571812442	COUPLING SHAFT	01	
10	0503010257	1/8" X 1" SPLIT PIN	01	
11	0581019511	COVER	01	
12	0503010848	5/16" X 3.1/2" BOLT	02	
13	0503010752	1/2" X 3.1/2" BOLT	01	
14	0503011336	1/2" HEX SELF ADJUSTING NUT	01	
15	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
16	0581019510	AXIS	01	
17	0581019512	PLATE TOP	01	
18	0503019351	LUBRICANT SLEEVE	02	
19	0521069591	LEFT SIDE	01	
20	0581019548	RIGHT SIDE BODY	01	




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	91	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	91	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0502012924	PRECISION PLANTING SUPPORT		01
02	0502012800	SUPPORT ARTICULATION PNEUMATIC		01
03	0503062406	SEED HOPPER		01
04	0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT 93 PROTECTION		01
05	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01
07	0503810009	BOLT		02
08	0571018649	SUPPORT FIXER		02
09	0503010243	CLAMP		01
10	0581017816	TERMINAL		01
11	0503034204	SEALING		01
12	0503010140	1/8" X 3/4" SPLIT PIN		01
13	0571014024	FAST BOLT GUIDE AXLE		01
14	0503034824	FIXATIVE		01
15	0503010293	CLAMP KNOB		01
16	0503010025	3/8 SPRING WASHER		05
17	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
18	0501110894	FIXER		01
19	0502012922	FIXING SUPPORT		01
20	0503011404	BOLT		01
21	0503013357	3/8 SELF-ADJUSTING NUT		01
22	0503010026	3/8" NUT		04
23	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04




Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01




Item	Code	Description	See page	QT
01	0521058084	REAR WITH RIGHT DDD SPICRR	95	01
02	0521056640	PRECISION PLANTING CSC CABLE / 92	92	01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" SPLIT PIN		01
05	0591017565	SEED CONDUCTOR GUIDE		01
06	0503015341	POP RIVET		02




Item	Code	Description	See page	QT
01	0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	96	01
02	0502012923	BEATER		01
03	0521056632	DEPTH CONTROL	83	01
04	0591011323	AXLE ARTICULATION WHEEL DEPTH		02
05	0502012920	SUPPORT ADJUSTING		01
06	0502012611	DEPTH CONTROL AXLE		01
07	0591011309	ADJUSTMENT BUSHING		02
08	0591011310	ADJUSTMENT BAR		02
09	0503019275	SLEEVE LUBRICATION SYSTEM		01
10	0581019473	ARTICULATED SLEEVE		02
11	0503010045	O'RING		02
12	0503013357	3/8 SELF-ADJUSTING NUT		02
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
14	0591011326	LOCK PIN		01
15	0571015326	ARTICULATION SLEEVE HANDLE		01
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2 UNC G.5 ZN HEX NUT		02
18	0503010019	1/2" SPRING WASHER		04
19	0591011324	SMALLER AXLE		01
20	0591011325	LARGER AXLE		01
21	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
22	0503030012	HITCH PIN CLIP		02
23	0501011445	FLAT WASHER		04
24	0521056633	MOUNTED RIGHT ARM	84	01
25	0521056631	MOUNTED LEFT ARM	85	01
26	0503012556	1/2" X 1" BOLT		02
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
28	0591011306	ADJUSTMENT LOCK		02
29	0521055093	BODY COMPACTOR	88	01
30	0521054990	LEFT COMPACTOR WHEEL	89	01
31	0521055017	RIGHT COMPACTOR WHEEL	90	01




Item	Code	Description	See page	QT
01	0502012929	BODY RIGHT		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 81 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 79 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0502012768	ROW SUPPORT CLAMP		02
02	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
03	0503010878	5/8" SELF ALIGNING NUT		04
04	0591018094	TURBINE SUPPORT PEDESTAL		01
05	0531050983	PRECISION PLANTING TURBINE WITH SUPPORT	98	01
06	0503010232	5/8" X 1.3/4" BOLT		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		04
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
06	0521050154	PRECISION PLANTING TURBINE WITH HOLE	99	01
07	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
08	0501010694	FLAT WASHER		02
09	0503010143	1/4" SPRING WASHER		02
10	0503010144	1/4" NUT		02
11	0503010190	2-114 N 3006-9B O'RING		04
12	0501081235	1/2 X 650 TR- TC HOSE		01
13	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
14	0503031087	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01



Item	Code	Description	See page	QT
01	0531050114	COMPLETE SIDE BOX SUPPORT	34	01
02	0531050113	BEARING HANGER ASSEMBLY	35	02
03	0531054290	CENTRAL SEED BOX	101	01
04	0503034345	DISPENSER COVER		09
05	0503010184	CLAMP		09
06	0513010405	CLAMP		08
07	0521053176	COVER KAP		01
07A	0581017528	15 OUTPUT TUBE COVER		01
07B	0503011372	102 TO 121 CLAMP		01




Item	Code	Description	See page	QT
01	0531062313	17-MOUTH AIR TUBE WITH FIXER		01
02	0503010025	3/8 SPRING WASHER		08
03	0503010849	3/8" X 1-1/2" BOLT		08
04	0531054289	CENTRAL SEED BOX	102	01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		30
06	0503013357	3/8 SELF-ADJUSTING NUT		26
07	0531054275	LOWER BOX SEED SYSTEM	103	01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04




Item	Code	Description	See page	QT
01	0513010632	RUBBER SMOOTH WASHER 28 X 10 X 2.00	26	
02	0503063688	COMPLETE POSITIVE AIR SEED BOX	01	
03	0531063623	LOWER BOX SYSTEM FIXING RULE	04	
04	0531063624	SYSTEM FIXING RULE	02	
05	0513010630	SCREW M6 X1 X 20 CCSI 10.9 SA	12	
06	0503019413	THREAD SCREW INTERNAL	04	

LOWER BOX SEED SYSTEM


0531054275




Item	Code	Description	See page	QT
01	0503063393	AIR PIPE SEAL 5 OUTPUTS		01
02	0503019290	BOLT		24
03	0503034692	FAST LOCK ASSY		06
04	0503034571	SEALING		01
05	0503030085	LOCK PIN		06
06	0503063392	AIR PIPE SEAL 6 OUTPUTS		02
07	0531063617	BOTTOM BOX SYSTEM 17 OUTPUTS		01
08	0503035462	COVER SEAL		03
09	0531063616	BOTTOM COVER BOX 418		03
10	0503015135	FLAT WASHER 10 X 18 X 2		06
11	0503011823	0.1" X 0.6" SPRING PIN		06
12	0581017529	ROD 9,53		03




Item	Code	Description	See page	QT
01	0581017801	PLATFORM ASSY		01
02	0531050115	PLATFORM/LADDER SIDE SUPPORT	38	01
03	0521052175	SUPPORT PLATFORM ASSY	37	02




Item	Code	Description	See page	QT
01	0531050952	FRONT SIDE HANDRAIL 824	106	01
02	0531050954	RIGHT HANDRAIL 2507	107	01
03	0531050947	U HANDRAIL FIXER	45	02
04	0591015150	L HANDRAIL FIXING		01
05	0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	46	02




Item	Code	Description	See page	QT
01	0591018005	TUBE 33,7 X 27 X 741		03
02	0511059383	HANDRAIL INTERNAL FIXER	21	06
03	0581012718	HANDRAIL		02
04	0581014429	SHIM HANDRAIL		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0581015996	TUBE 33,7 X 27 X 1131		02
07	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0591015263	TUBE 33,7 X 27,00 X 1070		03
02	0511059383	HANDRAIL INTERNAL FIXER	21	08
03	0581012718	HANDRAIL		04
04	0503011179	3/8" X 2-1/4" BOLT		04
05	0581015996	TUBE 33,7 X 27 X 1131		03
06	0581014429	SHIM HANDRAIL		03
07	0503013357	3/8 SELF-ADJUSTING NUT		04
08	0581015992	33,70 X 27 X 354 TUBE		02
09	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	43	07
10	0581019812	TUBE 33,7 X 27 X 550		03
11	0581015995	33,7 X 27 X 925 TUBE		01
12	0531061756	FIXER HANDRAIL		01
13	0591016448	BODY REAR SIDE HANDRAIL		02




Item	Code	Description	See page	QT
01	0531051031	SIDE AIR CONDUCTOR 6 BUTTONS X 2745	109	01
02	0531051032	AIR CONDUCTOR 2 MOUTH X 512	110	01
03	0531051028	SIDE HOSE SUPPORT	59	01
04	0521052549	CLAMP	57	08
05	0521052168	SEED HOSE GUIDE	58	01
06	0531051035	COMPLETE MAJOR AIR CONDUCTOR SUPPORT	56	03



Item	Code	Description	See page	QT
01	0581012427	AIR DISTRIBUTOR NOZZLE		01
02	0591018091	CONDUCT BODY AIR		01
03	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
03A	0503034763	AIR DITRIBUTOR PUMP		01
03B	0503015341	POP RIVET		02
04	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		06
04A	0503034812	SOCKET DISTRIBUTOR AR		06
04B	0503012856	POP RIVET		12
05	0511057036	AIR DISTRIBUTOR BOARD		01
05A	0503012567	T-JOIN FOR TUBE 110		01
05B	0581013890	AIR DISTRIBUTOR SOCKET		01
06	0591014650	CONDUCT BODY AIR		01




Item	Code	Description	See page	QT
01	0581012427	AIR DISTRIBUTOR NOZZLE		01
02	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		02
02A	0503034812	SOCKET DISTRIBUTOR AR		01
02B	0503012856	POP RIVET		04
03	0591018092	AIR CONDUCTOR		01
04	0581013633	AIR DISTRIBUTOR NOZZLE		01




Item	Code	Description	See page	QT
01	0591011152	GUTTER 30 X 55 X 3160		01
02	0521055102	BIGGEST FULL GUTTER SUPPORT	61	03

RIGHT SIDE DUCT ASSEMBLY


0531054463




Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY	63	03
02	0521053025	DUCT SUPPORT OIL	64	01
03	0581018415	PROTECTION BODY		09
04	0581018408	SUPPORT SCALE		03
05	0503011268	3/8" X 2-1/2" BOLT		02
06	0503010716	3/8" X 3-3/4" BOLT		06
07	0503010025	3/8 SPRING WASHER		08
08	0503010026	3/8" NUT		08
09	0521069339	OIL TUBE		01
10	0531061861	OIL TUBE		01
11	0531062282	OIL TUBE		02
12	0531062284	OIL TUBE		01
13	0531061749	OIL TUBE		02
14	0521069341	OIL DUCT R.3/4 X 1050		02
15	0521068953	OIL PIPE R.7/8 X 829		02
16	0521069338	OIL TUBE		02




Item	Code	Description	See page	QT
01	0521059366	COMPLETE DOUBLE ROTARY VALVE SUPPORT	114	01
02	0521059419	CASAPPA DOUBLE DIVIDER BRP00102 WITH NIPLES	115	01
03	0531050960	WHEEL SUPPORT WITH CONTROL VALVE	29	01




Item	Code	Description	See page	QT
01	0591015284	VALVE SUPPORT BODY		01
02	0571011070	5/8" UNC FASTENER		01
03	0501012140	FLAT WASHER		02
04	0503013389	5/8" SELF LOCKING NUT		02
05	0503013357	3/8 SELF-ADJUSTING NUT		04
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
07	0503010237	3/8" X 1" BOLT		04




Item	Code	Description	See page	QT
01	0503019810	DOUBLE ROTATING DIVIDER		01
02	0571013917	7/8"NF X 1.1/16 UNF NIPPLE		01
03	0503011109	2-119 N 3006-9B O'RING		01
04	0511010111	7/8" NIPPLE		02
05	0503010045	O'RING		02
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
07	0503013357	3/8 SELF-ADJUSTING NUT		04
08	0503010237	3/8" X 1" BOLT		04




Item	Code	Description	See page	QT
01	0531061386	LARGER CENTRAL FRAME		01
02	0501010276	BOLT		16
03	0503010012	1" SPRING WASHER		16
04	0503012182	1" NUT		16
05	0571012964	AXLE BODY WHEELS PIVOT		02
06	0501010630	1.1/2" CASTLE NUT		02
07	0503011345	1/4" X 3.1/2" SPLIT PIN		02
08	0521053207	INTERNAL PLATE WITH FIXATION SCREW 1/2	117	01




Item	Code	Description	See page	QT
01	0561017061	TUBE ADJUSTMENT PLATE		01
02	0503010019	1/2" SPRING WASHER		08
03	0501010161	1/2" X 1.1/4" BOLT		08




Item	Code	Description	See page	QT
01	0531061253	WHEEL SUPPORT		01
02	0591014085	GLOVE 90MM		06
03	0531061252	ROCKER ARTICULATING AXIS WITH FLANGE		02
04	0501111037	CENTRAL WHEELED ROCKER WITH GLOVE		02
05	0591016833	FLAT WASHER 65 X 160 X 12.50		02
06	0581013528	FLANGED NUT		02
07	0503012213	1/4" X 4" SPLIT PIN		02
08	0503014441	BOLT 3/4		12
09	0501010322	FLAT WASHER		16
10	0503010152	3/4" SELF LOCKING NUT		12
11	0521058864	WHEEL SUPPORT WITHOUT TIRE AND WITH 119 ROCKER ARM		04
12	0503011075	3/4" UNC NUT		04
13	0503016525	3/4" X 6" BOLT		04
14	0503010002	1800 GREASE FITTING		05
15	0531060954	SMALLER CYLINDER AXLE 179		02
16	0503011052	1.1/4" X 0.77" CASTLE NUT		04
17	0503010038	3/16" X 2" SPLIT PIN		04
18	0531061250	259 CYLINDER LOWER AXIS		03
19	0503011345	1/4" X 3.1/2" SPLIT PIN		03
20	0501010630	1.1/2" CASTLE NUT		03
21	0521058874	HYDRAULIC CYLINDER 63,50 X 150 X 731 X 322	120	02
22	0531061256	SMALL CENTRAL WHEELED CYLINDER AXIS		02
23	0531052442	ACTUATOR ASSEMBLY	121	01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0503010059	33287/33462 ROLLER BEARING		01
03	0503010009	RETAINER 00573-B		01
04	0503010086	SEAL 0009B-B		01
05	0551014473	GLOVE		01
06	0503012702	KM-12 NUT		02
07	0503012703	LOCK WASHER		01
08	0503010002	1800 GREASE FITTING		01
09	0503011444	SPRING WASHER		04
10	0503014048	22 X 1.5 HEX NUT		08
11	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
12	0503014050	22 X 1.5 BOLT		08
13	0511068415	SEAL GUIDE		01
14	0503010007	3982/3920 ROLLER BEARING		01
15	0591014921	MAJOR WHEEL AXLE		01
16	1882970002	GREASE SOAP		01




Item	Code	Description	See page	QT
01	0531061257	ROD		01
02	0531061258	CYLINDER BARREL		01
03	0541010615	MOVABLE COVER		01
04	0581018237	RING SUPPORT 63.50 X 150 X 80		01
05	0503014960	GASKET		01
06	0503010287	D-2500 SCRAPER RING		01
07	0503010971	W2-2750-500 PK RING G.I		02
08	0503010003	1845 GREASE FITTING		01
09	0581018236	PISTON 150 X 57		01
10	0503019098	O' RING 2-227 N 3006-90B		01
11	0581018235	10 X 30 NUT		01
12	0503015912	SELEMASTER SEALING		01
13	0503010002	1800 GREASE FITTING		01
14	0503030387	PLUG		02
15	0503010704	2-357 N 3006-9B O'RING		01
16	0503019286	BACK-UP RING 8-357		01




Item	Code	Description	See page	QT
01	0591019919	LIFT SENSOR ACTUATOR		01
02	0561016468	FASTENER		01
03	0503010589	1/2" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0503018841	DIAGONAL TIRE		01
02	0503034460	WHEEL		01
03	0503013999	VALVE		01




Item	Code	Description	See page	QT
01	0503018841	DIAGONAL TIRE		01
02	0503034460	WHEEL		01
03	0503013999	VALVE		01




Item	Code	Description	See page	QT
01	0531054290	CENTRAL SEED BOX	101	01
02	0521052156	ASSY CENTRAL SUPPORT	125	01
03	0503034345	DISPENSER COVER		09
04	0503010184	CLAMP		09
05	0513010405	CLAMP		08
06	0521053176	COVER KAP		01
06A	0581017528	15 OUTPUT TUBE COVER		01
06B	0503011372	102 TO 121 CLAMP		01




Item	Code	Description	See page	QT
01	0521068348	CENTRAL SUPPORT SEED BOX	01	
02	0581016040	LOWER SUPPORT CASH SEED	04	
03	0501011643	3/8 X 1"BOLT	16	
04	0503013357	3/8 SELF-ADJUSTING NUT	16	
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER	24	
06	0581012237	SEAL BOX FIXER	02	
07	0581012245	SEAL BOX SHOULDER	02	
08	0503010025	3/8 SPRING WASHER	04	
09	0503010026	3/8" NUT	04	
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04	
11	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN	06	
12	0503010589	1/2" UNC SELF ADJUSTING NUT	06	
13	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT	06	




Item	Code	Description	See page	QT
01	0521052154	ASSY REAR LADDER PLATFORM	127	02
02	0521069496	LARGER REAR PLATFORM BASE		01
03	0521054881	LARGER SIDE HANDRAIL FRAME CENTRAL	128	02
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2 UNC G.5 ZN HEX NUT		12
06	0503014734	BOLT		08
07	0503010395	1/2" X 1-1/4" BOLT		04
08	0581019228	PLATFORM PROTECTION		01
09	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
10	0503010025	3/8 SPRING WASHER		02
11	0503010026	3/8" NUT		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
13	0521057760	LED FLASHLIGHT WITH SUPPORT	129	02




Item	Code	Description	See page	QT
01	0521068347	PLATFORM 430 X 980		01
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04




Item	Code	Description	See page	QT
01	0581012750	SIDE HANDRAIL BODY (1085)		02
02	0511059383	HANDRAIL INTERNAL FIXER	21	06
03	0581019220	TUBE 33.7 X 27 X 668		03
04	0581012718	HANDRAIL		02
05	0581014429	SHIM HANDRAIL		02
06	0503011179	3/8" X 2-1/4" BOLT		04
07	0503010025	3/8 SPRING WASHER		04
08	0503013357	3/8 SELF-ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0591013259	LED FLASHLIGHT SUPPORT		01
02	0503019579	LED LANTERN		01




Item	Code	Description	See page	QT
01	0521068930	SACADOR AXLE		01
02	0521068931	SLEEVE SACADOR		01




Item	Code	Description	See page	QT
01	0571019137	SWITCH FIXER		01
02	0503013584	VACUUM GAUGE		01
03	0503010025	3/8 SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0581014411	BREATHE		01




Item	Code	Description	See page	QT
01	0503019303	CONTROL PANEL		01
02	0503019305	WHIP		01
03	0503019307	CABLE TRACTOR HEADLIGHT		01
04	0503019304	WIRES BLOCK COMMAND TRACTOR		01
05	0521051707	ASSY PANEL FIXER PLATE	133	01
06	0503016234	TRIMBLE FIXING WINDOW		01
07	0503016452	FIXING SUPPORT AG500 TRIMBLE		01




Item	Code	Description	See page	QT
01	0581015186	ELECTRIC PANEL FIXING PLATE		01
02	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
03	0503010669	FLAT WASHER		02
04	0503010667	3/16" NUT		02
05	0503010668	3/16" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0531061248	ARTICULATION ARM LEFT		01
02	0571011825	BUSHING		02
03	0503015322	BOLT 7/8		01
04	0503010408	7/8" SPRING WASHER		01
05	0571017893	HORIZONTAL ARTICULATION SHAFT		01
06	0503011198	C3/4" X 6" SCREW		01
07	0503011255	3/4" LOCK NUT		01
08	0503010002	1800 GREASE FITTING		01
09	0503032042	SHEET POLYETHYLENE		01
10	0503010814	5/16 BOLT		14
11	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
12	0571011767	125 X 88 X 4,76 FLAT WASHER		01
13	0503010004	1890 GREASE FITTING		01
14	0591014905	ARTICULATING CYLINDER AXLE		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503010019	1/2" SPRING WASHER		01
17	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0571011825	BUSHING		02
02	0503010408	7/8" SPRING WASHER		01
03	0503015322	BOLT 7/8		01
04	0571017893	HORIZONTAL ARTICULATION SHAFT		01
05	0503011198	C3/4" X 6" SCREW		01
06	0503011255	3/4" LOCK NUT		01
07	0503010002	1800 GREASE FITTING		01
08	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
09	0503032042	SHEET POLYETHYLENE		01
10	0503010814	5/16 BOLT		14
11	0531061247	RIGHT ARTICULATING ARM 1736		01
12	0571011767	125 X 88 X 4,76 FLAT WASHER		01
13	0503010004	1890 GREASE FITTING		01
14	0591014905	ARTICULATING CYLINDER AXLE		01
15	0503010019	1/2" SPRING WASHER		01
16	0503010060	1/2 UNC G.5 ZN HEX NUT		01
17	0503010752	1/2" X 3.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511058761	HYDRAULIC CYLINDER	137	02
02	0591014905	ARTICULATING CYLINDER AXLE		02
03	0503010752	1/2" X 3.1/2" BOLT		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0503010019	1/2" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0521066785	2.5" TURNBUCLE		01
02	0521066784	150 X 843 CYLINDER CASE		01
03	0503010287	D-2500 SCRAPER RING		01
04	0503010971	W2-2750-500 PK RING G.I		02
05	0581011197	PISTON		01
06	0581013481	MOBILE COVER 150		01
07	0503030384	CON PLUG N-001		02
08	0581011195	2.5" X 5" RING SUPPORT		01
09	0503014960	GASKET		01
10	0503018466	O'RING		01
11	0503018465	ANILLO O'RING		01
12	0503010141	2-226 N 3006-9B O'RING		01
13	0503018467	RING		01
14	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0531054466	CENTRAL DUTY ASSEMBLY	139	01
02	0503063057	COMMAND BLOCK		01
03	0521057526	SUPPORT BLOCK	141	01
04	0521058489	CASAPPA TRIPLE DIVIDER VALVE BRP00090 WITH NIPLES	142	01
05	0531050254	ASSY HOSE ARTICULATION	143	01
06	0531055059	HEADER HOSE ASSY	144	01
07	0531051240	HOSE KIT LIFFITING CYLINDER	145	01
08	0531052831	TURBINE HOSE KIT	146	01
09	0531055084	ALTERNATOR HOSE SET	147	01
10	0501053834	MALE QUICK COUPLER	148	10
11	0581017815	MALE ADAPTER		01
12	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0521069199	OIL DUCT R.3/4 X 1480		07
02	0531061249	RETURN OIL DUCT		01
03	0521069198	OIL DUCT R.7/8 X 1480		04
04	0521069200	OIL DUCT R.1.1/16 X 1480		02
05	0531061076	OIL DUCT 3 OUTPUTS R7 / 8 X 1726		01
06	0521053537	CENTRAL REAR DUCT SUPPORT	140	04
07	0581018415	PROTECTION BODY		04
08	0581018409	FASTENER BODY		04
09	0581018407	BODY FASTENER 2 DUCTS		08
10	0503011268	3/8" X 2-1/2" BOLT		02
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		08
12	0503011141	3/8" X 2-3/4" BOLT		02
13	0503011123	BOLT		04
14	0503010025	3/8 SPRING WASHER		16
15	0503010026	3/8" NUT		16
16	0581014867	SIDE DUTY SUPPORT		02
17	0591010127	SUPPORT LEFT DISTRIBUTOR		02
18	0591016461	19 X 22 X 7 DUCT HOLDING SUPPORT		02



Item	Code	Description	See page	QT
01	0571019615	FITTING 1/2 UNC 130 X 198 ZN		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0503010025	3/8 SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581017885	SUPPORT BODY		01
08	0503011141	3/8" X 2-3/4" BOLT		01
09	0581018407	BODY FASTENER 2 DUCTS		01




Item	Code	Description	See page	QT
01	0591012526	SUPPORT BLOCK		01
02	0503010172	M10 X 1,5 X 25 BOLT		03
03	0503010025	3/8 SPRING WASHER		03
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
05	0503010395	1/2" X 1-1/4" BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0503019501	VALVE		01
02	0581013111	NIPPLE R 1.1/6 UN X 1.5/16 12 WIRES		01
03	0503014724	2-215 N 3006-9B O'RING		01
04	0503012923	2-116 3006-9B O'RING		03
05	0501010590	NIPPLE		03
06	0503010026	3/8" NUT		04
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
08	0503010025	3/8 SPRING WASHER		04
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04

ASSY HOSE ARTICULATION


0531050254



Item	Code	Description	See page	QT
01	0501080450	3/8" X 86" TR-TC HOSE		02
02	0501080105	3/8 X 700 TR-TR HOSE		02
03	0501080128	3/8" X 71" TR-TR HOSE ASSY		02
04	0501080321	3/8" X 47" TR-TR HOSE ASSY		02
05	0501082184	HOSE 1/2 X 2100 TC-TC		01
06	0501080599	3/8 X 650 TR-TC HOSE		01
07	0501080465	3/8 X 400 TR-TC HOSE ASSY		01
08	0501080525	3/8 X 2300 TC-TC HOSE ASSY		01
09	0501081282	MANGUERA 3/8" X 1550 TC-TC		01
10	0501081884	HOSE		01




Item	Code	Description	See page	QT
01	0501080450	3/8" X 86" TR-TC HOSE		02
02	0501080128	3/8" X 71" TR-TR HOSE ASSY		02
03	0501081046	3/8" X 161.4" TC-TM HOSE ASSY		01
04	0501080390	3/8" X 150" TR-TC HOSE ASSY		01
05	0501080105	3/8 X 700 TR-TR HOSE		02




Item	Code	Description	See page	QT
01	0501080611	3/8" X 17.8" TR-TR HOSE ASSY		04
02	0501080465	3/8 X 400 TR-TC HOSE ASSY		08
03	0501080105	3/8 X 700 TR-TR HOSE		08
04	0501080218	1/2 X 750 HOSE		02
05	0501080522	3/8 X 700 TC-TC HOSE ASSY		04
06	0501080267	HOSE 1/2 X 2100 TR-TC		02
07	0501081442	3/4 X 1550 TR-TC HOSE		01
08	0501081824	3/8 X 1100 TC-TC HOSE		02
09	0501080285	1/2" X 16" TR-TC HOSE ASSY		01
10	0501080301	3/8 X 1300 TC-TC HOSE		02
11	0501082244	HOSE 1/2 X 1700 TC-TC 180G		01
12	0501080258	3/4 X 1500 TR-TC HOSE		02
13	0501080012	3/4 X 700 TR-TR HOSE		02
14	0501080347	HOSE 3/4 X 1800 TR-TR		02
15	0521053712	3/4 X 5900 TR-TM BLACK/RED HOSE		01
15A	0501082205	3/4 X 5900 TR-TM HOSE		01
15B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
15C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
15D	0503018952	PLASTIC BOLT		06
16	0521053707	3/4 X 5900 TR-TM BLACK/BLUE HOSE		01
16A	0501082205	3/4 X 5900 TR-TM HOSE		01
16B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
16C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
16D	0503018952	PLASTIC BOLT		06
17	0501082207	1/2 X 350 TC-TC HOSE		01
18	0501081288	3/4 X 500 TR-TC HOSE		01
19	0501080727	3/8 X 370 TR-TR HOSE		02
20	0501080054	3/8" X 17" TR-TC HOSE ASSY		02
21	0501082237	1/2 X 450 TC-TC HOSE		01

TURBINE HOSE KIT


0531052831




Item	Code	Description	See page	QT
01	0501081813	HOSE 1/2 X 1400 TC-TC		04
02	0501080301	3/8 X 1300 TC-TC HOSE		02
03	0501080024	1/2" X 700 TR-TR HOSE		06
04	0501080105	3/8 X 700 TR-TR HOSE		03
05	0501081235	1/2 X 650 TR- TC HOSE		02
06	0501080218	1/2 X 750 HOSE		02
07	0501080150	3/8 X 800 TR-TC HOSE		02
08	0501080135	HOSE 1/2 X 1800 TR-TR		10
09	0501080128	3/8" X 71" TR-TR HOSE ASSY		02
10	0501081510	HOSE 1/2 X 1700 TR-TC		01
11	0501080300	HOSE 1/2 X 1700 TR-TR		01
12	0501080056	3/8" X 1700 TR-TC HOSE ASSY		01
13	0501080461	3/8" X 70" TR-TC HOSE		01
14	0501080515	3/8" X 133" TR-TC HOSE		02
15	0501081595	HOSE 1/2 X 3400 TR-TC		10
16	0521053716	3/4 X 3200 TR-TM HOSE YELLOW / RED		02
16A	0501082206	HOSE 3/8 X 3200 TR-TM		02
16B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		02
16C	0503034495	HYDRAULIC HOSE GRIP (RED)		02
16D	0503018952	PLASTIC BOLT		12
17	0521053713	3/8 X 3200 TR-TM HOSE YELLOW / GREEN		01
17A	0501080441	HOSE ASSY		01
17B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
17C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
17D	0503018952	PLASTIC BOLT		06
18	0521053714	3/4 X 3200 TR-TM HOSE YELLOW / BLUE		02
18A	0501082206	HOSE 3/8 X 3200 TR-TM		02
18B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		02
18C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02
18D	0503018952	PLASTIC BOLT		12




Item	Code	Description	See page	QT
01	0501081831	3/8 X 1500 TR-TC HOSE		01
02	0501081834	1/2 X 1500 TR-TC HOSE		02
03	0521052564	HOSE 1/2 X 5900 TR-TM YELLOW / BLUE		01
03A	0501081841	1/2 X 5900 TR-TM HOSE		01
03B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
03C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
03D	0503018952	PLASTIC BOLT		06
04	0521052565	1/2 X 5900 TR-TM HOSE YELLOW / RED		01
04A	0501081841	1/2 X 5900 TR-TM HOSE		01
04B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
04C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
04D	0503018952	PLASTIC BOLT		06
05	0531055083	3/8 X 5900 TR-TM YELLOW/GREEN HOSE		01
05A	0501082100	3/8 X 5900 TR-TM HOSE		01
05B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
05C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
05D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521057760	LED FLASHLIGHT WITH SUPPORT	129	02
02	0521053672	LIGHTHOUSE ASSY	150	05
03	0521059535	ELECTRICAL ASSEMBLY		01
03A	0503019920	LIGHT / LANTERN CABLE		01
03B	0503019921	COMMAND BLOCK WHIP		01
04	0503018829	NYLON CLAMP		20
05	0503019902	NYLON CLAMP 7,8X1,8X225 MM		100




Item	Code	Description	See page	QT
01	0581015856	REDLIGHT SUPPORT		01
02	0503018738	HEADLIGHT		01
03	0501010694	FLAT WASHER		02
04	0503010358	5/16" X 5/8" BOLT		02
05	0551019884	45 X 50 X 3/8 FASTENER		02
06	0503013357	3/8 SELF-ADJUSTING NUT		04
07	0503010337	5/16" NUT		02
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		02




Item	Code	Description	See page	QT
01	0521053530	REAR CENTRAL AIR CONDUCTOR 1400 CSC	152	01
02	0521059355	CENTRAL AIR CONDUCTOR	153	01
03	0521051096	REAR CENTRAL AIR CONDUCTOR 1120 CSCP	154	02
04	0521055922	DOUBLE CONDUCTOR SUPPORT ASSY CENTRAL AIR	155	02
05	0531051035	COMPLETE MAJOR AIR CONDUCTOR SUPPORT	56	03
06	0531051112	CENTRAL AIR CONDUCTOR SUPPORT	156	02
07	0503011372	102 TO 121 CLAMP		06
08	0521052549	CLAMP	57	10
09	0521052168	SEED HOSE GUIDE	58	04
10	0521052153	ASSY HOSE GUIDE	157	02
11	0581018202	SUPPORT AIR CONDUCTION		02




Item	Code	Description	See page	QT
01	0581015132	BODY DISTRIBUTOR AR		01
02	0581013633	AIR DISTRIBUTOR NOZZLE		02




Item	Code	Description	See page	QT
01	0511057036	AIR DISTRIBUTOR BOARD		04
01A	0503012567	T-JOIN FOR TUBE 110		01
01B	0581013890	AIR DISTRIBUTOR SOCKET		01
02	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		10
02A	0503034812	SOCKET DISTRIBUTOR AR		01
02B	0503012856	POP RIVET		04
03	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		02
03A	0503034763	AIR DITRIBUTOR PUMP		01
03B	0503015341	POP RIVET		02
04	0591015280	CONDUCTOR BODY AIR 03 MOUTH		01
05	0591015281	CONDUCTOR BODY AIR 02 MOUTH		01
06	0591015279	CONDUCTOR BODY AIR 03 MOUTH		01
07	0581019586	AIR CONDUCTOR BODY 1 MOUTH 268 04 HOLES		02




Item	Code	Description	See page	QT
01	0581015132	BODY DISTRIBUTOR AR		01
02	0581013633	AIR DISTRIBUTOR NOZZLE		01
03	0521050393	ASSY KNEE		01
03A	0503017845	90 PVC KNEE		01
03B	0581013890	AIR DISTRIBUTOR SOCKET		01




Item	Code	Description	See page	QT
01	0591010198	DOUBLE CENTRAL CONDUCTOR SUPPORT		01
02	0521018402	AIR CONDUCTOR CLAMP		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
04	0503010337	5/16" NUT		04
05	0503010371	5/16" X 1" BOLT		04




Item	Code	Description	See page	QT
01	0521018402	AIR CONDUCTOR CLAMP		01
02	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
03	0503010337	5/16" NUT		02
04	0503010371	5/16" X 1" BOLT		02
05	0531062285	SUPPORT AIR CONDUCTOR		01



Item	Code	Description	See page	QT
01	0521068346	HOSE GUIDE		01
02	0503010025	3/8 SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0501011643	3/8 X 1"BOLT		02




Item	Code	Description	See page	QT
01	0531050952	FRONT SIDE HANDRAIL 824	106	01
02	0531050958	LEFT HANDRAIL 2507	159	01
03	0591015150	L HANDRAIL FIXING		01
04	0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	46	02




Item	Code	Description	See page	QT
01	0591015263	TUBE 33,7 X 27,00 X 1070		03
02	0511059383	HANDRAIL INTERNAL FIXER	21	08
03	0581012718	HANDRAIL		04
04	0503011179	3/8" X 2-1/4" BOLT		04
05	0581015996	TUBE 33,7 X 27 X 1131		03
06	0581014429	SHIM HANDRAIL		03
07	0503013357	3/8 SELF-ADJUSTING NUT		04
08	0581015992	33,70 X 27 X 354 TUBE		02
09	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	43	07
10	0581019812	TUBE 33,7 X 27 X 550		03
11	0581015995	33,7 X 27 X 925 TUBE		01
12	0531061747	LEFT HANDRAIL FIXER		01
13	0591016448	BODY REAR SIDE HANDRAIL		02

LEFT SIDE AIR DUCT ASSEMBLY


0531051256



Item	Code	Description	See page	QT
01	0531051030	AIR CONDUCTOR 2 MOUTH X 752	161	01
02	0531051033	SIDE AIR DRIVER 06 MOUTH	162	01
03	0531051028	SIDE HOSE SUPPORT	59	02
04	0521052549	CLAMP	57	08
05	0521052168	SEED HOSE GUIDE	58	01
06	0531051035	COMPLETE MAJOR AIR CONDUCTOR SUPPORT	56	03




Item	Code	Description	See page	QT
01	0581012427	AIR DISTRIBUTOR NOZZLE		01
02	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		02
02A	0503034812	SOCKET DISTRIBUTOR AR		01
02B	0503012856	POP RIVET		04
03	0591018090	SIDE AIR DRIVER 02 MOUTH		01
04	0581013633	AIR DISTRIBUTOR NOZZLE		01




Item	Code	Description	See page	QT
01	0581012427	AIR DISTRIBUTOR NOZZLE		01
02	0591018093	AIR CONDUCTOR BODY 6 MOUTH		01
03	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		06
03A	0503034812	SOCKET DISTRIBUTOR AR		01
03B	0503012856	POP RIVET		04
04	0521050393	ASSY KNEE		01
04B	0503017845	90 PVC KNEE		01
04C	0581013890	AIR DISTRIBUTOR SOCKET		01

LEFT SIDE DUCT ASSEMBLY


0531054461



Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY	63	03
02	0521053025	DUCT SUPPORT OIL	64	02
03	0581018415	PROTECTION BODY		15
04	0503010716	3/8" X 3-3/4" BOLT		10
05	0503010025	3/8 SPRING WASHER		10
06	0503010026	3/8" NUT		10
07	0521069341	OIL DUCT R.3/4 X 1050		03
08	0521068953	OIL PIPE R.7/8 X 829		02
09	0531061749	OIL TUBE		02
10	0531062283	OIL PIPE R.3/4 X 2574		01
11	0531062282	OIL TUBE		01
12	0531061861	OIL TUBE		01
13	0521069339	OIL TUBE		01
14	0531062280	OIL PIPE 03 OUTPUTS R.3/4 X 3240		01




Item	Code	Description	See page	QT
01	0521058906	COMPLETE ALTERNATOR SUPPORT	165	01
02	0501213901	SUPPORT		01




Item	Code	Description	See page	QT
01	0591014852	SIDE CHASSIS ALTERNATOR SUPPORT		01
02	0503014734	BOLT		04
03	0503010060	1/2 UNC G.5 ZN HEX NUT		12
04	0503010019	1/2" SPRING WASHER		12
05	0571014216	FRONT HOSE SUPPORT FIXER		02
06	0571019140	PRISONER 1/2 UNC X 255		04
07	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08

LEFT SIDE HANDRAIL


0531051246




Item	Code	Description	See page	QT
01	0531055104	RIGHT SIDE HANDRAIL 1789	167	01
02	0531055105	LEFT SIDE HANDRAIL 1745	168	01
03	0531055106	1027 FRONT SIDE HANDRAIL	40	01
04	0531055107	980 FRONT SIDE HANDRAIL	41	01
05	0531050947	U HANDRAIL FIXER	45	02
06	0591015150	L HANDRAIL FIXING		02
07	0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	46	02




Item	Code	Description	See page	QT
01	0501214024	33,70 X 27,00 X 1227 TUBE		03
02	0511059383	HANDRAIL INTERNAL FIXER	21	08
03	0581012718	HANDRAIL		03
04	0503011179	3/8" X 2-1/4" BOLT		04
05	0581015996	TUBE 33,7 X 27 X 1131		02
06	0581014429	SHIM HANDRAIL		02
07	0503013357	3/8 SELF-ADJUSTING NUT		04
08	0581015992	33,70 X 27 X 354 TUBE		02
09	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	43	04
10	0581019811	33,7 X27 X 398 TUBE		03
11	0581015995	33,7 X 27 X 925 TUBE		01




Item	Code	Description	See page	QT
01	0501214025	33,70 X 27,00 X 1183 TUBE		03
02	0511059383	HANDRAIL INTERNAL FIXER	21	08
03	0581012718	HANDRAIL		03
04	0503011179	3/8" X 2-1/4" BOLT		04
05	0581015996	TUBE 33,7 X 27 X 1131		02
06	0581014429	SHIM HANDRAIL		02
07	0503013357	3/8 SELF-ADJUSTING NUT		04
08	0581015992	33,70 X 27 X 354 TUBE		02
09	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	43	04
10	0581019811	33,7 X27 X 398 TUBE		03
11	0581015995	33,7 X 27 X 925 TUBE		01




Item	Code	Description	See page	QT
01	0531061730	LEFT LADDER		01
02	0502012742	FIXER SUPPORT LADDER		02
03	0503013357	3/8 SELF-ADJUSTING NUT		02
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0503010237	3/8" X 1" BOLT		04
07	0503010025	3/8 SPRING WASHER		04
08	0503010026	3/8" NUT		04
09	0503030403	1.85" X 2.87" BEATER		01




Item	Code	Description	See page	QT
01	0531050959	COMPLETE RIGHT SIDE TURBINE SUPPORT	171	01
02	0521045392	HYDRAULIC TURBINE WITH SCREEN	50	01




Item	Code	Description	See page	QT
01	0531062197	RIGHT SIDE CHASSIS TURBINE SUPPORT		01
02	0501012140	FLAT WASHER		04
03	0503010027	5/8 SPRING WASHER		06
04	0503010013	5/8 NUT		06
05	0571011070	5/8" UNC FASTENER		02
06	0503010232	5/8" X 1.3/4" BOLT		02




Item	Code	Description	See page	QT
01	0531051036	SIDE AIR CONDUCTOR 7 BUTTONS X 500 X 3258	55	01
02	0531051035	COMPLETE MAJOR AIR CONDUCTOR SUPPORT	56	03
03	0521052549	CLAMP	57	07
04	0521052168	SEED HOSE GUIDE	58	02
05	0531051028	SIDE HOSE SUPPORT	59	01




Item	Code	Description	See page	QT
01	0511059943	SUPPORT FASTENER ASSY	63	02
02	0521053025	DUCT SUPPORT OIL	64	01
03	0581018408	SUPPORT SCALE		02
04	0581018415	PROTECTION BODY		04
05	0503011268	3/8" X 2-1/2" BOLT		06
06	0503010025	3/8 SPRING WASHER		06
07	0503010026	3/8" NUT		06
08	0521069850	R.3/4 X 2260 OIL DUCT		02
09	0521069114	OIL DUCT R.7/8 2750		02
10	0521069115	OIL DUCT 3/4 X 2760		01



Item	Code	Description	See page	QT
01	0531062454	WATER TANK SUPPORT		01
02	0521058344	WATER RESERVOIR WITH SOAP	175	01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0503010237	3/8" X 1" BOLT		02
05	0503013357	3/8 SELF-ADJUSTING NUT		02



Item	Code	Description	See page	QT
01	0503014820	BLACK WATER RESERVOIR		01
02	0503019262	SOAP DISH VACUUM		01



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

