

ROW CROP PLANTERS

PST PLUS FLEX SUPREMA PP - FRAME 4045/5345 - CSU/TCE (FROM 08/2022)

Code: 0501093365
Series: S-0116
Revision: 00
Date Revision: AGOSTO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111390047	PST PLUS FLEX SUP PP 4045/9E450 ESPECIAL S-0116
0111390053	PST PLUS FLEX SUP PP 5345/11E500 ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909096454	ASSY FRAME - 4045/5345	1
0511057303	FRAME WITH WHEEL AXLE - 4045	2
0511057382	FRAME WITH WHEEL AXLE - 5345	3
0511057307	PLATFORM ASSEMBLY - 4045	4
0511057385	PLATFORM ASSEMBLY - 5345	5
0531055593	4045 ALPHA FERTILIZER HOPPER SET	6
0531055585	4045 HOPPER SUPPORT WITH ALPHA FERTILIZER METERING	7
0531055595	5345 ALPHA FERTILIZER HOPPER SET	8
0531055588	5345 HOPPER SUPPORT WITH ALPHA FERTILIZER METERING	9
0501053788	3/4 SQUARE AXLE FASTENER	10
0501056271	GEARBOX CLOSED BEARING	11
0531055292	ALPHA FERTILIZER METERING	12
0531055273	ALPHA FERTILIZER METERING CLAMP	13
0531055376	TRANSMISSION ALPHA FERTILIZER METERING HUB	14
0511058827	SINGLE SEED HOPPER - 4045/9 E450	15
0511058828	2 HOPPERS SET WITH 9 CONDUCTORS	16
0511058147	SINGLE SEED HOPPER - 4845/11 E450 - 5345/11 E500	17
0511057919	2 HOPPERS WITH 11 CONDUCTORS SET	18
0511057690	3" ARTICULATED SEED CONDUCTOR	19
0511059323	PLATFORM TRANSPORT SUPPORT	20
0521053445	MONITORING ASSEMBLY PLANTING SEEDS 09L PM400	21
0511058653	WHEELS WITH TRACTION SPRING	22
0511058654	WHEEL SUPPORT	23
0501058241	WHEEL SUPPORT CHAIN TENSIONER	24
0511052770	WHEEL WITH TIRE	25
0503062159	WHEEL WITH TIRE	26
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	27
0501058240	WHEEL FASTENER WITH TENSIONER	28
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	29
0501058244	WHEEL FIXED CHAIN TENSIONER	30
0501058242	WHEEL MOBILE CHAIN TENSIONER	31
0501058239	WHEEL CHAIN TENSIONER BEARING	32
0511056536	LADDER ASSEMBLY	33
0511054971	JACK ASSEMBLY	34
0511054601	HITCH ARTICULATED TRACTOR	35
0511057333	DRAWBAR ASSEMBLY - 3495/4045/4395/4845/5345/5745	36
0511057270	DRAWBAR EXTENDER	37
0511058655	CYLINDER SET - 3245/3495/4045/4395	38
0521045510	HYDRAULIC CYLINDER	39
0511058656	CYLINDER SET - 4845/5345/5745	40
0521054233	HYDRAULIC CYLINDER	41
0511057817	SUPPORT HOSE	42
0511057266	HYDRAULIC SYSTEM ASSEMBLY - 3245/3495/4045/4395	43
0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	44
0501053834	MALE QUICK COUPLER	45
0511053179	TRACTOR COUPLING SHAFT	46
0501050633	ROW MARKER DISK ASSEMBLY	47
0511053904	ROW MARKER DISC	48
0521050143	SET TURBINE 4045/8	49
0511057348	DISTRIBUTOR VACUUM	50
0521053890	MTH PP TURBINE ASSEMBLY	51
0521050016	DISTRIBUTOR AIR RIGHT 06 MOUTHS - 17 E500	52
0521050017	DISTRIBUTOR AIR LEFT 06 MOUTHS - 17 E500	53
0511059887	TURBINE PRECISION PLANTING	54
0521050154	PRECISION PLANTING TURBINE WITH HOLE	55




MARCHESAN

INDEX

0511057846	ASSY HOSE KIT	56
0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	57
0521056505	MANUAL CANISTER ASSY	58
0511057834	LABELS SET - 4045	59
0531051197	LABELS SET FOR HYDRAULIC MARKER - 5345	60
0511059322	LIFTING SUPPORT ASSEMBLY	61
0521059689	TRANSMISSION SET	62
0531051196	TRANSMISSION SET	63
0501052560	MOTOR AXLE SIGNAL	64
0511051434	TRANSMISSION ACTUATOR	65
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	66
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	67
0511057265	TRANSMISSION CHAIN TENSIONER	68
0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	69
0511050652	CHAIN TENSIONER	70
0531053451	BEARING WITH 20Z GEAR 3/4 HEX AXLE	71
0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	72
0531053447	RIGHT GEARBOX SET	73
0531053448	SEMI-ASSEMBLED RIGHT GEARBOX	74
0531053449	LEFT GEARBOX SET	75
0531053450	SEMI-ASSEMBLED LEFT GEARBOX	76
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	77
0501048790	AXLE WITH RING	78
0501056443	GEAR HOUSING BEARING	79
0501056444	BEARING WITH ROLLING	80
0511057258	TENSIONER WITH GEAR	81
0511054363	CHAIN TENSIONER	82
0511057499	HANDRAIL ASSY - 4045	83
0521056507	HANDRAIL ASSEMBLY	84
0511057387	SEMI-ASSEMBLED HYDRAULIC MARKER - 5345	85
0511058449	HYDRAULIC CYLINDER	86
0501054649	HBM SEQUENTIAL VALVE	87
0521055338	ROW SEED BEARING	88
0909096067	SEED/FERTILIZER ROW ASSY	89
0521054984	DEPTH/COMPACTOR SYSTEM - SPT	90
0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	91
0501052297	DEPTH WHEELS REGULATOR ASSY	92
0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	93
0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	94
0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	95
0521055033	SEMI-ASSEMBLED COMPACTOR BODY	96
0501052538	DEPTH BAND WITH ARMS	97
0521055017	RIGHT COMPACTOR WHEEL	98
0521054990	LEFT COMPACTOR WHEEL	99
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	100
0521058524	SEED ROW FRONT	101
0521059692	LONG FRONT SEED ROW	102
0521056941	RIGHT REAR P.P CSU TRANSMISSION/CABLE	103
0521056955	RIGHT DDD ASSY	104
0521056940	LEFT REAR P.P CSU TRANSMISSION CABLE	105
0521056954	LEFT DDD ASSY	106
0521056956	PRECISION PLANTING CSU CABLE/TRANSMISSION ASSY	107
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	108
0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT PROTECTION	109


INDEX

0521056477	SHORT FERTILIZER ROW DC20 WITHOUT LUBRICATION	110
0521056479	LONG DC20 FERTILIZER ROW WITHOUT LUBRICATION	111
0521056476	DC 20" ASSY	112
0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	113
0521053697	CUTTING DISK BOX	114
0521050525	FIXER FERTILIZER CONDUCTOR	115
0531050013	24" BLADE DISC ASSY	116
0531050014	24" BLADE DISC ASSY	117
0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	118
0521055868	RIGHT DUAL FERTILIZER DISC	119
0521054769	LEFT DDD FERTILIZER WITH SUPPORT	120
0521055869	LEFT DUAL FERTILIZER DISC	121
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	122
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	123
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	124
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	125
0521053946	SCARING ROD	126
0521057957	FIXED ROD EXTENSION WITH FIXATION	127




Item	Code	Description	See page	4045	5345
01	0511057303	FRAME WITH WHEEL AXLE - 4045	2	01	00
01.	0511057382	FRAME WITH WHEEL AXLE - 5345	3	00	01
02	0511057307	PLATFORM ASSEMBLY - 4045	4	01	00
02.	0511057385	PLATFORM ASSEMBLY - 5345	5	00	01
03	0531055593	4045 ALPHA FERTILIZER HOPPER SET	6	01	00
03.	0531055595	5345 ALPHA FERTILIZER HOPPER SET	8	00	01
04	0511058827	SINGLE SEED HOPPER - 4045/9 E450	15	01	00
04.	0511058147	SINGLE SEED HOPPER - 4845/11 E450 - 5345/11 E500	17	00	01
05	0511059323	PLATFORM TRANSPORT SUPPORT	20	04	04
06	0521053445	MONITORING ASSEMBLY PLANTING SEEDS 09L PM400	21	01	00
07	0511058653	WHEELS WITH TRACTION SPRING	22	04	04
08	0511056536	LADDER ASSEMBLY	33	02	02
09	0511054971	JACK ASSEMBLY	34	02	02
10	0511054601	HITCH ARTICULATED TRACTOR	35	01	01
11	0511057333	DRAWBAR ASSEMBLY 3495/4045/4395/4845/5345/5745	- 36	01	01
12	0511057270	DRAWBAR EXTENDER	37	01	01
13	0511058655	CYLINDER SET - 3245/3495/4045/4395	38	01	00
13.	0511058656	CYLINDER SET - 4845/5345/5745	40	00	01
14	0501068994	8,30 X 78 LOCK PIN		01	02
15	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01
16	0501047895	ROD STOP		01	02
17	0501047885	ROD STOP		01	02
18	0501047886	ROD STOP		01	02
19	0501047887	ROD STOP		01	02
20	0511057817	SUPPORT HOSE	42	01	01
21	0501065677	STRUT		02	02
22	0503030168	HITCH PIN CLIP		01	02
23	0503032624	FERTILIZER HOPPER GUTTER		05	07


Item	Code	Description	See page	4045	5345
24	0511057266	HYDRAULIC SYSTEM ASSEMBLY - 3245/3495/4045/4395	43	01	00
24.	0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	44	00	01
25	0503010003	1845 GREASE FITTING		04	06
26	0511053179	TRACTOR COUPLING SHAFT	46	01	01
27	0521013022	TRANSPORT LOCK		01	02
28	0501050633	ROW MARKER DISK ASSEMBLY	47	00	02
29	0501214546	SPRING KEY		01	01
30	0521050143	SET TURBINE 4045/8	49	01	00
30.	0521053890	MTH PP TURBINE ASSEMBLY	51	00	01
31	0503010060	1/2" NUT		04	04
32	0521056505	MANUAL CANISTER ASSY	58	01	01
33	0511057834	LABELS SET - 4045	59	01	00
33.	0531051197	LABELS SET FOR HYDRAULIC MARKER - 5345	60	00	01
34	0511059322	LIFTING SUPPORT ASSEMBLY	61	02	02
35	0521059689	TRANSMISSION SET	62	01	00
35.	0531051196	TRANSMISSION SET	63	00	01
36	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		04	04
37	0521014021	1/2" X 4.5" X 5.4" FASTENER		04	04
38	0511017302	FLAT WASHER		08	08
39	0503010019	1/2" SPRING WASHER		04	04
40	0503010780	N-2050 AMENDMENT		02	02
41	0503010951	REDUCTION		04	04
42	0503011750	AMENDMENT WITH LOCK		06	06
43	0503011751	REDUCTION		06	06
44	0511057499	HANDRAIL ASSY - 4045	83	01	00
44.	0521056507	HANDRAIL ASSEMBLY	84	00	01
45	0511057387	SEMI-ASSEMBLED HYDRAULIC MARKER - 5345	85	00	01
46	0521055338	ROW SEED BEARING	88	04	06
47	0571018914	3/4 X 1905 AXLE HEX		01	00
47.	0571018920	3/4 X 2555 AXLE HEX		00	01
48	0571018915	3/4 X 2090 AXLE HEX		01	00
48.	0571018921	3/4 X 2740 AXLE HEX		00	01
49	0511054314	TRANSMISSION AXLE LOCK SLEEVE		22	26
49A	0502012699	TRANSMISSION BOX LOCK SLEEVE		22	26
49B	0503010256	3/8" X 3/4" BOLT		22	26
50	0501053834	MALE QUICK COUPLER	45	01	01
51	0503010045	O'RING		01	01
52	0541010080	TERMINAL R.1 / 2 NPT		01	01
53	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01	01
54	0581013729	NIPLE 1/2 NPT		01	01
55	0503014120	CHAIN		01	01
56	0503014321	CABLE STEEL SHACKLE		02	02
57	0503034867	AIR DITRIBUTOR PUMP		04	05
58	0503010243	CLAMP		04	05
59	0521013164	EXTENSOR		00	02
60	0501011310	FIXER LOCK		00	08
61	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		00	08
62	0503010019	1/2" SPRING WASHER		00	08
63	0503010060	1/2" NUT		00	08
64	0571013990	GUTTER		02	02
65	0571017368	SUPPORT GUTTER		06	06
66	0501011643	3/8 X 1"BOLT		06	06
67	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06	06
68	0503010025	3/8" SPRING WASHER		06	06
69	0503010026	3/8" NUT		06	06
70	0909096067	SEED/FERTILIZER ROW ASSY	89	01	01




Item	Code	Description	See page	QT
01	0521065919	FRAME - 4045		01
02	0521065928	CARRYING-WHEELS PIVOT SHAFT - 4045		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	SCREW		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0521065922	FRAME - 5345		01
02	0521065931	PIVOT SHAFT WHEEL - 5345		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	SCREW		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0571018866	SET PLATFORM 4045		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		16
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0571018869	SET PLATFORM 5345		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		16
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0531055585	4045 HOPPER SUPPORT WITH ALPHA FERTILIZER 7 METERING		01
02	0503062391	FERTILIZER HOPPER		02
03	0503013751	3/8 UNC X 1.1/4 BOLT		16
04	0571019051	FIXER HOPPER WASHER		16
05	0503012535	3/8" SPRING WASHER		16
06	0503012531	3/8" INOX NUT		16
07	0503011957	NYLON LUG		02
08	0503010371	5/16" X 1" BOLT		04
09	0503010179	LOCK WASHER		04
10	0503010337	5/16" NUT		04
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		20
13	0503010025	3/8" SPRING WASHER		10
14	0503010026	3/8" NUT		10




Item	Code	Description	See page	QT
01	0531064281	4045 FERTILIZER HOPPER SUPPORT		01
02	0501053788	3/4 SQUARE AXLE FASTENER	10	08
03	0511061759	22Z P12,70 FQ 3/4" GEAR		02
04	0503030303	SUPPORT WASHER		04
05	0501056271	GEARBOX CLOSED BEARING	11	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER		04
09	0503010337	5/16" NUT		04
10	0531055292	ALPHA FERTILIZER METERING	12	10
11	0503031527	AGRICULTURAL BEARING		06
12	0521013959	3/4" X 30.2" SQUARE SHAFT		02
13	0591019866	SQUARE AXLE 3/4 X 1220		02
14	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		02
14A	0501214269	SQUARE SLEEVE		02
14B	0513010701	LOCK PIN		02




Item	Code	Description	See page	QT
01	0531055588	5345 HOPPER SUPPORT WITH ALPHA FERTILIZER 9 METERING		01
02	0503062362	FERTILIZER HOPPER		03
03	0503013751	3/8 UNC X 1.1/4 BOLT		18
04	0571019051	FIXER HOPPER WASHER		18
05	0503012535	3/8" SPRING WASHER		18
06	0503012531	3/8" INOX NUT		18
07	0503011957	NYLON LUG		02
08	0503010371	5/16" X 1" BOLT		04
09	0503010179	LOCK WASHER		04
10	0503010337	5/16" NUT		04
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		14
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		28
13	0503010025	3/8" SPRING WASHER		14
14	0503010026	3/8" NUT		14




Item	Code	Description	See page	QT
01	0531064284	5345 FERTILIZER HOPPER SUPPORT		01
02	0501053788	3/4 SQUARE AXLE FASTENER	10	08
03	0511061759	22Z P12,70 FQ 3/4" GEAR		02
04	0503030303	SUPPORT WASHER		04
05	0501056271	GEARBOX CLOSED BEARING	11	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER		04
09	0503010337	5/16" NUT		04
10	0531055292	ALPHA FERTILIZER METERING	12	12
11	0503031527	AGRICULTURAL BEARING		06
12	0591018971	SQUARE AXLE 3/4 X 1300		02
13	0551015363	SQUARE AXLE		02
14	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		02
14A	0501214269	SQUARE SLEEVE		02
14B	0513010701	LOCK PIN		02




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0503010025	3/8" SPRING WASHER		04
02	0503010026	3/8" NUT		04
03	0513010742	RETAINER 47 X 30 X 10 BRG 5285		01
04	0501214879	HORIZONTAL SEAL COVER ALPHA FERTILIZER METERING		01
05	0503035799	ALPHA FERTILIZER DOSAGE NOZZLE		01
06	0503035831	ALPHA FERTILIZER METERING COLLECTOR		01
07	0531055273	ALPHA FERTILIZER METERING CLAMP	13	01
08	0513010692	ALLEN SCREW 1/4 UNC X 7/8 C FLAT SI INOX		04
09	0501011643	3/8 X 1"BOLT		04
10	0503035796	REAR FIXER ALPHA FERTILIZER METERING COLLECTOR		02
11	0513010695	ALLEN SCREW 1/4 UNC X 7/8 CCSI INOX		04
12	0531055376	TRANSMISSION ALPHA FERTILIZER METERING 14 HUB		01
13	0502013049	ALPHA FERTILIZER DOSAGE HOPPER		01
14	0502013048	FLANGE FIXER BODY ALPHA FERTILIZER METERING		01
15	0501111134	COVER WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
15A	0503063799	COVER WITH FERTILIZER METERING WASHER ALPHA		01
15B	0503035822	GUIDE GLOVE SPRING CONDUCTOR FERTILIZER METERING ALPHA		01
16	0503035829	ADHESIVE LABEL LOGO TATU 38 X 28 X 0.30 ALPHA FERTILIZER METERING		01
17	0531055518	WORM THREAD ASSEMBLED		01
17A	0531064265	WORM THREAD		01
17B	0503035859	SUPPORT SLEEVE		01
18	0501111143	COATING WITH GUIDE ASSY SUPPLEMENTATION FERTILIZER METERING		01
18A	0501214951	FERTILIZER DOSAGE COATING		01
18B	0531055519	GUIDE ASSY WITH SUPPLEMENTATION		01




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0502013050	TRANSMISSION ALPHA FERTILIZER METERING HOPPER		01
02	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
03	0503011800	SEAL RING		02
04	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
05	0503016065	ROLLER BEARING		02
06	0501214237	TRANSMISSION HOPPER ALPHA FERTILIZER METERING SLEEVE		01
07	0503019373	6006 2RS1 NATIONAL BEARING		02
08	0503012858	502075 CLAMPING RING (FOR HOLE)		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01
10	0501214501	ALPHA FERTILIZER METERING COVER LOCK AXIS		01
11	0501214238	SHAFT LOCK SLEEVE HOPPER TRANSMISSION ALPHA FERTILIZER METERING		01
12	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01




Item	Code	Description	See page	QT
01	0511058828	2 HOPPERS SET WITH 9 CONDUCTORS	16	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0571019393	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16
15	0521066211	PROTECTOR CENTRAL		01
16	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
17	0501013519	FLAT WASHER		04
18	0503010019	1/2" SPRING WASHER		04
19	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521064748	05 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503061987	05 NOZZLES FERTILIZER HOPPER		02
03	0521063401	SINGLE SEED HOPPER FIXING LOCK		04
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	19	09
08	0501010942	3/8" X 1-1/4" BOLT		36
09	0503010025	3/8" SPRING WASHER		36
10	0503010026	3/8" NUT		36
11	0571015773	SUPPORT SEED		01
12	0501011643	3/8 X 1"BOLT		04
13	0503010025	3/8" SPRING WASHER		04
14	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0511057919	2 HOPPERS WITH 11 CONDUCTORS SET	18	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0571019395	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16
15	0521066211	PROTECTOR CENTRAL		01
16	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
17	0501013519	FLAT WASHER		04
18	0503010019	1/2" SPRING WASHER		04
19	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521063401	SINGLE SEED HOPPER FIXING LOCK		04
02	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR	19	11
06	0571015773	SUPPORT SEED		03
07	0501011643	3/8 X 1"BOLT		12
08	0501010942	3/8" X 1-1/4" BOLT		44
09	0521064874	07 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01



Item	Code	Description	See page	QT
01	0581011989	SIDE BODY FIXER PLATFORM		01
02	0551019884	45 X 50 X 3/8 FASTENER		01
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
07	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0503062794	SEED MONITORING KIT 9L 45/50 PM400		01
01A	0503016555	9 ROW SIMPLE MONITOR CABLE		01
01B	0503019100	SENSOR		09
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		45
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		**
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0511058654	WHEEL SUPPORT	23	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	28	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01

WHEEL SUPPORT


0511058654




Item	Code	Description	See page	QT
01	0521066716	WHEEL ARM ASSY		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
08	0503010027	5/8" SPRING WASHER		01
09	0501058241	WHEEL SUPPORT CHAIN TENSIONER	24	01
10	0503013030	5/8" X 3.1/4" BOLT		01
11	0551017715	FLAT WASHER		02
12	0511052770	WHEEL WITH TIRE	25	01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8" SPRING WASHER		02
15	0503011167	M16 X 2 X 30 BOLT		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	26	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	27	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	29	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	30	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	31	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	32	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	32	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	32	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0502012806	SUPPORT REAR FIXER DRAWBAR		04
02	0502012789	FIXER SUPPORT FERTILIZER ROW		04
03	0503017960	5/8" X 3-12" BOLT		16
04	0503010811	5/8" UNF SELF ADJUSTING NUT		16
05	0501010191	1" X 6" BOLT		04
06	0503010012	1" SPRING WASHER		04
07	0501010059	1.5/8 NUT		04
08	0502012805	SUPPORT FRONT FIXER DRAWBAR		04
09	0502012789	FIXER SUPPORT FERTILIZER ROW		04
10	0503017960	5/8" X 3-12" BOLT		16
11	0503010811	5/8" UNF SELF ADJUSTING NUT		16
12	0521065958	DRAWBAR		01
13	0561019087	DRAWBAR TRANSPORT LOCK		01
14	0551014099	COUPLING SHAFT 31,75 X 185		01
15	0521010544	1.2" X 4.9" COUPLING SHAFT		01
16	0503030085	LOCK PIN		02
17	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521065959	JACK R.1.1/2 UNC RIGHT X 240		01
03	0521065960	JACK R.1.1/2 UNC LEFT X 240		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521045510	HYDRAULIC CYLINDER	39	01
02	0551014099	COUPLING SHAFT 31,75 X 185		01
03	0521010547	1.2" X 6.5" COUPLING SHAFT		01
04	0503010523	1/4" X 2" COTTERPIN		02
05	0501047888	ROD STOP		01




Item	Code	Description	See page	QT
01	0521065976	SHIRT 127 X 438,5		01
02	0581013698	PISTON		01
03	0521067585	EXTENDER 50.80 X 371.5 WITH BUSHING		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010003	1845 GREASE FITTING		01
06	0503030385	CYLINDER PLUG N-002		02
07	0503018439	WIPER SEAL		01
08	0503018150	RING GUIDE		01
09	0502010382	5" END CAP		01
10	0581010353	RING SUPPORT		01
11	0503018026	1870-2000-375 B GASKET		01
12	0503011453	O'RING		02
13	0503018152	O'RING		02
14	0503018024	RING BS		01
15	0503018025	RING GUIDE		01
16	0503010039	D-2000 SCRAPER RING		01
17	0503010173	2-220 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0521054233	HYDRAULIC CYLINDER	41	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521010547	1.2" X 6.5" COUPLING SHAFT		02
04	0503010523	1/4" X 2" COTTERPIN		04
05	0501047888	ROD STOP		02
06	0571019384	SPACING SLEEVE 16,30 X 30 X 104		02
07	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		02
08	0503010027	5/8" SPRING WASHER		02
09	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0521069306	50.8 X 337.5 EXTENSION WITH 32.5 BUSHING		01
02	0521069305	SHIRT 101.6 X 438.5		01
03	0503030385	CYLINDER PLUG N-002		02
04	0503010004	1890 GREASE FITTING		01
05	0502012821	50.80 X 101.60 RING SUPPORT		01
06	0503011061	8-342 BACK-UP RING		02
07	0503018024	RING BS		01
08	0503010338	2-342 N 3006-9B O'RING		02
09	0503018026	1870-2000-375 B GASKET		01
10	0503018025	RING GUIDE		01
11	0503010039	D-2000 SCRAPER RING		01
12	0502012822	101.60 END CAP		01
13	0502012842	50,80 X 101,60 PISTON		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503018029	2-217 O'RING		01
16	0503015633	SELEMASTER SEALING		01




Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0511057267	HOSE KIT HYDRAULIC		01
01A	0501080722	3/8 X 3300 TC-TM HOSE ASSY		01
01B	0501082023	HOSE 3/8 X 3600 TC-TM		01
02	0501053834	MALE QUICK COUPLER	45	02
03	0503013100	NYLON CLAMP		02
04	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0511057335	HOSE KIT HYDRAULIC		01
01A	0501080025	3/8 X 1400 TR-TC HOSE		04
01B	0521052285	TC-TM HOSE ASSY		01
01BA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01BD	0503018952	PLASTIC BOLT		06
01C	0521052330	HOSE 3/8 X 4000 TC-TM PRET/AZUL		01
01CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01CB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01CC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01CD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	45	02
03	0511058120	KIT VALVE SUPPORT		01
03A	0521066354	OIL DISTRIBUTOR BODY		02
03B	0502010477	HOSE CLAMP		04
03C	0503011268	3/8" X 2-1/2" BOLT		02
03D	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
03E	0503010025	3/8" SPRING WASHER		02
03F	0503010026	3/8" NUT		02
04	0503013100	NYLON CLAMP		02
05	0502012702	BODY SUPPORT CLAMP		04
06	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
07	0503010180	7/16" SPRING WASHER		04
08	0531011180	UPPER BODY CLIP		04
09	0571017774	SPRING PROTECTION QUICK HOSE		01



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	48	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01

ROW MARKER DISC


0511053904




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	COVER DEPTH		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0581012111	RIGHT SUPPORT		01
02	0581012112	LEFT SUPPORT		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2" NUT		04
06	0581012166	HOSE		02
07	0503011372	102 TO 121 CLAMP		04
08	0511057348	DISTRIBUTOR VACUUM	50	02
09	0503031436	AIR DISTRIBUTOR PUMP		01
10	0503010246	CLAMP		01
11	0571019403	STAPLE FIXER		04
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
13	0503010025	3/8" SPRING WASHER		08
14	0503010026	3/8" NUT		08
15	0571013731	VACUUM GAUGE SUPPORT		01
16	0503013584	VACUUM GAUGE		01
17	0511057846	ASSY HOSE KIT	56	01
17A	0501080850	3/8" X 6100 TC-TM HOSE		01
17B	0501081810	HOSE 1/2 X 6200 TC-TM		02
17C	0501053834	MALE QUICK COUPLER	45	02
17D	0581012991	SPRING PROTECTION PLASTIC HOSE		01
17E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	57	01
18	0511059887	TURBINE PRECISION PLANTING	54	01
19	0503031576	ELBOW		02
20	0571019716	ADAPTER		08
21	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		08




Item	Code	Description	See page	QT
01	0571017215	SOCKET DISTRIBUTOR AR		01
02	0503012566	COVER KAP 110 YELLOW		01
03	0503031943	SOCKET		05
04	0503012856	POP RIVET		10
05	0571019405	BODY DISTRIBUTOR VACUUM 4845/5345		01




Item	Code	Description	See page	QT
01	0581012111	RIGHT SUPPORT		01
02	0581012112	LEFT SUPPORT		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2" NUT		04
06	0561011377	HOSE 4 X 2200		02
07	0503011372	102 TO 121 CLAMP		02
08	0521050016	DISTRIBUTOR AIR RIGHT 06 MOUTHS - 17 E500	52	01
09	0521050017	DISTRIBUTOR AIR LEFT 06 MOUTHS - 17 E500	53	01
10	0503034867	AIR DITRIBUTOR PUMP		01
11	0503010243	CLAMP		01
12	0571019403	STAPLE FIXER		04
13	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
14	0503010025	3/8" SPRING WASHER		08
15	0503010026	3/8" NUT		08
16	0571019552	SUPPORT VACUUM		01
17	0503013584	VACUUM GAUGE		01
18	0571019712	AIR CONDUCTOR		11
19	0511059887	TURBINE PRECISION PLANTING	54	01
20	0511057846	ASSY HOSE KIT	56	01
21	0521052549	CLAMP		22




Item	Code	Description	See page	QT
01	0581013131	AIR DISTRIBUTOR BODY		01
02	0503017845	PVC KNEE 90 SOLD AVEL		01
03	0571018559	WHITE PVC TUBE		01
04	0503031943	SOCKET		06
05	0503012856	POP RIVET		12
06	0503012566	COVER KAP 110 YELLOW		01
07	0521015543	DUTO 110 X 55		01




Item	Code	Description	See page	QT
01	0581013131	AIR DISTRIBUTOR BODY		01
02	0503017845	PVC KNEE 90 SOLD AVEL		01
03	0571018559	WHITE PVC TUBE		01
04	0503031943	SOCKET		06
05	0503012856	POP RIVET		12
06	0503012566	COVER KAP 110 YELLOW		01
07	0521015543	DUTO 110 X 55		01




Item	Code	Description	See page	QT
01	0521050154	PRECISION PLANTING TURBINE WITH HOLE	55	01
02	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
03	0501011460	7/8 NF REDUCTION NIPPLE		04
04	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
05	0503010392	2-046 N 3006 9B O'RING		01
06	0503010190	2-114 N 3006-9B O'RING		04
07	0501080218	1/2 X 750 HOSE		01
08	0581012096	ROUND SLEEVE		02
09	0503031087	ADHESIVE LABEL		01
10	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01



Item	Code	Description	See page	QT
01	0511057847	ASSY HOSE TURBINE		01
01A	0521052531	3/8 X 6108 TC-TM HOSE YELLOW / GREEN		01
01AA	0501080850	3/8" X 6100 TC-TM HOSE		01
01AB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01AC	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052528	1/2 X 6200 TC-TM HOSE YELLOW / RED		01
01BA	0501081810	HOSE 1/2 X 6200 TC-TM		01
01BB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01BD	0503018952	PLASTIC BOLT		06
01C	0521052529	1/2 X 6200 TC-TM HOSE YELLOW / BLUE		01
01CA	0501081810	HOSE 1/2 X 6200 TC-TM		01
01CB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01CC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01CD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	45	02
03	0581012991	SPRING PROTECTION PLASTIC HOSE		01
04	0503033981	ADHESIVE LABEL		01
05	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	57	01



Item	Code	Description	See page	QT
01	0503018799	QUICK COUPLING		01
02	0503011883	QUICK CONNECTION COVER		01




Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0503034228	ADHESIVE LABEL PST FLEX PLUS LOWER (05 NOZZLES)		02
02	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		02
03	0503033892	ADHESIVE LABEL LOGO TATU BOX 190 X 720		01
04	0503034258	ADHESIVE LABEL		01
05	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
07	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
08	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	ADHESIVE LABEL		01
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
12	0503031565	ADHESIVE LABEL CARE		02
13	0503031566	ADHESIVE LABEL		02
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
15	0503031425	ADHESIVE LABEL ATTENTION		02
16	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
17	0503031669	ADHESIVE LABEL		01
18	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
19	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503032930	ADHESIVE LABEL DANGER		05
21	0503031087	ADHESIVE LABEL		01
22	0503034003	SERIAL NUMBER TAG 61 X 118		01
23	0503010001	3.2 X 5.5 RIVET		04
24	0503032979	ADHESIVE LABEL LETTERS A B C D		02
25	0503034500	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0503034116	ADHESIVE LABEL		01
02	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530		02
03	0503033892	ADHESIVE LABEL LOGO TATU BOX 190 X 720		01
04	0503034257	ADHESIVE LABEL		01
05	0503033417	ADHESIVE LABEL		02
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
07	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		04
08	0503031428	READ MANUAL DECAL		01
09	0503031942	ADHESIVE LABEL		01
10	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
11	0503031565	ADHESIVE LABEL CARE		02
12	0503031566	ADHESIVE LABEL		02
13	0503034249	ADHESIVE LABEL TABLE PLANTS		02
14	0503031425	ADHESIVE LABEL ATTENTION		02
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503032930	ADHESIVE LABEL DANGER		06
19	0503031087	ADHESIVE LABEL		01
20	0503034003	SERIAL NUMBER TAG 61 X 118		01
21	0503010001	3.2 X 5.5 RIVET		04
22	0503032979	ADHESIVE LABEL LETTERS A B C D		02
23	0503034500	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521067033	FRAME LIFTING SUPPORT		01
03	0503017960	5/8" X 3-12" BOLT		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2" NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2" NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	24	04
13	0571018906	AXLE MOTOR 1950		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	64	02
16	0511051434	TRANSMISSION ACTUATOR	65	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	66	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	67	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		04
20	0501053788	3/4 SQUARE AXLE FASTENER	10	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING	11	02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
25	0503010025	3/8" SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	68	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
30	0503010140	1/8" X 3/4" COTTERPIN		02
31	0571018846	DISASSEMBLE LEVER		02

TRANSMISSION SET

0521059689

Item	Code	Description	See page	QT
32	0503033942	COVER REGULATORY WHEEL		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012407	5/8" X 1-1/2" BOLT		04
37	0503012412	5/8 UNC SELF LOCKING NUT		04
38	0531053449	LEFT GEARBOX SET	75	01
39	0501053788	3/4 SQUARE AXLE FASTENER	10	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING	11	02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
44	0503010025	3/8" SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	68	02
47	0511061757	18Z GEAR		02
48	0501053788	3/4 SQUARE AXLE FASTENER	10	02
49	0503030303	SUPPORT WASHER		02
50	0503010292	0.2" X 1.6" SPRING PIN		02
51	0521018630	1.4" X SQUARE 0.8" WASHER		02
52	0501056271	GEARBOX CLOSED BEARING	11	02
53	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
54	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
55	0503010025	3/8" SPRING WASHER		04
56	0503010026	3/8" NUT		04
57	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	69	02
58	0511050652	CHAIN TENSIONER	70	04
59	0531053451	BEARING WITH 20Z GEAR 3/4 HEX AXLE	71	02
60	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
61	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
62	0503013149	40-1 CHAIN X 157 LINK + MENDING + RED		02
63	0531062318	LEFT/RIGHT LOWER LEVER		02
64	0551019159	LEVER FIXER BODY		02
65	0561016468	FASTENER		02
66	0503011336	1/2" HEX SELF ADJUSTING NUT		04
67	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
68	0503010140	1/8" X 3/4" COTTERPIN		04
69	0531053447	RIGHT GEARBOX SET	73	01




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2" NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2" NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	24	04
13	0571018909	MOTOR SHAFT 2600		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	64	02
16	0511051434	TRANSMISSION ACTUATOR	65	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	66	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	67	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		04
20	0501053788	3/4 SQUARE AXLE FASTENER	10	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING	11	02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
25	0503010025	3/8" SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	68	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
30	0503010140	1/8" X 3/4" COTTERPIN		02
31	0571018846	DISASSEMBLE LEVER		02


TRANSMISSION SET

0531051196


Item	Code	Description	See page	QT
32	0503033942	COVER REGULATORY WHEEL		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
37	0503012412	5/8 UNC SELF LOCKING NUT		04
38	0531053449	LEFT GEARBOX SET	75	01
39	0501053788	3/4 SQUARE AXLE FASTENER	10	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING	11	02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
44	0503010025	3/8" SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	68	02
47	0511061757	18Z GEAR		02
48	0501053788	3/4 SQUARE AXLE FASTENER	10	02
49	0503030303	SUPPORT WASHER		02
50	0503010292	0.2" X 1.6" SPRING PIN		02
51	0521018630	1.4" X SQUARE 0.8" WASHER		02
52	0501056271	GEARBOX CLOSED BEARING	11	02
53	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
54	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
55	0503010025	3/8" SPRING WASHER		04
56	0503010026	3/8" NUT		04
57	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	69	02
58	0511050652	CHAIN TENSIONER	70	04
59	0531053451	BEARING WITH 20Z GEAR 3/4 HEX AXLE	71	02
60	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
61	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
62	0503013149	40-1 CHAIN X 157 LINK + MENDING + RED		02
63	0531062318	LEFT/RIGHT LOWER LEVER		02
64	0551019159	LEVER FIXER BODY		02
65	0561016468	FASTENER		02
66	0503011336	1/2" HEX SELF ADJUSTING NUT		04
67	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
68	0503010140	1/8" X 3/4" COTTERPIN		04
69	0531053447	RIGHT GEARBOX SET	73	01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		03
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0541011713	TENSIONER CHAIN LOWER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0551019171	CHAIN TIGHTENER AXLE		01
02	0503011410	ROLLER BEARING		01
03	0511062169	21Z P 1/2" GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503011105	SEAL RING		01
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0571010265	16.5 X 40 X 3 FLAT WASHER		01
08	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	72	01
02	0531063199	32Z GEAR WITH HEX AXLE		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010365	NUT		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02
07	0501010694	FLAT WASHER		04
08	0501013518	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		02
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01

RIGHT GEARBOX SET

0531053447



Item	Code	Description	See page	QT
01	0531053448	SEMI-ASSEMBLED RIGHT GEARBOX	74	01
02	0521065955	RH GEAR BOX COVER		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0503010019	1/2" SPRING WASHER		01
07	0501010694	FLAT WASHER		06
08	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521065939	RIGHT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN AXLE CONE		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2" NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	77	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING	11	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TENSIONER LEVER		02
18	0503010004	1890 GREASE FITTING		02
19	0501048790	AXLE WITH RING	78	02
20	0503031366	RIGHT TWISTED SPRING RECAMBIO		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511064536	28Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	79	01
31	0503010292	0.2" X 1.6" SPRING PIN		08


Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	81	01
33	0511054363	CHAIN TENSIONER	82	01
34	0571018901	DRIVEN AXLE		01
35	0511061757	18Z GEAR		01

LEFT GEARBOX SET

0531053449




Item	Code	Description	See page	QT
01	0531053450	SEMI-ASSEMBLED LEFT GEARBOX	76	01
02	0521065956	LH GEAR BOX COVER		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0503010019	1/2" SPRING WASHER		01
07	0501010694	FLAT WASHER		06
08	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521065940	LEFT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN AXLE CONE		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2" NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	77	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING	11	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TENSIONER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	78	02
20	0503031367	SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511064536	28Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	79	01
31	0503010292	0.2" X 1.6" SPRING PIN		08


Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	81	01
33	0511054363	CHAIN TENSIONER	82	01
34	0571018901	DRIVEN AXLE		01
35	0511061757	18Z GEAR		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING	80	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0571019207	DEVIATION AXLE GEAR BOX		01
06	0503010899	5/8" X 2-1/4" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01



Item	Code	Description	See page	QT
01	0521065950	HANDRAIL		02
02	0503010752	1/2" X 3.1/2" BOLT		08
03	0511017302	FLAT WASHER		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08




Item	Code	Description	See page	QT
01	0521065953	HANDRAIL FRAME 5345		02
02	0503010752	1/2" X 3.1/2" BOLT		08
03	0511017302	FLAT WASHER		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0581012916	INTERMEDIATE TUBE		02
07	0511059383	HANDRAIL INTERNAL FIXER		04




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8 UNC SELF LOCKING NUT		06
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0511058449	HYDRAULIC CYLINDER	86	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" COTTERPIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501066949	1235 TURNBUCKLE		02
21	0503011854	5/8" X 1-1/4" BOLT		04
22	0501054649	HBM SEQUENTIAL VALVE	87	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
25	0503010025	3/8" SPRING WASHER		02
26	0511057383	HOSE KIT MARKER HYDRAULIC		01
26A	0501080403	3/8" X 137" TR-TR HOSE ASSY		02
26B	0501080390	3/8" X 150" TR-TC HOSE ASSY		02
26C	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
26CA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
26CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01


Item	Code	Description	See page	QT
26CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
26CD	0503018952	PLASTIC BOLT		06
26D	0521052850	3/8 X 4200 TC-TM PURPLE/BLUE HOSE		01
26DA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
26DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26DD	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	45	02
28	0502012702	BODY SUPPORT CLAMP		06
29	0531011180	UPPER BODY CLIP		04
30	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		06
31	0503010180	7/16" SPRING WASHER		06
32	0503010244	7/16" NUT		02
33	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
34	0581010011	VALVE FIXING SUPPORT		01




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01



Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING		01
03A	0502012030	HOUSING BEARING		01
03B	0503012861	6006 2RS BALL BEARING		01
03C	0503012858	502075 CLAMPING RING (FOR HOLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02
07	0501013518	FLAT WASHER		02
08	0501010694	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521054984	DEPTH/COMPACTOR SYSTEM - SPT	90	01
02	0521058524	SEED ROW FRONT	101	01
03	0521059692	LONG FRONT SEED ROW	102	01
04	0521056941	RIGHT REAR P.P CSU TRANSMISSION/CABLE	103	01
05	0521056940	LEFT REAR P.P CSU TRANSMISSION CABLE	105	01
06	0521059698	ASSY JOINT TCE		01
07	0521059699	ASSY JOINT TCE		01
08	0521056477	SHORT FERTILIZER ROW DC20 WITHOUT LUBRICATION	110	01
09	0521056479	LONG DC20 FERTILIZER ROW WITHOUT LUBRICATION	111	01
10	0503031145	2" X 2" X 20" HOSE		01
11	0503031076	2" HOSE CLAMP		01
12	0521050525	FIXER FERTILIZER CONDUCTOR	115	01
13	0531013600	PRESS ADJUSTMENT LEVER		01
14	0521069127	BOTTOM NOZZLE FERTILIZER		01
15	0503031050	CURVED CONDUCTOR		01
16	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
17	0521068982	KEY CASH DISC CUTTING		01
18	0503010246	CLAMP		01
19	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
20	0503010025	3/8" SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
23	0531050013	24" BLADE DISC ASSY	116	01
24	0571011730	SEED CONDUCTOR 3" X 1500		01
25	0521054769	LEFT DDD FERTILIZER WITH SUPPORT	120	01
26	0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	118	01
27	0503030391	RIGHT FERTILIZER NOZZLE		01
28	0503030392	LEFT FERTILIZER NOZZLE		01
29	0521053946	SCARING ROD	126	01




Item	Code	Description	See page	QT
30	0503030483	FERTILIZER SOCKET		01
31	0511017969	0.1" SPACING PLATE		01
32	0511018662	SPACING PLATE		01
33	0521057957	FIXED ROD EXTENSION WITH FIXATION	127	01




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	91	01
02	0501052538	DEPTH BAND WITH ARMS	97	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL	99	01
06	0521055017	RIGHT COMPACTOR WHEEL	98	01




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	92	01
02	0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	93	01
03	0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	94	01
04	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	96	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	SCREW 3/8 UNC X 3/4		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED SLEEVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	95	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	95	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL BOX		01
02	0581019515	AXIS		01
03	0503034055	CLAMPING RING		01
04	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50		01
05	0503013758	1/4" X 1-1/2" BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0503010878	5/8" SELF ALIGNING NUT		01
10	0503030757	2.9" X 2" X 0.02" JOINT		01
11	0521019178	COVER DEPTH		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT SLEEVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	100	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	100	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
04	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN	02	
05	0502012812	SEED ROW ADJUSTMENT LEVER ASSY	01	
06	0503034198	SPRING TRACTION 40 X 198 X 5,5	01	
07	0571018883	PIN FIXER SPRING	03	
08	0503030168	HITCH PIN CLIP	04	
09	0501012140	FLAT WASHER	04	
10	0503017857	BOLT 5/8 UNF 4	04	
11	0591011156	PIVOT ARM SEED ROW	02	
12	0591011157	SPACER LOWER SLEEVE	04	
13	0503019273	AUTO LUBRICANT GLOVE	08	
14	0503010045	O'RING	08	
15	0531061528	REAR LINE SUPPORT	01	
16	0591012829	SPACER LOWER SLEEVE	04	
17	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	02	
18	0503013389	5/8" SELF LOCKING NUT	04	
19	0591011409	FLAT WASHER 16,5 X 35 X 3,00	04	
20	0591012828	LOCK PIN ROW ARTICULAT	01	




Item	Code	Description	See page	QT
001	0531061136	EXTENSION		01
002	0503012136	NUT 1/2 NF		04
003	0503010311	1/2" X 1-1/4" BOLT		04
004	0521058524	SEED ROW FRONT	101	01



Item	Code	Description	See page	QT
01	0521056955	RIGHT DDD ASSY	104	01
02	0503062403	TUBE SEED P.P		01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0521056956	PRECISION PLANTING CABLE/TRANSMISSION ASSY	CSU 107	01
06	0503012136	NUT 1/2 NF		04
07	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04




Item	Code	Description	See page	QT
01	0591011773	RIGHT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 124 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 122 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521056954	LEFT DDD ASSY	106	01
02	0503062403	TUBE SEED P.P		01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0521056956	PRECISION PLANTING CABLE/TRANSMISSION ASSY	CSU 107	01
06	0503012136	NUT 1/2 NF		04
07	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04

LEFT DDD ASSY


0521056954




Item	Code	Description	See page	QT
01	0591011772	LEFT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 124 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 122 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0502012924	PRECISION PLANTING SUPPORT		01
02	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
03	0503010589	1/2" UNC SELF ADJUSTING NUT		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0571014024	FAST BOLT GUIDE AXLE		01
06	0503034824	FIXATIVE		01
07	0503010293	CLAMP KNOB		01
08	0503010025	3/8" SPRING WASHER		06
09	0502012922	FIXING SUPPORT		01
10	0503011404	BOLT		01
11	0503013357	3/8" SELF-ADJUSTING NUT		01
12	0503010026	3/8" NUT		04
13	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04
14	0571019491	SLUICE PNEUMATIC PRECISION PLANTING		01
15	0501011643	3/8 X 1" BOLT		01
16	0503010209	3/8" UNC BUTTERFLY NUT		01
17	0502012807	SUPPORT HOPPER PRECISION PLANTING		01
18	0571019489	CLAMP PRECISION PLANTING		01
19	0503012721	1/4" X 4" BOLT		01
20	0503012880	1/4" UNC SELF ADJUSTING NUT		01
21	0503818139	BOLT		03
22	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
23	0503015110	M06 SPRING WASHER		02
24	0503037390	PACKING FOR PLANTING		01
25	0503010179	LOCK WASHER		04
26	0503011953	5/16" X 1" BOLT		03
27	0503010337	5/16" NUT		04
28	0503012163	5/16" X 1-1/2" BOLT		01
29	0581011226	FIXER CLOSING P PLANTING CONTR CPRA		01
30	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 108 DISC		01
31	0521066707	FEEDER		01




Item	Code	Description	See page	QT
01	0571019613	STRAW PRECISION PLANTING SHIELD		01
02	0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT PROTECTION	109	01




Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
01A	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0503011255	3/4" LOCK NUT		02
03	0571019062	SLEEVE		01
04	0571019059	SUPPORT WASHER		01
05	0503034320	COMPRESSSION SPRING		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503011854	5/8" X 1-1/4" BOLT		02
08	0511016281	3/4" X 8" BOLT		02
09	0503017960	5/8" X 3-12" BOLT		04
10	0502012813	FLANGE WASHER SPRING		01
11	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
12	0503010417	7/8" NUT		02
13	0502012789	FIXER SUPPORT FERTILIZER ROW		01
14	0521056476	DC 20" ASSY	112	01
15	0503011254	7/8" HEX SELF ADJUSTING NUT		01
16	0591011145	FERTILIZER ROW SUPPORT		01
17	0503019278	LUBRICANT SLEEVE		02
18	0591011147	SLEEVE ARM ROW		02
19	0503011109	2-119 N 3006-9B O'RING		02



Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
01A	0511057271	RH LONG ARM ROW FERTILIZER		01
02	0503011255	3/4" LOCK NUT		02
03	0571019062	SLEEVE		01
04	0571019059	SUPPORT WASHER		01
05	0503034320	COMPRESSSION SPRING		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503011854	5/8" X 1-1/4" BOLT		02
08	0511016281	3/4" X 8" BOLT		02
09	0503017960	5/8" X 3-12" BOLT		04
10	0502012813	FLANGE WASHER SPRING		01
11	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
12	0503010417	7/8" NUT		02
13	0502012789	FIXER SUPPORT FERTILIZER ROW		01
14	0521056476	DC 20" ASSY	112	01
15	0503011254	7/8" HEX SELF ADJUSTING NUT		01
16	0591011146	SUPPORT LONG		01
17	0503019278	LUBRICANT SLEEVE		02
18	0591011147	SLEEVE ARM ROW		02
19	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0571019034	FLANGE WASHER AXLE		01
02	0571019032	SUPPORT WASHER		01
03	0502012813	FLANGE WASHER SPRING		01
04	0591010619	DC SPRING SUPPORT		01
05	0503019274	WASHER		02
06	0581017628	COVER		02
07	0503019277	SLEEVE LUBRICATION SYSTEM		01
08	0501110964	RIGHT ARM WITH SLEEVE		01
09	0501110965	LEFT ARM WITH SLEEVE		01
10	0503034320	COMPRESSION SPRING		01
11	0591010624	SUPPORT ARM SLEEVE		01
12	0591010625	19,50 X 25 X 91,50/91,30 SLEEVE		01
13	0503010417	7/8" NUT		02
14	0503010390	SEAL RING		02
15	0503011198	C3/4" X 6" SCREW		01
16	0501010322	FLAT WASHER		01
17	0503011411	1/2" X 5-1/2" BOLT		01
18	0503010060	1/2" NUT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503011255	3/4" LOCK NUT		01
21	0503030430	7/16 X 2" PIN LOCK		01
22	0503019271	SELF LUBRICATING BUSHING		01
23	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	113	01
24	0503011254	7/8" HEX SELF ADJUSTING NUT		01
25	0521066743	REGULACION SPRING		01
26	0591011144	FIXATION AXLE		01
27	0591010628	DC AXIS BACKREST WASHER		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	CUTTING DISK BOX	114	01

CUTTING DISK BOX

0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4	01	
02	0502040872	REGULATORY NUT	01	
03	0503010370	502072 CLAMPING RING (FOR AXLE)	02	
04	0503010590	00674-B SEAL	02	
05	0503019285	RING	02	
06	0503012170	30207 ROLLER BEARING	02	
07	0502020641	BLADE DISC FLANGE	01	
08	0502012862	CUTTING DISK BOX	01	
09	0502040873	CUTTING DISC AXLE	01	
10	0503017755	NUT	01	
11	0503018825	5/16 UNC UNC BOLT	06	
12	0501010694	FLAT WASHER	06	
13	0503013816	5/16" LOCKNUT	06	
14	0511017907	1/8" BSPT X 6 PLUG	02	




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	NUT		02

24" BLADE DISC ASSY


0531050013




Item	Code	Description	See page	QT
01	0561015334	BLADE DISC AXLE ASSY		01
02	0561015610	FLAT WASHER		01
03	0503010361	SPRING PIN		01
04	0503010756	0.2" X 2.4" SPRING PIN		01
05	0503010571	1/4" X 1.1/2 COTTERPIN		01
06	0501069390	SPRING ROD		01
07	0503031346	COMPRESSION SPRING		01
08	0561015400	BLADE DISC SPRING GUIDE		01
09	0501010059	1.5/8 NUT		02
10	0561019515	COUPLING SHAFT		01
11	0501069637	AXLE NUT LOCK		02
12	0503010962	5/8" X 1-1/4" BOLT		02
13	0503011445	SPRING WASHER		02
14	0521068106	BLADE DISC FORK		01
15	0591016286	SPACING SLEEVE		02
16	0503019271	SELF LUBRICATING BUSHING		01
17	0521068107	SWIVEL BASE		01
18	0503019277	SLEEVE LUBRICATION SYSTEM		02
19	0591016342	CUTTING DISC AXLE		01
20	0591016288	LOCK WASHER		01
21	0503010023	3/4" SPRING WASHER		01
22	0501010098	3/4" UNC BOLT		01
23	0531050014	24" BLADE DISC ASSY	117	01




Item	Code	Description	See page	QT
001	0603030044	24" X 0.2" FLAT PLAIN DISC		01
002	0521011824	BLADE DISC FLANGE OUTER		01
003	0501010087	1.1/4" NUT		02
004	0503010060	1/2" NUT		16
005	0503010905	1/2" X 2-1/4" BOLT		08
006	0501017779	32 X 60 X 4.75 FLAT WASHER		02
007	0531050015	DISC HUB		01
007A	0521012661	BLADE DISC AXLE HUB		01
007B	0503011291	6209 BALL BEARING		02
007C	0502011477	BLADE DISC HOUSIG CP		01
007D	0503010134	3/8" X 1" BOLT		08
007E	0502011478	DISC HUB		01
007F	0503012106	00521-BR RETAINER		02
007G	1882970002	GREASE SOAP		01
007H	0511017907	1/8" BSPT X 6 PLUG		02
007I	0591016350	FERTILIZER BOX COVER		01



Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC	119	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
07	0503010025	3/8" SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 122 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 124 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC	121	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04

LEFT DUAL FERTILIZER DISC


0521055869




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
07	0503010025	3/8" SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 122 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 124 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	123	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01



Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUB DISC - HUB		01
02	0502012896	LOW CUBE FERTILIZER / SEED BOX		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	125	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	LOW CUBE FERTILIZER / SEED BOX		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01

SCARING ROD


0521053946



Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070085	FIXED ROD BEARING		01
03	0513010288	ELASTIC PIN 701211 10 X 24		02
04	0513010289	ELASTIC PIN 701211 10 X 24		02



Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

LEONARDO JOSÉ DA SILVA SOUZA

www.marchesan.com.br

