

ROW CROP PLANTERS

**PST PLUS FLEX TITANIUM - FRAME -
4045/4395/4845/5345/5745 - CSU (FROM
08/2022)**

Code:	0501093367
Series:	S-0116
Revision:	00
Date Revision:	DEZEMBRO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS

Code	Description
0111380212	PST PLUS FLEX 4045/8E500 CI MH CSU TIT PM400 S0116
0111380230	PST PLUS FLEX 4045/8E500 CI MH DC20 CSU TIT S-0116
0111380309	PST PLUS FLEX 4045/8E500 CPERA D CSU TIT S-0116
0111380388	PST PLUS FLEX 4045/8E500 ESPECIAL S-0116
0111380338	PST PLUS FLEX 4045/8E500 ESPECIAL S-0116
0111380177	PST PLUS FLEX 4045/8E500 ESPECIAL S-0116
0111380374	PST PLUS FLEX 4045/8E500 ESPECIAL S-0116
0111380118	PST PLUS FLEX 4045/8E500 IAPAR MH DC20 SPCRR CSU TIT PM400 CI S-0116
0111380092	PST PLUS FLEX 4045/9E450 CPRA D/HDA MH CSU TIT S-0116
0111380150	PST PLUS FLEX 4045/9E450 CPRA MH DC20 CSU TIT S-0116
0111380142	PST PLUS FLEX 4045/9E450 D/HDA DC20 CSU TIT S-0116
0111380166	PST PLUS FLEX 4045/9E450 ESPECIAL S-0116
0111380075	PST PLUS FLEX 4045/9E450 ESPECIAL S-0116
0111380199	PST PLUS FLEX 4045/9E450 ESPECIAL S-0116
0111380171	PST PLUS FLEX 4045/9E450 ESPECIAL S-0116
0111380339	PST PLUS FLEX 4045/9E450 ESPECIAL S-0116
0111380425	PST PLUS FLEX 4045/9E450 ESPECIAL S-0116
0111380421	PST PLUS FLEX 4395/10E450 CI MH DC20 CSU TIT S0116
0111380305	PST PLUS FLEX 4395/10E450 CPERA D CSU TIT S-0116
0111380423	PST PLUS FLEX 4395/10E450 ESPECIAL S-0116
0111380468	PST PLUS FLEX 4395/10E450 ESPECIAL S-0116
0111380497	PST PLUS FLEX 4395/10E450 ESPECIAL S-0116
0111380121	PST PLUS FLEX 4395/10E450 MH DC20 PM100 CSU TIT S-0116
0111380326	PST PLUS FLEX 4395/9E500 CI MH DC20 CSU TIT S-0116
0111380152	PST PLUS FLEX 4395/9E500 CSU TIT S-0116
0111380140	PST PLUS FLEX 4395/9E500 D MH DC20 CSU TIT S-0116
0111380183	PST PLUS FLEX 4395/9E500 ESPECIAL S-0116
0111380379	PST PLUS FLEX 4395/9E500 ESPECIAL S-0116
0111380203	PST PLUS FLEX 4395/9E500 ESPECIAL S-0116
0111380157	PST PLUS FLEX 4395/9E500 ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

PRODUCTS

0111380341	PST PLUS FLEX 4395/9E500 ESPECIAL S-0116
0111380252	PST PLUS FLEX 4395/9E500 ESPECIAL S-0116
0111380072	PST PLUS FLEX 4395/9E500 H DC20 CSU TIT S-0116
0111380094	PST PLUS FLEX 4395/9E500 MH DC20 CSU TIT S-0116
0111380138	PST PLUS FLEX 4395/9E500 MH DC20 PM400 CSU TIT S-0116
0111380139	PST PLUS FLEX 4395/9E500 MH TIT CSU PM400 S-0116
0111380331	PST PLUS FLEX 4845/10E500 D MH DC20 CSU TIT S-0116
0111380395	PST PLUS FLEX 4845/10E500 ESPECIAL S-0116
0111380162	PST PLUS FLEX 4845/10E500 ESPECIAL S-0116
0111380163	PST PLUS FLEX 4845/10E500 ESPECIAL S-0116
0111380350	PST PLUS FLEX 4845/10E500 ESPECIAL S-0116
0111380472	PST PLUS FLEX 4845/10E500 ESPECIAL S-0116
0111380216	PST PLUS FLEX 4845/10E500 ESPECIAL S-0116
0111380489	PST PLUS FLEX 4845/10E500 ESPECIAL S-0116
0111380287	PST PLUS FLEX 4845/10E500 ESPECIAL S-0116
0111380346	PST PLUS FLEX 4845/10E500 ESPECIAL S-0116
0111380214	PST PLUS FLEX 4845/10E500 ESPECIAL S-0116
0111380317	PST PLUS FLEX 4845/10E500 ESPECIAL S-0116
0111380441	PST PLUS FLEX 4845/10E500 ESPECIAL S-0116
0111380073	PST PLUS FLEX 4845/10E500 H CSU TIT S-0116
0111380095	PST PLUS FLEX 4845/10E500 MH DC20 CSU TIT S-0116
0111380145	PST PLUS FLEX 4845/10E500 MH DC20 PM100 CSU TIT S-0116
0111380108	PST PLUS FLEX 4845/10E500 SPA H CI MH DC20 CSU TIT S-0116
0111380093	PST PLUS FLEX 4845/11E450 CPRA D/HDA MH CSU TIT S-0116
0111380193	PST PLUS FLEX 4845/11E450 D/IAPAR CI MH CSU TIT S-0116
0111380233	PST PLUS FLEX 4845/11E450 ESPECIAL S-0116
0111380311	PST PLUS FLEX 4845/11E450 ESPECIAL S-0116
0111380070	PST PLUS FLEX 4845/11E450 MH CSU TIT S-0116
0111380330	PST PLUS FLEX 5345/11E500 D MH DC20 CSU TIT S-0116
0111380390	PST PLUS FLEX 5345/11E500 ESPECIAL S-0116
0111380344	PST PLUS FLEX 5345/11E500 ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

PRODUCTS

0111380324	PST PLUS FLEX 5345/11E500 ESPECIAL S-0116
0111380077	PST PLUS FLEX 5345/11E500 MH DC20 CSU TIT S-0116
0111380398	PST PLUS FLEX 5745/12E500 CI MH DC20 CSU TIT S0116
0111380345	PST PLUS FLEX 5745/12E500 ESPECIAL S-0116
0111380191	PST PLUS FLEX 5745/12E500 ESPECIAL S-0116
0111380313	PST PLUS FLEX 5745/12E500 ESPECIAL S-0116
0111380356	PST PLUS FLEX 5745/12E500 ESPECIAL S-0116
0111380308	PST PLUS FLEX 5745/12E500 ESPECIAL S-0116
0111380160	PST PLUS FLEX 5745/12E500 MH DC20 CSU TIT S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909096462	ASSY FRAME - 4045	1
0909096464	ASSY FRAME - 4395	2
0909096463	ASSY FRAME - 4845	3
0909096465	ASSY FRAME - 5345	4
0909096466	ASSY FRAME - 5745	5
0511057303	FRAME WITH WHEEL AXLE - 4045	6
0511057361	FRAME WITH WHEEL AXLE - 4395	7
0511057336	FRAME WITH WHEEL AXLE - 4845	8
0511057382	FRAME WITH WHEEL AXLE - 5345	9
0521050047	FRAME WITH WHEEL AXLE - 5745	10
0511057307	PLATFORM ASSEMBLY - 4045	11
0511057358	PLATFORM ASSEMBLY - 4395	12
0511057331	PLATFORM ASSEMBLY - 4845	13
0511057385	PLATFORM ASSEMBLY - 5345	14
0521050048	PLATFORM ASSEMBLY - 5745	15
0531055593	4045 ALPHA FERTILIZER HOPPER SET	16
0531055585	4045 HOPPER SUPPORT WITH ALPHA FERTILIZER METERING	17
0531055592	4395 ALPHA FERTILIZER HOPPER SET	18
0531055586	4395 HOPPER SUPPORT WITH ALPHA FERTILIZER METERING	19
0531055594	4845 ALPHA FERTILIZER HOPPER SET	20
0531055587	4845 HOPPER SUPPORT WITH ALPHA FERTILIZER METERING	21
0531055595	5345 ALPHA FERTILIZER HOPPER SET	22
0531055588	5345 HOPPER SUPPORT WITH ALPHA FERTILIZER METERING	23
0531055596	5745 ALPHA FERTILIZER HOPPER SET	24
0531055589	5745 HOPPER SUPPORT WITH ALPHA FERTILIZER METERING	25
0501053788	3/4 SQUARE AXLE FASTENER	26
0501056271	GEARBOX CLOSED BEARING	27
0531055292	ALPHA FERTILIZER METERING	28
0531055273	ALPHA FERTILIZER METERING CLAMP	29
0531055376	TRANSMISSION ALPHA FERTILIZER METERING HUB	30
0511058827	SINGLE SEED HOPPER - 4045/9 E450	31
0511058828	2 HOPPERS SET WITH 9 CONDUCTORS	32
0511058769	SINGLE SEED HOPPER - 4045/8 E500	33
0511058770	2 HOPPERS SET WITH 8 CONDUCTORS	34
0511057690	3" ARTICULATED SEED CONDUCTOR	35
0511059114	SINGLE SEED HOPPER - 4395/10 E450	36
0511059584	2 HOPPERS WITH 10 CONDUCTORS SET	37
0511058175	SINGLE SEED HOPPER - 4395/9 E500	38
0511058100	2 HOPPERS WITH 9 CONDUCTORS SET	39
0511058106	SINGLE SEED HOPPER - 4845/10 E500	40
0511057737	2 HOPPERS WITH 10 CONDUCTORS SET	41
0511058147	SINGLE SEED HOPPER - 4845/11 E450 - 5345/11 E500	42
0521057031	SEMI ASSEMBLED CSU C3 - 4845 APT	43
0531058264	ASSY BOX SEED - 4845	44
0531058261	ASSY BOX SEED	45
0531057950	3" X 175 SEED NOZZLE WITH FIXING	46
0531054471	CAP WITH FIXING	47
0521050767	SINGLE SEED HOPPER - 5745/12 E500	48
0511058724	2 HOPPERS WITH 12 CONDUCTORS ASSEMBLY	49
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	50
0909091038	HEX AXLE ASSEMBLY	51
0909098983	HEX AXLE ASSEMBLY - 245/3495/4395/4845	52
0521055338	ROW SEED BEARING	53
0511058653	WHEELS WITH TRACTION SPRING	54
0511058654	WHEEL SUPPORT	55



MARCHESAN

INDEX

0511052770	WHEEL WITH TIRE	56
0503062159	WHEEL WITH TIRE	57
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	58
0501058241	WHEEL SUPPORT CHAIN TENSIONER	59
0501058240	WHEEL FASTENER WITH TENSIONER	60
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	61
0501058244	WHEEL FIXED CHAIN TENSIONER	62
0501058242	WHEEL MOBILE CHAIN TENSIONER	63
0521050054	WHEELS TRACTION SPRING WITHOUT TRANSMISSION	64
0521050053	WHEEL SUPPORT WITHOUT TRANSMISSION	65
0521055239	WHEEL WITH TIRE WITHOUT TRANSMISSION	66
0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	67
0511056536	LADDER ASSEMBLY	68
0511054971	JACK ASSEMBLY	69
0511054601	HITCH ARTICULATED TRACTOR	70
0511057333	DRAWBAR ASSEMBLY - 3495/4045/4395/4845/5345/5745	71
0511057270	DRAWBAR EXTENDER	72
0511058655	CYLINDER SET - 3245/3495/4045/4395	73
0511058607	HYDRAULIC CYLINDER	74
0511056736	HOSE SUPPORT	75
0521057028	HOSE SUPPORT SET	76
0511057266	HYDRAULIC SYSTEM ASSEMBLY - 3245/3495/4045/4395	77
0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	78
0501053834	MALE QUICK COUPLER	79
0511057311	SEMI-ASSEMBLED HYDRAULIC MARKER - 4045	80
0521050114	SEMI-ASSEMBLED HYDRAULIC MARKER - 5745	81
0511057328	SEMI-ASSEMBLED HYDRAULIC MARKER - 4845	82
0501054649	HBM SEQUENTIAL VALVE	83
0511058119	VALVE SUPPORT ASSEMBLY	84
0511058449	HYDRAULIC CYLINDER	85
0511057845	MANUAL CANISTER	86
0511057834	LABELS SET - 4045	87
0511057833	SET LABEL ADHESIVE CSU - 4045	88
0511059457	LABELS KIT - 4395	89
0531057428	LABELS KIT - 4395	90
0521050768	LABELS KIT - 5745	91
0511057805	LABELS KIT - 4845	92
0531057456	SET LABELS	93
0511059322	LIFTING SUPPORT ASSEMBLY	94
0511058658	TRANSMISSION ASSEMBLY - 4045	95
0511058962	4095 - TRANSMISSION ASSY	96
0511058985	TRANSMISSION ASSEMBLY - 4395	97
0511058708	TRANSMISSION ASSY - 4395	98
0511058379	TRANSMISSION ASSEMBLY - 4845	99
0521057026	4845 - TRANSMISSION ASSEMBLY	100
0521057027	4845 - TRANSMISSION ASSEMBLY	101
0521050115	TRANSMISSION ASSEMBLY - 5745	102
0501052560	MOTOR AXLE SIGNAL	103
0511051434	TRANSMISSION ACTUATOR	104
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	105
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	106
0511057265	TRANSMISSION CHAIN TENSIONER	107
0501058810	RIGHT SEED HOPPER SUPPORT	108
0511050652	CHAIN TENSIONER	109
0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	110



MARCHESAN

INDEX

0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	111
0521055335	RIGHT GEAR HOUSING SET	112
0521055337	LEFT GEAR HOUSING SET	113
0511058381	RIGHT GEAR HOUSING	114
0511058382	LEFT GEAR HOUSING	115
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	116
0501048790	AXLE WITH RING	117
0501056443	GEAR HOUSING BEARING	118
0501056444	BEARING WITH ROLLER	119
0511057258	TENSIONER WITH GEAR	120
0511054363	CHAIN TENSIONER	121
0521052368	STRETCHER SIMPLE SEED	122
0511057306	HANDRAIL ASSEMBLY - 4045	123
0511057359	HANDRAIL ASSEMBLY - 4395	124
0511057330	HANDRAIL ASSEMBLY - 4845	125
0511057386	HANDRAIL ASSEMBLY - 5345	126
0521050055	HANDRAIL ASSEMBLY - 5745	127
0511059323	PLATFORM TRANSPORT SUPPORT	128
0501050633	ROW MARKER DISC ASSEMBLY	129
0531053676	10 ROWS SEED MONITORING SET	130
0531053630	12 ROWS PLANTING MONITORING SET	131
0531052986	PIVOT SUPPORT	132
0521057029	FILTER SUPPORT ASSY	133
0521057030	LIFT DRIVE ASSEMBLY	134
0521053635	ASSEMBLY ISO	135
0521055015	PARKER OMP 80 HYDRAULIC MOTOR WITH VALVE	136
0511056972	FILTER HYDAC	137
0909092511	SEED/FERTILIZER ROW ASSY	138
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	139
0521056317	DEPTH CONTROL WITH LEVER ANGLE REGULATOR AXIS CPERA	140
0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	141
0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	142
0511058650	SEMI-MOUNTED DEPTH CONTROL	143
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	144
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	145
0501052538	DEPTH BAND WITH ARMS	146
0511054333	COMPACT WHEEL RIGHT WITH BEARING	147
0511054334	COMPACT WHEEL LEFT WITH BEARING	148
0521056314	LEFT ARM WHEEL DEPTH WITH HUB CPERA	149
0521056316	DEPTH WHEEL HUB WITH COMPLETE ANGLE ADJUSTING AXLE	150
0521051423	COMPACTOR SUPPORT	151
0511050077	WHEEL STRIPED	152
0511052287	DEPTH WHEEL HUB ASSY	153
0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	154
0511059325	LEFT ARM COVERED WHEEL ASSEMBLED	155
0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED	156
0511051546	CUBE RIGHT CONTROL DEPTH	157
0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	158
0511051547	LEFT CUBE CONTROL DEPTH	159
0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	160
0501052908	COMPACTOR WHEEL WITH BEARING	161
0511055819	DEPTH BAND WITH RIM	162
0521054984	DEPTH/COMPACTOR SYSTEM - SPT	163



MARCHESAN

INDEX


0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	164
0501052297	DEPTH WHEELS REGULATOR ASSY	165
0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	166
0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	167
0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	168
0521055033	SEMI-ASSEMBLED COMPACTOR BODY	169
0521055017	RIGHT COMPACTOR WHEEL	170
0521054990	LEFT COMPACTOR WHEEL	171
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	172
0511056621	RIGHT REAR SEED ROW	173
0511056628	REAR RIGHT	174
0511056622	LEFT REAR SEED ROW	175
0511056629	LEFT REAR	176
0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8	177
0501058972	ASSEMBLY SENSOR ELECTRONIC	178
0511056586	15 X 15 SEED DDD LEFT	179
0511052302	LH SUPPORT DDD GUIDE	180
0511053173	CUBE LOW RIGHT WITH DISC 15	181
0511053172	LEFT LOW CUBE WITH DISC 15	182
0511057277	FRONT SHORT SEED ROW WITH RIGHT TRANSMISSION	183
0511057290	SEED ROW FRONT SHORT WITH TRANSMISSION	184
0511057278	FRONT LONG SEED ROW WITH RIGHT TRANSMISSION	185
0511057291	SEED ROW FRONT SHORT WITH TRANSMISSION	186
0511058766	BEARING	187
0511057159	TRANSMISSION HOPPER SEED ROW	188
0511057269	CHAIN TENSIONER	189
0511059872	BEARING	190
0511058512	PROTECTION LID	191
0511057275	TRANSMISSION WITH LEFT SUPPORT	192
0511057273	ASSEMBLY TRANSMISSION	193
0511057274	TRANSMISSION LOWER FRONT SEED ROW SHORT	194
0511052024	FAST CLOSING SET	195
0521058525	SHORT SEED ROW	196
0521058524	SEED ROW FRONT	197
0521056944	REAR FRAME	198
0521056955	RIGHT DDD ASSY	199
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	200
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	201
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	202
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	203
0521056582	TITANIUM SEED METER SET	204
0521056639	SEED ROW TRANSMISSION	205
0521058526	FRONT SEED ROW	206
0521056945	REAR FRAME	207
0521056954	LEFT DDD ASSY	208
0511059023	SEED SYSTEM ASSY	209
0501051094	ASSY SEED DISTRIBUTOR	210
0501051119	DOUBLE PULLEY ROCKER'S	211
0521050096	SEED HOPPER SYSTEM (CSU)	213
0511052058	SEED SYSTEM TITANIUM	214
0531055312	TITANIUM SINGLE SEED SYSTEM	215
0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	216
0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK LID	217
0511058639	SHORT FERTILIZER ROW WITH DDD/DC20	218
0511058635	SHORT FERTILIZER ROW DDD 18" BLADE DISC	219



MARCHESAN


INDEX

0521050673	SHORT FERTILIZER ROW	220
0511058641	SHORT FERTILIZER ROW	221
0511059051	SHORT FERTILIZER ROW	222
0511058640	LONG FERTILIZER ROW WITH DDD/DC20	223
0511058636	LONG FERTILIZER ROW DDD 18" BLADE DISC	224
0521050674	LONG FERTIL ROW	225
0511058642	LONG FERTIL ROW	226
0511059052	SHORT ROW FERTILIZER	227
0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	228
0511057272	LH SHORT ARM ROW FERTILIZER	229
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	230
0511058630	20" DISC BLADE	231
0521050672	LONG OSCILLATING DOUBLE DISC 20	232
0511058781	CORRUGATED DC BOX 20	233
0511056909	DISC BLADE HUB WITHOUT DISC	234
0511059050	DOC 20" ASSY	235
0511058838	20" WAVY COULTER BLADE HUB	236
0511058634	SUPPORT LONG	237
0511057271	RH LONG ARM ROW FERTILIZER	238
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	239
0511058629	18" COULTER BLADE ASSY FOR SHORT ROW	240
0511056910	HUB WITH 18" DISC BLADE	241
0521056477	SHORT FERTILIZER ROW DC20 WITHOUT LUBRICATION	242
0521056479	LONG DC20 FERTILIZER ROW WITHOUT LUBRICATION	243
0521056476	DC 20" ASSY	244
0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	245
0521053697	DISC BLADE HUB	246
0521057957	FIXED ROD EXTENSION WITH FIXATION	247
0521050342	HDA WITH RIGHT NOZZLE	248
0521053949	SCARIFIER SPINDLE WITH SOCKET RIGHT	249
0521050343	HDA WITH LEFT NOZZLE	250
0521053948	SCARIFIER SPINDLE WITH SOCKET LEFT	251
0521050337	STEM WITH NOZZLE	252
0521050341	ROD WITH AUTOMATIC DISARM	252
0501110864	STEM WITH NOZZLE 0084 HDA	253
0521053950	HDA AUTOMATIC DISARM	254
0521053951	STEM	255
0521053932	ROD WITH BEAK 0869	256
0503062066	DISC SET WITH CORN RING	257
0503062067	DISC SET / RING SOY 90F TITANIUM	258
0521050525	FIXER FERTILIZER CONDUCTOR	259
0501110804	SCARIFIER ROD WITH POINT	260
0511057984	V-COVERING RUBBER WHEEL - SHORT ROW	261
0511057985	V-COVERING RUBBER WHEEL - LONG ROW	262
0521054769	LEFT DDD FERTILIZER WITH SUPPORT	263
0521055869	LEFT DUAL FERTILIZER DISC	264
0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	265
0521055868	RIGHT DUAL FERTILIZER DISC	266




Item	Code	Description	See page	QT
01	0511057303	FRAME WITH WHEEL AXLE - 4045	6	01
02	0511057307	PLATFORM ASSEMBLY - 4045	11	01
03	0531055593	4045 ALPHA FERTILIZER HOPPER SET	16	01
04	0511058827	SINGLE SEED HOPPER - 4045/9 E450	31	01
04.	0511058769	SINGLE SEED HOPPER - 4045/8 E500	33	01
05	0511059323	PLATFORM TRANSPORT SUPPORT	128	04
06	0909091038	HEX AXLE ASSEMBLY	51	01
07	0511058653	WHEELS WITH TRACTION SPRING	54	04
08	0511056536	LADDER ASSEMBLY	68	02
09	0511054971	JACK ASSEMBLY	69	02
10	0511054601	HITCH ARTICULATED TRACTOR	70	01
11	0511057333	DRAWBAR ASSEMBLY	- 71	01
12	0511057270	DRAWBAR EXTENDER	72	01
13	0511058655	CYLINDER SET - 3245/3495/4045/4395	73	01
14	0501068994	8,30 X 78 LOCK PIN		01
15	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
16	0501047895	ROD STOP		01
17	0501047885	ROD STOP		01
18	0501047886	ROD STOP		01
19	0501047887	ROD STOP		01
20	0511056736	HOSE SUPPORT	75	01
21	0501065677	STRUT		02
22	0503030168	HITCH PIN CLIP		01
23	0503032624	FERTILIZER HOPPER GUTTER		05
24	0511057266	HYDRAULIC SYSTEM ASSEMBLY	- 77	01
25	0503010003	1845 GREASE FITTING		04
26	0511053179	TRACTOR COUPLING SHAFT		01
27	0521013022	TRANSPORT LOCK		01
28	0503010780	N-2050 AMENDMENT		02
29	0503010951	REDUCTION		04

Item	Code	Description	See page	QT
30	0511057311	SEMI-ASSEMBLED HYDRAULIC MARKER - 4045	80	01
31	0511057312	HOSE KIT MARKER HYDRAULIC		01
32	0511057845	MANUAL CANISTER	86	01
33	0511057834	LABELS SET - 4045	87	01
33.	0511057833	SET LABEL ADHESIVE CSU - 4045	88	01
34	0511059322	LIFTING SUPPORT ASSEMBLY	94	02
35	0511058658	TRANSMISSION ASSEMBLY - 4045	95	01
35.	0511058962	4095 - TRANSMISSION ASSY	96	01
36	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		02
37	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
38	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
39	0503010019	1/2" SPRING WASHER		04
40	0503010060	1/2 UNC G.5 ZN HEX NUT		04
41	0511057306	HANDRAIL ASSEMBLY - 4045	123	01
42	0503011750	AMENDMENT WITH LOCK		06
43	0503011751	REDUCTION		06
44	0501214546	SPRING KEY		01
45	0501050633	ROW MARKER DISC ASSEMBLY	129	02
46	0503014120	CHAIN		01
47	0503014321	CABLE STEEL SHACKLE		02
48	0909092511	SEED/FERTILIZER ROW ASSY	138	01




Item	Code	Description	See page	QT
01	0511057361	FRAME WITH WHEEL AXLE - 4395	7	01
02	0511057358	PLATFORM ASSEMBLY - 4395	12	01
03	0531055592	4395 ALPHA FERTILIZER HOPPER SET	18	01
04	0511059114	SINGLE SEED HOPPER - 4395/10 E450	36	01
04.	0511058175	SINGLE SEED HOPPER - 4395/9 E500	38	01
05	0511059323	PLATFORM TRANSPORT SUPPORT	128	04
06	0909098983	HEX AXLE ASSEMBLY - 245/3495/4395/4845	52	01
07	0511058653	WHEELS WITH TRACTION SPRING	54	04
08	0511056536	LADDER ASSEMBLY	68	02
09	0511054971	JACK ASSEMBLY	69	02
10	0511054601	HITCH ARTICULATED TRACTOR	70	01
11	0511057333	DRAWBAR ASSEMBLY	- 71	01
12	0511057270	DRAWBAR EXTENDER	72	01
13	0511058655	CYLINDER SET - 3245/3495/4045/4395	73	01
14	0501068994	8,30 X 78 LOCK PIN		01
15	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
16	0501047895	ROD STOP		01
17	0501047885	ROD STOP		01
18	0501047886	ROD STOP		01
19	0501047887	ROD STOP		01
20	0511056736	HOSE SUPPORT	75	01
21	0501065677	STRUT		02
22	0503030168	HITCH PIN CLIP		01
23	0503032624	FERTILIZER HOPPER GUTTER		04
24	0511057266	HYDRAULIC SYSTEM ASSEMBLY	- 77	01
25	0503010003	1845 GREASE FITTING		04
26	0511053179	TRACTOR COUPLING SHAFT		01
27	0521013022	TRANSPORT LOCK		01
28	0503010780	N-2050 AMENDMENT		02
29	0503010951	REDUCTION		04

Item	Code	Description	See page	QT
30	0511057355	SEMI-ASSEMBLED HYDRAULIC MARKER - 4395		01
31	0511057354	HOSE KIT MARKER HYDRAULIC 4395		01
32	0511057845	MANUAL CANISTER	86	01
33	0511059457	LABELS KIT - 4395	89	01
33.	0531057428	LABELS KIT - 4395	90	01
34	0511059322	LIFTING SUPPORT ASSEMBLY	94	02
35	0511058985	TRANSMISSION ASSEMBLY - 4395	97	01
35.	0511058708	TRANSMISSION ASSY - 4395	98	01
36	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		02
37	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
38	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
39	0503010019	1/2" SPRING WASHER		04
40	0503010060	1/2 UNC G.5 ZN HEX NUT		04
41	0511057359	HANDRAIL ASSEMBLY - 4395	124	01
42	0503011750	AMENDMENT WITH LOCK		06
43	0503011751	REDUCTION		06
44	0501214546	SPRING KEY		01
45	0531053676	10 ROWS SEED MONITORING SET	130	01
46	0571014383	GUTTER		02
47	0571017368	SUPPORT GUTTER		06
48	0501011643	3/8 X 1"BOLT		06
49	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
50	0503010025	3/8" SPRING WASHER		06
51	0503010026	3/8" NUT		06
52	0501050633	ROW MARKER DISC ASSEMBLY	129	02
53	0503014120	CHAIN		01
54	0503014321	CABLE STEEL SHACKLE		02
55	0909092511	SEED/FERTILIZER ROW ASSY	138	01




Item	Code	Description	See page	QT
01	0511057336	FRAME WITH WHEEL AXLE - 4845	8	01
02	0511057331	PLATFORM ASSEMBLY - 4845	13	01
03	0531055594	4845 ALPHA FERTILIZER HOPPER SET	20	01
04	0511058106	SINGLE SEED HOPPER - 4845/10 E500	40	01
04.	0511058147	SINGLE SEED HOPPER - 4845/11 E450 - 5345/11 E500	42	01
04..	0521057031	SEMI ASSEMBLED CSU C3 - 4845 APT	43	01
04...	0531058264	ASSY BOX SEED - 4845	44	01
05	0511059323	PLATFORM TRANSPORT SUPPORT	128	04
06	0909098983	HEX AXLE ASSEMBLY - 245/3495/4395/4845	52	01
07	0511058653	WHEELS WITH TRACTION SPRING	54	04
08	0511056536	LADDER ASSEMBLY	68	02
09	0511054971	JACK ASSEMBLY	69	02
10	0511054601	HITCH ARTICULATED TRACTOR	70	01
11	0511057333	DRAWBAR ASSEMBLY	- 71	01
12	0511057270	DRAWBAR EXTENDER	72	01
13	0511058656	CYLINDER SET - 4845/5345/5745		01
14	0501068994	8,30 X 78 LOCK PIN		02
15	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
16	0501047895	ROD STOP		02
17	0501047885	ROD STOP		02
18	0501047886	ROD STOP		02
19	0501047887	ROD STOP		02
20	0511056736	HOSE SUPPORT	75	01
21	0501065677	STRUT		02
22	0503030168	HITCH PIN CLIP		02
23	0503032624	FERTILIZER HOPPER GUTTER		06
24	0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	78	01
25	0503010003	1845 GREASE FITTING		06
26	0511053179	TRACTOR COUPLING SHAFT		01
27	0521013022	TRANSPORT LOCK		02

Item	Code	Description	See page	QT
28	0503010780	N-2050 AMENDMENT		02
29	0503010951	REDUCTION		04
30	0511057328	SEMI-ASSEMBLED HYDRAULIC MARKER - 4845	82	01
31	0511057334	HOSE KIT MARKER HYDRAULIC		01
32	0511057845	MANUAL CANISTER	86	01
33	0511057805	LABELS KIT - 4845	92	01
33.	0531057456	SET LABELS	93	01
34	0511059322	LIFTING SUPPORT ASSEMBLY	94	02
35	0511058379	TRANSMISSION ASSEMBLY - 4845	99	01
36	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		04
37	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
38	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
39	0503010019	1/2" SPRING WASHER		08
40	0503010060	1/2 UNC G.5 ZN HEX NUT		08
41	0511057330	HANDRAIL ASSEMBLY - 4845	125	01
42	0503011750	AMENDMENT WITH LOCK		06
43	0503011751	REDUCTION		06
44	0501214546	SPRING KEY		01
45	0531053630	12 ROWS PLANTING MONITORING SET	131	01
46	0571019693	GUN 25 X 58 X 800		02
47	0561019643	25 X 58 X 1000 GUTTER		02
48	0571017368	SUPPORT GUTTER		08
49	0501011643	3/8 X 1"BOLT		08
50	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
51	0503010025	3/8" SPRING WASHER		08
52	0503010026	3/8" NUT		08
53	0501050633	ROW MARKER DISC ASSEMBLY	129	02
54	0503014120	CHAIN		01
55	0503014321	CABLE STEEL SHACKLE		02
56	0521057029	FILTER SUPPORT ASSY	133	01
57	0521057030	LIFT DRIVE ASSEMBLY	134	01
58	0521053635	ASSEMBLY ISO	135	01
59	0521013164	EXTENSOR		02
60	0501011310	FIXER LOCK		08
61	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		08
62	0503010019	1/2" SPRING WASHER		08
63	0503010060	1/2 UNC G.5 ZN HEX NUT		08
64	0909092511	SEED/FERTILIZER ROW ASSY	138	01




Item	Code	Description	See page	QT
01	0511057382	FRAME WITH WHEEL AXLE - 5345	9	01
02	0511057385	PLATFORM ASSEMBLY - 5345	14	01
03	0531055595	5345 ALPHA FERTILIZER HOPPER SET	22	01
04	0511058147	SINGLE SEED HOPPER - 4845/11 E450 - 5345/11 E500	42	01
05	0511059323	PLATFORM TRANSPORT SUPPORT	128	04
06	0909091038	HEX AXLE ASSEMBLY	51	01
07	0511058653	WHEELS WITH TRACTION SPRING	54	04
08	0511056536	LADDER ASSEMBLY	68	02
09	0511054971	JACK ASSEMBLY	69	02
10	0511054601	HITCH ARTICULATED TRACTOR	70	01
11	0511057333	DRAWBAR ASSEMBLY 3495/4045/4395/4845/5345/5745	- 71	01
12	0511057270	DRAWBAR EXTENDER	72	01
13	0511058656	CYLINDER SET - 4845/5345/5745		01
14	0501068994	8,30 X 78 LOCK PIN		02
15	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
16	0501047895	ROD STOP		02
17	0501047885	ROD STOP		02
18	0501047886	ROD STOP		02
19	0501047887	ROD STOP		02
20	0511056736	HOSE SUPPORT	75	01
21	0501065677	STRUT		02
22	0503030168	HITCH PIN CLIP		02
23	0503032624	FERTILIZER HOPPER GUTTER		05
24	0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	78	01
25	0503010003	1845 GREASE FITTING		06
26	0511053179	TRACTOR COUPLING SHAFT		01
27	0521013022	TRANSPORT LOCK		02
28	0503010780	N-2050 AMENDMENT		02
29	0503010951	REDUCTION		04
30	0511057387	SEMI-ASSEMBLED HYDRAULIC MARKER - 5345		01

Item	Code	Description	See page	QT
31	0511057383	HOSE KIT MARKER HYDRAULIC		01
32	0511057845	MANUAL CANISTER	86	01
33	0511057835	LABELS KIT - 5345		01
34	0511059322	LIFTING SUPPORT ASSEMBLY	94	02
35	0511058937	TRANSMISSION ASSEMBLY - 5345		01
36	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		02
37	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
38	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
39	0503010019	1/2" SPRING WASHER		04
40	0503010060	1/2 UNC G.5 ZN HEX NUT		04
41	0511057386	HANDRAIL ASSEMBLY - 5345	126	01
42	0503011750	AMENDMENT WITH LOCK		06
43	0503011751	REDUCTION		06
44	0501214546	SPRING KEY		01
45	0521013164	EXTENSOR		02
46	0501011310	FIXER LOCK		08
47	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		08
48	0503010019	1/2" SPRING WASHER		08
49	0503010060	1/2 UNC G.5 ZN HEX NUT		08
50	0501050633	ROW MARKER DISC ASSEMBLY	129	02
51	0503014120	CHAIN		01
52	0503014321	CABLE STEEL SHACKLE		02
53	0909092511	SEED/FERTILIZER ROW ASSY	138	01




Item	Code	Description	See page	QT
01	0521050047	FRAME WITH WHEEL AXLE - 5745	10	01
02	0521050048	PLATFORM ASSEMBLY - 5745	15	01
03	0531055596	5745 ALPHA FERTILIZER HOPPER SET	24	01
04	0521050767	SINGLE SEED HOPPER - 5745/12 E500	48	01
05	0511059323	PLATFORM TRANSPORT SUPPORT	128	04
06	0909091038	HEX AXLE ASSEMBLY	51	01
07	0511058653	WHEELS WITH TRACTION SPRING	54	04
07.	0521050054	WHEELS TRACTION SPRING WITHOUT TRANSMISSION	64	02
08	0511056536	LADDER ASSEMBLY	68	02
09	0511054971	JACK ASSEMBLY	69	02
10	0511054601	HITCH ARTICULATED TRACTOR	70	01
11	0511057333	DRAWBAR ASSEMBLY 3495/4045/4395/4845/5345/5745	- 71	01
12	0511057270	DRAWBAR EXTENDER	72	01
13	0511058656	CYLINDER SET - 4845/5345/5745		01
14	0501068994	8,30 X 78 LOCK PIN		02
15	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
16	0501047895	ROD STOP		02
17	0501047885	ROD STOP		02
18	0501047886	ROD STOP		02
19	0501047887	ROD STOP		02
20	0511056736	HOSE SUPPORT	75	01
21	0501065677	STRUT		02
22	0503030168	HITCH PIN CLIP		02
23	0503032624	FERTILIZER HOPPER GUTTER		06
24	0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	78	01
25	0503010003	1845 GREASE FITTING		06
26	0511053179	TRACTOR COUPLING SHAFT		01
27	0521013022	TRANSPORT LOCK		02
28	0503010780	N-2050 AMENDMENT		02
29	0503010951	REDUCTION		04


Item	Code	Description	See page	QT
30	0521050114	SEMI-ASSEMBLED HYDRAULIC MARKER - 5745	81	01
31	0521050113	HYDRAULIC MARKER HAND SET		01
32	0511057845	MANUAL CANISTER	86	01
33	0521050768	LABELS KIT - 5745	91	01
34	0511059322	LIFTING SUPPORT ASSEMBLY	94	02
35	0521050115	TRANSMISSION ASSEMBLY - 5745	102	01
36	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		04
37	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
38	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
39	0503010019	1/2" SPRING WASHER		08
40	0503010060	1/2 UNC G.5 ZN HEX NUT		08
41	0521050055	HANDRAIL ASSEMBLY - 5745	127	01
42	0503011750	AMENDMENT WITH LOCK		06
43	0503011751	REDUCTION		06
44	0501214546	SPRING KEY		01
45	0521013164	EXTENSOR		02
46	0501011310	FIXER LOCK		08
47	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		08
48	0503010019	1/2" SPRING WASHER		08
49	0503010060	1/2 UNC G.5 ZN HEX NUT		08
50	0501050633	ROW MARKER DISC ASSEMBLY	129	02
51	0503014120	CHAIN		01
52	0503014321	CABLE STEEL SHACKLE		02
53	0909092511	SEED/FERTILIZER ROW ASSY	138	01




Item	Code	Description	See page	QT
01	0521065919	FRAME - 4045		01
02	0521065928	CARRYING-WHEELS PIVOT SHAFT - 4045		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0521065920	FRAME - 4395		01
02	0521065929	CARRYING-WHEELS PIVOT SHAFT - 4395		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0521065921	FRAME - 4845		01
02	0521065930	PIVOT SHAFT WHEEL - 4845		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0521065922	FRAME - 5345		01
02	0521065931	PIVOT SHAFT WHEEL - 5345		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0521067308	FRAME - 5745		01
02	0521067388	PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0501812140	FLAT WASHER		16
07	0503011445	SPRING WASHER		08
08	0503810013	NUT 5/8 NC		08




Item	Code	Description	See page	QT
01	0571018866	PLATFORM - 4045		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		16
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0571018867	PLATFORM - 4395		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		16
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0571018868	PLATFORM - 4845		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		16
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0571018869	PLATFORM - 5345		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		16
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0581012899	PLATFORM - 5745		02
02	0503010237	3/8" X 1" BOLT		06
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		12
04	0503010025	3/8" SPRING WASHER		06
05	0503010026	3/8" NUT		06




Item	Code	Description	See page	QT
01	0531055585	4045 HOPPER SUPPORT WITH ALPHA FERTILIZER 17 METERING	01	
02	0503062391	FERTILIZER HOPPER	02	
03	0503013751	3/8 UNC X 1.1/4 BOLT	16	
04	0571019051	FIXER HOPPER WASHER	16	
05	0503012535	3/8" SPRING WASHER	16	
06	0503012531	3/8" INOX NUT	16	
07	0503011957	NYLON LUG	02	
08	0503010371	5/16" X 1" BOLT	04	
09	0503010179	LOCK WASHER 5/16 ZN 1K01528	04	
10	0503010337	5/16" NUT	04	
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	10	
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN	20	
13	0503010025	3/8" SPRING WASHER	10	
14	0503010026	3/8" NUT	10	




Item	Code	Description	See page	QT
01	0531064281	4045 FERTILIZER HOPPER SUPPORT		01
02	0501053788	3/4 SQUARE AXLE FASTENER	26	08
03	0511061759	22Z P12,70 FQ 3/4" GEAR		02
04	0503030303	SUPPORT WASHER		04
05	0501056271	GEARBOX CLOSED BEARING	27	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0531055292	ALPHA FERTILIZER METERING	28	10
11	0503031527	AGRICULTURAL BEARING		06
12	0521013959	3/4" X 30.2" SQUARE SHAFT		02
13	0591019866	SQUARE AXLE 3/4 X 1220		02
14	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		02
14A	0501214269	SQUARE SLEEVE		02
14B	0513010701	LOCK PIN		02




Item	Code	Description	See page	QT
01	0531055586	4395 HOPPER SUPPORT WITH ALPHA FERTILIZER 19 METERING	01	01
02	0503062391	FERTILIZER HOPPER		02
03	0503013751	3/8 UNC X 1.1/4 BOLT		16
04	0571019051	FIXER HOPPER WASHER		16
05	0503012535	3/8" SPRING WASHER		16
06	0503012531	3/8" INOX NUT		16
07	0503011957	NYLON LUG		02
08	0503010371	5/16" X 1" BOLT		04
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
10	0503010337	5/16" NUT		04
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		20
13	0503010025	3/8" SPRING WASHER		10
14	0503010026	3/8" NUT		10




Item	Code	Description	See page	QT
01	0531064282	4395 FERTILIZER HOPPER SUPPORT		01
02	0501053788	3/4 SQUARE AXLE FASTENER	26	08
03	0511061759	22Z P12,70 FQ 3/4" GEAR		02
04	0503030303	SUPPORT WASHER		04
05	0501056271	GEARBOX CLOSED BEARING	27	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0531055292	ALPHA FERTILIZER METERING	28	10
11	0503031527	AGRICULTURAL BEARING		06
12	0501010787	AXLE		02
13	0591019866	SQUARE AXLE 3/4 X 1220		02
14	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		02
14A	0501214269	SQUARE SLEEVE		02
14B	0513010701	LOCK PIN		02




Item	Code	Description	See page	QT
01	0531055587	4845 HOPPER SUPPORT WITH ALPHA FERTILIZER 21 METERING	21	01
02	0503062362	FERTILIZER HOPPER		03
03	0503013751	3/8 UNC X 1.1/4 BOLT		18
04	0571019051	FIXER HOPPER WASHER		18
05	0503012535	3/8" SPRING WASHER		18
06	0503012531	3/8" INOX NUT		18
07	0503011957	NYLON LUG		02
08	0503010371	5/16" X 1" BOLT		04
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
10	0503010337	5/16" NUT		04
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		14
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		28
13	0503010025	3/8" SPRING WASHER		14
14	0503010026	3/8" NUT		14




Item	Code	Description	See page	QT
01	0531064283	4845 FERTILIZER HOPPER SUPPORT		01
02	0501053788	3/4 SQUARE AXLE FASTENER	26	08
03	0511061759	22Z P12,70 FQ 3/4" GEAR		02
04	0503030303	SUPPORT WASHER		04
05	0501056271	GEARBOX CLOSED BEARING	27	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0531055292	ALPHA FERTILIZER METERING	28	12
11	0503031527	AGRICULTURAL BEARING		06
12	0501018653	3/4" X 46" SQUARE SHAFT		02
13	0591019866	SQUARE AXLE 3/4 X 1220		02
14	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		02
14A	0501214269	SQUARE SLEEVE		02
14B	0513010701	LOCK PIN		02




Item	Code	Description	See page	QT
01	0531055588	5345 HOPPER SUPPORT WITH ALPHA FERTILIZER 23 METERING	01	
02	0503062362	FERTILIZER HOPPER	03	
03	0503013751	3/8 UNC X 1.1/4 BOLT	18	
04	0571019051	FIXER HOPPER WASHER	18	
05	0503012535	3/8" SPRING WASHER	18	
06	0503012531	3/8" INOX NUT	18	
07	0503011957	NYLON LUG	02	
08	0503010371	5/16" X 1" BOLT	04	
09	0503010179	LOCK WASHER 5/16 ZN 1K01528	04	
10	0503010337	5/16" NUT	04	
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	14	
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN	28	
13	0503010025	3/8" SPRING WASHER	14	
14	0503010026	3/8" NUT	14	




Item	Code	Description	See page	QT
01	0531064284	5345 FERTILIZER HOPPER SUPPORT		01
02	0501053788	3/4 SQUARE AXLE FASTENER	26	08
03	0511061759	22Z P12,70 FQ 3/4" GEAR		02
04	0503030303	SUPPORT WASHER		04
05	0501056271	GEARBOX CLOSED BEARING	27	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0531055292	ALPHA FERTILIZER METERING	28	12
11	0503031527	AGRICULTURAL BEARING		06
12	0591018971	SQUARE AXLE 3/4 X 1300		02
13	0551015363	SQUARE AXLE		02
14	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		02
14A	0501214269	SQUARE SLEEVE		02
14B	0513010701	LOCK PIN		02




Item	Code	Description	See page	QT
01	0531055589	5745 HOPPER SUPPORT WITH ALPHA FERTILIZER 25 METERING	25	01
02	0503062362	FERTILIZER HOPPER		01
03	0503062391	FERTILIZER HOPPER		02
04	0503013751	3/8 UNC X 1.1/4 BOLT		20
05	0571019051	FIXER HOPPER WASHER		20
06	0503012535	3/8" SPRING WASHER		20
07	0503012531	3/8" INOX NUT		20
08	0503011957	NYLON LUG		02
09	0503010371	5/16" X 1" BOLT		04
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
11	0503010337	5/16" NUT		04
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		14
13	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		28
14	0503010025	3/8" SPRING WASHER		14
15	0503010026	3/8" NUT		14




Item	Code	Description	See page	QT
01	0531064286	5745 RIGHT FERTILIZER HOPPER SUPPORT		01
02	0531064285	5745 LEFT FERTILIZER HOPPER SUPPORT		01
03	0501053788	3/4 SQUARE AXLE FASTENER	26	08
04	0511061759	22Z P12,70 FQ 3/4" GEAR		02
05	0503030303	SUPPORT WASHER		04
06	0501056271	GEARBOX CLOSED BEARING	27	02
07	0503011953	5/16" X 1" BOLT		04
08	0501010694	FLAT WASHER		04
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
10	0503010337	5/16" NUT		04
11	0531055292	ALPHA FERTILIZER METERING	28	14
12	0503031527	AGRICULTURAL BEARING		06
13	0551016112	SQUARE SHAFT		02
14	0561018739	SQUARE SHAFT		02
15	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		02
15A	0501214269	SQUARE SLEEVE		02
15B	0513010701	LOCK PIN		02




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0503010025	3/8" SPRING WASHER		04
02	0503010026	3/8" NUT		04
03	0513010742	RETAINER 47 X 30 X 10 BRG 5285		01
04	0501214879	HORIZONTAL SEAL LID ALPHA FERTILIZER METERING		01
05	0503035799	ALPHA FERTILIZER DOSAGE NOZZLE		01
06	0503035831	ALPHA FERTILIZER METERING COLLECTOR		01
07	0531055273	ALPHA FERTILIZER METERING CLAMP	29	01
08	0513010692	ALLEN SCREW 1/4 UNC X 7/8 C FLAT SI INOX		04
09	0501011643	3/8 X 1" BOLT		04
10	0503035796	REAR FIXER ALPHA FERTILIZER METERING COLLECTOR		02
11	0513010695	ALLEN SCREW 1/4 UNC X 7/8 CCSI INOX		04
12	0531055376	TRANSMISSION ALPHA FERTILIZER METERING 30 HUB		01
13	0502013049	ALPHA FERTILIZER DOSAGE HOPPER		01
14	0502013048	FLANGE FIXER BODY ALPHA FERTILIZER METERING		01
15	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
15A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
15B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
16	0503035829	ADHESIVE LABEL LOGO TATU 38 X 28 X 0.30 ALPHA FERTILIZER METERING		01
17	0531055518	WORM THREAD ASSEMBLED		01
17A	0531064265	WORM THREAD		01
17B	0503035859	SUPPORT SLEEVE		01
18	0501111143	COATING WITH GUIDE ASSY SUPPLEMENTATION FERTILIZER METERING		01
18A	0501214951	FERTILIZER DOSAGE COATING		01
18B	0531055519	GUIDE ASSY WITH SUPPLEMENTATION		01




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0502013050	TRANSMISSION ALPHA FERTILIZER METERING HOPPER		01
02	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
03	0503011800	SEAL RING		02
04	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
05	0503016065	ROLLER BEARING		02
06	0501214237	TRANSMISSION HOPPER ALPHA FERTILIZER METERING SLEEVE		01
07	0503019373	6006 2RS1 NATIONAL BEARING		02
08	0503012858	502075 CLAMPING RING (FOR HOLE)		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01
10	0501214501	ALPHA FERTILIZER METERING LID LOCK AXIS		01
11	0501214238	SHAFT LOCK SLEEVE HOPPER TRANSMISSION ALPHA FERTILIZER METERING		01
12	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01




Item	Code	Description	See page	QT
01	0511058828	2 HOPPERS SET WITH 9 CONDUCTORS	32	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0571019393	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16
15	0521066211	PROTECTOR CENTRAL		01
16	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
17	0501013519	FLAT WASHER		04
18	0503010019	1/2" SPRING WASHER		04
19	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0521064748	05 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503061987	05 NOZZLES FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	35	09
08	0501010942	3/8" X 1-1/4" BOLT		36
09	0503010025	3/8" SPRING WASHER		36
10	0503010026	3/8" NUT		36
11	0571015773	SUPPORT SEED		01
12	0501011643	3/8 X 1"BOLT		04
13	0503010025	3/8" SPRING WASHER		04
14	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0511058770	2 HOPPERS SET WITH 8 CONDUCTORS	34	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0571019393	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16
15	0521066211	PROTECTOR CENTRAL		01
16	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
17	0501013519	FLAT WASHER		04
18	0503010019	1/2" SPRING WASHER		04
19	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0521064748	05 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503061987	05 NOZZLES FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	35	08
08	0501010942	3/8" X 1-1/4" BOLT		32
09	0503010025	3/8" SPRING WASHER		32
10	0503010026	3/8" NUT		32
11	0571015773	SUPPORT SEED		02
12	0501011643	3/8 X 1"BOLT		08
13	0503010025	3/8" SPRING WASHER		08
14	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	5/16" NUT		02
11	0502012767	SEED NOZZLE FIXER SUPPORT		01




Item	Code	Description	See page	QT
01	0511059584	2 HOPPERS WITH 10 CONDUCTORS SET	37	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0571019394	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
03	0503010025	3/8" SPRING WASHER		52
04	0503010026	3/8" NUT		52
05	0511057690	3" ARTICULATED SEED CONDUCTOR	35	10
06	0571015773	SUPPORT SEED		02
07	0501011643	3/8 X 1"BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		40
09	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		02




Item	Code	Description	See page	QT
01	0511058100	2 HOPPERS WITH 9 CONDUCTORS SET	39	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0571019394	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	35	09
08	0501010942	3/8" X 1-1/4" BOLT		36
09	0503010025	3/8" SPRING WASHER		36
10	0503010026	3/8" NUT		36
11	0571015773	SUPPORT SEED		03
12	0501011643	3/8 X 1"BOLT		12
13	0503010025	3/8" SPRING WASHER		12
14	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
01	0511057737	2 HOPPERS WITH 10 CONDUCTORS SET	41	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0571019395	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	35	10
08	0501010942	3/8" X 1-1/4" BOLT		40
09	0503010025	3/8" SPRING WASHER		40
10	0503010026	3/8" NUT		40
11	0571015773	SUPPORT SEED		04
12	0501011643	3/8 X 1"BOLT		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0511057919	2 HOPPERS WITH 11 CONDUCTORS SET	01	
02	0521066102	TOWER SUPPORT HOPPER	04	
03	0501010942	3/8" X 1-1/4" BOLT	08	
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN	08	
05	0503010025	3/8" SPRING WASHER	08	
06	0503010026	3/8" NUT	08	
07	0502010175	HITCH CLAMP	04	
08	0501011543	5/8" X 4" BOLT	08	
09	0503012412	5/8 UNC SELF LOCKING NUT	08	
10	0571019395	PROTECTOR	02	
11	0551019884	45 X 50 X 3/8 FASTENER	08	
12	0501010453	FLAT WASHER	16	
13	0503010025	3/8" SPRING WASHER	16	
14	0503010026	3/8" NUT	16	
15	0521066211	PROTECTOR CENTRAL	01	
16	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
17	0501013519	FLAT WASHER	04	
18	0503010019	1/2" SPRING WASHER	04	
19	0503010060	1/2 UNC G.5 ZN HEX NUT	04	




Item	Code	Description	See page	QT
01	0511057737	2 HOPPERS WITH 10 CONDUCTORS SET	41	01
02	0521066102	TOWER SUPPORT HOPPER		02
03	0531060420	SUPPORT TOWER SEED BOX		02
04	0501010942	3/8" X 1-1/4" BOLT		08
05	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
06	0503010025	3/8" SPRING WASHER		08
07	0503010026	3/8" NUT		08
08	0502010175	HITCH CLAMP		04
09	0501011543	5/8" X 4" BOLT		08
10	0501010453	FLAT WASHER		16
11	0503012412	5/8 UNC SELF LOCKING NUT		08
12	0551019884	45 X 50 X 3/8 FASTENER		08
13	0571019395	PROTECTOR		02
14	0503010025	3/8" SPRING WASHER		16
15	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0531058261	ASSY BOX SEED	45	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8 UNC SELF LOCKING NUT		08
10	0571019395	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8" SPRING WASHER		16
14	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
05	0503010025	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0531057950	3" X 175 SEED NOZZLE WITH FIXING	46	10
08	0531054471	CAP WITH FIXING	47	04




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID		01
02	0501010942	3/8" X 1-1/4" BOLT		05
03	0503010025	3/8" SPRING WASHER		05
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	5/16" NUT		02
11	0502012767	SEED NOZZLE FIXER SUPPORT		01
12	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0571015773	SUPPORT SEED		01
02	0501011643	3/8 X 1" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0511058724	2 HOPPERS WITH 12 CONDUCTORS ASSEMBLY	49	01
02	0511058510	FIXER SUPPORT		04
02A	0521067305	FIXER SUPPORT		01
02B	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02C	0503017857	BOLT 5/8 UNF 4		04
02D	0503010811	5/8" UNF SELF ADJUSTING NUT		04
02E	0501010942	3/8" X 1-1/4" BOLT		04
02F	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
02G	0503010025	3/8" SPRING WASHER		04
02H	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR	35	12
06	0571015773	SUPPORT SEED		02
07	0501011643	3/8 X 1"BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		48
09	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT		01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	181	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	182	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	3245	3495	4045	4395	4845	5345	5745
01	0571018910	3/4 X 1505 AXLE HEX		01	00	00	00	00	00	00
01.	0571018911	3/4 X 1690 AXLE HEX		01	00	00	00	00	00	00
02	0571018912	3/4 X 1630 AXLE HEX		00	01	00	00	00	00	00
02.	0571018913	3/4 X 1815 AXLE HEX		00	01	00	00	00	00	00
03	0571018914	3/4 X 1905 AXLE HEX		00	00	01	00	00	00	00
03.	0571018915	3/4 X 2090 AXLE HEX		00	00	01	00	00	00	00
04	0571018916	3/4 X 2080 AXLE HEX		00	00	00	01	00	00	00
04.	0571018917	3/4 X 2265 AXLE HEX		00	00	00	01	00	00	00
05	0571018918	3/4 X 2305 AXLE HEX		00	00	00	00	01	00	00
05.	0571018919	3/4 X 2490 AXLE HEX		00	00	00	00	01	00	00
06	0571018920	3/4 X 2555 AXLE HEX		00	00	00	00	00	01	00
06.	0571018921	3/4 X 2740 AXLE HEX		00	00	00	00	00	01	00
06..	0581012908	3/4 X 2755 AXLE HEX		00	00	00	00	00	00	01
06...	0581012909	3/4 X 2940 AXLE HEX		00	00	00	00	00	00	01
07	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	111	01	01	01	01	01	01	01
07A	0502012031	HOUSING BEARING		01	01	01	01	01	01	01
07B	0503012861	6006 2RS BALL BEARING		02	02	02	02	02	02	02
07C	0503012858	502075 CLAMPING RING (FOR HOLE)		01	01	01	01	01	01	01
08	0511063185	20Z GEAR WITH HEX HOLE AXLE 20		01	01	01	01	01	01	01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01	01	01	01	01	01	01
10	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02	02	02	02	02	02	02
11	0501010694	FLAT WASHER		04	04	04	04	04	04	04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		02	02	02	02	02	02	02
13	0503010337	5/16" NUT		02	02	02	02	02	02	02
14	0581012949	BEARING COVER		01	01	01	01	01	01	01




Item	Code	Description	See page	3245	3495	4395	4845
01	0521055338	ROW SEED BEARING	53	04	04	04	04
02	0571018910	3/4 X 1505 AXLE HEX		01	00	00	00
02.	0571018912	3/4 X 1630 AXLE HEX		00	01	00	00
02..	0571018916	3/4 X 2080 AXLE HEX		00	00	01	00
02...	0571018918	3/4 X 2305 AXLE HEX		00	00	00	01
03	0571018911	3/4 X 1690 AXLE HEX		01	00	00	00
03.	0571018913	3/4 X 1815 AXLE HEX		00	01	00	00
03..	0571018917	3/4 X 2265 AXLE HEX		00	00	01	00
03...	0571018919	3/4 X 2490 AXLE HEX		00	00	00	01
04	0511054314	TRANSMISSION AXLE LOCK SLEEVE		18	20	24	26
04A	0502012699	TRANSMISSION HUB LOCK SLEEVE		18	20	24	26
04B	0503010256	3/8" X 3/4" BOLT		18	20	24	26




Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING		01
03A	0502012030	HOUSING BEARING		01
03B	0503012861	6006 2RS BALL BEARING		01
03C	0503012858	502075 CLAMPING RING (FOR HOLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02
07	0501013518	FLAT WASHER		02
08	0501010694	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511058654	WHEEL SUPPORT	55	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	60	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521066716	WHEEL ARM ASSY		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
08	0503010027	5/8" SPRING WASHER		01
09	0501058241	WHEEL SUPPORT CHAIN TENSIONER	59	01
10	0503013030	5/8" X 3.1/4" BOLT		01
11	0551017715	FLAT WASHER		02
12	0511052770	WHEEL WITH TIRE	56	01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8" SPRING WASHER		02
15	0503011167	M16 X 2 X 30 BOLT		02




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	57	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	58	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	61	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	62	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	63	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503011119	7/8" X 6" BOLT		04
02	0501014251	FLAT WASHER		04
03	0521050053	WHEEL SUPPORT WITHOUT TRANSMISSION	65	01
04	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0531016887	CARRYING WHEEL AXLE ARM		01
03	0503010523	1/4" X 2" COTTERPIN		01
04	0503010003	1845 GREASE FITTING		01
05	0511050681	TRACTION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0561016062	SPRING HITCH		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		04
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0521066716	WHEEL ARM ASSY		01
11	0503011167	M16 X 2 X 30 BOLT		02
12	0591010589	BODY LOCK WHEEL		02
13	0521055239	WHEEL WITH TIRE WITHOUT TRANSMISSION	66	01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	57	01
02	0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	67	01




Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0502012806	SUPPORT REAR FIXER DRAWBAR		04
02	0502012789	FIXER SUPPORT FERTILIZER ROW		04
03	0503017960	5/8" X 3-12" BOLT		16
04	0503010811	5/8" UNF SELF ADJUSTING NUT		16
05	0501010191	1" X 6" BOLT		04
06	0503010012	1" SPRING WASHER		04
07	0501010059	1.5/8 NUT		04
08	0502012805	SUPPORT FRONT FIXER DRAWBAR		04
09	0502012789	FIXER SUPPORT FERTILIZER ROW		04
10	0503017960	5/8" X 3-12" BOLT		16
11	0503010811	5/8" UNF SELF ADJUSTING NUT		16
12	0521065958	DRAWBAR		01
13	0561019087	DRAWBAR TRANSPORT LOCK		01
14	0551014099	COUPLING SHAFT 31,75 X 185		01
15	0521010544	1.2" X 4.9" COUPLING SHAFT		01
16	0503030085	LOCK PIN		02
17	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521065959	JACK R.1.1/2 UNC RIGHT X 240		01
03	0521065960	JACK R.1.1/2 UNC LEFT X 240		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521045510	HYDRAULIC CYLINDER		01
02	0551014099	COUPLING SHAFT 31,75 X 185		01
03	0521010547	1.2" X 6.5" COUPLING SHAFT		01
04	0503010523	1/4" X 2" COTTERPIN		02
05	0501047888	ROD STOP		01




Item	Code	Description	See page	QT
01	0521066740	CYLINDER CASE		01
02	0581013698	PISTON		01
03	0521067586	TURNBUCKLE		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010003	1845 GREASE FITTING		01
06	0503030385	CYLINDER PLUG N-002		02
07	0503018439	WIPER SEAL		01
08	0503018150	RING GUIDE		01
09	0502010382	5" END CAP		01
10	0581010353	RING SUPPORT		01
11	0503018026	1870-2000-375 B GASKET		01
12	0503011453	O'RING		02
13	0503018152	O'RING		02
14	0503018024	RING BS		01
15	0503018025	RING GUIDE		01
16	0503010039	D-2000 SCRAPER RING		01
17	0503010173	2-220 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0581019503	3/8" FASTENER		01
02	0503015135	FLAT WASHER 10 X 18 X 2		02
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0521069588	HOSE HOLDER		01
06	0531011180	UPPER BODY CLIP		01
07	0503011102	BOLT 7/16 UNC X 1.1/4 C S G.5 ZN		01
08	0503010180	7/16" SPRING WASHER		01




Item	Code	Description	See page	QT
01	0511057267	HOSE KIT HYDRAULIC		01
01A	0501080722	3/8 X 3300 TC-TM HOSE ASSY		01
01B	0501082023	HOSE 3/8 X 3600 TC-TM		01
02	0501053834	MALE QUICK COUPLER	79	02
03	0503013100	NYLON CLAMP		02
04	0571017774	SPRING PROTECTION QUICK HOSE		01



Item	Code	Description	See page	QT
01	0511057335	HOSE KIT HYDRAULIC		01
01A	0501080025	3/8 X 1400 TR-TC HOSE		04
01B	0521052285	TC-TM HOSE ASSY		01
01BA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01BD	0503018952	PLASTIC BOLT		06
01C	0521052330	HOSE 3/8 X 4000 TC-TM PRET/AZUL		01
01CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01CB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01CC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01CD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	79	02
03	0511058120	KIT VALVE SUPPORT		01
03A	0521066354	OIL DISTRIBUTOR BODY		02
03B	0502010477	HOSE CLAMP		04
03C	0503011268	3/8" X 2-1/2" BOLT		02
03D	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
03E	0503010025	3/8" SPRING WASHER		02
03F	0503010026	3/8" NUT		02
04	0503013100	NYLON CLAMP		02
05	0502012702	BODY SUPPORT CLAMP		04
06	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
07	0503010180	7/16" SPRING WASHER		04
08	0531011180	UPPER BODY CLIP		04
09	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8 UNC SELF LOCKING NUT		04
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0511058449	HYDRAULIC CYLINDER	85	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" COTTERPIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501069643	890 TURNBUCKLE		02
21	0503011854	5/8" X 1-1/4" BOLT		04
22	0501054649	HBM SEQUENTIAL VALVE	83	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
25	0503010025	3/8" SPRING WASHER		02
26	0511058119	VALVE SUPPORT ASSEMBLY	84	01
27	0501053834	MALE QUICK COUPLER	79	02
28	0502012702	BODY SUPPORT CLAMP		08
29	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		08
30	0503010180	7/16" SPRING WASHER		08
31	0503010244	7/16" NUT		02

Item	Code	Description	See page	QT
32	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
33	0511057312	HOSE KIT MARKER HYDRAULIC		
33A	0501081727	TR-TR HOSE ASSY		02
33B	0501080408	HOSE 3/8 X 3200 TR-TC		02
34	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
34A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
34B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
34C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
34D	0503018952	PLASTIC BOLT		06
35	0521052850	3/8 X 4200 TC-TM PURPLE/BUE HOSE		01
35A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
35B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
35C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
35D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8 UNC SELF LOCKING NUT		04
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0511061811	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0503012412	5/8 UNC SELF LOCKING NUT		02
13	0511058449	HYDRAULIC CYLINDER	85	02
14	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
15	0503010523	1/4" X 2" COTTERPIN		02
16	0511015779	1" X 4.2" AXLE		02
17	0503010523	1/4" X 2" COTTERPIN		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	8,30 X 78 LOCK PIN		02
20	0503030168	HITCH PIN CLIP		02
21	0501066949	1235 TURNBUCKLE		02
22	0503011854	5/8" X 1-1/4" BOLT		04
23	0501054649	HBM SEQUENTIAL VALVE	83	01
24	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
25	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
26	0503010025	3/8" SPRING WASHER		02
27	0521050113	HYDRAULIC MARKER HAND SET		01
27A	0501082108	TR-TR HOSE		02
27B	0501080605	3/8" X 160" TR-TC HOSE ASSY		02
27C	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
27CA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01

Item	Code	Description	See page	QT
27CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
27CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
27CD	0503018952	PLASTIC BOLT		06
27D	0521052850	3/8 X 4200 TC-TM PURPLE/BLUE HOSE		01
27DA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
27DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
27DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
27DD	0503018952	PLASTIC BOLT		06
28	0501053834	MALE QUICK COUPLER	79	02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		06
32	0503010180	7/16" SPRING WASHER		06
33	0503010244	7/16" NUT		02
34	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
35	0581010011	VALVE FIXING SUPPORT		01




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8 UNC SELF LOCKING NUT		04
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0503012412	5/8 UNC SELF LOCKING NUT		02
12	0511058449	HYDRAULIC CYLINDER	85	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" COTTERPIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501066949	1235 TURNBUCKLE		02
21	0503011854	5/8" X 1-1/4" BOLT		04
22	0501054649	HBM SEQUENTIAL VALVE	83	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
25	0503010025	3/8" SPRING WASHER		02
26	0511057334	HOSE KIT MARKER HYDRAULIC		01
26A	0501080343	TR-TR HOSE ASSY		02
26B	0501080435	3/8" X 3600 TR-TC HOSE		02
26C	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
26CA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
26CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01


Item	Code	Description	See page	QT
26CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
26CD	0503018952	PLASTIC BOLT		06
26D	0521052850	3/8 X 4200 TC-TM PURPLE/BUE HOSE		01
26DA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
26DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26DD	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	79	02
28	0502012702	BODY SUPPORT CLAMP		06
29	0531011180	UPPER BODY CLIP		04
30	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		06
31	0503010180	7/16" SPRING WASHER		06
32	0503010244	7/16" NUT		02
33	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
34	0501012140	FLAT WASHER		04
35	0581010011	VALVE FIXING SUPPORT		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02



Item	Code	Description	See page	QT
01	0581010011	VALVE FIXING SUPPORT		01
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
04	0503010025	3/8" SPRING WASHER		02
05	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0503034228	ADHESIVE LABEL PST FLEX PLUS LOWER (05 NOZZLES)		02
02	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		02
03	0503033892	ADHESIVE LABEL LOGO TATU HOPPER 190 X 720		01
04	0503034258	ADHESIVE LABEL		01
05	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
07	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
08	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	ADHESIVE LABEL		01
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
12	0503031565	ADHESIVE LABEL CARE		02
13	0503031566	ADHESIVE LABEL		02
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
15	0503031425	ADHESIVE LABEL ATTENTION		02
16	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
17	0503031669	ADHESIVE LABEL		01
18	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
19	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503032930	ADHESIVE LABEL DANGER		05
21	0503031087	ADHESIVE LABEL		01
22	0503034003	SERIAL NUMBER TAG 61 X 118		01
23	0503010001	3.2 X 5.5 RIVET		04
24	0503032979	ADHESIVE LABEL LETTERS A B C D		02
25	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
001	0503034228	ADHESIVE LABEL PST FLEX PLUS LOWER (05 NOZZLES)		02
002	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		02
003	0503033892	ADHESIVE LABEL LOGO TATU HOPPER 190 X 720		01
004	0503034258	ADHESIVE LABEL		01
005	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
006	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
007	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
008	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
009	0503031428	READ MANUAL DECAL		01
010	0503031942	ADHESIVE LABEL		01
011	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
012	0503031565	ADHESIVE LABEL CARE		02
013	0503031566	ADHESIVE LABEL		02
014	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
015	0503031425	ADHESIVE LABEL ATTENTION		02
016	0503031669	ADHESIVE LABEL		01
017	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
018	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
019	0503032930	ADHESIVE LABEL DANGER		05
020	0503031087	ADHESIVE LABEL		01
021	0503034003	SERIAL NUMBER TAG 61 X 118		01
022	0503010001	3.2 X 5.5 RIVET		04
023	0503032979	ADHESIVE LABEL LETTERS A B C D		02
024	0503034500	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0503034228	ADHESIVE LABEL PST FLEX PLUS LOWER (05 NOZZLES)		01
02	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		01
03	0503033892	ADHESIVE LABEL LOGO TATU HOPPER 190 X 720		01
04	0503034258	ADHESIVE LABEL		01
05	0503033417	ADHESIVE LABEL		02
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
07	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
08	0503033423	LABEL ADHESIVE NUMBER 9		02
09	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
10	0503031428	READ MANUAL DECAL		01
11	0503031942	ADHESIVE LABEL		01
12	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
13	0503031565	ADHESIVE LABEL CARE		02
14	0503031566	ADHESIVE LABEL		02
15	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
16	0503031425	ADHESIVE LABEL ATTENTION		02
17	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
18	0503031669	ADHESIVE LABEL		01
19	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
21	0503032930	ADHESIVE LABEL DANGER		05
22	0503031087	ADHESIVE LABEL		01
23	0503034003	SERIAL NUMBER TAG 61 X 118		01
24	0503010001	3.2 X 5.5 RIVET		04
25	0503032979	ADHESIVE LABEL LETTERS A B C D		02
26	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503034228	ADHESIVE LABEL PST FLEX PLUS LOWER (05 NOZZLES)		02
02	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		02
03	0503033892	ADHESIVE LABEL LOGO TATU HOPPER 190 X 720		01
04	0503034258	ADHESIVE LABEL		01
05	0503033417	ADHESIVE LABEL		02
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
07	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
08	0503033423	LABEL ADHESIVE NUMBER 9		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	ADHESIVE LABEL		01
11	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
12	0503031565	ADHESIVE LABEL CARE		02
13	0503031566	ADHESIVE LABEL		02
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
15	0503031425	ADHESIVE LABEL ATTENTION		02
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503032930	ADHESIVE LABEL DANGER		05
19	0503031087	ADHESIVE LABEL		01
20	0503034003	SERIAL NUMBER TAG 61 X 118		01
21	0503010001	3.2 X 5.5 RIVET		04
22	0503032979	ADHESIVE LABEL LETTERS A B C D		02
23	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503033892	ADHESIVE LABEL LOGO TATU HOPPER 190 X 720	01	
02	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530	01	
03	0503034228	ADHESIVE LABEL PST FLEX PLUS LOWER (05 NOZZLES)	02	
04	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)	02	
05	0503034258	ADHESIVE LABEL	01	
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	02	
07	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	04	
08	0503033421	ADHESIVE LABEL 7 NUMBER FOR PLANTING	02	
09	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
10	0503031428	READ MANUAL DECAL	01	
11	0503031942	ADHESIVE LABEL	01	
12	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
13	0503031565	ADHESIVE LABEL CARE	02	
14	0503031566	ADHESIVE LABEL	02	
15	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
16	0503031425	ADHESIVE LABEL ATTENTION	02	
17	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER	02	
18	0503031669	ADHESIVE LABEL	01	
19	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
20	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
21	0503032930	ADHESIVE LABEL DANGER	07	
22	0503031087	ADHESIVE LABEL	01	
23	0503034003	SERIAL NUMBER TAG 61 X 118	01	
24	0503010001	3.2 X 5.5 RIVET	04	
25	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
26	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
001	0503034115	ADHESIVE LABEL		01
002	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530		02
003	0503033892	ADHESIVE LABEL LOGO TATU HOPPER 190 X 720		01
004	0503034258	ADHESIVE LABEL		01
005	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
006	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
007	0503033422	ADHESIVE LABEL		02
008	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
009	0503031428	READ MANUAL DECAL		01
010	0503031942	ADHESIVE LABEL		01
011	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
012	0503031565	ADHESIVE LABEL CARE		02
013	0503031566	ADHESIVE LABEL		02
014	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
015	0503031425	ADHESIVE LABEL ATTENTION		02
016	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
017	0503031669	ADHESIVE LABEL		01
018	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
019	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
020	0503032930	ADHESIVE LABEL DANGER		06
021	0503031087	ADHESIVE LABEL		01
022	0503034003	SERIAL NUMBER TAG 61 X 118		01
023	0503010001	3.2 X 5.5 RIVET		04
024	0503032979	ADHESIVE LABEL LETTERS A B C D		02
025	0503034500	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0503034115	ADHESIVE LABEL	01	
02	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530	02	
03	0503033892	ADHESIVE LABEL LOGO TATU HOPPER 190 X 720	01	
04	0503034258	ADHESIVE LABEL	01	
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
07	0503033422	ADHESIVE LABEL	02	
08	0503031428	READ MANUAL DECAL	01	
09	0503031942	ADHESIVE LABEL	01	
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27	02	
11	0503031565	ADHESIVE LABEL CARE	02	
12	0503031566	ADHESIVE LABEL	02	
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
14	0503031425	ADHESIVE LABEL ATTENTION	02	
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER	02	
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503032930	ADHESIVE LABEL DANGER	06	
19	0503031087	ADHESIVE LABEL	01	
20	0503034003	SERIAL NUMBER TAG 61 X 118	01	
21	0503010001	3.2 X 5.5 RIVET	04	
22	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
23	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521067033	FRAME LIFTING SUPPORT		01
03	0503017960	5/8" X 3-12" BOLT		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	59	04
13	0571018906	AXLE MOTOR 1950		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	103	02
16	0511051434	TRANSMISSION ACTUATOR	104	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	105	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	106	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		02
20	0501053788	3/4 SQUARE AXLE FASTENER	26	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING	27	02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
25	0503010025	3/8" SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	107	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
30	0503010140	1/8" X 3/4" COTTERPIN		02
31	0571018846	DISASSEMBLE LEVER		02

Item	Code	Description	See page	QT
32	0503033942	COMPACTOR WHEEL REGULATOR LID		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
37	0503012412	5/8 UNC SELF LOCKING NUT		04
38	0511061759	22Z P12,70 FQ 3/4" GEAR		02
39	0501053788	3/4 SQUARE AXLE FASTENER	26	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING	27	02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
44	0503010025	3/8" SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	107	02
47	0511065209	20Z GEAR		02
48	0501053788	3/4 SQUARE AXLE FASTENER	26	02
49	0503030303	SUPPORT WASHER		02
50	0503010292	701164 6 X 40 SPRING PIN		02
51	0521018630	1.4" X SQUARE 0.8" WASHER		02
52	0501056271	GEARBOX CLOSED BEARING	27	02
53	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
54	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
55	0503010025	3/8" SPRING WASHER		04
56	0503010026	3/8" NUT		04
57	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY		02
58	0511050652	CHAIN TENSIONER	109	04
59	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	110	02
60	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
61	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
62	0503015001	40-1 X 153 CHAIN LINK + MENDING		02
63	0511069678	LH LOWER LEVER		02
64	0551019159	LEVER FIXER BODY		02
65	0561016468	FASTENER		02
66	0503011336	1/2" HEX SELF ADJUSTING NUT		04
67	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
68	0503010140	1/8" X 3/4" COTTERPIN		04
69	0521055335	RIGHT GEAR HOUSING SET	112	01
70	0521055337	LEFT GEAR HOUSING SET	113	01




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		20
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	59	04
13	0571018906	AXLE MOTOR 1950		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	103	02
16	0511051434	TRANSMISSION ACTUATOR	104	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	105	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	106	01
19	0511058383	GEARBOX RIGHT/LEFT ASSY		01
20	0511061759	22Z P12,70 FQ 3/4" GEAR		02
21	0501053788	3/4 SQUARE AXLE FASTENER	26	06
22	0503030303	SUPPORT WASHER		06
23	0501056271	GEARBOX CLOSED BEARING	27	06
24	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		12
25	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		24
26	0503010025	3/8" SPRING WASHER		14
27	0503010026	3/8" NUT		14
28	0511059238	CHAIN TENSIONER		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		02
30	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
31	0503010140	1/8" X 3/4" COTTERPIN		02

Item	Code	Description	See page	QT
32	0571018846	DISASSEMBLE LEVER		02
33	0503033942	COMPACTOR WHEEL REGULATOR LID		02
34	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
35	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
36	0503030093	TRACTION SPRING		02
37	0503012407	5/8" X 1-1/2" BOLT		04
37.	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
38	0503012412	5/8 UNC SELF LOCKING NUT		04
39	0511061759	22Z P12,70 FQ 3/4" GEAR		02
40	0503030275	AGRICULTURAL BEARING		02
41	0511065209	20Z GEAR		02
42	0503011336	1/2" HEX SELF ADJUSTING NUT		04
43	0503010292	701164 6 X 40 SPRING PIN		02
44	0521018630	1.4" X SQUARE 0.8" WASHER		02
45	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY		01
46	0511050652	CHAIN TENSIONER	109	04
47	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	110	02
48	0511057265	TRANSMISSION CHAIN TENSIONER	107	01
49	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
50	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
51	0503015001	40-1 X 153 CHAIN LINK + MENDING		02
52	0511069678	LH LOWER LEVER		02
53	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
54	0503010140	1/8" X 3/4" COTTERPIN		04
55	0551019159	LEVER FIXER BODY		02
56	0561016468	FASTENER		02




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	59	04
13	0571018907	AXLE MOTOR 2125		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	103	02
16	0511051434	TRANSMISSION ACTUATOR	104	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	105	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	106	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		02
20	0501053788	3/4 SQUARE AXLE FASTENER	26	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING	27	02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
25	0503010025	3/8" SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	107	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
30	0503010140	1/8" X 3/4" COTTERPIN		02
31	0571018846	DISASSEMBLE LEVER		02

Item	Code	Description	See page	QT
32	0503033942	COMPACTOR WHEEL REGULATOR LID		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012407	5/8" X 1-1/2" BOLT		04
37	0503012412	5/8 UNC SELF LOCKING NUT		04
38	0511061759	22Z P12,70 FQ 3/4" GEAR		02
39	0501053788	3/4 SQUARE AXLE FASTENER	26	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING	27	02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
44	0503010025	3/8" SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	107	02
47	0511065209	20Z GEAR		02
48	0501053788	3/4 SQUARE AXLE FASTENER	26	02
49	0503030303	SUPPORT WASHER		02
50	0503010292	701164 6 X 40 SPRING PIN		02
51	0521018630	1.4" X SQUARE 0.8" WASHER		02
52	0501056271	GEARBOX CLOSED BEARING	27	02
53	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
54	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
55	0503010025	3/8" SPRING WASHER		04
56	0503010026	3/8" NUT		04
57	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY		02
58	0511050652	CHAIN TENSIONER	109	04
59	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	110	02
60	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
61	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
62	0503015001	40-1 X 153 CHAIN LINK + MENDING		02
63	0511069678	LH LOWER LEVER		02
64	0551019159	LEVER FIXER BODY		02
65	0561016468	FASTENER		02
66	0503011336	1/2" HEX SELF ADJUSTING NUT		04
67	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
68	0503010140	1/8" X 3/4" COTTERPIN		04
69	0521055335	RIGHT GEAR HOUSING SET	112	01
70	0521055337	LEFT GEAR HOUSING SET	113	01




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	59	04
13	0571018907	AXLE MOTOR 2125		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	103	02
16	0511051434	TRANSMISSION ACTUATOR	104	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	105	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	106	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		02
20	0501053788	3/4 SQUARE AXLE FASTENER	26	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING	27	02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
25	0503010025	3/8" SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	107	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
30	0503010140	1/8" X 3/4" COTTERPIN		02
31	0571018846	DISASSEMBLE LEVER		02

Item	Code	Description	See page	QT
32	0503033942	COMPACTOR WHEEL REGULATOR LID		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012407	5/8" X 1-1/2" BOLT		04
37	0503012412	5/8 UNC SELF LOCKING NUT		04
38	0511061759	22Z P12,70 FQ 3/4" GEAR		02
39	0501053788	3/4 SQUARE AXLE FASTENER	26	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING	27	02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
44	0503010025	3/8" SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	107	02
47	0501053788	3/4 SQUARE AXLE FASTENER	26	02
48	0503030303	SUPPORT WASHER		02
49	0503010292	701164 6 X 40 SPRING PIN		02
50	0521018630	1.4" X SQUARE 0.8" WASHER		02
51	0501056271	GEARBOX CLOSED BEARING	27	02
52	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
53	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
54	0503010025	3/8" SPRING WASHER		04
55	0503010026	3/8" NUT		04
56	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY		02
57	0511050652	CHAIN TENSIONER	109	04
58	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	110	02
59	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
60	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
61	0503015001	40-1 X 153 CHAIN LINK + MENDING		02
62	0531062318	LEFT/RIGHT LOWER LEVER		02
63	0551019159	LEVER FIXER BODY		02
64	0561016468	FASTENER		02
65	0503011336	1/2" HEX SELF ADJUSTING NUT		04
66	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
67	0503010140	1/8" X 3/4" COTTERPIN		04
68	0521055335	RIGHT GEAR HOUSING SET	112	01
69	0521055337	LEFT GEAR HOUSING SET	113	01
70	0511065209	20Z GEAR		02




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	59	04
13	0571018908	MOTOR SHAFT 2350		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	103	02
16	0511051434	TRANSMISSION ACTUATOR	104	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	105	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	106	01
19	0511058383	GEARBOX RIGHT/LEFT ASSY		01
20	0511061759	22Z P12,70 FQ 3/4" GEAR		02
21	0501053788	3/4 SQUARE AXLE FASTENER	26	02
22	0503030303	SUPPORT WASHER		04
23	0501056271	GEARBOX CLOSED BEARING	27	02
24	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
25	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
26	0503010025	3/8" SPRING WASHER		04
27	0503010026	3/8" NUT		04
28	0511059238	CHAIN TENSIONER		02
29	0521010773	0.37" X 1.18" COUPLING SHAFT		02
30	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
31	0503010140	1/8" X 3/4" COTTERPIN		02


Item	Code	Description	See page	QT
32	0571018846	DISASSEMBLE LEVER		02
33	0503033942	COMPACTOR WHEEL REGULATOR LID		02
34	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
35	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
36	0503030093	TRACTION SPRING		02
37	0503012407	5/8" X 1-1/2" BOLT		04
37.	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
38	0503012412	5/8 UNC SELF LOCKING NUT		04
39	0511061759	22Z P12,70 FQ 3/4" GEAR		02
40	0503030275	AGRICULTURAL BEARING		02
41	0511065209	20Z GEAR		02
42	0503011336	1/2" HEX SELF ADJUSTING NUT		04
43	0503010292	701164 6 X 40 SPRING PIN		02
44	0521018630	1.4" X SQUARE 0.8" WASHER		02
45	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY		02
46	0511050652	CHAIN TENSIONER	109	04
47	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	110	02
48	0511057265	TRANSMISSION CHAIN TENSIONER	107	01
49	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
50	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
51	0503015001	40-1 X 153 CHAIN LINK + MENDING		02
52	0511069678	LH LOWER LEVER		02
53	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
54	0503010140	1/8" X 3/4" COTTERPIN		04
55	0551019159	LEVER FIXER BODY		02
56	0561016468	FASTENER		02



Item	Code	Description	See page	QT
01	0531060421	MOTOR SUPPORT		01
02	0581019503	3/8" FASTENER		02
03	0503015135	FLAT WASHER 10 X 18 X 2		04
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0521052368	STRETCHER SIMPLE SEED	122	01
07	0503010282	1/4" X 3/4" BOLT		01
08	0503010143	1/4" SPRING WASHER		01
09	0561011665	FLAT WASHER		01
10	0521064025	TRACTOR HITCH		01
11	0503011807	SCREW M8 X 1,25X10		02
12	0503012682	1/2" BSW NUT		02
13	0503010019	1/2" SPRING WASHER		02
14	0503011082	C1/2" X 1.3/4" SCREW		02
15	0571012766	SUPPORT ENCODER		01
16	0503062754	GEAR 34Z P.1/2 APT		01
17	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
18	0502012007	SQUARE SLEEVE		01
19	0503010010	1/4" X 2.1/2" COTTERPIN		01




Item	Code	Description	See page	QT
01	0503010282	1/4" X 3/4" BOLT		01
02	0503010143	1/4" SPRING WASHER		01
03	0561011665	FLAT WASHER		01
04	0521064025	TRACTOR HITCH		01
05	0503011807	SCREW M8 X 1,25X10		02
06	0521069326	20Z CONICAL GEAR		01
07	0571012766	SUPPORT ENCODER		01
08	0511054314	TRANSMISSION AXLE LOCK SLEEVE		02
08A	0502012699	TRANSMISSION HUB LOCK SLEEVE		01
08B	0503010256	3/8" X 3/4" BOLT		01
09	0591012027	31,75 X 150 X 20,00 SLEEVE		01
10	0503010010	1/4" X 2.1/2" COTTERPIN		01
11	0521052368	STRETCHER SIMPLE SEED	122	01
12	0503012682	1/2" BSW NUT		02
13	0503010019	1/2" SPRING WASHER		02
14	0503011082	C1/2" X 1.3/4" SCREW		02
15	0503013064	40-1 X 43 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	59	04
13	0581012892	MOTOR SHAFT		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	103	02
16	0511051434	TRANSMISSION ACTUATOR	104	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	105	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	106	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		02
20	0501053788	3/4 SQUARE AXLE FASTENER	26	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING	27	02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
25	0503010025	3/8" SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	107	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
30	0503010140	1/8" X 3/4" COTTERPIN		02
31	0571018846	DISASSEMBLE LEVER		02


Item	Code	Description	See page	QT
32	0503033942	COMPACTOR WHEEL REGULATOR LID		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
37	0503012412	5/8 UNC SELF LOCKING NUT		04
38	0511061759	22Z P12,70 FQ 3/4" GEAR		02
39	0501053788	3/4 SQUARE AXLE FASTENER	26	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING	27	02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
44	0503010025	3/8" SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	107	02
47	0511065209	20Z GEAR		02
48	0501053788	3/4 SQUARE AXLE FASTENER	26	02
49	0503030303	SUPPORT WASHER		02
50	0503010292	701164 6 X 40 SPRING PIN		02
51	0521018630	1.4" X SQUARE 0.8" WASHER		02
52	0501056271	GEARBOX CLOSED BEARING	27	02
53	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
54	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
55	0503010025	3/8" SPRING WASHER		04
56	0503010026	3/8" NUT		04
57	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY		02
58	0511050652	CHAIN TENSIONER	109	04
59	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	110	02
60	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
61	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
62	0503015001	40-1 X 153 CHAIN LINK + MENDING		02
63	0511069678	LH LOWER LEVER		02
64	0551019159	LEVER FIXER BODY		02
65	0561016468	FASTENER		02
66	0503011336	1/2" HEX SELF ADJUSTING NUT		04
67	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
68	0503010140	1/8" X 3/4" COTTERPIN		04
69	0521055335	RIGHT GEAR HOUSING SET	112	01
70	0521055337	LEFT GEAR HOUSING SET	113	01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
001	0511069823	RH SEED BOX SIDE SUPPORT		01
002	0503060640	COVER BOX RIGHT FERTILIZER		01
003	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02
004	0503010849	3/8" X 1-1/2" BOLT		04
005	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
006	0503010025	3/8" SPRING WASHER		04
007	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0551019171	CHAIN TIGHTENER AXLE		01
02	0503011410	ROLLER BEARING		01
03	0511062169	21Z P 1/2" GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503011105	SEAL RING		01
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0571010265	16.5 X 40 X 3 FLAT WASHER		01
08	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	111	01
02	0511063185	20Z GEAR WITH HEX HOLE AXLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		02
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01



Item	Code	Description	See page	QT
01	0511058381	RIGHT GEAR HOUSING	114	01
02	0521065955	RIGHT GEARBOX LID		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0503010019	1/2" SPRING WASHER		01
07	0501010694	FLAT WASHER		06
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0511058382	LEFT GEAR HOUSING	115	01
02	0521065956	LEFT GEARBOX LID		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
07	0503010019	1/2" SPRING WASHER		01
08	0501010694	FLAT WASHER		06




Item	Code	Description	See page	QT
01	0521065939	RIGHT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN SHAFT		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	116	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING	27	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TIGHTENER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	117	02
20	0503031366	RIGHT TWISTED SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	118	01
31	0503010292	701164 6 X 40 SPRING PIN		08

Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	120	01
33	0511054363	CHAIN TENSIONER	121	01
34	0571018901	DRIVEN AXLE		01




Item	Code	Description	See page	QT
01	0521065940	LEFT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN SHAFT		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	116	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING	27	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TIGHTENER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	117	02
20	0503031367	SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	118	01
31	0503010292	701164 6 X 40 SPRING PIN		08


Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	120	01
33	0511054363	CHAIN TENSIONER	121	01
34	0571018901	DRIVEN AXLE		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	119	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0571019207	DEVIATION AXLE GEAR BOX		01
06	0503010899	5/8" X 2-1/4" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0581016479	CURRENT STRETCH SHAFT 81		01
02	0503030402	PULLEY		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521065950	FRAME HANDRAIL - 4045		02
02	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0581012916	INTERMEDIATE TUBE		02
07	0511059383	HANDRAIL INTERNAL FIXER		04




Item	Code	Description	See page	QT
01	0521065951	FRAME HANDRAIL - 4395		02
02	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0581012916	INTERMEDIATE TUBE		02
07	0511059383	HANDRAIL INTERNAL FIXER		04




Item	Code	Description	See page	QT
01	0521065952	FRAME HANDRAIL - 4845		02
02	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0581012916	INTERMEDIATE TUBE		02
07	0511059383	HANDRAIL INTERNAL FIXER		04




Item	Code	Description	See page	QT
01	0521065953	FRAME HANDRAIL - 5345		02
02	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0581012916	INTERMEDIATE TUBE		02
07	0511059383	HANDRAIL INTERNAL FIXER		04




Item	Code	Description	See page	QT
01	0531063064	FRAME HANDRAIL - 5745		02
02	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0581012916	INTERMEDIATE TUBE		02
07	0511059383	HANDRAIL INTERNAL FIXER		04




Item	Code	Description	See page	QT
01	0581011989	SIDE BODY FIXER PLATFORM		01
02	0551019884	45 X 50 X 3/8 FASTENER		01
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
07	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0503063631	KIT MONITORING SEED		01
01A	0503019725	CABLE		01
01B	0503019100	SENSOR		10
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
01E	0503017031	CLEANING BRUSH		01
01F	0503019720	NYLON CLAMP		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010669	FLAT WASHER		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0503063629	SEED MONITORING KIT 12 ROWS 45/50 PM400		01
01A	0503019727	SIMPLE CABLE		01
01B	0503019100	SENSOR		12
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
01E	0503017031	CLEANING BRUSH		01
01F	0503019720	NYLON CLAMP		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010669	FLAT WASHER		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0501012140	FLAT WASHER		01
02	0503010019	1/2" SPRING WASHER		01
03	0531062908	HOSE SUPPORT ARM		01
04	0531062907	ARTICULATOR HOSE		01
05	0513010322	LUBRICANT SLEEVE		01
06	0501210533	FLANGE WASHER		01
07	0503013776	BOLT 1/2 UNC X 7/8 C S G.5 ZN		01
08	0521067600	FIXER SUPPORT		01
09	0503010806	5/8" X 3" BOLT		01
10	0503012795	5/8" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0581019507	SUPPORT FILTER		01
02	0503010025	3/8" SPRING WASHER		04
03	0503010026	3/8" NUT		04
04	0581019503	3/8" FASTENER		02
05	0503015135	FLAT WASHER 10 X 18 X 2		04




Item	Code	Description	See page	QT
01	0503016509	BOLT 3/16 UNC		02
02	0503010667	3/16" NUT		02
03	0503010668	3/16" SPRING WASHER		02
04	0503010669	FLAT WASHER		02
05	0571016242	LIFT SENSOR SUPT		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
09	0503014734	BOLT		01
10	0521064979	LIFTING SENSOR DRIVING		01
11	0561016468	FASTENER		01
12	0503011336	1/2" HEX SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0503062840	010080970 - 10 ROWS 450/500 ISOBUS KIT		01
01A	0503015065	MASTER CONTROL MODULE		01
01B	0503015066	CABLE CONTROL MASTER MODULE		01
01C	0503015479	TRACTOR CONNECTION CABLE ISO		01
01D	0503015071	CONCTOR		01
01E	0503015220	ENCODER ISOB 4,5M 464360171S1		02
01F	0503018734	SIMPLE CABLE		01
01G	0503017443	ANTENNA GPS PM 400		01
01H	0503017031	CLEANING BRUSH		01
01I	0503015218	SENSOR FOTOELE PM 400		10
02	0521055015	PARKER OMP 80 HYDRAULIC MOTOR WITH 136 VALVE		02
03	0511056972	FILTER HYDAC	137	01
04	0503017984	LIFT SENSOR		02
05	0503019023	CABLE GLAND		01
06	0503019017	WRENCH		01
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		200



Item	Code	Description	See page	QT
01	0503016055	PARKER OMP 80 ISOBUS HYDRAULIC MOTOR		01
02	0503010045	O'RING		02
03	0503019320	VALVE		01
04	0501010590	NIPPLE		02




Item	Code	Description	See page	QT
01	0503016376	FILTER SPRING		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	T 7/8" ADAPOR GIRAT NUT		01
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	139	01
01.	0521054984	DEPTH/COMPACTOR SYSTEM - SPT	163	01
01..	0521056317	DEPTH CONTROL WITH LEVER ANGLE REGULATOR AXIS CPERA	140	01
01...	0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	141	01
01....	0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	142	01
02	0511056621	RIGHT REAR SEED ROW	173	01
02.	0511056628	REAR RIGHT	174	01
03	0511056622	LEFT REAR SEED ROW	175	01
03.	0511056629	LEFT REAR	176	01
04	0511057277	FRONT SHORT SEED ROW WITH RIGHT TRANSMISSION	183	01
04.	0511057290	SEED ROW FRONT SHORT WITH TRANSMISSION	184	01
04..	0521058525	SHORT SEED ROW	196	01
05	0511057278	FRONT LONG SEED ROW WITH RIGHT TRANSMISSION	185	01
05.	0511057291	SEED ROW FRONT SHORT WITH TRANSMISSION	186	01
05..	0521058526	FRONT SEED ROW	206	01
06	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2 UNC G.5 ZN HEX NUT		01
09	0503062066	DISC SET WITH CORN RING	257	01
10	0503062067	DISC SET / RING SOY 90F TITANIUM	258	01
11	0511052024	FAST CLOSING SET	195	01
12	0503033672	NOZZLE WITHOUT TITANIUM		01
12.	0503035402	HIGHER LINE HIGH SEED		01
13	0503010905	1/2" X 2-1/4" BOLT		01
14	0503010019	1/2" SPRING WASHER		01
15	0503010060	1/2 UNC G.5 ZN HEX NUT		01
16	0511059023	SEED SYSTEM ASSY	209	01

Item	Code	Description	See page	QT
16.	0521050096	SEED HOPPER SYSTEM (CSU)	213	01
17	0531055312	TITANIUM SINGLE SEED SYSTEM	215	01
18	0503063193	CHAIN ASSY		01
19	0503063194	CHAIN ASSY		01
20	0521068982	DISC BLADE HUB KEY		01
21	0503031145	2" X 2" X 20" HOSE		01
22	0503031076	2" HOSE CLAMP		01
23	0511058639	SHORT FERTILIZER ROW WITH DDD/DC20	218	01
23.	0511058635	SHORT FERTILIZER ROW DDD 18" BLADE DISC	219	01
23..	0521050673	SHORT FERTILIZER ROW	220	01
23...	0511058641	SHORT FERTILIZER ROW	221	01
23....	0511059051	SHORT FERTILIZER ROW	222	01
23.....	0521056477	SHORT FERTILIZER ROW DC20 WITHOUT LUBRICATION	242	01
24	0511058640	LONG FERTILIZER ROW WITH DDD/DC20	223	01
24.	0511058636	LONG FERTILIZER ROW DDD 18" BLADE DISC	224	01
24..	0521050674	LONG FERTIL ROW	225	01
24...	0511058642	LONG FERTIL ROW	226	01
24....	0511059052	SHORT ROW FERTILIZER	227	01
24.....	0521056479	LONG DC20 FERTILIZER ROW WITHOUT LUBRICATION	243	01
25	0531052986	PIVOT SUPPORT	132	01
26	0521057957	FIXED ROD EXTENSION WITH FIXATION	247	01
27	0521050342	HDA WITH RIGHT NOZZLE	248	01
27.	0521053949	SCARIFIER SPINDLE WITH SOCKET RIGHT	249	01
28	0521050343	HDA WITH LEFT NOZZLE	250	01
28.	0521053948	SCARIFIER SPINDLE WITH SOCKET LEFT	251	01
29	0511057984	V-COVERING RUBBER WHEEL - SHORT ROW	261	01
30	0511057985	V-COVERING RUBBER WHEEL - LONG ROW	262	01
31	0503030391	RIGHT FERTILIZER NOZZLE		01
32	0503030392	LEFT FERTILIZER NOZZLE		01
33	0571011730	SEED CONDUCTOR 3" X 1500		01
34	0503031050	CURVED CONDUCTOR		01
35	0503010246	CLAMP		01
36	0521050525	FIXER FERTILIZER CONDUCTOR	259	01
37	0531013600	PRESS ADJUSTMENT LEVER		01
38	0501110804	SCARIFIER ROD WITH POINT	260	01
39	0521069127	BOTTOM NOZZLE FERTILIZER		01
40	0503030520	SEED SOCKET		01
41	0511017969	0.1" SPACING PLATE		01
42	0511018662	SPACING PLATE		01
43	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
44	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
45	0503010025	3/8" SPRING WASHER		01
46	0503010026	3/8" NUT		01
47	0521054769	LEFT DDD FERTILIZER WITH SUPPORT	263	01
48	0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	265	01



Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	143	01
02	0501052538	DEPTH BAND WITH ARMS	146	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	147	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	148	01
07	0503033942	COMPACTOR WHEEL REGULATOR LID		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
03	0521019093	0.6" X 2.7" PIVOT SHAFT		01
04	0503010581	RING		01
05	1902012116	PRESS WHEEL ADJUSTER		01
06	0501052297	DEPTH WHEELS REGULATOR ASSY	165	01
07	0501052908	COMPACTOR WHEEL WITH BEARING	161	02
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
09	0521014508	FLAT WASHER		10
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0581011100	DEPTH WHEEL AXLE		01
12	0571017749	FLAT WASHER		02
13	0521056314	LEFT ARM WHEEL DEPTH WITH HUB CPERA	149	01
14	0521056313	RIGHT ARM WHEEL DEPTH WITH HUB CPERA		01
15	0503010358	5/16" X 5/8" BOLT		08
16	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
17	0503013816	5/16" LOCKNUT		08
18	0501011445	FLAT WASHER		02
19	0503010311	1/2" X 1-1/4" BOLT		02
20	0503010019	1/2" SPRING WASHER		02
21	0503010025	3/8" SPRING WASHER		02
22	0503010026	3/8" NUT		02
23	0503010849	3/8" X 1-1/2" BOLT		02
24	0503010256	3/8" X 3/4" BOLT		01
25	0511055819	DEPTH BAND WITH RIM	162	02
26	0503010691	1/4" GREASE FITTING		02
27	0503033942	COMPACTOR WHEEL REGULATOR LID		01
28	0521064073	REGULACION WHEEL COMPACTOR		01
29	0541016906	PRESS WHEELS REGULATOR BODY		01
30	0521010539	0.3" X 1.2" COUPLING SHAFT		01
31	0503010140	1/8" X 3/4" COTTERPIN		01




PST PLUS FLEX TITANIUM - FRAME -
DEPTH CONTROL WITH LEVER ANGLE REGULATOR AXIS

Page 140
0521056317


Item	Code	Description	See page	QT
32	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0581014858	DEPTH WHEEL AXLE		01
04	0501110720	ARM LEFT		01
05	0501110719	DEPTH CONTROL RIGHT ARM		01
06	0502012663	EXTENSION		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY		01
09	0503034793	ARTICULATION SLEEVE		02
10	0521051423	COMPACTOR SUPPORT	151	01
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503016453	1/2" X 2.1/2 BOLT		02
14	0503034817	SPRING		01
15	0503010581	RING		01
16	0503034377	3/8 UNC X 3/4 BOLT		01
17	0503010019	1/2" SPRING WASHER		08
18	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
19	0503010060	1/2 UNC G.5 ZN HEX NUT		04
20	0501052908	COMPACTOR WHEEL WITH BEARING	161	02
21	0503013739	1/2" X 1" BOLT		01
22	0511050077	WHEEL STRIPED	152	02
23	0503010752	1/2" X 3.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	154	01
02	0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	160	01
03	0501052908	COMPACTOR WHEEL WITH BEARING	161	02
04	0503010019	1/2" SPRING WASHER		06
05	0503010752	1/2" X 3.1/2" BOLT		01
06	0503013739	1/2" X 1" BOLT		01
07	0503010479	BOLT		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503030012	HITCH PIN CLIP		01
10	0571013222	FIXING CHOCK		01
11	0503010741	1/2" X 2-3/4" BOLT		02
12	0511055819	DEPTH BAND WITH RIM	162	02
13	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
14	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	144	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	145	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	165	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL HUB		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL HUB		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	161	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	161	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0521056316	DEPTH WHEEL HUB WITH COMPLETE ANGLE 150 ADJUSTING AXLE		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501013636	SPACING SLEEVE		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010689	SEAL 00763-BR		01
04	0503011105	SEAL RING		01
05	0503010269	6204 BALL BEARING		02
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0521019178	PROTECTION LID		01
09	0503010143	1/4" SPRING WASHER		03
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0521060071	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0521068003	RIGHT SIDE		01
02	0521068002	LEFT SIDE		01
03	0581014847	PLATE UPPER		01
04	0581015855	SLEEVE		02
05	0521068004	HANDLE BODY		01
06	0581014969	GUIDE SLEEVE		01
07	0581014968	SLEEVE FLANGE		01
08	0503010937	5/16" X 3" BOLT		02
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0521068005	LEVER		01
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
12	0503010337	5/16" NUT		04
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2 UNC G.5 ZN HEX NUT		01
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010882	BOLT		02
17	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
18	0503030878	LEVER CRANK		01
19	0581015854	RIGHT PROTECTION COVER		01
20	0581015853	LEFT PROTECTION COVER		01
21	0581015903	SPACER WASHER		01




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	153	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEEL HUB		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0521063808	DEPTH CONTROL INNER COLUMN CONTROL WITH SCREW		01
02	0521063809	DEPTH CONTROL EXTERNAL COLUMN CONTROL WITH SCREW		01
03	0571013194	REGULATOR SPINDLE		01
04	0551010616	ROD HEX		01
05	0503010683	0,2" X 1,2" SPRING PIN		01
06	0571013202	COVERING WHEEL REGULATOR AXLE		01
07	0521063812	REGULATOR LEVER ALXE		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		01
09	0511065308	LOCK REGULATOR		01
10	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
11	0541011627	FLAT WASHER		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0511059325	LEFT ARM COVERED WHEEL ASSEMBLED	155	01
14	0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED	156	01
15	0571014709	SLEEVE LOCK CONTROL ARM		02
16	0503011440	SPRING WASHER		03
17	0503819099	BOLT		02
18	0511051546	CUBE RIGHT CONTROL DEPTH	157	01
19	0511051547	LEFT CUBE CONTROL DEPTH	159	01
20	0503011442	3/4" SPRING WASHER		02
21	0571013189	SLEEVE SUPPORT BEATER		01
22	0521063813	WHEEL PRESS BEATER		01
23	0501010937	13,50 X 28 X 3,00 FLAT WASHER		01
24	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01




Item	Code	Description	See page	QT
01	0502012844	LEFT ARM WHEELS		01
02	0581011340	ARM CASE		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	COVERING WHEEL ARM SUPPORT SLEEVE		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012843	RIGHT WHEEL ARM		01
02	0581011340	ARM CASE		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	COVERING WHEEL ARM SUPPORT SLEEVE		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	158	01
02	0511066638	RIGHT AXLE WITH DUST CLOAK		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	PROTECTION LID		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0502011907	DEPTH CONTROL WHEEL HUB		01
02	0503010269	6204 BALL BEARING		02
03	0501013636	SPACING SLEEVE		01
04	0503010689	SEAL 00763-BR		01
05	0503011105	SEAL RING		01
06	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	158	01
02	0511066637	LEFT AXLE WITH DUST CLOAK		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	PROTECTION LID		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0502012850	PRESS WHEELS ARM		01
02	0503030883	RIGHT TORSION SPRING		01
03	0502011066	PRESS WHEELS ARM SUPPORT		01
04	0531017415	1" X 4.72" AXLE JOINT		01
05	0503010839	03"X 0.6" SPRING PIN		01
06	0521063841	REGULATOR RIGHT COMPACTOR		01
07	0521063842	REGULATOR LEFT COMPACTOR		01
08	0503811404	BOLT		02
09	0503011443	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0571013295	ALXE REGULATOR COMPACTOR		01
12	0521063812	REGULATOR LEVER ALXE		01
13	0503011336	1/2" HEX SELF ADJUSTING NUT		02
14	0511065308	LOCK REGULATOR		01
15	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
16	0541011627	FLAT WASHER		01
17	0503010140	1/8" X 3/4" COTTERPIN		01
18	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW		01
19	0503811172	BOLT		01
20	0503010002	1800 GREASE FITTING		01
21	0581013744	PROTECTION CASE		01
22	0503813096	BOLT		01
23	0503013816	5/16" LOCKNUT		0




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	164	01
02	0501052538	DEPTH BAND WITH ARMS	146	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL	171	01
06	0521055017	RIGHT COMPACTOR WHEEL	170	01




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	165	01
02	0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	166	01
03	0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	167	01
04	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	169	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	3/8 UNC X 3/4 BOLT		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED SLEEVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	168	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	168	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL HUB		01
02	0581019515	AXIS		01
03	0503034055	CLAMPING RING		01
04	0581019168	DUST CLOAK		01
05	0503013758	1/4" X 1-1/2" BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0503010878	5/8" SELF ALIGNING NUT		01
10	0503030757	2.9" X 2" X 0.02" JOINT		01
11	0521019178	PROTECTION LID		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT SLEEVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	172	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	172	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8	177	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	50	01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8	177	01
02	0503033672	NOZZLE WITHOUT TITANIUM		01
03	0501058972	ASSEMBLY SENSOR ELECTRONIC	178	01
04	0503015920	3/8" UNC X 1.3/4" BOLT		04
05	0503011443	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	50	01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8	177	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511056586	15 X 15 SEED DDD LEFT	179	01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8	177	01
02	0503033672	NOZZLE WITHOUT TITANIUM		01
03	0501058972	ASSEMBLY SENSOR ELECTRONIC	178	01
04	0503015920	3/8" UNC X 1.3/4" BOLT		04
05	0503011443	3/8" SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511056586	15 X 15 SEED DDD LEFT	179	01




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502012639	12Z LOWER CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503015218	SENSOR FOTOELE PM 400		01
02	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		03




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	180	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	181	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	182	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02



Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01



Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0502012804	PIVOT ARM SEED ROW		02
05	0571018882	SEED ROW ARM SLEEVE		08
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8 UNC SELF LOCKING NUT		04
08	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
09	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
10	0571018883	PIN FIXER SPRING		03
11	0571018884	LOCK PIN ROW ARTICULAT		01
12	0503030168	HITCH PIN CLIP		04
13	0511058766	BEARING	187	01
14	0511057159	TRANSMISSION HOPPER SEED ROW	188	01
15	0571012492	5/8 X 330 AXLE HEX		01
16	0501056296	UNIVERSAL JOINT		01
17	0503011855	0.2" X 1.8" SPRING PIN		03
18	0521065942	FRAME REAR SHORT ROW SEED		01
19	0511057269	CHAIN TENSIONER	189	01
20	0511059872	BEARING	190	01
21	0581010239	SEED ROW AXLE TRANSMISSION		01
22	0521011859	FLAT WASHER		02
23	0581011694	PROTECTION REAR COVER SEED ROW		01
24	0503010765	3/8" X 3" BOLT		01
25	0503010025	3/8" SPRING WASHER		01
26	0503010026	3/8" NUT		01
27	0501012140	FLAT WASHER		08
28	0511058512	PROTECTION LID	191	01
29	0581011430	DRAWBAR ASSY		01
30	0581010976	5/8" HEX AXLE		01
31	0503032984	HOOD HEX AXLE ROW		01




PST PLUS FLEX TITANIUM - FRAME -
FRONT SHORT SEED ROW WITH RIGHT TRANSMISSION

Page 183
0511057277

Item	Code	Description	See page	QT
32	0503010004	1890 GREASE FITTING		04
33	0503013100	NYLON CLAMP		01
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
35	0503017857	BOLT 5/8 UNF 4		04



Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0501012140	FLAT WASHER		04
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8 UNC SELF LOCKING NUT		04
08	0502012804	PIVOT ARM SEED ROW		02
09	0571018882	SEED ROW ARM SLEEVE		08
10	0503010002	1800 GREASE FITTING		03
11	0503010004	1890 GREASE FITTING		01
12	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
13	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
14	0571018883	PIN FIXER SPRING		03
15	0571018884	LOCK PIN ROW ARTICULAT		01
16	0503030168	HITCH PIN CLIP		04
17	0511057275	TRANSMISSION WITH LEFT SUPPORT	192	01
18	0521065942	FRAME REAR SHORT ROW SEED		01
19	0511057269	CHAIN TENSIONER	189	01
20	0511057274	TRANSMISSION LOWER FRONT SEED ROW SHORT	194	01
21	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
22	0581012950	LEFT REAR PROTECTION SEED ROW COVER		01
23	0503010765	3/8" X 3" BOLT		01
24	0503010025	3/8" SPRING WASHER		01
25	0503010026	3/8" NUT		01
26	0511058512	PROTECTION LID	191	01
27	0581011430	DRAWBAR ASSY		01




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0502012804	PIVOT ARM SEED ROW		02
05	0571018882	SEED ROW ARM SLEEVE		08
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8 UNC SELF LOCKING NUT		04
08	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
09	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
10	0571018883	PIN FIXER SPRING		03
11	0571018884	LOCK PIN ROW ARTICULAT		01
12	0503030168	HITCH PIN CLIP		04
13	0511058766	BEARING	187	01
14	0511057159	TRANSMISSION HOPPER SEED ROW	188	01
15	0571012492	5/8 X 330 AXLE HEX		01
16	0501056296	UNIVERSAL JOINT		01
17	0503011855	0.2" X 1.8" SPRING PIN		03
18	0521065943	REAR FRAME LONG ROW SEED		01
19	0511057269	CHAIN TENSIONER	189	01
20	0511059872	BEARING	190	01
21	0581010240	SEED ROW AXLE TRANSMISSION		01
22	0521011859	FLAT WASHER		02
23	0581011694	PROTECTION REAR COVER SEED ROW		01
24	0503010765	3/8" X 3" BOLT		01
25	0503010025	3/8" SPRING WASHER		01
26	0503010026	3/8" NUT		01
27	0501012140	FLAT WASHER		08
28	0511058512	PROTECTION LID	191	01
29	0581011430	DRAWBAR ASSY		01
30	0581010976	5/8" HEX AXLE		01
31	0503032984	HOOD HEX AXLE ROW		01




PST PLUS FLEX TITANIUM - FRAME -
FRONT LONG SEED ROW WITH RIGHT TRANSMISSION

Page 185
0511057278


Item	Code	Description	See page	QT
32	0503010004	1890 GREASE FITTING		04
33	0503013100	NYLON CLAMP		01
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
35	0503017857	BOLT 5/8 UNF 4		04




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0501012140	FLAT WASHER		04
05	0503010811	5/8\" UNF SELF ADJUSTING NUT		04
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8 UNC SELF LOCKING NUT		04
08	0502012804	PIVOT ARM SEED ROW		02
09	0571018882	SEED ROW ARM SLEEVE		08
10	0503010002	1800 GREASE FITTING		03
11	0503010004	1890 GREASE FITTING		01
12	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
13	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
14	0571018883	PIN FIXER SPRING		03
15	0571018884	LOCK PIN ROW ARTICULAT		01
16	0503030168	HITCH PIN CLIP		04
17	0511057275	TRANSMISSION WITH LEFT SUPPORT	192	01
18	0521065943	REAR FRAME LONG ROW SEED		01
19	0511057269	CHAIN TENSIONER	189	01
20	0511057293	FRONT LOWER TRANSMISSION		01
21	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
22	0581012950	LEFT REAR PROTECTION SEED ROW COVER		01
23	0503010765	3/8\" X 3\" BOLT		01
24	0503010025	3/8\" SPRING WASHER		01
25	0503010026	3/8\" NUT		01
26	0511058512	PROTECTION LID	191	01
27	0581011430	DRAWBAR ASSY		01




Item	Code	Description	See page	QT
01	0502012852	ROW SEED UPPER BEARING		01
02	0503011105	SEAL RING		01
03	0502012851	17Z GEAR WITH HEX HOLE		01
04	0503011410	ROLLER BEARING		02
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010237	3/8" X 1" BOLT		02
07	0503010025	3/8" SPRING WASHER		02
08	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503031805	11Z 1/2" GEAR		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0581012948	HOUSING BEARING		01
02	0503011105	SEAL RING		01
03	0581012949	BEARING COVER		01
04	0503011410	ROLLER BEARING		02
05	0503018045	2-130 (AGEL) O'RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0502012851	17Z GEAR WITH HEX HOLE		01
08	0503011953	5/16" X 1" BOLT		02
09	0501010694	FLAT WASHER		02
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
11	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521066693	CAP BEARING		01
02	0503010834	1/2 X 1 BOLT		02
03	0503010019	1/2" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0511059873	TOP LEFT BEARING WITH ROW		01
02	0511057273	ASSEMBLY TRANSMISSION	193	01
03	0503010300	5/32" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0511057159	TRANSMISSION HOPPER SEED ROW	188	01
02	0503032984	HOOD HEX AXLE ROW		01
03	0503013100	NYLON CLAMP		01
04	0571012492	5/8 X 330 AXLE HEX		01
05	0501056296	UNIVERSAL JOINT		01
06	0581010976	5/8" HEX AXLE		01
07	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0511059872	BEARING	190	01
02	0581010239	SEED ROW AXLE TRANSMISSION		01
03	0521011859	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0521056944	REAR FRAME	198	01
02	0521058524	SEED ROW FRONT	197	01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		02
04	0503010019	1/2" SPRING WASHER		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
06	0511017303	FLAT WASHER		04
07	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
08	0503012880	1/4" UNC SELF ADJUSTING NUT		02
09	0503015135	FLAT WASHER 10 X 18 X 2		01
10	0503010026	3/8" NUT		01
11	0501011643	3/8 X 1" BOLT		01
12	0591014600	ENCAPSULATED CURRENT FIXER		01
13	0503013815	1/4" X 5/8" BOLT		02
14	0503011295	M 8 X 1,25 X 25 BOLT		02
15	0591014601	BEARING SUPPORT		01
16	0591014602	CHAIN GUIDE		01




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
04	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN	02	
05	0502012812	SEED ROW ADJUSTMENT LEVER ASSY	01	
06	0503034198	SPRING TRACTION 40 X 198 X 5,5	01	
07	0571018883	PIN FIXER SPRING	03	
08	0503030168	HITCH PIN CLIP	04	
09	0501012140	FLAT WASHER	04	
10	0503017857	BOLT 5/8 UNF 4	04	
11	0591011156	PIVOT ARM SEED ROW	02	
12	0591011157	SPACER LOWER SLEEVE	04	
13	0503019273	AUTO LUBRICANT SLEEVE	08	
14	0503010045	O'RING	08	
15	0531061528	REAR SUPPORT ROW	01	
16	0591012829	SPACER LOWER SLEEVE	04	
17	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	02	
18	0503013389	5/8" SELF LOCKING NUT	04	
19	0591011409	FLAT WASHER 16,5 X 35 X 3,00	04	
20	0591012828	LOCK PIN ROW ARTICULAT	01	




Item	Code	Description	See page	QT
01	0521056955	RIGHT DDD ASSY	199	01
02	0503012136	NUT 1/2 NF		04
03	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
04	0521056582	TITANIUM SEED METER SET	204	01




Item	Code	Description	See page	QT
01	0591011773	RIGHT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 202 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 200 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	201	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUB DISC - HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	203	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0521056639	SEED ROW TRANSMISSION	205	01
02	0503034575	TITANIUM HIGH ROW SEED NOZZLE		01
03	0503010257	1/8" X 1" COTTERPIN		01
04	0502012743	FAST BOLT ASSY		01
05	0571014024	FAST BOLT GUIDE AXLE		02
06	0561019270	FAST BOLT ADJUSTMENT		01
07	0502012744	SPEED LOCK LEVER ASSY		01
08	0502012921	BASE FIXING SYSTEM		01
09	0503010026	3/8" NUT		04
10	0503010025	3/8" SPRING WASHER		04
11	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04




Item	Code	Description	See page	QT
01	0502012932	MINOR SIDE		01
02	0503017046	BEARING		02
03	0503011410	ROLLER BEARING		02
04	0591011321	AXLE GEAR		01
05	0591011322	SPACER		01
06	0581019168	DUST CLOAK		01
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
08	0503010025	3/8" SPRING WASHER		01
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
10	0503011945	503050 CLAMPING RING (FOR AXLE)		01
11	0503010420	BOLT		02
12	0503011053	5/16" X 3" C S 6.5 ZN BOLT		04
13	0502012919	GRAGGER		01
14	0502012933	LARGER SIDE		01
15	0502012930	CONICAL GEAR		01
16	0502012931	CONICAL GEAR		01
17	0503010585	0,24" X 1.18" SPRING PIN		01




Item	Code	Description	See page	QT
01	0521058524	SEED ROW FRONT	197	01
02	0591014603	BEARING SUPPORT		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		02
04	0503010019	1/2" SPRING WASHER		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
06	0591014604	GUIDE CHAIN LEFT		01
07	0511017303	FLAT WASHER		04
08	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
09	0503012880	1/4" UNC SELF ADJUSTING NUT		02
10	0503015135	FLAT WASHER 10 X 18 X 2		01
11	0503010026	3/8" NUT		01
12	0501011643	3/8 X 1" BOLT		01
13	0591014600	ENCAPSULATED CURRENT FIXER		01
14	0503013815	1/4" X 5/8" BOLT		02
15	0503011295	M 8 X 1,25 X 25 BOLT		02
16	0521056945	REAR FRAME	207	01
17	0531061136	EXTENSION		01
18	0503012136	NUT 1/2 NF		04
19	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04




Item	Code	Description	See page	QT
01	0521056954	LEFT DDD ASSY	208	01
02	0503012136	NUT 1/2 NF		04
03	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
04	0521056582	TITANIUM SEED METER SET	204	01




Item	Code	Description	See page	QT
01	0591011772	LEFT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 202 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 200 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0502020693	SUPPORT SEED BOX		01
02	0502012721	SEED DISC LOWER TRAIL		01
03	0503034131	DEFLECTOR		01
04	0503010025	3/8" SPRING WASHER		03
05	0503010209	3/8" UNC BUTTERFLY NUT		03
06	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		04
07	0571018536	HEX PRISONER		01
08	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
09	0503010337	5/16" NUT		01
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
11	0503062582	DEPOSIT SEED		01
12	0581011346	ADAPTER DEPOSIT		01
13	0501010694	FLAT WASHER		04
14	0503016282	ALLEN BOLT		01
15	0503016283	M8 NUT HEX		01
16	0501051094	ASSY SEED DISTRIBUTOR	210	01
17	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
18	0503016219	RING TO SOYBEANS		01
19	0503010675	5/16" X 2.1/4" BOLT		01
20	0503030083	3/8" X 3/8" X 1.6" STUD		02




Item	Code	Description	See page	QT
01	0503030381	SEED DISTRIBUTOR BOX		01
02	0502010447	TRIGGER		02
03	0501013467	KEY AXLE		01
04	0503030378	0.4" X 1.1" X 0.03" SPRING		03
05	0501013466	KEY LIMITER AXLE		01
06	0501051119	DOUBLE PULLEY ROCKER'S	211	01
07	0501013468	ROCKER ARM AXLE, OF THE PULLEY		01
08	0503030377	SCRAPER		01




Item	Code	Description	See page	QT
01	0503031129	DOUBLE PULLEY ROCKER ARM		01
02	0503031128	5Z PLASTIC DOUB PULLEY FOR SOYBEAN		02
03	0521010649	TOOTH PULLEY COUPLING SHAFT		01
04	0503011853	503050 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0521050118	3" NOZZLE SEED HOPPER		01
02	0581014295	FIXING SLEEVE		01
03	0511052058	SEED SYSTEM TITANIUM	214	01
04	0503010358	5/16" X 5/8" BOLT		05
05	0501010694	FLAT WASHER		05
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
07	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
09.	0503016279	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01
14	0503062044	ASSEMBLY SEED HOPPER SET		01
14A	0503016285	BOLT		05
14B	0503016286	HEX NUT		05
14C	0503016287	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0511052058	SEED SYSTEM TITANIUM	214	01
02	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
03	0503010337	5/16" NUT		05
04	0501010694	FLAT WASHER		05
05	0503010358	5/16" X 5/8" BOLT		05
06	0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	216	01




Item	Code	Description	See page	QT
01	0503015536	M6 X 1" SELF ADJUSTING NUT		04
02	0581014295	FIXING SLEEVE		01
03	0501213431	SEED NOZZLE FIXING FLANGE		01
04	0501213520	SEED BREAKER BODY		01
05	0501213432	BREAKER SUPPORT BASE		01
06	0501213728	60 X 53 X 30 PVC TUBE		01
07	0513010720	M6 X 1 X 35 C S G.5 ZB BOLT		04
08	0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK 217 LID		01




Item	Code	Description	See page	QT
01	0503035751	SIGMA SINGLE SEED HOPPER		01
02	0503035750	SEED HOPPER LID		01
03	0503035298	BAKELITE HANDLE WITH THREAD		01
04	0503015536	M6 X 1" SELF ADJUSTING NUT		01
05	0503035297	CURVED NOZZLE SEED HOPPER		01







Item	Code	Description	See page	QT
01	0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	228	01
01A	0502012794	SHORT SUPPORT FERTILIZER ROW		01
02	0511058629	18" COULTER BLADE ASSY FOR SHORT ROW	240	01
03	0503011854	5/8" X 1-1/4" BOLT		02
04	0503010002	1800 GREASE FITTING		01
05	0502012789	FIXER SUPPORT FERTILIZER ROW		01
06	0503017960	5/8" X 3-12" BOLT		04
07	0503010811	5/8" UNF SELF ADJUSTING NUT		04
08	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
09	0571019062	SLEEVE		01
10	0571019059	SUPPORT WASHER		01
12	0503034320	COMPRESSION SPRING		01
13	0502012813	FLANGE WASHER SPRING		01
14	0503010417	7/8" NUT		02
15	0511016281	3/4" X 8" BOLT		02
16	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
17	0503011255	3/4" LOCK NUT		02
18	0511057272	LH SHORT ARM ROW FERTILIZER	229	01
18A	0521065972	LH SHORT ARM ROW FERTILIZER		01
18B	0502012815	DOUBLE-DISC SPACING PLATE		02
18C	0503810479	BOLT		02
18D	0503011440	SPRING WASHER		04
18E	0503010060	1/2 UNC G.5 ZN HEX NUT		04
19	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	230	01
20	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	228	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057272	LH SHORT ARM ROW FERTILIZER	229	01
06	0521050672	LONG OSCILLATING DOUBLE DISC 20	232	01




Item	Code	Description	See page	QT
01	0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	228	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0521065972	LH SHORT ARM ROW FERTILIZER		01
06	0511058630	20" DISC BLADE	231	01




Item	Code	Description	See page	QT
01	0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	228	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057272	LH SHORT ARM ROW FERTILIZER	229	01
06	0511059050	DOC 20" ASSY	235	01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	237	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057271	RH LONG ARM ROW FERTILIZER	238	01
06	0511058630	20" DISC BLADE	231	01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	237	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057271	RH LONG ARM ROW FERTILIZER	238	01
06	0511058629	18" COULTER BLADE ASSY FOR SHORT ROW	240	01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	237	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057271	RH LONG ARM ROW FERTILIZER	238	01
06	0521050672	LONG OSCILLATING DOUBLE DISC 20	232	01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	237	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0521065973	RH LONG ARM ROW FERTILIZER		01
06	0511058630	20" DISC BLADE	231	01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	237	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057271	RH LONG ARM ROW FERTILIZER	238	01
06	0511059050	DOC 20" ASSY	235	01




Item	Code	Description	See page	QT
01	0502012794	SHORT SUPPORT FERTILIZER ROW	01	
02	0503011854	5/8" X 1-1/4" BOLT	02	
03	0503010002	1800 GREASE FITTING	01	
04	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
05	0503017960	5/8" X 3-12" BOLT	04	
06	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
07	0521066744	FERTILIZER ROW ADJUSTMENT SPRING	01	
08	0571019062	SLEEVE	01	
09	0571019059	SUPPORT WASHER	01	
10	0503010417	7/8" NUT	04	
11	0503034320	COMPRESSION SPRING	01	
12	0502012813	FLANGE WASHER SPRING	01	




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	230	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	182	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	181	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0571018989	LH BLADE DISC ARM	01	
02	0502012790	LOCK NUT	01	
03	0511058648	HUB WITH 20" DISC BLADE	01	
04	0521065978	RIGHT ARM WITH WASHER LOCK	01	
05	0571019035	SLEEVE SUPPORT ARM	01	
06	0521010452	SLEEVE	01	
07	0521066743	SPRING REGULATOR	01	
08	0503010417	7/8" NUT	04	
09	0571019033	FIXATION AXLE	01	
10	0503034319	LOCK PIN	01	
11	0502012813	FLANGE WASHER SPRING	01	
12	0503034320	COMPRESSION SPRING	01	
13	0571019032	SUPPORT WASHER	01	
14	0571019034	FLANGE WASHER AXLE	02	
15	0503010002	1800 GREASE FITTING	01	
16	0503013185	3/4" X 5-1/2" BOLT	01	
17	0503011255	3/4" LOCK NUT	01	
18	0503011411	1/2" X 5-1/2" BOLT	01	
19	0503011440	SPRING WASHER	01	
20	0503010060	1/2 UNC G.5 ZN HEX NUT	01	




Item	Code	Description	See page	QT
01	0571018989	LH BLADE DISC ARM		01
02	0502012790	LOCK NUT		01
03	0511058781	CORRUGATED DC BOX 20	233	01
04	0521065978	RIGHT ARM WITH WASHER LOCK		01
05	0571019035	SLEEVE SUPPORT ARM		01
06	0521010452	SLEEVE		01
07	0521066743	SPRING REGULATOR		01
08	0503010417	7/8" NUT		04
09	0571019033	FIXATION AXLE		01
10	0503034319	LOCK PIN		01
11	0502012813	FLANGE WASHER SPRING		01
12	0503034320	COMPRESSION SPRING		01
13	0571019032	SUPPORT WASHER		01
14	0571019034	FLANGE WASHER AXLE		02
15	0503010002	1800 GREASE FITTING		01
16	0503013185	3/4" X 5-1/2" BOLT		01
17	0503011255	3/4" LOCK NUT		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	234	01
02	0607026008	20" PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0502012793	DISC HUB		01
02	0571018047	DISC BLADE HUB AXLE		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DUST CLOAK		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0571018989	LH BLADE DISC ARM		01
02	0502012790	LOCK NUT		01
03	0511058838	20" WAVY COULTER BLADE HUB	236	01
04	0521065978	RIGHT ARM WITH WASHER LOCK		01
05	0571019035	SLEEVE SUPPORT ARM		01
06	0521010452	SLEEVE		01
07	0521066743	SPRING REGULATOR		01
08	0503010417	7/8" NUT		04
09	0571019033	FIXATION AXLE		01
10	0503034319	LOCK PIN		01
11	0502012813	FLANGE WASHER SPRING		01
12	0503034320	COMPRESSION SPRING		01
13	0571019032	SUPPORT WASHER		01
14	0571019034	FLANGE WASHER AXLE		02
15	0503010002	1800 GREASE FITTING		01
16	0503013185	3/4" X 5-1/2" BOLT		01
17	0503011255	3/4" LOCK NUT		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	234	01
02	0607026025	DPLO20X4,5		01




Item	Code	Description	See page	QT
01	0502012795	SUPPORT LONG	01	
02	0503011854	5/8" X 1-1/4" BOLT	02	
03	0503010002	1800 GREASE FITTING	01	
04	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
05	0503017960	5/8" X 3-12" BOLT	04	
06	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
07	0521066744	FERTILIZER ROW ADJUSTMENT SPRING	01	
08	0571019062	SLEEVE	01	
09	0571019059	SUPPORT WASHER	01	
10	0503010417	7/8" NUT	04	
11	0503034320	COMPRESSION SPRING	01	
12	0502012813	FLANGE WASHER SPRING	01	




Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	239	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	181	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	182	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0571018989	LH BLADE DISC ARM		01
02	0502012790	LOCK NUT		01
03	0511056910	HUB WITH 18" DISC BLADE	241	01
04	0521065978	RIGHT ARM WITH WASHER LOCK		01
05	0571019035	SLEEVE SUPPORT ARM		01
06	0521010452	SLEEVE		01
07	0521066743	SPRING REGULATOR		01
08	0503010417	7/8" NUT		04
09	0571019033	FIXATION AXLE		01
10	0503034319	LOCK PIN		01
11	0502012813	FLANGE WASHER SPRING		01
12	0503034320	COMPRESSION SPRING		01
13	0571019032	SUPPORT WASHER		01
14	0571019034	FLANGE WASHER AXLE		02
15	0503010002	1800 GREASE FITTING		01
16	0503013185	3/4" X 5-1/2" BOLT		01
17	0503011255	3/4" LOCK NUT		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	234	01
02	0603026013	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
01A	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0503011255	3/4" LOCK NUT		02
03	0571019062	SLEEVE		01
04	0571019059	SUPPORT WASHER		01
05	0503034320	COMPRESSION SPRING		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503011854	5/8" X 1-1/4" BOLT		02
08	0511016281	3/4" X 8" BOLT		02
09	0503017960	5/8" X 3-12" BOLT		04
10	0502012813	FLANGE WASHER SPRING		01
11	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
12	0503010417	7/8" NUT		02
13	0502012789	FIXER SUPPORT FERTILIZER ROW		01
14	0521056476	DC 20" ASSY	244	01
15	0503011254	7/8" HEX SELF ADJUSTING NUT		01
16	0591011145	FERTILIZER ROW SUPPORT		01
17	0503019278	LUBRICANT SLEEVE		02
18	0591011147	SLEEVE ARM ROW		02
19	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
01A	0511057271	RH LONG ARM ROW FERTILIZER	238	01
02	0503011255	3/4" LOCK NUT		02
03	0571019062	SLEEVE		01
04	0571019059	SUPPORT WASHER		01
05	0503034320	COMPRESSSION SPRING		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503011854	5/8" X 1-1/4" BOLT		02
08	0511016281	3/4" X 8" BOLT		02
09	0503017960	5/8" X 3-12" BOLT		04
10	0502012813	FLANGE WASHER SPRING		01
11	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
12	0503010417	7/8" NUT		02
13	0502012789	FIXER SUPPORT FERTILIZER ROW		01
14	0521056476	DC 20" ASSY	244	01
15	0503011254	7/8" HEX SELF ADJUSTING NUT		01
16	0591011146	SUPPORT LONG		01
17	0503019278	LUBRICANT SLEEVE		02
18	0591011147	SLEEVE ARM ROW		02
19	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0571019034	FLANGE WASHER AXLE		01
02	0571019032	SUPPORT WASHER		01
03	0502012813	FLANGE WASHER SPRING		01
04	0591010619	DC SPRING SUPPORT		01
05	0503019274	WASHER		02
06	0581017628	LID		02
07	0503019277	SLEEVE LUBRICATION SYSTEM		01
08	0501110964	RIGHT ARM WITH SLEEVE		01
09	0501110965	LEFT ARM WITH SLEEVE		01
10	0503034320	COMPRESSION SPRING		01
11	0591010624	SUPPORT ARM SLEEVE		01
12	0591010625	19,50 X 25 X 91,50/91,30 SLEEVE		01
13	0503010417	7/8" NUT		02
14	0503010390	SEAL RING		02
15	0503011198	C3/4" X 6" SCREW		01
16	0501010322	FLAT WASHER		01
17	0503011411	1/2" X 5-1/2" BOLT		01
18	0503010060	1/2 UNC G.5 ZN HEX NUT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503011255	3/4" LOCK NUT		01
21	0503030430	7/16 X 2" PIN LOCK		01
22	0503019271	SELF LUBRICATING BUSHING		01
23	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	245	01
24	0503011254	7/8" HEX SELF ADJUSTING NUT		01
25	0521066743	SPRING REGULATOR		01
26	0591011144	FIXATION AXLE		01
27	0591010628	DC AXIS BACKREST WASHER		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	DISC BLADE HUB	246	01




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	DISC BLADE HUB		01
09	0502040873	DISC BLADE AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
001	0521050341	ROD WITH AUTOMATIC DISARM	252	01
002	0581010082	FERTILIZER SOCKET RIGHT		01




Item	Code	Description	See page	QT
01	0521053950	HDA AUTOMATIC DISARM	254	01
02	0581010082	FERTILIZER SOCKET RIGHT		01




Item	Code	Description	See page	QT
001	0521050341	ROD WITH AUTOMATIC DISARM	252	01
002	0581010083	FERTILIZER SOCKET LEFT		01




Item	Code	Description	See page	QT
01	0521053950	HDA AUTOMATIC DISARM	254	01
02	0581010083	FERTILIZER SOCKET LEFT		01




Item	Code	Description	See page	QT
01	0501110864	STEM WITH NOZZLE 0084 HDA	253	01
02	0521067065	FLANGE WASHER SPRING		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0581012092	AXLE FIXER		01
05	0521015818	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521050337	STEM WITH NOZZLE	252	01
02	0503012795	5/8" HEX SELF ADJUSTING NUT		01
03	0503010417	7/8" NUT		01
04	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
05	0503034106	80 X 230 X 16,50 COMPRESSSION SPRING		01
06	0503010691	1/4" GREASE FITTING		01
07	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		04
09	0521067522	HDA SPRING BOX		01
10	0581012084	ARTICULATED SLEEVE		01
11	0581012082	SCREW		01
12	0581012081	ARTICULATED SLEEVE		01
13	0571019462	SUPPORT GUIDE PRING		01
14	0581012094	SUPPORT WASHER		01
15	0571018541	BODY SOCKET FERTILIZER		01
16	0503010026	3/8" NUT		02
17	0503010025	3/8" SPRING WASHER		02
18	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010384	1/2" X 5" BOLT		02
22	0503017874	BOLT 1/2 UNC		02




Item	Code	Description	See page	QT
01	0521067523	STEM WITHOUT BEAK DISARM		01
02	0502070084	NOZZLE		01
03	0503010585	0,24" X 1.18" SPRING PIN		01
04	0503011373	0.4" X 1.1" SPRING PIN		01




Item	Code	Description	See page	QT
01	0521067522	HDA SPRING BOX		01
02	0521053951	STEM	255	01
03	0503034106	80 X 230 X 16,50 COMPRESSSION SPRING		01
04	0581012094	SUPPORT WASHER		01
05	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
06	0571019462	SUPPORT GUIDE PRING		01
07	0503012795	5/8" HEX SELF ADJUSTING NUT		01
08	0503010691	1/4" GREASE FITTING		01
09	0503010384	1/2" X 5" BOLT		02
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
11	0503011336	1/2" HEX SELF ADJUSTING NUT		04
12	0503017874	BOLT 1/2 UNC		02
13	0571018541	BODY SOCKET FERTILIZER		01
14	0503010026	3/8" NUT		02
15	0503010025	3/8" SPRING WASHER		02
16	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
17	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
18	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
19	0581012084	ARTICULATED SLEEVE		01
20	0581012082	SCREW		01
21	0503010417	7/8" NUT		01
22	0581012081	ARTICULATED SLEEVE		01




Item	Code	Description	See page	QT
01	0521053932	ROD WITH BEAK 0869	256	01
02	0521067065	FLANGE WASHER SPRING		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0581012092	AXLE FIXER		01
05	0521015818	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521067523	STEM WITHOUT BEAK DISARM		01
02	0502040901	FIXED ROD NOZZLE		01
03	0503016853	SPRING PIN		02
04	0503011402	0.2" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503016204	CORN DISC 12 ORANGE		01
02	0503016398	TITANIUM RING CORN / SOY (YELLOW FLAT)		01
03	0503016399	TITANIUM RING CORN (GREEN)		01
04	0503016400	TITANIUM RING CORN (GREY)		01
05	0503016401	TITANIUM RING CORN (BLUE)		01




Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016218	DISC OF SOYBEAN		01
03	0503016403	TITANIUM RING FOR SOYBEAN (LILAC)		01
04	0503016404	TITANIUM RING FOR SOYBEAN (PURPLE)		01
05	0503016406	TITANIUM RING FOR SOYBEAN (ORANGE)		01
06	0503016407	TITANIUM RING FOR SOYBEAN		01




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01




Item	Code	Description	See page	QT
01	0521066457	WHEEL SUPPORT		01
02	0531013272	0.5" X 1" X 2.2" SLEEVE		01
03	0511064128	PRESS SUPPORT LOWWER WHEEL		01
04	0502011757	PRESS REGULATOR		01
05	0501013491	5/8" TENSIONER SPRING		01
06	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
07	0503010752	1/2" X 3.1/2" BOLT		01
08	0503010019	1/2" SPRING WASHER		06
09	0503010060	1/2 UNC G.5 ZN HEX NUT		06
10	0503010013	5/8" NUT		02
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010026	3/8" NUT		02
13	0521014508	FLAT WASHER		07
14	0501052908	COMPACTOR WHEEL WITH BEARING	161	02
15	0503010025	3/8" SPRING WASHER		02
16	0503010003	1845 GREASE FITTING		01
17	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
18	0503016864	LH 1/2" LOCK NUT		01
19	0503012136	NUT 1/2 NF		01
20	0503016449	1/2 X 4 BOLT		01
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		05
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0521066456	WHEEL SUPPORT		01
02	0531013272	0.5" X 1" X 2.2" SLEEVE		01
03	0511064128	PRESS SUPPORT LOWWER WHEEL		01
04	0502011757	PRESS REGULATOR		01
05	0501013491	5/8" TENSIONER SPRING		01
06	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
07	0503010752	1/2" X 3.1/2" BOLT		01
08	0503010019	1/2" SPRING WASHER		06
09	0503010060	1/2 UNC G.5 ZN HEX NUT		06
10	0503010013	5/8" NUT		02
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010026	3/8" NUT		02
13	0521014508	FLAT WASHER		07
14	0501052908	COMPACTOR WHEEL WITH BEARING	161	02
15	0503010025	3/8" SPRING WASHER		02
16	0503010003	1845 GREASE FITTING		01
17	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
18	0503016864	LH 1/2" LOCK NUT		01
19	0503012136	NUT 1/2 NF		01
20	0503016449	1/2 X 4 BOLT		01
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		05
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC	264	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
07	0503010025	3/8" SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 200 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 202 FERTILIZER / SEED		01



Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC	266	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04



Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
07	0503010025	3/8" SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 200 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 202 FERTILIZER / SEED		01



MARCHESAN

Technical Publications | Elaboration and Revision

LEONARDO JOSÉ DA SILVA SOUZA

www.marchesan.com.br

