

ROW CROP PLANTERS

PST PLUS FLEX TITANIUM - FRAME 3495 - TCE (FROM 08/2022)

Code: 0501093372
Series: S-0116
Revision: 00
Date Revision: AGOSTO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code
0111380325

Description
PST PLUS FLEX 3495/7E500 ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.

INDEX


0909096470	ASSY FRAME - 3495		1
0511057371	FRAME WITH WHEEL AXLE - 3495		2
0511058655	CYLINDER SET - 3245/3495/4045/4395		3
0511058607	HYDRAULIC CYLINDER		4
0511057369	HANDRAIL ASSEMBLY - 3495		5
0511057370	PLATFORM ASSEMBLY - 3495		6
0511056536	LADDER ASSEMBLY		7
0511057333	DRAWBAR ASSEMBLY - 3495/4045/4395/4845/5345/5745		8
0511054601	HITCH ARTICULATED TRACTOR		9
0511056736	HOSE SUPPORT		10
0511057270	DRAWBAR EXTENDER		11
0511054971	JACK ASSEMBLY		12
0511057266	HYDRAULIC SYSTEM ASSEMBLY - 3245/3495/4045/4395		13
0501053834	MALE QUICK COUPLER		14
0511058653	WHEELS WITH TRACTION SPRING		15
0511058654	WHEEL SUPPORT		16
0511052770	WHEEL WITH TIRE		17
0503062159	WHEEL WITH TIRE		18
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE		19
0501058241	WHEEL SUPPORT CHAIN TENSIONER		20
0501058240	WHEEL FASTENER WITH TENSIONER		21
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER		22
0501058244	WHEEL FIXED CHAIN TENSIONER		23
0501058242	WHEEL MOBILE CHAIN TENSIONER		24
0511057365	LABELS KIT - 3495		25
0511053179	TRACTOR COUPLING SHAFT		26
0531055922	3495 ALPHA FERTILIZER HOPPER SET		27
0531055386	3495 HOPPER SUPPORT WITH ALPHA FERTILIZER METERING		28
0501056271	GEARBOX CLOSED BEARING		29
0531055292	ALPHA FERTILIZER METERING		30
0531055273	ALPHA FERTILIZER METERING CLAMP		31
0531055376	TRANSMISSION ALPHA FERTILIZER METERING HUB		32
0511059590	TRANSMISSION ASSEMBLY - 3495		33
0501052560	MOTOR AXLE SIGNAL		34
0511051434	TRANSMISSION ACTUATOR		35
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR		36
0511047070	LEFT SIDE TRANSMISSION ACTUATOR		37
0501053788	3/4 SQUARE AXLE FASTENER		38
0511057265	TRANSMISSION CHAIN TENSIONER		39
0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY		40
0511050652	CHAIN TENSIONER		41
0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT		43
0521055335	RIGHT GEAR HOUSING SET		44
0521055337	LEFT GEAR HOUSING SET		45
0511058381	RIGHT GEAR HOUSING		46
0511058382	LEFT GEAR HOUSING		47
0501048790	AXLE WITH RING		48
0501056443	GEAR HOUSING BEARING		49
0511054363	CHAIN TENSIONER		50
0511057258	TENSIONER WITH GEAR		51
0909091038	HEX AXLE ASSEMBLY		52
0511059322	LIFTING SUPPORT ASSEMBLY		53
0511058449	HYDRAULIC CYLINDER		54
0511057368	SEMI-ASSEMBLED HYDRAULIC MARKER - 3495		55
0501054649	HBM SEQUENTIAL VALVE		56



MARCHESAN

INDEX

0511058119	VALVE SUPPORT ASSEMBLY	57
0501050633	ROW MARKER DISK ASSEMBLY	58
0511057845	MANUAL CANISTER	59
0511059323	PLATFORM TRANSPORT SUPPORT	60
0909095820	SEED/FERTILIZER ROW ASSY	61
0521054984	DEPTH/COMPACTOR SYSTEM - SPT	62
0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	63
0501052297	DEPTH WHEELS REGULATOR ASSY	64
0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	65
0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	66
0521055033	SEMI-ASSEMBLED COMPACTOR BODY	67
0521052538	ASSY REGULATOR LEVER	68
0521054990	LEFT COMPACTOR WHEEL	69
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	70
0521055017	RIGHT COMPACTOR WHEEL	71
0521058525	SHORT SEED ROW	72
0521058526	FRONT SEED ROW	73
0521056944	REAR FRAME	74
0521056955	RIGHT DDD ASSY	75
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	76
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	77
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	78
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	79
0521056582	DOSER	80
0521056639	SEED ROW TRANSMISSION	81
0521056945	REAR FRAME	82
0521056954	LEFT DDD ASSY	83
0521058524	SEED ROW FRONT	84
0511056608	TITANIUM SEED SYSTEM	85
0521055338	ROW SEED BEARING	86
0521056477	SHORT FERTILIZER ROW DC20 WITHOUT LUBRICATION	87
0521056479	LONG DC20 FERTILIZER ROW WITHOUT LUBRICATION	88
0521056476	DC 20" ASSY	89
0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	90
0521053697	CUTTING DISK BOX	91
0521050525	FIXER FERTILIZER CONDUCTOR	92
0521050560	ASSY HOSE SUPPORT 3"	93
0501110804	SCARIFIER ROD WITH POINT	94
0503062066	DISC SET WITH CORN RING	95
0503062067	DISC SET / RING SOY 90F TITANIUM	96
0521057957	FIXED ROD EXTENSION WITH FIXATION	97
0521054769	LEFT DDD FERTILIZER WITH SUPPORT	98
0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	99
0521054765	DDD LEFT FERTILIZER	100
0521054764	DDD RIGHT FERTILIZER	101
0521054761	LEFT LOW CUBE	102
0521054760	DOWN LOW CUBE	103




Item	Code	Description	See page	QT
01	0511057371	FRAME WITH WHEEL AXLE - 3495	2	01
02	0511058655	CYLINDER SET - 3245/3495/4045/4395	3	01
03	0511057369	HANDRAIL ASSEMBLY - 3495	5	01
04	0511057370	PLATFORM ASSEMBLY - 3495	6	01
05	0511056536	LADDER ASSEMBLY	7	02
06	0511057333	DRAWBAR ASSEMBLY 3495/4045/4395/4845/5345/5745	- 8	01
07	0511054601	HITCH ARTICULATED TRACTOR	9	01
08	0511056736	HOSE SUPPORT	10	01
09	0511057270	DRAWBAR EXTENDER	11	01
10	0511054971	JACK ASSEMBLY	12	02
11	0511057266	HYDRAULIC SYSTEM ASSEMBLY 3245/3495/4045/4395	- 13	01
12	0511058653	WHEELS WITH TRACTION SPRING	15	04
13	0511057365	LABELS KIT - 3495	25	01
14	0501068994	8,30 X 78 LOCK PIN		01
15	0501065677	STRUT		02
16	0511053179	TRACTOR COUPLING SHAFT	26	01
17	0531055922	3495 ALPHA FERTILIZER HOPPER SET	27	01
18	0511059590	TRANSMISSION ASSEMBLY - 3495	33	01
19	0909091038	HEX AXLE ASSEMBLY	52	01
20	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
21	0501047895	ROD STOP		01
22	0501047885	ROD STOP		01
23	0501047886	ROD STOP		01
24	0501047887	ROD STOP		01
25	0503030168	HITCH PIN CLIP		01
26	0503032624	FERTILIZER HOPPER GUTTER		03
27	0503010003	1845 GREASE FITTING		04
28	0521013022	TRANSPORT LOCK		01
29	0503010780	N-2050 AMENDMENT		02
30	0503010951	REDUCTION		04




**PST PLUS FLEX TITANIUM - FRAME 3495 - TCE (FROM
ASSY FRAME - 3495**

Page 1
0909096470


Item	Code	Description	See page	QT
31	0511059322	LIFTING SUPPORT ASSEMBLY	53	02
32	0511057368	SEMI-ASSEMBLED HYDRAULIC MARKER - 3495	55	01
33	0511057845	MANUAL CANISTER	59	01
34	0511059323	PLATFORM TRANSPORT SUPPORT	60	04
35	0511066652	400 TURNBUCKLE		02
36	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		02
37	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
38	0511017302	FLAT WASHER		04
39	0503010019	1/2" SPRING WASHER		04
40	0503010060	1/2" NUT		04
41	0501214546	SPRING KEY		01
42	0503011750	AMENDMENT WITH LOCK		06
43	0503011751	REDUCTION		06
44	0501050633	ROW MARKER DISK ASSEMBLY	58	02
45	0503014120	CHAIN		01
46	0503014321	CABLE STEEL SHACKLE		02
47	0909095820	SEED/FERTILIZER ROW ASSY	61	01




Item	Code	Description	See page	QT
01	0521065918	FRAME - 3495		01
02	0521065927	CARRYING-WHEELS PIVOT SHAFT 3495		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	SCREW		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0521045510	HYDRAULIC CYLINDER		01
02	0551014099	COUPLING SHAFT 31,75 X 185		01
03	0521010547	1.2" X 6.5" COUPLING SHAFT		01
04	0503010523	1/4" X 2" COTTERPIN		02
05	0501047888	ROD STOP		01




Item	Code	Description	See page	QT
01	0521066740	CYLINDER CASE		01
02	0581013698	PISTON		01
03	0521067586	TURNBUCKLE		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010003	1845 GREASE FITTING		01
06	0503030385	CYLINDER PLUG N-002		02
07	0503018439	WIPER SEAL		01
08	0503018150	RING GUIDE		01
09	0502010382	5" END CAP		01
10	0581010353	RING SUPPORT		01
11	0503018026	1870-2000-375 B GASKET		01
12	0503011453	O'RING		02
13	0503018152	O'RING		02
14	0503018024	RING BS		01
15	0503018025	RING GUIDE		01
16	0503010039	D-2000 SCRAPER RING		01
17	0503010173	2-220 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0521065949	FRAME HANDRAIL - 3495		02
02	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
03	0511017302	FLAT WASHER		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2" NUT		08
06	0581012916	INTERMEDIATE TUBE		02
07	0511059383	HANDRAIL INTERNAL FIXER		04




Item	Code	Description	See page	QT
01	0571018865	PLATFORM - 3495		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		16
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0502012806	SUPPORT REAR FIXER DRAWBAR		04
02	0502012789	FIXER SUPPORT FERTILIZER ROW		04
03	0503017960	5/8" X 3-12" BOLT		16
04	0503010811	5/8" UNF SELF ADJUSTING NUT		16
05	0501010191	1" X 6" BOLT		04
06	0503010012	1" SPRING WASHER		04
07	0501010059	1.5/8 NUT		04
08	0502012805	SUPPORT FRONT FIXER DRAWBAR		04
09	0502012789	FIXER SUPPORT FERTILIZER ROW		04
10	0503017960	5/8" X 3-12" BOLT		16
11	0503010811	5/8" UNF SELF ADJUSTING NUT		16
12	0521065958	DRAWBAR		01
13	0561019087	DRAWBAR TRANSPORT LOCK		01
14	0551014099	COUPLING SHAFT 31,75 X 185		01
15	0521010544	1.2" X 4.9" COUPLING SHAFT		01
16	0503030085	LOCK PIN		02
17	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521065959	JACK R.1.1/2 UNC RIGHT X 240		01
03	0521065960	JACK R.1.1/2 UNC LEFT X 240		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0511057267	HOSE KIT HYDRAULIC		01
01A	0501080722	3/8 X 3300 TC-TM HOSE ASSY		01
01B	0501082023	HOSE 3/8 X 3600 TC-TM		01
02	0501053834	MALE QUICK COUPLER	14	02
03	0503013100	NYLON CLAMP		02
04	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511058654	WHEEL SUPPORT	16	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	21	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521066716	WHEEL ARM ASSY		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
08	0503010027	5/8" SPRING WASHER		01
09	0501058241	WHEEL SUPPORT CHAIN TENSIONER	20	01
10	0503013030	5/8" X 3.1/4" BOLT		01
11	0551017715	FLAT WASHER		02
12	0511052770	WHEEL WITH TIRE	17	01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8" SPRING WASHER		02
15	0503011167	M16 X 2 X 30 BOLT		02




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	18	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	19	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	22	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	23	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	24	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0503034115	ADHESIVE LABEL		02
02	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530		02
03	0503033417	ADHESIVE LABEL		02
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
06	0503033423	LABEL ADHESIVE NUMBER 9		02
07	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
08	0503031428	READ MANUAL DECAL		01
09	0503031942	ADHESIVE LABEL		01
10	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
11	0503031565	ADHESIVE LABEL CARE		02
12	0503031566	ADHESIVE LABEL		02
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
14	0503031425	ADHESIVE LABEL ATTENTION		02
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
16	0503031669	ADHESIVE LABEL		01
17	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
19	0503032930	ADHESIVE LABEL DANGER		04
20	0503031087	ADHESIVE LABEL		01
21	0503034003	SERIAL NUMBER TAG 61 X 118		01
22	0503010001	3.2 X 5.5 RIVET		04
23	0503032979	ADHESIVE LABEL LETTERS A B C D		02
24	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0531055386	3495 HOPPER SUPPORT WITH ALPHA FERTILIZER METERING	28	01
02	0503062362	FERTILIZER HOPPER		02
03	0503013751	3/8 UNC X 1.1/4 BOLT		12
04	0571019051	FIXER HOPPER WASHER		12
05	0503012535	3/8" SPRING WASHER		12
06	0503012531	3/8" INOX NUT		12
07	0503011957	NYLON LUG		02
08	0503010371	5/16" X 1" BOLT		04
09	0503010179	LOCK WASHER		04
10	0503010337	5/16" NUT		04
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		20
13	0503010025	3/8" SPRING WASHER		10
14	0503010026	3/8" NUT		10




Item	Code	Description	See page	QT
01	0531064089	3495 FERTILIZER HOPPER SUPPORT		01
02	0501053788	3/4 SQUARE AXLE FASTENER	38	08
03	0511061759	22Z P12,70 FQ 3/4" GEAR		02
04	0503030303	SUPPORT WASHER		04
05	0501056271	GEARBOX CLOSED BEARING	29	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER		04
09	0503010337	5/16" NUT		04
10	0531055292	ALPHA FERTILIZER METERING	30	08
11	0503031527	AGRICULTURAL BEARING		06
12	0521013958	3/4" X 26.3" SQUARE SHAFT		02
13	0501010787	AXLE		02
14	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		02
14A	0501214269	SQUARE SLEEVE		02
14B	0513010701	LOCK PIN		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0503010025	3/8" SPRING WASHER		04
02	0503010026	3/8" NUT		04
03	0513010742	RETAINER 47 X 30 X 10 BRG 5285		01
04	0501214879	HORIZONTAL SEAL COVER ALPHA FERTILIZER METERING		01
05	0503035799	ALPHA FERTILIZER DOSAGE NOZZLE		01
06	0503035831	ALPHA FERTILIZER METERING COLLECTOR		01
07	0531055273	ALPHA FERTILIZER METERING CLAMP	31	01
08	0513010692	ALLEN SCREW 1/4 UNC X 7/8 C FLAT SI INOX		04
09	0501011643	3/8 X 1" BOLT		04
10	0503035796	REAR FIXER ALPHA FERTILIZER METERING COLLECTOR		02
11	0513010695	ALLEN SCREW 1/4 UNC X 7/8 CCSI INOX		04
12	0531055376	TRANSMISSION ALPHA FERTILIZER METERING 32 HUB		01
13	0502013049	ALPHA FERTILIZER DOSAGE HOPPER		01
14	0502013048	FLANGE FIXER BODY ALPHA FERTILIZER METERING		01
15	0501111134	COVER WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
15A	0503063799	COVER WITH FERTILIZER METERING WASHER ALPHA		01
15B	0503035822	GUIDE GLOVE SPRING CONDUCTOR FERTILIZER METERING ALPHA		01
16	0503035829	ADHESIVE LABEL LOGO TATU 38 X 28 X 0.30 ALPHA FERTILIZER METERING		01
17	0531055518	WORM THREAD ASSEMBLED		01
17A	0531064265	WORM THREAD		01
17B	0503035859	SUPPORT SLEEVE		01
18	0501111143	COATING WITH GUIDE ASSY SUPPLEMENTATION FERTILIZER METERING		01
18A	0501214951	FERTILIZER DOSAGE COATING		01
18B	0531055519	GUIDE ASSY WITH SUPPLEMENTATION		01



Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0502013050	TRANSMISSION ALPHA FERTILIZER METERING HOPPER		01
02	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
03	0503011800	SEAL RING		02
04	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
05	0503016065	ROLLER BEARING		02
06	0501214237	TRANSMISSION HOPPER ALPHA FERTILIZER METERING SLEEVE		01
07	0503019373	6006 2RS1 NATIONAL BEARING		02
08	0503012858	502075 CLAMPING RING (FOR HOLE)		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01
10	0501214501	ALPHA FERTILIZER METERING COVER LOCK AXIS		01
11	0501214238	SHAFT LOCK SLEEVE HOPPER TRANSMISSION ALPHA FERTILIZER METERING		01
12	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2" NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2" NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	20	04
13	0571018905	AXLE MOTOR 1675		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	34	02
16	0511051434	TRANSMISSION ACTUATOR	35	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	36	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	37	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		02
20	0501053788	3/4 SQUARE AXLE FASTENER	38	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING	29	02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
25	0503010025	3/8" SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	39	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
30	0503010140	1/8" X 3/4" COTTERPIN		02
31	0571018846	DISASSEMBLE LEVER		02


Item	Code	Description	See page	QT
32	0503033942	COVER REGULATORY WHEEL		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
37	0503012412	5/8 UNC SELF LOCKING NUT		04
38	0511061759	22Z P12,70 FQ 3/4" GEAR		02
39	0501053788	3/4 SQUARE AXLE FASTENER	38	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING	29	02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
44	0503010025	3/8" SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	39	02
47	0511065209	20Z GEAR		02
48	0501053788	3/4 SQUARE AXLE FASTENER	38	02
49	0503030303	SUPPORT WASHER		02
50	0503010292	0.2" X 1.6" SPRING PIN		02
51	0521018630	1.4" X SQUARE 0.8" WASHER		02
52	0501056271	GEARBOX CLOSED BEARING	29	02
53	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
54	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
55	0503010025	3/8" SPRING WASHER		04
56	0503010026	3/8" NUT		04
57	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	40	02
58	0511050652	CHAIN TENSIONER	41	04
59	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	43	02
60	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
61	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
62	0503015001	40-1 X 153 CHAIN LINK + MENDING		02
63	0511069678	LH LOWER LEVER		02
64	0551019159	LEVER FIXER BODY		02
65	0561016468	FASTENER		02
66	0503011336	1/2" HEX SELF ADJUSTING NUT		04
67	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
68	0503010140	1/8" X 3/4" COTTERPIN		04
69	0521055335	RIGHT GEAR HOUSING SET	44	01
70	0521055337	LEFT GEAR HOUSING SET	45	01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	NUT		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2" NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER	01	
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
03	0503010060	1/2" NUT	01	
04	0521017590	GUIDE AXLE	01	
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING	01	
06	0502012009	DRIVING AXLE RIGHT FOLLOWER	01	
07	0501019734	FLAT WASHER	02	
08	0502010710	RIGHT CAM, SMALLER	02	
09	0503010003	1845 GREASE FITTING	02	
10	0502012539	26Z P12,7 GEAR	01	
11	0501019735	FLAT WASHER	01	
12	0521017593	FLAT WASHER	01	
13	0503010542	501045 CLAMPING RING (FOR AXLE)	01	




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2" NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		03
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0541011713	TENSIONER CHAIN LOWER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0551019171	CHAIN TIGHTENER AXLE		01
02	0503011410	ROLLER BEARING		01
03	0511062169	21Z P 1/2" GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503011105	SEAL RING		01
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0571010265	16.5 X 40 X 3 FLAT WASHER		01
08	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING		01
02	0511063185	20Z GEAR WITH HEX HOLE AXLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010365	NUT		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER		02
07	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0511058381	RIGHT GEAR HOUSING	46	01
02	0521065955	RH GEAR BOX COVER		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0503010019	1/2" SPRING WASHER		01
07	0501010694	FLAT WASHER		06
08	0511017302	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0511058382	LEFT GEAR HOUSING	47	01
02	0521065956	LH GEAR BOX COVER		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0511017302	FLAT WASHER		01
07	0503010019	1/2" SPRING WASHER		01
08	0501010694	FLAT WASHER		06




Item	Code	Description	See page	QT
01	0521065939	RIGHT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN AXLE CONE		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
05	0503010060	1/2" NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING		01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING	29	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TENSIONER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	48	02
20	0503031366	RIGHT TWISTED SPRING RECAMBIO		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	49	01
31	0503010292	0.2" X 1.6" SPRING PIN		08

Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	51	01
33	0511054363	CHAIN TENSIONER	50	01
34	0571018901	DRIVEN AXLE		01




Item	Code	Description	See page	QT
01	0521065940	LEFT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN AXLE CONE		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2" NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING		01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING	29	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TENSIONER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	48	02
20	0503031367	SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	49	01
31	0503010292	0.2" X 1.6" SPRING PIN		08


Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	51	01
33	0511054363	CHAIN TENSIONER	50	01
34	0571018901	DRIVEN AXLE		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2" NUT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0571019207	DEVIATION AXLE GEAR BOX		01
06	0503010899	5/8" X 2-1/4" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	3245	3495	4045	4395	4845	5345	5745
01	0571018910	3/4 X 1505 AXLE HEX	01	00	00	00	00	00	00	00
01.	0571018911	3/4 X 1690 AXLE HEX	01	00	00	00	00	00	00	00
02	0571018912	3/4 X 1630 AXLE HEX	00	01	00	00	00	00	00	00
02.	0571018913	3/4 X 1815 AXLE HEX	00	01	00	00	00	00	00	00
03	0571018914	3/4 X 1905 AXLE HEX	00	00	01	00	00	00	00	00
03.	0571018915	3/4 X 2090 AXLE HEX	00	00	01	00	00	00	00	00
04	0571018916	3/4 X 2080 AXLE HEX	00	00	00	01	00	00	00	00
04.	0571018917	3/4 X 2265 AXLE HEX	00	00	00	01	00	00	00	00
05	0571018918	3/4 X 2305 AXLE HEX	00	00	00	00	01	00	00	00
05.	0571018919	3/4 X 2490 AXLE HEX	00	00	00	00	01	00	00	00
06	0571018920	3/4 X 2555 AXLE HEX	00	00	00	00	00	01	00	00
06.	0571018921	3/4 X 2740 AXLE HEX	00	00	00	00	00	01	00	00
06..	0581012908	3/4 X 2755 AXLE HEX	00	00	00	00	00	00	01	00
06...	0581012909	3/4 X 2940 AXLE HEX	00	00	00	00	00	00	01	00
07	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	01	01	01	01	01	01	01	01
07A	0502012031	HOUSING BEARING	01	01	01	01	01	01	01	01
07B	0503012861	6006 2RS BALL BEARING	02	02	02	02	02	02	02	02
07C	0503012858	502075 CLAMPING RING (FOR HOLE)	01	01	01	01	01	01	01	01
08	0511063185	20Z GEAR WITH HEX HOLE AXLE 20	01	01	01	01	01	01	01	01
09	0503010707	501030 CLAMPING RING (FOR AXLE)	01	01	01	01	01	01	01	01
10	0503010365	NUT	02	02	02	02	02	02	02	02
11	0501010694	FLAT WASHER	04	04	04	04	04	04	04	04
12	0503010179	LOCK WASHER	02	02	02	02	02	02	02	02
13	0503010337	5/16" NUT	02	02	02	02	02	02	02	02
14	0581012949	BEARING COVER	01	01	01	01	01	01	01	01



Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521067033	FRAME LIFTING SUPPORT		01
03	0503017960	5/8" X 3-12" BOLT		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	MOBILE COVER		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8 UNC SELF LOCKING NUT		04
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0511058449	HYDRAULIC CYLINDER	54	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" COTTERPIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501069643	890 TURNBUCKLE		02
21	0503011854	5/8" X 1-1/4" BOLT		04
22	0501054649	HBM SEQUENTIAL VALVE	56	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
25	0503010025	3/8" SPRING WASHER		02
26	0511058119	VALVE SUPPORT ASSEMBLY	57	01
27	0501053834	MALE QUICK COUPLER	14	02
28	0502012702	BODY SUPPORT CLAMP		08
29	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		08
30	0503010180	7/16" SPRING WASHER		08
31	0503010244	7/16" NUT		02


Item	Code	Description	See page	QT
32	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
33	0511057367	HOSE KIT MARKER HYDRAULIC		01
33A	0501080296	3/8" X 106" TR-TR HOSE		02
33B	0501080397	3/8" X 120" TR-TC HOSE		02
34	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
34A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
34B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
34C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
34D	0503018952	PLASTIC BOLT		06
35	0521052850	3/8 X 4200 TC-TM PURPLE/BLEUE HOSE		01
35A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
35B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
35C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
35D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0581010011	VALVE FIXING SUPPORT		01
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
04	0503010025	3/8" SPRING WASHER		02
05	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" NUT		01



Item	Code	Description	See page	QT
01	0503060100	OPERATOR'S MANUAL STORAGE TUBE		01
02	0503010267	NYLON CLAMP		01
03	0503010363	5/16" X 1" BOLT		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0581011989	SIDE BODY FIXER PLATFORM		01
02	0551019884	45 X 50 X 3/8 FASTENER		01
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
07	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521054984	DEPTH/COMPACTOR SYSTEM - SPT	62	01
02	0521058525	SHORT SEED ROW	72	01
03	0521058526	FRONT SEED ROW	73	01
04	0511056608	TITANIUM SEED SYSTEM	85	01
05	0503010905	1/2" X 2-1/4" BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2" NUT		02
08	0503063193	CHAIN ASSY		01
09	0503063194	CHAIN ASSY		01
10	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		01
11	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
12	0511017302	FLAT WASHER		01
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2" NUT		01
15	0521055338	ROW SEED BEARING	86	01
16	0571018912	3/4 X 1630 AXLE HEX		01
17	0571018913	3/4 X 1815 AXLE HEX		01
18	0511054314	TRANSMISSION AXLE LOCK SLEEVE		01
18A	0502012699	TRANSMISSION BOX LOCK SLEEVE		01
18B	0503010256	3/8" X 3/4" BOLT		01
19	0521056477	SHORT FERTILIZER ROW DC20 WITHOUT LUBRICATION	87	01
20	0521056479	LONG DC20 FERTILIZER ROW WITHOUT LUBRICATION	88	01
21	0571011730	SEED CONDUCTOR 3" X 1500		01
22	0521050525	FIXER FERTILIZER CONDUCTOR	92	01
23	0521050560	ASSY HOSE SUPPORT 3"	93	01
24	0531013600	PRESS ADJUSTMENT LEVER		01
25	0501110804	SCARIFIER ROD WITH POINT	94	01
26	0521069127	BOTTOM NOZZLE FERTILIZER		01
27	0503031050	CURVED CONDUCTOR		01


Item	Code	Description	See page	QT
28	0511017969	0.1" SPACING PLATE		01
29	0511018662	SPACING PLATE		01
30	0503031145	2" X 2" X 20" HOSE		01
31	0503062066	DISC SET WITH CORN RING	95	01
32	0503062067	DISC SET / RING SOY 90F TITANIUM	96	01
33	0503030520	SEED SOCKET		01
34	0521057957	FIXED ROD EXTENSION WITH FIXATION	97	01
35	0521068982	KEY CASH DISC CUTTING		02
36	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		04
37	0503010019	1/2" SPRING WASHER		04
38	0503010060	1/2" NUT		04
39	0503010246	CLAMP		02
40	0503031076	2" HOSE CLAMP		02
41	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
42	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
43	0503010025	3/8" SPRING WASHER		02
44	0503010026	3/8" NUT		02
45	0521054769	LEFT DDD FERTILIZER WITH SUPPORT	98	04
46	0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	99	03
47	0503030391	RIGHT FERTILIZER NOZZLE		04
48	0503030392	LEFT FERTILIZER NOZZLE		03




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	63	01
02	0501052538	DEPTH BAND WITH ARMS		02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL	69	01
06	0521055017	RIGHT COMPACTOR WHEEL	71	01




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	64	01
02	0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	65	01
03	0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	66	01
04	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	67	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	SCREW 3/8 UNC X 3/4		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED SLEEVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION		01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2" NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION		01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT SLEEVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0521068564	REGULATOR LEVER		01
02	0581012718	HANDRAIL		01
03	0581016748	SCREW 1/2 UNC X 2		01
04	0503010060	1/2" NUT		01
05	0503014735	SCREW 1/2 UNC X 2		02
06	0503010019	1/2" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	70	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	70	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521056944	REAR FRAME	74	01
02	0521058524	SEED ROW FRONT	84	01
03	0503010060	1/2" NUT		02
04	0503010019	1/2" SPRING WASHER		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
06	0511017303	FLAT WASHER		04
07	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
08	0503012880	1/4" UNC SELF ADJUSTING NUT		02
09	0503015135	FLAT WASHER 10 X 18 X 2		01
10	0503010026	3/8" NUT		01
11	0501011643	3/8 X 1" BOLT		01
12	0591014600	ENCAPSULATED CURRENT FIXER		01
13	0503013815	1/4" X 5/8" BOLT		02
14	0503011295	M 8 X 1,25 X 25 BOLT		02
15	0591014601	BEARING SUPPORT		01
16	0591014602	CHAIN GUIDE		01




Item	Code	Description	See page	QT
01	0521058524	SEED ROW FRONT	84	01
02	0591014603	BEARING SUPPORT		01
03	0503010060	1/2" NUT		02
04	0503010019	1/2" SPRING WASHER		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
06	0591014604	GUIDE CHAIN LEFT		01
07	0511017303	FLAT WASHER		04
08	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
09	0503012880	1/4" UNC SELF ADJUSTING NUT		02
10	0503015135	FLAT WASHER 10 X 18 X 2		01
11	0503010026	3/8" NUT		01
12	0501011643	3/8 X 1" BOLT		01
13	0591014600	ENCAPSULATED CURRENT FIXER		01
14	0503013815	1/4" X 5/8" BOLT		02
15	0503011295	M 8 X 1,25 X 25 BOLT		02
16	0521056945	REAR FRAME	82	01
17	0531061136	EXTENSION		01
18	0503012136	NUT 1/2 NF		04
19	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04




Item	Code	Description	See page	QT
01	0521056955	RIGHT DDD ASSY	75	01
02	0503012136	NUT 1/2 NF		04
03	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
04	0521056582	DOSER	80	01




Item	Code	Description	See page	QT
01	0591011773	RIGHT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 76 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 78 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	77	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	LOW CUBE FERTILIZER / SEED BOX		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	79	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUB DISC - HUB		01
02	0502012896	LOW CUBE FERTILIZER / SEED BOX		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0521056639	SEED ROW TRANSMISSION	81	01
02	0503034575	BOCAL SEED LINE HIGH TITANIUM		01
03	0503010257	1/8" X 1" COTTERPIN		01
04	0502012743	FAST BOLT ASSY		01
05	0571014024	FAST BOLT GUIDE AXLE		02
06	0561019270	FAST BOLT ADJUSTMENT		01
07	0502012744	SPEED LOCK LEVER ASSY		01
08	0502012921	BASE FIXING SYSTEM		01
09	0503010026	3/8" NUT		04
10	0503010025	3/8" SPRING WASHER		04
11	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04




Item	Code	Description	See page	QT
01	0502012932	MINOR SIDE	01	
02	0503017046	BEARING	02	
03	0503011410	ROLLER BEARING	02	
04	0591011321	AXLE GEAR	01	
05	0591011322	SPACER	01	
06	0581019168	POWDER DOOR Ø63,50 X 20,2 X 7,50	01	
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	01	
08	0503010025	3/8" SPRING WASHER	01	
09	0503010179	LOCK WASHER	04	
10	0503011945	503050 CLAMPING RING (FOR AXLE)	01	
11	0503010420	BOLT	02	
12	0503011053	5/16" X 3" C S 6.5 ZN BOLT	04	
13	0502012919	GRAGGER	01	
14	0502012933	LARGER SIDE	01	
15	0502012930	CONICAL GEAR	01	
16	0502012931	CONICAL GEAR	01	
17	0503010585	0,24" X 1.18" SPRING PIN	01	




Item	Code	Description	See page	QT
01	0521056954	LEFT DDD ASSY	83	01
02	0503012136	NUT 1/2 NF		04
03	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
04	0521056582	DOSER	80	01




Item	Code	Description	See page	QT
01	0591011772	LEFT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8" SPRING WASHER		01
10	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 76 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 78 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT	01	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
03	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
04	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN	02	
05	0502012812	SEED ROW ADJUSTMENT LEVER ASSY	01	
06	0503034198	SPRING TRACTION 40 X 198 X 5,5	01	
07	0571018883	PIN FIXER SPRING	03	
08	0503030168	HITCH PIN CLIP	04	
09	0501012140	FLAT WASHER	04	
10	0503017857	BOLT 5/8 UNF 4	04	
11	0591011156	PIVOT ARM SEED ROW	02	
12	0591011157	SPACER LOWER SLEEVE	04	
13	0503019273	AUTO LUBRICANT GLOVE	08	
14	0503010045	O'RING	08	
15	0531061528	REAR LINE SUPPORT	01	
16	0591012829	SPACER LOWER SLEEVE	04	
17	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	02	
18	0503013389	5/8" SELF LOCKING NUT	04	
19	0591011409	FLAT WASHER 16,5 X 35 X 3,00	04	
20	0591012828	LOCK PIN ROW ARTICULAT	01	







Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING		01
03A	0502012030	HOUSING BEARING		01
03B	0503012861	6006 2RS BALL BEARING		01
03C	0503012858	502075 CLAMPING RING (FOR HOLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER		02
06	0503010337	5/16" NUT		02
07	0501013518	FLAT WASHER		02
08	0501010694	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
01A	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0503011255	3/4" LOCK NUT		02
03	0571019062	SLEEVE		01
04	0571019059	SUPPORT WASHER		01
05	0503034320	COMPRESSSION SPRING		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503011854	5/8" X 1-1/4" BOLT		02
08	0511016281	3/4" X 8" BOLT		02
09	0503017960	5/8" X 3-12" BOLT		04
10	0502012813	FLANGE WASHER SPRING		01
11	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
12	0503010417	7/8" NUT		02
13	0502012789	FIXER SUPPORT FERTILIZER ROW		01
14	0521056476	DC 20" ASSY	89	01
15	0503011254	7/8" HEX SELF ADJUSTING NUT		01
16	0591011145	FERTILIZER ROW SUPPORT		01
17	0503019278	LUBRICANT SLEEVE		02
18	0591011147	SLEEVE ARM ROW		02
19	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
01A	0511057271	RH LONG ARM ROW FERTILIZER		01
02	0503011255	3/4" LOCK NUT		02
03	0571019062	SLEEVE		01
04	0571019059	SUPPORT WASHER		01
05	0503034320	COMPRESSSION SPRING		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503011854	5/8" X 1-1/4" BOLT		02
08	0511016281	3/4" X 8" BOLT		02
09	0503017960	5/8" X 3-12" BOLT		04
10	0502012813	FLANGE WASHER SPRING		01
11	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
12	0503010417	7/8" NUT		02
13	0502012789	FIXER SUPPORT FERTILIZER ROW		01
14	0521056476	DC 20" ASSY	89	01
15	0503011254	7/8" HEX SELF ADJUSTING NUT		01
16	0591011146	SUPPORT LONG		01
17	0503019278	LUBRICANT SLEEVE		02
18	0591011147	SLEEVE ARM ROW		02
19	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0571019034	FLANGE WASHER AXLE		01
02	0571019032	SUPPORT WASHER		01
03	0502012813	FLANGE WASHER SPRING		01
04	0591010619	DC SPRING SUPPORT		01
05	0503019274	WASHER		02
06	0581017628	COVER		02
07	0503019277	SLEEVE LUBRICATION SYSTEM		01
08	0501110964	RIGHT ARM WITH SLEEVE		01
09	0501110965	LEFT ARM WITH SLEEVE		01
10	0503034320	COMPRESSION SPRING		01
11	0591010624	SUPPORT ARM SLEEVE		01
12	0591010625	19,50 X 25 X 91,50/91,30 SLEEVE		01
13	0503010417	7/8" NUT		02
14	0503010390	SEAL RING		02
15	0503011198	C3/4" X 6" SCREW		01
16	0501010322	FLAT WASHER		01
17	0503011411	1/2" X 5-1/2" BOLT		01
18	0503010060	1/2" NUT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503011255	3/4" LOCK NUT		01
21	0503030430	7/16 X 2" PIN LOCK		01
22	0503019271	SELF LUBRICATING BUSHING		01
23	0521053248	CUTTING DISK BOX 20 CONICAL ROLLING	90	01
24	0503011254	7/8" HEX SELF ADJUSTING NUT		01
25	0521066743	REGULACION SPRING		01
26	0591011144	FIXATION AXLE		01
27	0591010628	DC AXIS BACKREST WASHER		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	CUTTING DISK BOX	91	01




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	CUTTING DISK BOX		01
09	0502040873	CUTTING DISC AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	NUT		02




Item	Code	Description	See page	QT
01	0521067601	LH REGULATOR		01
02	0521067600	FIXER SUPPORT		01
03	0521067602	GUIDE ASSY		01
04	0501012140	FLAT WASHER		02
05	0511015098	FLAT WASHER		01
06	0503010806	5/8" X 3" BOLT		01
07	0521069693	EAR FIXATION		01
08	0503012795	5/8" HEX SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503016204	CORN DISK 12 ORANGE		01
02	0503016398	TITANIUM RING CORN / SOY (YELLOW FLAT)		01
03	0503016399	TITANIUM RING CORN (GREEN)		01
04	0503016400	TITANIUM RING CORN (GREY)		01
05	0503016401	TITANIUM RING CORN (BLUE)		01




Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016218	DISC OF SOYBEAN		01
03	0503016403	TITANIUM RING FOR SOYBEAN (LILAC)		01
04	0503016404	TITANIUM RING FOR SOYBEAN (PURPLE)		01
05	0503016406	TITANIUM RING FOR SOYBEAN (ORANGE)		01
06	0503016407	TITANIUM RING FOR SOYBEAN		01




Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2" NUT		02




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2" NUT		04




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	102	01
03	0521054760	DOWN LOW CUBE	103	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511815098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0521054761	LEFT LOW CUBE	102	01
03	0521054760	DOWN LOW CUBE	103	01
04	0501017541	RIGHT DOUBLE DISC SCRAPER		01
05	0501017542	LH DOUBLE DISC SCRAPER		01
06	0511815098	FLAT WASHER		02
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503034055	CLAMPING RING		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
13	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
14	0503010025	3/8" SPRING WASHER		01
15	0503010026	3/8" NUT		01
16	0502070062	SCRAPER		01
17	0503011402	0.2" X 0.8" SPRING PIN		01
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02



Item	Code	Description	See page	QT
01	0502012736	HUB LOWER		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06



Item	Code	Description	See page	QT
01	0502012736	HUB LOWER		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503019342	ROLLER BEARING		01
05	0503010546	5/16" X 7/8" BOLT		06
06	0503010337	5/16" NUT		06



MARCHESAN

Technical Publications | Elaboration and Revision

LEONARDO JOSÉ DA SILVA SOUZA

www.marchesan.com.br

