

ROW CROP PLANTERS

PST PLUS TITANIUM MAX - FRAME 3870 (FROM 08/2022)

Code: 0501093374
Series: S-0314
Revision: 00
Date Revision: AGOSTO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111370120	PST PLUS 8/7 CI MH TIT MAX S-0314

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX


0909096471	ASSY FRAME	1
0909094763	08 ROWS PLATFORM SET	2
0909094753	08 ROWS HANDRAIL SET	3
0909092875	GUARD BRACKET	4
0909092133	08 ROWS TRANSMISSION SET	5
0501055112	MICRO GRANULATED CHAIN TENSIONER	6
0511051757	DOUBLE GEAR	7
0501052560	MOTOR AXLE SIGNAL	8
0511040424	RH TRANSMISSION DRIVING ASSY	9
0511051980	DOUBLE BEARING	10
0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8	11
0501058236	BEARING WITH 21Z GEAR	12
0511048701	CHANGE FULL RIGHT	13
0501058212	SEMI MOUNTED RIGHT CHANGE	14
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	15
0501056443	GEAR HOUSING BEARING	16
0501056444	BEARING WITH ROLLER	17
0501056271	GEARBOX CLOSED BEARING	18
0501054655	CHAIN TENSIONER ASSY	19
0511048702	CHANGE FULL LEFT	20
0501058213	LH GEAR BOX	21
0909091622	SEED GEAR BOX (RIGHT)	22
0909092134	SEED GEAR BOX (LEFT)	23
0909091623	07/08 ROWS CARRYNG-WHEELS ASSY	24
0501058240	WHEEL FASTENER WITH TENSIONER	25
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	26
0501058244	WHEEL FIXED CHAIN TENSIONER	27
0501058242	WHEEL MOBILE CHAIN TENSIONER	28
0501058239	WHEEL CHAIN TENSIONER BEARING	29
0501054428	ASSY HEADER EXTENSOR	30
0501053834	MALE QUICK COUPLER	31
0511054971	JACK ASSEMBLY	32
0511056598	MANUAL STORAGE TUBE ASSY	33
0531055695	ALPHA FERTILIZER HOPPER SET - 08 ROWS	34
0531055697	LEFT HOPPER SUPPORT WITH ALPHA FERTILIZER METERING - 08 ROWS	35
0531055292	ALPHA FERTILIZER METERING	36
0531055273	ALPHA FERTILIZER METERING CLAMP	37
0531055376	TRANSMISSION ALPHA FERTILIZER METERING HUB	38
0501053788	3/4 SQUARE AXLE FASTENER	39
0531055696	RIGHT HOPPER SUPPORT WITH ALPHA FERTILIZER METERING - 08 ROWS	40
0511055891	HYDRAULIC MARKER ASSY	41
0531050220	SUPPORT FILTER	42
0501050633	ROW MARKER DISC ASSEMBLY	43
0511053904	ROW MARKER DISC	44
0909095532	SET LABEL ADHESIVE	45
0909095529	SEED FERTILIZER ROW ASSY	46
0531050231	FRONT LINE SEED SHORT RIGHT	47
0531050232	FRONT LINE SEED LONG RIGHT	48
0511052024	FAST CLOSING SET	49
0531050230	SEED SISTEM	50
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	51
0511058650	SEMI-MOUNTED DEPTH CONTROL	52
0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	53

INDEX

0501052627	ASSY DEPTH WHEEL HUB		54
0501052538	DEPTH BAND WITH ARMS		55
0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE		56
0501052297	DEPTH WHEELS REGULATOR ASSY		57
0511054333	COMPACT WHEEL RIGHT WITH BEARING		58
0501052908	COMPACTOR WHEEL WITH BEARING		59
0511054334	COMPACT WHEEL LEFT WITH BEARING		60
0511053252	FERTILIZER SHORT ROW WITH LEFT DDD/18" DC		61
0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC		62
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR		63
0511053172	LEFT LOW CUBE WITH DISC 15		64
0511053173	CUBE LOW RIGHT WITH DISC 15		65
0511044549	18" COULTER BLADE ASSY FOR SHORT ROW		66
0521054686	18" DISC BLADE HUB		67
0521054679	DISC BLADE HUB		68
0501058423	FERTILIZER ROD SPRING ROW		69
0511053253	FERTILIZER LONG ROW WITH RIGHT DDD/18" DC		70
0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC		71
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR		72
0511044573	18" COULTER BLADE ASSY FOR LONG ROW		73
0503062066	DISC SET WITH CORN RING		74
0503062067	DISC SET / RING SOY 90F TITANIUM		75

ASSY FRAME

0909096471




Item	Code	Description	See page	QT
01	0511051759	FRAME WITH WHEEL 3870		01
02	0503010003	1845 GREASE FITTING		04
03	0909091619	HEADER ASSY		01
04	0909094763	08 ROWS PLATFORM SET	2	01
05	0909094753	08 ROWS HANDRAIL SET	3	01
06	0909092875	GUARD BRACKET	4	02
07	0909092133	08 ROWS TRANSMISSION SET	5	01
08	0909091622	SEED GEAR BOX (RIGHT)	22	01
09	0909092134	SEED GEAR BOX (LEFT)	23	01
10	0909091623	07/08 ROWS CARRYNG-WHEELS ASSY	24	01
11	0501054428	ASSY HEADER EXTENSOR	30	01
12	0909092127	CYLINDER SET		01
13	0511059395	HOSE KIT HYDRAULIC		01
13A	0521056046	3/8" X 23.6" TR-TR HOSE ASSY		01
13AA	0501081660	HOSE		01
13AB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
13AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
13AD	0503018952	PLASTIC BOLT		06
13B	0521056047	3/8" X 23.6" TR-TR HOSE ASSY		01
13BA	0501081660	HOSE		01
13BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
13BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
13BD	0503018952	PLASTIC BOLT		06
14	0501053834	MALE QUICK COUPLER	31	02
15	0521013022	TRANSPORT LOCK		01
16	0501068994	8,30 X 78 LOCK PIN		01
17	0503030168	HITCH PIN CLIP		01
18	0511054971	JACK ASSEMBLY	32	02
19	0501065677	STRUT		02
20	0511056598	MANUAL STORAGE TUBE ASSY	33	01
21	0531055695	ALPHA FERTILIZER HOPPER SET - 08 ROWS	34	01


ASSY FRAME

0909096471


Item	Code	Description	See page	QT
22	0511055891	HYDRAULIC MARKER ASSY	41	01
23	0511066652	400 TURNBUCKLE		02
24	0503032624	FERTILIZER HOPPER GUTTER		04
25	0501047895	ROD STOP		01
26	0501047885	ROD STOP		01
27	0501047886	ROD STOP		01
28	0501047887	ROD STOP		01
29	0502012702	BODY SUPPORT CLAMP		01
30	0531011180	UPPER BODY CLIP		01
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		01
32	0503010180	7/16" SPRING WASHER		01
33	0503011751	REDUCTION		04
34	0503010780	N-2050 AMENDMENT		02
35	0503010951	REDUCTION		02
36	0503019958	IMPLEMENT EXTENSION CABLE		01
37	0503019962	MASTER WHIP		01
38	0503019961	MASTER WHIP		03
39	0503017945	CENTRAL VISUM 1040002		01
40	0503063275	ELECTRICAL ASSEMBLY		01
41	0531050220	SUPPORT FILTER	42	01
42	0501050633	ROW MARKER DISC ASSEMBLY	43	02
43	0909095532	SET LABEL ADHESIVE	45	01
44	0909095529	SEED FERTILIZER ROW ASSY	46	08




Item	Code	Description	See page	QT
01	0571011103	PLATAFORM 3550		02
02	0501010096	3/8" X 2" BOLT		02
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
04	0503010025	3/8" SPRING WASHER		02
05	0503010026	3/8" NUT		02



Item	Code	Description	See page	QT
01	0521063059	HANDRAIL		01
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0511064807	STIRRUP		02
02	0501018526	3/8" X 2" BOLT		08
03	0503010025	3/8" SPRING WASHER		08
04	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0521063048	PIVOT SHAFT CARRYING WHEELS		01
02	0501055112	MICRO GRANULATED CHAIN TENSIONER	6	02
02..	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY		02
02..	0501058254	UPPER SEED CHAIN TENSIONER		02
03	0521010569	COUPLING SHAFT		04
04	0503010571	1/4" X 1.1/2 COTTERPIN		08
05	0511065606	MOTOR CHOCK SUPPORT BEARING AXLE		02
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
07	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		14
08	0503010019	1/2" SPRING WASHER		12
09	0503010060	1/2 UNC G.5 ZN HEX NUT		14
10	0501110639	BEARING		06
11	0503010300	5/32" X 1" COTTERPIN		06
12	0503011099	GREASE FITTING		06
13	0571011102	MOTOR SHAFT		02
14	0511051757	DOUBLE GEAR	7	02
15	0511065562	20Z GEAR		02
16	0521010530	JUNCTION AXLE 6,80 X 60		02
17	0503010140	1/8" X 3/4" COTTERPIN		02
18	0501018466	FLAT WASHER		04
19	0511015961	LOCK BUSHING		04
20	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
21	0501052560	MOTOR AXLE SIGNAL	8	02
22	0511040424	RH TRANSMISSION DRIVING ASSY	9	02
23	0501065167	RATCHET PIVOT ARM		02
24	0503010140	1/8" X 3/4" COTTERPIN		06
25	0521062245	DISASSEMBLE RATCHET		02
26	0503030198	0.6" X 2.4" X 0.1" EXTENSION SPRING		02
27	0501069850	RATCHET BAR DES.		02
28	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		02
29	0511051980	DOUBLE BEARING	10	02


Item	Code	Description	See page	QT
30	0541010568	CHOCK BEARING		02
31	0571011100	5/8 X 1905 HEX AXLE		01
32	0571011101	5/8 X 1675 HEX AXLE		01
33	0501058236	BEARING WITH 21Z GEAR	12	02
34	0503011751	REDUCTION		04
35	0511017305	FLAT WASHER		06
36	0503010018	5/32 X 1-1/2 COTTERPIN		04
37	0511048701	CHANGE FULL RIGHT	13	01
38	0511048702	CHANGE FULL LEFT	20	01
39	0501010243	1/2" X 1-1/2" BOLT		04
40	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
41	0503012682	1/2" BSW NUT		04
42	0503012772	40-1 CHAIN X 80 LINK + REDECTION		02
43	0503013252	40-1 X CHAIN X 87 LINK + MENDING		04




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0571011062	AXLE GEAR DOUBLE		01
02	0503011410	ROLLER BEARING		02
03	0521063046	DOUBLE GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0501010163	5/8" X 4-1/2" BOLT		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0521017590	GUIDE AXLE		01
02	0503010542	501045 CLAMPING RING (FOR AXLE)		01
03	0521017593	FLAT WASHER		01
04	0501019734	FLAT WASHER		02
05	0502011329	14Z GEAR WITH RIGHT DRAGGER		01
06	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
07	0501019735	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		01
09	0502010711	RIGHT CAM,LARGER		01
10	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
11	0502011996	SLEEVE FIXER		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 C50 G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01
14	0503010003	1845 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8	11	01
02	0521063285	EXLE DOUBLE BEARING		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0503010397	5/16" X 1-3/4" BOLT		02
05	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	14	01
02	0503010256	3/8" X 3/4" BOLT		01
03	0503010002	1800 GREASE FITTING		02
04	0551018209	DRIVING AXLE		01
05	0521018259	DRIVEN AXLE		01
06	0551018210	DRIVEN AXLE		01
07	0551018211	INTERM SHAFT		01
08	0503030303	SUPPORT WASHER		05
09	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	15	01
10	0501056443	GEAR HOUSING BEARING	16	02
11	0501056271	GEARBOX CLOSED BEARING	18	05
12	0511060396	DRIVE/DRIVEN SHAFT		04
13	0503012389	1/2 BALL		04
14	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
15	0503010060	1/2 UNC G.5 ZN HEX NUT		06
16	0503010395	1/2" X 1-1/4" BOLT		04
17	0511061822	25Z P0.5" GEAR SQUARE HOL		01
18	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
19	0511061759	22Z P12,70 FQ 3/4" GEAR		01
20	0521018630	1.4" X SQUARE 0.8" WASHER		02
21	0503012204	40-1 CHAIN X 82 LINK + RED		02
22	0503012713	40-1 CHAIN X 45 LINK + MEN		01
23	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
25	0503010025	3/8" SPRING WASHER		01
26	0503011953	5/16" X 1" BOLT		08
27	0501010694	FLAT WASHER		08
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
29	0503010337	5/16" NUT		08
30	0503010292	701164 6 X 40 SPRING PIN		02
31	0501054655	CHAIN TENSIONER ASSY	19	02




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	17	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	21	01
02	0503010256	3/8" X 3/4" BOLT		01
03	0503010002	1800 GREASE FITTING		02
04	0551018209	DRIVING AXLE		01
05	0521018259	DRIVEN AXLE		01
06	0551018210	DRIVEN AXLE		01
07	0551018211	INTERM SHAFT		01
08	0503030303	SUPPORT WASHER		05
09	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	15	01
10	0501056443	GEAR HOUSING BEARING	16	02
11	0501056271	GEARBOX CLOSED BEARING	18	05
12	0511060396	DRIVE/DRIVEN SHAFT		04
13	0503012389	1/2 BALL		04
14	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
15	0503010060	1/2 UNC G.5 ZN HEX NUT		06
16	0503010395	1/2" X 1-1/4" BOLT		04
17	0511061822	25Z P0.5" GEAR SQUARE HOL		01
18	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
19	0511061759	22Z P12,70 FQ 3/4" GEAR		01
20	0521018630	1.4" X SQUARE 0.8" WASHER		02
21	0503012204	40-1 CHAIN X 82 LINK + RED		02
22	0503012713	40-1 CHAIN X 45 LINK + MEN		01
23	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
25	0503010025	3/8" SPRING WASHER		01
26	0503011953	5/16" X 1" BOLT		08
27	0501010694	FLAT WASHER		08
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
29	0503010337	5/16" NUT		08
30	0503010292	701164 6 X 40 SPRING PIN		02
31	0501054655	CHAIN TENSIONER ASSY	19	02



Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01



Item	Code	Description	See page	QT
00	0511048701	CHANGE FULL RIGHT	13	01
01	0501058212	SEMI MOUNTED RIGHT CHANGE	14	01
02	0503010256	3/8" X 3/4" BOLT		01
03	0503010002	1800 GREASE FITTING		02
04	0551018209	DRIVING AXLE		01
05	0521018259	DRIVEN AXLE		01
06	0551018210	DRIVEN AXLE		01
07	0551018211	INTERM SHAFT		01
08	0503030303	SUPPORT WASHER		05
09	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	15	01
10	0501056443	GEAR HOUSING BEARING	16	02
11	0501056271	GEARBOX CLOSED BEARING	18	05
12	0502040868	GEAR CONE REPLACEMENT		04
13	0503012389	1/2 BALL		04
14	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
15	0503010060	1/2 UNC G.5 ZN HEX NUT		06
16	0503010395	1/2" X 1-1/4" BOLT		04
17	0511061822	25Z P0.5" GEAR SQUARE HOL		01
18	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
19	0511061759	22Z P12,70 FQ 3/4" GEAR		01
20	0521018630	1.4" X SQUARE 0.8" WASHER		02
21	0503012204	40-1 CHAIN X 82 LINK + RED		02
22	0503012713	40-1 CHAIN X 45 LINK + MEN		01
23	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
25	0503010025	3/8" SPRING WASHER		01
26	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		08
27	0501010694	FLAT WASHER		08
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
29	0503010337	5/16" NUT		08
30	0503010292	701164 6 X 40 SPRING PIN		02




PST PLUS TITANIUM MAX - FRAME 3870 (FROM 08/2022)

Page 22

SEED GEAR BOX (RIGHT)

0909091622

Item	Code	Description	See page	QT
31	0501054655	CHAIN TENSIONER ASSY	19	02



Item	Code	Description	See page	QT
00	0511048702	CHANGE FULL LEFT	20	01
01	0501058213	LH GEAR BOX	21	01
02	0503010256	3/8" X 3/4" BOLT		01
03	0503010002	1800 GREASE FITTING		02
04	0551018209	DRIVING AXLE		01
05	0521018259	DRIVEN AXLE		01
06	0551018210	DRIVEN AXLE		01
07	0551018211	INTERM SHAFT		01
08	0503030303	SUPPORT WASHER		05
09	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	15	01
10	0501056443	GEAR HOUSING BEARING	16	02
11	0501056271	GEARBOX CLOSED BEARING	18	05
12	0502040868	GEAR CONE REPLACEMENT		04
13	0503012389	1/2 BALL		04
14	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
15	0503010060	1/2 UNC G.5 ZN HEX NUT		06
16	0503010395	1/2" X 1-1/4" BOLT		04
17	0511061822	25Z P0.5" GEAR SQUARE HOL		01
18	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
19	0511061759	22Z P12,70 FQ 3/4" GEAR		01
20	0521018630	1.4" X SQUARE 0.8" WASHER		02
21	0503012204	40-1 CHAIN X 82 LINK + RED		02
22	0503012713	40-1 CHAIN X 45 LINK + MEN		01
23	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
25	0503010025	3/8" SPRING WASHER		01
26	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		08
27	0501010694	FLAT WASHER		08
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
29	0503010337	5/16" NUT		08
30	0503010292	701164 6 X 40 SPRING PIN		02




PST PLUS TITANIUM MAX - FRAME 3870 (FROM 08/2022)

Page 23


SEED GEAR BOX (LEFT)

0909092134


Item	Code	Description	See page	QT
31	0501054655	CHAIN TENSIONER ASSY	19	02




Item	Code	Description	See page	QT
00	0511049139	CARRYNG-WHEELS ASSY		01
01	0501055479	WHEEL ARM ASSY		01
01A	0501055389	WHEEL ARM ASSY		01
01Aa	0501067549	WHEEL SUPPORT		01
01Ab	0511065547	WHEEL RIGHT ARM		01
01Ac	0511065548	WHEEL LEFT ARM		01
01Ad	0521010648	1.2" X 2.2" COUPLING SHAFT		02
01Ae	0503010523	1/4" X 2" COTTERPIN		02
01Af	0503030425	1" X 6" X 0.2"TRACTION SPRING		02
01Ag	0501013491	5/8" TENSIONER SPRING		03
01Ah	0503010013	5/8" NUT		06
01B	0511053174	STUB SHAFT HUB ASSY		01
01Ba	0511053874	WITHOUT WHEELS TIRE		01
01Bb	0503013001	9/16" CONICAL NUT		06
01Bc	0503011167	M16 X 2 X 30 BOLT		02
01Bd	0503010027	5/8" SPRING WASHER		02
01Be	0521012190	AXLE LOCK		03
01C	0503060112	WHEEL AND TIRE ASSY - 16-10 L		01
02	0501058240	WHEEL FASTENER WITH TENSIONER	25	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503010797	3/4" X 4" BOLT		04
05	0501010322	FLAT WASHER		04
06	0503010023	3/4" SPRING WASHER		04
07	0503010014	3/4" HEX NUT		04
08	0503015345	CHAIN		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	26	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	27	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	28	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	29	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	29	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	29	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0501067353	508 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0511031563	BAG WITH MANUAL		01
03	0503010267	NYLON CLAMP		01
04	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
05	0501010694	FLAT WASHER		01
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
07	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0531055696	RIGHT HOPPER SUPPORT WITH ALPHA 40 FERTILIZER METERING - 08 ROWS		01
02	0531055697	LEFT HOPPER SUPPORT WITH ALPHA 35 FERTILIZER METERING - 08 ROWS		01
03	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		08
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		08
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		32
08	0503010025	3/8" SPRING WASHER		16
09	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0531064308	RIGHT FERTILIZER HOPPER SUPPORT - 08 ROWS		01
02	0531055292	ALPHA FERTILIZER METERING	36	04
03	0521014167	CONE LOCK		01
04	0511061759	22Z P12,70 FQ 3/4" GEAR		01
05	0501110392	HOPPER SUPPORT BEARING		01
06	0521012485	GEAR BOX BEARING AGRICUTURAL		01
07	0521011039	FLAT WASHER		02
08	0503010003	1845 GREASE FITTING		01
09	0503011953	5/16" X 1" BOLT		02
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
11	0503010337	5/16" NUT		02
12	0501053788	3/4 SQUARE AXLE FASTENER	39	04
13	0503031527	AGRICULTURAL BEARING		04
14	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		01
14A	0501214269	SQUARE SLEEVE		01
14B	0513010701	LOCK PIN		01
15	0501010780	AXLE SQUARE 3/4 X 840		01
16	0521013959	3/4" X 30.2" SQUARE SHAFT		01




Item	Code	Description	See page	QT
01	0503010025	3/8" SPRING WASHER		04
02	0503010026	3/8" NUT		04
03	0513010742	RETAINER 47 X 30 X 10 BRG 5285		01
04	0501214879	HORIZONTAL SEAL LID ALPHA FERTILIZER METERING		01
05	0503035799	ALPHA FERTILIZER DOSAGE NOZZLE		01
06	0503035831	ALPHA FERTILIZER METERING COLLECTOR		01
07	0531055273	ALPHA FERTILIZER METERING CLAMP	37	01
08	0513010692	ALLEN SCREW 1/4 UNC X 7/8 C FLAT SI INOX		04
09	0501011643	3/8 X 1" BOLT		04
10	0503035796	REAR FIXER ALPHA FERTILIZER METERING COLLECTOR		02
11	0513010695	ALLEN SCREW 1/4 UNC X 7/8 CCSI INOX		04
12	0531055376	TRANSMISSION ALPHA FERTILIZER METERING 38 HUB		01
13	0502013049	ALPHA FERTILIZER DOSAGE HOPPER		01
14	0502013048	FLANGE FIXER BODY ALPHA FERTILIZER METERING		01
15	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
15A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
15B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
16	0503035829	ADHESIVE LABEL LOGO TATU 38 X 28 X 0.30 ALPHA FERTILIZER METERING		01
17	0531055518	WORM THREAD ASSEMBLED		01
17A	0531064265	WORM THREAD		01
17B	0503035859	SUPPORT SLEEVE		01
18	0501111143	COATING WITH GUIDE ASSY SUPPLEMENTATION FERTILIZER METERING		01
18A	0501214951	FERTILIZER DOSAGE COATING		01
18B	0531055519	GUIDE ASSY WITH SUPPLEMENTATION		01




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0502013050	TRANSMISSION ALPHA FERTILIZER METERING HOPPER		01
02	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
03	0503011800	SEAL RING		02
04	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
05	0503016065	ROLLER BEARING		02
06	0501214237	TRANSMISSION HOPPER ALPHA FERTILIZER METERING SLEEVE		01
07	0503019373	6006 2RS1 NATIONAL BEARING		02
08	0503012858	502075 CLAMPING RING (FOR HOLE)		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01
10	0501214501	ALPHA FERTILIZER METERING LID LOCK AXIS		01
11	0501214238	SHAFT LOCK SLEEVE HOPPER TRANSMISSION ALPHA FERTILIZER METERING		01
12	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01



Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01



Item	Code	Description	See page	QT
01	0531055292	ALPHA FERTILIZER METERING	36	04
02	0521014167	CONE LOCK		01
03	0511061759	22Z P12,70 FQ 3/4" GEAR		01
04	0501110392	HOPPER SUPPORT BEARING		01
05	0521012485	GEAR BOX BEARING AGRICUTURAL		01
06	0521011039	FLAT WASHER		02
07	0503010003	1845 GREASE FITTING		01
08	0503011953	5/16" X 1" BOLT		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	5/16" NUT		02
11	0501053788	3/4 SQUARE AXLE FASTENER	39	04
12	0503031527	AGRICULTURAL BEARING		04
13	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		01
13A	0501214269	SQUARE SLEEVE		01
13B	0513010701	LOCK PIN		01
14	0501010780	AXLE SQUARE 3/4 X 840		01
15	0521013959	3/4" X 30.2" SQUARE SHAFT		01
16	0531064309	LEFT FERTILIZER HOPPER SUPPORT - 08 ROWS		01




Item	Code	Description	See page	QT
01	0511062984	ROW MARKER SMALLER SUPPORT		02
02	0502010175	HITCH CLAMP		02
03	0501010216	3/4 UNC X 4.1/2 C S G.5 ZN BOLT		04
04	0503010023	3/4" SPRING WASHER		04
05	0503010014	3/4" HEX NUT		04
06	0511062982	RH LARGER SUPPORT		01
07	0511062983	LH LARGER SUPPORT		01
08	0502010175	HITCH CLAMP		02
09	0501010216	3/4 UNC X 4.1/2 C S G.5 ZN BOLT		04
10	0503010023	3/4" SPRING WASHER		04
11	0503010014	3/4" HEX NUT		04
12	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
14	0503010019	1/2" SPRING WASHER		04
15	0503010060	1/2 UNC G.5 ZN HEX NUT		04
16	0501069470	ROW MARKER ARM		02
17	0521061655	BOLT 5/8 UNC X 320 MM		02
18	0521017687	SPACING SLEEVE		02
19	0521010479	SLEEVE ARTICULATION		04
20	0511058449	HYDRAULIC CYLINDER		02
21	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
22	0503010571	1/4" X 1.1/2 COTTERPIN		02
23	0511015779	1" X 4.2" AXLE		02
24	0503010523	1/4" X 2" COTTERPIN		02
25	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
26	0501068994	8,30 X 78 LOCK PIN		02
27	0503030168	HITCH PIN CLIP		02
28	0511062755	740 TURNBUCKLE		02
29	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
30	0511011311	VALVE SUPPORT		01
31	0503010232	5/8" X 1.3/4" BOLT		02


HYDRAULIC MARKER ASSY

0511055891


Item	Code	Description	See page	QT
32	0503010027	5/8" SPRING WASHER		02
33	0503010013	5/8" NUT		02
34	0501054649	HBM SEQUENTIAL VALVE		01
35	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
36	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
37	0503010025	3/8" SPRING WASHER		02
38	0511057709	HYDRAULIC MARKER HAND SET		01
38A	0501080447	3/8" X 122" TR-TC HOSE ASSY		02
38B	0501080515	HOSE 3/8 X 3400 TR-TC		02
38C	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
38CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38CD	0503018952	PLASTIC BOLT		06
38D	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
38DA	0501080422	HOSE 3/8 X 4000 TC-TM		01
38DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
38DD	0503018952	PLASTIC BOLT		06
39	0501053834	MALE QUICK COUPLER	31	02
40	0502012702	BODY SUPPORT CLAMP		04
41	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
42	0521010445	0.53" X 0.75" X 0.45" SLEEVE		04
43	0503010180	7/16" SPRING WASHER		04
44	0503010244	7/16" NUT		04
45	0503012412	5/8 UNC SELF LOCKING NUT		02
46	0501012140	FLAT WASHER		04
47	0501050633	ROW MARKER DISC ASSEMBLY	43	02




Item	Code	Description	See page	QT
01	0591016603	SUPPORT FILTER		01
02	0503019412	RIVET SCREW INTERNAL		02
03	0591016604	CLAMP		01
04	0503013849	1/4" UNC X 3/4" BOLT		02
05	0503010143	1/4" SPRING WASHER		02
06	0503010305	FLAT WASHER		02
07	0503011828	FLAT WASHER		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		02
09	0503010019	1/2" SPRING WASHER		02
10	0521014021	1/2" X 4.5" X 5.4" FASTENER		01




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	44	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01



Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0503033866	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033422	ADHESIVE LABEL	02	
05	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
06	0503031428	READ MANUAL DECAL	01	
07	0503031942	ADHESIVE LABEL	01	
08	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
09	0503031565	ADHESIVE LABEL CARE	02	
10	0503031566	ADHESIVE LABEL	02	
11	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
12	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER	02	
13	0503031669	ADHESIVE LABEL	01	
14	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
15	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
16	0503032930	ADHESIVE LABEL DANGER	04	
17	0503031087	ADHESIVE LABEL	01	
18	0503034003	SERIAL NUMBER TAG 61 X 118	01	
19	0503010001	3.2 X 5.5 RIVET	04	
20	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
21	0503034500	ADHESIVE LABEL	01	



Item	Code	Description	See page	QT
01	0531050231	FRONT LINE SEED SHORT RIGHT	47	04
02	0531050232	FRONT LINE SEED LONG RIGHT	48	03
03	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	51	07
04	0511053252	FERTILIZER SHORT ROW WITH LEFT DDD/18" DC	61	04
05	0511053253	FERTILIZER LONG ROW WITH RIGHT DDD/18" DC	70	03
06	0501013714	STABILIZER BAR		06
07	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		10
08	0503010019	1/2" SPRING WASHER		10
09	0503010060	1/2 UNC G.5 ZN HEX NUT		10
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
11	0521010505	13,50 X 19,00 X 21,50 SLEEVE		10
12	0503010905	1/2" X 2-1/4" BOLT		16
13	0503010019	1/2" SPRING WASHER		16
14	0503010060	1/2 UNC G.5 ZN HEX NUT		16
15	0571013314	GUTTER 25 X 58 X 1500		02
16	0571017368	SUPPORT GUTTER		04
17	0501011643	3/8 X 1" BOLT		04
18	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
19	0503010025	3/8" SPRING WASHER		04
20	0503010026	3/8" NUT		04
21	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		16
22	0503011440	SPRING WASHER		16
23	0503010060	1/2 UNC G.5 ZN HEX NUT		16
24	0501018652	CORN STABILIZER BAR		03
25	0503062066	DISC SET WITH CORN RING	74	07
26	0503062067	DISC SET / RING SOY 90F TITANIUM	75	07
27	0501110231	SCARIFIER HEAD WITH SPIKE 0061		07
28	0511017969	0.1" SPACING PLATE		14
29	0521069124	PIVOTED FERTILIZER ROW NOZZLE		07
30	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		14
31	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		14




Item	Code	Description	See page	QT
32	0503010025	3/8" SPRING WASHER		14
33	0503010026	3/8" NUT		14




Item	Code	Description	See page	QT
001	0511056128	RIGHT DDD SHORT SEED ROW		01
001A	0521062183	SHORT SEED ROW ARM		01
001B	0502011830	ARTICULACCION SUPPORT		01
001C	0521018079	SEED ROW DRAWBAR LID		01
001D	0503014729	1/4" UNF X 1/2" BOLT		02
001E	0503010752	1/2" X 3.1/2" BOLT		02
001F	0503011440	SPRING WASHER		02
001G	0503010060	1/2 UNC G.5 ZN HEX NUT		02
001H	0502011561	BEARING SEMI		01
001I	0502010426	UPPER BEARING SEMI		02
001J	0503010479	BOLT		04
001K	0503011440	SPRING WASHER		04
001L	0503010060	1/2 UNC G.5 ZN HEX NUT		04
001M	0501013354	FLAT WASHER		01
001N	0502011400	18Z CONICAL GEAR		01
001O	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
001P	0502011505	18Z CONICAL GEAR		01
001Q	0521018077	1/2" X 58.6" HEX AXLE		01
001R	0501013352	FLAT WASHER		04
001S	0501013354	FLAT WASHER		01
001T	0503033672	NOZZLE WITHOUT TITANIUM		01
001U	0511051693	BASE FIXING SYSTEM		01
001UA	0502012704	BASE FIXING SYSTEM		01
001UB	0501013354	FLAT WASHER		01
001UC	0502011411	10Z CONICAL GEAR		01
001UD	0502011418	40Z CONICAL GEAR		01
001UE	0511018700	AXLE		01
001UF	0503010002	1800 GREASE FITTING		02
001V	0503015920	3/8" UNC X 1.3/4" BOLT		04
001W	0503011443	3/8" SPRING WASHER		04
001X	0503010026	3/8" NUT		04

Item	Code	Description	See page	QT
001Y	0501059631	DDD SEED 15 X 15 RIGHT		01
001Z	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
002	0511058212	FERTILIZER ROW SUPPORT ASSY		01
003	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
004	0501057261	SPRING ROD SUPPORT		01
004A	0502010890	SPRING ROD SUPPORT		01
004B	0503030679	BOLT 1/2 UNC X 1.1/4 CS PC G.5 ZN		01
004C	0503030678	BOLT 1/2 UNC X 1.1/2 CS PC G.5 ZN		01
004D	0503010060	1/2 UNC G.5 ZN HEX NUT		02
005	0502010891	SPRING CHOCK SUPPORT VARON		01
006	0511060376	SEED SPRING GUIDE		01
007	0521010542	COUPLING SHAFT		01
008	0503010257	1/8" X 1" COTTERPIN		01
009	0502040534	SPRING GUIDE BUSHING LOCK		01
010	0501018535	1/2 X 1 BOLT		01
011	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
012	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
013	0501013753	FLAT WASHER		01
014	0502040534	SPRING GUIDE BUSHING LOCK		01
015	0501018535	1/2 X 1 BOLT		01
016	0503010013	5/8" NUT		01
017	0511052024	FAST CLOSING SET	49	01
018	0531050230	SEED SISTEM	50	01
019	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
020	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
021	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
022	0503010019	1/2" SPRING WASHER		01
023	0503010060	1/2 UNC G.5 ZN HEX NUT		01
024	0503011099	GREASE FITTING		02
025	0503012412	5/8 UNC SELF LOCKING NUT		02




Item	Code	Description	See page	QT
001	0511056129	LEFT DDD LONG SEED ROW		01
001A	0521062184	LONG SEED ROW ARM		01
001B	0502011830	ARTICULACCION SUPPORT		01
001C	0521018079	SEED ROW DRAWBAR LID		01
001D	0503014729	1/4" UNF X 1/2" BOLT		02
001E	0503010752	1/2" X 3.1/2" BOLT		02
001F	0503011440	SPRING WASHER		02
001G	0503010060	1/2 UNC G.5 ZN HEX NUT		02
001H	0502011561	BEARING SEMI		01
001I	0502010426	UPPER BEARING SEMI		02
001J	0503010479	BOLT		04
001K	0503011440	SPRING WASHER		04
001L	0503010060	1/2 UNC G.5 ZN HEX NUT		04
001M	0501013354	FLAT WASHER		01
001N	0502011400	18Z CONICAL GEAR		01
001O	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
001P	0502011505	18Z CONICAL GEAR		01
001Q	0521018078	1/2" X 66.5" HEX AXLE		01
001R	0501013352	FLAT WASHER		04
001S	0501013354	FLAT WASHER		01
001T	0503033672	NOZZLE WITHOUT TITANIUM		01
001U	0511051693	BASE FIXING SYSTEM		01
001UA	0502012704	BASE FIXING SYSTEM		01
001UB	0501013354	FLAT WASHER		01
001UC	0502011411	10Z CONICAL GEAR		01
001UD	0502011418	40Z CONICAL GEAR		01
001UE	0511018700	AXLE		01
001UF	0503010002	1800 GREASE FITTING		02
001V	0503015920	3/8" UNC X 1.3/4" BOLT		04
001W	0503011443	3/8" SPRING WASHER		04
001X	0503010026	3/8" NUT		04


Item	Code	Description	See page	QT
001Y	0501059632	DDD SEED 15X15 LEFT		01
001Z	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
002	0511058212	FERTILIZER ROW SUPPORT ASSY		01
003	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
004	0501057261	SPRING ROD SUPPORT		01
004A	0502010890	SPRING ROD SUPPORT		01
004B	0503030679	BOLT 1/2 UNC X 1.1/4 CS PC G.5 ZN		01
004C	0503030678	BOLT 1/2 UNC X 1.1/2 CS PC G.5 ZN		01
004D	0503010060	1/2 UNC G.5 ZN HEX NUT		02
005	0502010891	SPRING CHOCK SUPPORT VARON		01
006	0511060376	SEED SPRING GUIDE		01
007	0521010542	COUPLING SHAFT		01
008	0503010257	1/8" X 1" COTTERPIN		01
009	0502040534	SPRING GUIDE BUSHING LOCK		01
010	0501018535	1/2 X 1 BOLT		01
011	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
012	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
013	0501013753	FLAT WASHER		01
014	0502040534	SPRING GUIDE BUSHING LOCK		01
015	0501018535	1/2 X 1 BOLT		01
016	0503010013	5/8" NUT		01
017	0511052024	FAST CLOSING SET	49	01
018	0531050230	SEED SISTEM	50	01
019	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
020	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
021	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
022	0503010019	1/2" SPRING WASHER		01
023	0503010060	1/2 UNC G.5 ZN HEX NUT		01
024	0503011099	GREASE FITTING		02
025	0503012412	5/8 UNC SELF LOCKING NUT		02




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0503063274	ASSY TITANIUM		01
02	0503062276	ASSY SEED DEPOSIT		01
03	0503010371	5/16" X 1" BOLT		05
04	0501010694	FLAT WASHER		05
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
06	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	52	01
02	0501052538	DEPTH BAND WITH ARMS	55	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	58	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	60	01
07	0503033942	COMPACTOR WHEEL REGULATOR LID		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT ARM WHEEL DEPTH WITH CUBE	53	01
07	0511058651	RIGHT ARM WHEEL DEPTH WITH CUBE	56	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	57	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL HUB	54	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	PROTECTION LID		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL HUB	54	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	59	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	59	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	62	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	66	01
07	0501058423	FERTILIZER ROD SPRING ROW	69	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	63	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	64	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	65	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01



Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0503010003	1845 GREASE FITTING		01
03	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
04	0521014137	RIGHT ARM BLADE DISC		01
05	0521014138	SUPPORT ARM LEFT BALDE DISC		01
06	0521054686	18" DISC BLADE HUB	67	01
07	0503010756	0.2" X 2.4" SPRING PIN		01
08	0503010361	SPRING PIN		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	1902020394	SPRING SUPPORT		01
14	1902020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0503010014	3/4" HEX NUT		02
17	0541018684	FLAT WASHER		01
18	0503013185	3/4" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01
21	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0521054679	DISC BLADE HUB	68	01
02	0603026013	PLAIN COULTER BLADE		01

DISC BLADE HUB


0521054679




Item	Code	Description	See page	QT
01	0502011562	DISC BLADE HUB		01
02	0502020641	BLADE DISC FLANGE		01
03	0503010276	6206 BALL BEARING		02
04	0521013610	BLADE DISC HUB AXLE		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
06	0503012417	SEAL		02
07	0503011800	SEAL RING		02
08	0503010691	1/4" GREASE FITTING		01
09	0521015376	DUST CLOAK		02
10	0503030832	FLAT WASHER		02
11	0511015346	FLAT WASHER		02
12	0521013510	3/4" NUT		02
13	0503010012	1" SPRING WASHER		02
14	0503010371	5/16" X 1" BOLT		06
15	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 C50P G.5 ZN		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" HEX NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT 71		01
02	0501010066	DOUBLE DISC		01
03	0521017831	3/4" X 9" BOLT		02
04	0511017232	SUPPORT SLEEVE SPACER		02
05	0511017232	FLAT WASHER		01
06	0503011255	3/4" LOCK NUT		01
07	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	73	01
08	0501058423	FERTILIZER ROD SPRING ROW	69	01
09	0503030392	LEFT FERTILIZER NOZZLE		01
10	0503031145	2" X 2" X 20" HOSE		01
	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061153	FERTILIZER ROW LONG ARM		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	72	01




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	65	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	64	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0503010003	1845 GREASE FITTING		01
03	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE		01
04	0521014137	RIGHT ARM BLADE DISC		01
05	0521014138	SUPPORT ARM LEFT BALDE DISC		01
06	0521054686	18" DISC BLADE HUB	67	01
07	0503010756	0.2" X 2.4" SPRING PIN		01
08	0503010361	SPRING PIN		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	1902020394	SPRING SUPPORT		01
14	1902020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0503010014	3/4" HEX NUT		02
17	0541018684	FLAT WASHER		01
18	0503013185	3/4" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01
21	0503011411	1/2" X 5-1/2" BOLT		01



Item	Code	Description	See page	QT
01	0503016204	CORN DISC 12 ORANGE		01
02	0503016398	TITANIUM RING CORN / SOY (YELLOW FLAT)		01
03	0503016399	TITANIUM RING CORN (GREEN)		01
04	0503016400	TITANIUM RING CORN (GREY)		01
05	0503016401	TITANIUM RING CORN (BLUE)		01



Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016218	DISC OF SOYBEAN		01
03	0503016403	TITANIUM RING FOR SOYBEAN (LILAC)		01
04	0503016404	TITANIUM RING FOR SOYBEAN (PURPLE)		01
05	0503016406	TITANIUM RING FOR SOYBEAN (ORANGE)		01
06	0503016407	TITANIUM RING FOR SOYBEAN		01



MARCHESAN

Technical Publications | Elaboration and Revision

LORENA ROCHA ALVES

www.marchesan.com.br

