

ROW CROP PLANTERS

PST DUO FLEX TITANIUM - FRAME
4880/5340/5950/6850 - CSU (FROM 08/2022)

Code: 0501093395
Series: S-0119
Revision: 00
Date Revision: MAIO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS

Code	Description
0111240540	PST DUO FLEX 4880/10E500 ESPECIAL S-0119
0111240547	PST DUO FLEX 4880/11E450 ESPECIAL S-0119
0111240551	PST DUO FLEX 5340/11E500 ESPECIAL S-0119
0111240549	PST DUO FLEX 5950/13E450 ESPECIAL S-0119
0111240546	PST DUO FLEX 6850/15E450 ESPECIAL S-0119

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

INDEX

0909096525	ASSY FRAME - 4880/5340/5950/6850	1
0521054576	FRAME WITH ARTICULATION 4880	2
0521054567	RIGHT FRAME WITH WHEELED AXLE 4880	3
0521054569	FRAME LEFT WITH SHAFT WHEELED 4880	4
0521054577	FRAME WITH ARTICULATION 5340	5
0521054570	RIGHT FRAME WITH WHEELED AXLE 5340	6
0521054571	FRAME LEFT WITH SHAFT WHEELED 5340	7
0521054578	FRAME WITH ARTICULATION 5950	8
0521054572	RIGHT FRAME WITH WHEELED AXLE 5950	9
0521054573	FRAME LEFT WITH SHAFT WHEELED 5950	10
0521053418	FRAME WITH ARTICULATION 6850	11
0521053420	RIGHT FRAME WITH WHEELED AXLE 6850	12
0521053419	FRAME LEFT WITH SHAFT WHEELED 6850	13
0511058667	SPRING FLOW ENSEMBLY	14
0521058402	WHEELED WITH 655 DRIFT SPRING WITH TRANSMISSION	15
0521058401	655 WHEELED SUPPORT WITH TRANSMISSION	16
0501058241	WHEEL SUPPORT CHAIN TENSIONER	17
0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH TRANSMISSION	18
0503063172	WHEEL	19
0521055233	WHEELED TRANSMISSION WITHOUT TIRE	20
0521055234	WHEELED FASTENER	21
0521055236	INTERMEDIARY CURRENT STRETCHER	22
0521055237	WHEEL FIXED CURRENT STRETCHER	23
0521055235	WHEEL MOBILE CURRENT STRETCHER	24
0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	25
0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	26
0521058394	WHEEL WITH TIRE	27
0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	28
0521054561	CYLINDER ASSEMBLY	29
0511058406	HYDRAULIC CYLINDER	30
0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	31
0501054452	FLOW DIVIDING VALVE	32
0501053834	MALE QUICK COUPLER	33
0511056832	ASSY SYSTEM HYDRAULIC 6850	34
0511056532	ASSY SYSTEM HYDRAULIC 5340	35
0501054694	FLOW DIVIDING VALVE ASSY	36
0909095186	DRAWBAR ASSY	37
0511055096	TRACTOR HITCH	38
0531052545	LEFT EXTENSION DRAWBAR 36.00 - 4880/5950	39
0521053311	RIGHT EXTENSOR DRAWBAR 36,00 - 4880/5720/5950	40
0511052311	3 POINT TURNBUCKLE	41
0511056736	HOSE SUPPORT	42
0531056440	4880 FERTILIZER HOPPER SET	43
0531056441	ALPHA FERTILIZER SILO SET 5340	44
0531056687	5340 LEFT HOPPER SUPPORT WITH FERTILIZER METERING	45
0531056686	5340 RIGHT HOPPER SUPPORT WITH FERTILIZER METERING	46
0531056566	4880 RIGHT HOPPER SUPPORT WITH FERTILIZER METERING	47
0531056567	4880 LEFT HOPPER SUPPORT WITH FERTILIZER METERING	48
0531055319	ALPHA II FERTILIZER METERING	49
0531055863	ASSY TRANSMISSION HUB	50
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	51
0531059139	ASSY COLLECTOR	52
0531055273	ALPHA FERTILIZER METERING CLAMP	53
0501053788	3/4 SQUARE AXLE FASTENER	54



MARCHESAN

INDEX

0531057911	22Z GEAR SIDE BEARING ASSEMBLY	55
0531057901	GEAR	56
0531056442	ALPHA FERTILIZER HOPPER SET 5950	57
0531056569	5950 LEFT HOPPER SUPPORT WITH FERTILIZER METERING	58
0531056568	5950 RIGHT HOPPER SUPPORT WITH FERTILIZER METERING	59
0531056444	6850 ALPHA FERTILIZER HOPPER SET	60
0531056428	6850 LEFT HOPPER SUPPORT WITH FERTILIZER METERING	61
0531056427	6850 RIGHT HOPPER SUPPORT WITH FERTILIZER METERING	62
0531057978	SIDE BEARING WITH TRANSMISSION	63
0909095174	ASSEMBLY TRANSMISSION 4880/5340/5720/5950/6350/6850	64
0501110639	BEARING	65
0501052560	MOTOR AXLE SIGNAL	66
0511051434	TRANSMISSION ACTUATOR	67
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	68
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	69
0521043316	RIGHT GEAR BOX ASSY	70
0521043317	LEFT GEAR BOX ASSY	71
0501058212	SEMI MOUNTED RIGHT CHANGE	72
0501058213	LH GEAR BOX	73
0511059266	CLOSED BEARING	74
0501056271	GEARBOX CLOSED BEARING	75
0501056443	GEAR HOUSING BEARING	76
0501056444	BEARING WITH ROLLER	77
0501048790	AXLE WITH RING	78
0501054655	CHAIN TENSIONER ASSY	79
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	80
0501055112	MICRO GRANULATED CHAIN TENSIONER	81
0521055217	LOWER CURRENT STRETCH	82
0501058254	UPPER SEED CHAIN TENSIONER	83
0521055216	BEARING WITH GEAR	84
0521055218	BEARING GEAR WITH DOUBLE	85
0521055214	BEARING GEAR WITH	86
0521055215	DOUBLE TRANSMISSION BEARING	87
0511054363	CHAIN TENSIONER	88
0521054562	PLATFORM ASSEMBLY 4880	89
0521054563	PLATFORM ASSEMBLY 5340	90
0521054564	PLATFORM ASSEMBLY 5950	91
0521054566	PLATFORM ASSEMBLY 6850	92
0511056746	HANDRAIL ASSY 4880	93
0511056535	HANDRAIL ASSY 5340	94
0521054568	HANDRAIL ASSY 5950	95
0511056836	HANDRAIL ASSY 6850	96
0511054971	JACK ASSEMBLY	97
0511056536	LADDER ASSEMBLY	98
0511059585	ASSEMBLY CSU C3 SEMI MOUNTED 4880	99
0511059584	2 HOPPERS WITH 10 CONDUCTORS SET	100
0511057690	3" ARTICULATED SEED CONDUCTOR	101
0521052687	RIGHT SUPPORT TOWER WITH BOLT	102
0521051931	LEFT SUPPORT TOWER WITH BOLT	103
0521051927	TOWER SUPPORT HOPPER	104
0531057985	ASSEMBLY CSU	105
0531057981	SINGLE SEED BOX SET	106
0531057986	ASSEMBLY CSU C3 SEMI MOUNTED	107
0531057984	SET CSU SM WITH 3 X 175 2 BOXES 7 MOUTH	108
0531057975	5950 SINGLE SEED HOPPER SET FOR 13 NOZZLES	109



MARCHESAN

INDEX

0531057980	5950 SINGLE SEED HOPPER FOR 13 NOZZLES	110
0531051994	RIGHT TOWER SUPPORT HOPPER SUPPORT WITH SCREW	111
0531051996	LEFT TOWER SUPPORT HOPPER SUPPORT WITH SCREW	112
0531057971	6850 SINGLE SEED HOPPER SET FOR 15 NOZZLES	113
0531057974	6850 SINGLE SEED HOPPER FOR 15 NOZZLES	114
0531057950	3" X 175 SEED NOZZLE WITH FIXING	115
0531054471	CAP WITH FIXING	116
0531052006	LEFT SUPPORT TOWER WITH BOLT	117
0521051929	SIDE FIXED TOWER LEFT HOPPER SUPPORT WITH SCREW	118
0521051928	FIXED TOWER SIDE RIGHT HOPPER SUPPORT WITH SCREW	119
0531052007	RIGHT SUPPORT TOWER RIGHT SUPPORT	120
0521054580	REAR LIGHTING ASSEMBLY 4880	121
0521054582	REAR LIGHTING ASSEMBLY 5720/5950	122
0521054584	REAR LIGHTING ASSEMBLY 6850	123
0521052792	MOUNTED REAR LIGHT	124
0521054585	MANUAL CANISTER ASSY	125
0521054181	TOOL BOX ASSEMBLY	126
0521054525	CONTAINER WATER TANK	127
0909095190	ASSY HEX AXLE	128
0531059620	KIT WITH ALPHA COMPONENTS - 10 ROWS	129
0531059621	KIT WITH ALPHA COMPONENTS - 11 ROWS	130
0531059623	KIT WITH ALPHA COMPONENTS - 13 ROWS	131
0531059625	KIT WITH ALPHA COMPONENTS - 15 ROWS	132
0521056983	SEMI MOUNTED HYDRAULIC MARKER 4880	133
0511056735	SEMI MOUNTED HYDRAULIC MARKER 5340	134
0511056789	SEMI MOUNTED HYDRAULIC MARKER 5720/5950	135
0511058449	HYDRAULIC CYLINDER	136
0501054649	HBM SEQUENTIAL VALVE	137
0521055204	ROW MARKER DISC	138
0909095138	6850/7860/7960/8160/8460/8960/9460/9960/10460 DOBLE HYDRAULIC ROW MARKER	139
0511059216	DOUBLE ARTICULATED HYDRAULIC MARKER	140
0511058431	HYDRAULIC CYLINDER	141
0521054588	LABEL ASSY FOR HYDRAULIC MARKER/CSU - 4880	142
0531058816	LABEL ASSY FOR HYDRAULIC MARKER/CSU - 4880	143
0531058866	ALPHA LABELS SET	144
0531058841	LABEL ASSY FOR HYDRAULIC MARKER/CSU - 5950	145
0531057782	LABEL ASSY FOR HYDRAULIC MARKER/CSU - 6850	146
0531054946	SET OF PLANTING MONITORING 16	147
0909096526	SEED/FERTILIZER ROW	148
0521053227	FRONT LEFT SHORT SEED ROW	149
0521053230	FRONT RIGHT SHORT SEED ROW	150
0521053228	FRONT LEFT LONG SEED ROW	151
0521053229	FRONT RIGHT LONG SEED ROW	152
0521054736	FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED ROW	153
0521055213	SEED ROW BEARING	154
0521055223	SEED ROW TRANSMISSION HUB	155
0511055260	SEED ROW CHAIN TENSIONER	156
0521055226	BEARING WITH AXLE JOINT	157
0501059326	UNIVERSAL JOINT AXLE	158
0521055219	BEARING WITH GEAR 17Z HEX 5/8	159
0521055220	BEARING FRONT SEED ROW	160
0511059333	SEMI-ASSEMBLED MECHANICAL FRAME	161
0511059334	BEARING WITH LONG FRONT AXLE	162
0511058143	UNIVERSAL JOINT AXLE	163




MARCHESAN

INDEX

0521055227	BEARING SHAFT HEX	164
0521052266	SEMI-ASSEMBLED MECHANICAL FRAME SPA	165
0521052268	LONG SHAFT BEARING AND JOINT SPA	166
0521052269	UNIVERSAL JOINT AXLE SPA	167
0521054771	LEFT REAR SEED ROW	168
0521054770	RIGHT REAR SEED ROW	169
0521055870	RIGHT DOUBLE DISC SEED 15 X 15	170
0521055871	LEFT DOUBLE DISC SEED 15 X 15	171
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	172
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	173
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	174
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	175
0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	176
0511052302	LH SUPPORT DDD GUIDE	177
0511052301	SUPPORT DDD 15 RIGHT	178
0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	179
0521055065	ASSY DEPTH / COMPACTOR	180
0501056769	DEPTH WHEELS REGULATOR ASSY	181
0521055033	SEMI-ASSEMBLED COMPACTOR BODY	182
0521055054	LEFT ARM WITH SLEEVE	183
0521055066	RIGHT ARM WITH SLEEVE	184
0521055068	RAYED WHEEL CENTER CLOSED	185
0521055055	HUB WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	186
0521054990	LEFT COMPACTOR WHEEL	187
0521055017	RIGHT COMPACTOR WHEEL	188
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	189
0521055397	DEEP WHEEL / COMPACTOR SYSTEM	190
0521055398	DEPTH WHEEL	191
0521054984	DEPTH/COMPACTOR SYSTEM - SPT	192
0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	193
0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	194
0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	195
0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	196
0501052538	DEPTH BAND WITH ARMS	197
0501059228	ADJUSTMENT LEVER	198
0521055399	LEFT ARM WITH WHEEL	199
0521055058	LEFT ARM	200
0521055400	RIGHT ARM WITH WHEEL	201
0521055074	RIGHT ARM WITH O-RING	202
0521055401	ASSY WHEEL	203
0521055073	ASSEMBLY DEPTH WHEEL HUB	204
0521055093	BODY COMPACTOR	205
0531050978	DEPTH CONTROL WITH FAST ANGLE REGULATING AXIS	206
0531050980	SEM SEMI-ASSEMBLED CONTROL WITHOUT LUBRICATION	207
0501052297	DEPTH WHEELS REGULATOR ASSY	208
0531050975	LEFT ARM WHEELS DEPTH WITH HUB WITHOUT LUBRICATION	209
0531050973	RIGHT ARM DEPTH WHEEL WITH HUB WITHOUT LUBRICATION	210
0531050974	CUBE CONTROL DEPTH WITHOUT LUBRICATION	211
0511055819	DEPTH BAND WITH RIM	212
0521054811	FERTILIZER SHORT ROW	213
0521054812	LONG FERTILIZER ROW	214
0521053231	DPL 20 SHORT ROW WITHOUT LUBRICATION CONICAL BEARING	215


INDEX

0521053232	DPL 20 LONG ROW WITHOUT LUBRICATION CONICAL BEARING	216
0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	217
0521053697	DISC BLADE HUB	218
0521054906	SPRING ASSY FERTILIZER	219
0521054900	FERTILIZER SHORT ROW ASSY DOC20	220
0521054901	LONG FERTILIZER DOC20 ASSY ROW	221
0521054845	DPLO 20 SHORT ROW WITHOUT LUBRICATION	222
0521054846	DPLO 20 LONG ROW WITHOUT LUBRICATION CONICAL BEARING	223
0521054844	20" WAVY COULTER BLADE HUB	224
0521054769	LEFT DDD FERTILIZER WITH SUPPORT	225
0521055869	LEFT DUAL FERTILIZER DISC	226
0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	227
0521055868	RIGHT DUAL FERTILIZER DISC	228
0521050096	SEED HOPPER SYSTEM (CSU)	229
0521050118	3" NOZZLE SEED HOPPER	230
0511052058	SEED SYSTEM TITANIUM	231
0511052024	FAST CLOSING SET	232
0521053946	SCARING ROD	233
0521050525	FIXER FERTILIZER CONDUCTOR	234
0503062066	DISC SET WITH CORN RING	235
0503062067	DISC SET / RING SOY 90F TITANIUM	236
0521057957	FIXED ROD EXTENSION WITH FIXATION	237
0521041006	COVERING WHEEL ASSY FERTILIZER RIGHT IRON	238
0521041007	COVERING WHEEL ASSY FERTILIZER LEFT IRON	239
0511052086	LEFT WHEEL COVERING IRON FERTILIZER	240
0521054912	RIGHT SUPPORT WITH DOC 18	241
0521054914	HUB WITH DOC 18 RIGHT	242
0521054913	LEFT SUPPORT WITH DOC 18	243
0521054915	HUB WITH DOC 18 LEFT	244
0521050168	MOUNTED FERTILIZER CONDUCTOR	245
0501054292	V RIGHT WHEEL PRESS FERTILIZER ASSY	246
0501054293	V LEFT WHEEL PRESS FERTILIZER ASSY	247
0511054333	COMPACT WHEEL RIGHT WITH BEARING	248
0511054334	COMPACT WHEEL LEFT WITH BEARING	249
0501052908	COMPACTOR WHEEL WITH BEARING	250
0531055312	TITANIUM SINGLE SEED SYSTEM	251
0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	252
0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK LID	253




Item	Code	Description	See page	4880	5340	5950	6850
01	0521054576	FRAME WITH ARTICULATION 4880	2	01	00	00	00
01.	0521054577	FRAME WITH ARTICULATION 5340	5	00	01	00	00
01..	0521054578	FRAME WITH ARTICULATION 5950	8	00	00	01	00
01...	0521053418	FRAME WITH ARTICULATION 6850	11	00	00	00	01
02	0521064285	LOCK LOWER FRAME		01	01	01	01
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		01	01	01	01
04	0503010002	1800 GREASE FITTING		01	01	01	01
05	0503010003	1845 GREASE FITTING		05	05	05	05
06	0503010004	1890 GREASE FITTING		02	02	02	02
07	0511058667	SPRING FLOW ENSEMBLY	14	01	01	01	01
08	0521058402	WHEELED WITH 655 DRIFT SPRING WITH 15 TRANSMISSION	15	04	04	04	04
09	0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT 25 TRANSMISSION	25	00	00	02	02
10	0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	31	01	00	01	00
10.	0511056832	ASSY SYSTEM HYDRAULIC 6850	34	00	00	00	01
10..	0511056532	ASSY SYSTEM HYDRAULIC 5340	35	00	01	00	00
11	0909095186	DRAWBAR ASSY	37	01	00	01	01
12	0511056736	HOSE SUPPORT	42	01	01	01	01
13	0531056440	4880 FERTILIZER HOPPER SET	43	01	00	00	00
13.	0531056441	ALPHA FERTILIZER SILO SET 5340	44	00	01	00	00
13..	0531056442	ALPHA FERTILIZER HOPPER SET 5950	57	00	00	01	00
13...	0531056444	6850 ALPHA FERTILIZER HOPPER SET	60	00	00	00	01
14	0909095187	ASSEMBLY TRANSMISSION		01	01	01	01
		4880/5340/5950/6350/6850					
15	0521054562	PLATFORM ASSEMBLY 4880	89	01	00	00	00
15.	0521054563	PLATFORM ASSEMBLY 5340	90	00	01	00	00
15..	0521054564	PLATFORM ASSEMBLY 5950	91	00	00	01	00
15...	0521054566	PLATFORM ASSEMBLY 6850	92	00	00	00	01
16	0511056746	HANDRAIL ASSY 4880	93	01	00	00	00
16.	0511056535	HANDRAIL ASSY 5340	94	00	01	00	00
16..	0521054568	HANDRAIL ASSY 5950	95	00	00	01	00


Item	Code	Description	See page	4880	5340	5950	6850
16...	0511056836	HANDRAIL ASSY 6850	96	00	00	00	01
17	0511054971	JACK ASSEMBLY	97	04	04	04	04
18	0511056536	LADDER ASSEMBLY	98	02	02	02	02
19	0511059585	ASSEMBLY CSU C3 SEMI MOUNTED 4880	99	01	00	00	00
19.	0531057985	ASSEMBLY CSU	105	01	00	00	00
19..	0531057981	SINGLE SEED BOX SET	106	00	01	00	00
19...	0531057975	5950 SINGLE SEED HOPPER SET FOR 13 NOZZLES	109	00	00	01	00
19....	0531057971	6850 SINGLE SEED HOPPER SET FOR 15 NOZZLES	113	00	00	00	01
20	0521054580	REAR LIGHTING ASSEMBLY 4880	121	01	00	00	00
20.	0521054581	REAR LIGHTING ASSEMBLY 5340		00	00	01	00
20..	0521054582	REAR LIGHTING ASSEMBLY 5720/5950	122	00	00	01	00
20...	0521054584	REAR LIGHTING ASSEMBLY 6850	123	00	00	00	01
21	0521054585	MANUAL CANISTER ASSY	125	01	01	01	01
22	0501065677	STRUT		02	02	02	02
23	0541015451	FIXED KEY 2.3/8 X 2.3/4		01	01	01	01
24	0501047895	25 ROD STOP		02	02	02	02
25	0501047885	30 ROD STOP		02	02	02	02
26	0501047886	35 ROD STOP		02	02	02	02
27	0501047887	40 ROD STOP		02	02	02	02
28	0521013022	TRANSPORT LOCK		02	02	02	02
29	0503030168	HITCH PIN CLIP		02	02	02	02
30	0501068994	8,30 X 78 LOCK PIN		02	02	02	02
31	0521054181	TOOL BOX ASSEMBLY	126	01	01	01	01
32	0521054525	CONTAINER WATER TANK	127	01	01	01	01
33	0503019262	SOAP DISH VACUUM		01	01	01	01
34	0503010780	N-2050 AMENDMENT		02	02	02	02
35	0503011750	AMENDMENT WITH LOCK		06	06	06	06
36	0503011751	REDUCTION		06	06	06	06
37	0503010951	REDUCTION		04	04	04	04
38	0909095190	ASSY HEX AXLE	128	01	01	01	01
39	0531059620	KIT WITH ALPHA COMPONENTS - 10 ROWS	129	01	00	00	00
39.	0531059621	KIT WITH ALPHA COMPONENTS - 11 ROWS	130	00	01	00	00
39..	0531059623	KIT WITH ALPHA COMPONENTS - 13 ROWS	131	00	00	01	00
39...	0531059625	KIT WITH ALPHA COMPONENTS - 15 ROWS	132	00	00	00	01
40	0521065613	HOSE HOLDER		01	01	01	01
41	0503011953	5/16" X 1" BOLT		02	02	02	02
42	0503013816	5/16" LOCKNUT		02	02	02	02
43	0521056983	SEMI MOUNTED HYDRAULIC MARKER 4880	133	01	00	00	00
43.	0511056735	SEMI MOUNTED HYDRAULIC MARKER 5340	134	00	01	00	00
43..	0511056789	SEMI MOUNTED HYDRAULIC MARKER 5720/5950	135	00	00	01	00
43...	0909095138	6850/7860/7960/8160/8460/8960/9460/9960/10460 DOBLE HYDRAULIC ROW MARKER	139	00	00	00	01
44	0521055204	ROW MARKER DISC	138	02	02	02	02
45	0503010023	3/4" SPRING WASHER		02	02	02	02
46	0503010014	3/4" HEX NUT		02	02	02	02
47	0521054588	LABEL ASSY FOR HYDRAULIC MARKER/CSU - 4880	142	01	00	00	00
47.	0531058816	LABEL ASSY FOR HYDRAULIC MARKER/CSU - 4880	143	01	00	00	00
47..	0531058866	ALPHA LABELS SET	144	00	01	00	00
47...	0531058841	LABEL ASSY FOR HYDRAULIC MARKER/CSU - 5950	145	00	00	01	00
47....	0531057782	LABEL ASSY FOR HYDRAULIC MARKER/CSU - 6850	146	00	00	00	01
48	0521054561	CYLINDER ASSEMBLY	29	01	01	01	01
49	0531054946	SET OF PLANTING MONITORING 16	147	00	00	01	00
50	0501090994	INSTRUCTIONS MANUAL		01	01	01	01
51	0909096526	SEED/FERTILIZER ROW	148	01	01	01	01




Item	Code	Description	See page	QT
01	0521054567	RIGHT FRAME WITH WHEELED AXLE 4880	3	01
02	0521054569	FRAME LEFT WITH SHAFT WHEELED 4880	4	01
03	0501110791	FRONT ARTICULATOR HUB WITH SLEEVES		01
04	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581018964	TROUGH 24 X 50 X 1320		02
20	0581018965	TROUGH 24 X 50 X 940		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8 SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
01	0521068942	RIGHT FRAME		01
02	0521069426	RIGHT ARTICULATED AXLE		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0521068943	LEFT FRAME		01
02	0521069427	LEFT ARTICULATED AXLE		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0521054570	RIGHT FRAME WITH WHEELED AXLE 5340	6	01
02	0521054571	FRAME LEFT WITH SHAFT WHEELED 5340	7	01
03	0501110791	FRONT ARTICULATOR HUB WITH SLEEVES		01
04	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581018962	TROUGH 24 X 50 X 1490		03
20	0581018963	24 X 50 X 1007 GUTTER		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8 SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
01	0521068944	RIGHT FRAME 5340		01
02	0521069428	ARTICULATED AXLE RIGHT SIDE ROLLER 5340		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0521068945	LEFT FRAME 5340		01
02	0521069429	LEFT ARTICULATED AXLE 5340		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0521054572	RIGHT FRAME WITH WHEELED AXLE 5950	9	01
02	0521054573	FRAME LEFT WITH SHAFT WHEELED 5950	10	01
03	0501110791	FRONT ARTICULATOR HUB WITH SLEEVES		01
04	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581018960	TROUGH 24 X 50 X 1855		02
20	0581018961	TROUGH 24 X 50 X 945		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8 SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
01	0521068946	RIGHT FRAME 5950		01
02	0521069430	RIGHT SIDE RIGHT ARTICULATED AXLE 5950		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0521068947	LEFT FRAME 5950		01
02	0521069431	LEFT ARTICULATED AXLE 5950		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0521053420	RIGHT FRAME WITH WHEELED AXLE 6850	12	01
02	0521053419	FRAME LEFT WITH SHAFT WHEELED 6850	13	01
03	0501110791	FRONT ARTICULATOR HUB WITH SLEEVES		01
04	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581017758	TROUGH 24 X 50 X 1900 6850		02
20	0581017759	TROUGH 24 X 50 X 1350 6850		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8 SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03
26	0591019177	SLEEVE		01




Item	Code	Description	See page	QT
01	0521068950	RIGHT FRAME 6850		01
02	0521069172	RIGHT SIDE RIGHT ARTICULATED AXLE 6850		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0521068951	LEFT FRAME 6850		01
02	0521069173	LEFT ARTICULATED AXLE 6850		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		06
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		12
03	0501012140	FLAT WASHER		24




Item	Code	Description	See page	QT
01	0521058401	655 WHEELED SUPPORT WITH TRANSMISSION	16	01
02	0521055234	WHEELED FASTENER	21	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	WHEEL SUPPORT CHAIN TENSIONER	17	01
07	0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH 18 TRANSMISSION		01
08	0503018981	BOLT		02
09	0503010027	5/8 SPRING WASHER		04
10	0591010589	BODY LOCK WHEEL		01
11	0521069983	WHEEL COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0503063172	WHEEL	19	01
02	0521055233	WHEELED TRANSMISSION WITHOUT TIRE	20	01




Item	Code	Description	See page	QT
01	0503019458	TIRE 7.00X16 14PR		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE	01	
02	0503010330	KM 9 LOCKNUT	01	
03	0503010329	LOCK WASHER	01	
04	0511015949	LOCK NUT	01	
05	0503010804	00547-B SEAL	02	
06	0503019364	BEARING 25590/25523	02	
07	0501110721	WHEEL HUB WITH SCREW / NUTS	01	
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION	01	
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR	06	
07C	0503016516	5/8 UNF CONIC NUT	06	
08	0502011339	15Z GEAR P 1.25"	01	
09	0503012550	5/16" X 3/4" BOLT	06	
10	0503010002	1800 GREASE FITTING	01	

WHEELED FASTENER


0521055234




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0521055236	INTERMEDIARY CURRENT STRETCHER	22	01
07	0521055237	WHEEL FIXED CURRENT STRETCHER	23	01
08	0521055235	WHEEL MOBILE CURRENT STRETCHER	24	01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
02	0551018245	CHAIN TENSIONER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0551018239	SLEEVE 19 X 13,50 X 45		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
02	0551018252	CHAIN TENSIONER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN		01
02	0551018244	CHAIN TENSIONER AXLE		01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	26	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8 SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02



Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8 SPRING WASHER		02
08	0591010589	BODY LOCK WHEEL		02
09	0521058394	WHEEL WITH TIRE	27	01




Item	Code	Description	See page	QT
01	0503063172	WHEEL	19	01
02	0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	28	01




Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01

CYLINDER ASSEMBLY


0521054561



Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	30	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521015501	COUPLING SHAFT		02
04	0503010523	1/4" X 2" SPLIT PIN		04
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
06	0531012565	SLEEVE 16,3X 30 X 88		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCKLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0571017027	VALVE SUPPORT		01
02	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0501054452	FLOW DIVIDING VALVE	32	01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER	33	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		02
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057089	HOSE KIT SYSTEM HYDRAULIC		01
19A	0501080045	3/8" X 850 TR-TR HOSE		01
19B	0501080999	3/8" X 39" TC-TC HOSE		01
19C	0501081987	HOSE 3/8 X 1550 TR-TC		01
19D	0501081986	HOSE 3/8 X 1550 TC-TC		01
19E	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
19EA	0501080185	HOSE 1/2 X 4000 TR-TM		01
19EB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
19EC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
19ED	0503018952	PLASTIC BOLT		06
19F	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
19FA	0501080185	HOSE 1/2 X 4000 TR-TM		01
19FB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01




Item	Code	Description	See page	QT
19FC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
19FD	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503010190	2-114 N 3006-9B O'RING		03
03	0501010617	3/4" NIPPLE		02
04	0501011460	7/8 NF REDUCTION NIPPLE		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01



Item	Code	Description	See page	QT
01	0571017027	VALVE SUPPORT		01
02	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0501054694	FLOW DIVIDING VALVE ASSY	36	01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER	33	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		01
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057106	ASSY HYDRAULIC SYSTEM HOSE 6850		01
19A	0501080373	TR-TR HOSE ASSY		01
19B	0501081989	HOSE 3/8 X 1400 TC-TC 90G		01
19C	0501081992	HOSE		01
19D	0501081991	HOSE 3/8 X 1950 TC-TC 180G		01
20	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
20A	0501080185	HOSE 1/2 X 4000 TR-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
20C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20D	0503018952	PLASTIC BOLT		06
21	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
21A	0501080185	HOSE 1/2 X 4000 TR-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01




Item	Code	Description	See page	QT
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06
22	0503013100	NYLON CLAMP		02



Item	Code	Description	See page	QT
01	0571017027	VALVE SUPPORT		01
02	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0501054694	FLOW DIVIDING VALVE ASSY	36	01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER	33	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		01
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057104	HOSE KIT SYSTEM HYDRAULIC		01
19A	0501080104	3/8 X 900 TR-TR HOSE		01
19B	0501080963	3/8 X 1050 TC-TC 90G LEFT OSE		01
19C	0501080714	3/8 X 1600 TR-TC HOSE		01
19D	0501081994	3/8 X 1600 TC-TC 180G HOSE		01
20	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
20A	0501080185	HOSE 1/2 X 4000 TR-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
20C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20D	0503018952	PLASTIC BOLT		06
21	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
21A	0501080185	HOSE 1/2 X 4000 TR-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01




Item	Code	Description	See page	QT
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06
22	0503013100	NYLON CLAMP		02



Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503030923	3/4" UNF X 13/16UN OFS X 40 NIPPLE		03
03	0503010190	2-114 N 3006-9B O'RING		03

DRAWBAR ASSY

0909095186



Item	Code	Description	See page	4880	5340	5950	6350	6850
01	0521068561	LONG COUPLING DRAWBAR		001	001	001	001	001
02	0511055096	TRACTOR HITCH	38	001	001	001	001	001
03	0511053179	TRACTOR COUPLING SHAFT		001	001	001	001	001
03A	0521064036	TRACTOR HITCH AXLE		001	001	001	001	001
03B	0503030012	HITCH PIN CLIP		001	001	001	001	001
04	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		001	001	001	001	001
04.	0501212237	HITCH SLEEVE ARTICULATED 85 X 35 MM		001	001	001	001	001
05	0503014120	CHAIN		001	001	001	001	001
06	0503014321	CABLE STEEL SHACKLE		002	002	002	002	002
07	0571010661	PIVOT SHAFT		001	001	001	001	001
08	0503010010	1/4" X 2.1/2" COTTERPIN		002	002	002	002	002
09	0521064203	EAR PIVOT DRAWBAR		001	001	001	001	001
10	0521053310	LEFT EXTENSION DRAWBAR 36.00 - 4880/5720/5950	-	001	000	001	000	000
10.	0531052545	LEFT EXTENSION DRAWBAR 36.00 - 4880/5950	39	001	000	000	000	000
10..	0521053313	LEFT EXTENSION DRAWBAR 36.00 - 5340		000	001	000	000	000
10...	0531052543	LEFT EXTENSION DRAWBAR 36.00 - 5340		000	001	000	000	000
10....	0521053320	LEFT EXTENSION DRAWBAR 36.00 - 6350		000	000	000	001	000
10.....	0531052540	DRAWBAR ASSY		000	000	000	001	000
10.....	0521053318	LEFT EXTENSION DRAWBAR 36.00 - 6850		000	000	000	000	001
11	0501010500	3/4" X 3" BOLT		002	002	002	002	002
12	0503010023	3/4" SPRING WASHER		002	002	002	002	002
13	0503010014	3/4" HEX NUT		002	002	002	002	002
14	0571019949	JUNCTION SHAFT		002	002	002	002	002
15	0503030119	LOCK PIN		002	002	002	002	002
16	0521053311	RIGHT EXTENSOR DRAWBAR 36,00 - 4880/5720/5950	- 40	001	000	001	000	000
16.	0521053312	RIGHT EXTENSOR DRAWBAR 36,00 - 5340		000	001	000	000	000
16..	0521053321	RIGHT EXTENSOR DRAWBAR 36,00 - 6350		000	000	000	001	000
16...	0521053319	RIGHT EXTENSOR DRAWBAR 36,00 - 6850		000	000	000	000	001
17	0521010572	0.9" X 2.9" COUPLING SHAFT		001	001	001	001	001
18	0503030085	LOCK PIN		004	004	004	004	004


DRAWBAR ASSY

0909095186


Item	Code	Description	See page	4880	5340	5950	6350	6850
19	0521063528	EXTENDING FIXER		001	001	001	001	001
20	0501010171	BOLT 1 UNC X 3.1/2 C S G.5		003	003	003	003	003
21	0503010012	1" SPRING WASHER		003	003	003	003	003
22	0501010059	1.5/8 NUT		003	003	003	003	003
23	0521062916	LEFT FRENCH HAND		001	001	001	001	001
24	0521010585	0.9" X 5.9" COUPLING SHAFT		001	001	001	001	001
25	0511052311	3 POINT TURNBUCKLE	41	001	001	001	001	001
26	0521012532	0.9" X 3.9" COUPLING SHAFT		001	001	001	001	001
27	0521010582	COUPLING SHAFT		001	001	001	001	001
28	0521063529	LOCK AXLE		001	001	001	001	001
29	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		001	001	001	001	001
30	0501212237	HITCH SLEEVE ARTICULATED 85 X 35 MM		000	000	000	001	000

TRACTOR HITCH


0511055096




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	LEFT COMPRESSION SPRING		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0531062838	LEFT POINT FIXER EXTENDING		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02
06	0531062839	ARTICULATED ARM BAR		01
07	0503010023	3/4" SPRING WASHER		04
08	0503010014	3/4" HEX NUT		04
09	0503035565	COMPRESSION SPRING		04
10	0503012951	3/4" X 10-1/2" BOLT		04
11	0501017065	FLAT WASHER		08



Item	Code	Description	See page	QT
01	0521064425	POINT FIXER EXTENDING RIGHT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0571012279	JACK RIGHT		01
03	0571012280	JACK LEFT		01
04	0531010264	SIDE RATCHET		02
05	0521018500	SHAFT LEVER EXTENSOR		01
06	0511061881	RATCHET FOLLOWER		01
07	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
08	0503011179	3/8" X 2-1/4" BOLT		05
09	0503010025	3/8 SPRING WASHER		05
10	0503010026	3/8" NUT		05
11	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01

4880 FERTILIZER HOPPER SET

0531056440




Item	Code	Description	See page	QT
01	0531056567	4880 LEFT HOPPER SUPPORT WITH FERTILIZER 48 METERING	01	01
02	0531056566	4880 RIGHT HOPPER SUPPORT WITH FERTILIZER 47 METERING	01	01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
04	0503010025	3/8 SPRING WASHER		12
05	0503010026	3/8" NUT		12
06	0503010849	3/8" X 1-1/2" BOLT		12
07	0571019051	FIXER HOPPER WASHER		20
08	0503013751	3/8 UNC X 1.1/4 BOLT		20
09	0503012535	3/8" SPRING WASHER		20
10	0503012531	3/8" INOX NUT		20
11	0503011957	NYLON HANDLE		02
12	0503010371	5/16" X 1" BOLT		04
13	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
14	0503010337	5/16" NUT		08
15	0501010694	FLAT WASHER		04
16	0503011953	5/16" X 1" BOLT		04
17	0551019168	SLEEVE		02
18	0551019167	SLEEVE UNION		02
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
20	0503010479	BOLT		02
21	0503011336	1/2" HEX SELF ADJUSTING NUT		06
22	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
23	0503010019	1/2" SPRING WASHER		02
24	0503010060	1/2 UNC G.5 ZN HEX NUT		02
25	0501013518	FLAT WASHER		06
26	0503010140	1/8" X 3/4" COTTERPIN		06
27	0511069678	LH LOWER LEVER		02
28	0561016468	FASTENER		02
29	0521061741	INNTER LEVER		02
30	0551019159	LEVER FIXER BODY		02



4880 FERTILIZER HOPPER SET

0531056440


Item	Code	Description	See page	QT
31	0503062589	FERTILIZER HOPPER MOUNTED		02
32	0581018923	LOWER LEVER LEVER CHANGE		02
33	0503011312	ROTATIVE CABLE		02
34	0521068994	SMALL LEVER		02




Item	Code	Description	See page	QT
01	0531056687	5340 LEFT HOPPER SUPPORT WITH FERTILIZER 45 METERING	01	01
02	0531056686	5340 RIGHT HOPPER SUPPORT WITH FERTILIZER 46 METERING	46	01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
04	0503010025	3/8 SPRING WASHER		12
05	0503010026	3/8" NUT		12
06	0503010849	3/8" X 1-1/2" BOLT		12
07	0571019051	FIXER HOPPER WASHER		20
08	0503013751	3/8 UNC X 1.1/4 BOLT		20
09	0503012535	3/8" SPRING WASHER		20
10	0503012531	3/8" INOX NUT		20
11	0503011957	NYLON HANDLE		02
12	0503010371	5/16" X 1" BOLT		04
13	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
14	0503010337	5/16" NUT		08
15	0501010694	FLAT WASHER		04
16	0503011953	5/16" X 1" BOLT		04
17	0551019168	SLEEVE		02
18	0551019167	SLEEVE UNION		02
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
20	0503010479	BOLT		02
21	0503011336	1/2" HEX SELF ADJUSTING NUT		06
22	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
23	0503010019	1/2" SPRING WASHER		02
24	0503010060	1/2 UNC G.5 ZN HEX NUT		02
25	0501013518	FLAT WASHER		06
26	0503010140	1/8" X 3/4" COTTERPIN		06
27	0511069678	LH LOWER LEVER		02
28	0561016468	FASTENER		02
29	0521061741	INNTER LEVER		02
30	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
31	0503062589	FERTILIZER HOPPER MOUNTED		02
32	0581012605	GEAR BOX LEVER LOCK		02
33	0501215701	ARM/DISARM LEVER		02




Item	Code	Description	See page	QT
01	0531064772	ALPHA FERTILIZER SILO LEFT SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	49	06
03	0501053788	3/4 SQUARE AXLE FASTENER	54	02
04	0503030303	SUPPORT WASHER		02
05	0501218487	3/4 X 390 AXLE		05
06	0531057908	SLEEVE 1/4 X 2		05
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	55	01
08	0501310862	3/4 X 503 SQUARE AXLE		01




Item	Code	Description	See page	QT
01	0531064771	RIGHT SUPPORT ALPHA FERTILIZER SILO		01
02	0531055319	ALPHA II FERTILIZER METERING	49	06
03	0501053788	3/4 SQUARE AXLE FASTENER	54	02
04	0503030303	SUPPORT WASHER		02
05	0501218487	3/4 X 390 AXLE		05
06	0531057908	SLEEVE 1/4 X 2		05
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	55	01
08	0501310862	3/4 X 503 SQUARE AXLE		01




Item	Code	Description	See page	QT
01	0531064692	4880 RIGHT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	49	06
03	0501053788	3/4 SQUARE AXLE FASTENER	54	02
04	0503030303	SUPPORT WASHER		02
05	0501310798	3/4 X 378 AXLE		01
06	0501218487	3/4 X 390 AXLE		05
07	0531057908	SLEEVE 1/4 X 2		05
07A	0502013069	SLEEVE 21 X 38 X 50		01
07B	0503010010	1/4" X 2.1/2" COTTERPIN		01
08	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	55	01




Item	Code	Description	See page	QT
01	0531064693	4880 LEFT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	49	02
03	0501053788	3/4 SQUARE AXLE FASTENER	54	02
04	0503030303	SUPPORT WASHER		02
05	0501310798	3/4 X 378 AXLE		01
06	0501218487	3/4 X 390 AXLE		05
07	0531057908	SLEEVE 1/4 X 2		05
07A	0502013069	SLEEVE 21 X 38 X 50		01
07B	0503010010	1/4" X 2.1/2" COTTERPIN		01
08	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	55	01




Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	ASSY TRANSMISSION HUB	50	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	51	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513011170	ALLEN SCREW 1/4 UNC X 7/8 CCSI STAINLESS STEEL		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501310211	FRONT COVER ADB ALPHA II DISPENSER		01
19	0503036177	ADB ALPHA DISPENSER COVER STRING		01
20	0531059139	ASSY COLLECTOR	52	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO ADHESIVE LABEL 41.5 X 29		01
15	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT GUIDE DOSING COVER		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT GLOVE FIXING SAFETY LOCK DISPENSER		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT GLOVE FIXING SAFETY LOCK DISPENSER		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	53	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01



Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007		02
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0503010337	5/16" NUT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0531057901	GEAR	56	01
07	0503010845	501035 CLAMPING RING (FOR AXLE)		01
08	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531065402	GEAR		01
02	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0531056569	5950 LEFT HOPPER SUPPORT WITH FERTILIZER METERING	58	01
02	0531056568	5950 RIGHT HOPPER SUPPORT WITH FERTILIZER METERING	59	01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
04	0503010025	3/8 SPRING WASHER		12
05	0503010026	3/8" NUT		12
06	0503010849	3/8" X 1-1/2" BOLT		12
07	0571019051	FIXER HOPPER WASHER		20
08	0503013751	3/8 UNC X 1.1/4 BOLT		20
09	0503012535	3/8" SPRING WASHER		20
10	0503012531	3/8" INOX NUT		20
11	0503011957	NYLON HANDLE		02
12	0503010371	5/16" X 1" BOLT		04
13	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
14	0503010337	5/16" NUT		08
15	0501010694	FLAT WASHER		04
16	0503011953	5/16" X 1" BOLT		04
17	0551019168	SLEEVE		02
18	0551019167	SLEEVE UNION		02
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
20	0503010479	BOLT		02
21	0503011336	1/2" HEX SELF ADJUSTING NUT		06
22	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
23	0503010019	1/2" SPRING WASHER		02
24	0503010060	1/2 UNC G.5 ZN HEX NUT		02
25	0501013518	FLAT WASHER		06
26	0503010140	1/8" X 3/4" COTTERPIN		06
27	0511069678	LH LOWER LEVER		02
28	0561016468	FASTENER		02
29	0521061741	INNTER LEVER		02
30	0551019159	LEVER FIXER BODY		02



Item	Code	Description	See page	QT
31	0581012605	GEAR BOX LEVER LOCK		02
32	0503062362	FERTILIZER HOPPER		02
33	0503062927	FERTILIZER HOPPER		02
34	0501215701	ARM/DISARM LEVER		02




Item	Code	Description	See page	QT
01	0531064695	LEFT HOPPER SUPPORT		01
02	0501053788	3/4 SQUARE AXLE FASTENER	54	11
03	0531055319	ALPHA II FERTILIZER METERING	49	07
04	0503031527	AGRICULTURAL BEARING		11
05	0531057908	SLEEVE 1/4 X 2		06
05A	0502013069	SLEEVE 21 X 38 X 50		01
05B	0503010010	1/4" X 2.1/2" COTTERPIN		01
06	0501218487	3/4 X 390 AXLE		04
07	0501218684	3/4 X 330 AXLE		01
08	0501218666	AXLE 3/4 X 155		01
09	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	55	01
10	0501311444	3/4 X 790 AXLE		01



Item	Code	Description	See page	QT
01	0501053788	3/4 SQUARE AXLE FASTENER	54	11
02	0531064694	RIGHT HOPPER SUPPORT		01
03	0531055319	ALPHA II FERTILIZER METERING	49	07
04	0503031527	AGRICULTURAL BEARING		11
05	0531057908	SLEEVE 1/4 X 2		06
05A	0502013069	SLEEVE 21 X 38 X 50		01
05B	0503010010	1/4" X 2.1/2" COTTERPIN		01
06	0501218666	AXLE 3/4 X 155		01
07	0501218684	3/4 X 330 AXLE		01
08	0501218487	3/4 X 390 AXLE		04
09	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	55	01
10	0501311444	3/4 X 790 AXLE		01

6850 ALPHA FERTILIZER HOPPER SET

0531056444




Item	Code	Description	See page	QT
01	0531056428	6850 LEFT HOPPER SUPPORT WITH FERTILIZER METERING	61	01
02	0531056427	6850 RIGHT HOPPER SUPPORT WITH FERTILIZER METERING	62	01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
04	0503010025	3/8 SPRING WASHER		12
05	0503010026	3/8" NUT		12
06	0503010849	3/8" X 1-1/2" BOLT		12
07	0571019051	FIXER HOPPER WASHER		24
08	0503013751	3/8 UNC X 1.1/4 BOLT		24
09	0503012535	3/8" SPRING WASHER		24
10	0503012531	3/8" INOX NUT		24
11	0503011957	NYLON HANDLE		02
12	0503010371	5/16" X 1" BOLT		04
13	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
14	0503010337	5/16" NUT		08
15	0501010694	FLAT WASHER		04
16	0503011953	5/16" X 1" BOLT		04
17	0551019168	SLEEVE		02
18	0551019167	SLEEVE UNION		02
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
20	0503010479	BOLT		02
21	0503011336	1/2" HEX SELF ADJUSTING NUT		06
22	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
23	0503010019	1/2" SPRING WASHER		02
24	0503010060	1/2 UNC G.5 ZN HEX NUT		02
25	0501013518	FLAT WASHER		06
26	0503010140	1/8" X 3/4" COTTERPIN		06
27	0511069678	LH LOWER LEVER		02
28	0561016468	FASTENER		02
29	0521061741	INNTER LEVER		02
30	0551019159	LEVER FIXER BODY		02




6850 ALPHA FERTILIZER HOPPER SET


0531056444

Item	Code	Description	See page	QT
31	0581012605	GEAR BOX LEVER LOCK		02
32	0503062362	FERTILIZER HOPPER		04
33	0501215701	ARM/DISARM LEVER		02




Item	Code	Description	See page	QT
01	0531064657	6850 LEFT FERTILIZER HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	49	08
03	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	55	01
04	0501218825	3/4 X 135 SQUARE AXLE WITH HOLE		02
05	0531057978	SIDE BEARING WITH TRANSMISSION	63	01
06	0501218487	3/4 X 390 AXLE		07
07	0501311325	3/4 X 270 AXLE		01
08	0531057908	SLEEVE 1/4 X 2		09
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010010	1/4" X 2.1/2" COTTERPIN		01






Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007		01
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0501218530	SIDE BEARING SHAFT BODY		01
03	0503030119	LOCK PIN		01
04	0503010845	501035 CLAMPING RING (FOR AXLE)		01
05	0503010337	5/16" NUT		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0501010694	FLAT WASHER		02
08	0503010371	5/16" X 1" BOLT		02




Item	Code	Description	See page	4880	5340	5720	5950	6350	6850
00a	0511056751	RIGHT TRANSMISSION ASSY - 4880		001	000	000	000	000	000
00b	0511056752	LEFT TRANSMISSION ASSY - 4880		001	000	000	000	000	000
00c	0511056541	RIGHT TRANSMISSION ASSEMBLY 5340		000	001	000	000	000	000
00d	0511056542	LEFT TRANSMISSION ASSEMBLY 5340		000	001	000	000	000	000
00e	0521054992	RIGHT TRANSMISSION ASSEMBLY 5720		000	000	001	000	000	000
00f	0521054993	LEFT TRANSMISSION ASSEMBLY 5720		000	000	001	000	000	000
00g	0511056818	RIGHT TRANSMISSION ASSY 5950		000	000	000	001	000	000
00h	0511056819	LEFT TRANSMISSION ASSY 5950		000	000	000	001	000	000
00i	0511056824	RIGHT TRANSMISSION ASSEMBLY 6350		000	000	000	000	001	000
00j	0511056825	LEFT TRANSMISSION ASSEMBLY 6350		000	000	000	000	001	000
00k	0511056830	RIGHT TRANSMISSION ASSEMBLY 6850		000	000	000	000	000	001
00l	0511056831	LEFT TRANSMISSION ASSEMBLY 6850		000	000	000	000	000	001
01	0501110639	BEARING	65	008	008	008	008	008	008
02	0503011099	GREASE FITTING		008	008	008	008	008	008
03	0503010300	5/32" X 1" COTTERPIN		008	008	008	008	008	008
04	0551019114	MOTOR BEARING AXLE SUPPORT		004	004	004	004	004	004
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		004	004	004	004	004	004
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		008	008	008	008	008	008
07	0503010019	1/2" SPRING WASHER		008	008	008	008	008	008
08	0503010060	1/2 UNC G.5 ZN HEX NUT		008	008	008	008	008	008
09	0561016876	MOTOR SHAFT		002	000	000	000	000	000
09.	0571017428	MOTOR SHAFT		000	002	000	000	000	000
09..	0581019450	MOTOR AXIS 2745 - 5720		000	000	002	000	000	000
09...	0571011442	MOTOR SHAFT		000	000	000	002	000	000
09....	0571013750	MOTOR AXLE 3060		000	000	000	000	002	000
09.....	0571017032	MOTOR SHAFT		000	000	000	000	000	002
10	0501018466	FLAT WASHER		004	004	004	004	004	004
11	0511015961	LOCK BUSHING		004	004	004	004	004	004
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		004	004	004	004	004	004
13	0503010060	1/2 UNC G.5 ZN HEX NUT		004	004	004	004	004	004
14	0501052560	MOTOR AXLE SIGNAL	66	002	002	002	002	002	002


Item	Code	Description	See page	4880	5340	5720	5950	6350	6850
15	0511051434	TRANSMISSION ACTUATOR	67	004	004	004	004	004	004
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	68	001	001	001	001	001	001
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	69	001	001	001	001	001	001
18	0521043316	RIGHT GEAR BOX ASSY	70	001	001	001	001	001	001
19	0521043317	LEFT GEAR BOX ASSY	71	001	001	001	001	001	001
20	0503014734	BOLT		006	006	006	006	006	006
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		004	004	004	004	004	004
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		008	008	008	008	008	008
23	0503010019	1/2" SPRING WASHER		010	010	010	010	010	010
24	0503010060	1/2 UNC G.5 ZN HEX NUT		010	010	010	010	010	010
25	0521064448	GEAR		002	002	002	002	002	002
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	81	002	002	002	002	002	002
27	0521055217	LOWER CURRENT STRETCH	82	002	002	002	002	002	002
28	0501058254	UPPER SEED CHAIN TENSIONER	83	002	002	002	002	002	002
29	0521055216	BEARING WITH GEAR	84	002	002	002	002	002	002
30	0521055218	BEARING GEAR WITH DOUBLE	85	002	002	002	002	002	002
31	0521055214	BEARING GEAR WITH	86	002	002	002	002	002	002
32	0503012204	40-1 CHAIN X 82 LINK + RED		002	002	002	002	002	002
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		002	002	002	002	002	002
34	0503012718	40-1 CHAIN X 111 LINK + MENDING		002	002	002	002	002	002
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		002	002	002	002	002	002
36	0503010256	3/8" X 3/4" BOLT		002	002	002	002	002	002
37	0503010025	3/8 SPRING WASHER		002	002	002	002	002	002
38	0501010984	10,50 X 27 X 3,00 FLAT WASHER		002	002	002	002	002	002
39	0501010637	FLAT WASHER		004	004	004	004	004	004
40	0503030275	AGRICULTURAL BEARING		002	002	002	002	002	002
41	0511054363	CHAIN TENSIONER	88	002	002	002	002	002	002




Item	Code	Description	See page	QT
01	0502012615	AGRICULTURAL BEARING BODY		01
02	0561014848	BEARING INTERNAL SLEEVE		01



Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

LEFT SIDE TRANSMISSION ACTUATOR


0511047070



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	72	01
02	0511059266	CLOSED BEARING	74	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	76	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	78	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	79	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	80	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	73	01
02	0511059266	CLOSED BEARING	74	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	76	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	78	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	79	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	80	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX	01	
02	0502011758	REAR TIGHTENER LEVER	02	
03	0503010292	701164 6 X 40 SPRING PIN	02	
04	0511061794	CHAIN TENSIONER	01	
05	0503031367	SPRING	01	
06	0511060392	CHAIN TENSIONER	01	
07	0503031366	RIGHT TWISTED SPRING	01	




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	75	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	77	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0521018933	FERT CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501011234	5/8" X 3" BOLT		01
02	0531017086	50 AXLETIGHTENER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0503019356	BEARING 6005 2RS1		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0503016460	5/8" X 4.1/2" BOLT		01
02	0551019175	DOUBLE GEAR AXLE		01
03	0503019356	BEARING 6005 2RS1		02
04	0511069680	20Z X 28Z DOBLE GEAR		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511063106	20Z AXLE BEARING DOUBLE		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521055215	DOUBLE TRANSMISSION BEARING	87	01
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503019356	BEARING 6005 2RS1		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521069416	RIGHT PLATFORM		01
02	0521069421	LEFT PLATFORM		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
06	0503010025	3/8 SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	HITCH PIN CLIP		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521069417	RIGHT PLATFORM 5340		01
02	0521069422	LEFT PLATFORM 5340		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
06	0503010025	3/8 SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	HITCH PIN CLIP		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521069418	RIGHT PLATFORM 5950		01
02	0521069423	LEFT PLATFORM 5950		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
06	0503010025	3/8 SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	HITCH PIN CLIP		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521069420	RIGHT PLATFORM 6850		01
02	0521069425	LEFT PLATFORM 6850		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
06	0503010025	3/8 SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	HITCH PIN CLIP		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521062988	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8 SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0521065384	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8 SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0521063175	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8 SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0521065192	HANDRAIL 6850		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8 SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8 SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
08	0503013357	3/8 SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0511059584	2 HOPPERS WITH 10 CONDUCTORS SET	100	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RIGHT SUPPORT TOWER WITH BOLT	102	01
07	0521051931	LEFT SUPPORT TOWER WITH BOLT	103	01
08	0521051927	TOWER SUPPORT HOPPER	104	02




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		52
04	0503010026	3/8" NUT		52
05	0511057690	3" ARTICULATED SEED CONDUCTOR	101	10
06	0571015773	SUPPORT SEED		02
07	0501011643	3/8 X 1"BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		40
09	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		02




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID	01	
02	0501010942	3/8" X 1-1/4" BOLT	01	
03	0503010025	3/8 SPRING WASHER	01	
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER	01	
05	0503010209	3/8" UNC BUTTERFLY NUT	01	
06	0521066332	CONDUCTOR WITH FLANGE	01	
07	0503010371	5/16" X 1" BOLT	02	
08	0501010694	FLAT WASHER	02	
09	0503010179	LOCK WASHER 5/16 ZN 1K01528	02	
10	0503010337	5/16" NUT	02	
11	0502012767	SEED NOZZLE FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0521066206	RIGHT HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066207	LEFT HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066208	HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0531057986	ASSEMBLY CSU C3 SEMI MOUNTED	107	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RIGHT SUPPORT TOWER WITH BOLT	102	01
07	0521051931	LEFT SUPPORT TOWER WITH BOLT	103	01
08	0531051994	RIGHT TOWER SUPPORT HOPPER SUPPORT WITH SCREW	111	01
09	0531051996	LEFT TOWER SUPPORT HOPPER SUPPORT WITH SCREW	112	01




Item	Code	Description	See page	QT
01	0531057984	SET CSU SM WITH 3 X 175 2 BOXES 7 MOUTH	108	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RIGHT SUPPORT TOWER WITH BOLT	102	01
07	0521051931	LEFT SUPPORT TOWER WITH BOLT	103	01
08	0531051994	RIGHT TOWER SUPPORT HOPPER SUPPORT WITH SCREW	111	01
09	0531051996	LEFT TOWER SUPPORT HOPPER SUPPORT WITH SCREW	112	01




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0531057950	3" X 175 SEED NOZZLE WITH FIXING	115	11
06	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		02
07	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		02
08	0531054471	CAP WITH FIXING	116	01




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0531057950	3" X 175 SEED NOZZLE WITH FIXING	115	11
06	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
07	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02
08	0531054471	CAP WITH FIXING	116	03




Item	Code	Description	See page	QT
01	0531057980	5950 SINGLE SEED HOPPER FOR 13 NOZZLES	110	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RIGHT SUPPORT TOWER WITH BOLT	102	01
07	0521051931	LEFT SUPPORT TOWER WITH BOLT	103	01
08	0531051994	RIGHT TOWER SUPPORT HOPPER SUPPORT WITH SCREW	111	01
09	0531051996	LEFT TOWER SUPPORT HOPPER SUPPORT WITH SCREW	112	01




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0531057950	3" X 175 SEED NOZZLE WITH FIXING	115	13
06	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02
07	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
08	0531054471	CAP WITH FIXING	116	01




Item	Code	Description	See page	QT
01	0531062614	RIGHT HOPPER SUPPORT TOWER		01
02	0503011084	3/4" X 5" BOLT		02
03	0502010175	HITCH CLAMP		01
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0531062615	LEFT HOPPER SUPPORT TOWER		01
02	0503011084	3/4" X 5" BOLT		02
03	0502010175	HITCH CLAMP		01
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0531057974	6850 SINGLE SEED HOPPER FOR 15 NOZZLES	114	01
02	0501010942	3/8" X 1-1/4" BOLT		16
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		16
05	0503010026	3/8" NUT		16
06	0531052006	LEFT SUPPORT TOWER WITH BOLT	117	01
07	0521051929	SIDE FIXED TOWER LEFT HOPPER SUPPORT WITH SCREW	118	01
08	0521051928	FIXED TOWER SIDE RIGHT HOPPER SUPPORT WITH SCREW	119	01
09	0521052687	RIGHT SUPPORT TOWER WITH BOLT	102	01
10	0521051931	LEFT SUPPORT TOWER WITH BOLT	103	01
11	0531052007	RIGHT SUPPORT TOWER RIGHT SUPPORT	120	01




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		08
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
03	0503010025	3/8 SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0531057950	3" X 175 SEED NOZZLE WITH FIXING	115	15
06	0503061987	05 NOZZLES FERTILIZER HOPPER		04
07	0521064748	05 NOZZLES SINGLE SEED HOPPER SUPPORT		04
08	0531054471	CAP WITH FIXING	116	05




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID	01	
02	0501010942	3/8" X 1-1/4" BOLT	05	
03	0503010025	3/8 SPRING WASHER	05	
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER	01	
05	0503010209	3/8" UNC BUTTERFLY NUT	01	
06	0521066332	CONDUCTOR WITH FLANGE	01	
07	0503010371	5/16" X 1" BOLT	02	
08	0501010694	FLAT WASHER	02	
09	0503010179	LOCK WASHER 5/16 ZN 1K01528	02	
10	0503010337	5/16" NUT	02	
11	0502012767	SEED NOZZLE FIXER SUPPORT	01	
12	0503010026	3/8" NUT	04	




Item	Code	Description	See page	QT
01	0571015773	SUPPORT SEED		01
02	0501011643	3/8 X 1"BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0531062623	LEFT SUPPORT TOWER HOPPER SUPPORT		01
02	0503011084	3/4" X 5" BOLT		02
03	0502010175	HITCH CLAMP		01
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066205	HOPPER SUPPORT LEFT SIDE FIXER TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066204	HOPPER SUPPORT RIGHT SIDE FIXER TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0531062624	RIGHT HOPPER SUPPORT TOWER		01
02	0503011084	3/4" X 5" BOLT		02
03	0502010175	HITCH CLAMP		01
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		15mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		02
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	124	02
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		14




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		17mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		02
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	124	02
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		14




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		22mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		04
04	0503012903	T-80M CRAMP NYLON		70
05	0521052792	MOUNTED REAR LIGHT	124	04
06	3505151602	TUBE		0,6mt
07	0503017702	FIXER		20




Item	Code	Description	See page	QT
01	0503018738	HEADLIGHT		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
08	0503010337	5/16" NUT		04



Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01
07	0511033413	PACKAGING WITH MANUAL / CATALOG		01




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0521069295	SUPPORT TOOL CHEST		01
06	0581017000	PLATE INTERMEDIARY		02
07	0503034772	BOX		01
08	0501011643	3/8 X 1"BOLT		04
09	0503010025	3/8 SPRING WASHER		04
10	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0521069405	WATER TANK SUPPORT		01
06	0503014820	BLACK WATER RESERVOIR		01

ASSY HEX AXLE


0909095190




Item	Code	Description	See page	4880	5340	5950	6350	6850
01	0531016944	RIGHT 5/8" X 96" HEX AXLE		001	000	000	000	000
01.	0561019199	5/8" X 2275 AXLE HEX		001	000	000	000	000
02	0571017427	5/8 X 2700 HEX AXLE		000	001	000	000	000
02.	0571017425	5/8 X 2530 HEX AXLE		000	001	000	000	000
03	0561018502	SHAFT AXIS 5/8 X 3000		000	000	001	001	000
03.	0571011980	5/8 X 2810 HEX AXLE		000	000	001	000	000
04	0531016949	LEFT 5/8" X 125" AXLE HEX		000	000	000	001	000
04.	0561018502	SHAFT AXIS 5/8 X 3000		000	000	000	001	000
05	0571017030	SHAFT AXLE 5 / 8X3450 14E500		000	000	000	000	001
05.	0571017029	5/8 X 3280 HEX AXLE		000	000	000	000	001
05..	0571017030	SHAFT AXLE 5 / 8X3450 14E500		000	000	000	000	001
05...	0571017029	5/8 X 3280 HEX AXLE		000	000	000	000	001
06	0561014215	BEARING COVER LOWER ROW FRAME		002	002	002	002	002
07	0521055214	BEARING GEAR WITH	86	002	002	002	002	002
08	0502040534	SPRING GUIDE BUSHING LOCK		004	004	004	004	004
09	0501018535	1/2 X 1 BOLT		004	004	004	004	004




Item	Code	Description	See page	QT
01	0531058988	WORM THREAD P.16 WITH FERTILIZER DOSING SHAFT COATING		10
01A	0531065012	WORM THREAD P.16MM ALPHA FERTILIZER DOSER		10
01B	0503035859	SUPPORT SLEEVE		10
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		10
02A	0501111196	PALLETIZED FERTILIZER COATING COMPLETE PLANTING FERTILIZER DOSER ALP II		10
02B	0531058987	WORM SCREW P.50 WITH ADB ALPHA DISPENSER SHAFT COATING		10
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	WORM THREAD P.16 WITH FERTILIZER DOSING SHAFT COATING		11
01A	0531065012	WORM THREAD P.16MM ALPHA FERTILIZER DOSER		11
01B	0503035859	SUPPORT SLEEVE		11
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		11
02A	0501111196	PALLETIZED FERTILIZER COATING COMPLETE PLANTING FERTILIZER DOSER ALP II		11
02B	0531058987	WORM SCREW P.50 WITH ADB ALPHA DISPENSER SHAFT COATING		11
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01



Item	Code	Description	See page	QT
01	0531058988	WORM THREAD P.16 WITH FERTILIZER DOSING SHAFT COATING		13
01A	0531065012	WORM THREAD P.16MM ALPHA FERTILIZER DOSER		13
01B	0503035859	SUPPORT SLEEVE		13
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		13
02A	0501111196	PALLETIZED FERTILIZER COATING COMPLETE PLANTING FERTILIZER DOSER ALP II		13
02B	0531058987	WORM SCREW P.50 WITH ADB ALPHA DISPENSER SHAFT COATING		13
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	WORM THREAD P.16 WITH FERTILIZER DOSING SHAFT COATING		15
01A	0531065012	WORM THREAD P.16MM ALPHA FERTILIZER DOSER		15
01B	0503035859	SUPPORT SLEEVE		15
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		15
02A	0501111196	PALLETIZED FERTILIZER COATING COMPLETE PLANTING FERTILIZER DOSER ALP II		15
02B	0531058987	WORM SCREW P.50 WITH ADB ALPHA DISPENSER SHAFT COATING		15
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0501014177	5/8" X 2-1/2" BOLT		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0531061696	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	136	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	137	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0511057090	HYDRAULIC MARKER HAND SET		01
24A	0501081728	HOSE 3/8 X 3100 TR-TR		01
24B	0501080392	3/8 X 3300 TR-TC HOSE		01
24C	0501081988	3/8" X 145.6" TR-TC HOSE		01
24D	0501081682	TC-TC HOSE ASSY		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	33	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04
38	0551018948	BODY MARKER SUPPORT ROW		02




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	136	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	137	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0511057101	HYDRAULIC MARKER HANDLE SET		01
24A	0501081330	HOSE		01
24B	0501081718	HOSE		01
24C	0501081799	HOSE		01
24D	0501081995	HOSE		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	33	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	136	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	137	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0511057091	HYDRAULIC MARKER HANDLE SET		01
24A	0501081793	HOSE		01
24B	0501081967	3/8" X 151" TR-TC HOSE		01
24C	0501081996	HOSE		01
24D	0501081997	HOSE		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01


Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	33	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01



Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02



Item	Code	Description	See page	QT
01	0521069643	DISC AXLE MARKER ROW		01
02	0602023094	DR16X3 C36AFPAFR73+4FR+4FR D474 10R		01
03	0581019513	DEPTH WHEEL HUB		01
04	0503019342	ROLLER BEARING		01
05	0581019168	DUST CLOAK		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503013758	1/4" X 1-1/2" BOLT		03
11	0503010143	1/4" SPRING WASHER		03
12	0503010358	5/16" X 5/8" BOLT		04
13	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
14	0503010337	5/16" NUT		04
15	0503034055	CLAMPING RING		01




Item	Code	Description	See page	14	15	16	17	18	19	20	21	22	24	L
01	0511059216	DOUBLE ARTICULATED HYDRAULIC MARKER	140	01	00	00	00	00	00	00	00	00	00	00
02	0511057512	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE		00	01	01	00	00	00	00	00	00	00	00
03	0521052886	8160 DOUBLE ARTICULATED HYDRAULIC MARKER		00	01	00	00	00	00	00	00	00	00	00
04	0521052852	DOUBLE ARTICULATED HYDRAULIC MARKER		00	00	01	00	00	00	00	00	00	00	00
05	0511057889	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE 8460		00	00	00	01	01	00	00	00	00	00	00
06	0511057879	17/45 DOUBLE ARTICULATED HYDRAULIC MARKER		00	00	00	01	00	00	00	00	00	00	00
07	0511056250	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE 8960		00	00	00	00	01	01	00	00	00	00	00
08	0511056158	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE 9460		00	00	00	00	00	01	01	00	00	00	00
09	0521052002	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE 9960		00	00	00	00	00	00	01	01	00	00	00
10	0511055786	ASSY MARKER HYDRAULIC ARTICULATED DOUBLE 10460		00	00	00	00	00	00	00	01	01	00	00
11	0521051379	DOUBLE ARTICULATED HYDRAULIC MARKER		00	00	00	00	00	00	00	00	01	01	00
12	0501054649	HBM SEQUENTIAL VALVE	137	01	01	01	01	01	01	01	01	01	01	01
13	0511058431	HYDRAULIC CYLINDER	141	01	01	01	01	01	01	00	00	00	00	00
14	0521011141	1.1/4" X 6.5" AXLE		02	02	02	02	02	02	02	02	02	02	02
15	0511058553	HYDRAULIC CYLINDER		00	00	00	00	00	00	02	02	02	02	02
16	0511015573	2.07" X 1.6" TRANSPORT LOCK		02	02	02	02	02	02	02	02	02	02	02
17	0501068994	8,30 X 78 LOCK PIN		02	02	02	02	02	02	02	02	02	02	02
18	0503030168	HITCH PIN CLIP		02	02	02	02	02	02	02	02	02	02	02
19	0511057093	HYDRAULIC MARKER HYGIENE SET		01	00	00	00	00	00	00	00	00	00	00
20	0511057094	HYDRAULIC HOSE MARKER ASSY 6450		00	01	01	00	00	00	00	00	00	00	00
21	0521052885	15/55 DOUBLE ARTICULATED HYDRAULIC MARKER		00	01	00	00	00	00	00	00	00	00	00
22	0521052851	HYDRAULIC MARKER HAND ASSY		00	00	01	00	00	00	00	00	00	00	00
23	0511057890	17 E 500 HYDRAULIC MARKER HOSE ASSEMBLY		00	00	00	01	01	00	00	00	00	00	00
24	0511057880	HYDRAULIC MARKER HAND ASSY		00	00	00	01	00	00	00	00	00	00	00
25	0511057739	HYDRAULIC MARKER HAND SET		00	00	00	00	01	01	00	00	00	00	00

Item	Code	Description	See page	14	15	16	17	18	19	20	21	22	24	L
26	0521050879	HYDRAULIC MARKER HOSE ASSY		00	00	00	00	00	00	01	01	00	00	
27	0511057526	HYDRAULIC MARKER HAND SET		00	00	00	00	00	00	00	01	01	00	
28	0521051377	15 / 450 DOUBLE ARTICULATED HYDRAULIC MARKER		00	00	00	00	00	00	00	00	01	01	
29	0501080388	3/8 X 4300 TR-TC HOSE ASSY		02	00	00	00	00	00	00	00	00	00	
30	0501081804	HOSE ASSY		00	02	02	00	00	00	00	00	00	00	
31	0501081953	3/8 X 4940 TR-TC HOSE		00	02	00	00	00	00	00	00	00	00	
32	0501081465	HOSE 3/8 X 4890 TR-TC		00	00	02	00	00	00	00	00	00	00	
33	0501081748	HOSE		00	00	00	02	02	00	00	00	00	00	
34	0501082037	HOSE 3/8 X 5150 TR-TC		00	00	00	02	00	00	00	00	00	00	
35	0501081981	HOSES		00	00	00	00	02	02	00	00	00	00	
36	0501080744	3/8" X 248" TR-TC HOSE ASSY		00	00	00	00	00	00	02	02	00	00	
37	0501082034	HOSE		00	00	00	00	00	00	00	02	02	00	
38	0501082135	3/8 X 7900 TR-TC HOSE		00	00	00	00	00	00	00	00	02	02	
39	0501081791	HOSE ASSY		02	00	00	00	00	00	00	00	00	00	
40	0501081093	3/8" X 188.9" TR-TC HOSE ASSY		00	02	02	00	00	00	00	00	00	00	
41	0501082037	HOSE 3/8 X 5150 TR-TC		00	02	00	00	00	00	00	00	00	00	
42	0501081225	HOSE 3/8 X 5000 TR-TC		00	00	02	00	00	00	00	00	00	00	
43	0501081981	HOSES		00	00	00	02	02	00	00	00	00	00	
44	0501082038	HOSE 3/8 X 5350 TR-TC		00	00	00	00	00	02	02	00	00	00	
45	0501081982	HOSE		00	00	00	00	00	00	00	02	02	00	
46	0501081447	3/8 X 6600 TC-TR HOSE		00	00	00	00	00	00	00	02	00	00	
47	0501082035	HOSE		00	00	00	00	00	00	00	00	02	00	
48	0501082136	3/8 X 8100 TR-TC HOSE		00	00	00	00	00	00	00	00	00	02	
49	0521052277	HOSE 3/8 X 4212 TC-TM PURPLE / RED		01	01	01	00	00	00	00	00	00	00	
50	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		00	00	00	00	01	00	00	00	00	00	
51	0521052510	3/8 X 5000 TC-TM ROXO/VERM HOSE		00	00	00	00	00	01	00	00	00	00	
52	0521052508	HOSE 3/8 X 4650 TC-TM PURPLE / RED		00	00	00	00	00	00	01	00	00	00	
53	0521052512	HOSE 3/8 X 5200 TC-TM PURPLE / RED		00	00	00	00	00	00	01	01	01	01	
54	0521052278	HOSE 3/8 X 4212 TC-TM PURPLE / BLUE		01	01	01	00	00	00	00	00	00	00	
55	0521052850	3/8 X 4200 TC-TM PURPLE/BLUE HOSE		00	00	00	01	01	00	00	00	00	00	
56	0521052511	3/8 X 5000 TC-TM ROXO/AZUL HOSE		00	00	00	00	01	00	00	00	00	00	
57	0521052509	HOSE 3/8 X 4650 TC-TM PURPLE / BLUE		00	00	00	00	00	01	00	00	00	00	
58	0521052513	HOSE 3/8 X 5200 TC-TM PURPLE / BLUE		00	00	00	00	00	00	01	01	01	01	
59	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01	01	01	01	01	01	01	01	01	01	
60	0503034495	HYDRAULIC HOSE GRIP (RED)		01	01	01	01	01	01	01	01	01	01	
61	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01	01	01	01	01	01	01	01	01	01	
62	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01	01	01	01	01	01	01	01	01	01	
63	0503018952	PLASTIC BOLT		02	02	02	02	02	02	02	02	02	02	
64	0501053834	MALE QUICK COUPLER	33	02	02	02	02	02	02	02	02	02	02	
65	0511018012	HIDRAULIC ADAPTER		04	04	04	04	04	04	04	04	04	04	
66	0501050633	ROW MARKER DISC ASSEMBLY		02	02	02	02	02	02	02	02	02	02	
67	0521061790	1750 TURNBUCKLE		02	02	02	02	02	02	02	02	02	02	
68	0511060014	ROW MARKER ARM		02	02	02	02	02	02	02	02	02	02	
69	0521012324	1/2" X 3.2"X 2.54" FASTENER		04	04	04	04	04	04	04	04	04	04	
70	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08	08	08	08	08	08	08	08	08	08	
71	0503010019	1/2" SPRING WASHER		08	08	08	08	08	08	08	08	08	08	
72	0503010060	1/2 UNC G.5 ZN HEX NUT		08	08	08	08	08	08	08	08	08	08	
73	0503010003	1845 GREASE FITTING		02	02	02	02	02	02	02	02	02	02	
74	0511060013	ROW MARKER ARM		02	02	02	02	02	02	02	02	02	02	
75	0503010004	1890 GREASE FITTING		02	02	02	02	02	02	02	02	02	02	
76	0521011142	1.1/4" X 7.5" AXLE		04	04	04	04	04	04	04	04	04	04	
77	0501019435	32 X 50 X 1.5 FLAT WASHER		16	16	16	16	16	16	16	16	16	16	
78	0511061022	ROW MARKER SUPPORT		02	02	02	02	02	02	02	02	02	02	
79	0511066119	MARKER SUPP FIXER FASTENER		04	04	04	04	04	04	04	04	04	04	
80	0502010175	HITCH CLAMP		08	08	08	08	08	08	08	08	08	08	
81	0501010216	3/4 UNC X 4.1/2 C S G.5 ZN BOLT		16	16	16	16	16	16	16	16	16	16	
82	0503010023	3/4" SPRING WASHER		16	16	16	16	16	16	16	16	16	16	
83	0503010014	3/4" HEX NUT		16	16	16	16	16	16	16	16	16	16	


[illegible]

DOUBLE ARTICULATED HYDRAULIC MARKER

0511059216




Item	Code	Description	See page	QT
01	0501054649	HBM SEQUENTIAL VALVE	137	01
02	0511058431	HYDRAULIC CYLINDER	141	02
03	0501010617	3/4" NIPPLE		04
04	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
05	0501068994	8,30 X 78 LOCK PIN		02
06	0503030168	HITCH PIN CLIP		02
07	0511057093	HYDRAULIC MARKER HYGIENE SET		01
07A	0501080388	3/8 X 4300 TR-TC HOSE ASSY		02
07B	0501081791	HOSE ASSY		02
07C	0521052512	HOSE 3/8 X 5200 TC-TM PURPLE / RED		01
07CA	0501081980	HOSE 3/8 X 5200 TC-TM		01
07CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
07CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
07CD	0503018952	PLASTIC BOLT		06
07D	0521052513	HOSE 3/8 X 5200 TC-TM PURPLE / BLUE		01
07DA	0501081980	HOSE 3/8 X 5200 TC-TM		01
07DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
07DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
07DD	0503018952	PLASTIC BOLT		06
08	0501053834	MALE QUICK COUPLER	33	02
09	0511018012	HIDRAULIC ADAPTER		04




Item	Code	Description	See page	QT
01	0501067700	2.5" X 25" CYLINDER CASE		01
02	0521066632	EXTENDER		01
03	0503030384	CON PLUG N-001		02
04	0502012837	PISTON		01
05	0503018005	RING		01
06	0503011109	2-119 N 3006-9B O'RING		01
07	0503010163	D-1500 SCRAPER RING		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503018004	RING		01
11	0503018003	GASKET		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503010002	1800 GREASE FITTING		02
15	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01



Item	Code	Description	See page	QT
01	0503034785	LABEL ADHESIVE PST DUO FLEX (04/06 MOUTHS)		01
02	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530		01
03	0503033857	LABEL ADHESIVE		01
04	0503033854	ADHESIVE LABEL		01
05	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
07	0503033422	ADHESIVE LABEL		04
08	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
09	0503033008	ADHESIVE LABEL		02
10	0503031428	READ MANUAL DECAL		01
11	0503031942	ADHESIVE LABEL		01
12	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		01
13	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
14	0503031565	ADHESIVE LABEL CARE		02
15	0503031566	ADHESIVE LABEL		02
16	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
17	0503031425	ADHESIVE LABEL ATTENTION		02
18	0503031669	ADHESIVE LABEL		01
19	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
21	0503032930	ADHESIVE LABEL DANGER		06
22	0503031087	ADHESIVE LABEL		01
23	0503034078	LIFTING POINTS DECAL		03
24	0503034003	SERIAL NUMBER TAG 61 X 118		01
25	0503010001	3.2 X 5.5 RIVET		04
26	0503032979	ADHESIVE LABEL LETTERS A B C D		02
27	0503034500	ADHESIVE LABEL		01
28	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02



Item	Code	Description	See page	QT
01	0503034785	LABEL ADHESIVE PST DUO FLEX (04/06 MOUTHS)		01
02	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530		01
03	0503033857	LABEL ADHESIVE		01
04	0503033854	ADHESIVE LABEL		01
05	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
07	0503033422	ADHESIVE LABEL		04
08	0503033008	ADHESIVE LABEL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	ADHESIVE LABEL		01
11	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		01
12	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
13	0503031565	ADHESIVE LABEL CARE		02
14	0503031566	ADHESIVE LABEL		02
15	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
16	0503031425	ADHESIVE LABEL ATTENTION		02
17	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
18	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
19	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503032930	ADHESIVE LABEL DANGER		06
21	0503031087	ADHESIVE LABEL		01
22	0503034078	LIFTING POINTS DECAL		03
23	0503034003	SERIAL NUMBER TAG 61 X 118		01
24	0503010001	3.2 X 5.5 RIVET		04
25	0503032979	ADHESIVE LABEL LETTERS A B C D		02
26	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503034785	LABEL ADHESIVE PST DUO FLEX (04/06 MOUTHS)		01
02	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530		01
03	0503033857	LABEL ADHESIVE		01
04	0503033854	ADHESIVE LABEL		01
05	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
06	0503033417	ADHESIVE LABEL		02
07	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
08	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
09	0503033008	ADHESIVE LABEL		02
10	0503031428	READ MANUAL DECAL		01
11	0503031942	ADHESIVE LABEL		01
12	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		01
13	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
14	0503031565	ADHESIVE LABEL CARE		02
15	0503031566	ADHESIVE LABEL		02
16	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
17	0503031425	ADHESIVE LABEL ATTENTION		02
18	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
19	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
21	0503032930	ADHESIVE LABEL DANGER		06
22	0503031087	ADHESIVE LABEL		01
23	0503034078	LIFTING POINTS DECAL		03
24	0503034003	SERIAL NUMBER TAG 61 X 118		01
25	0503010001	3.2 X 5.5 RIVET		04
26	0503032979	ADHESIVE LABEL LETTERS A B C D		02
27	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503034786	MINOR ADHESIVE LABEL (03 MOUTH)		01
02	0503034785	LABEL ADHESIVE PST DUO FLEX (04/06 MOUTHS)		01
03	0503034782	LABEL ADHESIVE LOGO SMALLER TATU (03 MOUTHS)		01
04	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530		01
05	0503033857	LABEL ADHESIVE		01
06	0503033854	ADHESIVE LABEL		01
07	0503033853	ADHESIVE LABEL		02
08	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
09	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		04
10	0503033423	LABEL ADHESIVE NUMBER 9		02
11	0503033008	ADHESIVE LABEL		02
12	0503031428	READ MANUAL DECAL		01
13	0503031942	ADHESIVE LABEL		01
14	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		01
15	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
16	0503031565	ADHESIVE LABEL CARE		02
17	0503031566	ADHESIVE LABEL		02
18	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
19	0503031425	ADHESIVE LABEL ATTENTION		02
20	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
21	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
22	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
23	0503032930	ADHESIVE LABEL DANGER		08
24	0503031087	ADHESIVE LABEL		01
25	0503034078	LIFTING POINTS DECAL		03
26	0503034003	SERIAL NUMBER TAG 61 X 118		01
27	0503010001	3.2 X 5.5 RIVET		04
28	0503032979	ADHESIVE LABEL LETTERS A B C D		02




Item	Code	Description	See page	QT
29	0503034500	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0503034785	LABEL ADHESIVE PST DUO FLEX (04/06 MOUTHS)		02
02	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530		02
03	0503033857	LABEL ADHESIVE		02
04	0503033854	ADHESIVE LABEL		02
05	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
07	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING		02
08	0503033422	ADHESIVE LABEL		02
09	0503033008	ADHESIVE LABEL		02
10	0503031428	READ MANUAL DECAL		01
11	0503031942	ADHESIVE LABEL		01
12	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		01
13	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
14	0503031565	ADHESIVE LABEL CARE		02
15	0503031566	ADHESIVE LABEL		02
16	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
17	0503031425	ADHESIVE LABEL ATTENTION		02
18	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
19	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
20	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
21	0503032930	ADHESIVE LABEL DANGER		08
22	0503031087	ADHESIVE LABEL		01
23	0503034078	LIFTING POINTS DECAL		03
24	0503034003	SERIAL NUMBER TAG 61 X 118		01
25	0503010001	3.2 X 5.5 RIVET		04
26	0503032979	ADHESIVE LABEL LETTERS A B C D		02
27	0503034500	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0503063728	010072449 16 ROWS 450/500 SEED MONITORING SET		01
01A	0513010274	020011377 16 ROWS CABLE FOR MESH SEED		01
01B	0503019100	SENSOR		16
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
01E	0503017031	CLEANING BRUSH		01
01F	0503019720	NYLON CLAMP		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010669	FLAT WASHER		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010667	3/16" NUT		02



Item	Code	Description	See page	QT
01	0521053227	FRONT LEFT SHORT SEED ROW	149	01
02	0521053230	FRONT RIGHT SHORT SEED ROW	150	01
03	0521053228	FRONT LEFT LONG SEED ROW	151	01
04	0521053229	FRONT RIGHT LONG SEED ROW	152	01
05	0521054736	FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED ROW	153	01
06	0511059333	SEMI-ASSEMBLED MECHANICAL FRAME	161	01
06.	0521052266	SEMI-ASSEMBLED MECHANICAL FRAME SPA	165	01
07	0521057957	FIXED ROD EXTENSION WITH FIXATION	237	01
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
09	0503010019	1/2" SPRING WASHER		01
10	0503010060	1/2 UNC G.5 ZN HEX NUT		01
11	0521054771	LEFT REAR SEED ROW	168	01
12	0521054770	RIGHT REAR SEED ROW	169	01
13	0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	179	01
13.	0521055397	DEEP WHEEL / COMPACTOR SYSTEM	190	01
13..	0531050978	DEPTH CONTROL WITH FAST REGULATING AXIS	ANGLE 206	01
13...	0521054984	DEPTH/COMPACTOR SYSTEM - SPT	192	01
14	0521054811	FERTILIZER SHORT ROW	213	01
14.	0521054900	FERTILIZER SHORT ROW ASSY DOC20	220	01
15	0521054812	LONG FERTILIZER ROW	214	01
15.	0521054901	LONG FERTILIZER DOC20 ASSY ROW	221	01
16	0521054769	LEFT DDD FERTILIZER WITH SUPPORT	225	01
17	0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	227	01
18	0521050096	SEED HOPPER SYSTEM (CSU)	229	01
19	0511052024	FAST CLOSING SET	232	01
20	0521053946	SCARING ROD	233	01
21	0503030391	RIGHT FERTILIZER NOZZLE		01
22	0503030392	LEFT FERTILIZER NOZZLE		01
23	0503031050	CURVED CONDUCTOR		01
24	0503010246	CLAMP		01


SEED/FERTILIZER ROW

0909096526

Item	Code	Description	See page	QT
25	0503031076	2" HOSE CLAMP		01
26	0503031145	2" X 2" X 20" HOSE		01
27	0571011730	SEED CONDUCTOR 3" X 1500		01
28	0521050525	FIXER FERTILIZER CONDUCTOR	234	01
29	0531013600	PRESS ADJUSTMENT LEVER		01
30	0521068982	DISC BLADE HUB KEY		01
31	0511017969	0.1" SPACING PLATE		01
32	0521069127	BOTTOM NOZZLE FERTILIZER		01
33	0503030483	FERTILIZER SOCKET		01
34	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
35	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
36	0503010025	3/8 SPRING WASHER		01
37	0503010026	3/8" NUT		01
38	0503062066	DISC SET WITH CORN RING	235	01
39	0503062067	DISC SET / RING SOY 90F TITANIUM	236	01
40	0503033672	NOZZLE WITHOUT TITANIUM		01
41	0503010905	1/2" X 2-1/4" BOLT		01
42	0503010019	1/2" SPRING WASHER		01
43	0503010060	1/2 UNC G.5 ZN HEX NUT		01
44	0511018662	SPACING PLATE		01
45	0521041006	COVERING WHEEL ASSY FERTILIZER RIGHT IRON	238	01
46	0521041007	COVERING WHEEL ASSY FERTILIZER LEFT IRON	239	01
47	0521054912	RIGHT SUPPORT WITH DOC 18	241	01
48	0521054913	LEFT SUPPORT WITH DOC 18	243	01
49	0521050168	MOUNTED FERTILIZER CONDUCTOR	245	01
50	0501054292	V RIGHT WHEEL PRESS FERTILIZER ASSY	246	01
51	0501054293	V LEFT WHEEL PRESS FERTILIZER ASSY	247	01
52	0531055312	TITANIUM SINGLE SEED SYSTEM	251	01

FRONT LEFT SHORT SEED ROW

0521053227




Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	SEED ROW BEARING	154	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED ROW TRANSMISSION HUB	155	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	156	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	157	01
20	0521064651	LEFT SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	159	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED ROW		01
31	0581017624	SPACING SLEEVE		06



FRONT LEFT SHORT SEED ROW

0521053227

Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
03	0521055213	SEED ROW BEARING	154	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED ROW TRANSMISSION HUB	155	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	156	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	157	01
20	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	159	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED ROW		01
31	0581017624	SPACING SLEEVE		06



FRONT RIGHT SHORT SEED ROW

0521053230

Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	SEED ROW BEARING	154	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED ROW TRANSMISSION HUB	155	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	156	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	157	01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	159	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED ROW		01
31	0581017624	SPACING SLEEVE		06



FRONT LEFT LONG SEED ROW

0521053228

Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	SEED ROW BEARING	154	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED ROW TRANSMISSION HUB	155	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	156	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	157	01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	159	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED ROW		01
31	0581017624	SPACING SLEEVE		06

**FRONT RIGHT LONG SEED ROW**

0521053229


Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	SEED ROW BEARING	154	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED ROW TRANSMISSION HUB	155	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	156	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	159	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED ROW		01
31	0581017624	SPACING SLEEVE		06




Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0502012718	ROW BEARING		01
02	0503019355	BEARING 6202 2RS1		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503019361	BEARING 6006 RS1		02
04	0503019363	BEARING 6005		01
05	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503019362	BEARING 6005 RS1		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501059326	UNIVERSAL JOINT AXLE	158	01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	164	01




Item	Code	Description	See page	QT
01	0561016322	5/8" HEX AXLE		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		02
04	0561014794	350 AXLE HEX		01




Item	Code	Description	See page	QT
01	0502012819	17Z GEAR WITH HEX HOLE		01
02	0521055220	BEARING FRONT SEED ROW	160	01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011697	GEARBOX BEARING		01
02	0503019356	BEARING 6005 2RS1		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521066496	FRAME MECHANICAL CENTRAL SEED ROW		01
02	0511059334	BEARING WITH LONG FRONT AXLE	162	01




Item	Code	Description	See page	QT
01	0511058143	UNIVERSAL JOINT AXLE	163	01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	164	01




Item	Code	Description	See page	QT
01	0561014794	350 AXLE HEX		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		02
04	0581010483	HEX AXLE		01




Item	Code	Description	See page	QT
01	0501059363	5/8" HEX AXLE BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521066539	CENTRAL SEED ROW FRAME		01
02	0521052268	LONG SHAFT BEARING AND JOINT SPA	166	01




Item	Code	Description	See page	QT
01	0521052269	UNIVERSAL JOINT AXLE SPA	167	01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	164	01




Item	Code	Description	See page	QT
01	0561014794	350 AXLE HEX		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		02
04	0581016333	HEX SHAFT 5/8 X 668 SPA		01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	176	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521055871	LEFT DOUBLE DISC SEED 15 X 15	171	01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	176	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521055870	RIGHT DOUBLE DISC SEED 15 X 15	170	01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	178	01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
06	0503010026	3/8" NUT		01
07	0503010025	3/8 SPRING WASHER		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 172 FERTILIZER / SEED		01
09	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 173 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	177	01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
06	0503010026	3/8" NUT		01
07	0503010025	3/8 SPRING WASHER		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 172 FERTILIZER / SEED		01
09	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 173 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	174	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	175	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUB DISC - HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0581019201	CROWN SHAFT		01
02	0503019340	LUBRICANT SLEEVE		02
03	0503011030	2-014 N 3006-9B O'RING		02
04	0581019200	CONICA 40Z GEAR		01
05	0581019199	FIXED BASE		01
06	0581019202	PINHAO CONICO 10Z X 5/8		01
07	0501013354	FLAT WASHER		01
08	0503010410	RING		02
09	0503019341	LUBRICANT SLEEVE		01




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	180	01
02	0521055068	RAYED WHEEL CENTER CLOSED	185	02
03	0521054990	LEFT COMPACTOR WHEEL	187	01
04	0521055017	RIGHT COMPACTOR WHEEL	188	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY	181	01
06	0503019398	AXLE RETAINER RING		01
07	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	182	01
08	0521055054	LEFT ARM WITH SLEEVE	183	01
09	0521055066	RIGHT ARM WITH SLEEVE	184	01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2 UNC G.5 ZN HEX NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED SLEEVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT SLEEVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0581019523	LEFT ARM WHEEL DEPTH		01
02	0581019514	LUBRICANT SLEEVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019524	RIGHT ARM DEPTH		01
02	0581019514	LUBRICANT SLEEVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521055055	HUB WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	186	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0581019522	CASE WHEEL DEPTH WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0503010143	1/4" SPRING WASHER		03
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019529	DEPTH REGULATOR SHAFT		01
11	0581019168	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	189	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05



Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	189	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521055398	DEPTH WHEEL	191	01
02	0521055093	BODY COMPACTOR	205	01
03	0521055017	RIGHT COMPACTOR WHEEL	188	01
04	0521054990	LEFT COMPACTOR WHEEL	187	01

DEPTH WHEEL


0521055398




Item	Code	Description	See page	QT
01	0581019532	DEPTH CONTROL SUPPORT		01
02	0581019531	ARTICULATED AXLE WHEEL DEPTH		02
03	0501059228	ADJUSTMENT LEVER	198	01
04	0502012611	DEPTH CONTROL AXLE		01
05	0571015326	ARTICULATION SLEEVE HANDLE		01
06	0581017075	LARGER AXLE		01
07	0581017076	SMALLER AXLE		01
08	0501011445	FLAT WASHER		04
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0503030012	HITCH PIN CLIP		04
12	0503011402	0.2" X 0.8" SPRING PIN		02
13	0503012795	5/8" HEX SELF ADJUSTING NUT		02
14	0503010237	3/8" X 1" BOLT		01
15	0503010025	3/8 SPRING WASHER		01
16	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
17	0581019526	ARTICULATED AXLE LEVER DEPTH		01
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0503010302	501019 SEAL RING		01
20	0581019473	ARTICULATED SLEEVE		02
21	0503010045	O'RING		02
22	0521055399	LEFT ARM WITH WHEEL	199	01
23	0521055400	RIGHT ARM WITH WHEEL	201	01




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	193	01
02	0501052538	DEPTH BAND WITH ARMS	197	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL	187	01
06	0521055017	RIGHT COMPACTOR WHEEL	188	01




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	208	01
02	0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	194	01
03	0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	196	01
04	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	182	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	3/8 UNC X 3/4 BOLT		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED SLEEVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	195	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02



Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL HUB		01
02	0581019515	AXIS		01
03	0503034055	CLAMPING RING		01
04	0581019168	DUST CLOAK		01
05	0503013758	1/4" X 1-1/2" BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0503010878	5/8" SELF ALIGNING NUT		01
10	0503030757	2.9" X 2" X 0.02" JOINT		01
11	0521019178	PROTECTION LID		01




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	195	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05

ADJUSTMENT LEVER


0501059228




Item	Code	Description	See page	QT
01	0502012603	ADJUSTMENT LEVER		01
02	0502011689	1/8" DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0511015976	FLAT WASHER		01
05	0503010140	1/8" X 3/4" COTTERPIN		01




Item	Code	Description	See page	QT
01	0521055058	LEFT ARM	200	01
02	0521055401	ASSY WHEEL	203	01
03	0581018815	SET DEVIATION		01
04	0503010741	1/2" X 2-3/4" BOLT		01
05	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0581019525	LEFT ARM WHEEL DEPTH		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02




Item	Code	Description	See page	QT
01	0521055074	RIGHT ARM WITH O-RING	202	01
02	0521055401	ASSY WHEEL	203	01
03	0581018815	SET DEVIATION		01
04	0503010741	1/2" X 2-3/4" BOLT		01
05	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0581019530	RIGHT ARM ROD DEPTH SPA NO LUBRICATION		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503030891	RUBBER BAND		01
03	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
05	0503010337	5/16" NUT		06
06	0521055073	ASSEMBLY DEPTH WHEEL HUB	204	01
07	0561016889	STRIPED CAP WHEEL DEPTH		01




Item	Code	Description	See page	QT
01	0581019528	WHEEL DEPTH SPA HUB WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	DUST CLOAK		01
11	0581019529	DEPTH REGULATOR SHAFT		01




Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT	02	
02	0503013816	5/16" LOCKNUT	04	
03	0581015855	SLEEVE	02	
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER	01	
05	0521068661	LEVER	01	
06	0503030878	LEVER CRANK	01	
07	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING	01	
08	0581019520	AXIS	01	
09	0571812442	COUPLING SHAFT	01	
10	0503010257	1/8" X 1" COTTERPIN	01	
11	0581019511	COVER	01	
12	0503010848	5/16" X 3.1/2" BOLT	02	
13	0503010752	1/2" X 3.1/2" BOLT	01	
14	0503011336	1/2" HEX SELF ADJUSTING NUT	01	
15	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
16	0581019510	AXIS	01	
17	0581019512	PLATE TOP	01	
18	0503019351	LUBRICANT SLEEVE	02	
19	0521069591	LEFT SIDE	01	
20	0581019548	RIGHT SIDE BODY	01	




Item	Code	Description	See page	QT
01	0531050980	SEM SEMI-ASSEMBLED CONTROL WITHOUT LUBRICATION	207	01
02	0503010358	5/16" X 5/8" BOLT		08
03	0503013816	5/16" LOCKNUT		08
04	0521055017	RIGHT COMPACTOR WHEEL	188	01
05	0521054990	LEFT COMPACTOR WHEEL	187	01
06	0511055819	DEPTH BAND WITH RIM	212	02




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	208	01
02	0531050975	LEFT ARM WHEELS DEPTH WITH HUB WITHOUT LUBRICATION	209	01
03	0531050973	RIGHT ARM DEPTH WHEEL WITH HUB WITHOUT LUBRICATION	210	01
04	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	182	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	3/8 UNC X 3/4 BOLT		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED SLEEVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0531050974	CUBE CONTROL DEPTH WITHOUT LUBRICATION	211	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0531050974	CUBE CONTROL DEPTH WITHOUT LUBRICATION	211	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL HUB		01
02	0503019342	ROLLER BEARING		01
03	0581019168	DUST CLOAK		01
04	0503034055	CLAMPING RING		01
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0521019178	PROTECTION LID		01
08	0503010143	1/4" SPRING WASHER		03
09	0503011105	SEAL RING		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0591018029	DEPTH REGULATING AXLE WITH ANGLE		01




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05




Item	Code	Description	See page	QT
01	0501010066	3/4" X 9" BOLT		01
02	0511017232	FLAT WASHER		02
03	0503011255	3/4" LOCK NUT		01
04	0502012873	SUPPORT DC FERTILIZER ROW		01
05	0503019278	LUBRICANT SLEEVE		02
06	0581019195	SIDE GUIDE SLEEVE		02
07	0581019196	CENTRAL GUIDE SLEEVE		01
08	0503010410	RING		02
09	0502012876	CLAMP		01
10	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
11	0503010013	5/8 NUT		02
12	0521054906	SPRING ASSY FERTILIZER	219	01
13	0521053231	DPL 20 SHORT ROW WITHOUT LUBRICATION CONICAL BEARING	215	01
14	0521066231	SHORT FERTILIZER ROW ARM		01
15	0503017857	BOLT 5/8 UNF 4		03
16	0503010811	5/8" UNF SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0501010066	3/4" X 9" BOLT		01
02	0511017232	FLAT WASHER		02
03	0503011255	3/4" LOCK NUT		01
04	0502012873	SUPPORT DC FERTILIZER ROW		01
05	0503019278	LUBRICANT SLEEVE		02
06	0581019195	SIDE GUIDE SLEEVE		02
07	0581019196	CENTRAL GUIDE SLEEVE		01
08	0503010410	RING		02
09	0502012876	CLAMP		01
10	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
11	0503010013	5/8 NUT		02
12	0521054906	SPRING ASSY FERTILIZER	219	01
13	0521053232	DPL 20 LONG ROW WITHOUT LUBRICATION CONICAL BEARING	216	01
14	0521066230	LONG FERTILIZER ROW ARM		01
15	0503017857	BOLT 5/8 UNF 4		03
16	0503010811	5/8" UNF SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	217	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	THRUST WASHER		01
08	0521068887	DC RIGHT ARM WITH SLEEVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH SLEEVE		01
17	0503019272	LUBRICANT SLEEVE		02
18	0503010390	SEAL RING		02
19	0581017628	LID		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	DISC BLADE FIXED AXLE		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	217	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	THRUST WASHER		01
08	0521068887	DC RIGHT ARM WITH SLEEVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH SLEEVE		01
17	0503019272	LUBRICANT SLEEVE		02
18	0503010390	SEAL RING		02
19	0581017628	LID		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	DISC BLADE FIXED AXLE		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	DISC BLADE HUB	218	01




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4	01	
02	0502040872	REGULATORY NUT	01	
03	0503010370	502072 CLAMPING RING (FOR AXLE)	02	
04	0503010590	00674-B SEAL	02	
05	0503019285	RING	02	
06	0503012170	30207 ROLLER BEARING	02	
07	0502020641	BLADE DISC FLANGE	01	
08	0502012862	DISC BLADE HUB	01	
09	0502040873	DISC BLADE AXLE	01	
10	0503017755	NUT	01	
11	0503018825	5/16 UNC UNC BOLT	06	
12	0501010694	FLAT WASHER	06	
13	0503013816	5/16" LOCKNUT	06	
14	0511017907	1/8" BSPT X 6 PLUG	02	




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK		02
02	0502012184	FERTILIZER SPRING GUIDE		02
03	0503031910	1.7" X 22.8" X 0.3" SPRING		01
04	0502012510	SPRING ROD SUPPORT		01
05	0591018219	JUNCTION SHAFT 12.70 X 109 ZN		01
06	0501018535	1/2 X 1 BOLT		02
07	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		02
09	0502010891	SPRING ROD SUPPORT CHOCK		01
10	0503010014	3/4" HEX NUT		01
11	0521067619	FERTILIZER ROW TUBE		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0501010937	13,50 X 28 X 3,00 FLAT WASHER		01




Item	Code	Description	See page	QT
01	0521066231	SHORT FERTILIZER ROW ARM		01
02	0502012873	SUPPORT DC FERTILIZER ROW		01
03	0502012876	CLAMP		01
04	0503017857	BOLT 5/8 UNF 4		03
05	0503010811	5/8\" UNF SELF ADJUSTING NUT		03
06	0503011255	3/4\" LOCK NUT		01
07	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
08	0503010013	5/8 NUT		02
09	0521054845	DPLO 20 SHORT ROW WITHOUT LUBRICATION	222	01
10	0521054906	SPRING ASSY FERTILIZER	219	01
11	0501010066	3/4\" X 9\" BOLT		01
12	0511017232	FLAT WASHER		02
13	0581019195	SIDE GUIDE SLEEVE		02
14	0503010410	RING		02
15	0503019278	LUBRICANT SLEEVE		02
16	0581019196	CENTRAL GUIDE SLEEVE		01




Item	Code	Description	See page	QT
01	0521066230	LONG FERTILIZER ROW ARM		01
02	0502012873	SUPPORT DC FERTILIZER ROW		01
03	0502012876	CLAMP		01
04	0503017857	BOLT 5/8 UNF 4		03
05	0503010811	5/8\" UNF SELF ADJUSTING NUT		03
06	0503011255	3/4\" LOCK NUT		01
07	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
08	0503010013	5/8 NUT		02
09	0521054846	DPLO 20 LONG ROW WITHOUT LUBRICATION 223 CONICAL BEARING		01
10	0521054906	SPRING ASSY FERTILIZER	219	01
11	0501010066	3/4\" X 9\" BOLT		01
12	0511017232	FLAT WASHER		02
13	0581019195	SIDE GUIDE SLEEVE		02
14	0503010410	RING		02
15	0503019278	LUBRICANT SLEEVE		02
16	0581019196	CENTRAL GUIDE SLEEVE		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521054844	20" WAVY COULTER BLADE HUB	224	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	THRUST WASHER		01
08	0521068887	DC RIGHT ARM WITH SLEEVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH SLEEVE		01
17	0503019272	LUBRICANT SLEEVE		02
18	0503010390	SEAL RING		02
19	0581017628	LID		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	DISC BLADE FIXED AXLE		01



Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521054844	20" WAVY COULTER BLADE HUB	224	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	THRUST WASHER		01
08	0521068887	DC RIGHT ARM WITH SLEEVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH SLEEVE		01
17	0503019272	LUBRICANT SLEEVE		02
18	0503010390	SEAL RING		02
19	0581017628	LID		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	DISC BLADE FIXED AXLE		01




Item	Code	Description	See page	QT
01	0521053697	DISC BLADE HUB	218	01
02	0607026025	DPLO20X4,5		01




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC	226	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04

LEFT DUAL FERTILIZER DISC


0521055869




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 172 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 173 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC	228	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 172 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 173 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521050118	3" NOZZLE SEED HOPPER	230	01
02	0581014295	FIXING SLEEVE		01
03	0511052058	SEED SYSTEM TITANIUM	231	01
04	0503010358	5/16" X 5/8" BOLT		05
05	0501010694	FLAT WASHER		05
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
07	0503010337	5/16" NUT		05



Item	Code	Description	See page	QT
01	0503062397	ASSY SEED HOPPER WITH 3" NOZZLE		01




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
09.	0503016279	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01
14	0503062044	ASSEMBLY SEED HOPPER SET		01
14A	0503016285	BOLT		05
14B	0503016286	HEX NUT		05
14C	0503016287	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02

SCARING ROD


0521053946




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070085	FIXED ROD BEARING		01
03	0513010288	ELASTIC PIN 701211 10 X 24		02
04	0513010289	ELASTIC PIN 701211 10 X 24		02




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0503016204	CORN DISC 12 ORANGE		01
02	0503016398	TITANIUM RING CORN / SOY (YELLOW FLAT)		01
03	0503016399	TITANIUM RING CORN (GREEN)		01
04	0503016400	TITANIUM RING CORN (GREY)		01
05	0503016401	TITANIUM RING CORN (BLUE)		01




Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016218	DISC OF SOYBEAN		01
03	0503016403	TITANIUM RING FOR SOYBEAN (LILAC)		01
04	0503016404	TITANIUM RING FOR SOYBEAN (PURPLE)		01
05	0503016406	TITANIUM RING FOR SOYBEAN (ORANGE)		01
06	0503016407	TITANIUM RING FOR SOYBEAN		01




Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0521063363	RIGHT SUPPORT COVERING WHEEL FERTILIZER IRON		01
02	0503010795	5/8" X 7" BOLT		01
03	0503012412	5/8" UNC SELF LOCKING NUT		01
04	0531016207	0.6" X 1" X 2.8" SLEEVE		01
05	0521063362	SUPPORT ARTICULATION COVERING WHEEL FERTILIZER IRON		01
06	0501010452	5/8" X 5" BOLT		01
07	0501012140	FLAT WASHER		02
08	0503012412	5/8" UNC SELF LOCKING NUT		01
09	0503010002	1800 GREASE FITTING		01
10	0511052086	LEFT WHEEL COVERING IRON FERTILIZER	240	01




Item	Code	Description	See page	QT
01	0521063364	LEFT SUPPORT COVERING WHEEL FERTILIZER IRON		01
02	0503010795	5/8" X 7" BOLT		01
03	0503012412	5/8" UNC SELF LOCKING NUT		01
04	0531016207	0.6" X 1" X 2.8" SLEEVE		01
05	0521063362	SUPPORT ARTICULATION COVERING WHEEL FERTILIZER IRON		01
06	0501010452	5/8" X 5" BOLT		01
07	0501012140	FLAT WASHER		02
08	0503012412	5/8" UNC SELF LOCKING NUT		01
09	0503010002	1800 GREASE FITTING		01
10	0511052086	LEFT WHEEL COVERING IRON FERTILIZER	240	01




Item	Code	Description	See page	QT
01	0502011970	IRON PRESS WHEEL		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0511015098	FLAT WASHER		01
06	0503030282	3/4" CASTLE NUT		01
07	0503010257	1/8" X 1" COTTERPIN		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0511016896	DUST CLOAK		01
13	0502011156	LEFT FIXER WHEEL		01
14	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
16	0503011440	SPRING WASHER		02




Item	Code	Description	See page	QT
01	0521069504	DOC DISC ARM		01
02	0581011838	SLEEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2 UNC G.5 ZN HEX NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503016063	ROLLER BEARING		01
10	0503030832	FLAT WASHER		01
11	0521054914	HUB WITH DOC 18 RIGHT	242	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0503011800	SEAL RING		01
02	0503012417	SEAL		01
03	0503016063	ROLLER BEARING		01
04	0503030832	FLAT WASHER		01
05	0502020641	BLADE DISC FLANGE		01
06	0607025032	PLAIN COULTER BLADE		01
07	0503010371	5/16" X 1" BOLT		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0503010337	5/16" NUT		06
10	0581019304	DISC HUB		01




Item	Code	Description	See page	QT
01	0521069504	DOC DISC ARM		01
02	0581011838	SLEEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2 UNC G.5 ZN HEX NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503016063	ROLLER BEARING		01
10	0503030832	FLAT WASHER		01
11	0521054915	HUB WITH DOC 18 LEFT	244	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0503011800	SEAL RING		01
02	0503012417	SEAL		01
03	0503016063	ROLLER BEARING		01
04	0503030832	FLAT WASHER		01
05	0502020641	BLADE DISC FLANGE		01
06	0607025032	PLAIN COULTER BLADE		01
07	0503010371	5/16" X 1" BOLT		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0503010337	5/16" NUT		06
10	0581019304	DISC HUB		01




Item	Code	Description	See page	QT
01	0581013298	SUPPORT		01
02	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
03	0521018517	FLAT WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0503030483	FERTILIZER SOCKET		01
07	0503031050	CURVED CONDUCTOR		01
08	0503010246	CLAMP		01




Item	Code	Description	See page	QT
01	0521062253	RIGHT PRESS WHEEL FERT UP SUPPORT		01
02	0511064128	PRESS SUPPORT LOWWER WHEEL		01
03	0503010752	1/2" X 3.1/2" BOLT		01
04	0531013272	0.5" X 1" X 2.2" SLEEVE		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	0501013491	5/8" TENSIONER SPRING		01
08	0503010013	5/8 NUT		02
09	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
10	0503010002	1800 GREASE FITTING		01
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010025	3/8 SPRING WASHER		02
13	0503010026	3/8" NUT		02
14	0503010795	5/8" X 7" BOLT		01
15	0503012412	5/8" UNC SELF LOCKING NUT		01
16	0502011757	PRESS REGULATOR		01
17	0511054333	COMPACT WHEEL RIGHT WITH BEARING	248	01
18	0511054334	COMPACT WHEEL LEFT WITH BEARING	249	01




Item	Code	Description	See page	QT
01	0521062254	LEFT PRESS WHEEL FERT UPPER SUPPORT		01
02	0511064128	PRESS SUPPORT LOWWER WHEEL		01
03	0503010752	1/2" X 3.1/2" BOLT		01
04	0531013272	0.5" X 1" X 2.2" SLEEVE		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	0501013491	5/8" TENSIONER SPRING		01
08	0503010013	5/8 NUT		02
09	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
10	0503010002	1800 GREASE FITTING		01
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010025	3/8 SPRING WASHER		02
13	0503010026	3/8" NUT		02
14	0503010795	5/8" X 7" BOLT		01
15	0503012412	5/8" UNC SELF LOCKING NUT		01
16	0502011757	PRESS REGULATOR		01
17	0511054333	COMPACT WHEEL RIGHT WITH BEARING	248	01
18	0511054334	COMPACT WHEEL LEFT WITH BEARING	249	01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	250	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	250	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0511052058	SEED SYSTEM TITANIUM	231	01
02	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
03	0503010337	5/16" NUT		05
04	0501010694	FLAT WASHER		05
05	0503010358	5/16" X 5/8" BOLT		05
06	0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	252	01



Item	Code	Description	See page	QT
01	0503015536	M6 X 1" SELF ADJUSTING NUT		04
02	0581014295	FIXING SLEEVE		01
03	0501213431	SEED NOZZLE FIXING FLANGE		01
04	0501213520	SEED BREAKER BODY		01
05	0501213432	BREAKER SUPPORT BASE		01
06	0501213728	60 X 53 X 30 PVC TUBE		01
07	0513010720	M6 X 1 X 35 C S G.5 ZB BOLT		04
08	0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK 253 LID		01



Item	Code	Description	See page	QT
01	0503035751	SIGMA SINGLE SEED HOPPER		01
02	0503035750	SEED HOPPER LID		01
03	0503035298	BAKELITE HANDLE WITH THREAD		01
04	0503015536	M6 X 1" SELF ADJUSTING NUT		01
05	0503035297	CURVED NOZZLE SEED HOPPER		01



MARCHESAN

Technical Publications | Elaboration and Revision

LEONARDO JOSÉ DA SILVA SOUZA

www.marchesan.com.br

