

ROW CROP PLANTERS

USAP 3200 AP SUPREMA ALP - FRAME 12820

Code: 0501093397
Series: S-0522
Revision: 00
Date Revision: FEVEREIRO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111510145	USAP 3200 AP 24E500 SUP ALP S-0522

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909090616	ASSY FRAME	1
0909091799	FRAME RIGHT SIDE ASSY	2
0909094815	ASSY CENTRAL FRAME	3
0909094817	LEFT SIDE FRAME ASSY	4
0531056309	DRAWBAR ASSY	5
0531056313	REAR DRAWBAR	6
0531052882	SIDE ARM LOCK ASSEMBLY WITH MINOR GLOVE	7
0531056310	SEMI-ASSEMBLED FRONT HEADING 24/25	8
0521057739	HYDRAULIC CYLINDER 38,10 X 63,50 X 397 X 126	9
0531054742	PANTOGRAPHIC HEADING FOR THIRD POINT	10
0531040499	HYDRAULIC CYLINDER 50.8 X 127 X 682 X 285	11
0521059886	SEMI-ASSEMBLED REST	12
0531051725	MAT ASSEMBLY	13
0531057052	COMPLETE THIRD POINT HEADER	14
0531057067	FULL HEAD HOSE STABILIZER	15
0531058117	FIXED GUTTER 3180MM COMPLETE	16
0531053166	CHUTE ASSY	17
0531051342	RAIL SUPPORT WITH FIXER	18
0531057567	MECHANICAL ASSEMBLY APT/3C/VAPPLY + VDRIVE	19
0531051558	SIDE BODY BEARING APT	20
0531056290	RIGHT CHAIN COVER WITH SCREW	21
0531056289	LEFT CHAIN COVER WITH SCREW	22
0531055917	ASSY PDM	23
0531057766	ASSY SHT SUP/TME/22E500A25E500 USAP	24
0531057718	SUPPORT WITH BLOCK	25
0531057762	GEARBOX WITH DOUBLE PUMP JIC/TME	26
0531057196	AXIAL PISTON PUMP 63CC - H JIC	27
0531057763	HYDRAULIC PUMP ENGRE 11CC - BD JIC	28
0531057719	SUPPORT WITH RADIATOR/TANK SUP/JIC/18E25	29
0531057358	COMPLETE TANK 180L JIC/AP	30
0531057695	SUPPORT RADIATOR SET	31
0531057707	COMMAND BLOCK	32
0531059117	FULL HEAD HOSE STABILIZER	33
0521059419	CASAPPA DOUBLE DIVIDER BRP00102 WITH NIPLES	34
0531053059	VDRIVE ASSY 24L 45/50 MS WV	35
0531054594	CONTROL 3 VAPPLY CHANNELS	36
0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	37
0511056972	FILTER HYDAC	38
0531057194	3F/AP LIGHTING/CONTROL ASSY	39
0531058753	HYDRAULIC HOSE ASSY 24E500 VDRIVE	40
0531058197	HOSE ASSY LATCHES 24/25E500	41
0531058199	HOSE SET HEADER 24/25E500	42
0531058205	CONTROL VALVE CONNECTION HOSES 24/25E500	43
0531058210	TURBINE HOSE SET 24/25E500	44
0531058170	WHEEL SUPPORT HOSE SET 24/25E500	45
0531058169	HOSE SET ROWS 24/25E500	46
0531058194	LIFT HOSE SET 24/25E500	47
0531058171	HOSE SET OPENS/CLOSES 4/25E500	48
0531058195	HOSE SET ARTICULATION CSC 24/25E500	49
0531058967	HOSE SET APT 24/25E500 VDRIVE	50
0531053111	SET LABEL ADHESIVE	51
0531052114	ASSY PORT MANUAL INSTRUCCION	52
0531056312	ASSY FRENCH HAND	53
0521057793	KNEECAP WITH RIGHT EXTENSION AXLE	54
0531056065	STABILIZER	55



MARCHESAN

INDEX

0531053738	STABILIZER EXTENDER	56
0531055743	RIGHT/LEFT SIDE BRACKET MOUNTED	57
0531050903	SIDE ARTICULATED CYLINDER 44.45X85.70X291X657	58
0531050901	ASSY STABILIZER	59
0521059948	ASSY LOCK AXLE	60
0531052866	CYLINDER 101,55X618X353	61
0531055572	RIGHT DOUBLE WHEEL SUPPORT WITH 500/50 TIRE	62
0531055842	RIGHT HYDRAULIC CYLINDER 44.45X85.70X326 CLOSED 607 COURSE	63
0531055358	COMPLETE SIDE CYLINDER BEARING	64
0531055357	LOCK PIN SET	65
0531055342	LEFT WHEEL ASSEMBLED	66
0531055341	RIGHT WHEEL MOUNTED	67
0531055574	DOUBLE SIDE WHEEL TIRE 500/50	68
0531055575	WHEEL COMPLETE BOX	69
0531056303	RIGHT SIDE HOPPER 10 MOUTHS	70
0531056304	RIGHT SIDE HOPPER 10 10 MOUTHS ALPHA	71
0531051684	SIDE AXLE	72
0531055292	ALPHA FERTILIZER METERING	73
0531055273	ALPHA FERTILIZER METERING CLAMP	74
0531055376	TRANSMISSION ALPHA FERTILIZER METERING HUB	75
0501053788	3/4 SQUARE AXLE FASTENER	76
0521051407	FERTILIZER HOPPER FIXER	77
0531050918	TOP SUPPORT MOUNTED LIFT EXTENSOR	78
0531052853	RIGHT LADDER SET	79
0531056308	HANDRAIL/PLATFORM ASSY	80
0521059839	ASSY REAR HEADLIGHT	81
0531053062	SUPPORT WITH VACUOMETER 18/25 LINES	82
0531056368	FERTILIZER DUCT SIDE SUPPORT	83
0531055920	MINOR DUCT COMPLETE FERTILIZER	84
0531055919	MINOR DUCT COMPLETE FERTILIZER	85
0531056366	TURBINE PRECISION PLANTING	86
0531057259	HYDRAULIC TURBINE WITH HOLE	87
0531056364	24/25 RIGHT HYDRAULIC DUCT ASSEMBLY	88
0531056365	FULL SIDE AIR DISTRIBUTOR SET	89
0521052549	CLAMP	90
0531056288	MOTOR BOARD WITH SPACER	91
0909091837	COMPLETE FERTILIZER ROW	92
0531055175	LONG FERTILIZER LINE SMALLER DC20 SHANKS	93
0531055166	SHORT FERTILIZER LINE DC20 WITHOUT LUBRICATION SHANKS	94
0531051744	SHORT LINE SPI TIRE WITHOUT FLAP TRANSMISSION ME PP	95
0531051745	LONG LINE SPI TIRE WITHOUT FLAP TRANSMISSION ME PP	96
0531055580	SUPER LONG LINE SPI TIRE WITHOUT FLAP TRANSMISSION/ME PP	97
0531055165	20 COMPLETE CURVED CORRUGATED CUTTING DISC	98
0521057679	ASSY CUTTING DISK 20	99
0521057681	BOX WITH DISC CUTTING 20 BEARING CONICO	100
0521057680	DISC CUTTING BOX	101
0521053673	SCARIFIER ROD WITH NOZZLE	102
0531053737	MOUNTED SUPPORT	103
0521059626	FRONT LINE	104
0531055581	SUPER LONG FRONT ME	105
0531051743	REAR RIGHT SPI	106
0531055099	REAR WITH LEFT DDD SPICRR WITHOUT FLAP PPH VDRIVE	107



MARCHESAN

INDEX

0531050536	REAR RIGHT SPI TIRE WITHOUT FLAP	108
0531055009	REAR ROW WITH LEFT DOUBLE DISC	109
0521056632	DEPTH CONTROL	110
0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	111
0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	112
0521055093	BODY COMPACTOR	113
0521055017	RIGHT COMPACTOR WHEEL	114
0521054990	LEFT COMPACTOR WHEEL	115
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	116
0531050538	MOUNTED LEFT ARM	117
0531050539	MOUNTED LEFT ARM	118
0521055056	WHEEL RAYED ASSY BAND	119
0521055073	ASSEMBLY DEPTH WHEEL HUB	120
0521056640	PRECISION PLANTING CSC CABLE / TRANSMISSION ASSY	121
0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT PROTECTION	122
0531051094	MOUNTED HOSE GUIDE ASSEMBLY	123
0521055869	LEFT DUAL FERTILIZER DISC	124
0521055868	RIGHT DUAL FERTILIZER DISC	125
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	126
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	127
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	128
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	129
0531055744	MOUNTED CENTRAL SUPPORT	130
0531055349	CENTRAL HOPPER WITH 07 NOZZLES ALPHA/APT/AP	131
0531055350	CENTRAL SUPPORT WITH 07 NOZZLES	132
0521054282	BEARING	133
0501056444	BEARING WITH ROLLER	134
0531055368	ASSY RIGHT ARTICULATION ARM AP	135
0531055369	ASSY LEFT ARTICULATION ARM AP	136
0531051599	LED FLASHLIGHT WITH SUPPORT	137
0531051769	MOUNTED DUCT SUPPORT	138
0531052063	4 MOUTH CENTRAL AIR DISTRIBUTOR	139
0531052865	HYDRAULIC CYLINDER 50,80X127X965X534	140
0531054353	CSC SILO ASSEMBLY	141
0531054356	HYDRAULIC TURBINE WITH CSC SCREEN 30 LINES	142
0501054983	NIPPLE HIDRAULIC MOTOR	143
0521044613	FAN 480X50 (HIDRAULIC)	144
0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE	145
0531054354	CENTRAL SEED BOX 2500 LITERS	146
0531054357	LOWER SYSTEM 28 PIPES	147
0531054350	DEPOSIT MOVEMENT SUPPORT	148
0531054351	HYDRAULIC CYLINDER 38.10X63.50X225X375	149
0531055847	RIGHT TELESCOPIC WHEEL 15	150
0531055353	LEFT TELESCOPIC WHEEL 15	151
0531055354	HYDRAULIC CYLINDER 44.45X85.70X326	152
0531055355	CENTRAL ASSY CUBE	153
0531054036	ASSY CENTER CYLINDER BEARING	154
0531055424	CENTRAL SUPPORT WITH 06 FERTILIZER DUCTS	155
0501053834	MALE QUICK COUPLER	156
0531056410	BEARING PLATE WITH BOLT	157
0531057754	SUPPORT ASSY DUCTS	158
0531052854	LEFT STAIRS SET	159
0531055573	LEFT DOUBLE WHEEL SUPPORT WITH 500/50 TIRE SMALLER	160
0531058139	LEFT SIDE HOPPER WITH 10 NOZZLES 175L ALPHA	161




MARCHESAN

INDEX

0531058140	LEFT SIDE HOPPER WITH 10 NOZZLES ALPHA		162
0531056363	LEFT HYDRAULIC DUCT SET 24/25		163

ASSY FRAME

0909090616




Item	Code	Description	See page	QT
01	0531056309	DRAWBAR ASSY	5	01
02	0909091799	FRAME RIGHT SIDE ASSY	2	01
03	0909094815	ASSY CENTRAL FRAME	3	01
04	0909094817	LEFT SIDE FRAME ASSY	4	01
05	0531053166	CHUTE ASSY	17	01
06	0531057567	MECHANICAL ASSEMBLY APT/3C/VAPPLY VDRIVE	+ 19	01
07	0531057766	ASSY SHT SUP/TME/22E500A25E500 USAP	24	01
08	0531053059	VDRIVE ASSY 24L 45/50 MS WV	35	01
09	0531054594	CONTROL 3 VAPPLY CHANNELS	36	01
10	0531057194	3F/AP LIGHTING/CONTROL ASSY	39	01
11	0531058753	HYDRAULIC HOSE ASSY 24E500 VDRIVE	40	01
12	0531053111	SET LABEL ADHESIVE	51	01
13	0531055394	MOUNTED TRANSPORT LOCK 315MM		04
13A	0531064139	TRANSPORT LOCK 315MM		01
13B	0531060392	PIN LOCK TRANSPORT		01
13C	0503030168	HITCH PIN CLIP		01
14	0531055395	MOUNTED TRANSPORT BEAM 600MM		04
14A	0531064140	TRAVA FOR TRANSPORTATION 600MM		01
14B	0531060392	PIN LOCK TRANSPORT		01
14C	0503030168	HITCH PIN CLIP		01
15	0501214555	LIFT SENSOR SUPPORT		01
16	0503013356	RIVET POP 3,2 X 10,0		01
17	0501216629	LIFTING ACTUATOR SUPPORT		01
18	0501216630	50MM LIFTING ACTUATOR		01
19	0503015321	3/8 UNC X 5/8 C S G.2 ZN BOLT		02
20	0503010025	3/8 SPRING WASHER		02
21	0503013849	1/4" UNC X 3/4" BOLT		02
22	0591012160	7 X 23 X 2.00 ZN FLAT WASHER		04
23	0503010143	1/4" SPRING WASHER		04
24	0503010144	1/4" NUT		04
25	0501217527	RCEM STAIRS LIFT ACTUATOR		02

ASSY FRAME

0909090616

Item	Code	Description	See page	QT
26	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
27	0503010019	1/2" SPRING WASHER		02
28	0503010060	1/2 UNC G.5 ZN HEX NUT		02
29	0503010461	1/4" X 1" BOLT		02
30	0531057207	SUPPORT SENSOR TE STAIRCASE		02
30A	0501217526	LIFTING SUPPORT LADDER		01
30B	0503013356	RIVET POP 3,2 X 10,0		01
31	0531052114	ASSY PORT MANUAL INSTRUCCION	52	01
32	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
33	0503018829	NYLON CLAMP		100
34	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		200
35	0531056312	ASSY FRENCH HAND	53	02
36	0531056065	STABILIZER	55	01
37	0521058345	SAFETY CHAIN WITH SHACKLE		01
37A	0503014120	CHAIN		01
37B	0503014321	CABLE STEEL SHACKLE		02
38	0503063897	CARDAN 21Z 1.3/8 X 21Z 1.3/8 800MM		01
39	0513011183	TERMINAL CARDAN TRIANGULAR 20Z 1.3/4 SERIE 06		01



Item	Code	Description	See page	QT
00	0531057306	RIGHT SIDE FRAME USAP 3200 AP 24E500 SUP ALP ESP S-0522		01
01	0531064575	RIGHT FRAME		01
02	0531055743	RIGHT/LEFT SIDE BRACKET MOUNTED	57	03
03	0531050901	ASSY STABILIZER	59	03
04	0591018043	BODY SUPPORT		02
05	0503010962	5/8" X 1-1/4" BOLT		06
06	0501010453	FLAT WASHER		06
07	0503010027	5/8 SPRING WASHER		07
08	0521059948	ASSY LOCK AXLE	60	01
09	0591018044	WASHER 65 X 130 X 20		01
10	0503012213	1/4" COTTERPIN		01
11	0591018042	FRICTION PLATE		02
12	0591015962	SEPARATOR GLOVE		04
13	0591018045	FRICTION TRACK		02
14	0591019522	SLEEVE WEAR		02
15	0591015374	HITCH AXIS		01
16	0503010232	5/8" X 1.3/4" BOLT		01
17	0511010721	FLAT WASHER		01
18	0501111058	ASSY FIXING GLOVE		02
19	0503011082	C1/2" X 1.3/4" SCREW		06
20	0503011336	1/2" HEX SELF ADJUSTING NUT		06
21	0591018541	SWIVEL CYLINDER COVER		02
22	0501210615	SIDE WHEEL JOINT AXLE		01
23	0503010391	501038 CLAMPING RING (FOR AXLE)		01
24	0531052866	CYLINDER 101,55X618X353	61	01
25	0531055572	RIGHT DOUBLE WHEEL SUPPORT WITH 500/50 TIRE	62	01
26	0531063770	SEED LINE FIXING TUBE/DC 4351/4349		02
27	0531056303	RIGHT SIDE HOPPER 10 MOUTHS	70	01
28	0531062503	LOWER RIGHT SIDE COMPLETE		01
29	0531052853	RIGHT LADDER SET	79	01


FRAME RIGHT SIDE ASSY

0909091799

Item	Code	Description	See page	QT
30	0503013389	5/8" SELF LOCKING NUT		12
31	0591011409	FLAT WASHER 16,5 X 35 X 3,00		12
32	0503010233	5/8" X 2-1/2" BOLT		12
33	0531062505	LARGE SIDE LEFT		01
34	0501218752	LARGER FIXER GLOVE		08
35	0591018936	GLOVE		02
36	0503010002	1800 GREASE FITTING		02
37	0503035468	HOSE PROTECTION		02
38	0531056308	HANDRAIL/PLATFORM ASSY	80	01
39	0521059839	ASSY REAR HEADLIGHT	81	01
40	0531053062	SUPPORT WITH VACUOMETER 18/25 LINES	82	01
41	0503010246	CLAMP		36
42	0503030195	2" X 2" X 12.2" HOSE		18
43	0531056368	FERTILIZER DUCT SIDE SUPPORT	83	01
44	0531064602	TRANSMISSION SUPPORT		02
45	0531056366	TURBINE PRECISION PLANTING	86	01
46	0531056364	24/25 RIGHT HYDRAULIC DUCT ASSEMBLY	88	01
47	0531056365	FULL SIDE AIR DISTRIBUTOR SET	89	01
48	0531061069	FRONT HAND FRENCH AXLE		01
49	0503011052	1.1/4" X 0.77" CASTLE NUT		01
50	0503010038	3/16 X 2 COTTERPIN		01
51	0501017779	32 X 60 X 4.75 FLAT WASHER		01
52	0501211160	TURBINE VALVE LOCK		01
53	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
54	0503010240	BOLT		01
55	0521052549	CLAMP	90	19
56	0503034867	AIR DITRIBUTOR PUMP		01
57	0503011372	102 TO 121 CLAMP		01
58	0531056288	MOTOR BOARD WITH SPACER	91	01
59	1164920015	BLACK SUCTION HOSE		52
60	1164920014	BLACK LIGHT SUCTION HOSE		16
61	1163920004	BLACK LIGHT SUCTION HOSE		04
62	0909091837	COMPLETE FERTILIZER ROW	92	09

ASSY CENTRAL FRAME

0909094815



Item	Code	Description	See page	QT
00	0531057305	CENTER FRAME USAP 3200 AP 24E500 SUP ALP ESP S-0522		01
01	0531064288	CENTRAL FRAME CSC 2500L 18/25 LINES		01
02	0531055744	MOUNTED CENTRAL SUPPORT	130	02
03	0531055349	CENTRAL HOPPER WITH 07 NOZZLES ALPHA/APT/AP	131	01
04	0531064101	SILO CENTRAL SUPPORT		01
05	0531064081	RIGHT CENTRAL SILO SUPPORT		01
06	0531064100	LEFT CENTRAL SILO SUPPORT		01
07	0531055368	ASSY RIGHT ARTICULATION ARM AP	135	01
08	0531055369	ASSY LEFT ARTICULATION ARM AP	136	01
09	0521011100	FLAT WASHER		04
10	0531062245	233 CYLINDER JOINT AXIS		02
11	0503010834	1/2 X 1 BOLT		02
12	0503010019	1/2" SPRING WASHER		06
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0503010246	CLAMP		24
15	0503010027	5/8 SPRING WASHER		06
16	0503010013	5/8 NUT		06
17	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		06
18	0503010023	3/4" SPRING WASHER		02
19	0503010014	3/4" HEX NUT		02
20	0501010098	3/4" UNC BOLT		02
21	0521059839	ASSY REAR HEADLIGHT	81	01
22	0531051599	LED FLASHLIGHT WITH SUPPORT	137	02
23	0503030195	2" X 2" X 12.2" HOSE		12
24	0531051769	MOUNTED DUCT SUPPORT	138	01
25	0503011372	102 TO 121 CLAMP		03
26	0531052063	4 MOUTH CENTRAL AIR DISTRIBUTOR	139	02
27	0521052549	CLAMP	90	14
28	0503034345	AIR DISPENSER COVER		02
29	0531052865	HYDRAULIC CYLINDER 50,80X127X965X534	140	02


ASSY CENTRAL FRAME

0909094815

Item	Code	Description	See page	QT
30	0531054353	CSC SILO ASSEMBLY	141	01
31	0531054350	DEPOSIT MOVEMENT SUPPORT	148	02
32	0531054351	HYDRAULIC CYLINDER 38.10X63.50X225X375	149	01
33	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
34	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
35	0531063645	CENTRAL PLATFORM FOR BOX 28 MOUTH		01
36	0503010589	1/2" UNC SELF ADJUSTING NUT		04
37	0503014378	1/2" X 1-1/2" BOLT		04
38	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
39	0531062945	PLATE WITH DUCT R.7/8 3 WAYS		01
40	0501017065	FLAT WASHER		12
41	0503019522	HEX NUT		12
42	0503019521	SCREW 3/4 UNF 3 CSRP G.8 ZN		12
43	0511015994	FLAT WASHER		02
44	0503018754	1-8 UNC NUT		02
45	0501010276	BOLT		02
46	0531055847	RIGHT TELESCOPIC WHEEL 15	150	01
47	0531055353	LEFT TELESCOPIC WHEEL 15	151	01
48	0531055424	CENTRAL SUPPORT WITH 06 FERTILIZER DUCTS	155	01
49	0531061847	FIXING TUBE SEED/FERTILIZER LINES		02
50	1164920015	BLACK SUCTION HOSE		25
51	1164920014	BLACK LIGHT SUCTION HOSE		10
52	1163920004	BLACK LIGHT SUCTION HOSE		01
53	1164920017	BLUE PVC FLAT HOSE		02
54	0501047895	25 ROD STOP		04
55	0501047885	30 ROD STOP		08
56	0501047886	35 ROD STOP		04
57	0501047887	40 ROD STOP		08
58	0503032624	FERTILIZER HOPPER GUTTER		06
59	0501068994	8,30 X 78 LOCK PIN		04
60	0503030168	HITCH PIN CLIP		04
61	0503011750	AMENDMENT WITH LOCK		06
62	0503011751	REDUCTION		06
63	0503019869	CLAMP		05
64	0503019222	BRACELET TYPE WIRE 3.2MM X 48 X 63 MM		05
65	0501053834	MALE QUICK COUPLER	156	01
66	0503010045	O'RING		01
67	0541010080	TERMINAL R.1 / 2 NPT		01
68	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
69	0581013729	NIPLE 1/2 NPT		01
70	0501214546	SPRING KEY		01
71	0531056410	BEARING PLATE WITH BOLT	157	01
72	0531057754	SUPPORT ASSY DUCTS	158	01
73	0909091837	COMPLETE FERTILIZER ROW	92	06

LEFT SIDE FRAME ASSY

0909094817



Item	Code	Description	See page	QT
00	0531057307	LEFT SIDE FRAME USAP 3200 AP 24E500 SUP ALP ESP S-0522		01
01	0531064574	LEFT FRAME		01
02	0591019522	SLEEVE WEAR		02
03	0591018043	BODY SUPPORT		02
04	0503010962	5/8" X 1-1/4" BOLT		06
05	0501010453	FLAT WASHER		06
06	0503010027	5/8 SPRING WASHER		07
07	0521059948	ASSY LOCK AXLE	60	01
08	0591018044	WASHER 65 X 130 X 20		01
09	0503012213	1/4" COTTERPIN		01
10	0591018042	FRICTION PLATE		02
11	0591015962	SEPARATOR GLOVE		04
12	0531055743	RIGHT/LEFT SIDE BRACKET MOUNTED	57	03
13	0531050901	ASSY STABILIZER	59	03
14	0531062504	SIDE BIGGER RIGHT ASSY		01
15	0503013389	5/8" SELF LOCKING NUT		12
16	0591011409	FLAT WASHER 16,5 X 35 X 3,00		12
17	0503010233	5/8" X 2-1/2" BOLT		12
18	0531062502	ASSY LEFT LOWER SIDE		01
19	0531052854	LEFT STAIRS SET	159	01
20	0591018045	FRICTION TRACK		02
21	0531055573	LEFT DOUBLE WHEEL SUPPORT WITH 500/50 160 TIRE SMALLER		01
22	0591015374	HITCH AXIS		01
23	0503010232	5/8" X 1.3/4" BOLT		01
24	0511010721	FLAT WASHER		01
25	0501218752	LARGER FIXER GLOVE		08
26	0591018936	GLOVE		02
27	0503010002	1800 GREASE FITTING		02
28	0503035468	HOSE PROTECTION		02
29	0501111058	ASSY FIXING GLOVE		02


LEFT SIDE FRAME ASSY

0909094817

Item	Code	Description	See page	QT
30	0503011082	C1/2" X 1.3/4" SCREW		06
31	0503011336	1/2" HEX SELF ADJUSTING NUT		06
32	0591018541	SWIVEL CYLINDER COVER		02
33	0501210615	SIDE WHEEL JOINT AXLE		01
34	0503010391	501038 CLAMPING RING (FOR AXLE)		01
35	0531052866	CYLINDER 101,55X618X353	61	01
36	0531063770	SEED LINE FIXING TUBE/DC 4351/4349		02
37	0531058139	LEFT SIDE HOPPER WITH 10 NOZZLES 175L 161 ALPHA		01
38	0531056308	HANDRAIL/PLATFORM ASSY	80	01
39	0521059839	ASSY REAR HEADLIGHT	81	01
40	0531053062	SUPPORT WITH VACUOMETER 18/25 LINES	82	01
41	0531056368	FERTILIZER DUCT SIDE SUPPORT	83	01
42	0503010246	CLAMP		38
43	0503030195	2" X 2" X 12.2" HOSE		19
44	0531056366	TURBINE PRECISION PLANTING	86	01
45	0531064602	TRANSMISSION SUPPORT		02
46	0531056363	LEFT HYDRAULIC DUCT SET 24/25	163	01
47	0531056365	FULL SIDE AIR DISTRIBUTOR SET	89	01
48	0531061069	FRONT HAND FRENCH AXLE		01
49	0503011052	1.1/4" X 0.77" CASTLE NUT		01
50	0503010038	3/16 X 2 COTTERPIN		01
51	0501017779	32 X 60 X 4.75 FLAT WASHER		01
52	0501211160	TURBINE VALVE LOCK		01
53	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
54	0503010240	BOLT		01
55	0521052549	CLAMP	90	19
56	0503034867	AIR DITRIBUTOR PUMP		01
57	0503011372	102 TO 121 CLAMP		01
58	0531056288	MOTOR BOARD WITH SPACER	91	01
59	1164920014	BLACK LIGHT SUCTION HOSE		16
60	1164920015	BLACK SUCTION HOSE		52
61	1163920004	BLACK LIGHT SUCTION HOSE		04
62	0909091837	COMPLETE FERTILIZER ROW	92	09

DRAWBAR ASSY


0531056309




Item	Code	Description	See page	QT
01	0531056313	REAR DRAWBAR	6	01
02	0531056310	SEMI-ASSEMBLED FRONT HEADING 24/25	8	01
03	0531051725	MAT ASSEMBLY	13	01
04	0531061650	FRONT HAND FRENCH AXLE		02
05	0503011052	1.1/4" X 0.77" CASTLE NUT		02
06	0503010038	3/16 X 2 COTTERPIN		02
07	0501017779	32 X 60 X 4.75 FLAT WASHER		02
08	0531057052	COMPLETE THIRD POINT HEADER	14	01
09	0521058345	SAFETY CHAIN WITH SHACKLE		01
09A	0503014120	CHAIN		01
09B	0503014321	CABLE STEEL SHACKLE		02
10	0531058117	FIXED GUTTER 3180MM COMPLETE	16	01

REAR DRAWBAR


0531056313



Item	Code	Description	See page	QT
01	0531064573	BODY REAR HEADER 24/25		01
02	0591015434	NYLON ADJUSTABLE BACK HEAD		04
03	0591015433	HEADER SUPPORT		04
04	0591015533	ADJUSTMENT SUPPORT		04
05	0503014007	1/2" X 1-1/4" BOLT		24
06	0503010019	1/2" SPRING WASHER		48
07	0503010002	1800 GREASE FITTING		08
08	0501010276	BOLT		12
09	0503010012	1" SPRING WASHER		14
10	0503012182	1" NUT		14
11	0591015435	NYLON ADJUSTMENT REGULATOR GUIDE		04
12	0591015432	HEAD ADJUSTMENT SUPPORT PLATE		04
13	0531052882	SIDE ARM LOCK ASSEMBLY WITH MINOR GLOVE	7	01
14	0591015431	HEADER ADJUSTMENT SUPPORT		04
15	0503011401	1/2" X 3/4" BOLT		24
16	0531062795	PULL ROD 1 UNC 8 FPP X 510		02




Item	Code	Description	See page	QT
01	0591015326	LATERAL FRAME LOCK	02	
02	0531061411	STABILIZER ASSY LOCK ARM	01	
03	0591015327	AXLE JUNCTION	02	
04	0591015328	SPACING GLOVE	04	
05	0591015329	CYLINDER GUIDE AXLE	01	
06	0591015330	WASHER SUPPORT	02	
07	0591015332	AXLE JUNCTION LOCK	03	
08	0503019522	HEX NUT	04	
09	0501010164	3/4" X 7 BOLT	02	
10	0501010322	FLAT WASHER	10	
11	0503010880	501032 CLAMPING RING (FOR AXLE)	05	
12	0531061445	TOP PLATE WITH GLOVE	02	
13	0503010019	1/2" SPRING WASHER	02	
14	0591015341	GLOVE SUPPORT	04	
15	0591015340	WASHER SUPPORT GUIDE AXIS	01	
16	0511016281	3/4" X 8" BOLT	02	
17	0531050017	HYDRAULIC CYLINDER 44,45 X 85,7 X 397 X 93MM	01	
18	0501210625	SUPPORT GLOVE	02	
19	0503013776	BOLT 1/2 UNC X 7/8 C S G.5 ZN	02	




Item	Code	Description	See page	QT
01	0531051649	HEADER LARGEST PULLEY		01
01A	0591018923	LARGER BODY HEADER PULLEY		01
01B	0551014862	NYLON PULLEY		02
02	0551014871	FLAT WASHER		06
03	0503010002	1800 GREASE FITTING		06
04	0591018925	AXLE BIGGER PULLEY		01
05	0503011105	SEAL RING		03
06	0591015449	AXLE LOCK HEADER		01
07	0503018754	1-8 UNC NUT		02
08	0591015450	LOCK BODY GLOVE		02
09	0591018926	BODY LOCK BIGGER		02
10	0501010888	1.3/4" 2.5/16" CASTLE NUT		01
11	0591015452	BODY AXLE LOCK		01
12	0591015453	BACK WASHER		02
13	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
14	0511054270	TENSIONER SPRING		01
14A	0511069520	TELESC LOCK SPRING TENSIONER		01
14B	0503010013	5/8 NUT		02
15	0591015454	SPRING HITCH LOCK		01
16	0591015456	CYLINDER GUIDE AXLE		01
17	0521011132	FLAT WASHER		02
18	0503010131	3/16" X 1-1/2" COTTERPIN		02
19	0503011052	1.1/4" X 0.77" CASTLE NUT		03
20	0503010038	3/16 X 2 COTTERPIN		03
21	0531060746	AXIS 278 TELESCOPIC HEADER		03
22	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		01
23	0521057739	HYDRAULIC CYLINDER 38,10 X 63,50 X 397 X 126	9	01
24	0591015457	CYLINDER GUIDE AXLE		01
25	0591018924	WHEEL BIGGEST SHAFT HEADER SIDE		02
26	0591018921	WASHER 63.5 X 39 X 6.30		04
27	0531051648	INTERNAL HEAD PULLEY		02


Item	Code	Description	See page	QT
27A	0591018922	INTERNAL PULLEY BODY HEAD		01
27B	0551014862	NYLON PULLEY		02
28	0501012140	FLAT WASHER		02
29	0503010027	5/8 SPRING WASHER		03
30	0503010962	5/8" X 1-1/4" BOLT		02
31	0531064571	TELESCOPIC HEADER 24/25		01
32	0501210174	SPRING SUPPORT		01
33	0503010233	5/8" X 2-1/2" BOLT		01
34	0501011299	FLAT WASHER		01
35	0503010013	5/8 NUT		01
36	0531054742	PANTOGRAPHIC HEADING FOR THIRD POINT	10	01
37	0531060748	REST SUPPORT		01
38	0521059886	SEMI-ASSEMBLED REST	12	01




Item	Code	Description	See page	QT
01	0531060718	CASE 63,50 X 285MM		01
02	0531060719	GUIA CILINDRO		01
03	0591013120	BODY STEM 38.10 X 280		01
04	0502012837	PISTON		01
05	0581010668	RING SUPPORT		01
06	0502010471	63,50 MOBILE CAP		01
07	0503018005	RING		01
08	0503011109	2-119 N 3006-9B O'RING		01
09	0503018004	RING		01
10	0503018003	GASKET		01
11	0503010163	D-1500 SCRAPER RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503030385	CYLINDER PLUG N-002		02



Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		03
02	0531060746	AXIS 278 TELESCOPIC HEADER		02
03	0531060792	AXIS 200 TELESCOPIC HEADER		01
04	0531060776	HYDRAULIC HOSE SUPPORT FIXER		01
05	0503011052	1.1/4" X 0.77" CASTLE NUT		02
06	0503010038	3/16 X 2 COTTERPIN		03
07	0531040499	HYDRAULIC CYLINDER 50.8 X 127 X 682 X 285	11	01
08	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		02
09	0531063225	LOWER ARM PANTOGRAPHIC HEAD		01
10	0531063226	UPPER ARM PANTOGRAPHIC HEAD		01
11	0531063829	SUPPORT WITH EAR PANTOGRAPHIC HEAD		01
12	0503010012	1" SPRING WASHER		06
13	0503012182	1" NUT		06
14	0501010276	BOLT		06
15	0531063828	HEAD HITCH		01




Item	Code	Description	See page	QT
01	0531061425	PANTOGRAPHIC HEAD CYLINDER CASE		01
02	0531061424	PANTOGRAPHIC HEAD CYLINDER ROD		01
03	0503010817	1.1/4" SELF LOCKING NUT		01
04	0503010345	2-218 N 3006-9B O'RING		01
05	0502010382	5" END CAP		01
06	0581010353	RING SUPPORT		01
07	0503018026	1870-2000-375 B GASKET		01
08	0503011453	O'RING		02
09	0503018152	O'RING		02
10	0503018024	RING BS		01
11	0503018025	RING GUIDE		01
12	0581010354	PISTON		01
13	0503018150	RING GUIDE		01
14	0503018151	RING BS		02
15	0503010039	D-2000 SCRAPER RING		01
16	0503030385	CYLINDER PLUG N-002		02



Item	Code	Description	See page	QT
01	0503010571	1/4" X 1.1/2 COTTERPIN		02
02	0521010784	COUPLING SHAFT		01
03	0531060758	AXLE JUNCTION 25.4 X 150 WITH HANDLE		01
04	0503030085	LOCK PIN		02
05	0531060667	REST		01
06	0521010580	COUPLING SHAFT		01
07	0521012533	COUPLING SHAFT		01
08	0591016111	TUBE 80 X 80 X 9,52 X 600MM		01
09	0531061640	REST		01

MAT ASSEMBLY


0531051725




Item	Code	Description	See page	QT
01	0531062501	REAR GUTTER	01	
02	0531062500	FRONT GUTTER	01	
03	0591018018	ARTICULATOR AXIS	02	
04	0591018019	ARTICULATOR AXIS	01	
05	0503014007	1/2" X 1-1/4" BOLT	06	
06	0503010019	1/2" SPRING WASHER	10	
07	0501013519	FLAT WASHER	10	
08	0591018531	GUTTER LOCK	04	
09	0511017303	FLAT WASHER	08	
10	0503010143	1/4" SPRING WASHER	08	
11	0503010144	1/4" NUT	08	
12	0503013849	1/4" UNC X 3/4" BOLT	08	
13	0531062509	GUTTER SUPPORT	01	
14	0591019035	RIGHT/LEFT GUTTER SUPPORT	02	
15	0503010060	1/2 UNC G.5 ZN HEX NUT	04	
16	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT	04	
17	0503035468	HOSE PROTECTION	02	

COMPLETE THIRD POINT HEADER


0531057052




Item	Code	Description	See page	QT
01	0501217466	TRACTION BAR GUIDE		02
02	0501010276	BOLT		04
03	0503010012	1" SPRING WASHER		04
04	0501010059	1.5/8 NUT		04
05	0503030119	LOCK PIN		01
06	0511069471	PLOUGH SUPPORT		02
07	0501011075	PIN		02
08	0503030285	HITCH PIN CLIP		02
09	0531065020	THIRD POINT HEADING		01
10	0503030085	LOCK PIN		08
11	0521068018	UPPER AXLE		01
12	0521068015	UPPER AXLE		01
13	0521068013	UPPER AXLE		01
14	0503012809	2" CASTLE NUT		01
15	0503010833	10 X 90 SPRING PIN		01
16	0501213695	EJE 1.1/4 X 380 MM		02
17	0531063869	AXLE 50 X 245 MM WITH THREAD 2 UNS 10 FPP		01
18	0521068011	AXLE LOWER		02
19	0531057067	FULL HEAD HOSE STABILIZER	15	01
20	0501217367	LEFT SUPPORT BOX		01
21	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
22	0503010589	1/2" UNC SELF ADJUSTING NUT		04
23	0501217366	RIGHT BOX SUPPORT		01
24	0503019293	SCREW 1/2 UNC X 2 COVER G7 ZN		04
25	0501217467	3 POINT CAB FIXING GUIDE GLOVE		04
26	0531057145	COMPLETE SAFETY LOCK AXIS		01
26A	0531064617	LOCK AXLE COUPLING		01
26B	0501217474	FLAT WASHER 38.50 X 70 X 6.30		02
26C	0513010701	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531065026	HEAD HOSE STABILIZER		01
02	0531061935	CONDUCTOR ARTICULATOR		02
03	0503010237	3/8" X 1" BOLT		03
04	0503010025	3/8 SPRING WASHER		03
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		03
06	0503010019	1/2" SPRING WASHER		03
07	0503012556	1/2" X 1" BOLT		03
08	0531061934	CONDUCTOR ARTICULATOR GUIDE		03
09	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
10	0503010589	1/2" UNC SELF ADJUSTING NUT		02
11	0531065130	HYDRAULIC HOSE ARTICULATOR		01




Item	Code	Description	See page	QT
01	0501218633	FIXED GUTTER 3180MM		01
02	0501218635	LARGER FIXING GUTTER FIXED		01
03	0501218636	FIXED CHUTE SUPPORT		01
04	0501218634	LOCK FIXED CHUTE		03
05	0503014007	1/2" X 1-1/4" BOLT		06
06	0503010019	1/2" SPRING WASHER		10
07	0503010060	1/2 UNC G.5 ZN HEX NUT		10
08	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
09	0511017303	FLAT WASHER		06
10	0503010144	1/4" NUT		06
11	0503013849	1/4" UNC X 3/4" BOLT		06
12	0503010143	1/4" SPRING WASHER		06



Item	Code	Description	See page	QT
01	0501210018	GUTTER 6S 50 X 50 X 2700		01
02	0591018623	5S GUTTER 50 X 50 X 2200		02
03	0591018564	GUTTER 3S 50 X 50 X 1700		02
04	0531051342	RAIL SUPPORT WITH FIXER	18	11




Item	Code	Description	See page	QT
01	0591018525	GUTTER SUPPORT		01
02	0503011828	FLAT WASHER		02
03	0503010060	1/2 UNC G.5 ZN HEX NUT		02
04	0503010019	1/2" SPRING WASHER		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
06	0501011643	3/8 X 1"BOLT		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0501214554	TOWER WHEEL LIFT ACTUATOR		01
02	0501214553	LIFTING ACTUATOR SUPPORT		01
03	0501214555	LIFT SENSOR SUPPORT		01
04	0503013356	RIVET POP 3,2 X 10,0		01
05	0503015321	3/8 UNC X 5/8 C S G.2 ZN BOLT		02
06	0503010025	3/8 SPRING WASHER		06
07	0531062331	SIDE CHASSI DUCT		04
08	0501011517	FLAT WASHER		04
09	0503010026	3/8" NUT		04
10	1902010477	UPPER CLAMP BODY		04
11	0531011180	UPPER BODY CLIP		04
12	0501010096	3/8" X 2" BOLT		04
13	0531057546	HOSE ASSY 3C/14L		01
13A	0501081294	1/2 X 1000 TC-TC HOSE		04
13B	0501080270	HOSE 1/2 X 2200 TC-TC		01
13C	0501081041	1/2 X 2400 TR-TC HOSE		01
14	0503010144	1/4" NUT		02
15	0503010143	1/4" SPRING WASHER		02
16	0503013849	1/4" UNC X 3/4" BOLT		02
17	0591012160	7 X 23 X 2.00 ZN FLAT WASHER		02
18	0531051558	SIDE BODY BEARING APT	20	03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
20	0503010019	1/2" SPRING WASHER		09
21	0503010060	1/2 UNC G.5 ZN HEX NUT		09
22	0561013049	CHAIN TIGHTENER AXLE		03
23	0503010302	501019 SEAL RING		03
24	0503030402	PULLEY		03
25	0503062754	GEAR 34Z P.1/2 APT		03
26	0521069832	15Z GEAR		03
27	0501212318	GLOVE ENCODER		03
28	0503011807	SCREW M8 X 1,25X10		02

Item	Code	Description	See page	QT
29	0503015162	M 8 X 1,25 X 20 BOLT		03
30	0503018827	CHAIN 40-1 X 57		03
31	0531056290	RIGHT CHAIN COVER WITH SCREW	21	02
32	0503063382	CENTRAL ENCAPSULATED CHAIN		01
33	0503030303	SUPPORT WASHER		09
34	0501013518	FLAT WASHER		03
35	0503010237	3/8" X 1" BOLT		03
36	0511017406	FLAT WASHER Q20 X 33 X 3.00		03
37	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		06
38	0503063431	RIGHT/LEFT SIDE ENCAPSULATED CHAIN		02
39	0531056289	LEFT CHAIN COVER WITH SCREW	22	01
40	0531055917	ASSY PDM	23	01




Item	Code	Description	See page	QT
01	0591018034	SHAFT BEARING GUIDE HITCH		01
02	0503010845	501035 CLAMPING RING (FOR AXLE)		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		01
04	0591018780	SIDE TRANSMISSION SHAFT		01
05	0503010849	3/8" X 1-1/2" BOLT		04
06	0503013357	3/8 SELF-ADJUSTING NUT		04
07	0503016061	BEARING		02




Item	Code	Description	See page	QT
01	0501215716	RIGHT CHAIN COVER		01
02	0503019412	RIVET SCREW INTERNAL		02
03	0501212320	ENCODER LOCK SCREW		01
04	0503019901	INTERNAL THREAD RIVET RM 1/4 P30S		01
05	0503013849	1/4" UNC X 3/4" BOLT		02
06	0503010143	1/4" SPRING WASHER		02
07	0503010305	FLAT WASHER		02

LEFT CHAIN COVER WITH SCREW


0531056289




Item	Code	Description	See page	QT
01	0501215715	LEFT CHAIN COVER		01
02	0503019412	RIVET SCREW INTERNAL		02
03	0501212320	ENCODER LOCK SCREW		01
04	0503019901	INTERNAL THREAD RIVET RM 1/4 P30S		01
05	0503013849	1/4" UNC X 3/4" BOLT		02
06	0503010143	1/4" SPRING WASHER		02
07	0503010305	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0501215221	SUPPORT BODY PDM		01
02	0503011776	M6 SELF ADJUSTINGNUT		04
03	0571019756	FASTENER 1/2 UNC X 220 X 198 ZN		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0531057718	SUPPORT WITH BLOCK	25	01
02	0531057762	GEARBOX WITH DOUBLE PUMP JIC/TME	26	01
03	0531057719	SUPPORT WITH RADIATOR/TANK SUP/JIC/18E25	29	01
04	0521059419	CASAPPA DOUBLE DIVIDER BRP00102 WITH NIPLES	34	01




Item	Code	Description	See page	QT
01	0531065334	SUPPORT HYDRAULIC BLOCKS		01
02	0531057090	CYLINDER DRIVE CONTROL BLOCK JIC		01
03	0531057089	LIFT DRIVE BLOCK JIC		01
04	0531057709	HYDRAULIC ROTATING DIVIDER WITH SUPPORT Q JIC		01
05	0531057697	HYDRAULIC CONTROL BLOCK SHT 2A JIC		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04
07	0503010019	1/2" SPRING WASHER		04
08	0501010155	1/2" X 1" BOLT		04
09	0503010025	3/8 SPRING WASHER		12
10	0503015112	M10 X 1,5 X 30 BOLT		12
11	0501013518	FLAT WASHER		12
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
13	0503013357	3/8 SELF-ADJUSTING NUT		04
14	0503010849	3/8" X 1-1/2" BOLT		04




Item	Code	Description	See page	QT
01	0513010710	MULTIPLIER BOX		01
02	0531057196	AXIAL PISTON PUMP 63CC - H JIC	27	01
03	0501217531	REDUCTION BOX FLANGE		02
04	0503015140	M12 X 1,75 X 30 BOLT		08
05	0503015076	M12 SPRING WASHER		08
06	0521014188	FLAT WASHER		08
07	0513011013	BOLT ALLEN M14 X 2 X 25MM CCSI		08
08	0503014007	1/2" X 1-1/4" BOLT		04
09	0503011828	FLAT WASHER		04
10	0503010019	1/2" SPRING WASHER		04
11	0531057763	HYDRAULIC PUMP ENGRE 11CC - BD JIC	28	01
12	0513010995	EXTERNAL GROOVED GLOVE 1.1/4 - Z14 X INTERNAL 7/8 Z13 X 42MM		01
13	0503010880	501032 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0513010724	AXIAL PISTON HYDRAULIC PUMP 63CC - H		01
02	0503063943	ADAPTER TERMINAL 7/16 UNF ORING X 7/16 UNF - JIC		01
03	0503063950	ADAPTER TERMINAL 7/8 UNF ORING X 7/8 UNF - JIC		01
04	0503063940	ADAPTER TERMINAL 1.5/16 UNF ORING X 1.5/16 UNF - JIC		01
05	0503063942	ADAPTER TERMINAL 1.7/8 UNF ORING X 2.1/2 UNF - JIC		01
06	0503018033	37 X R.7/8 UNF 90° JIC MALE CONNECTOR WITH ROTATING NUT		01




Item	Code	Description	See page	QT
01	0513011033	HYDRAULIC PUMP ENGRE 11CC - BD		01
02	0503063950	ADAPTER TERMINAL 7/8 UNF ORING X 7/8 UNF - JIC		01
03	0503063967	ADAPTER TERMINAL 7/8 UNF ORING X 1.1/16 UNF - JIC		01



Item	Code	Description	See page	QT
01	0531057358	COMPLETE TANK 180L JIC/AP	30	01
02	0501218213	LEFT SUPPORT LARGEST OIL RESERVOIR 180L		01
03	0501218212	RIGHT SUPPORT LARGEST OIL RESERVOIR 180L		01
04	0531057695	SUPPORT RADIATOR SET	31	01
05	0531057707	COMMAND BLOCK	32	01
06	0501010125	3/4" X 2-1/2" BOLT		08
07	0503011075	3/4" UNC NUT		08
08	0501010322	FLAT WASHER		08
09	0503010019	1/2" SPRING WASHER		08
10	0503011828	FLAT WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		08
12	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		08
13	0531059117	FULL HEAD HOSE STABILIZER	33	01
14	3402301204	OIL HYDRAULIC		220 Lts




Item	Code	Description	See page	QT
01	0503063771	180 LITER TANK		01
02	0503015406	SUCTION FILTER		01
03	0513010698	RETURN FILTER IN TANK 310 LITERS		01
04	0513011030	FILLING NOZZLE WITH AIR FILTER AND PRESSURIZATION		01
05	0503063547	VISOR LEVEL		01
06	0513010029	BALL VALVE 2 NPT 11.5 FPP		01
07	0503063970	THREADED PLUG 1.5/16 UNF		01
08	0503063968	THREADED PLUG 3/4 UNF		01
09	0503063957	ADAPTER TERMINAL 2 NPT X 2.1/2 UNF - JIC		01
10	0503063954	ADAPTER TERMINAL 3/4 UNF ORING X 7/8 UNF - JIC		02
11	0503063946	ADAPTER TERMINAL 1.1/2 BSP ORING X 1.5/8 UNF - JIC		01
12	0503063773	SUPPLY NOZZLE		01
13	0513010344	SHOCK ABSORBER/VIBRATION CUSHION N3 - R.M12		04
14	0501217469	CAP 1.1/4 BSP - 11FPP		01
15	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
16	0571011721	FLAT WASHER 40 X 13.50 X 3.00		08
17	0503015076	M12 SPRING WASHER		08
18	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		03
19	0503010025	3/8 SPRING WASHER		03
20	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
21	3402301204	OIL HYDRAULIC		200Lts




Item	Code	Description	See page	QT
01	0501010694	FLAT WASHER	04	
02	0501013518	FLAT WASHER	16	
03	0503010025	3/8 SPRING WASHER	10	
04	0503010179	LOCK WASHER 5/16 ZN 1K01528	04	
05	0503019952	RUBBER BUSHING 14 X 40 X 40	06	
06	0503011268	3/8" X 2-1/2" BOLT	06	
07	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN	04	
08	0503010026	3/8" NUT	10	
09	0571016789	PRISONER 3/8 UNC X 5/16 UNC X 65	04	
10	0501218150	HEAT EXCHANGER SUPPORT	01	
11	0591012708	CANVAS RADIATOR PROTECTION	01	
12	0531057694	COMPLETE HEAT EXCHANGER	01	
12A	0503063086	HEAT EXCHANGER	01	
12B	0503063949	ADAPTER TERMINAL 1 BSP ORING X 1.5/16 UNF - JIC	01	
12C	0503063944	ADAPTER TERMINAL 1 BSP ORING X 1.5/8 UNF - JIC	01	

COMMAND BLOCK


0531057707




Item	Code	Description	See page	QT
01	0513010676	COMMAND BLOCK		01
02	0501010694	FLAT WASHER		02
03	0503014371	M8 SPRING WASHER		02
04	0503015114	BOLT		02
05	0503063950	ADAPTER TERMINAL 7/8 UNF ORING X 7/8 UNF - JIC		03
06	0503063967	ADAPTER TERMINAL 7/8 UNF ORING X 1.1/16 UNF - JIC		01




Item	Code	Description	See page	QT
01	0531061934	CONDUCTOR ARTICULATOR GUIDE		01
02	0531061935	CONDUCTOR ARTICULATOR		01
03	0503010237	3/8" X 1" BOLT		01
04	0503010025	3/8 SPRING WASHER		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503012556	1/2" X 1" BOLT		01




Item	Code	Description	See page	QT
01	0503019810	CASAPPA DOUBLE ROTATING DIVIDER BRP00102		01
02	0571013917	7/8"NF X 1.1/16 UNF NIPPLE		01
03	0503011109	2-119 N 3006-9B O'RING		01
04	0511010111	7/8" NIPPLE		02
05	0503010045	O'RING		02
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
07	0503013357	3/8 SELF-ADJUSTING NUT		04
08	0503010237	3/8" X 1" BOLT		04




Item	Code	Description	See page	QT
01	0531057126	KIT CABIN SEEDSENSE GEN3		01
01A	0503063047	MONITOR KIT		01
01B	0503019536	MODULE		01
01C	0503063204	KIT BASE		01
01D	0503019759	WHIP		01
01E	0503017972	TRACTOR BATTERY WHIP		01
01F	0503017973	ENERGY DISTRIBUTOR MODULE		01
01G	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
01H	0503016234	TRIMBLE FIXING WINDOW		01
01I	0503018653	ADAPTER WHIP		01
01J	0503018097	WHIP BATTERY		01
01K	0503019424	WHIP JD STARFIRE GPS		01
02	0503062456	TRACTOR CONNECTION ASSEMBLY 729414 - 13,7MTS		01
03	0503017991	MAIN HARNESS SRM - 6 LINES 45/55 729466		01
04	0503018062	MAIN WHIP		02
05	0503018085	APEX EXTENSION CABLE		02
06	0503017996	EXTENSION CABLE APEX 729151 - 4,50MTS		01
07	0503018080	EXTENSION CABLE		02
08	0503018081	CAN EXTENSION CABLE SRM		02
09	0513010031	EXTERNAL LIFTING CABLE PSS-X1005B CAN-5M		01
10	0503062431	ELECTRIC MOTOR		24
11	0503019776	SEED TUBE WITH WAVE VISION SENSOR		24
12	0503019755	UNIT MODULE		24
13	0503017975	WHIP		24
14	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		**
15	0503019291	SUPPORT SENSOR		01
16	0513010275	PP725905 VACUUM SENSOR		03
17	0503018076	EXTENSION CABLE SRM - 0.60MTS 729255		24




Item	Code	Description	See page	QT
01	0513010493	EXTENSION CAN 6 PINS 9M 729203		03
02	0513010458	VAPPLY MODULE 724280		03
03	0513010459	HYDRAULIC ENGINE WHIP 724287		03
04	0513010460	WHIP Y 06 PINS 729508		03
05	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	37	03
06	0503019761	CAN TERMINATOR 4 PINS 729938		01
07	0511056972	FILTER HYDAC	38	01




Item	Code	Description	See page	QT
01	0503018768	MOTOR OMP 80		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02




Item	Code	Description	See page	QT
01	0503016376	FILTER SPRING		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	T 7/8" ADAPOR GIRAT NUT		01
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0513010813	PANEL CTRL BLOCO USAP 3200 AP SUP SHT BCE 5375.1		01
02	0513010994	LIGHTHOUSE HARNESS LED LANTERN 12 METERS BCE 5403.1		01
03	0513010975	LIGHTHOUSE EXTENSION 3 HOLES ECB 5381.9		02
04	0503019926	BLOCK WHIP WITH ECB 4555.9		01
05	0503019291	SUPPORT SENSOR		03
06	0501217647	SHT PANEL FIXING PLATE		01
07	0503016234	TRIMBLE FIXING WINDOW		01
08	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
09	0503018829	NYLON CLAMP		20
10	0503019902	NYLON CLAMP 7,8X1,8X225 MM		80
11	0503019924	BLOCK WHIP WITH ECB TREAT 4554.2		01
12	0513011205	HEAT EXCHANGER SWITCH PANEL		01
13	0513011204	TRACTOR POWER SWITCH CABLE 5463.5		01
14	0503019307	CABLE TRACTOR HEADLIGHT		01
15	0503062594	IMPLEMENT SWITCH CABLE (EXTENSION)		01
16	0503019305	WHIP		01
17	0513010191	BOLT		03




Item	Code	Description	See page	QT
01	0531058197	HOSE ASSY LATCHES 24/25E500	41	01
02	0531058199	HOSE SET HEADER 24/25E500	42	01
03	0531058205	CONTROL VALVE CONNECTION HOSES 24/25E500	43	01
04	0531058210	TURBINE HOSE SET 24/25E500	44	01
05	0531058170	WHEEL SUPPORT HOSE SET 24/25E500	45	01
06	0531058169	HOSE SET ROWS 24/25E500	46	01
07	0531058194	LIFT HOSE SET 24/25E500	47	01
08	0531058171	HOSE SET OPENS/CLOSES 4/25E500	48	01
09	0531058195	HOSE SET ARTICULATION CSC 24/25E500	49	01
10	0531058967	HOSE SET APT 24/25E500 VDRIVE	50	01




Item	Code	Description	See page	QT
01	0501082643	HOSE 3/8 X 9000 TR-TC		02
02	0501081797	HOSE ASSY 3/8 X 4550 TR-TC		01
03	0501081809	3/8" X 187" TR-TC HOSE		01




Item	Code	Description	See page	QT
01	0501082577	HOSE 3/8 X 8200 TR-TC		01
02	0501082491	HOSE 3/8 X 8700 TR-TC		01




Item	Code	Description	See page	QT
01	0501080825	1/2" X 1100 TR-TC HOSE		02
02	0501082830	HOSE 1/2 X 3500 TR-TC WITH HELICAL SPRING		01
03	0501082678	HOSE 1 X 1100 TR-TC 45° 2T		01
04	0501082765	HOSE 1 X 1100 TR-TC 2T		01
05	0501082647	HOSE 1 X 9000 TR-TC 2T - WITH HELICAL SPRING		01
06	0501082646	HOSE 1 X 8400 TR-TC 1T		01
07	0501082648	HOSE 1.1/4 X 1800 TR-TC		01
08	0501082649	HOSE 1/4 X 9100 TC-TC - WITH HELICAL SPRING		01
09	0501082852	HOSE 2 X 1300 TR-TC - WITH HELICAL SPRING WITH CLAMP		01




Item	Code	Description	See page	QT
01	0501080016	1/2 X 2800 TR-TC HOSE		04
02	0501081407	1/2 X 3100 TR-TC HOSE		02
03	0501080447	3/8" X 122" TR-TC HOSE ASSY		01
04	0501080621	1/2 X 1200 TC-TC HOSE		01
05	0501080625	1/2" X 1500 TC-TC HOSE		01
06	0501080039	1/2 X 1350 TR-TR HOSE ASSY		02
07	0501080479	TC-TC HOSE ASSY		02
08	0501080058	HOSE 1/2 X 1400 TR-TC		02
09	0501081519	7500 TR-TC HOSE		01




Item	Code	Description	See page	QT
01	0501080414	3/8" X 110.2" TR-TC HOSE ASSY		04
02	0501080328	3/8" X 29" TR-TC HOSE		02
03	0501080055	3/8 X 1000 TR-TC HOSE		02
04	0501081975	3/8 X 1450 TR-TC HOSE		02




Item	Code	Description	See page	QT
01	0501080485	3/8 X 1100 TR-TC HOSE		04
02	0501080436	3/8" X 62" TR-TC HOSE		04
03	0501080348	3/8 X 1200 TR-TC HOSE		04
04	0501080396	3/8" X 45" HOSE		02
05	0501080450	3/8" X 86" TR-TC HOSE		02
06	0501080092	1/2 X 700 TR-TC HOSE		01
07	0501080515	3/8" X 133" TR-TC HOSE		01
08	0501080720	HOSE 3/8 X 3500 TR-TC		01
09	0501080414	3/8" X 110.2" TR-TC HOSE ASSY		02
10	0501080419	3/8 X 2100 TR-TC HOSE		01




Item	Code	Description	See page	QT
01	0501080403	3/8" X 137" TR-TR HOSE ASSY		04
02	0501080451	3/8" X 94.5" TR-TC HOSE ASSY		02
03	0501080450	3/8" X 86" TR-TC HOSE		02
04	0501080439	3/8" X 43" TR-TR HOSE		02
05	0501081975	3/8 X 1450 TR-TC HOSE		02
06	0501082672	HOSE 3/8 X 280 TC-TC		04




Item	Code	Description	See page	QT
01	0501080124	HOSE 3/8 X 900 TR-TC		02
02	0501080348	3/8 X 1200 TR-TC HOSE		02
03	0501080419	3/8 X 2100 TR-TC HOSE		01
04	0501080267	HOSE 1/2 X 2100 TR-TC		01




Item	Code	Description	See page	QT
01	0501080249	3/8 X 850 TR-TC HOSE		01
02	0501080396	3/8" X 45" HOSE		01




Item	Code	Description	See page	QT
01	0501081294	1/2 X 1000 TC-TC HOSE		04
02	0501081041	1/2 X 2400 TR-TC HOSE		01
03	0501080016	1/2 X 2800 TR-TC HOSE		01
04	0501080281	HOSE 1/2 X 2600 TR-TC		01
05	0501080273	1/2 X 2700 HOSE TC-TC		01
06	0501081019	HOSE 3/4 X 2800 TR-TR		01
07	0501082442	HOSE 1/2 X 10000 TR-TR		02




Item	Code	Description	See page	QT
01	0503035133	ADHESIVE LABEL USAP 3200 (192 X 437)		08
02	0503034782	LABEL ADHESIVE LOGO SMALLER TATU (03 MOUTHS)		08
03	0503035135	ADHESIVE LABEL USAP 3200 (185 X 320)		04
04	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		04
05	0503035134	ADHESIVE LABEL USAP 3200 (190 X 613)		02
06	0503034983	LOGO TATU MARCHESAN ADHESIVE LABEL 190 X 613		08
07	0503035136	ADHESIVE LABEL USAP 3200 (170 X 820)		03
08	0503035137	ADHESIVE LABEL USAP 3200 (165 X 850)		03
09	0503034970	LOGO TATU MARCHESAN (CSC) 155 X 1120		03
10	0503034971	ADHESIVE LABEL LOGO TATU MARCHESAN (CSC) 150 X 1130		03
11	0503034338	ADHESIVE LABEL		02
12	0503035445	ADHESIVE LABEL LEVER BLUE HANDLE		01
13	0503035443	ADHESIVE LABEL LEVER RED HANDLE		01
14	0503035442	ADHESIVE LABEL FLOATING LEVER		01
15	0503033416	ADHESIVE LABEL		02
16	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
17	0503031565	ADHESIVE LABEL CARE		02
18	0503031428	READ MANUAL DECAL		01
19	0503031425	ADHESIVE LABEL ATTENTION		02
20	0503034078	LIFTING POINTS DECAL		02
21	0503031087	ADHESIVE LABEL		01
22	0503035316	LUBRICATED POINTS ADHESIVE LABEL		04
23	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
24	0503034249	ADHESIVE LABEL TABLE PLANTS		02
25	0503035494	ADHESIVE LABEL LEVER BLACK HANDLE		01
26	0503033981	ADHESIVE LABEL		03




Item	Code	Description	See page	QT
01	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
02	0503010267	NYLON CLAMP		01
03	0503010337	5/16" NUT		01
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
05	0503060100	INSTRUCTIONS MANUAL CANISTER		01
06	0511034152	BAG WITH INSTRUCTION MANUAL		01




Item	Code	Description	See page	QT
01	0521057793	KNEECAP WITH RIGHT EXTENSION AXLE	54	01
02	0531061434	SIDE EXTENSOR EAR		01
03	0571019949	JUNCTION SHAFT		01
04	0503030119	LOCK PIN		01
05	0531064572	FRENCH HAND 24/25		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521062617	NUT FIXER		01
02	0531060778	EXTENSION AXLE 466 WITH DRAG		01
03	0561019879	LOCK ATTACHMENT BAR		01
04	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0531053738	STABILIZER EXTENDER	56	01
02	0531064461	PROLONGER		02
03	0501015348	1-1/4" X 3-3/4" BOLT		02
04	0503010070	SPRING WASHER		02
05	0503013026	1.1/4" CASTLE NUT		02




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0531063229	LABEL WITH LEFT EXTENDER		01
03	0531063230	LABEL WITH RIGHT EXTENDER		01
04	0501211865	LABEL FIXER		02
05	0503011052	1.1/4" X 0.77" CASTLE NUT		02
06	0501061056	RH LOCKNUT WITH HANDLER		01
07	0503010002	1800 GREASE FITTING		02
08	0503010571	1/4" X 1.1/2 COTTERPIN		02




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		02
02	0503017857	BOLT 5/8 UNF 4		08
03	0503010811	5/8" UNF SELF ADJUSTING NUT		08
04	0531050903	SIDE ARTICULATED CYLINDER 58 44.45X85.70X291X657		01
05	0591017796	ARTICULATION AXIS 222 R.1.1 / 4 UNF		01
06	0531064321	UNIVERSAL SUPPORT		01
07	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
07A	0531061418	FIXING FLANGE HYDRAULIC CYLINDER WITHOUT LUBRICATION		01
07B	0503019408	IGLIDUR GSM-4550-30 AUTO LUBRICANT GLOVE		01
08	0503010019	1/2" SPRING WASHER		04
09	0501111070	SIDE SUPPORT ARTICULATOR		01
09A	0531062135	SIDE ARTICULATOR		01
09B	0503019375	AUTO LUBRICANT GLOVE IGLIDUR GFM-4044-50		02
10	0503011075	3/4" UNC NUT		06
11	0501010125	3/4" X 2-1/2" BOLT		06
12	0591013172	31.75 X126 AXLE WITH 8 HOLE		02
13	0591013173	CYLINDER INTERMEDIATE BUSHING		01
14	0503012231	1/4" X 3" COTTERPIN		02
15	0501011544	3/4" X 1-1/2" BOLT		01
16	0503010023	3/4" SPRING WASHER		01
17	0591018408	PIN LOCK LINES		01
18	0503030085	LOCK PIN		01
19	0591019305	FLAT WASHER 20 X 60 X 4.75 WITH CUT OUT		01
20	0501211496	GLOVE 16 X 25 X 27 WITH HOLE		01
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
22	0503010060	1/2 UNC G.5 ZN HEX NUT		04
23	0501010942	3/8" X 1-1/4" BOLT		02
24	0503013357	3/8 SELF-ADJUSTING NUT		02
25	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0531062138	CASE 85,7 X 486 WITH COVER		01
02	0503010761	D-1750 SCRAPER RING		01
03	0571019711	RING SUPPORT		01
04	0571019709	DETACHABLE COVER		01
05	0503017936	RING		01
06	0503017938	RING GUIDE		01
07	0503017937	GASKET		01
08	0503017940	8-337 BACK-UP RING		02
09	0503017939	2-337 N 3006-9B O' RING		02
10	0503018045	2-130 (AGEL) O'RING		04
11	0511064408	FORK		01
12	0503010025	3/8 SPRING WASHER		01
13	0503011094	3/8" X 2" BOLT		01
14	0503010026	3/8" NUT		01
15	0503010042	2-214 N 3006-9B O'RING		01
16	0503010063	1" SELF-ALIGNING NUT		01
17	0571019710	1.7" X 3.4" PISTON		01
18	0503017935	RING		01
19	0503018144	RING		01
20	0591017818	EXTENSOR 44,45 X 550		01




Item	Code	Description	See page	QT
01	0502011195	ADJUSTMENT NUT BODY		01
02	0503010002	1800 GREASE FITTING		02
03	0551013654	SPINDLE R.1.1 / 4 X R.1.1 / 2 RIGHT X 165		01
04	0502040747	32.54 CLEVIS CLAMP		01
05	0551013653	SPINDLE R.1.1 / 4 X LEFT X.1.1 / 2 X 165		01
06	0503011094	3/8" X 2" BOLT		01
07	0503010026	3/8" NUT		01
08	0503011443	3/8" SPRING WASHER		01
09	0501061056	RH LOCKNUT WITH HANDLER		01
10	0531062137	SIDE FERTILIZER BOX EXTENSOR		01
11	0521010779	31.75 X 95 COUPLING SHAFT		01
12	0503010571	1/4" X 1.1/2 COTTERPIN		01



Item	Code	Description	See page	QT
01	0502040080	FLANGE NUT R.2.1/2 UN		01
02	0503010002	1800 GREASE FITTING		01
03	0531061664	LOCK AXIS		01



Item	Code	Description	See page	QT
01	0581010302	RING OF SUPPORT		01
02	0502012822	101.60 END CAP		01
03	0503011061	8-342 BACK-UP RING		02
04	0503010338	2-342 N 3006-9B O'RING		02
05	0503017936	RING		01
06	0503017938	RING GUIDE		01
07	0503017937	GASKET		01
08	0503010761	D-1750 SCRAPER RING		01
09	0503018045	2-130 (AGEL) O'RING		04
10	0503030387	PLUG		02
11	0531062934	CASE 101.60 X 497		01
12	0531062936	SWIVEL CYLINDER STEM		01
13	0581010837	PISTON		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503015633	SELEMASTER SEALING		01
16	0503018029	2-217 O'RING		01




Item	Code	Description	See page	QT
01	0531064119	RIGHT SIDE WHEEL CHASSIS		01
02	0531055842	RIGHT HYDRAULIC CYLINDER 44.45X85.70X326 63 CLOSED 607 COURSE		01
03	0501214463	SIDE WHEEL PULLEY		06
04	0503014559	ROLLER BEARING		02
05	0503010095	01103-B SEAL		01
06	0501213909	WHEELED HUB COVER		01
07	0502040080	FLANGE NUT R.2.1/2 UN		01
08	0503010002	1800 GREASE FITTING		11
09	0501213917	ADJUSTMENT WASHER		01
10	0503012213	1/4" COTTERPIN		01
11	0531064113	SIDE WHEEL TOWER		01
12	0501214304	BEATER AXLE		01
13	0503010391	501038 CLAMPING RING (FOR AXLE)		02
14	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
15	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
16	0501214462	NYLON PULLEY BUSHING		12
17	0501214303	WHEEL CHAIN		04
18	0531064110	PULLEY LOCK AXLE		06
19	0503010834	1/2 X 1 BOLT		04
20	0503010019	1/2" SPRING WASHER		04
21	0591017921	BRONZE GLOVE 90.5 X 115 X 91		02
22	0501214460	AXLE 1.1/2 X 140MM		01
23	0503010390	SEAL RING		02
24	0531055358	COMPLETE SIDE CYLINDER BEARING	64	02
25	0531055357	LOCK PIN SET	65	02
26	0501214302	ADJUSTMENT COVER PLATE		04
27	0503034377	3/8 UNC X 3/4 BOLT		24
28	0503010025	3/8 SPRING WASHER		24
29	0531055342	LEFT WHEEL ASSEMBLED	66	01
30	0531055341	RIGHT WHEEL MOUNTED	67	01
31	0531055574	DOUBLE SIDE WHEEL TIRE 500/50	68	01




USAP 3200 AP SUPREMA ALP - FRAME 12820
RIGHT DOUBLE WHEEL SUPPORT WITH 500/50 TIRE

Page 62
0531055572

Item	Code	Description	See page	QT
32	0501017065	FLAT WASHER		06
33	0503011255	3/4" LOCK NUT		06
34	0501216430	ADJUSTING COVER CALCO		04




Item	Code	Description	See page	QT
01	0531064354	RIGHT SHIRT 85.70 X 253 WITH COVER		01
02	0503010042	2-214 N 3006-9B O'RING		01
03	0503010063	1" SELF-ALIGNING NUT		01
04	0503010761	D-1750 SCRAPER RING		01
05	0571019710	1.7" X 3.4" PISTON		01
06	0503017935	RING		01
07	0503018144	RING		01
08	0571019711	RING SUPPORT		01
09	0571019709	DETACHABLE COVER		01
10	0503017936	RING		01
11	0503017938	RING GUIDE		01
12	0503017937	GASKET		01
13	0503017940	8-337 BACK-UP RING		02
14	0503017939	2-337 N 3006-9B O' RING		02
15	0503030387	PLUG		02
16	0503018045	2-130 (AGEL) O'RING		04
17	0531064358	ROD 1.3/4 X 745MM		01




Item	Code	Description	See page	QT
01	0501111135	BIGGER BEARING CYLINDER SUPPORT WITHOUT LUBRICATION		01
01A	0531064111	LARGER FIXING FLANGE HYDRAULIC CYLIND		01
01B	0503019408	IGLIDUR GSM-4550-30 AUTO LUBRICANT GLOVE		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
03	0503010589	1/2" UNC SELF ADJUSTING NUT		02

LOCK PIN SET


0531055357




Item	Code	Description	See page	QT
01	0591016056	LOCK AXLE SUPPORT		01
02	0531061626	38 X 308 JUNCTION AXLE WITH HANDLE		02
03	0503030119	LOCK PIN		02
04	0503010834	1/2 X 1 BOLT		01
05	0503010019	1/2" SPRING WASHER		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0503035800	RIM 16 X 17 - 154 X 203 MM 08 HOLES 0017-2017		01
02	0513010700	TIRE 500-50-17 FLOTATION T422 I1 18PR TECH SHEET		01




Item	Code	Description	See page	QT
01	0503035800	RIM 16 X 17 - 154 X 203 MM 08 HOLES 0017-2017		01
02	0513010700	TIRE 500-50-17 FLOTATION T422 I1 18PR TECH SHEET		01




Item	Code	Description	See page	QT
01	0531064278	DOUBLE SIDE WHEEL SUPPORT		01
02	0503019246	BOLT		02
03	0503011075	3/4" UNC NUT		02
04	0531061575	BEARING		02
05	0501111142	MINOR MOUNTED CROSS		01
06	0503010019	1/2" SPRING WASHER		12
07	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		12
08	0501213743	LOCK AXLE		01
09	0501213742	SUPPORT WASHER		01
10	0503010953	BOLT 1 UNC X 2 C S G.5 ZN		01
11	0503010012	1" SPRING WASHER		01
12	0501213744	SINGLE ARM WHEEL AXLE		01
13	0531055575	WHEEL COMPLETE BOX	69	02
14	0501214898	DOUBLE SIDE WHEEL AXLE		01




Item	Code	Description	See page	QT
01	0503010059	33287/33462 ROLLER BEARING		01
02	0503010007	3982/3920 ROLLER BEARING		01
03	0503010050	SEAL 00085-B		01
04	0503010002	1800 GREASE FITTING		01
05	0501111130	WHEELED BOX WITH SCREW		01
05A	0501213765	WHEEL BOX		01
05B	0503011339	M22 X 1,5 X 72 BOLT		08
06	0541013225	WHEEL BOX COVER		01
07	0503011341	M22 X 0.6" NUT GR8		08
08	0503011340	SPHERICAL SPRING WASHER		08
09	0503011444	SPRING WASHER		06
10	0503010240	BOLT		06
11	0502040080	FLANGE NUT R.2.1/2 UN		01
12	0503011345	1/4" X 3-1/2" COTTERPIN		01
13	1882970002	GREASE SOAP		01




Item	Code	Description	See page	QT
01	0531056304	RIGHT SIDE HOPPER 10 10 MOUTHS ALPHA	71	01
02	0521051407	FERTILIZER HOPPER FIXER	77	20
03	0531050918	TOP SUPPORT MOUNTED LIFT EXTENSOR	78	03
04	0503063509	COMPLETE SILO 05 MOUTH 900L		02




Item	Code	Description	See page	QT
01	0531064566	SILO SUPPORT 10 SIDE BUCKETS		01
02	0531051685	CENTRAL BEARING SHAFT		02
03	0531051684	SIDE AXLE	72	02
04	0591018936	GLOVE		02
05	0503010002	1800 GREASE FITTING		02
06	0531055292	ALPHA FERTILIZER METERING	73	10
07	0501053788	3/4 SQUARE AXLE FASTENER	76	04
08	0503031527	AGRICULTURAL BEARING		04
09	0501218575	SQUARE AXIS 3/4 X 730MM WITH RELIEVE		01
10	0501218487	AXIS 3/4 X 390		04
11	0531057908	SLEEVE 1/4 X 2		06
11A	0502013069	SLEEVE 21 X 38 X 50		01
11B	0503010523	1/4" X 2" COTTERPIN		01
12	0501218573	SQUARE AXIS 3/4 X 865MM WITH RELIEVE		02




Item	Code	Description	See page	QT
01	0591018938	LOCK		01
02	0591018963	BIGGER ARTICULATED AXLE		01
03	0503010329	LOCK WASHER		01
04	0503010330	KM 9 LOCKNUT		02
05	0591015365	RING		02
06	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		02
07	0503010589	1/2" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0503010025	3/8 SPRING WASHER		04
02	0503010026	3/8" NUT		04
03	0513010742	RETAINER 47 X 30 X 10 BRG 5285		01
04	0501214879	HORIZONTAL SEAL LID ALPHA FERTILIZER METERING		01
05	0503035799	ALPHA FERTILIZER DOSAGE NOZZLE		01
06	0503035831	ALPHA FERTILIZER METERING COLLECTOR		01
07	0531055273	ALPHA FERTILIZER METERING CLAMP	74	01
08	0513010692	ALLEN SCREW 1/4 UNC X 7/8 C FLAT SI INOX		04
09	0501011643	3/8 X 1" BOLT		04
10	0503035796	REAR FIXER ALPHA FERTILIZER METERING COLLECTOR		02
11	0513010695	ALLEN SCREW 1/4 UNC X 7/8 CCSI INOX		04
12	0531055376	TRANSMISSION ALPHA FERTILIZER METERING 75 HUB		01
13	0502013049	ALPHA FERTILIZER DOSAGE HOPPER		01
14	0502013048	FLANGE FIXER BODY ALPHA FERTILIZER METERING		01
15	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
15A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
15B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
16	0503035829	ADHESIVE LABEL LOGO TATU 38 X 28 X 0.30 ALPHA FERTILIZER METERING		01
17	0531055518	WORM THREAD ASSEMBLED		01
17A	0531064265	WORM THREAD		01
17B	0503035859	SUPPORT SLEEVE		01
18	0501111143	COATING WITH GUIDE ASSY SUPPLEMENTATION FERTILIZER METERING		01
18A	0501214951	FERTILIZER DOSAGE COATING		01
18B	0531055519	GUIDE ASSY WITH SUPPLEMENTATION		01




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0502013050	TRANSMISSION ALPHA FERTILIZER METERING HOPPER		01
02	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
03	0503011800	SEAL RING		02
04	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
05	0503016065	ROLLER BEARING		02
06	0501214237	TRANSMISSION HOPPER ALPHA FERTILIZER METERING SLEEVE		01
07	0503019373	6006 2RS1 NATIONAL BEARING		02
08	0503012858	502075 CLAMPING RING (FOR HOLE)		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01
10	0501214501	ALPHA FERTILIZER METERING LID LOCK AXIS		01
11	0501214238	SHAFT LOCK SLEEVE HOPPER TRANSMISSION ALPHA FERTILIZER METERING		01
12	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01



Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0503012531	3/8" INOX NUT		01
02	0503012535	3/8" SPRING WASHER		01
03	0571019051	FIXER HOPPER WASHER		01
04	0503013751	3/8 UNC X 1.1/4 BOLT		01




Item	Code	Description	See page	QT
01	0501012140	FLAT WASHER		08
02	0503010811	5/8" UNF SELF ADJUSTING NUT		04
03	0503018814	SCREW 5/8 UNF X 5" G.5 CS ZN		04
04	0531062173	LIFT EXTENSOR TOP SUPPORT		01
05	1902011170	FIXER		02

RIGHT LADDER SET

0531052853




Item	Code	Description	See page	QT
01	0531061615	MOBILE LADDER		01
02	0531062924	RIGHT STAIR SUPPORT		01
03	0531062925	RIGHT LOCK LADDER		01
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
08	0503010589	1/2" UNC SELF ADJUSTING NUT		02
09	0503010752	1/2" X 3.1/2" BOLT		02
10	0503010140	1/8" X 3/4" COTTERPIN		01




Item	Code	Description	See page	QT
01	0503014007	1/2" X 1-1/4" BOLT		08
02	0501010937	13,50 X 28 X 3,00 FLAT WASHER		16
03	0503011336	1/2" HEX SELF ADJUSTING NUT		08
04	0503011957	NYLON HANDLE		02
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	5/16" NUT		04
08	0531064569	LEFT SIDE HANDRAIL		01
09	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		08
10	0503013357	3/8 SELF-ADJUSTING NUT		08
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
12	0531064568	RIGHT SIDE HANDRAIL		01
13	0531064570	SIDE PLATFORM 24/25		02
14	0503013389	5/8" SELF LOCKING NUT		04
15	0591011409	FLAT WASHER 16,5 X 35 X 3,00		04
16	0503010899	5/8 UNC X 2.1/4 BOLT		04
17	0531064567	HANDRAIL SUPPORT		01
18	0503010371	5/16" X 1" BOLT		02
19	0503013759	NUT		02

ASSY REAR HEADLIGHT


0521059839




Item	Code	Description	See page	QT
01	0591016055	REAR HEADLIGHT SUPPORT		01
02	0503018738	HEADLIGHT		01
03	0503010337	5/16" NUT		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		02




Item	Code	Description	See page	QT
01	0503013584	VACUUM GAUGE		01
02	0501210978	VACUOMETER SUPPORT		01




Item	Code	Description	See page	QT
01	0503013357	3/8 SELF-ADJUSTING NUT		09
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
03	0501211086	FERTILIZER DRIVER CHUTE 24/25		01
04	0531062574	GUIDE		09
05	0531055920	MINOR DUCT COMPLETE FERTILIZER	84	05
06	0531055919	MINOR DUCT COMPLETE FERTILIZER	85	04




Item	Code	Description	See page	QT
01	0501215024	TUBE FIXER BODY		01
02	0501010942	3/8" X 1-1/4" BOLT		02
03	0503013357	3/8 SELF-ADJUSTING NUT		02
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
05	0591015578	CLAMP		01
06	0591018876	SHORT FERTILIZER DISTRIBUTOR TUBE		01




Item	Code	Description	See page	QT
01	0501215024	TUBE FIXER BODY		01
02	0501010942	3/8" X 1-1/4" BOLT		02
03	0503013357	3/8 SELF-ADJUSTING NUT		02
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
05	0591015578	CLAMP		01
06	0591018875	LONG FERTILIZER DISTRIBUTOR TUBE		01




Item	Code	Description	See page	QT
01	0531057259	HYDRAULIC TURBINE WITH HOLE	87	01
02	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
03	0501011460	7/8 NF REDUCTION NIPPLE		04
04	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
05	0503010392	2-046 N 3006 9B O'RING		01
06	0503010190	2-114 N 3006-9B O'RING		04
07	0501080218	1/2 X 750 HOSE		01
08	0503031087	ADHESIVE LABEL		01
09	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
10	0501218958	FEMALE ADAPTER R.7/8 UNF X R.7/8 UNF		01



Item	Code	Description	See page	QT
01	0503011336	1/2" HEX SELF ADJUSTING NUT		02
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
03	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
04	0531064418	TURNING LID WITH SLEEVE		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
06	0503010421	5/16" X 1-1/2" BOLT		05
07	0503062627	HYDRAULIC TURBINE ASSY		01
08	0503035455	HYDRAULIC TURBINE SUCTION DUCT		01




Item	Code	Description	See page	QT
01	0581018409	FASTENER BODY		12
02	0503011123	BOLT		06
03	0503013357	3/8 SELF-ADJUSTING NUT		06
04	0503011267	5/8 UNC X 1.1/2 C S G.5 ZN BOLT		06
05	0503010013	5/8 NUT		06
06	0503010027	5/8 SPRING WASHER		06
07	0531061268	7/8 X 884 OIL PIPE		02
08	0531064600	OIL DUCT R.3/4 X 2755		02
09	0531064601	OIL DUCT R.3/4 X 3055		04
10	0531062570	DUCT SUPPORT		03




Item	Code	Description	See page	QT
01	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
02	0503010589	1/2" UNC SELF ADJUSTING NUT		06
03	0531064599	SIDE AIR DISTRIBUTOR 24/25		01
04	0531064598	SIDE AIR DISTRIBUTOR SUPPORT		01
05	0501010937	13,50 X 28 X 3,00 FLAT WASHER		10
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04

CLAMP


0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0501215713	MOTOR BOARD		01
02	0501215714	SPACER GLOVE 231		03
03	0503013389	5/8" SELF LOCKING NUT		06
04	0591011409	FLAT WASHER 16,5 X 35 X 3,00		06
05	0501210380	PRISONER 5/8 UNC X 330		03




Item	Code	Description	See page	QT
01	0531055175	LONG FERTILIZER LINE SMALLER DC20 SHANKS	93	01
02	0531055166	SHORT FERTILIZER LINE DC20 WITHOUT LUBRICATION SHANKS	94	01
03	0531051744	SHORT LINE SPI TIRE WITHOUT FLAP TRANSMISSION ME PP	95	01
04	0531051745	LONG LINE SPI TIRE WITHOUT FLAP TRANSMISSION ME PP	96	01
05	0531055580	SUPER LONG LINE SPI TIRE WITHOUT FLAP TRANSMISSION/ME PP	97	01
06	0531013600	PRESS ADJUSTMENT LEVER		01
07	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
08	0521068982	DISC BLADE HUB KEY		01
09	0521055869	LEFT DUAL FERTILIZER DISC	124	01
10	0521055868	RIGHT DUAL FERTILIZER DISC	125	01
11	0502012815	DOUBLE-DISC SPACING PLATE		01
12	0503010479	BOLT		01
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2 UNC G.5 ZN HEX NUT		01
15	0502070085	FIXED ROD BEARING		01
16	0503016853	SPRING PIN		01
17	0503011402	0.2" X 0.8" SPRING PIN		01
18	0503030391	RIGHT FERTILIZER NOZZLE		01
19	0503030392	LEFT FERTILIZER NOZZLE		01
20	0503031050	CURVED CONDUCTOR		01
21	0503031826	CURVED CONDUCTOR		01
22	0503010246	CLAMP		01
23	0503030195	2" X 2" X 12.2" HOSE		01
24	0503031076	2" HOSE CLAMP		01




Item	Code	Description	See page	QT
01	0503011255	3/4" LOCK NUT		02
02	0571019062	SLEEVE		01
03	0571019059	SUPPORT WASHER		01
04	0503034320	COMPRESSSSION SPRING		01
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503011854	5/8" X 1-1/4" BOLT		02
07	0503017960	5/8" X 3-12" BOLT		04
08	0502012813	FLANGE WASHER SPRING		01
09	0531062203	REGULATOR SPRING LINE FERTILIZER		01
10	0503010417	7/8" NUT		02
11	0502012789	FIXER SUPPORT FERTILIZER ROW		01
12	0591011146	SUPPORT LONG		01
13	0531064024	LONG ARM MINOR FERTILIZER LINE		01
14	0591011147	SLEEVE ARM ROW		02
15	0503019278	LUBRICANT SLEEVE		02
16	0503011109	2-119 N 3006-9B O'RING		02
17	0503011254	7/8" HEX SELF ADJUSTING NUT		01
18	0531055165	20 COMPLETE CURVED CORRUGATED CUTTING 98 DISC		01
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
20	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
21	0503010025	3/8 SPRING WASHER		02
22	0503010026	3/8" NUT		02
23	0521053673	SCARIFIER ROD WITH NOZZLE	102	01
24	0581014070	FERTILIZER NOZZLE		01
25	0521010066	3/4" X 8.12" BOLT		02
26	0531053737	MOUNTED SUPPORT	103	01




Item	Code	Description	See page	QT
01	0503011255	3/4" LOCK NUT		02
02	0571019062	SLEEVE		01
03	0571019059	SUPPORT WASHER		01
04	0503034320	COMPRESSSSION SPRING		01
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503011854	5/8" X 1-1/4" BOLT		02
07	0503017960	5/8" X 3-12" BOLT		04
08	0502012813	FLANGE WASHER SPRING		01
09	0531062203	REGULATOR SPRING LINE FERTILIZER		01
10	0503010417	7/8" NUT		02
11	0502012789	FIXER SUPPORT FERTILIZER ROW		01
12	0591011146	SUPPORT LONG		01
13	0531064025	LONG ARM MINOR FERTILIZER LINE		01
14	0591011147	SLEEVE ARM ROW		02
15	0503019278	LUBRICANT SLEEVE		02
16	0503011109	2-119 N 3006-9B O'RING		02
17	0503011254	7/8" HEX SELF ADJUSTING NUT		01
18	0521057679	ASSY CUTTING DISK 20	99	01
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
20	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
21	0503010025	3/8 SPRING WASHER		02
22	0503010026	3/8" NUT		02
23	0521053673	SCARIFIER ROD WITH NOZZLE	102	01
24	0581014070	FERTILIZER NOZZLE		01
25	0521010066	3/4" X 8.12" BOLT		02
26	0531053737	MOUNTED SUPPORT	103	01




Item	Code	Description	See page	QT
01	0521059626	FRONT LINE	104	01
02	0531051743	REAR RIGHT SPI	106	01
03	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	123	01



Item	Code	Description	See page	QT
01	0521059626	FRONT LINE	104	01
02	0531061136	EXTENSION		01
03	0503012136	NUT 1/2 NF		04
04	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
05	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	123	01
06	0531051743	REAR RIGHT SPI	106	01




Item	Code	Description	See page	QT
01	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	123	01
02	0531055581	SUPER LONG FRONT ME	105	01
03	0531055099	REAR WITH LEFT DDD SPICRR WITHOUT FLAP PPH VDRIVE	107	01
04	0503012136	NUT 1/2 NF		04
05	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04




Item	Code	Description	See page	QT
01	0531064023	SINGLE ARM DISC LONG CUT		01
02	0531064022	ARM SUPPORT		01
03	0571019034	FLANGE WASHER AXLE		01
04	0571019032	SUPPORT WASHER		01
05	0502012813	FLANGE WASHER SPRING		01
06	0502013046	SPRING SUPPORT DISC LONG CUT		01
07	0503019274	WASHER		02
08	0581017628	LID		02
09	0503034320	COMPRESSION SPRING		01
10	0591010625	19,50 X 25 X 91,50/91,30 SLEEVE		01
11	0503010417	7/8" NUT		02
12	0503010390	SEAL RING		02
13	0503011198	C3/4" X 6" SCREW		01
14	0503011255	3/4" LOCK NUT		01
15	0503030430	7/16 X 2" PIN LOCK		01
16	0503019271	SELF LUBRICATING BUSHING		01
17	0503011254	7/8" HEX SELF ADJUSTING NUT		01
18	0531061481	MONO SPRING DISC CUTTING REGULATOR		01
19	0591011144	FIXATION AXLE		01
20	0591010628	DC AXIS BACKREST WASHER		01
21	0503019272	LUBRICANT SLEEVE		02
22	0521057681	BOX WITH DISC CUTTING 20 BEARING CONICO	100	01
23	0503012412	5/8" UNC SELF LOCKING NUT		01
24	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01

ASSY CUTTING DISK 20

0521057679




Item	Code	Description	See page	QT
01	0531060662	MONO ARM DISC CUTTING		01
02	0531060661	ARM SUPPORT		01
03	0571019034	FLANGE WASHER AXLE		01
04	0571019032	SUPPORT WASHER		01
05	0502012813	FLANGE WASHER SPRING		01
06	0591010619	DC SPRING SUPPORT		01
07	0503019274	WASHER		02
08	0581017628	LID		02
09	0503034320	COMPRESSION SPRING		01
10	0591010625	19,50 X 25 X 91,50/91,30 SLEEVE		01
11	0503010417	7/8" NUT		02
12	0503010390	SEAL RING		02
13	0503011198	C3/4" X 6" SCREW		01
14	0503011255	3/4" LOCK NUT		01
15	0503030430	7/16 X 2" PIN LOCK		01
16	0503019271	SELF LUBRICATING BUSHING		01
17	0503011254	7/8" HEX SELF ADJUSTING NUT		01
18	0531061481	MONO SPRING DISC CUTTING REGULATOR		01
19	0591011144	FIXATION AXLE		01
20	0591010628	DC AXIS BACKREST WASHER		01
21	0503019272	LUBRICANT SLEEVE		02
22	0521057681	BOX WITH DISC CUTTING 20 BEARING CONICO	100	01
23	0503012412	5/8" UNC SELF LOCKING NUT		01
24	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521057680	DISC CUTTING BOX	101	01

DISC CUTTING BOX


0521057680




Item	Code	Description	See page	QT
01	0503010370	502072 CLAMPING RING (FOR AXLE)	02	
02	0502020641	BLADE DISC FLANGE	01	
03	0503018825	5/16 UNC UNC BOLT	06	
04	0503013816	5/16" LOCKNUT	06	
05	0501010694	FLAT WASHER	06	
06	0502012862	DISC BLADE HUB	01	
07	0511017907	1/8" BSPT X 6 PLUG	02	
08	0503019285	RING	02	
09	0503010590	00674-B SEAL	02	
10	0591012836	CUTTING DISC AXLE	01	
11	0502040872	REGULATORY NUT	01	
12	0503012170	30207 ROLLER BEARING	02	
13	0503010812	7/8" UNF SELF LOCKING NUT	01	
14	0501010067	22.5 X 56 X 4.75 FLAT WASHER	01	
15	0503019283	SCREW 7/8 UNF X 6.1/4	01	




Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER ROD		01
02	0503011402	0.2" X 0.8" SPRING PIN		02
03	0503016853	SPRING PIN		02
04	0502040869	FIXED ROD BEARING		01




Item	Code	Description	See page	QT
01	0531063324	LONG LINE COMPLEMENT SUPPORT		01
02	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0503010479	BOLT		02




Item	Code	Description	See page	QT
01	0531060663	FRONT FRAME SEED LINE	01	
02	0531061428	REAR LINE	01	
03	0503030168	HITCH PIN CLIP	05	
04	0571018883	PIN FIXER SPRING	02	
05	0503034198	SPRING TRACTION 40 X 198 X 5,5	01	
06	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
07	0502012812	SEED ROW ADJUSTMENT LEVER ASSY	01	
08	0591011156	PIVOT ARM SEED ROW	02	
09	0503017857	BOLT 5/8 UNF 4	04	
10	0501012140	FLAT WASHER	04	
11	0503010811	5/8\" UNF SELF ADJUSTING NUT	04	
12	0503019273	AUTO LUBRICANT SLEEVE	08	
13	0503010045	O'RING	08	
14	0591012829	SPACER LOWER SLEEVE	08	
15	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
16	0503012412	5/8\" UNC SELF LOCKING NUT	04	
17	0591012827	FRONT PENDULUM LINE	01	
18	0591012828	LOCK PIN ROW ARTICULAT	01	
19	0501219536	LINE GUTTER	01	
20	0501310623	SPRING FIXING PIN	02	




Item	Code	Description	See page	QT
01	0531063425	FRONT FRAME SEED ROW	01	
02	0531061428	REAR LINE	01	
03	0503030168	HITCH PIN CLIP	05	
04	0571018883	PIN FIXER SPRING	04	
05	0503034198	SPRING TRACTION 40 X 198 X 5,5	01	
06	1902010175	HITCH CLAMP	02	
07	0502012812	SEED ROW ADJUSTMENT LEVER ASSY	01	
08	0591011156	PIVOT ARM SEED ROW	02	
09	0503017857	BOLT 5/8 UNF 4	04	
10	0501012140	FLAT WASHER	04	
11	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
12	0503019273	AUTO LUBRICANT SLEEVE	08	
13	0503010045	O'RING	08	
14	0591012829	SPACER LOWER SLEEVE	08	
15	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
16	0503012412	5/8" UNC SELF LOCKING NUT	04	
17	0591012827	FRONT PENDULUM LINE	01	
18	0591012828	LOCK PIN ROW ARTICULAT	01	



Item	Code	Description	See page	QT
01	0531050536	REAR RIGHT SPI TIRE WITHOUT FLAP	108	01
02	0521056640	PRECISION PLANTING CSC CABLE / 121	121	01
03	0503062403	TRANSMISSION ASSY		01
04	0571017895	TUBE SEED P.P		01
05	0503010140	PIN FIXER CONDUCTOR P.P		01
06	0503010140	1/8" X 3/4" COTTERPIN		01
07	0591017565	SEED CONDUCTOR GUIDE		01
	0503015341	POP RIVET		02




Item	Code	Description	See page	QT
01	0531055009	REAR ROW WITH LEFT DOUBLE DISC	109	01
02	0521056640	PRECISION PLANTING CSC CABLE / TRANSMISSION ASSY	121	01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0591017565	SEED CONDUCTOR GUIDE		01
06	0503015341	POP RIVET		02



Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0521056632	DEPTH CONTROL	110	01
03	0502012920	SUPPORT ADJUSTING		01
04	0502012611	DEPTH CONTROL AXLE		01
05	0591011309	ADJUSTMENT BUSHING		02
06	0591011310	ADJUSTMENT BAR		02
07	0503019275	SLEEVE LUBRICATION SYSTEM		01
08	0581019473	ARTICULATED SLEEVE		02
09	0503010045	O'RING		02
10	0503013357	3/8 SELF-ADJUSTING NUT		02
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
12	0591011326	LOCK PIN		01
13	0571015326	ARTICULATION SLEEVE HANDLE		01
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503010060	1/2 UNC G.5 ZN HEX NUT		02
16	0503010019	1/2" SPRING WASHER		04
17	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
18	0501011445	FLAT WASHER		04
19	0503012556	1/2" X 1" BOLT		02
20	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
21	0591011306	ADJUSTMENT LOCK		02
22	0503012136	NUT 1/2 NF		04
23	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
24	0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	111	01
25	0521055093	BODY COMPACTOR	113	01
26	0521055017	RIGHT COMPACTOR WHEEL	114	01
27	0521054990	LEFT COMPACTOR WHEEL	115	01
28	0531050538	MOUNTED LEFT ARM	117	01
29	0531050539	MOUNTED LEFT ARM	118	01
30	0503010131	3/16" X 1-1/2" COTTERPIN		02
31	0591016900	BEATING AXLE		01


Item	Code	Description	See page	QT
32	0591016905	DEPTH WHEEL JOINT AXLE		02
33	0591016907	SPACER GLOVE 14MM		06
34	0591016988	SPICER PROTECTOR		01




Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0521056632	DEPTH CONTROL	110	01
03	0502012920	SUPPORT ADJUSTING		01
04	0502012611	DEPTH CONTROL AXLE		01
05	0591011309	ADJUSTMENT BUSHING		02
06	0591011310	ADJUSTMENT BAR		02
07	0503019275	SLEEVE LUBRICATION SYSTEM		01
08	0581019473	ARTICULATED SLEEVE		02
09	0503010045	O'RING		02
10	0503013357	3/8 SELF-ADJUSTING NUT		02
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
12	0591011326	LOCK PIN		01
13	0571015326	ARTICULATION SLEEVE HANDLE		01
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503010060	1/2 UNC G.5 ZN HEX NUT		02
16	0503010019	1/2" SPRING WASHER		04
17	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
18	0501011445	FLAT WASHER		04
19	0503012556	1/2" X 1" BOLT		02
20	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
21	0591011306	ADJUSTMENT LOCK		02
22	0591016907	SPACER GLOVE 14MM		06
23	0591016988	SPICER PROTECTOR		01
24	0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	112	01
25	0521055093	BODY COMPACTOR	113	01
26	0521055017	RIGHT COMPACTOR WHEEL	114	01
27	0521054990	LEFT COMPACTOR WHEEL	115	01
28	0531050538	MOUNTED LEFT ARM	117	01
29	0531050539	MOUNTED LEFT ARM	118	01
30	0503010131	3/16" X 1-1/2" COTTERPIN		02
31	0591016900	BEATING AXLE		01




Item	Code	Description	See page	QT
32	0591016905	DEPTH WHEEL JOINT AXLE		02




Item	Code	Description	See page	QT
01	0502012925	ADJUSTMENT BODY		01
02	0511015976	FLAT WASHER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0503010581	RING		01
05	0502012892	DEPTH CONTROL HANDLE		01
06	0581019526	ARTICULATED AXLE LEVER DEPTH		01
07	0503010302	501019 SEAL RING		01




Item	Code	Description	See page	QT
01	0502012929	BODY RIGHT		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 126 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 127 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0502012928	LEFT EXTENSOR		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 127 FERTILIZER / SEED		01
11	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 126 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT	02	
02	0503013816	5/16" LOCKNUT	04	
03	0581015855	SLEEVE	02	
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER	01	
05	0521068661	LEVER	01	
06	0503030878	LEVER CRANK	01	
07	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING	01	
08	0581019520	AXIS	01	
09	0571812442	COUPLING SHAFT	01	
10	0503010257	1/8" X 1" COTTERPIN	01	
11	0581019511	COVER	01	
12	0503010848	5/16" X 3.1/2" BOLT	02	
13	0503010752	1/2" X 3.1/2" BOLT	01	
14	0503011336	1/2" HEX SELF ADJUSTING NUT	01	
15	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
16	0581019510	AXIS	01	
17	0581019512	PLATE TOP	01	
18	0503019351	LUBRICANT SLEEVE	02	
19	0521069591	LEFT SIDE	01	
20	0581019548	RIGHT SIDE BODY	01	




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	116	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	116	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0502012927	LEFT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055056	WHEEL RAYED ASSY BAND	119	01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0502012926	RIGHT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055056	WHEEL RAYED ASSY BAND	119	01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
04	0503010337	5/16" NUT		06
05	0503032970	RUBBER BAND		01
06	0521055073	ASSEMBLY DEPTH WHEEL HUB	120	01




Item	Code	Description	See page	QT
01	0581019528	WHEEL DEPTH SPA HUB WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	DUST CLOAK		01
11	0581019529	DEPTH REGULATOR SHAFT		01



Item	Code	Description	See page	QT
01	0502012924	PRECISION PLANTING SUPPORT		01
02	0502012800	SUPPORT ARTICULATION PNEUMATIC		01
03	0503062406	SEED HOPPER		01
04	0521052131	DISTRIBUTOR VSET2 WITH CORN DISK WITHOUT 122 PROTECTION		01
05	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01
07	0503810009	BOLT		02
08	0571018649	SUPPORT FIXER		02
09	0503010243	CLAMP		01
10	0581017816	TERMINAL		01
11	0503034204	SEALING		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0571014024	FAST BOLT GUIDE AXLE		01
14	0503034824	FIXATIVE		01
15	0503010293	CLAMP KNOB		01
16	0503010025	3/8 SPRING WASHER		05
17	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
18	0501110894	FIXER		01
19	0502012922	FIXING SUPPORT		01
20	0503011404	BOLT		01
21	0503013357	3/8 SELF-ADJUSTING NUT		01
22	0503010026	3/8" NUT		04
23	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04




Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01




Item	Code	Description	See page	QT
01	0531062260	GUIDE HOSE L / TRANSMISSION		01
02	0571018883	PIN FIXER SPRING		01
03	0503010257	1/8" X 1" COTTERPIN		01

LEFT DUAL FERTILIZER DISC


0521055869




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 126 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 127 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 126 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 127 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	128	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01



Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	129	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUB DISC - HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01

MOUNTED CENTRAL SUPPORT


0531055744



Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW	02	
02	0503017857	BOLT 5/8 UNF 4	08	
03	0503010811	5/8" UNF SELF ADJUSTING NUT	08	
04	0591017796	ARTICULATION AXIS 222 R.1.1 / 4 UNF	01	
05	0531064321	UNIVERSAL SUPPORT	01	
06	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION	02	
07	0503010019	1/2" SPRING WASHER	04	
08	0503011075	3/4" UNC NUT	06	
09	0501010125	3/4" X 2-1/2" BOLT	06	
10	0591013172	31.75 X126 AXLE WITH 8 HOLE	02	
11	0591013173	CYLINDER INTERMEDIATE BUSHING	01	
12	0503012231	1/4" X 3" COTTERPIN	02	
13	0501111072	SIDE SUPPORT ARTICULATOR	01	
14	0501011544	3/4" X 1-1/2" BOLT	01	
15	0503010023	3/4" SPRING WASHER	01	
16	0531050903	SIDE ARTICULATED CYLINDER 58 44.45X85.70X291X657	01	
17	0591018408	PIN LOCK LINES	01	
18	0503030085	LOCK PIN	01	
19	0591019305	FLAT WASHER 20 X 60 X 4.75 WITH CUT OUT	01	
20	0501211496	GLOVE 16 X 25 X 27 WITH HOLE	01	
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	04	
22	0503010060	1/2 UNC G.5 ZN HEX NUT	04	
23	0501010942	3/8" X 1-1/4" BOLT	02	
24	0503013357	3/8 SELF-ADJUSTING NUT	02	
25	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	




Item	Code	Description	See page	QT
01	0531055350	CENTRAL SUPPORT WITH 07 NOZZLES	132	01
02	0503063507	COMPLETE SILO 03 MOUTHS 540L		01
03	0503063508	COMPLETE SILO 04 MOUTH 720L		01
04	0521051407	FERTILIZER HOPPER FIXER	77	14
05	0503010589	1/2" UNC SELF ADJUSTING NUT		06
06	0503014378	1/2" X 1-1/2" BOLT		06
07	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06




Item	Code	Description	See page	QT
01	0531064103	CENTRAL SILO SUPPORT 07 MOUTHS		01
02	0531055292	ALPHA FERTILIZER METERING	73	07
03	0521054282	BEARING	133	02
04	0501053788	3/4 SQUARE AXLE FASTENER	76	04
05	0503031527	AGRICULTURAL BEARING		04
06	0501218575	SQUARE AXIS 3/4 X 730MM WITH RELIEVE		02
07	0501218487	AXIS 3/4 X 390		03
08	0531057908	SLEEVE 1/4 X 2		04
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010523	1/4" X 2" COTTERPIN		01

BEARING


0521054282



Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	134	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531064124	LEFT ARTICULATING ARM	01	
02	0521063778	RELATION AVEC AXE VERTICAL LATCH	01	
03	0571011767	LISA WASHER 125 X 88 X 4.76	01	
04	0503010408	7/8" SPRING WASHER	01	
05	0503015322	BOLT 7/8	01	
06	0503010814	5/16 BOLT	10	
07	0503010002	1800 GREASE FITTING	02	
08	0571011825	BUSHING	02	
09	0503011345	1/4" X 3-1/2" COTTERPIN	01	
10	0531062168	CYLINDER JOINT AXIS	01	
11	0503010834	1/2 X 1 BOLT	01	
12	0503010019	1/2" SPRING WASHER	05	
13	0503010060	1/2 UNC G.5 ZN HEX NUT	04	
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	02	
15	0501013519	FLAT WASHER	04	
16	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT	02	
17	0591012948	700 X 130 X 10 PLATE	01	
18	0531063434	SUPPORT GUIDE HOSES SEED	02	
19	0591018508	24 X 50 X 1000 GUTTER	01	
20	0501013518	FLAT WASHER	02	
21	0503010025	3/8 SPRING WASHER	02	
22	0503010026	3/8" NUT	02	
23	0501011643	3/8 X 1" BOLT	02	
24	0503035505	HOSE PROTECTOR	01	
25	0501214491	CONIC GLOVE TIGHTENING	02	
26	0502040080	FLANGE NUT R.2.1/2 UN	01	
27	0501214492	FIXING WASHER	01	
28	0531064126	ARTICULATING AXLE	01	

ASSY LEFT ARTICULATION ARM AP


0531055369




Item	Code	Description	See page	QT
01	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
02	0571011767	LISA WASHER 125 X 88 X 4.76		01
03	0503010408	7/8" SPRING WASHER		01
04	0503015322	BOLT 7/8		01
05	0503010814	5/16 BOLT		10
06	0503010002	1800 GREASE FITTING		02
07	0571011825	BUSHING		02
08	0591012948	700 X 130 X 10 PLATE		01
09	0531064125	RIGHT ARTICULATING ARM		01
10	0531062168	CYLINDER JOINT AXIS		01
11	0503010834	1/2 X 1 BOLT		01
12	0503010019	1/2" SPRING WASHER		05
13	0501013519	FLAT WASHER		02
14	0503010060	1/2 UNC G.5 ZN HEX NUT		04
15	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0591018508	24 X 50 X 1000 GUTTER		01
18	0501013518	FLAT WASHER		02
19	0503010025	3/8 SPRING WASHER		02
20	0503010026	3/8" NUT		02
21	0501011643	3/8 X 1"BOLT		02
22	0503035505	HOSE PROTECTOR		01
23	0531063434	SUPPORT GUIDE HOSES SEED		02
24	0501214491	CONIC GLOVE TIGHTENING		02
25	0502040080	FLANGE NUT R.2.1/2 UN		01
26	0501214492	FIXING WASHER		01
27	0503011345	1/4" X 3-1/2" COTTERPIN		01
28	0531064126	ARTICULATING AXLE		01




Item	Code	Description	See page	QT
01	0503019579	LED LANTERN		01
02	0591018797	LED LANTERN SUPPORT		01
03	0503011828	FLAT WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0503010019	1/2" SPRING WASHER		02
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
07	0591018872	LANTERN COVER		01
08	0503019412	RIVET SCREW INTERNAL		02
09	0503013813	1/4" UNC X 7/8" BOLT		02
10	0503010143	1/4" SPRING WASHER		02
11	0503010305	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0591018537	DOUBLE CONNECTION SUPPORT		01
02	0501068706	DOUBLE CONNECTION		02
03	0503010026	3/8" NUT		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0503010589	1/2" UNC SELF ADJUSTING NUT		02
08	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02




Item	Code	Description	See page	QT
01	0531062269	PLATFORM LEFT FIXER		01
02	1902010175	HITCH CLAMP		01
03	0501011543	5/8" X 4" BOLT		02
04	0503010027	5/8 SPRING WASHER		02
05	0503010013	5/8 NUT		02
06	0503010025	3/8 SPRING WASHER		02
07	0503010026	3/8" NUT		02
08	0503010237	3/8" X 1" BOLT		02
09	0521067153	4 MOUTH CENTRAL AIR DISTRIBUTOR		01




Item	Code	Description	See page	QT
01	0581010353	RING SUPPORT		01
02	0502010382	5" END CAP		01
03	0581013698	PISTON		01
04	0531062933	CASE 127 X 773 MM		01
05	0531062932	EXTENSION 50.80 X 898 MM		01
06	0503010003	1845 GREASE FITTING		02
07	0503010817	1.1/4" SELF LOCKING NUT		01
08	0503018439	WIPER SEAL		01
09	0503018150	RING GUIDE		01
10	0503010173	2-220 N 3006-9B O'RING		01
11	0503018024	RING BS		01
12	0503018026	1870-2000-375 B GASKET		01
13	0503010039	D-2000 SCRAPER RING		01
14	0503018152	O'RING		02
15	0503018025	RING GUIDE		01
16	0503011453	O'RING		02




Item	Code	Description	See page	QT
01	0531063641	CENTRAL SEED BOX SUPPORT 2500 LITERS		01
02	0531054352	AXLE 1.1/2 X 167 MM WITH WASHER		04
02A	0501212952	PASADOR 1.1/2 X 167 MM		01
02B	0501212953	FLAT WASHER 39 X 60 X 3		04
02C	0503010010	1/4" X 2.1/2" COTTERPIN		02
03	0531054356	HYDRAULIC TURBINE WITH CSC SCREEN 30 142 LINES		01
04	0531054355	SUPPORT WITH VACUOMETER 18 TO 25 LINES		01
04A	0501212956	18/25 CENTRAL VACUUM SUPPORT		01
04B	0503013584	VACUUM GAUGE		01
05	0531054354	CENTRAL SEED BOX 2500 LITERS	146	01
06	0531063639	CSC HANDRAIL 2500 LITERS		02
07	0503011372	102 TO 121 CLAMP		02
08	0501213035	SILO SUPPORT GLOVE CSC 2500L		04
09	0513010405	CLAMP		28
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
11	0503010019	1/2" SPRING WASHER		08
12	0503010060	1/2 UNC G.5 ZN HEX NUT		02
13	0503010547	1/2" X 4" BOLT		02
14	0501212957	SILO LOCK CSC 2500 LITERS		02
15	0503014007	1/2" X 1-1/4" BOLT		06
16	0521018517	FLAT WASHER		02
17	0503010002	1800 GREASE FITTING		04
18	0521012538	1.2" X 3.5" COUPLING SHAFT		01
19	0503010010	1/4" X 2.1/2" COTTERPIN		01
20	0503014378	1/2" X 1-1/2" BOLT		06
21	0503010589	1/2" UNC SELF ADJUSTING NUT		06
22	0501213773	HOSE GUIDE SUPPORT		01
23	0503035468	HOSE PROTECTION		01




Item	Code	Description	See page	QT
01	0501054983	NIPPLE HIDRAULIC MOTOR	143	01
02	0531063640	TURBINE SUPPORT		01
03	0521044613	FAN 480X50 (HIDRAULIC)	144	01
04	0531061858	MECHANICAL SNAIL		01
05	0571018577	COVER SNAIL TURBINE		01
06	0571018578	TURBINE PROTECTIVE SCREEN		01
07	0521069167	FRONT PROTECTION		01
08	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC 145		01
09	0503010025	3/8 SPRING WASHER		10
10	0503010026	3/8" NUT		08
11	0503010143	1/4" SPRING WASHER		01
12	0503010849	3/8" X 1-1/2" BOLT		02
13	0531018764	FLAT WASHER		01
14	0503011104	M6 X 1" BOLT		01
15	0503012722	0.16" X 0.4" BLIND RIVET		19
16	0503010237	3/8" X 1" BOLT		06
17	0503010206	3/8 X 1/2 BOLT		02
18	0541013274	LISA WASHER 10 X 38 X 4.75		02




Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW		01
03	0561016941	3/4" NUT		01
04	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
05	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE		01
06	3914103037	TEFLON		0,001RI




Item	Code	Description	See page	QT
01	0571016947	DISC FRONT TURBINE		01
02	0571016949	DISC REAR TURBINE		01
03	0521065171	HUB FLANGE		01
04	0571016950	DISC STRENGTHENING TURBINE		01
05	0571016951	FLIP TURBINE		10
06	0503012651	M6 X 1" BOLT		05
07	0503010143	1/4" SPRING WASHER		05
08	0503011776	M6 SELF ADJUSTINGNUT		05




Item	Code	Description	See page	QT
01	0503012291	BLOCK COMMAND		01
02	0501010590	NIPPLE		04
03	0503010045	O'RING		04
04	0541011066	3/4" UNF X 43.5 NIPPLE		01
05	0503010190	2-114 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0503063436	COMPLETE POSITIVE AIR DOUBLE SEED BOX		01
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		46
03	0531054357	LOWER SYSTEM 28 PIPES	147	01
04	0503013357	3/8 SELF-ADJUSTING NUT		46
05	0503010849	3/8" X 1-1/2" BOLT		12
06	0503010025	3/8 SPRING WASHER		12
07	0531063644	AIR TUBE 28 OUTLETS WITH FIXER		01
08	0513010632	RUBBER SMOOTH WASHER 28 X 10 X 2.00		46
09	0531063885	SYSTEM FIXING RULE		02
10	0531063624	SYSTEM FIXING RULE		14
11	0513010630	SCREW M6 X1 X 20 CCSI 10.9 SA		30




Item	Code	Description	See page	QT
01	0531063643	OUTLET BODY WITH DUCTS		01
02	0503015135	FLAT WASHER 10 X 18 X 2		10
03	0503011823	0.1" X 0.6" SPRING PIN		10
04	0521068978	CASH FUND COVER		05
05	0581017529	ROD 9,53		05
06	0503034692	FAST LOCK ASSY		10
07	0503030085	LOCK PIN		10
08	0503034573	SEALING		05
09	0503035773	BOTTOM SEAL BOX SYSTEM 28 OUTPUTS		01
10	0503063723	AIR TUBE SEAL 04 OUTLETS 290		07



Item	Code	Description	See page	QT
01	0501212948	DEPOSIT SUPPORT BODY		02
02	0503011075	3/4" UNC NUT		04
03	0501011545	3/4" X 6-1/2" BOLT		04




Item	Code	Description	See page	QT
01	0502010471	63,50 MOBILE CAP		01
02	0581010668	RING SUPPORT		01
03	0502012837	PISTON		01
04	0503018163	BACK-UP RING		02
05	0503018162	O'RING		02
06	0503018004	RING		01
07	0503018003	GASKET		01
08	0503010163	D-1500 SCRAPER RING		01
09	0503011109	2-119 N 3006-9B O'RING		01
10	0503018005	RING		01
11	0531063638	SHIRT 63.50 X 345		01
12	0503018045	2-130 (AGEL) O'RING		04
13	0501212949	EXTENDER 38.10 X 38.05 X 380		01
14	0511064408	FORK		01
15	0503010025	3/8 SPRING WASHER		01
16	0503011094	3/8" X 2" BOLT		01
17	0503010026	3/8" NUT		01
18	0503030385	CYLINDER PLUG N-002		02



Item	Code	Description	See page	QT
01	0531064104	TELESCOPE WHEEL SUPPORT		01
02	0531064105	CENTRAL WHEEL TOWER		01
03	0531064106	CROSSHEAD WITH SUPPORT		01
04	0531055842	RIGHT HYDRAULIC CYLINDER 44.45X85.70X326 63 CLOSED 607 COURSE		01
05	0531055355	CENTRAL ASSY CUBE	153	02
06	0531055342	LEFT WHEEL ASSEMBLED	66	01
07	0531055341	RIGHT WHEEL MOUNTED	67	01
08	0501210807	PLASTIPRENE LOWER SUPPORT		02
09	0501210806	PLASTIPRENE TOP SUPPORT		02
10	0501214452	DAMPER SPINDLE		02
11	0501214453	PLASTIPRENE EAR		01
12	0501214454	GLOVE ARTICULATION AXLE		02
13	0531064108	ARTICULATOR AXLE CENTRAL WHEEL		01
14	0503010834	1/2 X 1 BOLT		05
15	0503010019	1/2" SPRING WASHER		05
16	0591011057	WASHER		01
17	0503011250	1" X 2" BOLT		01
18	0503011075	3/4" UNC NUT		02
19	0503013185	3/4" X 5-1/2" BOLT		02
20	0501214513	200MM BEATER SHAFT		01
21	0503010391	501038 CLAMPING RING (FOR AXLE)		02
22	0501214303	WHEEL CHAIN		04
23	0531054036	ASSY CENTER CYLINDER BEARING	154	02
24	0531064361	CYLINDER AXLE 170.50MM		01
25	0503011052	1.1/4" X 0.77" CASTLE NUT		01
26	0503012182	1" NUT		02
27	0503010002	1800 GREASE FITTING		06
28	0503010038	3/16 X 2 COTTERPIN		01
29	0591016434	PLASTIPRENE		02
30	0501214302	ADJUSTMENT COVER PLATE		04
31	0501214300	ADJUSTING CALCO		04


Item	Code	Description	See page	QT
32	0503034377	3/8 UNC X 3/4 BOLT		24
33	0503010025	3/8 SPRING WASHER		24
34	0501215027	CENTRAL WHEEL PULLEY		04
35	0531064332	CENTRAL PULLEY LOCK AXLE		04
36	0501214462	NYLON PULLEY BUSHING		08
37	0501017065	FLAT WASHER		04
38	0503011255	3/4" LOCK NUT		04




Item	Code	Description	See page	QT
01	0531064104	TELESCOPE WHEEL SUPPORT		01
02	0531064105	CENTRAL WHEEL TOWER		01
03	0531064106	CROSSHEAD WITH SUPPORT		01
04	0531055354	HYDRAULIC CYLINDER 44.45X85.70X326	152	01
05	0531055355	CENTRAL ASSY CUBE	153	02
06	0531055342	LEFT WHEEL ASSEMBLED	66	01
07	0531055341	RIGHT WHEEL MOUNTED	67	01
08	0501210807	PLASTIPRENE LOWER SUPPORT		02
09	0501210806	PLASTIPRENE TOP SUPPORT		02
10	0501214452	DAMPER SPINDLE		02
11	0501214453	PLASTIPRENE EAR		01
12	0501214454	GLOVE ARTICULATION AXLE		02
13	0531064108	ARTICULATOR AXLE CENTRAL WHEEL		01
14	0503010834	1/2 X 1 BOLT		05
15	0503010019	1/2" SPRING WASHER		05
16	0591011057	WASHER		01
17	0503011250	1" X 2" BOLT		01
18	0503011075	3/4" UNC NUT		02
19	0503013185	3/4" X 5-1/2" BOLT		02
20	0501214513	200MM BEATER SHAFT		01
21	0503010391	501038 CLAMPING RING (FOR AXLE)		02
22	0501214303	WHEEL CHAIN		04
23	0531054036	ASSY CENTER CYLINDER BEARING	154	02
24	0531064361	CYLINDER AXLE 170.50MM		01
25	0503011052	1.1/4" X 0.77" CASTLE NUT		01
26	0503012182	1" NUT		02
27	0503010002	1800 GREASE FITTING		06
28	0503010038	3/16 X 2 COTTERPIN		01
29	0591016434	PLASTIPRENE		02
30	0501214302	ADJUSTMENT COVER PLATE		04
31	0501214300	ADJUSTING CALCO		04




Item	Code	Description	See page	QT
32	0503034377	3/8 UNC X 3/4 BOLT		24
33	0503010025	3/8 SPRING WASHER		24
34	0501215027	CENTRAL WHEEL PULLEY		04
35	0531064332	CENTRAL PULLEY LOCK AXLE		04
36	0501214462	NYLON PULLEY BUSHING		08
37	0501017065	FLAT WASHER		04
38	0503011255	3/4" LOCK NUT		04




Item	Code	Description	See page	QT
01	0531064107	CASE 85.70 X 253 WITH COVER		01
02	0531064358	ROD 1.3/4 X 745MM		01
03	0503010042	2-214 N 3006-9B O'RING		01
04	0503010063	1" SELF-ALIGNING NUT		01
05	0503010761	D-1750 SCRAPER RING		01
06	0571019710	1.7" X 3.4" PISTON		01
07	0503017935	RING		01
08	0503018144	RING		01
09	0571019711	RING SUPPORT		01
10	0571019709	DETACHABLE COVER		01
11	0503017936	RING		01
12	0503017938	RING GUIDE		01
13	0503017937	GASKET		01
14	0503017940	8-337 BACK-UP RING		02
15	0503017939	2-337 N 3006-9B O' RING		02
16	0503030387	PLUG		02
17	0503018045	2-130 (AGEL) O'RING		04




Item	Code	Description	See page	QT
01	0501214451	CENTRAL WHEEL AXLE		01
02	0503010059	33287/33462 ROLLER BEARING		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010050	SEAL 00085-B		01
05	0503010002	1800 GREASE FITTING		01
06	0503011345	1/4" X 3-1/2" COTTERPIN		01
07	0501111130	WHEELED BOX WITH SCREW		01
07A	0501213765	WHEEL BOX		01
07B	0503011339	M22 X 1,5 X 72 BOLT		08
08	0541013225	WHEEL BOX COVER		01
09	0503011341	M22 X 0.6" NUT GR8		08
10	0503011340	SPHERICAL SPRING WASHER		08
11	0503011444	SPRING WASHER		06
12	0503010240	BOLT		06
13	0502040080	FLANGE NUT R.2.1/2 UN		01
14	1882970002	GREASE SOAP		01




Item	Code	Description	See page	QT
01	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
03	0503010589	1/2" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0591019407	FERTILIZER CONDUCTOR GUTTER		01
02	0531055920	MINOR DUCT COMPLETE FERTILIZER	84	02
03	0531055919	MINOR DUCT COMPLETE FERTILIZER	85	04
04	0503013357	3/8 SELF-ADJUSTING NUT		06
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		12
06	0531062574	GUIDE		06



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0501215717	MOTOR BOARD APT		01
02	0503013389	5/8" SELF LOCKING NUT		06
03	0591011409	FLAT WASHER 16,5 X 35 X 3,00		06
04	0501216051	SPACING GLOVE 170		03
05	0501017334	5/8"X 5/8" X 10.24" STUD		03




Item	Code	Description	See page	QT
01	0501218234	DUCT SUPPORT		01
02	0501068706	DOUBLE CONNECTION		01
03	0531063535	5 OUTLETS OIL DISTRIBUTOR		01
04	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		02
05	0501012140	FLAT WASHER		02
06	0503013389	5/8" SELF LOCKING NUT		02
07	0503010025	3/8 SPRING WASHER		04
08	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
09	0503010026	3/8" NUT		04
10	0503010237	3/8" X 1" BOLT		04

LEFT STAIRS SET

0531052854



Item	Code	Description	See page	QT
01	0531061615	MOBILE LADDER		01
02	0531062927	LEFT SUPPORT STAIRCASE		01
03	0531062926	LEFT LOCK LADDER		01
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
08	0503010589	1/2" UNC SELF ADJUSTING NUT		02
09	0503010752	1/2" X 3.1/2" BOLT		02
10	0503010140	1/8" X 3/4" COTTERPIN		01




Item	Code	Description	See page	QT
01	0531064112	LEFT SIDE WHEEL CHASSI		01
02	0531064113	SIDE WHEEL TOWER		01
03	0531055354	HYDRAULIC CYLINDER 44.45X85.70X326	152	01
04	0503014559	ROLLER BEARING		02
05	0503010095	01103-B SEAL		01
06	0501213909	WHEELED HUB COVER		01
07	0502040080	FLANGE NUT R.2.1/2 UN		01
08	0503010002	1800 GREASE FITTING		11
09	0501213917	ADJUSTMENT WASHER		01
10	0503012213	1/4" COTTERPIN		01
11	0501214304	BEATER AXLE		01
12	0503010391	501038 CLAMPING RING (FOR AXLE)		02
13	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
15	0501214463	SIDE WHEEL PULLEY		06
16	0501214462	NYLON PULLEY BUSHING		12
17	0501214303	WHEEL CHAIN		04
18	0531064110	PULLEY LOCK AXLE		06
19	0503010834	1/2 X 1 BOLT		06
20	0503010019	1/2" SPRING WASHER		06
21	0591017921	BRONZE GLOVE 90.5 X 115 X 91		02
22	0501214460	AXLE 1.1/2 X 140MM		01
23	0503010390	SEAL RING		02
24	0531055358	COMPLETE SIDE CYLINDER BEARING	64	02
25	0531055357	LOCK PIN SET	65	01
26	0501214302	ADJUSTMENT COVER PLATE		04
27	0503034377	3/8 UNC X 3/4 BOLT		24
28	0503010025	3/8 SPRING WASHER		24
29	0531055574	DOUBLE SIDE WHEEL TIRE 500/50	68	01
30	0531055342	LEFT WHEEL ASSEMBLED	66	01
31	0531055341	RIGHT WHEEL MOUNTED	67	01




USAP 3200 AP SUPREMA ALP - FRAME 12820
LEFT DOUBLE WHEEL SUPPORT WITH 500/50 TIRE SMALLER

Page 160
0531055573


Item	Code	Description	See page	QT
32	0501017065	FLAT WASHER		06
33	0503011255	3/4" LOCK NUT		06
34	0501216430	ADJUSTING COVER CALCO		04




Item	Code	Description	See page	QT
01	0531058140	LEFT SIDE HOPPER WITH 10 NOZZLES ALPHA	162	01
02	0521051407	FERTILIZER HOPPER FIXER	77	20
03	0531050918	TOP SUPPORT MOUNTED LIFT EXTENSOR	78	03
04	0503063509	COMPLETE SILO 05 MOUTH 900L		02



Item	Code	Description	See page	QT
01	0531064566	SILO SUPPORT 10 SIDE BUCKETS		01
02	0531051685	CENTRAL BEARING SHAFT		02
03	0531051684	SIDE AXLE	72	02
04	0591018936	GLOVE		02
05	0503010002	1800 GREASE FITTING		02
06	0531055292	ALPHA FERTILIZER METERING	73	10
07	0501053788	3/4 SQUARE AXLE FASTENER	76	04
08	0503031527	AGRICULTURAL BEARING		04
09	0501218487	AXIS 3/4 X 390		04
10	0531057908	SLEEVE 1/4 X 2		06
10A	0502013069	SLEEVE 21 X 38 X 50		01
10B	0503010523	1/4" X 2" COTTERPIN		01
11	0501218573	SQUARE AXIS 3/4 X 865MM WITH RELIEVE		02
12	0501218575	SQUARE AXIS 3/4 X 730MM WITH RELIEVE		01



Item	Code	Description	See page	QT
01	0581018409	FASTENER BODY		12
02	0503011123	BOLT		06
03	0503013357	3/8 SELF-ADJUSTING NUT		06
04	0503011267	5/8 UNC X 1.1/2 C S G.5 ZN BOLT		06
05	0503010013	5/8 NUT		06
06	0503010027	5/8 SPRING WASHER		06
07	0531061268	7/8 X 884 OIL PIPE		02
08	0531062570	DUCT SUPPORT		03
09	0531064600	OIL DUCT R.3/4 X 2755		02
10	0531064601	OIL DUCT R.3/4 X 3055		04



MARCHESAN

Technical Publications | Elaboration and Revision

ALESSANDRA PATRICIA KAWAHARA CARRILI

www.marchesan.com.br

