

ROW CROP PLANTERS

PST PLUS FLEX TITANIUM - FRAME - 5745 - CSU - DOUBLE DRAWBAR (FROM 08/2022)

Code: 0501093398
Series: S-0116
Revision: 00
Date Revision: OUTUBRO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0531043235	CABEÇALHO DUPLO MARCADOR HIDRAULICO - 5745
0111380469	PST PLUS FLEX 5745/12E500 CAB DUP ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909096537	PST PLUS FLEX TITANIUM - CSU - DOUBLE HEAD	1
0531043235	HYDRAULIC MARKER DOUBLE DRAWBAR	2
0511052306	SEMI MOUNTED DOUBLE DRAWBAR	3
0909093876	FIXER SUPPORT BOLT HOSE	4
0501054061	SEQUENCE VALVE WITH NIPPLES	5
0501054694	FLOW DIVIDING VALVE ASSY	6
0503062157	HEADER JACK	7
0909093880	DOUBLE HEADED HYDRAULIC CIRCUIT	8
0909093889	HYDRAULIC CIRCUIT TURBINE	9
0511052464	FLOW DIVIDING VALVE	10
0909093890	LIFTING HYDRAULIC CIRCUIT	11
0909093891	HYDRAULIC CIRCUIT ROW MARKER	12
0501054863	WELL AND TIRE ASSY	13
0503060414	WHEEL AND TIRE	14
0501051799	STUB SHAFT & HUB ASSY	15
0521028333	BOX WITH COMPONENTS - 5745	16
0521043443	ROW MARKER ASSEMBLY	17
0511042494	ROW MARKER DISC ASSY	18
0501054258	DRAWBAR ESTABILIZER ASSY	19
0501040364	HOSE SUPPORT ASSEMBLY	20
0501054862	AXIS LOCK RODE ASSY	21
0511053179	TRACTOR COUPLING SHAFT	22
0501051160	TRACTOR HITCH PIN	23
0511056409	TRACTOR HITCH	24
0501037958	PACKED PARTS	25
0501053835	FEMALE QUICK COUPLER	26
0511031536	PACKED PARTS MARKER ASSY	27
0501053834	MALE QUICK COUPLER	28
0909096538	PST PLUS FLEX TITANIUM - FRAME - 5745 - CSU	29
0521050047	FRAME WITH WHEEL AXLE - 5745	30
0521050048	PLATFORM ASSEMBLY - 5745	31
0531055596	5745 ALPHA FERTILIZER HOPPER SET	32
0531055589	5745 HOPPER SUPPORT WITH ALPHA FERTILIZER METERING	33
0501053788	3/4 SQUARE AXLE FASTENER	34
0501056271	GEARBOX CLOSED BEARING	35
0531055292	ALPHA FERTILIZER METERING	36
0531055273	ALPHA FERTILIZER METERING CLAMP	37
0531055376	TRANSMISSION ALPHA FERTILIZER METERING HUB	38
0503062362	FERTILIZER HOPPER	39
0503062391	FERTILIZER HOPPER	40
0521050767	SINGLE SEED HOPPER - 5745/12 E500	41
0511058724	2 HOPPERS WITH 12 CONDUCTORS ASSEMBLY	42
0511057690	3" ARTICULATED SEED CONDUCTOR	43
0511059323	PLATFORM TRANSPORT SUPPORT	44
0521055338	ROW SEED BEARING	45
0511058653	WHEELS WITH TRACTION SPRING	46
0511058654	WHEEL SUPPORT	47
0501058241	WHEEL SUPPORT CHAIN TENSIONER	48
0511052770	WHEEL WITH TIRE	49
0503062159	WHEEL WITH TIRE	50
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	51
0501058240	WHEEL FASTENER WITH TENSIONER	52
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	53
0501058244	WHEEL FIXED CHAIN TENSIONER	54
0501058242	WHEEL MOBILE CHAIN TENSIONER	55



MARCHESAN

INDEX


0521050054	WHEELS TRACTION SPRING WITHOUT TRANSMISSION	56
0521050053	WHEEL SUPPORT WITHOUT TRANSMISSION	57
0521055239	WHEEL WITH TIRE WITHOUT TRANSMISSION	58
0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	59
0511056536	LADDER ASSEMBLY	60
0511054971	JACK ASSEMBLY	61
0511054601	HITCH ARTICULATED TRACTOR	62
0511057333	DRAWBAR ASSEMBLY - 3495/4045/4395/4845/5345/5745	63
0511057270	DRAWBAR EXTENDER	64
0511058656	CYLINDER SET - 4845/5345/5745	65
0521054233	HYDRAULIC CYLINDER	66
0511056736	HOSE SUPPORT	67
0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	68
0521050114	SEMI-ASSEMBLED HYDRAULIC MARKER - 5745	69
0511058449	HYDRAULIC CYLINDER	70
0501054649	HBM SEQUENTIAL VALVE	71
0511057845	MANUAL CANISTER	72
0521050768	LABELS KIT - 5745	73
0511059322	LIFTING SUPPORT ASSEMBLY	74
0521050115	TRANSMISSION ASSEMBLY - 5745	75
0501052560	MOTOR AXLE SIGNAL	76
0511051434	TRANSMISSION ACTUATOR	77
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	78
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	79
0511057265	TRANSMISSION CHAIN TENSIONER	80
0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	81
0511050652	CHAIN TENSIONER	82
0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	83
0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	84
0521055335	RIGHT GEAR HOUSING SET	85
0521055337	LEFT GEAR HOUSING SET	86
0511058381	RIGHT GEAR HOUSING	87
0511058382	LEFT GEAR HOUSING	88
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	89
0501048790	AXLE WITH RING	90
0501056443	GEAR HOUSING BEARING	91
0501056444	BEARING WITH ROLLER	92
0511057258	TENSIONER WITH GEAR	93
0511054363	CHAIN TENSIONER	94
0521050055	HANDRAIL ASSEMBLY - 5745	95
0511059383	HANDRAIL INTERNAL FIXER	96
0501050633	ROW MARKER DISC ASSEMBLY	97
0511053904	ROW MARKER DISC	98
0531053443	PLANTING MONITORING SET 14L SEED PM400	99
0909096539	COMPLETE SEED/FERTILIZER ROW UNIT	100
0511057277	FRONT SHORT SEED ROW WITH RIGHT TRANSMISSION	101
0511057278	FRONT LONG SEED ROW WITH RIGHT TRANSMISSION	102
0511058766	BEARING	103
0511057159	TRANSMISSION HOPPER SEED ROW	104
0511057269	CHAIN TENSIONER	105
0511059872	BEARING	106
0511058512	PROTECTION LID	107
0511057290	SEED ROW FRONT SHORT WITH TRANSMISSION	108
0511057291	SEED ROW FRONT SHORT WITH TRANSMISSION	109
0511057275	TRANSMISSION WITH LEFT SUPPORT	110




MARCHESAN

INDEX


0511057273	ASSEMBLY TRANSMISSION	111
0511057274	TRANSMISSION LOWER FRONT SEED ROW SHORT	112
0511057293	FRONT LOWER TRANSMISSION	113
0521050096	SEED HOPPER SYSTEM (CSU)	114
0521050118	3" NOZZLE SEED HOPPER	115
0511052058	SEED SYSTEM TITANIUM	116
0531054532	WHEEL SYSTEM DEPTH / COMPACTOR	117
0501056769	DEPTH WHEELS REGULATOR ASSY	118
0521051423	COMPACTOR SUPPORT	119
0501052908	COMPACTOR WHEEL WITH BEARING	120
0511050077	WHEEL STRIPED	121
0511052287	DEPTH WHEEL HUB ASSY	122
0511058639	SHORT FERTILIZER ROW WITH DDD/DC20	123
0511058640	LONG FERTILIZER ROW WITH DDD/DC20	124
0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	125
0511058634	SUPPORT LONG	126
0511057272	LH SHORT ARM ROW FERTILIZER	127
0511057271	RH LONG ARM ROW FERTILIZER	128
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	129
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	130
0511058630	20" DISC BLADE	131
0511058648	HUB WITH 20" DISC BLADE	132
0511056909	DISC BLADE HUB WITHOUT DISC	133
0511056621	RIGHT REAR SEED ROW	134
0511056622	LEFT REAR SEED ROW	135
0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8	136
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	137
0511056586	15 X 15 SEED DDD LEFT	138
0511052301	SUPPORT DDD 15 RIGHT	139
0511052302	LH SUPPORT DDD GUIDE	140
0511053173	CUBE LOW RIGHT WITH DISC 15	141
0511053172	LEFT LOW CUBE WITH DISC 15	142
0521050525	FIXER FERTILIZER CONDUCTOR	143
0531052986	PIVOT SUPPORT	144
0501110804	SCARIFIER ROD WITH POINT	145
0521057957	FIXED ROD EXTENSION WITH FIXATION	146
0503062066	DISC SET WITH CORN RING	147
0503062067	DISC SET / RING SOY 90F TITANIUM	148
0511052024	FAST CLOSING SET	149



Item	Code	Description	See page	QT
01	0531043235	HYDRAULIC MARKER DOUBLE DRAWBAR	2	01
02	0909096538	PST PLUS FLEX TITANIUM - FRAME - 5745 - CSU	29	01



Item	Code	Description	See page	QT
01	0511052306	SEMI MOUNTED DOUBLE DRAWBAR	3	01
02	0501054863	WELL AND TIRE ASSY	13	02
03	0521028333	BOX WITH COMPONENTS - 5745	16	01




Item	Code	Description	See page	QT
01	0521063459	DOUBLE DRAWBAR FRAME		01
02	0511064219	FORK WHEEL DRAWBAR DOUBLE		02
03	0503010007	3982/3920 ROLLER BEARING		02
04	0503010059	33287/33462 ROLLER BEARING		02
05	0503013106	SEAL 00085-B		02
06	0502040080	FLANGE NUT R.2.1/2 UN		02
07	0503011345	1/4" X 3-1/2" COTTERPIN		02
08	0541013225	WHEEL BOX COVER		02
09	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		12
10	0503011444	SPRING WASHER		12
11	0503010002	1800 GREASE FITTING		03
12	0909093876	FIXER SUPPORT BOLT HOSE	4	04
13	0531017560	DISPLAYED IDENTIFICATION		10
14	0502012702	BODY SUPPORT CLAMP		11
15	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		11
16	0503010180	7/16" SPRING WASHER		11
17	0501053835	FEMALE QUICK COUPLER	26	08
18	0503010217	501040 CLAMPING RING (FOR AXLE)		16
19	0501053834	MALE QUICK COUPLER	28	04
20	0501054061	SEQUENCE VALVE WITH NIPPLES	5	01
21	0503010237	3/8" X 1" BOLT		02
22	0503010025	3/8" SPRING WASHER		02
23	0503010026	3/8" NUT		02
24	0502012702	BODY SUPPORT CLAMP		03
25	0503011103	7/16" X 2-1/2" BOLT		03
26	0503010180	7/16" SPRING WASHER		03
27	0511066114	CONDUCTOR VALVE SUPPORT		01
28	0501054694	FLOW DIVIDING VALVE ASSY	6	01
29	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
30	0501013518	FLAT WASHER		04
31	0503010143	1/4" SPRING WASHER		02




PST PLUS FLEX TITANIUM - FRAME - 5745 - CSU - DOUBLE
SEMI MOUNTED DOUBLE DRAWBAR

Page 3
0511052306


Item	Code	Description	See page	QT
32	0503010144	1/4" NUT		02
33	0503062157	HEADER JACK	7	01
34	0521010549	COUPLING SHAFT		01
35	0503030168	HITCH PIN CLIP		01
36	0909093880	DOUBLE HEADED HYDRAULIC CIRCUIT	8	01
37	0501054862	AXIS LOCK RODE ASSY	21	02




Item	Code	Description	See page	QT
01	0511064222	FIXER SUPPORT BOLT HOSE		02
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0502012702	BODY SUPPORT CLAMP		06
06	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
07	0503010180	7/16" SPRING WASHER		04




Item	Code	Description	See page	QT
01	0501011460	7/8 NF REDUCTION NIPPLE		02
02	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503030923	3/4" UNF X 13/16UN OFS X 40 NIPPLE		03
03	0503010190	2-114 N 3006-9B O'RING		03




Item	Code	Description	See page	QT
01	0503062157	HEADER JACK	7	01




Item	Code	Description	See page	QT
01	0909093889	HYDRAULIC CIRCUIT TURBINE	9	01
02	0909093890	LIFTING HYDRAULIC CIRCUIT	11	01
03	0909093891	HYDRAULIC CIRCUIT ROW MARKER	12	01
04	0521063459	DOUBLE DRAWBAR FRAME		01
05	0909093876	FIXER SUPPORT BOLT HOSE	4	04
06	0501053835	FEMALE QUICK COUPLER	26	08
07	0501053834	MALE QUICK COUPLER	28	07




Item	Code	Description	See page	QT
01	0521063568	SUPPORT VALVE		01
02	0511052464	FLOW DIVIDING VALVE	10	01
03	0501080849	1/2" X 2100 TR-TM HOSE		06
04	0501080185	HOSE 1/2 X 4000 TR-TM		03
05	0909093876	FIXER SUPPORT BOLT HOSE	4	04
06	0501053834	MALE QUICK COUPLER	28	03
07	0501053835	FEMALE QUICK COUPLER	26	06




Item	Code	Description	See page	QT
01	0503013791	DOUBLE MOTOR		01
02	0541018940	7/8 NF X R 1 BSPT X 55 NIPPLE		01
03	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
04	0503010025	3/8" SPRING WASHER		04
05	0503011051	M10 X 0.6" NUT		04




Item	Code	Description	See page	QT
01	0521063568	SUPPORT VALVE		01
02	0501054694	FLOW DIVIDING VALVE ASSY	6	01
03	0501080631	1/2" X 2100 TC-TM HOSE		04
04	0501080185	HOSE 1/2 X 4000 TR-TM		02
05	0909093876	FIXER SUPPORT BOLT HOSE	4	04
06	0501053834	MALE QUICK COUPLER	28	02
07	0501053835	FEMALE QUICK COUPLER	26	04




Item	Code	Description	See page	QT
01	0521063568	SUPPORT VALVE		01
02	0501054061	SEQUENCE VALVE WITH NIPPLES	5	01
03	0501080848	3/8" X 2000 TR-TM HOSE		04
04	0501081765	HOSE 1/2 X 4300 TC-TM		02
05	0909093876	FIXER SUPPORT BOLT HOSE	4	02
06	0501053834	MALE QUICK COUPLER	28	02
07	0501053835	FEMALE QUICK COUPLER	26	04




Item	Code	Description	See page	QT
01	0503060414	WHEEL AND TIRE	14	01
02	0501051799	STUB SHAFT & HUB ASSY	15	01
03	0531015109	WHEEL AXLE LOCK		02



Item	Code	Description	See page	QT
01	0503012108	WHEEL 10 LB X 15 X 8F X 203		01
02	0503010860	AIR CHAMBER 11L 15		01
03	0503011469	RIB TIRE BL - 12L		01



Item	Code	Description	See page	QT
01	0502010908	CARRYING WHEEL HUB	01	
02	0503012159	4.0" X 2.5" X 0.5" SEAL 5144	01	
03	0503010008	3780/3720 ROLLER BEARING	01	
04	0503010328	25590/25523 ROLLER BEARING	01	
05	0503012162	5046 BAG SEAL RING	01	
06	0521011209	425 TRANSP WHEEL AXLE	01	
07	0511015949	LOCK NUT	01	
08	0503010329	LOCK WASHER	01	
09	0503010330	KM 9 LOCKNUT	01	
10	0501010086	FLAT WASHER	01	
11	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR	08	
12	0503010064	5/8 UNF CONIC NUT	08	
13	0503011052	1.1/4" X 0.77" CASTLE NUT	02	
14	0503010067	3/16" X 2.1/2" COTTER PIN	02	




Item	Code	Description	See page	QT
01	0501100160	WOODEN BOX 2450X1050X920		01
02	0511064220	COUPLING SUPPORT DOUBLE DRAWBAR		02
03	0531017551	COUPLING SUPPORT FIXING BASE		02
04	0521043443	ROW MARKER ASSEMBLY	17	01
05	0521067307	STABILITY FIXER		02
06	0521014754	FIXING BASE ESTABILIZER		02
07	0501110262	245 ADJUSTMENT NUT		01
08	0501069529	653 TURNBUCKLE		02
09	0501054258	DRAWBAR ESTABILIZER ASSY	19	01
10	0511064217	TURNBUCKLE WITH EAR		02
11	0501068300	TURNBUCKLE WITH EAR		02
12	0501061056	RH LOCKNUT WITH HANDLER		04
13	0511060916	TURNBUCKLE WITH GLOVE		01
14	0511061029	TURNBUCKLE WITH GLOVE		01
15	0511060919	TURNBUCKLE WITH GLOVE		01
16	0501066284	SUPPORT FRONT TURNBUCKLE FIXER		02
17	0521012329	3/4 UNC X 130 X 173 FASTENER		02
18	0502012702	BODY SUPPORT CLAMP		04
19	0511064228	HOSE HOLDER		04
20	0511064310	FIXER PLATE FASTENER		02
21	0521014021	1/2" X 4.5" X 5.4" FASTENER		06
22	0501040364	HOSE SUPPORT ASSEMBLY	20	03
23	0521067306	SUPPORT FIXING REAR STABILIZER		02
24	0511064353	FASTENER		02
25	0501080779	1/2 X 1500 TM-TM HOSE		02
26	0501080850	3/8" X 6100 TC-TM HOSE		04
27	0501054862	AXIS LOCK RODE ASSY	21	02
28	0511053179	TRACTOR COUPLING SHAFT	22	01
29	0501051160	TRACTOR HITCH PIN	23	02
30	0511056409	TRACTOR HITCH	24	01
31	0571017510	GLOVE ARTICULATED HITCH		01



PST PLUS FLEX TITANIUM - FRAME - 5745 - CSU - DOUBLE
BOX WITH COMPONENTS - 5745

Page 16
0521028333

Item	Code	Description	See page	QT
32	0501037958	PACKED PARTS	25	01
33	0511031536	PACKED PARTS MARKER ASSY	27	01
34	0511031535	BAG WITH INSTRUCTION MANUAL		01



Item	Code	Description	See page	QT
01	0511065487	REGULATOR SPINDLE		02
02	0511065484	ROW MARK ARM		02
03	0511065480	RIGHT INTERMEDIATE ARM		01
04	0511065481	LEFT INTERMEDIATE ARM		01
05	0521062492	RIGHT SUPPORT SMALLER		01
06	0521062493	LEFT SUPPORT		01
07	0511065479	BEFORE ARM (ROW MARKER)		02
08	0511065475	ADJUSTMENT ROD		02
09	0511065477	2000 TURNBUCKLE		02
10	0511065476	LARGER LEVER		02
11	0511042494	ROW MARKER DISC ASSY	18	02
12	0511056753	PIVOT SHAFT		02
12A	0541012193	MARK ARM ARTICULACION ALXE		01
12B	0503011052	1.1/4" X 0.77" CASTLE NUT		01
13	0511056754	PIVOT SHAFT		02
13A	0541012194	INTERMEDIATE ARM ARTIC ALXE		01
13B	0503011052	1.1/4" X 0.77" CASTLE NUT		01
14	0541015714	CYLINDER ARTICULACION ALXE		02
15	0511056755	PIVOT SHAFT		02
15A	0541012195	ARM BEFORE ARTICULACION AXLE		01
15B	0503011052	1.1/4" X 0.77" CASTLE NUT		01
16	0541012196	SMALLER LEVER		02
17	0511058227	HYDRAULIC CYLINDER 38,10 X 63,50 X 608 X 290		02
18	0521061778	FASTENER		06
19	0511066355	ROW MARK FIXER SUPPORT		02
20	0502010584	CARRYING-WHEELS SUPPORT FIXER		12
21	0541015917	MARK ARM GUIDE		02
22	0502012702	BODY SUPPORT CLAMP		06
23	0531011180	UPPER BODY CLIP		06
24	0501080458	3/8" X 315" TC-TM HOSE ASSY		04
25	0503011070	BEATER		02




PST PLUS FLEX TITANIUM - FRAME - 5745 - CSU - DOUBLE
ROW MARKER ASSEMBLY

Page 17
0521043443


Item	Code	Description	See page	QT
26	0511017592	11.8" X 1.6" TRANSPORT LOCK		02

ROW MARKER DISC ASSY


0511042494




Item	Code	Description	See page	QT
01	0502011907	DEPTH CONTROL WHEEL HUB		01
02	0503010269	6204 BALL BEARING		02
03	0503010689	SEAL 00763-BR		01
04	0503011105	SEAL RING		01
05	0501013636	SPACING SLEEVE		01
06	0602023110	DR16X3 NOTCHED DISC BLADE		01
07	0503010358	5/16" X 5/8" BOLT		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0511065478	ROW MARKER DISC AXLE		01
11	0503010878	5/8" SELF ALIGNING NUT		01
12	0521019178	PROTECTION LID		01
13	0503030757	2.9" X 2" X 0.02" JOINT		01
14	0503814729	BOLT		03
15	0503011441	SPRING WASHER		03
16	0503010691	1/4" GREASE FITTING		01
17	0501069226	ROW MARKER ROD STOP		01
18	0501011778	3/8" X 2-1/2" BOLT		04
19	0503010025	3/8" SPRING WASHER		04
20	0503010026	3/8" NUT		04
21	0503010023	3/4" SPRING WASHER		01
22	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0501060409	HOSE SOPPORT ASSY		01
02	0503011442	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01



Item	Code	Description	See page	QT
01	0511064229	LOCK PIN		01
02	0503030978	COMPRES SPRING		01
03	0503010131	3/16" X 1-1/2" COTTERPIN		01
04	0503010292	701164 6 X 40 SPRING PIN		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0521010681	BUSHING COUPLING BODY		01
02	0502040556	HITCH TURNER		01
03	0521010639	COUPLING SHAFT		01
04	0503010571	1/4" X 1.1/2 COTTERPIN		01

TRACTOR HITCH


0511056409




Item	Code	Description	See page	QT
01	0571017512	HITCH JOINT		01
02	0571017511	SLEEVE HITCH ARTICULATION		01
03	0502040850	U TRACTOR COUPLING		01
04	0571012612	PIVOT SHAFT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503016482	BOLT		02
11	0503033731	COMPRESSION SPRING LEFT		02
12	0503011331	3/8 BALL		02
13	0503010002	1800 GREASE FITTING		01
14	1882970002	GREASE SOAP		01
15	0503010378	CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0501014172	1" X 8" BOLT		08
02	0503011135	BOLT		04
03	0501013233	5/8" X 2-3/4" BOLT		08
04	0503010797	3/4" X 4" BOLT		08
05	0503010180	7/16" SPRING WASHER		04
06	0503010019	1/2" SPRING WASHER		12
07	0503010027	5/8" SPRING WASHER		04
08	0503010023	3/4" SPRING WASHER		11
09	0503010012	1" SPRING WASHER		08
10	0503010060	1/2 UNC G.5 ZN HEX NUT		12
11	0503010013	5/8" NUT		04
12	0503010014	3/4" HEX NUT		11
13	0501010059	1.5/8 NUT		08
14	0521010572	0.9" X 2.9" COUPLING SHAFT		02
15	0521010594	1.1" X 4.1" COUPLING SHAFT		06
16	0503031035	HITCH PIN CLIP		07
17	0503030085	LOCK PIN		02
18	0503010002	1800 GREASE FITTING		11
19	0501053834	MALE QUICK COUPLER	28	02
20	0501053835	FEMALE QUICK COUPLER	26	02
21	0503012412	5/8 UNC SELF LOCKING NUT		08




Item	Code	Description	See page	QT
01	0503011883	QUICK CONNECTION COVER		01
02	0503011628	FEMALE QUICK COUPLER		01



Item	Code	Description	See page	QT
01	0503010523	1/4" X 2" COTTERPIN		04
02	0503010038	3/16 X 2 COTTERPIN		06
03	0503011084	3/4" X 5" BOLT		24
04	0503010023	3/4" SPRING WASHER		24
05	0503010014	3/4" HEX NUT		24
06	0503011267	BOLT 5/8 UNC X 1.1/2 C S G.5 ZN		04
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		12
08	0503010027	5/8" SPRING WASHER		12
09	0503010013	5/8" NUT		12
10	0501010322	FLAT WASHER		24
11	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		06
12	0503010180	7/16" SPRING WASHER		06
13	0503010244	7/16" NUT		06
14	0501053834	MALE QUICK COUPLER	28	04
15	0503010019	1/2" SPRING WASHER		02
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0501068994	8,30 X 78 LOCK PIN		02
18	0503030168	HITCH PIN CLIP		02
19	0501014063	25 X 55 COUPLING SHAFT		10
20	0503030085	LOCK PIN		10
21	0501019435	32 X 50 X 1.5 FLAT WASHER		04




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521050047	FRAME WITH WHEEL AXLE - 5745	30	01
02	0521050048	PLATFORM ASSEMBLY - 5745	31	01
03	0531055596	5745 ALPHA FERTILIZER HOPPER SET	32	01
04	0521050767	SINGLE SEED HOPPER - 5745/12 E500	41	01
05	0511059323	PLATFORM TRANSPORT SUPPORT	44	04
06	0521055338	ROW SEED BEARING	45	06
07	0511058653	WHEELS WITH TRACTION SPRING	46	04
07.	0521050054	WHEELS TRACTION SPRING WITHOUT TRANSMISSION	56	02
08	0511056536	LADDER ASSEMBLY	60	02
09	0511054971	JACK ASSEMBLY	61	02
10	0511054601	HITCH ARTICULATED TRACTOR	62	01
11	0511057333	DRAWBAR ASSEMBLY 3495/4045/4395/4845/5345/5745	- 63	01
12	0511057270	DRAWBAR EXTENDER	64	01
13	0511058656	CYLINDER SET - 4845/5345/5745	65	01
14	0501068994	8,30 X 78 LOCK PIN		02
15	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
16	0501047895	ROD STOP		02
17	0501047885	ROD STOP		02
18	0501047886	ROD STOP		02
19	0501047887	ROD STOP		02
20	0511056736	HOSE SUPPORT	67	01
21	0501065677	STRUT		02
22	0503030168	HITCH PIN CLIP		02
23	0581012909	3/4 X 2940 AXLE HEX		01
24	0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	68	01
25	0503010003	1845 GREASE FITTING		06
26	0511053179	TRACTOR COUPLING SHAFT	22	01
27	0521013022	TRANSPORT LOCK		02
28	0503010780	N-2050 AMENDMENT		02
29	0503010951	REDUCTION		04


Item	Code	Description	See page	QT
30	0521050114	SEMI-ASSEMBLED HYDRAULIC MARKER - 5745	69	01
31	0511054314	TRANSMISSION AXLE LOCK SLEEVE		28
31A	0502012699	TRANSMISSION HUB LOCK SLEEVE		01
31B	0503010256	3/8" X 3/4" BOLT		01
32	0511057845	MANUAL CANISTER	72	01
33	0521050768	LABELS KIT - 5745	73	01
34	0511059322	LIFTING SUPPORT ASSEMBLY	74	02
35	0521050115	TRANSMISSION ASSEMBLY - 5745	75	01
36	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		04
37	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
38	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
39	0503010019	1/2" SPRING WASHER		08
40	0503010060	1/2 UNC G.5 ZN HEX NUT		08
41	0521050055	HANDRAIL ASSEMBLY - 5745	95	01
42	0503011750	AMENDMENT WITH LOCK		06
43	0503011751	REDUCTION		06
44	0501214546	SPRING KEY		01
45	0521013164	EXTENSOR		02
46	0501011310	FIXER LOCK		08
47	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		08
48	0503010019	1/2" SPRING WASHER		08
49	0503010060	1/2 UNC G.5 ZN HEX NUT		08
50	0501050633	ROW MARKER DISC ASSEMBLY	97	02
51	0503014120	CHAIN		01
52	0503014321	CABLE STEEL SHACKLE		02
53	0581012908	3/4 X 2755 AXLE HEX		01
54	0531053443	PLANTING MONITORING SET 14L SEED PM400	99	01
55	0571018391	GUTTER 25 X 58 X 1200		04
56	0571017368	SUPPORT GUTTER		08
57	0501011643	3/8 X 1"BOLT		08
58	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
59	0503010025	3/8" SPRING WASHER		08
60	0503010026	3/8" NUT		08
61	0503017607	EXTENSOR CABLE PM400 6.0M 18X18 020010557		01
62	0909096539	COMPLETE SEED/FERTILIZER ROW UNIT	100	12




Item	Code	Description	See page	QT
01	0521067308	FRAME - 5745		01
02	0521067388	PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	SCREW		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0501812140	FLAT WASHER		16
07	0503011445	SPRING WASHER		08
08	0503810013	NUT 5/8 NC		08




Item	Code	Description	See page	QT
01	0581012899	PLATFORM - 5745		02
02	0503010237	3/8" X 1" BOLT		06
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		12
04	0503010025	3/8" SPRING WASHER		06
05	0503010026	3/8" NUT		06




Item	Code	Description	See page	QT
01	0531055589	5745 HOPPER SUPPORT WITH ALPHA FERTILIZER METERING	33	01
02	0503062362	FERTILIZER HOPPER	39	01
03	0503062391	FERTILIZER HOPPER	40	02
04	0503013751	3/8 UNC X 1.1/4 BOLT		20
05	0571019051	FIXER HOPPER WASHER		20
06	0503012535	3/8" SPRING WASHER		20
07	0503012531	3/8" INOX NUT		20
08	0503011957	NYLON LUG		02
09	0503010371	5/16" X 1" BOLT		04
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
11	0503010337	5/16" NUT		04
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		14
13	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		28
14	0503010025	3/8" SPRING WASHER		14
15	0503010026	3/8" NUT		14




Item	Code	Description	See page	QT
01	0531064286	5745 RIGHT FERTILIZER HOPPER SUPPORT		01
02	0531064285	5745 LEFT FERTILIZER HOPPER SUPPORT		01
03	0501053788	3/4 SQUARE AXLE FASTENER	34	08
04	0511061759	22Z P12,70 FQ 3/4" GEAR		02
05	0503030303	SUPPORT WASHER		04
06	0501056271	GEARBOX CLOSED BEARING	35	02
07	0503011953	5/16" X 1" BOLT		04
08	0501010694	FLAT WASHER		04
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
10	0503010337	5/16" NUT		04
11	0531055292	ALPHA FERTILIZER METERING	36	14
12	0503031527	AGRICULTURAL BEARING		06
13	0551016112	SQUARE SHAFT		02
14	0561018739	SQUARE SHAFT		02
15	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		02
15A	0501214269	SQUARE SLEEVE		02
15B	0513010701	LOCK PIN		02




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0503010025	3/8" SPRING WASHER		04
02	0503010026	3/8" NUT		04
03	0513010742	RETAINER 47 X 30 X 10 BRG 5285		01
04	0501214879	HORIZONTAL SEAL LID ALPHA FERTILIZER METERING		01
05	0503035799	ALPHA FERTILIZER DOSAGE NOZZLE		01
06	0503035831	ALPHA FERTILIZER METERING COLLECTOR		01
07	0531055273	ALPHA FERTILIZER METERING CLAMP	37	01
08	0513010692	ALLEN SCREW 1/4 UNC X 7/8 C FLAT SI INOX		04
09	0501011643	3/8 X 1" BOLT		04
10	0503035796	REAR FIXER ALPHA FERTILIZER METERING COLLECTOR		02
11	0513010695	ALLEN SCREW 1/4 UNC X 7/8 CCSI INOX		04
12	0531055376	TRANSMISSION ALPHA FERTILIZER METERING 38 HUB		01
13	0502013049	ALPHA FERTILIZER DOSAGE HOPPER		01
14	0502013048	FLANGE FIXER BODY ALPHA FERTILIZER METERING		01
15	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
15A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
15B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
16	0503035829	ADHESIVE LABEL LOGO TATU 38 X 28 X 0.30 ALPHA FERTILIZER METERING		01
17	0531055518	WORM THREAD ASSEMBLED		01
17A	0531064265	WORM THREAD		01
17B	0503035859	SUPPORT SLEEVE		01
18	0501111143	COATING WITH GUIDE ASSY SUPPLEMENTATION FERTILIZER METERING		01
18A	0501214951	FERTILIZER DOSAGE COATING		01
18B	0531055519	GUIDE ASSY WITH SUPPLEMENTATION		01




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0502013050	TRANSMISSION ALPHA FERTILIZER METERING HOPPER		01
02	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
03	0503011800	SEAL RING		02
04	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
05	0503016065	ROLLER BEARING		02
06	0501214237	TRANSMISSION HOPPER ALPHA FERTILIZER METERING SLEEVE		01
07	0503019373	6006 2RS1 NATIONAL BEARING		02
08	0503012858	502075 CLAMPING RING (FOR HOLE)		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01
10	0501214501	ALPHA FERTILIZER METERING LID LOCK AXIS		01
11	0501214238	SHAFT LOCK SLEEVE HOPPER TRANSMISSION ALPHA FERTILIZER METERING		01
12	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01




Item	Code	Description	See page	QT
01	0503034085	BEAN FERTILIZER ASSY		01
02	0503034086	HOPPER LID		01
03	0503034087	LID ARTICULATING TUBE		02
04	0503034088	WASHER		04
05	0503010131	3/16" X 1-1/2" COTTERPIN		04
06	0503034130	PLATE		01
07	0503032053	BOLT C.A.S.I		04
08	0503034220	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0503034127	FERTILIZER HOPPER		01
02	0503034129	LOWER HOPPER LID		01
03	0503034128	UPPER HOPPER LID		01
04	0503034130	PLATE		01
05	0503032053	BOLT C.A.S.I		04
06	0503034220	FLAT WASHER		04
07	0503034087	LID ARTICULATING TUBE		04
08	0503034088	WASHER		08
09	0503010131	3/16" X 1-1/2" COTTERPIN		08




Item	Code	Description	See page	QT
01	0511058724	2 HOPPERS WITH 12 CONDUCTORS ASSEMBLY	42	01
02	0511058510	FIXER SUPPORT		04
02A	0521067305	FIXER SUPPORT		01
02B	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02C	0503017857	BOLT 5/8 UNF 4		04
02D	0503010811	5/8" UNF SELF ADJUSTING NUT		04
02E	0501010942	3/8" X 1-1/4" BOLT		04
02F	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
02G	0503010025	3/8" SPRING WASHER		04
02H	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521063401	SINGLE SEED HOPPER FIXING LOCK		04
02	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR	43	12
06	0571015773	SUPPORT SEED		02
07	0501011643	3/8 X 1"BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		48
09	0521064874	07 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION	01	
02	0501010942	3/8" X 1-1/4" BOLT	01	
03	0503010025	3/8" SPRING WASHER	01	
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN	01	
05	0503010209	3/8" UNC BUTTERFLY NUT	01	
06	0521066332	CONDUCTOR WITH FLANGE	01	
07	0503010371	5/16" X 1" BOLT	02	
08	0501010694	FLAT WASHER	02	
09	0503010179	LOCK WASHER 5/16 ZN 1K01528	02	
10	0503010337	5/16" NUT	02	
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT	01	



Item	Code	Description	See page	QT
01	0581011989	SIDE BODY FIXER PLATFORM		01
02	0551019884	45 X 50 X 3/8 FASTENER		01
03	0503010025	3/8" SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
07	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING		01
03A	0502012030	HOUSING BEARING		01
03B	0503012861	6006 2RS BALL BEARING		01
03C	0503012858	502075 CLAMPING RING (FOR HOLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02
07	0501013518	FLAT WASHER		02
08	0501010694	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511058654	WHEEL SUPPORT	47	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	52	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01

WHEEL SUPPORT


0511058654




Item	Code	Description	See page	QT
01	0521066716	WHEEL ARM ASSY		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
08	0503010027	5/8" SPRING WASHER		01
09	0501058241	WHEEL SUPPORT CHAIN TENSIONER	48	01
10	0503013030	5/8" X 3.1/4" BOLT		01
11	0551017715	FLAT WASHER		02
12	0511052770	WHEEL WITH TIRE	49	01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8" SPRING WASHER		02
15	0503011167	M16 X 2 X 30 BOLT		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	50	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	51	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	53	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	54	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	55	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503011119	7/8" X 6" BOLT		04
02	0501014251	FLAT WASHER		04
03	0521050053	WHEEL SUPPORT WITHOUT TRANSMISSION	57	01
04	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0531016887	CARRYING WHEEL AXLE ARM		01
03	0503010523	1/4" X 2" COTTERPIN		01
04	0503010003	1845 GREASE FITTING		01
05	0511050681	TRACTION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0561016062	SPRING HITCH		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		04
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0521066716	WHEEL ARM ASSY		01
11	0503011167	M16 X 2 X 30 BOLT		02
12	0591010589	BODY LOCK WHEEL		02
13	0521055239	WHEEL WITH TIRE WITHOUT TRANSMISSION	58	01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	50	01
02	0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	59	01




Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		02
02	0503010237	3/8" X 1" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511069636	LADDER		01
06	0503011179	3/8" X 2-1/4" BOLT		02
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
08	0503013357	3/8" SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0502012806	SUPPORT REAR FIXER DRAWBAR		04
02	0502012789	FIXER SUPPORT FERTILIZER ROW		04
03	0503017960	5/8" X 3-12" BOLT		16
04	0503010811	5/8" UNF SELF ADJUSTING NUT		16
05	0501010191	1" X 6" BOLT		04
06	0503010012	1" SPRING WASHER		04
07	0501010059	1.5/8 NUT		04
08	0502012805	SUPPORT FRONT FIXER DRAWBAR		04
09	0502012789	FIXER SUPPORT FERTILIZER ROW		04
10	0503017960	5/8" X 3-12" BOLT		16
11	0503010811	5/8" UNF SELF ADJUSTING NUT		16
12	0521065958	DRAWBAR		01
13	0561019087	DRAWBAR TRANSPORT LOCK		01
14	0551014099	COUPLING SHAFT 31,75 X 185		01
15	0521010544	1.2" X 4.9" COUPLING SHAFT		01
16	0503030085	LOCK PIN		02
17	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521065959	JACK R.1.1/2 UNC RIGHT X 240		01
03	0521065960	JACK R.1.1/2 UNC LEFT X 240		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521054233	HYDRAULIC CYLINDER	66	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521010547	1.2" X 6.5" COUPLING SHAFT		02
04	0503010523	1/4" X 2" COTTERPIN		04
05	0501047888	ROD STOP		02
06	0571019384	SPACING SLEEVE 16,30 X 30 X 104		02
07	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		02
08	0503010027	5/8" SPRING WASHER		02
09	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0521069306	50.8 X 337.5 EXTENSION WITH 32.5 BUSHING		01
02	0521069305	101,6 X 438,5 TUBE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0503010004	1890 GREASE FITTING		01
05	0502012821	50.80 X 101.60 RING SUPPORT		01
06	0503011061	8-342 BACK-UP RING		02
07	0503018024	RING BS		01
08	0503010338	2-342 N 3006-9B O'RING		02
09	0503018026	1870-2000-375 B GASKET		01
10	0503018025	RING GUIDE		01
11	0503010039	D-2000 SCRAPER RING		01
12	0502012822	101.60 END CAP		01
13	0502012842	50,80 X 101,60 PISTON		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503018029	2-217 O'RING		01
16	0503015633	SELEMASTER SEALING		01



Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0511057335	HOSE KIT HYDRAULIC		01
01A	0501080025	3/8 X 1400 TR-TC HOSE		04
01B	0521052285	TC-TM HOSE ASSY		01
01BA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01BD	0503018952	PLASTIC BOLT		06
01C	0521052330	HOSE 3/8 X 4000 TC-TM PRET/AZUL		01
01CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01CB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01CC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01CD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	28	02
03	0511058120	KIT VALVE SUPPORT		01
03A	0521066354	OIL DISTRIBUTOR BODY		02
03B	0502010477	HOSE CLAMP		04
03C	0503011268	3/8" X 2-1/2" BOLT		02
03D	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
03E	0503010025	3/8" SPRING WASHER		02
03F	0503010026	3/8" NUT		02
04	0503013100	NYLON CLAMP		02
05	0502012702	BODY SUPPORT CLAMP		04
06	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
07	0503010180	7/16" SPRING WASHER		04
08	0531011180	UPPER BODY CLIP		04
09	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8 UNC SELF LOCKING NUT		04
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0511061811	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0503012412	5/8 UNC SELF LOCKING NUT		02
13	0511058449	HYDRAULIC CYLINDER	70	02
14	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
15	0503010523	1/4" X 2" COTTERPIN		02
16	0511015779	1" X 4.2" AXLE		02
17	0503010523	1/4" X 2" COTTERPIN		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	8,30 X 78 LOCK PIN		02
20	0503030168	HITCH PIN CLIP		02
21	0501066949	1235 TURNBUCKLE		02
22	0503011854	5/8" X 1-1/4" BOLT		04
23	0501054649	HBM SEQUENTIAL VALVE	71	01
24	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
25	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
26	0503010025	3/8" SPRING WASHER		02
27	0521050113	HYDRAULIC MARKER HAND SET		01
27A	0501082108	TR-TR HOSE		02
27B	0501080605	3/8" X 160" TR-TC HOSE ASSY		02
27C	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
27CA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01


Item	Code	Description	See page	QT
27CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
27CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
27CD	0503018952	PLASTIC BOLT		06
27D	0521052850	3/8 X 4200 TC-TM PURPLE/BLUE HOSE		01
27DA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
27DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
27DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
27DD	0503018952	PLASTIC BOLT		06
28	0501053834	MALE QUICK COUPLER	28	02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		06
32	0503010180	7/16" SPRING WASHER		06
33	0503010244	7/16" NUT		02
34	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
35	0581010011	VALVE FIXING SUPPORT		01




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01



Item	Code	Description	See page	QT
01	0503033892	ADHESIVE LABEL LOGO TATU HOPPER 190 X 720	01	
02	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530	01	
03	0503034228	ADHESIVE LABEL PST FLEX PLUS LOWER (05 NOZZLES)	02	
04	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)	02	
05	0503034258	ADHESIVE LABEL	01	
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	02	
07	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	04	
08	0503033421	ADHESIVE LABEL 7 NUMBER FOR PLANTING	02	
09	0503033424	DIRECT PLANTIO ADHESIVE LABEL	02	
10	0503031428	READ MANUAL DECAL	01	
11	0503031942	ADHESIVE LABEL	01	
12	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2	02	
13	0503031565	ADHESIVE LABEL CARE	02	
14	0503031566	ADHESIVE LABEL	02	
15	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
16	0503031425	ADHESIVE LABEL ATTENTION	02	
17	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER	02	
18	0503031669	ADHESIVE LABEL	01	
19	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
20	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
21	0503032930	ADHESIVE LABEL DANGER	07	
22	0503031087	ADHESIVE LABEL	01	
23	0503034003	SERIAL NUMBER TAG 61 X 118	01	
24	0503010001	3.2 X 5.5 RIVET	04	
25	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
26	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521067033	FRAME LIFTING SUPPORT		01
03	0503017960	5/8" X 3-12" BOLT		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	48	04
13	0581012892	MOTOR SHAFT		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	76	02
16	0511051434	TRANSMISSION ACTUATOR	77	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	78	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	79	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		02
20	0501053788	3/4 SQUARE AXLE FASTENER	34	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING	35	02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
25	0503010025	3/8" SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	80	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		06
30	0503010140	1/8" X 3/4" COTTERPIN		02
31	0571018846	DISASSEMBLE LEVER		02


Item	Code	Description	See page	QT
32	0503033942	COMPACTOR WHEEL REGULATOR LID		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
37	0503012412	5/8 UNC SELF LOCKING NUT		04
38	0511061759	22Z P12,70 FQ 3/4" GEAR		02
39	0501053788	3/4 SQUARE AXLE FASTENER	34	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING	35	02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
44	0503010025	3/8" SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	80	02
47	0511065209	20Z GEAR		02
48	0501053788	3/4 SQUARE AXLE FASTENER	34	02
49	0503030303	SUPPORT WASHER		02
50	0503010292	701164 6 X 40 SPRING PIN		02
51	0521018630	1.4" X SQUARE 0.8" WASHER		02
52	0501056271	GEARBOX CLOSED BEARING	35	02
53	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
54	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
55	0503010025	3/8" SPRING WASHER		04
56	0503010026	3/8" NUT		04
57	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	81	02
58	0511050652	CHAIN TENSIONER	82	04
59	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	83	02
60	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
61	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
62	0503015001	40-1 X 153 CHAIN LINK + MENDING		02
63	0511069678	LH LOWER LEVER		02
64	0551019159	LEVER FIXER BODY		02
65	0561016468	FASTENER		02
66	0503011336	1/2" HEX SELF ADJUSTING NUT		04
67	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
68	0503010140	1/8" X 3/4" COTTERPIN		04
69	0521055335	RIGHT GEAR HOUSING SET	85	01
70	0521055337	LEFT GEAR HOUSING SET	86	01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CS G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0541011713	TENSIONER CHAIN LOWER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551019171	CHAIN TIGHTENER AXLE		01
02	0503011410	ROLLER BEARING		01
03	0511062169	21Z P 1/2" GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503011105	SEAL RING		01
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0571010265	16.5 X 40 X 3 FLAT WASHER		01
08	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	84	01
02	0511063185	20Z GEAR WITH HEX HOLE AXLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		02
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0511058381	RIGHT GEAR HOUSING	87	01
02	0521065955	RIGHT GEARBOX LID		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0503010019	1/2" SPRING WASHER		01
07	0501010694	FLAT WASHER		06
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01



Item	Code	Description	See page	QT
01	0511058382	LEFT GEAR HOUSING	88	01
02	0521065956	LEFT GEARBOX LID		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
07	0503010019	1/2" SPRING WASHER		01
08	0501010694	FLAT WASHER		06

RIGHT GEAR HOUSING

0511058381



Item	Code	Description	See page	QT
01	0521065939	RIGHT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN SHAFT		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	89	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING	35	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TIGHTENER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	90	02
20	0503031366	RIGHT TWISTED SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	91	01
31	0503010292	701164 6 X 40 SPRING PIN		08


RIGHT GEAR HOUSING

0511058381

Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	93	01
33	0511054363	CHAIN TENSIONER	94	01
34	0571018901	DRIVEN AXLE		01

LEFT GEAR HOUSING

0511058382




Item	Code	Description	See page	QT
01	0521065940	LEFT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN SHAFT		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	89	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING	35	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TIGHTENER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	90	02
20	0503031367	SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	91	01
31	0503010292	701164 6 X 40 SPRING PIN		08


LEFT GEAR HOUSING

0511058382


Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	93	01
33	0511054363	CHAIN TENSIONER	94	01
34	0571018901	DRIVEN AXLE		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	92	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0571019207	DEVIATION AXLE GEAR BOX		01
06	0503010899	5/8" X 2-1/4" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0531063064	FRAME HANDRAIL - 5745		02
02	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0581012916	INTERMEDIATE TUBE		02
07	0511059383	HANDRAIL INTERNAL FIXER	96	04




Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	98	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01

ROW MARKER DISC


0511053904



Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04



Item	Code	Description	See page	QT
01	0503063619	14 ROWS SEED MONITORING KIT 45/50 PM400		01
01A	0513010217	14 ROWS CABLE FOR MESH SEED		01
01B	0503019100	SENSOR		14
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
01E	0503017031	CLEANING BRUSH		01
01F	0503019720	NYLON CLAMP		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010669	FLAT WASHER		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0511057277	FRONT SHORT SEED ROW WITH RIGHT TRANSMISSION	101	01
02	0511057290	SEED ROW FRONT SHORT WITH TRANSMISSION	108	01
03	0511057278	FRONT LONG SEED ROW WITH RIGHT TRANSMISSION	102	01
04	0511057291	SEED ROW FRONT SHORT WITH TRANSMISSION	109	01
05	0521050096	SEED HOPPER SYSTEM (CSU)	114	01
06	0531054532	WHEEL SYSTEM DEPTH / COMPACTOR	117	01
07	0511058639	SHORT FERTILIZER ROW WITH DDD/DC20	123	01
08	0511058640	LONG FERTILIZER ROW WITH DDD/DC20	124	01
09	0581011493	3" X 1300 SEED HOSE		01
10	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
11	0503010019	1/2" SPRING WASHER		01
12	0503010060	1/2 UNC G.5 ZN HEX NUT		01
13	0511056621	RIGHT REAR SEED ROW	134	01
14	0511056622	LEFT REAR SEED ROW	135	01
15	0503033672	NOZZLE WITHOUT TITANIUM		01
16	0503030391	RIGHT FERTILIZER NOZZLE		01
17	0503030392	LEFT FERTILIZER NOZZLE		01
18	0503031145	2" X 2" X 20" HOSE		01
19	0503031076	2" HOSE CLAMP		01
20	0503031050	CURVED CONDUCTOR		01
21	0503010246	CLAMP		01
22	0521050525	FIXER FERTILIZER CONDUCTOR	143	01
23	0531052986	PIVOT SUPPORT	144	01
24	0531013600	PRESS ADJUSTMENT LEVER		01
25	0501110804	SCARIFIER ROD WITH POINT	145	01
26	0511017969	0.1" SPACING PLATE		01
27	0511018662	SPACING PLATE		01
28	0521069127	BOTTOM NOZZLE FERTILIZER		01
29	0503030520	SEED SOCKET		01
30	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01



PST PLUS FLEX TITANIUM - FRAME - 5745 - CSU - DOUBLE
COMPLETE SEED/FERTILIZER ROW UNIT

Page 100
0909096539

Item	Code	Description	See page	QT
31	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
32	0503010025	3/8" SPRING WASHER		01
33	0503010060	1/2 UNC G.5 ZN HEX NUT		01
34	0521057957	FIXED ROD EXTENSION WITH FIXATION	146	01
35	0503010905	1/2" X 2-1/4" BOLT		01
36	0503062066	DISC SET WITH CORN RING	147	01
37	0503062067	DISC SET / RING SOY 90F TITANIUM	148	01
38	0511052024	FAST CLOSING SET	149	01




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0502012804	PIVOT ARM SEED ROW		02
05	0571018882	SEED ROW ARM SLEEVE		08
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8 UNC SELF LOCKING NUT		04
08	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
09	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
10	0571018883	PIN FIXER SPRING		03
11	0571018884	LOCK PIN ROW ARTICULAT		01
12	0503030168	HITCH PIN CLIP		04
13	0511058766	BEARING	103	01
14	0511057159	TRANSMISSION HOPPER SEED ROW	104	01
15	0571012492	5/8 X 330 AXLE HEX		01
16	0501056296	UNIVERSAL JOINT		01
17	0503011855	0.2" X 1.8" SPRING PIN		03
18	0521065942	FRAME REAR SHORT ROW SEED		01
19	0511057269	CHAIN TENSIONER	105	01
20	0511059872	BEARING	106	01
21	0581010239	SEED ROW AXLE TRANSMISSION		01
22	0521011859	FLAT WASHER		02
23	0581011694	PROTECTION REAR COVER SEED ROW		01
24	0503010765	3/8" X 3" BOLT		01
25	0503010025	3/8" SPRING WASHER		01
26	0503010026	3/8" NUT		01
27	0501012140	FLAT WASHER		08
28	0511058512	PROTECTION LID	107	01
29	0581011430	DRAWBAR ASSY		01
30	0581010976	5/8" HEX AXLE		01
31	0503032984	HOOD HEX AXLE ROW		01



PST PLUS FLEX TITANIUM - FRAME - 5745 - CSU - DOUBLE
FRONT SHORT SEED ROW WITH RIGHT TRANSMISSION

Page 101
0511057277

Item	Code	Description	See page	QT
32	0503010004	1890 GREASE FITTING		04
33	0503013100	NYLON CLAMP		01
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
35	0503017857	BOLT 5/8 UNF 4		04




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0502012804	PIVOT ARM SEED ROW		02
05	0571018882	SEED ROW ARM SLEEVE		08
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8 UNC SELF LOCKING NUT		04
08	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
09	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
10	0571018883	PIN FIXER SPRING		03
11	0571018884	LOCK PIN ROW ARTICULAT		01
12	0503030168	HITCH PIN CLIP		04
13	0511058766	BEARING	103	01
14	0511057159	TRANSMISSION HOPPER SEED ROW	104	01
15	0571012492	5/8 X 330 AXLE HEX		01
16	0501056296	UNIVERSAL JOINT		01
17	0503011855	0.2" X 1.8" SPRING PIN		03
18	0521065943	REAR FRAME LONG ROW SEED		01
19	0511057269	CHAIN TENSIONER	105	01
20	0511059872	BEARING	106	01
21	0581010240	SEED ROW AXLE TRANSMISSION		01
22	0521011859	FLAT WASHER		02
23	0581011694	PROTECTION REAR COVER SEED ROW		01
24	0503010765	3/8" X 3" BOLT		01
25	0503010025	3/8" SPRING WASHER		01
26	0503010026	3/8" NUT		01
27	0501012140	FLAT WASHER		08
28	0511058512	PROTECTION LID	107	01
29	0581011430	DRAWBAR ASSY		01
30	0581010976	5/8" HEX AXLE		01
31	0503032984	HOOD HEX AXLE ROW		01




PST PLUS FLEX TITANIUM - FRAME - 5745 - CSU - DOUBLE
FRONT LONG SEED ROW WITH RIGHT TRANSMISSION

Page 102
0511057278


Item	Code	Description	See page	QT
32	0503010004	1890 GREASE FITTING		04
33	0503013100	NYLON CLAMP		01
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
35	0503017857	BOLT 5/8 UNF 4		04




Item	Code	Description	See page	QT
01	0502012852	ROW SEED UPPER BEARING		01
02	0503011105	SEAL RING		01
03	0502012851	17Z GEAR WITH HEX HOLE		01
04	0503011410	ROLLER BEARING		02
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010237	3/8" X 1" BOLT		02
07	0503010025	3/8" SPRING WASHER		02
08	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503031805	11Z 1/2" GEAR		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0581012948	HOUSING BEARING		01
02	0503011105	SEAL RING		01
03	0581012949	BEARING COVER		01
04	0503011410	ROLLER BEARING		02
05	0503018045	2-130 (AGEL) O'RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0502012851	17Z GEAR WITH HEX HOLE		01
08	0503011953	5/16" X 1" BOLT		02
09	0501010694	FLAT WASHER		02
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
11	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521066693	CAP BEARING		01
02	0503010834	1/2 X 1 BOLT		02
03	0503010019	1/2" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0501012140	FLAT WASHER		04
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8 UNC SELF LOCKING NUT		04
08	0502012804	PIVOT ARM SEED ROW		02
09	0571018882	SEED ROW ARM SLEEVE		08
10	0503010002	1800 GREASE FITTING		03
11	0503010004	1890 GREASE FITTING		01
12	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
13	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
14	0571018883	PIN FIXER SPRING		03
15	0571018884	LOCK PIN ROW ARTICULAT		01
16	0503030168	HITCH PIN CLIP		04
17	0511057275	TRANSMISSION WITH LEFT SUPPORT	110	01
18	0521065942	FRAME REAR SHORT ROW SEED		01
19	0511057269	CHAIN TENSIONER	105	01
20	0511057274	TRANSMISSION LOWER FRONT SEED ROW SHORT	112	01
21	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
22	0581012950	LEFT REAR PROTECTION SEED ROW COVER		01
23	0503010765	3/8" X 3" BOLT		01
24	0503010025	3/8" SPRING WASHER		01
25	0503010026	3/8" NUT		01
26	0511058512	PROTECTION LID	107	01
27	0581011430	DRAWBAR ASSY		01




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0501012140	FLAT WASHER		04
05	0503010811	5/8\" UNF SELF ADJUSTING NUT		04
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8 UNC SELF LOCKING NUT		04
08	0502012804	PIVOT ARM SEED ROW		02
09	0571018882	SEED ROW ARM SLEEVE		08
10	0503010002	1800 GREASE FITTING		03
11	0503010004	1890 GREASE FITTING		01
12	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
13	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
14	0571018883	PIN FIXER SPRING		03
15	0571018884	LOCK PIN ROW ARTICULAT		01
16	0503030168	HITCH PIN CLIP		04
17	0511057275	TRANSMISSION WITH LEFT SUPPORT	110	01
18	0521065943	REAR FRAME LONG ROW SEED		01
19	0511057269	CHAIN TENSIONER	105	01
20	0511057293	FRONT LOWER TRANSMISSION	113	01
21	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
22	0581012950	LEFT REAR PROTECTION SEED ROW COVER		01
23	0503010765	3/8\" X 3\" BOLT		01
24	0503010025	3/8\" SPRING WASHER		01
25	0503010026	3/8\" NUT		01
26	0511058512	PROTECTION LID	107	01
27	0581011430	DRAWBAR ASSY		01




Item	Code	Description	See page	QT
01	0511059873	TOP LEFT BEARING WITH ROW		01
02	0511057273	ASSEMBLY TRANSMISSION	111	01
03	0503010300	5/32" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0511057159	TRANSMISSION HOPPER SEED ROW	104	01
02	0503032984	HOOD HEX AXLE ROW		01
03	0503013100	NYLON CLAMP		01
04	0571012492	5/8 X 330 AXLE HEX		01
05	0501056296	UNIVERSAL JOINT		01
06	0581010976	5/8" HEX AXLE		01
07	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0511059872	BEARING	106	01
02	0581010239	SEED ROW AXLE TRANSMISSION		01
03	0521011859	FLAT WASHER		02




Item	Code	Description	See page	QT
001	0511059872	BEARING	106	01
002	0581010240	SEED ROW AXLE TRANSMISSION		01
003	0521011859	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521050118	3" NOZZLE SEED HOPPER	115	01
02	0581014295	FIXING SLEEVE		01
03	0511052058	SEED SYSTEM TITANIUM	116	01
04	0503010358	5/16" X 5/8" BOLT		05
05	0501010694	FLAT WASHER		05
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
07	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0503062397	ASSY SEED HOPPER WITH 3" NOZZLE		01




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
09.	0503016279	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01
14	0503062044	ASSEMBLY SEED HOPPER SET		01
14A	0503016285	BOLT		05
14B	0503016286	HEX NUT		05
14C	0503016287	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0581014858	DEPTH WHEEL AXLE		01
04	0501110720	ARM LEFT		01
04A	0502012726	LEFT DEPTH WHEEL ARM		01
04B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL		02
05	0501110719	DEPTH CONTROL RIGHT ARM		01
05A	0502012725	DEPTH WHEEL RIGHT ARM		01
05B	0503034375	SLEEVE ARM WHEEL DEPTH CONTROL		02
06	0502012663	EXTENSION		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	118	01
09	0521051423	COMPACTOR SUPPORT	119	01
10	0503034793	ARTICULATION SLEEVE		02
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503010019	1/2" SPRING WASHER		08
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503010060	1/2 UNC G.5 ZN HEX NUT		04
16	0501052908	COMPACTOR WHEEL WITH BEARING	120	02
17	0503013739	1/2" X 1" BOLT		01
18	0511050077	WHEEL STRIPED	121	02
19	0503016453	1/2" X 2.1/2 BOLT		02
20	0503034817	SPRING		01
21	0503010752	1/2" X 3.1/2" BOLT		01
22	0503010581	RING		01
23	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521068003	RIGHT SIDE		01
02	0521068002	LEFT SIDE		01
03	0581014847	PLATE UPPER		01
04	0581015855	SLEEVE		02
05	0521068004	HANDLE BODY		01
06	0581014969	SLEEVE GUIDE		01
07	0581014968	SLEEVE FLANGE		01
08	0503010937	5/16" X 3" BOLT		02
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0521068005	LEVER		01
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
12	0503010337	5/16" NUT		04
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2 UNC G.5 ZN HEX NUT		01
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010882	BOLT		02
17	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
18	0503030878	LEVER CRANK		01
19	0581015854	RIGHT PROTECTION COVER		01
20	0581015853	LEFT PROTECTION COVER		01
21	0581015903	SPACER WASHER		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	122	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEEL HUB		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	125	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057272	LH SHORT ARM ROW FERTILIZER	127	01
06	0511058630	20" DISC BLADE	131	01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	126	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057271	RH LONG ARM ROW FERTILIZER	128	01
06	0511058630	20" DISC BLADE	131	01




Item	Code	Description	See page	QT
01	0502012794	SHORT SUPPORT FERTILIZER ROW	01	
02	0503011854	5/8" X 1-1/4" BOLT	02	
03	0503010002	1800 GREASE FITTING	01	
04	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
05	0503017960	5/8" X 3-12" BOLT	04	
06	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
07	0521066744	FERTILIZER ROW ADJUSTMENT SPRING	01	
08	0571019062	SLEEVE	01	
09	0571019059	SUPPORT WASHER	01	
10	0503010417	7/8" NUT	04	
11	0503034320	COMPRESSION SPRING	01	
12	0502012813	FLANGE WASHER SPRING	01	




Item	Code	Description	See page	QT
01	0502012795	SUPPORT LONG	01	
02	0503011854	5/8" X 1-1/4" BOLT	02	
03	0503010002	1800 GREASE FITTING	01	
04	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
05	0503017960	5/8" X 3-12" BOLT	04	
06	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
07	0521066744	FERTILIZER ROW ADJUSTMENT SPRING	01	
08	0571019062	SLEEVE	01	
09	0571019059	SUPPORT WASHER	01	
10	0503010417	7/8" NUT	04	
11	0503034320	COMPRESSION SPRING	01	
12	0502012813	FLANGE WASHER SPRING	01	




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	130	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	129	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0511053173	CUBE LOW RIGHT WITH DISC 15	141	01
02	0511053172	LEFT LOW CUBE WITH DISC 15	142	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW CUBE WITH DISC 15	142	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	141	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0571018989	LH BLADE DISC ARM		01
02	0502012790	LOCK NUT		01
03	0511058648	HUB WITH 20" DISC BLADE	132	01
04	0521065978	RIGHT ARM WITH WASHER LOCK		01
05	0571019035	SLEEVE SUPPORT ARM		01
06	0521010452	SLEEVE		01
07	0521066743	SPRING REGULATOR		01
08	0503010417	7/8" NUT		04
09	0571019033	FIXATION AXLE		01
10	0503034319	LOCK PIN		01
11	0502012813	FLANGE WASHER SPRING		01
12	0503034320	COMPRESSION SPRING		01
13	0571019032	SUPPORT WASHER		01
14	0571019034	FLANGE WASHER AXLE		02
15	0503010002	1800 GREASE FITTING		01
16	0503013185	3/4" X 5-1/2" BOLT		01
17	0503011255	3/4" LOCK NUT		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503011440	SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	133	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0502012793	DISC HUB		01
02	0571018047	DISC BLADE HUB AXLE		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DUST CLOAK		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8	136	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	137	01




Item	Code	Description	See page	QT
01	0511051888	FIXING BASE SYSTEM SYSTEM TITANIUM ASSY 5/8	136	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511056586	15 X 15 SEED DDD LEFT	138	01




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502012639	12Z LOWER CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	139	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	141	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	142	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	140	01
02	0511053173	CUBE LOW RIGHT WITH DISC 15	141	01
03	0511053172	LEFT LOW CUBE WITH DISC 15	142	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
08	0503010025	3/8" SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0501012140	FLAT WASHER		01
02	0503010019	1/2" SPRING WASHER		01
03	0531062908	HOSE SUPPORT ARM		01
04	0531062907	ARTICULATOR HOSE		01
05	0513010322	LUBRICANT SLEEVE		01
06	0501210533	FLANGE WASHER		01
07	0503013776	BOLT 1/2 UNC X 7/8 C S G.5 ZN		01
08	0521067600	FIXER SUPPORT		01
09	0503010806	5/8" X 3" BOLT		01
10	0503012795	5/8" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01




Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0503016204	CORN DISK 12 ORANGE		01
02	0503016398	TITANIUM RING CORN / SOY (YELLOW FLAT)		01
03	0503016399	TITANIUM RING CORN (GREEN)		01
04	0503016400	TITANIUM RING CORN (GREY)		01
05	0503016401	TITANIUM RING CORN (BLUE)		01



Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016218	DISC OF SOYBEAN		01
03	0503016403	TITANIUM RING FOR SOYBEAN (LILAC)		01
04	0503016404	TITANIUM RING FOR SOYBEAN (PURPLE)		01
05	0503016406	TITANIUM RING FOR SOYBEAN (ORANGE)		01
06	0503016407	TITANIUM RING FOR SOYBEAN		01



Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

