

ROW CROP PLANTERS

PST4 - FRAME 4845 - CSU (FROM 08/2022)

Code: 0501093444
Series: S-0116
Revision: 00
Date Revision: OUTUBRO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111151281	PST4 4845/11E450 ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909096561	FRAME ASSY	1
0501058196	WHEEL AXLE FRAME - 4845	2
0511056529	CYLINDER ASSY	3
0511058406	HYDRAULIC CYLINDER	4
0511056536	LADDER ASSEMBLY	5
0511054971	JACK ASSEMBLY	6
0511057131	MANUAL CANISTER ASSY	7
0531057770	SET LABELS 4845 ALPHA	8
0511057150	DRAWBAR ASSEMBLY - 4845/5345	9
0511057651	HANDRAIL ASSY - 4845	10
0531057983	SET CSU C3 X 175 2 BOXES 14 MOUTH 4845	11
0531057984	SET CSU SM WITH 3 X 175 2 BOXES 7 MOUTH	12
0531057950	3" X 175 SEED NOZZLE WITH FIXING	13
0531054471	CAP WITH FIXING	14
0521051927	TOWER SUPPORT HOPPER	15
0511057650	PLATFORM ASSY - 4845	16
0531056603	RIGHT/LEFT FERTILIZER HOPPER SET	17
0531056604	RIGHT HOPPER SUPPORT WITH ALPHA METERING	18
0531056605	LEFT HOPPER SUPPORT WITH ALPHA METERING	19
0531055292	ALPHA FERTILIZER METERING	20
0531055273	ALPHA FERTILIZER METERING CLAMP	21
0531055376	TRANSMISSION ALPHA FERTILIZER METERING HUB	22
0501053788	3/4 SQUARE AXLE FASTENER	23
0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845/11	24
0511058449	HYDRAULIC CYLINDER	25
0501054649	HBM SEQUENTIAL VALVE	26
0501053834	MALE QUICK COUPLER	27
0501050633	ROW MARKER DISC ASSEMBLY	28
0511053904	ROW MARKER DISC	29
0511056740	RIGHT TRANSMISSION ASSY - 4880	30
0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	31
0501052560	MOTOR AXLE SIGNAL	32
0511051434	TRANSMISSION ACTUATOR	33
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	34
0521043316	RIGHT GEAR BOX ASSY	35
0521043317	LEFT GEAR BOX ASSY	36
0501058212	SEMI MOUNTED RIGHT CHANGE	37
0501058213	LH GEAR BOX	38
0511059266	CLOSED BEARING	39
0501056271	GEARBOX CLOSED BEARING	40
0501056443	GEAR HOUSING BEARING	41
0501056444	BEARING WITH ROLLER	42
0501048790	AXLE WITH RING	43
0501054655	CHAIN TENSIONER ASSY	44
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	45
0511054363	CHAIN TENSIONER	46
0501058234	LOWER CHAIN TENSIONER	47
0521055207	TOP CURRENT STRETCHER	48
0501058236	BEARING WITH 21Z GEAR	49
0501058237	16Z GEAR BEARING	50
0501055112	MICRO GRANULATED CHAIN TENSIONER	51
0521043934	CARRYING WHEELS SPRING TRACTION	52
0501058240	WHEEL FASTENER WITH TENSIONER	53
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	54
0501058239	WHEEL CHAIN TENSIONER BEARING	55



MARCHESAN

INDEX

0501058244	WHEEL FIXED CHAIN TENSIONER	56
0501058242	WHEEL MOBILE CHAIN TENSIONER	57
0501059909	CARRYING WHEELS SUPPORT	58
0511052770	WHEEL WITH TIRE	59
0503062159	WHEEL WITH TIRE	60
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	61
0501058241	WHEEL SUPPORT CHAIN TENSIONER	62
0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	63
0501054258	DRAWBAR ESTABILIZER ASSY	64
0511054601	HITCH ARTICULATED TRACTOR	65
0511053179	TRACTOR COUPLING SHAFT	66
0511056736	HOSE SUPPORT	67
0909095145	ASSY HEX AXLE	68
0909096562	COMPLETE SEED/FERTILIZER ROW UNIT	69
0531058446	SEED LINE SHORT ELEVATION HIGH CSU SIGMA	70
0531058447	SEED LINE LONG ELEVATION HIGH CSU SIGMA	71
0521054642	SHORT HIGH FERTILIZER LINE DAOC DC20	72
0521054643	LONG HIGH FERTILIZER LINE DAOC DC20	73
0521052847	HIGH LINE PIVOTED SHORT HUB HIGH	74
0521052848	HIGH LINE PIVOTED SHORT HUB HIGH	75
0511059244	ROD SPRING LINE SEED	76
0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	77
0511052024	FAST CLOSING SET	78
0511051693	BASE FIXING SYSTEM	79
0501059631	DDD SEED 15 X 15 RIGHT	80
0501059632	DDD SEED 15X15 LEFT	81
0501054167	15" RIGHT OPENING DISC HUB	82
0501054168	15" LEFT DOUBLE DISC HUB	83
0511059350	FERTILIZER ROW SUPPORT ASSEMBLY	84
0521059094	SIGMA SOY SINGLE SEED SYSTEM	85
0503063223	SEMI-ASSEMBLED SINGLE SEED HOPPER	86
0531051514	SIGMA SOY SEED SYSTEM	87
0511057289	ASSY SEED DEFLECTOR	88
0521052838	RIGHT SUPPORT DOC18	89
0521052839	LEFT SUPPORT DOC18	90
0511059229	HUB WITH DOC 18 TURBO RIGHT	91
0511059230	HUB WITH DOC 18 TURBO LEFT	92
0521050168	MOUNTED FERTILIZER CONDUCTOR	93
0511058619	DISC CUT 20 SHORT LINE	94
0511058620	DISC CUT 20 LONG LINE	95
0511058648	HUB WITH 20" DISC BLADE	96
0511056909	DISC BLADE HUB WITHOUT DISC	97
0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	98
0521056317	DEPTH CONTROL WITH LEVER ANGLE REGULATOR AXIS CPERA	99
0501052297	DEPTH WHEELS REGULATOR ASSY	100
0501052908	COMPACTOR WHEEL WITH BEARING	101
0521056314	LEFT ARM WHEEL DEPTH WITH HUB CPERA	102
0521056316	DEPTH WHEEL HUB WITH COMPLETE ANGLE ADJUSTING AXLE	103
0521056313	RIGHT ARM WHEEL DEPTH WITH HUB CPERA	104
0511055819	DEPTH BAND WITH RIM	105
0521054769	LEFT DDD FERTILIZER WITH SUPPORT	106
0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	107
0521055869	LEFT DUAL FERTILIZER DISC	108




MARCHESAN

INDEX

0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED		109
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED		110
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED		111
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED		112
0521055868	RIGHT DUAL FERTILIZER DISC		113
0503063647	SIGMA CORN DISC SET		114
0503063648	SIGMA SOY DISC SET		115
0501110804	SCARIFIER ROD WITH POINT		116
0521050525	FIXER FERTILIZER CONDUCTOR		117

FRAME ASSY

0909096561




Item	Code	Description	See page	QT
01	0501058196	WHEEL AXLE FRAME - 4845	2	01
02	0503010003	1845 GREASE FITTING		06
03	0511056529	CYLINDER ASSY	3	01
04	0521013022	TRANSPORT LOCK		02
05	0501068994	8,30 X 78 LOCK PIN		02
06	0503030168	HITCH PIN CLIP		02
07	0511056536	LADDER ASSEMBLY	5	02
08	0511054971	JACK ASSEMBLY	6	02
09	0511057131	MANUAL CANISTER ASSY	7	01
10	0531057770	SET LABELS 4845 ALPHA	8	01
11	0511057150	DRAWBAR ASSEMBLY - 4845/5345	9	01
12	0511057651	HANDRAIL ASSY - 4845	10	01
13	0531057983	SET CSU C3 X 175 2 BOXES 14 MOUTH 4845	11	01
14	0511057650	PLATFORM ASSY - 4845	16	01
15	0531056603	RIGHT/LEFT FERTILIZER HOPPER SET	17	01
16	0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845/11	24	01
17	0501050633	ROW MARKER DISC ASSEMBLY	28	02
18	0511056740	RIGHT TRANSMISSION ASSY - 4880	30	01
19	0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	31	01
20	0521043934	CARRYING WHEELS SPRING TRACTION	52	04
21	0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	63	01
22	0501065677	STRUT		02
23	0521013164	EXTENSOR		02
24	0501011310	FIXER LOCK		08
25	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		04
26	0503010019	1/2" SPRING WASHER		04
27	0503010060	1/2 UNC G.5 ZN HEX NUT		04
28	0501054258	DRAWBAR ESTABILIZER ASSY	64	01
29	0511054601	HITCH ARTICULATED TRACTOR	65	01
30	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
31	0511053179	TRACTOR COUPLING SHAFT	66	01

FRAME ASSY

0909096561


Item	Code	Description	See page	QT
32	0511056736	HOSE SUPPORT	67	01
33	0501047895	ROD STOP		02
34	0501047885	ROD STOP		02
35	0501047886	ROD STOP		02
36	0501047887	ROD STOP		02
37	0503010246	CLAMP		06
38	0503014120	CHAIN		01
39	0503014321	CABLE STEEL SHACKLE		02
40	0503010780	N-2050 AMENDMENT		02
41	0503011750	AMENDMENT WITH LOCK		06
42	0503011751	REDUCTION		06
43	0503010951	REDUCTION		04
44	0909095145	ASSY HEX AXLE	68	01
45	0909096562	COMPLETE SEED/FERTILIZER ROW UNIT	69	11



Item	Code	Description	See page	QT
01	0511069616	FRAME		01
02	0511069717	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8" X 2-1/4" BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8" NUT		12

CYLINDER ASSY


0511056529



Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	4	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521012536	COUPLING SHAFT		02
04	0503010523	1/4" X 2" COTTERPIN		04
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02

HYDRAULIC CYLINDER


0511058406



Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01

LADDER ASSEMBLY


0511056536




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	

JACK ASSEMBLY


0511054971




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
06	0503033422	ADHESIVE LABEL	02	
07	0503033008	ADHESIVE LABEL	02	
08	0503031428	READ MANUAL DECAL	01	
09	0503031942	ADHESIVE LABEL	01	
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27	02	
11	0503031565	ADHESIVE LABEL CARE	02	
12	0503031566	ADHESIVE LABEL	02	
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
14	0503031425	ADHESIVE LABEL ATTENTION	02	
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER	02	
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503032930	ADHESIVE LABEL DANGER	06	
19	0503031087	ADHESIVE LABEL	01	
20	0503034078	LIFTING POINTS DECAL	03	
21	0503034003	SERIAL NUMBER TAG 61 X 118	01	
22	0503010001	3.2 X 5.5 RIVET	04	
23	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
24	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	1902012329	REAR SUPPORT FIXING DRAWBAR	04	
02	1902012330	FIXER SUPPORT ARTICULATED	08	
03	0503011084	3/4" X 5" BOLT	16	
04	0503010023	3/4" SPRING WASHER	16	
05	0503010014	3/4" HEX NUT	16	
06	1902012328	FIXED FRONT SUPPORT DRAWBAR	04	
07	0561014393	COUPLING SHAFT	04	
08	0503030119	LOCK PIN	08	
09	0511064808	DRAWBAR	01	
10	0561019087	DRAWBAR TRANSPORT LOCK	01	
11	0521010588	0.9" X 7.0" COUPLING SHAFT	01	
12	0521010578	COUPLING SHAFT	01	
13	0503030085	LOCK PIN	02	
14	0503010002	1800 GREASE FITTING	01	
15	0501010322	FLAT WASHER	16	




Item	Code	Description	See page	QT
01	0511069660	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0531057984	SET CSU SM WITH 3 X 175 2 BOXES 7 MOUTH	12	01
02	0521051927	TOWER SUPPORT HOPPER	15	04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
05	0503010025	3/8" SPRING WASHER		08
06	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0531057950	3" X 175 SEED NOZZLE WITH FIXING	13	11
06	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
07	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02
08	0531054471	CAP WITH FIXING	14	03




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID	01	
02	0501010942	3/8" X 1-1/4" BOLT	05	
03	0503010025	3/8" SPRING WASHER	05	
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN	01	
05	0503010209	3/8" UNC BUTTERFLY NUT	01	
06	0521066332	CONDUCTOR WITH FLANGE	01	
07	0503010371	5/16" X 1" BOLT	02	
08	0501010694	FLAT WASHER	02	
09	0503010179	LOCK WASHER 5/16 ZN 1K01528	02	
10	0503010337	5/16" NUT	02	
11	0502012767	SEED NOZZLE FIXER SUPPORT	01	
12	0503010026	3/8" NUT	04	




Item	Code	Description	See page	QT
01	0571015773	SUPPORT SEED		01
02	0501011643	3/8 X 1"BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521066208	HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT		04
02	0503010849	3/8" X 1-1/2" BOLT		08
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		16
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0511069718	PLATFORM RIGHT		01
07	0521062324	PLATFORM LEFT		01
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
09	0503011336	1/2" HEX SELF ADJUSTING NUT		04
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
13	0502012739	PLATFORM LEFT FIXER SUPPORT		01




Item	Code	Description	See page	QT
01	0531056604	RIGHT HOPPER SUPPORT WITH ALPHA METERING	18	01
02	0531056605	LEFT HOPPER SUPPORT WITH ALPHA METERING	19	01
03	0503062169	ASSEMBLED FERTILIZER HOPPER		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		20
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		40
07	0503010025	3/8" SPRING WASHER		20
08	0503010026	3/8" NUT		20
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0501010694	FLAT WASHER		04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" COTTERPIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531064717	RIGHT HOPPER SUPPORT ALPHA		01
02	0531055292	ALPHA FERTILIZER METERING	20	06
03	0511061759	22Z P12,70 FQ 3/4" GEAR		01
04	0521014167	CONE LOCK		01
05	0501110392	HOPPER SUPPORT BEARING		01
06	0521012485	GEAR BOX BEARING AGRICUTURAL		01
07	0503010003	1845 GREASE FITTING		01
08	0501053788	3/4 SQUARE AXLE FASTENER	23	04
09	0503011953	5/16" X 1" BOLT		02
10	0501010694	FLAT WASHER		02
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
12	0503010337	5/16" NUT		02
13	0503031527	AGRICULTURAL BEARING		03
14	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		01
14A	0501214269	SQUARE SLEEVE		01
14B	0513010701	LOCK PIN		01
15	0501018653	3/4" X 46" SQUARE SHAFT		02




Item	Code	Description	See page	QT
01	0531064718	LEFT HOPPER SUPPORT ALPHA		01
02	0531055292	ALPHA FERTILIZER METERING	20	06
03	0511061759	22Z P12,70 FQ 3/4" GEAR		01
04	0521014167	CONE LOCK		01
05	0501110392	HOPPER SUPPORT BEARING		01
06	0521012485	GEAR BOX BEARING AGRICUTURAL		01
07	0503010003	1845 GREASE FITTING		01
08	0501053788	3/4 SQUARE AXLE FASTENER	23	04
09	0503011953	5/16" X 1" BOLT		02
10	0501010694	FLAT WASHER		02
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
12	0503010337	5/16" NUT		02
13	0503031527	AGRICULTURAL BEARING		03
14	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		01
14A	0501214269	SQUARE SLEEVE		01
14B	0513010701	LOCK PIN		01
15	0501018653	3/4" X 46" SQUARE SHAFT		02




Item	Code	Description	See page	QT
01	0503010025	3/8" SPRING WASHER		04
02	0503010026	3/8" NUT		04
03	0513010742	RETAINER 47 X 30 X 10 BRG 5285		01
04	0501214879	HORIZONTAL SEAL LID ALPHA FERTILIZER METERING		01
05	0503035799	ALPHA FERTILIZER DOSAGE NOZZLE		01
06	0503035831	ALPHA FERTILIZER METERING COLLECTOR		01
07	0531055273	ALPHA FERTILIZER METERING CLAMP	21	01
08	0513010692	ALLEN SCREW 1/4 UNC X 7/8 C FLAT SI INOX		04
09	0501011643	3/8 X 1"BOLT		04
10	0503035796	REAR FIXER ALPHA FERTILIZER METERING COLLECTOR		02
11	0513010695	ALLEN SCREW 1/4 UNC X 7/8 CCSI INOX		04
12	0531055376	TRANSMISSION ALPHA FERTILIZER METERING 22 HUB		01
13	0502013049	ALPHA FERTILIZER DOSAGE HOPPER		01
14	0502013048	FLANGE FIXER BODY ALPHA FERTILIZER METERING		01
15	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
15A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
15B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
16	0503035829	ADHESIVE LABEL LOGO TATU 38 X 28 X 0.30 ALPHA FERTILIZER METERING		01
17	0531055518	WORM THREAD ASSEMBLED		01
17A	0531064265	WORM THREAD		01
17B	0503035859	SUPPORT SLEEVE		01
18	0501111143	COATING WITH GUIDE ASSY SUPPLEMENTATION FERTILIZER METERING		01
18A	0501214951	FERTILIZER DOSAGE COATING		01
18B	0531055519	GUIDE ASSY WITH SUPPLEMENTATION		01




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02



Item	Code	Description	See page	QT
01	0502013050	TRANSMISSION ALPHA FERTILIZER METERING HOPPER		01
02	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
03	0503011800	SEAL RING		02
04	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
05	0503016065	ROLLER BEARING		02
06	0501214237	TRANSMISSION HOPPER ALPHA FERTILIZER METERING SLEEVE		01
07	0503019373	6006 2RS1 NATIONAL BEARING		02
08	0503012858	502075 CLAMPING RING (FOR HOLE)		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01
10	0501214501	ALPHA FERTILIZER METERING LID LOCK AXIS		01
11	0501214238	SHAFT LOCK SLEEVE HOPPER TRANSMISSION ALPHA FERTILIZER METERING		01
12	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01



Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8 UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503011082	C1/2" X 1.3/4" SCREW		02
07	0501069470	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0501012140	FLAT WASHER		04
11	0503012412	5/8 UNC SELF LOCKING NUT		02
12	0511058449	HYDRAULIC CYLINDER	25	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" COTTERPIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501066949	1235 TURNBUCKLE		02
21	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
22	0511011311	VALVE SUPPORT		01
23	0503010232	5/8" X 1.3/4" BOLT		02
24	0503010027	5/8" SPRING WASHER		02
25	0503010013	5/8" NUT		02
26	0501054649	HBM SEQUENTIAL VALVE	26	01
27	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
28	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
29	0503010025	3/8" SPRING WASHER		02
30	0502012702	BODY SUPPORT CLAMP		06
31	0503011103	7/16" X 2-1/2" BOLT		06


Item	Code	Description	See page	QT
32	0501012803	FLAT WASHER		02
33	0503010180	7/16" SPRING WASHER		06
34	0503010244	7/16" NUT		06
35	0501053834	MALE QUICK COUPLER	27	02
36	0511057069	HYDRAULIC HOSE MARKER ASSY		01
36A	0501080343	TR-TR HOSE ASSY		02
36B	0501080720	HOSE 3/8 X 3500 TR-TC		02
37	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
37A	0501080422	HOSE 3/8 X 4000 TC-TM		01
37B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
37C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
37D	0503018952	PLASTIC BOLT		06
38	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38A	0501080422	HOSE 3/8 X 4000 TC-TM		01
38B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38D	0503018952	PLASTIC BOLT		06

HYDRAULIC CYLINDER


0511058449



Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCIAL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01

ROW MARKER DISC ASSEMBLY


0501050633




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	29	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01

ROW MARKER DISC

0511053904




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	32	01
15	0511051434	TRANSMISSION ACTUATOR	33	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	34	01
17	0521043316	RIGHT GEAR BOX ASSY	35	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	46	01
26	0501058234	LOWER CHAIN TENSIONER	47	01
27	0521055207	TOP CURRENT STRETCHER	48	01
28	0501058236	BEARING WITH 21Z GEAR	49	01
29	0501058237	16Z GEAR BEARING	50	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	51	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01


Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPP G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	32	01
15	0511051434	TRANSMISSION ACTUATOR	33	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR		01
17	0521043317	LEFT GEAR BOX ASSY	36	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	46	01
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	51	01
27	0501058234	LOWER CHAIN TENSIONER	47	01
28	0521055207	TOP CURRENT STRETCHER	48	01
29	0501058236	BEARING WITH 21Z GEAR	49	01
30	0501058237	16Z GEAR BEARING	50	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01




Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02



Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	37	01
02	0511059266	CLOSED BEARING	39	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	41	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	43	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	44	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	45	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY

0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	38	01
02	0511059266	CLOSED BEARING	39	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	41	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	43	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	44	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	45	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX	01	
02	0502011758	REAR TIGHTENER LEVER	02	
03	0503010292	701164 6 X 40 SPRING PIN	02	
04	0511061794	CHAIN TENSIONER	01	
05	0503031367	SPRING	01	
06	0511060392	CHAIN TENSIONER	01	
07	0503031366	RIGHT TWISTED SPRING	01	

LH GEAR BOX


0501058213




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	40	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01



Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	42	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01

CHAIN TENSIONER ASSY

0501054655




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02

CHAIN TENSIONER


0511054363




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01

LOWER CHAIN TENSIONER


0501058234



Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0551019173	CHAIN SLEEVE TENSIONER		01
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01

16Z GEAR BEARING


0501058237




Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019174	DOBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501058240	WHEEL FASTENER WITH TENSIONER	53	01
02	0503011119	7/8" X 6" BOLT		04
03	0501014251	FLAT WASHER		04
04	0503011254	7/8" HEX SELF ADJUSTING NUT		04
05	0501059909	CARRYING WHEELS SUPPORT	58	01
06	0503014887	2050 CHAIN X 80 LINK + REDUCTION		01
07	0502010584	CARRYING-WHEELS SUPPORT FIXER		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	54	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	56	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	57	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	55	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01



Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	55	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	55	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01

CARRYING WHEELS SUPPORT


0501059909




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0531016887	CARRYING WHEEL AXLE ARM		01
03	0503010523	1/4" X 2" COTTERPIN		01
04	0503010003	1845 GREASE FITTING		01
05	0511050681	TRACTION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0561016062	SPRING HITCH		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		04
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0511052770	WHEEL WITH TIRE	59	01
11	0501058241	WHEEL SUPPORT CHAIN TENSIONER	62	01
12	0521061565	WHEEL SUPPORT ARM		01
13	0503018981	BOLT		02
14	0521069983	WHEEL COVER		01
15	0591010589	BODY LOCK WHEEL		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	60	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	61	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01



Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511063404	"T" OIL CONDUCTOR		02
02	0581010091	SPRING PROTECTION PLASTIC HOSE		01
03	0503013100	NYLON CLAMP		02
04	0502012702	BODY SUPPORT CLAMP		02
05	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
06	0503010180	7/16" SPRING WASHER		02
07	0501053834	MALE QUICK COUPLER	27	02
08	0511057068	HOSE KIT SYSTEM HYDRAULIC		01
08A	0501080449	3/8" X 1500 TC-TC HOSE		04
09	0521052334	3/8 X 4000 TR-TM HOSE BLACK / BLUE		01
09A	0501080361	3/8" X 157" TR-TM HOSE		01
09B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
09C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
09D	0503018952	PLASTIC BOLT		06
10	0521052333	3/8 X 4000 TR-TM HOSE BLACK / RED		01
10A	0501080361	3/8" X 157" TR-TM HOSE		01
10B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
10C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
10D	0503018952	PLASTIC BOLT		06

DRAWBAR ESTABILIZER ASSY


0501054258



Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	COMPRESSION SPRING LEFT		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01



Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01

HOSE SUPPORT


0511056736




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01

ASSY HEX AXLE


0909095145




Item	Code	Description	See page	3245	4045	4845
01	0521013432	5/8" X 59" AXLE HEX		01	00	00
01.	0521013429	AXLE HEX 5/8 X 2180		00	01	00
01..	0521013430	HEX AXLE 5/8 X 2580		00	00	01
02	0521013428	HEX AXLE		01	00	00
02.	0521013433	5/8" X 75" AXLE HEX		00	01	00
02..	0521013434	HEX AXLE 5/8 X 2300		00	00	01
03	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"		02	02	02
04	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8		02	02	02
05	0503010003	1845 GREASE FITTING		02	02	02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04	04	04
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04	04	04
08	0501010694	FLAT WASHER		08	08	08
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04	04	04
10	0503010337	5/16" NUT		04	04	04
11	0511815098	FLAT WASHER		02	02	02
12	0511017305	FLAT WASHER		04	04	04
13	0511065562	20Z GEAR		02	02	02
14	0502011299	BUSHING GEAR		02	02	02
15	0503010571	1/4" X 1.1/2 COTTERPIN		02	02	02
16	0503010010	1/4" X 2.1/2" COTTERPIN		02	02	02




Item	Code	Description	See page	QT
01	0531058446	SEED LINE SHORT ELEVATION HIGH CSU SIGMA	70	01
02	0531058447	SEED LINE LONG ELEVATION HIGH CSU SIGMA	71	01
03	0521054642	SHORT HIGH FERTILIZER LINE DAOC DC20	72	01
04	0521054643	LONG HIGH FERTILIZER LINE DAOC DC20	73	01
05	0521056317	DEPTH CONTROL WITH LEVER ANGLE REGULATOR AXIS CPERA	99	01
06	0521054769	LEFT DDD FERTILIZER WITH SUPPORT	106	01
07	0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	107	01
08	0503063647	SIGMA CORN DISC SET	114	01
09	0503063648	SIGMA SOY DISC SET	115	01
10	0501110804	SCARIFIER ROD WITH POINT	116	01
11	0511017969	0.1" SPACING PLATE		01
12	0511018662	SPACING PLATE		01
13	0521069124	PIVOTED FERTILIZER ROW NOZZLE		01
14	0503030391	RIGHT FERTILIZER NOZZLE		01
15	0503030392	LEFT FERTILIZER NOZZLE		01
16	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
17	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
18	0503010025	3/8" SPRING WASHER		01
19	0503010026	3/8" NUT		01
20	0503031050	CURVED CONDUCTOR		01
21	0503010246	CLAMP		01
22	0571011730	SEED CONDUCTOR 3" X 1500		01
23	0521050525	FIXER FERTILIZER CONDUCTOR	117	01
24	0501018652	CORN STABILIZER BAR		01
25	0581015215	STABILIZER BAR E500 PIVOTED HIGH LINE		01
26	0503010905	1/2" X 2-1/4" BOLT		01
27	0503010019	1/2" SPRING WASHER		01
28	0503010060	1/2 UNC G.5 ZN HEX NUT		01
29	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01




Item	Code	Description	See page	QT
01	0521052847	HIGH LINE PIVOTED SHORT HUB HIGH	74	01
02	0511059350	FERTILIZER ROW SUPPORT ASSEMBLY	84	01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
05	0521059094	SIGMA SOY SINGLE SEED SYSTEM	85	01




Item	Code	Description	See page	QT
01	0521052848	HIGH LINE PIVOTED SHORT HUB HIGH	75	01
02	0511059350	FERTILIZER ROW SUPPORT ASSEMBLY	84	01
03	0503012412	5/8 UNC SELF LOCKING NUT		02
04	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
05	0521059094	SIGMA SOY SINGLE SEED SYSTEM	85	01




Item	Code	Description	See page	QT
01	0521068566	SHORT FERTILIZER LINE ARM		01
02	0521052838	RIGHT SUPPORT DOC18	89	01
03	0521050168	MOUNTED FERTILIZER CONDUCTOR	93	01
04	0501010066	3/4" X 9" BOLT		01
05	0521017831	SUPPORT SLEEVE SPACER		02
06	0511017232	FLAT WASHER		02
07	0503011255	3/4" LOCK NUT		01
08	0511058619	DISC CUT 20 SHORT LINE	94	01
09	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	98	01
10	0503031145	2" X 2" X 20" HOSE		01
11	0503031076	2" HOSE CLAMP		02



Item	Code	Description	See page	QT
01	0521068565	LONG FERTILIZER LINE ARM		01
02	0521052839	LEFT SUPPORT DOC18	90	01
03	0521050168	MOUNTED FERTILIZER CONDUCTOR	93	01
04	0501010066	3/4" X 9" BOLT		01
05	0521017831	SUPPORT SLEEVE SPACER		02
06	0511017232	FLAT WASHER		02
07	0503011255	3/4" LOCK NUT		01
08	0511058620	DISC CUT 20 LONG LINE	95	01
09	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	98	01
10	0503031145	2" X 2" X 20" HOSE		01
11	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521068663	SHORT SEED LINE ARM		01
02	0511059244	ROD SPRING LINE SEED	76	01
03	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	77	01
04	0511052024	FAST CLOSING SET	78	01
05	0503034575	TITANIUM HIGH ROW SEED NOZZLE		01
06	0521018077	1/2" X 58.6" HEX AXLE		01
07	0521018079	SEED ROW DRAWBAR LID		01
08	0502011830	ARTICULACCION SUPPORT		01
09	1902010426	UPPER BEARING SEMI		02
10	0511051693	BASE FIXING SYSTEM	79	01
11	0501059631	DDD SEED 15 X 15 RIGHT	80	01
12	0503010752	1/2" X 3.1/2" BOLT		02
13	0503011440	SPRING WASHER		08
14	0503010060	1/2 UNC G.5 ZN HEX NUT		08
15	1902011561	BEARING SEMI		01
16	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
17	0503014729	1/4" UNF X 1/2" BOLT		02
18	0503011441	SPRING WASHER		02
19	0503010479	BOLT		04
20	0501013352	FLAT WASHER		01
21	0502011505	18Z CONICAL GEAR		01
22	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
23	0501013354	FLAT WASHER		02
24	0502011400	18Z CONICAL GEAR		01
25	0581014526	ELEVATION PLATE 3/8		01
26	0581014527	ELEVATION PLATE 12,5		03
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
28	0503010025	3/8" SPRING WASHER		04
29	0503010026	3/8" NUT		04
30	0503011099	GREASE FITTING		02
31	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521068664	LONG SEED LINE ARM		01
02	0511059244	ROD SPRING LINE SEED	76	01
03	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	77	01
04	0511052024	FAST CLOSING SET	78	01
05	0503034575	TITANIUM HIGH ROW SEED NOZZLE		01
06	0521018078	1/2" X 66.5" HEX AXLE		01
07	0521018079	SEED ROW DRAWBAR LID		01
08	0502011830	ARTICULACCION SUPPORT		01
09	1902010426	UPPER BEARING SEMI		02
10	0511051693	BASE FIXING SYSTEM	79	01
11	0501059632	DDD SEED 15X15 LEFT	81	01
12	0503010752	1/2" X 3.1/2" BOLT		02
13	0503011440	SPRING WASHER		08
14	0503010060	1/2 UNC G.5 ZN HEX NUT		08
15	1902011561	BEARING SEMI		01
16	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
17	0503014729	1/4" UNF X 1/2" BOLT		02
18	0503011441	SPRING WASHER		02
19	0503010479	BOLT		04
20	0501013352	FLAT WASHER		01
21	0502011505	18Z CONICAL GEAR		01
22	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
23	0501013354	FLAT WASHER		02
24	0502011400	18Z CONICAL GEAR		01
25	0581014526	ELEVATION PLATE 3/8		01
26	0581014527	ELEVATION PLATE 12,5		03
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
28	0503010025	3/8" SPRING WASHER		04
29	0503010026	3/8" NUT		04
30	0503011099	GREASE FITTING		02
31	0503010002	1800 GREASE FITTING		02

ROD SPRING LINE SEED

0511059244




Item	Code	Description	See page	QT
01	0511060376	SEED SPRING GUIDE		01
02	0503010834	1/2 X 1 BOLT		02
03	0502040534	SPRING GUIDE BUSHING LOCK		02
04	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
05	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
06	0501013753	FLAT WASHER		01
07	0521010542	COUPLING SHAFT		01
08	0503010257	1/8" X 1" COTTERPIN		01
09	0503012412	5/8 UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0502012538	SPRING VARON SUPPORT		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503011336	1/2" HEX SELF ADJUSTING NUT		02

FAST CLOSING SET


0511052024




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02

BASE FIXING SYSTEM


0511051693




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502011411	10Z CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	15" RIGHT OPENING DISC HUB	82	01
04	0501054168	15" LEFT DOUBLE DISC HUB	83	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	PROTECTION LID		02
07	0503014729	1/4" UNF X 1/2" BOLT		06
08	0503011441	SPRING WASHER		06
09	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13	0503011443	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511052301	SUPPORT DDD 15 RIGHT		01
15A	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
15B	0571012491	SOCKET SEED GUIDE		01
15C	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	15" RIGHT OPENING DISC HUB	82	01
04	0501054168	15" LEFT DOUBLE DISC HUB	83	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	PROTECTION LID		02
07	0503014729	1/4" UNF X 1/2" BOLT		06
08	0503011441	SPRING WASHER		06
09	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13	0503011443	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511052302	LH SUPPORT DDD GUIDE		01
15A	0561015592	LEFT DOUBLE DISC SUPPORT		01
15B	0571012491	SOCKET SEED GUIDE		01
15C	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502011930	OPENING DISCS HUB		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT DOUB DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011930	OPENING DISCS HUB		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012823	DISC BLADE SUPPORT		01
02	0503034318	5/8 UNC X 2 BOLT		02
03	0503010013	5/8" NUT		02



Item	Code	Description	See page	QT
01	0503063223	SEMI-ASSEMBLED SINGLE SEED HOPPER	86	01
02	0581014295	FIXING SLEEVE		01
03	0503012545	FLAT WASHER		04
04	0503014442	BOLT		04
05	0591015106	SEED NOZZLE FIXING FLANGE		01
06	0513010192	LOCK WASHER		04
07	0513010191	BOLT		04
08	0503012534	LOCK WASHER		04
09	0531051514	SIGMA SOY SEED SYSTEM	87	01
10	0503035691	ADHESIVE LABEL		02




Item	Code	Description	See page	QT
01	0503035296	SINGLE SEED BOX		01
02	0503035295	DEPOSIT COVER		01
03	0503035298	BAKELITE HANDLE WITH THREAD		01
04	0503015536	M6 X 1" SELF ADJUSTING NUT		01
05	0503035297	CURVED NOZZLE SEED HOPPER		01




Item	Code	Description	See page	QT
01	0511057289	ASSY SEED DEFLECTOR	88	01
02	0503030083	3/8" X 3/8" X 1.6" STUD		02
03	0503010675	5/16" X 2.1/4" BOLT		01
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
05	0503010337	5/16" NUT		01
06	0502012974	LOWER SEED DISK TRACK		01
07	0501013518	FLAT WASHER		02
08	0503010025	3/8" SPRING WASHER		02
09	0503010209	3/8" UNC BUTTERFLY NUT		02
10	0503016282	ALLEN BOLT		01
11	0503019913	SELF-LOCKING NUT W/ NYLON M8 X 1.25 C.8 ZN		01
12	0503035299	PLATE SPRING 16 X 8.2 X 0.90		02
13	0591018706	SEED HOPPER SUPPORT		01
14	0513010140	SOCIDISCO SOY DISC 90 HOLES		01
15	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461		01
16	0503063405	SOY SEED DISTRIBUTOR CAP		01

ASSY SEED DEFLECTOR


0511057289




Item	Code	Description	See page	QT
01	0503010025	3/8" SPRING WASHER		01
02	0503010209	3/8" UNC BUTTERFLY NUT		01
03	0571018536	HEX PRISONER		01
04	0501013518	FLAT WASHER		02
05	0503034131	DEFLECTOR		01




Item	Code	Description	See page	QT
01	0521068662	DOC SHORT ARM		01
02	0581011838	SLEEVE GUIDES		01
03	0521015376	DUST CLOAK		01
04	0503010878	5/8" SELF ALIGNING NUT		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2 UNC G.5 ZN HEX NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503010276	6206 BALL BEARING		01
10	0503030832	FLAT WASHER		01
11	0511059229	HUB WITH DOC 18 TURBO RIGHT	91	01
12	0503010384	1/2" X 5" BOLT		02



Item	Code	Description	See page	QT
01	0521068662	DOC SHORT ARM		01
02	0581011838	SLEVE GUIDES		01
03	0521015376	DUST CLOAK		01
04	0503010878	5/8" SELF ALIGNING NUT		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2 UNC G.5 ZN HEX NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503010276	6206 BALL BEARING		01
10	0503030832	FLAT WASHER		01
11	0511059230	HUB WITH DOC 18 TURBO LEFT	92	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0502011562	DISC BLADE HUB		01
02	0503011800	SEAL RING		01
03	0503012417	SEAL		01
04	0503010276	6206 BALL BEARING		01
05	0503030832	FLAT WASHER		01
06	0503011444	SPRING WASHER		06
07	0503010691	1/4" GREASE FITTING		01
08	0503010337	5/16" NUT		06
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0607025032	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0502011562	DISC BLADE HUB		01
02	0503011800	SEAL RING		01
03	0503012417	SEAL		01
04	0503010276	6206 BALL BEARING		01
05	0503030832	FLAT WASHER		01
06	0503011444	SPRING WASHER		06
07	0503010691	1/4" GREASE FITTING		01
08	0503010337	5/16" NUT		06
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0607025032	PLAIN COULTER BLADE		01

MOUNTED FERTILIZER CONDUCTOR


0521050168




Item	Code	Description	See page	QT
01	0581013298	SUPPORT		01
02	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
03	0521018517	FLAT WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0503030483	FERTILIZER SOCKET		01
07	0503031050	CURVED CONDUCTOR		01
08	0503010246	CLAMP		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012825	DISC BLADE FIXED AXLE		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	THRUST WASHER		01
17	0503034319	LOCK PIN		01
18	0511058648	HUB WITH 20" DISC BLADE	96	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012824	DISC BLADE FIXED AXLE		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	THRUST WASHER		01
17	0503034319	LOCK PIN		01
18	0511058648	HUB WITH 20" DISC BLADE	96	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	97	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01



Item	Code	Description	See page	QT
01	0502012793	DISC HUB		01
02	0571018047	DISC BLADE HUB AXLE		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DUST CLOAK		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK	02	
02	0502012184	FERTILIZER SPRING GUIDE	02	
03	0503031910	1.7" X 22.8" X 0.3" SPRING	01	
04	0502012510	SPRING ROD SUPPORT	01	
05	0521068568	LARGE ELEVATION SPRING FERTILIZER	01	
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN	01	
07	0501018535	1/2 X 1 BOLT	02	
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
09	0503010060	1/2 UNC G.5 ZN HEX NUT	02	
10	0502010891	SPRING CHOCK SUPPORT VARON	01	
11	0503010014	3/4" HEX NUT	01	
12	0561014471	COUPLING SHAFT	01	
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN	01	
14	0503010257	1/8" X 1" COTTERPIN	01	




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
03	0521019093	0.6" X 2.7" PIVOT SHAFT		01
04	0503010581	RING		01
05	1902012116	PRESS WHEEL ADJUSTER		01
06	0501052297	DEPTH WHEELS REGULATOR ASSY	100	01
07	0501052908	COMPACTOR WHEEL WITH BEARING	101	02
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
09	0521014508	FLAT WASHER		10
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0581011100	DEPTH WHEEL AXLE		01
12	0571017749	FLAT WASHER		02
13	0521056314	LEFT ARM WHEEL DEPTH WITH HUB CPERA	102	01
14	0521056313	RIGHT ARM WHEEL DEPTH WITH HUB CPERA	104	01
15	0503010358	5/16" X 5/8" BOLT		08
16	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
17	0503013816	5/16" LOCKNUT		08
18	0501011445	FLAT WASHER		02
19	0503010311	1/2" X 1-1/4" BOLT		02
20	0503010019	1/2" SPRING WASHER		02
21	0503010025	3/8" SPRING WASHER		02
22	0503010026	3/8" NUT		02
23	0503010849	3/8" X 1-1/2" BOLT		02
24	0503010256	3/8" X 3/4" BOLT		01
25	0511055819	DEPTH BAND WITH RIM	105	02
26	0503010691	1/4" GREASE FITTING		02
27	0503033942	COMPACTOR WHEEL REGULATOR LID		01
28	0521064073	REGULACION WHEEL COMPACTOR		01
29	0541016906	PRESS WHEELS REGULATOR BODY		01
30	0521010539	0.3" X 1.2" COUPLING SHAFT		01
31	0503010140	1/8" X 3/4" COTTERPIN		01




Item	Code	Description	See page	QT
32	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0521056316	DEPTH WHEEL HUB WITH COMPLETE ANGLE 103 ADJUSTING AXLE		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501013636	SPACING SLEEVE		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010689	SEAL 00763-BR		01
04	0503011105	SEAL RING		01
05	0503010269	6204 BALL BEARING		02
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0521019178	PROTECTION LID		01
09	0503010143	1/4" SPRING WASHER		03
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0521060071	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0501110833	DEPTH CONTROL RIGHT ARM		01
02	0521056316	DEPTH WHEEL HUB WITH COMPLETE ANGLE 103 ADJUSTING AXLE		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC	108	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC	113	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04

LEFT DUAL FERTILIZER DISC


0521055869




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
07	0503010025	3/8" SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 109 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 110 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	111	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01



Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	112	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUB DISC - HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01

RIGHT DUAL FERTILIZER DISC


0521055868




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
07	0503010025	3/8" SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 109 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 110 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0513010117	SOCIDISCO CORN DISC 28 HOLES 9,0 AMC9R-002130		01
02	0513010118	SOCIDISCO CORN DISC 28 HOLES 9,5 VLD9.5R-002115		01
03	0513010119	SOCIDISCO CORN DISC 28 HOLES 10 SAL10R-002619		01
04	0513010120	SOCIDISCO CORN DISC 28 HOLES 10,5 RSP10.5R-002133		01
05	0513010121	SOCIDISCO CORN DISC 28 HOLES 11 LRA11R-002134		01
06	0513010122	SOCIDISCO CORN DISC 28 HOLES 11,5 MAG11.5R-002620		01
07	0513010123	SOCIDISCO CORN DISC 28 HOLES 12 VDA12R-002621		01
08	0513010124	SOCIDISCO CORN DISC 28 HOLES 12,5 AMP12.5R-002131		01
09	0513010125	SOCIDISCO CORN DISC 28 HOLES 13 VMV13R-002132		01
10	0513010126	SOCIDISCO CORN DISC 28 HOLES 13,5 RXR13.5R-002136		01
11	0513010187	SOCIDISCO CORN DISC 28 HOLES 14,8 X 10 VM4-002581		01
12	0513010188	SOCIDISCO CORN DISC 28 HOLES 11 X 8 BR8.1-002589		01
13	0513010189	SOCIDISCO CORN DISC 28 HOLES 12,5 X 8,5 AZ8.2-002587		01
14	0513010164	SOCIDISCO FLAT RING FOR CORN AMFOSLISO-002127		01
15	0513010159	SOCIDISCO RING FOR CORN 0,8MM LRFOSSR08-002120		01
16	0513010160	SOCIDISCO RING FOR CORN 1,4MM VMFOSR1.4-002245		01
17	0513010163	SOCIDISCO RING FOR CORN 2,0MM VDFOSR2-002116		01
18	0503063413	4Z CORN SEED DISTRIBUTOR CAP - 001798		01




Item	Code	Description	See page	QT
01	0513010136	SOCIDISCO SOY DISC 62 HOLES 7,5 LRA62.75-002357	01	01
02	0513010137	SOCIDISCO SOY DISC 62 HOLES 8,0 RSP62.80-002358	01	01
03	0513010138	SOCIDISCO SOY DISC 62 HOLES 8,5 RXR62.85-002359	01	01
04	0513010139	SOCIDISCO SOY DISC 62 HOLES 9,0 AZM62.90-002360	01	01
05	0513010141	SOCIDISCO SOY DISC 90 HOLES 8,0 RSP90.80-002287	01	01
06	0513010142	SOCIDISCO SOY DISC 90 HOLES 8,5 RXR90.85-002317	01	01
07	0513010143	SOCIDISCO SOY DISC 90 HOLES 9,0 AZM90.90-002288	01	01
08	0513010158	SOCIDISCO FLAT RING FOR SOY AZMSOJALISO-002243	01	01
09	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461	01	01
10	0513010162	SOCIDISCO RING FOR SOY 1,5MM RSPSOJASR1,5-002244	01	01
11	0503063412	4Z SOY/BEAN SEED DISTRIBUTOR CAP - 001804	01	01



Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01



Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

