

ROW CROP PLANTERS

PST PLUS FLEX - FRAME 4395 - CSU (FROM 05/2023)

Code: 0501093525

Series: S-0116

Revision: 00

Date Revision: MAIO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code
0111380511

Description
PST PLUS FLEX 4395/9E500 ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909094348	FRAME ASSY	1
0511057361	FRAME WITH WHEEL AXLE - 4395	2
0511057358	PLATFORM ASSEMBLY - 4395	3
0531059578	FERTILIZER SILO SET ALPHA II	4
0531059583	LEFT SILO SUPPORT 4395 WITH ALPHA DOSER	5
0531059579	RIGHT SILO SUPPORT 4395 WITH ALPHA DISPENSER	6
0531055319	ALPHA II FERTILIZER METERING	7
0531055863	ASSY TRANSMISSION HUB	8
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	9
0531059139	ASSY COLLECTOR	10
0531055273	ALPHA FERTILIZER METERING CLAMP	11
0501053788	3/4 SQUARE AXLE FASTENER	12
0531057913	DOUBLE BEARING ASSEMBLY	13
0531057912	DOUBLE SIDE BEARING	14
0531058278	CSU C3 X 175 SET 2 BOXES	15
0531058276	ASSY BOX SEED	16
0531057950	3" X 175 SEED NOZZLE WITH FIXING	17
0531054471	CAP WITH FIXING	18
0511059323	PLATFORM TRANSPORT SUPPORT	19
0909098983	HEX AXLE ASSEMBLY - 245/3495/4395/4845	20
0521055338	ROW SEED BEARING	21
0511058653	WHEELS WITH TRACTION SPRING	22
0511058654	WHEEL SUPPORT	23
0501058241	WHEEL SUPPORT CHAIN TENSIONER	24
0511052770	WHEEL WITH TIRE	25
0503062159	WHEEL WITH TIRE	26
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	27
0501058240	WHEEL FASTENER WITH TENSIONER	28
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	29
0501058239	WHEEL CHAIN TENSIONER BEARING	30
0501058244	WHEEL FIXED CHAIN TENSIONER	31
0501058242	WHEEL MOBILE CHAIN TENSIONER	32
0511056536	LADDER ASSEMBLY	33
0511054971	JACK ASSEMBLY	34
0511054601	HITCH ARTICULATED TRACTOR	35
0511057333	DRAWBAR ASSEMBLY - 3495/4045/4395/4845/5345/5745	36
0511057270	DRAWBAR EXTENDER	37
0511058655	CYLINDER SET - 3245/3495/4045/4395	38
0501053834	MALE QUICK COUPLER	39
0521045510	HYDRAULIC CYLINDER	40
0511057266	HYDRAULIC SYSTEM ASSEMBLY - 3245/3495/4045/4395	41
0511053179	TRACTOR COUPLING SHAFT	42
0511056736	HOSE SUPPORT	43
0511057845	MANUAL CANISTER	44
0511059322	LIFTING SUPPORT ASSEMBLY	45
0541050035	TRANSMISSION SET 7.00	46
0501052560	MOTOR AXLE SIGNAL	47
0511051434	TRANSMISSION ACTUATOR	48
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	49
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	50
0501056271	GEARBOX CLOSED BEARING	51
0511057265	TRANSMISSION CHAIN TENSIONER	52
0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	53
0511050652	CHAIN TENSIONER	54
0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	55



MARCHESAN

INDEX


0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	56
0521055335	RIGHT GEAR HOUSING SET	57
0521055337	LEFT GEAR HOUSING SET	58
0511058381	RIGHT GEAR HOUSING	59
0511058382	LEFT GEAR HOUSING	60
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	61
0501048790	AXLE WITH RING	62
0501056443	GEAR HOUSING BEARING	63
0501056444	BEARING WITH ROLLER	64
0511057258	TENSIONER WITH GEAR	65
0511054363	CHAIN TENSIONER	66
0511057359	HANDRAIL ASSEMBLY - 4395	67
0511059383	HANDRAIL INTERNAL FIXER	68
0531059619	KIT WITH ALPHA COMPONENTS 9 LINES	69
0909096712	ASSY SEED/FERTILIZER ROW	70
0531055721	SHORT SEED ROW FRONT WITH LUBRICATION	71
0531055723	LONG SEED ROW FRONT WITH LUBRICATION	72
0511058766	BEARING	73
0511057159	TRANSMISSION HOPPER SEED ROW	74
0511058512	PROTECTION LID	75
0531054983	SHORT BEARING WITH 17Z GEAR	76
0521052368	STRETCHER SIMPLE SEED	77
0531054981	LONG BEARING WITH 17Z GEAR	78
0531059396	RIGHT REAR SEED LINE FRONT SIGMA QUICK FITTING	79
0531059395	REAR LEFT SEED LINE FRONT SIGMA QUICK FIXING	80
0531058675	DDD SEED 15 X 15 RIGHT	81
0531058676	DDD SEED 15 X 15 LEFT	82
0511052301	SUPPORT DDD 15 RIGHT	83
0511053173	RIGHT LOW HUB WITH 15 DISC	84
0511053172	LEFT LOW HUB WITH 15 DISC	85
0511052302	LH SUPPORT DDD GUIDE	86
0511059051	SHORT FERTILIZER ROW	87
0511059052	SHORT ROW FERTILIZER	88
0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	89
0511057272	LH SHORT ARM ROW FERTILIZER	90
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	91
0511059050	DOC 20" ASSY	92
0511058838	20" WAVY COULTER BLADE HUB	93
0511056909	DISC BLADE HUB WITHOUT DISC	94
0511058634	SUPPORT LONG	95
0511057271	RH LONG ARM ROW FERTILIZER	96
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	97
0531059351	SEED SILO CSU FRONT TRANSMISSION QUICK FITTING	98
0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	99
0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK LID	100
0531059302	SEED SILO SUPPORT FRONT TRANSMISSION FAST FIXING SIGMA	101
0531054795	FRONT TRANSMISSION ASSEMBLY	102
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	103
0511058650	SEMI-MOUNTED DEPTH CONTROL	104
0511058652	LEFT DEPTH WHEEL ARM WITH HUB	105
0501052627	ASSY DEPTH WHEEL HUB	106
0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	107
0501052297	DEPTH WHEELS REGULATOR ASSY	108
0501052538	DEPTH BAND WITH ARMS	109



MARCHESAN


INDEX

0511054333	COMPACT WHEEL RIGHT WITH BEARING		110
0501052908	COMPACTOR WHEEL WITH BEARING		111
0511054334	COMPACT WHEEL LEFT WITH BEARING		112
0501110804	SCARIFIER ROD WITH POINT		113
0531050237	SEED CONDUCTOR FIXER 3 CSU RIGHT		114
0503063785	SIGMA V2 CORN DISC SET		115
0503063786	SIGMA V2 SOY DISC SET		116
0521057957	FIXED ROD EXTENSION WITH FIXATION		117




Item	Code	Description	See page	QT
01	0511057361	FRAME WITH WHEEL AXLE - 4395	2	01
02	0511057358	PLATFORM ASSEMBLY - 4395	3	01
03	0531059578	FERTILIZER SILO SET ALPHA II	4	01
04	0531058278	CSU C3 X 175 SET 2 BOXES	15	01
05	0511059323	PLATFORM TRANSPORT SUPPORT	19	01
06	0909098983	HEX AXLE ASSEMBLY - 245/3495/4395/4845	20	01
07	0511058653	WHEELS WITH TRACTION SPRING	22	04
08	0511056536	LADDER ASSEMBLY	33	02
09	0511054971	JACK ASSEMBLY	34	02
10	0511054601	HITCH ARTICULATED TRACTOR	35	01
11	0511057333	DRAWBAR ASSEMBLY	- 36	01
12	0511057270	DRAWBAR EXTENDER	37	01
13	0511058655	CYLINDER SET - 3245/3495/4045/4395	38	01
14	0501068994	8,30 X 78 LOCK PIN		01
15	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
16	0501047895	25 ROD STOP		01
17	0501047885	30 ROD STOP		01
18	0501047886	35 ROD STOP		01
19	0501047887	40 ROD STOP		01
20	0511056736	HOSE SUPPORT	43	01
21	0501065677	STRUT		02
22	0503030168	HITCH PIN CLIP		01
23	0521055338	ROW SEED BEARING		01
24	0511057266	HYDRAULIC SYSTEM ASSEMBLY	- 41	01
25	0503010003	1845 GREASE FITTING		04
26	0511053179	TRACTOR COUPLING SHAFT	42	01
27	0521013022	TRANSPORT LOCK		01
28	0503010780	N-2050 AMENDMENT		02
29	0503010951	REDUCTION		04
30	0503011750	AMENDMENT WITH LOCK		01


Item	Code	Description	See page	QT
31	0503011751	REDUCTION		01
32	0511057845	MANUAL CANISTER	44	01
33	0531057428	LABELS KIT - 4395		01
34	0511059322	LIFTING SUPPORT ASSEMBLY	45	02
35	0541050035	TRANSMISSION SET 7.00	46	01
36	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		02
37	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
38	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
39	0503010019	1/2" SPRING WASHER		04
40	0503010060	1/2 UNC G.5 ZN HEX NUT		04
41	0511057359	HANDRAIL ASSEMBLY - 4395	67	01
42	0503014120	CHAIN		01
43	0503014321	CABLE STEEL SHACKLE		02
44	0531059619	KIT WITH ALPHA COMPONENTS 9 LINES	69	01
45	0909096712	ASSY SEED/FERTILIZER ROW	70	09




Item	Code	Description	See page	QT
01	0521065920	FRAME - 4395		01
02	0521065929	CARRYING-WHEELS PIVOT SHAFT - 4395		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0571018867	PLATFORM - 4395		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0531059583	LEFT SILO SUPPORT 4395 WITH ALPHA DOSER	5	01
02	0531059579	RIGHT SILO SUPPORT 4395 WITH ALPHA 6 DISPENSER	6	01
03	0503011957	NYLON HANDLE		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
05	0503010337	5/16" NUT		04
06	0503018441	5/16" X 1-1/4" BOLT		04
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
08	0503010025	3/8 SPRING WASHER		10
09	0503010026	3/8" NUT		10
10	0501010984	10,50 X 27 X 3,00 FLAT WASHER		20
11	0503062391	FERTILIZER HOPPER		02
12	0503013751	3/8 UNC X 1.1/4 BOLT		16
13	0571019051	FIXER HOPPER WASHER		16
14	0503012535	3/8" SPRING WASHER		16
15	0503012531	3/8" INOX NUT		16




Item	Code	Description	See page	QT
01	0531065981	FERTILIZER SILO SUPPORT 4395 LEFT		01
02	0531055319	ALPHA II FERTILIZER METERING	7	05
03	0501053788	3/4 SQUARE AXLE FASTENER	12	02
04	0503030303	SUPPORT WASHER		02
05	0531057913	DOUBLE BEARING ASSEMBLY	13	01
06	0501218689	AXLE 3/4 X 190 WITH HOLE		01
07	0501218487	3/4 X 390 AXLE		05
08	0531057908	SLEEVE 1/4 X 2		05
08A	0502013069	SLEEVE 21 X 38 X 50		05
08B	0503010010	1/4" X 2.1/2" COTTERPIN		05




Item	Code	Description	See page	QT
01	0531065982	SUPPORT FERTILIZER SILO 4395 RIGHT		01
02	0531055319	ALPHA II FERTILIZER METERING	7	05
03	0501218487	3/4 X 390 AXLE		05
04	0531057908	SLEEVE 1/4 X 2		05
04A	0502013069	SLEEVE 21 X 38 X 50		05
04B	0503010010	1/4" X 2.1/2" COTTERPIN		05
05	0501053788	3/4 SQUARE AXLE FASTENER	12	02
06	0503030303	SUPPORT WASHER		02
07	0531057913	DOUBLE BEARING ASSEMBLY	13	01
08	0501218689	AXLE 3/4 X 190 WITH HOLE		01




Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	ASSY TRANSMISSION HUB	8	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	9	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513011170	ALLEN SCREW 1/4 UNC X 7/8 CCSI STAINLESS STEEL		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501310211	FRONT COVER ADB ALPHA II DISPENSER		01
19	0503036177	ADB ALPHA DISPENSER COVER STRING		01
20	0531059139	ASSY COLLECTOR	10	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO ADHESIVE LABEL 41.5 X 29		01
15	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT GUIDE DOSING COVER		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT GLOVE FIXING SAFETY LOCK DISPENSER		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT GLOVE FIXING SAFETY LOCK DISPENSER		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	11	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0531057912	DOUBLE SIDE BEARING	14	01
02	0502013068	SIDE BEARING SHAFT SUPPORT FERTILIZER SILO		01
03	0503010845	501035 CLAMPING RING (FOR AXLE)		01
04	0503010337	5/16" NUT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0531057901	GEAR		01
07	0503030119	LOCK PIN		01
08	0501010694	FLAT WASHER		02
09	0503010371	5/16" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0502013071	SIDE BEARING		01
02	0503016065	ROLLER BEARING		02
03	0503011800	SEAL RING		01




Item	Code	Description	See page	QT
01	0531058276	ASSY BOX SEED	16	02
02	0521066102	TOWER SUPPORT HOPPER		08
03	0501010942	3/8" X 1-1/4" BOLT		16
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
05	0503010025	3/8 SPRING WASHER		16
06	0503010026	3/8" NUT		16
07	0502010175	HITCH CLAMP		08
08	0501011543	5/8" X 4" BOLT		16
09	0503012412	5/8" UNC SELF LOCKING NUT		16
10	0571019394	PROTECTOR		04
11	0551019884	45 X 50 X 3/8 FASTENER		16
12	0501010453	FLAT WASHER		32
13	0503010025	3/8 SPRING WASHER		32
14	0503010026	3/8" NUT		32




Item	Code	Description	See page	QT
01	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0531057950	3" X 175 SEED NOZZLE WITH FIXING	17	09
08	0531054471	CAP WITH FIXING	18	03




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID		01
02	0501010942	3/8" X 1-1/4" BOLT		05
03	0503010025	3/8 SPRING WASHER		05
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	5/16" NUT		02
11	0502012767	SEED NOZZLE FIXER SUPPORT		01
12	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0571015773	SUPPORT SEED		01
02	0501011643	3/8 X 1"BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0581011989	SIDE BODY FIXER PLATFORM		01
02	0551019884	45 X 50 X 3/8 FASTENER		01
03	0503010025	3/8 SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	3245	3495	4395	4845
01	0521055338	ROW SEED BEARING	21	04	04	04	04
02	0571018910	3/4 X 1505 AXLE HEX		01	00	00	00
02.	0571018912	3/4 X 1630 AXLE HEX		00	01	00	00
02..	0571018916	3/4 X 2080 AXLE HEX		00	00	01	00
02...	0571018918	3/4 X 2305 AXLE HEX		00	00	00	01
03	0571018911	3/4 X 1690 AXLE HEX		01	00	00	00
03.	0571018913	3/4 X 1815 AXLE HEX		00	01	00	00
03..	0571018917	3/4 X 2265 AXLE HEX		00	00	01	00
03...	0571018919	3/4 X 2490 AXLE HEX		00	00	00	01
04	0511054314	TRANSMISSION AXLE LOCK SLEEVE		18	20	24	26
04A	0502012699	TRANSMISSION HUB LOCK SLEEVE		18	20	24	26
04B	0503010256	3/8" X 3/4" BOLT		18	20	24	26




Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING		01
03A	0502012030	HOUSING BEARING		01
03B	0503012861	6006 2RS BALL BEARING		01
03C	0503012858	502075 CLAMPING RING (FOR HOLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02
07	0501013518	FLAT WASHER		02
08	0501010694	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511058654	WHEEL SUPPORT	23	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	28	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521066716	WHEEL ARM ASSY		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
08	0503010027	5/8 SPRING WASHER		01
09	0501058241	WHEEL SUPPORT CHAIN TENSIONER	24	01
10	0503013030	5/8" X 3.1/4" BOLT		01
11	0551017715	FLAT WASHER		02
12	0511052770	WHEEL WITH TIRE	25	01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8 SPRING WASHER		02
15	0503011167	M16 X 2 X 30 BOLT		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	26	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	27	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	29	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	31	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	32	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	30	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	30	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	30	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8 SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
08	0503013357	3/8 SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0502012806	SUPPORT REAR FIXER DRAWBAR		04
02	0502012789	FIXER SUPPORT FERTILIZER ROW		04
03	0503017960	5/8" X 3-12" BOLT		16
04	0503010811	5/8" UNF SELF ADJUSTING NUT		16
05	0501010191	1" X 6" BOLT		04
06	0503010012	1" SPRING WASHER		04
07	0501010059	1.5/8 NUT		04
08	0502012805	SUPPORT FRONT FIXER DRAWBAR		04
09	0502012789	FIXER SUPPORT FERTILIZER ROW		04
10	0503017960	5/8" X 3-12" BOLT		16
11	0503010811	5/8" UNF SELF ADJUSTING NUT		16
12	0521065958	DRAWBAR		01
13	0561019087	DRAWBAR TRANSPORT LOCK		01
14	0551014099	COUPLING SHAFT 31,75 X 185		01
15	0521010544	1.2" X 4.9" COUPLING SHAFT		01
16	0503030085	LOCK PIN		02
17	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521065959	JACK R.1.1/2 UNC RIGHT X 240		01
03	0521065960	JACK R.1.1/2 UNC LEFT X 240		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521045510	HYDRAULIC CYLINDER	40	01
02	0551014099	COUPLING SHAFT 31,75 X 185		01
03	0521010547	1.2" X 6.5" COUPLING SHAFT		01
04	0503010523	1/4" X 2" SPLIT PIN		02
05	0501047888	45 ROD STOP		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521065976	127 X 438,5 TUBE		01
02	0581013698	PISTON		01
03	0521067585	EXTENDER 50.80 X 371.5 WITH BUSHING		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010003	1845 GREASE FITTING		01
06	0503030385	CYLINDER PLUG N-002		02
07	0503018439	WIPER SEAL		01
08	0503018150	RING GUIDE		01
09	0502010382	5" END CAP		01
10	0581010353	RING SUPPORT		01
11	0503018026	1870-2000-375 B GASKET		01
12	0503011453	O'RING		02
13	0503018152	O'RING		02
14	0503018024	RING BS		01
15	0503018025	RING GUIDE		01
16	0503010039	D-2000 SCRAPER RING		01
17	0503010173	2-220 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0511057267	HOSE KIT HYDRAULIC		01
01A	0501080722	3/8 X 3300 TC-TM HOSE ASSY		01
01B	0501082023	HOSE 3/8 X 3600 TC-TM		01
02	0501053834	MALE QUICK COUPLER	39	02
03	0503013100	NYLON CLAMP		02
04	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01



Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521067033	FRAME LIFTING SUPPORT		01
03	0503017960	5/8" X 3-12" BOLT		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	24	04
13	0571018907	AXLE MOTOR 2125		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	47	02
16	0511051434	TRANSMISSION ACTUATOR	48	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	49	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	50	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		02
20	0501053788	3/4 SQUARE AXLE FASTENER	12	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING	51	02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
25	0503010025	3/8 SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	52	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
30	0503010140	1/8" X 3/4" COTTERPIN		02
31	0571018846	DISASSEMBLE LEVER		02


Item	Code	Description	See page	QT
32	0503033942	COMPACTOR WHEEL REGULATOR LID		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012407	5/8" X 1-1/2" BOLT		04
37	0503012412	5/8" UNC SELF LOCKING NUT		04
38	0511061759	22Z P12,70 FQ 3/4" GEAR		02
39	0501053788	3/4 SQUARE AXLE FASTENER	12	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING	51	02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
44	0503010025	3/8 SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	52	02
47	0511065209	20Z GEAR		02
48	0501053788	3/4 SQUARE AXLE FASTENER	12	02
49	0503030303	SUPPORT WASHER		02
50	0503010292	701164 6 X 40 SPRING PIN		02
51	0521018630	1.4" X SQUARE 0.8" WASHER		02
52	0501056271	GEARBOX CLOSED BEARING	51	02
53	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
54	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
55	0503010025	3/8 SPRING WASHER		04
56	0503010026	3/8" NUT		04
57	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	53	02
58	0511050652	CHAIN TENSIONER	54	04
59	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	55	02
60	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
61	0503014911	40-1 X 63 CHAIN LINK + MENDING		02
62	0503015001	40-1 X 153 CHAIN LINK + MENDING		02
63	0531062318	LEFT/RIGHT LOWER LEVER		02
64	0551019159	LEVER FIXER BODY		02
65	0561016468	FASTENER		02
66	0503011336	1/2" HEX SELF ADJUSTING NUT		04
67	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
68	0503010140	1/8" X 3/4" COTTERPIN		04
69	0521055335	RIGHT GEAR HOUSING SET	57	01
70	0521055337	LEFT GEAR HOUSING SET	58	01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0541011713	TENSIONER CHAIN LOWER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551019171	CHAIN TIGHTENER AXLE		01
02	0503011410	ROLLER BEARING		01
03	0511062169	21Z P 1/2" GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503011105	SEAL RING		01
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0571010265	16.5 X 40 X 3 FLAT WASHER		01
08	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	56	01
02	0511063185	20Z GEAR WITH HEX HOLE AXLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		02
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01



Item	Code	Description	See page	QT
01	0511058381	RIGHT GEAR HOUSING	59	01
02	0521065955	RIGHT GEARBOX LID		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0503010019	1/2" SPRING WASHER		01
07	0501010694	FLAT WASHER		06
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01



Item	Code	Description	See page	QT
01	0511058382	LEFT GEAR HOUSING	60	01
02	0521065956	LEFT GEARBOX LID		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
07	0503010019	1/2" SPRING WASHER		01
08	0501010694	FLAT WASHER		06




Item	Code	Description	See page	QT
01	0521065939	RIGHT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN SHAFT		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	61	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING	51	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TIGHTENER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	62	02
20	0503031366	RIGHT TWISTED SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	63	01
31	0503010292	701164 6 X 40 SPRING PIN		08



Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	65	01
33	0511054363	CHAIN TENSIONER	66	01
34	0571018901	DRIVEN AXLE		01

LEFT GEAR HOUSING

0511058382




Item	Code	Description	See page	QT
01	0521065940	LEFT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN SHAFT		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	61	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING	51	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TIGHTENER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	62	02
20	0503031367	SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	63	01
31	0503010292	701164 6 X 40 SPRING PIN		08




LEFT GEAR HOUSING

0511058382


Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	65	01
33	0511054363	CHAIN TENSIONER	66	01
34	0571018901	DRIVEN AXLE		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	64	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0571019207	DEVIATION AXLE GEAR BOX		01
06	0503010899	5/8 UNC X 2.1/4 BOLT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521065951	FRAME HANDRAIL - 4395		02
02	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0581012916	INTERMEDIATE TUBE		02
07	0511059383	HANDRAIL INTERNAL FIXER	68	04



Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01



Item	Code	Description	See page	QT
01	0531058988	WORM THREAD P.16 WITH FERTILIZER DOSING SHAFT COATING		09
01A	0531065012	WORM THREAD P.16MM ALPHA FERTILIZER DOSER		09
01B	0503035859	SUPPORT SLEEVE		09
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		09
02A	0501111196	PALLETIZED FERTILIZER COATING COMPLETE PLANTING FERTILIZER DOSER ALP II		09
02B	0531058987	WORM SCREW P.50 WITH ADB ALPHA DISPENSER SHAFT COATING		09
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531055721	SHORT SEED ROW FRONT WITH LUBRICATION	71	01
02	0531055723	LONG SEED ROW FRONT WITH LUBRICATION	72	01
03	0531059396	RIGHT REAR SEED LINE FRONT SIGMA QUICK FITTING	79	01
04	0531059395	REAR LEFT SEED LINE FRONT SIGMA QUICK FIXING	80	01
05	0511059051	SHORT FERTILIZER ROW	87	01
06	0511059052	SHORT ROW FERTILIZER	88	01
07	0531059351	SEED SILO CSU FRONT TRANSMISSION QUICK FITTING	98	01
08	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	103	01
09	0501110804	SCARIFIER ROD WITH POINT	113	01
10	0531059865	RIGHT SEED CONDUCTOR WITH PROTECTION		01
11	0521069127	BOTTOM NOZZLE FERTILIZER		01
12	0531050237	SEED CONDUCTOR FIXER 3 CSU RIGHT	114	01
13	0503010025	3/8 SPRING WASHER		01
14	0503063785	SIGMA V2 CORN DISC SET	115	01
15	0503063786	SIGMA V2 SOY DISC SET	116	01
16	0503031050	CURVED CONDUCTOR		01
17	0503010246	CLAMP		01
18	0503030391	RIGHT FERTILIZER NOZZLE		01
19	0503030392	LEFT FERTILIZER NOZZLE		01
20	0503031145	2" X 2" X 20" HOSE		01
21	0503031076	2" HOSE CLAMP		01
22	0531013600	PRESS ADJUSTMENT LEVER		01
23	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
24	0503010019	1/2" SPRING WASHER		01
25	0503010060	1/2 UNC G.5 ZN HEX NUT		01
26	0503035755	440 SEED NOZZLE		01
27	0503030520	SEED SOCKET		01
28	0503010905	1/2" X 2-1/4" BOLT		01
29	0511017969	0.1" SPACING PLATE		01

**ASSY SEED/FERTILIZER ROW**

0909096712


Item	Code	Description	See page	QT
30	0511018662	SPACING PLATE		01
31	0503010026	3/8" NUT		01
32	0521057957	FIXED ROD EXTENSION WITH FIXATION	117	01
33	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
34	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01



Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
05	0503012412	5/8" UNC SELF LOCKING NUT		04
06	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
07	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
08	0571018883	PIN FIXER SPRING		03
09	0571018884	LOCK PIN ROW ARTICULAT		01
10	0503030168	HITCH PIN CLIP		04
11	0511058766	BEARING	73	01
12	0511057159	TRANSMISSION HOPPER SEED ROW	74	01
13	0571012492	5/8 X 330 AXLE HEX		01
14	0501056296	UNIVERSAL JOINT		01
15	0503011855	0.2" X 1.8" SPRING PIN		02
16	0531063926	REAR SHORT FRAME		01
17	0501213859	REAR PROTECTION CASE		01
18	0503010765	3/8" X 3" BOLT		01
19	0503010025	3/8 SPRING WASHER		01
20	0501012140	FLAT WASHER		04
21	0511058512	PROTECTION LID	75	01
22	0581011430	DRAWBAR ASSY		01
23	0581010976	5/8" HEX AXLE		01
24	0503032984	HOOD HEX AXLE ROW		01
25	0503013100	NYLON CLAMP		01
26	0503017857	BOLT 5/8 UNF 4		04
27	0531054983	SHORT BEARING WITH 17Z GEAR	76	01
28	0521052368	STRETCHER SIMPLE SEED	77	01
29	0503010209	3/8" UNC BUTTERFLY NUT		01
30	0513010290	ELASTIC PIN 701137 5 X 26		01
31	0503017491	40-1 X 99 LINKS + AMENDMENT CHAIN		01




Item	Code	Description	See page	QT
32	0502012804	PIVOT ARM SEED ROW		02
33	0503010004	1890 GREASE FITTING		04
34	0571018882	SEED ROW ARM SLEEVE		08




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
05	0503012412	5/8" UNC SELF LOCKING NUT		04
06	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
07	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
08	0571018883	PIN FIXER SPRING		03
09	0571018884	LOCK PIN ROW ARTICULAT		01
10	0503030168	HITCH PIN CLIP		04
11	0511058766	BEARING	73	01
12	0511057159	TRANSMISSION HOPPER SEED ROW	74	01
13	0571012492	5/8 X 330 AXLE HEX		01
14	0501056296	UNIVERSAL JOINT		01
15	0503011855	0.2" X 1.8" SPRING PIN		02
16	0531063927	REAR LONG FRAME		01
17	0501213859	REAR PROTECTION CASE		01
18	0503010765	3/8" X 3" BOLT		01
19	0503010025	3/8 SPRING WASHER		01
20	0501012140	FLAT WASHER		04
21	0511058512	PROTECTION LID	75	01
22	0581011430	DRAWBAR ASSY		01
23	0581010976	5/8" HEX AXLE		01
24	0503032984	HOOD HEX AXLE ROW		01
25	0503013100	NYLON CLAMP		01
26	0503017857	BOLT 5/8 UNF 4		04
27	0531054981	LONG BEARING WITH 17Z GEAR	78	01
28	0521052368	STRETCHER SIMPLE SEED	77	01
29	0503010209	3/8" UNC BUTTERFLY NUT		01
30	0513010290	ELASTIC PIN 701137 5 X 26		01
31	0503017491	40-1 X 99 LINKS + AMENDMENT CHAIN		01




Item	Code	Description	See page	QT
32	0502012804	PIVOT ARM SEED ROW		02
33	0503010004	1890 GREASE FITTING		04
34	0571018882	SEED ROW ARM SLEEVE		08




Item	Code	Description	See page	QT
01	0502012852	ROW SEED UPPER BEARING		01
02	0503011105	SEAL RING		01
03	0502012851	17Z GEAR WITH HEX HOLE		01
04	0503011410	ROLLER BEARING		02
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010237	3/8" X 1" BOLT		02
07	0503010025	3/8 SPRING WASHER		02
08	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0521066693	CAP BEARING		01
02	0503010834	1/2 X 1 BOLT		02
03	0503010019	1/2" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0503010337	5/16" NUT		02
02	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010707	501030 CLAMPING RING (FOR AXLE)		01
06	0503012861	6006 2RS BALL BEARING		01
07	0502012030	HOUSING BEARING		01
08	0501213865	3/4 X 157 HEXAGONAL AXLE		01
09	0513010290	ELASTIC PIN 701137 5 X 26		02
10	0531063929	BEARING SHAFT WITH 17Z GEAR		01




Item	Code	Description	See page	QT
01	0581016479	CURRENT STRETCH SHAFT 81		01
02	0503030402	PULLEY		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503010337	5/16" NUT		02
02	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010707	501030 CLAMPING RING (FOR AXLE)		01
06	0503012861	6006 2RS BALL BEARING		01
07	0502012030	HOUSING BEARING		01
08	0501213867	3/4 X 277 HEXAGONAL AXLE		01
09	0513010290	ELASTIC PIN 701137 5 X 26		02
10	0531063929	BEARING SHAFT WITH 17Z GEAR		01




Item	Code	Description	See page	QT
01	0531058675	DDD SEED 15 X 15 RIGHT	81	01
02	0501310465	FIXING BASE SET WITH PIVOTATION		01
03	0501310470	SUPPORT PULLEY SYSTEM		01
04	0531065921	PULLEY FIXER		01
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02
06	0503010733	1/4" X 1-3/4" BOLT		02
07	0531066017	QUICK LOCK FIXER		01
08	0503017813	3/8" X 2" BOLT		02
09	0503010026	3/8" NUT		04
10	0503010025	3/8 SPRING WASHER		04
11	0503015920	3/8" UNC X 1.3/4" BOLT		02




Item	Code	Description	See page	QT
01	0531058676	DDD SEED 15 X 15 LEFT	82	01
02	0501310465	FIXING BASE SET WITH PIVOTATION		01
03	0501310470	SUPPORT PULLEY SYSTEM		01
04	0531065921	PULLEY FIXER		01
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02
06	0503010733	1/4" X 1-3/4" BOLT		02
07	0531066017	QUICK LOCK FIXER		01
08	0503017813	3/8" X 2" BOLT		02
09	0503010026	3/8" NUT		04
10	0503010025	3/8 SPRING WASHER		04
11	0503015920	3/8" UNC X 1.3/4" BOLT		02




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	83	01
02	0511015098	FLAT WASHER		04
03	0511053173	RIGHT LOW HUB WITH 15 DISC	84	01
04	0511053172	LEFT LOW HUB WITH 15 DISC	85	01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503014679	2-134 O'RING		02
08	0571011152	DOUBLE DISC CAP		02
09	0503015081	502052 CLAMPING RING (FOR AXLE)		02
10	0511011927	DUST CLOAK		02
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0503010026	3/8" NUT		01
13	0503010025	3/8 SPRING WASHER		01
14	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	86	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	85	01
03	0511053173	RIGHT LOW HUB WITH 15 DISC	84	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0511015098	FLAT WASHER		04
07	0571011152	DOUBLE DISC CAP		02
08	0503015081	502052 CLAMPING RING (FOR AXLE)		02
09	0503014679	2-134 O'RING		02
10	0511011927	DUST CLOAK		02
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	89	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057272	LH SHORT ARM ROW FERTILIZER	90	01
06	0511059050	DOC 20" ASSY	92	01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	95	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057271	RH LONG ARM ROW FERTILIZER	96	01
06	0511059050	DOC 20" ASSY	92	01




Item	Code	Description	See page	QT
01	0502012794	SHORT SUPPORT FERTILIZER ROW		01
02	0503011854	5/8" X 1-1/4" BOLT		02
03	0503010002	1800 GREASE FITTING		01
04	0502012789	FIXER SUPPORT FERTILIZER ROW		01
05	0503017960	5/8" X 3-12" BOLT		04
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
08	0571019062	SLEEVE		01
09	0571019059	SUPPORT WASHER		01
10	0503010417	7/8" NUT		04
11	0503034320	COMPRESSION SPRING		01
12	0502012813	FLANGE WASHER SPRING		01




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	91	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	85	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	84	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0571018989	LH BLADE DISC ARM		01
02	0502012790	LOCK NUT		01
03	0511058838	20" WAVY COULTER BLADE HUB	93	01
04	0521065978	RIGHT ARM WITH WASHER LOCK		01
05	0571019035	SLEEVE SUPPORT ARM		01
06	0521010452	SLEEVE		01
07	0521066743	SPRING REGULATOR		01
08	0503010417	7/8" NUT		04
09	0571019033	FIXATION AXLE		01
10	0503034319	LOCK PIN		01
11	0502012813	FLANGE WASHER SPRING		01
12	0503034320	COMPRESSION SPRING		01
13	0571019032	SUPPORT WASHER		01
14	0571019034	FLANGE WASHER AXLE		02
15	0503010002	1800 GREASE FITTING		01
16	0503013185	3/4" X 5-1/2" BOLT		01
17	0503011255	3/4" LOCK NUT		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	94	01
02	0607026025	DPLO20X4,5		01




Item	Code	Description	See page	QT
01	0502012793	DISC HUB		01
02	0571018047	DISC BLADE HUB AXLE		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DUST CLOAK		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0502012795	SUPPORT LONG	01	
02	0503011854	5/8" X 1-1/4" BOLT	02	
03	0503010002	1800 GREASE FITTING	01	
04	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
05	0503017960	5/8" X 3-12" BOLT	04	
06	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
07	0521066744	FERTILIZER ROW ADJUSTMENT SPRING	01	
08	0571019062	SLEEVE	01	
09	0571019059	SUPPORT WASHER	01	
10	0503010417	7/8" NUT	04	
11	0503034320	COMPRESSION SPRING	01	
12	0502012813	FLANGE WASHER SPRING	01	




Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	97	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	84	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	85	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	99	01
02	0503012534	LOCK WASHER		05
03	0503012545	FLAT WASHER		05
04	0503014442	BOLT		05
05	0531059302	SEED SILO SUPPORT FRONT TRANSMISSION 101		01
		FAST FIXING SIGMA		
06	0503010025	3/8 SPRING WASHER		01
07	0503010209	3/8" UNC BUTTERFLY NUT		01
08	0501213674	DEFLECTOR FIXING AXLE		01
09	0501013518	FLAT WASHER		02
10	0503034131	DEFLECTOR		01




Item	Code	Description	See page	QT
01	0503015536	M6 X 1" SELF ADJUSTING NUT		04
02	0581014295	FIXING SLEEVE		01
03	0501213431	SEED NOZZLE FIXING FLANGE		01
04	0501213520	SEED BREAKER BODY		01
05	0501213432	BREAKER SUPPORT BASE		01
06	0501213728	60 X 53 X 30 PVC TUBE		01
07	0513010720	M6 X 1 X 35 C S G.5 ZB BOLT		04
08	0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK LID		01




Item	Code	Description	See page	QT
01	0503035751	SIGMA SINGLE SEED HOPPER		01
02	0503035750	SEED HOPPER LID		01
03	0503035298	BAKELITE HANDLE WITH THREAD		01
04	0503015536	M6 X 1" SELF ADJUSTING NUT		01
05	0503035297	CURVED NOZZLE SEED HOPPER		01




Item	Code	Description	See page	QT
01	0503010337	5/16" NUT		01
02	0513010140	SOCIDISCO SOY DISC 90 HOLES		01
03	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461		01
04	0503017373	BOLT		06
05	0502013040	DISC DRAWER		01
06	0501310478	SIGMA FRONT TRANSMISSION SEED SILO SUPPORT QUICK FIXING		01
07	0513010671	5/6 UNC X 2 CCSI 12.9 BOLT		01
08	0531054795	FRONT TRANSMISSION ASSEMBLY	102	01
09	0503010585	0,24" X 1.18" SPRING PIN		02
10	0513010672	M6 X 1 X 25 CCSI 12.9 BOLT		01
11	0503035789	SIGMA ALUMINUM ADHESIVE LABEL		01
12	0503013356	RIVET POP 3,2 X 10,0		04
13	0531055215	FIXING SET		02
13A	0501214203	THREADED BODY		02
13B	0503035749	LOCKING KNOB		02
13C	0503015536	M6 X 1" SELF ADJUSTING NUT		02
13D	0511017303	FLAT WASHER		02
13E	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
14	0503063778	SOY SEED DISTRIBUTOR CAP		01
15	0501310293	BODY SUPPORT SIGMA V2 DRIVEBOX		01
16	0503013849	1/4" UNC X 3/4" BOLT		01
17	0503010143	1/4" SPRING WASHER		01
18	0502013080	LOWER TRACK DISC WITH QUICK CLOSING LEVER SUPPORT SIG V3		01




Item	Code	Description	See page	QT
01	0503019356	BEARING 6005 2RS1		02
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012930	CONICAL GEAR		01
04	0503010585	0,24" X 1.18" SPRING PIN		01
05	0503017022	RING		01
06	0501213588	40Z CONICAL CROWN LOWER TRANSMISSION		01
07	0503017373	BOLT		04
08	0502050058	UPPER TRANSMISSION BODY		01
09	0501213625	12 SPACER SLEEVE		01
10	0501213624	142 PINION AXLE		01
11	0501213586	LOWER BODY FRONT TRANSMISSION		01
12	0513010773	BEARING 6003 2RS1 NAC		02




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	104	01
02	0501052538	DEPTH BAND WITH ARMS	109	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	110	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	112	01
07	0503033942	COMPACTOR WHEEL REGULATOR LID		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT DEPTH WHEEL ARM WITH HUB	105	01
07	0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	107	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	108	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL HUB	106	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	PROTECTION LID		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL HUB	106	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	111	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	111	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01



Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503013759	NUT		02
02	0501010694	FLAT WASHER		02
03	0502012979	CLAMP 3 RIGHT CSU		02
04	0503010421	5/16" X 1-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0513010117	SOCIDISCO CORN DISC 28 HOLES 9,0 AMC9R-002130		01
02	0513010118	SOCIDISCO CORN DISC 28 HOLES 9,5 VLD9.5R-002115		01
03	0513010119	SOCIDISCO CORN DISC 28 HOLES 10 SAL10R-002619		01
04	0513010120	SOCIDISCO CORN DISC 28 HOLES 10,5 RSP10.5R-002133		01
05	0513010121	SOCIDISCO CORN DISC 28 HOLES 11 LRA11R-002134		01
06	0513010122	SOCIDISCO CORN DISC 28 HOLES 11,5 MAG11.5R-002620		01
07	0513010123	SOCIDISCO CORN DISC 28 HOLES 12 VDA12R-002621		01
08	0513010124	SOCIDISCO CORN DISC 28 HOLES 12,5 AMP12.5R-002131		01
09	0513010125	SOCIDISCO CORN DISC 28 HOLES 13 VMV13R-002132		01
10	0513010126	SOCIDISCO CORN DISC 28 HOLES 13,5 RXR13.5R-002136		01
11	0513010187	SOCIDISCO CORN DISC 28 HOLES 14,8 X 10 VM4-002581		01
12	0513010188	SOCIDISCO CORN DISC 28 HOLES 11 X 8 BR8.1-002589		01
13	0513010189	SOCIDISCO CORN DISC 28 HOLES 12,5 X 8,5 AZ8.2-002587		01
14	0513010164	SOCIDISCO FLAT RING FOR CORN AMFOSLISO-002127		01
15	0513010159	SOCIDISCO RING FOR CORN 0,8MM LRFOSSR08-002120		01
16	0513010160	SOCIDISCO RING FOR CORN 1,4MM VMFOSR1.4-002245		01
17	0513010163	SOCIDISCO RING FOR CORN 2,0MM VDFOSR2-002116		01




Item	Code	Description	See page	QT
18	0503063779	SOCIDISCO 2808 4Z CORN SEED DISTRIBUTOR CAP		01



Item	Code	Description	See page	QT
01	0513010136	SOCIDISCO SOY DISC 62 HOLES 7,5 LRA62.75-002357	01	01
02	0513010137	SOCIDISCO SOY DISC 62 HOLES 8,0 RSP62.80-002358	01	01
03	0513010138	SOCIDISCO SOY DISC 62 HOLES 8,5 RXR62.85-002359	01	01
04	0513010139	SOCIDISCO SOY DISC 62 HOLES 9,0 AZM62.90-002360	01	01
05	0513010141	SOCIDISCO SOY DISC 90 HOLES 8,0 RSP90.80-002287	01	01
06	0513010142	SOCIDISCO SOY DISC 90 HOLES 8,5 RXR90.85-002317	01	01
07	0513010143	SOCIDISCO SOY DISC 90 HOLES 9,0 AZM90.90-002288	01	01
08	0513010158	SOCIDISCO FLAT RING FOR SOY AZMSOJALISO-002243	01	01
09	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461	01	01
10	0513010162	SOCIDISCO RING FOR SOY 1,5MM RSPSOJASR1,5-002244	01	01
11	0503063780	SOCIDISCO 2810 4Z SOY/BEAN SEED DISTRIBUTOR CAP	01	01



Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

