

ROW CROP PLANTERS

USAP 6000 SS SUPREMA FRAME 18190

Code: 0501093548
Series: S-0522
Revision: 00
Date Revision: MAIO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111570001	USAP 6000 SS 40E450 SUP S-0522

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

INDEX

0909096718	ASSY FRAME	1
0909096719	RIGHT HAND SIDE FRAME ASSY	2
0909096720	RIGHT FRAME ASSEMBLY	3
0909096721	ASSEMBLY CENTRAL FRAME	4
0909096722	LEFT FRAME ASSEMBLY	5
0909096723	RIGHT HAND SIDE FRAME ASSEMBLY	6
0531058518	TELESCOPIC HEADER 1008/2610 COMPLETE	7
0521058357	FRENCH HAND FRONT AXLE ASSY	8
0531055062	PANTOGRAPHIC HEADER 1630	9
0531055440	TRACTOR HITCH KIT WITH PIN LABELS 3	10
0531055444	HYDRAULIC CYLINDER 50.80 X 127 X 820 X 479	11
0531052688	SEMI ASSEMBLED REST	12
0531057100	RADIATOR ASSEMBLY WITH SUPPORT	13
0531055477	HYDRAULIC CYLINDER 38.10 X 63.50 X 395 X 159	14
0531058500	CYLINDER ACTIVATION CONTROL BLOCK	15
0531058503	HYDRAULIC CONTROL BLOCK CYLINDER 3A WITH SUPPORT	16
0531058193	HYDRAULIC TANK 280L DKO 72E450	17
0531058742	HEADING 3 POINT WITH PUMP SET	18
0531057052	DRAWBAR ASSY	19
0531057067	DRAWBAR ESTABILIZER ASSY	20
0531057856	HYDRAULIC PUMP WITH MULTIPLIER BOX	21
0531057857	PUMPS ASSEMBLY	22
0531058944	HYDRAULIC CYLINDER 63.50 X 150 X 844 X 1198	23
0531058946	AXLE WHEEL BEARING	24
0531059934	FULL HEAD ROUND	25
0521053037	TIRE WITH WHEEL 15 X 19,50 14 LONAS	26
0531059933	WHEELS WITHOUT TIRE WITHOUT TRANSMISSION	27
0521058145	AXLE LOCK ARM ROD	28
0531058556	FRENCH HAND 5870 ASSY LEFT	29
0531058558	FRENCH HAND 5870 ASSY RIGHT	30
0531058557	FRENCH HAND 5870 LEFT COMPLETE	31
0531058559	RIGHT FRENCH HAND 5825 ASSY	32
0511054713	ASSY TRANSMISSION SHAFT	33
0521058088	ROTULA WITH EXTENSOR AXIS 2	34
0531058571	BIGGER TOOL BOX 234L COMPLETE	35
0531056419	REAR LADDER	36
0531056157	LEFT REAR HANDRAILING STAIRCASE	37
0531056189	REAR RIGHT HANDRAILING STAIRCASE	38
0511059383	HANDRAIL INTERNAL FIXER	39
0531055802	REAR EASEL COMPLETE CENTRAL CHASSIS	40
0531055803	COMPLETE SIDE CHASSIS SUPPORT	41
0531056776	SIDE WHEELS WITHOUT TRANSMISSION TIRE 710/40-22.5 COMPLETE	42
0531056756	WHEELS WITHOUT TIRE WITHOUT TRANSMISSION 891	43
0531055434	HYDRAULIC CYLINDER 53.98X114.25X301 MM	44
0531056787	TIRE 710/40-22.5 16L LEFT COMPLETE	45
0531054290	CENTRAL SEED BOX	46
0531054289	CENTRAL SEED BOX	47
0531054275	LOWER BOX SEED SYSTEM	48
0521052175	SUPPORT PLATFORM ASSY	49
0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	50
0531058573	FRONT SIDE HANDRAIL 598	51
0531058574	SIDE HANDRAIL 2401 X 1119 X 880	52
0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	53
0531056342	HYDRAULIC TURBINE	54

INDEX

0531056343	HYDRAULIC ENGINE	55
0521044613	FAN 480X50 (HIDRAULIC)	56
0531056344	COMMAND BLOCK	57
0531055613	CONDUCTOR SUPPORT	58
0531055618	SIDE AIR TUBE WITH 05 OUTPUTS 440X2056	59
0521052549	CLAMP	60
0531050115	PLATFORM/LADDER SIDE SUPPORT	61
0531050114	COMPLETE SIDE BOX SUPPORT	62
0531050113	BEARING HANGER ASSEMBLY	63
0531057642	COMPLETE RIGHT LADDER	64
0531055455	POSITIVE TURBINE SUPPORT	65
0531050772	RIGHT CLAMP 4	66
0521052168	SEED HOSE GUIDE	67
0531058468	RIGHT FRAME OIL DUCT SET	68
0521050332	VACUOMETER WITH ASSY SUPPORT	69
0909096724	ASSEMBLY SEED ROW	70
0531050988	FRONT INTERNAL SHORT SEED LINE VDRIVE CSC PPH	71
0531050991	FRONT INTERNAL LONG SEED LINE VDRIVE CSC PPH	72
0531050989	FRONT SHORT SEED LINE VDRIVE CSC PPH	73
0531050990	FRONT LONG SEED LINE VDRIVE CSC PPH	74
0521058734	INTERNAL FRONT SEED LINE SLG VDRIVE	75
0511052300	CONDUCTOR SUPPORT ASSY SEED	76
0531055409	LEFT DISC BLADE DPL20 ASSY	77
0531055260	SHORT LOWER SUPPORT WITH 20" CUTTING DISC	78
0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	79
0521053697	DISC BLADE HUB	80
0531055099	REAR WITH LEFT DDD SPICRR WITHOUT FLAP PPH VDRIVE	81
0531055100	REAR WITH SPICER RIGHT DDD WITHOUT FLAP PPH V DRIVE	82
0531055009	REAR ROW WITH LEFT DOUBLE DISC	83
0521056632	DEPTH CONTROL	84
0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	85
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	86
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	87
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	88
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	89
0521055093	BODY COMPACTOR	90
0521055017	RIGHT COMPACTOR WHEEL	91
0521054990	LEFT COMPACTOR WHEEL	92
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	93
0531050538	MOUNTED LEFT ARM	94
0531050539	MOUNTED LEFT ARM	95
0521055056	WHEEL RAYED ASSY BAND	96
0521055073	ASSEMBLY DEPTH WHEEL HUB	97
0531055008	REAR ROW WITH RIGHT DOUBLE DISC	98
0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	99
0531055478	RIGHT HANDRAIL 3334	100
0531058575	FRONT SIDE HANDRAIL 1953 X 1651	101
0531058603	PP TURBINE WITH GREAT SUPPORT COMPLETE	102
0521050154	PRECISION PLANTING TURBINE WITH HOLE	103
0531058577	SIDE AIR CONDUCTOR 06 BUTTONS 2310	104
0531058578	SIDE AIR CONDUCTOR 03 BUTTONS 912 LEFT	105
0521053850	ASSY FRONT AIR CONDUCTOR SUPPORT	106
0521054353	OF THE AIR CENTRAL TUBE	107
0531057631	SUPPORT MOBILE HANDRAILING PLATFORM	108




MARCHESAN

INDEX


0531057632	COMPLETE U FASTENER	109
0531058465	RIGHT FRAME OIL DUCT SET	110
0531058294	LEFT ARM COMPLETE JOINT	111
0531058293	RIGHT ARM FULL JOINT	112
0531056789	TIRE 710/40-22.5 16L ASSY RIGHT	113
0521052156	ASSY CENTRAL SUPPORT	114
0521058860	LARGER REAR PLATFORM BASE ASSY LANTERN LED CSC	115
0521052154	ASSY REAR LADDER PLATFORM	116
0521054881	LARGER SIDE HANDRAIL FRAME CENTRAL	117
0521057760	LED FLASHLIGHT WITH SUPPORT	118
0531055469	HYDRAULIC CYLINDER 63.50 X 150 X 1262	119
0531058631	PRECISION PLANTING TURBINE WITH SUPPORT	120
0521051096	REAR CENTRAL AIR CONDUCTOR 1120 CSCP	121
0521053530	REAR CENTRAL AIR CONDUCTOR 1400 CSC	122
0521058863	CENTRAL AIR CONDUCTOR	123
0531058572	WHEEL SUPPORT WITHOUT TIRE	124
0521058864	WHEEL SUPPORT WITHOUT TIRE AND WITH ROCKER ARM	125
0531055445	HYDRAULIC CYLINDER 63.50 X 150 X 721 X 332MM	126
0531058467	RIGHT CENTRAL DUCT SET	127
0531058466	LEFT CENTRAL DUCTS SET	128
0531056346	4 WAY ROTATING DIVIDER	129
0531056347	LIFT DRIVE BLOCK	130
0531058630	DKO DOUBLE ROTATING DIVIDER	131
0531058425	DOUBLE ROTARY SPLITTER WITH FLANGES	132
0531058642	ADHESIVE LABELS SET	133
0531058484	VDRIVE SET 40 LINES 45/50 MS	134
0531057793	LIGHTING/CONTROL SET 5F	135
0541050247	HYDRAULIC HOSE SET 40E450	136
0541050242	LIFT HOSE SET 40E450	137
0541050243	PANTOGRAPHIC HOSE SET 40E450	138
0541050244	HOSE SET BLOCK	139
0541050245	POSITIVE/NEGATIVE TURBINE HOSE SET 40E450	140
0541050246	HOSE SET OPENS/CLOSES 40E450	141
0531055453	LEFT HANDRAIL 3334	142
0531058633	SIDE AIR CONDUCTOR 06 BUTTONS 2610	143
0531058576	SIDE AIR CONDUCTOR 03 BUTTONS 712 LEFT	144
0531058130	PP ALTERNATOR WITH 2 PDM	145
0531058469	LEFT CHASSIS DUCT SET 40E450	146
0531058497	UPPER CHASSIS LEFT DUCT ASSEMBLY	147
0531057641	FULL LEFT LADDER	148
0531051629	CROTETS WITH FIXING SUPPORTS	149
0521058344	WATER RESERVOIR WITH SOAP	150
0531058470	LEFT SIDE CHASSIS DUCT ASSEMBLY 40E450	151
0531050959	COMPLETE RIGHT SIDE TURBINE SUPPORT	152
0531058436	TURBINE HYDRAULIC CONTROL BLOCK ASSEMBLY	153

ASSY FRAME

0909096718



Item	Code	Description	See page	QT
01	0909096719	RIGHT HAND SIDE FRAME ASSY	2	01
02	0909096720	RIGHT FRAME ASSEMBLY	3	01
03	0909096721	ASSEMBLY CENTRAL FRAME	4	01
04	0909096722	LEFT FRAME ASSEMBLY	5	01
05	0909096723	RIGHT HAND SIDE FRAME ASSEMBLY	6	01
06	0531058518	TELESCOPIC HEADER 1008/2610 COMPLETE	7	01
07	0531058558	FRENCH HAND 5870 ASSY RIGHT	30	01
08	0531058556	FRENCH HAND 5870 ASSY LEFT	29	01
09	0531058571	BIGGER TOOL BOX 234L COMPLETE	35	01
10	0521058345	SAFETY CHAIN WITH SHACKLE		01
10A	0503014120	CHAIN		01
10B	0503014321	CABLE STEEL SHACKLE		02
11	0531056419	REAR LADDER	36	01
12	0531064336	FRONT SUPPORT CENTER CHASSIS		01
13	0531055802	REAR EASEL COMPLETE CENTRAL CHASSIS	40	02
14	0531055803	COMPLETE SIDE CHASSIS SUPPORT	41	08




Item	Code	Description	See page	QT
01	0531065520	RIGHT HAND SIDE FRAME		01
02	0531056776	SIDE WHEELS WITHOUT TRANSMISSION TIRE 710/40-22.5 COMPLETE	42	01
03	0531054290	CENTRAL SEED BOX	46	01
04	0521052175	SUPPORT PLATFORM ASSY	49	02
05	0581017801	PLATFORM ASSY		01
06	0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	50	01
07	0531058573	FRONT SIDE HANDRAIL 598	51	01
08	0531058574	SIDE HANDRAIL 2401 X 1119 X 880	52	01
09	0591015150	L HANDRAIL FIXING		02
10	0531056342	HYDRAULIC TURBINE	54	01
11	0503010232	5/8" X 1.3/4" BOLT		02
12	0503010027	5/8 SPRING WASHER		02
13	0503010013	5/8 NUT		02
14	0531055613	CONDUCTOR SUPPORT	58	02
15	0531055618	SIDE AIR TUBE WITH 05 OUTPUTS 440X2056	59	01
16	0521052549	CLAMP	60	05
17	0501217751	CONICAL BUSHING GRIP		02
18	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
19	0503010019	1/2" SPRING WASHER		01
20	0501217750	120 X 64 X 9,50 FIXING WASHER		01
21	0503010002	1800 GREASE FITTING		02
22	0501217752	LOCK NUT		01
23	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01
24	0581013528	FLANGED NUT		01
25	0501218015	85,10/85,00 X 549 AXLE BODY		01
26	0501215207	LOCK WASHER SIDE AXLE		01
27	0501216458	GUTTER 5S 55 X 50 X 2000		01
28	0503010025	3/8 SPRING WASHER		03
29	0503010026	3/8" NUT		03
30	0501011643	3/8 X 1"BOLT		03
31	0531050115	PLATFORM/LADDER SIDE SUPPORT	61	01

Item	Code	Description	See page	QT
32	0531050114	COMPLETE SIDE BOX SUPPORT	62	01
33	0531050113	BEARING HANGER ASSEMBLY	63	02
34	0531057642	COMPLETE RIGHT LADDER	64	01
35	0531055455	POSITIVE TURBINE SUPPORT	65	01
36	0531050772	RIGHT CLAMP 4	66	04
37	0521052168	SEED HOSE GUIDE	67	01
38	0503034345	DISPENSER COVER		09
39	0503010184	CLAMP		09
40	0513010405	CLAMP		08
41	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		02
42	0531058468	RIGHT FRAME OIL DUCT SET	68	01
43	1164920015	BLACK SUCTION HOSE		19
44	1164920014	BLACK LIGHT SUCTION HOSE		06
45	1163920004	BLACK LIGHT SUCTION HOSE		05
46	0521050332	VACUOMETER WITH ASSY SUPPORT	69	01
47	0503015062	TUBE		1.5 mts
48	0531055515	COMPLETE SIDE CYLINDER LOCK		01
48A	0501214858	SIDE CYLINDER LOCK		01
48B	0531061649	AXLE LOCKS TRANSPORT		01
48C	0503030168	HITCH PIN CLIP		01
49	0909096724	ASSEMBLY SEED ROW	70	05

RIGHT FRAME ASSEMBLY

0909096720



Item	Code	Description	See page	QT
01	0531065517	RIGHT CHASSIS 3755 X 3817		01
02	0531056776	SIDE WHEELS WITHOUT TRANSMISSION TIRE 710/40-22.5 COMPLETE	42	01
03	0531054290	CENTRAL SEED BOX	46	01
04	0521052175	SUPPORT PLATFORM ASSY	49	02
05	0591014648	PLATFORM 3420		01
06	0531055478	RIGHT HANDRAIL 3334	100	01
07	0591015150	L HANDRAIL FIXING		01
08	0531058575	FRONT SIDE HANDRAIL 1953 X 1651	101	01
09	0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	50	02
10	0591014479	GLOVE 102 X 77 X 150		04
11	0503010002	1800 GREASE FITTING		01
12	0531058603	PP TURBINE WITH GREAT SUPPORT COMPLETE	102	01
13	0531055613	CONDUCTOR SUPPORT	58	03
14	0531058577	SIDE AIR CONDUCTOR 06 BUTTONS 2310	104	01
15	0531058578	SIDE AIR CONDUCTOR 03 BUTTONS 912 LEFT	105	01
16	0521053850	ASSY FRONT AIR CONDUCTOR SUPPORT	106	02
17	0521054353	OF THE AIR CENTRAL TUBE	107	01
18	0521052549	CLAMP	60	09
19	0501216458	GUTTER 5S 55 X 50 X 2000		01
20	0501218233	GUTTER 4S 55 X 50 X 1550		01
21	0501216462	GUTTER IN 55 X 50 X 248		01
22	0503010025	3/8 SPRING WASHER		04
23	0503010026	3/8" NUT		04
24	0501011643	3/8 X 1" BOLT		04
25	0503013758	1/4" X 1-1/2" BOLT		02
26	0503010144	1/4" NUT		02
27	0503010143	1/4" SPRING WASHER		02
28	0531050772	RIGHT CLAMP 4	66	05
29	0531050114	COMPLETE SIDE BOX SUPPORT	62	01
30	0531050113	BEARING HANGER ASSEMBLY	63	02
31	0531057631	SUPPORT MOBILE HANDRAILING PLATFORM	108	01


RIGHT FRAME ASSEMBLY

0909096720

Item	Code	Description	See page	QT
32	0531057632	COMPLETE U FASTENER	109	02
33	0503013357	3/8 SELF-ADJUSTING NUT		02
34	0503011179	3/8" X 2-1/4" BOLT		02
35	0521052168	SEED HOSE GUIDE	67	03
36	0503034345	DISPENSER COVER		09
37	0503010184	CLAMP		09
38	0531058465	RIGHT FRAME OIL DUCT SET	110	01
39	0531058436	TURBINE HYDRAULIC CONTROL BLOCK ASSEMBLY	153	01
40	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		02
41	0513010405	CLAMP		08
42	0521053176	COVER KAP		01
42A	0581017528	15 OUTPUT TUBE COVER		01
42B	0503011372	102 TO 121 CLAMP		01
43	1164920015	BLACK SUCTION HOSE		20
44	1164920014	BLACK LIGHT SUCTION HOSE		11
45	1163920004	BLACK LIGHT SUCTION HOSE		03
46	0521050332	VACUOMETER WITH ASSY SUPPORT	69	01
47	0503015062	TUBE		1.5 mts
48	0531055515	COMPLETE SIDE CYLINDER LOCK		01
48A	0501214858	SIDE CYLINDER LOCK		01
48B	0531061649	AXLE LOCKS TRANSPORT		01
48C	0503030168	HITCH PIN CLIP		01
49	0909096724	ASSEMBLY SEED ROW	70	09

ASSEMBLY CENTRAL FRAME

0909096721



Item	Code	Description	See page	QT
01	0531065557	CENTRAL CHASSIS 5290		01
02	0531058294	LEFT ARM COMPLETE JOINT	111	01
03	0531058293	RIGHT ARM FULL JOINT	112	01
04	0531056787	TIRE 710/40-22.5 16L LEFT COMPLETE	45	02
05	0531056789	TIRE 710/40-22.5 16L ASSY RIGHT	113	02
06	0521052156	ASSY CENTRAL SUPPORT	114	01
07	0521058860	LARGER REAR PLATFORM BASE ASSY LANTERN LED CSC	115	01
08	0531055469	HYDRAULIC CYLINDER 63.50 X 150 X 1262	119	02
09	0531060957	LARGER CYLINDER AXIS		02
10	0503011052	1.1/4" X 0.77" CASTLE NUT		02
11	0503010038	3/16 X 2 COTTERPIN		02
12	0501010276	BOLT		20
13	0503012182	1" NUT		20
14	0503010012	1" SPRING WASHER		20
15	0571012964	AXLE BODY WHEELS PIVOT		02
16	0501010630	1.1/2" CASTLE NUT		02
17	0503011345	1/4" X 3-1/2" COTTERPIN		02
18	0591014474	AIR CONDUCTOR PROTECTION		02
19	0531054290	CENTRAL SEED BOX	46	01
20	0531058631	PRECISION PLANTING TURBINE WITH SUPPORT	120	01
21	0521051096	REAR CENTRAL AIR CONDUCTOR 1120 CSCP	121	02
22	0521053530	REAR CENTRAL AIR CONDUCTOR 1400 CSC	122	01
23	0521058863	CENTRAL AIR CONDUCTOR	123	01
24	0521052168	SEED HOSE GUIDE	67	08
25	0531061637	CENTRAL HOSE GUIDE 1.1/2		04
26	0503010849	3/8" X 1-1/2" BOLT		06
27	0503010025	3/8 SPRING WASHER		12
28	0503010026	3/8" NUT		12
29	0521053176	COVER KAP		01
29A	0581017528	15 OUTPUT TUBE COVER		01
29B	0503011372	102 TO 121 CLAMP		01


ASSEMBLY CENTRAL FRAME

0909096721

Item	Code	Description	See page	QT
30	0521052549	CLAMP	60	12
31	0531050772	RIGHT CLAMP 4	66	13
32	0503034345	DISPENSER COVER		09
33	0503010184	CLAMP		09
34	0513010405	CLAMP		08
35	0531055613	CONDUCTOR SUPPORT	58	03
36	0531058572	WHEEL SUPPORT WITHOUT TIRE	124	01
37	0501216459	GUTTER 6S 55 X 50 X 2450		02
38	0501216462	GUTTER IN 55 X 50 X 248		01
39	0501011643	3/8 X 1" BOLT		06
40	0531058467	RIGHT CENTRAL DUCT SET	127	01
41	0531058466	LEFT CENTRAL DUCTS SET	128	01
42	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		04
43	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		04
44	0513010916	TERMINAL KNEE 90 MF X FG TB35 1		01
45	0513011224	TEE TERMINAL MF X MF X FG TB35		01
46	0513011230	ADAPTER TERMINAL MF TB22 X FG TB35		01
47	0501219284	SUPPORT OPEN/CLOSED BLOCK		01
48	0501013518	FLAT WASHER		04
49	0503014734	BOLT		04
50	0503010060	1/2 UNC G.5 ZN HEX NUT		04
51	0503010019	1/2" SPRING WASHER		04
52	0521014188	FLAT WASHER		04
53	0531065607	SUPPORT COMMAND BLOCKS		01
54	0531056346	4 WAY ROTATING DIVIDER	129	01
55	0531056347	LIFT DRIVE BLOCK	130	01
56	0503011088	3/8" X 1-1/4" BOLT		04
57	0503015114	BOLT		04
58	0503014371	M8 SPRING WASHER		04
59	0503015075	M10 SPRING WASHER		04
60	0503010172	M10 X 1,5 X 25 BOLT		04
61	0531058630	DKO DOUBLE ROTATING DIVIDER	131	01
62	0531058425	DOUBLE ROTARY SPLITTER WITH FLANGES	132	01
63	0513011035	ADAPTER TERMINAL MF R1.1/16 UNF		04
64	0513010831	ADAPTER TERMINAL MF R.1.1/16		02
65	0513010745	HYDRAULIC CONTROL BLOCK LIFT 2AT		01
66	1164920015	BLACK SUCTION HOSE		22
67	1164920014	BLACK LIGHT SUCTION HOSE		14
68	1163920004	BLACK LIGHT SUCTION HOSE		06
69	0531058642	ADHESIVE LABELS SET	133	01
70	0531058484	VDRIVE SET 40 LINES 45/50 MS	134	01
71	0531057793	LIGHTING/CONTROL SET 5F	135	01
72	0541050247	HYDRAULIC HOSE SET 40E450	136	01
73	0531055514	ASSY CENTRAL CYLINDER LOCK		02
73A	0501214857	CENTRAL CYLINDER LOCK		01
73B	0531061649	AXLE LOCKS TRANSPORT		01
73C	0503030168	HITCH PIN CLIP		01
74	0531065366	CHASSIS LOCK FOR TRANSPORTATION 44.45X120		02
75	0561016793	FIXED WRENCH		01
76	0501047885	30 ROD STOP		08
77	0511042161	2.1/2" ROD STOP ASSY		02
78	0511042163	2.1/2" ROD STOP ASSY		02
79	0521050332	VACUOMETER WITH ASSY SUPPORT	69	01
80	0503015062	TUBE		1.5mt
81	0503018829	NYLON CLAMP		200
82	0511033763	PLASTIC COVER WITH INSTRUCTIONS MANUAL		01
83	0909096724	ASSEMBLY SEED ROW	70	12

LEFT FRAME ASSEMBLY

0909096722




Item	Code	Description	See page	QT
01	0531065518	LEFT CHASSIS 3755 X 3817		01
02	0531056776	SIDE WHEELS WITHOUT TRANSMISSION TIRE 710/40-22.5 COMPLETE	42	01
03	0531054290	CENTRAL SEED BOX	46	01
04	0503010002	1800 GREASE FITTING		01
05	0521052175	SUPPORT PLATFORM ASSY	49	02
06	0591014479	GLOVE 102 X 77 X 150		04
07	0591014648	PLATFORM 3420		01
08	0531055453	LEFT HANDRAIL 3334	142	01
09	0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	50	02
10	0591015150	L HANDRAIL FIXING		01
11	0531058575	FRONT SIDE HANDRAIL 1953 X 1651	101	01
12	0531058603	PP TURBINE WITH GREAT SUPPORT COMPLETE	102	01
13	0531055613	CONDUCTOR SUPPORT	58	03
14	0531058633	SIDE AIR CONDUCTOR 06 BUTTONS 2610	143	01
15	0531058576	SIDE AIR CONDUCTOR 03 BUTTONS 712 LEFT	144	01
16	0521053850	ASSY FRONT AIR CONDUCTOR SUPPORT	106	02
17	0521054353	OF THE AIR CENTRAL TUBE	107	01
18	0521052549	CLAMP	60	09
19	0531050114	COMPLETE SIDE BOX SUPPORT	62	01
20	0531050113	BEARING HANGER ASSEMBLY	63	02
21	0531050115	PLATFORM/LADDER SIDE SUPPORT	61	01
22	0531050772	RIGHT CLAMP 4	66	06
23	0501218233	GUTTER 4S 55 X 50 X 1550		01
24	0501216458	GUTTER 5S 55 X 50 X 2000		01
25	0501216462	GUTTER IN 55 X 50 X 248		01
26	0503010025	3/8 SPRING WASHER		05
27	0503010026	3/8" NUT		05
28	0501011643	3/8 X 1" BOLT		05
29	0531058130	PP ALTERNATOR WITH 2 PDM	145	01
30	0503013758	1/4" X 1-1/2" BOLT		02
31	0503010144	1/4" NUT		02

LEFT FRAME ASSEMBLY


0909096722

Item	Code	Description	See page	QT
32	0503010143	1/4" SPRING WASHER		02
33	0531058469	LEFT CHASSIS DUCT SET 40E450	146	01
34	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		02
35	0531058497	UPPER CHASSIS LEFT DUCT ASSEMBLY	147	01
36	1164920015	BLACK SUCTION HOSE		20
37	1164920014	BLACK LIGHT SUCTION HOSE		11
38	1163920004	BLACK LIGHT SUCTION HOSE		03
39	0513010405	CLAMP		08
40	0503034345	DISPENSER COVER		09
41	0503010184	CLAMP		09
42	0521050332	VACUOMETER WITH ASSY SUPPORT	69	01
43	0503015062	TUBE		1.5mt
44	0531055515	COMPLETE SIDE CYLINDER LOCK		01
44A	0501214858	SIDE CYLINDER LOCK		01
44B	0531061649	AXLE LOCKS TRANSPORT		01
44C	0503030168	HITCH PIN CLIP		01
45	0909096724	ASSEMBLY SEED ROW	70	09




Item	Code	Description	See page	QT
01	0531065519	LEFT SIDE CHASSIS 2224		01
02	0531056776	SIDE WHEELS WITHOUT TRANSMISSION TIRE 710/40-22.5 COMPLETE	42	01
03	0531054290	CENTRAL SEED BOX	46	01
04	0521052175	SUPPORT PLATFORM ASSY	49	02
05	0581017801	PLATFORM ASSY		01
06	0511059821	FIXER ASSY FRONT SIDE HANDLE CSCP	50	01
07	0531058573	FRONT SIDE HANDRAIL 598	51	01
08	0531058574	SIDE HANDRAIL 2401 X 1119 X 880	52	01
09	0591015150	L HANDRAIL FIXING		02
10	0531055613	CONDUCTOR SUPPORT	58	02
11	0531055618	SIDE AIR TUBE WITH 05 OUTPUTS 440X2056	59	01
12	0501217751	CONICAL BUSHING GRIP		02
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
14	0503010019	1/2" SPRING WASHER		01
15	0501217750	120 X 64 X 9,50 FIXING WASHER		01
16	0503010002	1800 GREASE FITTING		02
17	0501217752	LOCK NUT		01
18	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01
19	0581013528	FLANGED NUT		01
20	0501218015	85,10/85,00 X 549 AXLE BODY		01
21	0501215207	LOCK WASHER SIDE AXLE		01
22	0521052549	CLAMP	60	05
23	0501216458	GUTTER 5S 55 X 50 X 2000		01
24	0503010025	3/8 SPRING WASHER		02
25	0503010026	3/8" NUT		02
26	0501011643	3/8 X 1" BOLT		02
27	0531050114	COMPLETE SIDE BOX SUPPORT	62	01
28	0531050113	BEARING HANGER ASSEMBLY	63	02
29	0531057641	FULL LEFT LADDER	148	01
30	0531050772	RIGHT CLAMP 4	66	04
31	0531051629	CROTETS WITH FIXING SUPPORTS	149	01

Item	Code	Description	See page	QT
32	0531058470	LEFT SIDE CHASSIS DUCT ASSEMBLY 40E450	151	01
33	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		02
34	0503034345	DISPENSER COVER		09
35	0503010184	CLAMP		09
36	0513010405	CLAMP		08
37	0521052168	SEED HOSE GUIDE	67	01
38	1164920015	BLACK SUCTION HOSE		19
39	1164920014	BLACK LIGHT SUCTION HOSE		06
40	1163920004	BLACK LIGHT SUCTION HOSE		00
41	0531050115	PLATFORM/LADDER SIDE SUPPORT	61	01
42	0531050959	COMPLETE RIGHT SIDE TURBINE SUPPORT	152	01
43	0531056342	HYDRAULIC TURBINE	54	01
44	0521050332	VACUOMETER WITH ASSY SUPPORT	69	01
45	0503015062	TUBE		1.5 mts
46	0531055515	COMPLETE SIDE CYLINDER LOCK		01
46A	0501214858	SIDE CYLINDER LOCK		01
46B	0531061649	AXLE LOCKS TRANSPORT		01
46C	0503030168	HITCH PIN CLIP		01
47	0909096724	ASSEMBLY SEED ROW	70	05




Item	Code	Description	See page	QT
01	0531065521	INTERNAL STRAW HEADERS WITH FIXING EAR		01
02	0531065604	TELESCOPIC HEADING 1008/2610		01
03	0501218291	WEAR GUIDE 130 X 22.70		04
04	0501218258	WASHER CALCO 132 X 12.50 X 6.35		04
05	0501218257	TELESCOPIC HEADER NYLON FRAME		04
06	0503010834	1/2 X 1 BOLT		32
07	0503010060	1/2 UNC G.5 ZN HEX NUT		08
08	0503010002	1800 GREASE FITTING		10
09	0503010019	1/2" SPRING WASHER		24
10	0591018407	MINOR CYLINDER REAR AXLE		01
11	0503010010	1/4" X 2.1/2" COTTERPIN		06
12	0503010027	5/8 SPRING WASHER		05
13	0521058357	FRENCH HAND FRONT AXLE ASSY	8	02
14	0531055062	PANTOGRAPHIC HEADER 1630	9	01
15	0531052688	SEMI ASSEMBLED REST	12	01
16	0503012231	1/4" X 3" COTTERPIN		02
17	0501010630	1.1/2" CASTLE NUT		02
18	0531064198	AXIS 365 TELESCOPIC HEADER		02
19	0531064192	REST SUPPORT		01
20	0531057100	RADIATOR ASSEMBLY WITH SUPPORT	13	01
21	0513010344	SHOCK ABSORBER/VIBRATION CUSHION		12
22	0501218892	TANK SUPPORT 280 LITERS		03
23	0521011132	FLAT WASHER		04
24	0503010523	1/4" X 2" SPLIT PIN		01
25	0531055477	HYDRAULIC CYLINDER 38.10 X 63.50 X 395 X 159	14	01
26	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
27	0511054270	TENSIONER SPRING		01
27A	0511069520	TELESC LOCK SPRING TENSIONER		01
27B	0503010013	5/8 NUT		02
28	0571013059	PIVOT SHAFT LOCK		01
29	0531065218	LATCH DRAG 338 X 278		01


Item	Code	Description	See page	QT
30	0531061070	AXIS 365 TELESCOPIC HEADER		01
31	0503011052	1.1/4" X 0.77" CASTLE NUT		01
32	0501012694	FLAT WASHER		01
33	0503010233	5/8" X 2-1/2" BOLT		04
34	0501012140	FLAT WASHER		08
35	0503010013	5/8 NUT		04
36	0531061880	TRANSPORT LOCK		01
37	0513010757	STANDARD CLAMP SINGLE 35 MM - BLACK		06
38	0503036103	HYDRAULIC TUBE PT35 X PT35 X 2400		01
39	0503036104	HYDRAULIC TUBE PT22 X PT22 X 2400		02
40	0513010754	SINGLE STANDARD CLAMP 22 MM - BLACK		12
41	0513010753	SINGLE STANDARD CLAMP		12
42	0503036105	HYDRAULIC TUBE PT15 X PT15 X 2400		02
43	0503036106	HYDRAULIC TUBE PT12L X PT12L X 2400		01
44	0513010752	SINGLE STANDARD CLAMP 12 MM - BLACK		06
45	0501219254	CLAMP FIXER 2 15X1		03
46	0501215817	CLAMP FIXING COVER		03
47	0501218901	CLAMP FASTENER 2		03
48	0503010144	1/4" NUT		24
49	0503010305	FLAT WASHER		24
50	0503010143	1/4" SPRING WASHER		24
51	0501218890	CLAMP FIXER 1 TB		03
52	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		12
53	0503015323	1/4 UNC X 3.1/2 BOLT		12
54	0531058500	CYLINDER ACTIVATION CONTROL BLOCK	15	01
55	0531058503	HYDRAULIC CONTROL BLOCK CYLINDER 3A WITH SUPPORT	16	01
56	0531058193	HYDRAULIC TANK 280L DKO 72E450	17	01
57	0531065470	TELESCOPIC HOSE GUIDE		01
58	0531058742	HEADING 3 POINT WITH PUMP SET	18	01
59	0531058944	HYDRAULIC CYLINDER 63.50 X 150 X 844 X 1198	23	01
60	0531065737	556 ROCKER AXLE		01
61	0531065732	FRONT WHEEL TRANSPORTATION SUPPORT		01
62	0501111198	COMPLETE ROCKER SUPPORT		01
63	0531058946	AXLE WHEEL BEARING	24	04
64	0503010232	5/8" X 1.3/4" BOLT		01
65	0591014405	AXIS ROD CYLINDER LOWER		01
66	0531065733	AXIS LOCKING MOVEMENT		01
67	0503030119	LOCK PIN		01
68	0531059934	FULL HEAD ROUND	25	02




Item	Code	Description	See page	QT
01	0531061069	FRONT HAND FRENCH AXLE		01
02	0501017779	32 X 60 X 4.75 FLAT WASHER		01
03	0503011052	1.1/4" X 0.77" CASTLE NUT		01
04	0503010038	3/16 X 2 COTTERPIN		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		03
02	0531064171	EAR PANTOGRAPHIC HEAD		01
03	0531064170	AXIS 332 TELESCOPIC HEADER		02
04	0531064169	HYDRAULIC HOSE SUPPORT FIXER		01
05	0501010630	1.1/2" CASTLE NUT		02
06	0503012231	1/4" X 3" COTTERPIN		02
07	0531055440	TRACTOR HITCH KIT WITH PIN LABELS 3	10	01
08	0503011052	1.1/4" X 0.77" CASTLE NUT		03
09	0531064168	HEADLINE FRONT AXLE		02
10	0503010067	3/16" X 2.1/2" COTTER PIN		03
11	0531064167	PANTOGRAPHIC HEADING PLATE		01
12	0531055444	HYDRAULIC CYLINDER 50.80 X 127 X 820 X 479	11	01
13	0531064337	LOWER ARM PANTOGRAPHIC HEADER		01
14	0531064338	UPPER ARM PANTOGRAPHIC HEADING		01
15	0531064355	AXIS 239 PANTOGRAPHIC HEADING		01




Item	Code	Description	See page	QT
01	0531064165	TRACTOR COUPLING WITH LABELS 60X70X215		01
02	0591013086	SLEEVE		01
03	0503010002	1800 GREASE FITTING		01
04	0503018829	NYLON CLAMP		01




Item	Code	Description	See page	QT
01	0531064182	CYLINDER SHIRT HYDRAULIC HEADER		01
02	0531061035	STEM CYLINDER PANTOGRAPHIC HEADER		01
03	0503010817	1.1/4" SELF LOCKING NUT		01
04	0503010345	2-218 N 3006-9B O'RING		01
05	0502010382	5" END CAP		01
06	0581010353	RING SUPPORT		01
07	0503018026	1870-2000-375 B GASKET		01
08	0503011453	O'RING		02
09	0503018152	O'RING		02
10	0503018024	RING BS		01
11	0503018025	RING GUIDE		01
12	0581010354	PISTON		01
13	0503018150	RING GUIDE		01
14	0503018151	RING BS		02
15	0503010039	D-2000 SCRAPER RING		01




Item	Code	Description	See page	QT
01	0503010571	1/4" X 1.1/2 COTTERPIN		01
02	0521010784	COUPLING SHAFT		01
03	0531060758	AXLE JUNCTION 25.4 X 150 WITH HANDLE		01
04	0503030085	LOCK PIN		02
05	0531060667	REST		01
06	0521012533	COUPLING SHAFT		01
07	0531062876	INTERNAL TUBE WITH SHOE REST		01




Item	Code	Description	See page	QT
01	0531056321	INTERCAMBIADOR DE CALOR COMPLETO		01
01A	0503063086	HEAT EXCHANGER		01
01B	0513010820	ADAPTER TERMINAL MF 1 BSP X TB35		02
02	0531065054	CHANGER HOLDER		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		06
04	0503010019	1/2" SPRING WASHER		06
05	0521014188	FLAT WASHER		06
06	0503014007	1/2" X 1-1/4" BOLT		02
07	0503014378	1/2" X 1-1/2" BOLT		04
08	0591012708	CANVAS RADIATOR PROTECTION		01
09	0503019952	RUBBER BUSHING 14 X 40 X 40		06
10	0501013518	FLAT WASHER		16
11	0503011268	3/8" X 2-1/2" BOLT		06
12	0503010025	3/8 SPRING WASHER		10
13	0503010026	3/8" NUT		10
14	0571016789	PRISONER 3/8 UNC X 5/16 UNC X 65		04
15	0501010694	FLAT WASHER		04
16	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
17	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04




Item	Code	Description	See page	QT
01	0531064233	CASE 63.50 X 325		01
02	0581010670	CORPO HASTE 38,10 X 345		01
03	0511070058	GUIDE HIDRAULIC		01
04	0503010163	D-1500 SCRAPER RING		01
05	0502010471	63,50 MOBILE CAP		01
06	0501214770	RINGS SUPPORT 38.10 X 63.50		01
07	0503018004	RING		01
08	0503018003	GASKET		01
09	0503018163	BACK-UP RING		02
10	0503018162	O'RING		02
11	0502012837	PISTON		01
12	0503018005	RING		01
13	0503011109	2-119 N 3006-9B O'RING		01



Item	Code	Description	See page	QT
01	0501219247	SUPPORT HYDRAULIC COMMAND BLOCK		01
02	0503010026	3/8" NUT		04
03	0503010025	3/8 SPRING WASHER		04
04	0513010824	ADAPTER TERMINAL MF R.1.5/8 UNF X TB35		04
05	0513010837	ADAPTER TERMINAL MF R.9/16 UNF X MF TB12L		01
06	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		05
07	0513010743	BLOCK HYDRAULIC COMMAND		01
08	0513010331	M10 X 1,5 X 20 C S 5.6 ZN BOLT		06
09	0503015075	M10 SPRING WASHER		06
10	0503010237	3/8" X 1" BOLT		04
11	0513011035	ADAPTER TERMINAL MF R1.1/16 UNF		02



Item	Code	Description	See page	QT
01	0531058504	HYDRAULIC CONTROL BLOCK CYLINDER 3A DKO		01
01A	0513010744	HYDRAULIC CONTROL BLOCK		01
01B	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		02
01C	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		08
02	0503010060	1/2 UNC G.5 ZN HEX NUT		02
03	0503010019	1/2" SPRING WASHER		02
04	0571011721	FLAT WASHER 40 X 13.50 X 3.00		02
05	0501219248	HYDRAULIC CONTROL BLOCK SUPPORT		01
06	0503014007	1/2" X 1-1/4" BOLT		02
07	0503015075	M10 SPRING WASHER		04
08	0503010172	M10 X 1,5 X 25 BOLT		04




Item	Code	Description	See page	QT
01	0503035884	HYDRAULIC TANK 280 LITERS		01
02	0503035894	COVER CLEANING		01
03	0513011030	FILLING NOZZLE WITH AIR FILTER AND PRESSURIZATION		01
04	0513010699	SUCTION FILTER 300 LITERS		01
05	0513011208	SPHERE 2.1/2 REGISTRATION		01
06	0503014250	BALL REGISTRATION 1. 1/4		01
07	0531056345	RETURN FILTER WITH DKO ADAPTER		01
07A	0513010698	RETURN FILTER IN TANK 310 LITERS		01
07B	0513011209	ORIGINAL ER.1.1/2 BSP ADAPTER TERMINAL		01
08	0503015406	SUCTION FILTER		01
09	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		02
10	0513011207	ORIGINAL .1.1/4 BSP ADAPTER		01
11	0513010821	BODY UNION MALE TB42 X R.2.1/2 NPT		01
12	0513010824	ADAPTER TERMINAL MF R.1.5/8 UNF X TB35		01
13	0521013598	3/4\" PLUG		01
14	0503010190	2-114 N 3006-9B O'RING		01
15	0513010916	TERMINAL KNEE 90 MF X FG TB35 1		01
16	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
17	0513010826	KNEE TERMINAL 90G MF TB15 X FG TB15		02
18	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
19	0503036062	HYDRAULIC TUBE TB35 X 1230 FG X FG DKO		01
20	0503063547	VISOR LEVEL		01
21	0501215817	CLAMP FIXING COVER		01
22	0513010757	STANDARD CLAMP SINGLE 35 MM - BLACK		02
23	0503012720	1/4\" X 3\" BOLT		02
24	0503010143	1/4\" SPRING WASHER		02
25	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		12
26	0503010060	1/2 UNC G.5 ZN HEX NUT		12
27	0503011828	FLAT WASHER		24
28	0503010019	1/2\" SPRING WASHER		12
29	0503010180	7/16\" SPRING WASHER		03



USAP 6000 SS SUPREMA FRAME 18190
HYDRAULIC TANK 280L DKO 72E450

Page 17
0531058193


Item	Code	Description	See page	QT
30	0503010355	7/16" X 1" BOLT		03
31	0501218884	FLAT WASHER 12 X 20 X 2.00		03




Item	Code	Description	See page	QT
01	0531057052	DRAWBAR ASSY	19	01
02	0531057856	HYDRAULIC PUMP WITH MULTIPLIER BOX	21	01
03	0503063819	CARDAN 21Z 1.3/8 X 20Z 1.3/4		01

DRAWBAR ASSY


0531057052




Item	Code	Description	See page	QT
01	0501217466	TRACTION BAR GUIDE		02
02	0501010276	BOLT		04
03	0503010012	1" SPRING WASHER		04
04	0501010059	1.5/8 NUT		04
05	0503030119	LOCK PIN		01
06	0511069471	PLOUGH SUPPORT		02
07	0501011075	PIN		02
08	0503030285	HITCH PIN CLIP		02
09	0531065020	3 POINTS DRAWBAR ASSY		01
10	0503030085	LOCK PIN		08
11	0521068018	UPPER AXLE		01
12	0521068015	UPPER AXLE		01
13	0521068013	UPPER AXLE		01
14	0503012809	2" CASTLE NUT		01
15	0503010833	10 X 90 SPRING PIN		01
16	0501213695	EJE 1.1/4 X 380 MM		02
17	0531063869	AXLE 50 X 245 MM WITH THREAD 2 UNS 10 FPP		01
18	0521068011	AXLE LOWER		02
19	0531057067	DRAWBAR ESTABILIZER ASSY	20	01
20	0501217367	LEFT SUPPORT BOX		01
21	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
22	0503010589	1/2" UNC SELF ADJUSTING NUT		04
23	0501217366	RIGHT BOX SUPPORT		01
24	0503019293	SCREW 1/2 UNC X 2 COVER G7 ZN		04
25	0501217467	3 POINT CAB FIXING GUIDE GLOVE		04
26	0531057145	COMPLETE SAFETY LOCK AXIS		01
26A	0531064617	LOCK AXLE COUPLING		01
26B	0501217474	FLAT WASHER 38.50 X 70 X 6.30		02
26C	0513010701	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531065026	HEAD HOSE STABILIZER		01
02	0531061935	CONDUCTOR ARTICULATOR		02
03	0503010237	3/8" X 1" BOLT		03
04	0503010025	3/8 SPRING WASHER		03
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		03
06	0503010019	1/2" SPRING WASHER		03
07	0503012556	1/2" X 1" BOLT		03
08	0531061934	CONDUCTOR ARTICULATOR GUIDE		03
09	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
10	0503010589	1/2" UNC SELF ADJUSTING NUT		02
11	0531065130	HYDRAULIC HOSE ARTICULATOR		01




Item	Code	Description	See page	QT
01	0513010710	MULTIPLIER BOX		01
02	0531057857	PUMPS ASSEMBLY	22	01
03	0501217530	GEARBOX CAP		01
04	0503013274	BOLT M14 X 2 X 50 C.S. 10.9 ZN		08
05	0503015077	SPRING WASHER		08
06	0503015140	M12 X 1,75 X 30 BOLT		08
07	0503015076	M12 SPRING WASHER		08
08	0521014188	FLAT WASHER		08
09	0581012941	FLAT WASHER		04
10	0501218405	CALCO PUMP		01




Item	Code	Description	See page	QT
01	0513010749	HYDRAULIC PUMP AXIAL PISTON 84CC - H		01
02	0513010823	FLANGE SPLIT 2		01
03	0513010822	FLANGE SPLIT 1		02
04	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		01
05	0513010827	TERMINAL ADAPTER ORIGINAL R.7/16		01
06	0513011021	GEAR HYDRAULIC PUMP 51CC - B		01
07	0513010833	FLANGE SPLIT 1.1/4		01




Item	Code	Description	See page	QT
01	0531065350	FULL SHAFT 63.50 X 714		01
02	0531065736	WELDED SHIRT 718		01
03	0541010615	MOVABLE COVER		01
04	0581018237	RING SUPPORT 63.50 X 150 X 80		01
05	0503014960	GASKET		01
06	0503010287	D-2500 SCRAPER RING		01
07	0503010971	W2-2750-500 PK RING G.I		02
08	0581018236	PISTON 150 X 57		01
09	0503019098	O' RING 2-227 N 3006-90B		01
10	0581018235	10 X 30 NUT		01
11	0503015912	SELEMASTER SEALING		01
12	0503010002	1800 GREASE FITTING		02
13	0503010704	2-357 N 3006-9B O'RING		01
14	0503019286	BACK-UP RING 8-357		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		02
02	0503010003	1845 GREASE FITTING		02
03	0503012183	SNC 3/4" ZIN 1K03097 NUT		04
04	0502011725	UPPER BEARING SEMI		01
05	0502011724	INF BEARING SEMI		01
06	0511016281	3/4" X 8" BOLT		02
07	0501219764	BEARING 319 X 100		01



Item	Code	Description	See page	QT
01	0503010095	SEAL		02
02	0503014559	ROLLER BEARING		02
03	0501217944	RETAINER GUIDE GLOVE 75 X 108 X 45		01
04	0502040080	FLANGE NUT R.2.1/2 UN		01
05	0503019521	SCREW 3/4 UNF 3 CSRP G.8 ZN		12
06	0503010152	3/4" SELF LOCKING NUT		12
07	0531060987	ARM CUBE COVER		01
08	0503012213	1/4" COTTERPIN		01
09	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
11	0521053037	TIRE WITH WHEEL 15 X 19,50 14 LONAS	26	01
12	0531059933	WHEELS WITHOUT TIRE WITHOUT TRANSMISSION	27	01
13	0503010290	SELF ADJUSTING 1.1/2" UNF NUT		02
14	0501311309	WHEEL AXLE GUIDE GLOVE		02
15	0531066121	FRONT WHEEL FORK TRANSPORT OFFSET		01
16	0501311322	FLAT WASHER 45.50 X 75 X 8.00		01
17	0531066122	HEAD WHEEL ARM		01
18	0503010002	1800 GREASE FITTING		01
19	0521058145	AXLE LOCK ARM ROD	28	01




Item	Code	Description	See page	QT
01	0503034606	WHEEL		01
02	0503019123	TIRE 385/65 R 22,50 D711 DRC 15-19,50 20L		01
03	0503016098	VALVE		01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0503010059	33287/33462 ROLLER BEARING		01
03	0503010009	RETAINER 00573-B		01
04	0503010086	SEAL 0009B-B		01
05	0551014473	GLOVE		01
06	0503012702	KM-12 NUT		02
07	0503012703	LOCK WASHER		01
08	0503010002	1800 GREASE FITTING		01
09	0503011444	SPRING WASHER		04
10	0503014048	22 X 1.5 HEX NUT		08
11	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
12	1882970002	GREASE SOAP		01
13	0503014050	22 X 1.5 BOLT		08
14	0511068415	SEAL GUIDE		01
15	0503010007	3982/3920 ROLLER BEARING		01
16	0501311306	FRONT WHEEL AXLE 600		01

AXLE LOCK ARM ROD


0521058145




Item	Code	Description	See page	QT
01	0531060986	AXLE LOCK ROD		01
02	0503030978	COMPRES SPRING		01
03	0503010131	3/16" X 1-1/2" COTTERPIN		01
04	0503010292	701164 6 X 40 SPRING PIN		01




Item	Code	Description	See page	QT
01	0531058557	FRENCH HAND 5870 LEFT COMPLETE	31	01
02	0503036110	HYDRAULIC TUBE TB35 X 2200 MF X FG DKO		02
03	0503036103	HYDRAULIC TUBE PT35 X PT35 X 2400		02
04	0513010757	STANDARD CLAMP SINGLE 35 MM - BLACK		24
05	0501218897	CLAMP FIXER 2 TB35		06
06	0503010143	1/4" SPRING WASHER		42
07	0503012720	1/4" X 3" BOLT		12
08	0503036107	HYDRAULIC TUBE TB15 X 2200 MF X FG DKO		05
09	0503036105	HYDRAULIC TUBE PT15 X PT15 X 2400		05
10	0501218812	CLAMP FIXER 4 TB15		06
11	0513010753	SINGLE STANDARD CLAMP		60
12	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		18
13	0501218898	CLAMP FASTENER 1 TB15 30 X 42 X 6.30		06
14	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		12
15	0531058571	BIGGER TOOL BOX 234L COMPLETE	35	01
16	0501010694	FLAT WASHER		04
17	0503010358	5/16" X 5/8" BOLT		04
18	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
19	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0531058559	RIGHT FRENCH HAND 5825 ASSY	32	01
02	0503036107	HYDRAULIC TUBE TB15 X 2200 MF X FG DKO		03
03	0503036105	HYDRAULIC TUBE PT15 X PT15 X 2400		03
04	0513010753	SINGLE STANDARD CLAMP		36
05	0513010754	SINGLE STANDARD CLAMP 22 MM - BLACK		24
06	0503010143	1/4" SPRING WASHER		36
07	0503012720	1/4" X 3" BOLT		12
08	0501218901	CLAMP FASTENER 2		06
09	0501218812	CLAMP FIXER 4 TB15		06
10	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		24
11	0503036109	HYDRAULIC TUBE PT22 X FG 22 X 2200		02
12	0503036104	HYDRAULIC TUBE PT22 X PT22 X 2400		02




Item	Code	Description	See page	QT
01	0531065612	LEFT FRENCH HAND STRAW 5493		01
02	0531061900	FIXER SUPPORT		01
03	0511054713	ASSY TRANSMISSION SHAFT	33	01
04	0531062527	FRENCH MAO SIDE AXIS		01
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
06	0503010019	1/2" SPRING WASHER		01
07	0503014007	1/2" X 1-1/4" BOLT		01
08	0503010002	1800 GREASE FITTING		02
09	0521058088	ROTULA WITH EXTENSOR AXIS 2	34	01




Item	Code	Description	See page	QT
01	0531065613	RIGHT HAND FRENCH 5870		01
02	0531061900	FIXER SUPPORT		01
03	0511054713	ASSY TRANSMISSION SHAFT	33	01
04	0531062527	FRENCH MAO SIDE AXIS		01
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
06	0503010019	1/2" SPRING WASHER		01
07	0503014007	1/2" X 1-1/4" BOLT		01
08	0503010002	1800 GREASE FITTING		02
09	0521058088	ROTULA WITH EXTENSOR AXIS 2	34	01



Item	Code	Description	See page	QT
01	0521062244	PIVOT SHAFT		01
02	0551019529	FLAT WASHER		01
03	0503010027	5/8 SPRING WASHER		01
04	0503011267	5/8 UNC X 1.1/2 C S G.5 ZN BOLT		01




Item	Code	Description	See page	QT
01	0531061046	ROTULA WITH R2 LEFT NUT		01
02	0503010002	1800 GREASE FITTING		02
03	0501078990	TURNBUCKLE AXLE		01
04	0561019879	LOCK ATTACHMENT BAR		01




Item	Code	Description	See page	QT
01	0531065614	BIGGER TOOL BOX 234L		01
02	0551018356	BOX OF TOOLS COVER ASSY		01
03	0521010528	0.3" X 1.6" COUPLING SHAFT		02
04	0503010140	1/8" X 3/4" COTTERPIN		02
05	0503011907	NYLON HANDLE		01
06	0503010358	5/16" X 5/8" BOLT		02
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
08	0503010337	5/16" NUT		02

REAR LADDER


0531056419




Item	Code	Description	See page	QT
01	0501217828	REAR LADDER SIDE		02
02	0521064790	DEGRAU 600 USAP CXC		05
03	0503010025	3/8 SPRING WASHER		20
04	0503010026	3/8" NUT		20
05	0503010237	3/8" X 1" BOLT		20
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0503010589	1/2" UNC SELF ADJUSTING NUT		04
08	0531056157	LEFT REAR HANDRAILING STAIRCASE	37	01
09	0531056189	REAR RIGHT HANDRAILING STAIRCASE	38	01




Item	Code	Description	See page	QT
01	0581012741	SIDE HANDRAIL BODY (1113) CSCP		01
02	0511059383	HANDRAIL INTERNAL FIXER	39	08
03	0501217822	LARGER BODY SIDE HANDRAILING		02
04	0581012742	SIDE HANDRAIL BODY		01
05	0581012718	HANDRAIL		02
06	0581014429	SHIM HANDRAIL		02
07	0503011179	3/8" X 2-1/4" BOLT		04
08	0503013357	3/8 SELF-ADJUSTING NUT		04
09	0501217823	HANDRAIL REINFORCEMENT 27 X 33.70 X 284		02




Item	Code	Description	See page	QT
01	0581012741	SIDE HANDRAIL BODY (1113) CSCP		01
02	0511059383	HANDRAIL INTERNAL FIXER	39	08
03	0501217822	LARGER BODY SIDE HANDRAILING		02
04	0581012742	SIDE HANDRAIL BODY		01
05	0581012718	HANDRAIL		02
06	0581014429	SHIM HANDRAIL		02
07	0503010025	3/8 SPRING WASHER		04
08	0503010026	3/8" NUT		04
09	0503011179	3/8" X 2-1/4" BOLT		04
10	0501217823	HANDRAIL REINFORCEMENT 27 X 33.70 X 284		02




Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01




Item	Code	Description	See page	QT
01	0531064334	REAR EASEL CENTRAL FRAME		01
02	0501012140	FLAT WASHER		04
03	0503012412	5/8" UNC SELF LOCKING NUT		04
04	0531064333	FULL HOLDER BODY		01
05	0531063120	U-BOLT BEAM CLAMP		01




Item	Code	Description	See page	QT
01	0531064335	EASEL SIDE CHASSIS		01
02	0503012412	5/8" UNC SELF LOCKING NUT		04
03	0501012140	FLAT WASHER		04
04	0531063120	U-BOLT BEAM CLAMP		01
05	0571011070	5/8" UNC FASTENER		01




Item	Code	Description	See page	QT
01	0531064851	ROUND SIDE SUPPORT		01
02	0531064852	SIDE WHEEL FORK TIRE 710/40-22.5		01
03	0502012731	WHEEL HOLDER		04
04	0503012334	3/4" UNC X 3.1/2" BOLT		04
05	0503011075	3/4" UNC NUT		08
06	0521069575	FLANGE CYLINDER HYDRAULIC FIXER		02
07	0503010019	1/2" SPRING WASHER		05
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503010003	1845 GREASE FITTING		02
10	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
11	0503035229	CHAIN		01
12	0503016525	3/4" X 6" BOLT		04
13	0503010882	BOLT		01
14	0501010694	FLAT WASHER		02
15	0503010337	5/16" NUT		01
16	0531064839	376 WHEELED ARTICULATING AXLE		02
17	0501010630	1.1/2" CASTLE NUT		02
18	0531056756	WHEELS WITHOUT TIRE WITHOUT 43 TRANSMISSION 891		01
19	0501216660	WHEEL AXLE GUIDE GLOVE		02
20	0503011052	1.1/4" X 0.77" CASTLE NUT		02
21	0501017779	32 X 60 X 4.75 FLAT WASHER		02
22	0511019691	FLAT WASHER		01
23	0503010010	1/4" X 2.1/2" COTTERPIN		03
24	0503010002	1800 GREASE FITTING		02
25	0503011345	1/4" X 3-1/2" COTTERPIN		02
26	0531064160	AXLE WITH LOCK		01
27	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		01
28	0531055434	HYDRAULIC CYLINDER 53.98X114.25X301 MM	44	01
29	0531056787	TIRE 710/40-22.5 16L LEFT COMPLETE	45	01
30	0551014508	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0501216658	MAJOR WHEEL AXLE 891		01
03	0503010059	33287/33462 ROLLER BEARING		01
04	0503010009	RETAINER 00573-B		01
05	0503010086	SEAL 0009B-B		01
06	0551014473	GLOVE		01
07	0503012702	KM-12 NUT		02
08	0503012703	LOCK WASHER		01
09	0503010002	1800 GREASE FITTING		01
10	0503011444	SPRING WASHER		04
11	0503014048	22 X 1.5 HEX NUT		08
12	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
13	1882970002	GREASE SOAP		01
14	0503014050	22 X 1.5 BOLT		08
15	0511068415	SEAL GUIDE		01
16	0503010007	3982/3920 ROLLER BEARING		01
17	0501216659	BUSHING 63 X 80 X 171		01




Item	Code	Description	See page	QT
01	0531064161	SHIRT 114.25 X 450 3/4 NIPLE		01
02	0581015283	BODY		01
03	0531064162	EXTENDER 53.98 X 541		01
04	0561016578	PISTON BODY		01
05	0503015640	SEALING SELEMASTER		01
06	0503819100	SCREW		01
07	0502012644	RING SUPPORT		01
08	0503015641	WEAR RING		01
09	0503015642	U-CUP SEALING		01
10	0503015715	SCRAPER SEALING		01
11	0503011893	BACK-UP RING, 8-346		01
12	0503011892	O' RING, 2-346 N 3006-9B		01
13	0502011222	0.56" END CAP		01
14	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503014001	TIRE 710/40-22.5 SUPERFLOT 16 L		01
02	0503035793	ROUND 24X22.5 - 154X203MM 8F 0225-2144		01
03	0503013999	VALVE		01




Item	Code	Description	See page	QT
01	0531062313	17-MOUTH AIR TUBE WITH FIXER		01
02	0503010025	3/8 SPRING WASHER		08
03	0503010849	3/8" X 1-1/2" BOLT		08
04	0531054289	CENTRAL SEED BOX	47	01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		30
06	0503013357	3/8 SELF-ADJUSTING NUT		26
07	0531054275	LOWER BOX SEED SYSTEM	48	01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04




Item	Code	Description	See page	QT
01	0513010632	RUBBER SMOOTH WASHER 28 X 10 X 2.00	26	
02	0503063688	COMPLETE POSITIVE AIR SEED BOX	01	
03	0531063623	LOWER BOX SYSTEM FIXING RULE	04	
04	0531063624	SYSTEM FIXING RULE	02	
05	0513010630	SCREW M6 X1 X 20 CCSI 10.9 SA	12	
06	0503019413	THREAD SCREW INTERNAL	04	




Item	Code	Description	See page	QT
01	0503063393	AIR PIPE SEAL 5 OUTPUTS		01
02	0503019290	BOLT		24
03	0503034692	FAST LOCK ASSY		06
04	0503034571	SEALING		01
05	0503030085	LOCK PIN		06
06	0503063392	AIR PIPE SEAL 6 OUTPUTS		02
07	0531063617	BOTTOM BOX SYSTEM 17 OUTPUTS		01
08	0503035462	COVER SEAL		03
09	0531063616	BOTTOM COVER BOX 418		03
10	0503015135	FLAT WASHER 10 X 18 X 2		06
11	0503011823	0.1" X 0.6" SPRING PIN		06
12	0581017529	ROD 9,53		03




Item	Code	Description	See page	QT
01	0581016058	PLATFORM SUPPORT		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01
06	0503010395	1/2" X 1-1/4" BOLT		05
07	0503010589	1/2" UNC SELF ADJUSTING NUT		05




Item	Code	Description	See page	QT
01	0581012698	FRONT SIDE HANDRAIL FIXER		01
02	0503010237	3/8" X 1" BOLT		02
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503011179	3/8" X 2-1/4" BOLT		02



Item	Code	Description	See page	QT
01	0501219322	TUBE 33.70 X 27.00 X 516		03
02	0511059383	HANDRAIL INTERNAL FIXER	39	06
03	0581012718	HANDRAIL		02
04	0581014429	SHIM HANDRAIL		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0581015996	TUBE 33,7 X 27 X 1131		02
07	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0501219316	TUBE 33.70 X 27.00 X 798		03
02	0511059383	HANDRAIL INTERNAL FIXER	39	10
03	0581012718	HANDRAIL		02
04	0503011179	3/8" X 2-1/4" BOLT		06
05	0581015996	TUBE 33,7 X 27 X 1131		03
06	0581014429	SHIM HANDRAIL		03
07	0503013357	3/8 SELF-ADJUSTING NUT		06
08	0581015992	33,70 X 27 X 354 TUBE		04
09	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	53	08
10	0501213559	TUBE 27 X 33.70 X 1037		03
11	0501219317	TUBE 27 X 33.70 X 320		03
12	0581015995	33,7 X 27 X 925 TUBE		01




Item	Code	Description	See page	QT
01	0502012855	CENTRAL FIXER		01
02	0502012856	CENTRAL FIXER		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		02
04	0503015490	SELF-LOCKING NUT 7/16		02

HYDRAULIC TURBINE


0531056342




Item	Code	Description	See page	QT
01	0531056343	HYDRAULIC ENGINE	55	01
02	0503010025	3/8 SPRING WASHER		12
03	0503010026	3/8" NUT		10
04	0521044613	FAN 480X50 (HIDRAULIC)	56	01
05	0503010143	1/4" SPRING WASHER		01
06	0503010849	3/8" X 1-1/2" BOLT		02
07	0531018764	FLAT WASHER		01
08	0503011104	M6 X 1" BOLT		01
09	0503012722	0.16" X 0.4" BLIND RIVET		24
10	0521065857	CARACOL MECHANICAL TURBINE S MEC		01
11	0521065858	TURBIN SUPPORT		01
12	0531056344	COMMAND BLOCK	57	01
13	0561010634	VALVE SUPPORT ASSY		01
14	0503010237	3/8" X 1" BOLT		08
15	0503010206	3/8 X 1/2 BOLT		02
16	0571018577	COVER SNAIL TURBINE		01
17	0571018578	TURBINE PROTECTIVE SCREEN		01
18	0541013274	LISA WASHER 10 X 38 X 4.75		02
19	0521069167	FRONT PROTECTION		01
20	0503031087	ADHESIVE LABEL		01
21	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
22	0503033981	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0513010838	ADAPTER TERMINAL MF R.1/2 BSP ORING X MF TB15		02
03	0513010917	ADAPTER TERMINAL MF R.1/4 BSP ORING X MF TB15		01
04	0513010839	ADAPTER TERMINAL MF R.1/4 BSP ORING X MF TB10L		01




Item	Code	Description	See page	QT
01	0571016947	DISC FRONT TURBINE		01
02	0571016949	DISC REAR TURBINE		01
03	0521065171	HUB FLANGE		01
04	0571016950	DISC STRENGTHENING TURBINE		01
05	0571016951	FLIP TURBINE		10
06	0503012651	M6 X 1" BOLT		05
07	0503010143	1/4" SPRING WASHER		05
08	0503011776	M6 SELF ADJUSTINGNUT		05



Item	Code	Description	See page	QT
01	0503012291	BLOCK COMMAND		01
02	0513010841	ADAPTER TERMINAL MF R.3/4 UNF ORING X MF TB10L		01
03	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		04




Item	Code	Description	See page	QT
01	0531064290	AIR CONDUCTOR SUPPORT BIGGER		01
02	0571019615	FITTING 1/2 UNC 130 X 198 ZN		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0521018402	AIR CONDUCTOR CLAMP		01
07	0503010371	5/16" X 1" BOLT		02
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
09	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		05
01A	0503034812	SOCKET DISTRIBUTOR AR		01
01B	0503012856	POP RIVET		04
02	0581013633	AIR DISTRIBUTOR NOZZLE		01
03	0501214935	AIR CONDUCTOR BODY 05 BUTTONS		01
04	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
04A	0503034763	AIR DITRIBUTOR PUMP		01
04B	0503015341	POP RIVET		02

CLAMP


0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0521068228	SIDE SUPPORT		01
02	0571011070	5/8" UNC FASTENER		02
03	0501012140	FLAT WASHER		04
04	0503010027	5/8 SPRING WASHER		04
05	0503010013	5/8 NUT		04
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2 UNC G.5 ZN HEX NUT		01
09	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01




Item	Code	Description	See page	QT
01	0531061732	CENTRAL BOX SUPPORT		01
02	0581016040	LOWER SUPPORT CASH SEED		04
03	0501011643	3/8 X 1" BOLT		16
04	0503013357	3/8 SELF-ADJUSTING NUT		16
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
06	0581012237	SEAL BOX FIXER		02
07	0581012245	SEAL BOX SHOULDER		02
08	0503010025	3/8 SPRING WASHER		04
09	0503010026	3/8" NUT		04
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04




Item	Code	Description	See page	QT
01	0531061733	SUPPORT SHOE		01
02	0571011070	5/8" UNC FASTENER		02
03	0501012140	FLAT WASHER		04
04	0503013389	5/8" SELF LOCKING NUT		04
05	0503010589	1/2" UNC SELF ADJUSTING NUT		06
06	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		06




Item	Code	Description	See page	QT
01	0531065271	RIGHT LADDER 05 STEPS		01
02	0502012742	FIXER SUPPORT LADDER		02
03	0503013357	3/8 SELF-ADJUSTING NUT		02
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0503010237	3/8" X 1" BOLT		04
07	0503010025	3/8 SPRING WASHER		04
08	0503010026	3/8" NUT		04
09	0503030403	1.85" X 2.87" BEATER		01




Item	Code	Description	See page	QT
01	0503010811	5/8" UNF SELF ADJUSTING NUT		04
02	0503017960	5/8" X 3-12" BOLT		04
03	0531064194	PLATFORM SUPPORT / HANDRAILING		01




Item	Code	Description	See page	QT
01	0502012989	CLAMP BODY 4 RIGHT		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0521068360	SEED HOSE GUIDE		01
02	0521018402	AIR CONDUCTOR CLAMP		01
03	0503010371	5/16" X 1" BOLT		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501215794	DUCT TOP SUPPORT		02
02	0503036115	HYDRAULIC TUBE PT15 X PT15 X 1200		05
03	0513010753	SINGLE STANDARD CLAMP		20
04	0501215789	CLAMP FIXING COVER		02
05	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		12
06	0511017303	FLAT WASHER		12
07	0503010143	1/4" SPRING WASHER		12
08	0503010144	1/4" NUT		12
09	0571011070	5/8" UNC FASTENER		02
10	0501012140	FLAT WASHER		04
11	0503010027	5/8 SPRING WASHER		04
12	0503010013	5/8 NUT		04




Item	Code	Description	See page	QT
01	0571019137	SWITCH FIXER		01
02	0503013584	VACUUM GAUGE		01
03	0503010025	3/8 SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0581014411	BREATHE		01




Item	Code	Description	See page	QT
01	0531050988	FRONT INTERNAL SHORT SEED LINE VDRIVE CSC PPH	71	01
02	0531050991	FRONT INTERNAL LONG SEED LINE VDRIVE CSC PPH	72	01
03	0531050989	FRONT SHORT SEED LINE VDRIVE CSC PPH	73	01
04	0531050990	FRONT LONG SEED LINE VDRIVE CSC PPH	74	01
05	0521058734	INTERNAL FRONT SEED LINE SLG VDRIVE	75	01
06	0531055409	LEFT DISC BLADE DPL20 ASSY	77	01
07	0531055099	REAR WITH LEFT DDD SPICRR WITHOUT FLAP PPH VDRIVE	81	01
08	0531055100	REAR WITH SPICER RIGHT DDD WITHOUT FLAP PPH V DRIVE	82	01
09	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
10	0531013600	PRESS ADJUSTMENT LEVER		01
11	0521068982	DISC BLADE HUB KEY		01
12	0561016889	STRIPED CAP WHEEL DEPTH		01
13	0503018829	NYLON CLAMP		01
14	0503014234	BOLT 1/2 UNF X 1.3/4 CS G.5 ZN		01
15	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0521068449	SHORT SEED ROW FRONT		01
02	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION		01
03	0581018676	SLEEVE ARM SEED ROW		08
04	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION		01
05	0531061203	SEED LINE FRAME VDRIVE		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
08	0571012310	ROW LOCK BODY		01
09	0551015826	SEED ROW LOCK GUIDE SLEEV		01
10	0503010232	5/8" X 1.3/4" BOLT		01
11	0503030168	HITCH PIN CLIP		04
12	0501012140	FLAT WASHER		01
13	0503033728	FIXED SPRING PIN		02
14	0571014704	UPPER AXLE		01
15	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
16	0502012768	LINE SUPPORT CLAMP		02
17	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
18	0503010878	5/8" SELF ALIGNING NUT		04
19	0521068188	HOSE GUIDE		01
20	0503010025	3/8 SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0501011643	3/8 X 1" BOLT		01
23	0503019273	AUTO LUBRICANT SLEEVE		08
24	0503010045	O'RING		08
25	0502012568	UPPER ROCKER ARM		01
26	0503013389	5/8" SELF LOCKING NUT		01
27	0503010421	5/16" X 1-1/2" BOLT		01
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
29	0511052300	CONDUCTOR SUPPORT ASSY SEED	76	01




Item	Code	Description	See page	QT
01	0521068453	LONG FRONT SEED ROW		01
02	0581019795	SEED ARM SUPPORT ROW		01
03	0581018676	SLEEVE ARM SEED ROW		08
04	0581019796	LOWER ARM LARGER		01
05	0531061203	SEED LINE FRAME VDRIVE		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
08	0571012310	ROW LOCK BODY		01
09	0551015826	SEED ROW LOCK GUIDE SLEEV		01
10	0503010232	5/8" X 1.3/4" BOLT		01
11	0503030168	HITCH PIN CLIP		04
12	0501012140	FLAT WASHER		01
13	0503033728	FIXED SPRING PIN		02
14	0571014704	UPPER AXLE		01
15	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
16	0502012768	LINE SUPPORT CLAMP		02
17	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
18	0503010878	5/8" SELF ALIGNING NUT		04
19	0521068188	HOSE GUIDE		01
20	0503010025	3/8 SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0501011643	3/8 X 1" BOLT		01
23	0503019273	AUTO LUBRICANT SLEEVE		08
24	0503010045	O'RING		08
25	0502012568	UPPER ROCKER ARM		01
26	0503013389	5/8" SELF LOCKING NUT		01
27	0503010421	5/16" X 1-1/2" BOLT		01
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
29	0511052300	CONDUCTOR SUPPORT ASSY SEED	76	01




Item	Code	Description	See page	QT
01	0521068448	FRONT SUPPORT SHORT SEED LINE		01
02	0581019793	LOWER UPPER ARM WITHOUT LUBRICATION		01
03	0581018676	SLEEVE ARM SEED ROW		08
04	0581019794	LOWER LOWER ARM WITHOUT LUBRICATION		01
05	0531061203	SEED LINE FRAME VDRIVE		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
08	0571012310	ROW LOCK BODY		01
09	0551015826	SEED ROW LOCK GUIDE SLEEV		01
10	0503010232	5/8" X 1.3/4" BOLT		01
11	0503030168	HITCH PIN CLIP		04
12	0501012140	FLAT WASHER		01
13	0503033728	FIXED SPRING PIN		02
14	0571014704	UPPER AXLE		01
15	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
16	0502012768	LINE SUPPORT CLAMP		02
17	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
18	0503010878	5/8" SELF ALIGNING NUT		04
19	0521068188	HOSE GUIDE		01
20	0503010025	3/8 SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0501011643	3/8 X 1" BOLT		01
23	0503019273	AUTO LUBRICANT SLEEVE		08
24	0503010045	O'RING		08
25	0502012568	UPPER ROCKER ARM		01
26	0503013389	5/8" SELF LOCKING NUT		01
27	0503010421	5/16" X 1-1/2" BOLT		01
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
29	0511052300	CONDUCTOR SUPPORT ASSY SEED	76	01




Item	Code	Description	See page	QT
01	0521068452	UP SUPPORT		01
02	0581019795	SEED ARM SUPPORT ROW		01
03	0581018676	SLEEVE ARM SEED ROW		08
04	0581019796	LOWER ARM LARGER		01
05	0531061203	SEED LINE FRAME VDRIVE		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN		04
08	0571012310	ROW LOCK BODY		01
09	0551015826	SEED ROW LOCK GUIDE SLEEV		01
10	0503010232	5/8" X 1.3/4" BOLT		01
11	0503030168	HITCH PIN CLIP		04
12	0501012140	FLAT WASHER		01
13	0503033728	FIXED SPRING PIN		02
14	0571014704	UPPER AXLE		01
15	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
16	0502012768	LINE SUPPORT CLAMP		02
17	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN		04
18	0503010878	5/8" SELF ALIGNING NUT		04
19	0521068188	HOSE GUIDE		01
20	0503010025	3/8 SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0501011643	3/8 X 1" BOLT		01
23	0503019273	AUTO LUBRICANT SLEEVE		08
24	0503010045	O'RING		08
25	0502012568	UPPER ROCKER ARM		01
26	0503013389	5/8" SELF LOCKING NUT		01
27	0503010421	5/16" X 1-1/2" BOLT		01
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
29	0511052300	CONDUCTOR SUPPORT ASSY SEED	76	01




Item	Code	Description	See page	QT
01	0581018676	SLEEVE ARM SEED ROW	08	
02	0503010811	5/8" UNF SELF ADJUSTING NUT	02	
03	0503019025	BOLT 5/8 UNF X 8 C S RP G.5 ZN	02	
04	0503030168	HITCH PIN CLIP	03	
05	0503033728	FIXED SPRING PIN	02	
06	0571014704	UPPER AXLE	01	
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	01	
08	0502012768	LINE SUPPORT CLAMP	02	
09	0503019024	BOLT 5/8 UNF X 5.1/2 C S RP G.5 ZN	04	
10	0581019795	SEED ARM SUPPORT ROW	01	
11	0581019796	LOWER ARM LARGER	01	
12	0503010878	5/8" SELF ALIGNING NUT	04	
13	0503019273	AUTO LUBRICANT SLEEVE	08	
14	0503010045	O'RING	08	
15	0502012568	UPPER ROCKER ARM	01	
16	0503018829	NYLON CLAMP	02	
17	0521069980	INTERNAL FRONT SUPPORT LONG SUPER SEED LINE	01	




Item	Code	Description	See page	QT
01	0521063444	CONDUCTOR SUPPORT SEED		01
02	0501011643	3/8 X 1" BOLT		02
03	0503010025	3/8 SPRING WASHER		02
04	0503010026	3/8" NUT		02



Item	Code	Description	See page	QT
01	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
02	0503012798	5/8" X 2" BOLT		04
03	0503010878	5/8" SELF ALIGNING NUT		04
04	0531055260	SHORT LOWER SUPPORT WITH 20" CUTTING 78 DISC		01
05	0501214486	TOP SUPPORT CUTTING DISC		01




Item	Code	Description	See page	QT
01	0503019277	SLEEVE LUBRICATION SYSTEM		03
02	0503019278	LUBRICANT SLEEVE		02
03	0581018679	SLEEVE		01
04	0501212535	DISC SUPPORT AXLE		01
05	0503010361	SPRING PIN		01
06	0551015883	SPRING GUIDES SLEEVE		02
07	0503031575	COMPRESSION SPRING		02
08	0521068189	SPRING REGULACION		02
09	0501012140	FLAT WASHER		02
10	0503010152	3/4" SELF LOCKING NUT		01
11	0503010806	5/8" X 3" BOLT		02
12	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT		01
13	0503011075	3/4" UNC NUT		02
14	0503010878	5/8" SELF ALIGNING NUT		02
15	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	79	01
16	0521069351	RIGHT ARM		01
17	0521069350	LEFT ARM		01
18	0503010410	RING		02
19	0502012898	BOTTOM BRACKET		01
20	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
21	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
22	0571012370	PROTECTION FRONT		01
23	0581018678	FLANGE WASHER		01
24	0503010756	0.2" X 2.4" SPRING PIN		01
25	0501214497	WASHER 35 X 55 X 4.75		01
26	0503030430	7/16 X 2" PIN LOCK		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	DISC BLADE HUB	80	01

DISC BLADE HUB


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	DISC BLADE HUB		01
09	0502040873	DISC BLADE AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02



Item	Code	Description	See page	QT
01	0531055009	REAR ROW WITH LEFT DOUBLE DISC	83	01
02	0521056640	PRECISION PLANTING CSC CABLE / TRANSMISSION ASSY		01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0591017565	SEED CONDUCTOR GUIDE		01
06	0503015341	POP RIVET		02



Item	Code	Description	See page	QT
01	0531055008	REAR ROW WITH RIGHT DOUBLE DISC	98	01
02	0521056640	PRECISION PLANTING CSC CABLE /		01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0591017565	SEED CONDUCTOR GUIDE		01
06	0503015341	POP RIVET		02




Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0521056632	DEPTH CONTROL	84	01
03	0502012920	SUPPORT ADJUSTING		01
04	0502012611	DEPTH CONTROL AXLE		01
05	0591011309	ADJUSTMENT BUSHING		02
06	0591011310	ADJUSTMENT BAR		02
07	0503019275	SLEEVE LUBRICATION SYSTEM		01
08	0581019473	ARTICULATED SLEEVE		02
09	0503010045	O'RING		02
10	0503013357	3/8 SELF-ADJUSTING NUT		02
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
12	0591011326	LOCK PIN		01
13	0571015326	ARTICULATION SLEEVE HANDLE		01
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503010060	1/2 UNC G.5 ZN HEX NUT		02
16	0503010019	1/2" SPRING WASHER		04
17	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
18	0501011445	FLAT WASHER		04
19	0503012556	1/2" X 1" BOLT		02
20	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
21	0591011306	ADJUSTMENT LOCK		02
22	0591016907	SPACER GLOVE 14MM		06
23	0591016988	SPICER PROTECTOR		01
24	0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM 85 SPI		01
25	0521055093	BODY COMPACTOR	90	01
26	0521055017	RIGHT COMPACTOR WHEEL	91	01
27	0521054990	LEFT COMPACTOR WHEEL	92	01
28	0531050538	MOUNTED LEFT ARM	94	01
29	0531050539	MOUNTED LEFT ARM	95	01
30	0503010131	3/16" X 1-1/2" COTTERPIN		02
31	0591016900	BEATING AXLE		01




USAP 6000 SS SUPREMA FRAME 18190
REAR ROW WITH LEFT DOUBLE DISC

Page 83
0531055009


Item	Code	Description	See page	QT
32	0591016905	DEPTH WHEEL JOINT AXLE		02




Item	Code	Description	See page	QT
01	0502012925	ADJUSTMENT BODY		01
02	0511015976	FLAT WASHER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0503010581	RING		01
05	0502012892	DEPTH CONTROL HANDLE		01
06	0581019526	ARTICULATED AXLE LEVER DEPTH		01
07	0503010302	501019 SEAL RING		01




Item	Code	Description	See page	QT
01	0502012928	LEFT EXTENSOR		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 86 FERTILIZER / SEED		01
11	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 87 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	88	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	89	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUBLE DISC AXLE		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT	02	
02	0503013816	5/16" LOCKNUT	04	
03	0581015855	SLEEVE	02	
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER	01	
05	0521068661	LEVER	01	
06	0503030878	LEVER CRANK	01	
07	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING	01	
08	0581019520	AXIS	01	
09	0571812442	COUPLING SHAFT	01	
10	0503010257	1/8" X 1" COTTERPIN	01	
11	0581019511	COVER	01	
12	0503010848	5/16" X 3.1/2" BOLT	02	
13	0503010752	1/2" X 3.1/2" BOLT	01	
14	0503011336	1/2" HEX SELF ADJUSTING NUT	01	
15	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
16	0581019510	AXIS	01	
17	0581019512	PLATE TOP	01	
18	0503019351	LUBRICANT SLEEVE	02	
19	0521069591	LEFT SIDE	01	
20	0581019548	RIGHT SIDE BODY	01	




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	93	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	93	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0502012927	LEFT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055056	WHEEL RAYED ASSY BAND	96	01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0502012926	RIGHT ARM		01
02	0503011109	2-119 N 3006-9B O'RING		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055056	WHEEL RAYED ASSY BAND	96	01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01



Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
04	0503010337	5/16" NUT		06
05	0503032970	RUBBER BAND		01
06	0521055073	ASSEMBLY DEPTH WHEEL HUB	97	01



Item	Code	Description	See page	QT
01	0581019528	WHEEL DEPTH SPA HUB WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	DUST CLOAK		01
11	0581019529	DEPTH REGULATOR SHAFT		01




Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0521056632	DEPTH CONTROL	84	01
03	0502012920	SUPPORT ADJUSTING		01
04	0502012611	DEPTH CONTROL AXLE		01
05	0591011309	ADJUSTMENT BUSHING		02
06	0591011310	ADJUSTMENT BAR		02
07	0503019275	SLEEVE LUBRICATION SYSTEM		01
08	0581019473	ARTICULATED SLEEVE		02
09	0503010045	O'RING		02
10	0503013357	3/8 SELF-ADJUSTING NUT		02
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
12	0591011326	LOCK PIN		01
13	0571015326	ARTICULATION SLEEVE HANDLE		01
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503010060	1/2 UNC G.5 ZN HEX NUT		02
16	0503010019	1/2" SPRING WASHER		04
17	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
18	0501011445	FLAT WASHER		04
19	0503012556	1/2" X 1" BOLT		02
20	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
21	0591011306	ADJUSTMENT LOCK		02
22	0591016907	SPACER GLOVE 14MM		06
23	0591016988	SPICER PROTECTOR		01
24	0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	99	01
25	0521055093	BODY COMPACTOR	90	01
26	0521055017	RIGHT COMPACTOR WHEEL	91	01
27	0521054990	LEFT COMPACTOR WHEEL	92	01
28	0531050538	MOUNTED LEFT ARM	94	01
29	0531050539	MOUNTED LEFT ARM	95	01
30	0503010131	3/16" X 1-1/2" COTTERPIN		02
31	0591016900	BEATING AXLE		01




USAP 6000 SS SUPREMA FRAME 18190
REAR ROW WITH RIGHT DOUBLE DISC

Page 98
0531055008


Item	Code	Description	See page	QT
32	0591016905	DEPTH WHEEL JOINT AXLE		02




Item	Code	Description	See page	QT
01	0502012929	BODY RIGHT		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 87 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 86 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0581015996	TUBE 33,7 X 27 X 1131		03
02	0511059383	HANDRAIL INTERNAL FIXER	39	10
03	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	53	08
04	0501214693	TUBE 33.70 X 27.00 X 1850.50		03
05	0581019812	TUBE 33,7 X 27 X 550		03
06	0501214699	REAR SIDE HANDRAIL BODY		02
07	0581015995	33,7 X 27 X 925 TUBE		01
08	0531064234	FIXER RIGHT HANDRAIL		01
09	0581014429	SHIM HANDRAIL		03
10	0503011179	3/8" X 2-1/4" BOLT		02
11	0503013357	3/8 SELF-ADJUSTING NUT		02
12	0581015992	33,70 X 27 X 354 TUBE		04
13	0581012718	HANDRAIL		04




Item	Code	Description	See page	QT
01	0501214695	TUBE 33.70 X 27.00 X 1568		03
02	0511059383	HANDRAIL INTERNAL FIXER	39	08
03	0581012718	HANDRAIL		04
04	0581014429	SHIM HANDRAIL		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0581015996	TUBE 33,7 X 27 X 1131		02
07	0503013357	3/8 SELF-ADJUSTING NUT		02
08	0581015992	33,70 X 27 X 354 TUBE		02
09	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	53	04
10	0581015995	33,7 X 27 X 925 TUBE		01
11	0501219318	TUBE 27 X 33.70 X 220		03




Item	Code	Description	See page	QT
01	0591018596	BIGGEST PP TURBINE SUPPORT		01
02	0503010392	2-046 N 3006 9B O'RING		01
03	0521050154	PRECISION PLANTING TURBINE WITH HOLE	103	01
04	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
05	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
06	0503010143	1/4" SPRING WASHER		02
07	0503010144	1/4" NUT		02
08	0503010305	FLAT WASHER		02
09	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
10	0503031087	ADHESIVE LABEL		01
11	0511017907	1/8" BSPT X 6 PLUG		01
12	0581018240	AIR CONDUCTOR SUPPORT BODY		02
13	0571018437	PRISONER 1/2 X		04
14	0503010060	1/2 UNC G.5 ZN HEX NUT		08
15	0503010019	1/2" SPRING WASHER		08
16	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
17	0503062559	COUPLING FLEX 3 "C / 2 TAPES FOR MAIN TUBE		02
18	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		04
19	0513011120	TERMINAL ADAPTER R.7/16 UNF ORING X MF TB15		01
20	0513011102	HYDRAULIC HOSE 1/2 X 500 FG C90 TB15 X FG C90 TB15 A0 G		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01




Item	Code	Description	See page	QT
01	0581012427	AIR DISTRIBUTOR NOZZLE		01
02	0501219320	AIR CONDUCTOR BODY 06 BOUTES 2200		01
03	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		06
03A	0503034812	SOCKET DISTRIBUTOR AR		01
03B	0503012856	POP RIVET		04
04	0521050393	ASSY KNEE		01
04A	0503017845	90 PVC KNEE		01
04B	0581013890	AIR DISTRIBUTOR SOCKET		01




Item	Code	Description	See page	QT
01	0581012427	AIR DISTRIBUTOR NOZZLE		01
02	0501219321	AIR CONDUCTOR BODY 03 BOUTES 800		01
03	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		03
03A	0503034812	SOCKET DISTRIBUTOR AR		01
03B	0503012856	POP RIVET		04
04	0581013633	AIR DISTRIBUTOR NOZZLE		01




Item	Code	Description	See page	QT
01	0521069123	AIR CONDUCTOR SUPPORT		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0521018402	AIR CONDUCTOR CLAMP		01
06	0503010371	5/16" X 1" BOLT		02
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
08	0503010337	5/16" NUT		02
09	0571018437	PRISONER 1/2 X		02
10	0581018240	AIR CONDUCTOR SUPPORT BODY		01



Item	Code	Description	See page	QT
001	0581018670	BODY CONDUCTOR AIR		01
002	0581013633	AIR DISTRIBUTOR NOZZLE		02




Item	Code	Description	See page	QT
01	0531065262	SUPPORT HANDRAIL PLATFORM		01
02	0503010811	5/8" UNF SELF ADJUSTING NUT		04
03	0503017960	5/8" X 3-12" BOLT		04



Item	Code	Description	See page	QT
01	0501214927	FASTENER BODY U 150 X 50		01
02	0503010237	3/8" X 1" BOLT		02
03	0503013357	3/8 SELF-ADJUSTING NUT		02

RIGHT FRAME OIL DUCT SET


0531058465




Item	Code	Description	See page	QT
01	0501215794	DUCT TOP SUPPORT		002
02	0503036116	HYDRAULIC TUBE PT15 X PT15 X 700		006
03	0503036119	HYDRAULIC TUBE PT15 X PT15 X 1000		001
04	0503036118	HYDRAULIC TUBE PT15 X PT15 X 1500		001
05	0503036117	HYDRAULIC TUBE PT15 X PT15 X 2530		006
06	0513010753	SINGLE STANDARD CLAMP		108
07	0513011233	TERMINAL TEE FG X MF X FG TB15		002
08	0501215789	CLAMP FIXING COVER		013
09	0503010143	1/4" SPRING WASHER		032
10	0503012721	1/4" X 4" BOLT		024
11	0503010144	1/4" NUT		032
12	0511017303	FLAT WASHER		032
13	0571011070	5/8" UNC FASTENER		002
14	0501012140	FLAT WASHER		004
15	0503010027	5/8 SPRING WASHER		004
16	0503010129	5/8" NUT		004
17	0501215793	GLOVE 15 X 8.50 X 30		007
18	0501215790	CLAMP FIXATION CAP		002
19	0501219104	PRISONER R.1/4 X UNC X R.1/4 UNC 145		004
20	0513011275	UNION TERMINAL FG TB15 X FG TB15		001

LEFT ARM COMPLETE JOINT


0531058294




Item	Code	Description	See page	QT
01	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
02	0503010408	7/8" SPRING WASHER		01
03	0503015322	BOLT 7/8		01
04	0503010002	1800 GREASE FITTING		03
05	0501217751	CONICAL BUSHING GRIP		02
06	0501217752	LOCK NUT		01
07	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
08	0503010019	1/2" SPRING WASHER		01
09	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01
10	0501219020	PLATE 740 X 210 X 10		01
11	0503010814	5/16 BOLT		15
12	0503011052	1.1/4" X 0.77" CASTLE NUT		01
13	0503010038	3/16 X 2 COTTERPIN		01
14	0531065158	ARTICULATION AXIS 85 X 536		01
15	0502040080	FLANGE NUT R.2.1/2 UN		01
16	0501217750	120 X 64 X 9,50 FIXING WASHER		01
17	0531065542	LEFT JOINT ARM		01
18	0501217694	BUSHING WEAR 102 X 85,50 X 140		02
19	0531065159	MINOR AXLE CYLINDER 38.10 X 241		01
20	0571011767	LISA WASHER 125 X 88 X 4.76		01




Item	Code	Description	See page	QT
01	0521063778	RELATION AVEC AXE VERTICAL LATCH	01	01
02	0503010408	7/8" SPRING WASHER	01	01
03	0503015322	BOLT 7/8	01	01
04	0503010002	1800 GREASE FITTING	03	03
05	0501217751	CONICAL BUSHING GRIP	02	02
06	0501217752	LOCK NUT	01	01
07	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN	01	01
08	0503010019	1/2" SPRING WASHER	01	01
09	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT	01	01
10	0503010814	5/16 BOLT	15	15
11	0503011052	1.1/4" X 0.77" CASTLE NUT	01	01
12	0503010038	3/16 X 2 COTTERPIN	01	01
13	0531065158	ARTICULATION AXIS 85 X 536	01	01
14	0502040080	FLANGE NUT R.2.1/2 UN	01	01
15	0501217750	120 X 64 X 9,50 FIXING WASHER	01	01
16	0531065541	RIGHT JOINT ARM	01	01
17	0501217694	BUSHING WEAR 102 X 85,50 X 140	02	02
18	0531065159	MINOR AXLE CYLINDER 38.10 X 241	01	01
19	0571011767	LISA WASHER 125 X 88 X 4.76	01	01
20	0501219020	PLATE 740 X 210 X 10	01	01




Item	Code	Description	See page	QT
01	0503014001	TIRE 710/40-22.5 SUPERFLOT 16 L		01
02	0503035793	ROUND 24X22.5 - 154X203MM 8F 0225-2144		01
03	0503013999	VALVE		01




Item	Code	Description	See page	QT
01	0521068348	CENTRAL SUPPORT SEED BOX	01	
02	0581016040	LOWER SUPPORT CASH SEED	04	
03	0501011643	3/8 X 1" BOLT	16	
04	0503013357	3/8 SELF-ADJUSTING NUT	16	
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER	24	
06	0581012237	SEAL BOX FIXER	02	
07	0581012245	SEAL BOX SHOULDER	02	
08	0503010025	3/8 SPRING WASHER	04	
09	0503010026	3/8" NUT	04	
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04	
11	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN	06	
12	0503010589	1/2" UNC SELF ADJUSTING NUT	06	
13	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT	06	




Item	Code	Description	See page	QT
01	0521052154	ASSY REAR LADDER PLATFORM	116	02
02	0521069496	LARGER REAR PLATFORM BASE		01
03	0521054881	LARGER SIDE HANDRAIL FRAME CENTRAL	117	02
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2 UNC G.5 ZN HEX NUT		12
06	0503014734	BOLT		08
07	0503010395	1/2" X 1-1/4" BOLT		04
08	0581019228	PLATFORM PROTECTION		01
09	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
10	0503010025	3/8 SPRING WASHER		02
11	0503010026	3/8" NUT		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
13	0521057760	LED FLASHLIGHT WITH SUPPORT	118	02




Item	Code	Description	See page	QT
01	0521068347	PLATFORM 430 X 980		01
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04




Item	Code	Description	See page	QT
01	0581012750	SIDE HANDRAIL BODY (1085)		02
02	0511059383	HANDRAIL INTERNAL FIXER	39	06
03	0581019220	TUBE 33.7 X 27 X 668		03
04	0581012718	HANDRAIL		02
05	0581014429	SHIM HANDRAIL		02
06	0503011179	3/8" X 2-1/4" BOLT		04
07	0503010025	3/8 SPRING WASHER		04
08	0503013357	3/8 SELF-ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0591013259	LED FLASHLIGHT SUPPORT		01
02	0503019579	LED LANTERN		01




Item	Code	Description	See page	QT
01	0531060952	BAR 63,50 X 1091		01
02	0531064217	WELDED CYLINDER 150 X 1026		01
03	0503010287	D-2500 SCRAPER RING		01
04	0503010971	W2-2750-500 PK RING G.I		02
05	0581011197	PISTON		01
06	0581013481	MOBILE COVER 150		01
07	0581011195	2.5" X 5" RING SUPPORT		01
08	0503014960	GASKET		01
09	0503018465	ANILLO O'RING		01
10	0503018467	RING		01
11	0503010002	1800 GREASE FITTING		02
12	0511017907	1/8" BSPT X 6 PLUG		01
13	0503018466	O'RING		01




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
03	0521050154	PRECISION PLANTING TURBINE WITH HOLE	103	01
04	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
05	0501010694	FLAT WASHER		02
06	0503010143	1/4" SPRING WASHER		02
07	0503010144	1/4" NUT		02
08	0501081235	1/2 X 650 TR- TC HOSE		01
09	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
10	0503031087	ADHESIVE LABEL		01
11	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		04
12	0513011120	TERMINAL ADAPTER R.7/16 UNF ORING X MF TB15		01




Item	Code	Description	See page	QT
01	0581015132	BODY DISTRIBUTOR AR		01
02	0581013633	AIR DISTRIBUTOR NOZZLE		01
03	0521050393	ASSY KNEE		01
03A	0503017845	90 PVC KNEE		01
03B	0581013890	AIR DISTRIBUTOR SOCKET		01




Item	Code	Description	See page	QT
01	0581015132	BODY DISTRIBUTOR AR		01
02	0581013633	AIR DISTRIBUTOR NOZZLE		02




Item	Code	Description	See page	QT
01	0511057036	AIR DISTRIBUTOR BOARD		04
01A	0503012567	T-JOIN FOR TUBE 110		04
01B	0581013890	AIR DISTRIBUTOR SOCKET		04
02	0581019586	AIR CONDUCTOR BODY 1 MOUTH 268 04 HOLES		02
03	0591014915	3 BURNER AIR CONDUCTOR BODY		01
04	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		12
04A	0503034812	SOCKET DISTRIBUTOR AR		12
04B	0503012856	POP RIVET		48
05	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		02
05A	0503034763	AIR DITRIBUTOR PUMP		02
05B	0503015341	POP RIVET		04
06	0591014913	4-HOUSE AIR CONDUCTOR BODY		01
07	0591014914	3 BURNER AIR CONDUCTOR BODY		01




Item	Code	Description	See page	QT
01	0531064854	WHEEL SUPPORT	01	
02	0531064174	ROCKER ARTICULATING AXIS WITH FLANGE	02	
03	0501111138	CENTRAL ROUNDED ROCKER WITH GLOVE	02	
03A	0531064173	CENTRAL WHEELED ROCKER	01	
03B	0591014920	WEAR BUSHING	02	
04	0521058864	WHEEL SUPPORT WITHOUT TIRE AND WITH 125 ROCKER ARM	04	
05	0531061250	259 CYLINDER LOWER AXIS	03	
06	0503011345	1/4" X 3-1/2" COTTERPIN	03	
07	0501010630	1.1/2" CASTLE NUT	03	
08	0591014085	GLOVE 90MM	06	
09	0503010002	1800 GREASE FITTING	05	
10	0503010152	3/4" SELF LOCKING NUT	16	
11	0501010322	FLAT WASHER	04	
12	0503011075	3/4" UNC NUT	04	
13	0503016525	3/4" X 6" BOLT	04	
14	0591016833	FLAT WASHER 65 X 160 X 12.50	02	
15	0581013528	FLANGED NUT	02	
16	0503012213	1/4" COTTERPIN	02	
17	0503012913	3/4" X 3" BOLT	16	
18	0531055445	HYDRAULIC CYLINDER 63.50 X 150 X 721 X 332MM	126	02
19	0531060954	SMALLER CYLINDER AXLE 179	02	
20	0503010038	3/16 X 2 COTTERPIN	04	
21	0503011052	1.1/4" X 0.77" CASTLE NUT	04	
22	0531052442	ACTUATOR ASSEMBLY	01	
22A	0591019919	LIFT SENSOR ACTUATOR	01	
22B	0561016468	FASTENER	01	
22C	0503010589	1/2" UNC SELF ADJUSTING NUT	02	
23	0531065364	AXIS 348 CENTRAL CYLINDER LOCK	02	




Item	Code	Description	See page	QT
01	0502040760	CARRYING WHEEL HUB		01
02	0503010059	33287/33462 ROLLER BEARING		01
03	0503010009	RETAINER 00573-B		01
04	0503010086	SEAL 0009B-B		01
05	0551014473	GLOVE		01
06	0503012702	KM-12 NUT		02
07	0503012703	LOCK WASHER		01
08	0503010002	1800 GREASE FITTING		01
09	0503011444	SPRING WASHER		04
10	0503014048	22 X 1.5 HEX NUT		08
11	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
12	0503014050	22 X 1.5 BOLT		08
13	0511068415	SEAL GUIDE		01
14	0503010007	3982/3920 ROLLER BEARING		01
15	0591014921	MAJOR WHEEL AXLE		01
16	1882970002	GREASE SOAP		01




Item	Code	Description	See page	QT
01	0531061257	ROD		01
02	0531064164	WELDED CYLINDER BARREL 625		01
03	0541010615	MOVABLE COVER		01
04	0581018237	RING SUPPORT 63.50 X 150 X 80		01
05	0503014960	GASKET		01
06	0503010287	D-2500 SCRAPER RING		01
07	0503010971	W2-2750-500 PK RING G.I		02
08	0503010003	1845 GREASE FITTING		01
09	0581018236	PISTON 150 X 57		01
10	0503019098	O' RING 2-227 N 3006-90B		01
11	0581018235	10 X 30 NUT		01
12	0503015912	SELEMASTER SEALING		01
13	0503010002	1800 GREASE FITTING		01
14	0503010704	2-357 N 3006-9B O'RING		01
15	0503019286	BACK-UP RING 8-357		01




Item	Code	Description	See page	QT
01	0513010753	SINGLE STANDARD CLAMP	56	
02	0503036115	HYDRAULIC TUBE PT15 X PT15 X 1200	14	
03	0501219287	CLAMP FIXER 7	04	
04	0503012721	1/4" X 4" BOLT	16	
05	0503010144	1/4" NUT	16	
06	0511017303	FLAT WASHER	16	
07	0503010143	1/4" SPRING WASHER	16	
08	0531058582	COMPLETE CENTRAL AIR CONDUCTOR SUPPORT	02	
08A	0531065615	AIR CONDUCTOR SUPPORT	01	
08B	0503010179	LOCK WASHER 5/16 ZN 1K01528	02	
08C	0503010337	5/16" NUT	02	
08D	0503010371	5/16" X 1" BOLT	02	
08E	0521018402	AIR CONDUCTOR CLAMP	01	




Item	Code	Description	See page	QT
01	0503036114	HYDRAULIC TUBE PT35 X PT35 X 1200	02	
02	0503036115	HYDRAULIC TUBE PT15 X PT15 X 1200	11	
03	0501219289	CLAMP FIXER 2	04	
04	0501215790	CLAMP FIXATION CAP	08	
05	0503012721	1/4" X 4" BOLT	08	
06	0501219288	PRISONER R.1/4 X UNC X R.1/4 UNC 135	08	
07	0511017303	FLAT WASHER	24	
08	0503010143	1/4" SPRING WASHER	24	
09	0503010144	1/4" NUT	24	
10	0513010753	SINGLE STANDARD CLAMP	44	
11	0513010757	STANDARD CLAMP SINGLE 35 MM - BLACK	08	
12	0531058581	SUPPORT CONDUCTOR AIR	02	
12A	0531060089	SUPPORT DOUBLE AIR CONDUCTOR	01	
12B	0503010179	LOCK WASHER 5/16 ZN 1K01528	04	
12C	0503010337	5/16" NUT	04	
12D	0503010371	5/16" X 1" BOLT	04	
12E	0521018402	AIR CONDUCTOR CLAMP	02	




Item	Code	Description	See page	QT
01	0513010832	ADAPTER TERMINAL MF R.1.5/16 UNF ORING X TB28		01
02	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		04
03	0513010747	HYDRAULIC ROTATING DIVIDER		01




Item	Code	Description	See page	QT
01	0503063488	HYDRAULIC CONTROL BLOCK		01
02	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		12
03	0513011223	ADAPTER TERMINAL 1.1/16 ORING X MF TB35		01




Item	Code	Description	See page	QT
01	0503019810	DOUBLE ROTATING DIVIDER		01
02	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		02
03	0513011035	ADAPTER TERMINAL MF R1.1/16 UNF		01
04	0503010237	3/8" X 1" BOLT		04
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
06	0503013357	3/8 SELF-ADJUSTING NUT		04





Item	Code	Description	See page	QT
01	0513010784	DOUBLE HYDRAULIC ROTATING DIVIDER 51/51		01
02	0513011221	FLANGE SPLIT 1.1/4		01
03	0513011220	FLANGE SPLIT 1		02
04	0501219126	DOUBLE ROTATING DIVIDER SUPPORT		02
05	0501219127	FASTENER R.1/2 UNC 95 X 69		02
06	0503010019	1/2" SPRING WASHER		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04








Item	Code	Description	See page	QT
01	0503034334	ADHESIVE LABEL CSC (REAR)	03	
02	0503034335	ADHESIVE LABEL	03	
03	0503034336	ADHESIVE LABEL CSC (FRONT)	03	
04	0503034337	ADHESIVE LABEL	03	
05	0503034338	ADHESIVE LABEL	06	
06	0503034339	ADHESIVE LABEL	06	
07	0503031565	ADHESIVE LABEL CARE	04	
08	0503031827	LUBRICATE AND RETIGHTEN DAILY DECAL	05	
09	0503033621	ADHESIVE LABEL	04	
10	0503034682	ADHESIVE LABEL SEED TABLE	01	
11	0503031425	ADHESIVE LABEL ATTENTION	04	
12	0503033597	ADHESIVE	02	
13	0503031428	READ MANUAL DECAL	01	
14	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
15	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING	04	
16	0503034534	ADHESIVE LABEL	01	
17	0521056998	ALUMINUM IDENTIFICATION LABEL WITH RIVET	01	
17A	0503034003	SERIAL NUMBER TAG 61 X 118	01	
17B	0503010001	3.2 X 5.5 RIVET	04	
18	0503032986	ADHESIVE LABEL	02	
19	0503032988	ADHESIVE LABEL	02	
20	0503038197	OIL 140 ADHESIVE LABEL	02	




Item	Code	Description	See page	QT
01	0531057126	KIT CABIN SEEDSENSE GEN3	01	01
01A	0503063047	MONITOR KIT	01	01
01B	0503019536	MODULE	01	01
01C	0503063204	KIT BASE	01	01
01D	0503019759	WHIP	01	01
01E	0503017972	TRACTOR BATTERY WHIP	01	01
01F	0503017973	ENERGY DISTRIBUTOR MODULE	01	01
01G	0503016452	FIXING SUPPORT AG500 TRIMBLE	01	01
01H	0503016234	TRIMBLE FIXING WINDOW	01	01
01I	0503018653	ADAPTER WHIP	01	01
01J	0503018097	WHIP BATTERY	01	01
01K	0503019424	WHIP JD STARFIRE GPS	01	01
02	0503062457	TRACTOR CONNECTION ASSY	01	01
03	0503017991	MAIN HARNESS SRM - 6 LINES 45/55 729466	02	02
04	0503018062	MAIN WHIP	02	02
05	0503018060	SRM MAIN WHIP - 5 LINES	02	02
06	0503017980	APEX EXTENSION CABLE	04	04
07	0503017996	EXTENSION CABLE APEX 729151 - 4,50MTS	07	07
08	0503018085	APEX EXTENSION CABLE	03	03
09	0503017994	EXTENSION CABLE	01	01
10	0503018080	EXTENSION CABLE	03	03
11	0503018083	CAN EXTENSION CABLE SRM 729139 - 15.20MTS	01	01
12	0503017975	WHIP	40	40
13	0503019755	UNIT MODULE	40	40
14	0503019776	SEED TUBE WITH WAVE VISION SENSOR	40	40
15	0503062431	ELECTRIC MOTOR	40	40
16	0513010275	PP725905 VACUUM SENSOR	03	03
17	0513010031	EXTERNAL LIFTING CABLE PSS-X1005B CAN-5M	01	01
18	0503019291	SUPPORT SENSOR	01	01
19	0503062461	160 AMP ALTERNATOR SET	01	01
20	0503063210	SECURITY KIT PDM 729241	01	01




Item	Code	Description	See page	QT
01	0513010998	BLOCK CONTROL PANEL		001
02	0513011154	COMMAND BLOCK HARNESS		001
03	0503019920	LIGHT / LANTERN CABLE		001
04	0501217647	SHT PANEL FIXING PLATE		001
05	0503016234	TRIMBLE FIXING WINDOW		001
06	0503016452	FIXING SUPPORT AG500 TRIMBLE		001
07	0521057760	LED FLASHLIGHT WITH SUPPORT	118	002
08	0521053672	LIGHTHOUSE ASSY		005
09	0503018829	NYLON CLAMP		200
10	0503019902	NYLON CLAMP 7,8X1,8X225 MM		200
11	0503019924	BLOCK WHIP WITH ECB TREAT 4554.2		001
12	0513011205	HEAT EXCHANGER SWITCH PANEL		001
13	0513011204	TRACTOR POWER SWITCH CABLE 5463.5		001
14	0503019307	CABLE TRACTOR HEADLIGHT		002
15	0513011202	CONTROL CABLE EXTENDER		001
16	0503062594	IMPLEMENT SWITCH CABLE (EXTENSION)		001
17	0503019305	WHIP		001
18	0513010191	BOLT		003



Item	Code	Description	See page	QT
01	0541050242	LIFT HOSE SET 40E450	137	01
02	0541050243	PANTOGRAPHIC HOSE SET 40E450	138	01
03	0541050244	HOSE SET BLOCK	139	01
04	0541050245	POSITIVE/NEGATIVE TURBINE HOSE SET 40E450	140	01
05	0541050246	HOSE SET OPENS/CLOSES 40E450	141	01




Item	Code	Description	See page	QT
01	0501082615	HYDRAULIC HOSE 1/2 X 900 FG TB15 X FG C90 TB15		04
02	0501082582	HYDRAULIC HOSE 1/2 X 550		02
03	0501082820	HYDRAULIC HOSE 1.1/4 X 2900 FG TB35 X FG TB35 - 4SH		01
04	0501082821	HYDRAULIC HOSE 1.1/4 X 2800 FG TB35 X FG TB35 - 4SH		01
05	0501082784	HYDRAULIC HOSE 1/2 X 970		08
06	0501082818	HYDRAULIC HOSE 1.1/4 X 1700 FG TB35 X C45 - 4SH		01
07	0501082819	HYDRAULIC HOSE 1.1/4 X 3100 FG TB35 X FG C90 TB35 - 4SH		01
08	0501082796	HYDRAULIC HOSE 1/2 X 2900 FG TB15 X FG C90 LG TB15		04
09	0501082584	HYDRAULIC HOSE 1/2 X 2900 FG TB15 X FG C90 TB15		02
10	0501082597	HYDRAULIC HOSE 1/2 X 1000 FG TB15 X FG C90 TB15		04
11	0501082814	HYDRAULIC HOSE 1 X 850 FG TB28 X FG C45 TB28		01
12	0501082815	HYDRAULIC HOSE 1 X 940 FG TB28 X FLANGE C45		01
13	0501082816	HYDRAULIC HOSE 1 X 1250 FG TB28 X FLANGE C45		01
14	0501082603	HYDRAULIC HOSE 1/2 X 700 FG TB15 X FG TB15		08
15	0501082791	HYDRAULIC HOSE 1/2 X 1270 FG TB15 X FG TB15		02
16	0513010864	HYDRAULIC HOSE 1/2 X 800		02
17	0501082817	HYDRAULIC HOSE 1.1/4 X 1850 FG TB35 X FG C90 TB35 - 4SH		02




Item	Code	Description	See page	QT
01	0501082628	HYDRAULIC HOSE 1/2 X 1800 FG TB15 X FG C90 TB15		01
02	0513010845	HYDRAULIC HOSE 1/2 X 1200 FG TB15 X FG C90 TB15		02
03	0501082799	HYDRAULIC HOSE 1/2 X 1200 FG TB15 X FG C90 LG TB15		01
04	0501082800	HYDRAULIC HOSE 1/2 X 3100 FG TB15 X FG C90 TB15		01
05	0501082801	HYDRAULIC HOSE 1/2 X 3600 FG TB15 X FG C90 TB15		01
06	0513010851	HYDRAULIC HOSE 1/2 X 750 FG TB15 X FG C90 TB15		02

HOSE SET BLOCK


0541050244




Item	Code	Description	See page	QT
01	0501082789	HYDRAULIC HOSE 1/2 X 2050 FG TB15 X FG C90 TB15		02
02	0501082813	HYDRAULIC HOSE 1/2 X 1850		02
03	0501082822	HYDRAULIC HOSE 1/2 X 1300 FG TB35 X FG C45 TB35 - 1SN		01
04	0513010843	HYDRAULIC HOSE 1/2 X 650 FG TB10L X FG TB10L		01
05	0501082823	HYDRAULIC HOSE 1/2 X 700 FG TB35 X FG TB35 - 4SH		01
06	0501082834	HYDRAULIC HOSE 1/2 X 3100 FG TB10L X FG C90 TB10L		01
07	0501082835	HYDRAULIC HOSE 1/2 X 3100 FG C45 TB35 X FLANGE C90 90G		01
08	0501082836	HYDRAULIC HOSE 1/2 X 4100 FG TB15 X FG C90 TB15		01
09	0501082837	HYDRAULIC HOSE 1.1/4 X 3100 FG TB35 X FG TB35 - 1SN		01
10	0501082838	HYDRAULIC HOSE 2 X 3600 PF 9032 R04-32		01
11	0501082839	HYDRAULIC HOSE 3/4 X 1000 FG TB22 X FG C90 TB22		01
12	0501082840	HYDRAULIC HOSE 3/4 X 2850 FG TB22 X FG TB22		01
13	0501082841	HYDRAULIC HOSE 1.1/4 X 1800 FG TB15 X FG C90 TB15		01




Item	Code	Description	See page	QT
01	0501082582	HYDRAULIC HOSE 1/2 X 550		04
02	0501082813	HYDRAULIC HOSE 1/2 X 1850		02
03	0513010878	HYDRAULIC HOSE 1/2 X 1450		02
04	0513010880	HYDRAULIC HOSE 1/2 X 1250		01
05	0501082582	HYDRAULIC HOSE 1/2 X 550		05
06	0513010864	HYDRAULIC HOSE 1/2 X 800		02
07	0501082588	HYDRAULIC HOSE 1/2 X 550		03
08	0513010851	HYDRAULIC HOSE 1/2 X 750 FG TB15 X FG C90 TB15		02
09	0501082783	HYDRAULIC HOSE 1/2 X 2000		04
10	0501082604	HYDRAULIC HOSE 1/2 X 1900		03
11	0501082784	HYDRAULIC HOSE 1/2 X 970		12
12	0501082785	HYDRAULIC HOSE 1/2 X 3300		05
13	0501082641	HYDRAULIC HOSE 1/2 X 2300		03
14	0513011099	HYDRAULIC HOSE 1/2 X 500		01
15	0501082786	HYDRAULIC HOSE 1/2 X 420		01
16	0501082787	HYDRAULIC HOSE 1/2 X 540 FG TB15 X FG C90 TB15		02
17	0501082788	HYDRAULIC HOSE 1/2 X 640 FG TB15 X FG C90 TB15		02
18	0513010896	HYDRAULIC HOSE 1/2 X 1700 FG TB15 X FG C90 TB15		01
19	0501082615	HYDRAULIC HOSE 1/2 X 900 FG TB15 X FG C90 TB15		01
20	0501082791	HYDRAULIC HOSE 1/2 X 1270 FG TB15 X FG TB15		03
21	0501082628	HYDRAULIC HOSE 1/2 X 1800 FG TB15 X FG C90 TB15		02
22	0501082792	HYDRAULIC HOSE 1/2 X 2700 FG TB15 X FG C90 LG TB15		01
23	0501082793	HYDRAULIC HOSE 1/2 X 1900 FG TB15 X FG C90 LG TB15		01
24	0501082794	HYDRAULIC HOSE 1/2 X 1950 FG TB15 X FG C90 LG TB15		01




Item	Code	Description	See page	QT
01	0501082802	HYDRAULIC HOSE 1/2 X 2550		01
02	0501082803	HYDRAULIC HOSE 1/2 X 250		01
03	0513010848	HYDRAULIC HOSE 1/2 X 1600		02
04	0501082784	HYDRAULIC HOSE 1/2 X 970		04
05	0501082805	HYDRAULIC HOSE 1/2 X 4280		01
06	0501082806	HYDRAULIC HOSE 1/2 X 4280		01
07	0501082807	HYDRAULIC HOSE 1/2 X 1800		02
08	0501082783	HYDRAULIC HOSE 1/2 X 2000		02
09	0501082604	HYDRAULIC HOSE 1/2 X 1900		01
10	0501082809	HYDRAULIC HOSE 1/2 X 1900		01
11	0501082810	HYDRAULIC HOSE 1/2 X 800		01
12	0501082811	HYDRAULIC HOSE 1/2 X 2100		01
13	0501082812	HYDRAULIC HOSE 1/2 X 2250		01




Item	Code	Description	See page	QT
01	0501214693	TUBE 33.70 X 27.00 X 1850.50		03
02	0511059383	HANDRAIL INTERNAL FIXER	39	10
03	0581012718	HANDRAIL		04
04	0503011179	3/8" X 2-1/4" BOLT		04
05	0581015996	TUBE 33,7 X 27 X 1131		03
06	0581014429	SHIM HANDRAIL		03
07	0503013357	3/8 SELF-ADJUSTING NUT		04
08	0511059384	INTERNAL CENTRAL FIXER ASSY HANDLE	53	08
09	0581019812	TUBE 33,7 X 27 X 550		03
10	0531064185	LEFT HANDRAIL FIXER		01
11	0501214699	REAR SIDE HANDRAIL BODY		02
12	0581015995	33,7 X 27 X 925 TUBE		01
13	0581015992	33,70 X 27 X 354 TUBE		04




Item	Code	Description	See page	QT
01	0581012427	AIR DISTRIBUTOR NOZZLE		01
02	0501214752	AIR CONDUCTOR BODY 06 BOUTES 2500 04 HOLES		01
03	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		06
03A	0503034812	SOCKET DISTRIBUTOR AR		01
03B	0503012856	POP RIVET		04
04	0521050393	ASSY KNEE		01
04A	0503017845	90 PVC KNEE		01
04B	0581013890	AIR DISTRIBUTOR SOCKET		01




Item	Code	Description	See page	QT
01	0581012427	AIR DISTRIBUTOR NOZZLE		01
02	0501219319	AIR CONDUCTOR BODY 03 600 600 04 HOLES		01
03	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		03
03A	0503034812	SOCKET DISTRIBUTOR AR		01
03B	0503012856	POP RIVET		04
04	0581013633	AIR DISTRIBUTOR NOZZLE		01




Item	Code	Description	See page	QT
01	0501218751	SUPPORT ALTERNATOR KIT		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		10
03	0503010019	1/2" SPRING WASHER		10
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0571019756	FASTENER 1/2 UNC X 220 X 198 ZN		02
06	0591014851	PDM MODULE SUPPORT		01
07	0503011401	1/2" X 3/4" BOLT		06
08	0503011776	M6 SELF ADJUSTINGNUT		08




Item	Code	Description	See page	QT
01	0501215794	DUCT TOP SUPPORT	03	
02	0503036115	HYDRAULIC TUBE PT15 X PT15 X 1200	02	
03	0503036121	HYDRAULIC TUBE PT15 X PT15 X 1400	01	
04	0503036122	TUBO HIDRÁULICO PT15 X PT15 X 1800	05	
05	0503036123	HYDRAULIC TUBE PT15 X PT15 X 2000	02	
06	0503036124	HYDRAULIC TUBE PT15 X PT15 X 3250	02	
07	0513010753	SINGLE STANDARD CLAMP	72	
08	0501215789	CLAMP FIXING COVER	08	
09	0501218898	CLAMP FASTENER 1 TB15 30 X 42 X 6.30	01	
10	0503012721	1/4" X 4" BOLT	17	
11	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN	04	
12	0503010144	1/4" NUT	21	
13	0511017303	FLAT WASHER	21	
14	0503010143	1/4" SPRING WASHER	21	
15	0571011070	5/8" UNC FASTENER	03	
16	0501012140	FLAT WASHER	06	
17	0503010129	5/8" NUT	06	
18	0503010027	5/8 SPRING WASHER	06	
19	0513011233	TERMINAL TEE FG X MF X FG TB15	03	
20	0501215793	GLOVE 15 X 8.50 X 30	01	




Item	Code	Description	See page	QT
01	0501215791	DUCT TOP SUPPORT		02
02	0513010753	SINGLE STANDARD CLAMP		08
03	0501215790	CLAMP FIXATION CAP		02
04	0503036115	HYDRAULIC TUBE PT15 X PT15 X 1200		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0503010026	3/8" NUT		04
07	0503010025	3/8 SPRING WASHER		04
08	0501013518	FLAT WASHER		04
09	0503010144	1/4" NUT		04
10	0503010143	1/4" SPRING WASHER		04
11	0511017303	FLAT WASHER		04
12	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		04




Item	Code	Description	See page	QT
01	0531065270	LEFT STAIRS 05 STEPS		01
02	0502012742	FIXER SUPPORT LADDER		02
03	0503013357	3/8 SELF-ADJUSTING NUT		02
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
05	0503011179	3/8" X 2-1/4" BOLT		02
06	0503010237	3/8" X 1" BOLT		04
07	0503010025	3/8 SPRING WASHER		04
08	0503010026	3/8" NUT		04
09	0503030403	1.85" X 2.87" BEATER		01




Item	Code	Description	See page	QT
01	0531062454	WATER TANK SUPPORT		01
02	0521058344	WATER RESERVOIR WITH SOAP	150	01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0503010237	3/8" X 1" BOLT		02
05	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0503014820	BLACK WATER RESERVOIR		01
02	0503019262	SOAP DISH VACUUM		01




Item	Code	Description	See page	QT
01	0501218874	SUPPORT DUCTS 5 TB15	02	
02	0503036125	HYDRAULIC TUBE PT15 X PT15 X 1700	03	
03	0503036116	HYDRAULIC TUBE PT15 X PT15 X 700	02	
04	0513010753	SINGLE STANDARD CLAMP	30	
05	0501215789	CLAMP FIXING COVER	04	
06	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN	18	
07	0503010144	1/4" NUT	18	
08	0511017303	FLAT WASHER	18	
09	0503010143	1/4" SPRING WASHER	18	
10	0571011070	5/8" UNC FASTENER	02	
11	0503010129	5/8" NUT	04	
12	0501012140	FLAT WASHER	04	
13	0503010027	5/8 SPRING WASHER	04	
14	0501215793	GLOVE 15 X 8.50 X 30	02	



Item	Code	Description	See page	QT
01	0531062197	RIGHT SIDE CHASSIS TURBINE SUPPORT		01
02	0501012140	FLAT WASHER		04
03	0503010027	5/8 SPRING WASHER		06
04	0503010013	5/8 NUT		06
05	0571011070	5/8" UNC FASTENER		02
06	0503010232	5/8" X 1.3/4" BOLT		02



Item	Code	Description	See page	QT
01	0531058435	TURBINES HYDRAULIC CONTROL BLOCK		01
01A	0513010961	TURBINES HYDRAULIC CONTROL BLOCK		01
01B	0513011122	ADAPTER TERMINAL R.1.1/6 UNF		02
01C	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		06
02	0501219135	SUPPORT BLOCK 03 NEGATIVE TURBINES		01
03	0571019756	FASTENER 1/2 UNC X 220 X 198 ZN		02
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04
07	0503010172	M10 X 1,5 X 25 BOLT		04
08	0503015075	M10 SPRING WASHER		04
09	0591019860	FLAT WASHER 10.5 X 16 X 1.50 ZN		04



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

