

ROW CROP PLANTERS

**ULTRA FLEX SUPREMA PP - FRAME 5745/6645/7545
- CSU (FROM 05/2023)**

**ULTRA FLEX SUPREMA PP - CHASSI 5745/6645/7545
- CSU (A PARTIR 05/2023)**

Code: 0501093530

Series: S-0116

Revision: 00

Revision Date: JUNE/2024

PARTS CATALOGUE



MARCHESAN



PRODUCTS

Code	Working Width	Description
0111190387		ULTRA FLEX SUP PP 5745/12E500 CI MH DC20 SPCRR MTH PP CSU PM400 S-0116
0111190352		ULTRA FLEX SUP PP 5745/13E450 MH DC20 SPCRR MTH PP CSU PM400 S-0116
0111190455		ULTRA FLEX SUP PP 6645/15E450 SPCRR CI DC20 CSU ALP APT ISO 4C MS S/REC MTH
0111190471		ULTRA FLEX SUP PP 7545/15E500 ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909096710	ASSY FRAME - 5745/6645/7545	1
0501058211	FRAME WITH WHEEL ARTICULATOR SHAFT - 5745	2
0501054215	FRAME WITH WHEEL ARTICULATED AXIS	3
0521058396	TRACTION SPRING WHEEL ASSY WITH TRANSMISSION	4
0521058395	WHEEL SUPPORT ASSY WITH TRANSMISSION	5
0501058241	WHEEL SUPPORT CHAIN TENSIONER	6
0521058393	WHEEL WITH TIRE 7.00 X 16 14L PR TT WITH TRANSMISSION	7
0503063172	WHEEL	8
0521055233	WHEELED TRANSMISSION WITHOUT TIRE	9
0501058240	WHEEL FASTENER WITH TENSIONER	10
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	11
0501058244	WHEEL FIXED CHAIN TENSIONER	12
0501058242	WHEEL MOBILE CHAIN TENSIONER	13
0501058239	WHEEL CHAIN TENSIONER BEARING	14
0521058399	ASSY TRACTION SPRING WHEEL WITHOUT TRANSMISSION	15
0521058398	WHEEL SUPPORT WITHOUT TRANSMISSION	16
0521058394	WHEEL WITH TIRE	17
0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	18
0511054344	HYDRAULIC CYLINDER ASSEMBLY WITH 2	19
0511054418	HYDRAULIC CYLINDER ASSEMBLY WITH 3	20
0511058406	HYDRAULIC CYLINDER	21
0511054343	MOTOR SHAFT ASSEMBLY	22
0501052560	MOTOR AXLE SIGNAL	23
0511051434	TRANSMISSION ACTUATOR	24
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	25
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	26
0511054342	HEX AXLE ASSEMBLY - 5745	27
0511054545	HEX AXLE ASSEMBLY - 6645	28
0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	29
0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8	30
0511058556	PLATFORM ASSY - 5745	31
0511058670	PLATFORM ASSY - 6645	32
0511054346	OIL CONDUCTOR ASSY - 5745	33
0511054548	OIL CONDUCTOR ASSY - 6645	34
0501053834	MALE QUICK COUPLER	35
0511051209	13 ROWS HYDRAULIC MARKER ASSY - 5745	36
0511027906	BOX WITH HYDRAULIC MARKER COMPONENTS	37
0511058449	HYDRAULIC CYLINDER	38
0501054649	HBM SEQUENTIAL VALVE	39
0501050633	ROW MARKER DISC ASSEMBLY	40
0511053904	ROW MARKER DISC	41
0511054347	HANDRAIL ASSEMBLY - 5745	42
0511054549	HANDRAIL ASSEMBLY - 6645	43
0511058881	CSU C3 ASSEMBLY - 12 CONDUCTORS	44
0511058880	CSU C3 ASSEMBLY - 02 HOPPERS 05 NOZZLES + 01 HOPPER 06 NOZZLES - 12 CONDUCTORS	45
0511058565	CSU C3 ASSEMBLY - 13 CONDUCTORS	46
0511058564	CSU C3 ASSEMBLY - 02 HOPPERS 05 NOZZLES + 01 HOPPER 06 NOZZLES - 13 CONDUCTORS	47
0511057754	CSU C3 ASSEMBLY - 15 CONDUCTORS	48
0511057755	CSU C3 ASSEMBLY - 03 HOPPERS 06 NOZZLES - 15 CONDUCTORS	49
0531054470	3" X 400 SEED NOZZLE WITH FIXING	50
0531054471	CAP WITH FIXING	51
0511053356	LADDER ASSY	52
0521050585	TRANSMISSION ASSEMBLY	53
0541054730	TRANSMISSION ASSEMBLY	54
0521050183	RIGHT GEAR BOX ASSY	55
0501058212	SEMI MOUNTED RIGHT CHANGE	56



MARCHESAN

INDEX

0521050184	EXCHANGE LEFT ASSY	57
0501058213	LH GEAR BOX	58
0511059266	CLOSED BEARING	59
0501056271	GEARBOX CLOSED BEARING	60
0501056443	GEAR HOUSING BEARING	61
0501056444	ROLLER BEARING	62
0501048790	AXLE WITH RING	63
0501054655	CHAIN TENSIONER ASSY	64
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	65
0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	66
0511050125	BEARING WITH 17Z GEAR	67
0501056573	17Z GEAR ASSY	68
0511050126	MIDDLE BEARING TRANSMISSION	69
0501052759	GEARBOX BEARING ASSY	70
0511050127	CHAIN TENSIONER SUPPORT	71
0501055112	MICRO GRANULATED CHAIN TENSIONER	72
0531055881	5745 - ALPHA FERTILIZER HOPPER SET	73
0531059698	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING ALPHA II - 5745	74
0531059706	LEFT HOPPER SUPPORT WITH FERTILIZER METERING ALPHA II - 5745	75
0531055319	ALPHA II FERTILIZER METERING	76
0531055863	TRANSMISSION HUB ASSY	77
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	78
0531059139	COLLECTOR ASSY	79
0531055273	ALPHA FERTILIZER METERING CLAMP	80
0501053788	3/4" SQUARE AXLE FASTENER	81
0531057911	22Z GEAR SIDE BEARING ASSEMBLY	82
0531057901	GEAR	83
0531056670	ALPHA FERTILIZER HOPPER SET WITHOUT TRANSMISSAO - 6645	84
0531059780	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING ALPHA II WITHOUT TRANSMISSION - 6645	85
0531059781	LEFT HOPPER SUPPORT WITH FERTILIZER METERING ALPHA II WITHOUT TRANSMISSION - 6645	86
0531059058	DOUBLE GEAR BEARING SET	87
0531057912	DOUBLE SIDE BEARING	88
0511054350	DRAWBAR	89
0531057387	LABEL SET FOR HYDRAULIC MARKER 5745	90
0531056674	LABEL SET FOR APT WITHOUT GEARBOX 6645	91
0541054731	DECAL ASSY	92
0511056696	INSTRUCION MANUAL CANISTER	93
0511054971	JACK ASSEMBLY	94
0521052824	ASSY TURBINE P.P	95
0511059459	PRECISION PLANTING SUPREME TURBINE ASSY	96
0511059319	AIR FIXING SUPPORT	97
0511057785	VACUUM DISTRIBUTOR	98
0511057906	HOSE ASSY	99
0521050537	FEMALE QUICK HITCH WITH TURBINE HYDRAULIC DRAIN	100
0511059406	TURBINE PP MOUNTED	101
0521050154	PRECISION PLANTING TURBINE WITH HOLE	102
0501054258	DRAWBAR ESTABILIZER ASSY	103
0511054601	ARTICULATED TRACTOR HITCH	104
0511053179	TRACTOR COUPLING SHAFT	105
0521052549	CLAMP	106
0531053443	MONITORING ASSEMBLY PLANTING SEEDS 14 ROWS PM 400	107
0511058368	MOBILE SUPPORT	108
0531059622	ALPHA COMPONENTS KIT - 12 ROWS	109
0531059623	ALPHA COMPONENTS KIT - 13 ROWS	110
0531059625	ALPHA COMPONENTS KIT - 15 ROWS	111



MARCHESAN

INDEX


0521058310	VDRIVE SET 15 LINES	112
0541054732	MECHANICAL ASSY	113
0531057344	FULL PDM SUPPORT	114
0531056653	MECHANICAL ASSEMBLY APT/4C/ALPHA	115
0521050273	MOTOR SUPPORT SEED	116
0511056294	ASSY MODULE BOX	117
0511059348	APT ASSY MODULE BOX	118
0531050766	SENSOR ACTUATOR	119
0531056635	ASSY HOSE	120
0521058497	ISO 04 CHANNELS 15 ROWS ASSEMBLY	121
0511056972	FILTER HYDAC	122
0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	123
0909096711	ASSY SEED/FERTILIZER ROW	124
0511057243	LEFT SHORT SEED ROW FRONT	125
0511057244	RIGTH SHORT SEED ROW FRONT	126
0521050749	FRONT SHORT SEED ROW LEFT	127
0521050751	FRONT RIGHT SHORT SEED ROW	128
0511057246	RIGHT LONG SEED ROW FRONT	129
0511057247	LEFT LONG SEED ROW FRONT	130
0521050750	FRONT LONG RIGHT SEED ROW	131
0521050752	FRONT LONG LEFT SEED ROW	132
0511054635	BEARING AXLE BODY	133
0511057159	TRANSMISSION HOPPER SEED ROW	134
0511050609	BEARING WITH 17Z GEAR ASSY	135
0511050617	FRONT SEED ROW BEARING	136
0511055260	SEED ROW CHAIN TENSIONER	137
0511052426	TRANSMISSION CARDAN ASSY	138
0511052389	BEARING DOUBLE FRONT ROW SEED	139
0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	140
0541054733	SHORT ARM FERTILIZER LINE WITH LEFT DTR	141
0521055869	LEFT DUAL FERTILIZER DISC	142
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	143
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	144
0521055864	FERTILIZER/SEED RIGHT HUB ASSY	145
0521055865	FERTILIZER/SEED LEFT HUB ASSY	146
0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	147
0541054734	LONG ARM FERTILIZER LINE WITH RIGHT DTR	148
0521055868	RIGHT DUAL FERTILIZER DISC	149
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	150
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	151
0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	152
0521044545	20" SHORT CURVED CORRIGATED DISC	153
0511044585	20" COULTER BLADE ASSY FOR LONG ROW	154
0521054680	20" DISC BLADE HUB	155
0521054679	DISC BLADE HUB	156
0511058747	RIGHT REAR SUPREME SEED ROW P.P CSU	157
0511058748	LEFT REAR SUPREME SEED ROW P.P CSU	158
0521050737	PNEUMATIC SEED DISTRIBUTOR	159
0511057212	3 CSU PRECISION PLANTING V-SET2 ASSY	160
0511057155	PRECISION PLANTING LEFT TRANSMISSION HOPPER	161
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	162
0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	163
0511057154	RIGHT DDD	164
0511057153	DDD LEFT	165
0511053172	LEFT LOW HUB WITH 15 DISC	166
0511053173	RIGHT LOW HUB WITH 15 DISC	167
0531054532	WHEEL SYSTEM DEPTH / COMPACTOR	168
0501056769	DEPTH WHEELS REGULATOR ASSY	169



MARCHESAN

INDEX


0521051423	COMPACTOR SUPPORT		170
0501052908	COMPACTOR WHEEL WITH BEARING		171
0511050077	WHEEL STRIPED		172
0511052287	DEPTH WHEEL HUB ASSY		173
0511058212	FERTILIZER ROW SUPPORT ASSY		174
0531050237	3" RIGHT SEED CONDUCTOR FIXER		175
0501058423	FERTILIZER ROD SPRING ROW		176
0501110231	SCARIFIER ROD WITH TIP		177
0521057957	FIXED ROD EXTENSION WITH FIXATION		178




Item	Code	Description	See page	5745	6645	7545
01	0501058211	FRAME WITH WHEEL ARTICULATOR SHAFT - 5745	2	01	00	00
01.	0501054215	FRAME WITH WHEEL ARTICULATED AXIS	3	00	01	00
01..	0501054984	FRAME WITH WHEEL		00	00	01
02	0521058396	TRACTION SPRING WHEEL ASSY WITH 4 TRANSMISSION	4	04	00	04
02.	0521058399	ASSY TRACTION SPRING WHEEL WITHOUT TRANSMISSION	15	00	06	02
03	0511054344	HYDRAULIC CYLINDER ASSEMBLY WITH 2	19	01	00	00
03.	0511054418	HYDRAULIC CYLINDER ASSEMBLY WITH 3	20	00	01	01
04	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02	03	03
05	0531012565	SLEEVE 16,3X 30 X 88		02	03	03
06	0503010027	5/8 SPRING WASHER		02	03	03
07	0503010013	5/8 UNC G.5 ZN HEX NUT		02	03	03
08	0511054343	MOTOR SHAFT ASSEMBLY	22	01	00	00
08.	0511054580	MOTOR SHAFT ASSEMBLY		00	00	01
09	0511054342	HEX AXLE ASSEMBLY - 5745	27	01	00	01
09.	0511054545	HEX AXLE ASSEMBLY - 6645	28	00	01	00
10	0511058556	PLATFORM ASSY - 5745	31	01	00	00
10.	0511058670	PLATFORM ASSY - 6645	32	00	01	00
10..	0511058684	PLATFORM ASSY - 7545		00	00	01
11	0511054346	OIL CONDUCTOR ASSY - 5745	33	01	00	00
11.	0511054548	OIL CONDUCTOR ASSY - 6645	34	00	01	00
11..	0511054421	OIL CONDUCTOR ASSY - 7545		00	00	01
12	0511051209	13 ROWS HYDRAULIC MARKER ASSY - 5745	36	01	00	00
13	0501050633	ROW MARKER DISC ASSEMBLY	40	02	00	01
14	0511054347	HANDRAIL ASSEMBLY - 5745	42	01	00	00
14.	0511054549	HANDRAIL ASSEMBLY - 6645	43	00	01	00
14..	0511054582	HANDRAIL ASSEMBLY - 7545		00	00	01
15	0511058881	CSU C3 ASSEMBLY - 12 CONDUCTORS	44	01	00	00
15.	0511058565	CSU C3 ASSEMBLY - 13 CONDUCTORS	46	01	00	00
15..	0511057754	CSU C3 ASSEMBLY - 15 CONDUCTORS	48	00	01	00
15...	0511057779	ASSY CSU C3 SEMI MOUNTED UF 7545/15		00	00	01

Item	Code	Description	See page	5745	6645	7545
16	0511053356	LADDER ASSY	52	01	01	01
17	0521050585	TRANSMISSION ASSEMBLY	53	01	00	00
17.	0541054730	TRANSMISSION ASSEMBLY	54	00	00	01
18	0531055881	5745 - ALPHA FERTILIZER HOPPER SET	73	01	00	00
18.	0531056670	ALPHA FERTILIZER HOPPER SET WITHOUT TRANSMISSAO - 6645	84	00	01	00
18..	0531056137	ALPHA FERTILIZER HOPPER SET - 7545		00	00	01
19	0511054350	DRAWBAR	89	01	01	01
20	0531057387	LABEL SET FOR HYDRAULIC MARKER 5745	90	01	00	00
20.	0531056674	LABEL SET FOR APT WITHOUT GEARBOX 6645	91	00	01	00
20..	0541054731	DECAL ASSY	92	00	00	01
21	0511056696	INSTRUCION MANUAL CANISTER	93	01	01	01
22	0511054971	JACK ASSEMBLY	94	02	02	02
23	0503034003	61 X 118 SERIAL NUMBER TAG		01	01	01
24	0503010001	RIVET 3,2 X 5,5		04	04	04
25	0511054863	HYDRAULIC MARKER ASSEMBLY - 7545		00	00	01
26	0521052824	ASSY TURBINE P.P	95	01	00	00
26.	0511059459	PRECISION PLANTING SUPREME TURBINE ASSY	96	00	01	00
26..	0521053718	TURBINE SET - 7545		00	00	01
27	0501054258	DRAWBAR ESTABILIZER ASSY	103	01	01	01
28	0521013164	EXTENDER		02	00	00
29	0501011310	FIXER LOCK		08	00	00
30	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		08	00	00
31	0503010019	1/2" SPRING WASHER		08	00	00
32	0503010060	1/2 UNC G.5 ZN HEX NUT		08	00	00
33	0511054601	ARTICULATED TRACTOR HITCH	104	01	01	01
34	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01	01
35	0511053179	TRACTOR COUPLING SHAFT	105	01	01	01
36	0502012702	BODY SUPPORT CLAMP		01	01	01
37	0531011180	SUPPORT		01	01	01
38	0501047895	25 ROD STOP		02	03	03
39	0501047885	30 ROD STOP		02	03	03
40	0501047886	35 ROD STOP		02	03	03
41	0501047887	40 ROD STOP		02	03	03
42	0501065677	BRACKET		02	02	02
43	0521013022	TRANSPORT LOCK		02	03	03
44	0501068994	8,30 X 78 LOCK PIN		02	03	03
45	0503030168	HITCH PIN CLIP		02	03	03
46	0503010780	N-2050 AMENDMENT		04	04	04
47	0503011750	AMENDMENT WITH LOCK		06	06	06
48	0503011751	REDUCTION 40-1		06	06	06
49	0503010543	AMENDMENT WITH LOCK		02	02	02
50	0541011767	HOSE FIXATION		01	01	01
51	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02	02	02
52	0503010025	3/8" SPRING WASHER		02	02	02
53	0503010026	3/8" NUT		02	02	02
54	0503014120	CHAIN		01	01	01
55	0503014321	CABLE STEEL SHACKLE		02	02	02
56	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01	01	01
57	0581013729	NIPLE 1/2 NPT		01	01	01
58	0541010080	TERMINAL R.1 / 2 NPT		01	01	01
59	0503010045	O'RING		01	01	01
60	0501053834	MALE QUICK COUPLER	35	01	01	01
61	0521058497	ISO 04 CHANNELS 15 ROWS ASSEMBLY	121	00	01	00
62	0511027906	BOX WITH HYDRAULIC MARKER COMPONENTS	37	00	00	01
63	0503034867	AIR DISTRIBUTOR PUMP		09	07	08
64	0503010243	CLAMP		09	07	09
65	0531053443	MONITORING ASSEMBLY PLANTING SEEDS ROWS PM 400	14 107	01	00	00
66	0571017368	SUPPORT FASTENER		08	00	10
67	0571018391	1" X 2" X 47" SUPPORT		04	00	00


Item	Code	Description	See page	5745	6645	7545
67.	0571019131	25 X 58 X 2220 GUTTER		00	00	02
67..	0571017236	GUTTER		00	00	02
68	0501011643	3/8 X 1" BOLT		08	00	10
69	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08	00	10
70	0503010025	3/8" SPRING WASHER		08	00	10
71	0503010026	3/8" NUT		08	00	10
72	0511058368	MOBILE SUPPORT	108	02	02	02
73	0531059622	ALPHA COMPONENTS KIT - 12 ROWS	109	01	00	00
73.	0531059623	ALPHA COMPONENTS KIT - 13 ROWS	110	01	00	00
73..	0531059625	ALPHA COMPONENTS KIT - 15 ROWS	111	00	01	01
74	0521058310	VDRIVE SET 15 LINES	112	00	00	01
75	0531056653	MECHANICAL ASSEMBLY APT/4C/ALPHA	115	00	01	00
76	0541054732	MECHANICAL ASSY	113	00	00	01
77		ASSY SEED/FERTILIZER ROW	124			




Item	Code	Description	See page	QT
01	0511069354	FRAME - 5745		01
02	0521013199	LOWER BEARING SEMI		06
03	0503010899	5/8 UNC X 2.1/4 BOLT		12
04	0531013922	0.6" X 0.8" X 1" SLEEVE		12
05	0503011445	SPRING WASHER		12
06	0503010013	5/8 UNC G.5 ZN HEX NUT		12
07	0511063997	CARRYING-WHEELS PIVOT SHAFT		01
08	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		24




Item	Code	Description	See page	QT
01	0511069355	FRAME		01
02	0511063998	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8 UNC X 2.1/4 BOLT		12
05	0531013922	0.6" X 0.8" X 1" SLEEVE		12
06	0503010013	5/8 UNC G.5 ZN HEX NUT		12
07	0503011445	SPRING WASHER		02
08	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		24




Item	Code	Description	See page	QT
01	0521058395	WHEEL SUPPORT ASSY WITH TRANSMISSION	5	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	10	01
03	1902010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503013257	2050 CHAIN X 89 LINK + MENDING		01
07	0503011254	7/8" HEX SELF ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0521061565	WHEEL SUPPORT ARM		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4 X 2 SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	BOLT 5/8" UNC X 2 CS G.5 ZN		01
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0501058241	WHEEL SUPPORT CHAIN TENSIONER	6	01
11	0521058393	WHEEL WITH TIRE 7.00 X 16 14L PR TT WITH 7 TRANSMISSION		01
12	0521069983	WHEEL COVER		01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8 SPRING WASHER		04
15	0503018981	M16 X 2" X 1.77" C S 10.9 ZN BOLT		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503063172	WHEEL	8	01
02	0521055233	WHEELED TRANSMISSION WITHOUT TIRE	9	01

WHEEL


0503063172




Item	Code	Description	See page	QT
01	0503019458	TIRE 7.00X16 14PR		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	25590/25523 ROLLER BEARING		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL BOLT 5/8"UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0502011339	15Z GEAR P 1.25"		01
09	0503012550	5/16" X 3/4" BOLT		06
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 UNC G.5 ZN HEX NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	11	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	12	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	13	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	14	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	LOWER SHAFT		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	14	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	14	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0521058398	WHEEL SUPPORT WITHOUT TRANSMISSION	16	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0511050681	TRACTION SPRING		01
06A	0561016062	SPRING HITCH		02
07	0501010100	BOLT 5/8" UNC X 2 CS G.5 ZN		01
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0503010027	5/8 SPRING WASHER		02




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0521061565	WHEEL SUPPORT ARM		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4 X 2 SPLIT PIN		01
05	0521058394	WHEEL WITH TIRE	17	01
06	0591010589	BODY LOCK WHEEL		02
07	0503018981	M16 X 2" X 1.77" C S 10.9 ZN BOLT		02
08	0503010027	5/8 SPRING WASHER		02
09	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503063172	WHEEL	8	01
02	0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	18	01




Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	25590/25523 ROLLER BEARING		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL BOLT 5/8"UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	21	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521012536	COUPLING SHAFT		02
04	0503010523	1/4 X 2 SPLIT PIN		04
05	0503010003	1845 GREASE FITTING		08




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	21	03
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521012536	COUPLING SHAFT		04
04	0503010523	1/4 X 2 SPLIT PIN		06
05	0503010003	1845 GREASE FITTING		10




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCKLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE W2-2250-750		01
08	0503018026	GASKET 1870-2000-375 B POLYMAX		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	END CAP 4"		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01

MOTOR SHAFT ASSEMBLY


0511054343




Item	Code	Description	See page	QT
01	0511064914	MOTOR CHOCK BEARING SUPPORT		04
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0501110639	BEARING		08
07	0503010300	5/32" X 1" SPLIT PIN		08
08	0503011099	GREASE FITTING		08
09	0531017204	CHOCK BEARING		04
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		08
11	0503010025	3/8" SPRING WASHER		08
12	0503010026	3/8" NUT		08
13	0561016795	2775 MOTOR SHAFT		02
14	0501018466	FLAT WASHER		04
15	0511015961	LOCK BUSHING		04
16	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
17	0503010060	1/2 UNC G.5 ZN HEX NUT		04
18	0501052560	MOTOR AXLE SIGNAL	23	02
19	0511051434	TRANSMISSION ACTUATOR	24	04
20	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	25	01
21	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	26	01



Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	NUT 5/16 UNC G.5 ZN		02
05	0503031584	ORANGE SIGNAL ARROW DECAL		01
06	0503031585	SILVER SIGNAL ARROW DECAL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
05	0501019734	FLAT WASHER		02
06	0502010710	RIGHT CAM, SMALLER		02
07	0503010003	1845 GREASE FITTING		02
08	0502012539	26Z P12,7 GEAR		01
09	0501019735	FLAT WASHER		01
10	0521017593	FLAT WASHER		01
11	0503010542	501045 CLAMPING RING (FOR AXLE)		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01

LEFT SIDE TRANSMISSION ACTUATOR


0511047070




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 C50P G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0531016946	5/8" X 114" AXLE HEX		01
02	0531016947	LEFT 5/8" X 108" AXLE HEX		01
03	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	29	02
04	0561014215	BEARING COVER LOWER ROW FRAME		02
05	0502040534	SPRING GUIDE BUSHING LOCK		02
05A	1902012196	SPRING GUIDE LOCK SLEEVE		01
06	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0531016948	RIGHT 5/8" X 131" AXLE HEX		01
02	0531016949	LEFT 5/8" X 125" AXLE HEX		01
03	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	29	02
04	0561014215	BEARING COVER LOWER ROW FRAME		02
05	0502040534	SPRING GUIDE BUSHING LOCK		04
06	0503010237	3/8" X 1" BOLT		04




Item	Code	Description	See page	QT
01	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8	30	01
02	0511063106	20Z AXLE BEARING DOUBLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0581012453	PLATFORM - 5745		02
02	0501010942	3/8" X 1-1/4" BOLT		04
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0581012454	PLATFORM		02
02	0501010942	3/8" X 1-1/4" BOLT		04
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0511064465	OIL CONDUCTOR		01
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
03	0503010025	3/8" SPRING WASHER		02
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
05	0501053834	MALE QUICK COUPLER	35	02
06	0511057064	HOSE KIT SYSTEM HYDRAULIC		01
06A	0501080402	3/8" X 66" TR-TC HOSE		04
06B	0521052299	1/2" X 157.48" TR-TM BLACK/RED HOSE		01
06BA	0501080185	1/2" X 157" TR-TM HOSE		01
06BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
06BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
06BD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
06C	0521052300	1/2" X 157.48" TR-TM BLACK/BLUE HOSE		01
06CA	0501080185	1/2" X 157" TR-TM HOSE		01
06CB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
06CC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
06CD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
07	0581010729	SPRING PROTECTION PLASTIC HOSE 3/4" X 3800MM		01
08	0502012702	BODY SUPPORT CLAMP		04
09	0503012555	7/16" UNC X 2" CS RT G.7 ZN SCREW		04
10	0503010180	7/16" SPRING WASHER		04




Item	Code	Description	See page	QT
01	0511064627	15 MH OIL CONDUCTOR		01
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
03	0503010025	3/8" SPRING WASHER		02
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
05	0511057066	HOSE KIT HYDRAULIC		01
05A	0501080406	3/8" X 23" TR-TC HOSE		02
05B	0501080402	3/8" X 66" TR-TC HOSE		04
05C	0521052299	1/2" X 157.48" TR-TM BLACK/RED HOSE		01
05CA	0501080185	1/2" X 157" TR-TM HOSE		01
05CB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
05CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
05CD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
05D	0521052300	1/2" X 157.48" TR-TM BLACK/BLUE HOSE		01
05DA	0501080185	1/2" X 157" TR-TM HOSE		01
05DB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
05DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
05DD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
06	0501053834	MALE QUICK COUPLER	35	02
07	0571017774	SPRING PROTECTION QUICK HOSE		01
08	0502012702	BODY SUPPORT CLAMP		04
09	0503012555	7/16" UNC X 2" CS RT G.7 ZN SCREW		04
10	0503010180	7/16" SPRING WASHER		04




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511064067	HYDRAULIC ROW MARKER SUPPORT		02
02	0501010100	BOLT 5/8" UNC X 2 CS G.5 ZN		08
03	0503012412	5/8" UNC SELF LOCKING NUT		08
04	0511061811	ROW MARKER ARM		02
05	0521061655	BOLT 5/8 UNC X 320 MM		02
06	0521017687	SPACING SLEEVE		02
07	0521010479	SLEEVE ARTICULATION		04
08	0503012412	5/8" UNC SELF LOCKING NUT		02
09	0511058449	HYDRAULIC CYLINDER	38	02
10	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
11	0503010523	1/4 X 2 SPLIT PIN		02
12	0511015779	1" X 4.2" AXLE		02
13	0503010523	1/4 X 2 SPLIT PIN		02
14	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
15	0501068994	8,30 X 78 LOCK PIN		02
16	0503030168	HITCH PIN CLIP		02
17	0501066949	1235 TURNBUCKLE		02
18	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
19	0501054649	HBM SEQUENTIAL VALVE	39	01
20	0511057065	HYDRAULIC MARKER HAND SET		01
20A	0501080418	3/8" X 165" TR-TC HOSE		02
20B	0501081724	3/8" X 173.22" TR-TC HOSE		02
20C	0501080422	3/8" X 157" TC-TM HOSE		02
21	0501053834	MALE QUICK COUPLER	35	02
22	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
23	0502012702	BODY SUPPORT CLAMP		02
24	0503012555	7/16" UNC X 2" CS RT G.7 ZN SCREW		02
25	0503010180	7/16" SPRING WASHER		02
26	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04



Item	Code	Description	See page	QT
01	0501100045	WOODEN BOX		01
02	0511061022	ROW MARKER SUPPORT		02
03	0511066119	MARKER SUPP FIXER FASTENER		04
04	0502010175	HITCH CLAMP		08
05	0501010216	3/4 UNC X 4.1/2 C S G.5 ZN BOLT		16
06	0503010023	3/4" SPRING WASHER		16
07	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		16
08	0511060013	ROW MARKER ARM		02
09	0521013347	1.1/4" X 8.4" AXLE		02
10	0501019435	32 X 50 X 1.5 FLAT WASHER		16
11	0503010523	1/4 X 2 SPLIT PIN		16
12	0511060014	ROW MARKER ARM		02
13	0521011142	1.1/4" X 7.5" AXLE		04
14	0521011141	1.1/4" X 6.5" AXLE		02
15	0521061790	1750 TURNBUCKLE		02
16	0501050633	ROW MARKER DISC ASSEMBLY	40	02
17	0521012324	1/2" X 3.2" X 2.54" FASTENER		04
18	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
19	0503010019	1/2" SPRING WASHER		08
20	0503010060	1/2 UNC G.5 ZN HEX NUT		08
21	0503010004	1890 GREASE FITTING		02
22	0503010003	1845 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	O'RING 2-119 N 3006 9B		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	REPAIR KIT ASSY (0511058413)		01



Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCIAL VALVE		01
02	0501010617	NIPLE 3/4" NF X 3/4" NF HEX. 7/8" X 44		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02

ROW MARKER DISC ASSEMBLY


0501050633




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	41	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		01

ROW MARKER DISC


0511053904




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9\" X 2\" X 0.02\" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4\" UNF X 1/2\" BOLT		03
12	0503010878	5/8\" SELF ALIGNING NUT		01
13	0503010691	1/4\" GREASE FITTING		01
14	0503010358	5/16\" X 5/8\" BOLT		04
15	0503011444	SPRING WASHER 5/16\"		04
16	0503010337	NUT 5/16 UNC G.5 ZN		04




Item	Code	Description	See page	QT
01	0521067213	HANDRAIL - 5745		02
02	0521067211	HANDRAIL INTERMEDIARY		02
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		04
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		12
06	0503010019	1/2" SPRING WASHER		12
07	0503010060	1/2 UNC G.5 ZN HEX NUT		12
08	0581012447	TUBE		02




Item	Code	Description	See page	QT
01	0521067212	SIDE HANDRAIL 15L		02
02	0521067211	HANDRAIL INTERMEDIARY		02
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		04
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		12
06	0503010019	1/2" SPRING WASHER		12
07	0503010060	1/2 UNC G.5 ZN HEX NUT		12
08	0581012447	TUBE		02




Item	Code	Description	See page	QT
01	0511058880	CSU C3 ASSEMBLY - 02 HOPPERS 05 NOZZLES + 45 01 HOPPER 06 NOZZLES - 12 CONDUCTORS		01
02	0521051927	TOWER SUPPORT HOPPER		06
02A	0521066208	HOPPER SUPPORT TOWER		01
02B	0503011084	3/4" X 5" BOLT		02
02C	0502010175	HITCH CLAMP		01
02D	0503011075	3/4 UNC LOCK NUT		02
03	0501010942	3/8" X 1-1/4" BOLT		12
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		12
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
01	0521064748	5 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		01
03	0503061987	5 NOZZLES FRONT FERTILIZER HOPPER		02
04	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		01
05	0521063401	FIXING LOCK		06
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
07	0503010025	3/8" SPRING WASHER		06
08	0503010026	3/8" NUT		06
09	0531054470	3" X 400 SEED NOZZLE WITH FIXING	50	12
10	0531054471	CAP WITH FIXING	51	04




Item	Code	Description	See page	QT
01	0511058564	CSU C3 ASSEMBLY - 02 HOPPERS 05 NOZZLES + 47 01 HOPPER 06 NOZZLES - 13 CONDUCTORS		01
02	0521051927	TOWER SUPPORT HOPPER		06
02A	0521066208	HOPPER SUPPORT TOWER		01
02B	0503011084	3/4" X 5" BOLT		02
02C	0502010175	HITCH CLAMP		01
02D	0503011075	3/4 UNC LOCK NUT		02
03	0501010942	3/8" X 1-1/4" BOLT		12
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		12
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
01	0521064748	5 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		01
03	0503061987	5 NOZZLES FRONT FERTILIZER HOPPER		02
04	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		01
05	0521063401	FIXING LOCK		06
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
07	0503010025	3/8" SPRING WASHER		06
08	0503010026	3/8" NUT		06
09	0531054470	3" X 400 SEED NOZZLE WITH FIXING	50	13
10	0531054471	CAP WITH FIXING	51	03




Item	Code	Description	See page	QT
01	0511057755	CSU C3 ASSEMBLY - 03 HOPPERS 06 NOZZLES - 49		01
02	0521051927	TOWER SUPPORT HOPPER		06
02A	0521066208	HOPPER SUPPORT TOWER		01
02B	0503011084	3/4" X 5" BOLT		02
02C	0502010175	HITCH CLAMP		01
02D	0503011075	3/4 UNC LOCK NUT		02
03	0501010942	3/8" X 1-1/4" BOLT		12
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		12
05	0503010025	3/8" SPRING WASHER		12
06	0503010026	3/8" NUT		12



Item	Code	Description	See page	QT
01	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		03
02	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		03
03	0521063401	FIXING LOCK		06
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
05	0503010025	3/8" SPRING WASHER		06
06	0503010026	3/8" NUT		06
07	0531054470	3" X 400 SEED NOZZLE WITH FIXING	50	15
08	0531054471	CAP WITH FIXING	51	03




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID		01
02	0501010942	3/8" X 1-1/4" BOLT		05
03	0503010025	3/8" SPRING WASHER		05
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0531063447	CONDUCTOR		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	NUT 5/16 UNC G.5 ZN		02
11	0502012767	SEED NOZZLE FIXER SUPPORT		01
12	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0571015773	SUPPORT SEED		01
02	0501011643	3/8 X 1" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04

LADDER ASSY


0511053356



Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		04
02	0503010237	3/8" X 1" BOLT		08
03	0503010025	3/8" SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0511069636	LADDER		02
06	0503011179	3/8" X 2-1/4" BOLT		04
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
08	0503013357	3/8 SELF-ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521050183	RIGHT GEAR BOX ASSY	55	01
02	0521050184	EXCHANGE LEFT ASSY	57	01
03	0501010243	1/2" X 1-1/2" BOLT		06
04	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
06	0503010019	1/2" SPRING WASHER		10
07	0503012682	1/2" BSW NUT		06
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	66	02
10	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	29	02
11	0511050125	BEARING WITH 17Z GEAR	67	02
12	0511050126	MIDDLE BEARING TRANSMISSION	69	02
13	0511050127	CHAIN TENSIONER SUPPORT	71	02
14	0501055112	MICRO GRANULATED CHAIN TENSIONER	72	02
15	0561014215	BEARING COVER LOWER ROW FRAME		02
16	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		02
17	0503013073	40-1 CHAIN X 75 LINK + MENDING		02
18	0503013114	40-1 CHAIN X 89 LINK + MENDING		02
19	0503012390	40-1 CHAIN X 93 LINK + MENDING		02
20	0503013074	40-1 CHAIN X 130 LINK + REDUCION		02




Item	Code	Description	See page	QT
01	0521050183	RIGHT GEAR BOX ASSY	55	01
02	0521050184	EXCHANGE LEFT ASSY	57	01
03	0501010243	1/2" X 1-1/2" BOLT		06
04	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
06	0503010019	1/2" SPRING WASHER		10
07	0503012682	1/2" BSW NUT		06
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	66	02
10	0511050125	BEARING WITH 17Z GEAR	67	02
11	0501055112	MICRO GRANULATED CHAIN TENSIONER	72	02
12	0561014215	BEARING COVER LOWER ROW FRAME		02
13	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		02
14	0503013073	40-1 CHAIN X 75 LINK + MENDING		02
15	0503012390	40-1 CHAIN X 93 LINK + MENDING		02

RIGHT GEAR BOX ASSY

0521050183




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	56	01
02	0511059266	CLOSED BEARING	59	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	61	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	63	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	64	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	65	01
23	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERMEDIATE AXLE		01
30	0511065209	20Z GEAR		01



Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01

EXCHANGE LEFT ASSY


0521050184




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	58	01
02	0511059266	CLOSED BEARING	59	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	61	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	63	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	64	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	65	01
23	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERMEDIATE AXLE		01
30	0511065209	20Z GEAR		01

LH GEAR BOX


0501058213




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	60	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	ROLLER BEARING	62	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX SUPPORT		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011978	CENTRAL BEARING GEARBOX		01
02	0503013462	6005 2RS1 ROLLER BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0541011713	TENSIONER CHAIN LOWER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501056573	17Z GEAR ASSY	68	01
02	0521010454	0.83" X 1.25" X 0.79" SLEEVE		01
03	0503010741	1/2" X 2-3/4" BOLT		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0511063266	INTERMEDIARY BEARING SUPPORT		01
02	0501052759	GEARBOX BEARING ASSY	70	02
03	0531013674	INTERMEDIATE AXLE		01
04	0541011184	1.1" X 2" X 0.7" SLEEVE		01
05	0503010292	701164 6 X 40 SPRING PIN		02
06	0511063268	20Z P1/2" GEAR FOR HEX AXLE, 1"		01
07	0511063267	26Z P1/2" GEAR FOR HEX AXLE, 1"		01
08	0503010371	5/16" X 1" BOLT		02
09	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
11	0503010337	NUT 5/16 UNC G.5 ZN		02
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		06
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
14	0503010025	3/8" SPRING WASHER		06
15	0503010026	3/8" NUT		06




Item	Code	Description	See page	QT
01	0502011697	GEARBOX SUPPORT		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01



Item	Code	Description	See page	QT
01	0561015677	CHAIN TIGHTENER AXLE		01
02	0501010452	5/8" X 5" BOLT		01
03	0521069698	GEAR 21Z P 1/2		01
04	0503011410	ROLLER BEARING		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01
08	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		02




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0531059698	RIGHT HOPPER SUPPORT WITH FERTILIZER 74	74	01
02	0531059706	LEFT HOPPER SUPPORT WITH FERTILIZER 75	75	01
03	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		02
04	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		01
05	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02
06	0581010029	FERTILIZER HOPPER CLAMP		02
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0501010984	10,50 X 27 X 3,00 FLAT WASHER		40
09	0503010025	3/8" SPRING WASHER		20
10	0503010026	3/8" NUT		20
11	0551019156	GEAR BOX LEVER LOCK		02
12	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
13	0503011953	5/16" X 1" BOLT		04
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
15	0503010337	NUT 5/16 UNC G.5 ZN		04
16	0551019168	SLEEVE		02
17	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
18	0503010479	BOLT		02
19	0503011336	1/2" HEX SELF ADJUSTING NUT		06
20	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		06
21	0503010140	1/8" X 3/4" SPLIT PIN		06
22	0561016468	FASTENER		02
23	0551019159	LEVER FIXER BODY		02
24	0521061742	RH LOWER LEVER		01
25	0521061743	LH LOWER LEVER		01
26	0501310821	ARM/DISARM LEVER		02
27	0503010019	1/2" SPRING WASHER		02
28	0503010060	1/2 UNC G.5 ZN HEX NUT		02
29	0521061741	INTERMEDIATE LEVER		01
30	0531064366	INTERMEDIATE LEVER ARM/DISARM ALPHA		01




Item	Code	Description	See page	QT
31	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		02




Item	Code	Description	See page	QT
01	0531055319	ALPHA II FERTILIZER METERING	76	07
02	0501053788	3/4" SQUARE AXLE FASTENER	81	06
03	0503031527	AGRICULTURAL BEARING		06
04	0531066007	RIGHT HOPPER SUPPORT - 5745		01
05	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	82	01
06	0531057908	SLEEVE 1/4 X 2		07
06A	0502013069	SLEEVE 21 X 38 X 50		07
06B	0503010010	1/4" X 2.1/2" SPLIT PIN		07
07	0501218691	3/4 X 6,53/6,61 AXLE WITH HOLE		01
08	0501218692	3/4 X 13,11/13,18 AXLE		01
09	0501218487	3/4 X 390 AXLE		06




Item	Code	Description	See page	QT
01	0531055319	ALPHA II FERTILIZER METERING	76	07
02	0501053788	3/4" SQUARE AXLE FASTENER	81	06
03	0503031527	AGRICULTURAL BEARING		06
04	0531066006	LEFT HOPPER SUPPORT - 5745		01
05	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	82	01
06	0531057908	SLEEVE 1/4 X 2		07
06A	0502013069	SLEEVE 21 X 38 X 50		07
06B	0503010010	1/4" X 2.1/2" SPLIT PIN		07
07	0501218691	3/4 X 6,53/6,61 AXLE WITH HOLE		01
08	0501218692	3/4 X 13,11/13,18 AXLE		01
09	0501218487	3/4 X 390 AXLE		06



Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	TRANSMISSION HUB ASSY	77	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	78	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513010692	ALLEN SCREW 1/4 UNC X 7/8 C FLAT SI INOX		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501312601	FRONT COVER		01
19	0503036177	LID CORD		01
20	0531059139	COLLECTOR ASSY	79	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO DECAL		01
15	0503035316	LUBRICATED POINTS DECAL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT FERTILIZER METERING LID GUIDE		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01

COLLECTOR ASSY


0531059139




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	80	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007		02
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0503010337	NUT 5/16 UNC G.5 ZN		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0531057901	GEAR	83	01
07	0503010845	501035 CLAMPING RING (FOR AXLE)		01
08	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531065402	GEAR		01
02	0503013958	1/4" X 1" BOLT		02



Item	Code	Description	See page	QT
01	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		04
02	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
03	0581010029	FERTILIZER HOPPER CLAMP		02
04	0503010849	3/8" X 1-1/2" BOLT		28
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		56
06	0503010025	3/8" SPRING WASHER		28
07	0503010026	3/8" NUT		28
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0521066514	FERTILIZER HOPPER MOBILE SUPPORT		02
10	0502010891	SPRING ROD SUPPORT CHOCK		02
11	0503030678	BOLT 1/2 UNC X 1.1/2 C50 G.5 ZN		04
12	0531059780	RIGHT HOPPER SUPPORT WITH FERTILIZER 85 METERING ALPHA II WITHOUT TRANSMISSION - 6645		01
13	0531059781	LEFT HOPPER SUPPORT WITH FERTILIZER 86 METERING ALPHA II WITHOUT TRANSMISSION - 6645		01




Item	Code	Description	See page	QT
01	0501053788	3/4" SQUARE AXLE FASTENER	81	02
02	0503031527	AGRICULTURAL BEARING		02
03	0531055319	ALPHA II FERTILIZER METERING	76	08
04	0531066031	RIGHT HOPPER SUPPORT - 6645		01
05	0531059058	DOUBLE GEAR BEARING SET	87	01
06	0503030119	LOCK PIN		01
07	0531057908	SLEEVE 1/4 X 2		07
07A	0502013069	SLEEVE 21 X 38 X 50		07
07B	0503010010	1/4" X 2.1/2" SPLIT PIN		07
08	0501310891	3/4" X 14,17" SQUARE AXLE		01
09	0501311022	3/4" X 22,71" SQUARE AXLE WITH HOLE		01
10	0501310661	3/4" X 15,35"/15,27" AXLE		06




Item	Code	Description	See page	QT
01	0501053788	3/4" SQUARE AXLE FASTENER	81	02
02	0503031527	AGRICULTURAL BEARING		02
03	0531055319	ALPHA II FERTILIZER METERING	76	08
04	0531066032	LEFT HOPPER SUPPORT - 6645		01
05	0531059058	DOUBLE GEAR BEARING SET	87	01
06	0503030119	LOCK PIN		01
07	0531057908	SLEEVE 1/4 X 2		07
07A	0502013069	SLEEVE 21 X 38 X 50		07
07B	0503010010	1/4" X 2.1/2" SPLIT PIN		07
08	0501310891	3/4" X 14,17" SQUARE AXLE		01
09	0501311022	3/4" X 22,71" SQUARE AXLE WITH HOLE		01
10	0501310661	3/4" X 15,35"/15,27" AXLE		06

DOUBLE GEAR BEARING SET

0531059058




Item	Code	Description	See page	QT
01	0531057912	DOUBLE SIDE BEARING	88	01
02	0501219987	SIDE BEARING AXLE		01
03	0503010845	501035 CLAMPING RING (FOR AXLE)		01
04	0503010337	NUT 5/16 UNC G.5 ZN		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
07	0503010371	5/16" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0502013071	SIDE BEARING		01
02	0503016065	ROLLER BEARING		02
03	0503011800	SEAL RING		01

DRAWBAR

0511054350



Item	Code	Description	See page	QT
01	0502012328	DRAWBAR SUPPORT FRONT FIXATION		04
02	0502012330	SUPPORT FIXER PIVOT		04
03	0503011084	3/4" X 5" BOLT		08
04	0503010023	3/4" SPRING WASHER		08
05	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		08
06	0502012329	DRAWBAR FIXATION REAR SUPPORT		04
07	0502012330	SUPPORT FIXER PIVOT		04
08	0503011084	3/4" X 5" BOLT		08
09	0503010023	3/4" SPRING WASHER		08
10	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		08
11	0561014393	COUPLING SHAFT		04
12	0503010523	1/4 X 2 SPLIT PIN		04
13	0503030119	LOCK PIN		04
14	0511062824	DRAWBAR		00
15	0561019087	DRAWBAR TRANSPORT LOCK		01
16	0521010578	COUPLING SHAFT		01
17	0521010582	COUPLING SHAFT		01
18	0503030085	LOCK PIN		02
19	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503033909	ADHESIVE LABEL		03
02	0503033854	TATU LOGO DECAL		03
03	0503033853	SIDE TATU LOGO DECAL		02
04	0503033008	ON/OFF RATCHET DECAL		02
05	0503031087	AUTO CONTROL APPROVED DECAL		01
06	0503032930	DANGER DECAL		06
07	0503035927	P27 FERTILIZER TABLE DECAL		02
08	0503031942	MANUAL SEAL DECAL		01
09	0503033012	RIGHT GEAR BOX SEED/FERTILIZER DECAL		01
10	0503033013	LEFT GEAR BOX SEED/FERTILIZER DECAL		01
11	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL		02
12	0503031428	ATTENTION READ MANUAL DECAL		01
13	0503031566	ATTENTION JACK DECAL		02
14	0503031565	CAUTION TRANSPORTATION DECAL		02
15	0503031424	ATTENTION HYDRAULIC MARKER DECAL		02
16	0503031565	CAUTION TRANSPORTATION DECAL		02
17	0503034249	PLANTERS TABLE DECAL		02
18	0503033419	NUMBER 5 DECAL		04
19	0503033421	NUMBER 7 DECAL		02
20	0503033418	NUMBER 4 DECAL		02
21	0503032979	LETTERS A B C D DECAL		02
22	0503032949	ATTENTION 3 LANGUAGES DECAL		01



Item	Code	Description	See page	QT
01	0503033909	ADHESIVE LABEL		04
02	0503033854	TATU LOGO DECAL		04
03	0503033853	SIDE TATU LOGO DECAL		02
04	0503033418	NUMBER 4 DECAL		02
05	0503033419	NUMBER 5 DECAL		02
06	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING		04
07	0503031087	AUTO CONTROL APPROVED DECAL		01
08	0503032930	DANGER DECAL		06
09	0503031942	MANUAL SEAL DECAL		01
10	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL		02
11	0503031428	ATTENTION READ MANUAL DECAL		01
12	0503031566	ATTENTION JACK DECAL		02
13	0503031565	CAUTION TRANSPORTATION DECAL		02
14	0503032949	ATTENTION 3 LANGUAGES DECAL		01
15	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		02
16	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		01
17	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		02
18	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02




Item	Code	Description	See page	QT
01	0503033909	ADHESIVE LABEL		04
02	0503033854	TATU LOGO DECAL		04
03	0503033853	SIDE TATU LOGO DECAL		02
04	0503033418	NUMBER 4 DECAL		02
05	0503033419	NUMBER 5 DECAL		04
06	0503033421	NUMBER 7 DECAL		02
07	0503033008	ON/OFF RATCHET DECAL		02
08	0503031087	AUTO CONTROL APPROVED DECAL		01
09	0503032930	DANGER DECAL		06
10	0503035927	P27 FERTILIZER TABLE DECAL		02
11	0503031942	MANUAL SEAL DECAL		01
12	0503033012	RIGHT GEAR BOX SEED/FERTILIZER DECAL		01
13	0503033013	LEFT GEAR BOX SEED/FERTILIZER DECAL		01
14	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL		02
15	0503031428	ATTENTION READ MANUAL DECAL		01
16	0503031566	ATTENTION JACK DECAL		02
17	0503031424	ATTENTION HYDRAULIC MARKER DECAL		02
18	0503031565	CAUTION TRANSPORTATION DECAL		02
19	0503032979	LETTERS A B C D DECAL		02
20	0503032949	ATTENTION 3 LANGUAGES DECAL		01




Item	Code	Description	See page	QT
01	0503060100	SUPPORT INSTRUCTION MANUAL		01
02	0503010267	NYLON CLAMP 3,60 X 1,3 X 155 MM		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER 32,50 X 75 X 4,75		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	NUT 5/16 UNC G.5 ZN		01

JACK ASSEMBLY


0511054971




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0581011414	UPPER RIGHT SUPPORT		01
02	0581011413	UPPER LEFT SUPPORT		01
03	0503011239	1/2" X 2" BOLT		08
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0581011415	SUPPORTER FIXING BAR		01
07	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
08	0503010019	1/2" SPRING WASHER		04
09	0503010060	1/2 UNC G.5 ZN HEX NUT		04
10	0503011267	BOLT 5/8" UNC X 1.1/2 C S G.5 ZN		02
11	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		02
12	0503012412	5/8" UNC SELF LOCKING NUT		02
13	0561011377	4" X 86.60" HOSE		02
14	0571013731	VACUUM GAUGE SUPPORT		01
15	0503013584	VACUUM GAUGE		01
16	0511059319	AIR FIXING SUPPORT	97	04
17	0511057785	VACUUM DISTRIBUTOR	98	02
18	0503031576	ELBOW		02
19	0503015062	TUBE		03
20	0511057906	HOSE ASSY	99	01
21	0511059406	TURBINE PP MOUNTED	101	01




Item	Code	Description	See page	QT
01	0581011414	UPPER RIGHT SUPPORT		01
02	0581011413	UPPER LEFT SUPPORT		01
03	0503011239	1/2" X 2" BOLT		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0581011415	SUPPORTER FIXING BAR		01
07	0503011082	C1/2" X 1.3/4" SCREW		04
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
09	0503010019	1/2" SPRING WASHER		04
10	0503010060	1/2 UNC G.5 ZN HEX NUT		04
11	0503011267	BOLT 5/8" UNC X 1.1/2 C S G.5 ZN		02
12	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		02
13	0503012412	5/8" UNC SELF LOCKING NUT		02
14	0561011377	4" X 86.60" HOSE		02
15	0503011372	102 TO 121 CLAMP		02
16	0503015062	TUBE		03
17	0503013584	VACUUM GAUGE		01
18	0511059319	AIR FIXING SUPPORT	97	06
19	0511059090	VACUUM 8B LEFT DISTRIBUTOR		02
20	0571013731	VACUUM GAUGE SUPPORT		01
21	0511057906	HOSE ASSY	99	01
21A	0511057840	ASSY TURBINE HOSE REAR		01
21B	0501053834	MALE QUICK COUPLER	35	02
21BA	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
21BB	0503011882	MALE QUICK COUPLER CAP		01
21C	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
21D	0503033981	PRESSURE FREE RETAINER FOR TANK DECAL		01
21E	0521050537	FEMALE QUICK HITCH WITH TURBINE HYDRAULIC 100 DRAIN		01
21EA	0503018799	QUICK COUPLING		01
21EB	0503011883	PLASTIC COVER		01
22	0511059406	TURBINE PP MOUNTED	101	01




Item	Code	Description	See page	QT
01	0571019403	STAPLE FIXER		01
02	0503010025	3/8" SPRING WASHER		04
03	0503010026	3/8" NUT		04
04	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		02
05	0571019921	AIR SUPPORT FIXATION		01
06	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0571019982	BODY DISTRIBUTOR VACUUM		01
02	0503012566	COVER KAP 110 YELLOW		01
03	0571017215	AIR DISTRIBUTOR SOCKET		01
04	0503012856	POP RIVET		14
05	0503031943	SOCKET		07




Item	Code	Description	See page	QT
01	0511057840	ASSY TURBINE HOSE REAR		01
01A	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
01AA	0501081247	HOSE 1/2 X 7012 TC-TM		01
01AB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
01B	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01
01BA	0501081247	HOSE 1/2 X 7012 TC-TM		01
01BB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
01C	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
01CA	0501080477	3/8" X 276" TC-TM HOSE		01
01CB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01CC	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
01CD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	35	02
03	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
04	0503033981	PRESSURE FREE RETAINER FOR TANK DECAL		01
05	0521050537	FEMALE QUICK HITCH WITH TURBINE HYDRAULIC 100 DRAIN		01




Item	Code	Description	See page	QT
01	0503018799	QUICK COUPLING		01
02	0503011883	PLASTIC COVER		01




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		04
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0581012096	ROUND SLEEVE		02
06	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
07	0521050154	PRECISION PLANTING TURBINE WITH HOLE	102	01
08	0503031087	AUTO CONTROL APPROVED DECAL		01
09	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
10	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
11	0503010143	1/4" SPRING WASHER		02
12	0503010144	1/4" NUT		02
13	0503010190	2-114 N 3006-9B O'RING		04
14	0501081235	1/2 X 650 TR- TC HOSE		01
15	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01



Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	1.1/2" RIGHT LOCK-NUT		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	SCREW ASSY		01
05	0501011301	1.1/2" UNC 6FPP 2.5/16" NUT		01
06	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2" SPLIT PIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01

CLAMP


0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	SELF-LOCKING HEX NUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0503063619	14 ROWS SEED MONITORING KIT 45/50 PM400		01
01A	0513010217	14 ROWS CABLE FOR MESH SEED		01
01B	0503019100	ISOBUS PHOTOELECTRIC SENSOR		14
01C	0503017602	MONITOR PLANTING PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
01E	0503017031	CLEAN BRUSH		01
01F	0503019720	NYLON CLAMP		01
02	0503016234	FIXING VACUUM TRIMBLE 91357-AG		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010669	FLAT WASHER 5 X 11 X 1,00 ZN		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0521066608	LIFTING HOOK		01
02	0581019707	FIXATION SUPPORT SUPPORT		01
03	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
04	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
05	0503012412	5/8" UNC SELF LOCKING NUT		04




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		12
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		12
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		13
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		13
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		15
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		15
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531057126	KIT CABIN SEEDSENSE GEN3		001
01A	0503063047	MONITOR KIT		001
01B	0503019536	MODULE		001
01C	0503063204	KIT BASE		001
01D	0503019759	WHIP		001
01E	0503017972	TRACTOR BATTERY WHIP		001
01F	0503017973	ENERGY DISTRIBUTOR MODULE		001
01G	0503016452	FIXING SUPPORT AG500 TRIMBLE		001
01H	0503016234	FIXING VACUUM TRIMBLE 91357-AG		001
01I	0503019424	WHIP JD STARFIRE GPS		001
01J	0503018055	WHIP ADAPTER		001
01K	0513011194	TRIMBLE ADAPTER HARNESS GFX PP-727068		001
01L	0513011695	HARNESS ADAPTER CABLE		001
01M	0503018098	BATTERY HARNESS 3 ROUND PINS 725254		001
01N	0503017986	WHIP BATTERY FOR PLUG		001
01O	0513012252	PLUG ADAPTER DIN EUROPEIA 725719		001
01P	0503018653	ADAPTER WHIP		001
02	0503017992	SRM MAIN WHIP - 8 LINES 45/55 729468		001
03	0503018061	SRM MAIN WHIP - 7 LINES		001
04	0503018080	EXTENSION CABLE		001
05	0503062454	TRACTOR CONNECTION ASSY		001
06	0503018085	APEX EXTENSION CABLE		002
07	0503019291	SUPPORT SENSOR		001
08	0513010031	EXTERNAL LIFTING CABLE PSS-X1005B CAN-5M		001
09	0513010275	PP725905 VACUUM SENSOR		002
10	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		225
11	0503013100	NYLON CLAMP 4,8 X 1,3 X 200 MM		075
12	0503017975	WHIP		015
13	0503019755	UNIT MODULE		015
14	0503019776	SEED TUBE WITH WAVE VISION SENSOR		015
15	0503062431	ELECTRIC MOTOR		015



Item	Code	Description	See page	QT
01	0531057344	FULL PDM SUPPORT	114	01
02	0591015101	LIFT SENSOR SUPPORT		01
03	0503013356	RIVET POP 3,2 X 10,0		01
04	0531050766	SENSOR ACTUATOR	119	01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		30
06	0501010694	FLAT WASHER 32,50 X 75 X 4,75		30
07	0503011953	5/16" X 1" BOLT		30
08	0503010337	NUT 5/16 UNC G.5 ZN		30
09	0503010143	1/4" SPRING WASHER		15
10	0503010743	1/4" X 1-1/4" BOLT		15
11	0531054926	SRM MODULE SUPPORT WITH RIVET		15
11A	0501213785	SUPPORT PLATE MODULE		01
11B	0503019901	INTERNAL THREAD RIVET RM 1/4 P30S		01




Item	Code	Description	See page	QT
01	0501216846	PDM SUPPORT		01
02	0503013357	3/8 SELF-ADJUSTING NUT		08
03	0503011776	SELF-LOCKING HEX NUT		04
04	0501217768	PDM LOCK SUPPORT		01
05	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		08
06	0501017709	STUD		04




Item	Code	Description	See page	QT
01	0521050273	MOTOR SUPPORT SEED	116	02
02	0571017777	SUPPORT FILTER		01
03	0502011558	FASTENER		03
04	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		02
05	0503010023	3/4" SPRING WASHER		06
06	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		06
07	0511056294	ASSY MODULE BOX	117	01
08	0531064728	FERTILIZER HYDRAULIC MOTOR SUPPORT		02
09	0503011198	BOLT 3/4" UNC X 6" CS G.5		04
10	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
11	0503011082	C1/2" X 1.3/4" SCREW		02
12	0503010019	1/2" SPRING WASHER		06
13	0503010060	1/2 UNC G.5 ZN HEX NUT		06
14	0571012767	ENCODER SUPPORT		02
15	0501111116	MOTOR GEAR		02
16	0503062754	GEAR 34Z P.1/2 APT		02
17	0503015162	M 8 X 1,25 X 20 BOLT		02
18	0503014911	40-1 X 63 CHAIN LINK + MENDING		02
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
20	0503030402	PULLEY		02
21	0531019479	AXLE CHAIN GEAR		02
22	0591015101	LIFT SENSOR SUPPORT		01
23	0503013356	RIVET POP 3,2 X 10,0		01
24	0531050766	SENSOR ACTUATOR	119	01
25	0531056635	ASSY HOSE	120	01
26	0501053834	MALE QUICK COUPLER	35	02

MOTOR SUPPORT SEED


0521050273



Item	Code	Description	See page	QT
01	0521067490	HYDRAULIC MOTOR SUPPORT APT		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		03
05	0503010060	1/2 UNC G.5 ZN HEX NUT		03
06	0531019479	AXLE CHAIN GEAR		01
07	0521065328	20Z GEAR WITH HOLE SHAFT HEX 16.5		01
08	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
09	0571012766	SUPPORT ENCODER		01
10	0521064025	TRACTOR HITCH		01
11	0503011082	C1/2" X 1.3/4" SCREW		01
12	0502010175	HITCH CLAMP		01
13	0503010013	5/8 UNC G.5 ZN HEX NUT		02
14	0503010027	5/8 SPRING WASHER		02
15	0501011027	5/8" X 3-3/4" BOLT		02
16	0501011299	FLAT WASHER		02
17	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
18	0503011807	SCREW M8 X 1,25X10		02




Item	Code	Description	See page	QT
001	0511059348	APT ASSY MODULE BOX	118	01
002	0581011428	RIGHT MODULE BOX SUPPORT		01
003	0581011429	SUPPORT LEFT BOX		01
004	0502011558	FASTENER		01
005	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		02
006	0503010023	3/4" SPRING WASHER		02
007	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		02




Item	Code	Description	See page	QT
01	0521066834	MODULE BOX		01
02	0503018171	FAST LOCK ASSY		02
03	0521066833	BOX COVER		01
04	0571012006	COVER PIVOT SHAFT		01
05	0571012005	SUPPORT GUIDE ASSY		01
06	0501010694	FLAT WASHER 32,50 X 75 X 4,75		03
07	0503010257	1/8" X 1" SPLIT PIN		02
08	0511017303	FLAT WASHER		10
09	0503010298	1/4" X 1/2" BOLT		04
10	0503010143	1/4" SPRING WASHER		10
11	0503010294	1/4" X 7/8" BOLT		06
12	0503010144	1/4" NUT		06
13	0501011643	3/8 X 1" BOLT		04
14	0503010025	3/8" SPRING WASHER		04
15	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
16	0503010026	3/8" NUT		04

SENSOR ACTUATOR


0531050766




Item	Code	Description	See page	QT
01	0591015026	LIFTING SENSOR DRIVING BODY		01
02	0561016468	FASTENER		01
03	0503011336	1/2" HEX SELF ADJUSTING NUT		02
04	0591015027	SENSOR DRIVER		01
05	0503010282	1/4" X 3/4" BOLT		01
06	0503010144	1/4" NUT		01
07	0503010143	1/4" SPRING WASHER		01




Item	Code	Description	See page	QT
01	0521052519	1/2 X 4200 TC-TM GRAY/RED HOSE		01
01A	0501081073	1/2 X 4200 TC-TM HOSE		01
01B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
01C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
02	0501080013	1/2 X 850 TR-TC HOSE		01
03	0501080093	1/2" X 51.20" TR-TC HOSE		02
04	0501081276	1/2 X 129,92 TR-TR HOSE		01
05	0521057427	HOSE		01
05A	0501082120	1/2" X 177" TR-TM HOSE ASSY		01
05B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
05C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
05D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0503063187	15 ROWS 450/500 MS ISO 04 CHANNELS INTELLIAG KIT		01
02	0511056972	FILTER HYDAC	122	01
03	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	123	04
04	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		225
05	0503013100	NYLON CLAMP 4,8 X 1,3 X 200 MM		75
06	0503019291	SUPPORT SENSOR		01



Item	Code	Description	See page	QT
01	0503063151	PRESSURE FILTER MFM HYDAC 1319024BR		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	7/8" T ADAPTER		01
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503016506	5/16 UNC X 3/4 C S. G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02



Item	Code	Description	See page	QT
01	0513010049	MOTOR OMP X 80 EMD - 11185907		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02




Item	Code	Description	See page	QT
01	0511057243	LEFT SHORT SEED ROW FRONT	125	01
01.	0511057244	RIGTH SHORT SEED ROW FRONT	126	01
01..	0521050749	FRONT SHORT SEED ROW LEFT	127	01
01...	0521050751	FRONT RIGHT SHORT SEED ROW	128	01
02	0511057246	RIGHT LONG SEED ROW FRONT	129	01
02.	0511057247	LEFT LONG SEED ROW FRONT	130	01
02..	0521050750	FRONT LONG RIGHT SEED ROW	131	01
02...	0521050752	FRONT LONG LEFT SEED ROW	132	01
03	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	140	01
03.	0541054733	SHORT ARM FERTILIZER LINE WITH LEFT DTR	141	01
04	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	147	01
04.	0541054734	LONG ARM FERTILIZER LINE WITH RIGHT DTR	148	01
05	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	152	01
05.	0521044545	20" SHORT CURVED CORRIGATED DISC	153	01
06	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	154	01
06.	0521044546	20" LONG CURVED CORRUGATED DISC		01
07	0511058747	RIGHT REAR SUPREME SEED ROW P.P CSU	157	01
07.	0541054735	REAR RIGHT SEED ROW WITH DISTRIBUTOR PP CSU 3 P/VDRIVE		01
08	0511058748	LEFT REAR SUPREME SEED ROW P.P CSU	158	01
08.	0541054737	REAR LEFT SEED ROW WITH DISTRIBUTOR PP 3 P/VDRIVE		01
09	0531054532	WHEEL SYSTEM DEPTH / COMPACTOR	168	01
10	0511058212	FERTILIZER ROW SUPPORT ASSY	174	01
11	0531059865	RIGHT SEED CONDUCTOR WITH PROTECTION		01
12	0531050237	3" RIGHT SEED CONDUCTOR FIXER	175	01
13	0501058423	FERTILIZER ROD SPRING ROW	176	01
14	0502010175	HITCH CLAMP		01
15	0501011543	5/8" X 4" BOLT		01
16	0503012412	5/8" UNC SELF LOCKING NUT		01

Item	Code	Description	See page	QT
17	0501010066	3/4" X 9" BOLT		01
18	0511017232	FLAT WASHER		01
19	0521017831	SUPPORT SLEEVE SPACER		01
20	0503011255	3/4" LOCK NUT		01
21	0501110231	SCARIFIER ROD WITH TIP	177	01
21.	0521053673	SCARIFIER ROD WITH NOZZLE		01
22	0511017969	0.1" SPACING PLATE		01
23	0521069127	BOTTOM NOZZLE FERTILIZER		01
24	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
25	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
26	0503010025	3/8" SPRING WASHER		01
27	0503010026	3/8" NUT		01
28	0521057957	FIXED ROD EXTENSION WITH FIXATION	178	01
29	0503030483	FERTILIZER NOZZLE		01
30	0503031050	CURVED CONDUCTOR		01
31	0503010246	CLAMP		01
32	0503030391	RIGHT FERTILIZER NOZZLE		01
33	0503030392	LEFT FERTILIZER NOZZLE		01
34	0503031145	2" X 2" X 20" HOSE		01
34.	0503036220	HOSE 60 X 50 X 500		01
35	0503031076	2" HOSE CLAMP		01
35.	0503037049	FERTILIZER NOZZLE CLAMP 50		01
35..	0503037050	FERTILIZER NOZZLE CLAMP 60		01
36	0531013600	PRESS ADJUSTMENT LEVER		01
37	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
38	0503010905	1/2" X 2-1/4" BOLT		01
39	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
40	0503010019	1/2" SPRING WASHER		01
41	0503010060	1/2 UNC G.5 ZN HEX NUT		01
42	0503036268	CURVED CONDUCT		01
43	0513012079	CLAMP		01

LEFT SHORT SEED ROW FRONT


0511057243



Item	Code	Description	See page	QT
01	0521064651	LEFT SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	133	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	NUT 5/16 UNC G.5 ZN		04
10	0502012782	GEAR 17Z		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	134	01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	135	01
14	0511055260	SEED ROW CHAIN TENSIONER	137	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	UPPER ARM		01
22	0521065847	SHORT TIRE SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" SPLIT PIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" SPLIT PIN		01
31	0503034580	TRACTION SPRING		02
32	0511052426	TRANSMISSION CARDAN ASSY	138	01




Item	Code	Description	See page	QT
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	133	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	NUT 5/16 UNC G.5 ZN		04
10	0502012782	GEAR 17Z		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	134	01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	135	01
14	0511055260	SEED ROW CHAIN TENSIONER	137	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	UPPER ARM		01
22	0521065847	SHORT TIRE SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" SPLIT PIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" SPLIT PIN		01
31	0503034580	TRACTION SPRING		02
32	0511052426	TRANSMISSION CARDAN ASSY	138	01




Item	Code	Description	See page	QT
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521064651	LEFT SEED ROW SUPPORT FRONT		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0502012666	SEED ROW LOWER ARM		01
06	0503010003	1845 GREASE FITTING		02
07	0561015858	SPACER LOWER SLEEVE		01
08	0531015151	0.6" X 1" X 2.4" SLEEVE		01
09	0531015184	FLAT WASHER		02
10	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		01
11	0502012350	UPPER ARM		01
12	0503010003	1845 GREASE FITTING		02
13	0531015151	0.6" X 1" X 2.4" SLEEVE		02
14	0531015184	FLAT WASHER		02
15	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		01
16	0521065847	SHORT TIRE SEED ROW FRAME		01
17	0531015151	0.6" X 1" X 2.4" SLEEVE		04
18	0531015184	FLAT WASHER		04
19	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		02
20	0502012568	UPPER ROCKER ARM		01
21	0561019032	SEED FERTIL ROW LOCK		01
22	0501011388	COUPLING SHAFT		02
23	0503010071	3/16" X 1" SPLIT PIN		01
24	0503030168	HITCH PIN CLIP		01
25	0581018487	FIXER UPPER SPRING		01
26	0521010773	0.37" X 1.18" COUPLING SHAFT		01
27	0503010140	1/8" X 3/4" SPLIT PIN		01
28	0503034580	TRACTION SPRING		02
29	0503012412	5/8" UNC SELF LOCKING NUT		04
30	0503062430	SRM LINE ASSEMBLY		01




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0502012666	SEED ROW LOWER ARM		01
06	0503010003	1845 GREASE FITTING		02
07	0561015858	SPACER LOWER SLEEVE		01
08	0531015151	0.6" X 1" X 2.4" SLEEVE		01
09	0531015184	FLAT WASHER		02
10	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		01
11	0502012350	UPPER ARM		01
12	0503010003	1845 GREASE FITTING		02
13	0531015151	0.6" X 1" X 2.4" SLEEVE		02
14	0531015184	FLAT WASHER		02
15	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		01
16	0521065847	SHORT TIRE SEED ROW FRAME		01
17	0531015151	0.6" X 1" X 2.4" SLEEVE		04
18	0531015184	FLAT WASHER		04
19	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		02
20	0502012568	UPPER ROCKER ARM		01
21	0561019032	SEED FERTIL ROW LOCK		01
22	0501011388	COUPLING SHAFT		02
23	0503010071	3/16" X 1" SPLIT PIN		01
24	0503030168	HITCH PIN CLIP		01
25	0581018487	FIXER UPPER SPRING		01
26	0521010773	0.37" X 1.18" COUPLING SHAFT		01
27	0503010140	1/8" X 3/4" SPLIT PIN		01
28	0503034580	TRACTION SPRING		02
29	0503012412	5/8" UNC SELF LOCKING NUT		04
30	0503062430	SRM LINE ASSEMBLY		01



Item	Code	Description	See page	QT
01	0521064652	RH SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	133	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	NUT 5/16 UNC G.5 ZN		04
10	0502012782	GEAR 17Z		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	134	01
12	0561814904	ROW FRAME TRANSMISSION AXLE		01
13	0501052769	BEARING WITH 17Z GEAR		01
14	0511055260	SEED ROW CHAIN TENSIONER	137	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	UPPER ARM		01
22	0521065847	SHORT TIRE SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" SPLIT PIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" SPLIT PIN		01
31	0503034580	TRACTION SPRING		02
32	0511052426	TRANSMISSION CARDAN ASSY	138	01




Item	Code	Description	See page	QT
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064650	LEFT SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	133	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	NUT 5/16 UNC G.5 ZN		04
10	0502012782	GEAR 17Z		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	134	01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	135	01
14	0511055260	SEED ROW CHAIN TENSIONER	137	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	UPPER ARM		01
22	0521065847	SHORT TIRE SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" SPLIT PIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" SPLIT PIN		01
31	0503034580	TRACTION SPRING		02
32	0511052426	TRANSMISSION CARDAN ASSY	138	01




Item	Code	Description	See page	QT
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521064652	RH SEED ROW SUPPORT FRONT		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0502012666	SEED ROW LOWER ARM		01
06	0503010003	1845 GREASE FITTING		02
07	0561015858	SPACER LOWER SLEEVE		01
08	0531015151	0.6" X 1" X 2.4" SLEEVE		01
09	0531015184	FLAT WASHER		02
10	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		01
11	0502012350	UPPER ARM		01
12	0503010003	1845 GREASE FITTING		02
13	0531015151	0.6" X 1" X 2.4" SLEEVE		02
14	0531015184	FLAT WASHER		02
15	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		01
16	0521065847	SHORT TIRE SEED ROW FRAME		01
17	0531015151	0.6" X 1" X 2.4" SLEEVE		04
18	0531015184	FLAT WASHER		04
19	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		02
20	0502012568	UPPER ROCKER ARM		01
21	0561019032	SEED FERTIL ROW LOCK		01
22	0501011388	COUPLING SHAFT		02
23	0503010071	3/16" X 1" SPLIT PIN		01
24	0503030168	HITCH PIN CLIP		01
25	0581018487	FIXER UPPER SPRING		01
26	0521010773	0.37" X 1.18" COUPLING SHAFT		01
27	0503010140	1/8" X 3/4" SPLIT PIN		01
28	0503034580	TRACTION SPRING		02
29	0503012412	5/8" UNC SELF LOCKING NUT		04
30	0503062430	SRM LINE ASSEMBLY		01




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521064650	LEFT SEED ROW SUPPORT FRONT		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0502012666	SEED ROW LOWER ARM		01
06	0503010003	1845 GREASE FITTING		02
07	0561015858	SPACER LOWER SLEEVE		01
08	0531015151	0.6" X 1" X 2.4" SLEEVE		01
09	0531015184	FLAT WASHER		02
10	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		01
11	0502012350	UPPER ARM		01
12	0503010003	1845 GREASE FITTING		02
13	0531015151	0.6" X 1" X 2.4" SLEEVE		02
14	0531015184	FLAT WASHER		02
15	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		01
16	0521065847	SHORT TIRE SEED ROW FRAME		01
17	0531015151	0.6" X 1" X 2.4" SLEEVE		04
18	0531015184	FLAT WASHER		04
19	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		02
20	0502012568	UPPER ROCKER ARM		01
21	0561019032	SEED FERTIL ROW LOCK		01
22	0501011388	COUPLING SHAFT		02
23	0503010071	3/16" X 1" SPLIT PIN		01
24	0503030168	HITCH PIN CLIP		01
25	0581018487	FIXER UPPER SPRING		01
26	0521010773	0.37" X 1.18" COUPLING SHAFT		01
27	0503010140	1/8" X 3/4" SPLIT PIN		01
28	0503034580	TRACTION SPRING		02
29	0503012412	5/8" UNC SELF LOCKING NUT		04
30	0503062430	SRM LINE ASSEMBLY		01



Item	Code	Description	See page	QT
01	0502012718	ROW BEARING		01
02	0503012882	BEARING		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6 X 1 X 16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS DECAL		01




Item	Code	Description	See page	QT
01	0511050617	FRONT SEED ROW BEARING	136	01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0502012819	GEAR 17Z		01

FRONT SEED ROW BEARING


0511050617




Item	Code	Description	See page	QT
01	0502011697	GEARBOX SUPPORT		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511052389	BEARING DOUBLE FRONT ROW SEED	139	01
02	0551017559	BEARING AXLE BODY		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0551017540	5/8" X 73 AXLE HEX		01
05	0501056296	UNIVERSAL JOINT		01
06	0503011855	0.2" X 1.8" SPRING PIN		03
07	0571012412	HEX AXLE		01
08	0561014778	HEX UNIVERSAL JOINT		01
09	0503013958	1/4" X 1" BOLT		02



Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	150	01




Item	Code	Description	See page	QT
01	0521061121	SHORT FERTILIZER ROW ARM		01
02	0521055869	LEFT DUAL FERTILIZER DISC	142	01
03	0511018662	SPACING PLATE		04
04	0503010547	1/2" X 4" BOLT		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2 UNC G.5 ZN HEX NUT		02

LEFT DUAL FERTILIZER DISC


0521055869




Item	Code	Description	See page	QT
01	0502011161	SUPPORT DDD 15 X 15 LEFT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8" SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 143 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 144 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055864	FERTILIZER/SEED RIGHT HUB ASSY	145	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055865	FERTILIZER/SEED LEFT HUB ASSY	146	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUBLE DISC AXLE		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061153	FERTILIZER ROW LONG ARM		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	151	01




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC	149	01
02	0521061153	FERTILIZER ROW LONG ARM		01
03	0511018662	SPACING PLATE		04
04	0503010547	1/2" X 4" BOLT		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8" SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 143 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 144 FERTILIZER / SEED		01



Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	166	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	167	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	SUPPORT DDD 15 X 15 LEFT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8" SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	167	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	166	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02



Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
03	0541018684	FLAT WASHER		01
04	0503010756	0.2" X 2.4" SPRING PIN		01
05	0503010361	SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521014137	RIGHT ARM BLADE DISC		01
08	0521014138	LEFT DISC BLADE ARM		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503013185	BOLT 3/4" UNC X 5.1/2" C S G.7 ZN		01
12	0503011255	3/4" LOCK NUT		01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
14	0503011411	1/2" X 5-1/2" BOLT		01
15	0503010019	1/2" SPRING WASHER		01
16	0503010060	1/2 UNC G.5 ZN HEX NUT		01
17	0502020393	SPRING UPPER SUPPORT		01
18	0502020394	SPRING SUPPORT		01
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
20	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		02
21	0521054680	20" DISC BLADE HUB	155	01


20" SHORT CURVED CORRIGATED DISC

0521044545




Item	Code	Description	See page	QT
01	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
02	0502012368	BLADE DISC SUPPORT AXLE		01
03	0541018684	FLAT WASHER		01
04	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
05	0503010756	0.2" X 2.4" SPRING PIN		01
06	0503010361	SPRING PIN		01
07	0521014137	RIGHT ARM BLADE DISC		01
08	0521014138	LEFT DISC BLADE ARM		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		01
12	0503011255	3/4" LOCK NUT		01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
14	0503011411	1/2" X 5-1/2" BOLT		01
15	0503011440	SPRING WASHER		01
16	0503010060	1/2 UNC G.5 ZN HEX NUT		01
17	1902020393	SPRING UPPER SUPPORT		01
18	0502020394	SPRING SUPPORT		01
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
20	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		02
21	0511054673	DPLO20		01
21A	0502011562	DISC BLADE HUB		01
21B	0503010276	6206 BALL BEARING		02
21C	0521013610	BLADE DISC HUB AXLE		01
21D	0503030832	FLAT WASHER		02
21E	0503012417	SEAL		02
21F	0503011800	SEAL RING		02
21G	0503010691	1/4" GREASE FITTING		01
21H	0607026025	DPLO20X4,5		01
21I	0502020641	BLADE DISC FLANGE		01
21J	0503010371	5/16" X 1" BOLT		06
21K	0503011444	SPRING WASHER 5/16"		06

Item	Code	Description	See page	QT
21L	0503010337	NUT 5/16 UNC G.5 ZN		06
22	0521015376	DUST CLOAK		02
23	0511015346	FLAT WASHER		06
24	0503011438	SPRING WASHER		02
25	0521013510	3/4" NUT		02
26	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0511067044	LONG DISC BLADE FIXING AXIS		01
03	0541018684	FLAT WASHER		01
04	0503010756	0.2" X 2.4" SPRING PIN		01
05	0503010361	SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521014137	RIGHT ARM BLADE DISC		01
08	0521014138	LEFT DISC BLADE ARM		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503013185	BOLT 3/4" UNC X 5.1/2" C S G.7 ZN		01
12	0503011255	3/4" LOCK NUT		01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
14	0503011411	1/2" X 5-1/2" BOLT		01
15	0503010019	1/2" SPRING WASHER		01
16	0503010060	1/2 UNC G.5 ZN HEX NUT		01
17	0502020393	SPRING UPPER SUPPORT		02
18	0502020394	SPRING SUPPORT		01
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
20	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		02
21	0521054680	20" DISC BLADE HUB	155	01




Item	Code	Description	See page	QT
01	0521054679	DISC BLADE HUB	156	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01

DISC BLADE HUB


0521054679




Item	Code	Description	See page	QT
01	0502011562	DISC BLADE HUB		01
02	0502020641	BLADE DISC FLANGE		01
03	0503010276	6206 BALL BEARING		02
04	0521013610	BLADE DISC HUB AXLE		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
06	0503012417	SEAL		02
07	0503011800	SEAL RING		02
08	0503010691	1/4" GREASE FITTING		01
09	0521015376	DUST CLOAK		02
10	0503030832	FLAT WASHER		02
11	0511015346	FLAT WASHER		02
12	0521013510	3/4" NUT		02
13	0503010012	1" SPRING WASHER		02
14	0503010371	5/16" X 1" BOLT		06
15	0503010337	NUT 5/16 UNC G.5 ZN		06




Item	Code	Description	See page	QT
01	0521050737	PNEUMATIC SEED DISTRIBUTOR	159	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	RIGHT DDD	164	01



Item	Code	Description	See page	QT
01	0521050737	PNEUMATIC SEED DISTRIBUTOR	159	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8" SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT	165	01




Item	Code	Description	See page	QT
01	0511057212	3 CSU PRECISION PLANTING V-SET2 ASSY	160	01
02	0581012756	HEX AXLE 5/8 X 360		01




Item	Code	Description	See page	QT
01	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
02	0571017899	PIN LOCK		01
03	0503030190	0.5" X 1.6" X 0.05" SPRING		01
04	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
05	0511057155	PRECISION PLANTING LEFT TRANSMISSION 161 HOPPER		01
06	0571017894	PIN DRAG PRECISION PLANTING		01
07	0503013357	3/8 SELF-ADJUSTING NUT		01
08	0501013518	FLAT WASHER 10,50 X 24 X 1,50 ZN		02
09	0503015356	SPRING PIN		01
10	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
11	0571017895	PIN FIXER CONDUCTOR P.P		01
12	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
13	0503010293	CLAMP KNOB		02
14	0503010140	1/8" X 3/4" SPLIT PIN		02
15	0503010131	3/16" X 1.1/2" SPLIT PIN		01
16	0503010025	3/8" SPRING WASHER		02
17	0571019491	SLUICE PNEUMATIC		01
18	0501011643	3/8 X 1"BOLT		01
19	0503010209	3/8" UNC BUTTERFLY NUT		01
20	0502012807	SUPPORT HOPPER PRECISION PLANTING		01
21	0571019489	CLAMP PRECISION PLANTING		01
22	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
23	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 162 DISC		01
24	0561014778	HEX UNIVERSAL JOINT		01
25	0503013958	1/4" X 1" BOLT		02
26	0503011855	0.2" X 1.8" SPRING PIN		01
27	0503012721	1/4" X 4" BOLT		01
28	0503012880	1/4" UNC SELF ADJUSTING NUT		04
29	0571014024	FAST BOLT GUIDE AXLE		01


Item	Code	Description	See page	QT
30	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
31	0503015110	M06 SPRING WASHER		02
32	0503818139	BOLT		03
33	0503037390	PACKING FOR PLANTING		01
34	0503015752	3/8" X 2" BOLT		01
35	0503034824	FIXATIVE		01
36	0581011226	FIXER CLOSING P. PLANTING CONTROL CPRA		01
37	0503010337	NUT 5/16 UNC G.5 ZN		04
38	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
39	0503011953	5/16" X 1" BOLT		03
40	0503012163	5/16" X 1-1/2" BOLT		01
41	0521066707	FEEDER		01




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION HOPPER PP		01
02	0502050053	RIGHT SIDE TRANSMISSION HOPPER PP		01
03	0503011410	ROLLER BEARING		02
04	0503011182	6203 ROLLER BEARING		02
05	0503011184	502040 CLAMPING RING (FOR AXLE)		01
06	0571017655	FIXER SLEEVE		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
08	0503010144	1/4" NUT		03
09	0511057504	JOIN GEAR		01
09A	0571017898	BODY GEAR TRANSMISSION		01
09B	0503011769	M8 X 0.5" BOLT		01
10	0581011222	PINION AXLE 6Z PNEUMATIC		01
11	0503034340	PINION AXLE 6Z PNEUMATIC		01




Item	Code	Description	See page	QT
01	0571019613	STRAW PRECISION PLANTING SHIELD		01
02	0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	163	01




Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	166	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	RIGHT LOW HUB WITH 15 DISC	167	01
04	0503810026	3/8" NUT		01
05	0503011443	SPRING WASHER 3/8"		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012780	SUPPORT DDD RIGHT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	166	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC		01
03	0511053173	RIGHT LOW HUB WITH 15 DISC	167	01
04	0503810026	3/8" NUT		01
05	0503011443	SPRING WASHER 3/8"		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02



Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	NUT 5/16 UNC G.5 ZN		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUBLE DISC AXLE		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	NUT 5/16 UNC G.5 ZN		06
06	0502012736	HUB LOWER		01



Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0581014858	DEPTH WHEEL AXLE		01
04	0501110720	ARM LEFT		01
04A	0502012726	LEFT DEPTH WHEEL ARM		01
04B	0503034375	WHEEL ARM SLEEVE		02
05	0501110719	DEPTH CONTROL RIGHT ARM		01
05A	0502012725	DEPTH WHEEL RIGHT ARM		01
05B	0503034375	WHEEL ARM SLEEVE		02
06	0502012663	EXTENSION		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	169	01
09	0521051423	COMPACTOR SUPPORT	170	01
10	0503034793	ARTICULATION SLEEVE		02
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503010019	1/2" SPRING WASHER		08
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503010060	1/2 UNC G.5 ZN HEX NUT		04
16	0501052908	COMPACTOR WHEEL WITH BEARING	171	02
17	0503013739	1/2" X 1" BOLT		01
18	0511050077	WHEEL STRIPED	172	02
19	0503016453	1/2" X 2.1/2 BOLT		02
20	0503034817	SPRING		01
21	0503010752	1/2" X 3.1/2" BOLT		01
22	0503010581	RING		01
23	0503034377	3/8 UNC X 3/4 BOLT		01

DEPTH WHEELS REGULATOR ASSY


0501056769




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" SPLIT PIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01

COMPACTOR SUPPORT


0521051423



Item	Code	Description	See page	QT
01	0521068003	RIGHT SIDE		01
02	0521068002	LEFT SIDE		01
03	0581014847	PLATE UPPER		01
04	0581015855	SLEEVE		02
05	0521068004	HANDLE BODY		01
06	0581014969	GUIDE SLEEVE		01
07	0581014968	SLEEVE FLANGE		01
08	0503010937	5/16" X 3" BOLT		02
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0521068005	LEVER		01
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
12	0503010337	NUT 5/16 UNC G.5 ZN		04
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2 UNC G.5 ZN HEX NUT		01
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010882	BOLT		02
17	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
18	0503030878	LEVER CRANK		01
19	0581015854	RIGHT PROTECTION COVER		01
20	0581015853	LEFT PROTECTION COVER		01
21	0581015903	SPACER WASHER		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	173	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	NUT 5/16 UNC G.5 ZN		06

DEPTH WHEEL HUB ASSY


0511052287




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEEL HUB		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01



Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0503013759	NUT		02
02	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
03	0502012979	CLAMP 3 RIGHT CSU		02
04	0503010421	5/16" X 1-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503010257	1/8" X 1" SPLIT PIN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01

SCARIFIER ROD WITH TIP


0501110231



Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER ROD		01
02	1902070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01



Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

