

ROW CROP PLANTERS

PST DUO FLEX TITANIUM - FRAME 4880/5950 - CSU - APT

Code: 0501093550
Series: S-0119
Revision: 00
Date Revision: MAIO/2023

PARTS CATALOGUE



MARCHESAN



PRODUCTS

Code	Description
0111240532	PST DUO FLEX 4880/10E500 ESPECIAL S-0119
0111240554	PST DUO FLEX 5950/12E500 ESPECIAL S-0119

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909096726	ASSY FRAME	1
0521054576	FRAME WITH ARTICULATION 4880	2
0521054567	RIGHT FRAME WITH WHEELED AXLE 4880	3
0521054569	FRAME LEFT WITH SHAFT WHEELED 4880	4
0521054578	FRAME WITH ARTICULATION 5950	5
0521054572	RIGHT FRAME WITH WHEELED AXLE 5950	6
0521054573	FRAME LEFT WITH SHAFT WHEELED 5950	7
0511058667	SPRING FLOW ENSEMBLY	8
0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	9
0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	10
0521058394	WHEEL WITH TIRE	11
0503063172	WHEEL	12
0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	13
0521058402	WHEELED WITH 655 DRIFT SPRING WITH TRANSMISSION	14
0521058401	655 WHEELED SUPPORT WITH TRANSMISSION	15
0501058241	WHEEL SUPPORT CHAIN TENSIONER	16
0521055234	WHEELED FASTENER	17
0521055236	INTERMEDIARY CURRENT STRETCHER	18
0521055237	WHEEL FIXED CURRENT STRETCHER	19
0521055235	WHEEL MOBILE CURRENT STRETCHER	20
0521055238	BEARING TENSIONER CHAIN	21
0521054561	CYLINDER ASSEMBLY	22
0511058406	HYDRAULIC CYLINDER	23
0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	24
0501054452	FLOW DIVIDING VALVE	25
0501053834	MALE QUICK COUPLER	26
0909095186	DRAWBAR ASSY	27
0511055096	TRACTOR HITCH	28
0521053310	LEFT EXTENSION DRAWBAR 36.00 - 4880/5720/5950	29
0531052545	LEFT EXTENSION DRAWBAR 36.00 - 4880/5950	30
0521053313	LEFT EXTENSION DRAWBAR 36.00 - 5340	31
0531052543	LEFT EXTENSION DRAWBAR 36.00 - 5340	32
0521053320	LEFT EXTENSION DRAWBAR 36.00 - 6350	33
0531052540	DRAWBAR ASSY	34
0521053318	LEFT EXTENSION DRAWBAR 36.00 - 6850	35
0521053311	RIGHT EXTENSOR DRAWBAR 36,00 - 4880/5720/5950	36
0521053312	RIGHT EXTENSOR DRAWBAR 36,00 - 5340	37
0521053321	RIGHT EXTENSOR DRAWBAR 36,00 - 6350	38
0521053319	RIGHT EXTENSOR DRAWBAR 36,00 - 6850	39
0511052311	3 POINT TURNBUCKLE	40
0511056736	HOSE SUPPORT	41
0531056440	4880 FERTILIZER HOPPER SET	42
0531056567	4880 LEFT HOPPER SUPPORT WITH FERTILIZER METERING	43
0531056566	4880 RIGHT HOPPER SUPPORT WITH FERTILIZER METERING	44
0531055319	ALPHA II FERTILIZER METERING	45
0531055863	ASSY TRANSMISSION HUB	46
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	47
0531059139	ASSY COLLECTOR	48
0531055273	ALPHA FERTILIZER METERING CLAMP	49
0501053788	3/4 SQUARE AXLE FASTENER	50
0531057911	22Z GEAR SIDE BEARING ASSEMBLY	51
0531057901	GEAR	52
0531056442	ALPHA FERTILIZER HOPPER SET 5950	53
0531056569	5950 LEFT HOPPER SUPPORT WITH FERTILIZER METERING	54



MARCHESAN

INDEX

0531056568	5950 RIGHT HOPPER SUPPORT WITH FERTILIZER METERING	55
0521054562	PLATFORM ASSEMBLY 4880	56
0521054564	PLATFORM ASSEMBLY 5950	57
0511056746	HANDRAIL ASSY 4880	58
0521054568	HANDRAIL ASSY 5950	59
0531057969	ASSY BOX SEED	60
0531057970	ASSY BOX SEED	61
0531057950	3" X 175 SEED NOZZLE WITH FIXING	62
0531054471	CAP WITH FIXING	63
0521051927	TOWER SUPPORT HOPPER	64
0531057962	ASSY BOX SEED	65
0531057964	ASSY BOX SEED	66
0521051931	LEFT SUPPORT TOWER WITH BOLT	67
0531051994	RIGHT TOWER SUPPORT HOPPER SUPPORT WITH SCREW	68
0531051996	LEFT TOWER SUPPORT HOPPER SUPPORT WITH SCREW	69
0521056983	SEMI MOUNTED HYDRAULIC MARKER 4880	70
0511058449	HYDRAULIC CYLINDER	71
0501054649	HBM SEQUENTIAL VALVE	72
0511054971	JACK ASSEMBLY	73
0511056536	LADDER ASSEMBLY	74
0521055204	ROW MARKER DISC	75
0521054580	REAR LIGHTING ASSEMBLY 4880	76
0521054582	REAR LIGHTING ASSEMBLY 5720/5950	77
0521052792	MOUNTED REAR LIGHT	78
0521054585	MANUAL CANISTER ASSY	79
0521054181	TOOL BOX ASSEMBLY	80
0521054525	CONTAINER WATER TANK	81
0909095190	ASSY HEX AXLE	82
0521055214	BEARING GEAR WITH	83
0521055215	DOUBLE TRANSMISSION BEARING	84
0531059116	4880 MH/CSU/ALPHA/APT - SET LABEL ADHESIVE	85
0541050427	5950 CSU/ALPHA/APT - SET LABEL ADHESIVE	86
0521053597	ISO SET 4 CHANNEL PLANTING MONITORING C/M/E SEED	87
0521058495	ISOBUS SET	88
0511056972	FILTER HYDAC	89
0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	90
0531052082	MECHANICAL SET APT 4 CHANNELS FERTILIZER/SEED 4880	91
0531050765	MODULE BOX	92
0511059348	APT ASSY MODULE BOX	93
0531052052	COVER MOTOR HYDRAULIC	94
0531052053	COVER MOTOR HYDRAULIC	95
0531052049	SEED ENGINE LEFT CHAIN COVER	96
0531052051	COVER MOTOR HYDRAULIC	97
0541050429	APT MECHANICAL ASSEMBLY	98
0511056751	RIGHT TRANSMISSION ASSY - 4880	99
0501052560	MOTOR AXLE SIGNAL	100
0511051434	TRANSMISSION ACTUATOR	101
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	102
0521043316	RIGHT GEAR BOX ASSY	103
0501058212	SEMI MOUNTED RIGHT CHANGE	104
0511059266	CLOSED BEARING	105
0501056271	GEARBOX CLOSED BEARING	106
0501056443	GEAR HOUSING BEARING	107
0501056444	BEARING WITH ROLLER	108
0501048790	AXLE WITH RING	109



MARCHESAN

INDEX


0501054655	CHAIN TENSIONER ASSY	110
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	111
0511054363	CHAIN TENSIONER	112
0521055217	LOWER CURRENT STRETCH	113
0501058254	UPPER SEED CHAIN TENSIONER	114
0521055216	BEARING WITH GEAR	115
0521055218	BEARING GEAR WITH DOUBLE	116
0501055112	MICRO GRANULATED CHAIN TENSIONER	117
0511056818	RIGHT TRANSMISSION ASSY 5950	118
0511056752	LEFT TRANSMISSION ASSY - 4880	119
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	120
0521043317	LEFT GEAR BOX ASSY	121
0501058213	LH GEAR BOX	122
0501058265	STRETCHER LOWER CURRENT 21Z SEED	123
0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	124
0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	125
0511056819	LEFT TRANSMISSION ASSY 5950	126
0531059620	KIT WITH ALPHA COMPONENTS - 10 ROWS	127
0531059622	KIT WITH ALPHA COMPONENTS - 12 ROWS	128
0909096727	SEED LINE/COMPLETE FERTILIZER	129
0521053227	FRONT LEFT SHORT SEED ROW	130
0521055213	SEED ROW BEARING	131
0521055223	SEED ROW TRANSMISSION HUB	132
0511055260	SEED ROW CHAIN TENSIONER	133
0521055226	BEARING WITH AXLE JOINT	134
0521055227	BEARING SHAFT HEX	135
0521055219	BEARING WITH GEAR 17Z HEX 5/8	136
0521055220	BEARING FRONT SEED ROW	137
0521053230	FRONT RIGHT SHORT SEED ROW	138
0521053228	FRONT LEFT LONG SEED ROW	139
0521053229	FRONT RIGHT LONG SEED ROW	140
0521054736	FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED ROW	141
0511059333	SEMI-ASSEMBLED MECHANICAL FRAME	142
0511059334	BEARING WITH LONG FRONT AXLE	143
0511058143	UNIVERSAL JOINT AXLE	144
0521054771	LEFT REAR SEED ROW	145
0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	146
0521055871	LEFT DOUBLE DISC SEED 15 X 15	147
0511052302	LH SUPPORT DDD GUIDE	148
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	149
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	150
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	151
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	152
0521054770	RIGHT REAR SEED ROW	153
0521055870	RIGHT DOUBLE DISC SEED 15 X 15	154
0511052301	SUPPORT DDD 15 RIGHT	155
0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	156
0521055065	ASSY DEPTH / COMPACTOR	157
0501056769	DEPTH WHEELS REGULATOR ASSY	158
0521055068	RAYED WHEEL CENTER CLOSED	159
0521055055	HUB WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	160
0521054990	LEFT COMPACTOR WHEEL	161
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	162
0521055017	RIGHT COMPACTOR WHEEL	163
0521054811	FERTILIZER SHORT ROW	164

INDEX

0521054906	SPRING ASSY FERTILIZER		165
0521053231	DPL 20 SHORT ROW WITHOUT LUBRICATION CONICAL BEARING		166
0521053248	20" DISC BLADE HUB WITH CONICAL BEARING		167
0521053697	DISC BLADE HUB		168
0521054812	LONG FERTILIZER ROW		169
0521053232	DPL 20 LONG ROW WITHOUT LUBRICATION CONICAL BEARING		170
0521054769	LEFT DDD FERTILIZER WITH SUPPORT		171
0521055869	LEFT DUAL FERTILIZER DISC		172
0521054768	RIGHT DDD FERTILIZER WITH SUPPORT		173
0521055868	RIGHT DUAL FERTILIZER DISC		174
0531055312	TITANIUM SINGLE SEED SYSTEM		175
0511052058	SEED SYSTEM TITANIUM		176
0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER		177
0511052024	FAST CLOSING SET		178
0531050237	SEED CONDUCTOR FIXER 3 CSU RIGHT		179
0521053946	SCARING ROD		180
0503062066	DISC SET WITH CORN RING		181
0503062067	DISC SET / RING SOY 90F TITANIUM		182
0521057957	FIXED ROD EXTENSION WITH FIXATION		183

ASSY FRAME

0909096726




Item	Code	Description	See page	4880	5950
01	0521054576	FRAME WITH ARTICULATION 4880	2	01	00
01.	0521054578	FRAME WITH ARTICULATION 5950	5	00	01
02	0521064285	LOCK LOWER FRAME		01	01
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		01	01
04	0503010002	1800 GREASE FITTING		01	01
05	0503010003	1845 GREASE FITTING		05	05
06	0503010004	1890 GREASE FITTING		02	02
07	0511058667	SPRING FLOW ENSEMBLY	8	01	01
08	0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT 9		00	02
08.	0521058402	WHEELED WITH 655 DRIFT SPRING WITH 14		04	04
09	0521054561	CYLINDER ASSEMBLY	22	01	01
10	0511056742	ASSY SYSTEM HYDRAULIC 4880/5720/5950	24	01	01
11	0909095186	DRAWBAR ASSY	27	01	01
12	0511056736	HOSE SUPPORT	41	01	01
13	0531056440	4880 FERTILIZER HOPPER SET	42	01	00
13.	0531056442	ALPHA FERTILIZER HOPPER SET 5950	53	00	01
14	0521054562	PLATFORM ASSEMBLY 4880	56	01	00
14.	0521054564	PLATFORM ASSEMBLY 5950	57	00	01
15	0511056746	HANDRAIL ASSY 4880	58	01	00
15.	0521054568	HANDRAIL ASSY 5950	59	00	01
16	0531057969	ASSY BOX SEED	60	01	00
16.	0531057962	ASSY BOX SEED	65	00	01
17	0521056983	SEMI MOUNTED HYDRAULIC MARKER 4880	70	01	00
18	0511054971	JACK ASSEMBLY	73	04	04
19	0511056536	LADDER ASSEMBLY	74	02	02
20	0521055204	ROW MARKER DISC	75	02	00
21	0521054580	REAR LIGHTING ASSEMBLY 4880	76	01	00
21.	0521054582	REAR LIGHTING ASSEMBLY 5720/5950	77	00	01
22	0503010023	3/4" SPRING WASHER		02	02
23	0503010014	3/4" HEX NUT		02	02


ASSY FRAME

0909096726


Item	Code	Description	See page	4880	5950
24	0503011751	REDUCTION		06	06
25	0521054585	MANUAL CANISTER ASSY	79	01	01
26	0501065677	STRUT		02	02
27	0541015451	FIXED KEY 2.3/8 X 2.3/4		01	01
28	0501047895	25 ROD STOP		02	02
29	0501047885	30 ROD STOP		02	02
30	0501047886	35 ROD STOP		02	02
31	0501047887	40 ROD STOP		02	02
32	0521013022	TRANSPORT LOCK		02	02
33	0503030168	HITCH PIN CLIP		02	02
34	0501068994	8,30 X 78 LOCK PIN		02	02
35	0521054181	TOOL BOX ASSEMBLY	80	01	01
36	0521054525	CONTAINER WATER TANK	81	01	01
37	0503019262	SOAP DISH VACUUM		01	01
38	0503010246	CLAMP		10	12
39	0909095190	ASSY HEX AXLE	82	01	01
40	0521065613	HOSE HOLDER		01	01
41	0503011953	5/16" X 1" BOLT		02	02
42	0503013816	5/16" LOCKNUT		02	02
43	0531059116	4880 MH/CSU/ALPHA/APT - SET LABEL ADHESIVE	85	01	00
43.	0541050427	5950 CSU/ALPHA/APT - SET LABEL ADHESIVE	86	00	01
44	0521053597	ISO SET 4 CHANNEL PLANTING MONITORING C/M/E SEED	87	01	00
44.	0521058495	ISOBUS SET	88	00	01
45	0531052082	MECHANICAL SET APT 4 CHANNELS FERTILIZER/SEED 4880	91	01	00
45.	0541050429	APT MECHANICAL ASSEMBLY	98	00	01
46	0503010780	N-2050 AMENDMENT		02	02
47	0503010951	REDUCTION		04	04
48	0511056751	RIGHT TRANSMISSION ASSY - 4880	99	01	00
48.	0511056818	RIGHT TRANSMISSION ASSY 5950	118	00	01
49	0511056752	LEFT TRANSMISSION ASSY - 4880	119	01	00
49.	0511056819	LEFT TRANSMISSION ASSY 5950	126	00	01
50	0501090994	INSTRUCTIONS MANUAL		01	01
51	0531059620	KIT WITH ALPHA COMPONENTS - 10 ROWS	127	01	00
51.	0531059622	KIT WITH ALPHA COMPONENTS - 12 ROWS	128	00	01
52	0503011750	AMENDMENT WITH LOCK		06	06
53	0909096727	SEED LINE/COMPLETE FERTILIZER	129	10	12




Item	Code	Description	See page	QT
01	0521054567	RIGHT FRAME WITH WHEELED AXLE 4880	3	01
02	0521054569	FRAME LEFT WITH SHAFT WHEELED 4880	4	01
03	0501110791	FRONT ARTICULATOR HUB WITH SLEEVES		01
04	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581018964	TROUGH 24 X 50 X 1320		02
20	0581018965	TROUGH 24 X 50 X 940		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8 SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
01	0521068942	RIGHT FRAME		01
02	0521069426	RIGHT ARTICULATED AXLE		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0521068943	LEFT FRAME		01
02	0521069427	LEFT ARTICULATED AXLE		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0521054572	RIGHT FRAME WITH WHEELED AXLE 5950	6	01
02	0521054573	FRAME LEFT WITH SHAFT WHEELED 5950	7	01
03	0501110791	FRONT ARTICULATOR HUB WITH SLEEVES		01
04	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581018960	TROUGH 24 X 50 X 1855		02
20	0581018961	TROUGH 24 X 50 X 945		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8 SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
01	0521068946	RIGHT FRAME 5950		01
02	0521069430	RIGHT SIDE RIGHT ARTICULATED AXLE 5950		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0521068947	LEFT FRAME 5950		01
02	0521069431	LEFT ARTICULATED AXLE 5950		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8 NUT		06




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		06
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		12
03	0501012140	FLAT WASHER		24




Item	Code	Description	See page	QT
01	0521058403	655 WHEELED BRACKET WITHOUT 10 TRANSMISSION	10	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8 SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8 SPRING WASHER		02
08	0591010589	BODY LOCK WHEEL		02
09	0521058394	WHEEL WITH TIRE	11	01




Item	Code	Description	See page	QT
01	0503063172	WHEEL	12	01
02	0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	13	01




Item	Code	Description	See page	QT
01	0503019458	TIRE 7.00X16 14PR		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0521058401	655 WHEELED SUPPORT WITH TRANSMISSION	15	01
02	0521055234	WHEELED FASTENER	17	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	WHEEL SUPPORT CHAIN TENSIONER	16	01
07	0521058393	WHEEL WITH TIRE 7.00 X 16 14L PR TT WITH TRANSMISSION		01
08	0503018981	BOLT		02
09	0503010027	5/8 SPRING WASHER		04
10	0591010589	BODY LOCK WHEEL		01
11	0521069983	WHEEL COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01

WHEELED FASTENER


0521055234




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0521055236	INTERMEDIARY CURRENT STRETCHER	18	01
07	0521055237	WHEEL FIXED CURRENT STRETCHER	19	01
08	0521055235	WHEEL MOBILE CURRENT STRETCHER	20	01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN	21	01
02	0551018245	CHAIN TENSIONER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0551018239	SLEEVE 19 X 13,50 X 45		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN	21	01
02	0551018252	CHAIN TENSIONER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN	21	01
02	0551018244	CHAIN TENSIONER AXLE		01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503019355	BEARING 6202 2RS1		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01



Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	23	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521015501	COUPLING SHAFT		02
04	0503010523	1/4" X 2" SPLIT PIN		04
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
06	0531012565	SLEEVE 16,3X 30 X 88		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCKLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0571017027	VALVE SUPPORT		01
02	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0501054452	FLOW DIVIDING VALVE	25	01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER	26	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		02
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057089	HOSE KIT SYSTEM HYDRAULIC		01
19A	0501080045	3/8" X 850 TR-TR HOSE		01
19B	0501080999	3/8" X 39" TC-TC HOSE		01
19C	0501081987	HOSE 3/8 X 1550 TR-TC		01
19D	0501081986	HOSE 3/8 X 1550 TC-TC		01
19E	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
19EA	0501080185	HOSE 1/2 X 4000 TR-TM		01
19EB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
19EC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
19ED	0503018952	PLASTIC BOLT		06
19F	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
19FA	0501080185	HOSE 1/2 X 4000 TR-TM		01
19FB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01



Item	Code	Description	See page	QT
19FC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
19FD	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503010190	2-114 N 3006-9B O'RING		03
03	0501010617	3/4" NIPPLE		02
04	0501011460	7/8 NF REDUCTION NIPPLE		01



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01

DRAWBAR ASSY

0909095186



Item	Code	Description	See page	4880	5340	5950	6350	6850
01	0521068561	LONG COUPLING DRAWBAR		001	001	001	001	001
02	0511055096	TRACTOR HITCH	28	001	001	001	001	001
03	0511053179	TRACTOR COUPLING SHAFT		001	001	001	001	001
03A	0521064036	TRACTOR HITCH AXLE		001	001	001	001	001
03B	0503030012	HITCH PIN CLIP		001	001	001	001	001
04	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		001	001	001	001	001
04.	0501212237	HITCH SLEEVE ARTICULATED 85 X 35 MM		001	001	001	001	001
05	0503014120	CHAIN		001	001	001	001	001
06	0503014321	CABLE STEEL SHACKLE		002	002	002	002	002
07	0571010661	PIVOT SHAFT		001	001	001	001	001
08	0503010010	1/4" X 2.1/2" COTTERPIN		002	002	002	002	002
09	0521064203	EAR PIVOT DRAWBAR		001	001	001	001	001
10	0521053310	LEFT EXTENSION DRAWBAR 36.00 - 29	29	001	000	001	000	000
		4880/5720/5950						
10.	0531052545	LEFT EXTENSION DRAWBAR 36.00 - 4880/5950	30	001	000	000	000	000
10..	0521053313	LEFT EXTENSION DRAWBAR 36.00 - 5340	31	000	001	000	000	000
10...	0531052543	LEFT EXTENSION DRAWBAR 36.00 - 5340	32	000	001	000	000	000
10....	0521053320	LEFT EXTENSION DRAWBAR 36.00 - 6350	33	000	000	000	001	000
10.....	0531052540	DRAWBAR ASSY	34	000	000	000	001	000
10.....	0521053318	LEFT EXTENSION DRAWBAR 36.00 - 6850	35	000	000	000	000	001
11	0501010500	3/4" X 3" BOLT		002	002	002	002	002
12	0503010023	3/4" SPRING WASHER		002	002	002	002	002
13	0503010014	3/4" HEX NUT		002	002	002	002	002
14	0571019949	JUNCTION SHAFT		002	002	002	002	002
15	0503030119	LOCK PIN		002	002	002	002	002
16	0521053311	RIGHT EXTENSOR DRAWBAR 36,00 - 36	36	001	000	001	000	000
		4880/5720/5950						
16.	0521053312	RIGHT EXTENSOR DRAWBAR 36,00 - 5340	37	000	001	000	000	000
16..	0521053321	RIGHT EXTENSOR DRAWBAR 36,00 - 6350	38	000	000	000	001	000
16...	0521053319	RIGHT EXTENSOR DRAWBAR 36,00 - 6850	39	000	000	000	000	001
17	0521010572	0.9" X 2.9" COUPLING SHAFT		001	001	001	001	001
18	0503030085	LOCK PIN		004	004	004	004	004


DRAWBAR ASSY

0909095186


Item	Code	Description	See page	4880	5340	5950	6350	6850
19	0521063528	EXTENDING FIXER		001	001	001	001	001
20	0501010171	BOLT 1 UNC X 3.1/2 C S G.5		003	003	003	003	003
21	0503010012	1" SPRING WASHER		003	003	003	003	003
22	0501010059	1.5/8 NUT		003	003	003	003	003
23	0521062916	LEFT FRENCH HAND		001	001	001	001	001
24	0521010585	0.9" X 5.9" COUPLING SHAFT		001	001	001	001	001
25	0511052311	3 POINT TURNBUCKLE	40	001	001	001	001	001
26	0521012532	0.9" X 3.9" COUPLING SHAFT		001	001	001	001	001
27	0521010582	COUPLING SHAFT		001	001	001	001	001
28	0521063529	LOCK AXLE		001	001	001	001	001
29	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		001	001	001	001	001
30	0501212237	HITCH SLEEVE ARTICULATED 85 X 35 MM		000	000	000	001	000

TRACTOR HITCH


0511055096




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	LEFT COMPRESSION SPRING		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0521064426	POINT FIXER EXTENDING LEFT		01
02	0501078990	TURNBUCKLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0531062838	LEFT POINT FIXER EXTENDING		01
02	0501078990	TURNBUCKLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02
06	0531062839	ARTICULATED ARM BAR		01
07	0503010023	3/4" SPRING WASHER		04
08	0503010014	3/4" HEX NUT		04
09	0503035565	COMPRESSION SPRING		04
10	0503012951	3/4" X 10-1/2" BOLT		04
11	0501017065	FLAT WASHER		08



Item	Code	Description	See page	QT
01	0521064426	POINT FIXER EXTENDING LEFT		01
02	0521065193	TURNBUCKLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0531062838	LEFT POINT FIXER EXTENDING		01
02	0521065193	TURNBUCKLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02
06	0531062839	ARTICULATED ARM BAR		01
07	0503010023	3/4" SPRING WASHER		04
08	0503010014	3/4" HEX NUT		04
09	0503035565	COMPRESSION SPRING		04
10	0503012951	3/4" X 10-1/2" BOLT		04
11	0501017065	FLAT WASHER		08




Item	Code	Description	See page	QT
01	0521064238	POINT FIXER EXTENDING LEFT		01
02	0501078990	TURNBUCKLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02

DRAWBAR ASSY


0531052540




Item	Code	Description	See page	QT
01	0531062849	LEFT EXTENDER FIXED CRAMPON		01
02	0501078990	TURNBUCKLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02
06	0531062854	ARTICULATED ARM BAR		01
07	0503010023	3/4" SPRING WASHER		04
08	0503010014	3/4" HEX NUT		04
09	0503035565	COMPRESSSION SPRING		04
10	0503012951	3/4" X 10-1/2" BOLT		04
11	0501017065	FLAT WASHER		08




Item	Code	Description	See page	QT
01	0521064238	POINT FIXER EXTENDING LEFT		01
02	0521065193	TURNBUCKLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064425	POINT FIXER EXTENDING RIGHT		01
02	0501078990	TURNBUCKLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064425	POINT FIXER EXTENDING RIGHT		01
02	0521065193	TURNBUCKLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064237	POINT FIXER EXTENDING RIGHT		01
02	0501078990	TURNBUCKLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0521064237	POINT FIXER EXTENDING RIGHT		01
02	0521065193	TURNBUCKLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0571012279	JACK RIGHT		01
03	0571012280	JACK LEFT		01
04	0531010264	SIDE RATCHET		02
05	0521018500	SHAFT LEVER EXTENSOR		01
06	0511061881	RATCHET FOLLOWER		01
07	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
08	0503011179	3/8" X 2-1/4" BOLT		05
09	0503010025	3/8 SPRING WASHER		05
10	0503010026	3/8" NUT		05
11	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01

4880 FERTILIZER HOPPER SET

0531056440




Item	Code	Description	See page	QT
01	0531056567	4880 LEFT HOPPER SUPPORT WITH FERTILIZER 43 METERING	01	01
02	0531056566	4880 RIGHT HOPPER SUPPORT WITH FERTILIZER 44 METERING	44	01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
04	0503010025	3/8 SPRING WASHER		12
05	0503010026	3/8" NUT		12
06	0503010849	3/8" X 1-1/2" BOLT		12
07	0571019051	FIXER HOPPER WASHER		20
08	0503013751	3/8 UNC X 1.1/4 BOLT		20
09	0503012535	3/8" SPRING WASHER		20
10	0503012531	3/8" INOX NUT		20
11	0503011957	NYLON HANDLE		02
12	0503010371	5/16" X 1" BOLT		04
13	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
14	0503010337	5/16" NUT		08
15	0501010694	FLAT WASHER		04
16	0503011953	5/16" X 1" BOLT		04
17	0551019168	SLEEVE		02
18	0551019167	SLEEVE UNION		02
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
20	0503010479	BOLT		02
21	0503011336	1/2" HEX SELF ADJUSTING NUT		06
22	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
23	0503010019	1/2" SPRING WASHER		02
24	0503010060	1/2 UNC G.5 ZN HEX NUT		02
25	0501013518	FLAT WASHER		06
26	0503010140	1/8" X 3/4" COTTERPIN		06
27	0511069678	LH LOWER LEVER		02
28	0561016468	FASTENER		02
29	0521061741	INNTER LEVER		02
30	0551019159	LEVER FIXER BODY		02




4880 FERTILIZER HOPPER SET

0531056440


Item	Code	Description	See page	QT
31	0503062589	FERTILIZER HOPPER MOUNTED		02
32	0581018923	LOWER LEVER LEVER CHANGE		02
33	0503011312	ROTATIVE CABLE		02
34	0521068994	SMALL LEVER		02



Item	Code	Description	See page	QT
01	0531064693	4880 LEFT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	45	02
03	0501053788	3/4 SQUARE AXLE FASTENER	50	02
04	0503030303	SUPPORT WASHER		02
05	0501310798	3/4 X 378 AXLE		01
06	0501218487	3/4 X 390 AXLE		05
07	0531057908	SLEEVE 1/4 X 2		05
07A	0502013069	SLEEVE 21 X 38 X 50		01
07B	0503010010	1/4" X 2.1/2" COTTERPIN		01
08	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	51	01




Item	Code	Description	See page	QT
01	0531064692	4880 RIGHT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	45	06
03	0501053788	3/4 SQUARE AXLE FASTENER	50	02
04	0503030303	SUPPORT WASHER		02
05	0501310798	3/4 X 378 AXLE		01
06	0501218487	3/4 X 390 AXLE		05
07	0531057908	SLEEVE 1/4 X 2		05
07A	0502013069	SLEEVE 21 X 38 X 50		01
07B	0503010010	1/4" X 2.1/2" COTTERPIN		01
08	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	51	01




Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	ASSY TRANSMISSION HUB	46	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	47	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513011170	ALLEN SCREW 1/4 UNC X 7/8 CCSI STAINLESS STEEL		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501310211	FRONT COVER ADB ALPHA II DISPENSER		01
19	0503036177	ADB ALPHA DISPENSER COVER STRING		01
20	0531059139	ASSY COLLECTOR	48	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01

ASSY TRANSMISSION HUB

0531055863




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO ADHESIVE LABEL 41.5 X 29		01
15	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT GUIDE DOSING COVER		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT GLOVE FIXING SAFETY LOCK DISPENSER		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT GLOVE FIXING SAFETY LOCK DISPENSER		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01

ASSY COLLECTOR


0531059139




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	49	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01



Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007		02
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0503010337	5/16" NUT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0531057901	GEAR	52	01
07	0503010845	501035 CLAMPING RING (FOR AXLE)		01
08	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531065402	GEAR		01
02	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0531056569	5950 LEFT HOPPER SUPPORT WITH FERTILIZER METERING	54	01
02	0531056568	5950 RIGHT HOPPER SUPPORT WITH FERTILIZER METERING	55	01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		24
04	0503010025	3/8 SPRING WASHER		12
05	0503010026	3/8" NUT		12
06	0503010849	3/8" X 1-1/2" BOLT		12
07	0571019051	FIXER HOPPER WASHER		20
08	0503013751	3/8 UNC X 1.1/4 BOLT		20
09	0503012535	3/8" SPRING WASHER		20
10	0503012531	3/8" INOX NUT		20
11	0503011957	NYLON HANDLE		02
12	0503010371	5/16" X 1" BOLT		04
13	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
14	0503010337	5/16" NUT		08
15	0501010694	FLAT WASHER		04
16	0503011953	5/16" X 1" BOLT		04
17	0551019168	SLEEVE		02
18	0551019167	SLEEVE UNION		02
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
20	0503010479	BOLT		02
21	0503011336	1/2" HEX SELF ADJUSTING NUT		06
22	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
23	0503010019	1/2" SPRING WASHER		02
24	0503010060	1/2 UNC G.5 ZN HEX NUT		02
25	0501013518	FLAT WASHER		06
26	0503010140	1/8" X 3/4" COTTERPIN		06
27	0511069678	LH LOWER LEVER		02
28	0561016468	FASTENER		02
29	0521061741	INNTER LEVER		02
30	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
31	0581012605	GEAR BOX LEVER LOCK		02
32	0503062362	FERTILIZER HOPPER		02
33	0503062927	FERTILIZER HOPPER		02
34	0501215701	ARM/DISARM LEVER		02




Item	Code	Description	See page	QT
01	0531064695	LEFT HOPPER SUPPORT		01
02	0501053788	3/4 SQUARE AXLE FASTENER	50	11
03	0531055319	ALPHA II FERTILIZER METERING	45	07
04	0503031527	AGRICULTURAL BEARING		11
05	0531057908	SLEEVE 1/4 X 2		06
05A	0502013069	SLEEVE 21 X 38 X 50		01
05B	0503010010	1/4" X 2.1/2" COTTERPIN		01
06	0501218487	3/4 X 390 AXLE		04
07	0501218684	3/4 X 330 AXLE		01
08	0501218666	AXLE 3/4 X 155		01
09	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	51	01
10	0501311444	3/4 X 790 AXLE		01




Item	Code	Description	See page	QT
01	0501053788	3/4 SQUARE AXLE FASTENER	50	11
02	0531064694	RIGHT HOPPER SUPPORT		01
03	0531055319	ALPHA II FERTILIZER METERING	45	07
04	0503031527	AGRICULTURAL BEARING		11
05	0531057908	SLEEVE 1/4 X 2		06
05A	0502013069	SLEEVE 21 X 38 X 50		01
05B	0503010010	1/4" X 2.1/2" COTTERPIN		01
06	0501218666	AXLE 3/4 X 155		01
07	0501218684	3/4 X 330 AXLE		01
08	0501218487	3/4 X 390 AXLE		04
09	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	51	01
10	0501311444	3/4 X 790 AXLE		01




Item	Code	Description	See page	QT
01	0521069416	RIGHT PLATFORM		01
02	0521069421	LEFT PLATFORM		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
06	0503010025	3/8 SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	HITCH PIN CLIP		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521069418	RIGHT PLATFORM 5950		01
02	0521069423	LEFT PLATFORM 5950		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
06	0503010025	3/8 SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	HITCH PIN CLIP		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521062988	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8 SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0521063175	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8 SELF-ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0531057970	ASSY BOX SEED	61	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521051927	TOWER SUPPORT HOPPER	64	04




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0531057950	3" X 175 SEED NOZZLE WITH FIXING	62	10
06	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		02
07	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		02
08	0531054471	CAP WITH FIXING	63	02




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID		01
02	0501010942	3/8" X 1-1/4" BOLT		05
03	0503010025	3/8 SPRING WASHER		05
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	5/16" NUT		02
11	0502012767	SEED NOZZLE FIXER SUPPORT		01
12	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0571015773	SUPPORT SEED		01
02	0501011643	3/8 X 1"BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521066208	HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0531057964	ASSY BOX SEED	66	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521051931	LEFT SUPPORT TOWER WITH BOLT	67	02
07	0531051994	RIGHT TOWER SUPPORT HOPPER SUPPORT WITH SCREW	68	01
08	0531051996	LEFT TOWER SUPPORT HOPPER SUPPORT WITH SCREW	69	01




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0531057950	3" X 175 SEED NOZZLE WITH FIXING	62	12
06	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
07	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02
08	0531054471	CAP WITH FIXING	63	02




Item	Code	Description	See page	QT
01	0521066207	LEFT HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02



Item	Code	Description	See page	QT
01	0531062614	RIGHT HOPPER SUPPORT TOWER		01
02	0503011084	3/4" X 5" BOLT		02
03	0502010175	HITCH CLAMP		01
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0531062615	LEFT HOPPER SUPPORT TOWER		01
02	0503011084	3/4" X 5" BOLT		02
03	0502010175	HITCH CLAMP		01
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0501014177	5/8" X 2-1/2" BOLT		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0531061696	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	71	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	72	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0511057090	HYDRAULIC MARKER HAND SET		01
24A	0501081728	HOSE 3/8 X 3100 TR-TR		01
24B	0501080392	3/8 X 3300 TR-TC HOSE		01
24C	0501081988	3/8" X 145.6" TR-TC HOSE		01
24D	0501081682	TC-TC HOSE ASSY		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01


Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	26	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04
38	0551018948	BODY MARKER SUPPORT ROW		02




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01



Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8 SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
08	0503013357	3/8 SELF-ADJUSTING NUT	02	

ROW MARKER DISC


0521055204




Item	Code	Description	See page	QT
01	0521069643	DISC AXLE MARKER ROW		01
02	0602023094	DR16X3 C36AFPAFR73+4FR+4FR D474 10R		01
03	0581019513	DEPTH WHEEL HUB		01
04	0503019342	ROLLER BEARING		01
05	0581019168	DUST CLOAK		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503013758	1/4" X 1-1/2" BOLT		03
11	0503010143	1/4" SPRING WASHER		03
12	0503010358	5/16" X 5/8" BOLT		04
13	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
14	0503010337	5/16" NUT		04
15	0503034055	CLAMPING RING		01




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		15mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		02
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	78	02
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		14




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		17mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		02
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	78	02
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		14




Item	Code	Description	See page	QT
01	0503018738	HEADLIGHT		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
08	0503010337	5/16" NUT		04



Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01
07	0511033413	PACKAGING WITH MANUAL / CATALOG		01




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0521069295	SUPPORT TOOL CHEST		01
06	0581017000	PLATE INTERMEDIARY		02
07	0503034772	BOX		01
08	0501011643	3/8 X 1"BOLT		04
09	0503010025	3/8 SPRING WASHER		04
10	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0521069405	WATER TANK SUPPORT		01
06	0503014820	BLACK WATER RESERVOIR		01

ASSY HEX AXLE


0909095190



Item	Code	Description	See page	4880	5340	5950	6350	6850
01	0531016944	RIGHT 5/8" X 96" HEX AXLE		001	000	000	000	000
01.	0561019199	5/8" X 2275 AXLE HEX		001	000	000	000	000
02	0571017427	5/8 X 2700 HEX AXLE		000	001	000	000	000
02.	0571017425	5/8 X 2530 HEX AXLE		000	001	000	000	000
03	0561018502	SHAFT AXIS 5/8 X 3000		000	000	001	001	000
03.	0571011980	5/8 X 2810 HEX AXLE		000	000	001	000	000
04	0531016949	LEFT 5/8" X 125" AXLE HEX		000	000	000	001	000
04.	0561018502	SHAFT AXIS 5/8 X 3000		000	000	000	001	000
05	0571017030	SHAFT AXLE 5 / 8X3450 14E500		000	000	000	000	001
05.	0571017029	5/8 X 3280 HEX AXLE		000	000	000	000	001
05..	0571017030	SHAFT AXLE 5 / 8X3450 14E500		000	000	000	000	001
05...	0571017029	5/8 X 3280 HEX AXLE		000	000	000	000	001
06	0561014215	BEARING COVER LOWER ROW FRAME		002	002	002	002	002
07	0521055214	BEARING GEAR WITH	83	002	002	002	002	002
08	0502040534	SPRING GUIDE BUSHING LOCK		004	004	004	004	004
09	0501018535	1/2 X 1 BOLT		004	004	004	004	004



Item	Code	Description	See page	QT
01	0511063106	20Z AXLE BEARING DOUBLE		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521055215	DOUBLE TRANSMISSION BEARING	84	01
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503019356	BEARING 6005 2RS1		02
03	0503011105	SEAL RING		01



Item	Code	Description	See page	QT
01	0503034785	LABEL ADHESIVE PST DUO FLEX (04/06 MOUTHS)		01
02	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530		01
03	0503033857	LABEL ADHESIVE		01
04	0503033854	ADHESIVE LABEL		01
05	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
07	0503033422	ADHESIVE LABEL		04
08	0503031428	READ MANUAL DECAL		01
09	0503031942	ADHESIVE LABEL		01
10	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		01
11	0503031565	ADHESIVE LABEL CARE		02
12	0503031566	ADHESIVE LABEL		02
13	0503031425	ADHESIVE LABEL ATTENTION		02
14	0503032930	ADHESIVE LABEL DANGER		06
15	0503031087	ADHESIVE LABEL		01
16	0503034078	LIFTING POINTS DECAL		03
17	0503034003	SERIAL NUMBER TAG 61 X 118		01
18	0503010001	3.2 X 5.5 RIVET		04
19	0503034500	ADHESIVE LABEL		01
20	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		01
21	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		04
22	0503033981	ADHESIVE LABEL		01
23	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		04
24	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02
25	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
26	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
27	0503033008	ADHESIVE LABEL		02
28	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
29	0503032979	ADHESIVE LABEL LETTERS A B C D		02
30	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02




Item	Code	Description	See page	QT
31	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02




Item	Code	Description	See page	QT
01	0503034786	MINOR ADHESIVE LABEL (03 MOUTH)		01
02	0503034785	LABEL ADHESIVE PST DUO FLEX (04/06 MOUTHS)		01
03	0503034782	LABEL ADHESIVE LOGO SMALLER TATU (03 MOUTHS)		01
04	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530		01
05	0503033857	LABEL ADHESIVE		01
06	0503033854	ADHESIVE LABEL		01
07	0503033853	ADHESIVE LABEL		02
08	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
09	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		04
10	0503033423	LABEL ADHESIVE NUMBER 9		02
11	0503033008	ADHESIVE LABEL		02
12	0503031428	READ MANUAL DECAL		01
13	0503031942	ADHESIVE LABEL		01
14	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		01
15	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
16	0503031565	ADHESIVE LABEL CARE		02
17	0503031566	ADHESIVE LABEL		02
18	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
19	0503031425	ADHESIVE LABEL ATTENTION		02
20	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
21	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
22	0503032930	ADHESIVE LABEL DANGER		08
23	0503031087	ADHESIVE LABEL		01
24	0503034078	LIFTING POINTS DECAL		03
25	0503034003	SERIAL NUMBER TAG 61 X 118		01
26	0503010001	3.2 X 5.5 RIVET		04
27	0503032979	ADHESIVE LABEL LETTERS A B C D		02
28	0503034500	ADHESIVE LABEL		01
29	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		01




Item	Code	Description	See page	QT
30	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		04
31	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		04
32	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02




Item	Code	Description	See page	QT
01	0503062881	KIT ISO 10LINES 45/50 4C C/M/E SEED		01
01A	0503015065	MASTER CONTROL MODULE		01
01B	0503015066	CABLE CONTROL MASTER MODULE		01
01C	0503016029	CONNECTOR CABLE TRACTOR 6M KTATU6,0		01
01D	0503018734	SIMPLE CABLE		01
01E	0503017443	ANTENNA GPS PM 400		01
01F	0503017031	CLEANING BRUSH		01
01G	0503015218	SENSOR FOTOELE PM 400		10
02	0511056972	FILTER HYDAC	89	01
03	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	90	04
04	0503019291	SUPPORT SENSOR		01
05	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		150
06	0503013100	NYLON CLAMP		50




Item	Code	Description	See page	QT
01	0503063185	KIT INTELLIAG ISO 4C 12L 45/50 MS		01
01A	0503015065	MASTER CONTROL MODULE		01
01B	0503015066	CABLE CONTROL MASTER MODULE		01
01C	0503015071	CONNECTOR		01
01D	0503019840			01
01E	0503017443	ANTENNA GPS PM 400		01
01F	0503017031	CLEANING BRUSH		01
01G	0503015218	SENSOR FOTOLE PM 400		12
01H	0503019685	CABLE ISO CONNECTION TRACTOR 8,0 MT 020011353		01
02	0511056972	FILTER HYDAC	89	01
03	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	90	04
04	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		180
05	0503013100	NYLON CLAMP		60
06	0503019291	SUPPORT SENSOR		01



Item	Code	Description	See page	QT
01	0503063151	PRESSURE FILTER MFM HYDAC 1319024BR		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	7/8" T ADAPTER		01
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0513010049	MOTOR OMP X 80 EMD - 11185907		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02




Item	Code	Description	See page	QT
01	0591019625	ASSY FILTER SUPPORT		01
02	0531050765	MODULE BOX	92	01
03	0591015026	LIFTING SENSOR DRIVING BODY		01
04	0561016468	FASTENER		01
05	0503011336	1/2" HEX SELF ADJUSTING NUT		02
06	0591015027	SENSOR DRIVER		01
07	0503010282	1/4" X 3/4" BOLT		05
08	0503010144	1/4" NUT		01
09	0503010143	1/4" SPRING WASHER		17
10	0591015101	LIFT SENSOR SUPPORT		01
11	0503013356	RIVET POP 3,2 X 10,0		01
12	0521069832	15Z GEAR		04
13	0561011665	FLAT WASHER		04
14	0503062754	GEAR 34Z P.1/2 APT		02
15	0503011064	40-1 X 51 CHAIN LINK + MENDING		02
16	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
17	0503010019	1/2" SPRING WASHER		04
18	0503010060	1/2 UNC G.5 ZN HEX NUT		04
19	0531019479	AXLE CHAIN GEAR		04
20	0503030402	PULLEY		04
21	0521065328	20Z GEAR WITH HOLE SHAFT HEX 16.5		02
22	0503012142	40-1 CHAIN X 61 LINK + MENDING		02
23	0521052519	HOSE 1/2 X 4200 TC-TM GRAY / RED		01
23A	0501081073	HOSE 1/2 X 4200 TC-TM		01
23B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
23C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
23D	0503018952	PLASTIC BOLT		06
24	0501053834	MALE QUICK COUPLER	26	02
25	0503018033	37 X R.7/8 UNF 90° JIC MALE CONNECTOR WITH ROTATING NUT		04
26	0501080686	1/2 X 2100 TC-TC HOSE		01
27	0501080062	1/2 X 2000 TR-TC HOSE		02


Item	Code	Description	See page	QT
28	0501080454	1/2 X 170" TR-TR HOSE ASSY		01
29	0521056480	HOSE 1/2 X 5500 TC-TM GRAY / BLUE		01
29A	0501082246	1/2 X 5500 TC-TM HOSE		01
29B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
29C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
29D	0503018952	PLASTIC BOLT		06
30	0531052052	COVER MOTOR HYDRAULIC	94	01
31	0531052053	COVER MOTOR HYDRAULIC	95	01
32	0531052049	SEED ENGINE LEFT CHAIN COVER	96	01
33	0531052051	COVER MOTOR HYDRAULIC	97	01
34	0503013849	1/4" UNC X 3/4" BOLT		12
35	0503010305	FLAT WASHER		12




Item	Code	Description	See page	QT
01	0511059348	APT ASSY MODULE BOX	93	01
02	0521064978	BOX SUPPORT		02
03	0571016237	1/2"UNC X2.1" X1.6" FASTENER ASSY		02
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0521066834	MODULE BOX		01
02	0503018171	FAST LOCK ASSY		02
03	0521066833	BOX COVER		01
04	0571012006	COVER PIVOT SHAFT		01
05	0571012005	SUPPORT GUIDE ASSY		01
06	0501010694	FLAT WASHER		03
07	0503010257	1/8" X 1" COTTERPIN		02
08	0511017303	FLAT WASHER		10
09	0503010298	1/4" X 1/2" BOLT		04
10	0503010143	1/4" SPRING WASHER		10
11	0503010294	1/4" X 7/8" BOLT		06
12	0503010144	1/4" NUT		06
13	0501011643	3/8 X 1" BOLT		04
14	0503010025	3/8 SPRING WASHER		04
15	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
16	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
001	0591019627	COVER MOTOR HYDRAULIC		01
002	0503019412	RIVET SCREW INTERNAL		03




Item	Code	Description	See page	QT
01	0591019626	COVER MOTOR HYDRAULIC		01
02	0503019412	RIVET SCREW INTERNAL		03



Item	Code	Description	See page	QT
01	0591019610	LEFT CHAIN COVER		01
02	0503019412	RIVET SCREW INTERNAL		03




Item	Code	Description	See page	QT
01	0591019607	RIGHT CURRENT COVER		01
02	0503019412	RIVET SCREW INTERNAL		03




Item	Code	Description	See page	QT
01	0591019625	ASSY FILTER SUPPORT		01
02	0531050765	MODULE BOX	92	01
03	0591015026	LIFTING SENSOR DRIVING BODY		01
04	0561016468	FASTENER		01
05	0503011336	1/2" HEX SELF ADJUSTING NUT		02
06	0591015027	SENSOR DRIVER		01
07	0503010282	1/4" X 3/4" BOLT		03
08	0503010144	1/4" NUT		01
09	0503010143	1/4" SPRING WASHER		09
10	0591015101	LIFT SENSOR SUPPORT		01
11	0503013356	RIVET POP 3,2 X 10,0		01
12	0521069832	15Z GEAR		02
13	0561011665	FLAT WASHER		02
14	0503062754	GEAR 34Z P.1/2 APT		02
15	0503011064	40-1 X 51 CHAIN LINK + MENDING		02
16	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
17	0503010019	1/2" SPRING WASHER		12
18	0503010060	1/2 UNC G.5 ZN HEX NUT		12
19	0531019479	AXLE CHAIN GEAR		04
20	0503030402	PULLEY		04
21	0521065328	20Z GEAR WITH HOLE SHAFT HEX 16.5		02
22	0503012142	40-1 CHAIN X 61 LINK + MENDING		02
23	0521052519	HOSE 1/2 X 4200 TC-TM GRAY / RED		01
23A	0501081073	HOSE 1/2 X 4200 TC-TM		01
23B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
23C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
23D	0503018952	PLASTIC BOLT		06
24	0501053834	MALE QUICK COUPLER	26	02
25	0503018033	37 X R.7/8 UNF 90° JIC MALE CONNECTOR WITH ROTATING NUT		04
26	0501080454	1/2 X 170" TR-TR HOSE ASSY		01
27	0531052049	SEED ENGINE LEFT CHAIN COVER	96	01

Item	Code	Description	See page	QT
28	0531052051	COVER MOTOR HYDRAULIC	97	01
29	0503013849	1/4" UNC X 3/4" BOLT		06
30	0503010305	FLAT WASHER		06
31	0503011828	FLAT WASHER		04
32	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		08
33	0531056315	LEFT FERTILIZER HYDRAULIC MOTOR COVER WITH RIVET		01
34	0531056316	HYDRAULIC MOTOR COVER RIGHT FERTILIZER WITH RIVET		01
35	0501212318	GLOVE ENCODER		02
36	0503011807	SCREW M8 X 1,25X10		01
37	0503015162	M 8 X 1,25 X 20 BOLT		02
38	0531064938			02
39	0501080283	HOSE 1/2 X 2600 TC-TC		01
40	0501080827	1/2" X 90.55" TR-TR HOSE		01
41	0521056480	HOSE 1/2 X 5500 TC-TM GRAY / BLUE		01
41A	0501082246	1/2 X 5500 TC-TM HOSE		01
41B	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
41C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
41D	0503018952	PLASTIC BOLT		06
42	0501080827	1/2" X 90.55" TR-TR HOSE		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CS PC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	100	01
15	0511051434	TRANSMISSION ACTUATOR	101	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	102	01
17	0521043316	RIGHT GEAR BOX ASSY	103	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064448	GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	112	01
31	0521055217	LOWER CURRENT STRETCH	113	01


Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	114	01
33	0521055216	BEARING WITH GEAR	115	01
34	0521055218	BEARING GEAR WITH DOUBLE	116	01
35	0501055112	MICRO GRANULATED CHAIN TENSIONER	117	01
36	0503012204	40-1 CHAIN X 82 LINK + RED		01
37	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
38	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
39	0503014907	40-1 X 151 CHAIN LINK + MENDING		01



Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CS G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER	01	
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
03	0503010060	1/2 UNC G.5 ZN HEX NUT	01	
04	0521017590	GUIDE AXLE	01	
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING	01	
06	0502012009	DRIVING AXLE RIGHT FOLLOWER	01	
07	0501019734	FLAT WASHER	02	
08	0502010710	RIGHT CAM, SMALLER	02	
09	0503010003	1845 GREASE FITTING	02	
10	0502012539	26Z P12,7 GEAR	01	
11	0501019735	FLAT WASHER	01	
12	0521017593	FLAT WASHER	01	
13	0503010542	501045 CLAMPING RING (FOR AXLE)	01	

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	104	01
02	0511059266	CLOSED BEARING	105	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	107	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	109	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	110	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	111	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	106	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	108	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0521018933	CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501011234	5/8" X 3" BOLT		01
02	0531017086	50 AXLETIGHTENER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0503019356	BEARING 6005 2RS1		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0503016460	5/8" X 4.1/2" BOLT		01
02	0551019175	DOUBLE GEAR AXLE		01
03	0503019356	BEARING 6005 2RS1		02
04	0511069680	20Z X 28Z DOBLE GEAR		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0571011442	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	100	01
14A	0503031825	AXLE MOTOR SLOW-MOVING		02
14B	0503010240	BOLT		02
14C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
14D	0503010337	5/16" NUT		02
15	0511051434	TRANSMISSION ACTUATOR	101	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	102	01
17	0521043316	RIGHT GEAR BOX ASSY	103	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064448	GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01

Item	Code	Description	See page	QT
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	112	01
30A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
30B	0503031805	11Z 1/2" GEAR		01
30C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
30D	0503010019	1/2" SPRING WASHER		01
30E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	123	01
31A	0511062169	21Z P 1/2" GEAR		01
31B	0503011410	ROLLER BEARING		01
31C	0503011105	SEAL RING		01
31D	0531017086	50 AXLETIGHTENER		01
31E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
31F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
31G	0501012140	FLAT WASHER		01
31H	0503010027	5/8 SPRING WASHER		01
31I	0503010013	5/8 NUT		01
32	0501058254	UPPER SEED CHAIN TENSIONER	114	01
32A	0503031805	11Z 1/2" GEAR		01
32B	0503010302	501019 SEAL RING		01
32C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
32D	0503010019	1/2" SPRING WASHER		01
32E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
32F	0521018933	CHAIN TENSIONER AXLE		01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	124	01
33A	0511062169	21Z P 1/2" GEAR		01
33B	0503011410	ROLLER BEARING		01
33C	0503011105	SEAL RING		01
33D	0531017086	50 AXLETIGHTENER		01
33E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
33F	0501011234	5/8" X 3" BOLT		01
33G	0503012412	5/8" UNC SELF LOCKING NUT		01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	125	01
34A	0511069680	20Z X 28Z DOBLE GEAR		01
34B	0503011410	ROLLER BEARING		02
34C	0551019175	DOUBLE GEAR AXLE		01
34D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
34E	0503016460	5/8" X 4.1/2" BOLT		01
34F	0503012412	5/8" UNC SELF LOCKING NUT		01
35	0503012204	40-1 CHAIN X 82 LINK + RED		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01
39	0501055112	MICRO GRANULATED CHAIN TENSIONER	117	01
39A	0531019479	AXLE CHAIN GEAR		01
39B	0503031805	11Z 1/2" GEAR		01
39C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
39D	0503010019	1/2" SPRING WASHER		01
39E	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	100	01
15	0511051434	TRANSMISSION ACTUATOR	101	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	120	01
17	0521043317	LEFT GEAR BOX ASSY	121	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064448	GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	112	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	123	01


Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	114	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	124	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	125	01
35	0501055112	MICRO GRANULATED CHAIN TENSIONER	117	01
36	0503012204	40-1 CHAIN X 82 LINK + RED		01
37	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
38	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
39	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	122	01
02	0511059266	CLOSED BEARING	105	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	107	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	109	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	110	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	111	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01



Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501011234	5/8" X 3" BOLT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019175	DOUBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503016460	5/8" X 4.1/2" BOLT		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0571011442	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	100	01
14A	0503031825	AXLE MOTOR SLOW-MOVING		02
14B	0503010240	BOLT		02
14C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
14D	0503010337	5/16" NUT		02
15	0511051434	TRANSMISSION ACTUATOR	101	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	120	01
17	0521043317	LEFT GEAR BOX ASSY	121	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064448	GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01


LEFT TRANSMISSION ASSY 5950

0511056819


Item	Code	Description	See page	QT
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	112	01
30A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
30B	0503031805	11Z 1/2" GEAR		01
30C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
30D	0503010019	1/2" SPRING WASHER		01
30E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	123	01
31A	0511062169	21Z P 1/2" GEAR		01
31B	0503011410	ROLLER BEARING		01
31C	0503011105	SEAL RING		01
31D	0531017086	50 AXLETIGHTENER		01
31E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
31F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
31G	0501012140	FLAT WASHER		01
31H	0503010027	5/8 SPRING WASHER		01
31I	0503010013	5/8 NUT		01
32	0501058254	UPPER SEED CHAIN TENSIONER	114	01
32A	0503031805	11Z 1/2" GEAR		01
32B	0503010302	501019 SEAL RING		01
32C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
32D	0503010019	1/2" SPRING WASHER		01
32E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
32F	0521018933	CHAIN TENSIONER AXLE		01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	124	01
33A	0511062169	21Z P 1/2" GEAR		01
33B	0503011410	ROLLER BEARING		01
33C	0503011105	SEAL RING		01
33D	0531017086	50 AXLETIGHTENER		01
33E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
33F	0501011234	5/8" X 3" BOLT		01
33G	0503012412	5/8" UNC SELF LOCKING NUT		01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	125	01
34A	0511069680	20Z X 28Z DOBLE GEAR		01
34B	0503011410	ROLLER BEARING		02
34C	0551019175	DOUBLE GEAR AXLE		01
34D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
34E	0503016460	5/8" X 4.1/2" BOLT		01
34F	0503012412	5/8" UNC SELF LOCKING NUT		01
35	0503012204	40-1 CHAIN X 82 LINK + RED		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01
39	0501055112	MICRO GRANULATED CHAIN TENSIONER	117	01
39A	0531019479	AXLE CHAIN GEAR		01
39B	0503031805	11Z 1/2" GEAR		01
39C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
39D	0503010019	1/2" SPRING WASHER		01
39E	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0531058988	WORM THREAD P.16 WITH FERTILIZER DOSING SHAFT COATING		10
01A	0531065012	WORM THREAD P.16MM ALPHA FERTILIZER DOSER		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		10
02A	0501111196	PALLETIZED FERTILIZER COATING COMPLETE PLANTING FERTILIZER DOSER ALP II		01
02B	0531058987	WORM SCREW P.50 WITH ADB ALPHA DISPENSER SHAFT COATING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	WORM THREAD P.16 WITH FERTILIZER DOSING SHAFT COATING		12
01A	0531065012	WORM THREAD P.16MM ALPHA FERTILIZER DOSER		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		12
02A	0501111196	PALLETIZED FERTILIZER COATING COMPLETE PLANTING FERTILIZER DOSER ALP II		01
02B	0531058987	WORM SCREW P.50 WITH ADB ALPHA DISPENSER SHAFT COATING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01



Item	Code	Description	See page	QT
01	0521053227	FRONT LEFT SHORT SEED ROW	130	01
02	0521053230	FRONT RIGHT SHORT SEED ROW	138	01
03	0521053228	FRONT LEFT LONG SEED ROW	139	01
04	0521053229	FRONT RIGHT LONG SEED ROW	140	01
05	0521054736	FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED ROW	141	01
06	0503010019	1/2" SPRING WASHER		01
07	0511059333	SEMI-ASSEMBLED MECHANICAL FRAME	142	01
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
09	0503010019	1/2" SPRING WASHER		01
10	0503010060	1/2 UNC G.5 ZN HEX NUT		01
11	0521054771	LEFT REAR SEED ROW	145	01
12	0521054770	RIGHT REAR SEED ROW	153	01
13	0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	156	01
14	0521054811	FERTILIZER SHORT ROW	164	01
15	0521054812	LONG FERTILIZER ROW	169	01
16	0521054769	LEFT DDD FERTILIZER WITH SUPPORT	171	01
17	0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	173	01
18	0531055312	TITANIUM SINGLE SEED SYSTEM	175	01
19	0511052024	FAST CLOSING SET	178	01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01
21	0503030391	RIGHT FERTILIZER NOZZLE		01
22	0503030392	LEFT FERTILIZER NOZZLE		01
23	0503031050	CURVED CONDUCTOR		01
24	0503010246	CLAMP		01
25	0503031076	2" HOSE CLAMP		01
26	0503031145	2" X 2" X 20" HOSE		01
27	0531059865	RIGHT SEED CONDUCTOR WITH PROTECTION		01
27A	0501310971	SEED CONDUCTOR RIGHT 3 X 1500		01
27B	1164930001	BLACK VINYL TUBE 3.1/2		02
28	0531050237	SEED CONDUCTOR FIXER 3 CSU RIGHT	179	01
29	0531013600	PRESS ADJUSTMENT LEVER		01

Item	Code	Description	See page	QT
30	0521053946	SCARING ROD	180	01
31	0511017969	0.1" SPACING PLATE		01
32	0521069127	BOTTOM NOZZLE FERTILIZER		01
33	0503030483	FERTILIZER SOCKET		01
34	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
35	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
36	0503010025	3/8 SPRING WASHER		01
37	0503010026	3/8" NUT		01
38	0503062066	DISC SET WITH CORN RING	181	01
39	0503062067	DISC SET / RING SOY 90F TITANIUM	182	01
40	0503033672	NOZZLE WITHOUT TITANIUM		01
41	0521057957	FIXED ROD EXTENSION WITH FIXATION	183	01
42	0521068982	DISC BLADE HUB KEY		01
43	0503010905	1/2" X 2-1/4" BOLT		01
44	0511018662	SPACING PLATE		01



Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	SEED ROW BEARING	131	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED ROW TRANSMISSION HUB	132	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	133	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	134	01
20	0521064651	LEFT SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	136	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED ROW		01
31	0581017624	SPACING SLEEVE		06


FRONT LEFT SHORT SEED ROW

0521053227


Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08

SEED ROW BEARING


0521055213




Item	Code	Description	See page	QT
01	0502012718	ROW BEARING		01
02	0503019355	BEARING 6202 2RS1		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503019361	BEARING 6006 RS1		02
04	0503019363	BEARING 6005		01
05	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503019362	BEARING 6005 RS1		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501059326	UNIVERSAL JOINT AXLE		01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	135	01




Item	Code	Description	See page	QT
01	0501059363	5/8" HEX AXLE BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0502012819	17Z GEAR WITH HEX HOLE		01
02	0521055220	BEARING FRONT SEED ROW	137	01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011697	GEARBOX BEARING		01
02	0503019356	BEARING 6005 2RS1		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
03	0521055213	SEED ROW BEARING	131	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED ROW TRANSMISSION HUB	132	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	133	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	134	01
20	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	136	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED ROW		01
31	0581017624	SPACING SLEEVE		06



FRONT RIGHT SHORT SEED ROW

0521053230

Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	SEED ROW BEARING	131	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED ROW TRANSMISSION HUB	132	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	133	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	134	01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	136	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED ROW		01
31	0581017624	SPACING SLEEVE		06



FRONT LEFT LONG SEED ROW

0521053228


Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08



Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0521061427	SHORT SEED ROW FRAME		01
03	0521055213	SEED ROW BEARING	131	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED ROW TRANSMISSION HUB	132	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	133	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055226	BEARING WITH AXLE JOINT	134	01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	136	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED ROW		01
31	0581017624	SPACING SLEEVE		06



Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	SEED ROW BEARING	131	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	5/16" NUT		04
08	0521055223	SEED ROW TRANSMISSION HUB	132	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" COTTERPIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" COTTERPIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	133	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	136	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED ROW		01
31	0581017624	SPACING SLEEVE		06




PST DUO FLEX TITANIUM - FRAME 4880/5950 - CSU - APT
FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED ROW

Page 141
0521054736


Item	Code	Description	See page	QT
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0521066496	FRAME MECHANICAL CENTRAL SEED ROW		01
02	0511059334	BEARING WITH LONG FRONT AXLE	143	01




Item	Code	Description	See page	QT
01	0511058143	UNIVERSAL JOINT AXLE	144	01
02	0503010071	3/16" X 1" COTTERPIN		01
03	0521055227	BEARING SHAFT HEX	135	01




Item	Code	Description	See page	QT
01	0561014794	350 AXLE HEX		01
02	0501056296	UNIVERSAL JOINT		01
03	0503011855	0.2" X 1.8" SPRING PIN		02
04	0581010483	HEX AXLE		01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	146	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521055871	LEFT DOUBLE DISC SEED 15 X 15	147	01




Item	Code	Description	See page	QT
01	0581019201	CROWN SHAFT		01
02	0503019340	LUBRICANT SLEEVE		02
03	0503011030	2-014 N 3006-9B O'RING		02
04	0581019200	CONICA 40Z GEAR		01
05	0581019199	FIXED BASE		01
06	0581019202	PINHAO CONICO 10Z X 5/8		01
07	0501013354	FLAT WASHER		01
08	0503010410	RING		02
09	0503019341	LUBRICANT SLEEVE		01




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	148	01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
06	0503010026	3/8" NUT		01
07	0503010025	3/8 SPRING WASHER		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 149 FERTILIZER / SEED		01
09	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 151 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	150	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUB DISC - HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	152	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	146	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521055870	RIGHT DOUBLE DISC SEED 15 X 15	154	01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	155	01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
06	0503010026	3/8" NUT		01
07	0503010025	3/8 SPRING WASHER		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 149 FERTILIZER / SEED		01
09	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 151 FERTILIZER / SEED		01



Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	157	01
02	0521055068	RAYED WHEEL CENTER CLOSED	159	02
03	0521054990	LEFT COMPACTOR WHEEL	161	01
04	0521055017	RIGHT COMPACTOR WHEEL	163	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY	158	01
06	0503019398	AXLE RETAINER RING		01
07	0521055033	SEMI-ASSEMBLED COMPACTOR BODY		01
08	0521055054	LEFT ARM WITH SLEEVE		01
09	0521055066	RIGHT ARM WITH SLEEVE		01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2 UNC G.5 ZN HEX NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED SLEEVE		02
20	0503010045	O'RING		02

DEPTH WHEELS REGULATOR ASSY


0501056769




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521055055	HUB WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	160	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0581019522	CASE WHEEL DEPTH WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0503010143	1/4" SPRING WASHER		03
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019529	DEPTH REGULATOR SHAFT		01
11	0581019168	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	162	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05



Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	162	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0501010066	3/4" X 9" BOLT		01
02	0511017232	FLAT WASHER		02
03	0503011255	3/4" LOCK NUT		01
04	0502012873	SUPPORT DC FERTILIZER ROW		01
05	0503019278	LUBRICANT SLEEVE		02
06	0581019195	SIDE GUIDE SLEEVE		02
07	0581019196	CENTRAL GUIDE SLEEVE		01
08	0503010410	RING		02
09	0502012876	CLAMP		01
10	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
11	0503010013	5/8 NUT		02
12	0521054906	SPRING ASSY FERTILIZER	165	01
13	0521053231	DPL 20 SHORT ROW WITHOUT LUBRICATION CONICAL BEARING	166	01
14	0521066231	SHORT FERTILIZER ROW ARM		01
15	0503017857	BOLT 5/8 UNF 4		03
16	0503010811	5/8" UNF SELF ADJUSTING NUT		03

SPRING ASSY FERTILIZER


0521054906




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK		02
02	0502012184	FERTILIZER SPRING GUIDE		02
03	0503031910	1.7" X 22.8" X 0.3" SPRING		01
04	0502012510	SPRING ROD SUPPORT		01
05	0591018219	JUNCTION SHAFT 12.70 X 109 ZN		01
06	0501018535	1/2 X 1 BOLT		02
07	0503030678	BOLT 1/2 UNC X 1.1/2 C50P G.5 ZN		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		02
09	0502010891	SPRING ROD SUPPORT CHOCK		01
10	0503010014	3/4" HEX NUT		01
11	0521067619	FERTILIZER ROW TUBE		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0501010937	13,50 X 28 X 3,00 FLAT WASHER		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	167	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	THRUST WASHER		01
08	0521068887	DC RIGHT ARM WITH SLEEVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH SLEEVE		01
17	0503019272	LUBRICANT SLEEVE		02
18	0503010390	SEAL RING		02
19	0581017628	LID		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	DISC BLADE FIXED AXLE		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	DISC BLADE HUB	168	01




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	DISC BLADE HUB		01
09	0502040873	DISC BLADE AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02



Item	Code	Description	See page	QT
01	0501010066	3/4" X 9" BOLT		01
02	0511017232	FLAT WASHER		02
03	0503011255	3/4" LOCK NUT		01
04	0502012873	SUPPORT DC FERTILIZER ROW		01
05	0503019278	LUBRICANT SLEEVE		02
06	0581019195	SIDE GUIDE SLEEVE		02
07	0581019196	CENTRAL GUIDE SLEEVE		01
08	0503010410	RING		02
09	0502012876	CLAMP		01
10	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
11	0503010013	5/8 NUT		02
12	0521054906	SPRING ASSY FERTILIZER	165	01
13	0521053232	DPL 20 LONG ROW WITHOUT LUBRICATION CONICAL BEARING	170	01
14	0521066230	LONG FERTILIZER ROW ARM		01
15	0503017857	BOLT 5/8 UNF 4		03
16	0503010811	5/8" UNF SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	167	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	THRUST WASHER		01
08	0521068887	DC RIGHT ARM WITH SLEEVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH SLEEVE		01
17	0503019272	LUBRICANT SLEEVE		02
18	0503010390	SEAL RING		02
19	0581017628	LID		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	DISC BLADE FIXED AXLE		01




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC	172	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04

LEFT DUAL FERTILIZER DISC

0521055869




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 149 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 151 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC	174	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04

RIGHT DUAL FERTILIZER DISC


0521055868




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 149 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 151 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0511052058	SEED SYSTEM TITANIUM	176	01
02	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
03	0503010337	5/16" NUT		05
04	0501010694	FLAT WASHER		05
05	0503010358	5/16" X 5/8" BOLT		05
06	0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	177	01




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
09.	0503016279	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01
14	0503062044	ASSEMBLY SEED HOPPER SET		01
14A	0503016285	BOLT		05
14B	0503016286	HEX NUT		05
14C	0503016287	FLAT WASHER		05



Item	Code	Description	See page	QT
01	0503015536	M6 X 1" SELF ADJUSTING NUT	04	
02	0581014295	FIXING SLEEVE	01	
03	0501213431	SEED NOZZLE FIXING FLANGE	01	
04	0501213520	SEED BREAKER BODY	01	
05	0501213432	BREAKER SUPPORT BASE	01	
06	0501213728	60 X 53 X 30 PVC TUBE	01	
07	0513010720	M6 X 1 X 35 C S G.5 ZB BOLT	04	
08	0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK LID	01	




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0503013759	NUT		02
02	0501010694	FLAT WASHER		02
03	0502012979	CLAMP 3 RIGHT CSU		02
04	0503010421	5/16" X 1-1/2" BOLT		02

SCARING ROD


0521053946




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070085	FIXED ROD BEARING		01
03	0513010288	ELASTIC PIN 701211 10 X 24		02
04	0513010289	ELASTIC PIN 701211 10 X 24		02




Item	Code	Description	See page	QT
01	0503016204	CORN DISC 12 ORANGE		01
02	0503016398	TITANIUM RING CORN / SOY (YELLOW FLAT)		01
03	0503016399	TITANIUM RING CORN (GREEN)		01
04	0503016400	TITANIUM RING CORN (GREY)		01
05	0503016401	TITANIUM RING CORN (BLUE)		01



Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016218	DISC OF SOYBEAN		01
03	0503016403	TITANIUM RING FOR SOYBEAN (LILAC)		01
04	0503016404	TITANIUM RING FOR SOYBEAN (PURPLE)		01
05	0503016406	TITANIUM RING FOR SOYBEAN (ORANGE)		01
06	0503016407	TITANIUM RING FOR SOYBEAN		01



Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

LORENA ROCHA ALVES

www.marchesan.com.br

