

ROW CROP PLANTERS

PST4 - FRAME 4045/4495/4845/5345 - CSU (FROM 05/2023)

Code: 0501093552
Series: S-0116
Revision: 00
Date Revision: MAIO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111151260	PST4 4045/8E500 CI MH DC20 CSU S-0116
0111151158	PST4 4045/9E450 CPRA MH CSU S-0116
0111151171	PST4 4045/9E450 CSU S-0116
0111151155	PST4 4045/9E450 MH CSU S-0116
0111151174	PST4 4495/10E450 CI MH CSU S-0116
0111151233	PST4 4495/10E450 ESPECIAL S-0116
0111151236	PST4 4495/10E450 ESPECIAL S-0116
0111151222	PST4 4495/9E500 CI MH DC20 CSU S-0116
0111151173	PST4 4845/10E500 CI MH DC20 PM400 CSU S-0116
0111151156	PST4 4845/10E500 H MH DC20 CSU S-0116
0111151284	PST4 4845/11E450 ESPECIAL S-0116
0111151132	PST4 4845/11E450 MH CSU S-0116
0111151161	PST4 5345/12E450 MH CSU S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909096733	ASSY FRAME	1
0501058195	FRAME WITH AXLE WHEEL - 4045	2
0511050836	WHEEL AXLE FRAME - 4495	3
0501058196	WHEEL AXLE FRAME - 4845	4
0511051118	WHEEL AXLE FRAME - 5345	5
0511057124	CYLINDER ASSY	6
0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	7
0511056529	CYLINDER ASSY	8
0511058406	HYDRAULIC CYLINDER	9
0511056536	LADDER ASSEMBLY	10
0511054971	JACK ASSEMBLY	11
0511057131	MANUAL CANISTER ASSY	12
0531057800	LABEL SET - 4045	13
0531057101	LABEL SET - 4495	14
0531057770	LABEL SET - 4845	15
0531057806	LABEL SET - 5345	16
0511057142	DRAWBAR ASSEMBLY - 3245/3695/4045/4495	17
0511057150	DRAWBAR ASSEMBLY - 4845/5345	18
0511057130	HANDRAIL ASSY - 4045	19
0511057566	HANDRAIL ASSY - 4495	20
0511057651	HANDRAIL ASSY - 4845	21
0511058308	HANDRAIL ASSY - 5345	22
0511058101	ASSEMBLY CSU C3 SEMI MOUNTED 4045/4495	23
0511058100	2 HOPPERS WITH 9 CONDUCTORS SET	24
0511057690	3" ARTICULATED SEED CONDUCTOR	25
0521051927	TOWER SUPPORT HOPPER	26
0511059585	ASSEMBLY CSU C3 SEMI MOUNTED 4880	27
0511059584	2 HOPPERS WITH 10 CONDUCTORS SET	28
0521052687	RIGHT SUPPORT TOWER WITH BOLT	29
0521051931	LEFT SUPPORT TOWER WITH BOLT	30
0511059792	CSU C3 SEMI-ASSEMBLED ASSY 4045/4495 8	31
0511059790	CSU C3 2 HOPPERS ASSEMBLY	32
0511057736	CSU C3 SEMI-ASSEMBLED ASSY 4845/10	33
0511057737	2 HOPPERS WITH 10 CONDUCTORS SET	34
0511059318	CSU C3 SEMI-ASSEMBLED ASSY 5950/12	35
0511058724	2 HOPPERS WITH 12 CONDUCTORS ASSEMBLY	36
0511057129	PLATFORM ASSY - 4045	37
0511057565	PLATFORM ASSY - 4495	38
0511057650	PLATFORM ASSY - 4845	39
0511058312	PLATFORM ASSY - 5345	40
0531056602	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4045	41
0531056599	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4045	42
0531056598	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4045	43
0531055319	ALPHA II FERTILIZER METERING	44
0531055863	ASSY TRANSMISSION HUB	45
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	46
0531059139	ASSY COLLECTOR	47
0531055273	ALPHA FERTILIZER METERING CLAMP	48
0501053788	3/4 SQUARE AXLE FASTENER	49
0531057911	22Z GEAR SIDE BEARING ASSEMBLY	50
0531057901	GEAR	51
0531056757	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4495	52
0531056760	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4495	53



MARCHESAN

INDEX

0531056759	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4495	54
0531056603	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4845	55
0531056604	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4845	56
0531056605	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4845	57
0531056921	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 5345	58
0531056920	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 5345	59
0531056919	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 5345	60
0501058170	SEMI-ASSEMBLED HYDRAULIC MARKER 4045	61
0511058449	HYDRAULIC CYLINDER	62
0501054649	HBM SEQUENTIAL VALVE	63
0511057095	HYDRAULIC MARKER HOSE KIT	64
0501053834	MALE QUICK COUPLER	65
0511050838	SEMI-ASSEMBLED HYDRAULIC MARKER 4495	66
0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845	67
0511051119	SEMI-ASSEMBLED HYDRAULIC MARKER 5345	68
0501050633	ROW MARKER DISC ASSEMBLY	69
0511053904	ROW MARKER DISC	70
0511058597	RIGHT TRANSMISSION ASSY - 4045	71
0501052560	MOTOR AXLE SIGNAL	72
0511051434	TRANSMISSION ACTUATOR	73
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	74
0521043316	RIGHT GEAR BOX ASSY	75
0501058212	SEMI MOUNTED RIGHT CHANGE	76
0511059266	CLOSED BEARING	77
0501056271	GEARBOX CLOSED BEARING	78
0501056443	GEAR HOUSING BEARING	79
0501056444	BEARING WITH ROLLER	80
0501048790	AXLE WITH RING	81
0501054655	CHAIN TENSIONER ASSY	82
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	83
0511054363	CHAIN TENSIONER	84
0501058234	LOWER CHAIN TENSIONER	85
0501058235	STRETCHER CURRENT TOP SEED 17Z	86
0501058236	BEARING WITH 21Z GEAR	87
0501058237	16Z GEAR BEARING	88
0501055112	MICRO GRANULATED CHAIN TENSIONER	89
0511058970	RIGHT TRANSMISSION ASSY - 4495	90
0511056740	RIGHT TRANSMISSION ASSY - 4880	91
0521050178	RIGHT TRANSMISSION ASSY - 5345	92
0511058598	LEFT TRANSMISSION ASSY - 4045	93
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	94
0521043317	LEFT GEAR BOX ASSY	95
0501058213	LH GEAR BOX	96
0511058971	LEFT TRANSMISSION ASSY - 4495	97
0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	98
0521050179	ASSY TRANSMISSION LEFT - 5345	99
0521043934	CARRYING WHEELS SPRING TRACTION	100
0501058240	WHEEL FASTENER WITH TENSIONER	101
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	102
0501058239	WHEEL CHAIN TENSIONER BEARING	103
0501058244	WHEEL FIXED CHAIN TENSIONER	104
0501058242	WHEEL MOBILE CHAIN TENSIONER	105
0501059909	CARRYING WHEELS SUPPORT	106



MARCHESAN

INDEX

0511052770	WHEEL WITH TIRE	107
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	108
0501058241	WHEEL SUPPORT CHAIN TENSIONER	109
0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	110
0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	111
0501054258	DRAWBAR ESTABILIZER ASSY	112
0511054601	HITCH ARTICULATED TRACTOR	113
0511053179	TRACTOR COUPLING SHAFT	114
0511056736	HOSE SUPPORT	115
0531059618	KIT WITH ALPHA COMPONENTS - 08 ROWS	116
0531059619	KIT WITH ALPHA COMPONENTS - 09 ROWS	117
0531059620	KIT WITH ALPHA COMPONENTS - 10 ROWS	118
0531059621	KIT WITH ALPHA COMPONENTS - 11 ROWS	119
0531059622	KIT WITH ALPHA COMPONENTS - 12 ROWS	120
0909095145	ASSY HEX AXLE	121
0511058368	EAR MOVABLE	122
0511056394	11 ROWS SEED MONITORING SET	123
0909096734	ASSY SEED/FERTILIZER ROW	124
0511053252	FERTILIZER SHORT ROW WITH LEFT DDD/18" DC	125
0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	126
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	127
0511053172	LEFT LOW HUB WITH 15 DISC	128
0511053173	RIGHT LOW HUB WITH 15 DISC	129
0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	130
0501058423	FERTILIZER ROD SPRING ROW	131
0511053254	FERTILIZER SHORT ROW WITH LEFT DDD/20" DC	132
0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	133
0521054680	20" DISC BLADE HUB	134
0521054679	DISC BLADE HUB	135
0511053253	FERTILIZER LONG ROW WITH RIGHT DDD/18" DC	136
0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	137
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	138
0511044573	18" COULTER BLADE ASSY FOR LONG ROW	139
0521054686	18" DISC BLADE HUB	140
0511053255	FERTILIZER LONG ROW WITH RIGHT DDD/20" DC	141
0511044585	20" COULTER BLADE ASSY FOR LONG ROW	142
0521053154	FERTILIZER SHORT HIGH ROW WITH LEFT DDD/18" DC	143
0521053152	SHORT ARM WITH LEFT DDD	144
0511058617	DISC CUT 18 SHORT LINE	145
0511056909	DISC BLADE HUB WITHOUT DISC	146
0511056910	HUB WITH 18" DISC BLADE	147
0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	148
0521058872	FERTILIZER SHORT HIGH ROW WITH DAOC/20" DC	149
0521058870	SUPORT RIGHT BOX	150
0521058868	BOX ASSY	151
0521050168	MOUNTED FERTILIZER CONDUCTOR	152
0511058619	20" SHORT ROW DISC BLADE	153
0511058648	HUB WITH 20" DISC BLADE	154
0521053153	FERTILIZER LONG HIGH ROW WITH RIGHT DDD/18" DC	155
0521053151	LONG ARM WITH RIGHT DDD	156
0511058618	DISC CUT 18 LONG LINE	157
0521058873	FERTILIZER LONG HIGH ROW WITH DAOC/20" DC	158
0521058871	RIGHT SUPPORT	159
0521058869	BOX ASSY	160
0511058620	20" LONG ROW DISC BLADE	161




MARCHESAN

INDEX

0521046122	DEPTH SYSTEM / COMPACTOR ASSY	162
0511058650	SEMI-MOUNTED DEPTH CONTROL	163
0511058652	LEFT DEPTH WHEEL ARM WITH HUB	164
0501052627	ASSY DEPTH WHEEL HUB	165
0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	166
0501052538	DEPTH BAND WITH ARMS	167
0511054333	COMPACT WHEEL RIGHT WITH BEARING	168
0501052908	COMPACTOR WHEEL WITH BEARING	169
0511054334	COMPACT WHEEL LEFT WITH BEARING	170
0521056317	DEPTH CONTROL WITH LEVER ANGLE REGULATOR AXIS CPERA	171
0501052297	DEPTH WHEELS REGULATOR ASSY	172
0521056316	DEPTH WHEEL HUB WITH COMPLETE ANGLE ADJUSTING AXLE	173
0521056314	LEFT ARM WHEEL DEPTH WITH HUB CPERA	174
0521056313	RIGHT ARM WHEEL DEPTH WITH HUB CPERA	175
0511055819	DEPTH BAND WITH RIM	176
0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	177
0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	178
0511059325	LEFT ARM COVERED WHEEL ASSEMBLED	179
0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED	180
0511051546	RIGHT DEPTH CONTROL HUB	181
0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	182
0511051547	LEFT DEPTH CONTROL HUB	183
0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	184
0531054165	SHORT SEED ROW	185
0511056600	RIGHT DDD SHORT SEED ROW FRONT	186
0511051693	BASE FIXING SYSTEM	187
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	188
0511052301	SUPPORT DDD 15 RIGHT	189
0511058212	FERTILIZER ROW SUPPORT ASSY	190
0511052024	FAST CLOSING SET	191
0521059094	SIGMA SOY SINGLE SEED SYSTEM	192
0531051514	SIGMA SOY SEED SYSTEM	193
0511057289	ASSY SEED DEFLECTOR	194
0531054166	LONG SEED ROW	195
0511056601	LONG SEED ROW FRONT DDD LEFT	196
0531054159	HIGH SHORT SEED ROW	197
0521052840	SHORT PIVOTING HIGH ROW	198
0511059244	SEED ROW SPRING ROD	199
0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	200
0511059350	FERTILIZER ROW SUPPORT ASSEMBLY	201
0531054160	HIGH LONG SEED ROW	202
0521052841	LONG PIVOTING HIGH ROW	203
0511056586	15 X 15 SEED DDD LEFT	204
0511052302	LH SUPPORT DDD GUIDE	205
0521052631	HDA HIGH AUTOMATIC DISARM	206
0521050364	ROD WITH BEAK	207
0521050525	FIXER FERTILIZER CONDUCTOR	208

ASSY FRAME

0909096733




Item	Code	Description	See page	4045	4495	4845	5345
01	0501058195	FRAME WITH AXLE WHEEL - 4045	2	01	00	00	00
01.	0511050836	WHEEL AXLE FRAME - 4495	3	00	01	00	00
01..	0501058196	WHEEL AXLE FRAME - 4845	4	00	00	01	00
01...	0511051118	WHEEL AXLE FRAME - 5345	5	00	00	00	01
02	0503010003	1845 GREASE FITTING		04	04	06	06
03	0511057124	CYLINDER ASSY	6	01	01	00	00
03.	0511056529	CYLINDER ASSY	8	00	00	01	01
04	0521013022	TRANSPORT LOCK		01	01	02	02
05	0501068994	8,30 X 78 LOCK PIN		01	01	02	02
06	0503030168	HITCH PIN CLIP		01	01	02	02
07	0511056536	LADDER ASSEMBLY	10	02	02	02	02
08	0511054971	JACK ASSEMBLY	11	02	02	02	02
09	0511057131	MANUAL CANISTER ASSY	12	01	01	01	01
10	0531057800	LABEL SET - 4045	13	01	00	00	00
10.	0531057101	LABEL SET - 4495	14	00	01	00	00
10..	0531057770	LABEL SET - 4845	15	00	00	01	00
10...	0531057806	LABEL SET - 5345	16	00	00	00	01
11	0511057142	DRAWBAR ASSEMBLY - 3245/3695/4045/4495	17	01	01	00	00
11.	0511057150	DRAWBAR ASSEMBLY - 4845/5345	18	00	00	01	01
12	0511057130	HANDRAIL ASSY - 4045	19	01	00	00	00
12.	0511057566	HANDRAIL ASSY - 4495	20	00	01	00	00
12..	0511057651	HANDRAIL ASSY - 4845	21	00	00	01	00
12...	0511058308	HANDRAIL ASSY - 5345	22	00	00	00	01
13	0511058101	ASSEMBLY CSU C3 SEMI MOUNTED 4045/4495	23	01	01	00	00
13.	0511059585	ASSEMBLY CSU C3 SEMI MOUNTED 4880	27	00	01	00	00
13..	0511059792	CSU C3 SEMI-ASSEMBLED ASSY 4045/4495 8	31	01	00	00	00
13...	0511057736	CSU C3 SEMI-ASSEMBLED ASSY 4845/10	33	00	00	01	00
13....	0511059318	CSU C3 SEMI-ASSEMBLED ASSY 5950/12	35	00	00	00	01
14	0511057129	PLATFORM ASSY - 4045	37	01	00	00	00
14.	0511057565	PLATFORM ASSY - 4495	38	00	01	00	00
14..	0511057650	PLATFORM ASSY - 4845	39	00	00	01	00


ASSY FRAME

0909096733


Item	Code	Description	See page	4045	4495	4845	5345
14...	0511058312	PLATFORM ASSY - 5345	40	00	00	00	01
15	0531056602	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4045	41	01	00	00	00
15.	0531056757	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4495	52	00	01	00	00
15..	0531056603	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4845	55	00	00	01	00
15...	0531056921	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 5345	58	00	00	00	01
16	0501058170	SEMI-ASSEMBLED HYDRAULIC MARKER 4045	61	01	01	00	00
16.	0511050838	SEMI-ASSEMBLED HYDRAULIC MARKER 4495	66	00	01	00	00
16..	0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845	67	00	00	01	01
16...	0511051119	SEMI-ASSEMBLED HYDRAULIC MARKER 5345	68	00	00	00	01
17	0501050633	ROW MARKER DISC ASSEMBLY	69	02	02	02	02
18	0511058597	RIGHT TRANSMISSION ASSY - 4045	71	01	00	00	00
18.	0511058970	RIGHT TRANSMISSION ASSY - 4495	90	00	01	00	00
18..	0511056740	RIGHT TRANSMISSION ASSY - 4880	91	00	00	01	00
18...	0521050178	RIGHT TRANSMISSION ASSY - 5345	92	00	00	00	01
19	0511058598	LEFT TRANSMISSION ASSY - 4045	93	01	00	00	00
19.	0511058971	LEFT TRANSMISSION ASSY - 4495	97	00	01	00	00
19..	0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	98	00	00	01	00
19...	0521050179	ASSY TRANSMISSION LEFT - 5345	99	00	00	00	01
20	0521043934	CARRYING WHEELS SPRING TRACTION	100	04	04	04	04
21	0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	110	01	01	00	00
21.	0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	111	00	00	01	01
22	0501065677	STRUT		02	02	02	02
23	0521013164	EXTENSOR		00	00	02	02
24	0501011310	FIXER LOCK		00	00	08	08
25	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		00	00	04	04
26	0503010019	1/2" SPRING WASHER		00	00	04	04
27	0503010060	1/2 UNC G.5 ZN HEX NUT		00	00	04	04
28	0501054258	DRAWBAR ESTABILIZER ASSY	112	01	01	01	01
29	0511054601	HITCH ARTICULATED TRACTOR	113	01	01	01	01
30	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01	01	01
31	0511053179	TRACTOR COUPLING SHAFT	114	01	01	01	01
32	0511056736	HOSE SUPPORT	115	01	01	01	01
33	0501047895	25 ROD STOP		01	01	02	02
34	0501047885	30 ROD STOP		01	01	02	02
35	0501047886	35 ROD STOP		01	01	02	02
36	0501047887	40 ROD STOP		01	01	02	02
37	0531059618	KIT WITH ALPHA COMPONENTS - 08 ROWS	116	01	00	00	00
37.	0531059619	KIT WITH ALPHA COMPONENTS - 09 ROWS	117	01	00	00	00
37..	0531059620	KIT WITH ALPHA COMPONENTS - 10 ROWS	118	00	01	01	00
37...	0531059621	KIT WITH ALPHA COMPONENTS - 11 ROWS	119	00	00	01	00
37....	0531059622	KIT WITH ALPHA COMPONENTS - 12 ROWS	120	00	00	00	01
38	0503014120	CHAIN		01	01	01	01
39	0503014321	CABLE STEEL SHACKLE		02	02	02	02
40	0503010780	N-2050 AMENDMENT		02	02	02	02
41	0503011750	AMENDMENT WITH LOCK		06	06	06	06
42	0503011751	REDUCTION		06	06	06	06
43	0503010951	REDUCTION		04	04	04	04
44	0503010246	CLAMP		03	03	06	06
45	0909095145	ASSY HEX AXLE	121	01	01	01	01
46	0511058368	EAR MOVABLE	122	02	02	00	00
47	0511056394	11 ROWS SEED MONITORING SET	123	00	00	01	00
48	0511066652	400 TURNBUCKLE		01	01	01	01
49	0909096734	ASSY SEED/FERTILIZER ROW	124	01	01	01	01




Item	Code	Description	See page	QT
01	0511069529	FRAME		01
02	0511069682	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8 UNC X 2.1/4 BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8 NUT		08



Item	Code	Description	See page	QT
01	0521062243	FRAME		01
02	0521062242	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8 UNC X 2.1/4 BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8 NUT		08




Item	Code	Description	See page	QT
01	0511069616	FRAME		01
02	0511069717	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8 UNC X 2.1/4 BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8 NUT		12




Item	Code	Description	See page	QT
01	0521062442	FRAME		01
02	0521062447	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8 UNC X 2.1/4 BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8 NUT		12

CYLINDER ASSY

0511057124




Item	Code	Description	See page	QT
01	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	7	01
02	0531019171	1.25" X 7" COUPLING SHAFT		01
03	0521012536	COUPLING SHAFT		01
04	0503010523	1/4" X 2" SPLIT PIN		02
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02



Item	Code	Description	See page	QT
01	0511064055	5" X 15" CYLINDER CASE		01
02	0511064056	BUSHING 2" X 14" TURNBUCLE		01
03	0502010382	5" END CAP		01
04	0502012227	50.80 X 127 RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	1870-2000-375-B GASKET		01
07	0503010952	W2-2250-500 RING		01
08	0503010351	2-425 N 3006-9B O'RING		01
09	0503011062	8-425 BACK-UP RING		01
10	0502010963	2.0" X 5.0" PISTON		01
11	0503010552	PACKING 3750-4250-625-B		02
12	0503010345	2-218 N 3006-9B O'RING		01
13	0503010974	W2-5000-500 RING		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503010003	1845 GREASE FITTING		01
16	0503030385	CYLINDER PLUG N-002		02

CYLINDER ASSY


0511056529



Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	9	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521012536	COUPLING SHAFT		02
04	0503010523	1/4" X 2" SPLIT PIN		04
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02

HYDRAULIC CYLINDER


0511058406



Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCKLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01

LADDER ASSEMBLY


0511056536




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8 SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
08	0503013357	3/8 SELF-ADJUSTING NUT	02	

JACK ASSEMBLY


0511054971




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
07	0503033008	ADHESIVE LABEL		02
08	0503031428	READ MANUAL DECAL		01
09	0503031942	ADHESIVE LABEL		01
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
11	0503031565	ADHESIVE LABEL CARE		02
12	0503031566	ADHESIVE LABEL		02
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
14	0503031425	ADHESIVE LABEL ATTENTION		02
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503032930	ADHESIVE LABEL DANGER		05
19	0503031087	ADHESIVE LABEL		01
20	0503034078	LIFTING POINTS DECAL		03
21	0503034003	SERIAL NUMBER TAG 61 X 118		01
22	0503010001	3.2 X 5.5 RIVET		04
23	0503032979	ADHESIVE LABEL LETTERS A B C D		02
24	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
06	0503033423	LABEL ADHESIVE NUMBER 9	02	
07	0503033008	ADHESIVE LABEL	02	
08	0503031428	READ MANUAL DECAL	01	
09	0503031942	ADHESIVE LABEL	01	
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27	02	
11	0503031565	ADHESIVE LABEL CARE	02	
12	0503031566	ADHESIVE LABEL	02	
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
14	0503031425	ADHESIVE LABEL ATTENTION	02	
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER	02	
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503032930	ADHESIVE LABEL DANGER	04	
19	0503031087	ADHESIVE LABEL	01	
20	0503034078	LIFTING POINTS DECAL	03	
21	0503034003	SERIAL NUMBER TAG 61 X 118	01	
22	0503010001	3.2 X 5.5 RIVET	04	
23	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
24	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
06	0503033422	ADHESIVE LABEL	02	
07	0503033008	ADHESIVE LABEL	02	
08	0503031428	READ MANUAL DECAL	01	
09	0503031942	ADHESIVE LABEL	01	
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27	02	
11	0503031565	ADHESIVE LABEL CARE	02	
12	0503031566	ADHESIVE LABEL	02	
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
14	0503031425	ADHESIVE LABEL ATTENTION	02	
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER	02	
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503032930	ADHESIVE LABEL DANGER	06	
19	0503031087	ADHESIVE LABEL	01	
20	0503034078	LIFTING POINTS DECAL	03	
21	0503034003	SERIAL NUMBER TAG 61 X 118	01	
22	0503010001	3.2 X 5.5 RIVET	04	
23	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
24	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033417	ADHESIVE LABEL	02	
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	02	
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	04	
07	0503033008	ADHESIVE LABEL	02	
08	0503031428	READ MANUAL DECAL	01	
09	0503031942	ADHESIVE LABEL	01	
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27	02	
11	0503031565	ADHESIVE LABEL CARE	02	
12	0503031566	ADHESIVE LABEL	02	
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
14	0503031425	ADHESIVE LABEL ATTENTION	02	
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER	02	
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503032930	ADHESIVE LABEL DANGER	06	
19	0503031087	ADHESIVE LABEL	01	
20	0503034078	LIFTING POINTS DECAL	03	
21	0503034003	SERIAL NUMBER TAG 61 X 118	01	
22	0503010001	3.2 X 5.5 RIVET	04	
23	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
24	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0502012329	DRAWBAR FIXATION REAR SUPPORT		02
02	0502012330	SUPPORT FIXER PIVOT		04
03	0503011084	3/4" X 5" BOLT		08
04	0501010322	FLAT WASHER		08
05	0503010023	3/4" SPRING WASHER		08
06	0503010014	3/4" HEX NUT		08
07	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02
08	0561014393	COUPLING SHAFT		02
09	0503030119	LOCK PIN		04
10	0531063130	DRAWBAR		01
11	0561019087	DRAWBAR TRANSPORT LOCK		01
12	0521010578	COUPLING SHAFT		01
13	0521010588	0.9" X 7.0" COUPLING SHAFT		01
14	0503030085	LOCK PIN		02
15	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	1902012329	REAR SUPPORT FIXING DRAWBAR	04	
02	1902012330	FIXER SUPPORT ARTICULATED	08	
03	0503011084	3/4" X 5" BOLT	16	
04	0503010023	3/4" SPRING WASHER	16	
05	0503010014	3/4" HEX NUT	16	
06	1902012328	FIXED FRONT SUPPORT DRAWBAR	04	
07	0561014393	COUPLING SHAFT	04	
08	0503030119	LOCK PIN	08	
09	0511064808	DRAWBAR	01	
10	0561019087	DRAWBAR TRANSPORT LOCK	01	
11	0521010588	0.9" X 7.0" COUPLING SHAFT	01	
12	0521010578	COUPLING SHAFT	01	
13	0503030085	LOCK PIN	02	
14	0503010002	1800 GREASE FITTING	01	
15	0501010322	FLAT WASHER	16	




Item	Code	Description	See page	QT
01	0511069656	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0521062239	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0511069660	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0521062449	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0511058100	2 HOPPERS WITH 9 CONDUCTORS SET	24	01
02	0521051927	TOWER SUPPORT HOPPER	26	04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
05	0503010025	3/8 SPRING WASHER		08
06	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	25	09
08	0501010942	3/8" X 1-1/4" BOLT		36
09	0503010025	3/8 SPRING WASHER		36
10	0503010026	3/8" NUT		36
11	0571015773	SUPPORT SEED		03
12	0501011643	3/8 X 1"BOLT		12
13	0503010025	3/8 SPRING WASHER		12
14	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8 SPRING WASHER		01
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	5/16" NUT		02
11	0502012767	SEED NOZZLE FIXER SUPPORT		01




Item	Code	Description	See page	QT
01	0521066208	HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0511059584	2 HOPPERS WITH 10 CONDUCTORS SET	28	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521052687	RIGHT SUPPORT TOWER WITH BOLT	29	01
07	0521051931	LEFT SUPPORT TOWER WITH BOLT	30	01
08	0521051927	TOWER SUPPORT HOPPER	26	02




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		52
04	0503010026	3/8" NUT		52
05	0511057690	3" ARTICULATED SEED CONDUCTOR	25	10
06	0571015773	SUPPORT SEED		02
07	0501011643	3/8 X 1"BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		40
09	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		02




Item	Code	Description	See page	QT
01	0521066206	RIGHT HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521066207	LEFT HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0511059790	CSU C3 2 HOPPERS ASSEMBLY	32	01
02	0521066208	HOPPER SUPPORT TOWER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
05	0503010025	3/8 SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0501010453	FLAT WASHER		08
10	0503012412	5/8" UNC SELF LOCKING NUT		08




Item	Code	Description	See page	QT
01	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	25	08
08	0501010942	3/8" X 1-1/4" BOLT		32
09	0503010025	3/8 SPRING WASHER		32
10	0503010026	3/8" NUT		32
11	0571015773	SUPPORT SEED		04
12	0501011643	3/8 X 1"BOLT		16
13	0503010025	3/8 SPRING WASHER		16
14	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0511057737	2 HOPPERS WITH 10 CONDUCTORS SET	34	01
02	0521051927	TOWER SUPPORT HOPPER	26	04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
05	0503010025	3/8 SPRING WASHER		08
06	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	25	10
08	0501010942	3/8" X 1-1/4" BOLT		40
09	0503010025	3/8 SPRING WASHER		40
10	0503010026	3/8" NUT		40
11	0571015773	SUPPORT SEED		04
12	0501011643	3/8 X 1"BOLT		16
13	0503010025	3/8 SPRING WASHER		16
14	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0501010942	3/8" X 1-1/4" BOLT		08
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
03	0503010025	3/8 SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0521051927	TOWER SUPPORT HOPPER	26	04
06	0511058724	2 HOPPERS WITH 12 CONDUCTORS ASSEMBLY	36	01




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR	25	12
06	0571015773	SUPPORT SEED		02
07	0501011643	3/8 X 1"BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		48
09	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
04	0503010025	3/8 SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0511069665	PLATFORM RIGHT	01	
07	0521062323	PLATFORM LEFT	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
04	0503010025	3/8 SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521062237	RIGHT PLATAFORM	01	
07	0521062238	LEFT PLATAFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT		04
02	0503010849	3/8" X 1-1/2" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0511069718	PLATFORM RIGHT		01
07	0521062324	PLATFORM LEFT		01
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
09	0503011336	1/2" HEX SELF ADJUSTING NUT		04
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
13	0502012739	PLATFORM LEFT FIXER SUPPORT		01




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
04	0503010025	3/8 SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521062450	RIGHT PLATFORM	01	
07	0521062451	LEFT PLATFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0531056599	RIGHT HOPPER SUPPORT WITH FERTILIZER 42 METERING - 4045		01
02	0531056598	LEFT HOPPER SUPPORT WITH FERTILIZER 43 METERING - 4045		01
03	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		16
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
07	0503010025	3/8 SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0501010694	FLAT WASHER		04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" COTTERPIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531064716	RIGHT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	44	05
03	0501053788	3/4 SQUARE AXLE FASTENER	49	02
04	0503031527	AGRICULTURAL BEARING		02
05	0501310661	3/4" X 15,35"/15,27" AXLE		04
06	0531057908	SLEEVE 1/4 X 2		05
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	50	01
08	0501218668	3/4 X 135 AXLE		01
09	0501310839	3/4 X 305/303 AXLE		01




Item	Code	Description	See page	QT
01	0531064715	LEFT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	44	05
03	0501053788	3/4 SQUARE AXLE FASTENER	49	02
04	0503031527	AGRICULTURAL BEARING		02
05	0501310661	3/4" X 15,35"/15,27" AXLE		04
06	0531057908	SLEEVE 1/4 X 2		05
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	50	01
08	0501218668	3/4 X 135 AXLE		01
09	0501310839	3/4 X 305/303 AXLE		01




Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	ASSY TRANSMISSION HUB	45	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	46	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513011170	ALLEN SCREW 1/4 UNC X 7/8 CCSI STAINLESS STEEL		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501310211	FRONT COVER ADB ALPHA II DISPENSER		01
19	0503036177	ADB ALPHA DISPENSER COVER STRING		01
20	0531059139	ASSY COLLECTOR	47	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO ADHESIVE LABEL 41.5 X 29		01
15	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT GUIDE DOSING COVER		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT GLOVE FIXING SAFETY LOCK DISPENSER		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT GLOVE FIXING SAFETY LOCK DISPENSER		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01



Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	48	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01

22Z GEAR SIDE BEARING ASSEMBLY


0531057911




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007		02
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0503010337	5/16" NUT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0531057901	GEAR	51	01
07	0503010845	501035 CLAMPING RING (FOR AXLE)		01
08	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531065402	GEAR		01
02	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0531056760	RIGHT HOPPER SUPPORT WITH FERTILIZER 53 METERING - 4495		01
02	0531056759	LEFT HOPPER SUPPORT WITH FERTILIZER 54 METERING - 4495		01
03	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		09
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
07	0503010025	3/8 SPRING WASHER		09
08	0503010026	3/8" NUT		09
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0501010694	FLAT WASHER		04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" COTTERPIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531064842	RIGHT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	44	05
03	0501053788	3/4 SQUARE AXLE FASTENER	49	02
04	0503031527	AGRICULTURAL BEARING		02
05	0501310661	3/4" X 15,35"/15,27" AXLE		03
06	0531057908	SLEEVE 1/4 X 2		04
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	50	01
08	0501310859	3/4 X 490/488 AXLE		01
09	0501310860	3/4 X 350/348 AXLE		01




Item	Code	Description	See page	QT
01	0531064841	LEFT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	44	05
03	0501053788	3/4 SQUARE AXLE FASTENER	49	03
04	0503031527	AGRICULTURAL BEARING		03
05	0501310661	3/4" X 15,35"/15,27" AXLE		03
06	0531057908	SLEEVE 1/4 X 2		04
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	50	01
08	0501310859	3/4 X 490/488 AXLE		01
09	0501310860	3/4 X 350/348 AXLE		01




Item	Code	Description	See page	QT
01	0531056604	RIGHT HOPPER SUPPORT WITH FERTILIZER 56 METERING - 4845		01
02	0531056605	LEFT HOPPER SUPPORT WITH FERTILIZER 57 METERING - 4845		01
03	0503062169	ASSEMBLED FERTILIZER HOPPER		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		20
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		40
07	0503010025	3/8 SPRING WASHER		20
08	0503010026	3/8" NUT		20
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0501010694	FLAT WASHER		04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" COTTERPIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531064717	RIGHT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	44	06
03	0501053788	3/4 SQUARE AXLE FASTENER	49	03
04	0503031527	AGRICULTURAL BEARING		03
05	0501218487	3/4 X 390 AXLE		05
06	0531057908	SLEEVE 1/4 X 2		06
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	50	01
08	0501218676	3/4 X 125 AXLE WITH HOLE		01
09	0501218674	3/4 X 290 AXLE		01




Item	Code	Description	See page	QT
01	0531064718	LEFT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	44	06
03	0501053788	3/4 SQUARE AXLE FASTENER	49	03
04	0503031527	AGRICULTURAL BEARING		03
05	0501218487	3/4 X 390 AXLE		05
06	0531057908	SLEEVE 1/4 X 2		06
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	50	01
08	0501218676	3/4 X 125 AXLE WITH HOLE		01
09	0501218674	3/4 X 290 AXLE		01




Item	Code	Description	See page	QT
01	0531056920	RIGHT HOPPER SUPPORT WITH FERTILIZER 59 METERING - 5345		01
02	0531056919	LEFT HOPPER SUPPORT WITH FERTILIZER 60 METERING - 5345		01
03	0503062169	ASSEMBLED FERTILIZER HOPPER		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		20
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		40
07	0503010025	3/8 SPRING WASHER		20
08	0503010026	3/8" NUT		20
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0501010694	FLAT WASHER		04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" COTTERPIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02



Item	Code	Description	See page	QT
01	0531064949	RIGHT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	44	06
03	0501053788	3/4 SQUARE AXLE FASTENER	49	05
04	0503031527	AGRICULTURAL BEARING		05
05	0501218487	3/4 X 390 AXLE		05
06	0531057908	SLEEVE 1/4 X 2		06
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	50	01
08	0501218691	3/4 X 6.53/6.61 AXLE WITH HOLE		01
09	0501218858	3/4 X 355 AXLE		01



Item	Code	Description	See page	QT
01	0531064948	LEFT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	44	06
03	0501053788	3/4 SQUARE AXLE FASTENER	49	05
04	0503031527	AGRICULTURAL BEARING		05
05	0501218487	3/4 X 390 AXLE		05
06	0531057908	SLEEVE 1/4 X 2		06
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	50	01
08	0501218691	3/4 X 6,53/6,61 AXLE WITH HOLE		01
09	0501218858	3/4 X 355 AXLE		01



Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8" UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0503012412	5/8" UNC SELF LOCKING NUT		02
13	0511058449	HYDRAULIC CYLINDER	62	02
14	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
15	0503010523	1/4" X 2" SPLIT PIN		02
16	0511015779	1" X 4.2" AXLE		02
17	0503010523	1/4" X 2" SPLIT PIN		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	8,30 X 78 LOCK PIN		02
20	0503030168	HITCH PIN CLIP		02
21	0501069643	890 TURNBUCKLE		02
22	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
23	0511011311	VALVE SUPPORT		01
24	0503010232	5/8" X 1.3/4" BOLT		02
25	0503010027	5/8 SPRING WASHER		02
26	0503010013	5/8 NUT		02
27	0501054649	HBM SEQUENTIAL VALVE	63	01
28	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
29	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
30	0503010025	3/8 SPRING WASHER		02
31	0511057095	HYDRAULIC MARKER HOSE KIT	64	01


**SEMI-ASSEMBLED HYDRAULIC MARKER 4045**

0501058170


Item	Code	Description	See page	QT
32	0501053834	MALE QUICK COUPLER	65	02
33	0502012702	BODY SUPPORT CLAMP		06
34	0503011103	7/16" X 2-1/2" BOLT		06
35	0501012803	FLAT WASHER		02
36	0503010180	7/16" SPRING WASHER		06
37	0503010244	7/16" NUT		06

HYDRAULIC CYLINDER


0511058449




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02



Item	Code	Description	See page	QT
01	0501081727	TR-TR HOSE ASSY		02
02	0501080447	3/8" X 122" TR-TC HOSE ASSY		02
03	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
03A	0501080422	HOSE 3/8 X 4000 TC-TM		01
03B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
03C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
03D	0503018952	PLASTIC BOLT		06
04	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
04A	0501080422	HOSE 3/8 X 4000 TC-TM		01
04B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
04C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
04D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0501069470	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	62	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501069643	890 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	63	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0501053834	MALE QUICK COUPLER	65	02
25	0502012702	BODY SUPPORT CLAMP		06
26	0503011103	7/16" X 2-1/2" BOLT		06
27	0501012803	FLAT WASHER		02
28	0503010180	7/16" SPRING WASHER		06
29	0503010244	7/16" NUT		06
30	0501012140	FLAT WASHER		04
31	0503012412	5/8" UNC SELF LOCKING NUT		02

SEMI-ASSEMBLED HYDRAULIC MARKER 4495

0511050838

Item	Code	Description	See page	QT
32	0511011311	VALVE SUPPORT		01
33	0503010232	5/8" X 1.3/4" BOLT		02
34	0503010027	5/8 SPRING WASHER		02
35	0503010013	5/8 NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		08
37	0511057071	HYDRAULIC HOSE MARKER ASSY 10L		01
37A	0501081729	HOSE 3/8 X 3125 TR-TR		02
37B	0501081633	HOSE 3/8 X 3325 TR-TC		02
38	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38A	0501080422	HOSE 3/8 X 4000 TC-TM		01
38B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38D	0503018952	PLASTIC BOLT		06
39	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
39A	0501080422	HOSE 3/8 X 4000 TC-TM		01
39B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
39C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
39D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8" UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503011082	C1/2" X 1.3/4" SCREW		02
07	0501069470	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0501012140	FLAT WASHER		04
11	0503012412	5/8" UNC SELF LOCKING NUT		02
12	0511058449	HYDRAULIC CYLINDER	62	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" SPLIT PIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501066949	1235 TURNBUCKLE		02
21	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
22	0511011311	VALVE SUPPORT		01
23	0503010232	5/8" X 1.3/4" BOLT		02
24	0503010027	5/8 SPRING WASHER		02
25	0503010013	5/8 NUT		02
26	0501054649	HBM SEQUENTIAL VALVE	63	01
27	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
28	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
29	0503010025	3/8 SPRING WASHER		02
30	0502012702	BODY SUPPORT CLAMP		06
31	0503011103	7/16" X 2-1/2" BOLT		06

SEMI-ASSEMBLED HYDRAULIC MARKER 4845

0501058172

Item	Code	Description	See page	QT
32	0501012803	FLAT WASHER		02
33	0503010180	7/16" SPRING WASHER		06
34	0503010244	7/16" NUT		06
35	0501053834	MALE QUICK COUPLER	65	02
36	0511057069	HYDRAULIC HOSE MARKER ASSY		01
36A	0501080343	TR-TR HOSE ASSY		02
36B	0501080720	HOSE 3/8 X 3500 TR-TC		02
37	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
37A	0501080422	HOSE 3/8 X 4000 TC-TM		01
37B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
37C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
37D	0503018952	PLASTIC BOLT		06
38	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38A	0501080422	HOSE 3/8 X 4000 TC-TM		01
38B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0501012140	FLAT WASHER		12
04	0503012412	5/8" UNC SELF LOCKING NUT		10
05	0503011070	BEATER		02
06	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
07	0503010019	1/2" SPRING WASHER		02
08	0511061811	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0511058449	HYDRAULIC CYLINDER	62	02
12	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
13	0503010523	1/4" X 2" SPLIT PIN		04
14	0511015779	1" X 4.2" AXLE		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	63	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0501053834	MALE QUICK COUPLER	65	02
25	0531011180	UPPER BODY CLIP		08
26	0503010180	7/16" SPRING WASHER		08
27	0511011311	VALVE SUPPORT		01
28	0511059271	HYDRAULIC MARKER HAND SET		01
28A	0501081731	3/8 X 3550 TR-TR HOSE		02
28B	0501081732	3/8" X 3750 TR-TR HOSE		02
28C	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01


**SEMI-ASSEMBLED HYDRAULIC MARKER 5345**

0511051119

Item	Code	Description	See page	QT
28D	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
29	0503011103	7/16" X 2-1/2" BOLT		08
30	0502012702	BODY SUPPORT CLAMP		08
31	0503010244	7/16" NUT		08
32	0503010232	5/8" X 1.3/4" BOLT		02
33	0503010027	5/8 SPRING WASHER		02
34	0503010013	5/8 NUT		02

ROW MARKER DISC ASSEMBLY


0501050633




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	70	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01

ROW MARKER DISC

0511053904



Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	72	01
15	0511051434	TRANSMISSION ACTUATOR	73	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	74	01
17	0521043316	RIGHT GEAR BOX ASSY	75	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	84	01
26	0501058234	LOWER CHAIN TENSIONER	85	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	86	01
28	0501058236	BEARING WITH 21Z GEAR	87	01
29	0501058237	16Z GEAR BEARING	88	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	89	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01


RIGHT TRANSMISSION ASSY - 4045

0511058597

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8 SPRING WASHER		01
36	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02

RIGHT SIDE TRANSMISSION ACTUATOR


0511047069




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY


0521043316



Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	76	01
02	0511059266	CLOSED BEARING	77	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	79	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	81	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	82	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	83	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX	01	
02	0502011758	REAR TIGHTENER LEVER	02	
03	0503010292	701164 6 X 40 SPRING PIN	02	
04	0511061794	CHAIN TENSIONER	01	
05	0503031367	SPRING	01	
06	0511060392	CHAIN TENSIONER	01	
07	0503031366	RIGHT TWISTED SPRING	01	




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	78	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02

GEARBOX CLOSED BEARING


0501056271




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01



Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	80	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01

CHAIN TENSIONER ASSY


0501054655




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503012882	BEARING		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0551019173	CHAIN SLEEVE TENSIONER		01
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOUBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019174	DOUBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561018351	2155 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	72	01
15	0511051434	TRANSMISSION ACTUATOR	73	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	74	01
17	0521043316	RIGHT GEAR BOX ASSY	75	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	84	01
26	0501058234	LOWER CHAIN TENSIONER	85	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	86	01
28	0501058236	BEARING WITH 21Z GEAR	87	01
29	0501058237	16Z GEAR BEARING	88	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	89	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01


Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8 SPRING WASHER		01
36	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	72	01
15	0511051434	TRANSMISSION ACTUATOR	73	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	74	01
17	0521043316	RIGHT GEAR BOX ASSY	75	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	84	01
26	0501058234	LOWER CHAIN TENSIONER	85	01
27	0521055207	TOP CURRENT STRETCHER		01
28	0501058236	BEARING WITH 21Z GEAR	87	01
29	0501058237	16Z GEAR BEARING	88	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	89	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01




Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561019204	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	72	01
15	0511051434	TRANSMISSION ACTUATOR	73	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	74	01
17	0521043316	RIGHT GEAR BOX ASSY	75	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0503030303	SUPPORT WASHER		03
26	0501010637	FLAT WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	84	01
31	0501058234	LOWER CHAIN TENSIONER	85	01

Item	Code	Description	See page	QT
32	0501058235	STRETCHER CURRENT TOP SEED 17Z	86	01
33	0501058236	BEARING WITH 21Z GEAR	87	01
34	0501058237	16Z GEAR BEARING	88	01
35	0503012391	40-1 CHAIN X 83 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
38	0503012719	40-1 CHAIN X 113 LINK + MENDING		01



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	72	01
15	0511051434	TRANSMISSION ACTUATOR	73	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	94	01
17	0521043317	LEFT GEAR BOX ASSY	95	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	84	01
26	0501058234	LOWER CHAIN TENSIONER	85	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	86	01
28	0501058236	BEARING WITH 21Z GEAR	87	01
29	0501058237	16Z GEAR BEARING	88	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	89	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01


LEFT TRANSMISSION ASSY - 4045

0511058598

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8 SPRING WASHER		01
36	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02

LEFT SIDE TRANSMISSION ACTUATOR


0511047070



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	96	01
02	0511059266	CLOSED BEARING	77	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	79	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	81	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	82	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	83	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LH GEAR BOX

0501058213



Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561018351	2155 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	72	01
15	0511051434	TRANSMISSION ACTUATOR	73	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	94	01
17	0521043317	LEFT GEAR BOX ASSY	95	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	84	01
26	0501058234	LOWER CHAIN TENSIONER	85	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	86	01
28	0501058236	BEARING WITH 21Z GEAR	87	01
29	0501058237	16Z GEAR BEARING	88	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	89	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01


LEFT TRANSMISSION ASSY - 4495

0511058971

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8 SPRING WASHER		01
36	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02

LEFT TRANSMISSION ASSEMBLY - 4880

0511056741




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPP G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	72	01
15	0511051434	TRANSMISSION ACTUATOR	73	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	94	01
17	0521043317	LEFT GEAR BOX ASSY	95	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	84	01
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	89	01
27	0501058234	LOWER CHAIN TENSIONER	85	01
28	0521055207	TOP CURRENT STRETCHER		01
29	0501058236	BEARING WITH 21Z GEAR	87	01
30	0501058237	16Z GEAR BEARING	88	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01



LEFT TRANSMISSION ASSEMBLY - 4880

0511056741

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561019204	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	72	01
15	0511051434	TRANSMISSION ACTUATOR	73	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	94	01
17	0521043317	LEFT GEAR BOX ASSY	95	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0503030303	SUPPORT WASHER		03
26	0501010637	FLAT WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	84	01
31	0501058234	LOWER CHAIN TENSIONER	85	01


ASSY TRANSMISSION LEFT - 5345

0521050179


Item	Code	Description	See page	QT
32	0501058235	STRETCHER CURRENT TOP SEED 17Z	86	01
33	0501058236	BEARING WITH 21Z GEAR	87	01
34	0501058237	16Z GEAR BEARING	88	01
35	0503012391	40-1 CHAIN X 83 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
38	0503012719	40-1 CHAIN X 113 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501058240	WHEEL FASTENER WITH TENSIONER	101	01
02	0503011119	7/8" X 6" BOLT		04
03	0501014251	FLAT WASHER		04
04	0503011254	7/8" HEX SELF ADJUSTING NUT		04
05	0501059909	CARRYING WHEELS SUPPORT	106	01
06	0503014887	2050 CHAIN X 80 LINK + REDUCTION		01
07	0502010584	CARRYING-WHEELS SUPPORT FIXER		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	102	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	104	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	105	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	103	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01



Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	103	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	103	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01

CARRYING WHEELS SUPPORT


0501059909




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0531016887	CARRYING WHEEL AXLE ARM		01
03	0503010523	1/4" X 2" SPLIT PIN		01
04	0503010003	1845 GREASE FITTING		01
05	0511050681	TRACTION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0561016062	SPRING HITCH		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8 SPRING WASHER		04
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0511052770	WHEEL WITH TIRE	107	01
11	0501058241	WHEEL SUPPORT CHAIN TENSIONER	109	01
12	0521061565	WHEEL SUPPORT ARM		01
13	0503018981	BOLT		02
14	0521069983	WHEEL COVER		01
15	0591010589	BODY LOCK WHEEL		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE		01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	108	01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511057070	HOSE KIT HYDRAULIC		01
01A	0521052285	TC-TM HOSE ASSY		01
01AA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01AB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052287	TC-TM HOSE ASSY		01
01BA	0501080446	3/8 X" 169" TC-TM HOSE ASSY		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	65	02
03	0503013100	NYLON CLAMP		02
04	0581010091	SPRING PROTECTION PLASTIC HOSE		01




Item	Code	Description	See page	QT
01	0511063404	"T" OIL CONDUCTOR		02
02	0581010091	SPRING PROTECTION PLASTIC HOSE		01
03	0503013100	NYLON CLAMP		02
04	0502012702	BODY SUPPORT CLAMP		02
05	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
06	0503010180	7/16" SPRING WASHER		02
07	0501053834	MALE QUICK COUPLER	65	02
08	0511057068	HOSE KIT SYSTEM HYDRAULIC		01
08A	0501080449	3/8" X 1500 TC-TC HOSE		04
09	0521052334	3/8 X 4000 TR-TM HOSE BLACK / BLUE		01
09A	0501080361	3/8" X 157" TR-TM HOSE		01
09B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
09C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
09D	0503018952	PLASTIC BOLT		06
10	0521052333	3/8 X 4000 TR-TM HOSE BLACK / RED		01
10A	0501080361	3/8" X 157" TR-TM HOSE		01
10B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
10C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
10D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01

HOSE SUPPORT


0511056736




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0531058988	WORM THREAD P.16 WITH FERTILIZER DOSING SHAFT COATING		08
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		08
02A	0501111196	PALLETIZED FERTILIZER COATING COMPLETE PLANTING FERTILIZER DOSER ALP II		01
02B	0531058987	WORM SCREW P.50 WITH ADB ALPHA DISPENSER SHAFT COATING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01







Item	Code	Description	See page	QT
01	0531058988	WORM THREAD P.16 WITH FERTILIZER DOSING SHAFT COATING		09
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		09
01B	0503035859	SUPPORT SLEEVE		09
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		09
02A	0501111196	PALLETIZED FERTILIZER COATING COMPLETE PLANTING FERTILIZER DOSER ALP II		09
02B	0531058987	WORM SCREW P.50 WITH ADB ALPHA DISPENSER SHAFT COATING		09
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01



Item	Code	Description	See page	QT
01	0531058988	WORM THREAD P.16 WITH FERTILIZER DOSING SHAFT COATING		10
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		10
02A	0501111196	PALLETIZED FERTILIZER COATING COMPLETE PLANTING FERTILIZER DOSER ALP II		01
02B	0531058987	WORM SCREW P.50 WITH ADB ALPHA DISPENSER SHAFT COATING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	WORM THREAD P.16 WITH FERTILIZER DOSING SHAFT COATING		11
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		11
02A	0501111196	PALLETIZED FERTILIZER COATING COMPLETE PLANTING FERTILIZER DOSER ALP II		01
02B	0531058987	WORM SCREW P.50 WITH ADB ALPHA DISPENSER SHAFT COATING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	WORM THREAD P.16 WITH FERTILIZER DOSING SHAFT COATING		12
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		12
02A	0501111196	PALLETIZED FERTILIZER COATING COMPLETE PLANTING FERTILIZER DOSER ALP II		01
02B	0531058987	WORM SCREW P.50 WITH ADB ALPHA DISPENSER SHAFT COATING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01

ASSY HEX AXLE


0909095145




Item	Code	Description	See page	3245	4045	4845
01	0521013432	5/8" X 59" AXLE HEX		01	00	00
01.	0521013429	AXLE HEX 5/8 X 2180		00	01	00
01..	0521013430	HEX AXLE 5/8 X 2580		00	00	01
02	0521013428	HEX AXLE		01	00	00
02.	0521013433	5/8" X 75" AXLE HEX		00	01	00
02..	0521013434	HEX AXLE 5/8 X 2300		00	00	01
03	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"		02	02	02
04	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8		02	02	02
05	0503010003	1845 GREASE FITTING		02	02	02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04	04	04
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04	04	04
08	0501010694	FLAT WASHER		08	08	08
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04	04	04
10	0503010337	5/16" NUT		04	04	04
11	0511815098	FLAT WASHER		02	02	02
12	0511017305	FLAT WASHER		04	04	04
13	0511065562	20Z GEAR		02	02	02
14	0502011299	BUSHING GEAR		02	02	02
15	0503010571	1/4" X 1.1/2 COTTERPIN		02	02	02
16	0503010010	1/4" X 2.1/2" COTTERPIN		02	02	02



Item	Code	Description	See page	QT
01	0521066608	LIFTING HOOK		01
02	0581019707	FIXATION SUPPORT SUPPORT		01
03	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
04	0501012140	FLAT WASHER		04
05	0503012412	5/8" UNC SELF LOCKING NUT		04



Item	Code	Description	See page	11 L
01	0503016557	11 ROW SIMPLE MONITOR CABLE		01
02	0503017602	MONITOR PLANT PM400		01
03	0503016234	TRIMBLE FIXING WINDOW		01
04	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
05	0571012196	MOUNTING BRACKET PM 400		01
06	0503017443	ANTENNA GPS PM 400		01
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		165
08	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
09	0503010669	FLAT WASHER		02
10	0503010668	3/16" SPRING WASHER		02
11	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0511053252	FERTILIZER SHORT ROW WITH LEFT DDD/18" DC	125	01
01.	0511053254	FERTILIZER SHORT ROW WITH LEFT DDD/20" DC	132	01
02	0511053253	FERTILIZER LONG ROW WITH RIGHT DDD/18" DC	136	01
02.	0511053255	FERTILIZER LONG ROW WITH RIGHT DDD/20" DC	141	01
03	0521053154	FERTILIZER SHORT HIGH ROW WITH LEFT DDD/18" DC	143	01
03.	0521058872	FERTILIZER SHORT HIGH ROW WITH DAOC/20" DC	149	01
04	0521053153	FERTILIZER LONG HIGH ROW WITH RIGHT DDD/18" DC	155	01
04.	0521058873	FERTILIZER LONG HIGH ROW WITH DAOC/20" DC	158	01
05	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	162	01
05.	0521056317	DEPTH CONTROL WITH LEVER ANGLE REGULATOR AXIS CPERA	171	01
05..	0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	177	01
06	0531054165	SHORT SEED ROW	185	01
06.	0531054166	LONG SEED ROW	195	01
07	0531054159	HIGH SHORT SEED ROW	197	01
07.	0531054160	HIGH LONG SEED ROW	202	01
08	0501110231	SCARIFIER ROD WITH TIP		01
09	0511017969	0.1" SPACING PLATE		01
10	0521069124	PIVOTED FERTILIZER ROW NOZZLE		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511018662	SPACING PLATE		01
16	0521052631	HDA HIGH AUTOMATIC DISARM	206	01
17	0581010082	FERTILIZER SOCKET RIGHT		01
18	0581010083	FERTILIZER SOCKET LEFT		01
19	0571011730	SEED CONDUCTOR 3" X 1500		01


ASSY SEED/FERTILIZER ROW

0909096734


Item	Code	Description	See page	QT
20	0521050525	FIXER FERTILIZER CONDUCTOR	208	01
21	0503031050	CURVED CONDUCTOR		01
22	0503010246	CLAMP		01
23	0503063647	SIGMA CORN DISC SET		01
24	0503063648	SIGMA SOY DISC SET		01
25	0503010905	1/2" X 2-1/4" BOLT		01
26	0503010019	1/2" SPRING WASHER		01
27	0503010060	1/2 UNC G.5 ZN HEX NUT		01
28	0501013714	STABILIZER BAR		01
28.	0501018652	CORN STABILIZER BAR		01
29	0581015213	STABILIZER BAR E450		01
29.	0581015215	E500 STABILIZER BAR		01
30	0503030391	RIGHT FERTILIZER NOZZLE		01
31	0503030392	LEFT FERTILIZER NOZZLE		01
32	0521067360	PROTRACTOR CPRA		01
33	0511058877	REGULATORY KEY		01
33A	0521066800	BODY REGULATORY KEY		01
33B	0503030878	LEVER CRANK		01




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	126	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	130	01
07	0501058423	FERTILIZER ROD SPRING ROW	131	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	127	01



Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	128	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	129	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUB DISC - HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01

18" COULTER BLADE ASSY FOR SHORT ROW


0511044549




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0503010003	1845 GREASE FITTING		01
03	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
04	0521014137	RIGHT ARM BLADE DISC		01
05	0521014138	SUPPORT ARM LEFT BALDE DISC		01
06	0521054686	18" DISC BLADE HUB	140	01
07	0503010756	0.2" X 2.4" SPRING PIN		01
08	0503010361	SPRING PIN		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	1902020394	SPRING SUPPORT		01
14	1902020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0503010014	3/4" HEX NUT		02
17	0541018684	FLAT WASHER		01
18	0503013185	3/4" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01
21	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD	01	
02	0502040534	SPRING GUIDE BUSHING LOCK	02	
03	0502012184	FERTILIZER SPRING GUIDE	02	
04	0503031910	1.7" X 22.8" X 0.3" SPRING	01	
05	0502012510	SPRING ROD SUPPORT	01	
06	0503010257	1/8" X 1" COTTERPIN	01	
07	0501018535	1/2 X 1 BOLT	02	
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	02	
09	0503010060	1/2 UNC G.5 ZN HEX NUT	02	
10	1902010891	SPRING CHOCK SUPPORT VARON	01	
11	0503010014	3/4" HEX NUT	01	
12	0561014471	COUPLING SHAFT	01	
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN	01	



Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	126	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	133	01
07	0501058423	FERTILIZER ROD SPRING ROW	131	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
03	0541018684	FLAT WASHER		01
04	0503010756	0.2" X 2.4" SPRING PIN		01
05	0503010361	SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521014137	RIGHT ARM BLADE DISC		01
08	0521014138	SUPPORT ARM LEFT BALDE DISC		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0503011255	3/4" LOCK NUT		01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
14	0503011411	1/2" X 5-1/2" BOLT		01
15	0503010019	1/2" SPRING WASHER		01
16	0503010060	1/2 UNC G.5 ZN HEX NUT		01
17	0502020393	SPRING UPPER SUPPORT		01
18	0502020394	SPRING SUPPORT		01
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
20	0503010014	3/4" HEX NUT		02
21	0521054680	20" DISC BLADE HUB	134	01




Item	Code	Description	See page	QT
01	0521054679	DISC BLADE HUB	135	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01

DISC BLADE HUB


0521054679




Item	Code	Description	See page	QT
01	0502011562	DISC BLADE HUB		01
02	0502020641	BLADE DISC FLANGE		01
03	0503010276	6206 BALL BEARING		02
04	0521013610	BLADE DISC HUB AXLE		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
06	0503012417	SEAL		02
07	0503011800	SEAL RING		02
08	0503010691	1/4" GREASE FITTING		01
09	0521015376	DUST CLOAK		02
10	0503030832	FLAT WASHER		02
11	0511015346	FLAT WASHER		02
12	0521013510	3/4" NUT		02
13	0503010012	1" SPRING WASHER		02
14	0503010371	5/16" X 1" BOLT		06
15	0503010337	5/16" NUT		06



Item	Code	Description	See page	QT
01	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	137	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	139	01
07	0501058423	FERTILIZER ROD SPRING ROW	131	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061153	FERTILIZER ROW LONG ARM		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	138	01




Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	129	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	128	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02

18" COULTER BLADE ASSY FOR LONG ROW


0511044573




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0503010003	1845 GREASE FITTING		01
03	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE		01
04	0521014137	RIGHT ARM BLADE DISC		01
05	0521014138	SUPPORT ARM LEFT BALDE DISC		01
06	0521054686	18" DISC BLADE HUB	140	01
07	0503010756	0.2" X 2.4" SPRING PIN		01
08	0503010361	SPRING PIN		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	1902020394	SPRING SUPPORT		01
14	1902020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0503010014	3/4" HEX NUT		02
17	0541018684	FLAT WASHER		01
18	0503013185	3/4" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01
21	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0521054679	DISC BLADE HUB	135	01
02	0603026013	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	137	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	142	01
07	0501058423	FERTILIZER ROD SPRING ROW	131	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE		01
03	0541018684	FLAT WASHER		01
04	0503010756	0.2" X 2.4" SPRING PIN		01
05	0503010361	SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521014137	RIGHT ARM BLADE DISC		01
08	0521014138	SUPPORT ARM LEFT BALDE DISC		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0503011255	3/4" LOCK NUT		01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
14	0503011411	1/2" X 5-1/2" BOLT		01
15	0503010019	1/2" SPRING WASHER		01
16	0503010060	1/2 UNC G.5 ZN HEX NUT		01
17	0502020393	SPRING UPPER SUPPORT		02
18	0502020394	SPRING SUPPORT		01
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
20	0503010014	3/4" HEX NUT		02
21	0521054680	20" DISC BLADE HUB	134	01




Item	Code	Description	See page	QT
01	0521053152	SHORT ARM WITH LEFT DDD	144	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058617	DISC CUT 18 SHORT LINE	145	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	148	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521068566	SHORT FERTILIZER ROW ARM		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	127	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02



Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0503010003	1845 GREASE FITTING		01
03	0571019976	LEFT BRACELET CUTTING DISC		01
04	0503011411	1/2" X 5-1/2" BOLT		01
05	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
06	0503011440	SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0502020394	SPRING SUPPORT		01
09	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
10	0502020393	SPRING UPPER SUPPORT		01
11	0521010452	SLEEVE		01
12	0503013185	3/4" X 5-1/2" BOLT		01
13	0501067323	SPRING REGULATOR		01
14	0511056910	HUB WITH 18" DISC BLADE	147	01
15	0502012825	DISC BLADE FIXED AXLE		01
16	0503011255	3/4" LOCK NUT		02
17	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
18	0581011111	THRUST WASHER		01
19	0503034319	LOCK PIN		01
20	0511056909	DISC BLADE HUB WITHOUT DISC	146	01




Item	Code	Description	See page	QT
01	0502012793	DISC HUB		01
02	0571018047	DISC BLADE HUB AXLE		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DUST CLOAK		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	146	01
02	0603026013	PLAIN COULTER BLADE		01

TIGHT ELEVATION SPRING FULL FERTILIZER


0521052644




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK	02	
02	0502012184	FERTILIZER SPRING GUIDE	02	
03	0503031910	1.7" X 22.8" X 0.3" SPRING	01	
04	0502012510	SPRING ROD SUPPORT	01	
05	0521068568	LARGE ELEVATION SPRING FERTILIZER	01	
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN	01	
07	0501018535	1/2 X 1 BOLT	02	
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
09	0503010060	1/2 UNC G.5 ZN HEX NUT	02	
10	0502010891	SPRING ROD SUPPORT CHOCK	01	
11	0503010014	3/4" HEX NUT	01	
12	0561014471	COUPLING SHAFT	01	
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN	01	
14	0503010257	1/8" X 1" COTTERPIN	01	



Item	Code	Description	See page	QT
01	0521068566	SHORT FERTILIZER ROW ARM		01
02	0521058870	SUPPORT RIGHT BOX	150	01
03	0521050168	MOUNTED FERTILIZER CONDUCTOR	152	01
04	0501010066	3/4" X 9" BOLT		01
05	0521017831	SUPPORT SLEEVE SPACER		02
06	0511017232	FLAT WASHER		02
07	0503011255	3/4" LOCK NUT		01
08	0511058619	20" SHORT ROW DISC BLADE	153	01
09	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	148	01
10	0503031145	2" X 2" X 20" HOSE		01
11	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521068662	DOC SHORT ARM		01
02	0581011838	SLEEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2 UNC G.5 ZN HEX NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503010276	6206 BALL BEARING		01
10	0503030832	FLAT WASHER		01
11	0521058868	BOX ASSY	151	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0502011562	DISC BLADE HUB		01
02	0503011800	SEAL RING		01
03	0503012417	SEAL		01
04	0503010276	6206 BALL BEARING		01
05	0503030832	FLAT WASHER		01
06	0503011444	SPRING WASHER		06
07	0503010691	1/4" GREASE FITTING		01
08	0503010337	5/16" NUT		06
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0603026013	PLAIN COULTER BLADE		01

MOUNTED FERTILIZER CONDUCTOR


0521050168




Item	Code	Description	See page	QT
01	0581013298	SUPPORT		01
02	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
03	0521018517	FLAT WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0503030483	FERTILIZER SOCKET		01
07	0503031050	CURVED CONDUCTOR		01
08	0503010246	CLAMP		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012825	DISC BLADE FIXED AXLE		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	THRUST WASHER		01
17	0503034319	LOCK PIN		01
18	0511058648	HUB WITH 20" DISC BLADE	154	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	146	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0521053151	LONG ARM WITH RIGHT DDD	156	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511058618	DISC CUT 18 LONG LINE	157	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	148	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02



Item	Code	Description	See page	QT
01	0521068565	LONG FERTILIZER ROW ARM		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	138	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0503010003	1845 GREASE FITTING		01
03	0571019976	LEFT BRACELET CUTTING DISC		01
04	0503011411	1/2" X 5-1/2" BOLT		01
05	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
06	0503011440	SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0502020394	SPRING SUPPORT		01
09	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
10	0502020393	SPRING UPPER SUPPORT		01
11	0521010452	SLEEVE		01
12	0503013185	3/4" X 5-1/2" BOLT		01
13	0501067323	SPRING REGULATOR		01
14	0511056910	HUB WITH 18" DISC BLADE	147	01
15	0502012824	DISC BLADE FIXED AXLE		01
16	0503011255	3/4" LOCK NUT		02
17	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
18	0581011111	THRUST WASHER		01
19	0503034319	LOCK PIN		01




Item	Code	Description	See page	QT
01	0521068565	LONG FERTILIZER ROW ARM		01
02	0521058871	RIGHT SUPPORT	159	01
03	0521050168	MOUNTED FERTILIZER CONDUCTOR	152	01
04	0501010066	3/4" X 9" BOLT		01
05	0521017831	SUPPORT SLEEVE SPACER		02
06	0511017232	FLAT WASHER		02
07	0503011255	3/4" LOCK NUT		01
08	0511058620	20" LONG ROW DISC BLADE	161	01
09	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	148	01
10	0503031145	2" X 2" X 20" HOSE		01
11	0503031076	2" HOSE CLAMP		02

RIGHT SUPPORT


0521058871




Item	Code	Description	See page	QT
01	0521068662	DOC SHORT ARM		01
02	0581011838	SLEEVE GUIDES		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0521015376	DUST CLOAK		01
05	0503010019	1/2" SPRING WASHER		02
06	0503010060	1/2 UNC G.5 ZN HEX NUT		02
07	0503012417	SEAL		01
08	0503011800	SEAL RING		01
09	0503010276	6206 BALL BEARING		01
10	0503030832	FLAT WASHER		01
11	0521058869	BOX ASSY	160	01
12	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0502011562	DISC BLADE HUB		01
02	0503011800	SEAL RING		01
03	0503012417	SEAL		01
04	0503010276	6206 BALL BEARING		01
05	0503030832	FLAT WASHER		01
06	0503011444	SPRING WASHER		06
07	0503010691	1/4" GREASE FITTING		01
08	0503010337	5/16" NUT		06
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0603026013	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0502012816	CUTTING DISC SUPPORT		01
02	0571019976	LEFT BRACELET CUTTING DISC		01
03	0503011411	1/2" X 5-1/2" BOLT		01
04	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
05	0503011440	SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	1902020394	SPRING SUPPORT		01
08	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
09	1902020393	SPRING UPPER SUPPORT		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0501067323	SPRING REGULATOR		01
13	0502012824	DISC BLADE FIXED AXLE		01
14	0503011255	3/4" LOCK NUT		02
15	0521066738	BRACO RIGHT DISC CUT WITH WASHER LOCK PST		01
16	0581011111	THRUST WASHER		01
17	0503034319	LOCK PIN		01
18	0511058648	HUB WITH 20" DISC BLADE	154	01
19	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	163	01
02	0501052538	DEPTH BAND WITH ARMS	167	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	168	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	170	01
07	0503033942	COMPACTOR WHEEL REGULATOR LID		01



Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT DEPTH WHEEL ARM WITH HUB	164	01
07	0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	166	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	172	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL HUB	165	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	PROTECTION LID		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01

RIGHT DEPTH WHEEL ARM WITH HUB


0511058651




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL HUB	165	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	169	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01



Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03



Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	169	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
03	0521019093	0.6" X 2.7" PIVOT SHAFT		01
04	0503010581	RING		01
05	1902012116	PRESS WHEEL ADJUSTER		01
06	0501052297	DEPTH WHEELS REGULATOR ASSY	172	01
07	0501052908	COMPACTOR WHEEL WITH BEARING	169	02
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
09	0521014508	FLAT WASHER		10
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0581011100	DEPTH WHEEL AXLE		01
12	0571017749	FLAT WASHER		02
13	0521056314	LEFT ARM WHEEL DEPTH WITH HUB CPERA	174	01
14	0521056313	RIGHT ARM WHEEL DEPTH WITH HUB CPERA	175	01
15	0503010358	5/16" X 5/8" BOLT		08
16	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
17	0503013816	5/16" LOCKNUT		08
18	0501011445	FLAT WASHER		02
19	0503010311	1/2" X 1-1/4" BOLT		02
20	0503010019	1/2" SPRING WASHER		02
21	0503010025	3/8 SPRING WASHER		02
22	0503010026	3/8" NUT		02
23	0503010849	3/8" X 1-1/2" BOLT		02
24	0503010256	3/8" X 3/4" BOLT		01
25	0511055819	DEPTH BAND WITH RIM	176	02
26	0503010691	1/4" GREASE FITTING		02
27	0503033942	COMPACTOR WHEEL REGULATOR LID		01
28	0521064073	REGULACION WHEEL COMPACTOR		01
29	0541016906	PRESS WHEELS REGULATOR BODY		01
30	0521010539	0.3" X 1.2" COUPLING SHAFT		01
31	0503010140	1/8" X 3/4" COTTERPIN		01




Item	Code	Description	See page	QT
32	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01

DEPTH WHEELS REGULATOR ASSY


0501052297




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0501013636	SPACING SLEEVE		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010689	SEAL 00763-BR		01
04	0503011105	SEAL RING		01
05	0503010269	6204 BALL BEARING		02
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0521019178	PROTECTION LID		01
09	0503010143	1/4" SPRING WASHER		03
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0521060071	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0521056316	DEPTH WHEEL HUB WITH COMPLETE ANGLE 173 ADJUSTING AXLE		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110833	DEPTH CONTROL RIGHT ARM		01
02	0521056316	DEPTH WHEEL HUB WITH COMPLETE ANGLE 173 ADJUSTING AXLE		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05




Item	Code	Description	See page	QT
01	0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	178	01
02	0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	184	01
03	0501052908	COMPACTOR WHEEL WITH BEARING	169	02
04	0503010019	1/2" SPRING WASHER		06
05	0503010752	1/2" X 3.1/2" BOLT		01
06	0503013739	1/2" X 1" BOLT		01
07	0503010479	BOLT		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503030012	HITCH PIN CLIP		01
10	0571013222	FIXING CHOCK		01
11	0503010741	1/2" X 2-3/4" BOLT		02
12	0511055819	DEPTH BAND WITH RIM	176	02
13	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
14	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0521063808	DEPTH CONTROL INNER COLUMN CONTROL WITH SCREW		01
02	0521063809	DEPTH CONTROL EXTERNAL COLUMN CONTROL WITH SCREW		01
03	0571013194	REGULATOR SPINDLE		01
04	0551010616	ROD HEX		01
05	0503010683	0,2" X 1,2" SPRING PIN		01
06	0571013202	COVERING WHEEL REGULATOR AXLE		01
07	0521063812	REGULATOR LEVER ALXE		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		01
09	0511065308	LOCK REGULATOR		01
10	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
11	0541011627	FLAT WASHER		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0511059325	LEFT ARM COVERED WHEEL ASSEMBLED	179	01
14	0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED	180	01
15	0571014709	SLEEVE LOCK CONTROL ARM		02
16	0503011440	SPRING WASHER		03
17	0503819099	BOLT		02
18	0511051546	RIGHT DEPTH CONTROL HUB	181	01
19	0511051547	LEFT DEPTH CONTROL HUB	183	01
20	0503011442	3/4" SPRING WASHER		02
21	0571013189	SLEEVE SUPPORT BEATER		01
22	0521063813	WHEEL PRESS BEATER		01
23	0501010937	13,50 X 28 X 3,00 FLAT WASHER		01
24	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01

LEFT ARM COVERED WHEEL ASSEMBLED


0511059325




Item	Code	Description	See page	QT
01	0502012844	LEFT ARM WHEELS		01
02	0581011340	ARM CASE		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	COVERING WHEEL ARM SUPPORT SLEEVE		02
05	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0502012843	RIGHT WHEEL ARM		01
02	0581011340	ARM CASE		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	COVERING WHEEL ARM SUPPORT SLEEVE		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	182	01
02	0511066638	RIGHT AXLE WITH DUST CLOAK		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	PROTECTION LID		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0502011907	DEPTH CONTROL WHEEL HUB		01
02	0503010269	6204 BALL BEARING		02
03	0501013636	SPACING SLEEVE		01
04	0503010689	SEAL 00763-BR		01
05	0503011105	SEAL RING		01
06	0503010691	1/4" GREASE FITTING		01

LEFT DEPTH CONTROL HUB


0511051547




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	182	01
02	0511066637	LEFT AXLE WITH DUST CLOAK		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	PROTECTION LID		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03



Item	Code	Description	See page	QT
01	0502012850	PRESS WHEELS ARM		01
02	0503030883	RIGHT TORSION SPRING		01
03	0502011066	PRESS WHEELS ARM SUPPORT		01
04	0531017415	1" X 4.72" AXLE JOINT		01
05	0503010839	03"X 0.6" SPRING PIN		01
06	0521063841	REGULATOR RIGHT COMPACTOR		01
07	0521063842	REGULATOR LEFT COMPACTOR		01
08	0503811404	BOLT		02
09	0503011443	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0571013295	ALXE REGULATOR COMPACTOR		01
12	0521063812	REGULATOR LEVER ALXE		01
13	0503011336	1/2" HEX SELF ADJUSTING NUT		02
14	0511065308	LOCK REGULATOR		01
15	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
16	0541011627	FLAT WASHER		01
17	0503010140	1/8" X 3/4" COTTERPIN		01
18	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW		01
19	0503811172	BOLT		01
20	0503010002	1800 GREASE FITTING		01
21	0581013744	PROTECTION CASE		01
22	0503813096	BOLT		01
23	0503013816	5/16" LOCKNUT		0




Item	Code	Description	See page	QT
01	0511056600	RIGHT DDD SHORT SEED ROW FRONT	186	01
02	0511058212	FERTILIZER ROW SUPPORT ASSY	190	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0511060376	SEED SPRING GUIDE		01
06	0521010542	COUPLING SHAFT		01
07	0503010257	1/8" X 1" COTTERPIN		01
08	0502040534	SPRING GUIDE BUSHING LOCK		02
09	0501018535	1/2 X 1 BOLT		02
10	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
11	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
12	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
13	0501013753	FLAT WASHER		01
14	0502012538	SPRING VARON SUPPORT		01
15	0503010013	5/8 NUT		01
16	0511052024	FAST CLOSING SET	191	01
17	0521059094	SIGMA SOY SINGLE SEED SYSTEM	192	01
18	0503011099	GREASE FITTING		02
19	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
21	0503010019	1/2" SPRING WASHER		01
22	0503010060	1/2 UNC G.5 ZN HEX NUT		01
23	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
24	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
25	0503011336	1/2" HEX SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521062183	SHORT SEED ROW ARM		01
02	0502011830	ARTICULACCION SUPPORT		01
03	0521018079	SEED ROW DRAWBAR LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		02
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0503011440	SPRING WASHER		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0501013354	FLAT WASHER		02
15	0502011400	18Z CONICAL GEAR		01
16	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
17	0502011505	18Z CONICAL GEAR		01
18	0521018077	1/2" X 58.6" HEX AXLE		01
19	0501013352	FLAT WASHER		04
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	187	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04
25	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
26	0503011440	SPRING WASHER		02
27	0503010060	1/2 UNC G.5 ZN HEX NUT		02
28	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	188	01

BASE FIXING SYSTEM


0511051693




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502011411	10Z CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	189	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	129	01
03	0511053172	LEFT LOW HUB WITH 15 DISC	128	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O-RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02

FAST CLOSING SET


0511052024



Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0503063223	SEMI-ASSEMBLED SINGLE SEED HOPPER		01
02	0581014295	FIXING SLEEVE		01
03	0503012545	FLAT WASHER		04
04	0503014442	BOLT		04
05	0591015106	SEED NOZZLE FIXING FLANGE		01
06	0513010192	LOCK WASHER		04
07	0513010191	BOLT		04
08	0503012534	LOCK WASHER		04
09	0531051514	SIGMA SOY SEED SYSTEM	193	01
10	0503035691	ADHESIVE LABEL		02




Item	Code	Description	See page	QT
01	0511057289	ASSY SEED DEFLECTOR	194	01
02	0503030083	3/8" X 3/8" X 1.6" STUD		02
03	0503010675	5/16" X 2.1/4" BOLT		01
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
05	0503010337	5/16" NUT		01
06	0502012974	LOWER SEED DISK TRACK		01
07	0501013518	FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		02
09	0503010209	3/8" UNC BUTTERFLY NUT		02
10	0503016282	ALLEN BOLT		01
11	0503019913	SELF-LOCKING NUT W/ NYLON M8 X 1.25 C.8 ZN		01
12	0503035299	PLATE SPRING 16 X 8.2 X 0.90		02
13	0591018706	SEED HOPPER SUPPORT		01
14	0513010140	SOCIDISCO SOY DISC 90 HOLES		01
15	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461		01
16	0503063405	SOY SEED DISTRIBUTOR CAP		01

ASSY SEED DEFLECTOR


0511057289




Item	Code	Description	See page	QT
01	0503010025	3/8 SPRING WASHER		01
02	0503010209	3/8" UNC BUTTERFLY NUT		01
03	0571018536	HEX PRISONER		01
04	0501013518	FLAT WASHER		02
05	0503034131	DEFLECTOR		01



Item	Code	Description	See page	QT
01	0511056601	LONG SEED ROW FRONT DDD LEFT	196	01
02	0511058212	FERTILIZER ROW SUPPORT ASSY	190	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8\" UNC SELF LOCKING NUT		02
05	0511060376	SEED SPRING GUIDE		01
06	0521010542	COUPLING SHAFT		01
07	0503010257	1/8\" X 1\" COTTERPIN		01
08	0502040534	SPRING GUIDE BUSHING LOCK		02
09	0501018535	1/2 X 1 BOLT		02
10	0503031340	1.7\"X 19\" X 0.3\" COMPRESSION SPRING		01
11	0503031339	1\" X 19\" X 0.1\" COMPRESSION SPRING		01
12	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
13	0501013753	FLAT WASHER		01
14	0502012538	SPRING VARON SUPPORT		01
15	0503010013	5/8 NUT		01
16	0511052024	FAST CLOSING SET	191	01
17	0521059094	SIGMA SOY SINGLE SEED SYSTEM	192	01
18	0503011099	GREASE FITTING		02
19	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
21	0503010019	1/2\" SPRING WASHER		01
22	0503010060	1/2 UNC G.5 ZN HEX NUT		01
23	0521014021	1/2\" X 4.5\" X 5.4\" FASTENER		01
24	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
25	0503011336	1/2\" HEX SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521062184	LONG SEED ROW ARM		01
02	0502011830	ARTICULACION SUPPORT		01
03	0521018079	SEED ROW DRAWBAR LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		02
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0503011440	SPRING WASHER		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0501013354	FLAT WASHER		02
15	0502011400	18Z CONICAL GEAR		01
16	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
17	0502011505	18Z CONICAL GEAR		01
18	0521018078	1/2" X 66.5" HEX AXLE		01
19	0501013352	FLAT WASHER		04
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	187	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04
25	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
26	0503011440	SPRING WASHER		02
27	0503010060	1/2 UNC G.5 ZN HEX NUT		02
28	0511056586	15 X 15 SEED DDD LEFT	204	01



Item	Code	Description	See page	QT
01	0521052840	SHORT PIVOTING HIGH ROW	198	01
02	0511059350	FERTILIZER ROW SUPPORT ASSEMBLY	201	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0521059094	SIGMA SOY SINGLE SEED SYSTEM	192	01

SHORT PIVOTING HIGH ROW


0521052840




Item	Code	Description	See page	QT
01	0521068663	SHORT SEED ROW ARM		01
02	0511059244	SEED ROW SPRING ROD	199	01
03	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	200	01
04	0511052024	FAST CLOSING SET	191	01
05	0503034575	TITANIUM HIGH ROW SEED NOZZLE		01
06	0521018077	1/2" X 58.6" HEX AXLE		01
07	0521018079	SEED ROW DRAWBAR LID		01
08	0502011830	ARTICULACCION SUPPORT		01
09	1902010426	UPPER BEARING SEMI		02
10	0511051693	BASE FIXING SYSTEM	187	01
11	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	188	01
12	0503010752	1/2" X 3.1/2" BOLT		02
13	0503011440	SPRING WASHER		08
14	0503010060	1/2 UNC G.5 ZN HEX NUT		08
15	1902011561	BEARING SEMI		01
16	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
17	0503014729	1/4" UNF X 1/2" BOLT		02
18	0503011441	SPRING WASHER		02
19	0503010479	BOLT		04
20	0501013352	FLAT WASHER		01
21	0502011505	18Z CONICAL GEAR		01
22	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
23	0501013354	FLAT WASHER		02
24	0502011400	18Z CONICAL GEAR		01
25	0581014526	ELEVATION PLATE 3/8		01
26	0581014527	ELEVATION PLATE 12,5		03
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
28	0503010025	3/8 SPRING WASHER		04
29	0503010026	3/8" NUT		04
30	0503011099	GREASE FITTING		02
31	0503010002	1800 GREASE FITTING		02

SEED ROW SPRING ROD


0511059244




Item	Code	Description	See page	QT
01	0511060376	SEED SPRING GUIDE		01
02	0503010834	1/2 X 1 BOLT		02
03	0502040534	SPRING GUIDE BUSHING LOCK		02
04	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
05	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
06	0501013753	FLAT WASHER		01
07	0521010542	COUPLING SHAFT		01
08	0503010257	1/8" X 1" COTTERPIN		01
09	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0502012538	SPRING VARON SUPPORT		01
02	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503011336	1/2" HEX SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0502012823	DISC BLADE SUPPORT		01
02	0503034318	5/8 UNC X 2 BOLT		02
03	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0521052841	LONG PIVOTING HIGH ROW	203	01
02	0511059350	FERTILIZER ROW SUPPORT ASSEMBLY	201	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0521059094	SIGMA SOY SINGLE SEED SYSTEM	192	01




Item	Code	Description	See page	QT
01	0521068664	LONG SEED ROW ARM		01
02	0511059244	SEED ROW SPRING ROD	199	01
03	0511059243	ASSEMBLY GUIDE VARIUM SPRING SEED	200	01
04	0511052024	FAST CLOSING SET	191	01
05	0503034575	TITANIUM HIGH ROW SEED NOZZLE		01
06	0521018078	1/2" X 66.5" HEX AXLE		01
07	0521018079	SEED ROW DRAWBAR LID		01
08	0502011830	ARTICULACCION SUPPORT		01
09	1902010426	UPPER BEARING SEMI		02
10	0511051693	BASE FIXING SYSTEM	187	01
11	0511056586	15 X 15 SEED DDD LEFT	204	01
12	0503010752	1/2" X 3.1/2" BOLT		02
13	0503011440	SPRING WASHER		08
14	0503010060	1/2 UNC G.5 ZN HEX NUT		08
15	1902011561	BEARING SEMI		01
16	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
17	0503014729	1/4" UNF X 1/2" BOLT		02
18	0503011441	SPRING WASHER		02
19	0503010479	BOLT		04
20	0501013352	FLAT WASHER		01
21	0502011505	18Z CONICAL GEAR		01
22	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
23	0501013354	FLAT WASHER		02
24	0502011400	18Z CONICAL GEAR		01
25	0581014526	ELEVATION PLATE 3/8		01
26	0581014527	ELEVATION PLATE 12,5		03
27	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		04
28	0503010025	3/8 SPRING WASHER		04
29	0503010026	3/8" NUT		04
30	0503011099	GREASE FITTING		02
31	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	205	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	129	01
03	0511053172	LEFT LOW HUB WITH 15 DISC	128	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0521068567	BOX SPRING		01
02	0521050364	ROD WITH BEAK	207	01
03	0503034106	80 X 230 X 16,50 COMPRESSSION SPRING		01
04	0581012094	SUPPORT WASHER		01
05	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
06	0571019462	SUPPORT GUIDE PRING		01
07	0581012081	ARTICULATED SLEEVE		01
08	0581012084	ARTICULATED SLEEVE		01
09	0581012082	SCREW		01
10	0503012795	5/8" HEX SELF ADJUSTING NUT		01
11	0503010691	1/4" GREASE FITTING		01
12	0503010384	1/2" X 5" BOLT		02
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0503017874	BOLT 1/2 UNC		02
16	0571018541	BODY SOCKET FERTILIZER		01
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
18	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
19	0503010025	3/8 SPRING WASHER		02
20	0503010026	3/8" NUT		02
21	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
22	0503010417	7/8" NUT		01

ROD WITH BEAK


0521050364



Item	Code	Description	See page	QT
01	0501110865	ROD WITH BEAK HDA		01
02	0521067065	FLANGE WASHER SPRING		01
03	0581012092	AXLE FIXER		01
04	0581012093	WASHER		02
05	0503010406	501025 CLAMPING RING (FOR AXLE)		02



Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02



MARCHESAN

Technical Publications | Elaboration and Revision

LORENA ROCHA ALVES

www.marchesan.com.br

