

ROW CROP PLANTERS

PST PLUS FLEX SUPREMA P.P - FRAME 4395 - CSU - APT

Code: 0501093560
Series: S-0116
Revision: 00
Date Revision: JUNHO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111390101	PST PLUS FLEX SUP PP 4395/9E500 ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

INDEX


0909095169	ASSY FRAME	1
0511057361	FRAME WITH WHEEL AXLE - 4395	2
0521045510	HYDRAULIC CYLINDER	2
0511058655	CYLINDER SET - 3245/3495/4045/4395	3
0521050054	WHEELS TRACTION SPRING WITHOUT TRANSMISSION	3
0521050053	WHEEL SUPPORT WITHOUT TRANSMISSION	4
0521055239	WHEEL WITH TIRE WITHOUT TRANSMISSION	5
0503062159	WHEEL WITH TIRE	6
0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	7
0531059578	4395 ALPHA II FERTILIZER HOPPER SET	8
0531059583	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4395	9
0531059579	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4395	10
0531055319	ALPHA II FERTILIZER METERING	11
0531055863	ASSY TRANSMISSION HUB	12
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	13
0531059139	ASSY COLLECTOR	14
0531055273	ALPHA FERTILIZER METERING CLAMP	15
0501053788	3/4 SQUARE AXLE FASTENER	16
0531057913	DOUBLE BEARING ASSEMBLY	17
0531057912	DOUBLE SIDE BEARING	18
0511057266	HYDRAULIC SYSTEM ASSEMBLY - 3245/3495/4045/4395	19
0501053834	MALE QUICK COUPLER	20
0541050449	VDRIVE ASSY 9 LINES 500 MS WV	21
0541050405	CONTROL 2C VAPPLY GEN-3	22
0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	23
0511056972	FILTER HYDAC	24
0511057358	PLATFORM ASSEMBLY - 4395	25
0511056536	LADDER ASSEMBLY	26
0511054971	JACK ASSEMBLY	27
0511057333	DRAWBAR ASSEMBLY - 3495/4045/4395/4845/5345/5745	28
0541050469	LABELS SET	29
0531059619	KIT WITH ALPHA COMPONENTS - 09 ROWS	30
0511059322	LIFTING SUPPORT ASSEMBLY	31
0511059323	SUPPORT PLATFORM TRANSPORT	32
0511059403	HANDRAIL ASSY - 4395	33
0531055877	BOX SEED SINGLE	34
0511058100	2 HOPPERS WITH 9 CONDUCTORS SET	35
0511057690	3" ARTICULATED SEED CONDUCTOR	36
0541050450	MECHANICAL ASSY APT VDRIVE/VAPPLY	37
0531050766	SENSOR ACTUATOR	38
0531050811	APT FILTER SUPPORT	39
0541050401	MOUNTED FERTILIZER MOTOR SUPPORT	40
0521052368	STRETCHER SIMPLE SEED	41
0521050269	SET TURBINE	42
0511059887	TURBINE PRECISION PLANTING	43
0521050154	PRECISION PLANTING TURBINE WITH HOLE	44
0511057270	DRAWBAR EXTENDER	45
0511054601	HITCH ARTICULATED TRACTOR	46
0511053179	TRACTOR COUPLING SHAFT	47
0511057817	SUPPORT HOSE	48
0909096743	SEED LINE/FERTILIZER ASSY	49
0531055866	FRONT LINE SEED P.P SHORT VDRIVE	50
0531055867	FRONT LINE SEED P.P LONG VDRIVE	51
0511058639	SHORT FERTILIZER ROW WITH DDD/DC20	52

INDEX

0511058640	LONG FERTILIZER ROW WITH DDD/DC20	53
0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	54
0511057272	LH SHORT ARM ROW FERTILIZER	55
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	56
0511053172	LEFT LOW HUB WITH 15 DISC	57
0511053173	RIGHT LOW HUB WITH 15 DISC	58
0511058630	20" DISC BLADE	59
0511058648	HUB WITH 20" DISC BLADE	60
0511056909	DISC BLADE HUB WITHOUT DISC	61
0511058634	SUPPORT LONG	62
0511057271	RH LONG ARM ROW FERTILIZER	63
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	64
0531055869	RIGHT REAR SEED ROW PP CSU VDRIVE	65
0531055871	REAR LEFT SEED ROW PP CSU VDRIVE	66
0511057154	RIGHT DDD	67
0511057153	DDD LEFT	68
0531055868	SET PP V-SET2 SUPREME CSU 3 VDRIVE	69
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	70
0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	71
0521056317	DEPTH CONTROL WITH LEVER ANGLE REGULATOR AXIS CPERA	72
0501052297	DEPTH WHEELS REGULATOR ASSY	73
0501052908	COMPACTOR WHEEL WITH BEARING	74
0521056314	LEFT ARM WHEEL DEPTH WITH HUB CPERA	75
0521056313	RIGHT ARM WHEEL DEPTH WITH HUB CPERA	76
0521056316	DEPTH WHEEL HUB WITH COMPLETE ANGLE ADJUSTING AXLE	77
0511055819	DEPTH BAND WITH RIM	78
0531050237	SEED CONDUCTOR FIXER 3 CSU RIGHT	79

ASSY FRAME

0909095169




Item	Code	Description	See page	QT
01	0511057361	FRAME WITH WHEEL AXLE - 4395	2	01
02	0503010003	1845 GREASE FITTING		04
03	0511058655	CYLINDER SET - 3245/3495/4045/4395	3	01
04	0521050054	WHEELS TRACTION SPRING WITHOUT TRANSMISSION	3	02
05	0531059578	4395 ALPHA II FERTILIZER HOPPER SET	8	01
06	0511057266	HYDRAULIC SYSTEM ASSEMBLY 3245/3495/4045/4395	- 19	01
07	0503014321	CABLE STEEL SHACKLE		02
08	0541050449	VDRIVE ASSY 9 LINES 500 MS WV	21	01
09	0541050405	CONTROL 2C VAPPLY GEN-3	22	01
10	0511057358	PLATFORM ASSEMBLY - 4395	25	01
11	0511056536	LADDER ASSEMBLY	26	02
12	0511054971	JACK ASSEMBLY	27	02
13	0511057333	DRAWBAR ASSEMBLY 3495/4045/4395/4845/5345/5745	- 28	01
14	0541050469	LABELS SET	29	01
15	0531059619	KIT WITH ALPHA COMPONENTS - 09 ROWS	30	01
16	0511059322	LIFTING SUPPORT ASSEMBLY	31	02
17	0511059323	SUPPORT PLATFORM TRANSPORT	32	04
18	0511059403	HANDRAIL ASSY - 4395	33	01
19	0531055877	BOX SEED SINGLE	34	01
20	0541050450	MECHANICAL ASSY APT VDRIVE/VAPPLY	37	01
21	0521050269	SET TURBINE	42	01
22	0501065677	STRUT		02
23	0511057270	DRAWBAR EXTENDER	45	01
24	0511054601	HITCH ARTICULATED TRACTOR	46	01
25	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
26	0511053179	TRACTOR COUPLING SHAFT	47	01
27	0521013022	TRANSPORT LOCK		01
28	0501068994	8,30 X 78 LOCK PIN		01
29	0503030168	HITCH PIN CLIP		01


ASSY FRAME

0909095169


Item	Code	Description	See page	QT
30	0511057817	SUPPORT HOSE	48	01
31	0501047895	25 ROD STOP		01
32	0501047885	30 ROD STOP		01
33	0501047886	35 ROD STOP		01
34	0501047887	40 ROD STOP		01
35	0503034867	AIR DITRIBUTOR PUMP		03
36	0503010246	CLAMP		09
37	0501053834	MALE QUICK COUPLER	20	01
38	0503010045	O'RING		01
39	0541010080	TERMINAL R.1 / 2 NPT		01
40	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
41	0581013729	NIPLE 1/2 NPT		01
42	0503014120	CHAIN		01
43	0909096743	SEED LINE/FERTILIZER ASSY	49	09




Item	Code	Description	See page	QT
01	0521065920	FRAME - 4395		01
02	0521065929	CARRYING-WHEELS PIVOT SHAFT - 4395		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0521065976	127 X 438,5 TUBE		01
02	0581013698	PISTON		01
03	0521067585	EXTENDER 50.80 X 371.5 WITH BUSHING		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010003	1845 GREASE FITTING		01
06	0503030385	CYLINDER PLUG N-002		02
07	0503018439	WIPER SEAL		01
08	0503018150	RING GUIDE		01
09	0502010382	5" END CAP		01
10	0581010353	RING SUPPORT		01
11	0503018026	1870-2000-375 B GASKET		01
12	0503011453	O'RING		02
13	0503018152	O'RING		02
14	0503018024	RING BS		01
15	0503018025	RING GUIDE		01
16	0503010039	D-2000 SCRAPER RING		01
17	0503010173	2-220 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0521045510	HYDRAULIC CYLINDER	2	01
02	0551014099	COUPLING SHAFT 31,75 X 185		01
03	0521010547	1.2" X 6.5" COUPLING SHAFT		01
04	0503010523	1/4" X 2" SPLIT PIN		02
05	0501047888	45 ROD STOP		01




Item	Code	Description	See page	QT
01	0503011119	7/8" X 6" BOLT		04
02	0501014251	FLAT WASHER		04
03	0521050053	WHEEL SUPPORT WITHOUT TRANSMISSION	4	01
04	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0531016887	CARRYING WHEEL AXLE ARM		01
03	0503010523	1/4" X 2" SPLIT PIN		01
04	0503010003	1845 GREASE FITTING		01
05	0511050681	TRACTION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0561016062	SPRING HITCH		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8 SPRING WASHER		04
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0521066716	WHEEL ARM ASSY		01
11	0503011167	M16 X 2 X 30 BOLT		02
12	0591010589	BODY LOCK WHEEL		02
13	0521055239	WHEEL WITH TIRE WITHOUT TRANSMISSION	5	01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	6	01
02	0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	7	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0531059583	LEFT HOPPER SUPPORT WITH FERTILIZER 9 METERING - 4395		01
02	0531059579	RIGHT HOPPER SUPPORT WITH FERTILIZER 10 METERING - 4395		01
03	0503011957	NYLON HANDLE		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
05	0503010337	5/16" NUT		04
06	0503018441	5/16" X 1-1/4" BOLT		04
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
08	0503010025	3/8 SPRING WASHER		10
09	0503010026	3/8" NUT		10
10	0501010984	10,50 X 27 X 3,00 FLAT WASHER		20
11	0503062391	FERTILIZER HOPPER		02
12	0503013751	3/8 UNC X 1.1/4 BOLT		16
13	0571019051	FIXER HOPPER WASHER		16
14	0503012535	3/8" SPRING WASHER		16
15	0503012531	3/8" INOX NUT		16




Item	Code	Description	See page	QT
01	0531065981	LEFT HOPPER SUPPORT - 4395		01
02	0531055319	ALPHA II FERTILIZER METERING	11	05
03	0501218487	3/4 X 390 AXLE		03
04	0531057908	SLEEVE 1/4 X 2		04
04A	0502013069	SLEEVE 21 X 38 X 50		01
04B	0503010010	1/4" X 2.1/2" COTTERPIN		01
05	0501053788	3/4 SQUARE AXLE FASTENER	16	07
06	0503030303	SUPPORT WASHER		07
07	0531057913	DOUBLE BEARING ASSEMBLY	17	01
08	0501218689	AXLE 3/4 X 190 WITH HOLE		01
09	0501218577	3/4 X 790 AXLE WITH RELIEF		01




Item	Code	Description	See page	QT
01	0531065982	RIGHT HOPPER SUPPORT - 4395		01
02	0531055319	ALPHA II FERTILIZER METERING	11	05
03	0501218487	3/4 X 390 AXLE		03
04	0531057908	SLEEVE 1/4 X 2		04
04A	0502013069	SLEEVE 21 X 38 X 50		01
04B	0503010010	1/4" X 2.1/2" COTTERPIN		01
05	0501053788	3/4 SQUARE AXLE FASTENER	16	07
06	0503030303	SUPPORT WASHER		07
07	0531057913	DOUBLE BEARING ASSEMBLY	17	01
08	0501218689	AXLE 3/4 X 190 WITH HOLE		01
09	0501218577	3/4 X 790 AXLE WITH RELIEF		01



Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	ASSY TRANSMISSION HUB	12	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	13	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513011170	ALLEN SCREW 1/4 UNC X 7/8 CCSI STAINLESS STEEL		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501310211	FRONT LID		01
19	0503036177	LID CORD		01
20	0531059139	ASSY COLLECTOR	14	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO ADHESIVE LABEL 41.5 X 29		01
15	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT GUIDE DOSING COVER		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01

ASSY COLLECTOR


0531059139




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	15	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0531057912	DOUBLE SIDE BEARING	18	01
02	0502013068	SIDE BEARING SHAFT SUPPORT FERTILIZER SILO		01
03	0503010845	501035 CLAMPING RING (FOR AXLE)		01
04	0503010337	5/16" NUT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0531057901	GEAR		01
07	0503030119	LOCK PIN		01
08	0501010694	FLAT WASHER		02
09	0503010371	5/16" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0502013071	SIDE BEARING		01
02	0503016065	ROLLER BEARING		02
03	0503011800	SEAL RING		01




Item	Code	Description	See page	QT
01	0511057267	HOSE KIT HYDRAULIC		01
01A	0501080722	3/8 X 3300 TC-TM HOSE ASSY		01
01B	0501082023	HOSE 3/8 X 3600 TC-TM		01
02	0501053834	MALE QUICK COUPLER	20	02
03	0503013100	NYLON CLAMP		02
04	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0531057126	KIT CABIN SEEDSENSE GEN3		001
01A	0503063047	MONITOR KIT		001
01B	0503019536	MODULE		001
01C	0503063204	KIT BASE		001
01D	0503019759	WHIP		001
01E	0503017972	TRACTOR BATTERY WHIP		001
01F	0503017973	ENERGY DISTRIBUTOR MODULE		001
01G	0503016452	FIXING SUPPORT AG500 TRIMBLE		001
01H	0503016234	TRIMBLE FIXING WINDOW		001
01I	0503018653	ADAPTER WHIP		001
01J	0503018097	WHIP BATTERY		001
01K	0503019424	WHIP JD STARFIRE GPS		001
02	0503018062	MAIN WHIP		001
03	0503017994	EXTENSION CABLE		001
04	0503062454	TRACTOR CONNECTION ASSY		001
05	0503017996	EXTENSION CABLE APEX 729151 - 4,50MTS		001
06	0503019291	SUPPORT SENSOR		001
07	0513010031	EXTERNAL LIFTING CABLE PSS-X1005B CAN-5M		001
08	0513010275	PP725905 VACUUM SENSOR		002
09	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		180
10	0503013100	NYLON CLAMP		060
11	0503017975	WHIP		009
12	0503019755	UNIT MODULE		009
13	0503019776	SEED TUBE WITH WAVE VISION SENSOR		009
14	0503062431	ELECTRIC MOTOR		009
15	0503018055	WHIP ADAPTER		001




Item	Code	Description	See page	QT
01	0513010491	EXTENSION 06 PINS		02
02	0513011519	GRANULAR VAPPLY MODULE		02
03	0513010459	HYDRAULIC ENGINE WHIP 724287		02
04	0513010460	WHIP Y 06 PINS 729508		02
05	0513011898	DELPHI PWM ADAPTER 02 WAY MALE		02
06	0513011899	ENCODER ADAPTER DT06/6S/DELPHI 03 FEMALE WAYS		02
07	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	23	02
08	0511056972	FILTER HYDAC	24	01




Item	Code	Description	See page	QT
01	0513010049	MOTOR OMP X 80 EMD - 11185907		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02



Item	Code	Description	See page	QT
01	0503063151	PRESSURE FILTER MFM HYDAC 1319024BR		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	7/8" T ADAPTER		01
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0571018867	PLATFORM - 4395		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8 SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
08	0503013357	3/8 SELF-ADJUSTING NUT	02	

JACK ASSEMBLY

0511054971




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012806	SUPPORT REAR FIXER DRAWBAR		04
02	0502012789	FIXER SUPPORT FERTILIZER ROW		04
03	0503017960	5/8" X 3-12" BOLT		16
04	0503010811	5/8" UNF SELF ADJUSTING NUT		16
05	0501010191	1" X 6" BOLT		04
06	0503010012	1" SPRING WASHER		04
07	0501010059	1.5/8 NUT		04
08	0502012805	SUPPORT FRONT FIXER DRAWBAR		04
09	0502012789	FIXER SUPPORT FERTILIZER ROW		04
10	0503017960	5/8" X 3-12" BOLT		16
11	0503010811	5/8" UNF SELF ADJUSTING NUT		16
12	0521065958	DRAWBAR		01
13	0561019087	DRAWBAR TRANSPORT LOCK		01
14	0551014099	COUPLING SHAFT 31,75 X 185		01
15	0521010544	1.2" X 4.9" COUPLING SHAFT		01
16	0503030085	LOCK PIN		02
17	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503034226	LABEL ADHESIVE	02	
02	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)	02	
03	0503033892	ADHESIVE LABEL LOGO TATU HOPPER 190 X 720	01	
04	0503034257	ADHESIVE LABEL	01	
05	0503033417	ADHESIVE LABEL	02	
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	02	
07	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
08	0503033423	LABEL ADHESIVE NUMBER 9	02	
09	0503031428	READ MANUAL DECAL	01	
10	0503031942	ADHESIVE LABEL	01	
11	0503031565	ADHESIVE LABEL CARE	02	
12	0503031566	ADHESIVE LABEL	02	
13	0503031425	ADHESIVE LABEL ATTENTION	02	
14	0503032930	ADHESIVE LABEL DANGER	05	
15	0503031087	ADHESIVE LABEL	01	
16	0503034003	SERIAL NUMBER TAG 61 X 118	01	
17	0503010001	3.2 X 5.5 RIVET	04	
18	0503034500	ADHESIVE LABEL	01	
19	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER	02	
20	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER	01	




Item	Code	Description	See page	QT
01	0531058988	WORM THREAD P.16 WITH FERTILIZER DOSING SHAFT COATING		09
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		09
01B	0503035859	SUPPORT SLEEVE		09
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		09
02A	0501111196	PALLETIZED FERTILIZER COATING COMPLETE PLANTING FERTILIZER DOSER ALP II		09
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		09
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521067033	FRAME LIFTING SUPPORT		01
03	0503017960	5/8" X 3-12" BOLT		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0581011989	SIDE BODY FIXER PLATFORM		01
02	0551019884	45 X 50 X 3/8 FASTENER		01
03	0503010025	3/8 SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521065951	FRAME HANDRAIL - 4395		02
02	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
03	0503010752	1/2" X 3.1/2" BOLT		04
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
05	0503010019	1/2" SPRING WASHER		08
06	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0511058100	2 HOPPERS WITH 9 CONDUCTORS SET	35	01
02	0521066102	TOWER SUPPORT HOPPER		02
03	0531060420	SUPPORT TOWER SEED BOX		02
04	0501010942	3/8" X 1-1/4" BOLT		08
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
06	0503010025	3/8 SPRING WASHER		08
07	0503010026	3/8" NUT		08
08	0502010175	HITCH CLAMP		04
09	0501011543	5/8" X 4" BOLT		08
10	0503012412	5/8" UNC SELF LOCKING NUT		08
11	0571019394	PROTECTOR		02
12	0551019884	45 X 50 X 3/8 FASTENER		08
13	0501010453	FLAT WASHER		16
14	0503010025	3/8 SPRING WASHER		16
15	0503010026	3/8" NUT		16



Item	Code	Description	See page	QT
01	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	36	09
08	0501010942	3/8" X 1-1/4" BOLT		36
09	0503010025	3/8 SPRING WASHER		36
10	0503010026	3/8" NUT		36
11	0571015773	SUPPORT SEED		03
12	0501011643	3/8 X 1"BOLT		12
13	0503010025	3/8 SPRING WASHER		12
14	0503010026	3/8" NUT		12



Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8 SPRING WASHER		01
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	5/16" NUT		02
11	0502012767	SEED NOZZLE FIXER SUPPORT		01




Item	Code	Description	See page	QT
01	0591015101	LIFT SENSOR SUPPORT		01
02	0503013356	RIVET POP 3,2 X 10,0		01
03	0531050766	SENSOR ACTUATOR	38	01
04	0531050811	APT FILTER SUPPORT	39	01
05	0571016236	HIDRAULIC ADAPTER		01
06	0503012341	7/8" T ADAPTER		01
07	0501053834	MALE QUICK COUPLER	20	02
08	0521067685	SUPPORT PDM VDRIVE		01
09	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		04
10	0503015110	M06 SPRING WASHER		04
11	0571016237	1/2"UNC X2.1" X1.6" FASTENER ASSY		01
12	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
13	0503010019	1/2" SPRING WASHER		02
14	0503010060	1/2 UNC G.5 ZN HEX NUT		02
15	0541050401	MOUNTED FERTILIZER MOTOR SUPPORT	40	02
16	0541050183	MOUNTED SUPPORT RIGHT SIDE VAPPLY MODULE		02
17	0541050387	HOSE SET		01
17A	0501080134	1/2 X 1600 TC-TC HOSE		01
17B	0501080057	HOSE 1/2 X 900 TR-TC		01
17C	0521057427	HOSE		01
17CA	0501082120	1/2" X 177" TR-TM HOSE ASSY		01
17CB	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
17CC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
17CD	0503018952	PLASTIC BOLT		06
17D	0521052519	HOSE 1/2 X 4200 TC-TM GRAY / RED		01
17DA	0501081073	HOSE 1/2 X 4200 TC-TM		01
17DB	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
17DC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
17DD	0503018952	PLASTIC BOLT		06
18	0571017368	SUPPORT GUTTER		06
19	0501011643	3/8 X 1"BOLT		06


Item	Code	Description	See page	QT
20	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
21	0503010025	3/8 SPRING WASHER		06
22	0503010026	3/8" NUT		06
23	0501312707	GUTTER 25 X 100 X 1700		02

SENSOR ACTUATOR


0531050766




Item	Code	Description	See page	QT
01	0591015026	LIFTING SENSOR DRIVING BODY		01
02	0561016468	FASTENER		01
03	0503011336	1/2" HEX SELF ADJUSTING NUT		02
04	0591015027	SENSOR DRIVER		01
05	0503010282	1/4" X 3/4" BOLT		01
06	0503010144	1/4" NUT		01
07	0503010143	1/4" SPRING WASHER		01




Item	Code	Description	See page	QT
01	0591017488	APT FILTER SUPPORT		01
02	0581019503	3/8" FASTENER		02
03	0503015135	FLAT WASHER 10 X 18 X 2		04
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0501312573	FERTILIZER MOTOR SUPPORT		01
02	0581019503	3/8" FASTENER		01
03	0503015135	FLAT WASHER 10 X 18 X 2		02
04	0503010025	3/8 SPRING WASHER		02
05	0503010026	3/8" NUT		02
06	0521052368	STRETCHER SIMPLE SEED	41	01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		02
08	0503010019	1/2" SPRING WASHER		02
09	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		02
10	0501212318	GLOVE ENCODER		01
11	0503011807	SCREW M8 X 1,25X10		01
12	0503015162	M 8 X 1,25 X 20 BOLT		01
13	0531064938	GEAR 15Z P12.70 ENGINE		01
14	0503062754	GEAR 34Z P.1/2 APT		01
15	0501312572	SUPPORT DYNAPAR ENCODER		01
16	0503015002	40-1 CHAIN X 66 LINK + REDUCTION		01
17	0503010144	1/4" NUT		01
18	0503010143	1/4" SPRING WASHER		01
19	0503013849	1/4" UNC X 3/4" BOLT		01




Item	Code	Description	See page	QT
01	0581016479	CURRENT STRETCH SHAFT 81		01
02	0503030402	PULLEY		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0581012111	RIGHT SUPPORT		01
02	0581012112	LEFT SUPPORT		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0581012166	HOSE		02
07	0503011372	102 TO 121 CLAMP		04
08	0511057348	DISTRIBUTOR VACUUM		02
09	0503031436	AIR DISTRIBUTOR PUMP		01
10	0503010246	CLAMP		01
11	0571019403	STAPLE FIXER		04
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
13	0503010025	3/8 SPRING WASHER		08
14	0503010026	3/8" NUT		08
15	0571013731	VACUUM GAUGE SUPPORT		01
16	0503013584	VACUUM GAUGE		01
17	0511057846	ASSY HOSE KIT		01
17A	0501080850	3/8" X 240" TC-TM HOSE		01
17B	0501081810	HOSE 1/2 X 6200 TC-TM		02
17C	0501053834	MALE QUICK COUPLER	20	02
17D	0581012991	SPRING PROTECTION PLASTIC HOSE		01
17E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN		01
18	0511059887	TURBINE PRECISION PLANTING	43	01
19	0503031576	ELBOW		02
20	0571019716	ADAPTER		08
21	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		08
22	0503015062	TUBE		2,5




Item	Code	Description	See page	QT
01	0521050154	PRECISION PLANTING TURBINE WITH HOLE	44	01
02	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
03	0501011460	7/8 NF REDUCTION NIPPLE		04
04	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
05	0503010392	2-046 N 3006 9B O'RING		01
06	0503010190	2-114 N 3006-9B O'RING		04
07	0501080218	1/2 X 750 HOSE		01
08	0581012096	ROUND SLEEVE		02
09	0503031087	ADHESIVE LABEL		01
10	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521065959	JACK R.1.1/2 UNC RIGHT X 240		01
03	0521065960	JACK R.1.1/2 UNC LEFT X 240		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02







Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0531055866	FRONT LINE SEED P.P SHORT VDRIVE	50	01
02	0531055867	FRONT LINE SEED P.P LONG VDRIVE	51	01
03	0511058639	SHORT FERTILIZER ROW WITH DDD/DC20	52	01
04	0511058640	LONG FERTILIZER ROW WITH DDD/DC20	53	01
05	0531055869	RIGHT REAR SEED ROW PP CSU VDRIVE	65	01
06	0531055871	REAR LEFT SEED ROW PP CSU VDRIVE	66	01
07	0521056317	DEPTH CONTROL WITH LEVER ANGLE 72 REGULATOR AXIS CPERA	72	01
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
09	0503010905	1/2" X 2-1/4" BOLT		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0531059866	SEED CONDUCTOR RIGHT 3 X 1300		01
12A	0501311187	RIGHT SEED CONDUCTOR 3 X 1300		01
12B	1164930001	BLACK VINYL TUBE 3.1/2		01
13	0503030391	RIGHT FERTILIZER NOZZLE		01
14	0503030392	LEFT FERTILIZER NOZZLE		01
15	0503031145	2" X 2" X 20" HOSE		01
16	0503031076	2" HOSE CLAMP		01
17	0531050237	SEED CONDUCTOR FIXER 3 CSU RIGHT	79	01
18	0531013600	PRESS ADJUSTMENT LEVER		01
19	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
20	0503010243	CLAMP		01




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0501012140	FLAT WASHER		04
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8" UNC SELF LOCKING NUT		04
08	0502012804	PIVOT ARM SEED ROW		02
09	0571018882	SEED ROW ARM SLEEVE		08
10	0503010002	1800 GREASE FITTING		03
11	0503010004	1890 GREASE FITTING		01
12	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
13	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
14	0571018883	PIN FIXER SPRING		03
15	0571018884	LOCK PIN ROW ARTICULAT		01
16	0503030168	HITCH PIN CLIP		04
17	0521065943	REAR FRAME LONG ROW SEED		01
18	0503010765	3/8" X 3" BOLT		01
19	0503010025	3/8 SPRING WASHER		01
20	0503010026	3/8" NUT		01
21	0521064369	HOSE HOLDER		01




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0501012140	FLAT WASHER		04
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8" UNC SELF LOCKING NUT		04
08	0502012804	PIVOT ARM SEED ROW		02
09	0571018882	SEED ROW ARM SLEEVE		08
10	0503010002	1800 GREASE FITTING		03
11	0503010004	1890 GREASE FITTING		01
12	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
13	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
14	0571018883	PIN FIXER SPRING		03
15	0571018884	LOCK PIN ROW ARTICULAT		01
16	0503030168	HITCH PIN CLIP		04
17	0521066158	FRAME REAR LONG ROW SEED		01
18	0503010765	3/8" X 3" BOLT		01
19	0503010025	3/8 SPRING WASHER		01
20	0503010026	3/8" NUT		01
21	0521064369	HOSE HOLDER		01




Item	Code	Description	See page	QT
01	0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	54	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057272	LH SHORT ARM ROW FERTILIZER	55	01
06	0511058630	20" DISC BLADE	59	01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	62	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057271	RH LONG ARM ROW FERTILIZER	63	01
06	0511058630	20" DISC BLADE	59	01




Item	Code	Description	See page	QT
01	0502012794	SHORT SUPPORT FERTILIZER ROW	01	
02	0503011854	5/8" X 1-1/4" BOLT	02	
03	0503010002	1800 GREASE FITTING	01	
04	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
05	0503017960	5/8" X 3-12" BOLT	04	
06	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
07	0521066744	FERTILIZER ROW ADJUSTMENT SPRING	01	
08	0571019062	SLEEVE	01	
09	0571019059	SUPPORT WASHER	01	
10	0503010417	7/8" NUT	04	
11	0503034320	COMPRESSION SPRING	01	
12	0502012813	FLANGE WASHER SPRING	01	




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	56	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02



Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	57	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	58	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUBLE DISC AXLE		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01

20" DISC BLADE


0511058630




Item	Code	Description	See page	QT
01	0571018989	LH BLADE DISC ARM		01
02	0502012790	LOCK NUT		01
03	0511058648	HUB WITH 20" DISC BLADE	60	01
04	0521065978	RIGHT ARM WITH WASHER LOCK		01
05	0571019035	SLEEVE SUPPORT ARM		01
06	0521010452	SLEEVE		01
07	0521066743	SPRING REGULATOR		01
08	0503010417	7/8" NUT		04
09	0571019033	FIXATION AXLE		01
10	0503034319	LOCK PIN		01
11	0502012813	FLANGE WASHER SPRING		01
12	0503034320	COMPRESSION SPRING		01
13	0571019032	SUPPORT WASHER		01
14	0571019034	FLANGE WASHER AXLE		02
15	0503010002	1800 GREASE FITTING		01
16	0503013185	3/4" X 5-1/2" BOLT		01
17	0503011255	3/4" LOCK NUT		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503011440	SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	61	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0502012793	DISC HUB		01
02	0571018047	DISC BLADE HUB AXLE		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DUST CLOAK		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0502012795	SUPPORT LONG		01
02	0503011854	5/8" X 1-1/4" BOLT		02
03	0503010002	1800 GREASE FITTING		01
04	0502012789	FIXER SUPPORT FERTILIZER ROW		01
05	0503017960	5/8" X 3-12" BOLT		04
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
08	0571019062	SLEEVE		01
09	0571019059	SUPPORT WASHER		01
10	0503010417	7/8" NUT		04
11	0503034320	COMPRESSION SPRING		01
12	0502012813	FLANGE WASHER SPRING		01




Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	64	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	58	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	57	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511057154	RIGHT DDD	67	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0531055868	SET PP V-SET2 SUPREME CSU 3 VDRIVE	69	01




Item	Code	Description	See page	QT
01	0511057153	DDD LEFT	68	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0531055868	SET PP V-SET2 SUPREME CSU 3 VDRIVE	69	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	57	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	RIGHT LOW HUB WITH 15 DISC	58	01
04	0503810026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012780	SUPPORT DDD RIGHT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	57	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	RIGHT LOW HUB WITH 15 DISC	58	01
04	0503810026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0571017895	PIN FIXER CONDUCTOR P.P		01
02	0503010293	CLAMP KNOB		01
03	0503010140	1/8" X 3/4" COTTERPIN		02
04	0503010025	3/8 SPRING WASHER		02
05	0571019491	SLUICE PNEUMATIC		01
06	0501011643	3/8 X 1" BOLT		01
07	0503010209	3/8" UNC BUTTERFLY NUT		01
08	0502012807	SUPPORT HOPPER PRECISION PLANTING		01
09	0571019489	CLAMP PRECISION PLANTING		01
10	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
11	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 70 DISC		01
12	0503012721	1/4" X 4" BOLT		01
13	0503012880	1/4" UNC SELF ADJUSTING NUT		01
14	0571014024	FAST BOLT GUIDE AXLE		01
15	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
16	0503015110	M06 SPRING WASHER		02
17	0503018139	BOLT M6 X 10 CYLINDRICAL HEAD WITH SLOT		03
18	0503037390	PACKING FOR PLANTING		01
19	0503034824	FIXATIVE		01
20	0581011226	FIXER CLOSING P. PLANTING CONTROL CPRA		01
21	0503010337	5/16" NUT		04
22	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
23	0503011953	5/16" X 1" BOLT		03
24	0503012163	5/16" X 1-1/2" BOLT		01
25	0521066707	FEEDER		01
26	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
27	0503010589	1/2" UNC SELF ADJUSTING NUT		01



Item	Code	Description	See page	QT
01	0571019613	STRAW PRECISION PLANTING SHIELD		01
02	0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	71	01



Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
03	0521019093	0.6" X 2.7" PIVOT SHAFT		01
04	0503010581	RING		01
05	1902012116	PRESS WHEEL ADJUSTER		01
06	0501052297	DEPTH WHEELS REGULATOR ASSY	73	01
07	0501052908	COMPACTOR WHEEL WITH BEARING	74	02
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
09	0521014508	FLAT WASHER		10
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0581011100	DEPTH WHEEL AXLE		01
12	0571017749	FLAT WASHER		02
13	0521056314	LEFT ARM WHEEL DEPTH WITH HUB CPERA	75	01
14	0521056313	RIGHT ARM WHEEL DEPTH WITH HUB CPERA	76	01
15	0503010358	5/16" X 5/8" BOLT		08
16	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
17	0503013816	5/16" LOCKNUT		08
18	0501011445	FLAT WASHER		02
19	0503010311	1/2" X 1-1/4" BOLT		02
20	0503010019	1/2" SPRING WASHER		02
21	0503010025	3/8 SPRING WASHER		02
22	0503010026	3/8" NUT		02
23	0503010849	3/8" X 1-1/2" BOLT		02
24	0503010256	3/8" X 3/4" BOLT		01
25	0511055819	DEPTH BAND WITH RIM	78	02
26	0503010691	1/4" GREASE FITTING		02
27	0503033942	COMPACTOR WHEEL REGULATOR LID		01
28	0521064073	REGULACION WHEEL COMPACTOR		01
29	0541016906	PRESS WHEELS REGULATOR BODY		01
30	0521010539	0.3" X 1.2" COUPLING SHAFT		01
31	0503010140	1/8" X 3/4" COTTERPIN		01




PST PLUS FLEX SUPREMA P.P - FRAME 4395 - CSU - APT
DEPTH CONTROL WITH LEVER ANGLE REGULATOR AXIS

Page 72
0521056317


Item	Code	Description	See page	QT
32	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0521056316	DEPTH WHEEL HUB WITH COMPLETE ANGLE 77 ADJUSTING AXLE		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110833	DEPTH CONTROL RIGHT ARM		01
02	0521056316	DEPTH WHEEL HUB WITH COMPLETE ANGLE 77		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501013636	SPACING SLEEVE		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010689	SEAL 00763-BR		01
04	0503011105	SEAL RING		01
05	0503010269	6204 BALL BEARING		02
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0521019178	PROTECTION LID		01
09	0503010143	1/4" SPRING WASHER		03
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0521060071	DEPTH CONTROL AXLE		01



Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05



Item	Code	Description	See page	QT
01	0503013759	NUT		02
02	0501010694	FLAT WASHER		02
03	0502012979	CLAMP 3 RIGHT CSU		02
04	0503010421	5/16" X 1-1/2" BOLT		02



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

