

ROW CROP PLANTERS

**PST4 FLEX SUPREMA P.P - FRAME
3245/3695/4045/4495/4845/5345 – CSU
(FROM 05/2023)**

Code: 0501093587
Series: S-0116
Revision: 00
Date Revision: JUNHO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111290136	PST4 FLEX SUP PP 3245/4E900 ESPECIAL S-0116
0111290158	PST4 FLEX SUP PP 3245/5E650 ESPECIAL S-0116
0111290143	PST4 FLEX SUP PP 3695/7E500 ESPECIAL S-0116
0111290152	PST4 FLEX SUP PP 4045/8E500 ESPECIAL S-0116
0111290131	PST4 FLEX SUP PP 4045/8E500 ESPECIAL S-0116
0111290135	PST4 FLEX SUP PP 4495/9E500 ESPECIAL S-0116
0111290142	PST4 FLEX SUP PP 4495/9E500 ESPECIAL S-0116
0111290130	PST4 FLEX SUP PP 4845/10E500 ESPECIAL S-0116
0111290133	PST4 FLEX SUP PP 4845/10E500 ESPECIAL S-0116
0111290137	PST4 FLEX SUP PP 4845/10E500 ESPECIAL S-0116
0111290128	PST4 FLEX SUP PP 4845/10E500 MH CSU MTH PP S-0116
0111290148	PST4 FLEX SUP PP 4845/11E450 ESPECIAL S-0116
0111290140	PST4 FLEX SUP PP 5345/12E450 ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909096756	ASSY FRAME	1
0501058194	FRAME WITH AXLE WHEEL - 3245	2
0511051956	FRAME WITH AXLE WHEEL - 3695	3
0511050836	WHEEL AXLE FRAME - 4495	4
0501058196	WHEEL AXLE FRAME - 4845	5
0511051118	WHEEL AXLE FRAME - 5345	6
0511057124	CYLINDER ASSY	7
0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	8
0511056529	CYLINDER ASSY	9
0511058406	HYDRAULIC CYLINDER	10
0511059265	WHEELED WITH SPRING TRACTION WITH TRANSMISSION	11
0511059262	WHEEL SUPPORT ASSY	12
0501058241	WHEEL SUPPORT CHAIN TENSIONER	13
0511052770	WHEEL WITH TIRE	14
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	15
0501058240	WHEEL FASTENER WITH TENSIONER	16
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	17
0501058239	WHEEL CHAIN TENSIONER BEARING	18
0501058244	WHEEL FIXED CHAIN TENSIONER	19
0501058242	WHEEL MOBILE CHAIN TENSIONER	20
0521050486	RIGHT TRANSMISSION ASSY - 3245	21
0511059077	RIGHT TRANSMISSION ASSY - 3695	22
0521050189	RIGHT TRANSMISSION ASSY - 4045	23
0521053969	RIGHT TRANSMISSION ASSY - 4495	24
0521050294	RIGHT TRANSMISSION ASSY - 4880	25
0521056820	RIGHT TRANSMISSION ASSY - 5345	26
0501052560	MOTOR AXLE SIGNAL	27
0511051434	TRANSMISSION ACTUATOR	28
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	29
0521050183	RIGHT GEAR BOX ASSY	30
0501058212	SEMI MOUNTED RIGHT CHANGE	31
0511059266	CLOSED BEARING	32
0501056271	GEARBOX CLOSED BEARING	33
0501056443	GEAR HOUSING BEARING	34
0501056444	BEARING WITH ROLLER	35
0501048790	AXLE WITH RING	36
0501054655	CHAIN TENSIONER ASSY	37
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	38
0511054363	CHAIN TENSIONER	39
0501058265	STRETCHER LOWER CURRENT 21Z SEED	40
0501058254	UPPER SEED CHAIN TENSIONER	41
0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42
0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43
0521050487	LEFT TRANSMISSION ASSY - 3245	44
0511059078	LEFT TRANSMISSION ASSY - 3695	45
0521050190	LEFT TRANSMISSION ASSY - 4045	46
0521053970	LEFT TRANSMISSION ASSY - 4495	47
0521050295	LEFT TRANSMISSION ASSY - 4880	48
0521056821	LEFT TRANSMISSION ASSY - 5345	49
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	50
0521050184	EXCHANGE LEFT ASSY	51
0501058213	LH GEAR BOX	52
0521055217	LOWER CURRENT STRETCH	53
0521055216	BEARING WITH GEAR	54
0521055218	BEARING GEAR WITH DOUBLE	55



MARCHESAN

INDEX

0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	56
0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	57
0501058165	SEMI-ASSEMBLED HYDRAULIC MARKER 3245/7	58
0511052482	SEMI-ASSEMBLED HYDRAULIC MARKER 3695	59
0501058170	SEMI-ASSEMBLED HYDRAULIC MARKER 4045	60
0511050838	SEMI-ASSEMBLED HYDRAULIC MARKER 4495	61
0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845	62
0511051119	SEMI-ASSEMBLED HYDRAULIC MARKER 5345	63
0511058449	HYDRAULIC CYLINDER	64
0501054649	HBM SEQUENTIAL VALVE	65
0501050633	ROW MARKER DISC ASSEMBLY	66
0511053904	ROW MARKER DISC	67
0531056600	3245 - RIGHT/LEFT FERTILIZER HOPPER SET	68
0531056601	3695 - RIGHT/LEFT FERTILIZER HOPPER SET	69
0531056602	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4045	70
0531056757	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4495	71
0531056603	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4845	72
0531056921	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 5345	73
0531056920	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 5345	74
0531055319	ALPHA II FERTILIZER METERING	75
0531055863	ASSY TRANSMISSION HUB	76
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	77
0531059139	ASSY COLLECTOR	78
0531055273	ALPHA FERTILIZER METERING CLAMP	79
0501053788	3/4" SQUARE AXLE FASTENER	80
0531057911	22Z GEAR SIDE BEARING ASSEMBLY	81
0531057901	GEAR	82
0531056919	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 5345	83
0511057236	HANDRAIL ASSY - 3245	84
0511058318	HANDRAIL ASSY - 3695	85
0511057130	HANDRAIL ASSY - 4045	86
0511057566	HANDRAIL ASSY - 4495	87
0511057651	HANDRAIL ASSY - 4845	88
0511058308	HANDRAIL ASSY - 5345	89
0511057237	PLATFORM ASSY - 3245	90
0511058319	PLATFORM ASSY - 3695	91
0511057129	PLATFORM ASSY - 4045	92
0511057565	PLATFORM ASSY - 4495	93
0511057650	PLATFORM ASSY - 4845	94
0511058312	PLATFORM ASSY - 5345	95
0511056536	LADDER ASSEMBLY	96
0511054971	JACK ASSEMBLY	97
0511057142	DRAWBAR ASSEMBLY - 3245/3695/4045/4495	98
0511057150	DRAWBAR ASSEMBLY - 4845/5345	99
0511057239	MANUAL CANISTER ASSY	100
0531057179	3245 - ALPHA II HYDRAULIC MARKER DECAL SET	101
0531057816	3695 - ALPHA II HYDRAULIC MARKER DECAL SET	102
0531057818	4045 - ALPHA II HYDRAULIC MARKER DECAL SET	103
0531057819	4495 - ALPHA II HYDRAULIC MARKER DECAL SET	104
0531057820	4845 - ALPHA II HYDRAULIC MARKER DECAL SET	105
0531057821	4845 - ALPHA II HYDRAULIC MARKER DECAL SET	106
0531057822	5345 - ALPHA II HYDRAULIC MARKER DECAL SET	107
0501054258	DRAWBAR ESTABILIZER ASSY	108
0511054601	HITCH ARTICULATED TRACTOR	109



MARCHESAN

INDEX

0511053179	TRACTOR COUPLING SHAFT	110
0511057817	SUPPORT HOSE	111
0521055554	ASSY TURBINE MTH P.P CSU 3245/4	112
0511059319	AIR FIXING SUPPORT	113
0521050261	DISTRIBUTOR AIR CENTER 08 MOUTHS - 19 A 21	114
0511059406	TURBINE P.P MOUNTED	115
0521050154	PRECISION PLANTING TURBINE WITH HOLE	116
0521052549	CLAMP	117
0511057906	HOSE ASSY	118
0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	119
0521050482	TURBINE ASSEMBLY MTH P.P CSU 3245/7 - 3695	120
0521050553	ASSY TURBINE MTH P.P CSU 4045/9	121
0511057348	DISTRIBUTOR VACUUM	122
0521053973	ASSY TURBINE MTH P.P CSU 4495/9	123
0521050016	RIGHT AIR DISTRIBUTOR 06 NOZZLES - 17 E500	124
0521050017	LEFT AIR DISTRIBUTOR 06 NOZZLES - 17 E500	125
0521050707	ASSY TURBINE MTH P.P CSU 4845/10	126
0531051497	TURBINE ASSEMBLY MTH P.P CSU 4845/11	127
0521056824	ASSY TURBINE MTH P.P CSU 5345/12	128
0521053445	9 ROWS SEED MONITORING SET	129
0531053676	10 ROWS SEED MONITORING SET	130
0511056394	11 ROWS SEED MONITORING SET	131
0521053448	12 ROWS SEED MONITORING SET	132
0531059614	KIT WITH ALPHA COMPONENTS - 04 ROWS	133
0531059615	KIT WITH ALPHA COMPONENTS - 05 ROWS	134
0531059617	KIT WITH ALPHA COMPONENTS - 07 ROWS	135
0531059618	KIT WITH ALPHA COMPONENTS - 08 ROWS	136
0531059619	KIT WITH ALPHA COMPONENTS - 09 ROWS	137
0531059620	KIT WITH ALPHA COMPONENTS - 10 ROWS	138
0531059621	KIT WITH ALPHA COMPONENTS - 11 ROWS	139
0531059622	KIT WITH ALPHA COMPONENTS - 12 ROWS	140
0511058368	EAR MOVABLE	141
0909099234	HEX AXLE ASSEMBLY	142
0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	143
0521055555	CSU C3 SEMI-ASSEMBLED ASSY 3245/4	144
0521055563	CSU C3 2 HOPPERS ASSEMBLY	145
0511057690	3" ARTICULATED SEED CONDUCTOR	146
0521051927	TOWER SUPPORT HOPPER	147
0521050491	CSU C3 SEMI-ASSEMBLED ASSY 3245/3695 7	148
0521050490	2 HOPPERS WITH 7 CONDUCTORS SET	149
0521052687	RIGHT SUPPORT TOWER WITH BOLT	150
0511059792	CSU C3 SEMI-ASSEMBLED ASSY 4045/4495 8	151
0511059790	CSU C3 2 HOPPERS ASSEMBLY	152
0511058101	ASSEMBLY CSU C3 SEMI MOUNTED 4045/4495	153
0511058100	2 HOPPERS WITH 9 CONDUCTORS SET	154
0511057736	CSU C3 SEMI-ASSEMBLED ASSY 4845/10	155
0511057737	2 HOPPERS WITH 10 CONDUCTORS SET	156
0511059318	CSU C3 SEMI-ASSEMBLED ASSY 5950/12	157
0511058724	2 HOPPERS WITH 12 CONDUCTORS ASSEMBLY	158
0521055993	SEED VDRIVE ASSY 4845/10E500	159
0521053840	MONITOR / ANTENNA COMPONENT ASSEMBLY HEMISFERE VDRIVE USAP	160
0501053834	MALE QUICK COUPLER	161
0909096757	ASSY SEED/FERTILIZER ROW	162
0511057243	LEFT SHORT SEED ROW FRONT	163



MARCHESAN

INDEX

0511054635	BEARING AXLE BODY	164
0511057159	TRANSMISSION HOPPER SEED ROW	165
0511050609	BEARING WITH 17Z GEAR ASSY	166
0511050617	FRONT SEED ROW BEARING	167
0511055260	SEED ROW CHAIN TENSIONER	168
0511052426	TRANSMISSION CARDAN ASSY	169
0511052389	BEARING DOUBLE FRONT ROW SEED	170
0511057244	RIGTH SHORT SEED ROW FRONT	171
0511057246	RIGHT LONG SEED ROW FRONT	172
0501052769	BEARING WITH 17Z GEAR	173
0511057247	LEFT LONG SEED ROW FRONT	174
0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	175
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	176
0511053172	LEFT LOW HUB WITH 15 DISC	177
0511053173	RIGHT LOW HUB WITH 15 DISC	178
0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	179
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	180
0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	181
0521054680	20" DISC BLADE HUB	182
0521054679	DISC BLADE HUB	183
0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	184
0521054686	18" DISC BLADE HUB	185
0511044585	20" COULTER BLADE ASSY FOR LONG ROW	186
0511044573	18" COULTER BLADE ASSY FOR LONG ROW	187
0511058747	RIGHT REAR SUPREME SEED ROW P.P CSU	188
0521050737	PNEUMATIC SEED DISTRIBUTOR	189
0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	190
0511057155	PRECISION PLANTING LEFT TRANSMISSION HOPPER	191
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	192
0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	193
0511057154	RIGHT DDD	194
0511058756	RIGHT REAR SUPREME SEED ROW P.P PM400 CSU	195
0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX	196
0511057502	SET PRECISION PLANTING	197
0501058972	ASSEMBLY SENSOR ELECTRONIC	198
0511058748	LEFT REAR SUPREME SEED ROW P.P CSU	199
0511057153	DDD LEFT	200
0511058755	LEFT REAR SUPREME SEED ROW P.P PM400 CSU	201
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	202
0511058650	SEMI-MOUNTED DEPTH CONTROL	203
0511058652	LEFT DEPTH WHEEL ARM WITH HUB	204
0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	205
0501052627	ASSY DEPTH WHEEL HUB	206
0501052297	DEPTH WHEELS REGULATOR ASSY	207
0501052538	DEPTH BAND WITH ARMS	208
0511054333	COMPACT WHEEL RIGHT WITH BEARING	209
0501052908	COMPACTOR WHEEL WITH BEARING	210
0511054334	COMPACT WHEEL LEFT WITH BEARING	211
0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	212
0501056769	DEPTH WHEELS REGULATOR ASSY	213
0521051423	COMPACTOR SUPPORT	214
0511050077	WHEEL STRIPED	215
0511052287	DEPTH WHEEL HUB ASSY	216
0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	217




MARCHESAN

INDEX

0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD		218
0511059325	LEFT ARM COVERED WHEEL ASSEMBLED		219
0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED		220
0511051546	RIGHT DEPTH CONTROL HUB		221
0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB		222
0511051547	LEFT DEPTH CONTROL HUB		223
0511052970	SYSTEM COMPACTOR V SEMI MOUNTED		224
0511055819	DEPTH BAND WITH RIM		225
0501058423	FERTILIZER ROD SPRING ROW		226
0511058212	FERTILIZER ROW SUPPORT ASSY		227
0521057957	FIXED ROD EXTENSION WITH FIXATION		228
0521050525	FIXER FERTILIZER CONDUCTOR		229
0511059413	HDA BF		230

ASSY FRAME

0909096756



Item	Code	Description	See page	3245	3695	4045	4495	4845	5345
01	0501058194	FRAME WITH AXLE WHEEL - 3245	2	001	000	000	000	000	000
01.	0511051956	FRAME WITH AXLE WHEEL - 3695	3	000	001	000	000	000	000
01..	0501058195	FRAME WITH AXLE WHEEL - 4045		000	000	001	000	000	000
01...	0511050836	WHEEL AXLE FRAME - 4495	4	000	000	000	001	000	000
01....	0501058196	WHEEL AXLE FRAME - 4845	5	000	000	000	000	001	000
01.....	0511051118	WHEEL AXLE FRAME - 5345	6	000	000	000	000	000	001
02	0503010003	1845 GREASE FITTING		004	004	004	004	006	006
03	0511057124	CYLINDER ASSY	7	001	001	001	001	000	000
03.	0511056529	CYLINDER ASSY	9	000	000	000	000	001	001
04	0511059265	WHEELED WITH SPRING TRACTION WITH TRANSMISSION	11	002	002	004	004	004	004
05	0521050486	RIGHT TRANSMISSION ASSY - 3245	21	001	000	000	000	000	000
05.	0511059077	RIGHT TRANSMISSION ASSY - 3695	22	000	001	000	000	000	000
05..	0521050189	RIGHT TRANSMISSION ASSY - 4045	23	000	000	001	000	000	000
05...	0521053969	RIGHT TRANSMISSION ASSY - 4495	24	000	000	000	001	000	000
05....	0521050294	RIGHT TRANSMISSION ASSY - 4880	25	000	000	000	000	001	000
05.....	0521056820	RIGHT TRANSMISSION ASSY - 5345	26	000	000	000	000	000	001
06	0521050487	LEFT TRANSMISSION ASSY - 3245	44	001	000	000	000	000	000
06.	0511059078	LEFT TRANSMISSION ASSY - 3695	45	000	001	000	000	000	000
06..	0521050190	LEFT TRANSMISSION ASSY - 4045	46	000	000	001	000	000	000
06...	0521053970	LEFT TRANSMISSION ASSY - 4495	47	000	000	000	001	000	000
06....	0521050295	LEFT TRANSMISSION ASSY - 4880	48	000	000	000	000	001	000
06.....	0521056821	LEFT TRANSMISSION ASSY - 5345	49	000	000	000	000	000	001
07	0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	56	001	001	001	001	000	000
07.	0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	57	000	000	000	000	001	001
08	0501058165	SEMI-ASSEMBLED HYDRAULIC MARKER 3245/7	58	001	000	000	000	000	000
08.	0511052482	SEMI-ASSEMBLED HYDRAULIC MARKER 3695	59	000	001	000	000	000	000
08..	0501058170	SEMI-ASSEMBLED HYDRAULIC MARKER 4045	60	000	000	001	000	000	000
08...	0511050838	SEMI-ASSEMBLED HYDRAULIC MARKER 4495	61	000	000	000	001	000	000
08....	0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845	62	000	000	000	000	001	000
08.....	0511051119	SEMI-ASSEMBLED HYDRAULIC MARKER 5345	63	000	000	000	000	000	001
09	0501050633	ROW MARKER DISC ASSEMBLY	66	002	002	002	002	002	002

ASSY FRAME


0909096756

Item	Code	Description	See page	3245	3695	4045	4495	4845	5345
10	0531056600	3245 - RIGHT/LEFT FERTILIZER HOPPER SET	68	001	000	000	000	000	000
10.	0531056601	3695 - RIGHT/LEFT FERTILIZER HOPPER SET	69	000	001	000	000	000	000
10..	0531056602	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4045	70	000	000	001	000	000	000
10...	0531056757	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4495	71	000	000	000	001	000	000
10....	0531056603	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4845	72	000	000	000	000	001	000
10.....	0531056921	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 5345	73	000	000	000	000	000	001
11	0511057236	HANDRAIL ASSY - 3245	84	001	000	000	000	000	000
11.	0511058318	HANDRAIL ASSY - 3695	85	000	001	000	000	000	000
11..	0511057130	HANDRAIL ASSY - 4045	86	000	000	001	000	000	000
11...	0511057566	HANDRAIL ASSY - 4495	87	000	000	000	001	000	000
11....	0511057651	HANDRAIL ASSY - 4845	88	000	000	000	000	001	000
11.....	0511058308	HANDRAIL ASSY - 5345	89	000	000	000	000	000	001
12	0511057237	PLATFORM ASSY - 3245	90	001	000	000	000	000	000
12.	0511058319	PLATFORM ASSY - 3695	91	000	001	000	000	000	000
12..	0511057129	PLATFORM ASSY - 4045	92	000	000	001	000	000	000
12...	0511057565	PLATFORM ASSY - 4495	93	000	000	000	001	000	000
12....	0511057650	PLATFORM ASSY - 4845	94	000	000	000	000	001	000
12.....	0511058312	PLATFORM ASSY - 5345	95	000	000	000	000	000	001
13	0511056536	LADDER ASSEMBLY	96	002	002	002	002	002	002
14	0511054971	JACK ASSEMBLY	97	002	002	002	002	002	002
15	0511057142	DRAWBAR ASSEMBLY - 3245/3695/4045/4495	98	001	001	001	001	000	000
15.	0511057150	DRAWBAR ASSEMBLY - 4845/5345	99	000	000	000	000	001	001
16	0511057239	MANUAL CANISTER ASSY	100	001	001	001	001	001	001
17	0531057179	3245 - ALPHA II HYDRAULIC MARKER DECAL SET	101	001	000	000	000	000	000
17.	0531057816	3695 - ALPHA II HYDRAULIC MARKER DECAL SET	102	000	001	000	000	000	000
17..	0531057818	4045 - ALPHA II HYDRAULIC MARKER DECAL SET	103	000	000	001	000	000	000
17...	0531057819	4495 - ALPHA II HYDRAULIC MARKER DECAL SET	104	000	000	000	001	000	000
17....	0531057820	4845 - ALPHA II HYDRAULIC MARKER DECAL SET	105	000	000	000	000	001	000
17.....	0531057821	4845 - ALPHA II HYDRAULIC MARKER DECAL SET	106	000	000	000	000	001	000
17.....	0531057822	5345 - ALPHA II HYDRAULIC MARKER DECAL SET	107	000	000	000	000	000	001
18	0501065677	STRUT		002	002	002	002	002	002
19	0501054258	DRAWBAR ESTABILIZER ASSY	108	001	001	001	001	001	001
20	0511054601	HITCH ARTICULATED TRACTOR	109	001	001	001	001	001	001
21	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		001	001	001	001	001	001
22	0511053179	TRACTOR COUPLING SHAFT	110	001	001	001	001	001	001
23	0521013022	TRANSPORT LOCK		001	001	001	001	001	001
24	0501068994	8,30 X 78 LOCK PIN		001	001	001	001	001	001
25	0503030168	HITCH PIN CLIP		001	001	001	001	001	001
26	0511057817	SUPPORT HOSE	111	001	001	001	001	001	001
27	0503014120	CHAIN		001	001	001	001	001	001
28	0503014321	CABLE STEEL SHACKLE		002	002	002	002	002	002
29	0521055554	ASSY TURBINE MTH P.P CSU 3245/4	112	001	000	000	000	000	000
29.	0521050482	TURBINE ASSEMBLY MTH P.P CSU 3245/7 - 3695	120	000	001	000	000	000	000
29..	0521050553	ASSY TURBINE MTH P.P CSU 4045/9	121	000	000	001	000	000	000
29...	0521053973	ASSY TURBINE MTH P.P CSU 4495/9	123	000	000	000	001	000	000
29....	0521050707	ASSY TURBINE MTH P.P CSU 4845/10	126	000	000	000	000	001	000
29.....	0531051497	TURBINE ASSEMBLY MTH P.P CSU 4845/11	127	000	000	000	000	001	000
29.....	0521056824	ASSY TURBINE MTH P.P CSU 5345/12	128	000	000	000	000	000	001
30	0521053445	9 ROWS SEED MONITORING SET	129	000	000	000	001	000	000
30.	0531053676	10 ROWS SEED MONITORING SET	130	000	000	001	000	000	000
30..	0511056394	11 ROWS SEED MONITORING SET	131	000	000	000	000	001	000
30...	0521053448	12 ROWS SEED MONITORING SET	132	000	000	000	000	000	001
31	0501047895	25 ROD STOP		001	001	001	001	002	002
32	0501047885	30 ROD STOP		001	001	001	001	002	002
33	0501047886	35 ROD STOP		001	001	001	001	002	002
34	0501047887	40 ROD STOP		001	001	001	001	002	002


ASSY FRAME

0909096756


Item	Code	Description	See page	3245	3695	4045	4495	4845	5345
35	0531059614	KIT WITH ALPHA COMPONENTS - 04 ROWS	133	001	000	000	000	000	000
35.	0531059615	KIT WITH ALPHA COMPONENTS - 05 ROWS	134	001	000	000	000	000	000
35..	0531059617	KIT WITH ALPHA COMPONENTS - 07 ROWS	135	000	001	000	000	000	000
35...	0531059618	KIT WITH ALPHA COMPONENTS - 08 ROWS	136	000	000	001	000	000	000
35....	0531059619	KIT WITH ALPHA COMPONENTS - 09 ROWS	137	000	000	000	001	000	000
35.....	0531059620	KIT WITH ALPHA COMPONENTS - 10 ROWS	138	000	000	000	000	001	000
35.....	0531059621	KIT WITH ALPHA COMPONENTS - 11 ROWS	139	000	000	000	000	001	000
35.....	0531059622	KIT WITH ALPHA COMPONENTS - 12 ROWS	140	000	000	000	000	000	001
36	0503031436	AIR DISTRIBUTOR PUMP		004	003	005	004	004	006
37	0503010246	CLAMP		004	010	013	013	014	018
38	0503010780	N-2050 AMENDMENT		002	002	002	002	002	002
39	0503011750	AMENDMENT WITH LOCK		006	006	006	006	006	006
40	0503010951	REDUCTION		004	004	004	004	004	004
41	0503011751	REDUCTION		006	006	006	006	006	006
42	0511058368	EAR MOVABLE	141	002	002	002	002	000	000
43	0909099234	HEX AXLE ASSEMBLY	142	001	001	001	001	001	001
44	0571017237	GUTTER 25 X 58 X 900		000	000	000	000	002	000
45	0571017368	SUPPORT GUTTER		000	000	000	004	008	008
46	0501011643	3/8 X 1"BOLT		000	000	000	004	008	008
47	0501010984	10,50 X 27 X 3,00 FLAT WASHER		000	000	000	004	008	008
48	0503010025	3/8 SPRING WASHER		000	000	000	004	008	008
49	0503010026	3/8" NUT		000	000	000	004	008	008
50	0511066652	400 TURNBUCKLE		000	000	002	000	000	000
51	0521055555	CSU C3 SEMI-ASSEMBLED ASSY 3245/4	144	001	000	000	000	000	000
51.	0521050491	CSU C3 SEMI-ASSEMBLED ASSY 3245/3695 7	148	000	001	000	000	000	000
51..	0511059792	CSU C3 SEMI-ASSEMBLED ASSY 4045/4495 8	151	000	000	001	000	000	000
51...	0511058101	ASSEMBLY CSU C3 SEMI MOUNTED 4045/4495	153	000	000	001	001	000	000
51....	0511057736	CSU C3 SEMI-ASSEMBLED ASSY 4845/10	155	000	000	000	000	001	000
51.....	0511059318	CSU C3 SEMI-ASSEMBLED ASSY 5950/12	157	000	000	000	000	000	001
52	0521013164	EXTENDER		000	000	000	000	002	002
53	0501011310	FIXER LOCK		000	000	000	000	008	008
54	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		000	000	000	000	004	004
55	0503010019	1/2" SPRING WASHER		000	000	000	000	004	004
56	0503010060	1/2 UNC G.5 ZN HEX NUT		000	000	000	000	004	004
57	0571013314	GUTTER 25 X 58 X 1500		000	000	000	002	000	000
58	0571018391	GUTTER 25 X 58 X 1200		000	000	000	000	000	002
59	0561019643	25 X 58 X 1000 GUTTER		000	000	000	000	000	002
60	0521055993	SEED VDRIVE ASSY 4845/10E500	159	000	000	000	000	001	000
61	0501053834	MALE QUICK COUPLER	161	001	001	001	001	001	001
62	0503010045	O'RING		001	001	001	001	001	001
63	0541010080	TERMINAL R.1 / 2 NPT		001	001	001	001	001	001
64	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		001	001	001	001	001	001
65	0581013729	NIPLE 1/2 NPT		001	001	001	001	001	001
66	0909096757	ASSY SEED/FERTILIZER ROW	162	001	001	001	001	001	001




Item	Code	Description	See page	QT
01	0511069615	FRAME		01
02	0511069724	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8 UNC X 2.1/4 BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8 NUT		08




Item	Code	Description	See page	QT
01	0521063230	FRAME		01
02	0521063231	WHEEL ARTICULATED AXLE		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8 UNC X 2.1/4 BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8 NUT		08




Item	Code	Description	See page	QT
01	0521062243	FRAME		01
02	0521062242	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8 UNC X 2.1/4 BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8 NUT		08




Item	Code	Description	See page	QT
01	0511069616	FRAME		01
02	0511069717	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8 UNC X 2.1/4 BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8 NUT		12




Item	Code	Description	See page	QT
01	0521062442	FRAME		01
02	0521062447	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8 UNC X 2.1/4 BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8 NUT		12




Item	Code	Description	See page	QT
01	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	8	01
02	0531019171	1.25" X 7" COUPLING SHAFT		01
03	0521012536	COUPLING SHAFT		01
04	0503010523	1/4" X 2" SPLIT PIN		02
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0511064055	5" X 15" CYLINDER CASE		01
02	0511064056	BUSHING 2" X 14" TURNBUCLE		01
03	0502010382	5" END CAP		01
04	0502012227	50.80 X 127 RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	1870-2000-375-B GASKET		01
07	0503010952	W2-2250-500 RING		01
08	0503010351	2-425 N 3006-9B O'RING		01
09	0503011062	8-425 BACK-UP RING		01
10	0502010963	2.0" X 5.0" PISTON		01
11	0503010552	PACKING 3750-4250-625-B		02
12	0503010345	2-218 N 3006-9B O'RING		01
13	0503010974	W2-5000-500 RING		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503010003	1845 GREASE FITTING		01
16	0503030385	CYLINDER PLUG N-002		02




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	10	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521012536	COUPLING SHAFT		02
04	0503010523	1/4" X 2" SPLIT PIN		04
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCKLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O'RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O'RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0511059262	WHEEL SUPPORT ASSY	12	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	16	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	WHEEL SUPPORT CHAIN TENSIONER	13	01
07	0511052770	WHEEL WITH TIRE	14	01
08	0503018981	BOLT		02
09	0503010027	5/8 SPRING WASHER		04
10	0591010589	BODY LOCK WHEEL		01
11	0521069983	WHEEL COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE		01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	15	01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	17	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	19	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	20	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	18	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01



Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	18	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	18	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016882	1535 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	27	01
15	0511051434	TRANSMISSION ACTUATOR	28	01
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	29	01
17	0521050183	RIGHT GEAR BOX ASSY	30	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
35	0503012204	40-1 CHAIN X 82 LINK + RED		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		03
02	0503011099	GREASE FITTING		03
03	0503010300	5/32" X 1" COTTERPIN		03
04	0551019114	MOTOR BEARING AXLE SUPPORT		01
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
07	0503010019	1/2" SPRING WASHER		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		02
09	0571011602	MOTOR AXLE		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	27	01
15	0511051434	TRANSMISSION ACTUATOR	28	01
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	29	01
17	0521050183	RIGHT GEAR BOX ASSY	30	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
35	0503012204	40-1 CHAIN X 82 LINK + RED		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	27	01
15	0511051434	TRANSMISSION ACTUATOR	28	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	29	01
17	0521050183	RIGHT GEAR BOX ASSY	30	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
35	0503012204	40-1 CHAIN X 82 LINK + RED		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561018351	2155 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	27	01
15	0511051434	TRANSMISSION ACTUATOR	28	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	29	01
17	0521050183	RIGHT GEAR BOX ASSY	30	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
35	0503012204	40-1 CHAIN X 82 LINK + RED		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	27	01
14A	0503031825	AXLE MOTOR SLOW-MOVING		02
14B	0503010240	BOLT		02
14C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
14D	0503010337	5/16" NUT		02
15	0511051434	TRANSMISSION ACTUATOR	28	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	29	01
17	0521050183	RIGHT GEAR BOX ASSY	30	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01

Item	Code	Description	See page	QT
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
30A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
30B	0503031805	11Z 1/2" GEAR		01
30C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
30D	0503010019	1/2" SPRING WASHER		01
30E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01
31A	0511062169	21Z P 1/2" GEAR		01
31B	0503011410	ROLLER BEARING		01
31C	0503011105	SEAL RING		01
31D	0531017086	50 AXLETIGHTENER		01
31E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
31F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
31G	0501012140	FLAT WASHER		01
31H	0503010027	5/8 SPRING WASHER		01
31I	0503010013	5/8 NUT		01
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
32A	0503031805	11Z 1/2" GEAR		01
32B	0503010302	501019 SEAL RING		01
32C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
32D	0503010019	1/2" SPRING WASHER		01
32E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
32F	0521018933	CHAIN TENSIONER AXLE		01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
33A	0511062169	21Z P 1/2" GEAR		01
33B	0503011410	ROLLER BEARING		01
33C	0503011105	SEAL RING		01
33D	0531017086	50 AXLETIGHTENER		01
33E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
33F	0501011234	5/8" X 3" BOLT		01
33G	0503012412	5/8" UNC SELF LOCKING NUT		01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
34A	0511069680	20Z X 28Z DOUBLE GEAR		01
34B	0503011410	ROLLER BEARING		02
34C	0551019175	DOUBLE GEAR AXLE		01
34D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
34E	0503016460	5/8" X 4.1/2" BOLT		01
34F	0503012412	5/8" UNC SELF LOCKING NUT		01
35	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561019204	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	27	01
15	0511051434	TRANSMISSION ACTUATOR	28	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	29	01
17	0521050183	RIGHT GEAR BOX ASSY	30	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
31	0521055217	LOWER CURRENT STRETCH	53	01


Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
33	0521055216	BEARING WITH GEAR	54	01
34	0521055218	BEARING GEAR WITH DOUBLE	55	01
35	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CS G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
05	0501019734	FLAT WASHER		02
06	0502010710	RIGHT CAM, SMALLER		02
07	0503010003	1845 GREASE FITTING		02
08	0502012539	26Z P12,7 GEAR		01
09	0501019735	FLAT WASHER		01
10	0521017593	FLAT WASHER		01
11	0503010542	501045 CLAMPING RING (FOR AXLE)		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	31	01
02	0511059266	CLOSED BEARING	32	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	34	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	36	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	37	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	38	01
23	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01
30	0511065209	20Z GEAR		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	33	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	35	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0521018933	CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501011234	5/8" X 3" BOLT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOUBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019175	DOUBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503016460	5/8" X 4.1/2" BOLT		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016882	1535 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CS PC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	27	01
15	0511051434	TRANSMISSION ACTUATOR	28	01
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	50	01
17	0521050184	EXCHANGE LEFT ASSY	51	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
35	0503012204	40-1 CHAIN X 82 LINK + RED		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		03
02	0503011099	GREASE FITTING		03
03	0503010300	5/32" X 1" COTTERPIN		03
04	0551019114	MOTOR BEARING AXLE SUPPORT		01
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
07	0503010019	1/2" SPRING WASHER		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		02
09	0571011602	MOTOR AXLE		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CS PC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	27	01
15	0511051434	TRANSMISSION ACTUATOR	28	01
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	50	01
17	0521050184	EXCHANGE LEFT ASSY	51	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
35	0503012204	40-1 CHAIN X 82 LINK + RED		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CS PC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	27	01
15	0511051434	TRANSMISSION ACTUATOR	28	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	50	01
17	0521050184	EXCHANGE LEFT ASSY	51	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
35	0503012204	40-1 CHAIN X 82 LINK + RED		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561018351	2155 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CS PC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	27	01
15	0511051434	TRANSMISSION ACTUATOR	28	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	50	01
17	0521050184	EXCHANGE LEFT ASSY	51	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
35	0503012204	40-1 CHAIN X 82 LINK + RED		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	27	01
14A	0503031825	AXLE MOTOR SLOW-MOVING		02
14B	0503010240	BOLT		02
14C	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
14D	0503010337	5/16" NUT		02
15	0511051434	TRANSMISSION ACTUATOR	28	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	50	01
17	0521050184	EXCHANGE LEFT ASSY	51	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01

Item	Code	Description	See page	QT
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
30A	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
30B	0503031805	11Z 1/2" GEAR		01
30C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
30D	0503010019	1/2" SPRING WASHER		01
30E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
31	0501058265	STRETCHER LOWER CURRENT 21Z SEED	40	01
31A	0511062169	21Z P 1/2" GEAR		01
31B	0503011410	ROLLER BEARING		01
31C	0503011105	SEAL RING		01
31D	0531017086	50 AXLETIGHTENER		01
31E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
31F	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
31G	0501012140	FLAT WASHER		01
31H	0503010027	5/8 SPRING WASHER		01
31I	0503010013	5/8 NUT		01
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
32A	0503031805	11Z 1/2" GEAR		01
32B	0503010302	501019 SEAL RING		01
32C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
32D	0503010019	1/2" SPRING WASHER		01
32E	0503010060	1/2 UNC G.5 ZN HEX NUT		01
32F	0521018933	CHAIN TENSIONER AXLE		01
33	0501058266	BEARING WITH 21Z GEAR INTERMEDIATE SEED	42	01
33A	0511062169	21Z P 1/2" GEAR		01
33B	0503011410	ROLLER BEARING		01
33C	0503011105	SEAL RING		01
33D	0531017086	50 AXLETIGHTENER		01
33E	0503010406	501025 CLAMPING RING (FOR AXLE)		01
33F	0501011234	5/8" X 3" BOLT		01
33G	0503012412	5/8" UNC SELF LOCKING NUT		01
34	0501058267	DOUBLE BEARING WITH 17Z GEAR SEED	43	01
34A	0511069680	20Z X 28Z DOUBLE GEAR		01
34B	0503011410	ROLLER BEARING		02
34C	0551019175	DOUBLE GEAR AXLE		01
34D	0503010406	501025 CLAMPING RING (FOR AXLE)		01
34E	0503016460	5/8" X 4.1/2" BOLT		01
34F	0503012412	5/8" UNC SELF LOCKING NUT		01
35	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01





Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" COTTERPIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561019204	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	27	01
15	0511051434	TRANSMISSION ACTUATOR	28	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	50	01
17	0521050184	EXCHANGE LEFT ASSY	51	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521064449	36Z P1/2 SH 3/4 GEAR		01
25	0503030275	AGRICULTURAL BEARING		01
26	0501010637	FLAT WASHER		02
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	39	01
31	0521055217	LOWER CURRENT STRETCH	53	01

Item	Code	Description	See page	QT
32	0501058254	UPPER SEED CHAIN TENSIONER	41	01
33	0521055216	BEARING WITH GEAR	54	01
34	0521055218	BEARING GEAR WITH DOUBLE	55	01
35	0503012522	40-1 CHAIN X 85 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012719	40-1 CHAIN X 113 LINK + MENDING		01
38	0503014907	40-1 X 151 CHAIN LINK + MENDING		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01







Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0501011234	5/8" X 3" BOLT		01
02	0531017086	50 AXLETIGHTENER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0503019356	BEARING 6005 2RS1		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0503016460	5/8" X 4.1/2" BOLT		01
02	0551019175	DOUBLE GEAR AXLE		01
03	0503019356	BEARING 6005 2RS1		02
04	0511069680	20Z X 28Z DOUBLE GEAR		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511057070	HOSE KIT HYDRAULIC		01
01A	0521052285	TC-TM HOSE ASSY		01
01AA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01AB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052287	TC-TM HOSE ASSY		01
01BA	0501080446	3/8 X" 169" TC-TM HOSE ASSY		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	161	02
03	0503013100	NYLON CLAMP		02
04	0581010091	SPRING PROTECTION PLASTIC HOSE		01



Item	Code	Description	See page	QT
01	0511063404	"T" OIL CONDUCTOR		02
02	0581010091	SPRING PROTECTION PLASTIC HOSE		01
03	0503013100	NYLON CLAMP		02
04	0502012702	BODY SUPPORT CLAMP		02
05	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
06	0503010180	7/16" SPRING WASHER		02
07	0501053834	MALE QUICK COUPLER	161	02
08	0511057068	HOSE KIT SYSTEM HYDRAULIC		01
08A	0501080449	3/8" X 1500 TC-TC HOSE		04
09	0521052334	3/8 X 4000 TR-TM HOSE BLACK / BLUE		01
09A	0501080361	3/8" X 157" TR-TM HOSE		01
09B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
09C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
09D	0503018952	PLASTIC BOLT		06
10	0521052333	3/8 X 4000 TR-TM HOSE BLACK / RED		01
10A	0501080361	3/8" X 157" TR-TM HOSE		01
10B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
10C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
10D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
31A	0501080452	3/8" X 98" TR-TR HOSE		02
31B	0501080401	3/8" X 106" TR-TC HOSE		02
31C	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
31CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
31CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
31CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
31CD	0503018952	PLASTIC BOLT		06
31D	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
31DA	0501080422	HOSE 3/8 X 4000 TC-TM		01
31DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
31DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
31DD	0503018952	PLASTIC BOLT		06
32	0501053834	MALE QUICK COUPLER	161	02
33	0502012702	BODY SUPPORT CLAMP		06
34	0503011103	7/16" X 2-1/2" BOLT		06
35	0501012803	FLAT WASHER		02
36	0503010180	7/16" SPRING WASHER		06
37	0503010244	7/16" NUT		06




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8" UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0503012412	5/8" UNC SELF LOCKING NUT		02
13	0511058449	HYDRAULIC CYLINDER	64	02
14	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
15	0503010523	1/4" X 2" SPLIT PIN		02
16	0511015779	1" X 4.2" AXLE		02
17	0503010523	1/4" X 2" SPLIT PIN		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	8,30 X 78 LOCK PIN		02
20	0503030168	HITCH PIN CLIP		02
21	0501069643	890 TURNBUCKLE		02
22	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
23	0511011311	VALVE SUPPORT		01
24	0503010232	5/8" X 1.3/4" BOLT		02
25	0503010027	5/8 SPRING WASHER		02
26	0503010013	5/8 NUT		02
27	0501054649	HBM SEQUENTIAL VALVE	65	01
28	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
29	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
30	0503010025	3/8 SPRING WASHER		02
31	0511057075	HYDRAULIC MARKER HOSE KIT		01

Item	Code	Description	See page	QT
31A	0501080296	3/8" X 106" TR-TR HOSE		02
31B	0501080397	3/8" X 120" TR-TC HOSE		02
31C	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
31CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
31CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
31CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
31CD	0503018952	PLASTIC BOLT		06
31D	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
31DA	0501080422	HOSE 3/8 X 4000 TC-TM		01
31DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
31DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
31DD	0503018952	PLASTIC BOLT		06
32	0501053834	MALE QUICK COUPLER	161	02
33	0502012702	BODY SUPPORT CLAMP		06
34	0503011103	7/16" X 2-1/2" BOLT		06
35	0501012803	FLAT WASHER		02
36	0503010180	7/16" SPRING WASHER		06
37	0503010244	7/16" NUT		06




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8" UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0503012412	5/8" UNC SELF LOCKING NUT		02
13	0511058449	HYDRAULIC CYLINDER	64	02
14	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
15	0503010523	1/4" X 2" SPLIT PIN		02
16	0511015779	1" X 4.2" AXLE		02
17	0503010523	1/4" X 2" SPLIT PIN		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	8,30 X 78 LOCK PIN		02
20	0503030168	HITCH PIN CLIP		02
21	0501069643	890 TURNBUCKLE		02
22	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
23	0511011311	VALVE SUPPORT		01
24	0503010232	5/8" X 1.3/4" BOLT		02
25	0503010027	5/8 SPRING WASHER		02
26	0503010013	5/8 NUT		02
27	0501054649	HBM SEQUENTIAL VALVE	65	01
28	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
29	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
30	0503010025	3/8 SPRING WASHER		02
31	0511057095	HYDRAULIC MARKER HOSE KIT		01

Item	Code	Description	See page	QT
32	0501053834	MALE QUICK COUPLER	161	02
33	0502012702	BODY SUPPORT CLAMP		06
34	0503011103	7/16" X 2-1/2" BOLT		06
35	0501012803	FLAT WASHER		02
36	0503010180	7/16" SPRING WASHER		06
37	0503010244	7/16" NUT		06




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0501069470	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	64	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501069643	890 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	65	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0501053834	MALE QUICK COUPLER	161	02
25	0502012702	BODY SUPPORT CLAMP		06
26	0503011103	7/16" X 2-1/2" BOLT		06
27	0501012803	FLAT WASHER		02
28	0503010180	7/16" SPRING WASHER		06
29	0503010244	7/16" NUT		06
30	0501012140	FLAT WASHER		04
31	0503012412	5/8" UNC SELF LOCKING NUT		02

Item	Code	Description	See page	QT
32	0511011311	VALVE SUPPORT		01
33	0503010232	5/8" X 1.3/4" BOLT		02
34	0503010027	5/8 SPRING WASHER		02
35	0503010013	5/8 NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		08
37	0511057071	HYDRAULIC HOSE MARKER ASSY 10L		01
37A	0501081729	HOSE 3/8 X 3125 TR-TR		02
37B	0501081633	HOSE 3/8 X 3325 TR-TC		02
38	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38A	0501080422	HOSE 3/8 X 4000 TC-TM		01
38B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38D	0503018952	PLASTIC BOLT		06
39	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
39A	0501080422	HOSE 3/8 X 4000 TC-TM		01
39B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
39C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
39D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8" UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503011082	C1/2" X 1.3/4" SCREW		02
07	0501069470	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0501012140	FLAT WASHER		04
11	0503012412	5/8" UNC SELF LOCKING NUT		02
12	0511058449	HYDRAULIC CYLINDER	64	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" SPLIT PIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501066949	1235 TURNBUCKLE		02
21	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
22	0511011311	VALVE SUPPORT		01
23	0503010232	5/8" X 1.3/4" BOLT		02
24	0503010027	5/8 SPRING WASHER		02
25	0503010013	5/8 NUT		02
26	0501054649	HBM SEQUENTIAL VALVE	65	01
27	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
28	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
29	0503010025	3/8 SPRING WASHER		02
30	0502012702	BODY SUPPORT CLAMP		06
31	0503011103	7/16" X 2-1/2" BOLT		06

Item	Code	Description	See page	QT
32	0501012803	FLAT WASHER		02
33	0503010180	7/16" SPRING WASHER		06
34	0503010244	7/16" NUT		06
35	0501053834	MALE QUICK COUPLER	161	02
36	0511057069	HYDRAULIC HOSE MARKER ASSY		01
36A	0501080343	TR-TR HOSE ASSY		02
36B	0501080720	HOSE 3/8 X 3500 TR-TC		02
37	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
37A	0501080422	HOSE 3/8 X 4000 TC-TM		01
37B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
37C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
37D	0503018952	PLASTIC BOLT		06
38	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38A	0501080422	HOSE 3/8 X 4000 TC-TM		01
38B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0501012140	FLAT WASHER		12
04	0503012412	5/8" UNC SELF LOCKING NUT		10
05	0503011070	BEATER		02
06	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
07	0503010019	1/2" SPRING WASHER		02
08	0511061811	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0511058449	HYDRAULIC CYLINDER	64	02
12	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
13	0503010523	1/4" X 2" SPLIT PIN		04
14	0511015779	1" X 4.2" AXLE		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	65	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0501053834	MALE QUICK COUPLER	161	02
25	0531011180	UPPER BODY CLIP		08
26	0503010180	7/16" SPRING WASHER		08
27	0511011311	VALVE SUPPORT		01
28	0511059271	HYDRAULIC MARKER HAND SET		01
28A	0501081731	3/8 X 3550 TR-TR HOSE		02
28B	0501081732	3/8" X 3750 TR-TR HOSE		02
28C	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01


Item	Code	Description	See page	QT
28D	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
29	0503011103	7/16" X 2-1/2" BOLT		08
30	0502012702	BODY SUPPORT CLAMP		08
31	0503010244	7/16" NUT		08
32	0503010232	5/8" X 1.3/4" BOLT		02
33	0503010027	5/8 SPRING WASHER		02
34	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	67	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0531056589	3245 - RIGHT HOPPER SUPPORT WITH FERTILIZER METERING		01
02	0531056588	3245 - LEFT HOPPER SUPPORT WITH FERTILIZER METERING		01
03	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		02
04	0503010849	3/8" X 1-1/2" BOLT		16
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
06	0503010025	3/8 SPRING WASHER		16
07	0503010026	3/8" NUT		16
08	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
12	0501010694	FLAT WASHER		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" COTTERPIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531056597	3695 - RIGHT HOPPER SUPPORT WITH FERTILIZER METERING		01
02	0531056596	3695 - LEFT HOPPER SUPPORT WITH FERTILIZER METERING		01
03	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		16
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
07	0503010025	3/8 SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
12	0501010694	FLAT WASHER		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" COTTERPIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531056599	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4045		01
02	0531056598	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4045		01
03	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		16
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
07	0503010025	3/8 SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0501010694	FLAT WASHER		04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" COTTERPIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531056760	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4495		01
02	0531056759	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4495		01
03	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		09
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
07	0503010025	3/8 SPRING WASHER		09
08	0503010026	3/8" NUT		09
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0501010694	FLAT WASHER		04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" COTTERPIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531056604	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4845		01
02	0531056605	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4845		01
03	0503062169	ASSEMBLED FERTILIZER HOPPER		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		20
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		40
07	0503010025	3/8 SPRING WASHER		20
08	0503010026	3/8" NUT		20
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0501010694	FLAT WASHER		04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" COTTERPIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531056920	RIGHT HOPPER SUPPORT WITH FERTILIZER 74 METERING - 5345		01
02	0531056919	LEFT HOPPER SUPPORT WITH FERTILIZER 83 METERING - 5345		01
03	0503062169	ASSEMBLED FERTILIZER HOPPER		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		20
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		40
07	0503010025	3/8 SPRING WASHER		20
08	0503010026	3/8" NUT		20
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0501010694	FLAT WASHER		04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" COTTERPIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531064949	RIGHT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	75	06
03	0501053788	3/4" SQUARE AXLE FASTENER	80	05
04	0503031527	AGRICULTURAL BEARING		05
05	0501218487	3/4 X 390 AXLE		05
06	0531057908	SLEEVE 1/4 X 2		06
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	81	01
08	0501218691	3/4 X 6,53/6,61 AXLE WITH HOLE		01
09	0501218858	3/4 X 355 AXLE		01




Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	ASSY TRANSMISSION HUB	76	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	77	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513011170	ALLEN SCREW 1/4 UNC X 7/8 CCSI STAINLESS STEEL		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501310211	FRONT LID		01
19	0503036177	LID CORD		01
20	0531059139	ASSY COLLECTOR	78	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO ADHESIVE LABEL 41.5 X 29		01
15	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT GUIDE DOSING COVER		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	79	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007		02
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0503010337	5/16" NUT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0531057901	GEAR	82	01
07	0503010845	501035 CLAMPING RING (FOR AXLE)		01
08	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531065402	GEAR		01
02	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0531064948	LEFT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	75	06
03	0501053788	3/4" SQUARE AXLE FASTENER	80	05
04	0503031527	AGRICULTURAL BEARING		05
05	0501218487	3/4 X 390 AXLE		05
06	0531057908	SLEEVE 1/4 X 2		06
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	81	01
08	0501218691	3/4 X 6,53/6,61 AXLE WITH HOLE		01
09	0501218858	3/4 X 355 AXLE		01




Item	Code	Description	See page	QT
01	0511069635	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0521063250	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0511069656	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0521062239	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0511069660	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0521062449	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
04	0503010025	3/8 SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0511069725	RIGHT PLATFORM	01	
07	0521062318	LEFT PLATFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
04	0503010025	3/8 SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521063248	RIGHT PLATFORM	01	
07	0521063249	LEFT PLATFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
04	0503010025	3/8 SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0511069665	PLATFORM RIGHT	01	
07	0521062323	PLATFORM LEFT	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
04	0503010025	3/8 SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521062237	RIGHT PLATAFORM	01	
07	0521062238	LEFT PLATAFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
04	0503010025	3/8 SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0511069718	PLATFORM RIGHT	01	
07	0521062324	PLATFORM LEFT	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
04	0503010025	3/8 SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521062450	RIGHT PLATFORM	01	
07	0521062451	LEFT PLATFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32"X 2" COTTERPIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		02
02	0503010237	3/8" X 1" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511069636	LADDER		01
06	0503011179	3/8" X 2-1/4" BOLT		02
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012329	DRAWBAR FIXATION REAR SUPPORT		02
02	0502012330	SUPPORT FIXER PIVOT		04
03	0503011084	3/4" X 5" BOLT		08
04	0501010322	FLAT WASHER		08
05	0503010023	3/4" SPRING WASHER		08
06	0503010014	3/4" HEX NUT		08
07	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02
08	0561014393	COUPLING SHAFT		02
09	0503030119	LOCK PIN		04
10	0531063130	DRAWBAR		01
11	0561019087	DRAWBAR TRANSPORT LOCK		01
12	0521010578	COUPLING SHAFT		01
13	0521010588	0.9" X 7.0" COUPLING SHAFT		01
14	0503030085	LOCK PIN		02
15	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	1902012329	REAR SUPPORT FIXING DRAWBAR	04	
02	1902012330	FIXER SUPPORT ARTICULATED	08	
03	0503011084	3/4" X 5" BOLT	16	
04	0503010023	3/4" SPRING WASHER	16	
05	0503010014	3/4" HEX NUT	16	
06	1902012328	FIXED FRONT SUPPORT DRAWBAR	04	
07	0561014393	COUPLING SHAFT	04	
08	0503030119	LOCK PIN	08	
09	0511064808	DRAWBAR	01	
10	0561019087	DRAWBAR TRANSPORT LOCK	01	
11	0521010588	0.9" X 7.0" COUPLING SHAFT	01	
12	0521010578	COUPLING SHAFT	01	
13	0503030085	LOCK PIN	02	
14	0503010002	1800 GREASE FITTING	01	
15	0501010322	FLAT WASHER	16	




Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01







Item	Code	Description	See page	QT
01	0503033903	ADHESIVE LABEL		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503033417	ADHESIVE LABEL		02
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
06	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING		02
07	0503033423	LABEL ADHESIVE NUMBER 9		02
08	0503033008	ADHESIVE LABEL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	ADHESIVE LABEL		01
11	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
12	0503031565	ADHESIVE LABEL CARE		02
13	0503031566	ADHESIVE LABEL		02
14	0503034249	ADHESIVE LABEL TABLE PLANTS		02
15	0503031425	ADHESIVE LABEL ATTENTION		02
16	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
17	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
19	0503032930	ADHESIVE LABEL DANGER		04
20	0503031087	ADHESIVE LABEL		01
21	0503034078	LIFTING POINTS DECAL		03
22	0503034003	SERIAL NUMBER TAG 61 X 118		01
23	0503010001	3.2 X 5.5 RIVET		04
24	0503032979	ADHESIVE LABEL LETTERS A B C D		02
25	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503033903	ADHESIVE LABEL		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
07	0503033008	ADHESIVE LABEL		02
08	0503031428	READ MANUAL DECAL		01
09	0503031942	ADHESIVE LABEL		01
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
11	0503031565	ADHESIVE LABEL CARE		02
12	0503031566	ADHESIVE LABEL		02
13	0503034249	ADHESIVE LABEL TABLE PLANTS		02
14	0503031425	ADHESIVE LABEL ATTENTION		02
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503032930	ADHESIVE LABEL DANGER		04
19	0503031087	ADHESIVE LABEL		01
20	0503034003	SERIAL NUMBER TAG 61 X 118		01
21	0503010001	3.2 X 5.5 RIVET		04
22	0503034078	LIFTING POINTS DECAL		03
23	0503032979	ADHESIVE LABEL LETTERS A B C D		02
24	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503033903	ADHESIVE LABEL		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
06	0503033423	LABEL ADHESIVE NUMBER 9		02
07	0503033008	ADHESIVE LABEL		02
08	0503031428	READ MANUAL DECAL		01
09	0503031942	ADHESIVE LABEL		01
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
11	0503031565	ADHESIVE LABEL CARE		02
12	0503031566	ADHESIVE LABEL		02
13	0503034249	ADHESIVE LABEL TABLE PLANTS		02
14	0503031425	ADHESIVE LABEL ATTENTION		02
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503032930	ADHESIVE LABEL DANGER		05
19	0503031087	ADHESIVE LABEL		01
20	0503034003	SERIAL NUMBER TAG 61 X 118		01
21	0503010001	3.2 X 5.5 RIVET		04
22	0503034078	LIFTING POINTS DECAL		03
23	0503032979	ADHESIVE LABEL LETTERS A B C D		02
24	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503033903	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
06	0503033422	ADHESIVE LABEL	02	
07	0503033008	ADHESIVE LABEL	02	
08	0503031428	READ MANUAL DECAL	01	
09	0503031942	ADHESIVE LABEL	01	
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27	02	
11	0503031565	ADHESIVE LABEL CARE	02	
12	0503031566	ADHESIVE LABEL	02	
13	0503034249	ADHESIVE LABEL TABLE PLANTS	02	
14	0503031425	ADHESIVE LABEL ATTENTION	02	
15	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
16	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
17	0503032930	ADHESIVE LABEL DANGER	06	
18	0503031087	ADHESIVE LABEL	01	
19	0503034078	LIFTING POINTS DECAL	03	
20	0503034003	SERIAL NUMBER TAG 61 X 118	01	
21	0503010001	3.2 X 5.5 RIVET	04	
22	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
23	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503033903	ADHESIVE LABEL		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
06	0503033422	ADHESIVE LABEL		02
07	0503033008	ADHESIVE LABEL		02
08	0503031428	READ MANUAL DECAL		01
09	0503031942	ADHESIVE LABEL		01
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
11	0503031565	ADHESIVE LABEL CARE		02
12	0503031566	ADHESIVE LABEL		02
13	0503034249	ADHESIVE LABEL TABLE PLANTS		02
14	0503031425	ADHESIVE LABEL ATTENTION		02
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503032930	ADHESIVE LABEL DANGER		06
19	0503031087	ADHESIVE LABEL		01
20	0503034078	LIFTING POINTS DECAL		03
21	0503034003	SERIAL NUMBER TAG 61 X 118		01
22	0503010001	3.2 X 5.5 RIVET		04
23	0503032979	ADHESIVE LABEL LETTERS A B C D		02
24	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503033903	ADHESIVE LABEL		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503033417	ADHESIVE LABEL		02
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		04
07	0503033008	ADHESIVE LABEL		02
08	0503031428	READ MANUAL DECAL		01
09	0503031942	ADHESIVE LABEL		01
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
11	0503031565	ADHESIVE LABEL CARE		02
12	0503031566	ADHESIVE LABEL		02
13	0503034249	ADHESIVE LABEL TABLE PLANTS		02
14	0503031425	ADHESIVE LABEL ATTENTION		02
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503032930	ADHESIVE LABEL DANGER		06
19	0503031087	ADHESIVE LABEL		01
20	0503034078	LIFTING POINTS DECAL		03
21	0503034003	SERIAL NUMBER TAG 61 X 118		01
22	0503010001	3.2 X 5.5 RIVET		04
23	0503032979	ADHESIVE LABEL LETTERS A B C D		02
24	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0581011413	UPPER LEFT SUPPORT		01
02	0581011414	BODY RIGHT SUPPORT TURBINE		01
03	0581011415	SUPPORTER FIXING BAR		01
04	0503011239	1/2" X 2" BOLT		04
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
06	0503010019	1/2" SPRING WASHER		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0503011267	5/8 UNC X 1.1/2 C S G.5 ZN BOLT		02
09	0501012140	FLAT WASHER		02
10	0503012412	5/8" UNC SELF LOCKING NUT		02
11	0571013731	VACUUM GAUGE SUPPORT		01
12	0503013584	VACUUM GAUGE		01
13	0511059319	AIR FIXING SUPPORT	113	04
14	0521050261	DISTRIBUTOR AIR CENTER 08 MOUTHS - 19 A 21	114	01
15	0581012166	HOSE		02
16	0503011372	102 TO 121 CLAMP		02
17	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		04
18	0571019716	ADAPTER		04
19	0503031436	AIR DISTRIBUTOR PUMP		04
20	0503010246	CLAMP		04
21	0511059406	TURBINE P.P MOUNTED	115	01
22	0521052549	CLAMP	117	08
23	0511057906	HOSE ASSY	118	01




Item	Code	Description	See page	QT
01	0571019403	STAPLE FIXER		01
02	0503010025	3/8 SPRING WASHER		04
03	0503010026	3/8" NUT		04
04	0501013518	FLAT WASHER		02
05	0571019921	AIR SUPPORT FIXATION		01
06	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0571018559	WHITE PVC TUBE		02
02	0503031943	SOCKET		08
03	0503012856	POP RIVET		16
04	0503012567	T-JOIN FOR TUBE 110		02
05	0521015543	110 X 55 AIR DUCT		02
06	0503012566	COVER KAP 110 YELLOW		02
07	0571019406	BODY DISTRIBUTOR VACUUM		01
08	0561017670	BODY DISTRIBUTOR AR		02




Item	Code	Description	See page	QT
01	0581012099	BODY SUPPORT TURBINE		01
02	0501011460	7/8 NF REDUCTION NIPPLE		04
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0581012096	ROUND SLEEVE		02
06	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
07	0521050154	PRECISION PLANTING TURBINE WITH HOLE	116	01
08	0503031087	ADHESIVE LABEL		01
09	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
10	0501010694	FLAT WASHER		02
11	0503010143	1/4" SPRING WASHER		02
12	0503010144	1/4" NUT		02
13	0503010190	2-114 N 3006-9B O'RING		04
14	0501081235	1/2 X 650 TR- TC HOSE		01
15	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0511057840	ASSY TURBINE HOSE REAR		01
01A	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
01AA	0501081247	HOSE 1/2 X 7012 TC-TM		01
01AB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01
01BA	0501081247	HOSE 1/2 X 7012 TC-TM		01
01BB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PLASTIC BOLT		06
01C	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
01CA	0501080477	HOSE 3/8 X 7012 TC-TM		01
01CB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01CC	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
01CD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	161	02
03	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
04	0503033981	ADHESIVE LABEL		01
05	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	119	01




Item	Code	Description	See page	QT
01	0503018799	QUICK COUPLING		01
02	0503011883	QUICK CONNECTION COVER		01




Item	Code	Description	See page	QT
01	0511059406	TURBINE P.P MOUNTED	115	01
02	0503011267	5/8 UNC X 1.1/2 C S G.5 ZN BOLT		02
03	0501012140	FLAT WASHER		02
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0581011414	BODY RIGHT SUPPORT TURBINE		01
06	0581011413	UPPER LEFT SUPPORT		01
07	0581011415	SUPPORTER FIXING BAR		01
08	0503011239	1/2" X 2" BOLT		04
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
10	0503010019	1/2" SPRING WASHER		04
11	0503010060	1/2 UNC G.5 ZN HEX NUT		04
12	0581012166	HOSE		02
13	0503011372	102 TO 121 CLAMP		02
14	0521050261	DISTRIBUTOR AIR CENTER 08 MOUTHS - 19 A 21	114	01
15	0511059319	AIR FIXING SUPPORT	113	04
16	0511057906	HOSE ASSY	118	01
16A	0511057840	ASSY TURBINE HOSE REAR		01
16AA	0501081247	HOSE 1/2 X 7012 TC-TM		02
16AB	0501080477	HOSE 3/8 X 7012 TC-TM		01
16B	0501053834	MALE QUICK COUPLER	161	02
16C	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
16D	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	119	01
17	0571013731	VACUUM GAUGE SUPPORT		01
18	0503013584	VACUUM GAUGE		01
19	0571019716	ADAPTER		07
20	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		07
21	0503031436	AIR DISTRIBUTOR PUMP		01
22	0503010246	CLAMP		01




Item	Code	Description	See page	QT
01	0581011413	UPPER LEFT SUPPORT		01
02	0581011414	BODY RIGHT SUPPORT TURBINE		01
03	0581011415	SUPPORTER FIXING BAR		01
04	0503011239	1/2" X 2" BOLT		04
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
06	0503010019	1/2" SPRING WASHER		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0503011267	5/8 UNC X 1.1/2 C S G.5 ZN BOLT		02
09	0501012140	FLAT WASHER		02
10	0503012412	5/8" UNC SELF LOCKING NUT		02
11	0571013731	VACUUM GAUGE SUPPORT		01
12	0503013584	VACUUM GAUGE		01
13	0511059319	AIR FIXING SUPPORT	113	04
14	0511057348	DISTRIBUTOR VACUUM	122	02
15	0581012166	HOSE		02
16	0503011372	102 TO 121 CLAMP		02
17	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		09
18	0571019716	ADAPTER		09
19	0503031436	AIR DISTRIBUTOR PUMP		01
20	0503010246	CLAMP		01
21	0511059406	TURBINE P.P MOUNTED	115	01
22	0521052549	CLAMP	117	18
23	0511057906	HOSE ASSY	118	01




Item	Code	Description	See page	QT
01	0571017215	AIR DISTRIBUTOR SOCKET		01
02	0503012566	COVER KAP 110 YELLOW		01
03	0503031943	SOCKET		05
04	0503012856	POP RIVET		10
05	0571019405	BODY DISTRIBUTOR VACUUM 4845/5345		01




Item	Code	Description	See page	QT
01	0581011413	UPPER LEFT SUPPORT		01
02	0581011414	BODY RIGHT SUPPORT TURBINE		01
03	0581011415	SUPPORTER FIXING BAR		01
04	0503011239	1/2" X 2" BOLT		04
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
06	0503010019	1/2" SPRING WASHER		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0503011267	5/8 UNC X 1.1/2 C S G.5 ZN BOLT		02
09	0501012140	FLAT WASHER		02
10	0503012412	5/8" UNC SELF LOCKING NUT		02
11	0571013731	VACUUM GAUGE SUPPORT		01
12	0503013584	VACUUM GAUGE		01
13	0511059319	AIR FIXING SUPPORT	113	04
14	0511057906	HOSE ASSY	118	01
15	0561011377	HOSE 4 X 2200		02
16	0503011372	102 TO 121 CLAMP		02
17	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		09
18	0571019716	ADAPTER		09
19	0503031436	AIR DISTRIBUTOR PUMP		03
20	0503010246	CLAMP		03
21	0511059406	TURBINE P.P MOUNTED	115	01
22	0521052549	CLAMP	117	18
23	0521050016	RIGHT AIR DISTRIBUTOR 06 NOZZLES - 17 E500	124	01
24	0521050017	LEFT AIR DISTRIBUTOR 06 NOZZLES - 17 E500	125	01




Item	Code	Description	See page	QT
01	0581013131	AIR DISTRIBUTOR BODY		01
02	0503017845	90 PVC KNEE		01
03	0571018559	WHITE PVC TUBE		01
04	0503031943	SOCKET		06
05	0503012856	POP RIVET		12
06	0503012566	COVER KAP 110 YELLOW		01
07	0521015543	110 X 55 AIR DUCT		01




Item	Code	Description	See page	QT
01	0581013131	AIR DISTRIBUTOR BODY		01
02	0503017845	90 PVC KNEE		01
03	0571018559	WHITE PVC TUBE		01
04	0503031943	SOCKET		06
05	0503012856	POP RIVET		12
06	0503012566	COVER KAP 110 YELLOW		01
07	0521015543	110 X 55 AIR DUCT		01




Item	Code	Description	See page	QT
01	0581011413	UPPER LEFT SUPPORT		01
02	0581011414	BODY RIGHT SUPPORT TURBINE		01
03	0581011415	SUPPORTER FIXING BAR		01
04	0503011239	1/2" X 2" BOLT		04
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
06	0503010019	1/2" SPRING WASHER		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0503011267	5/8 UNC X 1.1/2 C S G.5 ZN BOLT		02
09	0501012140	FLAT WASHER		02
10	0503012412	5/8" UNC SELF LOCKING NUT		02
11	0571013731	VACUUM GAUGE SUPPORT		01
12	0503013584	VACUUM GAUGE		01
13	0511059319	AIR FIXING SUPPORT	113	04
14	0511057906	HOSE ASSY	118	01
15	0561011377	HOSE 4 X 2200		02
16	0503011372	102 TO 121 CLAMP		02
17	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		10
18	0571019716	ADAPTER		10
19	0503031436	AIR DISTRIBUTOR PUMP		02
20	0503010246	CLAMP		02
21	0511059406	TURBINE P.P MOUNTED	115	01
22	0521052549	CLAMP	117	20
23	0521050016	RIGHT AIR DISTRIBUTOR 06 NOZZLES - 17 E500	124	01
24	0521050017	LEFT AIR DISTRIBUTOR 06 NOZZLES - 17 E500	125	01







Item	Code	Description	See page	QT
01	0581011413	UPPER LEFT SUPPORT		01
02	0581011414	BODY RIGHT SUPPORT TURBINE		01
03	0581011415	SUPPORTER FIXING BAR		01
04	0503011239	1/2" X 2" BOLT		04
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
06	0503010019	1/2" SPRING WASHER		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0503011267	5/8 UNC X 1.1/2 C S G.5 ZN BOLT		02
09	0501012140	FLAT WASHER		02
10	0503012412	5/8" UNC SELF LOCKING NUT		02
11	0571013731	VACUUM GAUGE SUPPORT		01
12	0503013584	VACUUM GAUGE		01
13	0511059319	AIR FIXING SUPPORT	113	04
14	0511057906	HOSE ASSY	118	01
15	0561011377	HOSE 4 X 2200		02
16	0503011372	102 TO 121 CLAMP		02
17	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		12
18	0571019716	ADAPTER		12
19	0521050016	RIGHT AIR DISTRIBUTOR 06 NOZZLES - 17 E500	124	01
20	0521050017	LEFT AIR DISTRIBUTOR 06 NOZZLES - 17 E500	125	01
21	0511059406	TURBINE P.P MOUNTED	115	01
22	0521052549	CLAMP	117	24




Item	Code	Description	See page	QT
01	0503062794	SEED MONITORING KIT 9L 45/50 PM400		01
01A	0503016555	9 ROW SIMPLE MONITOR CABLE		01
01B	0503019100	SENSOR		09
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		45
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		**
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0503063631	KIT MONITORING SEED		01
01A	0503019725	CABLE		01
01B	0503019100	SENSOR		10
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
01E	0503017031	CLEANING BRUSH		01
01F	0503019720	NYLON CLAMP		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010669	FLAT WASHER		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010667	3/16" NUT		02




Item	Code	Description	See page	11 L
01	0503016557	11 ROW SIMPLE MONITOR CABLE		01
02	0503017602	MONITOR PLANT PM400		01
03	0503016234	TRIMBLE FIXING WINDOW		01
04	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
05	0571012196	MOUNTING BRACKET PM 400		01
06	0503017443	ANTENNA GPS PM 400		01
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		165
08	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
09	0503010669	FLAT WASHER		02
10	0503010668	3/16" SPRING WASHER		02
11	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0503062797	KIT MONITORING SEED 12L 45/50 PM400 PM412SSM		01
01A	0503016558	12 ROW SIMPLE CABLE MONITORING		01
01B	0503019100	SENSOR		12
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503013100	NYLON CLAMP		60
06	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		180
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
08	0503010669	FLAT WASHER		02
09	0503010668	3/16" SPRING WASHER		02
10	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		04
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		04
01B	0503035859	SUPPORT SLEEVE		04
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		04
02A	0501111196	PELLETED FERTILIZER METERING COATING		04
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		04
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		05
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		05
01B	0503035859	SUPPORT SLEEVE		05
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		05
02A	0501111196	PELLETED FERTILIZER METERING COATING		05
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		05
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		07
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		07
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		08
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		08
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01







Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		09
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		09
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		10
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		10
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		11
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		11
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		12
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		12
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0521066608	LIFTING HOOK		01
02	0581019707	FIXATION SUPPORT SUPPORT		01
03	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
04	0501012140	FLAT WASHER		04
05	0503012412	5/8" UNC SELF LOCKING NUT		04




Item	Code	Description	See page	3245	3695	4045	4445	4845	5345
01	0531016940	5/8 X 1650 RIGHT HEX AXLE		001	000	000	000	000	000
02	0531016941	LEFT 5/8" X 59" AXLE HEX		001	000	000	000	000	000
03	0571011624	RIGHT HEX AXLE 5/8 X 1875		000	001	000	000	000	000
04	0571011625	LEFT HEX AXLE 5/8 X 1725		000	001	000	000	000	000
05	0531016942	RIGHT HEX AXLE 5/8 X 2050		000	000	001	000	000	000
06	0531016943	LEFT HEX AXLE 5/8 X 1900		000	000	001	000	000	000
07	0561019199	5/8" X 2275 AXLE HEX		000	000	000	001	000	000
08	0561019200	5/8" X 2125 AXLE HEX		000	000	000	001	000	000
09	0531016944	RIGHT 5/8" X 96" HEX AXLE		000	000	000	000	001	000
10	0531016945	LEFT 5/8" X 90" HEX AXLE		000	000	000	000	001	000
11	0561019202	HEX AXLE RIGHT		000	000	000	000	000	001
12	0561019203	HEX AXLE 5/8 X 2525 LEFT		000	000	000	000	000	001
13	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	143	002	002	002	002	002	002
14	0561014215	BEARING COVER LOWER ROW FRAME		002	002	002	002	002	002
15	0502040534	SPRING GUIDE BUSHING LOCK		004	004	004	004	004	004
16	0501018535	1/2 X 1 BOLT		004	004	004	004	004	004




Item	Code	Description	See page	QT
01	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8		01
02	0511063106	20Z AXLE BEARING DOUBLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521055563	CSU C3 2 HOPPERS ASSEMBLY	145	01
02	0521051927	TOWER SUPPORT HOPPER	147	04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
05	0503010025	3/8 SPRING WASHER		08
06	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0521064748	05 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503061987	05 NOZZLES FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	146	04
08	0501010942	3/8" X 1-1/4" BOLT		16
09	0503010025	3/8 SPRING WASHER		16
10	0503010026	3/8" NUT		16
11	0571015773	SUPPORT SEED		06
12	0501011643	3/8 X 1" BOLT		24
13	0503010025	3/8 SPRING WASHER		24
14	0503010026	3/8" NUT		24




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID	01	
02	0501010942	3/8" X 1-1/4" BOLT	01	
03	0503010025	3/8 SPRING WASHER	01	
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER	01	
05	0503010209	3/8" UNC BUTTERFLY NUT	01	
06	0521066332	CONDUCTOR WITH FLANGE	01	
07	0503010371	5/16" X 1" BOLT	02	
08	0501010694	FLAT WASHER	02	
09	0503010179	LOCK WASHER 5/16 ZN 1K01528	02	
10	0503010337	5/16" NUT	02	
11	0502012767	SEED NOZZLE FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0521066208	HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0521050490	2 HOPPERS WITH 7 CONDUCTORS SET	149	01
02	0521051927	TOWER SUPPORT HOPPER	147	03
03	0521052687	RIGHT SUPPORT TOWER WITH BOLT	150	01
04	0501010942	3/8" X 1-1/4" BOLT		08
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
06	0503010025	3/8 SPRING WASHER		08
07	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0521064748	05 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503061987	05 NOZZLES FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	146	07
08	0501010942	3/8" X 1-1/4" BOLT		28
09	0503010025	3/8 SPRING WASHER		28
10	0503010026	3/8" NUT		28
11	0571015773	SUPPORT SEED		03
12	0501011643	3/8 X 1"BOLT		12
13	0503010025	3/8 SPRING WASHER		12
14	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
01	0521066206	RIGHT HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02




Item	Code	Description	See page	QT
01	0511059790	CSU C3 2 HOPPERS ASSEMBLY	152	01
02	0521066208	HOPPER SUPPORT TOWER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
05	0503010025	3/8 SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0501010453	FLAT WASHER		08
10	0503012412	5/8" UNC SELF LOCKING NUT		08




Item	Code	Description	See page	QT
01	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	146	08
08	0501010942	3/8" X 1-1/4" BOLT		32
09	0503010025	3/8 SPRING WASHER		32
10	0503010026	3/8" NUT		32
11	0571015773	SUPPORT SEED		04
12	0501011643	3/8 X 1" BOLT		16
13	0503010025	3/8 SPRING WASHER		16
14	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0511058100	2 HOPPERS WITH 9 CONDUCTORS SET	154	01
02	0521051927	TOWER SUPPORT HOPPER	147	04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
05	0503010025	3/8 SPRING WASHER		08
06	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	146	09
08	0501010942	3/8" X 1-1/4" BOLT		36
09	0503010025	3/8 SPRING WASHER		36
10	0503010026	3/8" NUT		36
11	0571015773	SUPPORT SEED		03
12	0501011643	3/8 X 1"BOLT		12
13	0503010025	3/8 SPRING WASHER		12
14	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
01	0511057737	2 HOPPERS WITH 10 CONDUCTORS SET	156	01
02	0521051927	TOWER SUPPORT HOPPER	147	04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
05	0503010025	3/8 SPRING WASHER		08
06	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0511057690	3" ARTICULATED SEED CONDUCTOR	146	10
08	0501010942	3/8" X 1-1/4" BOLT		40
09	0503010025	3/8 SPRING WASHER		40
10	0503010026	3/8" NUT		40
11	0571015773	SUPPORT SEED		04
12	0501011643	3/8 X 1"BOLT		16
13	0503010025	3/8 SPRING WASHER		16
14	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0501010942	3/8" X 1-1/4" BOLT		08
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
03	0503010025	3/8 SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0521051927	TOWER SUPPORT HOPPER	147	04
06	0511058724	2 HOPPERS WITH 12 CONDUCTORS ASSEMBLY	158	01




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR	146	12
06	0571015773	SUPPORT SEED		02
07	0501011643	3/8 X 1"BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		48
09	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02




Item	Code	Description	See page	QT
01	0521053840	MONITOR / ANTENNA COMPONENT ASSEMBLY 160 HEMISFERE VDRIVE USAP	160	01
02	0503062453	TRACTOR CONNECTION ASSY 729411 - 4,5MTS		01
03	0503017976	UNIT MODULE		10
04	0503017975	WHIP		10
05	0503062431	ELECTRIC MOTOR		10
06	0503062433	SEED TUBE WITH SENSOR		10
07	0503017988	VACUUM SENSOR		01
08	0503017987	SENSOR LEVANTE EXTENDED WHIP		01
09	0503017984	LIFT SENSOR		02
10	0503018063	SRM MAIN WHIP - 10 ROWS		01
11	0503018074	CAN TERMINATOR		01
12	0503017980	APEX EXTENSION CABLE		01
13	0503017993	EXTENSION CABLE		01



Item	Code	Description	See page	QT
01	0503062427	CONTROL / MONITOR ASSEMBLY		01
01A	0503018046	MONITOR		01
01B	0503018047	MONITOR SUPPORT		01
02	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
03	0503016234	TRIMBLE FIXING WINDOW		01
04	0503018052	VDRIVE INSTRUCTIONS MANUAL		01
05	0503062428	CONTROL CABIN		01
06	0503017969	WHIP CABIN TRACTOR		01
07	0503018653	ADAPTER WHIP		01
08	0503018097	WHIP BATTERY		01
09	0503062449	ANTENNA ASSY		01
10	0503062429	SRM ASSY		01
11	0503017986	WHIP BATTERY FOR PLUG		01
12	0503019424	WHIP JD STARFIRE GPS		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511057243	LEFT SHORT SEED ROW FRONT	163	01
02	0511057244	RIGTH SHORT SEED ROW FRONT	171	01
03	0511057246	RIGHT LONG SEED ROW FRONT	172	01
04	0511057247	LEFT LONG SEED ROW FRONT	174	01
05	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	175	01
06	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	179	01
07	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	181	01
07.	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	184	01
08	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	186	01
08.	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	187	01
09	0511058747	RIGHT REAR SUPREME SEED ROW P.P CSU	188	01
09.	0511058756	RIGHT REAR SUPREME SEED ROW P.P PM400 CSU	195	01
10	0511058748	LEFT REAR SUPREME SEED ROW P.P CSU	199	01
10.	0511058755	LEFT REAR SUPREME SEED ROW P.P PM400 CSU	201	01
11	0571011730	SEED CONDUCTOR 3" X 1500		01
12	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	202	01
12.	0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	212	01
12..	0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	217	01
13	0501110231	SCARIFIER ROD WITH TIP		01
14	0501058423	FERTILIZER ROD SPRING ROW	226	01
15	0511017232	FLAT WASHER		01
16	0503011255	3/4" LOCK NUT		01
17	0521017831	SUPPORT SLEEVE SPACER		01
18	0503031145	2" X 2" X 20" HOSE		01
19	0503031076	2" HOSE CLAMP		01
20	0503030391	RIGHT FERTILIZER NOZZLE		01
21	0503030392	LEFT FERTILIZER NOZZLE		01

Item	Code	Description	See page	QT
22	0503031050	CURVED CONDUCTOR		01
23	0503010246	CLAMP		01
24	0511058212	FERTILIZER ROW SUPPORT ASSY	227	01
25	0502010175	HITCH CLAMP		01
26	0501011543	5/8" X 4" BOLT		01
27	0503012412	5/8" UNC SELF LOCKING NUT		01
28	0521057957	FIXED ROD EXTENSION WITH FIXATION	228	01
29	0531013600	PRESS ADJUSTMENT LEVER		01
30	0501010066	3/4" X 9" BOLT		01
31	0521069127	BOTTOM NOZZLE FERTILIZER		01
32	0503030483	FERTILIZER SOCKET		01
33	0511017969	0.1" SPACING PLATE		01
34	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
35	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
36	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
37	0503010025	3/8 SPRING WASHER		01
38	0503010026	3/8" NUT		01
39	0503010905	1/2" X 2-1/4" BOLT		01
40	0503010019	1/2" SPRING WASHER		01
41	0503010060	1/2 UNC G.5 ZN HEX NUT		01
42	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
43	0511061852	ADJUSTAMENT CONDUCTOR FERTILIZER		01
44	0521067360	PROTRACTOR CPRA		01
45	0581010082	FERTILIZER SOCKET RIGHT		01
46	0581010083	FERTILIZER SOCKET LEFT		01
47	0521050525	FIXER FERTILIZER CONDUCTOR	229	01
48	0511059413	HDA BF	230	01
49	0511058877	REGULATORY KEY		01
49A	0521066800	BODY REGULATORY KEY		01
49B	0503030878	LEVER CRANK		01




Item	Code	Description	See page	QT
01	0521064651	LEFT SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	164	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	165	01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	166	01
14	0511055260	SEED ROW CHAIN TENSIONER	168	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521065847	SHORT TIRE SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" COTTERPIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" COTTERPIN		01
31	0503034580	TRACTION SPRING		02


Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY	169	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0502012718	ROW BEARING		01
02	0503012882	BEARING		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0511050617	FRONT SEED ROW BEARING	167	01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0502012819	17Z GEAR WITH HEX HOLE		01




Item	Code	Description	See page	QT
01	0502011697	GEARBOX BEARING		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0511052389	BEARING DOUBLE FRONT ROW SEED	170	01
02	0551017559	BEARING AXLE BODY		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0551017540	5/8" X 73 AXLE HEX		01
05	0501056296	UNIVERSAL JOINT		01
06	0503011855	0.2" X 1.8" SPRING PIN		03
07	0571012412	HEX AXLE		01
08	0561014778	HEX UNIVERSAL JOINT		01
09	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	164	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	165	01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	166	01
14	0511055260	SEED ROW CHAIN TENSIONER	168	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521065847	SHORT TIRE SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" COTTERPIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" COTTERPIN		01
31	0503034580	TRACTION SPRING		02

Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY	169	01
33	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521064652	RH SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	164	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	165	01
12	0561814904	ROW FRAME TRANSMISSION AXLE		01
13	0501052769	BEARING WITH 17Z GEAR	173	01
14	0511055260	SEED ROW CHAIN TENSIONER	168	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521065847	SHORT TIRE SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" COTTERPIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" COTTERPIN		01
31	0503034580	TRACTION SPRING		02

Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY	169	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0503010406	501025 CLAMPING RING (FOR AXLE)		01
02	0502011697	GEARBOX BEARING		01
03	0503011410	ROLLER BEARING		01
04	0503011105	SEAL RING		01
05	0503011953	5/16" X 1" BOLT		02
06	0501010694	FLAT WASHER		02
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
08	0503010337	5/16" NUT		02
09	0502012819	17Z GEAR WITH HEX HOLE		01




Item	Code	Description	See page	QT
01	0521064650	LEFT SEED ROW SUPPORT FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0511054635	BEARING AXLE BODY	164	02
06	0503011953	5/16" X 1" BOLT		04
07	0501010694	FLAT WASHER		04
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
09	0503010337	5/16" NUT		04
10	0502012782	17Z GEAR WITH HEX HOLE		01
11	0511057159	TRANSMISSION HOPPER SEED ROW	165	01
12	0561014904	TRANSMISSION AXLE FRAME ROW		01
13	0511050609	BEARING WITH 17Z GEAR ASSY	166	01
14	0511055260	SEED ROW CHAIN TENSIONER	168	01
15	0502012666	SEED ROW LOWER ARM		01
16	0503010003	1845 GREASE FITTING		04
17	0561015858	SPACER LOWER SLEEVE		01
18	0531015151	0.6" X 1" X 2.4" SLEEVE		07
19	0531015184	FLAT WASHER		08
20	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
21	0502012350	SEED ROW UPPER ARM		01
22	0521065847	SHORT TIRE SEED ROW FRAME		01
23	0502012568	UPPER ROCKER ARM		01
24	0561019032	SEED FERTIL ROW LOCK		01
25	0501011388	COUPLING SHAFT		02
26	0503010071	3/16" X 1" COTTERPIN		01
27	0503030168	HITCH PIN CLIP		01
28	0581018487	FIXER UPPER SPRING		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		01
30	0503010140	1/8" X 3/4" COTTERPIN		01
31	0503034580	TRACTION SPRING		02


Item	Code	Description	See page	QT
32	0511052426	TRANSMISSION CARDAN ASSY	169	01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	176	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	177	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	178	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUBLE DISC AXLE		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061153	FERTILIZER ROW LONG ARM		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	180	01




Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	178	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	177	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
03	0541018684	FLAT WASHER		01
04	0503010756	0.2" X 2.4" SPRING PIN		01
05	0503010361	SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521014137	RIGHT ARM BLADE DISC		01
08	0521014138	SUPPORT ARM LEFT BALDE DISC		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0503011255	3/4" LOCK NUT		01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
14	0503011411	1/2" X 5-1/2" BOLT		01
15	0503010019	1/2" SPRING WASHER		01
16	0503010060	1/2 UNC G.5 ZN HEX NUT		01
17	0502020393	SPRING UPPER SUPPORT		01
18	0502020394	SPRING SUPPORT		01
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
20	0503010014	3/4" HEX NUT		02
21	0521054680	20" DISC BLADE HUB	182	01




Item	Code	Description	See page	QT
01	0521054679	DISC BLADE HUB	183	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0502011562	DISC BLADE HUB		01
02	0502020641	BLADE DISC FLANGE		01
03	0503010276	6206 BALL BEARING		02
04	0521013610	BLADE DISC HUB AXLE		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
06	0503012417	SEAL		02
07	0503011800	SEAL RING		02
08	0503010691	1/4" GREASE FITTING		01
09	0521015376	DUST CLOAK		02
10	0503030832	FLAT WASHER		02
11	0511015346	FLAT WASHER		02
12	0521013510	3/4" NUT		02
13	0503010012	1" SPRING WASHER		02
14	0503010371	5/16" X 1" BOLT		06
15	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0503010003	1845 GREASE FITTING		01
03	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
04	0521014137	RIGHT ARM BLADE DISC		01
05	0521014138	SUPPORT ARM LEFT BALDE DISC		01
06	0521054686	18" DISC BLADE HUB	185	01
07	0503010756	0.2" X 2.4" SPRING PIN		01
08	0503010361	SPRING PIN		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	1902020394	SPRING SUPPORT		01
14	1902020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0503010014	3/4" HEX NUT		02
17	0541018684	FLAT WASHER		01
18	0503013185	3/4" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01
21	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0521054679	DISC BLADE HUB	183	01
02	0603026013	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE		01
03	0541018684	FLAT WASHER		01
04	0503010756	0.2" X 2.4" SPRING PIN		01
05	0503010361	SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521014137	RIGHT ARM BLADE DISC		01
08	0521014138	SUPPORT ARM LEFT BALDE DISC		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503013185	3/4" X 5-1/2" BOLT		01
12	0503011255	3/4" LOCK NUT		01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
14	0503011411	1/2" X 5-1/2" BOLT		01
15	0503010019	1/2" SPRING WASHER		01
16	0503010060	1/2 UNC G.5 ZN HEX NUT		01
17	0502020393	SPRING UPPER SUPPORT		02
18	0502020394	SPRING SUPPORT		01
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
20	0503010014	3/4" HEX NUT		02
21	0521054680	20" DISC BLADE HUB	182	01




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0503010003	1845 GREASE FITTING		01
03	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE		01
04	0521014137	RIGHT ARM BLADE DISC		01
05	0521014138	SUPPORT ARM LEFT BALDE DISC		01
06	0521054686	18" DISC BLADE HUB	185	01
07	0503010756	0.2" X 2.4" SPRING PIN		01
08	0503010361	SPRING PIN		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	1902020394	SPRING SUPPORT		01
14	1902020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0503010014	3/4" HEX NUT		02
17	0541018684	FLAT WASHER		01
18	0503013185	3/4" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01
21	0503011411	1/2" X 5-1/2" BOLT		01



Item	Code	Description	See page	QT
01	0521050737	PNEUMATIC SEED DISTRIBUTOR	189	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	RIGHT DDD	194	01




Item	Code	Description	See page	QT
01	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA 190 CSU 3		01
02	0581012756	HEX AXLE 5/8 X 360		01




Item	Code	Description	See page	QT
01	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
02	0571017899	PIN LOCK		01
03	0503030190	0.5" X 1.6" X 0.05" SPRING		01
04	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
05	0511057155	PRECISION PLANTING LEFT TRANSMISSION 191 HOPPER		01
06	0571017894	PIN DRAG PRECISION PLANTING		01
07	0503013357	3/8 SELF-ADJUSTING NUT		01
08	0501013518	FLAT WASHER		02
09	0503015356	SPRING PIN		01
10	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
11	0571017895	PIN FIXER CONDUCTOR P.P		01
12	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
13	0503010293	CLAMP KNOB		02
14	0503010140	1/8" X 3/4" COTTERPIN		02
15	0503010131	3/16" X 1-1/2" COTTERPIN		01
16	0503010025	3/8 SPRING WASHER		02
17	0571019491	SLUICE PNEUMATIC		01
18	0501011643	3/8 X 1" BOLT		01
19	0503010209	3/8" UNC BUTTERFLY NUT		01
20	0502012807	SUPPORT HOPPER PRECISION PLANTING		01
21	0571019489	CLAMP PRECISION PLANTING		01
22	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
23	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 192 DISC		01
24	0561014778	HEX UNIVERSAL JOINT		01
25	0503013958	1/4" X 1" BOLT		02
26	0503011855	0.2" X 1.8" SPRING PIN		01
27	0503012721	1/4" X 4" BOLT		01
28	0503012880	1/4" UNC SELF ADJUSTING NUT		04
29	0571014024	FAST BOLT GUIDE AXLE		01


Item	Code	Description	See page	QT
30	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
31	0503015110	M06 SPRING WASHER		02
32	0503818139	BOLT		03
33	0503037390	PACKING FOR PLANTING		01
34	0503015752	3/8" X 2" BOLT		01
35	0503034824	FIXATIVE		01
36	0581011226	FIXER CLOSING P. PLANTING CONTROL CPRA		01
37	0503010337	5/16" NUT		04
38	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
39	0503011953	5/16" X 1" BOLT		03
40	0503012163	5/16" X 1-1/2" BOLT		01
41	0521066707	FEEDER		01




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION HOPPER PP		01
02	0502050053	RIGHT SIDE TRANSMISSION HOPPER PP		01
03	0503011410	ROLLER BEARING		02
04	0503011182	6203 ROLLER BEARING		02
05	0503011184	502040 CLAMPING RING (FOR AXLE)		01
06	0571017655	FIXER SLEEVE		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
08	0503010144	1/4" NUT		03
09	0511057504	JOIN GEAR		01
09A	0571017898	BODY GEAR TRANSMISSION		01
09B	0503011769	M8 X 0.5" BOLT		01
10	0581011222	PINION AXLE 6Z PNEUMATIC		01
11	0503034340	PINION AXLE 6Z PNEUMATIC		01




Item	Code	Description	See page	QT
01	0571019613	STRAW PRECISION PLANTING SHIELD		01
02	0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	193	01




Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01



Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	177	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	RIGHT LOW HUB WITH 15 DISC	178	01
04	0503810026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012780	SUPPORT DDD RIGHT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX	196	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	RIGHT DDD	194	01
07	0501058972	ASSEMBLY SENSOR ELECTRONIC	198	01
08	0521066707	FEEDER		01
09	0503011953	5/16" X 1" BOLT		04
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
11	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0511057502	SET PRECISION PLANTING	197	01
02	0502012807	SUPPORT HOPPER PRECISION PLANTING		01
03	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
04	0503037390	PACKING FOR PLANTING		01
05	0571017899	PIN LOCK		01
06	0503030190	0.5" X 1.6" X 0.05" SPRING		01
07	0571014024	FAST BOLT GUIDE AXLE		02
08	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
09	0502012786	FAST LOCK PRECISION PLANTING		01
10	0511057155	PRECISION PLANTING LEFT TRANSMISSION 191 HOPPER		01
10A	0502050053	RIGHT SIDE TRANSMISSION HOPPER PP		01
10B	0502050052	LEFT SIDE TRANSMISSION HOPPER PP		01
10C	0503033975	24Z GEAR PNEUMATIC		01
10D	0571017898	BODY GEAR TRANSMISSION		01
10E	0503011410	ROLLER BEARING		02
10F	0503033976	GEAR 6Z PNEUMATIC 2014		01
10G	0503011182	6203 ROLLER BEARING		02
10H	0571016187	PINION AXLE 6Z PNEUMATIC		01
10I	0503011184	502040 CLAMPING RING (FOR AXLE)		01
10J	0571017655	FIXER SLEEVE		01
10K	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
10L	0503010144	1/4" NUT		03
11	0571017894	PIN DRAG PRECISION PLANTING		01
12	0503013357	3/8 SELF-ADJUSTING NUT		01
13	0503015752	3/8" X 2" BOLT		01
14	0501013518	FLAT WASHER		02
15	0503015356	SPRING PIN		01
16	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
17	0571017895	PIN FIXER CONDUCTOR P.P		01
18	0503011776	M6 SELF ADJUSTINGNUT		03
19	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02

Item	Code	Description	See page	QT
20	0503010293	CLAMP KNOB		01
21	0503010140	1/8" X 3/4" COTTERPIN		03
22	0503010131	3/16" X 1-1/2" COTTERPIN		01
23	0503010025	3/8 SPRING WASHER		01
24	0571011803	PRISONER CLOSE FAST		01
25	0571019491	SLUICE PNEUMATIC		01
26	0501011643	3/8 X 1" BOLT		01
27	0503010209	3/8" UNC BUTTERFLY NUT		01
28	0503012721	1/4" X 4" BOLT		01
29	0503012880	1/4" UNC SELF ADJUSTING NUT		01
30	0571011804	FAST BOLT ADJUSTMENT		01
31	0571019489	CLAMP PRECISION PLANTING		01
32	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
33	0503011855	0.2" X 1.8" SPRING PIN		02
34	0561014778	HEX UNIVERSAL JOINT		01
35	0503013958	1/4" X 1" BOLT		02
36	0503011855	0.2" X 1.8" SPRING PIN		01
37	0503818139	BOLT		03
38	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
39	0503015110	M06 SPRING WASHER		02
40	0501056296	UNIVERSAL JOINT		01
41	0571012452	HEX AXLE		01
42	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 192 DISC		01
42A	0503062405	SEED DISTRIBUTOR		01
42B	0503062407	SET SOYBEAN DISTRIBUTION		01
42B-01	0503062417	KIT CORN DISTRIBUTION		01
42B-02	0503062471	DISTRIBUTION ASSY (SORGHUM / MILLET)		01
42B-03	0503062577	DISTRIBUTION ASSY (LARGE CORN / SUNFLOWER)		01
42B-04	0503062578	DISTRIBUTION ASSY (LARGE CORN)		01
42B-05	0503062579	DISTRIBUTION ASSY (CORN / SUNFLOWER)		01
42B-06	0503062580	DISTRIBUTION ASSY (POPCORN / COTTON)		01
42B-07	0503062581	DISTRIBUTION ASSY (SMALL CORN / POP CORN)		01
42B-08	0503062573	CONVERSATION SET FOR DISTRIBUTION (LARGE BEAN)		01
42B-09	0503062574	CONVERSATION SET FOR DISTRIBUTION (SMALL BEET)		01
42B-10	0503062564	CONVERSATION SET FOR DISTRIBUTION (SOYBEAN / BEAN)		01
42C	0571019613	STRAW PRECISION PLANTING SHIELD		01




Item	Code	Description	See page	QT
01	0502012807	SUPPORT HOPPER PRECISION PLANTING		01
01A	1902012807	SEED HOPPER SUPPORT		01
02	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
03	0571017899	PIN LOCK		01
04	0503030190	0.5" X 1.6" X 0.05" SPRING		01
05	0571014024	FAST BOLT GUIDE AXLE		02
06	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
07	0581011225	FIXER P PLANTING CONTR CPRA		01
08	0511057155	PRECISION PLANTING LEFT TRANSMISSION 191 HOPPER		01
09	0571017894	PIN DRAG PRECISION PLANTING		01
10	0503013357	3/8 SELF-ADJUSTING NUT		01
11	0503015752	3/8" X 2" BOLT		01
12	0501013518	FLAT WASHER		02
13	0503015356	SPRING PIN		01
14	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
15	0571017895	PIN FIXER CONDUCTOR P.P		01
16	0503011776	M6 SELF ADJUSTINGNUT		03
17	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
18	0503010293	CLAMP KNOB		01
19	0503010140	1/8" X 3/4" COTTERPIN		03
20	0503010131	3/16" X 1-1/2" COTTERPIN		01
21	0503010025	3/8 SPRING WASHER		01
22	0503037390	PACKING FOR PLANTING		01
23	0571019491	SLUICE PNEUMATIC		01
24	0501011643	3/8 X 1" BOLT		01
25	0503010209	3/8" UNC BUTTERFLY NUT		01
26	0503012721	1/4" X 4" BOLT		01
27	0503012880	1/4" UNC SELF ADJUSTING NUT		01
28	0581011226	FIXER CLOSING P. PLANTING CONTROL CPRA		01
29	0571019489	CLAMP PRECISION PLANTING		01


Item	Code	Description	See page	QT
30	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
31	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 192 DISC		01
31A	0503062405	SEED DISTRIBUTOR		01
31B	0503062407	SET SOYBEAN DISTRIBUTION		01
31B-01	0503062417	KIT CORN DISTRIBUTION		01
31B-02	0503062471	DISTRIBUTION ASSY (SORGHUM / MILLET)		01
31B-03	0503062577	DISTRIBUTION ASSY (LARGE CORN / SUNFLOWER)		01
31B-04	0503062578	DISTRIBUTION ASSY (LARGE CORN)		01
31B-05	0503062579	DISTRIBUTION ASSY (CORN / SUNFLOWER)		01
31B-06	0503062580	DISTRIBUTION ASSY (POPCORN / COTTON)		01
31B-07	0503062581	DISTRIBUTION ASSY (SMALL CORN / POP CORN)		01
31B-08	0503062573	CONVERSATION SET FOR DISTRIBUTION (LARGE BEAN)		01
31B-09	0503062574	CONVERSATION SET FOR DISTRIBUTION (SMALL BEET)		01
31B-10	0503062564	CONVERSATION SET FOR DISTRIBUTION (SOYBEAN / BEAN)		01
32	0561014778	HEX UNIVERSAL JOINT		01
33	0503013958	1/4" X 1" BOLT		02
34	0503818139	BOLT		03
35	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
36	0503015110	M06 SPRING WASHER		02




Item	Code	Description	See page	QT
01	0503015218	SENSOR FOTOELE PM 400		01
02	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		03




Item	Code	Description	See page	QT
01	0521050737	PNEUMATIC SEED DISTRIBUTOR	189	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT	200	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	177	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	RIGHT LOW HUB WITH 15 DISC	178	01
04	0503810026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O-RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511057606	PNEUMATIC SEED DISTRIBUTOR WHIT AXLE HEX	196	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT	200	01
07	0501058972	ASSEMBLY SENSOR ELECTRONIC	198	01
08	0521066707	FEEDER		01
09	0503011953	5/16" X 1" BOLT		04
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
11	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	203	01
02	0501052538	DEPTH BAND WITH ARMS	208	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	209	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	211	01
07	0503033942	COMPACTOR WHEEL REGULATOR LID		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT DEPTH WHEEL ARM WITH HUB	204	01
07	0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	205	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	207	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL HUB	206	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL HUB	206	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	PROTECTION LID		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	210	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	210	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0581014858	DEPTH WHEEL AXLE		01
04	0501110720	ARM LEFT		01
05	0501110719	DEPTH CONTROL RIGHT ARM		01
06	0502012663	EXTENSION		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	213	01
09	0503034793	ARTICULATION SLEEVE		02
10	0521051423	COMPACTOR SUPPORT	214	01
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503016453	1/2" X 2.1/2 BOLT		02
14	0503034817	SPRING		01
15	0503010581	RING		01
16	0503034377	3/8 UNC X 3/4 BOLT		01
17	0503010019	1/2" SPRING WASHER		08
18	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
19	0503010060	1/2 UNC G.5 ZN HEX NUT		04
20	0501052908	COMPACTOR WHEEL WITH BEARING	210	02
21	0503013739	1/2" X 1" BOLT		01
22	0511050077	WHEEL STRIPED	215	02
23	0503010752	1/2" X 3.1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521068003	RIGHT SIDE		01
02	0521068002	LEFT SIDE		01
03	0581014847	PLATE UPPER		01
04	0581015855	SLEEVE		02
05	0521068004	HANDLE BODY		01
06	0581014969	GUIDE SLEEVE		01
07	0581014968	SLEEVE FLANGE		01
08	0503010937	5/16" X 3" BOLT		02
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0521068005	LEVER		01
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
12	0503010337	5/16" NUT		04
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2 UNC G.5 ZN HEX NUT		01
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010882	BOLT		02
17	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
18	0503030878	LEVER CRANK		01
19	0581015854	RIGHT PROTECTION COVER		01
20	0581015853	LEFT PROTECTION COVER		01
21	0581015903	SPACER WASHER		01




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	216	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEEL HUB		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	218	01
02	0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	224	01
03	0501052908	COMPACTOR WHEEL WITH BEARING	210	02
04	0503010019	1/2" SPRING WASHER		06
05	0503010752	1/2" X 3.1/2" BOLT		01
06	0503013739	1/2" X 1" BOLT		01
07	0503010479	BOLT		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503030012	HITCH PIN CLIP		01
10	0571013222	FIXING CHOCK		01
11	0503010741	1/2" X 2-3/4" BOLT		02
12	0511055819	DEPTH BAND WITH RIM	225	02
13	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
14	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0521063808	DEPTH CONTROL INNER COLUMN CONTROL WITH SCREW		01
02	0521063809	DEPTH CONTROL EXTERNAL COLUMN CONTROL WITH SCREW		01
03	0571013194	REGULATOR SPINDLE		01
04	0551010616	ROD HEX		01
05	0503010683	0,2" X 1,2" SPRING PIN		01
06	0571013202	COVERING WHEEL REGULATOR AXLE		01
07	0521063812	REGULATOR LEVER ALXE		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		01
09	0511065308	LOCK REGULATOR		01
10	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
11	0541011627	FLAT WASHER		01
12	0503010140	1/8" X 3/4" COTTERPIN		01
13	0511059325	LEFT ARM COVERED WHEEL ASSEMBLED	219	01
14	0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED	220	01
15	0571014709	SLEEVE LOCK CONTROL ARM		02
16	0503011440	SPRING WASHER		03
17	0503819099	BOLT		02
18	0511051546	RIGHT DEPTH CONTROL HUB	221	01
19	0511051547	LEFT DEPTH CONTROL HUB	223	01
20	0503011442	3/4" SPRING WASHER		02
21	0571013189	SLEEVE SUPPORT BEATER		01
22	0521063813	WHEEL PRESS BEATER		01
23	0501010937	13,50 X 28 X 3,00 FLAT WASHER		01
24	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01




Item	Code	Description	See page	QT
01	0502012844	LEFT ARM WHEELS		01
02	0581011340	ARM CASE		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	COVERING WHEEL ARM SUPPORT SLEEVE		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012843	RIGHT WHEEL ARM		01
02	0581011340	ARM CASE		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	COVERING WHEEL ARM SUPPORT SLEEVE		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	222	01
02	0511066638	RIGHT AXLE WITH DUST CLOAK		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	PROTECTION LID		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0502011907	DEPTH CONTROL WHEEL HUB		01
02	0503010269	6204 BALL BEARING		02
03	0501013636	SPACING SLEEVE		01
04	0503010689	SEAL 00763-BR		01
05	0503011105	SEAL RING		01
06	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	222	01
02	0511066637	LEFT AXLE WITH DUST CLOAK		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	PROTECTION LID		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0502012850	PRESS WHEELS ARM		01
02	0503030883	RIGHT TORSION SPRING		01
03	0502011066	PRESS WHEELS ARM SUPPORT		01
04	0531017415	1" X 4.72" AXLE JOINT		01
05	0503010839	03"X 0.6" SPRING PIN		01
06	0521063841	REGULATOR RIGHT COMPACTOR		01
07	0521063842	REGULATOR LEFT COMPACTOR		01
08	0503811404	BOLT		02
09	0503011443	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0571013295	ALXE REGULATOR COMPACTOR		01
12	0521063812	REGULATOR LEVER ALXE		01
13	0503011336	1/2" HEX SELF ADJUSTING NUT		02
14	0511065308	LOCK REGULATOR		01
15	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
16	0541011627	FLAT WASHER		01
17	0503010140	1/8" X 3/4" COTTERPIN		01
18	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW		01
19	0503811172	BOLT		01
20	0503010002	1800 GREASE FITTING		01
21	0581013744	PROTECTION CASE		01
22	0503813096	BOLT		01
23	0503013816	5/16" LOCKNUT		0




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 C50 G.5 ZN		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" HEX NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02



Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02



Item	Code	Description	See page	QT
01	0521067063	SPRING HUB		01
02	0511059411	SCARIFIER SPINDLE WITH POINT		01
03	0581812084	LARGE BUSHING		01
04	0503012795	5/8" HEX SELF ADJUSTING NUT		01
05	0581812082	BOLT FIXER		01
06	0503810417	NUT		01
07	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
08	0503034106	80 X 230 X 16,50 COMPRESSSION SPRING		01
09	0503010691	1/4" GREASE FITTING		01
10	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
11	0571018541	BODY SOCKET FERTILIZER		01
12	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
14	0503010026	3/8" NUT		02
15	0503010025	3/8 SPRING WASHER		02
16	0503010384	1/2" X 5" BOLT		02
17	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
18	0503010547	1/2" X 4" BOLT		02
19	0503011336	1/2" HEX SELF ADJUSTING NUT		04
20	0571019462	SUPPORT GUIDE PRING		01
21	0581812081	SMALLER BUSHING		01
22	0581012094	SUPPORT WASHER		01



MARCHESAN

Technical Publications | Elaboration and Revision

LORENA ROCHA ALVES

www.marchesan.com.br

