

ROW CROP PLANTERS

COP TRIO 650 SUPREMA - FRAME 6850 - CSU/TCE/APT ISO (FROM 05/2023)

Code: 0501093589
Series: S-0419
Revision: 00
Date Revision: JUNHO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111420079	COP TRIO 650 SUP 6850/15E450 ESPECIAL S-0419

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909096758	ASSY FRAME	1
0521056065	FRAME SHAFT	2
0521056088	WHEEL ASSY RIGHT FIXING EXTENSOR	3
0521056089	WHEEL ASSY LEFT FIXING EXTENSOR	4
0521056090	RIGHT WHEEL ASSY	5
0521056091	LEFT WHEEL ASSY	6
0521057820	WHEEL ASSEMBLY WITHOUT TRANSMISSION	7
0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH TRANSMISSION	8
0521056160	SIDE TRANSMISSION CURRENT STRETCHER	9
0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	10
0521056299	MOUNTED RIGHT STRETCHER	11
0521056095	ARTICULATED BEARING WHEELED WITHOUT LUBRICATION	12
0501058239	WHEEL CHAIN TENSIONER BEARING	13
0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY	14
0521056100	WHEEL HUB ASSY WITH TRANSMISSION	15
0521055238	BEARING TENSIONER CHAIN	16
0521056300	MOUNTED LEFT STRETCHER	17
0521057818	WHEEL WITH TIRE 7.00 X 16 14L ASSY WITHOUT TRANSMISSION	18
0521057819	ASSY WHEEL HUB WITHOUT TRANSMISSION	19
0521057817	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	20
0521056119	SQUARE AXIS ASSEMBLY 730	21
0501056271	GEARBOX CLOSED BEARING	22
0501056444	BEARING WITH ROLLER	23
0501053788	3/4" SQUARE AXLE FASTENER	24
0521056084	MOTOR SHAFT ASSEMBLY - 6850	25
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	26
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	27
0511051434	TRANSMISSION ACTUATOR	28
0521056085	PLATE BEARING ASSY	29
0531052786	HEX AXLE ASSEMBLY 6850	30
0531052779	BEARING WITH 26Z GEAR	31
0521055498	SEED TRANSMISSION DOUBLE BEARING	32
0521056144	INTERMEDIATE SEED TRANSMISSION	33
0531052790	TRANSMISSION ASSY	34
0531052780	DOUBLE BEARING WITH 22Z X 20Z GEAR	35
0521055217	LOWER CURRENT STRETCH	36
0521056134	STRETCHER FERTILIZER CURRENT 17Z	37
0521054446	LOWER CURRENT STRETCHER 21Z	38
0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	39
0511052333	ASSEMBLY SUPPORT LEFT FIXER CHANGE	40
0531052782	LEFT GEAR BOX ASSY	41
0531052781	RIGHT GEAR BOX ASSY	42
0501048790	AXLE WITH RING	43
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	44
0501054655	CHAIN TENSIONER ASSY	45
0501056443	GEAR HOUSING BEARING	45
0511059261	CHAIN TENSIONER	46
0511059266	CLOSED BEARING	46
0531058971	FERTILIZER SILO SET ALPHA 6850	47
0531058970	SUPPORT WITH ALPHA FERTILIZER STRAIGHT FERTILIZER SILO DOSER	48
0531058968	SUPPORT WITH SILO ALPHA FERTILIZER CENTRAL FERTILIZER	49



MARCHESAN

INDEX

0531058969	SUPPORT WITH ALPHA FERTILIZER LEFT FERTILIZER SILO DOSER	50
0531055319	ALPHA II FERTILIZER METERING	51
0531055863	ASSY TRANSMISSION HUB	52
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	53
0531059139	ASSY COLLECTOR	54
0531055273	ALPHA FERTILIZER METERING CLAMP	55
0531057978	SIDE BEARING WITH TRANSMISSION	56
0521057078	HANDRAIL ASSY - 6850	57
0531051907	PLATFORM ASSEMBLY - 6850	58
0521057199	6850 - HYDRAULIC SET	59
0521057899	SUPPORT VALVE BLOCK VACUOMETER ASSY 5750/7350	60
0521057855	CASAPPA DIVIDER VALVE WITH FIXING NIPLES	61
0521057886	HOSE CLAMP ASSEMBLY	62
0521057259	OIL CONDUCTOR FIXATION	63
0521057704	SLIDING SUPPORT HYDRAULIC HOSE	64
0501053834	MALE QUICK COUPLER	65
0511053356	ASSY LADDER	66
0511058191	REST ASSY	67
0511057803	ASSY PORT MANUAL INSTRUCCION	68
0511059494	TRACTION SPRING ASSY	69
0521057140	TURBINE ASSEMBLY - 6850	70
0521057131	CENTRAL TURBINE MOUNTED WITH CSU SUPPORT	71
0521056673	TURBINE P.P CSC	72
0521050154	PRECISION PLANTING TURBINE WITH HOLE	73
0521056143	RIGHT SIDE AIR DISTRIBUTOR	74
0521056112	LEFT SIDE AIR DISTRIBUTOR	75
0521057135	CENTRAL AIR DISTRIBUTOR 1978	76
0521052549	CLAMP	77
0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	78
0521057289	VACUOMETER FIXING SUPPORT CSU	79
0521057018	CSU CONDUCTOR 3 SEMI-ASSEMBLED ASSY - 6850	80
0521051730	ASSY FIXING SUPPORT	81
0511057755	ASSEMBLY CSU 6850	82
0511057690	3" ARTICULATED SEED CONDUCTOR	83
0521057149	ASSY RIGHT FIXING SUPPORT	84
0521057151	FIXING SUPPORT LEFT ASSY	85
0521057094	ASSY STICKER - 6850	86
0521057928	REAR HEADLIGHT ASSY 6850 A 7350	87
0521053672	LIGHTHOUSE ASSY	88
0521052792	MOUNTED REAR LIGHT	89
0531058975	MECHANICAL ASSY 6-CHANNELS FERTILIZER/SEED	90
0531055259	SUPPORT WITH LEFT ENGINE	91
0531050693	MODULE BOX	92
0511059348	APT ASSY MODULE BOX	93
0531050811	APT FILTER SUPPORT	94
0531050763	FIXING OIL CONDUCTORS SET FOR 5 TUBES	95
0531058974	LEFT ENGINE COVER	96
0531058973	ENGINE RIGHT PROTECTION COVER	97
0531058972	ENGINE RIGHT PROTECTION COVER	98
0531051005	15 ROWS 450/500 6 CANALS ISO6 MS SET	99
0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	100
0511056972	FILTER HYDAC	101
0521054490	FLOW DIVIDING VALVE ASSY	102
0909095745	HEADER ASSY ASSEMBLY	103



MARCHESAN

INDEX

0521045756	HYDRAULIC CYLINDER	104
0521050573	EXTENSOR 3RD POINT	105
0511055096	TRACTOR HITCH	106
0511053179	TRACTOR COUPLING SHAFT	107
0521057452	ASSY INTERMEDIATE DRAWBAR FIXATION SUPPORT	108
0521050574	EXTENSOR	109
0521050133	TURNBUCKLE SIDE 755/480	110
0521056993	ASSY WATER RESERVOIR	111
0521056994	ASSY TOOL CHEST	112
0909096759	GEARBOX COMPONENT BOX	113
0501056451	BEARING	114
0531055898	CHAIN TIGHTENER	115
0531055896	80 INTERMEDIATE TRANSMISSION BEARING ASSEMBLED	116
0511057817	SUPPORT HOSE	117
0531059625	KIT WITH ALPHA COMPONENTS - 15 ROWS	118
0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	119
0909096760	SEED LINE/ASSY FERTILIZER	120
0521056240	FRONT SHORT ROW	121
0521056241	FRONT LONG ROW	122
0531052956	ASSEMBLY SEED ROW TRANSMISSION FIXING BEARING	123
0521056941	RIGHT REAR P.P CSU TRANSMISSION/CABLE	124
0521056940	LEFT REAR P.P CSU TRANSMISSION CABLE	125
0521056955	RIGHT DDD ASSY	126
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	127
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	128
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	129
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	130
0521056956	PRECISION PLANTING CSU CABLE/TRANSMISSION ASSY	131
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	132
0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	133
0521056954	LEFT DDD ASSY	134
0521054984	DEPTH/COMPACTOR SYSTEM - SPT	135
0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	136
0501052297	DEPTH WHEELS REGULATOR ASSY	137
0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	138
0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	139
0521055033	SEMI-ASSEMBLED COMPACTOR BODY	140
0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	141
0501052538	DEPTH BAND WITH ARMS	142
0521054990	LEFT COMPACTOR WHEEL	143
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	144
0521055017	RIGHT COMPACTOR WHEEL	145
0521056069	SEMI-ASSEMBLED SHORT FERTILIZER ROW	146
0521056066	SEMI-ASSEMBLED LONG FERTILIZER ROW	147
0521056070	DC 20 ASSY	148
0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	149
0521053697	DISC BLADE HUB	150
0521051447	FRONT ASSY ROW BEARING	151
0531050181	ASSY JOINT TCE	152
0531050182	ASSY JOINT TCE	153
0531051830	ASSY JOINT TCE 1441	154
0531052349	CURRENT GUIDE ASSEMBLY	155
0521059758	SUPPORT ASSY	156
0521056844	SCARIFIER ROD	157




MARCHESAN

INDEX

0521053673	SCARIFIER ROD WITH NOZZLE		158
0531050237	SEED CONDUCTOR FIXER 3 CSU RIGHT		159

ASSY FRAME

0909096758



Item	Code	Description	See page	QT
01	0521056065	FRAME SHAFT	2	01
02	0521056088	WHEEL ASSY RIGHT FIXING EXTENSOR	3	01
03	0521056089	WHEEL ASSY LEFT FIXING EXTENSOR	4	01
04	0521056090	RIGHT WHEEL ASSY	5	01
05	0521056091	LEFT WHEEL ASSY	6	01
06	0521057820	WHEEL ASSEMBLY WITHOUT TRANSMISSION	7	04
07	0521056119	SQUARE AXIS ASSEMBLY 730	21	01
08	0521056084	MOTOR SHAFT ASSEMBLY - 6850	25	01
09	0531052786	HEX AXLE ASSEMBLY 6850	30	01
10	0531052790	TRANSMISSION ASSY	34	01
11	0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	39	01
12	0511052333	ASSEMBLY SUPPORT LEFT FIXER CHANGE	40	01
13	0531052782	LEFT GEAR BOX ASSY	41	01
14	0531052781	RIGHT GEAR BOX ASSY	42	01
15	0531058971	FERTILIZER SILO SET ALPHA 6850	47	01
16	0521057078	HANDRAIL ASSY - 6850	57	01
17	0531051907	PLATFORM ASSEMBLY - 6850	58	01
18	0521057199	6850 - HYDRAULIC SET	59	01
19	0511053356	ASSY LADDER	66	01
20	0511058191	REST ASSY	67	01
21	0521064285	LOCK LOWER FRAME		04
22	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		04
23	0511057803	ASSY PORT MANUAL INSTRUCCION	68	01
24	0511059494	TRACTION SPRING ASSY	69	10
25	0521057140	TURBINE ASSEMBLY - 6850	70	01
26	0521057018	CSU CONDUCTOR 3 SEMI-ASSEMBLED ASSY - 6850	80	01
27	0521057094	ASSY STICKER - 6850	86	01
28	0503034867	AIR DISTRIBUTOR PUMP		07
29	0503010243	CLAMP		07
30	0521057928	REAR HEADLIGHT ASSY 6850 A 7350	87	01


ASSY FRAME

0909096758


Item	Code	Description	See page	QT
31	0531058975	MECHANICAL ASSY 6-CHANNELS FERTILIZER/SEED	90	01
32	0531051005	15 ROWS 450/500 6 CANALS ISO6 MS SET	99	01
33	0909095745	HEADER ASSY ASSEMBLY	103	01
34	0909096759	GEARBOX COMPONENT BOX	113	01
35	0511057817	SUPPORT HOSE	117	01
36	0521013022	TRANSPORT LOCK		08
37	0501068994	8,30 X 78 LOCK PIN		08
38	0503030168	HITCH PIN CLIP		08
39	0501047895	25 ROD STOP		08
40	0501047885	30 ROD STOP		08
41	0501047886	35 ROD STOP		08
42	0501047887	40 ROD STOP		08
43	0521066303	HOSE GUIDE		01
44	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02
45	0503013816	5/16" LOCKNUT		02
46	0503010002	1800 GREASE FITTING		02
47	0521018501	TURNBUCKLE LEVER		01
48	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
49	0581013729	NIPLE 1/2 NPT		01
50	0541010080	TERMINAL R.1 / 2 NPT		01
51	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
52	0503010045	O'RING		01
53	0501053834	MALE QUICK COUPLER	65	01
54	0503014321	CABLE STEEL SHACKLE		02
55	0503014120	CHAIN		01
56	0501093353	MARCHESAN OPERATOR'S MANUAL - ISO6		01
57	0531059625	KIT WITH ALPHA COMPONENTS - 15 ROWS	118	01
58	0503011750	AMENDMENT WITH LOCK		06
59	0503011751	REDUCTION		06
60	0503010780	N-2050 AMENDMENT		06
61	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	119	02
62	0909096760	SEED LINE/ASSY FERTILIZER	120	15

FRAME SHAFT

0521056065



Item	Code	Description	See page	QT
01	0521069990	RIGHT SIDE FRAME 6850		01
02	0521069989	LEFT SIDE FRAME 6850		01
03	0521063003	LOCK PIN		02
04	0571010969	LOCK SLEEVE FRAME		02
05	0503013627	1.1/2 SPRING WASHER		02
06	0501010110	1.1/2" NUT		02
07	0521069988	CENTRAL FRAME		01
08	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		04
09	0503011442	3/4" SPRING WASHER		20
10	0501010098	3/4" UNC BOLT		20
11	0571010094	SLEEVE FLANGE		12
12	0521066298	ARTICULATOR		04
13	0571013510	LOCK AXLE		04
14	0503030085	LOCK PIN		04
15	0571010095	FLAT WASHER		04
16	0521064285	LOCK LOWER FRAME		04
17	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		04
18	0591012308	SIDE GUTTER 24 X 50 X 1950		02
19	0591012303	CENTRAL TRACK		02
20	0503013029	3/8" X 3/4" BOLT		08
21	0501013518	FLAT WASHER		08
22	0503010025	3/8 SPRING WASHER		08
23	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0521066480	RH WHEELS SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 8 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	9	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	10	01
15	0501047888	45 ROD STOP		02
16	0511064744	WHEEL FORK		01
17	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8 SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" SPLIT PIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056299	MOUNTED RIGHT STRETCHER	11	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8 NUT		02

WHEEL ASSY RIGHT FIXING EXTENSOR

0521056088

Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 12 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOCK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TENSIONER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	WHEEL CHAIN TENSIONER BEARING	13	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01



Item	Code	Description	See page	QT
01	0521066479	RH WHEELS SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 8 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	9	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	10	01
15	0501047888	45 ROD STOP		01
16	0511065842	LEFT WHEEL FORK		01
17	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8 SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" SPLIT PIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056300	MOUNTED LEFT STRETCHER	17	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8 NUT		02


WHEEL ASSY LEFT FIXING EXTENSOR

0521056089

Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 12 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOCK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TENSIONER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	WHEEL CHAIN TENSIONER BEARING	13	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01

RIGHT WHEEL ASSY

0521056090



Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 8 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	9	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	10	01
15	0501047888	45 ROD STOP		01
16	0511064744	WHEEL FORK		01
17	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8 SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" SPLIT PIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056299	MOUNTED RIGHT STRETCHER	11	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8 NUT		02


RIGHT WHEEL ASSY

0521056090

Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 12 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOCK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TENSIONER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	WHEEL CHAIN TENSIONER BEARING	13	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01

LEFT WHEEL ASSY

0521056091



Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0541010763	FLAT WASHER		04
05	0503010152	3/4" SELF LOCKING NUT		04
06	0502012720	WHEEL SUPPORT FIXER		01
07	0503017857	BOLT 5/8 UNF 4		04
08	0501012140	FLAT WASHER		04
09	0503010811	5/8" UNF SELF ADJUSTING NUT		04
10	0521056099	EE WHEEL WITH TIRE 7.00 X 16 ASSY WITH 8 TRANSMISSION		01
11	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
12	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
13	0521056160	SIDE TRANSMISSION CURRENT STRETCHER	9	01
14	0521056094	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	10	01
15	0501047888	45 ROD STOP		01
16	0511065842	LEFT WHEEL FORK		01
17	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
18	0503011167	M16 X 2 X 30 BOLT		02
19	0503010027	5/8 SPRING WASHER		02
20	0503010834	1/2 X 1 BOLT		06
21	0503010019	1/2" SPRING WASHER		14
22	0521010546	1.2" X 5.7" COUPLING SHAFT		01
23	0501017779	32 X 60 X 4.75 FLAT WASHER		02
24	0503010523	1/4" X 2" SPLIT PIN		01
25	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
26	0521056300	MOUNTED LEFT STRETCHER	17	01
27	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8 NUT		02


LEFT WHEEL ASSY

0521056091


Item	Code	Description	See page	QT
30	0531060127	15Z GEAR AXLE WITHOUT LUBRICATION		01
31	0501018466	FLAT WASHER		03
32	0521056095	ARTICULATED BEARING WHEELED WITHOUT 12 LUBRICATION		02
33	0503010411	RING 2-023 N 3006-9B		04
34	0561013021	BEARING INNER LOCK		02
35	0561013022	BEARING EXTERNAL LOCK		02
36	0561013020	KM 12 NUT		02
37	0503010398	501082 CLAMPING RING (FOR AXLE)		02
38	0511061809	15Z GEAR WITH COUPLING		01
39	0503011103	7/16" X 2-1/2" BOLT		01
40	0503010180	7/16" SPRING WASHER		01
41	0503010244	7/16" NUT		01
42	0503013232	1/2' BOLT		08
43	0551018252	CHAIN TENSIONER AXLE		01
44	0521010479	SLEEVE ARTICULATION		01
45	0501058239	WHEEL CHAIN TENSIONER BEARING	13	01
46	0503011336	1/2" HEX SELF ADJUSTING NUT		01

WHEEL ASSEMBLY WITHOUT TRANSMISSION


0521057820




Item	Code	Description	See page	QT
01	0531060795	WHEEL SUPPORT	01	
02	0503010019	1/2" SPRING WASHER	13	
03	0503013232	1/2" BOLT	08	
04	0561013021	BEARING INNER LOCK	02	
05	0561013022	BEARING EXTERNAL LOCK	02	
06	0503010398	501082 CLAMPING RING (FOR AXLE)	02	
07	0561013020	KM 12 NUT	02	
08	0503010408	7/8" SPRING WASHER	02	
09	0503012419	7/8" X 2-3/4" BOLT	02	
10	0501047888	45 ROD STOP	02	
11	0521057818	WHEEL WITH TIRE 7.00 X 16 14L ASSY WITHOUT TRANSMISSION	01	
12	0503016485	BOLT 3/4	04	
13	0503010152	3/4" SELF LOCKING NUT	04	
14	0501010322	FLAT WASHER	04	
15	0503017857	BOLT 5/8 UNF 4	04	
16	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
17	0501012140	FLAT WASHER	04	
18	0503010834	1/2 X 1 BOLT	05	
19	0501017779	32 X 60 X 4.75 FLAT WASHER	02	
20	0503010523	1/4" X 2" SPLIT PIN	01	
21	0521010546	1.2" X 5.7" COUPLING SHAFT	01	
22	0531060798	CENTRAL WHEEL FORK WITHOUT TRANSMISSION	01	
23	0501110968	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION	02	
24	0521057817	HYDRAULIC CYLINDER 44,45 X 101,6 X 203 X 181 WITHOUT LUBRICATION	01	
25	0502010584	CARRYING-WHEELS SUPPORT FIXER	02	
26	0591010098	ARTICULATED BEARING WHEELED WITHOUT TRANSMISSION WITHOUT LUBRICATION	02	
27	0502012720	WHEEL SUPPORT FIXER	01	




Item	Code	Description	See page	QT
01	0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY	14	01
02	0521056100	WHEEL HUB ASSY WITH TRANSMISSION	15	01




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		01
02	0591010747	CURRENT STRETCHER AXIS		01
03	0503010302	501019 SEAL RING		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
07	0541016454	PULLEY		01




Item	Code	Description	See page	QT
01	0531060012	CASE 101.6 X 324.5 WITHOUT LUBRICATION		01
02	0541017674	TURNBUCLE BODY		01
03	0511064408	FORK		01
04	0503011094	3/8" X 2" BOLT		01
05	0503010025	3/8 SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581010302	RING OF SUPPORT		01
08	0502012822	101.60 END CAP		01
09	0503011061	8-342 BACK-UP RING		02
10	0503010338	2-342 N 3006-9B O'RING		02
11	0503017936	RING		01
12	0503017938	RING GUIDE		01
13	0503017937	GASKET		01
14	0503010761	D-1750 SCRAPER RING		01
15	0581010837	PISTON		01
16	0503010817	1.1/4" SELF LOCKING NUT		01
17	0503015633	SELEMASTER SEALING		01
18	0503018029	2-217 O'RING		01
19	0503018045	2-130 (AGEL) O'RING		04
20	0503030387	PLUG		02
21	0511033019	CYLINDER REPAIR KIT 44.45 X 101.60		01




Item	Code	Description	See page	QT
01	0503010027	5/8 SPRING WASHER		01
02	0503010013	5/8 NUT		01
03	0521055238	BEARING TENSIONER CHAIN	16	01
04	0551018241	SLEEVE 16,30 X 30 X 8		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	0551018252	CHAIN TENSIONER AXLE		01
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
09	0503010232	5/8" X 1.3/4" BOLT		01
10	0531016916	SLEEVE BEARING SUPPORT		01
11	0531018654	CHAIN TIGHTENER SUPPORT		01




Item	Code	Description	See page	QT
01	0591010097	ARTICULATED BEARING WHEELED WITHOUT LUBRICATION		01
02	0503019409	SELF LUBRICATING BUSHING		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0503016518	WHEEL		01
02	0503010033	7.50 X 16 INNER TIRE		01
03	0503019458	TIRE 7.00X16 14PR		01




Item	Code	Description	See page	QT
01	0503010804	00547-B SEAL		02
02	0503010330	KM 9 LOCKNUT		01
03	0511015949	LOCK NUT		01
04	0503010329	LOCK WASHER		01
05	0503010002	1800 GREASE FITTING		01
06	0501110721	WHEEL HUB WITH SCREW / NUTS		01
06A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
06B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
06C	0503016516	5/8 UNF CONIC NUT		06
07	0503019364	BEARING 25590/25523		02
08	0521018363	00547-B SEAL		01
09	0511062015	14Z GEAR WITH FLANGE		01
10	0503010421	5/16" X 1-1/2" BOLT		06
11	0503011444	SPRING WASHER		06




Item	Code	Description	See page	QT
01	0503019355	BEARING 6202 2RS1		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0503010027	5/8 SPRING WASHER		01
02	0503010013	5/8 NUT		01
03	0521055238	BEARING TENSIONER CHAIN	16	01
04	0551018241	SLEEVE 16,30 X 30 X 8		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	0551018252	CHAIN TENSIONER AXLE		01
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
09	0503010232	5/8" X 1.3/4" BOLT		01
10	0531016916	SLEEVE BEARING SUPPORT		01
11	0541012098	LEFT CHAIN TIGHTENER LARGER SUPPORT		01



Item	Code	Description	See page	QT
01	0503063073	EE WHEEL WITH TIRE 7.00 X 16 14L ASSEMBLY	14	01
02	0521057819	ASSY WHEEL HUB WITHOUT TRANSMISSION	19	01




Item	Code	Description	See page	QT
01	0503010804	00547-B SEAL		02
02	0503010330	KM 9 LOCKNUT		01
03	0511015949	LOCK NUT		01
04	0503010329	LOCK WASHER		01
05	0503010002	1800 GREASE FITTING		01
06	0501110721	WHEEL HUB WITH SCREW / NUTS		01
06A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
06B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
06C	0503016516	5/8 UNF CONIC NUT		06
07	0503019364	BEARING 25590/25523		02
08	0591013435	TRANSMISSION WHEEL AXLE		01




Item	Code	Description	See page	QT
01	0531060797	CYLINDER CASE		01
02	0541017674	TURNBUCLE BODY		01
03	0511064408	FORK		01
04	0503011094	3/8" X 2" BOLT		01
05	0503010025	3/8 SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0581010302	RING OF SUPPORT		01
08	0591013736	MOBILE COVER		01
09	0503011061	8-342 BACK-UP RING		02
10	0503010338	2-342 N 3006-9B O'RING		02
11	0503017936	RING		01
12	0503017938	RING GUIDE		01
13	0503017937	GASKET		01
14	0503010761	D-1750 SCRAPER RING		01
15	0581010837	PISTON		01
16	0503010817	1.1/4" SELF LOCKING NUT		01
17	0503015633	SELEMASTER SEALING		01
18	0503018029	2-217 O'RING		01
19	0503018045	2-130 (AGEL) O'RING		04
20	0503030387	PLUG		02
21	0511033019	CYLINDER REPAIR KIT 44.45 X 101.60		01

SQUARE AXIS ASSEMBLY 730


0521056119




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	22	02
02	0501056444	BEARING WITH ROLLER	23	02
03	0503011953	5/16" X 1" BOLT		08
04	0501010694	FLAT WASHER		08
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
06	0503010337	5/16" NUT		08
07	0511014218	3/4" X 28.7"SQUARE SHAFT		02
08	0501053788	3/4" SQUARE AXLE FASTENER	24	04
09	0503030275	AGRICULTURAL BEARING		04
10	0521061852	LEVER RATCHET		02
11	0521061847	AXLE ADRIVING ASSY		02
12	0521061849	DISASSEMBLE LEVER		02
13	0503030679	BOLT 1/2 UNC X 1.1/4 C50P G.5 ZN		04
14	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
15	0503010140	1/8" X 3/4" COTTERPIN		04
16	0571012792	LOWER LEVER		02
17	0503011082	C1/2" X 1.3/4" SCREW		02
18	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2 UNC G.5 ZN HEX NUT		02
21	0561016797	SLEEVE UNION LEVER		02
22	0503010026	3/8" NUT		02
23	0503010025	3/8 SPRING WASHER		02
24	0503010849	3/8" X 1-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01



Item	Code	Description	See page	QT
01	0502011697	GEARBOX BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01



Item	Code	Description	See page	QT
01	0503011082	C1/2" X 1.3/4" SCREW		08
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
03	0503010019	1/2" SPRING WASHER		08
04	0503010060	1/2 UNC G.5 ZN HEX NUT		08
05	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	26	01
06	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	27	01
07	0511051434	TRANSMISSION ACTUATOR	28	04
08	0591010711	MOTOR AXLE BEARING SUPPORT		04
09	0521056085	PLATE BEARING ASSY	29	08
10	0571014441	MOTOR SHAFT		02

RIGHT SIDE TRANSMISSION ACTUATOR


0511047069




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
05	0501019734	FLAT WASHER		02
06	0502010710	RIGHT CAM, SMALLER		02
07	0503010003	1845 GREASE FITTING		02
08	0502012539	26Z P12,7 GEAR		01
09	0501019735	FLAT WASHER		01
10	0521017593	FLAT WASHER		01
11	0503010542	501045 CLAMPING RING (FOR AXLE)		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 CSPP G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01

LEFT SIDE TRANSMISSION ACTUATOR


0511047070




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0503019402	BEARING B207-22 V22 FRM		01
02	0503019403	PFL 207 FRM BEARING PLATE		02
03	0503010026	3/8" NUT		02
04	0503010025	3/8 SPRING WASHER		02
05	0501011643	3/8 X 1"BOLT		02




Item	Code	Description	See page	QT
01	0531052779	BEARING WITH 26Z GEAR	31	02
02	0591010685	3/4 X 2127 HEX AXLE		01
03	0591010683	3/4 X 2247 HEX AXLE		01
04	0591010684	3/4" X 63" HEX AXLE		01
05	0591010682	HEX AXLE 3/4 X 1120		01
06	0521056144	INTERMEDIATE SEED TRANSMISSION	33	02
07	0511063123	BUSHING WITH NUT		08
08	0501018535	1/2 X 1 BOLT		08
09	0581015056	SLEEVE		08




Item	Code	Description	See page	QT
01	0521055498	SEED TRANSMISSION DOUBLE BEARING	32	01
02	0531062897	26Z GEAR		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02
06	0501010694	FLAT WASHER		04
07	0503018441	5/16" X 1-1/4" BOLT		02




Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012858	502075 CLAMPING RING (FOR HOLE)		01
03	0503019373	6006 2RS1 NATIONAL BEARING		02




Item	Code	Description	See page	QT
01	0503010243	CLAMP		02
02	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
03	0503012880	1/4" UNC SELF ADJUSTING NUT		02
04	0503063012	SEED TRANSMISSION SHAFT HEX 3/4		01
05	0503034773	HOSE 1.1/2 X 1.1/2 X 120		01




Item	Code	Description	See page	QT
01	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
02	0503010019	1/2" SPRING WASHER		02
03	0503010060	1/2 UNC G.5 ZN HEX NUT		02
04	0561017281	ARTICULACION ARM		02
05	0531052780	DOUBLE BEARING WITH 22Z X 20Z GEAR	35	02
06	0521055217	LOWER CURRENT STRETCH	36	04
07	0521056134	STRETCHER FERTILIZER CURRENT 17Z	37	02
08	0521054446	LOWER CURRENT STRETCHER 21Z	38	02
09	0571019829	LEVER FIXER		02
10	0503010237	3/8" X 1" BOLT		06
11	0503010025	3/8 SPRING WASHER		06
12	0503010026	3/8" NUT		06
13	0571019830	LEVER FIXER		02
14	0503011312	ROTATIVE CABLE		02
15	0503030093	TRACTION SPRING		02
16	0561017273	FIXER SPRING		02
17	0561017282	LOWER LEVER		02
18	0561016797	SLEEVE UNION LEVER		02
19	0591010705	ARTICULATION SLEEVE		02
20	0503011082	C1/2" X 1.3/4" SCREW		02
21	0521010773	0.37" X 1.18" COUPLING SHAFT		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
23	0541014973	COUPLING SHAFT		02
24	0503010140	1/8" X 3/4" COTTERPIN		04
25	0503017874	BOLT 1/2 UNC		02
26	0503011336	1/2" HEX SELF ADJUSTING NUT		02
27	0503013065	40-1 X 159 CHAIN LINK + MENDING		02
28	0503016737	40-1 X 114 CHAIN LINK + REDUCION		02




Item	Code	Description	See page	QT
01	0503019356	BEARING 6005 2RS1		02
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0503012412	5/8" UNC SELF LOCKING NUT		01
04	0531062898	DOUBLE GEAR		01
05	0551019175	DOUBLE GEAR AXLE		01
06	0501010163	5/8" X 4-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503019355	BEARING 6202 2RS1		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	0591010693	CURRENT DEVIATION SLEEVE		01
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01



Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503019356	BEARING 6005 2RS1		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0501012140	FLAT WASHER		01
06	0581015136	40MM STRETCHING SHAFT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01
08	0501011541	5/8" X 3" BOLT		01




Item	Code	Description	See page	QT
01	0561019899	RIGHT GEARBOX FIXER SUPPORT		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8" UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2 UNC G.5 ZN HEX NUT		02



Item	Code	Description	See page	QT
01	0561019898	LEFT SUPPORT FIXER GEARBOX		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8" UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2 UNC G.5 ZN HEX NUT		02

LEFT GEAR BOX ASSY

0531052782



Item	Code	Description	See page	QT
01	0501048790	AXLE WITH RING	43	02
02	0551018209	DRIVING AXLE		01
03	0521018259	DRIVEN AXLE		01
04	0551018210	DRIVEN AXLE		01
05	0551018211	INTERM SHAFT		01
06	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	44	01
07	0503030303	SUPPORT WASHER		06
08	0501056443	GEAR HOUSING BEARING	45	02
09	0511059266	CLOSED BEARING	46	05
10	0503012389	1/2 BALL		04
11	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
12	0503010834	1/2 X 1 BOLT		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		06
14	0503031805	11Z 1/2" GEAR		04
15	0503010302	501019 SEAL RING		04
16	0511061830	17Z P 0.5" GEAR SQUARE HOL		03
17	0511067501	26Z GEAR		01
18	0521018630	1.4" X SQUARE 0.8" WASHER		05
19	0503010292	701164 6 X 40 SPRING PIN		10
20	0501054655	CHAIN TENSIONER ASSY	45	02
21	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
22	0503010256	3/8" X 3/4" BOLT		01
23	0503012204	40-1 CHAIN X 82 LINK + RED		02
24	0503012713	40-1 CHAIN X 45 LINK + MEN		01
25	0511060396	DRIVE/DRIVEN SHAFT		04
26	0511061822	25Z P0.5" GEAR SQUARE HOL		01
27	0502011758	REAR TIGHTENER LEVER		02
28	0531060029	LONGER CURRENT STRETCHER WITHOUT LUBRICATION		01
29	0503031367	SPRING		01
30	0503031366	RIGHT TWISTED SPRING		01
31	0531060008	LEFT EXCHANGE BODY WITHOUT LUBRICATION		01


LEFT GEAR BOX ASSY

0531052782

Item	Code	Description	See page	QT
32	0531060025	MINOR CHAIN STRETCHER WITHOUT LUBRICATION		01
33	0503019418	SLEEVE		04
34	0503011034	RING		04
35	0511059261	CHAIN TENSIONER	46	01
36	0591010679	19.4 / 19.6 X 26 BEARING		01
37	0503014734	BOLT		02
38	0503010019	1/2" SPRING WASHER		02

RIGHT GEAR BOX ASSY

0531052781




Item	Code	Description	See page	QT
01	0501048790	AXLE WITH RING	43	02
02	0551018209	DRIVING AXLE		01
03	0521018259	DRIVEN AXLE		01
04	0551018210	DRIVEN AXLE		01
05	0551018211	INTERM SHAFT		01
06	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	44	01
07	0503030303	SUPPORT WASHER		06
08	0501056443	GEAR HOUSING BEARING	45	02
09	0511059266	CLOSED BEARING	46	05
10	0503012389	1/2 BALL		04
11	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
12	0503010834	1/2 X 1 BOLT		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		06
14	0503031805	11Z 1/2" GEAR		04
15	0503010302	501019 SEAL RING		04
16	0511061830	17Z P 0.5" GEAR SQUARE HOL		03
17	0511067501	26Z GEAR		01
18	0521018630	1.4" X SQUARE 0.8" WASHER		05
19	0503010292	701164 6 X 40 SPRING PIN		10
20	0501054655	CHAIN TENSIONER ASSY	45	02
21	0591010679	19.4 / 19.6 X 26 BEARING		01
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
23	0503010256	3/8" X 3/4" BOLT		01
24	0503012204	40-1 CHAIN X 82 LINK + RED		02
25	0503012713	40-1 CHAIN X 45 LINK + MEN		01
26	0511060396	DRIVE/DRIVEN SHAFT		04
27	0511061822	25Z P0.5" GEAR SQUARE HOL		01
28	0502011758	REAR TIGHTENER LEVER		02
29	0531060029	LONGER CURRENT STRETCHER WITHOUT LUBRICATION		01
30	0503031367	SPRING		01
31	0503031366	RIGHT TWISTED SPRING		01


RIGHT GEAR BOX ASSY

0531052781


Item	Code	Description	See page	QT
32	0531060009	RIGHT EXCHANGE BODY WITHOUT LUBRICATION		01
33	0503019418	SLEEVE		04
34	0503011034	RING		04
35	0531060025	MINOR CHAIN STRETCHER WITHOUT LUBRICATION		01
36	0511059261	CHAIN TENSIONER	46	01
37	0503014734	BOLT		02
38	0503010019	1/2" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	23	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0503031805	11Z 1/2" GEAR		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	22	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531058970	SUPPORT WITH ALPHA FERTILIZER STRAIGHT 48 FERTILIZER SILO DOSER		01
02	0531058968	SUPPORT WITH SILO ALPHA FERTILIZER 49 CENTRAL FERTILIZER		01
03	0531058969	SUPPORT WITH ALPHA FERTILIZER LEFT 50 FERTILIZER SILO DOSER		01
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
05	0503010026	3/8" NUT		16
06	0503010849	3/8" X 1-1/2" BOLT		16
07	0503010025	3/8 SPRING WASHER		16
08	0503011957	NYLON HANDLE		02
09	0503010371	5/16" X 1" BOLT		04
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
11	0503010337	5/16" NUT		04
12	0521010572	0.9" X 2.9" COUPLING SHAFT		02
13	0503030085	LOCK PIN		02
14	0503062391	FERTILIZER HOPPER		03
15	0571019051	FIXER HOPPER WASHER		24
16	0503013751	3/8 UNC X 1.1/4 BOLT		24
17	0503012535	3/8" SPRING WASHER		24
18	0503012531	3/8" INOX NUT		24




Item	Code	Description	See page	QT
01	0531064872	RIGHT SUPPORT SILO FERTILIZER ALPHA		01
02	0501053788	3/4" SQUARE AXLE FASTENER	24	02
03	0531055319	ALPHA II FERTILIZER METERING	51	05
04	0503031527	AGRICULTURAL BEARING		02
05	0531057908	SLEEVE 1/4 X 2		04
05A	0502013069	SLEEVE 21 X 38 X 50		04
05B	0503010010	1/4" X 2.1/2" COTTERPIN		04
06	0501218663	AXIS 3/4 X 130		01
07	0501218664	AXIS 3/4 X 322		01
08	0501218487	3/4 X 390 AXLE		02
09	0531057978	SIDE BEARING WITH TRANSMISSION	56	01
10	0501056444	BEARING WITH ROLLER	23	01
11	0503011953	5/16" X 1" BOLT		02
12	0503013816	5/16" LOCKNUT		02
13	0521011039	FLAT WASHER		02
14	0501219795	AXIS 3/4 X 796		01



Item	Code	Description	See page	QT
01	0531064770	CENTRAL SUPPORT SILO		01
02	0531055319	ALPHA II FERTILIZER METERING	51	05
03	0501053788	3/4" SQUARE AXLE FASTENER	24	04
04	0503031527	AGRICULTURAL BEARING		04
05	0501218487	3/4 X 390 AXLE		01
06	0531057908	SLEEVE 1/4 X 2		03
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0531057978	SIDE BEARING WITH TRANSMISSION	56	02
08	0501218655	AXIS 3/4 X 460		02
09	0501219795	AXIS 3/4 X 796		01




Item	Code	Description	See page	QT
01	0531064873	LEFT SUPPORT SILO FERTILIZER ALPHA		01
02	0501053788	3/4" SQUARE AXLE FASTENER	24	02
03	0531055319	ALPHA II FERTILIZER METERING	51	05
04	0503031527	AGRICULTURAL BEARING		02
05	0531057908	SLEEVE 1/4 X 2		04
05A	0502013069	SLEEVE 21 X 38 X 50		04
05B	0503010010	1/4" X 2.1/2" COTTERPIN		04
06	0501218663	AXIS 3/4 X 130		01
07	0501218664	AXIS 3/4 X 322		01
08	0501218487	3/4 X 390 AXLE		02
09	0531057978	SIDE BEARING WITH TRANSMISSION	56	01
10	0503011953	5/16" X 1" BOLT		02
11	0503013816	5/16" LOCKNUT		02
12	0521011039	FLAT WASHER		02
13	0501056444	BEARING WITH ROLLER	23	01
14	0501219795	AXIS 3/4 X 796		01




Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	ASSY TRANSMISSION HUB	52	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	53	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513011170	ALLEN SCREW 1/4 UNC X 7/8 CCSI STAINLESS STEEL		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501310211	FRONT LID		01
19	0503036177	LID CORD		01
20	0531059139	ASSY COLLECTOR	54	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01

ASSY TRANSMISSION HUB

0531055863




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO ADHESIVE LABEL 41.5 X 29		01
15	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT GUIDE DOSING COVER		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01

ASSY COLLECTOR


0531059139




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	55	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007		01
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0501218530	SIDE BEARING SHAFT BODY		01
03	0503030119	LOCK PIN		01
04	0503010845	501035 CLAMPING RING (FOR AXLE)		01
05	0503010337	5/16" NUT		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0501010694	FLAT WASHER		02
08	0503010371	5/16" X 1" BOLT		02



Item	Code	Description	See page	QT
01	0531060446	HANDRAIL		01
02	0551019884	45 X 50 X 3/8 FASTENER		04
03	0503013357	3/8 SELF-ADJUSTING NUT		08
04	0503011082	C1/2" X 1.3/4" SCREW		08
05	0503010019	1/2" SPRING WASHER		12
06	0503010060	1/2 UNC G.5 ZN HEX NUT		12
07	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
08	0531060448	HANDRAIL		02
09	0571017991	CHAIN FIXER HANDRAIL		04
10	0503034094	22 TWISTED CHAIN		02




Item	Code	Description	See page	QT
01	0521067102	ARTICULATION CENTRAL PLATFORM	04	
02	0531062585	CENTRAL PLATFORM	01	
03	0503011336	1/2" HEX SELF ADJUSTING NUT	06	
04	0503010741	1/2" X 2-3/4" BOLT	06	
05	0521067100	LEFT PLATAFORM	01	
06	0521067104	LEFT SIDE ARTICULATION PLATFORM	01	
07	0521067101	RIGHT PLATAFORM	01	
08	0521067103	RIGHT SIDE ARTICULATION PLATFORM	01	
09	0581012193	PLATFORM AMENDMENT PROTECTION	02	
10	0551019115	LOCKING PLATFORM FIXATION	03	
11	0571019831	X 0.2" SLEEVE	03	
12	0501010096	3/8" X 2" BOLT	03	
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER	31	
14	0503013357	3/8 SELF-ADJUSTING NUT	03	
15	0503011333	COVER FIXER	04	
16	0503010274	5/32"X 2" COTTERPIN	04	
17	1902012740	PLATFORM RIGHT FIXER SUPPORT	02	
18	1902012739	PLATFORM LEFT FIXER SUPPORT	02	
19	0503010849	3/8" X 1-1/2" BOLT	12	
20	0503010025	3/8 SPRING WASHER	16	
21	0503010026	3/8" NUT	16	
22	0501010942	3/8" X 1-1/4" BOLT	04	




Item	Code	Description	See page	QT
01	0521057899	SUPPORT VALVE BLOCK VACUOMETER ASSY 5750/7350	60	01
02	0521057886	HOSE CLAMP ASSEMBLY	62	02
03	0581010324	HOSE PROTECTOR		01
04	0503010358	5/16" X 5/8" BOLT		04
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
06	0503010337	5/16" NUT		04
07	0503013493	T CONNECTION MALE		02
08	0521057259	OIL CONDUCTOR FIXATION	63	08
09	0531060538	OIL CONDUCTOR		04
10	0531060537	OIL CONDUCTOR		02
11	0531060540	OIL TUBE		02
12	0531060545	OIL DUCT 275 6350		02
13	0521057915	HOSE KIT HYDRAULIC SYSTEM 6 WHEEL		01
13A	0501082269	HOSE 1/2 X 300 TR-TR		04
13B	0501080087	1/2" X 450 HOSE		03
13C	0501080096	1/2 X 500 TC-TC HOSE		08
13D	0501081235	1/2 X 650 TR- TC HOSE		02
13E	0501080024	1/2" X 700 TR-TR HOSE		04
13F	0501080218	1/2 X 750 HOSE		02
13G	0501080093	1/2 X 1300 HOSE TR-TC		01
13H	0501080058	HOSE 1/2 X 1400 TR-TC		01
13I	0501081834	1/2 X 1500 TR-TC HOSE		02
13J	0521057243	1/2 X 4350 TC-TM HOSE BLACK / RED		01
13JA	0501082259	HOSE 1/2 X 4350 TC-TM		01
13JB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
13JC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
13JD	0503018952	PLASTIC BOLT		06
13K	0521057244	HOSE 1/2 X 4900 TC-TM BLACK / BLUE		01
13KA	0501082260	HOSE 1/2 X 4900 TC-TM		01
13KB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
13KC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01

Item	Code	Description	See page	QT
13KD	0503018952	PLASTIC BOLT		06
14	0521057704	SLIDING SUPPORT HYDRAULIC HOSE	64	04
15	0581010091	SPRING PROTECTION PLASTIC HOSE		01
16	0581012991	SPRING PROTECTION PLASTIC HOSE		01
17	0501053834	MALE QUICK COUPLER	65	02
18	0581010090	SPRING PROTECTION PLASTIC HOSE		02
19	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		01




Item	Code	Description	See page	QT
01	0503062960	COMMAND BLOCK		01
02	0591013473	VACUOMETER GUIDE SCREW BOLT		02
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0503010026	3/8" NUT		02
05	0503010025	3/8 SPRING WASHER		02
06	0502011170	FIXER		02
07	0503010384	1/2" X 5" BOLT		04
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
09	0503010589	1/2" UNC SELF ADJUSTING NUT		04
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
11	0503015114	BOLT		04
12	0531060808	SUPPORT FIXING VALVE TRIPLE BLOCK		01
13	0521057855	CASAPPA DIVIDER VALVE WITH FIXING NIPLES	61	01
14	0591014208	HYDRAULIC BLOCK SUPPORT SLEEVE		02



Item	Code	Description	See page	QT
01	0503019548	FLOW DIVIDER VALVE		01
02	0501010590	NIPPLE		03
03	0503010026	3/8" NUT		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0511018014	7/8"NF X 1.1/16 UN NIPPLE		01
08	0503010045	O'RING		03
09	0503011109	2-119 N 3006-9B O'RING		01

HOSE CLAMP ASSEMBLY


0521057886




Item	Code	Description	See page	QT
01	0502010477	HOSE CLAMP		02
02	0502012702	BODY SUPPORT CLAMP		01
03	0503010718	3/8" X 3-1/2" BOLT		01
04	0503010026	3/8" NUT		01
05	0503010025	3/8 SPRING WASHER		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01

OIL CONDUCTOR FIXATION


0521057259




Item	Code	Description	See page	QT
01	0591012302	LOWER CLAMP FIXING OIL CONDUCTOR		01
02	0591012301	TOP CLAMP FIXING OIL CONDUCTOR		01
03	0503010025	3/8 SPRING WASHER		03
04	0503010026	3/8" NUT		03
05	0561017277	OIL CONDUCTOR FIXER PLATE		01
06	0521010718	5/8" U BOLT		01
07	0501012140	FLAT WASHER		02
08	0503010027	5/8 SPRING WASHER		02
09	0503010013	5/8 NUT		02
10	0501011755	3/8" X 3" BOLT		02
11	0502010477	HOSE CLAMP		02
12	0501010096	3/8" X 2" BOLT		01




Item	Code	Description	See page	QT
01	0591012962	SLIDING SUPPORT BODY HYDRAULIC HOSE		01
02	0591012961	16,30 X 30 X 230 SLEEVE		01
03	0591012963	HOSE SLEEVE FIXING AXLE		01
04	0503010013	5/8 NUT		02
05	0501012140	FLAT WASHER		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010071	3/16" X 1" COTTERPIN		02




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01



Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		04
02	0503010237	3/8" X 1" BOLT		08
03	0503010025	3/8 SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0511069636	LADDER		02
06	0503011179	3/8" X 2-1/4" BOLT		04
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
08	0503013357	3/8 SELF-ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0502011530	SUPPORT		02
02	0502010175	HITCH CLAMP		02
03	0501011543	5/8" X 4" BOLT		04
04	0503012412	5/8" UNC SELF LOCKING NUT		04
05	0501069951	PLOUGH SUPPORT		04
06	0501011075	PIN		02
07	0503030012	HITCH PIN CLIP		02




Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01

TRACTION SPRING ASSY

0511059494




Item	Code	Description	See page	QT
01	0503013030	5/8" X 3.1/4" BOLT		02
02	0511050681	TRACTION SPRING		01
02A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
02B	0561016062	SPRING HITCH		02
03	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521057131	CENTRAL TURBINE MOUNTED WITH CSU SUPPORT	71	01
02	0521056143	RIGHT SIDE AIR DISTRIBUTOR	74	01
03	0521056112	LEFT SIDE AIR DISTRIBUTOR	75	01
04	0521057135	CENTRAL AIR DISTRIBUTOR 1978	76	01
05	0581012184	HOSE 4 X 250		02
06	0511015569	HOSE		02
07	0501082282	SEED CONDUCTOR 1.1/2 X 2000		15
08	0521052549	CLAMP	77	30
09	0503011372	102 TO 121 CLAMP		08
10	0591012114	SUPPORT WITH FOLDING FIXATION AIR DUCT CSU		02
11	0503010026	3/8" NUT		24
12	0503010025	3/8 SPRING WASHER		24
13	0503010237	3/8" X 1" BOLT		04
14	0571019403	STAPLE FIXER		06
15	0501013518	FLAT WASHER		12
16	0591012113	STRAIGHT SUPPORT FIXING AIR DUCT		04
17	0501010942	3/8" X 1-1/4" BOLT		08
18	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
19	0501053834	MALE QUICK COUPLER	65	02
20	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	78	01
21	0521057109	1/2 X 7000 TR-TM HOSE YELLOW / BLUE		01
21A	0501082007	HOSE 1/2 X 7000 TR-TM		01
21B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06
22	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
22A	0501080477	HOSE 3/8 X 7012 TC-TM		01
22B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
22C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01


Item	Code	Description	See page	QT
22D	0503018952	PLASTIC BOLT		06
23	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
23A	0501081247	HOSE 1/2 X 7012 TC-TM		01
23B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
23C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
23D	0503018952	PLASTIC BOLT		06
24	0581012991	SPRING PROTECTION PLASTIC HOSE		01
25	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
26	0581011173	SPRING PROTECTION PLASTIC HOSE		02
27	0503033981	ADHESIVE LABEL		01
28	0521057289	VACUOMETER FIXING SUPPORT CSU	79	01




Item	Code	Description	See page	QT
01	0521056673	TURBINE P.P CSC	72	01
02	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
03	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
04	0503010190	2-114 N 3006-9B O'RING		02
05	0501011460	7/8 NF REDUCTION NIPPLE		02
06	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
07	0503010143	1/4" SPRING WASHER		02
08	0503010144	1/4" NUT		02
09	0503010305	FLAT WASHER		02
10	0501082254	HOSE 1/2 X 210 TC-TC		01
11	0503015114	BOLT		02
12	0591012425	CENTRAL SUPPORT FIXING TURBINE		01
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04




Item	Code	Description	See page	QT
01	0521050154	PRECISION PLANTING TURBINE WITH HOLE	73	01
02	0501011460	7/8 NF REDUCTION NIPPLE		02
03	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
04	0503010392	2-046 N 3006 9B O'RING		01
05	0503010190	2-114 N 3006-9B O'RING		02
06	0581012096	ROUND SLEEVE		02
07	0503031087	ADHESIVE LABEL		01
08	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01



Item	Code	Description	See page	QT
01	0591010690	CONDUCTOR BODY AIR 5 MOUTH 1650 5 HOLES		01
02	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		05
02A	0503034812	SOCKET DISTRIBUTOR AR		01
02B	0503012856	POP RIVET		04
03	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
03A	0503034763	AIR DITRIBUTOR PUMP		01
03B	0503015341	POP RIVET		02
04	0503017845	90 PVC KNEE		01
05	0581013890	AIR DISTRIBUTOR SOCKET		01




Item	Code	Description	See page	QT
01	0591010690	CONDUCTOR BODY AIR 5 MOUTH 1650 5 HOLES		01
02	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		05
02A	0503034812	SOCKET DISTRIBUTOR AR		01
02B	0503012856	POP RIVET		04
03	0521056049	AIR DISTRIBUTOR CAP WITH RIVET		01
03A	0503034763	AIR DITRIBUTOR PUMP		01
03B	0503015341	POP RIVET		02
04	0503017845	90 PVC KNEE		01
05	0581013890	AIR DISTRIBUTOR SOCKET		01




Item	Code	Description	See page	QT
01	0503012567	T-JOIN FOR TUBE 110		02
02	0581013890	AIR DISTRIBUTOR SOCKET		04
03	0503017845	90 PVC KNEE		04
04	0571019146	110 X 130 GLOVE		02
05	0591012118	AIR CONDUCTOR BODY		01
06	0521056048	AIR DISTRIBUTOR NOZZLE 1.1 / 2 WITH RIVET		05
06A	0503034812	SOCKET DISTRIBUTOR AR		01
06B	0503012856	POP RIVET		04
07	0581019586	AIR CONDUCTOR BODY 1 MOUTH 268 04 HOLES		02

CLAMP


0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0503018799	QUICK COUPLING		01
02	0503011883	QUICK CONNECTION COVER		01




Item	Code	Description	See page	QT
01	0591012157	VACUOMETER FIXATION		01
02	0503013584	VACUUM GAUGE		01




Item	Code	Description	See page	QT
01	0521051730	ASSY FIXING SUPPORT	81	02
02	0511057755	ASSEMBLY CSU 6850	82	01
03	0521057149	ASSY RIGHT FIXING SUPPORT	84	02
04	0521057151	FIXING SUPPORT LEFT ASSY	85	02




Item	Code	Description	See page	QT
01	0531060573	FIXING SUPPORT CSU		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
07	0503010025	3/8 SPRING WASHER		04
08	0503010026	3/8" NUT		04



Item	Code	Description	See page	QT
01	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		03
02	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		03
03	0521063401	FIXING LOCK		06
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
05	0503010025	3/8 SPRING WASHER		78
06	0503010026	3/8" NUT		78
07	0511057690	3" ARTICULATED SEED CONDUCTOR	83	15
08	0501010942	3/8" X 1-1/4" BOLT		60
09	0501011643	3/8 X 1" BOLT		12
10	0571015773	SUPPORT SEED		03




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID	01	
02	0501010942	3/8" X 1-1/4" BOLT	01	
03	0503010025	3/8 SPRING WASHER	01	
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER	01	
05	0503010209	3/8" UNC BUTTERFLY NUT	01	
06	0521066332	CONDUCTOR WITH FLANGE	01	
07	0503010371	5/16" X 1" BOLT	02	
08	0501010694	FLAT WASHER	02	
09	0503010179	LOCK WASHER 5/16 ZN 1K01528	02	
10	0503010337	5/16" NUT	02	
11	0502012767	SEED NOZZLE FIXER SUPPORT	01	



Item	Code	Description	See page	QT
01	0531060480	RIGHT FIXING SUPPORT CSU		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
07	0503010025	3/8 SPRING WASHER		04
08	0503010026	3/8" NUT		04

FIXING SUPPORT LEFT ASSY


0521057151




Item	Code	Description	See page	QT
01	0531060485	FIXING SUPPORT LEFT CSU		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
07	0503010025	3/8 SPRING WASHER		04
08	0503010026	3/8" NUT		04



Item	Code	Description	See page	QT
01	0503034963	ADHESIVE LABEL		01
02	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		03
03	0503031565	ADHESIVE LABEL CARE		02
04	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
05	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
06	0503032930	ADHESIVE LABEL DANGER		04
07	0503031425	ADHESIVE LABEL ATTENTION		02
08	0503031087	ADHESIVE LABEL		01
09	0503031942	ADHESIVE LABEL		01
10	0503031669	ADHESIVE LABEL		01
11	0503031546	ADHESIVE LABEL TABLE FERTILIZER P2		02
12	0503034249	ADHESIVE LABEL TABLE PLANTS		02
13	0503033424	DIRECT PLANTIO ADHESIVE LABEL		02
14	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
15	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
16	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING		02
17	0503033422	ADHESIVE LABEL		02
18	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		04
19	0503034078	LIFTING POINTS DECAL		03
20	0503032979	ADHESIVE LABEL LETTERS A B C D		02
21	0503032949	ADHESIVE LABEL		01
22	0503031428	READ MANUAL DECAL		01
23	0503034500	ADHESIVE LABEL		01
24	0521056998	ALUMINUM IDENTIFICATION LABEL WITH RIVET		01
24A	0503034003	SERIAL NUMBER TAG 61 X 118		01
24B	0503010001	3.2 X 5.5 RIVET		04
25	0503034967	ADHESIVE LABEL (190 X 720)		04
26	0503034966	ADHESIVE LABEL (185 X 320)		03




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		17
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		03
04	0503012903	T-80M CRAMP NYLON		50
05	0521053672	LIGHTHOUSE ASSY	88	02
06	0521052792	MOUNTED REAR LIGHT	89	01
07	0503015907	MALE TERMINAL		02
08	0503015908	FEMALE TERMINAL		02
09	0503015906	TWO-WAY MALE CONNECTOR		01
10	0503015905	TWO-WAY FEMALE MALE CONNECTOR		01
11	0503015911	CABLE SEAL		04
12	3505151602	TUBE		01
13	0503017702	FIXER		03




Item	Code	Description	See page	QT
01	0581015856	REDLIGHT SUPPORT		01
02	0503018738	HEADLIGHT		01
03	0501010694	FLAT WASHER		02
04	0503010358	5/16" X 5/8" BOLT		02
05	0551019884	45 X 50 X 3/8 FASTENER		02
06	0503013357	3/8 SELF-ADJUSTING NUT		04
07	0503010337	5/16" NUT		02
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		02

MOUNTED REAR LIGHT

0521052792




Item	Code	Description	See page	QT
01	0503018738	HEADLIGHT		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
08	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0531055259	SUPPORT WITH LEFT ENGINE	91	03
02	0502012623	UPPER BODY HOSE CLAMP 3/4		06
03	0503011179	3/8" X 2-1/4" BOLT		03
04	0501013518	FLAT WASHER		05
05	0503010025	3/8 SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0503010237	3/8" X 1" BOLT		03
08	0501214233	SUPPORT HOSE GUIDE		03
09	0531050693	MODULE BOX	92	01
10	0531050811	APT FILTER SUPPORT	94	01
11	0571016236	HIDRAULIC ADAPTER		01
12	0503012341	7/8" T ADAPTER		01
13	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
14	0503011053	5/16" X 3" C S 6.5 ZN BOLT		02
15	0503010337	5/16" NUT		02
16	0501213673	VALVE SUPPORT		01
17	0531063860	OIL DISTRIBUTOR		01
18	0503013055	"T" ADAPTOR WITH GIRAT NUT		01
19	0503011404	BOLT		02
20	0521069589	POSITION SENSOR SUPPORT		01
21	0503011135	BOLT		02
22	0503010244	7/16" NUT		02
23	0503010180	7/16" SPRING WASHER		02
24	0503013356	RIVET POP 3.2 X 10,0		01
25	0581018875	SENSOR DRIVER		01
26	0531050763	FIXING OIL CONDUCTORS SET FOR 5 TUBES	95	04
27	0531060540	OIL TUBE		04
28	0501053834	MALE QUICK COUPLER	65	02
29	0531058962	HOSE SET APT 6 CHANNELS		01
29A	0521052519	HOSE 1/2 X 4200 TC-TM GRAY / RED		01
29AA	0501081073	HOSE 1/2 X 4200 TC-TM		01


Item	Code	Description	See page	QT
29AB	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
29AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
29AD	0503018952	PLASTIC BOLT		06
29B	0521056363	HOSE 1/2 X 4800 TR-TM GRAY/BLUE		01
29BA	0501080038	HOSE 1/2 X 4800 TR-TM		01
29BB	0503034489	HYDRAULIC HOSE GAUNTLET (GRAY)		01
29BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
29BD	0503018952	PLASTIC BOLT		06
29C	0501080239	HOSE 1/2 X 350 TR-TC		01
29D	0501082057	HOSE		01
29E	0501080811	HOSE 1/2 X 900 TC-TC 90G RIGHT		01
29F	0501080060	1/2" X 63" TR-TC HOSE		01
29G	0501080282	HOSE 1/2		01
29H	0501080173	HOSE 1/2 X 1650 TR-TR		01
29I	0501080293	HOSE 1/2 X 800 TC-TC		01
29J	0501080603	HOSE		01
29K	0501080250	HOSE		01
29L	0501080173	HOSE 1/2 X 1650 TR-TR		01
29M	0501080282	HOSE 1/2		01
29N	0501080058	HOSE 1/2 X 1400 TR-TC		01
29O	0501080825	1/2" X 1100 TR-TC HOSE		01
30	0503018033	37 X R.7/8 UNF 90° JIC MALE CONNECTOR WITH ROTATING NUT		06
31	0503062754	GEAR 34Z P.1/2 APT		03
32	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
33	0503010019	1/2" SPRING WASHER		03
34	0503010060	1/2 UNC G.5 ZN HEX NUT		03
35	0503030402	PULLEY		03
36	0531019479	AXLE CHAIN GEAR		03
37	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
38	0531058974	LEFT ENGINE COVER	96	01
39	0501111116	MOTOR GEAR		03
40	0531058973	ENGINE RIGHT PROTECTION COVER	97	01
41	0503014626	40-1 CHAIN X 55 LINK + MENDING		01
42	0531058972	ENGINE RIGHT PROTECTION COVER	98	01



Item	Code	Description	See page	QT
01	0501214235	SEED MOTOR PLATE	01	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8 SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0503010811	5/8" UNF SELF ADJUSTING NUT	02	
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN	01	
07	0503010019	1/2" SPRING WASHER	03	
08	0503010060	1/2 UNC G.5 ZN HEX NUT	03	
09	0503030402	PULLEY	01	
10	0531019479	AXLE CHAIN GEAR	01	
11	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN	02	
12	0501214234	SEED MOTOR CAP	01	
13	0503019901	INTERNAL THREAD RIVET RM 1/4 P30S	03	
14	0503013813	1/4" UNC X 7/8" BOLT	02	
15	0503010143	1/4" SPRING WASHER	02	
16	0503010305	FLAT WASHER	02	
17	0501111116	MOTOR GEAR	01	
18	0503015162	M 8 X 1,25 X 20 BOLT	01	
19	0503017960	5/8" X 3-12" BOLT	02	
20	0531060590	HYDRAULIC MOTOR SUPPORT	01	
21	0502010175	HITCH CLAMP	01	
22	0501012140	FLAT WASHER	02	
23	0531063551	GEAR 25Z HEXAGONAL 20	01	
24	0511054314	TRANSMISSION AXLE LOCK SLEEVE	02	
24A	0502012699	TRANSMISSION HUB LOCK SLEEVE	02	
24B	0503010256	3/8" X 3/4" BOLT	02	
25	0503012142	40-1 CHAIN X 61 LINK + MENDING	01	
26	0503013849	1/4" UNC X 3/4" BOLT	01	




Item	Code	Description	See page	QT
01	0511059348	APT ASSY MODULE BOX	93	01
02	0521069584	BOX SUPPORT		02
03	0581019503	3/8" FASTENER		02
04	0503015135	FLAT WASHER 10 X 18 X 2		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04



Item	Code	Description	See page	QT
01	0521066834	MODULE BOX		01
02	0503018171	FAST LOCK ASSY		02
03	0521066833	BOX COVER		01
04	0571012006	COVER PIVOT SHAFT		01
05	0571012005	SUPPORT GUIDE ASSY		01
06	0501010694	FLAT WASHER		03
07	0503010257	1/8" X 1" COTTERPIN		02
08	0511017303	FLAT WASHER		10
09	0503010298	1/4" X 1/2" BOLT		04
10	0503010143	1/4" SPRING WASHER		10
11	0503010294	1/4" X 7/8" BOLT		06
12	0503010144	1/4" NUT		06
13	0501011643	3/8 X 1" BOLT		04
14	0503010025	3/8 SPRING WASHER		04
15	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
16	0503010026	3/8" NUT		04

APT FILTER SUPPORT


0531050811



Item	Code	Description	See page	QT
01	0591017488	APT FILTER SUPPORT		01
02	0581019503	3/8" FASTENER		02
03	0503015135	FLAT WASHER 10 X 18 X 2		04
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04

FIXING OIL CONDUCTORS SET FOR 5 TUBES


0531050763




Item	Code	Description	See page	QT
01	0581018415	PROTECTION BODY		02
02	0503010025	3/8 SPRING WASHER		03
03	0503010026	3/8" NUT		03
04	0561017277	OIL CONDUCTOR FIXER PLATE		01
05	0521010718	5/8" U BOLT		01
06	0501012140	FLAT WASHER		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02
09	0501011755	3/8" X 3" BOLT		02
10	0502010477	HOSE CLAMP		02
11	0501010096	3/8" X 2" BOLT		01

LEFT ENGINE COVER


0531058974




Item	Code	Description	See page	QT
01	0501215596	LEFT PROTECTION CASE		01
02	0503019901	INTERNAL THREAD RIVET RM 1/4 P30S		03
03	0503013849	1/4" UNC X 3/4" BOLT		02
04	0503010143	1/4" SPRING WASHER		02
05	0503010305	FLAT WASHER		02
06	0501212320	ENCODER LOCK SCREW		01




Item	Code	Description	See page	QT
01	0501215594	RIGHT PROTECTION CASE		01
02	0503019901	INTERNAL THREAD RIVET RM 1/4 P30S		03
03	0503013849	1/4" UNC X 3/4" BOLT		02
04	0503010143	1/4" SPRING WASHER		02
05	0503010305	FLAT WASHER		02
06	0501212320	ENCODER LOCK SCREW		01




Item	Code	Description	See page	QT
01	0501215595	RIGHT PROTECTION CASE		01
02	0503019901	INTERNAL THREAD RIVET RM 1/4 P30S		03
03	0503013849	1/4" UNC X 3/4" BOLT		02
04	0503010143	1/4" SPRING WASHER		02
05	0503010305	FLAT WASHER		02
06	0501212320	ENCODER LOCK SCREW		01




Item	Code	Description	See page	QT
01	0503063387	15 ROWS ISO6 INTELLIAG KIT		01
01A	0503019526	CONTROL MODULE ISO6 6CH ADV		01
01B	0503019384	CABLE CTRL MASTER MODULE		01
01C	0503015071	CONNECTOR		01
01D	0503019386	MODULES "C"		01
01E	0503019385	WHIP ELETTRIC		01
01F	0503019616	EXTENSION CABLE		06
01G	0503019617	EXTENSION CABLE		06
01H	0513010023	EXTERNAL LIFTING CABLE		01
01I	0503017443	ANTENNA GPS PM 400		01
01J	0503017031	CLEANING BRUSH		01
01K	0503015218	SENSOR FOTOELE PM 400		15
01L	0503019685	CABLE ISO CONNECTION TRACTOR 8,0 MT 020011353		01
01M	0503016561	15 ROW SIMPLE MONITOR CABLE		01
02	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	100	06
03	0511056972	FILTER HYDAC	101	01
04	0503019291	SUPPORT SENSOR		01
05	0521054490	FLOW DIVIDING VALVE ASSY	102	01
06	0503013100	NYLON CLAMP		75
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		**



Item	Code	Description	See page	QT
01	0513010049	MOTOR OMP X 80 EMD - 11185907		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02




Item	Code	Description	See page	QT
01	0503063151	PRESSURE FILTER MFM HYDAC 1319024BR		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	7/8" T ADAPTER		01
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02



Item	Code	Description	See page	QT
01	0503016227	FLOW DIVIDING VALVE		01
02	0503013917	O'RING 2-224		03
03	0571013917	7/8"NF X 1.1/16 UNF NIPPLE		03

HEADER ASSY ASSEMBLY

0909095745




Item	Code	Description	See page	QT
01	0521066289	5750/6350/6850 FRONT DRAWBAR		01
02	0531060570	INTERMEDIATE HEADER 5750/6850		01
03	0571019949	JUNCTION SHAFT		06
04	0503030119	LOCK PIN		10
05	0521045756	HYDRAULIC CYLINDER	104	01
06	0521010779	31.75 X 95 COUPLING SHAFT		01
07	0521010581	0.9" X 4.9" COUPLING SHAFT		01
08	0503030085	LOCK PIN		06
09	0531016049	FLAT WASHER		02
10	0521050573	EXTENSOR 3RD POINT	105	01
11	0571019951	JUNCTION SHAFT		02
12	0503010523	1/4" X 2" SPLIT PIN		04
13	0511055096	TRACTOR HITCH	106	01
14	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
15	0511053179	TRACTOR COUPLING SHAFT	107	01
16	0521057452	ASSY INTERMEDIATE DRAWBAR FIXATION SUPPORT	108	04
17	0521050574	EXTENSOR	109	02
18	0521050133	TURNBUCKLE SIDE 755/480	110	02
19	0571019950	COUPLING SHAFT		01
20	0521018532	1.4" X 12" COUPLING SHAFT		01
21	0521050693	ASSEMBLY SET HOSE CYLINDER FRONT HEAD		01
21A	0521050692	HOSE KIT CYLINDER HEAD FRONT		01
21AA	0521052310	HOSE 1/2 X 4500 TM-TM GREEN / RED		01
21AAA	0501081929	HOSE 1/2 X 4500 TM-TM		01
21AAB	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
21AAC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21AAD	0503018952	PLASTIC BOLT		06
21AB	0521052309	HOSE 1/2 X 4500 TM-TM GREEN / BLUE		01
21ABA	0501081929	HOSE 1/2 X 4500 TM-TM		01
21ABB	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
21ABC	0503034495	HYDRAULIC HOSE GRIP (RED)		01


HEADER ASSY ASSEMBLY

0909095745

Item	Code	Description	See page	QT
21ABD	0503018952	PLASTIC BOLT		06
21B	0501053834	MALE QUICK COUPLER	65	04
22	0503014321	CABLE STEEL SHACKLE		02
23	0503014120	CHAIN		01
24	0521056993	ASSY WATER RESERVOIR	111	01
25	0521056994	ASSY TOOL CHEST	112	01
26	0503019262	SOAP DISH VACUUM		01
27	0521010571	COUPLING SHAFT		04




Item	Code	Description	See page	QT
01	0511057653	HYDRAULIC CYLINDER		01
02	0501053835	FEMALE QUICK COUPLER		02




Item	Code	Description	See page	QT
01	0511061880	SIDE RIGHT RATCHET		01
02	0531010264	SIDE RATCHET		01
03	0511061881	RATCHET FOLLOWER		01
04	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
05	0503011179	3/8" X 2-1/4" BOLT		05
06	0503011443	3/8" SPRING WASHER		05
07	0503010026	3/8" NUT		05
08	0503010002	1800 GREASE FITTING		02
09	0503030012	HITCH PIN CLIP		01
10	0502012783	STABILIZER BODY GREATER		01
11	0521067623	FUSE 713 EXTENSION RIGHT 3RD POINT		01
12	0521067622	FUSE 470 EXTENSION LEFT 3RD POINT		01

TRACTOR HITCH


0511055096




Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	LEFT COMPRESSION SPRING		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0521067716	FIXER TUBE		01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503016485	BOLT 3/4		04
04	0503010152	3/4" SELF LOCKING NUT		04
05	0501010322	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521066300	RIGHT TURNBUCKLE		01
02	0503010002	1800 GREASE FITTING		02
03	0521066301	LEFT TURNBUCKLE		01
04	0541018672	COUNTERNUT		01
05	0502011195	ADJUSTMENT NUT BODY		01



Item	Code	Description	See page	QT
01	0521065193	TURNBUCKLE AXLE		01
02	0521067392	FIXED BRACKET		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03




Item	Code	Description	See page	QT
01	0503014820	BLACK WATER RESERVOIR		01
02	0521068651	SUPPORT BOX		01
03	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		02
04	0503010025	3/8 SPRING WASHER		02
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521068652	TOOLS BOX SUPPORT		01
02	0503011334	BOLT 3/8 UNC X 3/4 CS G.5 ZN		02
03	0503010025	3/8 SPRING WASHER		06
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
05	0501011643	3/8 X 1"BOLT		04
06	0503010026	3/8" NUT		04
07	0503034772	BOX		01
08	0581017000	PLATE INTERMEDIARY		02

GEARBOX COMPONENT BOX


0909096759




Item	Code	Description	See page	QT
01	0501010780	AXLE SQUARE 3/4 X 840		02
02	0501053788	3/4" SQUARE AXLE FASTENER	24	06
03	0501056451	BEARING	114	04
04	0501214268	SQUARE AXLE 3/4 X 1110		03
05	0501215618	SQUARE AXLE 3/4 X 128 ALPHA		02
06	0511061759	22Z P12,70 FQ 3/4" GEAR		02
07	0521063187	GEAR 22Z P.1/2 (Q.19,2)		06
08	0531055898	CHAIN TIGHTENER	115	04
09	0501215677	3/4 X 690 QUADRATE AXLE		01
10	0531055896	80 INTERMEDIATE TRANSMISSION BEARING ASSEMBLED	116	02
11	0503010002	1800 GREASE FITTING		01
12	0503010733	1/4" X 1-3/4" BOLT		06
13	0503012880	1/4" UNC SELF ADJUSTING NUT		06
14	0503012761	40-1 CHAIN X 52 LINK + REDUCTION		04
15	0503011953	5/16" X 1" BOLT		04
16	0503031527	AGRICULTURAL BEARING		04
17	0521011039	FLAT WASHER		02
18	0521014167	CONE LOCK		10
19	0521018630	1.4" X SQUARE 0.8" WASHER		04
20	0591010679	19.4 / 19.6 X 26 BEARING		02
21	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
22	0503012880	1/4" UNC SELF ADJUSTING NUT		08




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501215149	CHAIN STRETCH AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0501056451	BEARING	114	01
02	0503031527	AGRICULTURAL BEARING		01
03	0521063187	GEAR 22Z P.1/2 (Q.19,2)		01
04	0503012880	1/4" UNC SELF ADJUSTING NUT		01
05	0521011039	FLAT WASHER		06
06	0503011953	5/16" X 1" BOLT		06
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
08	0503010337	5/16" NUT		06
09	0503010733	1/4" X 1-3/4" BOLT		01
10	0501215084	80 INTERMEDIATE TRANSMISSION BEARING BODY		01
11	0501215144	3/4 X 105 QUADRATE AXLE		01
12	0521014167	CONE LOCK		01




Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01



Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		15
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		15
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0503030331	1.2" X 1.2" X 12.2" HOSE		01
02	0503010243	CLAMP		02
03	0503062755	TRANSMISSION AXLE		01
04	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0521056240	FRONT SHORT ROW	121	01
02	0521056241	FRONT LONG ROW	122	01
03	0521056941	RIGHT REAR P.P CSU TRANSMISSION/CABLE	124	01
04	0521056940	LEFT REAR P.P CSU TRANSMISSION CABLE	125	01
05	0521054984	DEPTH/COMPACTOR SYSTEM - SPT	135	01
06	0521056069	SEMI-ASSEMBLED SHORT FERTILIZER ROW	146	01
07	0521056066	SEMI-ASSEMBLED LONG FERTILIZER ROW	147	01
08	0521051447	FRONT ASSY ROW BEARING	151	01
09	0531060405	EXTENSION		01
10	0531050181	ASSY JOINT TCE	152	01
11	0531050182	ASSY JOINT TCE	153	01
12	0531051830	ASSY JOINT TCE 1441	154	01
13	0521056844	SCARIFIER ROD	157	01
14	0503031145	2" X 2" X 20" HOSE		01
15	0503031076	2" HOSE CLAMP		01
16	0531059866	SEED CONDUCTOR RIGHT 3 X 1300		01
16A	0501311187	RIGHT SEED CONDUCTOR 3 X 1300		01
16B	0501311187	RIGHT SEED CONDUCTOR 3 X 1300		01
16C	1164930001	BLACK VINYL TUBE 3.1/2		01
16D	1164930001	BLACK VINYL TUBE 3.1/2		01
17	0531050237	SEED CONDUCTOR FIXER 3 CSU RIGHT	159	01
18	0503031050	CURVED CONDUCTOR		01
19	0503010246	CLAMP		01
20	0531061786	SEED ROW PRESSURE REGULATING LEVER		01
21	0521068982	DISC BLADE HUB KEY		01
22	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
23	0531052349	CURRENT GUIDE ASSEMBLY	155	01

FRONT SHORT ROW


0521056240




Item	Code	Description	See page	QT
01	0503019273	AUTO LUBRICANT SLEEVE	08	
02	0591011316	SEED ROW SUPPORT SLEEVE	08	
03	0531060069	TOP ARM	01	
04	0531062744	FRONT LOWER ARM SHORT SEED ROW	01	
05	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
06	0531060077	PRESSURE REGULATOR	01	
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	02	
08	0591010915	SPRING REGULATOR	01	
09	0591010914	LOWER AXLE	01	
10	0591011315	SPRING AXLE	01	
11	0503010045	O'RING	08	
12	0503010131	3/16" X 1-1/2" COTTERPIN	01	
13	0503030168	HITCH PIN CLIP	01	
14	0531060068	REAR ROW	01	
15	0503019295	SCREW 5/8 UNF X 7 CS RP G.5 ZN	04	
16	0502010175	HITCH CLAMP	02	
17	0503017857	BOLT 5/8 UNF 4	04	
18	0501012140	FLAT WASHER	04	
19	0531060073	FRONT ROW SUPPORT	01	
20	0521010542	COUPLING SHAFT	01	
21	0503010300	5/32" X 1" COTTERPIN	01	
22	0591010913	TRANSPORT BUMPER	01	
23	0501010301	FLAT WASHER	04	
24	0503010878	5/8" SELF ALIGNING NUT	04	
25	0503030012	HITCH PIN CLIP	01	
26	0571016296	FLAT WASHER	04	
27	0531052956	ASSEMBLY SEED ROW TRANSMISSION FIXING 123 BEARING	01	




Item	Code	Description	See page	QT
01	0503019273	AUTO LUBRICANT SLEEVE	08	
02	0591011316	SEED ROW SUPPORT SLEEVE	08	
03	0531060069	TOP ARM	01	
04	0531060070	LOWER ARM	01	
05	0503010811	5/8" UNF SELF ADJUSTING NUT	08	
06	0531060077	PRESSURE REGULATOR	01	
07	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING	02	
08	0591010915	SPRING REGULATOR	01	
09	0591010914	LOWER AXLE	01	
10	0591011315	SPRING AXLE	01	
11	0503010045	O'RING	08	
12	0503010131	3/16" X 1-1/2" COTTERPIN	01	
13	0503030168	HITCH PIN CLIP	01	
14	0531060068	REAR ROW	01	
15	0503019295	SCREW 5/8 UNF X 7 CS RP G.5 ZN	04	
16	0531060073	FRONT ROW SUPPORT	01	
17	0521010542	COUPLING SHAFT	01	
18	0503010300	5/32" X 1" COTTERPIN	01	
19	0591010913	TRANSPORT BUMPER	01	
20	0501010301	FLAT WASHER	04	
21	0531060072	EXTENDER	01	
22	0502010175	HITCH CLAMP	02	
23	0503017857	BOLT 5/8 UNF 4	04	
24	0501012140	FLAT WASHER	08	
25	0503012798	5/8" X 2" BOLT	04	
26	0503010878	5/8" SELF ALIGNING NUT	04	
27	0503030012	HITCH PIN CLIP	01	
28	0571016296	FLAT WASHER	04	
29	0531052956	ASSEMBLY SEED ROW TRANSMISSION FIXING 123 BEARING	01	




Item	Code	Description	See page	QT
01	0531060071	BEARING		01
02	0551015804	BEARING AXLE BODY		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02
07	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
08	0503012880	1/4" UNC SELF ADJUSTING NUT		02
09	0503019373	6006 2RS1 NATIONAL BEARING		01
10	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0521056955	RIGHT DDD ASSY	126	01
02	0503062403	TUBE SEED P.P		01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0521056956	PRECISION PLANTING CABLE/TRANSMISSION ASSY	CSU 131	01
06	0503012136	NUT 1/2 NF		04
07	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04




Item	Code	Description	See page	QT
01	0521056954	LEFT DDD ASSY	134	01
02	0503062403	TUBE SEED P.P		01
03	0571017895	PIN FIXER CONDUCTOR P.P		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0521056956	PRECISION PLANTING CABLE/TRANSMISSION ASSY	CSU 131	01
06	0503012136	NUT 1/2 NF		04
07	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04




Item	Code	Description	See page	QT
01	0591011773	RIGHT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 127 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 128 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	129	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	130	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUBLE DISC AXLE		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01



Item	Code	Description	See page	QT
01	0502012924	PRECISION PLANTING SUPPORT		01
02	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
03	0503010589	1/2" UNC SELF ADJUSTING NUT		01
04	0503010140	1/8" X 3/4" COTTERPIN		01
05	0571014024	FAST BOLT GUIDE AXLE		01
06	0503034824	FIXATIVE		01
07	0503010293	CLAMP KNOB		01
08	0503010025	3/8 SPRING WASHER		06
09	0502012922	FIXING SUPPORT		01
10	0503011404	BOLT		01
11	0503013357	3/8 SELF-ADJUSTING NUT		01
12	0503010026	3/8" NUT		04
13	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04
14	0571019491	SLUICE PNEUMATIC		01
15	0501011643	3/8 X 1" BOLT		01
16	0503010209	3/8" UNC BUTTERFLY NUT		01
17	0502012807	SUPPORT HOPPER PRECISION PLANTING		01
18	0571019489	CLAMP PRECISION PLANTING		01
19	0503012721	1/4" X 4" BOLT		01
20	0503012880	1/4" UNC SELF ADJUSTING NUT		01
21	0503818139	BOLT		03
22	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
23	0503015110	M06 SPRING WASHER		02
24	0503037390	PACKING FOR PLANTING		01
25	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
26	0503011953	5/16" X 1" BOLT		03
27	0503010337	5/16" NUT		04
28	0503012163	5/16" X 1-1/2" BOLT		01
29	0581011226	FIXER CLOSING P. PLANTING CONTROL CPRA		01
30	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 132 DISC		01
31	0521066707	FEEDER		01




Item	Code	Description	See page	QT
01	0571019613	STRAW PRECISION PLANTING SHIELD		01
02	0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	133	01




Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01

LEFT DDD ASSY


0521056954




Item	Code	Description	See page	QT
01	0591011772	LEFT DDD BODY		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0503013129	ELASTIC PIN		01
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 127 FERTILIZER / SEED		01
12	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 128 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	136	01
02	0501052538	DEPTH BAND WITH ARMS	142	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL	143	01
06	0521055017	RIGHT COMPACTOR WHEEL	145	01




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	137	01
02	0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	138	01
03	0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	139	01
04	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	140	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	3/8 UNC X 3/4 BOLT		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED SLEEVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	141	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	141	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT SLEEVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL HUB		01
02	0581019515	AXIS		01
03	0503034055	CLAMPING RING		01
04	0581019168	DUST CLOAK		01
05	0503013758	1/4" X 1-1/2" BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0503010878	5/8" SELF ALIGNING NUT		01
10	0503030757	2.9" X 2" X 0.02" JOINT		01
11	0521019178	PROTECTION LID		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	144	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	144	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0531060002	FERTILIZER ROW REAR SUPPORT		01
02	0503019405	SLEEVE		08
03	0591010640	ARM SPACER SLEEVE WITHOUT LUBRICATION		08
04	0503010045	O'RING		04
05	0531060001	TOP SUPPORT FERTILIZER ROW		01
06	0521069998	LOWER SUPPORT FERTILIZER ROW		01
07	0591010629	SHORT FERTILIZER ROW SUPPORT		01
08	0503010233	5/8" X 2-1/2" BOLT		02
09	0503012412	5/8" UNC SELF LOCKING NUT		05
10	0501010452	5/8" X 5" BOLT		03
11	0502012727	BLADE DISC SUPPORT		01
12	0503011255	3/4" LOCK NUT		02
13	0503011328	3/4" X 4" BOLT		02
14	0501010322	FLAT WASHER		02
15	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
16	0503010013	5/8 NUT		02
17	0521056070	DC 20 ASSY	148	01
18	0521011158	SPRING LOCKNUT		01
19	0521062073	SPRING GUIDE		01
20	0521018575	REGULATOR SPINDLE 100		01
21	0503031450	2.7" X 9.2" X 0.03" SPRING		01
22	0521016057	COUP SHA OF THE CARRY-W SPRING GUI		01
23	0503030168	HITCH PIN CLIP		01
24	0502020393	SPRING UPPER SUPPORT		02



Item	Code	Description	See page	QT
01	0531060002	FERTILIZER ROW REAR SUPPORT		01
02	0503019405	SLEEVE		08
03	0591010640	ARM SPACER SLEEVE WITHOUT LUBRICATION		08
04	0503010045	O'RING		04
05	0531060001	TOP SUPPORT FERTILIZER ROW		01
06	0521069998	LOWER SUPPORT FERTILIZER ROW		01
07	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		04
08	0503010233	5/8" X 2-1/2" BOLT		02
09	0503012412	5/8" UNC SELF LOCKING NUT		09
10	0501010452	5/8" X 5" BOLT		02
11	0502012727	BLADE DISC SUPPORT		01
12	0503011255	3/4" LOCK NUT		02
13	0521069993	LONG FERTILIZER ROW SUPPORT		01
14	0501010125	3/4" X 2-1/2" BOLT		02
15	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
16	0503010013	5/8 NUT		02
17	0521056070	DC 20 ASSY	148	01
18	0521011158	SPRING LOCKNUT		01
19	0521062073	SPRING GUIDE		01
20	0521018575	REGULATOR SPINDLE 100		01
21	0503031450	2.7" X 9.2" X 0.03" SPRING		01
22	0521016057	COUP SHA OF THE CARRY-W SPRING GUI		01
23	0503030168	HITCH PIN CLIP		01
24	0502020393	SPRING UPPER SUPPORT		02
25	0502012724	FERTILIZER ROW FIXER		01
26	0501010163	5/8" X 4-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0571019034	FLANGE WASHER AXLE		02
02	0571019032	SUPPORT WASHER		01
03	0502012813	FLANGE WASHER SPRING		01
04	0591010619	DC SPRING SUPPORT		01
05	0503019274	WASHER		02
06	0581017628	LID		02
07	0503019277	SLEEVE LUBRICATION SYSTEM		01
08	0501110964	RIGHT ARM WITH SLEEVE		01
09	0501110965	LEFT ARM WITH SLEEVE		01
10	0503034709	COMPRESSION SPRING 100 X 315 X 15.87		01
11	0521069996	ROD SPRING FERTILIZER		01
12	0591010624	SUPPORT ARM SLEEVE		01
13	0591010625	19,50 X 25 X 91,50/91,30 SLEEVE		01
14	0503010417	7/8" NUT		02
15	0503010390	SEAL RING		02
16	0503011198	C3/4" X 6" SCREW		01
17	0501010322	FLAT WASHER		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503010060	1/2 UNC G.5 ZN HEX NUT		01
20	0503010019	1/2" SPRING WASHER		01
21	0503011255	3/4" LOCK NUT		01
22	0503030430	7/16 X 2" PIN LOCK		01
23	0503019271	SELF LUBRICATING BUSHING		01
24	0521069997	DC FIXING AXIS WITH LIMITER		01
25	0591010628	DC AXIS BACKREST WASHER		01
26	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	149	01
27	0503011254	7/8" HEX SELF ADJUSTING NUT		01



Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	DISC BLADE HUB	150	01

DISC BLADE HUB


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	DISC BLADE HUB		01
09	0502040873	DISC BLADE AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02

FRONT ASSY ROW BEARING


0521051447




Item	Code	Description	See page	QT
01	0581014691	BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503012861	6006 2RS BALL BEARING		01
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0581015056	SLEEVE		01
08	0551015804	BEARING AXLE BODY		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0531052349	CURRENT GUIDE ASSEMBLY	155	01
02	0521059758	SUPPORT ASSY	156	01
03	0503063267	SHORT ENCAPSULATED CURRENT		01




Item	Code	Description	See page	QT
01	0531052349	CURRENT GUIDE ASSEMBLY	155	01
02	0521059758	SUPPORT ASSY	156	01
03	0503063268	LONG ENCAPSULATED CURRENT		01



Item	Code	Description	See page	QT
01	0531052349	CURRENT GUIDE ASSEMBLY	155	01
02	0521059758	SUPPORT ASSY	156	01
03	0503063269	LONG ENCAPSULATED CURRENT		01




Item	Code	Description	See page	QT
01	0501011778	3/8" X 2-1/2" BOLT		02
02	0503010025	3/8 SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0591016329	ENCAPSULATED CHAIN CLOSING		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010669	FLAT WASHER		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010667	3/16" NUT		02
09	0531062745	CHAIN GUIDE		01




Item	Code	Description	See page	QT
01	0521068129	ENCAPSULATED CHAIN FIXATION SUPPORT		01
02	0591015755	CHAIN SUPPORT SLEEVE		02
03	0591016332	SUPPORT REAR SLEEVE		01
04	0501011753	5/16" X 1-3/4" BOLT		03
05	0501010694	FLAT WASHER		01
06	0503019657	HEX LOCK NUT WITH NYLON 5/16		03
07	0591016334	FLAT WASHER 8,50 X 23 X 4,00		02
08	0511017303	FLAT WASHER		04
09	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
10	0503012880	1/4" UNC SELF ADJUSTING NUT		02

SCARIFIER ROD


0521056844




Item	Code	Description	See page	QT
01	0521053673	SCARIFIER ROD WITH NOZZLE	158	01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521069127	BOTTOM NOZZLE FERTILIZER		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
08	0503010025	3/8 SPRING WASHER		02
09	0503010026	3/8" NUT		02
10	0503030483	FERTILIZER SOCKET		01



Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER ROD		01
02	0503011402	0.2" X 0.8" SPRING PIN		02
03	0503016853	SPRING PIN		02
04	0502040869	FIXED ROD BEARING		01



Item	Code	Description	See page	QT
01	0503013759	NUT		02
02	0501010694	FLAT WASHER		02
03	0502012979	CLAMP 3 RIGHT CSU		02
04	0503010421	5/16" X 1-1/2" BOLT		02



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

