

ROW CROP PLANTERS

PST PLUS TITANIUM - FRAME 3120/3870 (FROM 05/2023)

Code: 0501093602
Series: S-0314
Revision: 00
Date Revision: JULHO/2023

PARTS CATALOGUE



MARCHESAN



PRODUCTS

Code	Description
0111370139	PST PLUS 7/6 ESPECIAL S-0314
0111370141	PST PLUS 8/5 E750 ESPECIAL S-0314

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909091114	ASSY FRAME - 3120/3870	1
0511050802	FRAME WITH WHEEL 3120	2
0511051759	FRAME WITH WHEEL 3870	3
0909091619	DRAWBAR ASSY	4
0511054601	HITCH ARTICULATED TRACTOR	5
0511053179	TRACTOR COUPLING SHAFT	6
0909094752	07 ROWS PLATFORM SET	7
0909094763	08 ROWS PLATFORM SET	8
0909094751	07 ROWS HANDRAIL SET	9
0909094753	08 ROWS HANDRAIL SET	10
0909092875	GUARD BRACKET	11
0909091621	07 ROWS TRANSMISSION SET	12
0909092133	08 ROWS TRANSMISSION SET	13
0501055112	MICRO GRANULATED CHAIN TENSIONER	14
0511051757	DOUBLE GEAR	15
0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	16
0501058254	UPPER SEED CHAIN TENSIONER	17
0501052560	MOTOR AXLE SIGNAL	18
0511040424	RH TRANSMISSION DRIVING ASSY	19
0511051980	DOUBLE BEARING	20
0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8	21
0501053950	FINE SEED ASSY INTERMEDIATE BEARING	22
0501058236	BEARING WITH 21Z GEAR	23
0511048701	CHANGE FULL RIGHT	24
0511048702	CHANGE FULL LEFT	25
0501058212	SEMI MOUNTED RIGHT CHANGE	26
0501058213	LH GEAR BOX	27
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	28
0501056443	GEAR HOUSING BEARING	29
0501056444	BEARING WITH ROLLER	30
0501056271	GEARBOX CLOSED BEARING	31
0501054655	CHAIN TENSIONER ASSY	32
0531059615	KIT WITH ALPHA COMPONENTS - 05 ROWS	33
0531059616	KIT WITH ALPHA COMPONENTS - 06 ROWS	34
0909091623	07/08 ROWS CARRYNG-WHEELS ASSY	35
0501058240	WHEEL FASTENER WITH TENSIONER	36
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	37
0501058244	WHEEL FIXED CHAIN TENSIONER	38
0501058242	WHEEL MOBILE CHAIN TENSIONER	39
0501058239	WHEEL CHAIN TENSIONER BEARING	40
0501054428	ASSY DRAWBAR EXTENDER	41
0909091117	DECAL SET - 07/08	42
0909092127	CYLINDER SET	43
0511042474	2.0" X 4" X 18.31" HYDRAULIC CYLINDER	44
0511059395	HOSE KIT HYDRAULIC	45
0501053834	MALE QUICK COUPLER	46
0511054971	JACK ASSEMBLY	47
0511056598	MANUAL STORAGE TUBE ASSY	48
0531059660	ALPHA II FERTILIZER HOPPER SET - 3120	49
0531059659	HOPPER SUPPORT WITH ALPHA II FERTILIZER METERING - 3120	50
0531059668	ALPHA II FERTILIZER HOPPER SET - 3870	51
0531059667	RIGHT HOPPER SUPPORT WITH ALPHA II FERTILIZER METERING - 3870	52



MARCHESAN

INDEX


0531059666	LEFT HOPPER SUPPORT WITH ALPHA II FERTILIZER METERING - 3870	53
0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS	54
0531055319	ALPHA II FERTILIZER METERING	55
0531055863	ASSY TRANSMISSION HUB	56
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	57
0531059139	ASSY COLLECTOR	58
0531055273	ALPHA FERTILIZER METERING CLAMP	59
0501053788	3/4" SQUARE AXLE FASTENER	60
0531057911	22Z GEAR SIDE BEARING ASSEMBLY	61
0531057910	SIDE BEARING WITH BEARING 6007	62
0909091636	HYDRAULIC ROW MARKER ASSY	63
0511058449	HYDRAULIC CYLINDER	64
0531052689	HOISTING EAR WITH LOCK	65
0501050633	ROW MARKER DISC ASSEMBLY	66
0511053904	ROW MARKER DISC	67
0909091116	ASSY FERTILIZER/SEED ROW	68
0511051731	SHORT FRONT SEED ROW	69
0511056128	RIGHT DDD SHORT SEED ROW	70
0511051732	LONG FRONT SEED ROW	71
0511056129	LEFT DDD LONG SEED ROW	72
0501059631	DDD SEED 15 X 15 RIGHT	73
0501059632	DDD SEED 15X15 LEFT	74
0501054167	15" RIGHT DOUBLE DISC HUB	75
0501054168	15" LEFT DOUBLE DISC HUB	76
0511051693	BASE FIXING SYSTEM	77
0511058212	FERTILIZER ROW SUPPORT ASSY	78
0511052024	FAST CLOSING SET	79
0531057890	TITANIUM INDIVIDUAL SEED SYSTEM	80
0511052058	SEED SYSTEM TITANIUM	81
0511053252	FERTILIZER SHORT ROW WITH LEFT DDD/18" DC	82
0511053253	FERTILIZER LONG ROW WITH RIGHT DDD/18" DC	83
0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	84
0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	85
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	86
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	87
0511053173	RIGHT LOW HUB WITH 15 DISC	88
0511053172	LEFT LOW HUB WITH 15 DISC	89
0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	90
0511044573	18" COULTER BLADE ASSY FOR LONG ROW	91
0521054686	18" DISC BLADE HUB	92
0521054679	DISC BLADE HUB	93
0501058423	FERTILIZER ROD SPRING ROW	94
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	95
0511058650	SEMI-MOUNTED DEPTH CONTROL	96
0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	97
0511058652	LEFT DEPTH WHEEL ARM WITH HUB	98
0501052627	ASSY DEPTH WHEEL HUB	99
0501052297	DEPTH WHEELS REGULATOR ASSY	100
0501052538	DEPTH BAND WITH ARMS	101
0511054333	COMPACT WHEEL RIGHT WITH BEARING	102
0511054334	COMPACT WHEEL LEFT WITH BEARING	103
0501052908	COMPACTOR WHEEL WITH BEARING	104
0501110231	SCARIFIER ROD WITH TIP	105
0503062066	DISC SET WITH CORN RING	106



MARCHESAN

INDEX

0503062067	DISC SET / RING SOY 90F TITANIUM		107
------------	----------------------------------	-------	-----




Item	Code	Description	See page	3120	3870
01	0511050802	FRAME WITH WHEEL 3120	2	01	00
01.	0511051759	FRAME WITH WHEEL 3870	3	00	01
02	0503010003	1845 GREASE FITTING		04	04
03	0909091619	DRAWBAR ASSY	4	01	01
04	0909094752	07 ROWS PLATFORM SET	7	01	00
04.	0909094763	08 ROWS PLATFORM SET	8	00	01
05	0909094751	07 ROWS HANDRAIL SET	9	01	00
05.	0909094753	08 ROWS HANDRAIL SET	10	00	01
06	0909092875	GUARD BRACKET	11	02	02
07	0909091621	07 ROWS TRANSMISSION SET	12	01	00
07.	0909092133	08 ROWS TRANSMISSION SET	13	00	01
08	0511048701	CHANGE FULL RIGHT	24	01	01
09	0511048702	CHANGE FULL LEFT	25	01	01
10	0531059615	KIT WITH ALPHA COMPONENTS - 05 ROWS	33	00	01
10.	0531059616	KIT WITH ALPHA COMPONENTS - 06 ROWS	34	01	00
11	0909091623	07/08 ROWS CARRYNG-WHEELS ASSY	35	01	01
12	0501054428	ASSY DRAWBAR EXTENDER	41	01	01
13	0909091117	DECAL SET - 07/08	42	01	01
14	0909092127	CYLINDER SET	43	01	01
15	0511059395	HOSE KIT HYDRAULIC	45	01	01
16	0501053834	MALE QUICK COUPLER	46	02	02
17	0521013022	TRANSPORT LOCK		01	01
18	0501068994	8,30 X 78 LOCK PIN		01	01
19	0503030168	HITCH PIN CLIP		01	01
20	0511054971	JACK ASSEMBLY	47	02	02
21	0501065677	STRUT		02	02
22	0511056598	MANUAL STORAGE TUBE ASSY	48	01	01
23	0531059660	ALPHA II FERTILIZER HOPPER SET - 3120	49	01	00
23.	0531059668	ALPHA II FERTILIZER HOPPER SET - 3870	51	00	01
24	0501047887	40 ROD STOP		02	02
25	0909091636	HYDRAULIC ROW MARKER ASSY	63	01	01


**ASSY FRAME - 3120/3870**

0909091114

Item	Code	Description	See page	3120	3870
26	0501047895	25 ROD STOP		02	02
27	0501047885	30 ROD STOP		02	02
28	0501047886	35 ROD STOP		02	02
29	0511066652	400 TURNBUCKLE		02	02
30	0503010780	N-2050 AMENDMENT		02	02
31	0503010951	REDUCTION		04	04
32	0503011750	AMENDMENT WITH LOCK		06	06
33	0503011751	REDUCTION		06	06
34	0503014120	CHAIN		01	01
35	0503014321	CABLE STEEL SHACKLE		02	02
36	0531052689	HOISTING EAR WITH LOCK	65	02	02
37	0909091116	ASSY FERTILIZER/SEED ROW	68	01	01




Item	Code	Description	See page	QT
01	0521062205	FRAME		01
02	0521062207	CARRYING-WHEELS PIVOT SHAFT		01
03	0521010569	COUPLING SHAFT		04
04	0503010571	1/4" X 1.1/2 COTTERPIN		08



Item	Code	Description	See page	QT
01	0521063032	FRAME		01
02	0521063048	PIVOT SHAFT CARRYING WHEELS		01
03	0521010569	COUPLING SHAFT		04
04	0503010571	1/4" X 1.1/2 COTTERPIN		08

DRAWBAR ASSY


0909091619




Item	Code	Description	See page	QT
01	0511065581	DRAWBAR		01
02	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02
03	0502012329	DRAWBAR FIXATION REAR SUPPORT		02
04	0503011084	3/4" X 5" BOLT		08
05	0501010322	FLAT WASHER		08
06	0503010023	3/4" SPRING WASHER		08
07	0503010014	3/4" HEX NUT		08
08	0502012330	SUPPORT FIXER PIVOT		04
09	0561014393	COUPLING SHAFT		02
10	0503010523	1/4" X 2" SPLIT PIN		02
11	0503030119	LOCK PIN		02
12	0531015979	DRAWBAR LOCK		01
13	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
14	0503010019	1/2" SPRING WASHER		02
15	0503010060	1/2 UNC G.5 ZN HEX NUT		02
16	0502012702	BODY SUPPORT CLAMP		01
17	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		01
18	0503010180	7/16" SPRING WASHER		01
19	0511054601	HITCH ARTICULATED TRACTOR	5	01
20	0503010002	1800 GREASE FITTING		01
21	0541011767	HOSE FIXATION		01
22	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
23	0511053179	TRACTOR COUPLING SHAFT	6	01

HITCH ARTICULATED TRACTOR


0511054601




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0561018277	PLATFORM		02
02	0501010942	3/8" X 1-1/4" BOLT		02
03	0503010025	3/8 SPRING WASHER		02
04	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0571011103	PLATAFORM 3550		02
02	0501010096	3/8" X 2" BOLT		02
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0503010025	3/8 SPRING WASHER		02
05	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0521062235	HANDRAIL		01
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04



Item	Code	Description	See page	QT
01	0521063059	HANDRAIL		01
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0511064807	STIRRUP		02
02	0501018526	3/8" X 2" BOLT		08
03	0503010025	3/8 SPRING WASHER		08
04	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0521062207	CARRYING-WHEELS PIVOT SHAFT		01
02	0501055112	MICRO GRANULATED CHAIN TENSIONER	14	02
03	0521010569	COUPLING SHAFT		04
04	0503010571	1/4" X 1.1/2 COTTERPIN		08
05	0511065606	MOTOR CHOCK SUPPORT BEARING AXLE		02
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
07	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		14
08	0503010019	1/2" SPRING WASHER		12
09	0503010060	1/2 UNC G.5 ZN HEX NUT		14
10	0501110639	BEARING		06
11	0503010300	5/32" X 1" COTTERPIN		06
12	0503011099	GREASE FITTING		06
13	0561018359	MOTOR SHAFT		02
14	0511051757	DOUBLE GEAR	15	02
15	0511065562	20Z GEAR		02
16	0521010530	JUNCTION AXLE 6,80 X 60		02
17	0503010140	1/8" X 3/4" COTTERPIN		02
18	0501018466	FLAT WASHER		04
19	0511015961	LOCK BUSHING		04
20	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
21	0501052560	MOTOR AXLE SIGNAL	18	02
22	0511040424	RH TRANSMISSION DRIVING ASSY	19	02
23	0501065167	RATCHET PIVOT ARM		02
24	0503010140	1/8" X 3/4" COTTERPIN		06
25	0521062245	DISASSEMBLE RATCHET		02
26	0503030198	0.6" X 2.4" X 0.1" EXTENSION SPRING		02
27	0501069850	RATCHET BAR DES.		02
28	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		02
29	0511051980	DOUBLE BEARING	20	02
30	0541010568	CHOCK BEARING		02
31	0561018360	HEX AXLE 5/8 X 1450		01

Item	Code	Description	See page	QT
32	0561018361	HEX AXLE 5/8 X 1680		01
33	0501053950	FINE SEED ASSY INTERMEDIATE BEARING	22	02
34	0503011751	REDUCTION		04
35	0511017305	FLAT WASHER		06
36	0503010018	5/32 X 1-1/2 COTTERPIN		04
37	0511048701	CHANGE FULL RIGHT	24	01
38	0511048702	CHANGE FULL LEFT	25	01
39	0501010243	1/2" X 1-1/2" BOLT		04
40	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
41	0503012682	1/2" BSW NUT		04
42	0503012772	40-1 CHAIN X 80 LINK + REDECTION		02
43	0503013252	40-1 X CHAIN X 87 LINK + MENDING		04




Item	Code	Description	See page	QT
01	0521063048	PIVOT SHAFT CARRYING WHEELS		01
02	0501055112	MICRO GRANULATED CHAIN TENSIONER	14	02
02..	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	16	02
02..	0501058254	UPPER SEED CHAIN TENSIONER	17	02
03	0521010569	COUPLING SHAFT		04
04	0503010571	1/4" X 1.1/2 COTTERPIN		08
05	0511065606	MOTOR CHOCK SUPPORT BEARING AXLE		02
06	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
07	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		14
08	0503010019	1/2" SPRING WASHER		12
09	0503010060	1/2 UNC G.5 ZN HEX NUT		14
10	0501110639	BEARING		06
11	0503010300	5/32" X 1" COTTERPIN		06
12	0503011099	GREASE FITTING		06
13	0571011102	MOTOR SHAFT		02
14	0511051757	DOUBLE GEAR	15	02
15	0511065562	20Z GEAR		02
16	0521010530	JUNCTION AXLE 6,80 X 60		02
17	0503010140	1/8" X 3/4" COTTERPIN		02
18	0501018466	FLAT WASHER		04
19	0511015961	LOCK BUSHING		04
20	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
21	0501052560	MOTOR AXLE SIGNAL	18	02
22	0511040424	RH TRANSMISSION DRIVING ASSY	19	02
23	0501065167	RATCHET PIVOT ARM		02
24	0503010140	1/8" X 3/4" COTTERPIN		06
25	0521062245	DISASSEMBLE RATCHET		02
26	0503030198	0.6" X 2.4" X 0.1" EXTENSION SPRING		02
27	0501069850	RATCHET BAR DES.		02
28	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		02
29	0511051980	DOUBLE BEARING	20	02


Item	Code	Description	See page	QT
30	0541010568	CHOCK BEARING		02
31	0571011100	5/8 X 1905 HEX AXLE		01
32	0571011101	5/8 X 1675 HEX AXLE		01
33	0501058236	BEARING WITH 21Z GEAR	23	02
34	0503011751	REDUCTION		04
35	0511017305	FLAT WASHER		06
36	0503010018	5/32 X 1-1/2 COTTERPIN		04
37	0511048701	CHANGE FULL RIGHT	24	01
38	0511048702	CHANGE FULL LEFT	25	01
39	0501010243	1/2" X 1-1/2" BOLT		04
40	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
41	0503012682	1/2" BSW NUT		04
42	0503012772	40-1 CHAIN X 80 LINK + REDECTION		02
43	0503013252	40-1 X CHAIN X 87 LINK + MENDING		04




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	1 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0571011062	AXLE GEAR DOUBLE		01
02	0503011410	ROLLER BEARING		02
03	0521063046	DOUBLE GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0501010163	5/8" X 4-1/2" BOLT		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0541011713	TENSIONER CHAIN LOWER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521018933	CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0521017590	GUIDE AXLE		01
02	0503010542	501045 CLAMPING RING (FOR AXLE)		01
03	0521017593	FLAT WASHER		01
04	0501019734	FLAT WASHER		02
05	0502011329	14Z GEAR WITH RIGHT DRAGGER		01
06	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
07	0501019735	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		01
09	0502010711	RIGHT CAM,LARGER		01
10	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
11	0502011996	SLEEVE FIXER		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01
14	0503010003	1845 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8	21	01
02	0521063285	EXLE DOUBLE BEARING		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0503010397	5/16" X 1-3/4" BOLT		02
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531015204	MIDDLE BEARING AXLE		01
02	0501011543	5/8" X 4" BOLT		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503010027	5/8 SPRING WASHER		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01
07	0503011410	ROLLER BEARING		01
08	0521069698	GEAR 21Z P 1/2		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	26	01
02	0503010256	3/8" X 3/4" BOLT		01
03	0503010002	1800 GREASE FITTING		02
04	0551018209	DRIVING AXLE		01
05	0521018259	DRIVEN AXLE		01
06	0551018210	DRIVEN AXLE		01
07	0551018211	INTERM SHAFT		01
08	0503030303	SUPPORT WASHER		05
09	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	28	01
10	0501056443	GEAR HOUSING BEARING	29	02
11	0501056271	GEARBOX CLOSED BEARING	31	05
12	0511060396	DRIVE/DRIVEN SHAFT		04
13	0503012389	1/2 BALL		04
14	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
15	0503010060	1/2 UNC G.5 ZN HEX NUT		06
16	0503010395	1/2" X 1-1/4" BOLT		04
17	0511061822	25Z P0.5" GEAR SQUARE HOL		01
18	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
19	0511061759	22Z P12,70 FQ 3/4" GEAR		01
20	0521018630	1.4" X SQUARE 0.8" WASHER		02
21	0503012204	40-1 CHAIN X 82 LINK + RED		02
22	0503012713	40-1 CHAIN X 45 LINK + MEN		01
23	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
25	0503010025	3/8 SPRING WASHER		01
26	0503011953	5/16" X 1" BOLT		08
27	0501010694	FLAT WASHER		08
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
29	0503010337	5/16" NUT		08
30	0503010292	701164 6 X 40 SPRING PIN		02
31	0501054655	CHAIN TENSIONER ASSY	32	02




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	27	01
02	0503010256	3/8" X 3/4" BOLT		01
03	0503010002	1800 GREASE FITTING		02
04	0551018209	DRIVING AXLE		01
05	0521018259	DRIVEN AXLE		01
06	0551018210	DRIVEN AXLE		01
07	0551018211	INTERM SHAFT		01
08	0503030303	SUPPORT WASHER		05
09	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	28	01
10	0501056443	GEAR HOUSING BEARING	29	02
11	0501056271	GEARBOX CLOSED BEARING	31	05
12	0511060396	DRIVE/DRIVEN SHAFT		04
13	0503012389	1/2 BALL		04
14	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
15	0503010060	1/2 UNC G.5 ZN HEX NUT		06
16	0503010395	1/2" X 1-1/4" BOLT		04
17	0511061822	25Z P0.5" GEAR SQUARE HOL		01
18	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
19	0511061759	22Z P12,70 FQ 3/4" GEAR		01
20	0521018630	1.4" X SQUARE 0.8" WASHER		02
21	0503012204	40-1 CHAIN X 82 LINK + RED		02
22	0503012713	40-1 CHAIN X 45 LINK + MEN		01
23	0511063105	34Z P 1/2" GEAR SQUARE HOLE 3/4"		01
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
25	0503010025	3/8 SPRING WASHER		01
26	0503011953	5/16" X 1" BOLT		08
27	0501010694	FLAT WASHER		08
28	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
29	0503010337	5/16" NUT		08
30	0503010292	701164 6 X 40 SPRING PIN		02
31	0501054655	CHAIN TENSIONER ASSY	32	02




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	30	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		05
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		05
01B	0503035859	SUPPORT SLEEVE		05
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		05
02A	0501111196	PELLETED FERTILIZER METERING COATING		05
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		05
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		06
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		06
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
00	0511049139	CARRYNG-WHEELS ASSY		01
01	0501055479	WHEEL ARM ASSY		01
01A	0501055389	WHEEL ARM ASSY		01
01Aa	0501067549	WHEEL SUPPORT		01
01Ab	0511065547	WHEEL RIGHT ARM		01
01Ac	0511065548	WHEEL LEFT ARM		01
01Ad	0521010648	1.2" X 2.2" COUPLING SHAFT		02
01Ae	0503010523	1/4" X 2" SPLIT PIN		02
01Af	0503030425	1" X 6" X 0.2"TRACTION SPRING		02
01Ag	0501013491	5/8" TENSIONER SPRING		03
01Ah	0503010013	5/8 NUT		06
01B	0511053174	STUB SHAFT HUB ASSY		01
01Ba	0511053874	WITHOUT WHEELS TIRE		01
01Bb	0503013001	9/16" CONICAL NUT		06
01Bc	0503011167	M16 X 2 X 30 BOLT		02
01Bd	0503010027	5/8 SPRING WASHER		02
01Be	0521012190	AXLE LOCK		03
01C	0503060112	WHEEL AND TIRE ASSY - 16-10 L		01
02	0501058240	WHEEL FASTENER WITH TENSIONER	36	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503010797	3/4" X 4" BOLT		04
05	0501010322	FLAT WASHER		04
06	0503010023	3/4" SPRING WASHER		04
07	0503010014	3/4" HEX NUT		04
08	0503015345	CHAIN		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	37	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	38	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	39	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	40	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	40	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	40	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0501067353	508 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	07	08
01	0503033866	ADHESIVE LABEL		02	02
02	0503033854	ADHESIVE LABEL		02	02
03	0503033853	ADHESIVE LABEL		02	02
04	0503033421	ADHESIVE LABEL 7 NUMBER FOR PLANTING		02	00
05	0503033422	ADHESIVE LABEL		00	02
06	0503031428	READ MANUAL DECAL		01	01
07	0503031942	ADHESIVE LABEL		01	01
08	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02	02
09	0503031565	ADHESIVE LABEL CARE		02	02
10	0503031566	ADHESIVE LABEL		02	02
11	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02	02
12	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02	02
13	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01	01
14	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01	01
15	0503032930	ADHESIVE LABEL DANGER		04	04
16	0503031087	ADHESIVE LABEL		01	01
17	0503034003	SERIAL NUMBER TAG 61 X 118		01	01
18	0503010001	3.2 X 5.5 RIVET		04	04
19	0503032979	ADHESIVE LABEL LETTERS A B C D		02	02
20	0503034500	ADHESIVE LABEL		01	01




Item	Code	Description	See page	QT
01	0511042474	2.0" X 4" X 18.31" HYDRAULIC CYLINDER	44	01
02	0521010588	0.9" X 7.0" COUPLING SHAFT		01
03	0521012536	COUPLING SHAFT		01
04	0503010523	1/4" X 2" SPLIT PIN		02




Item	Code	Description	See page	QT
01	0511065439	4" X 6.3" CYLINDER CASE		01
02	0511062164	2" X 13.35" TURNBUCKLE WITH BUSHING		01
03	0502010017	4" LID		01
04	0502010778	2" X 4.2" RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	1870-2000-375-B GASKET		01
07	0503010952	W2-2250-500 RING		01
08	0503011061	8-342 BACK-UP RING		01
09	0503010338	2-342 N 3006-9B O'RING		01
10	0503010345	2-218 N 3006-9B O'RING		01
11	0502010992	2.0" X 4.0" PISTON		01
12	0503010043	PACKING 3750-3250		02
13	0503010994	W2-4000-500 PK RING G.E		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521056046	3/8" X 23.6" TR-TR HOSE ASSY		01
01A	0501081660	3/8" X 141" TR-TM HOSE		01
01B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01D	0503018952	PLASTIC BOLT		06
02	0521056047	3/8" X 23.6" TR-TR HOSE ASSY		01
02A	0501081660	3/8" X 141" TR-TM HOSE		01
02B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
02C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
02D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0511031563	BAG WITH MANUAL		01
03	0503010267	NYLON CLAMP		01
04	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
05	0501010694	FLAT WASHER		01
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
07	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0531059659	HOPPER SUPPORT WITH ALPHA II FERTILIZER 50 METERING - 3120		01
02	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS	54	02
03	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		02
04	0503010849	3/8" X 1-1/2" BOLT		14
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		28
06	0503010025	3/8 SPRING WASHER		14
07	0503010026	3/8" NUT		14
08	0571015546	FERTILIZER HOPPER FIXER		01




Item	Code	Description	See page	QT
01	0531065858	HOPPER SUPPORT - 3120		01
02	0531055319	ALPHA II FERTILIZER METERING	55	08
03	0503031527	AGRICULTURAL BEARING		06
04	0501053788	3/4" SQUARE AXLE FASTENER	60	06
05	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	61	02
06	0501218676	3/4 X 125 AXLE WITH HOLE		02
07	0501218854	3/4 X 290 AXLE		04
08	0501218487	3/4 X 390 AXLE		04
09	0531057908	SLEEVE 1/4 X 2		08
09A	0502013069	SLEEVE 21 X 38 X 50		01
09B	0503010010	1/4" X 2.1/2" COTTERPIN		01




Item	Code	Description	See page	QT
01	0531059667	RIGHT HOPPER SUPPORT WITH ALPHA II 52 FERTILIZER METERING - 3870		01
02	0531059666	LEFT HOPPER SUPPORT WITH ALPHA II 53 FERTILIZER METERING - 3870		01
03	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS	54	02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		08
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		08
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
08	0503010025	3/8 SPRING WASHER		16
09	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0531065997	RIGHT HOPPER SUPPORT - 3870		01
02	0531055319	ALPHA II FERTILIZER METERING	55	04
03	0503031527	AGRICULTURAL BEARING		03
04	0501053788	3/4" SQUARE AXLE FASTENER	60	03
05	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	61	01
06	0501218668	3/4 X 135 AXLE		01
07	0501218669	3/4 X 330 AXLE		01
08	0501218487	3/4 X 390 AXLE		03
09	0531057908	SLEEVE 1/4 X 2		04
09A	0502013069	SLEEVE 21 X 38 X 50		01
09B	0503010010	1/4" X 2.1/2" COTTERPIN		01




Item	Code	Description	See page	QT
01	0531065996	LEFT HOPPER SUPPORT - 3870		01
02	0531055319	ALPHA II FERTILIZER METERING	55	04
03	0503031527	AGRICULTURAL BEARING		03
04	0501053788	3/4" SQUARE AXLE FASTENER	60	03
05	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	61	01
06	0501218668	3/4 X 135 AXLE		01
07	0501218688	3/4 X 325 AXLE		01
08	0501218487	3/4 X 390 AXLE		03
09	0531057908	SLEEVE 1/4 X 2		04
09A	0502013069	SLEEVE 21 X 38 X 50		01
09B	0503010010	1/4" X 2.1/2" COTTERPIN		01




Item	Code	Description	See page	QT
01	0503033576	FERTILIZER HOPPER		01
02	0503033578	FERTILIZER BEAM LOCK		01
03	0503032134	FERTILIZER HOPPER LID		02
04	0503032052	LID ARTICULATING SHAFT		04
05	0503032051	LID SHAFT FIXER		08
06	0503032054	FLAT WASHER (INOX)		02
07	0503032053	BOLT C.A.S.I		02
08	0503032055	BOLT LID		02



Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	ASSY TRANSMISSION HUB	56	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	57	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513011170	ALLEN SCREW 1/4 UNC X 7/8 CCSI STAINLESS STEEL		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501310211	FRONT LID		01
19	0503036177	LID CORD		01
20	0531059139	ASSY COLLECTOR	58	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO ADHESIVE LABEL 41.5 X 29		01
15	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0503035915	RIGHT GUIDE DOSING COVER		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01

ASSY COLLECTOR


0531059139




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	59	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02

ALPHA FERTILIZER METERING CLAMP


0531055273




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02



Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007	62	02
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0503010337	5/16" NUT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0531057901	GEAR		01
07	0503010845	501035 CLAMPING RING (FOR AXLE)		01
08	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
02	0503016065	ROLLER BEARING		01
03	0503011800	SEAL RING		01

HYDRAULIC ROW MARKER ASSY


0909091636




Item	Code	Description	See page	QT
01	0511062984	ROW MARKER SMALLER SUPPORT		02
02	0502010175	HITCH CLAMP		04
03	0501010216	3/4 UNC X 4.1/2 C S G.5 ZN BOLT		08
04	0503010023	3/4" SPRING WASHER		08
05	0503010014	3/4" HEX NUT		08
06	0511062982	RH LARGER SUPPORT		01
07	0511062983	LH LARGER SUPPORT		01
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
10	0503010019	1/2" SPRING WASHER		04
11	0503010060	1/2 UNC G.5 ZN HEX NUT		04
12	0501069470	ROW MARKER ARM		02
13	0521061655	BOLT 5/8 UNC X 320 MM		02
14	0521017687	SPACING SLEEVE		02
15	0521010479	SLEEVE ARTICULATION		04
16	0501012140	FLAT WASHER		04
17	0503012412	5/8" UNC SELF LOCKING NUT		02
18	0511058449	HYDRAULIC CYLINDER	64	02
19	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
20	0503010571	1/4" X 1.1/2 COTTERPIN		02
21	0511015779	1" X 4.2" AXLE		02
22	0503010523	1/4" X 2" SPLIT PIN		02
23	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
24	0501068994	8,30 X 78 LOCK PIN		02
25	0503030168	HITCH PIN CLIP		02
26	0511062755	740 TURNBUCKLE		02
27	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
28	0511066652	400 TURNBUCKLE		02
29	0501050633	ROW MARKER DISC ASSEMBLY	66	02




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0531062877	EAR LIFTING		01
02	0501210401	FIXING LOCK		01
03	0502010891	SPRING ROD SUPPORT CHOCK		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		03
05	0503030679	BOLT 1/2 UNC X 1.1/4 C S P C G.5 ZN		01
06	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
07	0503010019	1/2\" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	67	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0511051731	SHORT FRONT SEED ROW	69	01
02	0511051732	LONG FRONT SEED ROW	71	01
03	0511053252	FERTILIZER SHORT ROW WITH LEFT DDD/18" DC	82	01
04	0511053253	FERTILIZER LONG ROW WITH RIGHT DDD/18" DC	83	01
05	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	95	01
06	0503010905	1/2" X 2-1/4" BOLT		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2 UNC G.5 ZN HEX NUT		01
09	0501013714	STABILIZER BAR		01
10	0501018652	CORN STABILIZER BAR		01
11	0501110231	SCARIFIER ROD WITH TIP	105	01
12	0521069124	PIVOTED FERTILIZER ROW NOZZLE		01
13	0511017969	0.1" SPACING PLATE		01
14	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
15	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
16	0503010025	3/8 SPRING WASHER		01
17	0503010026	3/8" NUT		01
18	0503062066	DISC SET WITH CORN RING	106	01
19	0503062067	DISC SET / RING SOY 90F TITANIUM	107	01




Item	Code	Description	See page	QT
01	0511056128	RIGHT DDD SHORT SEED ROW	70	01
02	0511058212	FERTILIZER ROW SUPPORT ASSY	78	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0501057261	SPRING ROD SUPPORT		01
05	0502010891	SPRING ROD SUPPORT CHOCK		01
06	0511060376	SEED SPRING GUIDE		01
07	0521010542	COUPLING SHAFT		01
08	0503010257	1/8" X 1" COTTERPIN		01
09	0502040534	SPRING GUIDE BUSHING LOCK		01
10	0501018535	1/2 X 1 BOLT		01
11	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
12	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
13	0501013753	FLAT WASHER		01
14	0502040534	SPRING GUIDE BUSHING LOCK		01
15	0501018535	1/2 X 1 BOLT		01
16	0503010013	5/8 NUT		01
17	0511052024	FAST CLOSING SET	79	01
18	0531057890	TITANIUM INDIVIDUAL SEED SYSTEM	80	01
19	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
20	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
21	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
22	0503010019	1/2" SPRING WASHER		01
23	0503010060	1/2 UNC G.5 ZN HEX NUT		01
24	0503011099	GREASE FITTING		02
25	0503012412	5/8" UNC SELF LOCKING NUT		02




Item	Code	Description	See page	QT
01	0521062183	SHORT SEED ROW ARM		01
02	0502011830	ARTICULACCION SUPPORT		01
03	0521018079	SEED ROW DRAWBAR LID		01
04	0503011441	SPRING WASHER		02
05	0503014729	1/4" UNF X 1/2" BOLT		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		08
08	0503010060	1/2 UNC G.5 ZN HEX NUT		08
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0501013354	FLAT WASHER		03
13	0502011400	18Z CONICAL GEAR		01
14	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
15	0502011505	18Z CONICAL GEAR		01
16	0521018077	1/2" X 58.6" HEX AXLE		01
17	0501013352	FLAT WASHER		04
18	0501059631	DDD SEED 15 X 15 RIGHT	73	01
19	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	77	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0511056129	LEFT DDD LONG SEED ROW	72	01
02	0511058212	FERTILIZER ROW SUPPORT ASSY	78	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0501057261	SPRING ROD SUPPORT		01
05	0502010891	SPRING ROD SUPPORT CHOCK		01
06	0511060376	SEED SPRING GUIDE		01
07	0521010542	COUPLING SHAFT		01
08	0503010257	1/8" X 1" COTTERPIN		01
09	0502040534	SPRING GUIDE BUSHING LOCK		01
10	0501018535	1/2 X 1 BOLT		01
11	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
12	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
13	0501013753	FLAT WASHER		01
14	0502040534	SPRING GUIDE BUSHING LOCK		01
15	0501018535	1/2 X 1 BOLT		01
16	0503010013	5/8 NUT		01
17	0511052024	FAST CLOSING SET	79	01
18	0531057890	TITANIUM INDIVIDUAL SEED SYSTEM	80	01
19	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
20	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
21	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
22	0503010019	1/2" SPRING WASHER		01
23	0503010060	1/2 UNC G.5 ZN HEX NUT		01
24	0503011099	GREASE FITTING		02
25	0503012412	5/8" UNC SELF LOCKING NUT		02




Item	Code	Description	See page	QT
01	0521062184	LONG SEED ROW ARM		01
02	0502011830	ARTICULACION SUPPORT		01
03	0521018079	SEED ROW DRAWBAR LID		01
04	0503011441	SPRING WASHER		02
05	0503014729	1/4" UNF X 1/2" BOLT		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		08
08	0503010060	1/2 UNC G.5 ZN HEX NUT		08
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0501013354	FLAT WASHER		03
13	0502011400	18Z CONICAL GEAR		01
14	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
15	0502011505	18Z CONICAL GEAR		01
16	0521018078	1/2" X 66.5" HEX AXLE		01
17	0501013352	FLAT WASHER		04
18	0501059632	DDD SEED 15X15 LEFT	74	01
19	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	77	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	15" RIGHT DOUBLE DISC HUB	75	01
04	0501054168	15" LEFT DOUBLE DISC HUB	76	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	PROTECTION LID		02
07	0503014729	1/4" UNF X 1/2" BOLT		06
08	0503011441	SPRING WASHER		06
09	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503011443	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511052301	SUPPORT DDD 15 RIGHT		01
15A	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
15B	0571012491	SOCKET SEED GUIDE		01
15C	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0511015098	FLAT WASHER		02
02	0511011927	DUST CLOAK		02
03	0501054167	15" RIGHT DOUBLE DISC HUB	75	01
04	0501054168	15" LEFT DOUBLE DISC HUB	76	01
05	0503030757	2.9" X 2" X 0.02" JOINT		02
06	0521019178	PROTECTION LID		02
07	0503014729	1/4" UNF X 1/2" BOLT		06
08	0503011441	SPRING WASHER		06
09	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503011443	3/8" SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0511052302	LH SUPPORT DDD GUIDE		01
15A	0561015592	LEFT DOUBLE DISC SUPPORT		01
15B	0571012491	SOCKET SEED GUIDE		01
15C	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502011930	OPENING DISCS HUB		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT DOUB DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502011930	OPENING DISCS HUB		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019148	LEFT DOUBLE DISC HUB		01
05	0503030282	3/4" CASTLE NUT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
08	0503010546	5/16" X 7/8" BOLT		06
09	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502011411	10Z CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" COTTERPIN		02




Item	Code	Description	See page	QT
01	0503063752	SIGMA INDIVIDUAL SEED HOPPER		01
02	0511052058	SEED SYSTEM TITANIUM	81	01
03	0503010371	5/16" X 1" BOLT		05
04	0501010694	FLAT WASHER		05
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
06	0503010337	5/16" NUT		05




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
09.	0503016279	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01
14	0503062044	ASSEMBLY SEED HOPPER SET		01
14A	0503016285	BOLT		05
14B	0503016286	HEX NUT		05
14C	0503016287	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT 84 DOUBLE DISC		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	90	01
07	0501058423	FERTILIZER ROD SPRING ROW	94	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT 85	01	01
02	0501010066	DOUBLE DISC		01
03	0521017831	3/4" X 9" BOLT		02
04	0511017232	SUPPORT SLEEVE SPACER		02
05	0511017232	FLAT WASHER		01
06	0503011255	3/4" LOCK NUT		01
07	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	91	01
08	0501058423	FERTILIZER ROD SPRING ROW	94	01
09	0503030392	LEFT FERTILIZER NOZZLE		01
10	0503031145	2" X 2" X 20" HOSE		01
	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	86	01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061153	FERTILIZER ROW LONG ARM		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	87	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	89	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	88	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02



Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	88	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	89	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUBLE DISC AXLE		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01

18" COULTER BLADE ASSY FOR SHORT ROW


0511044549



Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0503010003	1845 GREASE FITTING		01
03	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE		01
04	0521014137	RIGHT ARM BLADE DISC		01
05	0521014138	SUPPORT ARM LEFT BALDE DISC		01
06	0521054686	18" DISC BLADE HUB	92	01
07	0503010756	0.2" X 2.4" SPRING PIN		01
08	0503010361	SPRING PIN		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	1902020394	SPRING SUPPORT		01
14	1902020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0503010014	3/4" HEX NUT		02
17	0541018684	FLAT WASHER		01
18	0503013185	3/4" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01
21	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE		01
02	0503010003	1845 GREASE FITTING		01
03	0511067044	LONG WHIT BEATER BLADE DISC FIX AXLE		01
04	0521014137	RIGHT ARM BLADE DISC		01
05	0521014138	SUPPORT ARM LEFT BALDE DISC		01
06	0521054686	18" DISC BLADE HUB	92	01
07	0503010756	0.2" X 2.4" SPRING PIN		01
08	0503010361	SPRING PIN		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503011255	3/4" LOCK NUT		01
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
13	1902020394	SPRING SUPPORT		01
14	1902020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0503010014	3/4" HEX NUT		02
17	0541018684	FLAT WASHER		01
18	0503013185	3/4" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01
21	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0521054679	DISC BLADE HUB	93	01
02	0603026013	PLAIN COULTER BLADE		01

DISC BLADE HUB


0521054679




Item	Code	Description	See page	QT
01	0502011562	DISC BLADE HUB		01
02	0502020641	BLADE DISC FLANGE		01
03	0503010276	6206 BALL BEARING		02
04	0521013610	BLADE DISC HUB AXLE		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
06	0503012417	SEAL		02
07	0503011800	SEAL RING		02
08	0503010691	1/4" GREASE FITTING		01
09	0521015376	DUST CLOAK		02
10	0503030832	FLAT WASHER		02
11	0511015346	FLAT WASHER		02
12	0521013510	3/4" NUT		02
13	0503010012	1" SPRING WASHER		02
14	0503010371	5/16" X 1" BOLT		06
15	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD		01
02	0502040534	SPRING GUIDE BUSHING LOCK		02
03	0502012184	FERTILIZER SPRING GUIDE		02
04	0503031910	1.7" X 22.8" X 0.3" SPRING		01
05	0502012510	SPRING ROD SUPPORT		01
06	0503010257	1/8" X 1" COTTERPIN		01
07	0501018535	1/2 X 1 BOLT		02
08	0503030678	BOLT 1/2 UNC X 1.1/2 C50P G.5 ZN		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02
10	1902010891	SPRING CHOCK SUPPORT VARON		01
11	0503010014	3/4" HEX NUT		01
12	0561014471	COUPLING SHAFT		01
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	96	01
02	0501052538	DEPTH BAND WITH ARMS	101	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	102	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	103	01
07	0503033942	COMPACTOR WHEEL REGULATOR LID		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT DEPTH WHEEL ARM WITH HUB	98	01
07	0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	97	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	100	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL HUB	99	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL HUB	99	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	PROTECTION LID		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	104	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	104	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER ROD		01
02	1902070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01



Item	Code	Description	See page	QT
01	0503016204	CORN DISC 12 ORANGE		01
02	0503016398	TITANIUM RING CORN / SOY (YELLOW FLAT)		01
03	0503016399	TITANIUM RING CORN (GREEN)		01
04	0503016400	TITANIUM RING CORN (GREY)		01
05	0503016401	TITANIUM RING CORN (BLUE)		01



Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016218	DISC OF SOYBEAN		01
03	0503016403	TITANIUM RING FOR SOYBEAN (LILAC)		01
04	0503016404	TITANIUM RING FOR SOYBEAN (PURPLE)		01
05	0503016406	TITANIUM RING FOR SOYBEAN (ORANGE)		01
06	0503016407	TITANIUM RING FOR SOYBEAN		01



MARCHESAN

Technical Publications | Elaboration and Revision

LEONARDO JOSÉ DA SILVA SOUZA

www.marchesan.com.br

