

ROW CROP PLANTERS

**PST PLUS FLEX TITANIUM - FRAME 5345/5745 - CSU
(FROM 05/2023)**

**PST PLUS FLEX TITANIUM - CHASSI 5345/5745 -
CSU (A PARTIR 05/2023)**

Code: 0501093618
Series: S-0116
Revision: 00
Revision Date: OCTOBER/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Working Width	Description
0111380330		PST PLUS FLEX 5345/11E500 D MH DC20 CSU TIT S-0116
0111380344		PST PLUS FLEX 5345/11E500 ESPECIAL S-0116
0111380390		PST PLUS FLEX 5345/11E500 ESPECIAL S-0116
0111380324		PST PLUS FLEX 5345/11E500 ESPECIAL S-0116
0111380077		PST PLUS FLEX 5345/11E500 MH DC20 CSU TIT S-0116
0111380527		PST PLUS FLEX 5345/12E450 ESPECIAL S-0116
0111380398		PST PLUS FLEX 5745/12E500 CI MH DC20 CSU TIT S0116
0111380191		PST PLUS FLEX 5745/12E500 ESPECIAL S-0116
0111380308		PST PLUS FLEX 5745/12E500 ESPECIAL S-0116
0111380313		PST PLUS FLEX 5745/12E500 ESPECIAL S-0116
0111380345		PST PLUS FLEX 5745/12E500 ESPECIAL S-0116
0111380356		PST PLUS FLEX 5745/12E500 ESPECIAL S-0116
0111380160		PST PLUS FLEX 5745/12E500 MH DC20 CSU TIT S-0116
0111380523		PST PLUS FLEX 5745/13E450 ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

INDEX

0909096852	ASSY FRAME - 5345/5745	1
0511057382	FRAME WITH WHEEL AXLE - 5345	2
0521050047	FRAME WITH WHEEL AXLE - 5745	3
0511058656	CYLINDER SET - 4845/5345/5745	4
0521054233	50,8 X 101,6 X 240,5 X 507,5 HYDRAULIC CYLINDER	5
0511057386	HANDRAIL ASSEMBLY - 5345	6
0521050055	HANDRAIL ASSEMBLY - 5745	7
0511059383	HANDRAIL INTERNAL FIXER	8
0511057385	PLATFORM ASSEMBLY - 5345	9
0521050048	PLATFORM ASSEMBLY - 5745	10
0511056536	LADDER ASSEMBLY	11
0511057333	DRAWBAR ASSEMBLY - 3495/4045/4395/4845/5345/5745	12
0511054601	HITCH ARTICULATED TRACTOR	13
0511057270	DRAWBAR EXTENDER	14
0511056736	HOSE SUPPORT	15
0511054971	JACK ASSEMBLY	16
0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	17
0511058653	WHEELS WITH TRACTION SPRING	18
0511058654	WHEEL SUPPORT	19
0511052770	WHEEL WITH TIRE	20
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	21
0503062159	WHEEL WITH TIRE	22
0501058241	WHEEL SUPPORT CHAIN TENSIONER	23
0501058240	WHEEL FASTENER WITH TENSIONER	24
0501058242	WHEEL MOBILE CHAIN TENSIONER	25
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	26
0501058244	WHEEL FIXED CHAIN TENSIONER	27
0501058239	WHEEL CHAIN TENSIONER BEARING	28
0521050054	WHEELS TRACTION SPRING WITHOUT TRANSMISSION	29
0521050053	WHEEL SUPPORT WITHOUT TRANSMISSION	30
0521055239	WHEEL WITH TIRE WITHOUT TRANSMISSION	31
0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	32
0531055595	5345 ALPHA II FERTILIZER HOPPER SET	33
0531055588	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 5345	34
0541050215	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 5345	35
0531055596	5745 ALPHA II FERTILIZER HOPPER SET	36
0531059665	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 5745	37
0531055589	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 5745	38
0501053788	3/4" SQUARE AXLE FASTENER	39
0531055319	ALPHA II FERTILIZER METERING	40
0531055863	TRANSMISSION HUB ASSY	41
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	42
0531059139	COLLECTOR ASSY	43
0531055273	ALPHA FERTILIZER METERING CLAMP	44
0531057911	22Z GEAR SIDE BEARING ASSEMBLY	45
0531057901	GEAR	46
0503062362	FERTILIZER HOPPER	47
0503062391	FERTILIZER HOPPER	48
0511058147	SINGLE SEED HOPPER - 4845/11 E450 - 5345/11 E500	49
0511057919	2 HOPPERS WITH 11 CONDUCTORS SET	50
0511059054	SINGLE SEED HOPPER - 5345/12 E450	51
0511058724	2 HOPPERS WITH 12 CONDUCTORS ASSEMBLY	52
0521050767	SINGLE SEED HOPPER - 5745/12 E500	53



MARCHESAN

INDEX

0531058403	SINGLE SEED SET	54
0531057980	SINGLE SEED SET C3 - 13 CONDUCTORS	55
0531057950	3" X 175 SEED NOZZLE WITH FIXING	56
0531054471	CAP WITH FIXING	57
0511058510	FIXER SUPPORT	58
0511057690	3" ARTICULATED SEED CONDUCTOR	59
0521055338	ROW SEED BEARING	60
0501053566	ROW SEED BEARING	61
0511057387	SEMI-ASSEMBLED HYDRAULIC MARKER - 5345	62
0521050114	SEMI-ASSEMBLED HYDRAULIC MARKER - 5745	63
0511058449	HYDRAULIC CYLINDER	64
0501054649	HBM SEQUENTIAL VALVE	65
0501053834	MALE QUICK COUPLER	66
0501050633	ROW MARKER DISC ASSEMBLY	67
0511053904	ROW MARKER DISC	68
0511059323	SUPPORT PLATFORM TRANSPORT	69
0531057457	ALPHA DECAL SET - 5345	70
0531057458	ALPHA LABEL SET - 5745	71
0511053179	TRACTOR COUPLING SHAFT	72
0511058937	TRANSMISSION ASSEMBLY - 5345	73
0521050115	TRANSMISSION ASSEMBLY - 5745	74
0501052560	MOTOR AXLE SIGNAL	75
0511051434	TRANSMISSION ACTUATOR	76
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	77
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	78
0511057265	TRANSMISSION CHAIN TENSIONER	79
0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	80
0511050652	CHAIN TENSIONER	81
0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	82
0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	83
0521055335	RIGHT GEAR HOUSING SET	84
0511058381	RIGHT GEAR HOUSING	85
0521055337	LEFT GEAR HOUSING SET	86
0511058382	LEFT GEAR HOUSING	87
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	88
0501048790	AXLE WITH RING	89
0501056443	GEAR HOUSING BEARING	90
0501056444	ROLLER BEARING	91
0511057258	TENSIONER WITH GEAR	92
0511054363	CHAIN TENSIONER	93
0511057845	MANUAL CANISTER	94
0531059621	KIT WITH ALPHA COMPONENTS - 11 ROWS	95
0531059622	KIT ALPHA COMPONENTS - 12 ROWS	96
0511059322	LIFTING SUPPORT ASSEMBLY	97
0531053630	MONITORING ASSEMBLY PLANTING SEEDS 12 ROWS PM 400	98
0531053443	MONITORING ASSEMBLY PLANTING SEEDS 14 ROWS PM 400	99
0909096853	SEED/FERTILIZER ROW ASSY	100
0511057277	FRONT SHORT SEED ROW WITH RIGHT TRANSMISSION	101
0521056500	FRONT SHORT SEED ROW WITH RIGHT TRANSMISSION WITHOUT LUBRIFICATION	102
0541051368	FRONT SHORT SEED ROW WITH TRANSMISSION	103
0511057278	FRONT LONG SEED ROW WITH RIGHT TRANSMISSION	104
0521056501	FRONT LONG SEED ROW WITH RIGHT TRANSMISSION WITHOUT LUBRIFICATION	105
0541051369	FRONT LONG SEED ROW WITH TRANSMISSION	106



MARCHESAN

INDEX


0511058766	BEARING	107
0511057159	TRANSMISSION HOPPER SEED ROW	108
0511058512	PROTECTION LID	109
0511059872	BEARING	110
0511057269	CHAIN TENSIONER	111
0511056621	RIGHT REAR SEED ROW	112
0521054770	RIGHT REAR SEED ROW	113
0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	114
0521055870	RIGHT DOUBLE DISC SEED 15 X 15	115
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	116
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	117
0521055864	FERTILIZER/SEED RIGHT HUB ASSY	118
0521055865	FERTILIZER/SEED LEFT HUB ASSY	119
0511056622	LEFT REAR SEED ROW	120
0521054771	LEFT REAR SEED ROW	121
0521055871	LEFT DOUBLE DISC SEED 15 X 15	122
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	123
0511056586	15 X 15 SEED DDD LEFT	124
0511052301	SUPPORT DDD 15 RIGHT	125
0511052302	LH SUPPORT DDD GUIDE	126
0511053173	RIGHT LOW HUB WITH 15 DISC	127
0511053172	LEFT LOW HUB WITH 15 DISC	128
0511051888	5/8 ASSY TITANIUM SYSTEM FIXING BASE	129
0511058639	SHORT FERTILIZER ROW WITH DDD/DC20	130
0511059051	SHORT FERTILIZER ROW	131
0511058640	LONG FERTILIZER ROW WITH DDD/DC20	132
0511059052	SHORT ROW FERTILIZER	133
0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	134
0511058634	SUPPORT LONG	135
0511057272	LH SHORT ARM ROW FERTILIZER	136
0511057271	RH LONG ARM ROW FERTILIZER	137
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	138
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	139
0511058630	20" DISC BLADE	140
0511058648	HUB WITH 20" DISC BLADE	141
0511056909	DISC BLADE HUB WITHOUT DISC	142
0511059050	DOC 20" ASSY	143
0511058838	20" WAVY COULTER BLADE HUB	144
0521050064	SHORT FERTILIZER ROW WITH DAOC/DC 20"	145
0541051332	SHORT FERTILIZER LINE	146
0541051334	FLAT DISC SMOOTH RIBBED	147
0521055373	HUB WITH CUTTING DISC DPLE 20 TB 60E WITHOUT LUBRICATION	148
0521053697	DISC BLADE HUB	149
0521050065	LONG FERTILIZER ROW WITH DAOC/DC 20"	150
0541051333	LONG FERTILIZER ROW	151
0521050062	SHORT ARM FERTILIZER ROW	152
0521050063	RH LONG ARM ROW FERTILIZER	153
0521050061	18" WAVY COULTER BLADE ASSY	154
0511057544	ASSY TURBO CUTTING DISC (18)	155
0511057537	COULTER BLADE ASSY	156
0531055312	TITANIUM SINGLE SEED SYSTEM	157
0511052058	SEED SYSTEM TITANIUM	158
0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	159
0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK LID	160



MARCHESAN


INDEX

0521046122	DEPTH SYSTEM / COMPACTOR ASSY	161
0511058650	SEMI-MOUNTED DEPTH CONTROL	162
0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	163
0511058652	LEFT DEPTH WHEEL ARM WITH HUB	164
0501052627	ASSY DEPTH WHEEL HUB	165
0501052297	DEPTH WHEELS REGULATOR ASSY	166
0501052538	DEPTH BAND WITH ARMS	167
0511054333	COMPACT WHEEL RIGHT WITH BEARING	168
0511054334	COMPACT WHEEL LEFT WITH BEARING	169
0501052908	COMPACTOR WHEEL WITH BEARING	170
0521052626	SYSTEM DEEP WHEEL / COMPACTOR RAPID IRON ADJUSTMENT	171
0501056769	DEPTH WHEELS REGULATOR ASSY	172
0521051423	COMPACTOR SUPPORT	173
0501052957	IRON V PRESS WHEELS	174
0511050077	WHEEL STRIPED	175
0511052287	DEPTH WHEEL HUB ASSY	176
0531054532	WHEEL SYSTEM DEPTH / COMPACTOR	177
0501110804	SCARIFIER ROD WITH POINT	178
0531050237	3" RIGHT SEED CONDUCTOR FIXER	179
0531052986	PIVOT SUPPORT	180
0503062066	DISC SET WITH CORN RING	181
0503062067	DISC SET / RING SOY 90F TITANIUM	182
0511052024	FAST CLOSING SET	183
0521057957	FIXED ROD EXTENSION WITH FIXATION	184
0511057984	V-COVERING RUBBER WHEEL - SHORT ROW	185
0511057985	V-COVERING RUBBER WHEEL - LONG ROW	186
0521054769	LEFT DDD FERTILIZER WITH SUPPORT	187
0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	188
0521055869	LEFT DUAL FERTILIZER DISC	189
0521055868	RIGHT DUAL FERTILIZER DISC	190




Item	Code	Description	See page	5345	5745
01	0511057382	FRAME WITH WHEEL AXLE - 5345	2	01	00
01.	0521050047	FRAME WITH WHEEL AXLE - 5745	3	00	01
02	0511058656	CYLINDER SET - 4845/5345/5745	4	01	01
03	0511057386	HANDRAIL ASSEMBLY - 5345	6	01	00
03.	0521050055	HANDRAIL ASSEMBLY - 5745	7	00	01
04	0511057385	PLATFORM ASSEMBLY - 5345	9	01	00
04.	0521050048	PLATFORM ASSEMBLY - 5745	10	00	01
05	0511056536	LADDER ASSEMBLY	11	02	02
06	0511057333	DRAWBAR ASSEMBLY	12	01	01
		3495/4045/4395/4845/5345/5745			
07	0511054601	HITCH ARTICULATED TRACTOR	13	01	01
08	0511057270	DRAWBAR EXTENDER	14	01	01
09	0511056736	HOSE SUPPORT	15	01	01
10	0511054971	JACK ASSEMBLY	16	02	02
11	0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	17	01	01
12	0511058653	WHEELS WITH TRACTION SPRING	18	04	04
12.	0521050054	WHEELS TRACTION SPRING WITHOUT TRANSMISSION	29	00	02
13	0531055595	5345 ALPHA II FERTILIZER HOPPER SET	33	01	00
13.	0531055596	5745 ALPHA II FERTILIZER HOPPER SET	36	00	01
14	0511058147	SINGLE SEED HOPPER - 4845/11 E450 - 5345/11 E500	49	01	00
14.	0511059054	SINGLE SEED HOPPER - 5345/12 E450	51	01	00
14..	0521050767	SINGLE SEED HOPPER - 5745/12 E500	53	00	01
14...	0531058403	SINGLE SEED SET	54	00	01
15	0571018920	3/4 X 2555 AXLE HEX		01	00
15.	0581012908	3/4 X 2755 AXLE HEX		00	01
16	0571018921	3/4 X 2740 AXLE HEX		01	00
16.	0581012909	3/4 X 2940 AXLE HEX		00	01
17	0521055338	ROW SEED BEARING	60	06	06


Item	Code	Description	See page	5345	5745
18	0511054314	TRANSMISSION AXLE LOCK SLEEVE		04	04
18A	0502012699	TRANSMISSION HUB LOCK SLEEVE		01	01
18B	0503010256	3/8" X 3/4" BOLT		01	01
19	0511057845	MANUAL CANISTER	94	01	01
20	0511057387	SEMI-ASSEMBLED HYDRAULIC MARKER - 5345	62	01	00
20.	0521050114	SEMI-ASSEMBLED HYDRAULIC MARKER - 5745	63	00	01
21	0501050633	ROW MARKER DISC ASSEMBLY	67	02	02
22	0521013164	EXTENDER		02	02
23	0501011310	FIXER LOCK		08	08
24	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		08	08
25	0503010019	1/2" SPRING WASHER		08	08
26	0503010060	1/2 UNC G.5 ZN HEX NUT		08	08
27	0511059323	SUPPORT PLATFORM TRANSPORT	69	04	04
28	0531057457	ALPHA DECAL SET - 5345	70	01	00
28.	0531057458	ALPHA LABEL SET - 5745	71	00	01
29	0501065677	STRUT		02	02
30	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01
31	0511053179	TRACTOR COUPLING SHAFT	72	01	01
32	0521013022	TRANSPORT LOCK		02	02
33	0501047895	25 ROD STOP		02	02
34	0501047885	30 ROD STOP		02	02
35	0501047886	35 ROD STOP		02	02
36	0501047887	40 ROD STOP		02	02
37	0531059621	KIT WITH ALPHA COMPONENTS - 11 ROWS	95	01	00
37.	0531059622	KIT ALPHA COMPONENTS - 12 ROWS	96	01	01
38	0503014120	CHAIN		01	01
39	0503014321	CABLE STEEL SHACKLE		02	02
40	0501068994	8,30 X 78 LOCK PIN		02	02
41	0503030168	HITCH PIN CLIP		02	02
42	0503010780	N-2050 AMENDMENT		02	02
43	0503010951	REDUCTION		04	04
44	0503011750	AMENDMENT WITH LOCK		06	06
45	0503011751	REDUCTION		06	06
46	0503010003	1845 GREASE FITTING		06	06
47	0511058937	TRANSMISSION ASSEMBLY - 5345	73	01	00
47.	0521050115	TRANSMISSION ASSEMBLY - 5745	74	00	01
48	0511059322	LIFTING SUPPORT ASSEMBLY	97	02	02
49	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		04	04
50	0521014021	1/2" X 4.5" X 5.4" FASTENER		04	04
51	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08	08
52	0503010019	1/2" SPRING WASHER		08	08
53	0503010060	1/2 UNC G.5 ZN HEX NUT		08	08
54	0571017368	SUPPORT GUTTER		08	08
55	0501011643	3/8 X 1"BOLT		08	08
56	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08	08
57	0503010025	3/8 SPRING WASHER		08	08
58	0503010026	3/8" NUT		08	08
59	0571018391	GUTTER 25 X 58 X 1200		02	04
60	0531053630	MONITORING ASSEMBLY PLANTING SEEDS ROWS PM 400	12 98	01	00
60.	0531053443	MONITORING ASSEMBLY PLANTING SEEDS ROWS PM 400	14 99	00	01
61		SEED/FERTILIZER ROW ASSY	100		




Item	Code	Description	See page	QT
01	0521065922	FRAME - 5345		01
02	0521065931	PIVOT SHAFT WHEEL - 5345		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0521067308	FRAME - 5745		01
02	0521067388	PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0501812140	FLAT WASHER		16
07	0503011445	SPRING WASHER		08
08	0503810013	NUT 5/8 NC		08




Item	Code	Description	See page	QT
01	0521054233	50,8 X 101,6 X 240,5 X 507,5 HYDRAULIC CYLINDER	5	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521010547	1.2" X 6.5" COUPLING SHAFT		02
04	0503010523	1/4" X 2" SPLIT PIN		04
05	0501047888	45 ROD STOP		02
06	0571019384	SPACING SLEEVE 16,30 X 30 X 104		02
07	0501013867	BOLT 5/8" UNC X 6 CS G.5 ZN		02
08	0503010027	5/8 SPRING WASHER		02
09	0503010013	NUT 5/8" UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0521069306	50.8 X 337.5 EXTENSION WITH 32.5 BUSHING		01
02	0521069305	101,6 X 438,5 TUBE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0503010004	1890 GREASE FITTING		01
05	0502012821	2" X 4" RING SUPPORT		01
06	0503011061	8-342 BACK-UP RING		02
07	0503018024	RING BS OD050805200171D-BR		01
08	0503010338	2-342 N 3006-9B O'RING		02
09	0503018026	GASKET 1870-2000-375 B POLYMAX		01
10	0503018025	RING GUIDE W2-2250-750		01
11	0503010039	D-2000 SCRAPER RING		01
12	0502012822	END CAP 4"		01
13	0502012842	50,80 X 101,60 PISTON		01
14	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
15	0503018029	O'RING 2-217 N 3006 90B		01
16	0503015633	SELEMASTER SEALING		01
17	0511034644	50,8 X 101,6 HYDRAULIC CYLINDER SPARE SET		01




Item	Code	Description	See page	QT
01	0521065953	FRAME HANDRAIL - 5345		02
02	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0581012916	INTERMEDIATE TUBE		02
07	0511059383	HANDRAIL INTERNAL FIXER	8	04




Item	Code	Description	See page	QT
01	0531063064	FRAME HANDRAIL - 5745		02
02	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0581012916	INTERMEDIATE TUBE		02
07	0511059383	HANDRAIL INTERNAL FIXER	8	04




Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01




Item	Code	Description	See page	QT
01	0571018869	PLATFORM - 5345		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0581012899	PLATFORM - 5745		02
02	0503010237	3/8" X 1" BOLT		06
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		12
04	0503010025	3/8 SPRING WASHER		06
05	0503010026	3/8" NUT		06




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		02
02	0503010237	3/8" X 1" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511069636	LADDER		01
06	0503011179	3/8" X 2-1/4" BOLT		02
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0502012806	SUPPORT REAR FIXER DRAWBAR		04
02	0502012789	FIXER SUPPORT FERTILIZER ROW		04
03	0503017960	5/8" X 3-12" BOLT		16
04	0503010811	5/8" UNF SELF ADJUSTING NUT		16
05	0501010191	1" X 6" BOLT		04
06	0503010012	1" SPRING WASHER		04
07	0501010059	1.5/8 NUT		04
08	0502012805	SUPPORT FRONT FIXER DRAWBAR		04
09	0502012789	FIXER SUPPORT FERTILIZER ROW		04
10	0503017960	5/8" X 3-12" BOLT		16
11	0503010811	5/8" UNF SELF ADJUSTING NUT		16
12	0521065958	DRAWBAR		01
13	0561019087	DRAWBAR TRANSPORT LOCK		01
14	0551014099	COUPLING SHAFT 31,75 X 185		01
15	0521010544	1.2" X 4.9" COUPLING SHAFT		01
16	0503030085	LOCK PIN		02
17	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	SCREW ASSY		01
05	0501011301	1.1/2" UNC 6FPP 2.5/16" NUT		01
06	0503010010	SPLIT PIN 1/4" X 2.1/2"		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2" SPLIT PIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521065959	JACK R.1.1/2 UNC RIGHT X 240		01
03	0521065960	JACK R.1.1/2 UNC LEFT X 240		01
04	0501061056	1.1/2" RIGHT LOCK-NUT		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0511057335	HOSE KIT HYDRAULIC		01
01A	0501080025	3/8" X 55,11" TR-TC HOSE		04
01B	0521052285	TC-TM HOSE ASSY		01
01BA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01BD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
01C	0521052330	3/8" X 157.50" TC-TM BLACK/BLUE HOSE		01
01CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01CB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01CC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01CD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	66	02
03	0511058120	KIT VALVE SUPPORT		01
03A	0521066354	OIL DISTRIBUTOR BODY		02
03B	0502010477	HOSE CLAMP		04
03C	0503011268	3/8" X 2-1/2" BOLT		02
03D	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03E	0503010025	3/8 SPRING WASHER		02
03F	0503010026	3/8" NUT		02
04	0503013100	NYLON CLAMP 4,8 X 1,3 X 200 MM		02
05	0502012702	BODY SUPPORT CLAMP		04
06	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
07	0503010180	7/16" SPRING WASHER		04
08	0531011180	UPPER BODY CLIP		04
09	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0511058654	WHEEL SUPPORT	19	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	24	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521066716	WHEEL ARM ASSY		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	BOLT 5/8" UNC X 2 CS G.5 ZN		01
08	0503010027	5/8 SPRING WASHER		01
09	0501058241	WHEEL SUPPORT CHAIN TENSIONER	23	01
10	0503013030	5/8" X 3.1/4" BOLT		01
11	0551017715	FLAT WASHER		02
12	0511052770	WHEEL WITH TIRE	20	01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8 SPRING WASHER		02
15	0503011167	M16 X 2 X 30 BOLT		02




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	22	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	21	01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL BOLT 5/8"UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503012113	TIRE 7.00 X 16 10 CANVAS		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	NUT 5/8" UNC G.5 ZN		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	26	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	27	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	25	01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	28	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	28	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	28	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0503011119	7/8" X 6" BOLT		04
02	0501014251	FLAT WASHER		04
03	0521050053	WHEEL SUPPORT WITHOUT TRANSMISSION	30	01
04	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0531016887	CARRYING WHEEL AXLE ARM		01
03	0503010523	1/4" X 2" SPLIT PIN		01
04	0503010003	1845 GREASE FITTING		01
05	0511050681	TRACTION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0561016062	SPRING HITCH		02
06	0501010100	BOLT 5/8" UNC X 2 CS G.5 ZN		01
07	0503010027	5/8 SPRING WASHER		04
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0521066716	WHEEL ARM ASSY		01
11	0503011167	M16 X 2 X 30 BOLT		02
12	0591010589	BODY LOCK WHEEL		02
13	0521055239	WHEEL WITH TIRE WITHOUT TRANSMISSION	31	01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	22	01
02	0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	32	01




Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	25590/25523 ROLLER BEARING		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL BOLT 5/8" UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0531055588	RIGHT HOPPER SUPPORT WITH FERTILIZER 34 METERING - 5345		01
02	0541050215	LEFT HOPPER SUPPORT WITH FERTILIZER 35 METERING - 5345		01
03	0503013751	3/8 UNC X 1.1/4 BOLT		20
04	0571019051	FIXER HOPPER WASHER		20
05	0503012535	3/8" SPRING WASHER		20
06	0503012531	3/8" INOX NUT		20
07	0503011957	NYLON HANDLE		02
08	0503010371	5/16" X 1" BOLT		04
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
10	0503010337	NUT 5/16 UNC G.5 ZN		04
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		14
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		28
13	0503010025	3/8 SPRING WASHER		14
14	0503010026	3/8" NUT		14
15	0503062362	FERTILIZER HOPPER	47	03




Item	Code	Description	See page	QT
01	0531064284	RIGHT HOPPER SUPPORT - 5345		01
02	0501053788	3/4" SQUARE AXLE FASTENER	39	04
03	0503031527	AGRICULTURAL BEARING		04
04	0531057913	DOUBLE BEARING ASSEMBLY		01
05	0501218849	3/4 X 143/145 AXLE WITH HOLE		01
06	0531055319	ALPHA II FERTILIZER METERING	40	06
07	0501218487	3/4 X 390 AXLE		03
08	0531057908	SLEEVE 1/4 X 2		06
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010010	SPLIT PIN 1/4" X 2.1/2"		01
09	0501218684	3/4 X 330 AXLE		01
10	0501218873	3/4 X 484 AXLE		02




Item	Code	Description	See page	QT
01	0531061698	LEFT HOPPER SUPPORT - 5345		01
02	0501053788	3/4" SQUARE AXLE FASTENER	39	04
03	0503031527	AGRICULTURAL BEARING		04
04	0531057913	DOUBLE BEARING ASSEMBLY		01
05	0501218849	3/4 X 143/145 AXLE WITH HOLE		01
06	0531055319	ALPHA II FERTILIZER METERING	40	06
07	0501218487	3/4 X 390 AXLE		03
08	0531057908	SLEEVE 1/4 X 2		06
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010010	SPLIT PIN 1/4" X 2.1/2"		01
09	0501218684	3/4 X 330 AXLE		01
10	0501218873	3/4 X 484 AXLE		02




Item	Code	Description	See page	QT
01	0531059665	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 5745	37	01
02	0531055589	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 5745	38	01
03	0503062391	FERTILIZER HOPPER	48	02
04	0503013751	3/8 UNC X 1.1/4 BOLT		20
05	0571019051	FIXER HOPPER WASHER		20
06	0503012535	3/8" SPRING WASHER		20
07	0503012531	3/8" INOX NUT		20
08	0503011957	NYLON HANDLE		02
09	0503018441	5/16" X 1-1/4" BOLT		04
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
11	0503010337	NUT 5/16 UNC G.5 ZN		04
12	0503010849	3/8" X 1-1/2" BOLT		14
13	0501010984	10,50 X 27 X 3,00 FLAT WASHER		28
14	0503010025	3/8 SPRING WASHER		14
15	0503010026	3/8" NUT		14
16	0503062362	FERTILIZER HOPPER	47	01




Item	Code	Description	See page	QT
01	0531064286	RIGHT HOPPER SUPPORT - 5745		01
02	0501053788	3/4" SQUARE AXLE FASTENER	39	03
03	0503030303	SUPPORT WASHER		03
04	0531057913	DOUBLE BEARING ASSEMBLY		01
05	0501218487	3/4 X 390 AXLE		06
06	0531055319	ALPHA II FERTILIZER METERING	40	07
07	0501310854	3/4 X 520 AXLE		01
08	0531057908	SLEEVE 1/4 X 2		06
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010010	SPLIT PIN 1/4" X 2.1/2"		01



Item	Code	Description	See page	QT
01	0531064285	LEFT HOPPER SUPPORT - 5745		01
02	0501053788	3/4" SQUARE AXLE FASTENER	39	03
03	0503030303	SUPPORT WASHER		03
04	0531057913	DOUBLE BEARING ASSEMBLY		01
05	0501218487	3/4 X 390 AXLE		06
06	0531055319	ALPHA II FERTILIZER METERING	40	07
07	0501310854	3/4 X 520 AXLE		01
08	0531057908	SLEEVE 1/4 X 2		06
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010010	SPLIT PIN 1/4" X 2.1/2"		01



Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	TRANSMISSION HUB ASSY	41	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	42	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513011170	ALLEN SCREW 1/4 UNC X 7/8 CCSI STAINLESS STEEL		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501310211	FRONT LID		01
19	0503036177	LID CORD		01
20	0531059139	COLLECTOR ASSY	43	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02




**PST PLUS FLEX TITANIUM - FRAME 5345/5745 - CSU (FROM
ALPHA II FERTILIZER METERING**

Page 40
0531055319


Item	Code	Description	See page	QT
23	0501111195	GRANULATED FERTILIZER COATING		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO DECAL		01
15	0503035316	LUBRICATED POINTS DECAL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT FERTILIZER METERING LID GUIDE		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	44	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007		02
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0503010337	NUT 5/16 UNC G.5 ZN		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0531057901	GEAR	46	01
07	0503010845	501035 CLAMPING RING (FOR AXLE)		01
08	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531065402	GEAR		01
02	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0503034085	BEAN FERTILIZER ASSY		01
02	0503034086	HOPPER LID		01
03	0503034087	LID ARTICULATING TUBE		02
04	0503034088	WASHER		04
05	0503010131	3/16" X 1.1/2" SPLIT PIN		04
06	0503034130	PLATE		01
07	0503032053	BOLT C.A.S.I		04
08	0503034220	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0503034127	FERTILIZER HOPPER		01
02	0503034129	LOWER HOPPER LID		01
03	0503034128	UPPER HOPPER LID		01
04	0503034130	PLATE		01
05	0503032053	BOLT C.A.S.I		04
06	0503034220	FLAT WASHER		04
07	0503034087	LID ARTICULATING TUBE		04
08	0503034088	WASHER		08
09	0503010131	3/16" X 1.1/2" SPLIT PIN		08




Item	Code	Description	See page	QT
01	0511057919	2 HOPPERS WITH 11 CONDUCTORS SET	50	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
05	0503010025	3/8 SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8" UNC SELF LOCKING NUT		08
10	0571019395	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8 SPRING WASHER		16
14	0503010026	3/8" NUT		16
15	0521066211	PROTECTOR CENTRAL		01
16	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
17	0501013519	FLAT WASHER		04
18	0503010019	1/2" SPRING WASHER		04
19	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR	59	11
06	0571015773	SUPPORT SEED		03
07	0501011643	3/8 X 1" BOLT		12
08	0501010942	3/8" X 1-1/4" BOLT		44
09	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02




Item	Code	Description	See page	QT
01	0511058724	2 HOPPERS WITH 12 CONDUCTORS ASSEMBLY	52	01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
05	0503010025	3/8 SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8" UNC SELF LOCKING NUT		08
10	0571019395	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8 SPRING WASHER		16
14	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR	59	12
06	0571015773	SUPPORT SEED		02
07	0501011643	3/8 X 1" BOLT		08
08	0501010942	3/8" X 1-1/4" BOLT		48
09	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02




Item	Code	Description	See page	QT
01	0511058724	2 HOPPERS WITH 12 CONDUCTORS ASSEMBLY	52	01
02	0511058510	FIXER SUPPORT	58	04
02A	0521067305	FIXER SUPPORT		01
02B	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02C	0503017857	BOLT 5/8 UNF 4		04
02D	0503010811	5/8" UNF SELF ADJUSTING NUT		04
02E	0501010942	3/8" X 1-1/4" BOLT		04
02F	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
02G	0503010025	3/8 SPRING WASHER		04
02H	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0531057980	SINGLE SEED SET C3 - 13 CONDUCTORS	55	01
02	0511058510	FIXER SUPPORT	58	04




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		04
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0531057950	3" X 175 SEED NOZZLE WITH FIXING	56	13
06	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02
07	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
08	0531054471	CAP WITH FIXING	57	01




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID		01
02	0501010942	3/8" X 1-1/4" BOLT		05
03	0503010025	3/8 SPRING WASHER		05
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	NUT 5/16 UNC G.5 ZN		02
11	0502012767	SEED NOZZLE FIXER SUPPORT		01
12	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0571015773	SUPPORT SEED		01
02	0501011643	3/8 X 1" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521067305	FIXER SUPPORT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
07	0503010025	3/8 SPRING WASHER		04
08	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8 SPRING WASHER		01
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	NUT 5/16 UNC G.5 ZN		02
11	0502012767	SEED NOZZLE FIXER SUPPORT		01



Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING	61	01
03A	0502012030	HOUSING BEARING		01
03B	0503012861	6006 2RS BALL BEARING		01
03C	0503012858	502075 CLAMPING RING (FOR HOLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	NUT 5/16 UNC G.5 ZN		02
07	0501013518	FLAT WASHER		02
08	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02




Item	Code	Description	See page	QT
01	0502012030	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		01
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8" UNC SELF LOCKING NUT		06
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
12	0511058449	HYDRAULIC CYLINDER	64	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" SPLIT PIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501066949	1235 TURNBUCKLE		02
21	0503011854	5/8" X 1-1/4" BOLT		04
22	0501054649	HBM SEQUENTIAL VALVE	65	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
25	0503010025	3/8 SPRING WASHER		02
26	0511057383	HOSE KIT MARKER HYDRAULIC		01
26A	0501080403	3/8" X 137" TR-TR HOSE ASSY		02
26B	0501080390	3/8" X 150" TR-TC HOSE ASSY		02
26C	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
26CA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01

Item	Code	Description	See page	QT
26CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
26CD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
26D	0521052850	3/8 X 4200 TC-TM PURPLE/BLUE HOSE		01
26DA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
26DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26DD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	66	02
28	0502012702	BODY SUPPORT CLAMP		06
29	0531011180	UPPER BODY CLIP		04
30	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		06
31	0503010180	7/16" SPRING WASHER		06
32	0503010244	7/16" NUT		02
33	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
34	0581010011	VALVE FIXING SUPPORT		01




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8" UNC SELF LOCKING NUT		04
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0511061811	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
12	0503012412	5/8" UNC SELF LOCKING NUT		02
13	0511058449	HYDRAULIC CYLINDER	64	02
14	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
15	0503010523	1/4" X 2" SPLIT PIN		02
16	0511015779	1" X 4.2" AXLE		02
17	0503010523	1/4" X 2" SPLIT PIN		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	8,30 X 78 LOCK PIN		02
20	0503030168	HITCH PIN CLIP		02
21	0501066949	1235 TURNBUCKLE		02
22	0503011854	5/8" X 1-1/4" BOLT		04
23	0501054649	HBM SEQUENTIAL VALVE	65	01
24	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
25	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
26	0503010025	3/8 SPRING WASHER		02
27	0521050113	HYDRAULIC MARKER HAND SET		01
27A	0501082108	TR-TR HOSE		02
27B	0501080605	3/8" X 160" TR-TC HOSE ASSY		02
27C	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01


Item	Code	Description	See page	QT
27CA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
27CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
27CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
27CD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
27D	0521052850	3/8 X 4200 TC-TM PURPLE/BLUE HOSE		01
27DA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
27DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
27DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
27DD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
28	0501053834	MALE QUICK COUPLER	66	02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		06
32	0503010180	7/16" SPRING WASHER		06
33	0503010244	7/16" NUT		02
34	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
35	0581010011	VALVE FIXING SUPPORT		01




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	O'RING 2-119 N 3006 9B		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	REPAIR KIT ASSY (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCEL VALVE		01
02	0501010617	NIPLE 3/4" NF X 3/4" NF HEX. 7/8" X 44		02
03	0503010190	2-114 N 3006-9B O-RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O-RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	68	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER 5/16"		04
16	0503010337	NUT 5/16 UNC G.5 ZN		04




Item	Code	Description	See page	QT
01	0581011989	SIDE BODY FIXER PLATFORM		01
02	0551019884	45 X 50 X 3/8 FASTENER		01
03	0503010025	3/8 SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1" BOLT		02
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0503034115	PST PLUS FLEX DECAL		01
02	0503034114	TATU LOGO DECAL		02
03	0503033892	TATU LOGO DECAL		01
04	0503034258	PST PLUS FLEX DECAL		01
05	0503033417	NUMBER 3 DECAL		02
06	0503033418	NUMBER 4 DECAL		02
07	0503033419	NUMBER 5 DECAL		04
08	0503031428	READ MANUAL DECAL		01
09	0503031942	MANUAL SEAL DECAL		01
10	0503035927	P27 FERTILIZER TABLE DECAL		02
11	0503031565	CAUTION TRANSPORTATION DECAL		02
12	0503031566	ATTENTION JACK DECAL		02
13	0503032997	SEED DISTRIBUTION TABLE DECAL		02
14	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL		02
15	0503031424	ATTENTION HYDRAULIC MARKER DECAL		02
16	0503033012	RIGHT GEAR BOX SEED/FERTILIZER DECAL		01
17	0503033013	LEFT GEAR BOX SEED/FERTILIZER DECAL		01
18	0503032930	DANGER DECAL		06
19	0503031087	AUTO CONTROL APPROVED DECAL		01
20	0503034003	61 X 118 SERIAL NUMBER TAG		01
21	0503010001	RIVET 3,2 X 5,5		04
22	0503032979	LETTERS A B C D DECAL		02
23	0503034500	GRIP COLORS (PLANTERS) DECAL		01



Item	Code	Description	See page	QT
01	0503034228	ADHESIVE LABEL PST FLEX PLUS LOWER (05 NOZZLES)		02
02	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		02
03	0503033892	TATU LOGO DECAL		01
04	0503034258	PST PLUS FLEX DECAL		01
05	0503034114	TATU LOGO DECAL		01
06	0503033418	NUMBER 4 DECAL		02
07	0503033419	NUMBER 5 DECAL		04
08	0503033421	NUMBER 7 DECAL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	MANUAL SEAL DECAL		01
11	0503035927	P27 FERTILIZER TABLE DECAL		02
12	0503031565	CAUTION TRANSPORTATION DECAL		02
13	0503031566	ATTENTION JACK DECAL		02
14	0503032997	SEED DISTRIBUTION TABLE DECAL		02
15	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL		02
16	0503031424	ATTENTION HYDRAULIC MARKER DECAL		02
17	0503033012	RIGHT GEAR BOX SEED/FERTILIZER DECAL		01
18	0503033013	LEFT GEAR BOX SEED/FERTILIZER DECAL		01
19	0503032930	DANGER DECAL		07
20	0503031087	AUTO CONTROL APPROVED DECAL		01
21	0503034003	61 X 118 SERIAL NUMBER TAG		01
22	0503010001	RIVET 3,2 X 5,5		04
23	0503032979	LETTERS A B C D DECAL		02
24	0503034500	GRIP COLORS (PLANTERS) DECAL		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" SPLIT PIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	23	04
13	0571018909	MOTOR SHAFT 2600		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	75	02
16	0511051434	TRANSMISSION ACTUATOR	76	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	77	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	78	01
19	0511058383	GEARBOX RIGHT/LEFT ASSY		01
20	0511061759	22Z P12,70 FQ 3/4" GEAR		02
21	0501053788	3/4" SQUARE AXLE FASTENER	39	02
22	0503030303	SUPPORT WASHER		04
23	0501056271	GEARBOX CLOSED BEARING		02
24	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
25	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
26	0503010025	3/8 SPRING WASHER		04
27	0503010026	3/8" NUT		04
28	0511059238	CHAIN TENSIONER		02
29	0521010773	0.37" X 1.18" COUPLING SHAFT		02
30	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06

Item	Code	Description	See page	QT
31	0503010140	1/8" X 3/4" SPLIT PIN		02
32	0571018846	DISASSEMBLE LEVER		02
33	0503033942	COMPACTOR WHEEL REGULATOR LID		02
34	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
35	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
36	0503030093	TRACTION SPRING		02
37	0503012407	5/8" X 1-1/2" BOLT		04
37.	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
38	0503012412	5/8" UNC SELF LOCKING NUT		04
39	0511061759	22Z P12,70 FQ 3/4" GEAR		02
40	0503030275	AGRICULTURAL BEARING		02
41	0511065209	20Z GEAR		02
42	0503011336	1/2" HEX SELF ADJUSTING NUT		04
43	0503010292	701164 6 X 40 SPRING PIN		02
44	0521018630	1.4" X SQUARE 0.8" WASHER		02
45	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	80	02
46	0511050652	CHAIN TENSIONER	81	04
47	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	82	02
48	0511057265	TRANSMISSION CHAIN TENSIONER	79	01
49	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
50	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
51	0503015001	40-1 X 153 CHAIN LINK + MENDING		02
52	0511069678	LH LOWER LEVER		02
53	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
54	0503010140	1/8" X 3/4" SPLIT PIN		04
55	0551019159	LEVER FIXER BODY		02
56	0561016468	FASTENER		02




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" SPLIT PIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	23	04
13	0581012892	MOTOR SHAFT		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	75	02
16	0511051434	TRANSMISSION ACTUATOR	76	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	77	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	78	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		02
20	0501053788	3/4" SQUARE AXLE FASTENER	39	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING		02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
25	0503010025	3/8 SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	79	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
30	0503010140	1/8" X 3/4" SPLIT PIN		02


Item	Code	Description	See page	QT
31	0571018846	DISASSEMBLE LEVER		02
32	0503033942	COMPACTOR WHEEL REGULATOR LID		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
37	0503012412	5/8" UNC SELF LOCKING NUT		04
38	0511061759	22Z P12,70 FQ 3/4" GEAR		02
39	0501053788	3/4" SQUARE AXLE FASTENER	39	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING		02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
44	0503010025	3/8 SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	79	02
47	0511065209	20Z GEAR		02
48	0501053788	3/4" SQUARE AXLE FASTENER	39	02
49	0503030303	SUPPORT WASHER		02
50	0503010292	701164 6 X 40 SPRING PIN		02
51	0521018630	1.4" X SQUARE 0.8" WASHER		02
52	0501056271	GEARBOX CLOSED BEARING		02
53	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
54	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
55	0503010025	3/8 SPRING WASHER		04
56	0503010026	3/8" NUT		04
57	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	80	02
58	0511050652	CHAIN TENSIONER	81	04
59	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	82	02
60	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
61	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
62	0503015001	40-1 X 153 CHAIN LINK + MENDING		02
63	0511069678	LH LOWER LEVER		02
64	0551019159	LEVER FIXER BODY		02
65	0561016468	FASTENER		02
66	0503011336	1/2" HEX SELF ADJUSTING NUT		04
67	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
68	0503010140	1/8" X 3/4" SPLIT PIN		04
69	0521055335	RIGHT GEAR HOUSING SET	84	01
70	0521055337	LEFT GEAR HOUSING SET	86	01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	NUT 5/16 UNC G.5 ZN		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
05	0501019734	FLAT WASHER		02
06	0502010710	RIGHT CAM, SMALLER		02
07	0503010003	1845 GREASE FITTING		02
08	0502012539	26Z P12,7 GEAR		01
09	0501019735	FLAT WASHER		01
10	0521017593	FLAT WASHER		01
11	0503010542	501045 CLAMPING RING (FOR AXLE)		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 CSPP G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0541011713	TENSIONER CHAIN LOWER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551019171	CHAIN TIGHTENER AXLE		01
02	0503011410	ROLLER BEARING		01
03	0511062169	21Z P 1/2" GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503011105	SEAL RING		01
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0571010265	16.5 X 40 X 3 FLAT WASHER		01
08	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	83	01
02	0511063185	20Z GEAR WITH HEX HOLE AXLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	NUT 5/16 UNC G.5 ZN		02



Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		02
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0511058381	RIGHT GEAR HOUSING	85	01
02	0521065955	RIGHT GEARBOX LID		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0503010019	1/2" SPRING WASHER		01
07	0501010694	FLAT WASHER 32,50 X 75 X 4,75		06
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01



Item	Code	Description	See page	QT
01	0521065939	RIGHT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN SHAFT		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	88	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING		03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER 32,50 X 75 X 4,75		06
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
15	0503010337	NUT 5/16 UNC G.5 ZN		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TIGHTENER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	89	02
20	0503031366	RIGHT TWISTED SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	90	01


Item	Code	Description	See page	QT
31	0503010292	701164 6 X 40 SPRING PIN		08
32	0511057258	TENSIONER WITH GEAR	92	01
33	0511054363	CHAIN TENSIONER	93	01
34	0571018901	DRIVEN AXLE		01



Item	Code	Description	See page	QT
01	0511058382	LEFT GEAR HOUSING	87	01
02	0521065956	LEFT GEARBOX LID		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
07	0503010019	1/2" SPRING WASHER		01
08	0501010694	FLAT WASHER 32,50 X 75 X 4,75		06


LEFT GEAR HOUSING

0511058382




Item	Code	Description	See page	QT
01	0521065940	LEFT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN SHAFT		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	88	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING		03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER 32,50 X 75 X 4,75		06
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
15	0503010337	NUT 5/16 UNC G.5 ZN		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TIGHTENER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	89	02
20	0503031367	SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	90	01


Item	Code	Description	See page	QT
31	0503010292	701164 6 X 40 SPRING PIN		08
32	0511057258	TENSIONER WITH GEAR	92	01
33	0511054363	CHAIN TENSIONER	93	01
34	0571018901	DRIVEN AXLE		01




Item	Code	Description	See page	QT
01	0502011978	CENTRAL BEARING GEARBOX		01
02	0503013462	6005 2RS1 ROLLER BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0501056444	ROLLER BEARING	91	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX SUPPORT		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0571019207	DEVIATION AXLE GEAR BOX		01
06	0503010899	5/8 UNC X 2.1/4 BOLT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503060100	SUPPORT INSTRUCTION MANUAL		01
02	0503010267	NYLON CLAMP 3,60 X 1,3 X 155 MM		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER 32,50 X 75 X 4,75		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	NUT 5/16 UNC G.5 ZN		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		11
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		11
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		12
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		12
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521067033	FRAME LIFTING SUPPORT		01
03	0503017960	5/8" X 3-12" BOLT		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0503063629	SEED MONITORING KIT 12 ROWS 45/50 PM400		01
01A	0503019727	SIMPLE CABLE		01
01B	0503019100	SENSOR		12
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
01E	0503017031	CLEANING BRUSH		01
01F	0503019720	NYLON CLAMP		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010669	FLAT WASHER		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0503063619	14 ROWS SEED MONITORING KIT 45/50 PM400		01
01A	0513010217	14 ROWS CABLE FOR MESH SEED		01
01B	0503019100	SENSOR		14
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
01E	0503017031	CLEANING BRUSH		01
01F	0503019720	NYLON CLAMP		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010669	FLAT WASHER		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0511057277	FRONT SHORT SEED ROW WITH RIGHT TRANSMISSION	101	01
01.	0521056500	FRONT SHORT SEED ROW WITH RIGHT TRANSMISSION WITHOUT LUBRIFICATION	102	01
01..	0541051368	FRONT SHORT SEED ROW WITH TRANSMISSION	103	01
02	0511057278	FRONT LONG SEED ROW WITH RIGHT TRANSMISSION	104	01
02.	0521056501	FRONT LONG SEED ROW WITH RIGHT TRANSMISSION WITHOUT LUBRIFICATION	105	01
02..	0541051369	FRONT LONG SEED ROW WITH TRANSMISSION	106	01
03	0511056621	RIGHT REAR SEED ROW	112	01
03.	0521054770	RIGHT REAR SEED ROW	113	01
04	0511056622	LEFT REAR SEED ROW	120	01
04.	0521054771	LEFT REAR SEED ROW	121	01
05	0531055312	TITANIUM SINGLE SEED SYSTEM	157	01
06	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	161	01
06.	0521052626	SYSTEM DEEP WHEEL / COMPACTOR RAPID IRON ADJUSTMENT	171	01
06..	0531054532	WHEEL SYSTEM DEPTH / COMPACTOR	177	01
07	0511058639	SHORT FERTILIZER ROW WITH DDD/DC20	130	01
07.	0511059051	SHORT FERTILIZER ROW	131	01
07..	0521050064	SHORT FERTILIZER ROW WITH DAOC/DC 20"	145	01
07...	0541051332	SHORT FERTILIZER LINE	146	01
08	0511058640	LONG FERTILIZER ROW WITH DDD/DC20	132	01
08.	0511059052	SHORT ROW FERTILIZER	133	01
08..	0521050065	LONG FERTILIZER ROW WITH DAOC/DC 20"	150	01
08...	0541051333	LONG FERTILIZER ROW	151	01
09	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0531059865	RIGHT SEED CONDUCTOR WITH PROTECTION		01

Item	Code	Description	See page	QT
13	0531050237	3" RIGHT SEED CONDUCTOR FIXER	179	01
14	0503030391	RIGHT FERTILIZER NOZZLE		01
15	0503030392	LEFT FERTILIZER NOZZLE		01
16	0503031145	2" X 2" X 20" HOSE		01
17	0503031076	2" HOSE CLAMP		01
18	0531013600	PRESS ADJUSTMENT LEVER		01
19	0501110804	SCARIFIER ROD WITH POINT	178	01
20	0511017969	0.1" SPACING PLATE		01
21	0511018662	SPACING PLATE		01
22	0521069127	BOTTOM NOZZLE FERTILIZER		01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
25	0503010025	3/8 SPRING WASHER		01
26	0503010026	3/8" NUT		01
27	0503031050	CURVED CONDUCTOR		01
28	0503010246	CLAMP		01
29	0503062066	DISC SET WITH CORN RING	181	01
30	0503062067	DISC SET / RING SOY 90F TITANIUM	182	01
31	0511052024	FAST CLOSING SET	183	01
32	0503033672	NOZZLE WITHOUT TITANIUM		01
33	0531052986	PIVOT SUPPORT	180	01
34	0503030520	SEED SOCKET		01
35	0503010905	1/2" X 2-1/4" BOLT		01
36	0503010019	1/2" SPRING WASHER		01
37	0503010060	1/2 UNC G.5 ZN HEX NUT		01
38	0521057957	FIXED ROD EXTENSION WITH FIXATION	184	01
39	0511057984	V-COVERING RUBBER WHEEL - SHORT ROW	185	01
40	0511057985	V-COVERING RUBBER WHEEL - LONG ROW	186	01
41	0521054769	LEFT DDD FERTILIZER WITH SUPPORT	187	01
42	0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	188	01



Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0502012804	PIVOT ARM SEED ROW		02
05	0571018882	SEED ROW ARM SLEEVE		08
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8" UNC SELF LOCKING NUT		04
08	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
09	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
10	0571018883	PIN FIXER SPRING		03
11	0571018884	ARTICULATION ROW LOCK PIN		01
12	0503030168	HITCH PIN CLIP		04
13	0511058766	BEARING	107	01
14	0511057159	TRANSMISSION HOPPER SEED ROW	108	01
15	0571012492	5/8 X 330 AXLE HEX		01
16	0501056296	UNIVERSAL JOINT		01
17	0503011855	0.2" X 1.8" SPRING PIN		03
18	0521065942	FRAME REAR SHORT ROW SEED		01
19	0511057269	CHAIN TENSIONER	111	01
20	0511059872	BEARING	110	01
21	0581010239	SEED ROW AXLE TRANSMISSION		01
22	0521011859	FLAT WASHER		02
23	0581011694	PROTECTION REAR COVER SEED ROW		01
24	0503010765	3/8" X 3" BOLT		01
25	0503010025	3/8 SPRING WASHER		01
26	0503010026	3/8" NUT		01
27	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		08
28	0511058512	PROTECTION LID	109	01
29	0581011430	DRAWBAR ASSY		01
30	0581010976	5/8" HEX AXLE		01

Item	Code	Description	See page	QT
31	0503032984	HOOD HEX AXLE ROW		01
32	0503010004	1890 GREASE FITTING		04
33	0503013100	NYLON CLAMP 4,8 X 1,3 X 200 MM		01
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
35	0503017857	BOLT 5/8 UNF 4		04




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
05	0503012412	5/8" UNC SELF LOCKING NUT		04
06	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
07	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
08	0571018883	PIN FIXER SPRING		03
09	0571018884	ARTICULATION ROW LOCK PIN		01
10	0503030168	HITCH PIN CLIP		04
11	0511058766	BEARING	107	01
12	0511057159	TRANSMISSION HOPPER SEED ROW	108	01
13	0571012492	5/8 X 330 AXLE HEX		01
14	0501056296	UNIVERSAL JOINT		01
15	0503011855	0.2" X 1.8" SPRING PIN		03
16	0521065942	FRAME REAR SHORT ROW SEED		01
17	0511059872	BEARING	110	01
18	0581010239	SEED ROW AXLE TRANSMISSION		01
19	0521011859	FLAT WASHER		02
20	0581011694	PROTECTION REAR COVER SEED ROW		01
21	0503010765	3/8" X 3" BOLT		01
22	0503010025	3/8 SPRING WASHER		01
23	0503010026	3/8" NUT		01
24	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		08
25	0511058512	PROTECTION LID	109	01
26	0581011430	DRAWBAR ASSY		01
27	0581010976	5/8" HEX AXLE		01
28	0503032984	HOOD HEX AXLE ROW		01
29	0503013100	NYLON CLAMP 4,8 X 1,3 X 200 MM		01
30	0503013215	40-1 CHAIN X 89 LINK + MENDING		01



**PST PLUS FLEX TITANIUM - FRAME 5345/5745 - CSU (FROM
FRONT SHORT SEED ROW WITH RIGHT TRANSMISSION**


Page 102
0521056500

Item	Code	Description	See page	QT
31	0511057269	CHAIN TENSIONER	111	01
32	0503017857	BOLT 5/8 UNF 4		04
33	0591011156	PIVOT ARM SEED ROW		02
34	0591011157	SPACER LOWER SLEEVE		08
35	0503019273	AUTO LUBRICANT SLEEVE		08
36	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
05	0503012412	5/8" UNC SELF LOCKING NUT		04
06	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
07	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
08	0571018883	PIN FIXER SPRING		03
09	0571018884	ARTICULATION ROW LOCK PIN		01
10	0503030168	HITCH PIN CLIP		04
11	0511057159	TRANSMISSION HOPPER SEED ROW	108	01
12	0571012492	5/8 X 330 AXLE HEX		01
13	0501056296	UNIVERSAL JOINT		01
14	0503011855	0.2" X 1.8" SPRING PIN		02
15	0521065942	FRAME REAR SHORT ROW SEED		01
16	0511059872	BEARING	110	01
17	0581010239	SEED ROW AXLE TRANSMISSION		01
18	0521011859	FLAT WASHER		02
19	0503010765	3/8" X 3" BOLT		01
20	0503010025	3/8 SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		08
23	0511058512	PROTECTION LID	109	01
24	0581011430	DRAWBAR ASSY		01
25	0581010976	5/8" HEX AXLE		01
26	0503032984	HOOD HEX AXLE ROW		01
27	0503013100	NYLON CLAMP 4,8 X 1,3 X 200 MM		01
28	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
29	0511057269	CHAIN TENSIONER	111	01
30	0503017857	BOLT 5/8 UNF 4		04

Item	Code	Description	See page	QT
31	0591011156	PIVOT ARM SEED ROW		02
32	0591011157	SPACER LOWER SLEEVE		08
33	0503019273	AUTO LUBRICANT SLEEVE		08
34	0503010045	O'RING		08
35	0511059873	TOP LEFT BEARING WITH ROW		01
36	0581012950	LEFT REAR PROTECTION SEED ROW COVER		01




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0502012804	PIVOT ARM SEED ROW		02
05	0571018882	SEED ROW ARM SLEEVE		08
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8" UNC SELF LOCKING NUT		04
08	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
09	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
10	0571018883	PIN FIXER SPRING		03
11	0571018884	ARTICULATION ROW LOCK PIN		01
12	0503030168	HITCH PIN CLIP		04
13	0511058766	BEARING	107	01
14	0511057159	TRANSMISSION HOPPER SEED ROW	108	01
15	0571012492	5/8 X 330 AXLE HEX		01
16	0501056296	UNIVERSAL JOINT		01
17	0503011855	0.2" X 1.8" SPRING PIN		03
18	0521065943	REAR FRAME LONG ROW SEED		01
19	0511057269	CHAIN TENSIONER	111	01
20	0511059872	BEARING	110	01
21	0581010240	SEED ROW AXLE TRANSMISSION		01
22	0521011859	FLAT WASHER		02
23	0581011694	PROTECTION REAR COVER SEED ROW		01
24	0503010765	3/8" X 3" BOLT		01
25	0503010025	3/8 SPRING WASHER		01
26	0503010026	3/8" NUT		01
27	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		08
28	0511058512	PROTECTION LID	109	01
29	0581011430	DRAWBAR ASSY		01
30	0581010976	5/8" HEX AXLE		01

Item	Code	Description	See page	QT
31	0503032984	HOOD HEX AXLE ROW		01
32	0503010004	1890 GREASE FITTING		04
33	0503013100	NYLON CLAMP 4,8 X 1,3 X 200 MM		01
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
35	0503017857	BOLT 5/8 UNF 4		04




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
05	0503012412	5/8" UNC SELF LOCKING NUT		04
06	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
07	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
08	0571018883	PIN FIXER SPRING		03
09	0571018884	ARTICULATION ROW LOCK PIN		01
10	0503030168	HITCH PIN CLIP		04
11	0511058766	BEARING	107	01
12	0511057159	TRANSMISSION HOPPER SEED ROW	108	01
13	0571012492	5/8 X 330 AXLE HEX		01
14	0501056296	UNIVERSAL JOINT		01
15	0503011855	0.2" X 1.8" SPRING PIN		03
16	0521065943	REAR FRAME LONG ROW SEED		01
17	0511059872	BEARING	110	01
18	0581010240	SEED ROW AXLE TRANSMISSION		01
19	0521011859	FLAT WASHER		02
20	0581011694	PROTECTION REAR COVER SEED ROW		01
21	0503010765	3/8" X 3" BOLT		01
22	0503010025	3/8 SPRING WASHER		01
23	0503010026	3/8" NUT		01
24	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		08
25	0511058512	PROTECTION LID	109	01
26	0581011430	DRAWBAR ASSY		01
27	0581010976	5/8" HEX AXLE		01
28	0503032984	HOOD HEX AXLE ROW		01
29	0503013100	NYLON CLAMP 4,8 X 1,3 X 200 MM		01
30	0503013215	40-1 CHAIN X 89 LINK + MENDING		01

Item	Code	Description	See page	QT
31	0511057269	CHAIN TENSIONER	111	01
32	0503017857	BOLT 5/8 UNF 4		04
33	0591011156	PIVOT ARM SEED ROW		02
34	0591011157	SPACER LOWER SLEEVE		08
35	0503019273	AUTO LUBRICANT SLEEVE		08
36	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
05	0503012412	5/8" UNC SELF LOCKING NUT		04
06	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
07	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
08	0571018883	PIN FIXER SPRING		03
09	0571018884	ARTICULATION ROW LOCK PIN		01
10	0503030168	HITCH PIN CLIP		04
11	0511057159	TRANSMISSION HOPPER SEED ROW	108	01
12	0571012492	5/8 X 330 AXLE HEX		01
13	0501056296	UNIVERSAL JOINT		01
14	0503011855	0.2" X 1.8" SPRING PIN		02
15	0521065943	REAR FRAME LONG ROW SEED		01
16	0511059872	BEARING	110	01
17	0581010240	SEED ROW AXLE TRANSMISSION		01
18	0521011859	FLAT WASHER		02
19	0503010765	3/8" X 3" BOLT		01
20	0503010025	3/8 SPRING WASHER		01
21	0503010026	3/8" NUT		01
22	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		08
23	0511058512	PROTECTION LID	109	01
24	0581011430	DRAWBAR ASSY		01
25	0581010976	5/8" HEX AXLE		01
26	0503032984	HOOD HEX AXLE ROW		01
27	0503013100	NYLON CLAMP 4,8 X 1,3 X 200 MM		01
28	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
29	0511057269	CHAIN TENSIONER	111	01
30	0503017857	BOLT 5/8 UNF 4		04


Item	Code	Description	See page	QT
31	0591011156	PIVOT ARM SEED ROW		02
32	0591011157	SPACER LOWER SLEEVE		08
33	0503019273	AUTO LUBRICANT SLEEVE		08
34	0503010045	O'RING		08
35	0511059873	TOP LEFT BEARING WITH ROW		01
36	0581012950	LEFT REAR PROTECTION SEED ROW COVER		01




Item	Code	Description	See page	QT
01	0502012852	ROW SEED UPPER BEARING		01
02	0503011105	SEAL RING		01
03	0502012851	17Z GEAR WITH HEX HOLE		01
04	0503011410	ROLLER BEARING		02
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010237	3/8" X 1" BOLT		02
07	0503010025	3/8 SPRING WASHER		02
08	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6 X 1 X 16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS DECAL		01




Item	Code	Description	See page	QT
01	0521066693	CAP BEARING		01
02	0503010834	1/2 X 1 BOLT		02
03	0503010019	1/2" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0581012948	HOUSING BEARING		01
02	0503011105	SEAL RING		01
03	0581012949	BEARING COVER		01
04	0503011410	ROLLER BEARING		02
05	0503018045	2-130 (AGEL) O'RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0502012851	17Z GEAR WITH HEX HOLE		01
08	0503011953	5/16" X 1" BOLT		02
09	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
11	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0503031805	11Z 1/2" GEAR		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0511051888	5/8 ASSY TITANIUM SYSTEM FIXING BASE	129	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	SPRING WASHER 3/8"		04
04	0503010026	3/8" NUT		04
05	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	123	01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	114	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521055870	RIGHT DOUBLE DISC SEED 15 X 15	115	01




Item	Code	Description	See page	QT
01	0581019201	CROWN SHAFT		01
02	0503019340	LUBRICANT SLEEVE		02
03	0503011030	2-014 N 3006-9B O'RING		02
04	0581019200	CONICA 40Z GEAR		01
05	0581019199	FIXED BASE		01
06	0581019202	10Z X 5/8" CONICAL PINION		01
07	0501013354	FLAT WASHER		01
08	0503010410	RING		02
09	0503019341	LUBRICANT SLEEVE		01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	125	01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
06	0503010026	3/8" NUT		01
07	0503010025	3/8 SPRING WASHER		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 116 FERTILIZER / SEED		01
09	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 117 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055864	FERTILIZER/SEED RIGHT HUB ASSY	118	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055865	FERTILIZER/SEED LEFT HUB ASSY	119	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUBLE DISC AXLE		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O-RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0511051888	5/8 ASSY TITANIUM SYSTEM FIXING BASE	129	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503011443	SPRING WASHER 3/8"		04
04	0503010026	3/8" NUT		04
05	0511056586	15 X 15 SEED DDD LEFT	124	01




Item	Code	Description	See page	QT
01	0521054818	BASE 5/8 FIXATION WITHOUT ASSY LUBRICATION	114	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0521055871	LEFT DOUBLE DISC SEED 15 X 15	122	01




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	126	01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
06	0503010026	3/8" NUT		01
07	0503010025	3/8 SPRING WASHER		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 116 FERTILIZER / SEED		01
09	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 117 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	125	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	127	01
03	0511053172	LEFT LOW HUB WITH 15 DISC	128	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	126	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	127	01
03	0511053172	LEFT LOW HUB WITH 15 DISC	128	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUBLE DISC AXLE		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	NUT 5/16 UNC G.5 ZN		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	NUT 5/16 UNC G.5 ZN		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502012639	12Z LOWER CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	134	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057272	LH SHORT ARM ROW FERTILIZER	136	01
06	0511058630	20" DISC BLADE	140	01




Item	Code	Description	See page	QT
01	0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	134	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057272	LH SHORT ARM ROW FERTILIZER	136	01
06	0511059050	DOC 20" ASSY	143	01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	135	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057271	RH LONG ARM ROW FERTILIZER	137	01
06	0511058630	20" DISC BLADE	140	01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	135	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057271	RH LONG ARM ROW FERTILIZER	137	01
06	0511059050	DOC 20" ASSY	143	01




Item	Code	Description	See page	QT
01	0502012794	SHORT SUPPORT FERTILIZER ROW		01
02	0503011854	5/8" X 1-1/4" BOLT		02
03	0503010002	1800 GREASE FITTING		01
04	0502012789	FIXER SUPPORT FERTILIZER ROW		01
05	0503017960	5/8" X 3-12" BOLT		04
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
08	0571019062	SLEEVE		01
09	0571019059	SUPPORT WASHER		01
10	0503010417	7/8" NUT		04
11	0503034320	COMPRESSION SPRING		01
12	0502012813	FLANGE WASHER SPRING		01




Item	Code	Description	See page	QT
01	0502012795	SUPPORT LONG		01
02	0503011854	5/8" X 1-1/4" BOLT		02
03	0503010002	1800 GREASE FITTING		01
04	0502012789	FIXER SUPPORT FERTILIZER ROW		01
05	0503017960	5/8" X 3-12" BOLT		04
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
08	0571019062	SLEEVE		01
09	0571019059	SUPPORT WASHER		01
10	0503010417	7/8" NUT		04
11	0503034320	COMPRESSION SPRING		01
12	0502012813	FLANGE WASHER SPRING		01




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	139	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	138	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	127	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	128	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	128	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	127	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0571018989	LH BLADE DISC ARM		01
02	0502012790	LOCK NUT		01
03	0511058648	HUB WITH 20" DISC BLADE	141	01
04	0521065978	RIGHT ARM WITH WASHER LOCK		01
05	0571019035	SLEEVE SUPPORT ARM		01
06	0521010452	SLEEVE		01
07	0521066743	SPRING REGULATOR		01
08	0503010417	7/8" NUT		04
09	0571019033	FIXATION AXLE		01
10	0503034319	LOCK PIN		01
11	0502012813	FLANGE WASHER SPRING		01
12	0503034320	COMPRESSION SPRING		01
13	0571019032	SUPPORT WASHER		01
14	0571019034	FLANGE WASHER AXLE		02
15	0503010002	1800 GREASE FITTING		01
16	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		01
17	0503011255	3/4" LOCK NUT		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503011440	SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	142	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0502012793	DISC HUB		01
02	0571018047	DISC BLADE HUB AXLE		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DUST CLOAK		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	FLAT WASHER 32,50 X 75 X 4,75		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0571018989	LH BLADE DISC ARM		01
02	0502012790	LOCK NUT		01
03	0511058838	20" WAVY COULTER BLADE HUB	144	01
04	0521065978	RIGHT ARM WITH WASHER LOCK		01
05	0571019035	SLEEVE SUPPORT ARM		01
06	0521010452	SLEEVE		01
07	0521066743	SPRING REGULATOR		01
08	0503010417	7/8" NUT		04
09	0571019033	FIXATION AXLE		01
10	0503034319	LOCK PIN		01
11	0502012813	FLANGE WASHER SPRING		01
12	0503034320	COMPRESSION SPRING		01
13	0571019032	SUPPORT WASHER		01
14	0571019034	FLANGE WASHER AXLE		02
15	0503010002	1800 GREASE FITTING		01
16	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		01
17	0503011255	3/4" LOCK NUT		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	142	01
02	0607026025	DPLO20X4,5		01




Item	Code	Description	See page	QT
01	0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	134	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0521050062	SHORT ARM FERTILIZER ROW	152	01
06	0511058630	20" DISC BLADE	140	01




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0503011255	3/4" LOCK NUT		02
03	0571019062	SLEEVE		01
04	0571019059	SUPPORT WASHER		01
05	0503034320	COMPRESSION SPRING		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503011854	5/8" X 1-1/4" BOLT		02
08	0511016281	3/4" X 8" BOLT		02
09	0503017960	5/8" X 3-12" BOLT		04
10	0502012813	FLANGE WASHER SPRING		01
11	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
12	0503010417	7/8" NUT		02
13	0502012789	FIXER SUPPORT FERTILIZER ROW		01
14	0541051334	FLAT DISC SMOOTH RIBBED	147	01
15	0503011254	7/8" HEX SELF ADJUSTING NUT		01
16	0591011145	FERTILIZER ROW SUPPORT		01
17	0503019278	LUBRICANT SLEEVE		02
18	0591011147	SLEEVE ARM ROW		02
19	0503011109	O'RING 2-119 N 3006 9B		02




Item	Code	Description	See page	QT
01	0571019034	FLANGE WASHER AXLE		01
02	0571019032	SUPPORT WASHER		01
03	0502012813	FLANGE WASHER SPRING		01
04	0591010619	DC SPRING SUPPORT		01
05	0503019274	WASHER		02
06	0581017628	LID		02
07	0503019277	SLEEVE LUBRICATION SYSTEM		01
08	0501110964	RIGHT ARM WITH SLEEVE		01
09	0501110965	LEFT ARM WITH SLEEVE		01
10	0503034320	COMPRESSION SPRING		01
11	0591010624	SUPPORT ARM SLEEVE		01
12	0591010625	19,50 X 25 X 91,50/91,30 SLEEVE		01
13	0503010417	7/8" NUT		02
14	0503010390	SEAL RING		02
15	0503011198	BOLT 3/4" UNC X 6" CS G.5		01
16	0501010322	FLAT WASHER		01
17	0503011411	1/2" X 5-1/2" BOLT		01
18	0503010060	1/2 UNC G.5 ZN HEX NUT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503011255	3/4" LOCK NUT		01
21	0503030430	7/16 X 2" PIN LOCK		01
22	0503019271	SELF LUBRICATING BUSHING		01
23	0521055373	HUB WITH CUTTING DISC DPLE 20 TB 60E 148 WITHOUT LUBRICATION		01
24	0503011254	7/8" HEX SELF ADJUSTING NUT		01
25	0521066743	SPRING REGULATOR		01
26	0591011144	FIXATION AXLE		01
27	0591010628	SHAFT THRUST WASHER		01




Item	Code	Description	See page	QT
01	0521053697	DISC BLADE HUB	149	01
02	0605027058	20" X 0.1771" PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	DISC BLADE HUB		01
09	0502040873	DISC BLADE AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	FLAT WASHER 32,50 X 75 X 4,75		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	135	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0521050063	RH LONG ARM ROW FERTILIZER	153	01
06	0511058630	20" DISC BLADE	140	01




Item	Code	Description	See page	QT
01	0591011146	SUPPORT LONG		01
02	0503011854	5/8" X 1-1/4" BOLT		02
03	0502012789	FIXER SUPPORT FERTILIZER ROW		01
04	0503017960	5/8" X 3-12" BOLT		04
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
07	0571019062	SLEEVE		01
08	0571019059	SUPPORT WASHER		01
09	0503010417	7/8" NUT		02
10	0503034320	COMPRESSION SPRING		01
11	0502012813	FLANGE WASHER SPRING		01
12	0521065973	RH LONG ARM ROW FERTILIZER		01
13	0511016281	3/4" X 8" BOLT		02
14	0503011255	3/4" LOCK NUT		02
15	0541051334	FLAT DISC SMOOTH RIBBED	147	01
16	0591011147	SLEEVE ARM ROW		02
17	0503019278	LUBRICANT SLEEVE		02
18	0503011109	O'RING 2-119 N 3006 9B		02
19	0503011254	7/8" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0521050061	18" WAVY COULTER BLADE ASSY	154	01
03	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
02	0521050061	18" WAVY COULTER BLADE ASSY	154	01
03	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0511057544	ASSY TURBO CUTTING DISC (18)	155	01
02	0571019645	CONDUCTOR SUPPORT		01
03	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
04	0521018517	FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01
07	0503030483	FERTILIZER SOCKET		01




Item	Code	Description	See page	QT
01	0571019636	UPPER SLEEVE		02
02	0571019637	RIGHT ARM		01
03	0571019638	LEFT ARM		01
04	0511057537	COULTER BLADE ASSY	156	01
05	0521015376	DUST CLOAK		02
06	0511015346	FLAT WASHER		02
07	0503011438	SPRING WASHER		02
08	0521013510	3/4" NUT		02




Item	Code	Description	See page	QT
01	0521013610	BLADE DISC HUB AXLE		01
02	0502011562	DISC BLADE HUB		01
03	0503011800	SEAL RING		02
04	0503012417	SEAL		02
05	0503010276	6206 BALL BEARING		02
06	0503030832	FLAT WASHER		02
07	0503011444	SPRING WASHER 5/16"		06
08	0503010691	1/4" GREASE FITTING		01
09	0503010337	NUT 5/16 UNC G.5 ZN		06
10	0502020641	BLADE DISC FLANGE		01
11	0503010371	5/16" X 1" BOLT		06
12	0607025032	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0511052058	SEED SYSTEM TITANIUM	158	01
02	0503010179	LOCK WASHER 5/16 ZN 1K01528		05
03	0503010337	NUT 5/16 UNC G.5 ZN		05
04	0501010694	FLAT WASHER 32,50 X 75 X 4,75		05
05	0503010358	5/16" X 5/8" BOLT		05
06	0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	159	01




Item	Code	Description	See page	QT
01	0503062031	BASE SET		01
02	0503062032	NECK TITANIUM ASSY		01
03	0503062033	OPPOSITE BASE SET		01
04	0503062034	CENTRAL ADAPTER SET		01
05	0503062035	SET FALSE ADAPT CENTER		01
06	0503062036	SUBSET ASSY LOCK BASE		01
07	0503062037	SUBSET ESCOVAFLEX ASSY		01
08	0503062038	ASSY ANTI-LEAP		01
09	0503062039	POLIFLOW TITANIUM ASSY		01
09.	0503016279	POLIFLOW TITANIUM ASSY		01
10	0503062040	DISPLAY ASSY TITANIUM 1050010		01
11	0503062041	TITANIUM DISPLAY PROTECTION ASSY		01
12	0503062042	SET BOLT ARTICULADOR		01
13	0503062043	ASSY LIMIT WEIGHT		01
14	0503062044	ASSEMBLY SEED HOPPER SET		01
14A	0503016285	BOLT		05
14B	0503016286	HEX NUT		05
14C	0503016287	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0503015536	M6 X 1" SELF ADJUSTING NUT		04
02	0581014295	FIXING SLEEVE		01
03	0501213431	SEED NOZZLE FIXING FLANGE		01
04	0501213520	SEED BREAKER BODY		01
05	0501213432	BREAKER SUPPORT BASE		01
06	0501213728	60 X 53 X 30 PVC TUBE		01
07	0513010720	M6 X 1 X 35 C S G.5 ZB BOLT		04
08	0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK 160 LID		01




Item	Code	Description	See page	QT
01	0503035751	SIGMA SINGLE SEED HOPPER		01
02	0503035750	SEED HOPPER LID		01
03	0503035298	BAKELITE HANDLE WITH THREAD		01
04	0503015536	M6 X 1" SELF ADJUSTING NUT		01
05	0503035297	CURVED NOZZLE SEED HOPPER		01




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	162	01
02	0501052538	DEPTH BAND WITH ARMS	167	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	168	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	169	01
07	0503033942	COMPACTOR WHEEL REGULATOR LID		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT DEPTH WHEEL ARM WITH HUB	164	01
07	0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	163	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	166	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	SPRING WASHER 3/8"		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" SPLIT PIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL HUB	165	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL HUB	165	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	PROTECTION LID		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" SPLIT PIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	170	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	170	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0581014858	DEPTH WHEEL AXLE		01
04	0501110720	ARM LEFT		01
05	0501110719	DEPTH CONTROL RIGHT ARM		01
06	0502012663	EXTENSION		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	172	01
09	0503034793	ARTICULATION SLEEVE		02
10	0521051423	COMPACTOR SUPPORT	173	01
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503016453	1/2" X 2.1/2 BOLT		02
14	0503034817	SPRING		01
15	0503010581	RING		01
16	0503034377	3/8 UNC X 3/4 BOLT		01
17	0503010019	1/2" SPRING WASHER		08
18	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
19	0503010060	1/2 UNC G.5 ZN HEX NUT		04
20	0501052957	IRON V PRESS WHEELS	174	02
21	0503013739	1/2" X 1" BOLT		01
22	0511050077	WHEEL STRIPED	175	02
23	0503010752	1/2" X 3.1/2" BOLT		01
24	0521014508	FLAT WASHER		06




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" SPLIT PIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521068003	RIGHT SIDE		01
02	0521068002	LEFT SIDE		01
03	0581014847	PLATE UPPER		01
04	0581015855	SLEEVE		02
05	0521068004	HANDLE BODY		01
06	0581014969	GUIDE SLEEVE		01
07	0581014968	SLEEVE FLANGE		01
08	0503010937	5/16" X 3" BOLT		02
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0521068005	LEVER		01
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
12	0503010337	NUT 5/16 UNC G.5 ZN		04
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2 UNC G.5 ZN HEX NUT		01
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010882	BOLT		02
17	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
18	0503030878	LEVER CRANK		01
19	0581015854	RIGHT PROTECTION COVER		01
20	0581015853	LEFT PROTECTION COVER		01
21	0581015903	SPACER WASHER		01




Item	Code	Description	See page	QT
01	0502011932	IRON PRESS WHEELS		01
02	0503010269	6204 BALL BEARING		02
03	0503011105	SEAL RING		01
04	0503013848	5072-BR SEAL		02
05	0521019147	V COMPACT WHEELS AXLE		02
06	0511011927	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	176	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	NUT 5/16 UNC G.5 ZN		06




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEEL HUB		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0581014858	DEPTH WHEEL AXLE		01
04	0501110720	ARM LEFT		01
04A	0502012726	LEFT DEPTH WHEEL ARM		01
04B	0503034375	WHEEL ARM SLEEVE		02
05	0501110719	DEPTH CONTROL RIGHT ARM		01
05A	0502012725	DEPTH WHEEL RIGHT ARM		01
05B	0503034375	WHEEL ARM SLEEVE		02
06	0502012663	EXTENSION		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	172	01
09	0521051423	COMPACTOR SUPPORT	173	01
10	0503034793	ARTICULATION SLEEVE		02
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503010019	1/2" SPRING WASHER		08
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
15	0503010060	1/2 UNC G.5 ZN HEX NUT		04
16	0501052908	COMPACTOR WHEEL WITH BEARING	170	02
17	0503013739	1/2" X 1" BOLT		01
18	0511050077	WHEEL STRIPED	175	02
19	0503016453	1/2" X 2.1/2" BOLT		02
20	0503034817	SPRING		01
21	0503010752	1/2" X 3.1/2" BOLT		01
22	0503010581	RING		01
23	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503013759	NUT		02
02	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
03	0502012979	CLAMP 3 RIGHT CSU		02
04	0503010421	5/16" X 1-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		01
02	0503010019	1/2" SPRING WASHER		01
03	0531062908	HOSE SUPPORT ARM		01
04	0531062907	ARTICULATOR HOSE		01
05	0513010322	LUBRICANT SLEEVE		01
06	0501210533	FLANGE WASHER		01
07	0503013776	BOLT 1/2 UNC X 7/8 C S G.5 ZN		01
08	0521067600	FIXER SUPPORT		01
09	0503010806	5/8" X 3" BOLT		01
10	0503012795	5/8" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0503016204	CORN DISC 12 ORANGE		01
02	0503016398	TITANIUM RING CORN / SOY (YELLOW FLAT)		01
03	0503016399	TITANIUM RING CORN (GREEN)		01
04	0503016400	TITANIUM RING CORN (GREY)		01
05	0503016401	TITANIUM RING CORN (BLUE)		01




Item	Code	Description	See page	QT
01	0503016217	SOYBEAN SEED DISC 34 OBLONG		01
02	0503016218	DISC OF SOYBEAN		01
03	0503016403	TITANIUM RING FOR SOYBEAN (LILAC)		01
04	0503016404	TITANIUM RING FOR SOYBEAN (PURPLE)		01
05	0503016406	TITANIUM RING FOR SOYBEAN (ORANGE)		01
06	0503016407	TITANIUM RING FOR SOYBEAN		01




Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" SPLIT PIN		02




Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0521066457	WHEEL SUPPORT		01
02	0531013272	0.5" X 1" X 2.2" SLEEVE		01
03	0511064128	LOWER COVER WHEEL SUPPORT		01
04	0502011757	PRESS REGULATOR		01
05	0501013491	5/8" TENSIONER SPRING		01
06	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
07	0503010752	1/2" X 3.1/2" BOLT		01
08	0503010019	1/2" SPRING WASHER		06
09	0503010060	1/2 UNC G.5 ZN HEX NUT		06
10	0503010013	NUT 5/8" UNC G.5 ZN		02
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010026	3/8" NUT		02
13	0521014508	FLAT WASHER		07
14	0501052908	COMPACTOR WHEEL WITH BEARING	170	02
15	0503010025	3/8 SPRING WASHER		02
16	0503010003	1845 GREASE FITTING		01
17	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
18	0503016864	LH 1/2" LOCK NUT		01
19	0503012136	NUT 1/2 NF		01
20	0503016449	1/2 X 4 BOLT		01
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		05
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0521066456	WHEEL SUPPORT		01
02	0531013272	0.5" X 1" X 2.2" SLEEVE		01
03	0511064128	LOWER COVER WHEEL SUPPORT		01
04	0502011757	PRESS REGULATOR		01
05	0501013491	5/8" TENSIONER SPRING		01
06	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
07	0503010752	1/2" X 3.1/2" BOLT		01
08	0503010019	1/2" SPRING WASHER		06
09	0503010060	1/2 UNC G.5 ZN HEX NUT		06
10	0503010013	NUT 5/8" UNC G.5 ZN		02
11	0503010849	3/8" X 1-1/2" BOLT		02
12	0503010026	3/8" NUT		02
13	0521014508	FLAT WASHER		07
14	0501052908	COMPACTOR WHEEL WITH BEARING	170	02
15	0503010025	3/8 SPRING WASHER		02
16	0503010003	1845 GREASE FITTING		01
17	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
18	0503016864	LH 1/2" LOCK NUT		01
19	0503012136	NUT 1/2 NF		01
20	0503016449	1/2 X 4 BOLT		01
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		05
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC	189	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC	190	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04



Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 116 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 117 FERTILIZER / SEED		01



Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 116 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 117 FERTILIZER / SEED		01



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

