

ROW CROP PLANTERS

PST4 - FRAME 3245/3695/4045/4495/4845/5345 (FROM 05/2023)

Code: 0501093620
Series: S-0116
Revision: 00
Date Revision: AGOSTO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111151169	PST4 3245/4E800 MH S-0116
0111151157	PST4 3245/5E700 MH S-0116
0111151165	PST4 3245/6E500 MH DOC20 S-0116
0111151230	PST4 3245/7E450 CI MH DC20 S-0116
0111151147	PST4 3245/7E450 D/HDA S-0116
0111151227	PST4 3245/7E450 H CI MH DC20 S-0116
0111151167	PST4 3245/7E450 H S-0116
0111150243	PST4 3245/7E450 MH S-0116
0111151177	PST4 3695/7E500 CI MH DC20 CBRF S-0116
0111151192	PST4 3695/7E500 CI MH DC20 S-0116
0111151139	PST4 3695/8E450 D CPRA S-0116
0111151172	PST4 4045/6E700 CI MH DC20 S-0116
0111150468	PST4 4045/7E500 MH S-0116
0111151215	PST4 4045/8E500 CI DC20 S-0116
0111151229	PST4 4045/8E500 CI DOC20 S-0116
0111151208	PST4 4045/8E500 CI MH DC20 S-0116
0111151235	PST4 4045/8E500 H CI DC20 CBRF S-0116
0111151137	PST4 4045/8E500 H MM S-0116
0111151152	PST4 4045/8E500 H S-0116
0111151150	PST4 4045/8E500 MH DC20 SPCRR CBRF S-0116
0111151124	PST4 4045/8E500 MH S-0116
0111151125	PST4 4045/8E500 S-0116
0111151146	PST4 4045/9E450 CPRA HDA S-0116
0111151159	PST4 4045/9E450 D MH S-0116
0111151256	PST4 4045/9E450 D/HDA BF MH DC20 S-0116
0111151130	PST4 4045/9E450 D/HDA S-0116
0111151118	PST4 4045/9E450 DC20 S-0116
0111151207	PST4 4045/9E450 H CI DC20 S-0116
0111151145	PST4 4045/9E450 H MH DC20 S-0116
0111151122	PST4 4045/9E450 H MM DC20 S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

PRODUCTS

0111151131	PST4 4045/9E450 H S-0116
0111151119	PST4 4045/9E450 HDA S-0116
0111151138	PST4 4045/9E450 IAPAR MH S-0116
0111151144	PST4 4045/9E450 MH DC20 S-0116
0111151129	PST4 4045/9E450 MH S-0116
0111151134	PST4 4045/9E450 RAIAD MH S-0116
0111151142	PST4 4045/9E450 S-0116
0111151261	PST4 4495/10E450 CI DC20 S-0116
0111151234	PST4 4495/10E450 CI MH DC20 S-0116
0111151175	PST4 4495/10E450 D MH S-0116
0111151127	PST4 4495/10E450 H S-0116
0111151148	PST4 4495/10E450 MH DC20 S-0116
0111151198	PST4 4495/8E550 CI MH DC20 S-0116
0111151226	PST4 4495/9E500 CI MH DC20 S-0116
0111151216	PST4 4495/9E500 CI MH S-0116
0111151164	PST4 4495/9E500 DC20 S-0116
0111151184	PST4 4495/9E500 H CI DC20 S-0116
0111151143	PST4 4495/9E500 H MH S-0116
0111151151	PST4 4495/9E500 H S-0116
0111151154	PST4 4495/9E500 MH DC20 S-0116
0111150454	PST4 4495/9E500 MH S-0116
0111151149	PST4 4495/9E500 MM S-0116
0111151176	PST4 4845/10E500 CI H MH DC20 S-0116
0111151270	PST4 4845/10E500 CPERA D/HDA DC18 CSI S-0116
0111151170	PST4 4845/10E500 HDA MH DC20 S-0116
0111151123	PST4 4845/10E500 MH DC20 S-0116
0111151210	PST4 4845/11E450 CI DC20 S-0116
0111150456	PST4 4845/11E450 ESPECIAL S-0116
0111151126	PST4 4845/11E450 IAPAR MH S-0116
0111151120	PST4 4845/11E450 MH S-0116
0111151136	PST4 4845/7E700 MH S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

PRODUCTS



0111151274	PST4 5345/11E500 SPT CI MH DC20 CSI S-0116
0111151241	PST4 5345/12E450 S/D/H MH DC20 S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

INDEX

0909096819	ASSY FRAME - 3245/3695/4045/4495/4845/5345	1
0501058194	FRAME WITH AXLE WHEEL - 3245	2
0511051956	FRAME WITH AXLE WHEEL - 3695	3
0501058195	FRAME WITH AXLE WHEEL - 4045	4
0511050836	WHEEL AXLE FRAME - 4495	5
0501058196	WHEEL AXLE FRAME - 4845	6
0511051118	WHEEL AXLE FRAME - 5345	7
0511057124	CYLINDER ASSY	8
0511056529	CYLINDER ASSY	9
0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	10
0511058406	HYDRAULIC CYLINDER	11
0521043934	CARRYING WHEELS SPRING TRACTION	12
0501058240	WHEEL FASTENER WITH TENSIONER	13
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	14
0501058244	WHEEL FIXED CHAIN TENSIONER	15
0501058242	WHEEL MOBILE CHAIN TENSIONER	16
0501059909	CARRYING WHEELS SUPPORT	17
0511052770	WHEEL WITH TIRE	18
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	19
0501058241	WHEEL SUPPORT CHAIN TENSIONER	20
0511057493	RIGHT TRANSMISSION ASSY - 3245	21
0511059611	RIGHT TRANSMISSION ASSY - 3695	22
0511058597	RIGHT TRANSMISSION ASSY - 4045	23
0511058970	RIGHT TRANSMISSION ASSY - 4495	24
0511056740	RIGHT TRANSMISSION ASSY - 4880	25
0521050178	RIGHT TRANSMISSION ASSY - 5345	26
0511057346	LEFT TRANSMISSION ASSY - 3245	27
0511059612	LEFT TRANSMISSION ASSY - 3695	28
0511058598	LEFT TRANSMISSION ASSY - 4045	29
0511058971	LEFT TRANSMISSION ASSY - 4495	30
0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	31
0521050179	ASSY TRANSMISSION LEFT - 5345	32
0501052560	MOTOR AXLE SIGNAL	33
0511051434	TRANSMISSION ACTUATOR	34
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	35
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	36
0521043316	RIGHT GEAR BOX ASSY	37
0521043317	LEFT GEAR BOX ASSY	38
0501058212	SEMI MOUNTED RIGHT CHANGE	39
0501058213	LH GEAR BOX	40
0511059266	CLOSED BEARING	41
0501056443	GEAR HOUSING BEARING	42
0501056444	SUPPORT WITH ROLLER BEARING	43
0501048790	AXLE WITH RING	44
0501054655	CHAIN TENSIONER ASSY	45
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	46
0511054363	CHAIN TENSIONER	47
0501058234	LOWER CHAIN TENSIONER	48
0501058235	STRETCHER CURRENT TOP SEED 17Z	49
0501058236	BEARING WITH 21Z GEAR	50
0501058237	16Z GEAR BEARING	51
0501055112	MICRO GRANULATED CHAIN TENSIONER	52
0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	53
0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	54
0501053834	MALE QUICK COUPLER	55



MARCHESAN

INDEX

0501058165	SEMI-ASSEMBLED HYDRAULIC MARKER 3245/7	56
0511052482	SEMI-ASSEMBLED HYDRAULIC MARKER 3695	57
0501058170	SEMI-ASSEMBLED HYDRAULIC MARKER 4045	58
0501058169	SEMI-ASSEMBLED MECHANICAL MARKER 4045/9	59
0511050854	MECANIC ROW MARK 4495/9	60
0511050838	SEMI-ASSEMBLED HYDRAULIC MARKER 4495	61
0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845	62
0511051119	SEMI-ASSEMBLED HYDRAULIC MARKER 5345	63
0511058449	HYDRAULIC CYLINDER	64
0501054649	HBM SEQUENTIAL VALVE	65
0511057095	HYDRAULIC MARKER HOSE KIT	66
0501050633	ROW MARKER DISC ASSEMBLY	67
0531056600	3245 - RIGHT/LEFT FERTILIZER HOPPER SET	68
0531056589	3245 - RIGHT HOPPER SUPPORT WITH FERTILIZER METERING	69
0531056588	3245 - LEFT HOPPER SUPPORT WITH FERTILIZER METERING	70
0531056601	3695 - RIGHT/LEFT FERTILIZER HOPPER SET	71
0531056597	3695 - RIGHT HOPPER SUPPORT WITH FERTILIZER METERING	72
0531056596	3695 - LEFT HOPPER SUPPORT WITH FERTILIZER METERING	73
0531056602	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4045	74
0531056599	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4045	75
0531056598	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4045	76
0531056757	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4495	77
0531056760	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4495	78
0531056759	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4495	79
0531056603	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4845	80
0531056604	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4845	81
0531056605	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4845	82
0531056921	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 5345	83
0531056920	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 5345	84
0531056919	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 5345	85
0501053788	3/4" SQUARE AXLE FASTENER	86
0531055319	ALPHA II FERTILIZER METERING	87
0531055863	ASSY TRANSMISSION HUB	88
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	89
0531059139	ASSY COLLECTOR	90
0531055273	ALPHA FERTILIZER METERING CLAMP	91
0531057911	22Z GEAR SIDE BEARING ASSEMBLY	92
0531057901	GEAR	93
0511057237	PLATFORM ASSY - 3245	94
0511058319	PLATFORM ASSY - 3695	95
0511057129	PLATFORM ASSY - 4045	96
0511057565	PLATFORM ASSY - 4495	97
0511057650	PLATFORM ASSY - 4845	98
0511058312	PLATFORM ASSY - 5345	99
0511057236	HANDRAIL ASSY - 3245	100
0511058318	HANDRAIL ASSY - 3695	101
0511057130	HANDRAIL ASSY - 4045	102
0511057566	HANDRAIL ASSY - 4495	103
0511057651	HANDRAIL ASSY - 4845	104
0511058308	HANDRAIL ASSY - 5345	105



MARCHESAN

INDEX

0511056536	LADDER ASSEMBLY	106
0511054971	JACK ASSEMBLY	107
0511057142	DRAWBAR ASSEMBLY - 3245/3695/4045/4495	108
0511057150	DRAWBAR ASSEMBLY - 4845/5345	109
0511057131	MANUAL CANISTER ASSY	110
0531057796	LABEL SET - 3245	111
0531057798	LABEL SET - 3695	112
0531057801	LABEL SET - 4045	113
0531057800	LABEL SET - 4045	114
0531057803	LABEL SET - 4495	115
0531057101	LABEL SET - 4495	116
0531057770	LABEL SET - 4845	117
0531057806	LABEL SET - 5345	118
0909098921	ASSY HEX AXLE	119
0501054258	DRAWBAR ESTABILIZER ASSY	120
0511054601	HITCH ARTICULATED TRACTOR	121
0511053179	TRACTOR COUPLING SHAFT	122
0511056736	HOSE SUPPORT	123
0531059614	KIT WITH ALPHA COMPONENTS - 04 ROWS	124
0531059615	KIT WITH ALPHA COMPONENTS - 05 ROWS	125
0531059616	KIT WITH ALPHA COMPONENTS - 06 ROWS	126
0531059617	KIT WITH ALPHA COMPONENTS - 07 ROWS	127
0531059618	KIT WITH ALPHA COMPONENTS - 08 ROWS	128
0531059619	KIT WITH ALPHA COMPONENTS - 09 ROWS	129
0531059620	KIT WITH ALPHA COMPONENTS - 10 ROWS	130
0531059621	KIT WITH ALPHA COMPONENTS - 11 ROWS	131
0531059622	KIT WITH ALPHA COMPONENTS - 12 ROWS	132
0511058368	MOBILE SUPPORT	133
0909096219	ASSY SEED/FERTILIZER ROW	134
0511053254	FERTILIZER SHORT ROW WITH LEFT DDD/20" DC	135
0531050532	SHORT FERTILIZER LOWER LEFT DDD DC20	136
0511050967	SHORT FERTILIZER ROW	137
0521051039	SHORT FERTILIZER ROW LEFT DDD DOC20	138
0511053255	FERTILIZER LONG ROW WITH RIGHT DDD/20" DC	139
0531050534	RIGHT LONGER FERTILIZER DDD RIGHT DC20	140
0511050968	LONG FERTILIZER ROW	141
0521051041	LONG FERTILIZER ROW RIGHT DDD DOC20	142
0501058271	SHORT FERTILIZER ROW WITHOUT DDD/H	143
0501058272	LONG FERTILIZER ROW WITHOUT DDD/H	144
0511053253	FERTILIZER LONG ROW WITH RIGHT DDD/18" DC	145
0511053252	FERTILIZER SHORT ROW WITH LEFT DDD/18" DC	146
0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	147
0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	148
0521052634	SHORT LOWER FERTILIZER ROW ARM WITH LEFT DDD	149
0521052635	LONG LOWER ARM FERTILIZER ROW WITH RIGHT DDD	150
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	151
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	152
0511053172	LEFT LOW HUB WITH 15 DISC	153
0511053173	RIGHT LOW HUB WITH 15 DISC	154
0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	155
0511044585	20" COULTER BLADE ASSY FOR LONG ROW	156
0511044573	18" COULTER BLADE ASSY FOR LONG ROW	157
0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	158
0501054887	20 BLADE DISC WITH FLAT PLAN DISC	159
0521044545	20" SHORT CURVED CORRIGATED DISC	160




MARCHESAN

INDEX

0521044546	20" LONG CURVED CORRUGATED DISC	161
0501058423	FERTILIZER ROD SPRING ROW	162
0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	163
0531054249	INDIVIDUAL SHORT SEED ROW	164
0511056600	RIGHT DDD SHORT SEED ROW FRONT	165
0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	166
0511052301	SUPPORT DDD 15 RIGHT	167
0531054248	INDIVIDUAL LONG SEED ROW	168
0511056601	LONG SEED ROW FRONT DDD LEFT	169
0511056586	15 X 15 SEED DDD LEFT	170
0511052302	LH SUPPORT DDD GUIDE	171
0511051693	BASE FIXING SYSTEM	172
0511058212	FERTILIZER ROW SUPPORT ASSY	173
0511052024	FAST CLOSING SET	174
0531053925	SIGMA SOY INDIVIDUAL SEED SYSTEM	175
0531051514	SIGMA SOY SEED SYSTEM	176
0511057289	ASSY SEED DEFLECTOR	177
0503063647	SIGMA CORN DISC SET	178
0503063648	SIGMA SOY DISC SET	179
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	180
0511058650	SEMI-MOUNTED DEPTH CONTROL	181
0511058652	LEFT DEPTH WHEEL ARM WITH HUB	182
0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	183
0501052627	ASSY DEPTH WHEEL HUB	184
0501052297	DEPTH WHEELS REGULATOR ASSY	185
0501052538	DEPTH BAND WITH ARMS	186
0511054333	COMPACT WHEEL RIGHT WITH BEARING	187
0511054334	COMPACT WHEEL LEFT WITH BEARING	188
0501052908	COMPACTOR WHEEL WITH BEARING	189
0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	190
0501056769	DEPTH WHEELS REGULATOR ASSY	191
0521051423	COMPACTOR SUPPORT	192
0511050077	WHEEL STRIPED	193
0511052287	DEPTH WHEEL HUB ASSY	194
0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	195
0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	196
0511059325	LEFT ARM COVERED WHEEL ASSEMBLED	197
0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED	198
0511051546	RIGHT DEPTH CONTROL HUB	199
0511051547	LEFT DEPTH CONTROL HUB	200
0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	201
0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	202
0511055819	DEPTH BAND WITH RIM	203
0521042327	DEPTH CONTROL & PRESS WHEEL ASSY	204
0511053550	DEPTH CONTROL ASSY	205
0521056317	DEPTH CONTROL WITH LEVER ANGLE REGULATOR AXIS CPERA	206
0521056313	RIGHT ARM WHEEL DEPTH WITH HUB CPERA	207
0521056314	LEFT ARM WHEEL DEPTH WITH HUB CPERA	208
0521056316	DEPTH WHEEL HUB WITH COMPLETE ANGLE ADJUSTING AXLE	209
0501110231	SCARIFIER ROD WITH TIP	210
0501050120	LARGER WALKING BEAM ASSY	211
0501053866	COVERING WHEEL FERTILIZER V RIGHT IRON	212
0501053867	COVERING V WHEEL FERTILIZER LEFT IRON	213

INDEX


0511054837	RH IRON PRESS WHEEL		214
0511054838	LH IRON PRESS WHEEL		215
0501052957	IRON V PRESS WHEELS		216
0501052735	COVERING WHEEL RIGHT FERTILIZER ASSY IRON		217
0501052736	COVERING WHEEL LEFT FERTILIZER ASSY IRON		218
0501056288	RIGHT IRON COVERING WHEEL		219
0501056289	LEFT IRON COVERING WHEEL		220
0501053186	RIGHT IRON PRESS WHEEL ASSY		221
0521053955	ROD WITH ARM/DISARMMENT		222
0521053937	SCARIFIER SPINDLE WITH POINT		223
0521053959	ROD WITH AUTOMATIC DISARM TIP		224
0501110723	SCARIFIER ROD		225
0521050168	MOUNTED FERTILIZER CONDUCTOR		226




Item	Code	Description	See page	3245	3695	4045	4495	4845	5345
01	0501058194	FRAME WITH AXLE WHEEL - 3245	2	01	00	00	00	00	00
01.	0511051956	FRAME WITH AXLE WHEEL - 3695	3	00	01	00	00	00	00
01..	0501058195	FRAME WITH AXLE WHEEL - 4045	4	00	00	01	00	00	00
01...	0511050836	WHEEL AXLE FRAME - 4495	5	00	00	00	01	00	00
01....	0501058196	WHEEL AXLE FRAME - 4845	6	00	00	00	00	01	00
01.....	0511051118	WHEEL AXLE FRAME - 5345	7	00	00	00	00	00	01
02	0503010003	1845 GREASE FITTING		04	04	04	04	06	06
03	0511057124	CYLINDER ASSY	8	01	01	01	01	00	00
03.	0511056529	CYLINDER ASSY	9	00	00	00	00	01	01
04	0521043934	CARRYING WHEELS SPRING TRACTION	12	02	02	04	04	04	04
05	0511057493	RIGHT TRANSMISSION ASSY - 3245	21	01	00	00	00	00	00
05.	0511059611	RIGHT TRANSMISSION ASSY - 3695	22	00	01	00	00	00	00
05..	0511058597	RIGHT TRANSMISSION ASSY - 4045	23	00	00	01	00	00	00
05...	0511058970	RIGHT TRANSMISSION ASSY - 4495	24	00	00	00	01	00	00
05....	0511056740	RIGHT TRANSMISSION ASSY - 4880	25	00	00	00	00	01	00
05.....	0521050178	RIGHT TRANSMISSION ASSY - 5345	26	00	00	00	00	00	01
06	0511057346	LEFT TRANSMISSION ASSY - 3245	27	01	00	00	00	00	00
06.	0511059612	LEFT TRANSMISSION ASSY - 3695	28	00	01	00	00	00	00
06..	0511058598	LEFT TRANSMISSION ASSY - 4045	29	00	00	01	00	00	00
06...	0511058971	LEFT TRANSMISSION ASSY - 4495	30	00	00	00	01	00	00
06....	0511056741	LEFT TRANSMISSION ASSEMBLY - 4880	31	00	00	00	00	01	00
06.....	0521050179	ASSY TRANSMISSION LEFT - 5345	32	00	00	00	00	00	01
07	0511057127	ASSY SYSTEM HYDRAULIC - 3245/3695/4045/4495	53	01	01	01	01	00	00
07.	0511057146	HYDRAULIC SYSTEM ASSY - 4845/5345	54	00	00	00	00	01	01
08	0501058165	SEMI-ASSEMBLED HYDRAULIC MARKER 3245/7	56	01	00	00	00	00	00
08.	0511052482	SEMI-ASSEMBLED HYDRAULIC MARKER 3695	57	00	01	00	00	00	00
08..	0501058170	SEMI-ASSEMBLED HYDRAULIC MARKER 4045	58	00	00	01	00	00	00
08...	0501058169	SEMI-ASSEMBLED MECHANICAL MARKER 4045/9	59	00	00	01	00	00	00
08....	0511050854	MECANIC ROW MARK 4495/9	60	00	00	00	01	00	00
08.....	0511050838	SEMI-ASSEMBLED HYDRAULIC MARKER 4495	61	00	00	00	01	00	00
08.....	0501058172	SEMI-ASSEMBLED HYDRAULIC MARKER 4845	62	00	00	00	00	01	00

Item	Code	Description	See page	3245	3695	4045	4495	4845	5345
08.....	0511051119	SEMI-ASSEMBLED HYDRAULIC MARKER 5345	63	00	00	00	00	00	01
09	0501050633	ROW MARKER DISC ASSEMBLY	67	02	02	02	02	02	02
10	0531056600	3245 - RIGHT/LEFT FERTILIZER HOPPER SET	68	01	00	00	00	00	00
10.	0531056601	3695 - RIGHT/LEFT FERTILIZER HOPPER SET	71	00	01	00	00	00	00
10..	0531056602	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4045	74	00	00	01	00	00	00
10...	0531056757	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4495	77	00	00	00	01	00	00
10....	0531056603	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 4845	80	00	00	00	00	01	00
10.....	0531056921	RIGHT/LEFT ALPHA II FERTILIZER HOPPER SET - 5345	83	00	00	00	00	00	01
11	0511057237	PLATFORM ASSY - 3245	94	01	00	00	00	00	00
11.	0511058319	PLATFORM ASSY - 3695	95	00	01	00	00	00	00
11..	0511057129	PLATFORM ASSY - 4045	96	00	00	01	00	00	00
11...	0511057565	PLATFORM ASSY - 4495	97	00	00	00	01	00	00
11....	0511057650	PLATFORM ASSY - 4845	98	00	00	00	00	01	00
11.....	0511058312	PLATFORM ASSY - 5345	99	00	00	00	00	00	01
12	0511057236	HANDRAIL ASSY - 3245	100	01	00	00	00	00	00
12.	0511058318	HANDRAIL ASSY - 3695	101	00	01	00	00	00	00
12..	0511057130	HANDRAIL ASSY - 4045	102	00	00	01	00	00	00
12...	0511057566	HANDRAIL ASSY - 4495	103	00	00	00	01	00	00
12....	0511057651	HANDRAIL ASSY - 4845	104	00	00	00	00	01	00
12.....	0511058308	HANDRAIL ASSY - 5345	105	00	00	00	00	00	01
13	0511056536	LADDER ASSEMBLY	106	02	02	02	02	02	02
14	0511054971	JACK ASSEMBLY	107	02	02	02	02	02	02
15	0511057142	DRAWBAR ASSEMBLY - 3245/3695/4045/4495	108	01	01	01	01	00	00
15.	0511057150	DRAWBAR ASSEMBLY - 4845/5345	109	00	00	00	00	01	01
16	0511057131	MANUAL CANISTER ASSY	110	01	01	01	01	01	01
17	0531057796	LABEL SET - 3245	111	01	00	00	00	00	00
17.	0531057798	LABEL SET - 3695	112	00	01	00	00	00	00
17..	0531057801	LABEL SET - 4045	113	00	00	01	00	00	00
17...	0531057800	LABEL SET - 4045	114	00	00	01	00	00	00
17....	0531057803	LABEL SET - 4495	115	00	00	00	01	00	00
17.....	0531057101	LABEL SET - 4495	116	00	00	00	01	00	00
17.....	0531057770	LABEL SET - 4845	117	00	00	00	00	01	00
17.....	0531057806	LABEL SET - 5345	118	00	00	00	00	00	01
18	0909098921	ASSY HEX AXLE	119	01	01	01	01	01	01
19	0501065677	STRUT		02	02	02	02	02	02
20	0501054258	DRAWBAR ESTABILIZER ASSY	120	01	01	01	01	01	01
21	0511054601	HITCH ARTICULATED TRACTOR	121	01	01	01	01	01	01
22	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01	01	01	01	01
23	0511053179	TRACTOR COUPLING SHAFT	122	01	01	01	01	01	01
24	0521013022	TRANSPORT LOCK		01	01	01	01	01	01
25	0501068994	8,30 X 78 LOCK PIN		01	01	01	01	01	01
26	0503030168	HITCH PIN CLIP		01	01	01	01	01	01
27	0503014120	CHAIN		01	01	01	01	01	01
28	0503014321	CABLE STEEL SHACKLE		02	02	02	02	02	02
29	0511056736	HOSE SUPPORT	123	01	01	01	01	01	01
30	0501047895	25 ROD STOP		01	01	01	01	02	02
31	0501047885	30 ROD STOP		01	01	01	01	02	02
32	0501047886	35 ROD STOP		01	01	01	01	02	02
33	0501047887	40 ROD STOP		01	01	01	01	02	02
34	0531059614	KIT WITH ALPHA COMPONENTS - 04 ROWS	124	01	00	00	00	00	00
34.	0531059615	KIT WITH ALPHA COMPONENTS - 05 ROWS	125	01	01	00	00	00	00
34..	0531059616	KIT WITH ALPHA COMPONENTS - 06 ROWS	126	01	00	01	00	00	00
34...	0531059617	KIT WITH ALPHA COMPONENTS - 07 ROWS	127	01	01	01	00	00	00
34....	0531059618	KIT WITH ALPHA COMPONENTS - 08 ROWS	128	00	01	01	01	00	00
34.....	0531059619	KIT WITH ALPHA COMPONENTS - 09 ROWS	129	00	00	01	01	00	00
34.....	0531059620	KIT WITH ALPHA COMPONENTS - 10 ROWS	130	00	00	00	01	01	00


Item	Code	Description	See page	3245	3695	4045	4495	4845	5345
34.....	0531059621	KIT WITH ALPHA COMPONENTS - 11 ROWS	131	00	00	00	00	01	01
34.....	0531059622	KIT WITH ALPHA COMPONENTS - 12 ROWS	132	00	00	00	00	00	01
35	0503010780	N-2050 AMENDMENT		02	02	02	02	02	02
36	0503011750	AMENDMENT WITH LOCK		06	06	06	06	06	06
37	0503010951	REDUCTION		04	04	04	04	04	04
38	0503011751	REDUCTION		06	06	06	06	06	06
39	0503010246	CLAMP		03	02	03	03	04	06
40	0511058368	MOBILE SUPPORT	133	02	02	02	02	00	00
41	0521013164	EXTENDER		00	00	00	00	02	02
42	0501011310	FIXER LOCK		00	00	00	00	08	08
43	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		00	00	00	00	08	08
44	0503010019	1/2" SPRING WASHER		00	00	00	00	08	08
45	0503010060	1/2 UNC G.5 ZN HEX NUT		00	00	00	00	08	08
46	0511066652	400 TURNBUCKLE		02	00	00	00	00	00
47	0909096219	ASSY SEED/FERTILIZER ROW	134	01	01	01	01	01	01




Item	Code	Description	See page	QT
01	0511069615	FRAME		01
02	0511069724	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8 UNC X 2.1/4 BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8 NUT		08




Item	Code	Description	See page	QT
01	0521063230	FRAME		01
02	0521063231	WHEEL ARTICULATED AXLE		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8 UNC X 2.1/4 BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8 NUT		08




Item	Code	Description	See page	QT
01	0511069529	FRAME		01
02	0511069682	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8 UNC X 2.1/4 BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8 NUT		08



Item	Code	Description	See page	QT
01	0521062243	FRAME		01
02	0521062242	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		04
04	0503010899	5/8 UNC X 2.1/4 BOLT		08
05	0501012140	FLAT WASHER		16
06	0531013922	0.6" X 0.8" X 1" SLEEVE		08
07	0503011445	SPRING WASHER		08
08	0503010013	5/8 NUT		08




Item	Code	Description	See page	QT
01	0511069616	FRAME		01
02	0511069717	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8 UNC X 2.1/4 BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8 NUT		12



Item	Code	Description	See page	QT
01	0521062442	FRAME		01
02	0521062447	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		06
04	0503010899	5/8 UNC X 2.1/4 BOLT		12
05	0501012140	FLAT WASHER		24
06	0531013922	0.6" X 0.8" X 1" SLEEVE		12
07	0503011445	SPRING WASHER		12
08	0503010013	5/8 NUT		12

CYLINDER ASSY


0511057124




Item	Code	Description	See page	QT
01	0511041188	2" X 5" X 19.5" X 7.5" HYDRAULIC CYLINDER	10	01
02	0531019171	1.25" X 7" COUPLING SHAFT		01
03	0521012536	COUPLING SHAFT		01
04	0503010523	1/4" X 2" SPLIT PIN		02
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02

CYLINDER ASSY

0511056529




Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	11	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521012536	COUPLING SHAFT		02
04	0503010523	1/4" X 2" SPLIT PIN		04
05	0531012565	SLEEVE 16,3X 30 X 88		02
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
07	0503010027	5/8 SPRING WASHER		02
08	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0511064055	5" X 15" CYLINDER CASE		01
02	0511064056	BUSHING 2" X 14" TURNBUCLE		01
03	0502010382	5" END CAP		01
04	0502012227	50.80 X 127 RING SUPPORT		01
05	0503010039	D-2000 SCRAPER RING		01
06	0503010991	1870-2000-375-B GASKET		01
07	0503010952	W2-2250-500 RING		01
08	0503010351	2-425 N 3006-9B O'RING		01
09	0503011062	8-425 BACK-UP RING		01
10	0502010963	2.0" X 5.0" PISTON		01
11	0503010552	PACKING 3750-4250-625-B		02
12	0503010345	2-218 N 3006-9B O'RING		01
13	0503010974	W2-5000-500 RING		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503010003	1845 GREASE FITTING		01
16	0503030385	CYLINDER PLUG N-002		02

HYDRAULIC CYLINDER


0511058406




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCKLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0501058240	WHEEL FASTENER WITH TENSIONER	13	01
02	0503011119	7/8" X 6" BOLT		04
03	0501014251	FLAT WASHER		04
04	0503011254	7/8" HEX SELF ADJUSTING NUT		04
05	0501059909	CARRYING WHEELS SUPPORT	17	01
06	0503014887	2050 CHAIN X 80 LINK + REDUCTION		01
07	0502010584	CARRYING-WHEELS SUPPORT FIXER		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	14	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	15	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	16	01



Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01

CARRYING WHEELS SUPPORT


0501059909




Item	Code	Description	See page	QT
01	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
02	0531016887	CARRYING WHEEL AXLE ARM		01
03	0503010523	1/4" X 2" SPLIT PIN		01
04	0503010003	1845 GREASE FITTING		01
05	0511050681	TRACTION SPRING		01
05A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
05B	0561016062	SPRING HITCH		02
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8 SPRING WASHER		04
08	0503013030	5/8" X 3.1/4" BOLT		01
09	0551017715	FLAT WASHER		02
10	0511052770	WHEEL WITH TIRE	18	01
11	0501058241	WHEEL SUPPORT CHAIN TENSIONER	20	01
12	0521061565	WHEEL SUPPORT ARM		01
13	0503018981	BOLT		02
14	0521069983	WHEEL COVER		01
15	0591010589	BODY LOCK WHEEL		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE		01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	19	01



Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016882	1535 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CS PC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	35	01
17	0521043316	RIGHT GEAR BOX ASSY	37	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8 SPRING WASHER		01
36	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0571011602	MOTOR AXLE		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	35	01
17	0521043316	RIGHT GEAR BOX ASSY	37	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8 SPRING WASHER		01
36	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	35	01
17	0521043316	RIGHT GEAR BOX ASSY	37	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8 SPRING WASHER		01
36	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561018351	2155 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	35	01
17	0521043316	RIGHT GEAR BOX ASSY	37	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

**RIGHT TRANSMISSION ASSY - 4495**

0511058970


Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8 SPRING WASHER		01
36	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	35	01
17	0521043316	RIGHT GEAR BOX ASSY	37	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0521055207	TOP CURRENT STRETCHER		01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01




Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561019204	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	35	01
17	0521043316	RIGHT GEAR BOX ASSY	37	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0503030303	SUPPORT WASHER		03
26	0501010637	FLAT WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	47	01
31	0501058234	LOWER CHAIN TENSIONER	48	01

Item	Code	Description	See page	QT
32	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
33	0501058236	BEARING WITH 21Z GEAR	50	01
34	0501058237	16Z GEAR BEARING	51	01
35	0503012391	40-1 CHAIN X 83 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
38	0503012719	40-1 CHAIN X 113 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016882	1535 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CS PC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	36	01
17	0521043317	LEFT GEAR BOX ASSY	38	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

**LEFT TRANSMISSION ASSY - 3245**

0511057346

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8 SPRING WASHER		01
36	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0571011602	MOTOR AXLE		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	36	01
17	0521043317	LEFT GEAR BOX ASSY	38	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

LEFT TRANSMISSION ASSY - 3695

0511059612

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8 SPRING WASHER		01
36	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016881	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	36	01
17	0521043317	LEFT GEAR BOX ASSY	38	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01

LEFT TRANSMISSION ASSY - 4045

0511058598

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8 SPRING WASHER		01
36	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02



Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561018351	2155 MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CS PC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	36	01
17	0521043317	LEFT GEAR BOX ASSY	38	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501058234	LOWER CHAIN TENSIONER	48	01
27	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
28	0501058236	BEARING WITH 21Z GEAR	50	01
29	0501058237	16Z GEAR BEARING	51	01
30	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
31	0503012522	40-1 CHAIN X 85 LINK + MENDING		01


LEFT TRANSMISSION ASSY - 4495

0511058971

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02
34	0503010256	3/8" X 3/4" BOLT		01
35	0503010025	3/8 SPRING WASHER		01
36	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
37	0501010637	FLAT WASHER		01
38	0503030303	SUPPORT WASHER		02

LEFT TRANSMISSION ASSEMBLY - 4880

0511056741




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561016876	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	36	01
17	0521043317	LEFT GEAR BOX ASSY	38	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010019	1/2" SPRING WASHER		05
21	0503012682	1/2" BSW NUT		03
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0511054363	CHAIN TENSIONER	47	01
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	52	01
27	0501058234	LOWER CHAIN TENSIONER	48	01
28	0521055207	TOP CURRENT STRETCHER		01
29	0501058236	BEARING WITH 21Z GEAR	50	01
30	0501058237	16Z GEAR BEARING	51	01
31	0503012391	40-1 CHAIN X 83 LINK + MENDING		01

LEFT TRANSMISSION ASSEMBLY - 4880

0511056741

Item	Code	Description	See page	QT
32	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
33	0503012718	40-1 CHAIN X 111 LINK + MENDING		02




Item	Code	Description	See page	QT
01	0501110639	BEARING		04
02	0503011099	GREASE FITTING		04
03	0503010300	5/32" X 1" SPLIT PIN		04
04	0551019114	MOTOR BEARING AXLE SUPPORT		02
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
07	0503010019	1/2" SPRING WASHER		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0561019204	MOTOR SHAFT		01
10	0501018466	FLAT WASHER		02
11	0511015961	LOCK BUSHING		02
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		02
13	0503010060	1/2 UNC G.5 ZN HEX NUT		02
14	0501052560	MOTOR AXLE SIGNAL	33	01
15	0511051434	TRANSMISSION ACTUATOR	34	02
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	36	01
17	0521043317	LEFT GEAR BOX ASSY	38	01
18	0501010243	1/2" X 1-1/2" BOLT		03
19	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010019	1/2" SPRING WASHER		05
22	0503012682	1/2" BSW NUT		03
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0521062072	33Z GEAR		01
25	0503030303	SUPPORT WASHER		03
26	0501010637	FLAT WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503010025	3/8 SPRING WASHER		01
29	0503010256	3/8" X 3/4" BOLT		01
30	0511054363	CHAIN TENSIONER	47	01
31	0501058234	LOWER CHAIN TENSIONER	48	01


ASSY TRANSMISSION LEFT - 5345

0521050179

Item	Code	Description	See page	QT
32	0501058235	STRETCHER CURRENT TOP SEED 17Z	49	01
33	0501058236	BEARING WITH 21Z GEAR	50	01
34	0501058237	16Z GEAR BEARING	51	01
35	0503012391	40-1 CHAIN X 83 LINK + MENDING		01
36	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		01
37	0503012718	40-1 CHAIN X 111 LINK + MENDING		01
38	0503012719	40-1 CHAIN X 113 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CS PC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02

RIGHT SIDE TRANSMISSION ACTUATOR


0511047069



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
05	0501019734	FLAT WASHER		02
06	0502010710	RIGHT CAM, SMALLER		02
07	0503010003	1845 GREASE FITTING		02
08	0502012539	26Z P12,7 GEAR		01
09	0501019735	FLAT WASHER		01
10	0521017593	FLAT WASHER		01
11	0503010542	501045 CLAMPING RING (FOR AXLE)		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01

LEFT SIDE TRANSMISSION ACTUATOR


0511047070



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY


0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	39	01
02	0511059266	CLOSED BEARING	41	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	42	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	44	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	45	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	46	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01

LEFT GEAR BOX ASSY


0521043317




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	40	01
02	0511059266	CLOSED BEARING	41	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	42	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	44	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	45	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	46	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING		01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0501056444	SUPPORT WITH ROLLER BEARING	43	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX SUPPORT		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01

CHAIN TENSIONER ASSY

0501054655




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011978	CENTRAL BEARING GEARBOX		01
02	0503013462	6005 2RS1 ROLLER BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02

CHAIN TENSIONER


0511054363




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0502012367	17Z X P 1/2" GEAR INTERM		01
02	0503012882	BEARING		01
03	0503011945	503050 CLAMPING RING (FOR AXLE)		01
04	0551019173	CHAIN SLEEVE TENSIONER		01
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0503011411	1/2" X 5-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0551019171	CHAIN TIGHTENER AXLE		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01

16Z GEAR BEARING


0501058237




Item	Code	Description	See page	QT
01	0511069680	20Z X 28Z DOUBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019174	DOUBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	1 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511057070	HOSE KIT HYDRAULIC		01
01A	0521052285	TC-TM HOSE ASSY		01
01AA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01AB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052287	TC-TM HOSE ASSY		01
01BA	0501080446	3/8 X" 169" TC-TM HOSE ASSY		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	55	02
03	0503013100	NYLON CLAMP		02
04	0581010091	SPRING PROTECTION PLASTIC HOSE		01



Item	Code	Description	See page	QT
01	0511063404	"T" OIL CONDUCTOR		02
02	0581010091	SPRING PROTECTION PLASTIC HOSE		01
03	0503013100	NYLON CLAMP		02
04	0502012702	BODY SUPPORT CLAMP		02
05	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		02
06	0503010180	7/16" SPRING WASHER		02
07	0501053834	MALE QUICK COUPLER	55	02
08	0511057068	HOSE KIT SYSTEM HYDRAULIC		01
08A	0501080449	3/8" X 1500 TC-TC HOSE		04
09	0521052334	3/8 X 4000 TR-TM HOSE BLACK / BLUE		01
09A	0501080361	3/8" X 157" TR-TM HOSE		01
09B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
09C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
09D	0503018952	PLASTIC BOLT		06
10	0521052333	3/8 X 4000 TR-TM HOSE BLACK / RED		01
10A	0501080361	3/8" X 157" TR-TM HOSE		01
10B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
10C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
10D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8" UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0503012412	5/8" UNC SELF LOCKING NUT		02
13	0511058449	HYDRAULIC CYLINDER	64	02
14	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
15	0503010523	1/4" X 2" SPLIT PIN		02
16	0511015779	1" X 4.2" AXLE		02
17	0503010523	1/4" X 2" SPLIT PIN		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	8,30 X 78 LOCK PIN		02
20	0503030168	HITCH PIN CLIP		02
21	0501069643	890 TURNBUCKLE		02
22	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
23	0511011311	VALVE SUPPORT		01
24	0503010232	5/8" X 1.3/4" BOLT		02
25	0503010027	5/8 SPRING WASHER		02
26	0503010013	5/8 NUT		02
27	0501054649	HBM SEQUENTIAL VALVE	65	01
28	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
29	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
30	0503010025	3/8 SPRING WASHER		02
31	0511057191	HYDRAULIC HOSE MARKER ASSY 3245/7		01

Item	Code	Description	See page	QT
31A	0501080452	3/8" X 98" TR-TR HOSE		02
31B	0501080401	3/8" X 106" TR-TC HOSE		02
31C	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
31CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
31CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
31CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
31CD	0503018952	PLASTIC BOLT		06
31D	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
31DA	0501080422	HOSE 3/8 X 4000 TC-TM		01
31DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
31DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
31DD	0503018952	PLASTIC BOLT		06
32	0501053834	MALE QUICK COUPLER	55	02
33	0502012702	BODY SUPPORT CLAMP		06
34	0503011103	7/16" X 2-1/2" BOLT		06
35	0501012803	FLAT WASHER		02
36	0503010180	7/16" SPRING WASHER		06
37	0503010244	7/16" NUT		06



Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8" UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0503012412	5/8" UNC SELF LOCKING NUT		02
13	0511058449	HYDRAULIC CYLINDER	64	02
14	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
15	0503010523	1/4" X 2" SPLIT PIN		02
16	0511015779	1" X 4.2" AXLE		02
17	0503010523	1/4" X 2" SPLIT PIN		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	8,30 X 78 LOCK PIN		02
20	0503030168	HITCH PIN CLIP		02
21	0501069643	890 TURNBUCKLE		02
22	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
23	0511011311	VALVE SUPPORT		01
24	0503010232	5/8" X 1.3/4" BOLT		02
25	0503010027	5/8 SPRING WASHER		02
26	0503010013	5/8 NUT		02
27	0501054649	HBM SEQUENTIAL VALVE	65	01
28	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
29	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
30	0503010025	3/8 SPRING WASHER		02
31	0511057075	HYDRAULIC MARKER HOSE KIT		01

Item	Code	Description	See page	QT
31A	0501080296	3/8" X 106" TR-TR HOSE		02
31B	0501080397	3/8" X 120" TR-TC HOSE		02
31C	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
31CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
31CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
31CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
31CD	0503018952	PLASTIC BOLT		06
31D	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
31DA	0501080422	HOSE 3/8 X 4000 TC-TM		01
31DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
31DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
31DD	0503018952	PLASTIC BOLT		06
32	0501053834	MALE QUICK COUPLER	55	02
33	0502012702	BODY SUPPORT CLAMP		06
34	0503011103	7/16" X 2-1/2" BOLT		06
35	0501012803	FLAT WASHER		02
36	0503010180	7/16" SPRING WASHER		06
37	0503010244	7/16" NUT		06




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8" UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0503012412	5/8" UNC SELF LOCKING NUT		02
13	0511058449	HYDRAULIC CYLINDER	64	02
14	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
15	0503010523	1/4" X 2" SPLIT PIN		02
16	0511015779	1" X 4.2" AXLE		02
17	0503010523	1/4" X 2" SPLIT PIN		02
18	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
19	0501068994	8,30 X 78 LOCK PIN		02
20	0503030168	HITCH PIN CLIP		02
21	0501069643	890 TURNBUCKLE		02
22	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
23	0511011311	VALVE SUPPORT		01
24	0503010232	5/8" X 1.3/4" BOLT		02
25	0503010027	5/8 SPRING WASHER		02
26	0503010013	5/8 NUT		02
27	0501054649	HBM SEQUENTIAL VALVE	65	01
28	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
29	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
30	0503010025	3/8 SPRING WASHER		02
31	0511057095	HYDRAULIC MARKER HOSE KIT	66	01

**SEMI-ASSEMBLED HYDRAULIC MARKER 4045**


0501058170

Item	Code	Description	See page	QT
32	0501053834	MALE QUICK COUPLER	55	02
33	0502012702	BODY SUPPORT CLAMP		06
34	0503011103	7/16" X 2-1/2" BOLT		06
35	0501012803	FLAT WASHER		02
36	0503010180	7/16" SPRING WASHER		06
37	0503010244	7/16" NUT		06




Item	Code	Description	See page	QT
01	0511069621	MECANIC ROW MARK SUPPORT	02	
02	0503012407	5/8" X 1-1/2" BOLT	08	
03	0551018204	RIGHT ROW MARKER FIXER	01	
04	0551018205	LH ROW MARKER FIXER	01	
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04	
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER	08	
07	0503010025	3/8 SPRING WASHER	04	
08	0503010026	3/8" NUT	04	
09	0521010549	COUPLING SHAFT	02	
10	0503030168	HITCH PIN CLIP	02	
11	0511060475	ROW MARKER ARM	01	
12	0511060576	LH ROW MARKER ARM	01	
13	0503010769	5/8" X 2-1/4" BOLT	04	
14	0521010479	SLEEVE ARTICULATION	04	
15	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	02	
16	0501010984	10,50 X 27 X 3,00 FLAT WASHER	04	
17	0503010025	3/8 SPRING WASHER	02	
18	0503010026	3/8" NUT	02	
19	0501069643	890 TURNBUCKLE	02	
20	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	04	
21	0502010421	SIDE PULLEY	02	
22	0521010445	0.53" X 0.75" X 0.45" SLEEVE	02	
23	0521010641	COUPLING SHAFT	02	
24	0503010140	1/8" X 3/4" SPLIT PIN	02	
25	0501058197	ROW MARKER PIVOT	01	
25A	0501065640	ROW MARKER ROD GUIDE	02	
25B	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN	04	
25C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN	06	
25D	0503010019	1/2" SPRING WASHER	09	
25E	0503010060	1/2 UNC G.5 ZN HEX NUT	07	
25F	0501065644	ROW MARKER ARM/DISARMMENT ROD	01	

Item	Code	Description	See page	QT
25G	0501064229	REGULATOR ARM/DISARMMENT ROD		01
25H	0501062547	ROW MARKER BAR REGULATOR		01
25I	0503010395	1/2" X 1-1/4" BOLT		01
25J	0521010454	0.83" X 1.25" X 0.79" SLEEVE		01
25K	0503010734	1/2" X 2-1/2" BOLT		01
25L	0521010539	0.3" X 1.2" COUPLING SHAFT		02
25M	0503010140	1/8" X 3/4" SPLIT PIN		02
25N	0521062281	ROW MARK ARM LOCK		02
25O	0503032995	STEEL CABLE		01
25P	0501010096	3/8" X 2" BOLT		02
25Q	0531010415	ROW MARKER ARM/DISARM GUIDE SLEEVE		04
25R	0503010025	3/8 SPRING WASHER		02
25S	0503010026	3/8" NUT		02
25T	0501065642	ROW MARKER SUPPORT		01
25U	0502011231	CENTRAL PULLEY		02
25V	0521010693	PULLEY FIXER PLATE		01
25W	0511011308	BOLT		02
25Y	0503010691	1/4" GREASE FITTING		02
25Z	0503010232	5/8" X 1.3/4" BOLT		02
25Z1	0503010027	5/8 SPRING WASHER		02
25Z2	0503010013	5/8 NUT		02
26	0502011231	CENTRAL PULLEY		01
27	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
28	0503011128	6,4 X 1400 CHAIN		02
29	0502011291	CHAIN SLEEVE		02
30	0503010683	0,2" X 1,2" SPRING PIN		02
31	0551018206	LEFT COVER ARM/DISARMMENT		01
32	0551018207	LEFT COVER PROTECTION		01
33	0511017961	1/2" X 1-1/4" REB BOLT		02
34	0503010019	1/2" SPRING WASHER		02
35	0503010060	1/2 UNC G.5 ZN HEX NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		09




Item	Code	Description	See page	QT
01	0511069621	MECANIC ROW MARK SUPPORT	02	
02	0503012407	5/8" X 1-1/2" BOLT	08	
03	0551018204	RIGHT ROW MARKER FIXER	01	
04	0551018205	LH ROW MARKER FIXER	01	
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	04	
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER	08	
07	0503010025	3/8 SPRING WASHER	04	
08	0503010026	3/8" NUT	04	
09	0521010549	COUPLING SHAFT	02	
10	0503030168	HITCH PIN CLIP	02	
11	0511060475	ROW MARKER ARM	01	
12	0511060576	LH ROW MARKER ARM	01	
13	0503010769	5/8" X 2-1/4" BOLT	04	
14	0521010479	SLEEVE ARTICULATION	04	
15	0503010751	C3/8" X 1.1/4" HEX BOLT G.5	02	
16	0501010984	10,50 X 27 X 3,00 FLAT WASHER	04	
17	0503010025	3/8 SPRING WASHER	02	
18	0503010026	3/8" NUT	02	
19	0501069643	890 TURNBUCKLE	02	
20	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	04	
21	0502010421	SIDE PULLEY	02	
22	0521010445	0.53" X 0.75" X 0.45" SLEEVE	02	
23	0521010641	COUPLING SHAFT	02	
24	0503010140	1/8" X 3/4" SPLIT PIN	02	
25	0501058197	ROW MARKER PIVOT	01	
25A	0501065640	ROW MARKER ROD GUIDE	02	
25B	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN	04	
25C	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN	04	
25D	0503010019	1/2" SPRING WASHER	04	
25E	0503010060	1/2 UNC G.5 ZN HEX NUT	04	
25F	0501065644	ROW MARKER ARM/DISARMMENT ROD	01	

Item	Code	Description	See page	QT
25G	0501064229	REGULATOR ARM/DISARMMENT ROD		01
25H	0501062547	ROW MARKER BAR REGULATOR		01
25I	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
25J	0521010454	0.83" X 1.25" X 0.79" SLEEVE		01
25K	0503010734	1/2" X 2-1/2" BOLT		01
25L	0521010539	0.3" X 1.2" COUPLING SHAFT		02
25M	0503010140	1/8" X 3/4" SPLIT PIN		02
25N	0521062281	ROW MARK ARM LOCK		02
25O	0503032995	STEEL CABLE		01
25P	0501010096	3/8" X 2" BOLT		02
25Q	0531010415	ROW MARKER ARM/DISARM GUIDE SLEEVE		04
25R	0503010025	3/8 SPRING WASHER		02
25S	0503010026	3/8" NUT		02
25T	0501065642	ROW MARKER SUPPORT		01
25U	0502011231	CENTRAL PULLEY		02
25V	0521010693	PULLEY FIXER PLATE		01
25W	0511011308	BOLT		02
25Y	0503010691	1/4" GREASE FITTING		02
25Z	0503010232	5/8" X 1.3/4" BOLT		02
25Z1	0503010027	5/8 SPRING WASHER		02
25Z2	0503010013	5/8 NUT		02
26	0502011231	CENTRAL PULLEY		01
27	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
28	0503016066	6,4 X 1630 CHAIN		02
29	0502011291	CHAIN SLEEVE		02
30	0503010683	0,2" X 1,2" SPRING PIN		02
31	0561018354	RIGHT COVER PROTECTION		01
32	0561018355	LEFT COVER PROTECTION		01
33	0511017961	1/2" X 1-1/4" REB BOLT		02
34	0503010019	1/2" SPRING WASHER		02
35	0503010060	1/2 UNC G.5 ZN HEX NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		08
37	0503012412	5/8" UNC SELF LOCKING NUT		04
38	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0501069470	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	64	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501069643	890 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	65	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0501053834	MALE QUICK COUPLER	55	02
25	0502012702	BODY SUPPORT CLAMP		06
26	0503011103	7/16" X 2-1/2" BOLT		06
27	0501012803	FLAT WASHER		02
28	0503010180	7/16" SPRING WASHER		06
29	0503010244	7/16" NUT		06
30	0501012140	FLAT WASHER		04
31	0503012412	5/8" UNC SELF LOCKING NUT		02

Item	Code	Description	See page	QT
32	0511011311	VALVE SUPPORT		01
33	0503010232	5/8" X 1.3/4" BOLT		02
34	0503010027	5/8 SPRING WASHER		02
35	0503010013	5/8 NUT		02
36	0503012412	5/8" UNC SELF LOCKING NUT		08
37	0511057071	HYDRAULIC HOSE MARKER ASSY 10L		01
37A	0501081729	HOSE 3/8 X 3125 TR-TR		02
37B	0501081633	HOSE 3/8 X 3325 TR-TC		02
38	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38A	0501080422	HOSE 3/8 X 4000 TC-TM		01
38B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38D	0503018952	PLASTIC BOLT		06
39	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
39A	0501080422	HOSE 3/8 X 4000 TC-TM		01
39B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
39C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
39D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8" UNC SELF LOCKING NUT		08
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503011082	C1/2" X 1.3/4" SCREW		02
07	0501069470	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0501012140	FLAT WASHER		04
11	0503012412	5/8" UNC SELF LOCKING NUT		02
12	0511058449	HYDRAULIC CYLINDER	64	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" SPLIT PIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501066949	1235 TURNBUCKLE		02
21	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
22	0511011311	VALVE SUPPORT		01
23	0503010232	5/8" X 1.3/4" BOLT		02
24	0503010027	5/8 SPRING WASHER		02
25	0503010013	5/8 NUT		02
26	0501054649	HBM SEQUENTIAL VALVE	65	01
27	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
28	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
29	0503010025	3/8 SPRING WASHER		02
30	0502012702	BODY SUPPORT CLAMP		06
31	0503011103	7/16" X 2-1/2" BOLT		06

Item	Code	Description	See page	QT
32	0501012803	FLAT WASHER		02
33	0503010180	7/16" SPRING WASHER		06
34	0503010244	7/16" NUT		06
35	0501053834	MALE QUICK COUPLER	55	02
36	0511057069	HYDRAULIC HOSE MARKER ASSY		01
36A	0501080343	TR-TR HOSE ASSY		02
36B	0501080720	HOSE 3/8 X 3500 TR-TC		02
37	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
37A	0501080422	HOSE 3/8 X 4000 TC-TM		01
37B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
37C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
37D	0503018952	PLASTIC BOLT		06
38	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
38A	0501080422	HOSE 3/8 X 4000 TC-TM		01
38B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
38C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
38D	0503018952	PLASTIC BOLT		06



Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0501012140	FLAT WASHER		12
04	0503012412	5/8" UNC SELF LOCKING NUT		10
05	0503011070	BEATER		02
06	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
07	0503010019	1/2" SPRING WASHER		02
08	0511061811	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0511058449	HYDRAULIC CYLINDER	64	02
12	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
13	0503010523	1/4" X 2" SPLIT PIN		04
14	0511015779	1" X 4.2" AXLE		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	65	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
23	0503010025	3/8 SPRING WASHER		02
24	0501053834	MALE QUICK COUPLER	55	02
25	0531011180	UPPER BODY CLIP		08
26	0503010180	7/16" SPRING WASHER		08
27	0511011311	VALVE SUPPORT		01
28	0511059271	HYDRAULIC MARKER HAND SET		01
28A	0501081731	3/8 X 3550 TR-TR HOSE		02
28B	0501081732	3/8" X 3750 TR-TR HOSE		02
28C	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01


**SEMI-ASSEMBLED HYDRAULIC MARKER 5345**

0511051119


Item	Code	Description	See page	QT
28D	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
29	0503011103	7/16" X 2-1/2" BOLT		08
30	0502012702	BODY SUPPORT CLAMP		08
31	0503010244	7/16" NUT		08
32	0503010232	5/8" X 1.3/4" BOLT		02
33	0503010027	5/8 SPRING WASHER		02
34	0503010013	5/8 NUT		02

HYDRAULIC CYLINDER


0511058449



Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02



Item	Code	Description	See page	QT
01	0501081727	TR-TR HOSE ASSY		02
02	0501080447	3/8" X 122" TR-TC HOSE ASSY		02
03	0521052286	HOSE 3/8 X 4000 TC-TM PURPLE / RED		01
03A	0501080422	HOSE 3/8 X 4000 TC-TM		01
03B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
03C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
03D	0503018952	PLASTIC BOLT		06
04	0521052288	3/8 X 4000 TC-TM HOSE PURPLE / BLUE		01
04A	0501080422	HOSE 3/8 X 4000 TC-TM		01
04B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
04C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
04D	0503018952	PLASTIC BOLT		06

ROW MARKER DISC ASSEMBLY


0501050633




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01

3245 - RIGHT/LEFT FERTILIZER HOPPER SET


0531056600




Item	Code	Description	See page	QT
01	0531056589	3245 - RIGHT HOPPER SUPPORT WITH 69 FERTILIZER METERING	01	01
02	0531056588	3245 - LEFT HOPPER SUPPORT WITH FERTILIZER 70 METERING	01	01
03	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		02
04	0503010849	3/8" X 1-1/2" BOLT		16
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
06	0503010025	3/8 SPRING WASHER		16
07	0503010026	3/8" NUT		16
08	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
12	0501010694	FLAT WASHER		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" SPLIT PIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531064707	3245 - RIGHT HOPPER SUPPORT WITH FERTILIZER METERING		01
02	0501053788	3/4" SQUARE AXLE FASTENER	86	03
03	0503031527	AGRICULTURAL BEARING		03
04	0531055319	ALPHA II FERTILIZER METERING	87	04
05	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	92	01
06	0501311446	SQUARE AXLE		01
07	0531057908	SLEEVE 1/4 X 2		03
07A	0502013069	SLEEVE 21 X 38 X 50		01
07B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
08	0501310890	SQUARE AXLE		02
09	0501218674	3/4 X 290 AXLE		01




Item	Code	Description	See page	QT
01	0501053788	3/4" SQUARE AXLE FASTENER	86	03
02	0503031527	AGRICULTURAL BEARING		03
03	0531064706	3245 - LEFT HOPPER SUPPORT WITH FERTILIZER METERING		01
04	0531055319	ALPHA II FERTILIZER METERING	87	04
05	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	92	01
06	0531057908	SLEEVE 1/4 X 2		03
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0501311446	SQUARE AXLE		01
08	0501310890	SQUARE AXLE		02
09	0501218674	3/4 X 290 AXLE		01




Item	Code	Description	See page	QT
01	0531056597	3695 - RIGHT HOPPER SUPPORT WITH FERTILIZER METERING	72	01
02	0531056596	3695 - LEFT HOPPER SUPPORT WITH FERTILIZER METERING	73	01
03	0503061984	FERTILIZER HOPPER WITH 4 TRUNNELS		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		16
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
07	0503010025	3/8 SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
12	0501010694	FLAT WASHER		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" SPLIT PIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531064714	3695 - RIGHT HOPPER SUPPORT WITH FERTILIZER METERING		01
02	0501053788	3/4" SQUARE AXLE FASTENER	86	03
03	0503031527	AGRICULTURAL BEARING		03
04	0531055319	ALPHA II FERTILIZER METERING	87	04
05	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	92	01
06	0531057908	SLEEVE 1/4 X 2		04
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0501218666	AXLE 3/4 X 155		01
08	0501218684	3/4 X 330 AXLE		01
09	0501218487	3/4 X 390 AXLE		03




Item	Code	Description	See page	QT
01	0501053788	3/4" SQUARE AXLE FASTENER	86	03
02	0503031527	AGRICULTURAL BEARING		03
03	0531064713	3695 - LEFT HOPPER SUPPORT WITH FERTILIZER METERING		01
04	0531055319	ALPHA II FERTILIZER METERING	87	04
05	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	92	01
06	0501218666	AXLE 3/4 X 155		01
07	0531057908	SLEEVE 1/4 X 2		04
07A	0502013069	SLEEVE 21 X 38 X 50		01
07B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
08	0501218684	3/4 X 330 AXLE		01
09	0501218487	3/4 X 390 AXLE		03




Item	Code	Description	See page	QT
01	0531056599	RIGHT HOPPER SUPPORT WITH FERTILIZER 75 METERING - 4045		01
02	0531056598	LEFT HOPPER SUPPORT WITH FERTILIZER 76 METERING - 4045		01
03	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		16
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
07	0503010025	3/8 SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0501010694	FLAT WASHER		04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" SPLIT PIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531064716	RIGHT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	87	05
03	0501053788	3/4" SQUARE AXLE FASTENER	86	02
04	0503031527	AGRICULTURAL BEARING		02
05	0501310661	3/4" X 15,35"/15,27" AXLE		04
06	0531057908	SLEEVE 1/4 X 2		05
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	92	01
08	0501218668	3/4 X 135 AXLE		01
09	0501310839	3/4 X 305/303 AXLE		01




Item	Code	Description	See page	QT
01	0531064715	LEFT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	87	05
03	0501053788	3/4" SQUARE AXLE FASTENER	86	02
04	0503031527	AGRICULTURAL BEARING		02
05	0501310661	3/4" X 15,35"/15,27" AXLE		04
06	0531057908	SLEEVE 1/4 X 2		05
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	92	01
08	0501218668	3/4 X 135 AXLE		01
09	0501310839	3/4 X 305/303 AXLE		01




Item	Code	Description	See page	QT
01	0531056760	RIGHT HOPPER SUPPORT WITH FERTILIZER 78 METERING - 4495		01
02	0531056759	LEFT HOPPER SUPPORT WITH FERTILIZER 79 METERING - 4495		01
03	0503061985	FERTILIZER HOPPER WITH 5 TRUNNELS		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		09
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		18
07	0503010025	3/8 SPRING WASHER		09
08	0503010026	3/8" NUT		09
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0501010694	FLAT WASHER		04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" SPLIT PIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531064842	RIGHT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	87	05
03	0501053788	3/4" SQUARE AXLE FASTENER	86	02
04	0503031527	AGRICULTURAL BEARING		02
05	0501310661	3/4" X 15,35"/15,27" AXLE		03
06	0531057908	SLEEVE 1/4 X 2		04
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	92	01
08	0501310859	3/4 X 490/488 AXLE		01
09	0501310860	3/4 X 350/348 AXLE		01




Item	Code	Description	See page	QT
01	0531064841	LEFT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	87	05
03	0501053788	3/4" SQUARE AXLE FASTENER	86	03
04	0503031527	AGRICULTURAL BEARING		03
05	0501310661	3/4" X 15,35"/15,27" AXLE		03
06	0531057908	SLEEVE 1/4 X 2		04
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	92	01
08	0501310859	3/4 X 490/488 AXLE		01
09	0501310860	3/4 X 350/348 AXLE		01




Item	Code	Description	See page	QT
01	0531056604	RIGHT HOPPER SUPPORT WITH FERTILIZER 81 METERING - 4845	01	01
02	0531056605	LEFT HOPPER SUPPORT WITH FERTILIZER 82 METERING - 4845	01	01
03	0503062169	ASSEMBLED FERTILIZER HOPPER		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		20
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		40
07	0503010025	3/8 SPRING WASHER		20
08	0503010026	3/8" NUT		20
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0501010694	FLAT WASHER		04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" SPLIT PIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531064717	RIGHT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	87	06
03	0501053788	3/4" SQUARE AXLE FASTENER	86	03
04	0503031527	AGRICULTURAL BEARING		03
05	0501218487	3/4 X 390 AXLE		05
06	0531057908	SLEEVE 1/4 X 2		06
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	92	01
08	0501218676	3/4 X 125 AXLE WITH HOLE		01
09	0501218674	3/4 X 290 AXLE		01




Item	Code	Description	See page	QT
01	0531064718	LEFT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	87	06
03	0501053788	3/4" SQUARE AXLE FASTENER	86	03
04	0503031527	AGRICULTURAL BEARING		03
05	0501218487	3/4 X 390 AXLE		05
06	0531057908	SLEEVE 1/4 X 2		06
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	92	01
08	0501218676	3/4 X 125 AXLE WITH HOLE		01
09	0501218674	3/4 X 290 AXLE		01




Item	Code	Description	See page	QT
01	0531056920	RIGHT HOPPER SUPPORT WITH FERTILIZER 84 METERING - 5345	01	01
02	0531056919	LEFT HOPPER SUPPORT WITH FERTILIZER 85 METERING - 5345	01	01
03	0503062169	ASSEMBLED FERTILIZER HOPPER		02
04	0521015267	L 1.1/2" X 1/4" X 26.6" WITH HOLE		04
05	0503010849	3/8" X 1-1/2" BOLT		20
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		40
07	0503010025	3/8 SPRING WASHER		20
08	0503010026	3/8" NUT		20
09	0551019156	GEAR BOX LEVER LOCK		02
10	0503011953	5/16" X 1" BOLT		04
11	0501010694	FLAT WASHER		04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
13	0503010337	5/16" NUT		04
14	0551019168	SLEEVE		02
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
16	0503010479	BOLT		02
17	0503011336	1/2" HEX SELF ADJUSTING NUT		06
18	0501215701	ARM/DISARM LEVER		02
19	0551019167	SLEEVE UNION		02
20	0531064712	INNER LEVER		02
21	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0501013518	FLAT WASHER		06
25	0503010140	1/8" X 3/4" SPLIT PIN		06
26	0511069678	LH LOWER LEVER		02
27	0561016468	FASTENER		02
28	0551019159	LEVER FIXER BODY		02




Item	Code	Description	See page	QT
01	0531064949	RIGHT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	87	06
03	0501053788	3/4" SQUARE AXLE FASTENER	86	05
04	0503031527	AGRICULTURAL BEARING		05
05	0501218487	3/4 X 390 AXLE		05
06	0531057908	SLEEVE 1/4 X 2		06
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	92	01
08	0501218691	3/4 X 6,53/6,61 AXLE WITH HOLE		01
09	0501218858	3/4 X 355 AXLE		01




Item	Code	Description	See page	QT
01	0531064948	LEFT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	87	06
03	0501053788	3/4" SQUARE AXLE FASTENER	86	05
04	0503031527	AGRICULTURAL BEARING		05
05	0501218487	3/4 X 390 AXLE		05
06	0531057908	SLEEVE 1/4 X 2		06
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	92	01
08	0501218691	3/4 X 6,53/6,61 AXLE WITH HOLE		01
09	0501218858	3/4 X 355 AXLE		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01



Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	ASSY TRANSMISSION HUB	88	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	89	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513011170	ALLEN SCREW 1/4 UNC X 7/8 CCSI STAINLESS STEEL		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501310211	FRONT LID		01
19	0503036177	LID CORD		01
20	0531059139	ASSY COLLECTOR	90	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO ADHESIVE LABEL 41.5 X 29		01
15	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT GUIDE DOSING COVER		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01

ASSY COLLECTOR

0531059139




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	91	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02

22Z GEAR SIDE BEARING ASSEMBLY


0531057911




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007		02
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0503010337	5/16" NUT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0531057901	GEAR	93	01
07	0503010845	501035 CLAMPING RING (FOR AXLE)		01
08	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531065402	GEAR		01
02	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
04	0503010025	3/8 SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0511069725	RIGHT PLATFORM	01	
07	0521062318	LEFT PLATFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32" X 2" SPLIT PIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
04	0503010025	3/8 SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521063248	RIGHT PLATFORM	01	
07	0521063249	LEFT PLATFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32" X 2" SPLIT PIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT		04
02	0503010849	3/8" X 1-1/2" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0511069665	PLATFORM RIGHT		01
07	0521062323	PLATFORM LEFT		01
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
09	0503011336	1/2" HEX SELF ADJUSTING NUT		04
10	0503011333	COVER FIXER		02
11	0503010274	5/32" X 2" SPLIT PIN		02
12	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
13	0502012739	PLATFORM LEFT FIXER SUPPORT		01




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
04	0503010025	3/8 SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521062237	RIGHT PLATAFORM	01	
07	0521062238	LEFT PLATAFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32" X 2" SPLIT PIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT		04
02	0503010849	3/8" X 1-1/2" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0511069718	PLATFORM RIGHT		01
07	0521062324	PLATFORM LEFT		01
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
09	0503011336	1/2" HEX SELF ADJUSTING NUT		04
10	0503011333	COVER FIXER		02
11	0503010274	5/32" X 2" SPLIT PIN		02
12	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
13	0502012739	PLATFORM LEFT FIXER SUPPORT		01




Item	Code	Description	See page	QT
01	0511069661	PLATFORM SUPPORT PIVOT	04	
02	0503010849	3/8" X 1-1/2" BOLT	08	
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
04	0503010025	3/8 SPRING WASHER	08	
05	0503010026	3/8" NUT	08	
06	0521062450	RIGHT PLATFORM	01	
07	0521062451	LEFT PLATFORM	01	
08	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN	04	
09	0503011336	1/2" HEX SELF ADJUSTING NUT	04	
10	0503011333	COVER FIXER	02	
11	0503010274	5/32" X 2" SPLIT PIN	02	
12	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
13	0502012739	PLATFORM LEFT FIXER SUPPORT	01	




Item	Code	Description	See page	QT
01	0511069635	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0521063250	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0511069656	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08



Item	Code	Description	See page	QT
01	0521062239	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0511069660	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0521062449	HANDRAIL		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08

LADDER ASSEMBLY

0511056536




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8 SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
08	0503013357	3/8 SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01

DRAWBAR ASSEMBLY - 3245/3695/4045/4495


0511057142




Item	Code	Description	See page	QT
01	0502012329	DRAWBAR FIXATION REAR SUPPORT		02
02	0502012330	SUPPORT FIXER PIVOT		04
03	0503011084	3/4" X 5" BOLT		08
04	0501010322	FLAT WASHER		08
05	0503010023	3/4" SPRING WASHER		08
06	0503010014	3/4" HEX NUT		08
07	0502012328	DRAWBAR SUPPORT FRONT FIXATION		02
08	0561014393	COUPLING SHAFT		02
09	0503030119	LOCK PIN		04
10	0531063130	DRAWBAR		01
11	0561019087	DRAWBAR TRANSPORT LOCK		01
12	0521010578	COUPLING SHAFT		01
13	0521010588	0.9" X 7.0" COUPLING SHAFT		01
14	0503030085	LOCK PIN		02
15	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	1902012329	REAR SUPPORT FIXING DRAWBAR	04	
02	1902012330	FIXER SUPPORT ARTICULATED	08	
03	0503011084	3/4" X 5" BOLT	16	
04	0503010023	3/4" SPRING WASHER	16	
05	0503010014	3/4" HEX NUT	16	
06	1902012328	FIXED FRONT SUPPORT DRAWBAR	04	
07	0561014393	COUPLING SHAFT	04	
08	0503030119	LOCK PIN	08	
09	0511064808	DRAWBAR	01	
10	0561019087	DRAWBAR TRANSPORT LOCK	01	
11	0521010588	0.9" X 7.0" COUPLING SHAFT	01	
12	0521010578	COUPLING SHAFT	01	
13	0503030085	LOCK PIN	02	
14	0503010002	1800 GREASE FITTING	01	
15	0501010322	FLAT WASHER	16	




Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033416	ADHESIVE LABEL	02	
05	0503033417	ADHESIVE LABEL	02	
06	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	02	
07	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
08	0503033008	ADHESIVE LABEL	02	
09	0503031428	READ MANUAL DECAL	01	
10	0503031942	ADHESIVE LABEL	01	
11	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27	02	
12	0503031565	ADHESIVE LABEL CARE	02	
13	0503031566	ADHESIVE LABEL	02	
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
15	0503031425	ADHESIVE LABEL ATTENTION	02	
16	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER	02	
17	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
19	0503032930	ADHESIVE LABEL DANGER	04	
20	0503031087	ADHESIVE LABEL	01	
21	0503034003	SERIAL NUMBER TAG 61 X 118	01	
22	0503010001	3.2 X 5.5 RIVET	04	
23	0503034078	LIFTING POINTS DECAL	03	
24	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
25	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033417	ADHESIVE LABEL	02	
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
06	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING	02	
07	0503033423	LABEL ADHESIVE NUMBER 9	02	
08	0503033008	ADHESIVE LABEL	02	
09	0503031428	READ MANUAL DECAL	01	
10	0503031942	ADHESIVE LABEL	01	
11	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27	02	
12	0503031565	ADHESIVE LABEL CARE	02	
13	0503031566	ADHESIVE LABEL	02	
14	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
15	0503031425	ADHESIVE LABEL ATTENTION	02	
16	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER	02	
17	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
19	0503032930	ADHESIVE LABEL DANGER	04	
20	0503031087	ADHESIVE LABEL	01	
21	0503034078	LIFTING POINTS DECAL	03	
22	0503034003	SERIAL NUMBER TAG 61 X 118	01	
23	0503010001	3.2 X 5.5 RIVET	04	
24	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
25	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING	02	
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
07	0503033008	ADHESIVE LABEL	02	
08	0503031428	READ MANUAL DECAL	01	
09	0503031942	ADHESIVE LABEL	01	
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27	02	
11	0503031565	ADHESIVE LABEL CARE	02	
12	0503031566	ADHESIVE LABEL	02	
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
14	0503031425	ADHESIVE LABEL ATTENTION	02	
15	0503031567	ADHESIVE LABEL ATTENTION	02	
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503032930	ADHESIVE LABEL DANGER	05	
19	0503031087	ADHESIVE LABEL	01	
20	0503034078	LIFTING POINTS DECAL	03	
21	0503034003	SERIAL NUMBER TAG 61 X 118	01	
22	0503010001	3.2 X 5.5 RIVET	04	
23	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
24	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
07	0503033008	ADHESIVE LABEL		02
08	0503031428	READ MANUAL DECAL		01
09	0503031942	ADHESIVE LABEL		01
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
11	0503031565	ADHESIVE LABEL CARE		02
12	0503031566	ADHESIVE LABEL		02
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
14	0503031425	ADHESIVE LABEL ATTENTION		02
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503032930	ADHESIVE LABEL DANGER		05
19	0503031087	ADHESIVE LABEL		01
20	0503034078	LIFTING POINTS DECAL		03
21	0503034003	SERIAL NUMBER TAG 61 X 118		01
22	0503010001	3.2 X 5.5 RIVET		04
23	0503032979	ADHESIVE LABEL LETTERS A B C D		02
24	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
06	0503033423	LABEL ADHESIVE NUMBER 9	02	
07	0503033008	ADHESIVE LABEL	02	
08	0503031428	READ MANUAL DECAL	01	
09	0503031942	ADHESIVE LABEL	01	
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27	02	
11	0503031565	ADHESIVE LABEL CARE	02	
12	0503031566	ADHESIVE LABEL	02	
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
14	0503031425	ADHESIVE LABEL ATTENTION	02	
15	0503031567	ADHESIVE LABEL ATTENTION	02	
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503032930	ADHESIVE LABEL DANGER	04	
19	0503031087	ADHESIVE LABEL	01	
20	0503034078	LIFTING POINTS DECAL	03	
21	0503034003	SERIAL NUMBER TAG 61 X 118	01	
22	0503010001	3.2 X 5.5 RIVET	04	
23	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
24	0503034500	ADHESIVE LABEL	01	



Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
06	0503033423	LABEL ADHESIVE NUMBER 9	02	
07	0503033008	ADHESIVE LABEL	02	
08	0503031428	READ MANUAL DECAL	01	
09	0503031942	ADHESIVE LABEL	01	
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27	02	
11	0503031565	ADHESIVE LABEL CARE	02	
12	0503031566	ADHESIVE LABEL	02	
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
14	0503031425	ADHESIVE LABEL ATTENTION	02	
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER	02	
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503032930	ADHESIVE LABEL DANGER	04	
19	0503031087	ADHESIVE LABEL	01	
20	0503034078	LIFTING POINTS DECAL	03	
21	0503034003	SERIAL NUMBER TAG 61 X 118	01	
22	0503010001	3.2 X 5.5 RIVET	04	
23	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
24	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL	02	
02	0503033854	ADHESIVE LABEL	02	
03	0503033853	ADHESIVE LABEL	02	
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	04	
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
06	0503033422	ADHESIVE LABEL	02	
07	0503033008	ADHESIVE LABEL	02	
08	0503031428	READ MANUAL DECAL	01	
09	0503031942	ADHESIVE LABEL	01	
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27	02	
11	0503031565	ADHESIVE LABEL CARE	02	
12	0503031566	ADHESIVE LABEL	02	
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE	02	
14	0503031425	ADHESIVE LABEL ATTENTION	02	
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER	02	
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503032930	ADHESIVE LABEL DANGER	06	
19	0503031087	ADHESIVE LABEL	01	
20	0503034078	LIFTING POINTS DECAL	03	
21	0503034003	SERIAL NUMBER TAG 61 X 118	01	
22	0503010001	3.2 X 5.5 RIVET	04	
23	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
24	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503033869	ADHESIVE LABEL		02
02	0503033854	ADHESIVE LABEL		02
03	0503033853	ADHESIVE LABEL		02
04	0503033417	ADHESIVE LABEL		02
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		04
07	0503033008	ADHESIVE LABEL		02
08	0503031428	READ MANUAL DECAL		01
09	0503031942	ADHESIVE LABEL		01
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
11	0503031565	ADHESIVE LABEL CARE		02
12	0503031566	ADHESIVE LABEL		02
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
14	0503031425	ADHESIVE LABEL ATTENTION		02
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503032930	ADHESIVE LABEL DANGER		06
19	0503031087	ADHESIVE LABEL		01
20	0503034078	LIFTING POINTS DECAL		03
21	0503034003	SERIAL NUMBER TAG 61 X 118		01
22	0503010001	3.2 X 5.5 RIVET		04
23	0503032979	ADHESIVE LABEL LETTERS A B C D		02
24	0503034500	ADHESIVE LABEL		01

ASSY HEX AXLE


0909098921




Item	Code	Description	See page	3695	4045	4495	4845	5345
01	0571011601	HEX AXIS 5/8 X 2005	01	00	00	00	00	00
01.	0521013429	AXLE HEX 5/8 X 2180	00	01	00	00	00	00
01..	0561018352	RIGHT HEX SHAFT 5/8 X 2375	00	00	01	00	00	00
01...	0521013430	HEX AXLE 5/8 X 2580	00	00	00	01	00	00
01....	0561019214	HEX AXLE 5/8 X 2805 RIGHT	00	00	00	00	00	01
02	0571011600	SIXTH AXIS 5/8 X 1725	01	00	00	00	00	00
02.	0521013433	5/8" X 75" AXLE HEX	00	01	00	00	00	00
02..	0561018353	5/8 X 2150 LEFT HEX AXLE	00	00	01	00	00	00
02...	0521013434	HEX AXLE 5/8 X 2300	00	00	00	01	00	00
02....	0561019215	HEX AXLE 5/8 X 2555 LEFT	00	00	00	00	00	01
03	0503010571	1/4" X 1.1/2" SPLIT PIN	02	02	02	02	02	02
04	0501110037	AGRICULTURAL BEARING HEX SHAFT 5/8"	02	02	02	02	02	02
05	0502040723	5/8 HEX AXLE BEARING SLEEVE 5/8	02	02	02	02	02	02
06	0503010003	1845 GREASE FITTING	02	02	02	02	02	02
07	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN	04	04	04	04	04	04
08	0501010984	10,50 X 27 X 3,00 FLAT WASHER	04	04	04	04	04	04
09	0501010694	FLAT WASHER	08	08	08	08	08	08
10	0503010179	LOCK WASHER 5/16 ZN 1K01528	04	04	04	04	04	04
11	0503010337	5/16" NUT	04	04	04	04	04	04
12	0511015098	FLAT WASHER	02	02	02	02	02	02
13	0511017305	FLAT WASHER	04	04	04	04	04	04
14	0511065562	20Z GEAR	02	02	02	02	02	02
15	0502011299	BUSHING GEAR	02	02	02	02	02	02
16	0503010010	1/4" X 2.1/2" SPLIT PIN	02	02	02	02	02	02



Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0511062887	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2" SPLIT PIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01

HOSE SUPPORT


0511056736




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		04
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		04
01B	0503035859	SUPPORT SLEEVE		04
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		04
02A	0501111196	PELLETED FERTILIZER METERING COATING		04
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		04
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		05
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		05
01B	0503035859	SUPPORT SLEEVE		05
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		05
02A	0501111196	PELLETED FERTILIZER METERING COATING		05
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		05
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		06
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		06
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		07
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		07
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		08
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		08
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01







Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		09
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		09
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		10
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		10
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		11
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		11
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01



Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		12
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		12
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01



Item	Code	Description	See page	QT
01	0521066608	LIFTING HOOK		01
02	0581019707	FIXATION SUPPORT SUPPORT		01
03	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
04	0501012140	FLAT WASHER		04
05	0503012412	5/8" UNC SELF LOCKING NUT		04




Item	Code	Description	See page	QT
01	0511053254	FERTILIZER SHORT ROW WITH LEFT DDD/20" DC	135	01
01.	0531050532	SHORT FERTILIZER LOWER LEFT DDD DC20	136	01
02	0511050967	SHORT FERTILIZER ROW	137	01
03	0521051039	SHORT FERTILIZER ROW LEFT DDD DOC20	138	01
04	0511053255	FERTILIZER LONG ROW WITH RIGHT DDD/20" DC	139	01
04.	0531050534	RIGHT LONGER FERTILIZER DDD RIGHT DC20	140	01
05	0511050968	LONG FERTILIZER ROW	141	01
06	0521051041	LONG FERTILIZER ROW RIGHT DDD DOC20	142	01
07	0501058271	SHORT FERTILIZER ROW WITHOUT DDD/H	143	01
08	0501058272	LONG FERTILIZER ROW WITHOUT DDD/H	144	01
09	0511053253	FERTILIZER LONG ROW WITH RIGHT DDD/18" DC	145	01
10	0511053252	FERTILIZER SHORT ROW WITH LEFT DDD/18" DC	146	01
11	0531054249	INDIVIDUAL SHORT SEED ROW	164	01
12	0531054248	INDIVIDUAL LONG SEED ROW	168	01
13	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	180	01
13.	0521051424	WHEEL SYSTEM DEPTH/COMPACTOR QUICK ADJUSTMENT	190	01
13..	0521044538	DEPHT WHIT REGULACION ANGLE COMPACT CONTROL	195	01
13...	0521042327	DEPTH CONTROL & PRESS WHEEL ASSY	204	01
13....	0521056317	DEPTH CONTROL WITH LEVER ANGLE REGULATOR AXIS CPERA	206	01
14	0501110231	SCARIFIER ROD WITH TIP	210	01
15	0511017969	0.1" SPACING PLATE		01
16	0521069124	PIVOTED FERTILIZER ROW NOZZLE		01
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
18	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
19	0503010025	3/8 SPRING WASHER		01
20	0503010026	3/8" NUT		01
21	0503010905	1/2" X 2-1/4" BOLT		01
22	0503010019	1/2" SPRING WASHER		01
23	0503010060	1/2 UNC G.5 ZN HEX NUT		01


ASSY SEED/FERTILIZER ROW

0909096219


Item	Code	Description	See page	QT
24	0503063647	SIGMA CORN DISC SET	178	01
25	0503063648	SIGMA SOY DISC SET	179	01
26	0501053866	COVERING WHEEL FERTILIZER V RIGHT IRON	212	01
27	0501053867	COVERING V WHEEL FERTILIZER LEFT IRON	213	01
28	0503030391	RIGHT FERTILIZER NOZZLE		01
29	0503030392	LEFT FERTILIZER NOZZLE		01
30	0501013714	STABILIZER BAR		01
31	0503031050	CURVED CONDUCTOR		01
32	0503010246	CLAMP		01
33	0501018652	CORN STABILIZER BAR		01
34	0511018662	SPACING PLATE		01
35	0511061769	RIGHT FERTILIZER CONDUCTOR WITH REGULATOR		01
36	0511061770	LEFT CONDUCTOR FERTILIZER WITH REGULATOR		01
37	0501052735	COVERING WHEEL RIGHT FERTILIZER ASSY IRON	217	01
38	0501052736	COVERING WHEEL LEFT FERTILIZER ASSY IRON	218	01
39	0521053955	ROD WITH ARM/DISARMMENT	222	01
40	0581010082	FERTILIZER SOCKET RIGHT		01
41	0581010083	FERTILIZER SOCKET LEFT		01
42	0503031145	2" X 2" X 20" HOSE		01
43	0521067360	PROTRACTOR CPRA		01
44	0501110723	SCARIFIER ROD	225	01
45	0503031076	2" HOSE CLAMP		01
46	0521050168	MOUNTED FERTILIZER CONDUCTOR	226	01
47	0511058877	REGULATORY KEY		01
47A	0521066800	BODY REGULATORY KEY		01
47B	0503030878	LEVER CRANK		01




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT 147		01
		DOUBLE DISC		
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	155	01
07	0501058423	FERTILIZER ROD SPRING ROW	162	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521052634	SHORT LOWER FERTILIZER ROW ARM WITH LEFT DDD	149	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	155	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	163	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521061121	SHORT FERTILIZER ROW ARM		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044563	20" COULTER BLADE ASSY FOR SHORT ROW	155	01
07	0501058423	FERTILIZER ROD SPRING ROW	162	01




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT 147		01
02	0501010066	DOUBLE DISC		01
03	0521017831	3/4" X 9" BOLT		02
04	0511017232	SUPPORT SLEEVE SPACER		02
05	0511017232	FLAT WASHER		01
06	0503011255	3/4" LOCK NUT		01
07	0521044545	20" SHORT CURVED CORRIGATED DISC	160	01
08	0501058423	FERTILIZER ROD SPRING ROW	162	01
09	0503030391	RIGHT FERTILIZER NOZZLE		01
10	0503031145	2" X 2" X 20" HOSE		01
	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	148	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	156	01
07	0501058423	FERTILIZER ROD SPRING ROW	162	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521052635	LONG LOWER ARM FERTILIZER ROW WITH RIGHT DDD	150	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	156	01
07	0521052644	TIGHT ELEVATION SPRING FULL FERTILIZER	163	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521061153	FERTILIZER ROW LONG ARM		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044585	20" COULTER BLADE ASSY FOR LONG ROW	156	01
07	0501058423	FERTILIZER ROD SPRING ROW	162	01




Item	Code	Description	See page	QT
01	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	148	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0521044546	20" LONG CURVED CORRUGATED DISC	161	01
07	0501058423	FERTILIZER ROD SPRING ROW	162	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0521061121	SHORT FERTILIZER ROW ARM		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	158	01
07	0501058423	FERTILIZER ROD SPRING ROW	162	01




Item	Code	Description	See page	QT
01	0521061153	FERTILIZER ROW LONG ARM		01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	157	01
07	0501058423	FERTILIZER ROD SPRING ROW	162	01




Item	Code	Description	See page	QT
01	0511053251	LONG ARM FERTILIZER ROW WITH RIGHT DOUBLE DISC	148	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044573	18" COULTER BLADE ASSY FOR LONG ROW	157	01
07	0501058423	FERTILIZER ROD SPRING ROW	162	01
08	0503030392	LEFT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511053250	SHORT ARM FERTILIZER ROW WITH LEFT DOUBLE DISC	147	01
02	0501010066	3/4" X 9" BOLT		01
03	0521017831	SUPPORT SLEEVE SPACER		02
04	0511017232	FLAT WASHER		02
05	0503011255	3/4" LOCK NUT		01
06	0511044549	18" COULTER BLADE ASSY FOR SHORT ROW	158	01
07	0501058423	FERTILIZER ROD SPRING ROW	162	01
08	0503030391	RIGHT FERTILIZER NOZZLE		01
09	0503031145	2" X 2" X 20" HOSE		01
10	0503031076	2" HOSE CLAMP		02




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061121	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	151	01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521061153	FERTILIZER ROW LONG ARM		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	152	01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521068566	SHORT FERTILIZER ROW ARM		01
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	151	01




Item	Code	Description	See page	QT
01	0511018662	SPACING PLATE		04
02	0503010547	1/2" X 4" BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02
05	0521068565	LONG FERTILIZER ROW ARM		01
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	152	01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	153	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	154	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02



Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	154	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	153	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUBLE DISC AXLE		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01

20" COULTER BLADE ASSY FOR SHORT ROW

0511044563




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01	
03	0541018684	FLAT WASHER	01	
04	0503010756	0.2" X 2.4" SPRING PIN	01	
05	0503010361	SPRING PIN	01	
06	0503010003	1845 GREASE FITTING	01	
07	0521014137	RIGHT ARM BLADE DISC	01	
08	0521014138	LEFT DISC BLADE ARM	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503013185	3/4" X 5-1/2" BOLT	01	
12	0503011255	3/4" LOCK NUT	01	
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
14	0503011411	1/2" X 5-1/2" BOLT	01	
15	0503010019	1/2" SPRING WASHER	01	
16	0503010060	1/2 UNC G.5 ZN HEX NUT	01	
17	0502020393	SPRING UPPER SUPPORT	01	
18	0502020394	SPRING SUPPORT	01	
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
20	0503010014	3/4" HEX NUT	02	
21	0521054680	20" DISC BLADE HUB	01	



Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0511067044	LONG DISC BLADE FIXING AXIS	01	
03	0541018684	FLAT WASHER	01	
04	0503010756	0.2" X 2.4" SPRING PIN	01	
05	0503010361	SPRING PIN	01	
06	0503010003	1845 GREASE FITTING	01	
07	0521014137	RIGHT ARM BLADE DISC	01	
08	0521014138	LEFT DISC BLADE ARM	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503013185	3/4" X 5-1/2" BOLT	01	
12	0503011255	3/4" LOCK NUT	01	
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
14	0503011411	1/2" X 5-1/2" BOLT	01	
15	0503010019	1/2" SPRING WASHER	01	
16	0503010060	1/2 UNC G.5 ZN HEX NUT	01	
17	0502020393	SPRING UPPER SUPPORT	02	
18	0502020394	SPRING SUPPORT	01	
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
20	0503010014	3/4" HEX NUT	02	
21	0521054680	20" DISC BLADE HUB	01	

18" COULTER BLADE ASSY FOR LONG ROW


0511044573




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0503010003	1845 GREASE FITTING	01	
03	0511067044	LONG DISC BLADE FIXING AXIS	01	
04	0521014137	RIGHT ARM BLADE DISC	01	
05	0521014138	LEFT DISC BLADE ARM	01	
06	0521054686	18" DISC BLADE HUB	01	
07	0503010756	0.2" X 2.4" SPRING PIN	01	
08	0503010361	SPRING PIN	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503011255	3/4" LOCK NUT	01	
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
13	1902020394	SPRING SUPPORT	01	
14	1902020393	SPRING UPPER SUPPORT	01	
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
16	0503010014	3/4" HEX NUT	02	
17	0541018684	FLAT WASHER	01	
18	0503013185	3/4" X 5-1/2" BOLT	01	
19	0503010019	1/2" SPRING WASHER	01	
20	0503010060	1/2 UNC G.5 ZN HEX NUT	01	
21	0503011411	1/2" X 5-1/2" BOLT	01	

18" COULTER BLADE ASSY FOR SHORT ROW

0511044549




Item	Code	Description	See page	QT
01	0502012368	BLADE DISC SUPPORT AXLE	01	
02	0503010003	1845 GREASE FITTING	01	
03	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01	
04	0521014137	RIGHT ARM BLADE DISC	01	
05	0521014138	LEFT DISC BLADE ARM	01	
06	0521054686	18" DISC BLADE HUB	01	
07	0503010756	0.2" X 2.4" SPRING PIN	01	
08	0503010361	SPRING PIN	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503011255	3/4" LOCK NUT	01	
12	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
13	1902020394	SPRING SUPPORT	01	
14	1902020393	SPRING UPPER SUPPORT	01	
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
16	0503010014	3/4" HEX NUT	02	
17	0541018684	FLAT WASHER	01	
18	0503013185	3/4" X 5-1/2" BOLT	01	
19	0503010019	1/2" SPRING WASHER	01	
20	0503010060	1/2 UNC G.5 ZN HEX NUT	01	
21	0503011411	1/2" X 5-1/2" BOLT	01	



Item	Code	Description	See page	QT
01	0502011562	DISC BLADE HUB		01
02	0503010276	6206 BALL BEARING		02
03	0521013610	BLADE DISC HUB AXLE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603027851	20" X 0.2" FLAT PLAIN DISC		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503011444	SPRING WASHER		06
12	0503010337	5/16" NUT		06

20" SHORT CURVED CORRIGATED DISC

0521044545



Item	Code	Description	See page	QT
01	0511067045	SHORT WHIT BEATER BLADE DISC FIX AXLE	01	
02	0502012368	BLADE DISC SUPPORT AXLE	01	
03	0541018684	FLAT WASHER	01	
04	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	02	
05	0503010756	0.2" X 2.4" SPRING PIN	01	
06	0503010361	SPRING PIN	01	
07	0521014137	RIGHT ARM BLADE DISC	01	
08	0521014138	LEFT DISC BLADE ARM	01	
09	0501067323	SPRING REGULATOR	01	
10	0521010452	SLEEVE	01	
11	0503013185	3/4" X 5-1/2" BOLT	01	
12	0503011255	3/4" LOCK NUT	01	
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	
14	0503011411	1/2" X 5-1/2" BOLT	01	
15	0503011440	SPRING WASHER	01	
16	0503010060	1/2 UNC G.5 ZN HEX NUT	01	
17	1902020393	SPRING UPPER SUPPORT	01	
18	0502020394	SPRING SUPPORT	01	
19	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	
20	0503010014	3/4" HEX NUT	02	
21	0511054673	DPLO20	01	
21A	0502011562	DISC BLADE HUB	01	
21B	0503010276	6206 BALL BEARING	02	
21C	0521013610	BLADE DISC HUB AXLE	01	
21D	0503030832	FLAT WASHER	02	
21E	0503012417	SEAL	02	
21F	0503011800	SEAL RING	02	
21G	0503010691	1/4" GREASE FITTING	01	
21H	0607026025	DPLO20X4,5	01	
21I	0502020641	BLADE DISC FLANGE	01	
21J	0503010371	5/16" X 1" BOLT	06	


**20" SHORT CURVED CORRIGATED DISC**

0521044545

Item	Code	Description	See page	QT
21K	0503011444	SPRING WASHER		06
21L	0503010337	5/16" NUT		06
22	0521015376	DUST CLOAK		02
23	0511015346	FLAT WASHER		06
24	0503011438	SPRING WASHER		02
25	0521013510	3/4" NUT		02
26	0503010003	1845 GREASE FITTING		01

20" LONG CURVED CORRUGATED DISC

0521044546




Item	Code	Description	See page	QT
01	0511067044	LONG DISC BLADE FIXING AXIS	01	01
02	0502012368	BLADE DISC SUPPORT AXLE	01	01
03	0541018684	FLAT WASHER	01	01
04	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN	02	02
05	0503010756	0.2" X 2.4" SPRING PIN	01	01
06	0503010361	SPRING PIN	01	01
07	0521014137	RIGHT ARM BLADE DISC	01	01
08	0521014138	LEFT DISC BLADE ARM	01	01
09	0501067323	SPRING REGULATOR	01	01
10	0521010452	SLEEVE	01	01
11	0503013185	3/4" X 5-1/2" BOLT	01	01
12	0503011255	3/4" LOCK NUT	01	01
13	0571010188	13,50 X 19 X 86,30/86 SLEEVE	01	01
14	0503011411	1/2" X 5-1/2" BOLT	01	01
15	0503011440	SPRING WASHER	01	01
16	0503010060	1/2 UNC G.5 ZN HEX NUT	01	01
17	1902020393	SPRING UPPER SUPPORT	02	02
18	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING	01	01
19	0503010014	3/4" HEX NUT	02	02
20	0511054673	DPLO20	01	01
20A	0502011562	DISC BLADE HUB	01	01
20B	0503010276	6206 BALL BEARING	02	02
20C	0521013610	BLADE DISC HUB AXLE	01	01
20D	0503030832	FLAT WASHER	02	02
20E	0503012417	SEAL	02	02
20F	0503011800	SEAL RING	02	02
20G	0503010691	1/4" GREASE FITTING	01	01
20H	0607026025	DPLO20X4,5	01	01
20I	0502020641	BLADE DISC FLANGE	01	01
20J	0503010371	5/16" X 1" BOLT	06	06
20K	0503011444	SPRING WASHER	06	06


**20" LONG CURVED CORRUGATED DISC**

0521044546


Item	Code	Description	See page	QT
20L	0503010337	5/16" NUT		06
21	0521015376	DUST CLOAK		02
22	0511015346	FLAT WASHER		06
23	0503011438	SPRING WASHER		02
24	0521013510	3/4" NUT		02
25	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511069645	FERTILIZER SPRING ROD	01	
02	0502040534	SPRING GUIDE BUSHING LOCK	02	
03	0502012184	FERTILIZER SPRING GUIDE	02	
04	0503031910	1.7" X 22.8" X 0.3" SPRING	01	
05	0502012510	SPRING ROD SUPPORT	01	
06	0503010257	1/8" X 1" SPLIT PIN	01	
07	0501018535	1/2 X 1 BOLT	02	
08	0503030678	BOLT 1/2 UNC X 1.1/2 C50P G.5 ZN	02	
09	0503010060	1/2 UNC G.5 ZN HEX NUT	02	
10	1902010891	SPRING CHOCK SUPPORT VARON	01	
11	0503010014	3/4" HEX NUT	01	
12	0561014471	COUPLING SHAFT	01	
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN	01	




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK	02	
02	0502012184	FERTILIZER SPRING GUIDE	02	
03	0503031910	1.7" X 22.8" X 0.3" SPRING	01	
04	0502012510	SPRING ROD SUPPORT	01	
05	0521068568	LARGE ELEVATION SPRING FERTILIZER	01	
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN	01	
07	0501018535	1/2 X 1 BOLT	02	
08	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	01	
09	0503010060	1/2 UNC G.5 ZN HEX NUT	02	
10	0502010891	SPRING ROD SUPPORT CHOCK	01	
11	0503010014	3/4" HEX NUT	01	
12	0561014471	COUPLING SHAFT	01	
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN	01	
14	0503010257	1/8" X 1" SPLIT PIN	01	




Item	Code	Description	See page	QT
01	0511056600	RIGHT DDD SHORT SEED ROW FRONT	165	01
02	0511058212	FERTILIZER ROW SUPPORT ASSY	173	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0511060376	SEED SPRING GUIDE		01
06	1902012538	SPRING ROD SUPPORT		01
07	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
09	0503011336	1/2" HEX SELF ADJUSTING NUT		02
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8" X 1" SPLIT PIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		02
13	0501018535	1/2 X 1 BOLT		02
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
16	0501013753	FLAT WASHER		01
17	0503010013	5/8 NUT		01
18	0511052024	FAST CLOSING SET	174	01
19	0531053925	SIGMA SOY INDIVIDUAL SEED SYSTEM	175	01
20	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
22	0503010019	1/2" SPRING WASHER		01
23	0503010060	1/2 UNC G.5 ZN HEX NUT		01
24	0503011099	GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521062183	SHORT SEED ROW ARM		01
02	0502011830	ARTICULATION SUPPORT		01
03	0521018079	SEED ROW DRAWBAR LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		02
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0503011440	SPRING WASHER		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0501013354	FLAT WASHER		02
15	0502011400	18Z CONICAL GEAR		01
16	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
17	0502011505	18Z CONICAL GEAR		01
18	0521018077	1/2" X 58.6" HEX AXLE		01
19	0501013352	FLAT WASHER		04
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	172	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04
25	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
26	0503011440	SPRING WASHER		02
27	0503010060	1/2 UNC G.5 ZN HEX NUT		02
28	0511056585	RIGHT 15" X 15" DOUBLE DISC SEED	166	01




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	167	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	154	01
03	0511053172	LEFT LOW HUB WITH 15 DISC	153	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0511056601	LONG SEED ROW FRONT DDD LEFT	169	01
02	0511058212	FERTILIZER ROW SUPPORT ASSY	173	01
03	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0511060376	SEED SPRING GUIDE		01
06	1902012538	SPRING ROD SUPPORT		01
07	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
09	0503011336	1/2" HEX SELF ADJUSTING NUT		02
10	0521010542	COUPLING SHAFT		01
11	0503010257	1/8" X 1" SPLIT PIN		01
12	0502040534	SPRING GUIDE BUSHING LOCK		02
13	0501018535	1/2 X 1 BOLT		02
14	0503031340	1.7"X 19" X 0.3" COMPRESSION SPRING		01
15	0503031339	1" X 19" X 0.1" COMPRESSION SPRING		01
16	0501013753	FLAT WASHER		01
17	0503010013	5/8 NUT		01
18	0511052024	FAST CLOSING SET	174	01
19	0531053925	SIGMA SOY INDIVIDUAL SEED SYSTEM	175	01
20	0521010505	13,50 X 19,00 X 21,50 SLEEVE		01
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
22	0503010019	1/2" SPRING WASHER		01
23	0503010060	1/2 UNC G.5 ZN HEX NUT		01
24	0503011099	GREASE FITTING		02



Item	Code	Description	See page	QT
01	0521062184	LONG SEED ROW ARM		01
02	0502011830	ARTICULATION SUPPORT		01
03	0521018079	SEED ROW DRAWBAR LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		02
05	0503011441	SPRING WASHER		02
06	0503010752	1/2" X 3.1/2" BOLT		02
07	0503011440	SPRING WASHER		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		02
09	0502011561	BEARING SEMI		01
10	0502010426	UPPER BEARING SEMI		02
11	0503010479	BOLT		04
12	0503011440	SPRING WASHER		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0501013354	FLAT WASHER		02
15	0502011400	18Z CONICAL GEAR		01
16	0502011296	1/2 HEX AXLE BEARING SLEEVE		01
17	0502011505	18Z CONICAL GEAR		01
18	0521018078	1/2" X 66.5" HEX AXLE		01
19	0501013352	FLAT WASHER		04
20	0503033672	NOZZLE WITHOUT TITANIUM		01
21	0511051693	BASE FIXING SYSTEM	172	01
22	0503015920	3/8" UNC X 1.3/4" BOLT		04
23	0503011443	3/8" SPRING WASHER		04
24	0503010026	3/8" NUT		04
25	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
26	0503011440	SPRING WASHER		02
27	0503010060	1/2 UNC G.5 ZN HEX NUT		02
28	0511056586	15 X 15 SEED DDD LEFT	170	01




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	171	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	154	01
03	0511053172	LEFT LOW HUB WITH 15 DISC	153	01
04	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		01
09	0503010026	3/8" NUT		01
10	0511815098	FLAT WASHER		04
11	0571011152	DOUBLE DISC CAP		02
12	0503015081	502052 CLAMPING RING (FOR AXLE)		02
13	0503014679	2-134 O'RING		02
14	0511011927	DUST CLOAK		02
15	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02

BASE FIXING SYSTEM

0511051693




Item	Code	Description	See page	QT
01	0502012704	BASE FIXING SYSTEM		01
02	0501013354	FLAT WASHER		01
03	0502011411	10Z CONICAL GEAR		01
04	0502011418	40Z CONICAL GEAR		01
05	0511018700	AXLE		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0502011567	FERTILIZER ROW SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02

FAST CLOSING SET


0511052024



Item	Code	Description	See page	QT
01	0571011803	PRISONER CLOSE FAST		01
02	0571011804	FAST BOLT ADJUSTMENT		01
03	0502012744	SPEED LOCK LEVER ASSY		01
04	0571014024	FAST BOLT GUIDE AXLE		02
05	0503010140	1/8" X 3/4" SPLIT PIN		02




Item	Code	Description	See page	QT
01	0531051514	SIGMA SOY SEED SYSTEM	176	01
02	0503063602	SEMI-ASSEMBLED SIGMA INDIVIDUAL SEED HOPPER		01
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
04	0501010694	FLAT WASHER		04
05	0503010240	BOLT		04
06	0503035691	ADHESIVE LABEL		02




Item	Code	Description	See page	QT
01	0511057289	ASSY SEED DEFLECTOR	177	01
02	0503030083	3/8" X 3/8" X 1.6" STUD		02
03	0503010675	5/16" X 2.1/4" BOLT		01
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
05	0503010337	5/16" NUT		01
06	0502012974	LOWER SEED DISC BASE		01
07	0501013518	FLAT WASHER		02
08	0503010025	3/8 SPRING WASHER		02
09	0503010209	3/8" UNC BUTTERFLY NUT		02
10	0503016282	ALLEN BOLT		01
11	0503019913	SELF-LOCKING NUT W/ NYLON M8 X 1.25 C.8 ZN		01
12	0503035299	PLATE SPRING 16 X 8.2 X 0.90		02
13	0591018706	SEED HOPPER SUPPORT		01
14	0513010140	SOCIDISCO SOY DISC 90 HOLES		01
15	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461		01
16	0503063405	SOY SEED DISTRIBUTOR CAP		01

ASSY SEED DEFLECTOR


0511057289




Item	Code	Description	See page	QT
01	0503010025	3/8 SPRING WASHER		01
02	0503010209	3/8" UNC BUTTERFLY NUT		01
03	0571018536	HEX PRISONER		01
04	0501013518	FLAT WASHER		02
05	0503034131	DEFLECTOR		01




Item	Code	Description	See page	QT
01	0513010117	SOCIDISCO CORN DISC 28 HOLES 9,0 AMC9R-002130	01	01
02	0513010118	SOCIDISCO CORN DISC 28 HOLES 9,5 VLD9.5R-002115	01	01
03	0513010119	SOCIDISCO CORN DISC 28 HOLES 10 SAL10R-002619	01	01
04	0513010120	SOCIDISCO CORN DISC 28 HOLES 10,5 RSP10.5R-002133	01	01
05	0513010121	SOCIDISCO CORN DISC 28 HOLES 11 LRA11R-002134	01	01
06	0513010122	SOCIDISCO CORN DISC 28 HOLES 11,5 MAG11.5R-002620	01	01
07	0513010123	SOCIDISCO CORN DISC 28 HOLES 12 VDA12R-002621	01	01
08	0513010124	SOCIDISCO CORN DISC 28 HOLES 12,5 AMP12.5R-002131	01	01
09	0513010125	SOCIDISCO CORN DISC 28 HOLES 13 VMV13R-002132	01	01
10	0513010126	SOCIDISCO CORN DISC 28 HOLES 13,5 RXR13.5R-002136	01	01
11	0513010187	SOCIDISCO CORN DISC 28 HOLES 14,8 X 10 VM4-002581	01	01
12	0513010188	SOCIDISCO CORN DISC 28 HOLES 11 X 8 BR8.1-002589	01	01
13	0513010189	SOCIDISCO CORN DISC 28 HOLES 12,5 X 8,5 AZ8.2-002587	01	01
14	0513010164	SOCIDISCO FLAT RING FOR CORN AMFOSLISO-002127	01	01
15	0513010159	SOCIDISCO RING FOR CORN 0,8MM LRFOSSR08-002120	01	01
16	0513010160	SOCIDISCO RING FOR CORN 1,4MM VMFOSR1.4-002245	01	01
17	0513010163	SOCIDISCO RING FOR CORN 2,0MM VDFOSR2-002116	01	01
18	0503063413	4Z CORN SEED DISTRIBUTOR CAP - 001798	01	01




Item	Code	Description	See page	QT
01	0513010136	SOCIDISCO SOY DISC 62 HOLES 7,5 LRA62.75-002357	01	01
02	0513010137	SOCIDISCO SOY DISC 62 HOLES 8,0 RSP62.80-002358	01	01
03	0513010138	SOCIDISCO SOY DISC 62 HOLES 8,5 RXR62.85-002359	01	01
04	0513010139	SOCIDISCO SOY DISC 62 HOLES 9,0 AZM62.90-002360	01	01
05	0513010141	SOCIDISCO SOY DISC 90 HOLES 8,0 RSP90.80-002287	01	01
06	0513010142	SOCIDISCO SOY DISC 90 HOLES 8,5 RXR90.85-002317	01	01
07	0513010143	SOCIDISCO SOY DISC 90 HOLES 9,0 AZM90.90-002288	01	01
08	0513010158	SOCIDISCO FLAT RING FOR SOY AZMSOJALISO-002243	01	01
09	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461	01	01
10	0513010162	SOCIDISCO RING FOR SOY 1,5MM RSPSOJASR1,5-002244	01	01
11	0503063412	4Z SOY/BEAN SEED DISTRIBUTOR CAP - 001804	01	01



Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	181	01
02	0501052538	DEPTH BAND WITH ARMS	186	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	187	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	188	01
07	0503033942	COMPACTOR WHEEL REGULATOR LID		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT DEPTH WHEEL ARM WITH HUB	182	01
07	0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	183	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	185	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" SPLIT PIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL HUB	184	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01

RIGHT DEPTH WHEEL ARM WITH HUB

0511058651




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL HUB	184	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	PROTECTION LID		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01

DEPTH WHEELS REGULATOR ASSY


0501052297




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" SPLIT PIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	189	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	189	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0581014858	DEPTH WHEEL AXLE		01
04	0501110720	ARM LEFT		01
05	0501110719	DEPTH CONTROL RIGHT ARM		01
06	0502012663	EXTENSION		01
07	0503010002	1800 GREASE FITTING		02
08	0501056769	DEPTH WHEELS REGULATOR ASSY	191	01
09	0503034793	ARTICULATION SLEEVE		02
10	0521051423	COMPACTOR SUPPORT	192	01
11	0571017749	FLAT WASHER		02
12	0503010311	1/2" X 1-1/4" BOLT		02
13	0503016453	1/2" X 2.1/2 BOLT		02
14	0503034817	SPRING		01
15	0503010581	RING		01
16	0503034377	3/8 UNC X 3/4 BOLT		01
17	0503010019	1/2" SPRING WASHER		08
18	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
19	0503010060	1/2 UNC G.5 ZN HEX NUT		04
20	0501052908	COMPACTOR WHEEL WITH BEARING	189	02
21	0503013739	1/2" X 1" BOLT		01
22	0511050077	WHEEL STRIPED	193	02
23	0503010752	1/2" X 3.1/2" BOLT		01



Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" SPLIT PIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521068003	RIGHT SIDE		01
02	0521068002	LEFT SIDE		01
03	0581014847	PLATE UPPER		01
04	0581015855	SLEEVE		02
05	0521068004	HANDLE BODY		01
06	0581014969	GUIDE SLEEVE		01
07	0581014968	SLEEVE FLANGE		01
08	0503010937	5/16" X 3" BOLT		02
09	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
10	0521068005	LEVER		01
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
12	0503010337	5/16" NUT		04
13	0503010019	1/2" SPRING WASHER		01
14	0503010060	1/2 UNC G.5 ZN HEX NUT		01
15	0503010847	1/2" X 3.1/4" BOLT		01
16	0503010882	BOLT		02
17	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
18	0503030878	LEVER CRANK		01
19	0581015854	RIGHT PROTECTION COVER		01
20	0581015853	LEFT PROTECTION COVER		01
21	0581015903	SPACER WASHER		01




Item	Code	Description	See page	QT
01	0511052287	DEPTH WHEEL HUB ASSY	194	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	5/16" NUT		06

DEPTH WHEEL HUB ASSY


0511052287




Item	Code	Description	See page	QT
01	0502011918	DEPHT WHEEL HUB		01
02	0503030757	2.9" X 2" X 0.02" JOINT		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503011098	1/4" GREASE FITTING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503010269	6204 BALL BEARING		02
09	0501013636	SPACING SLEEVE		01
10	0503010689	SEAL 00763-BR		01
11	0503011105	SEAL RING		01
12	0521063443	DEPTH CONTROL AXLE		01




Item	Code	Description	See page	QT
01	0511052971	SEMI-ASSEMBLED DEPTH CONTROL WITH THREAD	196	01
02	0511052970	SYSTEM COMPACTOR V SEMI MOUNTED	202	01
03	0501052908	COMPACTOR WHEEL WITH BEARING	189	02
04	0503010019	1/2" SPRING WASHER		06
05	0503010752	1/2" X 3.1/2" BOLT		01
06	0503013739	1/2" X 1" BOLT		01
07	0503010479	BOLT		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503030012	HITCH PIN CLIP		01
10	0571013222	FIXING CHOCK		01
11	0503010741	1/2" X 2-3/4" BOLT		02
12	0511055819	DEPTH BAND WITH RIM	203	02
13	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		08
14	0503013816	5/16" LOCKNUT		08




Item	Code	Description	See page	QT
01	0521063808	DEPTH CONTROL INNER COLUMN CONTROL WITH SCREW		01
02	0521063809	DEPTH CONTROL EXTERNAL COLUMN CONTROL WITH SCREW		01
03	0571013194	REGULATOR SPINDLE		01
04	0551010616	ROD HEX		01
05	0503010683	0,2" X 1,2" SPRING PIN		01
06	0571013202	COVERING WHEEL REGULATOR AXLE		01
07	0521063812	REGULATOR LEVER AXIS		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		01
09	0511065308	LOCK REGULATOR		01
10	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
11	0541011627	FLAT WASHER		01
12	0503010140	1/8" X 3/4" SPLIT PIN		01
13	0511059325	LEFT ARM COVERED WHEEL ASSEMBLED	197	01
14	0511059324	RIGHT ARM COVERED WHEEL ASSEMBLED	198	01
15	0571014709	SLEEVE LOCK CONTROL ARM		02
16	0503011440	SPRING WASHER		03
17	0503819099	BOLT		02
18	0511051546	RIGHT DEPTH CONTROL HUB	199	01
19	0511051547	LEFT DEPTH CONTROL HUB	200	01
20	0503011442	3/4" SPRING WASHER		02
21	0571013189	SLEEVE SUPPORT BEATER		01
22	0521063813	WHEEL PRESS BEATER		01
23	0501010937	13,50 X 28 X 3,00 FLAT WASHER		01
24	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01



Item	Code	Description	See page	QT
01	0502012844	LEFT ARM WHEELS		01
02	0581011340	ARM CASE		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	COVERING WHEEL ARM SUPPORT SLEEVE		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012843	RIGHT WHEEL ARM		01
02	0581011340	ARM CASE		01
03	0503011402	0.2" X 0.8" SPRING PIN		02
04	0503034383	COVERING WHEEL ARM SUPPORT SLEEVE		02
05	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	201	01
02	0511066638	RIGHT AXLE WITH DUST CLOAK		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	PROTECTION LID		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03

LEFT DEPTH CONTROL HUB


0511051547




Item	Code	Description	See page	QT
01	0511051583	SEMI-ASSEMBLED DEPTH WHEEL HUB	201	01
02	0511066637	LEFT AXLE WITH DUST CLOAK		01
03	0503010878	5/8" SELF ALIGNING NUT		01
04	0503030757	2.9" X 2" X 0.02" JOINT		01
05	0521019178	PROTECTION LID		01
06	0503014729	1/4" UNF X 1/2" BOLT		03
07	0503011441	SPRING WASHER		03




Item	Code	Description	See page	QT
01	0502011907	DEPTH CONTROL WHEEL HUB		01
02	0503010269	6204 BALL BEARING		02
03	0501013636	SPACING SLEEVE		01
04	0503010689	SEAL 00763-BR		01
05	0503011105	SEAL RING		01
06	0503010691	1/4" GREASE FITTING		01



Item	Code	Description	See page	QT
01	0502012850	PRESS WHEELS ARM		01
02	0503030883	RIGHT TORSION SPRING		01
03	0502011066	PRESS WHEELS ARM SUPPORT		01
04	0531017415	1" X 4.72" AXLE JOINT		01
05	0503010839	03"X 0.6" SPRING PIN		01
06	0521063841	REGULATOR RIGHT COMPACTOR		01
07	0521063842	REGULATOR LEFT COMPACTOR		01
08	0503811404	BOLT		02
09	0503011443	3/8" SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0571013295	ALXE REGULATOR COMPACTOR		01
12	0521063812	REGULATOR LEVER AXIS		01
13	0503011336	1/2" HEX SELF ADJUSTING NUT		02
14	0511065308	LOCK REGULATOR		01
15	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
16	0541011627	FLAT WASHER		01
17	0503010140	1/8" X 3/4" SPLIT PIN		01
18	0571013293	SLEEVE LOCK COMPACTOR V CONTROL WITH SCREW		01
19	0503811172	BOLT		01
20	0503010002	1800 GREASE FITTING		01
21	0581013744	PROTECTION CASE		01
22	0503813096	BOLT		01
23	0503013816	5/16" LOCKNUT		0




Item	Code	Description	See page	QT
01	0503034008	DEPTH CONTROL		01
02	0521010832	RIM FLANGE		02
03	0503013758	1/4" X 1-1/2" BOLT		05
04	0503013814	1/4" NC LOCKNUT		05




Item	Code	Description	See page	QT
01	0511053550	DEPTH CONTROL ASSY	205	01
02	0511050077	WHEEL STRIPED	193	02
03	0511054333	COMPACT WHEEL RIGHT WITH BEARING	187	01
04	0511054334	COMPACT WHEEL LEFT WITH BEARING	188	01
05	0503033942	COMPACTOR WHEEL REGULATOR LID		01

DEPTH CONTROL ASSY

0511053550




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521064073	REGULACION WHEEL COMPACTOR		01
03	0521019093	0.6" X 2.7" PIVOT SHAFT		01
04	0503010581	RING		01
05	0571013054	DEPTH CONTROL WHEEL AXLE		01
06	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
07	0511015346	FLAT WASHER		04
08	0501110720	ARM LEFT		01
08A	0502012726	LEFT DEPTH WHEEL ARM		01
08B	0503034375	WHEEL ARM SLEEVE		02
09	0501110719	DEPTH CONTROL RIGHT ARM		01
09A	0502012725	DEPTH WHEEL RIGHT ARM		01
09B	0503034375	WHEEL ARM SLEEVE		02
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
11	0503011440	SPRING WASHER		04
12	1902012116	PRESS WHEEL ADJUSTER		01
13	0503010849	3/8" X 1-1/2" BOLT		02
14	0503011443	3/8" SPRING WASHER		02
15	0503010026	3/8" NUT		02
16	0521010539	0.3" X 1.2" COUPLING SHAFT		01
17	0503010140	1/8" X 3/4" SPLIT PIN		01
18	0502012663	EXTENSION		01
19	0503010002	1800 GREASE FITTING		02
20	0503010060	1/2 UNC G.5 ZN HEX NUT		02
21	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
22	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
23	0541016906	PRESS WHEELS REGULATOR BODY		01
24	0501056769	DEPTH WHEELS REGULATOR ASSY	191	01
25	0503010311	1/2" X 1-1/4" BOLT		02
26	0503010256	3/8" X 3/4" BOLT		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
03	0521019093	0.6" X 2.7" PIVOT SHAFT		01
04	0503010581	RING		01
05	1902012116	PRESS WHEEL ADJUSTER		01
06	0501052297	DEPTH WHEELS REGULATOR ASSY	185	01
07	0501052908	COMPACTOR WHEEL WITH BEARING	189	02
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
09	0521014508	FLAT WASHER		10
10	0503011336	1/2" HEX SELF ADJUSTING NUT		02
11	0581011100	DEPTH WHEEL AXLE		01
12	0571017749	FLAT WASHER		02
13	0521056314	LEFT ARM WHEEL DEPTH WITH HUB CPERA	208	01
14	0521056313	RIGHT ARM WHEEL DEPTH WITH HUB CPERA	207	01
15	0503010358	5/16" X 5/8" BOLT		08
16	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
17	0503013816	5/16" LOCKNUT		08
18	0501011445	FLAT WASHER		02
19	0503010311	1/2" X 1-1/4" BOLT		02
20	0503010019	1/2" SPRING WASHER		02
21	0503010025	3/8 SPRING WASHER		02
22	0503010026	3/8" NUT		02
23	0503010849	3/8" X 1-1/2" BOLT		02
24	0503010256	3/8" X 3/4" BOLT		01
25	0511055819	DEPTH BAND WITH RIM	203	02
26	0503010691	1/4" GREASE FITTING		02
27	0503033942	COMPACTOR WHEEL REGULATOR LID		01
28	0521064073	REGULACION WHEEL COMPACTOR		01
29	0541016906	PRESS WHEELS REGULATOR BODY		01
30	0521010539	0.3" X 1.2" COUPLING SHAFT		01
31	0503010140	1/8" X 3/4" SPLIT PIN		01




Item	Code	Description	See page	QT
32	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01



Item	Code	Description	See page	QT
01	0501110833	DEPTH CONTROL RIGHT ARM		01
02	0521056316	DEPTH WHEEL HUB WITH COMPLETE ANGLE 209 ADJUSTING AXLE		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0521056316	DEPTH WHEEL HUB WITH COMPLETE ANGLE 209 ADJUSTING AXLE		01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501013636	SPACING SLEEVE		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010689	SEAL 00763-BR		01
04	0503011105	SEAL RING		01
05	0503010269	6204 BALL BEARING		02
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0521019178	PROTECTION LID		01
09	0503010143	1/4" SPRING WASHER		03
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0521060071	DEPTH CONTROL AXLE		01

SCARIFIER ROD WITH TIP


0501110231




Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER ROD		01
02	1902070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503030379	LARGER ROCKER ARM		01
02	0502060001	PLASTIC PULLEY FOR MAIZE		01
03	0503010669	FLAT WASHER		01
04	0503010667	3/16" NUT		02
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		01




Item	Code	Description	See page	QT
01	0511062081	RH SUPPORT		01
02	0511064765	SMALLER WHEEL PRESS FERTILIZER ARM		01
03	0503010571	1/4" X 1.1/2" SPLIT PIN		01
04	0503010002	1800 GREASE FITTING		01
05	0503010013	5/8 NUT		02
06	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
07	0502011757	PRESS REGULATOR		01
08	0503010849	3/8" X 1-1/2" BOLT		02
09	0503010025	3/8 SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0501013491	5/8" TENSIONER SPRING		01
12	0521010579	COUPLING SHAFT		01
13	0511054837	RH IRON PRESS WHEEL	214	01
14	0511054838	LH IRON PRESS WHEEL	215	01




Item	Code	Description	See page	QT
01	0511062082	LH SUPPORT		01
02	0511064765	SMALLER WHEEL PRESS FERTILIZER ARM		01
03	0503010571	1/4" X 1.1/2" SPLIT PIN		01
04	0503010002	1800 GREASE FITTING		01
05	0503010013	5/8 NUT		02
06	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
07	0502011757	PRESS REGULATOR		01
08	0503010849	3/8" X 1-1/2" BOLT		02
09	0503010025	3/8 SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0501013491	5/8" TENSIONER SPRING		01
12	0521010579	COUPLING SHAFT		01
13	0511054837	RH IRON PRESS WHEEL	214	01
14	0511054838	LH IRON PRESS WHEEL	215	01




Item	Code	Description	See page	QT
01	0501052957	IRON V PRESS WHEELS	216	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		05
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052957	IRON V PRESS WHEELS	216	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		05
04	0503016864	LH 1/2" LOCK NUT		01



Item	Code	Description	See page	QT
01	0502011932	IRON PRESS WHEELS		01
02	0503010269	6204 BALL BEARING		02
03	0503011105	SEAL RING		01
04	0503013848	5072-BR SEAL		02
05	0521019147	V COMPACT WHEELS AXLE		02
06	0511011927	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501056288	RIGHT IRON COVERING WHEEL	219	01
02	0502012347	LEFT WHEEL ARM SUPPORT		01
03	0531016207	0.6" X 1" X 2.8" SLEEVE		01
04	0501010163	5/8" X 4-1/2" BOLT		01
05	0503010027	5/8 SPRING WASHER		01
06	0503010013	5/8 NUT		01
07	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501056289	LEFT IRON COVERING WHEEL	220	01
02	0502012347	LEFT WHEEL ARM SUPPORT		01
03	0531016207	0.6" X 1" X 2.8" SLEEVE		01
04	0501010163	5/8" X 4-1/2" BOLT		01
05	0503010027	5/8 SPRING WASHER		01
06	0503010013	5/8 NUT		01
07	0503010003	1845 GREASE FITTING		01

RIGHT IRON COVERING WHEEL


0501056288



Item	Code	Description	See page	QT
01	0503011440	SPRING WASHER		02
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
03	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
04	0501053186	RIGHT IRON PRESS WHEEL ASSY	221	01
05	0502012348	RIGHT WHEEL ARM		01
06	0502011155	RIGHT FIXER WHEEL		01




Item	Code	Description	See page	QT
01	0503011440	SPRING WASHER		02
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
03	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
04	0501053186	RIGHT IRON PRESS WHEEL ASSY	221	01
05	0502012349	LEFT WHEEL ARM STEEL		01
06	0502011156	LEFT FIXER WHEEL		01




Item	Code	Description	See page	QT
01	0502011970	IRON PRESS WHEEL		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT SHAFT DOUBLE DISC HUB		01
05	0511015098	FLAT WASHER		01
06	0503030282	3/4" CASTLE NUT		01
07	0503010257	1/8" X 1" SPLIT PIN		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503013758	1/4" X 1-1/2" BOLT		03
12	0511016896	DUST CLOAK		01

ROD WITH ARM/DISARMMENT


0521053955



Item	Code	Description	See page	QT
01	0521053937	SCARIFIER SPINDLE WITH POINT	223	01
02	0503012795	5/8" HEX SELF ADJUSTING NUT		01
03	0503010417	7/8" NUT		01
04	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
05	0503034106	80 X 230 X 16,50 COMPRESSSION SPRING		01
06	0503010691	1/4" GREASE FITTING		01
07	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
08	0503011336	1/2" HEX SELF ADJUSTING NUT		04
09	0521067063	SPRING HUB		01
10	0581012084	ARTICULATED SLEEVE		01
11	0581012082	SCREW		01
12	0581012081	ARTICULATED SLEEVE		01
13	0571019462	SUPPORT GUIDE PRING		01
14	0581012094	SUPPORT WASHER		01
15	0571018541	BODY SOCKET FERTILIZER		01
16	0503010026	3/8" NUT		02
17	0503010025	3/8 SPRING WASHER		02
18	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
20	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
21	0503010384	1/2" X 5" BOLT		02
22	0503010547	1/2" X 4" BOLT		02




Item	Code	Description	See page	QT
01	0521053959	ROD WITH AUTOMATIC DISARM TIP	224	01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521067065	FLANGE WASHER SPRING		01
04	0521015818	FLAT WASHER		02
05	0581012092	AXLE FIXER		01




Item	Code	Description	See page	QT
01	0521067066	ROD WITHOUT NOZZLE AUTOMATIC DISARM		01
02	0502040901	FIXED ROD NOZZLE		01
03	0503016853	SPRING PIN		02
04	0503011402	0.2" X 0.8" SPRING PIN		02

SCARIFIER ROD


0501110723



Item	Code	Description	See page	QT
01	0521063867	SCARIFIER ROD		01
02	0502070082	POINT SUBSOILER		01
03	0503010585	0,24" X 1.18" SPRING PIN		03



Item	Code	Description	See page	QT
01	0581013298	SUPPORT		01
02	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		01
03	0521018517	FLAT WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010019	1/2" SPRING WASHER		01
06	0503030483	FERTILIZER SOCKET		01
07	0503031050	CURVED CONDUCTOR		01
08	0503010246	CLAMP		01



MARCHESAN

Technical Publications | Elaboration and Revision

LEONARDO JOSÉ DA SILVA SOUZA

www.marchesan.com.br

