

ROW CROP PLANTERS

**PST PLUS FLEX - FRAME 3495/5345 - CSU - PEANUT
PST PLUS FLEX - CHASSI 3495/5345 - CSU -
AMENDOIM**

Code: 0501093673
Series: S-0116
Revision: 00
Revision Date: NOVEMBER/2023

PARTS CATALOGUE



MARCHESAN



PRODUCTS

Code	Working Width	Description
0111380545		PST PLUS FLEX 3495/4E900 SPICRR CI DTR MH DOC22 CSU 390 SIG V3 ALP II CBRF U MP36
0111380539		PST PLUS FLEX 3495/4E900 SPICRR CI DTR MH DOC22 CSU 540 SIG V3 ALP II CBRF U TMC
0111380530		PST PLUS FLEX 5345/6E900 SPICRR CI DTR MH DC22 CSU 540 SIG V3 ALP II CBRF U TMC

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909091279	FRAME ASSY - 3495/5345	1
0541050747	CARRYING-WHEEL AXIS FRAME - 3495	2
0541051537	FRAME CARRYING-WHEEL AXIS - 5345	3
0511058655	CYLINDER ASSY - 3245/3495/4045/4395	4
0521045510	HYDRAULIC CYLINDER	5
0541051827	CYLINDER ASSY - 5345	6
0521054233	50,8 X 101,6 X 240,5 X 507,5 HYDRAULIC CYLINDER	7
0541050782	WHEELS WITH TRACTION SPRING	8
0501058240	WHEEL FASTENER WITH TENSIONER	9
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	10
0501058244	WHEEL FIXED CHAIN TENSIONER	11
0501058242	WHEEL MOBILE CHAIN TENSIONER	12
0501058239	WHEEL CHAIN TENSIONER BEARING	13
0541050784	RIGHT CARRYING-WHEEL	14
0501058241	WHEEL SUPPORT CHAIN TENSIONER	15
0541050785	WHEEL WITH TRANSMISSION TIRE	16
0531055341	RIGHT WHEEL MOUNTED	17
0541050789	WHEEL HUB ASSY	18
0541052686	TRANSMISSION ASSY - 3495	19
0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	20
0541050079	SEED ROW UPPER TRANSMISSION GEAR BOX	21
0541051478	TRANSMISSION ASSY - 5345	22
0501052560	MOTOR AXLE SIGNAL	23
0511051434	TRANSMISSION ACTUATOR	24
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	25
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	26
0511057265	TRANSMISSION CHAIN TENSIONER	27
0541051476	BEARING WITH DOUBLE GEAR	28
0511057867	3.15" CHAIN STRETCHER ASSY	29
0541051477	BEARING WITH 3/4 HEX AXLE GEAR	30
0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	31
0511059969	CHAIN TENSIONER	32
0521055338	ROW SEED BEARING	33
0541050799	LEFT GEAR SET	34
0541050800	RIGHT REPLACEMENT SET	35
0541050801	LEFT TRANSMISSION WITHOUT TRANSMISSION	36
0541050802	DIRECT RETURN WITHOUT TRANSMISSION	37
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	38
0501056271	GEARBOX CLOSED BEARING	39
0501048790	AXLE WITH RING	40
0501056443	GEAR HOUSING BEARING	41
0501056444	ROLLER BEARING	42
0511057258	TENSIONER WITH GEAR	43
0511054363	CHAIN TENSIONER	44
0541050096	MECHANICAL TRANSMISSION BOX	45
0503064041	CARDAN T.S 16,00 X Q 15,90 X Q 22 X 697	46
0541050875	SIDE BEARING SET	47
0541050873	SIDE BEARING SET	48
0531057910	SIDE BEARING WITH BEARING 6007	49
0541050793	FERTILIZER HOPPER ASSY - 3495	50
0541050794	CENTRAL FERTILIZER HOPPER SUPPORT	51
0541051552	FERTILIZER HOPPER ASSY - 5345	52
0541051550	RIGHT FERTILIZER BOX SUPPORT	53
0541051551	LEFT FERTILIZER BOX SUPPORT	54
0541050452	ALPHA II FERTILIZER METERING LOWER FLANGE	55



MARCHESAN

INDEX


0531055863	TRANSMISSION HUB ASSY	56
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	57
0531059139	COLLECTOR ASSY	58
0531055273	ALPHA FERTILIZER METERING CLAMP	59
0531057911	22Z GEAR SIDE BEARING ASSEMBLY	60
0531057901	GEAR	61
0501053788	3/4" SQUARE AXLE FASTENER	62
0541050877	SIDE BEARING SET	63
0531057978	SIDE BEARING WITH TRANSMISSION	64
0511057266	HYDRAULIC SYSTEM ASSEMBLY - 3245/3495/4045/4395	65
0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	66
0501053834	MALE QUICK COUPLER	67
0541050808	HYDRAULIC MARKER SEMI-ASSEMBLED - 3495	68
0541051568	HYDRAULIC MARKER SEMI-ASSEMBLED - 5345	69
0511058449	HYDRAULIC CYLINDER	70
0501054649	HBM SEQUENTIAL VALVE	71
0511058119	VALVE SUPPORT ASSEMBLY	72
0511057370	PLATFORM ASSEMBLY - 3495	73
0511057385	PLATFORM ASSEMBLY - 5345	74
0511056536	LADDER ASSEMBLY	75
0511054971	JACK ASSEMBLY	76
0541052898	REST ASSY	77
0541050752	DRAWBAR ASSEMBLY INVERTED SUPPORT	78
0531057453	DECAL SET - 3495	79
0531057457	ALPHA DECAL SET - 5345	80
0541052783	SET LABELS	81
0511059322	LIFTING SUPPORT ASSEMBLY	82
0541050745	HANDRAIL ASSY - 3495	83
0541051539	HANDRAIL ASSY - 5345	84
0511059323	SUPPORT PLATFORM TRANSPORT	85
0541050796	CSU SET - 3495	86
0531052127	CONDUCTOR HOPPER SUPPORT	87
0531053039	SEED DEFLECTOR 517 MOUNTED PEANUTS	88
0541051542	CSU SET - 5345	89
0531050237	3" RIGHT SEED CONDUCTOR FIXER	90
0541051541	CSU SUPPORT WITH BAFFLE	91
0541051540	SEED DEFLECTOR 694	92
0531053043	SEED CONDUCTOR 3 FULL ARTICULATED	93
0501050633	ROW MARKER DISC ASSEMBLY	94
0511053904	ROW MARKER DISC	95
0511057270	DRAWBAR EXTENDER	96
0511054601	HITCH ARTICULATED TRACTOR	97
0541051835	MANUAL CANISTER ASSY	98
0511056736	HOSE SUPPORT	99
0531059614	ALPHA COMPONENTS KIT - 04 ROWS	100
0531059616	ALPHA COMPONENTS KIT - 06 ROWS	101
0541050447	PLANTING MONITORING ASSY	102
0909090096	SEED/FERTILIZER ROW ASSY	103
0521058524	SEED ROW FRONT	104
0541051739	RIGHT REAR	105
0541051705	LEFT SYSTEM FIXATION BASE	106
0541050098	UNILATERAL GEARBOX	107
0541051744	RIGHT REAR MECHANICAL	108
0521056632	DEPTH CONTROL	109
0521055093	BODY COMPACTOR	110



MARCHESAN


INDEX

0521054990	LEFT COMPACTOR WHEEL	111
0521055017	RIGHT COMPACTOR WHEEL	112
0531050538	MOUNTED LEFT ARM	113
0531050539	MOUNTED LEFT ARM	114
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	115
0521055056	SPOKED WHEEL ASSY	116
0521055073	ASSEMBLY DEPTH WHEEL HUB	117
0541051742	DOUBLE DISC RIGHT	118
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	119
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	120
0521055865	FERTILIZER/SEED LEFT HUB ASSY	121
0521055864	FERTILIZER/SEED RIGHT HUB ASSY	122
0541051730	MECHANICAL SEED HOPPER	123
0541050399	SEED HOPPER WITH COUPLING	124
0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	125
0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK LID	126
0541051731	PEANUT DISTRIBUTOR	127
0541050737	SHORT FERTILIZER ROW 20" DISC BLADE	128
0541050740	22" DISC BLADE ASSY	129
0541050741	22" DISC HUB	130
0521057680	DISC CUTTING BOX	131
0541050742	SUPPORT SPRING GUIDE	132
0541052224	SHORT FERTILIZER ROW 20" WAVY COULTER DISC BLADE	133
0541052225	22" WAVY COULTER DISC BLADE ASSY	134
0541052226	22" WAVY COULTER DISC HUB	135
0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	136
0521055868	RIGHT DUAL FERTILIZER DISC	137
0531052159	LEFT IRON COVERING WHEEL	138
0531052160	RIGHT IRON COVERING WHEEL	139
0501056288	RIGHT IRON COVERING WHEEL	140
0501053186	RIGHT IRON PRESS WHEEL ASSY	141
0501056289	LEFT IRON COVERING WHEEL	142
0501110804	SCARIFIER ROD WITH POINT	143
0521053946	SCARING ROD	144
0541051703	QUICK LOCK SET SIGMA V3	145




Item	Code	Description	See page	3495	5345
01	0541050747	CARRYING-WHEEL AXIS FRAME - 3495	2	01	00
01.	0541051537	FRAME CARRYING-WHEEL AXIS - 5345	3	00	01
02	0503010003	1845 GREASE FITTING		04	06
03	0511058655	CYLINDER ASSY - 3245/3495/4045/4395	4	01	00
03.	0541051827	CYLINDER ASSY - 5345	6	00	01
04	0541050782	WHEELS WITH TRACTION SPRING	8	02	04
05	0541052686	TRANSMISSION ASSY - 3495	19	01	00
05.	0541051478	TRANSMISSION ASSY - 5345	22	00	01
06	0541050793	FERTILIZER HOPPER ASSY - 3495	50	01	00
06.	0541051552	FERTILIZER HOPPER ASSY - 5345	52	00	01
07	0511057266	HYDRAULIC SYSTEM ASSEMBLY - 3245/3495/4045/4395	65	01	00
07.	0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	66	00	01
08	0541050808	HYDRAULIC MARKER SEMI-ASSEMBLED - 3495	68	01	00
08.	0541051568	HYDRAULIC MARKER SEMI-ASSEMBLED - 5345	69	00	01
09	0511057370	PLATFORM ASSEMBLY - 3495	73	01	00
09.	0511057385	PLATFORM ASSEMBLY - 5345	74	00	01
10	0511056536	LADDER ASSEMBLY	75	02	02
11	0511054971	JACK ASSEMBLY	76	02	02
11.	0541052898	REST ASSY	77	00	01
12	0541050752	DRAWBAR ASSEMBLY INVERTED SUPPORT	78	01	01
13	0531057453	DECAL SET - 3495	79	01	00
13.	0531057457	ALPHA DECAL SET - 5345	80	00	01
14	0511059322	LIFTING SUPPORT ASSEMBLY	82	02	02
15	0541050745	HANDRAIL ASSY - 3495	83	01	00
15.	0541051539	HANDRAIL ASSY - 5345	84	00	01
16	0511059323	SUPPORT PLATFORM TRANSPORT	85	04	04
17	0541050796	CSU SET - 3495	86	01	00
17.	0541051542	CSU SET - 5345	89	00	01
18	0501050633	ROW MARKER DISC ASSEMBLY	94	02	02


Item	Code	Description	See page	3495	5345
19	0501065677	STRUT		02	02
20	0511057270	DRAWBAR EXTENDER	96	01	01
21	0511054601	HITCH ARTICULATED TRACTOR	97	01	01
22	0503014120	CHAIN		01	01
23	0503014321	CABLE STEEL SHACKLE		02	02
24	0541051835	MANUAL CANISTER ASSY	98	01	01
25	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01
26	0511053179	TRACTOR COUPLING SHAFT		01	01
27	0521013022	TRANSPORT LOCK		02	02
28	0501068994	8,30 X 78 LOCK PIN		02	02
29	0503030168	HITCH PIN CLIP		02	02
30	0511056736	HOSE SUPPORT	99	01	01
31	0501047895	25 ROD STOP		01	02
32	0501047885	30 ROD STOP		01	02
33	0501047886	35 ROD STOP		01	02
34	0501047887	40 ROD STOP		01	02
35	0531059614	ALPHA COMPONENTS KIT - 04 ROWS	100	01	00
35.	0531059616	ALPHA COMPONENTS KIT - 06 ROWS	101	00	01
36	0503010780	N-2050 AMENDMENT		02	02
37	0503010951	REDUCTION		04	04
38	0503011750	AMENDMENT WITH LOCK		06	06
39	0503011751	REDUCTION		06	06
40	0571017368	SUPPORT GUTTER		00	04
41	0571018391	GUTTER 25 X 58 X 1200		00	02
42	0501011643	3/8 X 1" BOLT		00	04
43	0501010984	10,50 X 27 X 3,00 FLAT WASHER		00	04
44	0503010025	3/8 SPRING WASHER		00	04
45	0503010026	3/8" NUT		00	04
46	0511034818	BAG WITH MANUAL		01	01
47	0541050447	PLANTING MONITORING ASSY	102	00	01
48		SEED/FERTILIZER ROW ASSY	103		




Item	Code	Description	See page	QT
01	0521013199	LOWER BEARING SEMI		04
02	0503010899	5/8 UNC X 2.1/4 BOLT		08
03	0531013922	0.6" X 0.8" X 1" SLEEVE		08
04	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		16
05	0503011445	SPRING WASHER		08
06	0503010013	5/8" UNC G.5 ZN HEX NUT		08
07	0531066473	CARRYING-WHEEL ARTICULATION SHAFT		01
08	0521065918	FRAME - 3495		01




Item	Code	Description	See page	QT
01	0521013199	LOWER BEARING SEMI		04
02	0503010899	5/8 UNC X 2.1/4 BOLT		08
03	0531013922	0.6" X 0.8" X 1" SLEEVE		08
04	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		16
05	0503011445	SPRING WASHER		08
06	0503010013	5/8" UNC G.5 ZN HEX NUT		08
07	0531066892	CARRYING-WHEEL ARTICULATION AXLE		01
08	0531066893	FRAME 5345		01




Item	Code	Description	See page	QT
01	0521045510	HYDRAULIC CYLINDER	5	01
02	0551014099	COUPLING SHAFT 31,75 X 185		01
03	0521010547	1.2" X 6.5" COUPLING SHAFT		01
04	0503010523	1/4" X 2" SPLIT PIN		02
05	0501047888	45 ROD STOP		01




Item	Code	Description	See page	QT
01	0521065976	127 X 438,5 TUBE		01
02	0581013698	PISTON 2" X 5" C/R. M36 X 1,5		01
03	0521067585	EXTENDER 50.80 X 371.5 WITH BUSHING		01
04	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
05	0503010003	1845 GREASE FITTING		01
06	0503030385	CYLINDER PLUG N-002		02
07	0503018439	WIPER SEAL T-SEAL 1905127		01
08	0503018150	RING GUIDE W2-5000-984 (4528)		01
09	0502010382	5" END CAP		01
10	0581010353	RING SUPPORT		01
11	0503018026	GASKET 1870-2000-375 B POLYMAX		01
12	0503011453	O'RING		02
13	0503018152	O'RING		02
14	0503018024	RING BS OD050805200171D-BR		01
15	0503018025	RING GUIDE W2-2250-750		01
16	0503010039	D-2000 SCRAPER RING		01
17	0503010173	2-220 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0521054233	50,8 X 101,6 X 240,5 X 507,5 HYDRAULIC CYLINDER	7	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0501218778	31,75 X 200 JOINT SHAFT		02
04	0503010523	1/4" X 2" SPLIT PIN		04
05	0501047888	45 ROD STOP		02
06	0571019384	SPACING SLEEVE 16,30 X 30 X 104		02
07	0501013867	BOLT 5/8" UNC X 6 CS G.5 ZN		02
08	0503010027	5/8 SPRING WASHER		02
09	0503010013	5/8" UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0521069306	50.8 X 337.5 EXTENSION WITH 32.5 BUSHING		01
02	0521069305	101,6 X 438,5 TUBE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0503010004	1890 GREASE FITTING		01
05	0502012821	2" X 4" RING SUPPORT		01
06	0503011061	8-342 BACK-UP RING		02
07	0503018024	RING BS OD050805200171D-BR		01
08	0503010338	2-342 N 3006-9B O'RING		02
09	0503018026	GASKET 1870-2000-375 B POLYMAX		01
10	0503018025	RING GUIDE W2-2250-750		01
11	0503010039	D-2000 SCRAPER RING		01
12	0502012822	END CAP 4"		01
13	0502012842	50,80 X 101,60 PISTON		01
14	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
15	0503018029	O'RING 2-217 N 3006 90B		01
16	0503015633	SELEMASTER SEALING		01
17	0511034644	50,8 X 101,6 HYDRAULIC CYLINDER SPARE SET		01




Item	Code	Description	See page	QT
01	0501058240	WHEEL FASTENER WITH TENSIONER	9	01
02	0503011119	7/8" X 6" BOLT		06
03	0501014251	FLAT WASHER		08
04	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
05	0503011254	7/8" HEX SELF ADJUSTING NUT		06
06	0541050784	RIGHT CARRYING-WHEEL	14	01
07	0503013257	2050 CHAIN X 89 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" UNC G.5 ZN HEX NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	10	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	11	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	12	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	13	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	13	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	13	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0503010003	1845 GREASE FITTING		01
02	0511050681	TRACTION SPRING		02
02A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
02B	0561016062	SPRING HITCH		02
03	0501010100	BOLT 5/8" UNC X 2 CS G.5 ZN		02
04	0503010027	5/8 SPRING WASHER		06
05	0503013030	5/8" X 3.1/4" BOLT		02
06	0551017715	FLAT WASHER		04
07	0501058241	WHEEL SUPPORT CHAIN TENSIONER	15	01
08	0503018981	BOLT		02
09	0591010589	BODY LOCK WHEEL		01
10	0501010630	1.1/2" CASTLE NUT		01
11	0551012215	FLAT WASHER		01
12	0503010571	1/4" X 1.1/2" SPLIT PIN		01
13	0531062643	PEANUT WHEEL COVER		01
14	0541050785	WHEEL WITH TRANSMISSION TIRE	16	01
15	0531066511	LOWER CARRYING-WHEEL		01
16	0531066507	WHEEL SUPPORT		01
17	0531066509	ARTICULATION AXLE		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0531055341	RIGHT WHEEL MOUNTED	17	01
02	0541050789	WHEEL HUB ASSY	18	01



Item	Code	Description	See page	QT
01	0503035800	RIM 16 X 17 - 154 X 203 MM 08 HOLES 0017-2017		01
02	0513010700	TIRE 500-50-17 FLOTATION T422 I1 18PR TECH SHEET		01




Item	Code	Description	See page	QT
01	0501110751	HUB AND SPINDLE WITH BOLT		01
01A	0502040522	HUB CARRYING-WHEELS		01
01B	0503011339	M22 X 1,5 X 72 BOLT		08
01C	0503011340	SPHERICAL SPRING WASHER		08
01D	0503011341	M22 X 0.6" NUT GR8		08
02	0503010059	33287/33462 ROLLER BEARING		01
03	0503010007	3982/3920 ROLLER BEARING		01
04	0503010050	SEAL 00085-B		01
05	0503012702	KM-12 NUT		02
06	0503012703	LOCK WASHER		01
07	0503011444	SPRING WASHER 5/16"		12
08	0501010694	FLAT WASHER 32,50 X 75 X 4,75		06
09	0503010002	1800 GREASE FITTING		01
10	1882970002	GREASE		01
11	0501313140	WHEEL AXLE		01
12	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
13	0531066504	WHEEL BOX EXTENSIONER		01
14	0502011339	15Z GEAR P 1.25"		01
15	0503013124	5/16" X 5/8" UNC ALLEN BOLT		06




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		02
02	0501110639	BEARING		06
03	0503011099	GREASE FITTING		02
04	0503010003	1845 GREASE FITTING		04
05	0503010300	5/32" X 1" SPLIT PIN		06
06	0511015961	LOCK BUSHING		04
07	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		06
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		11
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0571018905	AXLE MOTOR 1675		02
13	0501052560	MOTOR AXLE SIGNAL	23	02
14	0511051434	TRANSMISSION ACTUATOR	24	02
15	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	25	01
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	26	01
17	0511057265	TRANSMISSION CHAIN TENSIONER	27	02
18	0521010773	0.37" X 1.18" COUPLING SHAFT		02
19	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
20	0503010140	1/8" X 3/4" SPLIT PIN		02
21	0571018846	DISASSEMBLE LEVER		02
22	0503033942	COMPACTOR WHEEL REGULATOR LID		02
23	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
24	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
25	0503030093	TRACTION SPRING		02
26	0541051476	BEARING WITH DOUBLE GEAR	28	02
27	0501314632	DOUBLE GEAR FIXING GUIDE		02
28	0511057867	3.15" CHAIN STRETCHER ASSY	29	04
29	0541051477	BEARING WITH 3/4 HEX AXLE GEAR	30	02
30	0511059969	CHAIN TENSIONER	32	02


Item	Code	Description	See page	QT
31	0503010834	1/2 X 1 BOLT		04
32	0503014911	40-1 X 63 CHAIN LINK + MENDING		02
33	0503017397	CHAIN 40-1 X 60 ELOS + RED		02
34	0503012477	40-1 X 129 CHAIN LINK + MENDING		02
35	0531062318	LEFT/RIGHT LOWER LEVER		02
36	0551019159	LEVER FIXER BODY		02
37	0561016468	FASTENER		02
38	0503011336	1/2" HEX SELF ADJUSTING NUT		04
39	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
40	0503010140	1/8" X 3/4" SPLIT PIN		04
41	0511054314	TRANSMISSION AXLE LOCK SLEEVE		05
41A	0502012699	TRANSMISSION HUB LOCK SLEEVE		01
41B	0503010256	3/8" X 3/4" BOLT		01
42	0521055338	ROW SEED BEARING	33	02
43	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	20	02
44	0541050799	LEFT GEAR SET	34	01
45	0541050800	RIGHT REPLACEMENT SET	35	01
46	0541050096	MECHANICAL TRANSMISSION BOX	45	04
47	0501313180	CARDAN BEARING SUPPORT		02
48	0541050079	SEED ROW UPPER TRANSMISSION GEAR BOX	21	04
49	0503064041	CARDAN T.S 16,00 X Q 15,90 X Q 22 X 697	46	04
50	0571018911	3/4 X 1690 AXLE HEX		02
51	0541050875	SIDE BEARING SET	47	02
52	0541050873	SIDE BEARING SET	48	02



Item	Code	Description	See page	QT
01	0541011713	TENSIONER CHAIN LOWER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6 X 1 X 16 C S 8.8 ZN BOLT		05
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0503011105	SEAL RING		01
11	0503011409	6005 Z BALL BEARING		01
12	0503017008	SEAL RING		01
13	0503017007	SEAL RING		02
14	0511017907	1/8" BSPT X 6 PLUG		01
15	0503010003	1845 GREASE FITTING		01
16	0503035316	LUBRICATED POINTS DECAL		01
17	0501311461	CONIC GEAR 14 TEETH		01
18	0531066150	WELDED DRIVE AXLE		01
19	0501311524	FIXER BOX TRANSMISSION		01
20	0503011953	5/16" X 1" BOLT		02
21	0503013759	NUT		02
22	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
23	0503015110	M06 SPRING WASHER		02




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		04
04	0503010003	1845 GREASE FITTING		04
05	0503010300	5/32" X 1" SPLIT PIN		08
06	0511015961	LOCK BUSHING		08
07	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		08
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		11
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		20
10	0503010019	1/2" SPRING WASHER		26
11	0503010060	1/2 UNC G.5 ZN HEX NUT		30
12	0571018909	MOTOR SHAFT 2600		02
13	0501052560	MOTOR AXLE SIGNAL	23	02
14	0511051434	TRANSMISSION ACTUATOR	24	04
15	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	25	01
16	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	26	01
17	0511057265	TRANSMISSION CHAIN TENSIONER	27	02
18	0521010773	0.37" X 1.18" COUPLING SHAFT		02
19	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
20	0503010140	1/8" X 3/4" SPLIT PIN		02
21	0571018846	DISASSEMBLE LEVER		02
22	0503033942	COMPACTOR WHEEL REGULATOR LID		02
23	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
24	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
25	0503030093	TRACTION SPRING		02
26	0541051476	BEARING WITH DOUBLE GEAR	28	02
27	0501314632	DOUBLE GEAR FIXING GUIDE		02
28	0511057867	3.15" CHAIN STRETCHER ASSY	29	04
29	0541051477	BEARING WITH 3/4 HEX AXLE GEAR	30	02
30	0511059969	CHAIN TENSIONER	32	04

Item	Code	Description	See page	QT
31	0503010834	1/2 X 1 BOLT		04
32	0503014911	40-1 X 63 CHAIN LINK + MENDING		02
33	0503017397	CHAIN 40-1 X 60 ELOS + RED		02
34	0503012477	40-1 X 129 CHAIN LINK + MENDING		02
35	0531062318	LEFT/RIGHT LOWER LEVER		02
36	0551019159	LEVER FIXER BODY		02
37	0561016468	FASTENER		02
38	0503011336	1/2" HEX SELF ADJUSTING NUT		04
39	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
40	0503010140	1/8" X 3/4" SPLIT PIN		04
41	0511054314	TRANSMISSION AXLE LOCK SLEEVE		05
41A	0502012699	TRANSMISSION HUB LOCK SLEEVE		01
41B	0503010256	3/8" X 3/4" BOLT		01
42	0521055338	ROW SEED BEARING	33	02
43	0503011953	5/16" X 1" BOLT		01
44	0541050799	LEFT GEAR SET	34	01
45	0541050800	RIGHT REPLACEMENT SET	35	01
46	0541050096	MECHANICAL TRANSMISSION BOX	45	06
47	0501313180	CARDAN BEARING SUPPORT		03
48	0541050079	SEED ROW UPPER TRANSMISSION GEAR BOX	21	06
49	0503064041	CARDAN T.S 16,00 X Q 15,90 X Q 22 X 697	46	06
50	0561016764	3/4 X 2645 HEX AXLE		02
51	0541050875	SIDE BEARING SET	47	02
52	0541050873	SIDE BEARING SET	48	02




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	NUT 5/16 UNC G.5 ZN		02
05	0503031584	ORANGE SIGNAL ARROW DECAL		01
06	0503031585	SILVER SIGNAL ARROW DECAL		01



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CS PC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02

RIGHT SIDE TRANSMISSION ACTUATOR


0511047069




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
05	0501019734	FLAT WASHER		02
06	0502010710	RIGHT CAM, SMALLER		02
07	0503010003	1845 GREASE FITTING		02
08	0502012539	26Z P12,7 GEAR		01
09	0501019735	FLAT WASHER		01
10	0521017593	FLAT WASHER		01
11	0503010542	501045 CLAMPING RING (FOR AXLE)		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01

LEFT SIDE TRANSMISSION ACTUATOR


0511047070




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 C50P G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503011410	ROLLER BEARING		02
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0503012412	5/8" UNC SELF LOCKING NUT		01
04	0531066879	DOUBLE GEAR BODY		01
05	0501314634	DOUBLE GEAR SHAFT		01
06	0503015017	5/8" X BOLT		01




Item	Code	Description	See page	QT
01	0503011410	ROLLER BEARING		01
02	0511062169	21Z P 1/2" GEAR		01
03	0503011105	SEAL RING		01
04	0551010511	80MM STRETCH SHAFT		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0571010265	16.5 X 40 X 3 FLAT WASHER		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01
08	0503010796	5/8" X 4-1/4" BOLT		01




Item	Code	Description	See page	QT
01	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	31	01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		02
03	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	NUT 5/16 UNC G.5 ZN		02
06	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
07	0501013518	FLAT WASHER		02
08	0531066880	GEAR 20Z WITH SHAFT		01



Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		02
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0581012970	TIGHTENER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING		01
03A	0502012030	HOUSING BEARING		01
03B	0503012861	6006 2RS BALL BEARING		01
03C	0503012858	502075 CLAMPING RING (FOR HOLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	NUT 5/16 UNC G.5 ZN		02
07	0501013518	FLAT WASHER		02
08	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02

LEFT GEAR SET

0541050799




Item	Code	Description	See page	QT
01	0521065956	LEFT GEARBOX LID		01
02	0503010240	BOLT		02
03	0503013816	5/16" LOCKNUT		02
04	0503033682	KNOB 3P K3 60A M12 X 40		01
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
06	0503010019	1/2" SPRING WASHER		01
07	0501010694	FLAT WASHER 32,50 X 75 X 4,75		06
08	0541050801	LEFT TRANSMISSION WITHOUT TRANSMISSION	36	01



Item	Code	Description	See page	QT
01	0521065955	RIGHT GEARBOX LID		01
02	0503010240	BOLT		02
03	0503013816	5/16" LOCKNUT		02
04	0503033682	KNOB 3P K3 60A M12 X 40		01
05	0503010019	1/2" SPRING WASHER		01
06	0501010694	FLAT WASHER 32,50 X 75 X 4,75		06
07	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
08	0541050802	DIRECT RETURN WITHOUT TRANSMISSION	37	01


LEFT TRANSMISSION WITHOUT TRANSMISSION

0541050801




Item	Code	Description	See page	QT
01	0521065940	LEFT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN SHAFT		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	38	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503013252	40-1 X CHAIN X 87 LINK + MENDING		01
11	0501056271	GEARBOX CLOSED BEARING	39	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER 32,50 X 75 X 4,75		06
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
15	0503010337	NUT 5/16 UNC G.5 ZN		06
16	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
17	0502011758	REAR TIGHTENER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	40	02
20	0503031367	SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0501313214	INTERMEDIATE AXLE		01
25	0511064536	28Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0501313213	DRIVE SHAFT		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	41	01

Item	Code	Description	See page	QT
31	0503010292	701164 6 X 40 SPRING PIN		08
32	0511057258	TENSIONER WITH GEAR	43	01
33	0511054363	CHAIN TENSIONER	44	01
34	0501313212	DRIVEN AXIS		01




Item	Code	Description	See page	QT
01	0521065939	RIGHT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN SHAFT		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	38	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503013252	40-1 X CHAIN X 87 LINK + MENDING		01
11	0501056271	GEARBOX CLOSED BEARING	39	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER 32,50 X 75 X 4,75		06
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
15	0503010337	NUT 5/16 UNC G.5 ZN		06
16	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
17	0502011758	REAR TIGHTENER LEVER		02
18	0503010004	1890 GREASE FITTING		02
19	0501048790	AXLE WITH RING	40	02
20	0503031366	RIGHT TWISTED SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0501313214	INTERMEDIATE AXLE		01
25	0511064536	28Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0501313213	DRIVE SHAFT		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	41	01


Item	Code	Description	See page	QT
31	0503010292	701164 6 X 40 SPRING PIN		08
32	0511057258	TENSIONER WITH GEAR	43	01
33	0511054363	CHAIN TENSIONER	44	01
34	0501313212	DRIVEN AXIS		01




Item	Code	Description	See page	QT
01	0502011978	CENTRAL BEARING GEARBOX		01
02	0503013462	6005 2RS1 ROLLER BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0501056444	ROLLER BEARING	42	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX SUPPORT		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0571019207	DEVIATION AXLE GEAR BOX		01
06	0503010899	5/8 UNC X 2.1/4 BOLT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01



Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6 X 1 X 16 C S 8.8 ZN BOLT		05
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0503011105	SEAL RING		01
11	0503011409	6005 Z BALL BEARING		01
12	0503017008	SEAL RING		01
13	0503017007	SEAL RING		02
14	0511017907	1/8" BSPT X 6 PLUG		01
15	0503010003	1845 GREASE FITTING		01
16	0503035316	LUBRICATED POINTS DECAL		01
17	0501311461	CONIC GEAR 14 TEETH		01
18	0531066150	WELDED DRIVE AXLE		01
19	0503015110	M06 SPRING WASHER		02
20	0501311538	LEFT HUB FIXER		01
21	0513011980	1/4 UNC X 1 CAPQ G2 ZN SCREW		02
22	0503014876	NUT PARLOCK 1/4"		02



Item	Code	Description	See page	QT
01	0503064136	CARDAN TS 16,00 X Q 15,90 X Q 22 X 697		01
02	0503034480	CARDAN COIF		01

SIDE BEARING SET


0541050875




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007	49	02
02	0503010337	NUT 5/16 UNC G.5 ZN		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0503010845	501035 CLAMPING RING (FOR AXLE)		01
07	0503030119	LOCK PIN		01
08	0541050876	20Z GEAR ASSY		01
08A	0531066542	20Z GEAR		01
08B	0503013958	1/4\" X 1\" BOLT		02

SIDE BEARING SET


0541050873




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007	49	02
02	0503010337	NUT 5/16 UNC G.5 ZN		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0503010845	501035 CLAMPING RING (FOR AXLE)		01
07	0503030119	LOCK PIN		01
08	0541050874	28Z GEAR ASSY		01
08A	0531066541	28Z GEAR		01
08B	0503013958	1/4\" X 1\" BOLT		02




Item	Code	Description	See page	QT
01	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
02	0503016065	ROLLER BEARING		01
03	0503011800	SEAL RING		01



Item	Code	Description	See page	QT
01	0503062362	FERTILIZER HOPPER		02
02	0503011957	NYLON HANDLE		02
03	0503010371	5/16" X 1" BOLT		04
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
05	0503010337	NUT 5/16 UNC G.5 ZN		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
07	0503010025	3/8 SPRING WASHER		10
08	0503010026	3/8" NUT		10
09	0501010984	10,50 X 27 X 3,00 FLAT WASHER		20
10	0503035931	FERTILIZER METERING SEAL		08
11	0571019051	FIXER HOPPER WASHER		12
12	0503013751	3/8 UNC X 1.1/4 BOLT		12
13	0503012535	3/8" SPRING WASHER		12
14	0503012531	3/8" INOX NUT		12
15	0541050794	CENTRAL FERTILIZER HOPPER SUPPORT	51	01




Item	Code	Description	See page	QT
01	0541050452	ALPHA II FERTILIZER METERING LOWER FLANGE	55	04
02	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	60	02
03	0501218830	3/4 X 151,5/153,5 SQUARE AXLE WITH HOLE		02
04	0531057908	SLEEVE 1/4 X 2		02
04A	0502013069	SLEEVE 21 X 38 X 50		01
04B	0503010010	SPLIT PIN 1/4" X 2.1/2"		01
05	0501310529	SQUARE AXIS 3/4 X 1330		02
06	0501053788	3/4" SQUARE AXLE FASTENER	62	04
07	0503031527	AGRICULTURAL BEARING		04
08	0541050877	SIDE BEARING SET	63	02
09	0561013049	CHAIN TIGHTENER AXLE		02
10	0503010019	1/2" SPRING WASHER		02
11	0503010060	1/2 UNC G.5 ZN HEX NUT		02
12	0501013519	FLAT WASHER		02
13	0503010302	501019 SEAL RING		02
14	0503031805	11Z 1/2" GEAR		02
15	0503015002	40-1 CHAIN X 66 LINK + REDUCTION		02
16	0531066846	FERTILIZER HOPPER SUPPORT		01
17	0503019414	THREAD RIVET		16
18	0501314730	CENTER BASE COVER		04
19	0503036550	LID SEAL		04
20	0503012537	5/16" X 1" BOLT		16
21	0503012534	LOCK WASHER		16



Item	Code	Description	See page	QT
01	0503062362	FERTILIZER HOPPER		03
02	0503011957	NYLON HANDLE		02
03	0503010371	5/16" X 1" BOLT		04
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
05	0503010337	NUT 5/16 UNC G.5 ZN		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
07	0503010025	3/8 SPRING WASHER		10
08	0503010026	3/8" NUT		10
09	0501010984	10,50 X 27 X 3,00 FLAT WASHER		20
10	0503035931	FERTILIZER METERING SEAL		12
11	0571019051	FIXER HOPPER WASHER		02
12	0503013751	3/8 UNC X 1.1/4 BOLT		02
13	0503012535	3/8" SPRING WASHER		02
14	0503012531	3/8" INOX NUT		02
15	0541051550	RIGHT FERTILIZER BOX SUPPORT	53	01
16	0541051551	LEFT FERTILIZER BOX SUPPORT	54	01

RIGHT FERTILIZER BOX SUPPORT


0541051550




Item	Code	Description	See page	QT
01	0541050452	ALPHA II FERTILIZER METERING LOWER FLANGE	55	03
02	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	60	01
03	0501218830	3/4 X 151,5/153,5 SQUARE AXLE WITH HOLE		01
04	0531057908	SLEEVE 1/4 X 2		02
04A	0502013069	SLEEVE 21 X 38 X 50		02
04B	0503010010	SPLIT PIN 1/4" X 2.1/2"		02
05	0501310529	SQUARE AXIS 3/4 X 1330		01
06	0501053788	3/4" SQUARE AXLE FASTENER	62	03
07	0503031527	AGRICULTURAL BEARING		03
08	0541050877	SIDE BEARING SET	63	01
09	0561013049	CHAIN TIGHTENER AXLE		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0501013519	FLAT WASHER		01
13	0503010302	501019 SEAL RING		01
14	0503031805	11Z 1/2" GEAR		01
15	0503015002	40-1 CHAIN X 66 LINK + REDUCTION		01
16	0531066896	RIGHT FERTILIZER HOPPER SUPPORT		01
17	0531057978	SIDE BEARING WITH TRANSMISSION	64	01
18	0501314729	SQUARE AXIS 3/4		01
19	0503019414	THREAD RIVET		12
20	0501314730	CENTER BASE COVER		03
21	0503036550	LID SEAL		03
22	0503012537	5/16" X 1" BOLT		12
23	0503012534	LOCK WASHER		12

LEFT FERTILIZER BOX SUPPORT


0541051551




Item	Code	Description	See page	QT
01	0531066897	LEFT FERTILIZER HOPPER SUPPORT		01
02	0541050452	ALPHA II FERTILIZER METERING LOWER FLANGE	55	03
03	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	60	01
04	0501218830	3/4 X 151,5/153,5 SQUARE AXLE WITH HOLE		01
05	0531057908	SLEEVE 1/4 X 2		02
05A	0502013069	SLEEVE 21 X 38 X 50		02
05B	0503010010	SPLIT PIN 1/4" X 2.1/2"		01
06	0501310529	SQUARE AXIS 3/4 X 1330		01
07	0501053788	3/4" SQUARE AXLE FASTENER	62	02
08	0503031527	AGRICULTURAL BEARING		02
09	0541050877	SIDE BEARING SET	63	01
10	0561013049	CHAIN TIGHTENER AXLE		01
11	0503010019	1/2" SPRING WASHER		01
12	0503010060	1/2 UNC G.5 ZN HEX NUT		01
13	0501013519	FLAT WASHER		01
14	0503010302	501019 SEAL RING		01
15	0503031805	11Z 1/2" GEAR		01
16	0503015002	40-1 CHAIN X 66 LINK + REDUCTION		01
17	0531057978	SIDE BEARING WITH TRANSMISSION	64	01
18	0501314729	SQUARE AXIS 3/4		01
19	0501314730	CENTER BASE COVER		03
20	0503036550	LID SEAL		03
21	0503012537	5/16" X 1" BOLT		12
22	0503012534	LOCK WASHER		12
23	0503019414	THREAD RIVET		12




Item	Code	Description	See page	QT
01	0503035911	REAR COLLECTOR SEAL		01
02	0503035912	FRONT COLLECTOR SEAL		01
03	0531055518	WORM THREAD ASSEMBLED		01
03A	0531064265	WORM THREAD		01
03B	0503035859	SUPPORT SLEEVE		01
04	0531055863	TRANSMISSION HUB ASSY	56	01
05	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	57	01
06	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
06A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
06B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
07	0501214337	FERTILIZER METERING BOX		01
08	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
09	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
10	0513011173	NUT 3/8 UNC X 1		04
11	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		04
12	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
13	0513011171	1/4 NC HEX NUT		08
14	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
15	0503036177	LID CORD		01
16	0531059139	COLLECTOR ASSY	58	01
17	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
18	0503035797	FRONT COLLECTOR FIXER		02
19	0501111195	GRANULATED FERTILIZER COATING		01
20	0513010692	ALLEN SCREW 1/4 UNC X 7/8 C FLAT SI INOX		04
21	0503036182	LOWER FLANGE		01
22	0501312601	FRONT COVER		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO DECAL		01
15	0503035316	LUBRICATED POINTS DECAL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT FERTILIZER METERING LID GUIDE		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	59	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02



Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007	49	02
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0503010337	NUT 5/16 UNC G.5 ZN		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0531057901	GEAR	61	01
07	0503010845	501035 CLAMPING RING (FOR AXLE)		01
08	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531065402	GEAR		01
02	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01

SIDE BEARING SET


0541050877




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007	49	02
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		02
01B	0503016065	ROLLER BEARING		02
01C	0503011800	SEAL RING		02
02	0503010337	NUT 5/16 UNC G.5 ZN		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0503010845	501035 CLAMPING RING (FOR AXLE)		01
07	0503030119	LOCK PIN		01
08	0541050878	GEAR 23Z WITH FASTENER		01
08A	0531066544	GEAR 23Z INTERNAL HEX		01
08B	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007	49	01
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0501218530	SIDE BEARING SHAFT BODY		01
03	0503030119	LOCK PIN		01
04	0503010845	501035 CLAMPING RING (FOR AXLE)		01
05	0503010337	NUT 5/16 UNC G.5 ZN		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
08	0503010371	5/16" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0511057267	HOSE KIT HYDRAULIC		01
01A	0501080722	3/8 X 3300 TC-TM HOSE ASSY		01
01B	0501082023	HOSE 3/8 X 3600 TC-TM		01
02	0501053834	MALE QUICK COUPLER	67	02
03	0503013100	NYLON CLAMP 4,8 X 1,3 X 200 MM		02
04	0571017774	SPRING PROTECTION QUICK HOSE		01



Item	Code	Description	See page	QT
01	0511057335	HOSE KIT HYDRAULIC		01
01A	0501080025	3/8" X 55,11" TR-TC HOSE		04
01B	0521052285	TC-TM HOSE ASSY		01
01BA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01BD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
01C	0521052330	3/8" X 157.50" TC-TM BLACK/BLUE HOSE		01
01CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01CB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01CC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01CD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	67	02
03	0511058120	KIT VALVE SUPPORT		01
03A	0521066354	OIL DISTRIBUTOR BODY		02
03B	0502010477	HOSE CLAMP		04
03C	0503011268	3/8" X 2-1/2" BOLT		02
03D	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03E	0503010025	3/8 SPRING WASHER		02
03F	0503010026	3/8" NUT		02
04	0503013100	NYLON CLAMP 4,8 X 1,3 X 200 MM		02
05	0502012702	BODY SUPPORT CLAMP		04
06	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
07	0503010180	7/16" SPRING WASHER		04
08	0531011180	UPPER BODY CLIP		04
09	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8" UNC SELF LOCKING NUT		10
04	0503011070	BEATER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0501069470	ROW MARKER ARM		02
07	0521061655	BOLT 5/8 UNC X 320 MM		02
08	0521010479	SLEEVE ARTICULATION		04
09	0511058449	HYDRAULIC CYLINDER	70	02
10	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
11	0503010523	1/4" X 2" SPLIT PIN		02
12	0511015779	1" X 4.2" AXLE		02
13	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
14	0503014876	NUT PARLOCK 1/4"		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0503030168	HITCH PIN CLIP		02
17	0511062755	740 TURNBUCKLE		02
18	0503011854	5/8" X 1-1/4" BOLT		04
19	0501054649	HBM SEQUENTIAL VALVE	71	01
20	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
21	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
22	0503010025	3/8 SPRING WASHER		02
23	0541050810	HOSES SET - 3495		01
23A	0501080397	3/8" X 120" TR-TC HOSE		04
23B	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
23BA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
23BB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
23BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
23BD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
23C	0521052850	3/8 X 4200 TC-TM PURPLE/BLUE HOSE		01

Item	Code	Description	See page	QT
23CA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
23CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
23CC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
23CD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
24	0501053834	MALE QUICK COUPLER	67	02
25	0502012702	BODY SUPPORT CLAMP		08
26	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		08
27	0503010180	7/16" SPRING WASHER		08
28	0503010244	7/16" NUT		02
29	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
30	0511058119	VALVE SUPPORT ASSEMBLY	72	01
31	0501068994	8,30 X 78 LOCK PIN		02




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503012412	5/8" UNC SELF LOCKING NUT		10
04	0503011070	BEATER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0501069470	ROW MARKER ARM		02
07	0521061655	BOLT 5/8 UNC X 320 MM		02
08	0521010479	SLEEVE ARTICULATION		04
09	0511058449	HYDRAULIC CYLINDER	70	02
10	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
11	0503010523	1/4" X 2" SPLIT PIN		02
12	0511015779	1" X 4.2" AXLE		02
13	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
14	0503014876	NUT PARLOCK 1/4"		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0503030168	HITCH PIN CLIP		02
17	0501066949	1235 TURNBUCKLE		02
18	0503011854	5/8" X 1-1/4" BOLT		04
19	0501054649	HBM SEQUENTIAL VALVE	71	01
20	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
21	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
22	0503010025	3/8 SPRING WASHER		02
23	0511057383	HOSE KIT MARKER HYDRAULIC		01
23A	0501080403	3/8" X 137" TR-TR HOSE ASSY		02
23B	0501080390	3/8" X 150" TR-TC HOSE ASSY		02
23C	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
23CA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
23CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
23CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
23CD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06


Item	Code	Description	See page	QT
23D	0521052850	3/8 X 4200 TC-TM PURPLE/BLUE HOSE		01
23DA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
23DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
23DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
23DD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
24	0501053834	MALE QUICK COUPLER	67	02
25	0502012702	BODY SUPPORT CLAMP		10
26	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		10
27	0503010180	7/16" SPRING WASHER		10
28	0503010244	7/16" NUT		02
29	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
30	0511058119	VALVE SUPPORT ASSEMBLY	72	01
31	0501068994	8,30 X 78 LOCK PIN		02




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	O'RING 2-119 N 3006 9B		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	REPAIR KIT ASSY (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	NIPPLE 3/4" NF X 3/4" NF HEX. 7/8" X 44		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0581010011	VALVE FIXING SUPPORT		01
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
04	0503010025	3/8 SPRING WASHER		02
05	0503010026	3/8" NUT		02



Item	Code	Description	See page	QT
01	0571018865	PLATFORM - 3495		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0571018869	PLATFORM - 5345		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		02
02	0503010237	3/8" X 1" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511069636	LADDER		01
06	0503011179	3/8" X 2-1/4" BOLT		02
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503013357	3/8 SELF-ADJUSTING NUT		02

JACK ASSEMBLY

0511054971




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0503030012	HITCH PIN CLIP		01
03	0503012412	5/8" UNC SELF LOCKING NUT		02
04	0501011075	PIN		01
05	0502010175	HITCH CLAMP		01
06	0502011530	SUPPORT		01
07	0521067869	PLOUGH SUPPORT		01

DRAWBAR ASSEMBLY INVERTED SUPPORT


0541050752



Item	Code	Description	See page	QT
01	0521065958	DRAWBAR		01
02	0502012805	SUPPORT FRONT FIXER DRAWBAR		02
03	0502012789	FIXER SUPPORT FERTILIZER ROW		08
04	0502012806	SUPPORT REAR FIXER DRAWBAR		04
05	0503017960	5/8" X 3-12" BOLT		32
06	0503010811	5/8" UNF SELF ADJUSTING NUT		32
07	0501010191	1" X 6" BOLT		04
08	0503010012	1" SPRING WASHER		04
09	0501010059	1.5/8 NUT		04
10	0561019087	DRAWBAR TRANSPORT LOCK		01
11	0551014099	COUPLING SHAFT 31,75 X 185		01
12	0503030085	LOCK PIN		02
13	0503010002	1800 GREASE FITTING		02
14	0521010544	1.2" X 4.9" COUPLING SHAFT		01
15	0531066475	DISPLACED FASTENER		02




Item	Code	Description	See page	QT
01	0503034115	PST PLUS FLEX DECAL		01
02	0503034258	PST PLUS FLEX DECAL		01
03	0503034114	TATU LOGO DECAL		01
04	0503033892	TATU LOGO DECAL		01
05	0503033417	NUMBER 3 DECAL		02
06	0503033418	NUMBER 4 DECAL		02
07	0503033419	NUMBER 5 DECAL		02
08	0503033423	NUMBER 9 DECAL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	MANUAL SEAL DECAL		01
11	0503035927	P27 FERTILIZER TABLE DECAL		02
12	0503031565	CAUTION TRANSPORTATION DECAL		02
13	0503031566	ATTENTION JACK DECAL		02
14	0503032997	SEED DISTRIBUTION TABLE DECAL		02
15	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL		02
16	0503031424	ATTENTION HYDRAULIC MARKER DECAL		02
17	0503033012	RIGHT GEAR BOX SEED/FERTILIZER DECAL		01
18	0503033013	LEFT GEAR BOX SEED/FERTILIZER DECAL		01
19	0503032930	DANGER DECAL		04
20	0503031087	AUTO CONTROL APPROVED DECAL		01
21	0503034003	61 X 118 SERIAL NUMBER TAG		01
22	0503010001	RIVET 3,2 X 5,5		04
23	0503032979	LETTERS A B C D DECAL		02
24	0503034500	GRIP COLORS (PLANTERS) DECAL		01




Item	Code	Description	See page	QT
01	0503034115	PST PLUS FLEX DECAL		01
02	0503034114	TATU LOGO DECAL		02
03	0503033892	TATU LOGO DECAL		01
04	0503034258	PST PLUS FLEX DECAL		01
05	0503033417	NUMBER 3 DECAL		02
06	0503033418	NUMBER 4 DECAL		02
07	0503033419	NUMBER 5 DECAL		04
08	0503031428	READ MANUAL DECAL		01
09	0503031942	MANUAL SEAL DECAL		01
10	0503035927	P27 FERTILIZER TABLE DECAL		02
11	0503031565	CAUTION TRANSPORTATION DECAL		02
12	0503031566	ATTENTION JACK DECAL		02
13	0503032997	SEED DISTRIBUTION TABLE DECAL		02
14	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL		02
15	0503031424	ATTENTION HYDRAULIC MARKER DECAL		02
16	0503033012	RIGHT GEAR BOX SEED/FERTILIZER DECAL		01
17	0503033013	LEFT GEAR BOX SEED/FERTILIZER DECAL		01
18	0503032930	DANGER DECAL		06
19	0503031087	AUTO CONTROL APPROVED DECAL		01
20	0503034003	61 X 118 SERIAL NUMBER TAG		01
21	0503010001	RIVET 3,2 X 5,5		04
22	0503032979	LETTERS A B C D DECAL		02
23	0503034500	GRIP COLORS (PLANTERS) DECAL		01




Item	Code	Description	See page	QT
01	0503034115	PST PLUS FLEX DECAL		01
02	0503034258	PST PLUS FLEX DECAL		01
03	0503034114	TATU LOGO DECAL		01
04	0503033892	TATU LOGO DECAL		01
05	0503033417	NUMBER 3 DECAL		02
06	0503033418	NUMBER 4 DECAL		02
07	0503033419	NUMBER 5 DECAL		02
08	0503033423	NUMBER 9 DECAL		02
09	0503031428	READ MANUAL DECAL		01
10	0503031942	MANUAL SEAL DECAL		01
11	0503035927	P27 FERTILIZER TABLE DECAL		02
12	0503031565	CAUTION TRANSPORTATION DECAL		02
13	0503031566	ATTENTION JACK DECAL		02
14	0503038335	ETIQUETA ADHESIVA		02
15	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL		02
16	0503031424	ATTENTION HYDRAULIC MARKER DECAL		02
17	0503033012	RIGHT GEAR BOX SEED/FERTILIZER DECAL		01
18	0503033013	LEFT GEAR BOX SEED/FERTILIZER DECAL		01
19	0503032930	DANGER DECAL		04
20	0503031087	AUTO CONTROL APPROVED DECAL		01
21	0503034003	61 X 118 SERIAL NUMBER TAG		01
22	0503010001	RIVET 3,2 X 5,5		04
23	0503032979	LETTERS A B C D DECAL		02
24	0503034500	GRIP COLORS (PLANTERS) DECAL		01




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521067033	FRAME LIFTING SUPPORT		01
03	0503017960	5/8" X 3-12" BOLT		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
03	0503010019	1/2" SPRING WASHER		08
04	0503010060	1/2 UNC G.5 ZN HEX NUT		08
05	0511059383	HANDRAIL INTERNAL FIXER		04
06	0581012642	REAR HANDRAIL REFERENCE		02
07	0521067257	HANDRAIL - 3495		02




Item	Code	Description	See page	QT
01	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
03	0503010019	1/2" SPRING WASHER		08
04	0503010060	1/2 UNC G.5 ZN HEX NUT		08
05	0511059383	HANDRAIL INTERNAL FIXER		04
06	0581012642	REAR HANDRAIL REFERENCE		02
07	0531067038	HANDRAILING WITH GRADE		02




Item	Code	Description	See page	QT
01	0581011989	SIDE BODY FIXER PLATFORM		01
02	0551019884	45 X 50 X 3/8 FASTENER		01
03	0503010025	3/8 SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1" BOLT		02
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0531066515	TOWER SUPPORT SUPPORT		04
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		16
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		32
04	0503010025	3/8 SPRING WASHER		16
05	0503010026	3/8" NUT		16
06	0502012789	FIXER SUPPORT FERTILIZER ROW		04
07	0503017857	BOLT 5/8 UNF 4		16
08	0503010811	5/8" UNF SELF ADJUSTING NUT		16
09	0501310971	SEED CONDUCTOR RIGHT 3 X 1500		04
10	0531050237	3" RIGHT SEED CONDUCTOR FIXER	90	08
11	0531052127	CONDUCTOR HOPPER SUPPORT	87	02




Item	Code	Description	See page	QT
01	0531062660	HOPPER SUPPORT		01
02	0503010025	3/8 SPRING WASHER		12
03	0503010026	3/8" NUT		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		12
05	0501011643	3/8 X 1" BOLT		04
06	0503062464	FERTILIZER HOPPER ASSY		01
07	0591019764	SEED HOPPER FIXER SUPPORT		02
08	0503010209	3/8" UNC BUTTERFLY NUT		08
09	0531053039	SEED DEFLECTOR 517 MOUNTED PEANUTS	88	02




Item	Code	Description	See page	QT
01	0531063036	PEANUT DEFLECTOR BODY		01
02	0531053043	SEED CONDUCTOR 3 FULL ARTICULATED	93	01
03	0501010942	3/8" X 1-1/4" BOLT		04
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0531066515	TOWER SUPPORT SUPPORT		06
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		24
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		48
04	0503010025	3/8 SPRING WASHER		24
05	0503010026	3/8" NUT		24
06	0502012789	FIXER SUPPORT FERTILIZER ROW		06
07	0503017857	BOLT 5/8 UNF 4		24
08	0503010811	5/8" UNF SELF ADJUSTING NUT		24
09	0501310971	SEED CONDUCTOR RIGHT 3 X 1500		06
10	0531050237	3" RIGHT SEED CONDUCTOR FIXER	90	12
11	1164930001	BLACK VINYL TUBE 3.1/2		09 mts
12	0541051541	CSU SUPPORT WITH BAFFLE	91	03




Item	Code	Description	See page	QT
01	0503013759	NUT		02
02	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
03	0502012979	CLAMP 3 RIGHT CSU		02
04	0503010421	5/16" X 1-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0503010025	3/8 SPRING WASHER		12
02	0503010026	3/8" NUT		04
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		12
04	0501011643	3/8 X 1" BOLT		04
05	0591019764	SEED HOPPER FIXER SUPPORT		02
06	0503010209	3/8" UNC BUTTERFLY NUT		08
07	0503062587	FERTILIZER HOPPER ASSY		01
08	0531066894	SUPPORT SINGLE SEED BOX		01
09	0541051540	SEED DEFLECTOR 694	92	02



Item	Code	Description	See page	QT
01	0531053043	SEED CONDUCTOR 3 FULL ARTICULATED	93	01
02	0501010942	3/8" X 1-1/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0531066895	DEFLECTOR BODY 694		01




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8 SPRING WASHER		01
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0531063035	DRIVER 3 COM FLANGE 70 AMENDOIM		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	NUT 5/16 UNC G.5 ZN		02
11	0502012767	SEED NOZZLE FIXER SUPPORT		01




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	95	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		01

ROW MARKER DISC


0511053904




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER 5/16"		04
16	0503010337	NUT 5/16 UNC G.5 ZN		04




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521065959	JACK R.1.1/2 UNC RIGHT X 240		01
03	0521065960	JACK R.1.1/2 UNC LEFT X 240		01
04	0501061056	1.1/2" RIGHT LOCK-NUT		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	SCREW ASSY		01
05	0501011301	1.1/2" UNC 6FPP 2.5/16" NUT		01
06	0503010010	SPLIT PIN 1/4" X 2.1/2"		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2" SPLIT PIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0503060100	SUPPORT INSTRUCTION MANUAL		01
02	0503010267	NYLON CLAMP 3,60 X 1,3 X 155 MM		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER 32,50 X 75 X 4,75		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	NUT 5/16 UNC G.5 ZN		01
07	0511034752	BAG WITH MANUAL		01




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		04
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		04
01B	0503035859	SUPPORT SLEEVE		04
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		04
02A	0501111196	PELLETED FERTILIZER METERING COATING		04
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		04
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01



Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		06
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		06
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0503064144	SEED/FERTILIZER MONITORING KIT 8 LINES		01
01A	0503019723	CABLE		02
01B	0503019100	SENSOR		08
01C	0503018932	FLOW FERTILIZER SENSOR		08
01D	0503019719	PLANTING MONITOR MP36		01
01E	0503017443	ANTENNA GPS PM 400		01
01F	0503017031	CLEANING BRUSH		01
01G	0503019720	NYLON CLAMP		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503010293	CLAMP KNOB		02
04	0591016146	0.63" X 0.51" X 1.89" SLEEVE		01
05	0503011141	3/8" X 2-3/4" BOLT		01
06	0531061651	LARGER U SUPPORT		01
07	0501013518	FLAT WASHER		03
08	0531061652	SMALLER U SUPPORT		01
09	0503010025	3/8 SPRING WASHER		01
10	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0521058524	SEED ROW FRONT	104	01
02	0531061136	EXTENSION		01
03	0503010311	1/2" X 1-1/4" BOLT		01
04	0503012136	NUT 1/2 NF		01
05	0541051739	RIGHT REAR	105	01
06	0541051730	MECHANICAL SEED HOPPER	123	01
07	0541050737	SHORT FERTILIZER ROW 20" DISC BLADE	128	01
07.	0541052224	SHORT FERTILIZER ROW 20" WAVY COULTER DISC BLADE	133	01
08	0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	136	01
09	0503030391	RIGHT FERTILIZER NOZZLE		01
10	0503030392	LEFT FERTILIZER NOZZLE		01
11	0503030520	SEED SOCKET		01
11.	0503030483	FERTILIZER SOCKET		01
12	0503011266	CLAMP 2.1/4" A 3" 57-76		01
13	0503036268	CURVED CONDUCT		01
14	0503036154	HOSE 2 X 2 X 505		01
15	0503031076	2" HOSE CLAMP		01
16	0503010246	CLAMP		01
17	0531052159	LEFT IRON COVERING WHEEL	138	01
18	0531052160	RIGHT IRON COVERING WHEEL	139	01
19	0531013600	PRESS ADJUSTMENT LEVER		01
20	0501110804	SCARIFIER ROD WITH POINT	143	01
20.	0521053946	SCARING ROD	144	01
21	0521069127	BOTTOM NOZZLE FERTILIZER		01
22	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
23	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
24	0503010025	3/8 SPRING WASHER		01
25	0503010026	3/8" NUT		01
26	0503031050	CURVED CONDUCTOR		01




Item	Code	Description	See page	QT
27	0511017969	0.1" SPACING PLATE		01
28	0511018662	SPACING PLATE		01
29	0513010610	PEANUT DISC SOCIDISC		01
30	0513010615	PEANUT DISC SOCIDISC		01
31	0503034576	475 SIGMA SEED NOZZLE		01
32	0541051703	QUICK LOCK SET SIGMA V3	145	01
33	0521068982	DISC BLADE HUB KEY		01



Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
05	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
06	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
07	0571018883	PIN FIXER SPRING		03
08	0503030168	HITCH PIN CLIP		04
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
10	0503017857	BOLT 5/8 UNF 4		04
11	0591011156	PIVOT ARM SEED ROW		02
12	0591011157	SPACER LOWER SLEEVE		04
13	0503019273	AUTO LUBRICANT SLEEVE		08
14	0503010045	O'RING		08
15	0531061528	REAR SUPPORT ROW		01
16	0591012829	SPACER LOWER SLEEVE		04
17	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		02
18	0503013389	5/8" SELF LOCKING NUT		04
19	0591011409	FLAT WASHER 16,5 X 35 X 3,00		04
20	0591012828	LOCK PIN ROW ARTICULAT		01




Item	Code	Description	See page	QT
01	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04
02	0503010025	3/8 SPRING WASHER		04
03	0503010026	3/8" NUT		04
04	0541051705	LEFT SYSTEM FIXATION BASE	106	01
05	0541051744	RIGHT REAR MECHANICAL	108	01



Item	Code	Description	See page	QT
01	0541050098	UNILATERAL GEARBOX	107	01
02	0501314957	INDEX SUPPORT		02
03	0501314959	SYSTEM FIXATION BASE		01
04	0513012066	ALLEN SCREW M4 X 10		02

UNILATERAL GEARBOX


0541050098



Item	Code	Description	See page	QT
01	0502012932	MINOR SIDE		01
02	0503017046	BEARING		02
03	0591011322	SPACER		01
04	0581019168	DUST CLOAK		01
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
06	0503010025	3/8 SPRING WASHER		01
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
08	0503011945	503050 CLAMPING RING (FOR AXLE)		01
09	0503011053	5/16" X 3" C S 6.5 ZN BOLT		04
10	0502012919	GRAGGER		01
11	0502012933	LARGER SIDE		01
12	0502012930	CONICAL GEAR		01
13	0502012931	CONICAL GEAR		01
14	0503010585	0,24" X 1.18" SPRING PIN		01
15	0503017022	RING		02
16	0503019356	BEARING 6005 2RS1		02
17	0501311539	PINION AXIS 170		01

RIGHT REAR MECHANICAL

0541051744




Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0521056632	DEPTH CONTROL	109	01
03	0591016905	DEPTH WHEEL JOINT AXLE		02
04	0502012920	SUPPORT ADJUSTING		01
05	0502012611	DEPTH CONTROL AXLE		01
06	0591011309	ADJUSTMENT BUSHING		02
07	0591011310	ADJUSTMENT BAR		02
08	0503019275	SLEEVE LUBRICATION SYSTEM		01
09	0581019473	ARTICULATED SLEEVE		02
10	0503010045	O'RING		02
11	0503013357	3/8 SELF-ADJUSTING NUT		02
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
13	0591011326	LOCK PIN		01
14	0571015326	ARTICULATION SLEEVE HANDLE		01
15	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
16	0503010060	1/2 UNC G.5 ZN HEX NUT		02
17	0503010019	1/2" SPRING WASHER		04
18	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
19	0501011445	FLAT WASHER		04
20	0503012556	1/2" X 1" BOLT		02
21	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
22	0591011306	ADJUSTMENT LOCK		02
23	0503012136	NUT 1/2 NF		04
24	0503012135	BOLT 1/2 UNF X 1.1/2 CS G.5 ZN		04
25	0521055093	BODY COMPACTOR	110	01
26	0521054990	LEFT COMPACTOR WHEEL	111	01
27	0521055017	RIGHT COMPACTOR WHEEL	112	01
28	0531050538	MOUNTED LEFT ARM	113	01
29	0531050539	MOUNTED LEFT ARM	114	01
30	0503010131	3/16" X 1.1/2" SPLIT PIN		02


RIGHT REAR MECHANICAL

0541051744


Item	Code	Description	See page	QT
31	0591016900	BEATING AXLE		01
32	0591016907	SPACER SLEEVE		06
33	0591016988	SPICER PROTECTOR		01
34	0541051742	DOUBLE DISC RIGHT	118	01




Item	Code	Description	See page	QT
01	0502012925	ADJUSTMENT BODY		01
02	0511015976	FLAT WASHER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0503010581	RING		01
05	0502012892	DEPTH CONTROL HANDLE		01
06	0581019526	ARTICULATED AXLE LEVER DEPTH		01
07	0503010302	501019 SEAL RING		01




Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT		02
02	0503013816	5/16" LOCKNUT		04
03	0581015855	SLEEVE		02
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
05	0521068661	LEVER		01
06	0503030878	LEVER CRANK		01
07	0503031393	1.57" X 5.98" X 0.2" TRACTION SPRING		01
08	0581019520	AXIS		01
09	0571812442	COUPLING SHAFT		01
10	0503010257	1/8" X 1" SPLIT PIN		01
11	0581019511	COVER		01
12	0503010848	5/16" X 3.1/2" BOLT		02
13	0503010752	1/2" X 3.1/2" BOLT		01
14	0503011336	1/2" HEX SELF ADJUSTING NUT		01
15	0503030190	0.5" X 1.6" X 0.05" SPRING		01
16	0581019510	AXIS		01
17	0581019512	PLATE TOP		01
18	0503019351	LUBRICANT SLEEVE		02
19	0521069591	LEFT SIDE		01
20	0581019548	RIGHT SIDE BODY		01




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	115	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	115	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012927	LEFT ARM		01
02	0503011109	O'RING 2-119 N 3006 9B		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055056	SPOKED WHEEL ASSY	116	01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		01



Item	Code	Description	See page	QT
01	0502012926	RIGHT ARM		01
02	0503011109	O'RING 2-119 N 3006 9B		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055056	SPOKED WHEEL ASSY	116	01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		01




Item	Code	Description	See page	QT
01	0502012894	WHEEL HUB		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
04	0503010337	NUT 5/16 UNC G.5 ZN		06
05	0503032970	RUBBER BAND		01
06	0521055073	ASSEMBLY DEPTH WHEEL HUB	117	01

ASSEMBLY DEPTH WHEEL HUB


0521055073




Item	Code	Description	See page	QT
01	0581019528	WHEEL DEPTH SPA HUB WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	DUST CLOAK		01
11	0581019529	DEPTH REGULATOR SHAFT		01




Item	Code	Description	See page	QT
01	0502012929	BODY RIGHT		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0503010026	3/8" NUT		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
07	0503010025	3/8 SPRING WASHER		01
08	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
09	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 119 FERTILIZER / SEED		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 120 FERTILIZER / SEED		01
11	0502012779	PNEUMATIC DRIVING PROTECTOR		01
12	0501212058	TITANIUM SEED DRIVER'S GUIDE		01
13	0503015341	POP RIVET		02




Item	Code	Description	See page	QT
01	0521055865	FERTILIZER/SEED LEFT HUB ASSY	121	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055864	FERTILIZER/SEED RIGHT HUB ASSY	122	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUBLE DISC AXLE		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O-RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0541050399	SEED HOPPER WITH COUPLING	124	01
02	0503030085	LOCK PIN		01
03	0503010025	3/8 SPRING WASHER		01
04	0503010209	3/8" UNC BUTTERFLY NUT		01
05	0501013518	FLAT WASHER		01
06	0501312560	DEFLECTOR FIXING AXLE		01
07	0541051731	PEANUT DISTRIBUTOR	127	01
08	0591016430	PEANUT DEFLECTOR		01



Item	Code	Description	See page	QT
01	0503012537	5/16" X 1" BOLT		05
02	0503012545	FLAT WASHER		05
03	0503019657	HEX LOCK NUT WITH NYLON 5/16		05
04	0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	125	01
05	0502050061	COUPLING BODY		01




Item	Code	Description	See page	QT
01	0503015536	M6 X 1" SELF ADJUSTING NUT		04
02	0581014295	FIXING SLEEVE		01
03	0501213431	SEED NOZZLE FIXING FLANGE		01
04	0501213520	SEED BREAKER BODY		01
05	0501213432	BREAKER SUPPORT BASE		01
06	0501213728	60 X 53 X 30 PVC TUBE		01
07	0513010720	M6 X 1 X 35 C S G.5 ZB BOLT		04
08	0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK 126 LID		01




Item	Code	Description	See page	QT
01	0503035751	SIGMA SINGLE SEED HOPPER		01
02	0503035750	SEED HOPPER LID		01
03	0503035298	BAKELITE HANDLE WITH THREAD		01
04	0503015536	M6 X 1" SELF ADJUSTING NUT		01
05	0503035297	CURVED NOZZLE SEED HOPPER		01

PEANUT DISTRIBUTOR

0541051731




Item	Code	Description	See page	QT
01	0503010337	NUT 5/16 UNC G.5 ZN		01
02	0513010671	5/6 UNC X 2 CCSI 12.9 BOLT		01
03	0503035789	SIGMA ALUMINUM DECAL		01
04	0503013356	RIVET POP 3,2 X 10,0		04
05	0503036321	QUICK LOCK		02
06	0503016282	ALLEN BOLT		01
07	0503019913	SELF-LOCKING NUT W/ NYLON M8 X 1.25 C.8 ZN		01
08	0503035299	PLATE SPRING 16 X 8.2 X 0.90		02
09	0503030168	HITCH PIN CLIP		01
10	0503036312	LID SEAL		01
11	0503036313	COUPLING GUIDE SUPPORT		04
12	0503036302	SPIN LIMITER		01
13	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		08
14	0503036311	DRAIN GUIDE SUPPORT		01
15	0502050060	SEED DISTRIBUTOR		01
16	0513011816	ALLEN SCREW M4 X 16 CCS		10
17	0503050090	DRAIN COVER		01
18	0503064043	SEED DISTRIBUTOR BOX		01
19	0501314956	BOTTOM TRACK		01
20	0513010609	PEANUT DISC		01




Item	Code	Description	See page	QT
01	0503011255	3/4" LOCK NUT		02
02	0503034320	COMPRESSION SPRING		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503011854	5/8" X 1-1/4" BOLT		02
05	0503017960	5/8" X 3-12" BOLT		04
06	0502012813	FLANGE WASHER SPRING		01
07	0503010417	7/8" NUT		02
08	0502012789	FIXER SUPPORT FERTILIZER ROW		01
09	0591011147	SLEEVE ARM ROW		02
10	0503019278	LUBRICANT SLEEVE		02
11	0503011109	O'RING 2-119 N 3006 9B		02
12	0503011254	7/8" HEX SELF ADJUSTING NUT		01
13	0521010066	3/4" X 8.12" BOLT		01
14	0541050740	22" DISC BLADE ASSY	129	01
15	0591011145	FERTILIZER ROW SUPPORT		01
16	0531066467	FERTILIZER ROW ARM		01
17	0571019032	SUPPORT WASHER		01
18	0501010164	3/4" X 7 BOLT		01
19	0531066466	SPRING REGULATOR		01
20	0501312988	SLEEVE		01

22" DISC BLADE ASSY

0541050740




Item	Code	Description	See page	QT
01	0571019034	FLANGE WASHER AXLE		01
02	0503019274	WASHER		04
03	0503030430	7/16 X 2" PIN LOCK		01
04	0591011144	FIXATION AXLE		01
05	0591010628	SHAFT THRUST WASHER		01
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
07	0541050741	22" DISC HUB	130	01
08	0541050742	SUPPORT SPRING GUIDE	132	01
09	0551015883	SPRING GUIDES SLEEVE		02
10	0521068189	SPRING REGULACION		02
11	0503011075	UNC NUT 3/4 UNC ALTA G.5 ZN		02
12	0531066471	ARM GUIDE DC 22		01
13	0503031575	COMPRESSION SPRING		02
14	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		02
15	0503010806	5/8" X 3" BOLT		02
16	0503010878	5/8" SELF ALIGNING NUT		03
17	0503019341	LUBRICANT SLEEVE		02
18	0501312998	ARM LOCK GUIDE SLEEVE		02
19	0503011243	5/8" X 2" BOLT		02
20	0503010027	5/8 SPRING WASHER		02
21	0531066470	ARM DC 22		01




Item	Code	Description	See page	QT
01	0521057680	DISC CUTTING BOX	131	01
02	0603029523	22" X 0.2" FLAT PLAIN DISC		01

DISC CUTTING BOX


0521057680



Item	Code	Description	See page	QT
01	0503010370	502072 CLAMPING RING (FOR AXLE)	02	
02	0502020641	BLADE DISC FLANGE	01	
03	0503018825	5/16 UNC UNC BOLT	06	
04	0503013816	5/16" LOCKNUT	06	
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75	06	
06	0502012862	DISC BLADE HUB	01	
07	0511017907	1/8" BSPT X 6 PLUG	02	
08	0503019285	RING	02	
09	0503010590	00674-B SEAL	02	
10	0591012836	CUTTING DISC AXLE	01	
11	0502040872	REGULATORY NUT	01	
12	0503012170	30207 ROLLER BEARING	02	
13	0503010812	7/8" UNF SELF LOCKING NUT	01	
14	0501010067	22.5 X 56 X 4.75 FLAT WASHER	01	
15	0503019283	SCREW 7/8 UNF X 6.1/4	01	




Item	Code	Description	See page	QT
01	0531066469	DOUBLE SPRING GUIDE SUPPORT		01
02	0501313000	SPRING SUPPORT		01
03	0503012660	1" X 4" BOLT		01
04	0503014182	SELF-ADJUSTING NUT		01
05	0501312999	LOWER WASHER		01
06	0503019271	SELF LUBRICATING BUSHING		01
07	0503019277	SLEEVE LUBRICATION SYSTEM		01




Item	Code	Description	See page	QT
01	0503011255	3/4" LOCK NUT		02
02	0503034320	COMPRESSION SPRING		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503011854	5/8" X 1-1/4" BOLT		02
05	0503017960	5/8" X 3-12" BOLT		04
06	0502012813	FLANGE WASHER SPRING		01
07	0503010417	7/8" NUT		02
08	0502012789	FIXER SUPPORT FERTILIZER ROW		01
09	0591011147	SLEEVE ARM ROW		02
10	0503019278	LUBRICANT SLEEVE		02
11	0503011109	O'RING 2-119 N 3006 9B		02
12	0503011254	7/8" HEX SELF ADJUSTING NUT		01
13	0521010066	3/4" X 8.12" BOLT		01
14	0541052225	22" WAVY COULTER DISC BLADE ASSY	134	01
15	0591011145	FERTILIZER ROW SUPPORT		01
16	0531066467	FERTILIZER ROW ARM		01
17	0571019032	SUPPORT WASHER		01
18	0501010164	3/4" X 7 BOLT		01
19	0531066466	SPRING REGULATOR		01
20	0501312988	SLEEVE		01

22" WAVY COULTER DISC BLADE ASSY


0541052225



Item	Code	Description	See page	QT
01	0571019034	FLANGE WASHER AXLE		01
02	0503019274	WASHER		04
03	0503030430	7/16 X 2" PIN LOCK		01
04	0591011144	FIXATION AXLE		01
05	0591010628	SHAFT THRUST WASHER		01
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01
07	0541052226	22" WAVY COULTER DISC HUB	135	01
08	0541050742	SUPPORT SPRING GUIDE	132	01
09	0551015883	SPRING GUIDES SLEEVE		02
10	0521068189	SPRING REGULACION		02
11	0503011075	UNC NUT 3/4 UNC ALTA G.5 ZN		02
12	0531066471	ARM GUIDE DC 22		01
13	0503031575	COMPRESSION SPRING		02
14	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		02
15	0503010806	5/8" X 3" BOLT		02
16	0503010878	5/8" SELF ALIGNING NUT		03
17	0503019341	LUBRICANT SLEEVE		02
18	0501312998	ARM LOCK GUIDE SLEEVE		02
19	0503011243	5/8" X 2" BOLT		02
20	0503010027	5/8 SPRING WASHER		02
21	0531066470	ARM DC 22		01




Item	Code	Description	See page	QT
01	0521057680	DISC CUTTING BOX	131	01
02	0607027008	22" WAVY COULTER DISC		01




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC	137	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04

RIGHT DUAL FERTILIZER DISC


0521055868




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 120 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 119 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0531062676	LEFT SUPPORT ARM WHEEL COVERING IRON PEANUTS		01
02	0503019272	LUBRICANT SLEEVE		02
03	0591016234	SIDE GUIDE SLEEVE		02
04	0501056288	RIGHT IRON COVERING WHEEL	140	01
05	0503010410	RING		02
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503010027	5/8 SPRING WASHER		01
08	0503010013	5/8" UNC G.5 ZN HEX NUT		01
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02
10	0503010019	1/2" SPRING WASHER		02
11	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0531062676	LEFT SUPPORT ARM WHEEL COVERING IRON PEANUTS		01
02	0503019272	LUBRICANT SLEEVE		02
03	0591016234	SIDE GUIDE SLEEVE		02
04	0501056289	LEFT IRON COVERING WHEEL	142	01
05	0503010410	RING		02
06	0501010163	5/8" X 4-1/2" BOLT		01
07	0503010027	5/8 SPRING WASHER		01
08	0503010013	5/8" UNC G.5 ZN HEX NUT		01
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02
10	0503010019	1/2" SPRING WASHER		02
11	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0503011440	SPRING WASHER		02
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
03	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
04	0501053186	RIGHT IRON PRESS WHEEL ASSY	141	01
05	0502012348	RIGHT WHEEL ARM		01
06	0502011155	RIGHT FIXER WHEEL		01



Item	Code	Description	See page	QT
01	0502011970	IRON PRESS WHEEL		01
02	0503010598	30204 BALL BEARING		02
03	0503011112	SEAL 02376-BRG		01
04	0521019154	RIGHT SHAFT DOUBLE DISC HUB		01
05	0511015098	FLAT WASHER		01
06	0503030282	3/4" CASTLE NUT		01
07	0503010257	1/8" X 1" SPLIT PIN		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503013758	1/4" X 1-1/2" BOLT		03
12	0511016896	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0503011440	SPRING WASHER		02
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
03	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
04	0501053186	RIGHT IRON PRESS WHEEL ASSY	141	01
05	0502012349	LEFT WHEEL ARM STEEL		01
06	0502011156	LEFT FIXER WHEEL		01




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01

SCARING ROD


0521053946



Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070085	FIXED ROD BEARING		01
03	0513010288	ELASTIC PIN 701211 10 X 24		02
04	0513010289	ELASTIC PIN 701211 10 X 24		02



Item	Code	Description	See page	QT
01	0571011804	FAST BOLT ADJUSTMENT		01
02	0502012744	SPEED LOCK LEVER ASSY		01
03	0571014024	FAST BOLT GUIDE AXLE		02
04	0503010140	1/8" X 3/4" SPLIT PIN		02
05	0501314958	QUICK HITCH PRISONER		01



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

