

ROW CROP PLANTERS

PST PLUS FLEX - FRAME 4845 - CSU (FROM 08/2023)

Code: 0501093683
Series: S-0116
Revision: 00
Date Revision: SETEMBRO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code
0111380535

Description
PST PLUS FLEX 4845/6E900 ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

INDEX

0909096886	FRAME ASSY - 4845	1
0511057336	FRAME WITH WHEEL AXLE - 4845	2
0511058656	CYLINDER SET - 4845/5345/5745	3
0521054233	50,8 X 101,6 X 240,5 X 507,5 HYDRAULIC CYLINDER	4
0511057330	HANDRAIL ASSEMBLY - 4845	5
0511059383	HANDRAIL INTERNAL FIXER	6
0511057331	PLATFORM ASSEMBLY - 4845	7
0511056536	LADDER ASSEMBLY	8
0511057333	DRAWBAR ASSEMBLY - 3495/4045/4395/4845/5345/5745	9
0511054601	HITCH ARTICULATED TRACTOR	10
0511057270	DRAWBAR EXTENDER	11
0511056736	HOSE SUPPORT	12
0511054971	JACK ASSEMBLY	13
0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	14
0511058653	WHEELS WITH TRACTION SPRING	15
0511058654	WHEEL SUPPORT	16
0511052770	WHEEL WITH TIRE	17
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	18
0503062159	WHEEL WITH TIRE	19
0501058241	WHEEL SUPPORT CHAIN TENSIONER	20
0501058240	WHEEL FASTENER WITH TENSIONER	21
0501058242	WHEEL MOBILE CHAIN TENSIONER	22
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	23
0501058244	WHEEL FIXED CHAIN TENSIONER	24
0501058239	WHEEL CHAIN TENSIONER BEARING	25
0531059596	4845 ALPHA II FERTILIZER HOPPER SET	26
0531059598	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4845	27
0531059597	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4845	28
0501053788	3/4" SQUARE AXLE FASTENER	29
0531055319	ALPHA II FERTILIZER METERING	30
0531055863	ASSY TRANSMISSION HUB	31
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	32
0531059139	ASSY COLLECTOR	33
0531055273	ALPHA FERTILIZER METERING CLAMP	34
0531057911	22Z GEAR SIDE BEARING ASSEMBLY	35
0531057901	GEAR	36
0503062362	FERTILIZER HOPPER	37
0531058332	CSU C3 SET - 06 CONDUCTORS	38
0531058331	CSU C3 SET - 02 HOPPERS 07 NOZZLES - 06 CONDUCTORS	39
0531057950	3" X 175 SEED NOZZLE WITH FIXING	40
0531054471	CAP WITH FIXING	41
0521055338	ROW SEED BEARING	42
0501053566	ROW SEED BEARING	43
0511057328	SEMI-ASSEMBLED HYDRAULIC MARKER - 4845	44
0511058449	HYDRAULIC CYLINDER	45
0501054649	HBM SEQUENTIAL VALVE	46
0511058119	VALVE SUPPORT ASSEMBLY	47
0501053834	MALE QUICK COUPLER	48
0501050633	ROW MARKER DISC ASSEMBLY	49
0511053904	ROW MARKER DISC	50
0511059323	SUPPORT PLATFORM TRANSPORT	51
0531057456	ALPHA LABEL SET - 4845	52
0511053179	TRACTOR COUPLING SHAFT	53
0541051026	TRANSMISSION ASSEMBLY - 4845	54




MARCHESAN

INDEX

0501052560	MOTOR AXLE SIGNAL	55
0511051434	TRANSMISSION ACTUATOR	56
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	57
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	58
0511057265	TRANSMISSION CHAIN TENSIONER	59
0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	60
0511050652	CHAIN TENSIONER	61
0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	62
0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	63
0521055335	RIGHT GEAR HOUSING SET	64
0511058381	RIGHT GEAR HOUSING	65
0521055337	LEFT GEAR HOUSING SET	66
0511058382	LEFT GEAR HOUSING	67
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	68
0501048790	AXLE WITH RING	69
0501056443	GEAR HOUSING BEARING	70
0501056444	SUPPORT WITH ROLLER BEARING	71
0511057258	TENSIONER WITH GEAR	72
0511054363	CHAIN TENSIONER	73
0511057845	MANUAL CANISTER	74
0531059616	KIT WITH ALPHA COMPONENTS - 06 ROWS	75
0511059322	LIFTING SUPPORT ASSEMBLY	76
0909096887	ASSY SEED/FERTILIZER ROW	77
0521056500	FRONT SHORT SEED ROW WITH RIGHT TRANSMISSION WITHOUT LUBRIFICATION	78
0521056501	FRONT LONG SEED ROW WITH RIGHT TRANSMISSION WITHOUT LUBRIFICATION	79
0511058766	BEARING	80
0511057159	TRANSMISSION HOPPER SEED ROW	81
0511058512	PROTECTION LID	82
0511059872	BEARING	83
0511057269	CHAIN TENSIONER	84
0541051691	RIGHT REAR SIGMA V3 SEED ROW	85
0541051692	LEFT REAR SIGMA V3 SEED ROW	86
0541051706	5/8" SIGMA V3 ASSY BASE	87
0511052301	SUPPORT DDD 15 RIGHT	88
0511052302	LH SUPPORT DDD GUIDE	89
0521055870	RIGHT DOUBLE DISC SEED 15 X 15	90
0521055871	LEFT DOUBLE DISC SEED 15 X 15	91
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	92
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	93
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	94
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	95
0521056477	SHORT FERTILIZER ROW DC20 WITHOUT LUBRICATION	96
0521056479	LONG DC20 FERTILIZER ROW WITHOUT LUBRICATION	97
0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	98
0521054769	LEFT DDD FERTILIZER WITH SUPPORT	99
0521055868	RIGHT DUAL FERTILIZER DISC	100
0521055869	LEFT DUAL FERTILIZER DISC	101
0521056476	DC 20" ASSY	102
0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	103
0521053697	DISC BLADE HUB	104
0541050396	ASSY SIGMA V3 CSU MECHANICAL SEED HOPPER	105
0541050399	SEED HOPPER WITH COUPLING	106
0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	107


INDEX

0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK LID		108
0541050398	SEED DISTRIBUTION BODY		109
0503063405	SOY SEED DISTRIBUTOR CAP		110
0501052297	DEPTH WHEELS REGULATOR ASSY		111
0501052538	DEPTH BAND WITH ARMS		112
0521054984	DEPTH/COMPACTOR SYSTEM - SPT		113
0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION		114
0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION		115
0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION		116
0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION		117
0521055033	SEMI-ASSEMBLED COMPACTOR BODY		118
0521055017	RIGHT COMPACTOR WHEEL		119
0521054990	LEFT COMPACTOR WHEEL		120
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION		121
0501110804	SCARIFIER ROD WITH POINT		122
0531050237	3" RIGHT SEED CONDUCTOR FIXER		123
0531052986	PIVOT SUPPORT		124
0503063647	SIGMA CORN DISC SET		125
0503063648	SIGMA SOY DISC SET		126
0541051703	QUICK LOCK SET SIGMA V3		127
0521057957	FIXED ROD EXTENSION WITH FIXATION		128




Item	Code	Description	See page	4845
01	0511057336	FRAME WITH WHEEL AXLE - 4845	2	01
02	0511058656	CYLINDER SET - 4845/5345/5745	3	01
03	0511057330	HANDRAIL ASSEMBLY - 4845	5	01
04	0511057331	PLATFORM ASSEMBLY - 4845	7	01
05	0511056536	LADDER ASSEMBLY	8	02
06	0511057333	DRAWBAR ASSEMBLY 3495/4045/4395/4845/5345/5745	- 9	01
07	0511054601	HITCH ARTICULATED TRACTOR	10	01
08	0511057270	DRAWBAR EXTENDER	11	01
09	0511056736	HOSE SUPPORT	12	01
10	0511054971	JACK ASSEMBLY	13	02
11	0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	14	01
12	0511058653	WHEELS WITH TRACTION SPRING	15	04
13	0531059596	4845 ALPHA II FERTILIZER HOPPER SET	26	01
14	0531058332	CSU C3 SET - 06 CONDUCTORS	38	01
15	0571018918	3/4 X 2305 AXLE HEX		01
16	0571018919	3/4 X 2490 AXLE HEX		01
17	0521055338	ROW SEED BEARING	42	06
18	0511054314	TRANSMISSION AXLE LOCK SLEEVE		04
18A	0502012699	TRANSMISSION HUB LOCK SLEEVE		04
18B	0503010256	3/8" X 3/4" BOLT		04
19	0511057845	MANUAL CANISTER	74	01
20	0511057328	SEMI-ASSEMBLED HYDRAULIC MARKER - 4845	44	01
21	0501050633	ROW MARKER DISC ASSEMBLY	49	02
22	0521013164	EXTENDER		02
23	0501011310	FIXER LOCK		08
24	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		08
25	0503010019	1/2" SPRING WASHER		08
26	0503010060	1/2 UNC G.5 ZN HEX NUT		08
27	0511059323	SUPPORT PLATFORM TRANSPORT	51	04
28	0531057456	ALPHA LABEL SET - 4845	52	01
29	0501065677	STRUT		02


Item	Code	Description	See page	4845
30	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01
31	0511053179	TRACTOR COUPLING SHAFT	53	01
32	0521013022	TRANSPORT LOCK		02
33	0501047895	25 ROD STOP		02
34	0501047885	30 ROD STOP		02
35	0501047886	35 ROD STOP		02
36	0501047887	40 ROD STOP		02
37	0531059616	KIT WITH ALPHA COMPONENTS - 06 ROWS	75	01
38	0503014120	CHAIN		01
39	0503014321	CABLE STEEL SHACKLE		02
40	0501068994	8,30 X 78 LOCK PIN		02
41	0503030168	HITCH PIN CLIP		02
42	0503010780	N-2050 AMENDMENT		02
43	0503010951	REDUCTION		04
44	0503011750	AMENDMENT WITH LOCK		06
45	0503011751	REDUCTION		06
46	0503010003	1845 GREASE FITTING		06
47	0541051026	TRANSMISSION ASSEMBLY - 4845	54	01
48	0511059322	LIFTING SUPPORT ASSEMBLY	76	02
49	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		04
50	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
51	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
52	0503010019	1/2" SPRING WASHER		08
53	0503010060	1/2 UNC G.5 ZN HEX NUT		08
54	0909096887	ASSY SEED/FERTILIZER ROW	77	01




Item	Code	Description	See page	QT
01	0521065921	FRAME - 4845		01
02	0521065930	PIVOT SHAFT WHEEL - 4845		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0521054233	50,8 X 101,6 X 240,5 X 507,5 HYDRAULIC CYLINDER	4	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521010547	1.2" X 6.5" COUPLING SHAFT		02
04	0503010523	1/4" X 2" SPLIT PIN		04
05	0501047888	45 ROD STOP		02
06	0571019384	SPACING SLEEVE 16,30 X 30 X 104		02
07	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		02
08	0503010027	5/8 SPRING WASHER		02
09	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0521069306	50.8 X 337.5 EXTENSION WITH 32.5 BUSHING		01
02	0521069305	101,6 X 438,5 TUBE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0503010004	1890 GREASE FITTING		01
05	0502012821	50.80 X 101.60 RING SUPPORT		01
06	0503011061	8-342 BACK-UP RING		02
07	0503018024	RING BS		01
08	0503010338	2-342 N 3006-9B O'RING		02
09	0503018026	1870-2000-375 B GASKET		01
10	0503018025	RING GUIDE		01
11	0503010039	D-2000 SCRAPER RING		01
12	0502012822	101.60 END CAP		01
13	0502012842	50,80 X 101,60 PISTON		01
14	0503010817	1.1/4" SELF LOCKING NUT		01
15	0503018029	2-217 O'RING		01
16	0503015633	SELEMASTER SEALING		01
17	0511034644	50,8 X 101,6 HYDRAULIC CYLINDER SPARE SET		01



Item	Code	Description	See page	QT
01	0521065952	FRAME HANDRAIL - 4845		02
02	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0581012916	INTERMEDIATE TUBE		02
07	0511059383	HANDRAIL INTERNAL FIXER	6	04




Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01




Item	Code	Description	See page	QT
01	0571018868	PLATFORM - 4845		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08

LADDER ASSEMBLY


0511056536




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8 SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
08	0503013357	3/8 SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0502012806	SUPPORT REAR FIXER DRAWBAR		04
02	0502012789	FIXER SUPPORT FERTILIZER ROW		04
03	0503017960	5/8" X 3-12" BOLT		16
04	0503010811	5/8" UNF SELF ADJUSTING NUT		16
05	0501010191	1" X 6" BOLT		04
06	0503010012	1" SPRING WASHER		04
07	0501010059	1.5/8 NUT		04
08	0502012805	SUPPORT FRONT FIXER DRAWBAR		04
09	0502012789	FIXER SUPPORT FERTILIZER ROW		04
10	0503017960	5/8" X 3-12" BOLT		16
11	0503010811	5/8" UNF SELF ADJUSTING NUT		16
12	0521065958	DRAWBAR		01
13	0561019087	DRAWBAR TRANSPORT LOCK		01
14	0551014099	COUPLING SHAFT 31,75 X 185		01
15	0521010544	1.2" X 4.9" COUPLING SHAFT		01
16	0503030085	LOCK PIN		02
17	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2" SPLIT PIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521065959	JACK R.1.1/2 UNC RIGHT X 240		01
03	0521065960	JACK R.1.1/2 UNC LEFT X 240		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0511057335	HOSE KIT HYDRAULIC		01
01A	0501080025	3/8" X 55,11" TR-TC HOSE		04
01B	0521052285	TC-TM HOSE ASSY		01
01BA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01BD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
01C	0521052330	3/8" X 157.50" TC-TM BLACK/BLUE HOSE		01
01CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01CB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01CC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01CD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	48	02
03	0511058120	KIT VALVE SUPPORT		01
03A	0521066354	OIL DISTRIBUTOR BODY		02
03B	0502010477	HOSE CLAMP		04
03C	0503011268	3/8" X 2-1/2" BOLT		02
03D	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03E	0503010025	3/8 SPRING WASHER		02
03F	0503010026	3/8" NUT		02
04	0503013100	NYLON CLAMP		02
05	0502012702	BODY SUPPORT CLAMP		04
06	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
07	0503010180	7/16" SPRING WASHER		04
08	0531011180	UPPER BODY CLIP		04
09	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0511058654	WHEEL SUPPORT	16	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	21	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521066716	WHEEL ARM ASSY		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
08	0503010027	5/8 SPRING WASHER		01
09	0501058241	WHEEL SUPPORT CHAIN TENSIONER	20	01
10	0503013030	5/8" X 3.1/4" BOLT		01
11	0551017715	FLAT WASHER		02
12	0511052770	WHEEL WITH TIRE	17	01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8 SPRING WASHER		02
15	0503011167	M16 X 2 X 30 BOLT		02




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	19	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	18	01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503012113	TIRE 7.00 X 16 10 CANVAS		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	23	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	24	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	22	01




Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	25	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	25	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	25	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0531059598	RIGHT HOPPER SUPPORT WITH FERTILIZER 27 METERING - 4845		01
02	0531059597	LEFT HOPPER SUPPORT WITH FERTILIZER 28 METERING - 4845		01
03	0503013751	3/8 UNC X 1.1/4 BOLT		20
04	0571019051	FIXER HOPPER WASHER		20
05	0503012535	3/8" SPRING WASHER		20
06	0503012531	3/8" INOX NUT		20
07	0503011957	NYLON HANDLE		02
08	0503018441	5/16" X 1-1/4" BOLT		04
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
10	0503010337	5/16" NUT		04
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		14
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		28
13	0503010025	3/8 SPRING WASHER		14
14	0503010026	3/8" NUT		14
15	0503062362	FERTILIZER HOPPER	37	03




Item	Code	Description	See page	QT
01	0531065992	RIGHT HOPPER SUPPORT - 4845		01
02	0501053788	3/4" SQUARE AXLE FASTENER	29	07
03	0503030303	SUPPORT WASHER		07
04	0531057913	DOUBLE BEARING ASSEMBLY		01
05	0501218577	3/4 X 790 AXLE WITH RELIEF		01
06	0531055319	ALPHA II FERTILIZER METERING	30	06
07	0501218487	3/4 X 390 AXLE		03
08	0531057908	SLEEVE 1/4 X 2		04
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
09	0501310789	3/4 X 477 AXLE		01




Item	Code	Description	See page	QT
01	0531065991	LEFT HOPPER SUPPORT - 4845		01
02	0501053788	3/4" SQUARE AXLE FASTENER	29	07
03	0503030303	SUPPORT WASHER		07
04	0531057913	DOUBLE BEARING ASSEMBLY		01
05	0501218577	3/4 X 790 AXLE WITH RELIEF		01
06	0531055319	ALPHA II FERTILIZER METERING	30	06
07	0501218487	3/4 X 390 AXLE		03
08	0531057908	SLEEVE 1/4 X 2		04
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010010	1/4" X 2.1/2" SPLIT PIN		01
09	0501310789	3/4 X 477 AXLE		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	ASSY TRANSMISSION HUB	31	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	32	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513011170	ALLEN SCREW 1/4 UNC X 7/8 CCSI STAINLESS STEEL		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501310211	FRONT LID		01
19	0503036177	LID CORD		01
20	0531059139	ASSY COLLECTOR	33	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO ADHESIVE LABEL 41.5 X 29		01
15	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0503035915	RIGHT FERTILIZER METERING LID GUIDE		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	34	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02

22Z GEAR SIDE BEARING ASSEMBLY


0531057911




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007		02
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0503010337	5/16" NUT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0531057901	GEAR	36	01
07	0503010845	501035 CLAMPING RING (FOR AXLE)		01
08	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531065402	GEAR		01
02	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0503034085	BEAN FERTILIZER ASSY		01
02	0503034086	HOPPER LID		01
03	0503034087	LID ARTICULATING TUBE		02
04	0503034088	WASHER		04
05	0503010131	3/16" X 1.1/2" SPLIT PIN		04
06	0503034130	PLATE		01
07	0503032053	BOLT C.A.S.I		04
08	0503034220	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0531058331	CSU C3 SET - 02 HOPPERS 07 NOZZLES - 06 39 CONDUCTORS		01
02	0521066102	TOWER SUPPORT HOPPER		04
03	0501010942	3/8" X 1-1/4" BOLT		08
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
05	0503010025	3/8 SPRING WASHER		08
06	0503010026	3/8" NUT		08
07	0502010175	HITCH CLAMP		04
08	0501011543	5/8" X 4" BOLT		08
09	0503012412	5/8" UNC SELF LOCKING NUT		08
10	0571019395	PROTECTOR		02
11	0551019884	45 X 50 X 3/8 FASTENER		08
12	0501010453	FLAT WASHER		16
13	0503010025	3/8 SPRING WASHER		16
14	0503010026	3/8" NUT		16




Item	Code	Description	See page	QT
01	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		02
03	0521063401	FIXING LOCK		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0531057950	3" X 175 SEED NOZZLE WITH FIXING	40	06
08	0531054471	CAP WITH FIXING	41	08




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID		01
02	0501010942	3/8" X 1-1/4" BOLT		05
03	0503010025	3/8 SPRING WASHER		05
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	5/16" NUT		02
11	0502012767	SEED NOZZLE FIXER SUPPORT		01
12	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0571015773	SUPPORT SEED		01
02	0501011643	3/8 X 1"BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04



Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING	43	01
03A	0502012030	HOUSING BEARING		01
03B	0503012861	6006 2RS BALL BEARING		01
03C	0503012858	502075 CLAMPING RING (FOR HOLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02
07	0501013518	FLAT WASHER		02
08	0501010694	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502012030	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		01
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8" UNC SELF LOCKING NUT		04
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0503012412	5/8" UNC SELF LOCKING NUT		02
12	0511058449	HYDRAULIC CYLINDER	45	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" SPLIT PIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501066949	1235 TURNBUCKLE		02
21	0503011854	5/8" X 1-1/4" BOLT		04
22	0501054649	HBM SEQUENTIAL VALVE	46	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
25	0503010025	3/8 SPRING WASHER		02
26	0511057334	HYDRAULIC MARKER HOSE KIT - 4845		01
26A	0501080343	TR-TR HOSE ASSY		02
26B	0501080435	3/8" X 141" TR-TC HOSE		02
26C	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
26CA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
26CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01


Item	Code	Description	See page	QT
26CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
26CD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
26D	0521052850	3/8 X 4200 TC-TM PURPLE/BUE HOSE		01
26DA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
26DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26DD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	48	02
28	0502012702	BODY SUPPORT CLAMP		06
29	0531011180	UPPER BODY CLIP		04
30	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		06
31	0503010180	7/16" SPRING WASHER		06
32	0503010244	7/16" NUT		02
33	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
34	0501012140	FLAT WASHER		04
35	0581010011	VALVE FIXING SUPPORT		01




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0581010011	VALVE FIXING SUPPORT		01
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
04	0503010025	3/8 SPRING WASHER		02
05	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	50	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0581011989	SIDE BODY FIXER PLATFORM		01
02	0551019884	45 X 50 X 3/8 FASTENER		01
03	0503010025	3/8 SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503013357	3/8 SELF-ADJUSTING NUT		02



Item	Code	Description	See page	QT
01	0503034115	ADHESIVE LABEL		01
02	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530		02
03	0503033892	ADHESIVE LABEL LOGO TATU HOPPER 190 X 720		01
04	0503034258	ADHESIVE LABEL		01
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
07	0503033422	ADHESIVE LABEL		02
08	0503031428	READ MANUAL DECAL		01
09	0503031942	ADHESIVE LABEL		01
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
11	0503031565	ADHESIVE LABEL CARE		02
12	0503031566	ADHESIVE LABEL		02
13	0503032997	ADHESIVE LABEL SEED DISTRIBUTOR TABLE		02
14	0503031425	ADHESIVE LABEL ATTENTION		02
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
18	0503032930	ADHESIVE LABEL DANGER		06
19	0503031087	AUTO CONTROL APPROVED DECAL		01
20	0503034003	61 X 118 SERIAL NUMBER TAG		01
21	0503010001	3.2 X 5.5 RIVET		04
22	0503032979	ADHESIVE LABEL LETTERS A B C D		02
23	0503034500	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" SPLIT PIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	20	04
13	0571018908	MOTOR SHAFT 2350		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	55	02
16	0511051434	TRANSMISSION ACTUATOR	56	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	57	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	58	01
19	0521055335	RIGHT GEAR HOUSING SET	64	01
20	0521055337	LEFT GEAR HOUSING SET	66	01
21	0511061759	22Z P12,70 FQ 3/4" GEAR		02
22	0501053788	3/4" SQUARE AXLE FASTENER	29	06
23	0503030303	SUPPORT WASHER		06
24	0501056271	GEARBOX CLOSED BEARING		06
25	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		12
26	0501010984	10,50 X 27 X 3,00 FLAT WASHER		28
27	0503010025	3/8 SPRING WASHER		12
28	0503010026	3/8" NUT		12
29	0511057265	TRANSMISSION CHAIN TENSIONER	59	04
30	0521010773	0.37" X 1.18" COUPLING SHAFT		02
31	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06


TRANSMISSION ASSEMBLY - 4845

0541051026


Item	Code	Description	See page	QT
32	0503010140	1/8" X 3/4" SPLIT PIN		02
33	0571018846	DISASSEMBLE LEVER		02
34	0503033942	COMPACTOR WHEEL REGULATOR LID		02
35	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
36	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
37	0503030093	TRACTION SPRING		02
38	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
39	0503012412	5/8" UNC SELF LOCKING NUT		04
40	0511061759	22Z P12,70 FQ 3/4" GEAR		02
41	0503030275	AGRICULTURAL BEARING		02
42	0503010292	701164 6 X 40 SPRING PIN		02
43	0521018630	1.4" X SQUARE 0.8" WASHER		02
44	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	60	02
45	0511050652	CHAIN TENSIONER	61	04
46	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	62	02
47	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
48	0503014911	40-1 X 63 CHAIN LINK + MENDING		02
49	0503013149	40-1 CHAIN X 157 LINK + MENDING + RED		02
50	0511069678	LH LOWER LEVER		02
51	0551019159	LEVER FIXER BODY		02
52	0561016468	FASTENER		02
53	0503011336	1/2" HEX SELF ADJUSTING NUT		04
54	0503010140	1/8" X 3/4" SPLIT PIN		04
55	0511064536	28Z GEAR		02



Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
05	0501019734	FLAT WASHER		02
06	0502010710	RIGHT CAM, SMALLER		02
07	0503010003	1845 GREASE FITTING		02
08	0502012539	26Z P12,7 GEAR		01
09	0501019735	FLAT WASHER		01
10	0521017593	FLAT WASHER		01
11	0503010542	501045 CLAMPING RING (FOR AXLE)		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01

LEFT SIDE TRANSMISSION ACTUATOR


0511047070




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0541011713	TENSIONER CHAIN LOWER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551019171	CHAIN TIGHTENER AXLE		01
02	0503011410	ROLLER BEARING		01
03	0511062169	21Z P 1/2" GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503011105	SEAL RING		01
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0571010265	16.5 X 40 X 3 FLAT WASHER		01
08	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	63	01
02	0511063185	20Z GEAR WITH HEX HOLE AXLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		02
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01



Item	Code	Description	See page	QT
01	0511058381	RIGHT GEAR HOUSING	65	01
02	0521065955	RIGHT GEARBOX LID		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0503010019	1/2" SPRING WASHER		01
07	0501010694	FLAT WASHER		06
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0521065939	RIGHT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN SHAFT		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	68	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING		03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TIGHTENER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	69	02
20	0503031366	RIGHT TWISTED SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	70	01
31	0503010292	701164 6 X 40 SPRING PIN		08

RIGHT GEAR HOUSING

0511058381


Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	72	01
33	0511054363	CHAIN TENSIONER	73	01
34	0571018901	DRIVEN AXLE		01



Item	Code	Description	See page	QT
01	0511058382	LEFT GEAR HOUSING	67	01
02	0521065956	LEFT GEARBOX LID		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
07	0503010019	1/2" SPRING WASHER		01
08	0501010694	FLAT WASHER		06

LEFT GEAR HOUSING

0511058382




Item	Code	Description	See page	QT
01	0521065940	LEFT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN SHAFT		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	68	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING		03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TIGHTENER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	69	02
20	0503031367	SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	70	01
31	0503010292	701164 6 X 40 SPRING PIN		08


**LEFT GEAR HOUSING**

0511058382


Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	72	01
33	0511054363	CHAIN TENSIONER	73	01
34	0571018901	DRIVEN AXLE		01




Item	Code	Description	See page	QT
01	0502011978	CENTRAL BEARING GEARBOX		01
02	0503013462	6005 2RS1 ROLLER BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0501056444	SUPPORT WITH ROLLER BEARING	71	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX SUPPORT		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0571019207	DEVIATION AXLE GEAR BOX		01
06	0503010899	5/8 UNC X 2.1/4 BOLT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01



Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		06
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		06
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01



Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521067033	FRAME LIFTING SUPPORT		01
03	0503017960	5/8" X 3-12" BOLT		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0521056500	FRONT SHORT SEED ROW WITH RIGHT 78	01	01
		TRANSMISSION WITHOUT LUBRIFICATION		
02	0521056501	FRONT LONG SEED ROW WITH RIGHT 79	01	01
		TRANSMISSION WITHOUT LUBRIFICATION		
03	0541051691	RIGHT REAR SIGMA V3 SEED ROW	85	01
04	0541051692	LEFT REAR SIGMA V3 SEED ROW	86	01
05	0521056477	SHORT FERTILIZER ROW DC20 WITHOUT 96	01	01
		LUBRICATION		
06	0521056479	LONG DC20 FERTILIZER ROW WITHOUT 97	01	01
		LUBRICATION		
07	0541050396	ASSY SIGMA V3 CSU MECHANICAL SEED HOPPER 105	01	01
08	0521054984	DEPTH/COMPACTOR SYSTEM - SPT	113	01
09	0501110804	SCARIFIER ROD WITH POINT	122	01
10	0531059865	RIGHT SEED CONDUCTOR WITH PROTECTION		01
11	0521069127	BOTTOM NOZZLE FERTILIZER		01
12	0531050237	3" RIGHT SEED CONDUCTOR FIXER	123	01
13	0531052986	PIVOT SUPPORT	124	01
14	0503063647	SIGMA CORN DISC SET	125	01
15	0503063648	SIGMA SOY DISC SET	126	01
16	0503031050	CURVED CONDUCTOR		01
17	0503010246	CLAMP		01
18	0503030391	RIGHT FERTILIZER NOZZLE		01
19	0503030392	LEFT FERTILIZER NOZZLE		01
20	0503036154	HOSE 2 X 2 X 505		01
21	0503031076	2" HOSE CLAMP		01
22	0531013600	PRESS ADJUSTMENT LEVER		01
23	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
24	0503010019	1/2" SPRING WASHER		01
25	0503010060	1/2 UNC G.5 ZN HEX NUT		01
26	0503034576	475 SIGMA SEED NOZZLE		01
27	0503030520	SEED SOCKET		01
28	0503010905	1/2" X 2-1/4" BOLT		01

ASSY SEED/FERTILIZER ROW

0909096887


Item	Code	Description	See page	QT
29	0511017969	0.1" SPACING PLATE		01
30	0511018662	SPACING PLATE		01
31	0541051703	QUICK LOCK SET SIGMA V3	127	01
32	0521057957	FIXED ROD EXTENSION WITH FIXATION	128	01
33	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
34	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
35	0503010025	3/8 SPRING WASHER		01
36	0503010026	3/8" NUT		01
37	0521068982	DISC BLADE HUB KEY		01
38	0511054314	TRANSMISSION AXLE LOCK SLEEVE		01
38A	0502012699	TRANSMISSION HUB LOCK SLEEVE		01
38B	0503010256	3/8" X 3/4" BOLT		01
39	0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	98	01
40	0521054769	LEFT DDD FERTILIZER WITH SUPPORT	99	01



Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
05	0503012412	5/8" UNC SELF LOCKING NUT		04
06	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
07	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
08	0571018883	PIN FIXER SPRING		03
09	0571018884	ARTICULATION ROW LOCK PIN		01
10	0503030168	HITCH PIN CLIP		04
11	0511058766	BEARING	80	01
12	0511057159	TRANSMISSION HOPPER SEED ROW	81	01
13	0571012492	5/8 X 330 AXLE HEX		01
14	0501056296	UNIVERSAL JOINT		01
15	0503011855	0.2" X 1.8" SPRING PIN		03
16	0521065942	FRAME REAR SHORT ROW SEED		01
17	0511059872	BEARING	83	01
18	0581010239	SEED ROW AXLE TRANSMISSION		01
19	0521011859	FLAT WASHER		02
20	0581011694	PROTECTION REAR COVER SEED ROW		01
21	0503010765	3/8" X 3" BOLT		01
22	0503010025	3/8 SPRING WASHER		01
23	0503010026	3/8" NUT		01
24	0501012140	FLAT WASHER		08
25	0511058512	PROTECTION LID	82	01
26	0581011430	DRAWBAR ASSY		01
27	0581010976	5/8" HEX AXLE		01
28	0503032984	HOOD HEX AXLE ROW		01
29	0503013100	NYLON CLAMP		01
30	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
31	0511057269	CHAIN TENSIONER	84	01




Item	Code	Description	See page	QT
32	0503017857	BOLT 5/8 UNF 4		04
33	0591011156	PIVOT ARM SEED ROW		02
34	0591011157	SPACER LOWER SLEEVE		08
35	0503019273	AUTO LUBRICANT SLEEVE		08
36	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		01
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
05	0503012412	5/8" UNC SELF LOCKING NUT		04
06	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
07	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
08	0571018883	PIN FIXER SPRING		03
09	0571018884	ARTICULATION ROW LOCK PIN		01
10	0503030168	HITCH PIN CLIP		04
11	0511058766	BEARING	80	01
12	0511057159	TRANSMISSION HOPPER SEED ROW	81	01
13	0571012492	5/8 X 330 AXLE HEX		01
14	0501056296	UNIVERSAL JOINT		01
15	0503011855	0.2" X 1.8" SPRING PIN		03
16	0521065943	REAR FRAME LONG ROW SEED		01
17	0511059872	BEARING	83	01
18	0581010240	SEED ROW AXLE TRANSMISSION		01
19	0521011859	FLAT WASHER		02
20	0581011694	PROTECTION REAR COVER SEED ROW		01
21	0503010765	3/8" X 3" BOLT		01
22	0503010025	3/8 SPRING WASHER		01
23	0503010026	3/8" NUT		01
24	0501012140	FLAT WASHER		08
25	0511058512	PROTECTION LID	82	01
26	0581011430	DRAWBAR ASSY		01
27	0581010976	5/8" HEX AXLE		01
28	0503032984	HOOD HEX AXLE ROW		01
29	0503013100	NYLON CLAMP		01
30	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
31	0511057269	CHAIN TENSIONER	84	01




Item	Code	Description	See page	QT
32	0503017857	BOLT 5/8 UNF 4		04
33	0591011156	PIVOT ARM SEED ROW		02
34	0591011157	SPACER LOWER SLEEVE		08
35	0503019273	AUTO LUBRICANT SLEEVE		08
36	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012852	ROW SEED UPPER BEARING		01
02	0503011105	SEAL RING		01
03	0502012851	17Z GEAR WITH HEX HOLE		01
04	0503011410	ROLLER BEARING		02
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010237	3/8" X 1" BOLT		02
07	0503010025	3/8 SPRING WASHER		02
08	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0521066693	CAP BEARING		01
02	0503010834	1/2 X 1 BOLT		02
03	0503010019	1/2" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0581012948	HOUSING BEARING		01
02	0503011105	SEAL RING		01
03	0581012949	BEARING COVER		01
04	0503011410	ROLLER BEARING		02
05	0503018045	2-130 (AGEL) O'RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0502012851	17Z GEAR WITH HEX HOLE		01
08	0503011953	5/16" X 1" BOLT		02
09	0501010694	FLAT WASHER		02
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
11	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0503031805	11Z 1/2" GEAR		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0541051706	5/8" SIGMA V3 ASSY BASE	87	01
02	0521055870	RIGHT DOUBLE DISC SEED 15 X 15	90	01
03	0503015920	3/8" UNC X 1.3/4" BOLT		04
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0541051706	5/8" SIGMA V3 ASSY BASE	87	01
02	0521055871	LEFT DOUBLE DISC SEED 15 X 15	91	01
03	0503015920	3/8" UNC X 1.3/4" BOLT		04
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0501013354	FLAT WASHER		01
02	0501314957	INDEX SUPPORT		02
03	0581019200	CONICA 40Z GEAR		01
04	0581019201	CROWN SHAFT		01
05	0503019340	LUBRICANT SLEEVE		02
06	0503011030	2-014 N 3006-9B O'RING		02
07	0581019202	10Z X 5/8" CONICAL PINION		01
08	0503019341	LUBRICANT SLEEVE		01
09	0503010410	RING		02
10	0501314960	SIGMA V3 FIXATION BASE		01
11	0513012066	ALLEN SCREW M4 X 10		02




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	88	01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
06	0503010026	3/8" NUT		01
07	0503010025	3/8 SPRING WASHER		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 92 FERTILIZER / SEED		01
09	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 93 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	89	01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
06	0503010026	3/8" NUT		01
07	0503010025	3/8 SPRING WASHER		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 92 FERTILIZER / SEED		01
09	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 93 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	94	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	95	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUBLE DISC AXLE		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
01A	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0503011255	3/4" LOCK NUT		02
03	0571019062	SLEEVE		01
04	0571019059	SUPPORT WASHER		01
05	0503034320	COMPRESSSSION SPRING		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503011854	5/8" X 1-1/4" BOLT		02
08	0511016281	3/4" X 8" BOLT		02
09	0503017960	5/8" X 3-12" BOLT		04
10	0502012813	FLANGE WASHER SPRING		01
11	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
12	0503010417	7/8" NUT		02
13	0502012789	FIXER SUPPORT FERTILIZER ROW		01
14	0521056476	DC 20" ASSY	102	01
15	0503011254	7/8" HEX SELF ADJUSTING NUT		01
16	0591011145	FERTILIZER ROW SUPPORT		01
17	0503019278	LUBRICANT SLEEVE		02
18	0591011147	SLEEVE ARM ROW		02
19	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
01A	0511057271	RH LONG ARM ROW FERTILIZER		01
02	0503011255	3/4" LOCK NUT		02
03	0571019062	SLEEVE		01
04	0571019059	SUPPORT WASHER		01
05	0503034320	COMPRESSSSION SPRING		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503011854	5/8" X 1-1/4" BOLT		02
08	0511016281	3/4" X 8" BOLT		02
09	0503017960	5/8" X 3-12" BOLT		04
10	0502012813	FLANGE WASHER SPRING		01
11	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
12	0503010417	7/8" NUT		02
13	0502012789	FIXER SUPPORT FERTILIZER ROW		01
14	0521056476	DC 20" ASSY	102	01
15	0503011254	7/8" HEX SELF ADJUSTING NUT		01
16	0591011146	SUPPORT LONG		01
17	0503019278	LUBRICANT SLEEVE		02
18	0591011147	SLEEVE ARM ROW		02
19	0503011109	2-119 N 3006-9B O'RING		02



Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC	100	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC	101	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 92 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 93 FERTILIZER / SEED		01

LEFT DUAL FERTILIZER DISC


0521055869




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 92 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 93 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0571019034	FLANGE WASHER AXLE		01
02	0571019032	SUPPORT WASHER		01
03	0502012813	FLANGE WASHER SPRING		01
04	0591010619	DC SPRING SUPPORT		01
05	0503019274	WASHER		02
06	0581017628	LID		02
07	0503019277	SLEEVE LUBRICATION SYSTEM		01
08	0501110964	RIGHT ARM WITH SLEEVE		01
09	0501110965	LEFT ARM WITH SLEEVE		01
10	0503034320	COMPRESSION SPRING		01
11	0591010624	SUPPORT ARM SLEEVE		01
12	0591010625	19,50 X 25 X 91,50/91,30 SLEEVE		01
13	0503010417	7/8" NUT		02
14	0503010390	SEAL RING		02
15	0503011198	C3/4" X 6" SCREW		01
16	0501010322	FLAT WASHER		01
17	0503011411	1/2" X 5-1/2" BOLT		01
18	0503010060	1/2 UNC G.5 ZN HEX NUT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503011255	3/4" LOCK NUT		01
21	0503030430	7/16 X 2" PIN LOCK		01
22	0503019271	SELF LUBRICATING BUSHING		01
23	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	103	01
24	0503011254	7/8" HEX SELF ADJUSTING NUT		01
25	0521066743	SPRING REGULATOR		01
26	0591011144	FIXATION AXLE		01
27	0591010628	DC AXIS BACKREST WASHER		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	DISC BLADE HUB	104	01




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	DISC BLADE HUB		01
09	0502040873	DISC BLADE AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	FLAT WASHER		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02




Item	Code	Description	See page	QT
01	0541050399	SEED HOPPER WITH COUPLING	106	01
02	0503030085	LOCK PIN		01
03	0541050398	SEED DISTRIBUTION BODY	109	01
04	0503010025	3/8 SPRING WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0501013518	FLAT WASHER		01
07	0501312560	DEFLECTOR FIXING AXLE		01
08	0503034131	DEFLECTOR		01



Item	Code	Description	See page	QT
01	0503012537	5/16" X 1" BOLT		05
02	0503012545	FLAT WASHER		05
03	0503019657	HEX LOCK NUT WITH NYLON 5/16		05
04	0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	107	01
05	0502050061	COUPLING BODY		01




Item	Code	Description	See page	QT
01	0503015536	M6 X 1" SELF ADJUSTING NUT		04
02	0581014295	FIXING SLEEVE		01
03	0501213431	SEED NOZZLE FIXING FLANGE		01
04	0501213520	SEED BREAKER BODY		01
05	0501213432	BREAKER SUPPORT BASE		01
06	0501213728	60 X 53 X 30 PVC TUBE		01
07	0513010720	M6 X 1 X 35 C S G.5 ZB BOLT		04
08	0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK 108 LID		01




Item	Code	Description	See page	QT
01	0503035751	SIGMA SINGLE SEED HOPPER		01
02	0503035750	SEED HOPPER LID		01
03	0503035298	BAKELITE HANDLE WITH THREAD		01
04	0503015536	M6 X 1" SELF ADJUSTING NUT		01
05	0503035297	CURVED NOZZLE SEED HOPPER		01

SEED DISTRIBUTION BODY


0541050398




Item	Code	Description	See page	QT
01	0503010337	5/16" NUT		01
02	0513010140	SOCIDISCO SOY DISC 90 HOLES		01
03	0513010671	5/6 UNC X 2 CCSI 12.9 BOLT		01
04	0503035789	SIGMA ALUMINUM ADHESIVE LABEL		01
05	0503013356	RIVET POP 3,2 X 10,0		04
06	0502013097	LOWER BASE		01
07	0503036321	QUICK LOCK		02
08	0503016282	ALLEN BOLT		01
09	0503019913	SELF-LOCKING NUT W/ NYLON M8 X 1.25 C.8 ZN		01
10	0503035299	PLATE SPRING 16 X 8.2 X 0.90		02
11	0503030168	HITCH PIN CLIP		01
12	0503036312	LID SEAL		01
13	0503036313	COUPLING GUIDE SHOE		04
14	0503036302	SPIN LIMITER		01
15	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		08
16	0503036311	CUERPO GUÍA DE DRENAJE		01
17	0503063405	SOY SEED DISTRIBUTOR CAP	110	01
18	0502050060	SEED DISTRIBUTOR		01
19	0513011816	ALLEN SCREW M4 X 16 CCS		10
20	0503050090	DRAIN COVER		01
21	0513010161	SOCIDISCO RING FOR SOY 0,8MM		01
		AZCSOJAR08-002461		




Item	Code	Description	See page	QT
01	0513010184	SCRAPER TRIGGER SHAFT - 000417		01
02	0513010169	SEED DISTRIBUTION BOX SOCIDISCO - 001793		01
03	0513010171	TRIGGER HEIGHT REGULATOR SOCIDISCO - 001796		01
04	0503063406	DOUBLE PULLEY ROCKER - 000422		01
05	0513010174	DISTRIBUTOR BOX PROTECTION - 001794		01
06	0513010179	LIFT TRIGGER SOCIDISCO - 001795		01
07	0513010180	FLAT HEAD SCREW - 000902		01
08	0513010177	PROPELLER SPRING - 000419		03
09	0513010172	RUBBER SCRAPER - 000412		01
10	0513010176	UNIVERSAL SCRAPER TRIGGER M22E - N - 2805		01
11	0513010181	ROCKER SHAFT PULLEY SOCIDISCO - 000418		01
12	0513011721	PROPELLER SPRING SIGMA - 1824		01
13	0513011722	UNIVERSAL SCRAPER TRIGGER M22D - N - 2806		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" SPLIT PIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0521054986	DEPTH CONTROL SEMI MOUNTED WITHOUT LUBRICATION	114	01
02	0501052538	DEPTH BAND WITH ARMS	112	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0521054990	LEFT COMPACTOR WHEEL	120	01
06	0521055017	RIGHT COMPACTOR WHEEL	119	01




Item	Code	Description	See page	QT
01	0501052297	DEPTH WHEELS REGULATOR ASSY	111	01
02	0521054987	LEFT ARM WITH HUB WITHOUT LUBRIFICATION	116	01
03	0521054988	RIGHT ARM WITH HUB WITHOUT LUBRIFICATION	115	01
04	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	118	01
05	0502012282	DEPTH CONTROL SUPPORT		01
06	0503034377	3/8 UNC X 3/4 BOLT		01
07	0503010311	1/2" X 1-1/4" BOLT		02
08	0503010019	1/2" SPRING WASHER		02
09	0571017749	FLAT WASHER		02
10	0571015974	WASHER		02
11	0511015346	FLAT WASHER		02
12	0581011100	DEPTH WHEEL AXLE		01
13	0521019093	0.6" X 2.7" PIVOT SHAFT		01
14	0503010581	RING		01
15	0503019275	SLEEVE LUBRICATION SYSTEM		01
16	0581019473	ARTICULATED SLEEVE		02
17	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0581019527	RIGHT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	117	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019472	LEFT ARM WHEEL CONTROL DEPTH		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0521055016	CUBE DEPTH CONTROL WITHOUT LUBRICATION	117	01
06	0581019514	LUBRICANT SLEEVE		02
07	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL HUB		01
02	0581019515	AXIS		01
03	0503034055	CLAMPING RING		01
04	0581019168	DUST CLOAK		01
05	0503013758	1/4" X 1-1/2" BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0503010878	5/8" SELF ALIGNING NUT		01
10	0503030757	2.9" X 2" X 0.02" JOINT		01
11	0521019178	PROTECTION LID		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT SLEEVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" SPLIT PIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	121	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	121	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	WHEEL HUB		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503013759	NUT		02
02	0501010694	FLAT WASHER		02
03	0502012979	CLAMP 3 RIGHT CSU		02
04	0503010421	5/16" X 1-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0501012140	FLAT WASHER		01
02	0503010019	1/2" SPRING WASHER		01
03	0531062908	HOSE SUPPORT ARM		01
04	0531062907	ARTICULATOR HOSE		01
05	0513010322	LUBRICANT SLEEVE		01
06	0501210533	FLANGE WASHER		01
07	0503013776	BOLT 1/2 UNC X 7/8 C S G.5 ZN		01
08	0521067600	FIXER SUPPORT		01
09	0503010806	5/8" X 3" BOLT		01
10	0503012795	5/8" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0513010117	SOCIDISCO CORN DISC 28 HOLES 9,0 AMC9R-002130	01	01
02	0513010118	SOCIDISCO CORN DISC 28 HOLES 9,5 VLD9.5R-002115	01	01
03	0513010119	SOCIDISCO CORN DISC 28 HOLES 10 SAL10R-002619	01	01
04	0513010120	SOCIDISCO CORN DISC 28 HOLES 10,5 RSP10.5R-002133	01	01
05	0513010121	SOCIDISCO CORN DISC 28 HOLES 11 LRA11R-002134	01	01
06	0513010122	SOCIDISCO CORN DISC 28 HOLES 11,5 MAG11.5R-002620	01	01
07	0513010123	SOCIDISCO CORN DISC 28 HOLES 12 VDA12R-002621	01	01
08	0513010124	SOCIDISCO CORN DISC 28 HOLES 12,5 AMP12.5R-002131	01	01
09	0513010125	SOCIDISCO CORN DISC 28 HOLES 13 VMV13R-002132	01	01
10	0513010126	SOCIDISCO CORN DISC 28 HOLES 13,5 RXR13.5R-002136	01	01
11	0513010187	SOCIDISCO CORN DISC 28 HOLES 14,8 X 10 VM4-002581	01	01
12	0513010188	SOCIDISCO CORN DISC 28 HOLES 11 X 8 BR8.1-002589	01	01
13	0513010189	SOCIDISCO CORN DISC 28 HOLES 12,5 X 8,5 AZ8.2-002587	01	01
14	0513010164	SOCIDISCO FLAT RING FOR CORN AMFOSLISO-002127	01	01
15	0513010159	SOCIDISCO RING FOR CORN 0,8MM LRFOSSR08-002120	01	01
16	0513010160	SOCIDISCO RING FOR CORN 1,4MM VMFOSR1.4-002245	01	01
17	0513010163	SOCIDISCO RING FOR CORN 2,0MM VDFOSR2-002116	01	01
18	0503063413	4Z CORN SEED DISTRIBUTOR CAP - 001798	01	01




Item	Code	Description	See page	QT
01	0513010136	SOCIDISCO SOY DISC 62 HOLES 7,5 LRA62.75-002357	01	01
02	0513010137	SOCIDISCO SOY DISC 62 HOLES 8,0 RSP62.80-002358	01	01
03	0513010138	SOCIDISCO SOY DISC 62 HOLES 8,5 RXR62.85-002359	01	01
04	0513010139	SOCIDISCO SOY DISC 62 HOLES 9,0 AZM62.90-002360	01	01
05	0513010141	SOCIDISCO SOY DISC 90 HOLES 8,0 RSP90.80-002287	01	01
06	0513010142	SOCIDISCO SOY DISC 90 HOLES 8,5 RXR90.85-002317	01	01
07	0513010143	SOCIDISCO SOY DISC 90 HOLES 9,0 AZM90.90-002288	01	01
08	0513010158	SOCIDISCO FLAT RING FOR SOY AZMSOJALISO-002243	01	01
09	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461	01	01
10	0513010162	SOCIDISCO RING FOR SOY 1,5MM RSPSOJASR1,5-002244	01	01
11	0503063412	4Z SOY/BEAN SEED DISTRIBUTOR CAP - 001804	01	01



Item	Code	Description	See page	QT
01	0571011804	FAST BOLT ADJUSTMENT		01
02	0502012744	SPEED LOCK LEVER ASSY		01
03	0571014024	FAST BOLT GUIDE AXLE		02
04	0503010140	1/8" X 3/4" SPLIT PIN		02
05	0501314958	QUICK HITCH PRISONER		01



Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

LEONARDO JOSÉ DA SILVA SOUZA

www.marchesan.com.br

