

ROW CROP PLANTERS

COP FLEX 600 SUPREMA PP - FRAME 5745 - CSU (FROM 05/2023)

Code: 0501093687
Series: S-0115
Revision: 00
Revision Date: SEPTEMBER/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111200347	COP FLEX 600 SUP PP 5745/13E450 ESPECIAL S-0115

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909096902	FRAME ASSY	1
0511053289	ASSY DRAWBAR	2
0511054601	HITCH ARTICULATED TRACTOR	3
0511053179	TRACTOR COUPLING SHAFT	4
0511050439	RIGHT WHEEL ASSY	5
0511050440	WHITH LEFT WHEEL ASSY	6
0501054284	STRETCHER CURRENT TRANSMISSION SIDE	7
0501110625	BEARING ARTICULATION WHEEL	8
0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED HUB	9
0511052766	CARRYING WHEEL HUB ASSY	10
0503062158	EEE WHEEL WITH TIRE 700 X 16-10L ASSY	11
0501053522	WHEEL CHAIN TENSIONER	12
0511053375	CURRENT DEVIATION ASSY WHEEL	13
0501058239	WHEEL CHAIN TENSIONER BEARING	14
0511050443	RIGHT CARRYING-WHEEL ASSY	15
0511050444	LEFT CARRYING-WHEEL ASSY	16
0511053373	HYDRAULIC SET	17
0511053358	VALVE FIXING ASSEMBLY	18
0511053350	FIXER HYDRAULIC HOSE ASSEMBLY	19
0511053368	HYDRAULIC CYLINDER ASSEMBLY	20
0511058411	HYDRAULIC CYLINDER	21
0511053290	HOSE KIT	22
0511050639	RIGHT GEAR BOX ASSY	23
0511050640	LEFT GEAR BOX ASSY	24
0501048790	AXLE WITH RING	25
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	26
0501056443	GEAR HOUSING BEARING	27
0501056444	ROLLER BEARING	28
0501056271	GEARBOX CLOSED BEARING	29
0501054655	CHAIN TENSIONER ASSY	30
0531058007	HOPPER SET WITH FERTILIZER METERING ALPHA II - 5745	31
0531057057	LEFT HOPPER SUPPORT WITH FERTILIZER METERING ALPHA II - 5745	32
0531057058	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING ALPHA II - 5745	33
0531055319	ALPHA II FERTILIZER METERING	34
0531055863	TRANSMISSION HUB ASSY	35
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	36
0531059139	COLLECTOR ASSY	37
0531055273	ALPHA FERTILIZER METERING CLAMP	38
0501053788	3/4" SQUARE AXLE FASTENER	39
0531057911	22Z GEAR SIDE BEARING ASSEMBLY	40
0531057901	GEAR	41
0511053339	PLATFORM SET	42
0511053356	LADDER ASSY	43
0511053376	JOINT HANDRAIL SET	44
0511053287	HYDRAULIC MARKER	45
0511058449	HYDRAULIC CYLINDER	46
0501054649	HBM SEQUENTIAL VALVE	47
0501050633	ROW MARKER DISC ASSEMBLY	48
0511053904	ROW MARKER DISC	49
0511054971	JACK ASSEMBLY	50
0511053341	MOTOR SHAFT ASSEMBLY	51
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	52
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	53




MARCHESAN

INDEX

0511051434	TRANSMISSION ACTUATOR	54
0511056598	MANUAL STORAGE TUBE ASSY	55
0511053434	SQUARE SHAFT SET	56
0511053361	HEX AXLE ASSEMBLY	57
0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	58
0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8	59
0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	60
0511052333	ASSEMBLY SUPPORT LEFT FIXER CHANGE	61
0511053364	LEFT TRANSMISSION ASSY	62
0511053357	RIGHT TRANSMISSION ASSY	63
0511053366	CHAIN TENSIONER EXCHANGE	64
0511050385	BEARING DOUBLE GEAR	65
0501058265	STRETCHER LOWER CURRENT 21Z SEED	66
0511056387	INTERMEDIATE BEARING SEED WITH GEAR 21Z	67
0511050127	CHAIN TENSIONER SUPPORT	68
0501053126	FERTILIZER CHAIN TENSIONER ASSY	69
0511058843	ASSEMBLY CSU	70
0511058564	ASSEMBLY CSU	71
0511057690	3" ARTICULATED SEED CONDUCTOR	72
0511058677	REAR TURBINE FIXING ASSEMBLY	73
0511057700	HYDRAULIC TURBINE	74
0501054983	HYDRAULIC MOTOR	75
0521044613	480 X 50 FAN (HIDRAULIC)	76
0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE	77
0511059319	AIR FIXING SUPPORT	78
0511057906	HOSE ASSY	79
0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	80
0511050906	DRAWBAR TURNBUCKLE	81
0501053834	MALE QUICK COUPLER	82
0531059623	ALPHA COMPONENTS KIT - 13 ROWS	83
0541051895	DECAL SET - 5745	84
0909096903	SEED/FERTILIZER ROW ASSY	85
0521051622	FRONT SEED SHORT ROW	86
0521051621	FRONT SEED LONG ROW	87
0511052393	BEARING FOLLOWER ROW ASSY	88
0511050609	BEARING WITH 17Z GEAR ASSY	89
0511050617	FRONT SEED ROW BEARING	90
0511055260	SEED ROW CHAIN TENSIONER	91
0511054635	BEARING AXLE BODY	92
0511057159	TRANSMISSION HOPPER SEED ROW	93
0511057625	ROW SEED BEARING	94
0511057156	SEMI-ASSEMBLED ROW BEARING	95
0511057108	RIGHT REAR SEED ROW PRECISION PLANTING CSU 3	96
0511057115	REAR LEFT SEED ROW PRECISION PLANTING CSU 3	97
0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA CSU 3	98
0511057155	PRECISION PLANTING LEFT TRANSMISSION HOPPER	99
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	100
0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	101
0511057154	RIGHT DDD	102
0511057153	DDD LEFT	103
0511053172	LEFT LOW HUB WITH 15 DISC	104
0511053173	RIGHT LOW HUB WITH 15 DISC	105
0511053023	LONG FERTILIZER ROW	106
0511053024	SHORT FERTILIZER ROW	107


INDEX

0511053223	FERTILIZER ROW SUPPORT WITH SCREW	108
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	109
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	110
0511051819	DC 20 SEMI MOUNTED	111
0501054887	20 BLADE DISC WITH FLAT PLAN DISC	112
0501110231	SCARIFIER ROD WITH TIP	113
0531050237	3" RIGHT SEED CONDUCTOR FIXER	114
0521046122	DEPTH SYSTEM / COMPACTOR ASSY	115
0511058650	SEMI-MOUNTED DEPTH CONTROL	116
0511058652	LEFT DEPTH WHEEL ARM WITH HUB	117
0501052627	ASSY DEPTH WHEEL HUB	118
0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	119
0501052297	DEPTH WHEELS REGULATOR ASSY	120
0501052538	DEPTH BAND WITH ARMS	121
0511054333	COMPACT WHEEL RIGHT WITH BEARING	122
0511054334	COMPACT WHEEL LEFT WITH BEARING	123
0501052908	COMPACTOR WHEEL WITH BEARING	124
0521052549	CLAMP	125




Item	Code	Description	See page	QT
01	0521061933	FRAME (5745)		01
02	0511053289	ASSY DRAWBAR	2	01
03	0511054601	HITCH ARTICULATED TRACTOR	3	01
04	0511053179	TRACTOR COUPLING SHAFT	4	01
05	0511050439	RIGHT WHEEL ASSY	5	01
06	0511050440	WHITH LEFT WHEEL ASSY	6	01
07	0511050443	RIGHT CARRYING-WHEEL ASSY	15	01
08	0511050444	LEFT CARRYING-WHEEL ASSY	16	01
09	0511053373	HYDRAULIC SET	17	01
10	0511050639	RIGHT GEAR BOX ASSY	23	01
11	0511050640	LEFT GEAR BOX ASSY	24	01
12	0531058007	HOPPER SET WITH FERTILIZER METERING ALPHA II - 5745	31	01
13	0511053339	PLATFORM SET	42	01
14	0511053356	LADDER ASSY	43	02
15	0511053376	JOINT HANDRAIL SET	44	01
16	0511053287	HYDRAULIC MARKER	45	01
17	0501050633	ROW MARKER DISC ASSEMBLY	48	02
18	0511054971	JACK ASSEMBLY	50	02
19	0511053341	MOTOR SHAFT ASSEMBLY	51	01
20	0511056598	MANUAL STORAGE TUBE ASSY	55	01
21	0511053434	SQUARE SHAFT SET	56	01
22	0511053361	HEX AXLE ASSEMBLY	57	01
23	0511052332	ASSY SUPPORT RIGHT FIXER CHANGE	60	01
24	0511052333	ASSEMBLY SUPPORT LEFT FIXER CHANGE	61	01
25	0511053364	LEFT TRANSMISSION ASSY	62	01
26	0511053357	RIGHT TRANSMISSION ASSY	63	01
27	0511058843	ASSEMBLY CSU	70	01
28	0511058677	REAR TURBINE FIXING ASSEMBLY	73	01
29	0511050906	DRAWBAR TURNBUCKLE	81	01
30	0521018532	1.4" X 12" COUPLING SHAFT		01
31	0521010578	COUPLING SHAFT		01


Item	Code	Description	See page	QT
32	0503030085	LOCK PIN		03
33	0501053834	MALE QUICK COUPLER	82	01
34	0503010045	O'RING		01
35	0541010080	TERMINAL R.1 / 2 NPT		01
36	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
37	0581013729	NIPLE 1/2 NPT		01
38	0531059623	ALPHA COMPONENTS KIT - 13 ROWS	83	01
39	0521013164	EXTENDER		02
40	0501011310	FIXER LOCK		02
41	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		04
42	0503010019	1/2" SPRING WASHER		04
43	0503010060	1/2 UNC G.5 ZN HEX NUT		04
44	0541051895	DECAL SET - 5745	84	01
45	0503034003	61 X 118 SERIAL NUMBER TAG		01
46	0503010001	3.2 X 5.5 RIVET		04
47	0909096903	SEED/FERTILIZER ROW ASSY	85	01



Item	Code	Description	See page	QT
01	0511062824	DRAWBAR		00
02	0502012328	DRAWBAR SUPPORT FRONT FIXATION		04
03	0502012329	DRAWBAR FIXATION REAR SUPPORT		04
04	0561014393	COUPLING SHAFT		04
05	0503030119	LOCK PIN		04
06	0502012330	SUPPORT FIXER PIVOT		08
07	0503011084	3/4" X 5" BOLT		16
08	0503010023	3/4" SPRING WASHER		08
09	0503010014	3/4" HEX NUT		08
10	0503010002	1800 GREASE FITTING		01
11	0561019087	DRAWBAR TRANSPORT LOCK		01
12	0521018532	1.4" X 12" COUPLING SHAFT		01
13	0521010578	COUPLING SHAFT		01
14	0503030085	LOCK PIN		03
15	0501010322	FLAT WASHER		08




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" SPLIT PIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2" SPLIT PIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01



Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01


RIGHT WHEEL ASSY

0511050439




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0501054284	STRETCHER CURRENT TRANSMISSION SIDE	7	01
03	0511064744	WHEEL FORK		01
04	0501110625	BEARING ARTICULATION WHEEL	8	02
05	0503013232	1/2" BOLT		08
06	0503010019	1/2" SPRING WASHER		08
07	0561013021	BEARING INNER LOCK		02
08	0561013022	BEARING EXTERNAL LOCK		02
09	0503010398	501082 CLAMPING RING (FOR AXLE)		02
10	0561013020	KM 12 NUT		02
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED 9 HUB		01
12	0591010589	BODY LOCK WHEEL		02
13	0503010027	5/8 SPRING WASHER		02
14	0503011167	M16 X 2 X 30 BOLT		02
15	0511061808	15Z GEAR WITH AXLE		01
16	0501018466	FLAT WASHER		01
17	0511061809	15Z GEAR WITH COUPLING		01
18	0503011103	7/16" X 2-1/2" BOLT		01
19	0503010180	7/16" SPRING WASHER		01
20	0503010244	7/16" NUT		01
21	0503010004	1890 GREASE FITTING		02
22	0541012098	LEFT CHAIN TIGHTENER LARGER SUPPORT		01
23	0531018653	CHAIN TIGHTENER MINOR SUPPORT		01
24	0531016916	SLEEVE BEARING SUPPORT		02
25	0503010899	5/8 UNC X 2.1/4 BOLT		01
26	0503010027	5/8 SPRING WASHER		01
27	0503010013	5/8 NUT		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8 NUT		02
30	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
31	0501053522	WHEEL CHAIN TENSIONER	12	01

Item	Code	Description	See page	QT
32	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
33	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
34	0511053375	CURRENT DEVIATION ASSY WHEEL	13	01
35	0531016051	CARRY-WHEEL CHAIN PROTECTION CAP		01
36	0503010834	1/2 X 1 BOLT		02
37	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
38	0503010019	1/2" SPRING WASHER		02
39	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
40	0503016485	BOLT 3/4		04
41	0501010322	FLAT WASHER		04
42	0503010152	3/4" SELF LOCKING NUT		04
43	0502012720	WHEEL SUPPORT FIXER		01
44	0503017857	BOLT 5/8 UNF 4		04
45	0503010811	5/8" UNF SELF ADJUSTING NUT		04
46	0501012140	FLAT WASHER		04
47	0501047888	45 ROD STOP		01




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0501054284	STRETCHER CURRENT TRANSMISSION SIDE	7	01
03	0511065842	LEFT WHEEL FORK		01
04	0501110625	BEARING ARTICULATION WHEEL	8	02
05	0503013232	1/2" BOLT		08
06	0503010019	1/2" SPRING WASHER		08
07	0561013021	BEARING INNER LOCK		02
08	0561013022	BEARING EXTERNAL LOCK		02
09	0503010398	501082 CLAMPING RING (FOR AXLE)		02
10	0561013020	KM 12 NUT		02
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED 9 HUB		01
12	0591010589	BODY LOCK WHEEL		02
13	0503010027	5/8 SPRING WASHER		02
14	0503011167	M16 X 2 X 30 BOLT		02
15	0511061808	15Z GEAR WITH AXLE		01
16	0501018466	FLAT WASHER		01
17	0511061809	15Z GEAR WITH COUPLING		01
18	0503011103	7/16" X 2-1/2" BOLT		01
19	0503010180	7/16" SPRING WASHER		01
20	0503010244	7/16" NUT		01
21	0503010004	1890 GREASE FITTING		02
22	0531018654	CHAIN TIGHTENER SUPPORT		01
23	0531018653	CHAIN TIGHTENER MINOR SUPPORT		01
24	0531016916	SLEEVE BEARING SUPPORT		02
25	0503010899	5/8 UNC X 2.1/4 BOLT		01
26	0503010027	5/8 SPRING WASHER		01
27	0503010013	5/8 NUT		01
28	0501013491	5/8" TENSIONER SPRING		01
29	0503010013	5/8 NUT		02
30	0503031103	0.9" X 4.1" X 0.1" TRACTION SPRING		01
31	0501053522	WHEEL CHAIN TENSIONER	12	01


Item	Code	Description	See page	QT
32	0503016738	2050 CHAIN X 44 LINK + REDUCTION		01
33	0503012570	CHAIN 2050 X 2.8" LINK + MENDING		01
34	0511053375	CURRENT DEVIATION ASSY WHEEL	13	01
35	0541012543	LEFT CARRY-WHEEL CHAIN PROTECTION		01
36	0503010834	1/2 X 1 BOLT		02
37	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
38	0503010019	1/2" SPRING WASHER		02
39	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
40	0503016485	BOLT 3/4		04
41	0501010322	FLAT WASHER		04
42	0503010152	3/4" SELF LOCKING NUT		04
43	0502012720	WHEEL SUPPORT FIXER		01
44	0503017857	BOLT 5/8 UNF 4		04
45	0503010811	5/8" UNF SELF ADJUSTING NUT		04
46	0501012140	FLAT WASHER		04
47	0501047888	45 ROD STOP		01




Item	Code	Description	See page	QT
01	0531017202	AXLE CHAIN TIGHTENER		01
02	0503030402	PULLEY		01
03	0503010302	501019 SEAL RING		01
04	0503010004	1890 GREASE FITTING		01
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
06	0503010019	1/2" SPRING WASHER		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		01
08	0511015098	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0561015879	WHEELED JOINT BEARING		01
02	0561012895	SLEEVE		01




Item	Code	Description	See page	QT
01	0511052766	CARRYING WHEEL HUB ASSY	10	01
02	0503062158	EEE WHEEL WITH TIRE 700 X 16-10L ASSY	11	01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503010328	25590/25523 ROLLER BEARING		02
03	0503010804	00547-B SEAL		02
04	0521018363	00547-B SEAL		01
05	0511062015	14Z GEAR WITH FLANGE		01
06	0503010421	5/16\" X 1-1/2\" BOLT		06
07	0503011444	SPRING WASHER		06
08	0511015949	LOCK NUT		01
09	0503010329	LOCK WASHER		01
10	0503010330	KM 9 LOCKNUT		01
11	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503016518	WHEEL		01
02	0503012114	7.00 X 16 INNER TIRE		01
03	0503012113	TIRE 7.00 X 16 10 CANVAS		01




Item	Code	Description	See page	QT
01	0531012640	AXLE CHAIN TIGHTENER		01
02	0531012678	4.5" X 0.9" X 0.2" SLEEVE		01
03	0502012853	GEAR		01
04	0503012882	BEARING		01
05	0503011945	503050 CLAMPING RING (FOR AXLE)		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
07	0503010019	1/2" SPRING WASHER		01
08	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE	14	01
02	0501058239	WHEEL CHAIN TENSIONER BEARING		01
03	0521010479	SLEEVE ARTICULATION		01
04	0503011336	1/2" HEX SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0503011167	M16 X 2 X 30 BOLT		02
03	0511064744	WHEEL FORK		01
04	0501110625	BEARING ARTICULATION WHEEL	8	02
05	0503013232	1/2" BOLT		08
06	0503010019	1/2" SPRING WASHER		08
07	0561013021	BEARING INNER LOCK		02
08	0561013022	BEARING EXTERNAL LOCK		02
09	0503010398	501082 CLAMPING RING (FOR AXLE)		02
10	0561013020	KM 12 NUT		02
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED 9 HUB		01
12	0521012190	AXLE LOCK		02
13	0503010027	5/8 SPRING WASHER		02
14	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
15	0511010736	5/8" X 5-1/4" BOLT		04
16	0501013753	FLAT WASHER		04
17	0503010811	5/8" UNF SELF ADJUSTING NUT		04
18	0502012720	WHEEL SUPPORT FIXER		01
19	0503017857	BOLT 5/8 UNF 4		04
20	0503010811	5/8" UNF SELF ADJUSTING NUT		04
21	0501012140	FLAT WASHER		04
22	0501047888	45 ROD STOP		01




Item	Code	Description	See page	QT
01	0521063678	WHEEL SUPPORT		01
02	0503011167	M16 X 2 X 30 BOLT		02
03	0511065842	LEFT WHEEL FORK		01
04	0501110625	BEARING ARTICULATION WHEEL	8	02
05	0503013232	1/2" BOLT		08
06	0503010019	1/2" SPRING WASHER		08
07	0561013021	BEARING INNER LOCK		02
08	0561013022	BEARING EXTERNAL LOCK		02
09	0503010398	501082 CLAMPING RING (FOR AXLE)		02
10	0561013020	KM 12 NUT		02
11	0511052768	EEE WHEEL WITH 7.00X16 TIRE / ASSY WHEELED 9 HUB		01
12	0521012190	AXLE LOCK		02
13	0503010027	5/8 SPRING WASHER		02
14	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
15	0511010736	5/8" X 5-1/4" BOLT		04
16	0501013753	FLAT WASHER		04
17	0503010811	5/8" UNF SELF ADJUSTING NUT		04
18	0503017857	BOLT 5/8 UNF 4		04
19	0503010811	5/8" UNF SELF ADJUSTING NUT		04
20	0501012140	FLAT WASHER		04
21	0502012720	WHEEL SUPPORT FIXER		01
22	0501047888	45 ROD STOP		01




Item	Code	Description	See page	QT
01	0511053358	VALVE FIXING ASSEMBLY	18	01
02	0511053350	FIXER HYDRAULIC HOSE ASSEMBLY	19	01
03	0511053368	HYDRAULIC CYLINDER ASSEMBLY	20	01
04	0511053290	HOSE KIT	22	01
05	0501053834	MALE QUICK COUPLER	82	02




Item	Code	Description	See page	QT
01	0571010596	SUPPORT VALVE 50/50		01
02	0503010371	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02
06	0503013791	DOUBLE MOTOR		01
07	0541018940	7/8 NF X R 1 BSPT X 55 NIPPLE		01
08	0551012463	1/2" BSPT X 3/4" UNF X 51 NIPPLE		02
09	0503015075	M10 SPRING WASHER		04
10	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
11	0503011051	M10 X 0.6" NUT		04
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0503012341	7/8" T ADAPTER		02
14	0541012166	NIPPLE 3/4" UNF X 7/8"		01
15	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01




Item	Code	Description	See page	QT
01	0561017277	OIL CONDUCTOR FIXER PLATE	04	
02	0521010718	5/8" U BOLT	04	
03	0503010027	5/8 SPRING WASHER	08	
04	0503010013	5/8 NUT	08	
05	0521065261	MH OIL CONDUCTOR	04	
06	0521064673	OIL CONDUCTOR	04	
07	0502012702	BODY SUPPORT CLAMP	10	
08	0503011268	3/8" X 2-1/2" BOLT	10	
09	0503010025	3/8 SPRING WASHER	10	
10	0503010026	3/8" NUT	10	
11	0501012140	FLAT WASHER	08	




Item	Code	Description	See page	QT
01	0511066351	FLANGE CYLINDER HYDRAULIC FIXER		12
02	0503010834	1/2 X 1 BOLT		24
03	0503010019	1/2" SPRING WASHER		24
04	0511058411	HYDRAULIC CYLINDER	21	06
05	0521010546	1.2" X 5.7" COUPLING SHAFT		06
06	0501017779	32 X 60 X 4.75 FLAT WASHER		12
07	0503010523	1/4" X 2" SPLIT PIN		06



Item	Code	Description	See page	QT
01	0511066774	2.5" X 28" CYLINDER CASE		01
02	0541017674	TURNBUCLE BODY		01
03	0503030385	CYLINDER PLUG N-002		02
04	0511064408	FORK		01
05	0503011094	3/8" X 2" BOLT		01
06	0503010025	3/8 SPRING WASHER		01
07	0503010026	3/8" NUT		01
08	0581010302	RING OF SUPPORT		01
09	0502012822	101.60 END CAP		01
10	0503011061	8-342 BACK-UP RING		02
11	0503010338	2-342 N 3006-9B O'RING		02
12	0503017936	RING		01
13	0503017938	RING GUIDE		01
14	0503017937	GASKET		01
15	0503010761	D-1750 SCRAPER RING		01
16	0581010837	PISTON		01
17	0503010817	1.1/4" SELF LOCKING NUT		01
18	0503015633	SELEMASTER SEALING		01
19	0503018029	2-217 O'RING		01



Item	Code	Description	See page	QT
01	0501080760	3/8" X 500 TC-TC HOSE		08
02	0501080413	3/8" X 27" TR-TC HOSE		02
03	0501080055	3/8 X 1000 TR-TC HOSE		02
04	0501080352	3/8 X 1400 TR-TR HOSE		03
05	0501080025	3/8" X 55,11" TR-TC HOSE		01
06	0501081073	HOSE 1/2 X 4200 TC-TM		02




Item	Code	Description	See page	QT
01	0511050639	RIGHT GEAR BOX ASSY	23	01
01A	0501058212	SEMI MOUNTED RIGHT CHANGE		01
02	0503031805	11Z 1/2" GEAR		04
03	0503010302	501019 SEAL RING		04
04	0501048790	AXLE WITH RING	25	02
05	0503010002	1800 GREASE FITTING		02
06	0551018209	DRIVING AXLE		01
07	0521018259	DRIVEN AXLE		01
08	0551018210	DRIVEN AXLE		01
09	0551018211	INTERM SHAFT		01
10	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	26	01
11	0503030303	SUPPORT WASHER		05
12	0501056443	GEAR HOUSING BEARING	27	02
13	0501056271	GEARBOX CLOSED BEARING	29	05
14	0503010256	3/8" X 3/4" BOLT		01
15	0503030275	AGRICULTURAL BEARING		01
16	0521018630	1.4" X SQUARE 0.8" WASHER		03
17	0511061822	25Z P0.5" GEAR SQUARE HOL		01
18	0502040868	GEAR CONE REPLACEMENT		04
19	0503012389	1/2 BALL		04
20	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
21	0503010060	1/2 UNC G.5 ZN HEX NUT		04
22	0503010395	1/2" X 1-1/4" BOLT		04
23	0521062072	33Z GEAR		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0511067501	26Z GEAR		01
26	0503010292	701164 6 X 40 SPRING PIN		07
27	0503012204	40-1 CHAIN X 82 LINK + RED		02
28	0503012713	40-1 CHAIN X 45 LINK + MEN		01
29	0501054655	CHAIN TENSIONER ASSY	30	02
30	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01



**COP FLEX 600 SUPREMA PP - FRAME 5745 - CSU (FROM
RIGHT GEAR BOX ASSY**

Page 23
0511050639

Item	Code	Description	See page	QT
31	0503010025	3/8 SPRING WASHER		01




Item	Code	Description	See page	QT
01	0511050640	LEFT GEAR BOX ASSY	24	01
01A	0501058213	LH GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		04
03	0503010302	501019 SEAL RING		04
04	0501048790	AXLE WITH RING	25	02
05	0503010002	1800 GREASE FITTING		02
06	0551018209	DRIVING AXLE		01
07	0521018259	DRIVEN AXLE		01
08	0551018210	DRIVEN AXLE		01
09	0551018211	INTERM SHAFT		01
10	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	26	01
11	0503030303	SUPPORT WASHER		05
12	0501056443	GEAR HOUSING BEARING	27	02
13	0501056271	GEARBOX CLOSED BEARING	29	05
14	0503010256	3/8" X 3/4" BOLT		01
15	0503030275	AGRICULTURAL BEARING		01
16	0521018630	1.4" X SQUARE 0.8" WASHER		03
17	0511061822	25Z P0.5" GEAR SQUARE HOL		01
18	0502040868	GEAR CONE REPLACEMENT		04
19	0503012389	1/2 BALL		04
20	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
21	0503010060	1/2 UNC G.5 ZN HEX NUT		04
22	0503010395	1/2" X 1-1/4" BOLT		04
23	0521062072	33Z GEAR		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0511067501	26Z GEAR		01
26	0503010292	701164 6 X 40 SPRING PIN		07
27	0503012204	40-1 CHAIN X 82 LINK + RED		02
28	0503012713	40-1 CHAIN X 45 LINK + MEN		01
29	0501054655	CHAIN TENSIONER ASSY	30	02
30	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01




COP FLEX 600 SUPREMA PP - FRAME 5745 - CSU (FROM
LEFT GEAR BOX ASSY

Page 24
0511050640


Item	Code	Description	See page	QT
31	0503010025	3/8 SPRING WASHER		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0502011978	CENTRAL BEARING GEARBOX		01
02	0503013462	6005 2RS1 ROLLER BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0501056444	ROLLER BEARING	28	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX SUPPORT		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0531057057	LEFT HOPPER SUPPORT WITH FERTILIZER 32 METERING ALPHA II - 5745		01
02	0531057058	RIGHT HOPPER SUPPORT WITH FERTILIZER 33 METERING ALPHA II - 5745		01
03	0503010849	3/8" X 1-1/2" BOLT		24
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		48
05	0503010025	3/8 SPRING WASHER		24
06	0503010026	3/8" NUT		24
07	0571013223	ANGLE BAR		02
08	0503060663	FERTILIZER HOPPER WITH 4 TRUNNELS		01
09	0503060664	FERTILIZER HOPPER WITH 5 TRUNNELS		02
10	0571013225	STRINGER FIXING CASH FERTILIZER		02




Item	Code	Description	See page	QT
01	0531065024	LEFT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	34	07
03	0501053788	3/4" SQUARE AXLE FASTENER	39	02
04	0503031527	AGRICULTURAL BEARING		02
05	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	40	01
06	0501311446	SQUARE AXLE		01
07	0501311454	3/4 X 403 SQUARE SHAFT		06
08	0531057908	SLEEVE 1/4 X 2		06
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010010	1/4" X 2.1/2" SPLIT PIN		01




Item	Code	Description	See page	QT
01	0531065023	RIGHT HOPPER SUPPORT		01
02	0531055319	ALPHA II FERTILIZER METERING	34	07
03	0501053788	3/4" SQUARE AXLE FASTENER	39	02
04	0503031527	AGRICULTURAL BEARING		02
05	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	40	01
06	0501311446	SQUARE AXLE		01
07	0501311454	3/4 X 403 SQUARE SHAFT		06
08	0531057908	SLEEVE 1/4 X 2		06
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010010	1/4" X 2.1/2" SPLIT PIN		01




Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	TRANSMISSION HUB ASSY	35	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	36	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513011170	ALLEN SCREW 1/4 UNC X 7/8 CCSI STAINLESS STEEL		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501310211	FRONT LID		01
19	0503036177	LID CORD		01
20	0531059139	COLLECTOR ASSY	37	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO ADHESIVE LABEL 41.5 X 29		01
15	0503035316	LUBRICATED POINTS DECAL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT FERTILIZER METERING LID GUIDE		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	38	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007		02
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0503010337	5/16" NUT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0531057901	GEAR	41	01
07	0503010845	501035 CLAMPING RING (FOR AXLE)		01
08	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531065402	GEAR		01
02	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0521061861	PLATFORM FIXER	02	
02	0521062061	CENTRAL ARTICULACION	01	
03	0521062062	CENTRAL ARTICULACION	01	
04	0503010849	3/8" X 1-1/2" BOLT	08	
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER	16	
06	0503010025	3/8 SPRING WASHER	08	
07	0503010026	3/8" NUT	08	
08	0521062091	PLATFORM LEFT	01	
09	0521062092	PLATFORM RIGHT	01	
10	0521010549	COUPLING SHAFT	04	
11	0503010300	5/32" X 1" SPLIT PIN	04	
12	0503011333	COVER FIXER	02	
13	0503010274	5/32" X 2" SPLIT PIN	02	
14	0551019115	LOCKING PLATFORM FIXATION	02	
15	0501010096	3/8" X 2" BOLT	02	
16	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
17	0503013357	3/8 SELF-ADJUSTING NUT	02	
18	0521061676	PLATFORM PROLONG	02	
19	0511069664	PLATFORM EXTENSION LOCK	02	
20	0503010257	1/8" X 1" SPLIT PIN	02	
21	0502012740	PLATFORM RIGHT FIXER SUPPORT	01	
22	0502012739	PLATFORM LEFT FIXER SUPPORT	01	
23	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	04	
24	0503010019	1/2" SPRING WASHER	04	
25	0503010060	1/2 UNC G.5 ZN HEX NUT	04	



Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		04
02	0503010237	3/8" X 1" BOLT		08
03	0503010025	3/8 SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0511069636	LADDER		02
06	0503011179	3/8" X 2-1/4" BOLT		04
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
08	0503013357	3/8 SELF-ADJUSTING NUT		04



Item	Code	Description	See page	QT
01	0521061171	HANDRAIL		02
02	0521018290	RANDRAIL HOLDER		02
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0511065449	ROW MARKER ARM SUPPORT		02
02	0501010098	3/4" UNC BOLT		08
03	0503011255	3/4" LOCK NUT		08
04	0511061811	ROW MARKER ARM		02
05	0503011067	5/8" X 2-1/2" BOLT		04
06	0521010479	SLEEVE ARTICULATION		04
07	0503012795	5/8" HEX SELF ADJUSTING NUT		04
08	0511058449	HYDRAULIC CYLINDER	46	02
09	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
10	0503010571	1/4" X 1.1/2" SPLIT PIN		02
11	0511015779	1" X 4.2" AXLE		02
12	0503010523	1/4" X 2" SPLIT PIN		02
13	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
14	0501068994	8,30 X 78 LOCK PIN		02
15	0503030168	HITCH PIN CLIP		02
16	0501066949	1235 TURNBUCKLE		02
17	0503010962	5/8" X 1-1/4" BOLT		04
18	0501054649	HBM SEQUENTIAL VALVE	47	01
19	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
20	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
21	0503010025	3/8 SPRING WASHER		02
22	0511057082	HOSE KIT SYSTEM HYDRAULIC		01
22A	0501080635	3/8" X 19" TR-TR HOSE		02
22B	0501080124	HOSE 3/8 X 900 TR-TC		04
22C	0501080105	3/8 X 700 TR-TR HOSE		02
22D	0501080675	3/8 X 1000 TC-TC 180G HOSE		02
22E	0501080301	3/8 X 1300 TC-TC HOSE		02
22F	0501080878	3/8 X 4200 TC-TM HOSE ASSY		02
23	0541012165	3/4" NIPPLE		04
24	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		04
25	0501053834	MALE QUICK COUPLER	82	02




**COP FLEX 600 SUPREMA PP - FRAME 5745 - CSU (FROM
HYDRAULIC MARKER**

Page 45
0511053287


Item	Code	Description	See page	QT
26	0503011070	BEATER		02
27	0503010019	1/2" SPRING WASHER		02
28	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
29	0501012140	FLAT WASHER		04
30	0501050633	ROW MARKER DISC ASSEMBLY	48	01




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	49	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0561017269	MOTOR AXLE BEARING SUPPORT		04
02	0503011082	C1/2" X 1.3/4" SCREW		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0501110639	BEARING		08
07	0503010300	5/32" X 1" SPLIT PIN		08
08	0503011099	GREASE FITTING		08
09	0561016795	2775 MOTOR SHAFT		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	52	01
15	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	53	01
16	0511051434	TRANSMISSION ACTUATOR	54	04
17	0503012958	2050 CHAIN X 42 LINK + REDUCTION		04




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
05	0501019734	FLAT WASHER		02
06	0502010710	RIGHT CAM, SMALLER		02
07	0503010003	1845 GREASE FITTING		02
08	0502012539	26Z P12,7 GEAR		01
09	0501019735	FLAT WASHER		01
10	0521017593	FLAT WASHER		01
11	0503010542	501045 CLAMPING RING (FOR AXLE)		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0511031563	BAG WITH MANUAL		01
03	0503010267	NYLON CLAMP		01
04	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
05	0501010694	FLAT WASHER		01
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
07	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	29	02
02	0501056444	ROLLER BEARING	28	02
03	0503011953	5/16" X 1" BOLT		08
04	0501010694	FLAT WASHER		08
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
06	0503010337	5/16" NUT		08
07	0501018653	3/4" X 46" SQUARE SHAFT		02
08	0521010691	AXLE FASTENER		04
09	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		04
10	0511017303	FLAT WASHER		04
11	0503010143	1/4" SPRING WASHER		04
12	0503010144	1/4" NUT		04
13	0503030303	SUPPORT WASHER		04
14	0521061852	LEVER RATCHET		02
15	0521061847	AXLE ADRIVING ASSY		02
16	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
17	0521061849	DISASSEMBLE LEVER		02
18	0503010140	1/8" X 3/4" SPLIT PIN		04
19	0571012792	LOWER LEVER		02
20	0503011082	C1/2" X 1.3/4" SCREW		02
21	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02
24	0561016797	SLEEVE UNION LEVER		02
25	0501010096	3/8" X 2" BOLT		02
26	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
27	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0501053608	BEARING ASSY WITH GEAR 20Z 5/8" HEX AXLE	58	02
02	0531016946	5/8" X 114" AXLE HEX		01
03	0531016947	LEFT 5/8" X 108" AXLE HEX		01
04	0511063123	BUSHING WITH NUT		04
05	0503010834	1/2 X 1 BOLT		04




Item	Code	Description	See page	QT
01	0501053609	BEARING TRANSMISSION DOUBLE SEED 5/8	59	01
02	0511063106	20Z AXLE BEARING DOUBLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01



Item	Code	Description	See page	QT
01	0561019899	RIGHT GEARBOX FIXER SUPPORT		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8" UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2 UNC G.5 ZN HEX NUT		02



Item	Code	Description	See page	QT
01	0561019898	LEFT SUPPORT FIXER GEARBOX		01
02	0521010718	5/8" U BOLT		01
03	0503012412	5/8" UNC SELF LOCKING NUT		02
04	0503011082	C1/2" X 1.3/4" SCREW		02
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0561018212	ARTICULAT SLEEVE		01
02	0503010547	1/2" X 4" BOLT		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0561017281	ARTICULACION ARM		01
07	0511053366	CHAIN TENSIONER EXCHANGE	64	01
08	0511050385	BEARING DOUBLE GEAR	65	01
09	0501058265	STRETCHER LOWER CURRENT 21Z SEED	66	01
10	0511056387	INTERMEDIATE BEARING SEED WITH GEAR 21Z	67	01
11	0511050127	CHAIN TENSIONER SUPPORT	68	01
12	0501053126	FERTILIZER CHAIN TENSIONER ASSY	69	01
13	0561017275	LEVER FIXER		01
14	0503010237	3/8" X 1" BOLT		02
15	0503010025	3/8 SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0561017280	LH LEVER DISASSEMBLE (COP 11)		01
18	0503030093	TRACTION SPRING		01
19	0561017273	FIXER SPRING		01
20	0503010237	3/8" X 1" BOLT		01
21	0503010025	3/8 SPRING WASHER		01
22	0503010026	3/8" NUT		01
23	0561017282	LOWER LEVER		01
24	0561016797	SLEEVE UNION LEVER		01
25	0503011082	C1/2" X 1.3/4" SCREW		01
26	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
27	0503010019	1/2" SPRING WASHER		01
28	0503010060	1/2 UNC G.5 ZN HEX NUT		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		02
30	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
31	0503010140	1/8" X 3/4" SPLIT PIN		02



**COP FLEX 600 SUPREMA PP - FRAME 5745 - CSU (FROM
LEFT TRANSMISSION ASSY**

Page 62
0511053364

Item	Code	Description	See page	QT
32	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503016737	40-1 X 114 CHAIN LINK + REDUCION		01
35	0503011721	40-1 CHAIN X 122 LINK + REDUCTION		01




Item	Code	Description	See page	QT
01	0561018212	ARTICULAT SLEEVE		01
02	0503010547	1/2" X 4" BOLT		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0561017281	ARTICULACION ARM		01
07	0511053366	CHAIN TENSIONER EXCHANGE	64	01
08	0511050385	BEARING DOUBLE GEAR	65	01
09	0501058265	STRETCHER LOWER CURRENT 21Z SEED	66	01
10	0511056387	INTERMEDIATE BEARING SEED WITH GEAR 21Z	67	01
11	0511050127	CHAIN TENSIONER SUPPORT	68	01
12	0501053126	FERTILIZER CHAIN TENSIONER ASSY	69	01
13	0561017275	LEVER FIXER		01
14	0503010237	3/8" X 1" BOLT		02
15	0503010025	3/8 SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0561017279	RH LEVER DISASSEMBLE (COP 11)		01
18	0503030093	TRACTION SPRING		01
19	0561017273	FIXER SPRING		01
20	0503010237	3/8" X 1" BOLT		01
21	0503010025	3/8 SPRING WASHER		01
22	0503010026	3/8" NUT		01
23	0561017282	LOWER LEVER		01
24	0561016797	SLEEVE UNION LEVER		01
25	0503011082	C1/2" X 1.3/4" SCREW		01
26	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
27	0503010019	1/2" SPRING WASHER		01
28	0503010060	1/2 UNC G.5 ZN HEX NUT		01
29	0521010773	0.37" X 1.18" COUPLING SHAFT		02
30	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
31	0503010140	1/8" X 3/4" SPLIT PIN		02




**COP FLEX 600 SUPREMA PP - FRAME 5745 - CSU (FROM
RIGHT TRANSMISSION ASSY**

Page 63
0511053357


Item	Code	Description	See page	QT
32	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
33	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
34	0503016737	40-1 X 114 CHAIN LINK + REDUCION		01
35	0503011721	40-1 CHAIN X 122 LINK + REDUCTION		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
05	0503010019	1/2" SPRING WASHER		01




Item	Code	Description	See page	QT
01	0521061843	20Z DOBLE GEAR		01
02	0503011410	ROLLER BEARING		02
03	0551019175	DOUBLE GEAR AXLE		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0501010163	5/8" X 4-1/2" BOLT		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0521069698	GEAR 21Z P 1/2		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
07	0501012140	FLAT WASHER		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8 NUT		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0561015677	CHAIN TIGHTENER AXLE		01
02	0501010452	5/8" X 5" BOLT		01
03	0521069698	GEAR 21Z P 1/2		01
04	0503011410	ROLLER BEARING		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01
08	0501012140	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521018415	TIGHTENER AXLE		01
02	0503011410	ROLLER BEARING		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0521069698	GEAR 21Z P 1/2		01
05	0503011105	SEAL RING		01
06	0501011234	5/8" X 3" BOLT		01
07	0503010027	5/8 SPRING WASHER		01
08	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511058564	ASSEMBLY CSU	71	01
02	0521063064	SEED HOPPER SUPPORT TOWER		06
03	0501010942	3/8" X 1-1/4" BOLT		12
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		12
05	0503010025	3/8 SPRING WASHER		12
06	0503010026	3/8" NUT		12
07	0502010175	HITCH CLAMP		06
08	0501011543	5/8" X 4" BOLT		12
09	0503012412	5/8" UNC SELF LOCKING NUT		12
10	0501010453	FLAT WASHER		12




Item	Code	Description	See page	QT
01	0521064748	5 NOZZLES SINGLE SEED HOPPER SUPPORT		02
02	0521064813	6 NOZZLES SINGLE SEED HOPPER SUPPORT		01
03	0503061987	5 NOZZLES FERTILIZER HOPPER		02
04	0503061899	6 NOZZLES FRONT FERTILIZER HOPPER		01
05	0521063401	FIXING LOCK		06
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
07	0503010025	3/8 SPRING WASHER		06
08	0503010026	3/8" NUT		06
09	0511057690	3" ARTICULATED SEED CONDUCTOR	72	13
10	0501010942	3/8" X 1-1/4" BOLT		52
11	0503010025	3/8 SPRING WASHER		52
12	0503010026	3/8" NUT		52
13	0571015773	SUPPORT SEED		03
14	0501011643	3/8 X 1"BOLT		12
15	0503010025	3/8 SPRING WASHER		12
16	0503010026	3/8" NUT		12




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8 SPRING WASHER		01
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	5/16" NUT		02
11	0502012767	SEED NOZZLE FIXER SUPPORT		01




Item	Code	Description	See page	QT
01	0581011414	UPPER RIGHT SUPPORT		01
02	0581011413	UPPER LEFT SUPPORT		01
03	0503011239	1/2" X 2" BOLT		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0581011415	SUPPORTER FIXING BAR		01
07	0503011082	C1/2" X 1.3/4" SCREW		04
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
09	0503010019	1/2" SPRING WASHER		04
10	0503010060	1/2 UNC G.5 ZN HEX NUT		04
11	0511057700	HYDRAULIC TURBINE	74	01
12	0503011267	5/8 UNC X 1.1/2 C S G.5 ZN BOLT		02
13	0501012140	FLAT WASHER		02
14	0503012412	5/8" UNC SELF LOCKING NUT		02
15	0503015062	TUBE		03
16	0503031576	ELBOW		04
17	0521018615	HOSE 4 X 1300		02
18	0503011372	102 TO 121 CLAMP		04
19	0511059319	AIR FIXING SUPPORT	78	04
20	0531053824	AIR CONDUCTOR		02
21	0503013584	VACUUM GAUGE		01
22	0571019552	SUPPORT VACUUM		01
23	0511057906	HOSE ASSY	79	01




Item	Code	Description	See page	QT
01	0501054983	HYDRAULIC MOTOR	75	01
02	0503010025	3/8 SPRING WASHER		10
03	0503010026	3/8" NUT		08
04	0521044613	480 X 50 FAN (HIDRAULIC)	76	01
05	0503010143	1/4" SPRING WASHER		01
06	0503010849	3/8" X 1-1/2" BOLT		02
07	0531018764	FLAT WASHER		01
08	0503011104	M6 X 1" BOLT		01
09	0503012722	0.16" X 0.4" BLIND RIVET		20
10	0521065858	TURBIN SUPPORT		01
11	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC 77 TURBINE		01
12	0561010634	VALVE SUPPORT ASSY		01
13	0503010237	3/8" X 1" BOLT		06
14	0503010206	3/8 X 1/2 BOLT		02
15	0571018577	COVER SNAIL TURBINE		01
16	0521066237	SNAIL MECHANICAL TURBINE HIDRAULIC		01
17	0503010358	5/16" X 5/8" BOLT		02
18	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
19	0503010337	5/16" NUT		02
20	0501080125	HOSE 1/2 X 500 TR TR		02
21	0501080635	3/8" X 19" TR-TR HOSE		01
22	0521018517	FLAT WASHER		02
23	0503031649	CONECTOR CENTER		01




Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW		01
03	0561016941	3/4" NUT		01
04	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
05	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE		01
06	3914103037	TEFLON		0,001RI




Item	Code	Description	See page	QT
01	0571016947	DISC FRONT TURBINE		01
02	0571016949	DISC REAR TURBINE		01
03	0521065171	HUB FLANGE		01
04	0571016950	DISC STRENGTHENING TURBINE		01
05	0571016951	FLIP TURBINE		10
06	0503012651	M6 X 1" BOLT		05
07	0503010143	1/4" SPRING WASHER		05
08	0503011776	M6 SELF ADJUSTINGNUT		05




Item	Code	Description	See page	QT
01	0503012291	BLOCK COMMAND		01
02	0501010590	NIPPLE		04
03	0503010045	O'RING		04
04	0541011066	3/4" UNF X 43.5 NIPPLE		01
05	0503010190	2-114 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0571019403	STAPLE FIXER		01
02	0503010025	3/8 SPRING WASHER		04
03	0503010026	3/8" NUT		04
04	0501013518	FLAT WASHER		02
05	0571019921	AIR SUPPORT FIXATION		01
06	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0511057840	ASSY TURBINE HOSE REAR		01
01A	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
01AA	0501081247	HOSE 1/2 X 7012 TC-TM		01
01AB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
01B	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01
01BA	0501081247	HOSE 1/2 X 7012 TC-TM		01
01BB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
01C	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
01CA	0501080477	HOSE 3/8 X 7012 TC-TM		01
01CB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01CC	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
01CD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	82	02
03	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
04	0503033981	ADHESIVE LABEL		01
05	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	80	01




Item	Code	Description	See page	QT
01	0503018799	QUICK COUPLING		01
02	0503011883	QUICK CONNECTION COVER		01



Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521062278	RIGHT TURNBUCKLE		01
03	0511062888	LH TURNBUCKLE		01
04	0501061056	1.1/2" RIGHT LOCK-NUT		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		13
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		13
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01



Item	Code	Description	See page	QT
01	0503031424	ATTENTION HYDRAULIC MARKER DECAL	02	
02	0503031565	CAUTION TRANSPORTATION DECAL	02	
03	0503033012	RIGHT GEAR BOX SEED/FERTILIZER DECAL	01	
04	0503033013	LEFT GEAR BOX SEED/FERTILIZER DECAL	01	
05	0503032930	DANGER DECAL	04	
06	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL	02	
07	0503031087	AUTO CONTROL APPROVED DECAL	01	
08	0503031942	MANUAL SEAL DECAL	01	
09	0503035927	P27 FERTILIZER TABLE DECAL	01	
10	0503034249	PLANTERS TABLE DECAL	02	
11	0503033889	COP FLEX 600 SUPREMA DECAL	03	
12	0503033854	TATU LOGO DECAL	03	
13	0503033853	SIDE TATU LOGO DECAL	02	
14	0503033419	NUMBER 5 DECAL	04	
15	0503033418	NUMBER 4 DECAL	02	
16	0503033421	NUMBER 7 DECAL	02	
17	0503032979	LETTERS A B C D DECAL	02	
18	0503032949	ATTENTION 3 LANGUAGES DECAL	01	
19	0503031428	READ MANUAL DECAL	01	
20	0503034500	GRIP COLORS (PLANTERS) DECAL	01	



Item	Code	Description	See page	QT
01	0521051622	FRONT SEED SHORT ROW	86	01
02	0521051621	FRONT SEED LONG ROW	87	01
03	0511057108	RIGHT REAR SEED ROW PRECISION PLANTING CSU 3	96	01
04	0511057115	REAR LEFT SEED ROW PRECISION PLANTING CSU 3	97	01
05	0511053023	LONG FERTILIZER ROW	106	01
06	0511053024	SHORT FERTILIZER ROW	107	01
07	0511051819	DC 20 SEMI MOUNTED	111	01
08	0501110231	SCARIFIER ROD WITH TIP	113	01
09	0503031050	CURVED CONDUCTOR		01
10	0503010246	CLAMP		01
11	0571019712	AIR CONDUCTOR		01
12	0531059865	RIGHT SEED CONDUCTOR WITH PROTECTION		01
13	0531050237	3" RIGHT SEED CONDUCTOR FIXER	114	01
14	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
14A	0503019280	PLASTIC DISC 56 SOY / SMALL BEANS		01
14B	0503062764	SOY SEED EJECTOR ASSEMBLY		01
15	0521069127	BOTTOM NOZZLE FERTILIZER		01
16	0503030483	FERTILIZER SOCKET		01
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
18	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
19	0503010025	3/8 SPRING WASHER		01
20	0503010026	3/8" NUT		01
21	0531013600	PRESS ADJUSTMENT LEVER		01
22	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
23	0503010905	1/2" X 2-1/4" BOLT		01
24	0503010019	1/2" SPRING WASHER		01
25	0503010060	1/2 UNC G.5 ZN HEX NUT		01
26	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	115	01
27	0521052549	CLAMP	125	01




Item	Code	Description	See page	QT
01	0521065914	FRAME ASSY		01
02	0571012443	COUPLING SHAFT		01
03	0571012442	COUPLING SHAFT		03
04	0571012441	TRANSMISSION AXLE		01
05	0511052393	BEARING FOLLOWER ROW ASSY	88	01
06	0571012449	CONTROL AXLE		01
07	0571012448	LOCK SLEEVE AXLE REGULATION		01
08	0521068100	SHORT SEED ROW FRONT SUPPORT		01
09	0502012784	DRIVER PIVOT		02
10	1902012814	BODY LOCK REGULATOR LEVER REGULATOR SEED		01
11	0502012785	SEED ROW ADJUSTMENT LEVER ASSY		01
12	0503017857	BOLT 5/8 UNF 4		04
13	0503010811	5/8" UNF SELF ADJUSTING NUT		04
14	0502012789	FIXER SUPPORT FERTILIZER ROW		01
15	0503016501	40-1 X 49 CHAIN LINK + MENDING		01
16	0511050609	BEARING WITH 17Z GEAR ASSY	89	01
17	0511055260	SEED ROW CHAIN TENSIONER	91	01
18	0503010002	1800 GREASE FITTING		04
19	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
20	0503012412	5/8" UNC SELF LOCKING NUT		04
21	0503030024	1.7" X 10.2" X 0.2" EXTENSION SPRING		02
22	0503030168	HITCH PIN CLIP		02
23	0503010131	3/16" X 1.1/2" SPLIT PIN		03
24	0511054635	BEARING AXLE BODY	92	02
25	0503011953	5/16" X 1" BOLT		08
26	0501010694	FLAT WASHER		08
27	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
28	0503010337	5/16" NUT		08
29	0511057159	TRANSMISSION HOPPER SEED ROW	93	01
30	0503011378	M6X1X16 C S 8.8 ZN BOLT		02
31	0503015110	M06 SPRING WASHER		02



**COP FLEX 600 SUPREMA PP - FRAME 5745 - CSU (FROM
FRONT SEED SHORT ROW**


Page 86
0521051622

Item	Code	Description	See page	QT
32	0502012782	17Z GEAR WITH HEX HOLE		01
33	0581014435	SEED ROW ARM SLEEVE		08
34	0511057625	ROW SEED BEARING	94	01
35	0503032984	HOOD HEX AXLE ROW		01
36	0503013100	NYLON CLAMP		01
37	0581015124	LIMITER COURSE		01




Item	Code	Description	See page	QT
01	0521065914	FRAME ASSY		01
02	0571012443	COUPLING SHAFT		01
03	0571012442	COUPLING SHAFT		03
04	0571012441	TRANSMISSION AXLE		01
05	0511052393	BEARING FOLLOWER ROW ASSY	88	01
06	0571012449	CONTROL AXLE		01
07	0571012448	LOCK SLEEVE AXLE REGULATION		01
08	0521068102	LONG SEED ROW FRONT SUPPORT		01
09	0502012784	DRIVER PIVOT		02
10	1902012814	BODY LOCK REGULATOR LEVER REGULATOR SEED		01
11	0502012785	SEED ROW ADJUSTMENT LEVER ASSY		01
12	0503017857	BOLT 5/8 UNF 4		04
13	0503010811	5/8" UNF SELF ADJUSTING NUT		04
14	0502012789	FIXER SUPPORT FERTILIZER ROW		01
15	0503012142	40-1 CHAIN X 61 LINK + MENDING		01
16	0511050609	BEARING WITH 17Z GEAR ASSY	89	01
17	0511055260	SEED ROW CHAIN TENSIONER	91	01
18	0503010002	1800 GREASE FITTING		04
19	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
20	0503012412	5/8" UNC SELF LOCKING NUT		04
21	0503030024	1.7" X10.2" X 0.2" EXTENSION SPRING		02
22	0503030168	HITCH PIN CLIP		02
23	0503010131	3/16" X 1.1/2" SPLIT PIN		03
24	0511054635	BEARING AXLE BODY	92	02
25	0503011953	5/16" X 1" BOLT		08
26	0501010694	FLAT WASHER		08
27	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
28	0503010337	5/16" NUT		08
29	0511057159	TRANSMISSION HOPPER SEED ROW	93	01
30	0503011378	M6X1X16 C S 8.8 ZN BOLT		02
31	0503015110	M06 SPRING WASHER		02


Item	Code	Description	See page	QT
32	0502012782	17Z GEAR WITH HEX HOLE		01
33	0581014435	SEED ROW ARM SLEEVE		08
34	0511057625	ROW SEED BEARING	94	01
35	0503032984	HOOD HEX AXLE ROW		01
36	0503013100	NYLON CLAMP		01
37	0581015124	LIMITER COURSE		01




Item	Code	Description	See page	QT
01	0521063532	BEARING FOLLOWER ROW ASSY		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0571012450	AXLE		01
05	0571012459	AXLE		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		02
07	0503015356	SPRING PIN		01
08	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511050617	FRONT SEED ROW BEARING	90	01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		01
03	0502012819	17Z GEAR WITH HEX HOLE		01




Item	Code	Description	See page	QT
01	0502011697	GEARBOX SUPPORT		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502012718	ROW BEARING		01
02	0503012882	BEARING		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS DECAL		01




Item	Code	Description	See page	QT
01	0511057156	SEMI-ASSEMBLED ROW BEARING	95	01
02	0571018731	HEX AXLE		01
03	0571017900	5/8" X 77" HEX AXLE		01
04	0501056296	UNIVERSAL JOINT		01
05	0503011855	0.2" X 1.8" SPRING PIN		03
06	0503013958	1/4" X 1" BOLT		02
07	0561014778	HEX UNIVERSAL JOINT		01




Item	Code	Description	See page	QT
01	0521065913	ROW SEED BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		02
05	0571017815	BEARING AXLE BODY		01
06	0503017008	SEAL RING		01



Item	Code	Description	See page	QT
01	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA 98 CSU 3		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	RIGHT DDD	102	01




Item	Code	Description	See page	QT
01	0511057212	ASSY PRECISION PLANTING V-SET2 SUPREMA 98 CSU 3		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT	103	01




Item	Code	Description	See page	QT
01	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
02	0571017899	PIN LOCK		01
03	0503030190	0.5" X 1.6" X 0.05" SPRING		01
04	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
05	0511057155	PRECISION PLANTING LEFT TRANSMISSION 99 HOPPER		01
06	0571017894	PIN DRAG PRECISION PLANTING		01
07	0503013357	3/8 SELF-ADJUSTING NUT		01
08	0501013518	FLAT WASHER		02
09	0503015356	SPRING PIN		01
10	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
11	0571017895	PIN FIXER CONDUCTOR P.P		01
12	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
13	0503010293	CLAMP KNOB		02
14	0503010140	1/8" X 3/4" SPLIT PIN		02
15	0503010131	3/16" X 1.1/2" SPLIT PIN		01
16	0503010025	3/8 SPRING WASHER		02
17	0571019491	SLUICE PNEUMATIC		01
18	0501011643	3/8 X 1" BOLT		01
19	0503010209	3/8" UNC BUTTERFLY NUT		01
20	0502012807	SUPPORT HOPPER PRECISION PLANTING		01
21	0571019489	CLAMP PRECISION PLANTING		01
22	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
23	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 100 DISC		01
24	0561014778	HEX UNIVERSAL JOINT		01
25	0503013958	1/4" X 1" BOLT		02
26	0503011855	0.2" X 1.8" SPRING PIN		01
27	0503012721	1/4" X 4" BOLT		01
28	0503012880	1/4" UNC SELF ADJUSTING NUT		04
29	0571014024	FAST BOLT GUIDE AXLE		01


Item	Code	Description	See page	QT
30	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
31	0503015110	M06 SPRING WASHER		02
32	0503818139	BOLT		03
33	0503037390	PACKING FOR PLANTING		01
34	0503015752	3/8" X 2" BOLT		01
35	0503034824	FIXATIVE		01
36	0581011226	FIXER CLOSING P. PLANTING CONTROL CPRA		01
37	0503010337	5/16" NUT		04
38	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
39	0503011953	5/16" X 1" BOLT		03
40	0503012163	5/16" X 1-1/2" BOLT		01
41	0521066707	FEEDER		01




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION HOPPER PP		01
02	0502050053	RIGHT SIDE TRANSMISSION HOPPER PP		01
03	0503011410	ROLLER BEARING		02
04	0503011182	6203 ROLLER BEARING		02
05	0503011184	502040 CLAMPING RING (FOR AXLE)		01
06	0571017655	FIXER SLEEVE		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
08	0503010144	1/4" NUT		03
09	0511057504	JOIN GEAR		01
09A	0571017898	BODY GEAR TRANSMISSION		01
09B	0503011769	M8 X 0.5" BOLT		01
10	0581011222	PINION AXLE 6Z PNEUMATIC		01
11	0503034340	PINION AXLE 6Z PNEUMATIC		01




Item	Code	Description	See page	QT
01	0571019613	STRAW PRECISION PLANTING SHIELD		01
02	0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	101	01




Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	104	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	RIGHT LOW HUB WITH 15 DISC	105	01
04	0503810026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012780	SUPPORT DDD RIGHT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O-RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	104	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	RIGHT LOW HUB WITH 15 DISC	105	01
04	0503810026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02



Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUBLE DISC AXLE		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01



Item	Code	Description	See page	QT
01	0521063759	ROW FERTILIZER SUPPORT		01
02	0511053223	FERTILIZER ROW SUPPORT WITH SCREW	108	01
03	0503017855	3/4" BOLT		02
04	0503010152	3/4" SELF LOCKING NUT		02
05	0521063504	FERTILIZER ROW LOWER SUPPORT		01
06	0503010233	5/8" X 2-1/2" BOLT		02
07	0511015098	FLAT WASHER		06
08	0561017928	ARTICULATED SLEEVE		02
09	0503012412	5/8" UNC SELF LOCKING NUT		02
10	0511063862	FERTILIZER ROW UPPER SUPPORT		01
11	0501010163	5/8" X 4-1/2" BOLT		01
12	0531015184	FLAT WASHER		01
13	0531016031	1/2" SPRING WASHER		01
14	0503012412	5/8" UNC SELF LOCKING NUT		01
15	0531016207	0.6" X 1" X 2.8" SLEEVE		01
16	0521061855	FERTILIZER ROW REAR SUPPORT		01
17	0501010452	5/8" X 5" BOLT		02
18	0531016031	1/2" SPRING WASHER		04
19	0531016207	0.6" X 1" X 2.8" SLEEVE		02
20	0503012412	5/8" UNC SELF LOCKING NUT		02
21	0521062073	SPRING GUIDE		01
22	0521016057	JUNCTION AXIS		01
23	0503030168	HITCH PIN CLIP		01
24	1902020393	SPRING UPPER SUPPORT		01
25	0503031450	2.7" X 9.2" X 0.03" SPRING		01
26	1902020393	SPRING UPPER SUPPORT		01
27	0521011158	SPRING LOCKNUT		01
28	0521018575	REGULATOR SPINDLE 100		01
29	0502012724	FERTILIZER ROW FIXER		01
30	0503017960	5/8" X 3-12" BOLT		04
31	0503010811	5/8" UNF SELF ADJUSTING NUT		04

Item	Code	Description	See page	QT
32	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	109	01
33	0502012352	DOUBLE-DISC SPACING PLATE		01
34	0541013035	5.55" X 4.0" X 0.38" PLATE		01
35	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
36	0503010019	1/2" SPRING WASHER		02
37	0503010060	1/2 UNC G.5 ZN HEX NUT		02
38	0503010752	1/2" X 3.1/2" BOLT		02
39	0503010019	1/2" SPRING WASHER		02
40	0503010060	1/2 UNC G.5 ZN HEX NUT		02
41	0503030520	SEED SOCKET		01
42	0503031145	2" X 2" X 20" HOSE		01
43	0503031076	2" HOSE CLAMP		02
44	0503010003	1845 GREASE FITTING		02
45	0503010004	1890 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511053223	FERTILIZER ROW SUPPORT WITH SCREW	108	01
02	0502012728	ROW FERTILIZER SUPPORT		01
03	0503017856	BOLT 3/4		02
04	0503010152	3/4" SELF LOCKING NUT		02
05	0521063504	FERTILIZER ROW LOWER SUPPORT		01
06	0561017928	ARTICULATED SLEEVE		02
07	0511015098	FLAT WASHER		06
08	0503010233	5/8" X 2-1/2" BOLT		02
09	0503012412	5/8" UNC SELF LOCKING NUT		02
10	0511063862	FERTILIZER ROW UPPER SUPPORT		01
11	0501010452	5/8" X 5" BOLT		01
12	0531016207	0.6" X 1" X 2.8" SLEEVE		01
13	0503012412	5/8" UNC SELF LOCKING NUT		01
14	0521061855	FERTILIZER ROW REAR SUPPORT		01
15	0501010452	5/8" X 5" BOLT		02
16	0531016031	1/2" SPRING WASHER		04
17	0531016207	0.6" X 1" X 2.8" SLEEVE		02
18	0503012412	5/8" UNC SELF LOCKING NUT		02
19	0521062073	SPRING GUIDE		01
20	0521016057	JUNCTION AXIS		01
21	0503030168	HITCH PIN CLIP		01
22	1902020393	SPRING UPPER SUPPORT		01
23	0503031450	2.7" X 9.2" X 0.03" SPRING		01
24	1902020393	SPRING UPPER SUPPORT		01
25	0521011158	SPRING LOCKNUT		01
26	0521018575	REGULATOR SPINDLE 100		01
27	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	110	01
28	0502012352	DOUBLE-DISC SPACING PLATE		01
29	0541013035	5.55" X 4.0" X 0.38" PLATE		01
30	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
31	0503010019	1/2" SPRING WASHER		02




COP FLEX 600 SUPREMA PP - FRAME 5745 - CSU (FROM
SHORT FERTILIZER ROW

Page 107
0511053024


Item	Code	Description	See page	QT
32	0503010060	1/2 UNC G.5 ZN HEX NUT		02
33	0503010752	1/2" X 3.1/2" BOLT		02
34	0503010019	1/2" SPRING WASHER		02
35	0503010060	1/2 UNC G.5 ZN HEX NUT		02
36	0503030520	SEED SOCKET		01
37	0503031145	2" X 2" X 20" HOSE		01
38	0503031076	2" HOSE CLAMP		02
39	0503010003	1845 GREASE FITTING		03




Item	Code	Description	See page	QT
01	0502012727	BLADE DISC SUPPORT		01
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02




Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	105	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	104	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	104	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	105	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521062962	BLADE DISC AXLE		01
02	0502012369	BLADE DISC SUPPORT		01
03	0541018684	FLAT WASHER		01
04	0503010361	SPRING PIN		01
05	0503010756	0.2" X 2.4" SPRING PIN		01
06	0503010003	1845 GREASE FITTING		01
07	0521018935	RIGHT ARM		01
08	0521018936	LEFT ARM		01
09	0501067323	SPRING REGULATOR		01
10	0521010452	SLEEVE		01
11	0503016525	3/4" X 6" BOLT		01
12	0503011442	3/4" SPRING WASHER		01
13	0503010014	3/4" HEX NUT		01
14	0502020393	SPRING UPPER SUPPORT		01
15	0503031341	2.7 X 8 X 0.5 COMPRESSION SPRING		01
16	0502020394	SPRING SUPPORT		01
17	0503010014	3/4" HEX NUT		02
18	0501054887	20 BLADE DISC WITH FLAT PLAN DISC	112	01
19	0521015376	DUST CLOAK		02
20	0511015346	FLAT WASHER		02
21	0503011438	SPRING WASHER		02
22	0521013510	3/4" NUT		02
23	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
24	0503011411	1/2" X 5-1/2" BOLT		01
25	0503011440	SPRING WASHER		01
26	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011562	DISC BLADE HUB		01
02	0503010276	6206 BALL BEARING		02
03	0521013610	BLADE DISC HUB AXLE		01
04	0503030832	FLAT WASHER		02
05	0503012417	SEAL		02
06	0503011800	SEAL RING		02
07	0503010691	1/4" GREASE FITTING		01
08	0603027851	20" X 0.2" FLAT PLAIN DISC		01
09	0502020641	BLADE DISC FLANGE		01
10	0503010371	5/16" X 1" BOLT		06
11	0503011444	SPRING WASHER		06
12	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER ROD		01
02	1902070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503013759	NUT		02
02	0501010694	FLAT WASHER		02
03	0502012979	CLAMP 3 RIGHT CSU		02
04	0503010421	5/16" X 1-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	116	01
02	0501052538	DEPTH BAND WITH ARMS	121	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	122	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	123	01
07	0503033942	COMPACTOR WHEEL REGULATOR LID		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT DEPTH WHEEL ARM WITH HUB	117	01
07	0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	119	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	120	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" SPLIT PIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL HUB	118	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	PROTECTION LID		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL HUB	118	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" SPLIT PIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	124	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	124	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01



Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03



Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01



MARCHESAN

Technical Publications | Elaboration and Revision

LEONARDO JOSÉ DA SILVA SOUZA

www.marchesan.com.br

