

ROW CROP PLANTERS

**PST TRIO FLEX SUPREMA P.P - FRAME 7860 - CSU
(FROM 05/2023)**

**PST TRIO FLEX SUPREMA P.P - CHASSI 7860 - CSU
(A PARTIR 05/2023)**

Code: 0501093798
Series: S-0119
Revision: 00
Revision Date: JANUARY/2024

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Working Width	Description
0111360151		PST TRIO FLEX SUP PP 7860/17E450 ESPECIAL S-0119

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909097063	ASSY FRAME	1
0511059983	7860 ARTICULATION FRAME WITH	2
0511053135	RIGHT FRAME WITH WHEELED AXLE 7860	3
0511053136	LEFT FRAME WITH WHEELED AXLE 7860	4
0511059288	CENTRAL FRAME WITH WHEELED AXLE 5750/6850/7860/8160	5
0511059232	ASSEMBLY SPRING TRACTION	6
0521058402	WHEELED WITH 655 DRIFT SPRING WITH TRANSMISSION	7
0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	8
0501058241	WHEEL SUPPORT CHAIN TENSIONER	9
0521058393	WHEEL WITH TIRE 7.00 X 16 14L PR TT WITH TRANSMISSION	10
0503063172	WHEEL	11
0521055233	WHEELED TRANSMISSION WITHOUT TIRE	12
0521055234	WHEELED FASTENER	13
0521055236	INTERMEDIARY CURRENT STRETCHER	14
0521055238	BEARING TENSIONER CHAIN	15
0521055237	WHEEL FIXED CURRENT STRETCHER	16
0521055235	WHEEL MOBILE CURRENT STRETCHER	17
0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	18
0521058394	WHEEL WITH TIRE	19
0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	20
0521052796	CYLINDER ASSEMBLY 5750/6850/7860/7960/8460	21
0511058406	HYDRAULIC CYLINDER	22
0521053100	TRANSMISSION ASSEMBLY 7860	23
0501052560	MOTOR AXLE SIGNAL	24
0511051434	TRANSMISSION ACTUATOR	25
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	26
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	27
0521050183	RIGHT GEAR BOX ASSY	28
0521050184	EXCHANGE LEFT ASSY	29
0511059261	CHAIN TENSIONER	30
0521055217	LOWER CURRENT STRETCH	31
0501058254	UPPER SEED CHAIN TENSIONER	32
0521055216	BEARING WITH GEAR	33
0521055218	BEARING GEAR WITH DOUBLE	34
0521055214	BEARING GEAR WITH	35
0501058212	SEMI MOUNTED RIGHT CHANGE	36
0511059266	CLOSED BEARING	37
0501056443	GEAR HOUSING BEARING	38
0501048790	AXLE WITH RING	39
0501054655	CHAIN TENSIONER ASSY	40
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	41
0501056271	GEARBOX CLOSED BEARING	42
0501056444	ROLLER BEARING	43
0501058213	LH GEAR BOX	44
0521055215	DOUBLE TRANSMISSION BEARING	45
0521052675	PLATFORM ASSEMBLY 7860	46
0511058276	HANDLE ASSEMBLY 7860	47
0511054971	JACK ASSEMBLY	48
0511056536	LADDER ASSEMBLY	49
0511057879	DOUBLE ARTICULATED HYDRAULIC MARKER	50
0501054649	HBM SEQUENTIAL VALVE	51
0511058431	HYDRAULIC CYLINDER	52
0501053834	MALE QUICK COUPLER	53
0531059446	LABELS SET	54



MARCHESAN

INDEX

0521052844	REAR LIGHT ASSEMBLY 7860/7960/8160/8460	55
0521052792	MOUNTED REAR LIGHT	56
0531054980	18 ROWS PLANTING MONITORING SET	57
0521053016	TURBINE ASSEMBLY MTH PP CSU	58
0521050260	SUPPORT ASSEMBLY P.P MTH	59
0521050016	RIGHT AIR DISTRIBUTOR 06 NOZZLES - 17 E500	60
0521050017	LEFT AIR DISTRIBUTOR 06 NOZZLES - 17 E500	61
0521052999	DISTRIBUTOR AIR CENTRAL 7 MOUTHS - 17	62
0511059319	AIR FIXING SUPPORT	63
0511057292	ASSY FLOW REGULATION VALVE	64
0511057906	HOSE ASSY	65
0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	66
0521052549	CLAMP	67
0511059887	TURBINE PRECISION PLANTING	68
0521050154	PRECISION PLANTING TURBINE WITH HOLE	69
0521052814	MANUAL STORAGE TUBE ASSY	70
0531056210	FERTILIZER SILO ALPHA SET	71
0531056254	SILO SUPPORT/LEFT FERTILIZER WITH ALPHA DOSER	72
0501053788	3/4" SQUARE AXLE FASTENER	73
0531055319	ALPHA II FERTILIZER METERING	74
0531055863	TRANSMISSION HUB ASSY	75
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	76
0531059139	COLLECTOR ASSY	77
0531055273	ALPHA FERTILIZER METERING CLAMP	78
0531056253	SUPPORT SILO/DIRECT FERTILIZER WITH ALPHA DOSER	79
0531055898	CHAIN TIGHTENER	80
0531055897	INTERMEDIATE TRANSMISSION BEARING	81
0501056451	BEARING	82
0531057911	22Z GEAR SIDE BEARING ASSEMBLY	83
0531057901	GEAR	84
0531059737	RIGHT BEARING WITH ALPHA GEAR	85
0531059739	SINGLE SIDE GEAR BEARING SET 22Z	86
0531056252	SILO SUPPORT/CENTRAL FERTILIZER WITH ALPHA DOSER	87
0531059738	LEFT EARLY BEARING	88
0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	89
0511058398	ASSEMBLY CSU C3 SEMI MOUNTED 7860/8460	90
0511058397	ASSEMBLY CSU C3 3BOX 7B WITH 17 C 7860	91
0511057690	3" ARTICULATED SEED CONDUCTOR	92
0521051931	LEFT SUPPORT TOWER WITH BOLT	93
0521052687	RIGHT SUPPORT TOWER WITH BOLT	94
0521051927	TOWER SUPPORT HOPPER	95
0521052858	AXIS TRANSMISSION SEED ASSY 7860	96
0511057287	TRANSMISSION	97
0503062392	DRIVE SHAFT	98
0511059419	HYDRAULIC SYSTEM ASSEMBLY 6850/7285/7450/7860/7960	99
0511059290	VALVE ASSEMBLY	100
0501053835	FEMALE QUICK COUPLER	101
0909098905	DRAWBAR ASSEMBLY - FRAME 5750/5850/6850/7450	102
0511055096	TRACTOR HITCH	103
0511053179	TRACTOR COUPLING SHAFT	104
0521051614	TURNBUCKLE SIDE UPPER	105
0521052754	SIDE EXTENDER 505/316	106
0521051616	TURNBUCKLE SIDE 505/480	107
0521050133	TURNBUCKLE SIDE 755/480	108
0511059237	3 POINT TURNBUCKLE	109



MARCHESAN

INDEX


0521045756	HYDRAULIC CYLINDER	110
0511057817	SUPPORT HOSE	111
0531059627	ALPHA COMPONENTS KIT - 17 ROWS	112
0521025447	BOX WITH HYDRAULIC MARKER COMPONENTS	113
0521055204	ROW MARKER DISC	114
0909097064	ASSY SEED / FERTILIZER ROW	115
0521054739	FRONT ROW SHORT LEFT SEED WITH CARDAN WITHOUT LUBRICATION	116
0521054738	FRONT ROW SHORT RIGHT SEED WITH CARDAN WITHOUT LUBRICATION	117
0521054741	FRONT SEED ROW LONG LEFT WITH CARDAN WITHOUT LUBRICATION	118
0521054740	FRONT ROW LONG RIGHT SEED WITH CARDAN WITHOUT LUBRICATION	119
0521054737	FRONT SEMI-ASSEMBLED LONG LEFT SEED ROW	120
0521054736	FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED ROW	121
0521055213	SEED ROW BEARING	122
0521055223	SEED ROW TRANSMISSION HUB	123
0511055260	SEED ROW CHAIN TENSIONER	124
0521055224	TRANSMISSION CARDAN ASSY	125
0521055219	BEARING WITH GEAR 17Z HEX 5/8	126
0511059501	FRAME PRECISION PLANTING SEMI MOUNTED	127
0521054795	REAR LEFT SEED ROW P.P CSU 3 NAC	128
0521054794	REAR RIGHT SEED ROW P.P CSU 3 NAC	129
0521055873	LEFT DOUBLE DISC FAST EXCHANGE SEED 15X15	130
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	131
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	132
0521055865	FERTILIZER/SEED LEFT HUB ASSY	133
0521055208	ASSEMBLY PRECISION PLANTING V-SET2 CSU 3 CSU SUPREMA P.P	134
0521055210	LEFT P.P TRANSMISSION BOX	135
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	136
0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	137
0521055872	RIGHT DOUBLE DISC FAST EXCHANGE SEED 15X15	138
0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	139
0521055065	ASSY DEPTH / COMPACTOR	140
0521055068	RAYED WHEEL CENTER CLOSED	141
0521054990	LEFT COMPACTOR WHEEL	142
0521055017	RIGHT COMPACTOR WHEEL	143
0501056769	DEPTH WHEELS REGULATOR ASSY	144
0521055033	SEMI-ASSEMBLED COMPACTOR BODY	145
0521055054	LEFT ARM WITH SLEEVE	146
0521055066	RIGHT ARM WITH SLEEVE	147
0521055055	HUB WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	148
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	149
0521054811	FERTILIZER SHORT ROW	150
0521054812	LONG FERTILIZER ROW	151
0521054906	SPRING ASSY FERTILIZER	152
0521053231	DPL 20 SHORT ROW WITHOUT LUBRICATION CONICAL BEARING	153
0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	154
0521053697	DISC BLADE HUB	155
0521053232	DPL 20 LONG ROW WITHOUT LUBRICATION CONICAL BEARING	156
0521054769	LEFT DDD FERTILIZER WITH SUPPORT	157
0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	158



MARCHESAN


INDEX

0521055869	LEFT DUAL FERTILIZER DISC		159
0521055868	RIGHT DUAL FERTILIZER DISC		160
0531050237	3" RIGHT SEED CONDUCTOR FIXER		161
0521053946	SCARING ROD		162
0521057957	FIXED ROD EXTENSION WITH FIXATION		163




Item	Code	Description	See page	QT
01	0511059983	7860 ARTICULATION FRAME WITH	2	01
02	0521064285	LOCK LOWER FRAME		02
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		02
04	0503010002	1800 GREASE FITTING		02
05	0503010003	1845 GREASE FITTING		08
06	0503010004	1890 GREASE FITTING		02
07	0511059232	ASSEMBLY SPRING TRACTION	6	02
08	0521058402	WHEELED WITH 655 DRIFT SPRING WITH 7 TRANSMISSION	7	04
09	0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT 8 TRANSMISSION	8	04
10	0521052796	CYLINDER ASSEMBLY 5750/6850/7860/7960/8460	21	01
11	0521053100	TRANSMISSION ASSEMBLY 7860	23	01
12	0521052675	PLATFORM ASSEMBLY 7860	46	01
13	0511058276	HANDLE ASSEMBLY 7860	47	01
14	0511054971	JACK ASSEMBLY	48	02
15	0511056536	LADDER ASSEMBLY	49	02
16	0511057879	DOUBLE ARTICULATED HYDRAULIC MARKER	50	01
17	0531059446	LABELS SET	54	01
18	0521052844	REAR LIGHT ASSEMBLY 7860/7960/8160/8460	55	01
19	0531054980	18 ROWS PLANTING MONITORING SET	57	01
20	0521053016	TURBINE ASSEMBLY MTH PP CSU	58	01
21	0521052814	MANUAL STORAGE TUBE ASSY	70	01
22	0531056210	FERTILIZER SILO ALPHA SET	71	01
23	0511058398	ASSEMBLY CSU C3 SEMI MOUNTED 7860/8460	90	01
24	0521052858	AXIS TRANSMISSION SEED ASSY 7860	96	01
25	0511059419	HYDRAULIC SYSTEM ASSEMBLY 6850/7285/7450/7860/7960	99	01
26		DRAWBAR ASSEMBLY - FRAME 5750/5850/6850/7450	102	
27	0541015451	WRENCH 2.3/8 X 2.3/4		01


Item	Code	Description	See page	QT
28	0501065677	STRUT		02
29	0521013022	TRANSPORT LOCK		03
30	0503030168	HITCH PIN CLIP		03
31	0501068994	8,30 X 78 LOCK PIN		03
32	0501047895	25 ROD STOP		03
33	0501047885	30 ROD STOP		03
34	0501047886	35 ROD STOP		03
35	0501047887	40 ROD STOP		03
36	0521018501	TURNBUCKLE LEVER		01
37	0511057817	SUPPORT HOSE	111	01
38	0521066304	HOSE GUIDE		01
39	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		02
40	0503013816	5/16" LOCKNUT		02
41	0503019262	SOAP DISH VACUUM		01
42	0501053834	MALE QUICK COUPLER	53	01
43	0503010045	O'RING		01
44	0541010080	TERMINAL R.1 / 2 NPT		01
45	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01
46	0581013729	NIPLE 1/2 NPT		01
47	0503010780	N-2050 AMENDMENT		02
48	0503010951	REDUCTION		04
49	0503011750	AMENDMENT WITH LOCK		06
50	0503011751	REDUCTION		06
51	0531059627	ALPHA COMPONENTS KIT - 17 ROWS	112	01
52	0521025447	BOX WITH HYDRAULIC MARKER COMPONENTS	113	01
53		ASSY SEED / FERTILIZER ROW	115	




Item	Code	Description	See page	QT
01	0511053135	RIGHT FRAME WITH WHEELED AXLE 7860	3	01
02	0511053136	LEFT FRAME WITH WHEELED AXLE 7860	4	01
03	0511059288	CENTRAL FRAME WITH WHEELED AXLE 5750/6850/7860/8160	5	01
04	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		04
05	0503011442	3/4" SPRING WASHER		18
06	0501010098	BOLT 3/4" UNC X 2 C S G.5 ZN		18
07	0571010094	SLEEVE FLANGE		06
08	0521063912	PIVOT SHAFT		02
09	0571013510	LOCK AXLE		02
10	0503030085	LOCK PIN		02
11	0571010095	FLAT WASHER		02
12	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
13	0503011444	SPRING WASHER 5/16"		04
14	0502012698	CLAMP		04
15	0501011643	3/8 X 1" BOLT		14
16	0503010025	3/8 SPRING WASHER		14
17	0503010026	3/8" NUT		14
18	0521063003	LOCK PIN		02
19	0571010969	LOCK SLEEVE FRAME		02
20	0503013627	1.1/2 SPRING WASHER		02
21	0501010110	NUT 1.1/2 NC 6FPP HEXAGONAL 2.3/8" ZN		02
22	0581016293	TROUGH 24 X 50 X 1420		02
23	0581017747	GUTTER 25 X 50 X 1200		02
24	0581015857	GUTTER 24 X 50 X 1080		02




Item	Code	Description	See page	QT
01	0521063971	FRAME BRACKET		01
02	0521063975	CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" UNC G.5 ZN HEX NUT		06




Item	Code	Description	See page	QT
01	0521063972	FRAME BRACKET		01
02	0521063981	SIDE CARRYING-WHEELS PIVOT SHAFT		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8 UNC X 2.1/4 BOLT		06
05	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" UNC G.5 ZN HEX NUT		06




Item	Code	Description	See page	QT
01	0521066916	CENTRAL FRAME		01
02	0521013199	LOWER BEARING SEMI		04
03	0503010899	5/8 UNC X 2.1/4 BOLT		08
04	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		16
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503010013	5/8" UNC G.5 ZN HEX NUT		08
08	0521063878	ARTICLE AXLE ROLLED		01




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		05
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		10
03	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		10




Item	Code	Description	See page	QT
01	0521058401	655 WHEELED SUPPORT WITH TRANSMISSION		01
02	0521055234	WHEELED FASTENER	13	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	18	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	BOLT 5/8" UNC X 2 CS G.5 ZN		01
07	0503010027	5/8 SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503063172	WHEEL	11	01
02	0521055233	WHEELED TRANSMISSION WITHOUT TIRE	12	01




Item	Code	Description	See page	QT
01	0503019458	TIRE 7.00X16 14PR		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	25590/25523 ROLLER BEARING		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL BOLT 5/8" UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0502011339	15Z GEAR P 1.25"		01
09	0503012550	5/16" X 3/4" BOLT		06
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" UNC G.5 ZN HEX NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0521055236	INTERMEDIARY CURRENT STRETCHER	14	01
07	0521055237	WHEEL FIXED CURRENT STRETCHER	16	01
08	0521055235	WHEEL MOBILE CURRENT STRETCHER	17	01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN	15	01
02	0551018245	CHAIN TENSIONER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0551018239	SLEEVE 19 X 13,50 X 45		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503019355	BEARING 6202 2RS1		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN	15	01
02	0551018252	CHAIN TENSIONER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN	15	01
02	0551018244	CHAIN TENSIONER AXLE		01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8 SPRING WASHER		02
08	0591010589	BODY LOCK WHEEL		02
09	0521058394	WHEEL WITH TIRE	19	01




Item	Code	Description	See page	QT
01	0503063172	WHEEL	11	01
02	0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	20	01




Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	25590/25523 ROLLER BEARING		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL BOLT 5/8" UNF X 2.1/8 CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01



Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	22	03
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521015501	COUPLING SHAFT		03
04	0503010523	1/4" X 2" SPLIT PIN		06
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		03
06	0531012565	SLEEVE 16,3X 30 X 88		03
07	0503010027	5/8 SPRING WASHER		03
08	0503010013	5/8" UNC G.5 ZN HEX NUT		03
09	0551014099	COUPLING SHAFT 31,75 X 185		01




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCKLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE W2-2250-750		01
08	0503018026	GASKET 1870-2000-375 B POLYMAX		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	END CAP 4"		01
12	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0501110639	BEARING		08
02	0503011099	GREASE FITTING		08
03	0503010300	5/32" X 1" SPLIT PIN		08
04	0551019114	MOTOR BEARING AXLE SUPPORT		04
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
07	0503010019	1/2" SPRING WASHER		08
08	0503010060	1/2 UNC G.5 ZN HEX NUT		08
09	0571014440	ENGINE SHAFT 2475		02
10	0501018466	FLAT WASHER		04
11	0511015961	LOCK BUSHING		04
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
13	0503010060	1/2 UNC G.5 ZN HEX NUT		04
14	0501052560	MOTOR AXLE SIGNAL	24	02
15	0511051434	TRANSMISSION ACTUATOR	25	04
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	26	01
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	27	01
18	0521050183	RIGHT GEAR BOX ASSY	28	01
19	0521050184	EXCHANGE LEFT ASSY	29	01
20	0503014734	BOLT		06
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
23	0503010019	1/2" SPRING WASHER		10
24	0503010060	1/2 UNC G.5 ZN HEX NUT		10
25	0521064449	36Z P1/2 SH 3/4 GEAR		02
26	0511059261	CHAIN TENSIONER	30	04
27	0521055217	LOWER CURRENT STRETCH	31	02
28	0501058254	UPPER SEED CHAIN TENSIONER	32	02
29	0521055216	BEARING WITH GEAR	33	02
30	0521055218	BEARING GEAR WITH DOUBLE	34	02


Item	Code	Description	See page	QT
31	0521055214	BEARING GEAR WITH	35	02
32	0503012522	40-1 CHAIN X 85 LINK + MENDING		02
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		02
34	0503013215	40-1 CHAIN X 89 LINK + MENDING		02
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		02




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	NUT 5/16 UNC G.5 ZN		02
05	0503031584	ORANGE SIGNAL ARROW DECAL		01
06	0503031585	SILVER SIGNAL ARROW DECAL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CS PC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0521017590	GUIDE AXLE		01
03	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
04	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
05	0501019734	FLAT WASHER		02
06	0502010710	RIGHT CAM, SMALLER		02
07	0503010003	1845 GREASE FITTING		02
08	0502012539	26Z P12,7 GEAR		01
09	0501019735	FLAT WASHER		01
10	0521017593	FLAT WASHER		01
11	0503010542	501045 CLAMPING RING (FOR AXLE)		01
12	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
13	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	36	01
02	0511059266	CLOSED BEARING	37	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	38	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	39	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	40	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	41	01
23	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERMEDIATE AXLE		01
30	0511065209	20Z GEAR		01




Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	44	01
02	0511059266	CLOSED BEARING	37	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	38	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	39	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	40	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	41	01
23	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		01
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8 SPRING WASHER		01
27	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERMEDIATE AXLE		01
30	0511065209	20Z GEAR		01




Item	Code	Description	See page	QT
01	0503031805	11Z 1/2" GEAR		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		01
03	0521069698	GEAR 21Z P 1/2		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8 SPRING WASHER		01
09	0503010013	5/8" UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521018933	CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501011234	5/8" X 3" BOLT		01
02	0531017086	50 AXLETIGHTENER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0503019356	BEARING 6005 2RS1		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0503016460	5/8" X 4.1/2" BOLT		01
02	0551019175	DOUBLE GEAR AXLE		01
03	0503019356	BEARING 6005 2RS1		02
04	0511069680	20Z X 28Z DOUBLE GEAR		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0511063106	20Z AXLE BEARING DOUBLE		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521055215	DOUBLE TRANSMISSION BEARING	45	01
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	42	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0501056444	ROLLER BEARING	43	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011978	CENTRAL BEARING GEARBOX		01
02	0503013462	6005 2RS1 ROLLER BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0502011697	GEARBOX SUPPORT		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503019356	BEARING 6005 2RS1		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521068504	RIGHT PLATFORM		01
02	0521068597	CENTRAL PLATFORM		01
03	0521068586	LEFT PLATFORM		01
04	0581015863	PLATFORM ENHANCEMENT PROTECTION		02
05	0501010942	3/8" X 1-1/4" BOLT		04
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		28
07	0503010025	3/8 SPRING WASHER		16
08	0503010026	3/8" NUT		16
09	0521068316	JOINT SUPPORT		06
10	0503010849	3/8" X 1-1/2" BOLT		12
11	0521010549	COUPLING SHAFT		06
12	0503030168	HITCH PIN CLIP		06
13	0503010741	1/2" X 2-3/4" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
16	0502012739	PLATFORM LEFT FIXER SUPPORT		02
17	0503011333	COVER FIXER		03
18	0503010274	5/32" X 2" SPLIT PIN		03




Item	Code	Description	See page	QT
01	0521063976	SIDE HANDRAIL		02
02	0521063875	CENTRAL HANDRAIL		01
03	0503010395	1/2" X 1-1/4" BOLT		04
04	0503010019	1/2" SPRING WASHER		12
05	0503010060	1/2 UNC G.5 ZN HEX NUT		12
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		06
07	0503011082	C1/2" X 1.3/4" SCREW		02
08	0551019884	45 X 50 X 3/8 FASTENER		08
09	0571017991	CHAIN FIXER HANDRAIL		08
10	0503013357	3/8 SELF-ADJUSTING NUT		16
11	0503034094	22 TWISTED CHAIN		04




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER		02
02	0503010237	3/8" X 1" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0511069636	LADDER		01
06	0503011179	3/8" X 2-1/4" BOLT		02
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
08	0503013357	3/8 SELF-ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0501054649	HBM SEQUENTIAL VALVE	51	01
02	0511058431	HYDRAULIC CYLINDER	52	01
03	0511058431	HYDRAULIC CYLINDER	52	01
04	0511015573	2.07" X 1.6" TRANSPORT LOCK		02
05	0503030168	HITCH PIN CLIP		02
06	0511057880	HYDRAULIC MARKER HAND ASSY		01
06A	0521052512	HOSE 3/8 X 5200 TC-TM PURPLE / RED		01
06AA	0501081980	HOSE 3/8 X 5200 TC-TM		01
06AB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
06AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
06AD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
06B	0521052513	HOSE 3/8 X 5200 TC-TM PURPLE / BLUE		01
06BA	0501081980	HOSE 3/8 X 5200 TC-TM		01
06BB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
06BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
06BD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
06C	0501082037	HOSE 3/8 X 5150 TR-TC		02
06D	0501082038	HOSE 3/8 X 5350 TR-TC		02
07	0501053834	MALE QUICK COUPLER	53	02
08	0511018012	HIDRAULIC ADAPTER		04
09	0501068994	8,30 X 78 LOCK PIN		02




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCEL VALVE		01
02	0501010617	NIPLE 3/4" NF X 3/4" NF HEX. 7/8" X 44		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02



Item	Code	Description	See page	QT
01	0501067700	2.5" X 25" CYLINDER CASE		01
02	0521066632	EXTENDER		01
03	0503030384	CON PLUG N-001		02
04	0502012837	PISTON		01
05	0503018005	RING		01
06	0503011109	O'RING 2-119 N 3006 9B		01
07	0503010163	D-1500 SCRAPER RING		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503018004	RING		01
11	0503018003	GASKET		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0503010002	1800 GREASE FITTING		02
15	0511032280	REPAIR KIT ASSY (0511058413)		01



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0503034420	ADHESIVE LABEL		01
02	0503034419	ADHESIVE LABEL PST TRIO FLEX SUPREME MINOR (05 MOUTH)		01
03	0503034114	TATU LOGO DECAL		01
04	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		01
05	0503033854	TATU LOGO DECAL		01
06	0503034056	ADHESIVE LABEL PST TRIO FLEX SUPREMA		02
07	0503033414	NUMBER 0 DECAL		02
08	0503033420	ADHESIVE LABEL 6 NUMBER FOR PLANTING		02
09	0503033421	NUMBER 7 DECAL		02
10	0503033422	NUMBER 8 DECAL		02
11	0503033008	ON/OFF RATCHET DECAL		02
12	0503031428	READ MANUAL DECAL		01
13	0503031942	MANUAL SEAL DECAL		01
14	0503033676	WARNING LABEL ADHESIVE SEAL LOCK AXIS		02
15	0503035927	P27 FERTILIZER TABLE DECAL		02
16	0503031565	CAUTION TRANSPORTATION DECAL		02
17	0503031566	ATTENTION JACK DECAL		02
18	0503034249	PLANTERS TABLE DECAL		02
19	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL		02
20	0503033012	RIGHT GEAR BOX SEED/FERTILIZER DECAL		01
21	0503033013	LEFT GEAR BOX SEED/FERTILIZER DECAL		01
22	0503032930	DANGER DECAL		09
23	0503031087	AUTO CONTROL APPROVED DECAL		01
24	0503034078	LIFTING POINTS DECAL		03
25	0503034003	61 X 118 SERIAL NUMBER TAG		01
26	0503010001	RIVET 3,2 X 5,5		04
27	0503031424	ATTENTION HYDRAULIC MARKER DECAL		02
28	0503032979	LETTERS A B C D DECAL		02




**PST TRIO FLEX SUPREMA P.P - FRAME 7860 - CSU (FROM
LABELS SET**

Page 54
0531059446


Item	Code	Description	See page	QT
29	0503034500	GRIP COLORS (PLANTERS) DECAL		01




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		17
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		03
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	56	03
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		15



Item	Code	Description	See page	QT
01	0503018738	HEADLIGHT		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
08	0503010337	NUT 5/16 UNC G.5 ZN		04




Item	Code	Description	See page	QT
01	0503063729	010072430 18 ROWS 450/500 SEED MONITORING SET		01
01A	0503017602	MONITOR PLANT PM400		01
01B	0503019100	SENSOR		18
01C	0513010271	020011968 18 ROWS CABLE FOR MESH SEED		01
01D	0503017443	ANTENNA GPS PM 400		01
01E	0503017031	CLEANING BRUSH		01
01F	0503019720	NYLON CLAMP		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010669	FLAT WASHER		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010667	3/16" NUT		02




Item	Code	Description	See page	QT
01	0581012166	HOSE		02
02	0551015245	4 X 1150 HOSE		02
03	0503011372	102 TO 121 CLAMP		08
04	0521050260	SUPPORT ASSEMBLY P.P MTH	59	02
05	0521050016	RIGHT AIR DISTRIBUTOR 06 NOZZLES - 17 E500	60	01
06	0521050017	LEFT AIR DISTRIBUTOR 06 NOZZLES - 17 E500	61	01
07	0521052999	DISTRIBUTOR AIR CENTRAL 7 MOUTHS - 17	62	01
08	0503031436	AIR DISTRIBUTOR PUMP		02
09	0503010246	CLAMP		02
10	0571019764	AIR CONDUCTOR 1.1 / 2 X 1600		17
11	0571019716	ADAPTER		17
12	0511059319	AIR FIXING SUPPORT	63	04
13	0521068698	AIR CONDUCTOR FIXING SUPPORT		04
14	0581013454	VALVE SUPPORT		01
15	0511057292	ASSY FLOW REGULATION VALVE	64	01
16	0521060118	"T" TERMINAL		01
17	0503033787	NUT 3/4 UNF		01
18	0502012702	BODY SUPPORT CLAMP		02
19	0503010674	7/16" X 3-1/4" BOLT		01
20	0503015490	SELF-LOCKING NUT 7/16		01
21	0501080714	3/8 X 1600 TR-TC HOSE		02
22	0501080060	1/2" X 63" TR-TC HOSE		04
23	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
24	0503010019	1/2" SPRING WASHER		02
25	0503010060	1/2 UNC G.5 ZN HEX NUT		02
26	0503012456	3/8" X 7/8" BOLT		02
27	0503010025	3/8 SPRING WASHER		02
28	0581010952	VACUUM GAUGE SUPPORT		01
29	0503013584	VACUUM GAUGE		01
30	0511057906	HOSE ASSY	65	01


Item	Code	Description	See page	QT
31	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01
31A	0501081247	HOSE 1/2 X 7012 TC-TM		01
31B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
31C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
31D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
32	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
32A	0501080477	3/8" X 276.06" TC-TM HOSE		01
32B	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
32C	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
32D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
33	0501053834	MALE QUICK COUPLER	53	02
34	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
35	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	66	01
36	0521052549	CLAMP	67	34
37	0511059887	TURBINE PRECISION PLANTING	68	02




Item	Code	Description	See page	QT
01	0502010175	HITCH CLAMP		01
02	0501011543	5/8" X 4" BOLT		02
03	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		02
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0571019403	STAPLE FIXER		01
06	0503010025	3/8 SPRING WASHER		03
07	0503010026	3/8" NUT		03
08	0521067492	SUPPORT		01
09	0501013518	FLAT WASHER		02
10	0521067491	SUPPORT MTH P.P		01
11	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
12	0503010143	1/4" SPRING WASHER		02
13	0503010144	1/4" NUT		02
14	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02




Item	Code	Description	See page	QT
01	0581013131	AIR DISTRIBUTOR BODY		01
02	0503017845	90 PVC KNEE		01
03	0571018559	WHITE PVC TUBE		01
04	0503031943	SOCKET		06
05	0503012856	POP RIVET		12
06	0503012566	COVER KAP 110 YELLOW		01
07	0521015543	110 X 55 AIR DUCT		01




Item	Code	Description	See page	QT
01	0581013131	AIR DISTRIBUTOR BODY		01
02	0503017845	90 PVC KNEE		01
03	0571018559	WHITE PVC TUBE		01
04	0503031943	SOCKET		06
05	0503012856	POP RIVET		12
06	0503012566	COVER KAP 110 YELLOW		01
07	0521015543	110 X 55 AIR DUCT		01




Item	Code	Description	See page	QT
01	0571019573	AR 1000 CONDUCTOR BODY		01
02	0503031943	SOCKET		07
03	0503012856	POP RIVET		14
04	0581012167	AR 600 CONDUCTOR BODY		02
05	0511057036	AIR DISTRIBUTOR BOARD		02
06	0503012566	COVER KAP 110 YELLOW		02




Item	Code	Description	See page	QT
01	0571019403	STAPLE FIXER		01
02	0503010025	3/8 SPRING WASHER		04
03	0503010026	3/8" NUT		04
04	0501013518	FLAT WASHER		02
05	0571019921	AIR SUPPORT FIXATION		01
06	0503010237	3/8" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0503014774	HFB0709111 CONTROL VALVE		01
02	0501010590	NIPPLE		06
03	0503010045	O'RING		06




Item	Code	Description	See page	QT
01	0511057840	ASSY TURBINE HOSE REAR		01
01A	0521052534	HOSE 1/2 X 7012 TC-TM YELLOW / RED		01
01AA	0501081247	HOSE 1/2 X 7012 TC-TM		01
01AB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01AC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01AD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
01B	0521052535	HOSE 1/2 X 7012 TC-TM YELLOW / BLUE		01
01BA	0501081247	HOSE 1/2 X 7012 TC-TM		01
01BB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01BC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01BD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
01C	0521052536	HOSE 3/8 X 7012 TC-TM YELLOW / GREEN		01
01CA	0501080477	3/8" X 276.06" TC-TM HOSE		01
01CB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01CC	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
01CD	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	53	02
03	0581010092	SPRING PROTECTION PLASTIC HOSE 3/4		01
04	0503033981	ADHESIVE LABEL		01
05	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	66	01




Item	Code	Description	See page	QT
01	0503018799	QUICK COUPLING		01
02	0503011883	QUICK CONNECTION COVER		01




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	SELF-LOCKING HEX NUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0521050154	PRECISION PLANTING TURBINE WITH HOLE	69	01
02	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
03	0501011460	7/8 NF REDUCTION NIPPLE		04
04	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
05	0503010392	2-046 N 3006 9B O'RING		01
06	0503010190	2-114 N 3006-9B O'RING		04
07	0501080218	1/2 X 750 HOSE		01
08	0581012096	ROUND SLEEVE		02
09	0503031087	AUTO CONTROL APPROVED DECAL		01
10	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01



Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01




Item	Code	Description	See page	QT
01	0503060100	SUPPORT INSTRUCTION MANUAL		01
02	0503010267	NYLON CLAMP 3,60 X 1,3 X 155 MM		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER 32,50 X 75 X 4,75		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	NUT 5/16 UNC G.5 ZN		01




Item	Code	Description	See page	QT
01	0531056254	SILO SUPPORT/LEFT FERTILIZER WITH ALPHA 72 DOSER		01
02	0531056253	SUPPORT SILO/DIRECT FERTILIZER WITH ALPHA 79 DOSER		01
03	0531056252	SILO SUPPORT/CENTRAL FERTILIZER WITH 87 ALPHA DOSER		01
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		40
05	0503010025	3/8 SPRING WASHER		20
06	0503010026	3/8" NUT		20
07	0503010849	3/8" X 1-1/2" BOLT		20
08	0503062391	FERTILIZER HOPPER		01
09	0571019051	FIXER HOPPER WASHER		28
10	0503013751	3/8 UNC X 1.1/4 BOLT		28
11	0503012535	3/8" SPRING WASHER		28
12	0503012531	3/8" INOX NUT		28
13	0503011957	NYLON HANDLE		02
14	0503010371	5/16" X 1" BOLT		04
15	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
16	0503010337	NUT 5/16 UNC G.5 ZN		08
17	0581012605	GEAR BOX LEVER LOCK		02
18	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
19	0503011953	5/16" X 1" BOLT		04
20	0551019168	SLEEVE		02
21	0551019167	SLEEVE UNION		02
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
23	0503010479	BOLT		02
24	0503011336	1/2" HEX SELF ADJUSTING NUT		06
25	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
26	0503010019	1/2" SPRING WASHER		02
27	0503010060	1/2 UNC G.5 ZN HEX NUT		02


Item	Code	Description	See page	QT
28	0501013518	FLAT WASHER		06
29	0503010140	1/8" X 3/4" SPLIT PIN		06
30	0511069678	LH LOWER LEVER		02
31	0561016468	FASTENER		02
32	0521061741	INTERMEDIATE LEVER		02
33	0551019159	LEVER FIXER BODY		02
34	0503062589	FERTILIZER HOPPER MOUNTED		02
35	0521052736	INTERMEDIATE TRANSMISSION OF FERTILIZER	89	02
36	0501215701	ARM/DISARM LEVER		02




Item	Code	Description	See page	QT
01	0531064543	LEFT SUPPORT ALPHA FERTILIZER SILO		01
02	0501053788	3/4" SQUARE AXLE FASTENER	73	02
03	0531055319	ALPHA II FERTILIZER METERING	74	06
04	0503031527	AGRICULTURAL BEARING		02
05	0531055898	CHAIN TIGHTENER	80	01
06	0503012761	40-1 CHAIN X 52 LINK + REDUCTION		01
07	0531055897	INTERMEDIATE TRANSMISSION BEARING	81	01
08	0531059738	LEFT EARLY BEARING	88	01
09	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	83	01
10	0501311436	SQUARE AXLE 3/4 X 347		01
11	0531057908	SLEEVE 1/4 X 2		04
11A	0502013069	SLEEVE 21 X 38 X 50		01
11B	0503010010	SPLIT PIN 1/4" X 2.1/2"		01
12	0501310661	3/4" X 15,35"/15,27" AXLE		02
13	0501310842	AXIS Q 3/4 X 512		01
14	0501215679	3/4 X 780QUADRATE AXLE		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	TRANSMISSION HUB ASSY	75	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	76	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513010692	ALLEN SCREW 1/4 UNC X 7/8 C FLAT SI INOX		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501312601	FRONT COVER		01
19	0503036177	LID CORD		01
20	0531059139	COLLECTOR ASSY	77	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO DECAL		01
15	0503035316	LUBRICATED POINTS DECAL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT FERTILIZER METERING LID GUIDE		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	78	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0501053788	3/4" SQUARE AXLE FASTENER	73	02
02	0531064542	RIGHT SUPPORT ALPHA FERTILIZER SILO		01
03	0531055319	ALPHA II FERTILIZER METERING	74	06
04	0503031527	AGRICULTURAL BEARING		02
05	0531055898	CHAIN TIGHTENER	80	01
06	0503012761	40-1 CHAIN X 52 LINK + REDUCTION		01
07	0531055897	INTERMEDIATE TRANSMISSION BEARING	81	01
08	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	83	01
09	0501310842	AXIS Q 3/4 X 512		01
10	0531059737	RIGHT BEARING WITH ALPHA GEAR	85	01
11	0531057908	SLEEVE 1/4 X 2		04
11A	0502013069	SLEEVE 21 X 38 X 50		01
11B	0503010010	SPLIT PIN 1/4" X 2.1/2"		01
12	0501310661	3/4" X 15,35"/15,27" AXLE		02
13	0501311436	SQUARE AXLE 3/4 X 347		01
14	0501215679	3/4 X 780QUADRATE AXLE		01




Item	Code	Description	See page	QT
01	0501215149	CHAIN STRETCH AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0501215144	3/4 X 105 QUADRATE AXLE		01
02	0501056451	BEARING	82	01
03	0501215142	INTERMEDIATE TRANSMISSION BEARING BODY		01
04	0503031527	AGRICULTURAL BEARING		01
05	0521063187	GEAR 22Z P.1/2 (Q.19,2)		01
06	0503012880	1/4" UNC SELF ADJUSTING NUT		01
07	0521011039	FLAT WASHER		06
08	0503011953	5/16" X 1" BOLT		06
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
10	0503010337	NUT 5/16 UNC G.5 ZN		06
11	0503010733	1/4" X 1-3/4" BOLT		01
12	0521014167	CONE LOCK		01




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503013462	6005 2RS1 ROLLER BEARING		02
03	0503011105	SEAL RING		01







Item	Code	Description	See page	QT
01	0531065402	GEAR		01
02	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0531059739	SINGLE SIDE GEAR BEARING SET 22Z	86	01
02	0501310951	LEFT BEARING PLATE BALANCE		01
03	0503030796	5/16" X 1" BOLT		02
04	0503010337	NUT 5/16 UNC G.5 ZN		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0521011039	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007		01
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0503010337	NUT 5/16 UNC G.5 ZN		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0531057901	GEAR	84	01
04A	0531065402	GEAR		01
04B	0503013958	1/4" X 1" BOLT		02
05	0503010845	501035 CLAMPING RING (FOR AXLE)		01
06	0502012902	SINGLE BEARING SHAFT		01
07	0503010371	5/16" X 1" BOLT		02
08	0503012880	1/4" UNC SELF ADJUSTING NUT		01
09	0503010733	1/4" X 1-3/4" BOLT		01




Item	Code	Description	See page	QT
01	0531064544	ALPHA FERTILIZER HOPPER CENTRAL SUPPORT		01
02	0531055898	CHAIN TIGHTENER	80	02
03	0503012761	40-1 CHAIN X 52 LINK + REDUCTION		02
04	0531055897	INTERMEDIATE TRANSMISSION BEARING	81	02
05	0531055319	ALPHA II FERTILIZER METERING	74	05
06	0531057908	SLEEVE 1/4 X 2		03
06A	0502013069	SLEEVE 21 X 38 X 50		03
06B	0503010010	SPLIT PIN 1/4" X 2.1/2"		03
07	0501053788	3/4" SQUARE AXLE FASTENER	73	04
08	0503031527	AGRICULTURAL BEARING		04
09	0531059738	LEFT EARLY BEARING	88	01
10	0531059737	RIGHT BEARING WITH ALPHA GEAR	85	01
11	0501310661	3/4" X 15,35"/15,27" AXLE		03
12	0501311486	SQUARE AXIS 3/4 X 400		02




Item	Code	Description	See page	QT
01	0501310953	RIGHT BEARING PLATE BALANCE		01
02	0531059739	SINGLE SIDE GEAR BEARING SET 22Z	86	01
03	0503030796	5/16" X 1" BOLT		02
04	0503010337	NUT 5/16 UNC G.5 ZN		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0521011039	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503030331	1.2" X 1.2" X 12.2" HOSE		01
02	0503010243	CLAMP		02
03	0503062755	TRANSMISSION AXLE		01
04	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
05	0503012880	1/4" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0511058397	ASSEMBLY CSU C3 3BOX 7B WITH 17 C 7860	91	01
02	0501010942	3/8" X 1-1/4" BOLT		12
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		12
04	0503010025	3/8 SPRING WASHER		12
05	0503010026	3/8" NUT		12
06	0521051931	LEFT SUPPORT TOWER WITH BOLT	93	01
07	0521052687	RIGHT SUPPORT TOWER WITH BOLT	94	01
08	0521051927	TOWER SUPPORT HOPPER	95	04




Item	Code	Description	See page	QT
01	0521063401	FIXING LOCK		06
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
03	0503010025	3/8 SPRING WASHER		90
04	0503010026	3/8" NUT		90
05	0511057690	3" ARTICULATED SEED CONDUCTOR	92	17
06	0501010942	3/8" X 1-1/4" BOLT		68
07	0571015773	SUPPORT SEED		04
08	0501011643	3/8 X 1" BOLT		16
09	0521064874	7 NOZZLES SINGLE SEED HOPPER SUPPORT		03
10	0503062165	7 NOZZLES FRONT FERTILIZER HOPPER		03




Item	Code	Description	See page	QT
01	0571015779	ARTICULATION NOZZLE SUPPORT LID		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8 SPRING WASHER		01
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	NUT 5/16 UNC G.5 ZN		02
11	0502012767	SEED NOZZLE FIXER SUPPORT		01




Item	Code	Description	See page	QT
01	0521066207	LEFT HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	UNC NUT 3/4 UNC ALTA G.5 ZN		02




Item	Code	Description	See page	QT
01	0521066206	RIGHT HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	UNC NUT 3/4 UNC ALTA G.5 ZN		02




Item	Code	Description	See page	QT
01	0521066208	HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	UNC NUT 3/4 UNC ALTA G.5 ZN		02




Item	Code	Description	See page	QT
01	0571013469	5/8 X 700 HEX AXLE		01
02	0571013470	5/8 X 1100 HEX AXLE		01
03	0581013887	5/8 X 2560 HEX AXLE		02
04	0511057287	TRANSMISSION	97	02
05	0561014215	BEARING COVER LOWER ROW FRAME		02
06	0502040534	SPRING GUIDE BUSHING LOCK		08
07	0501018535	1/2 X 1 BOLT		08



Item	Code	Description	See page	QT
01	0503062392	DRIVE SHAFT	98	01
02	0503030331	1.2" X 1.2" X 12.2" HOSE		01
03	0503010243	CLAMP		02
04	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0503062392	DRIVE SHAFT	98	01




Item	Code	Description	See page	QT
01	0591019605	FLOW DIVIDER VALVE SUPPORT		01
01.	0591019604	VALVE SUPPORT		01
02	0511059290	VALVE ASSEMBLY	100	01
03	0501053835	FEMALE QUICK COUPLER	101	02
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
05	0531011180	UPPER BODY CLIP		04
06	0521066564	DUCT SEAL OIL		01
07	0531013922	0.6" X 0.8" X 1" SLEEVE		02
08	0503011179	3/8" X 2-1/4" BOLT		02
09	0503010025	3/8 SPRING WASHER		02
10	0503010026	3/8" NUT		02
11	0502012702	BODY SUPPORT CLAMP		12
12	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
13	0501053834	MALE QUICK COUPLER	53	04
14	0503010723	7/16UNC X 4 C SG.5 ZN1K19920 BOLT		04
15	0503010244	7/16" NUT		04
16	0503010180	7/16" SPRING WASHER		08
17	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
18	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
19	0503010019	1/2" SPRING WASHER		02
20	0503010060	1/2 UNC G.5 ZN HEX NUT		02
21	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
22	0571017774	SPRING PROTECTION QUICK HOSE		01
23	0511059418	HYDRAULIC SYSTEM HOSE ASSEMBLY		01
23A	0501080406	3/8" X 23" TR-TC HOSE		01
23B	0501080150	3/8 X 800 TR-TC HOSE		01
23C	0501081930	HOSE		01
23D	0501081646	TC-TC HOSE ASSY		03
24	0521052484	HOSE 1/2 X 4122 TM-TM BLACK / RED		01
24A	0501080881	HOSE 1/2 X 4122 TM-TM		01


Item	Code	Description	See page	QT
24B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
24C	0503034495	HYDRAULIC HOSE GRIP (RED)		02
24D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		12
25	0521052485	HOSE 1/2 X 4122 TM-TM BLACK / BLUE		01
25A	0501080881	HOSE 1/2 X 4122 TM-TM		01
25B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		02
25C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		02
25D	0503018952	PH 2,5 X 10 ZB PLASTIC BOLT		12



Item	Code	Description	See page	QT
01	0503016524	DIVIDER VALVE		01
02	0581011593	NIPPLE R.1.1/16 UN		01
03	0511010111	7/8" NIPPLE		03
04	0503011109	O'RING 2-119 N 3006 9B		01
05	0503010045	O'RING		03




Item	Code	Description	See page	QT
01	0503011883	QUICK CONNECTION COVER		01
02	0503011628	FEMALE QUICK COUPLER		01




Item	Code	Description	See page	5750	5850	6850	7450
01	0521066289	5750/6350/6850 FRONT DRAWBAR		001	001	001	001
02	0521066290	INTERMEDIATE DRAWBAR - 5750/6850/7860/8160		001	000	001	000
02.	0521067151	INTERMEDIATE DRAWBAR - 5850/7960		000	001	000	000
02...	0521067075	INTERMEDIATE DRAWBAR 6450/7285/7350/7450/8460	-	000	000	000	001
03	0571019949	JUNCTION SHAFT		006	006	006	006
04	0503030119	LOCK PIN		010	010	010	010
05	0511055096	TRACTOR HITCH	103	001	001	001	001
06	0511053179	TRACTOR COUPLING SHAFT	104	001	001	001	001
07	0503014120	CHAIN		001	001	001	001
08	0521051614	TURNBUCKLE SIDE UPPER	105	002	002	002	002
09	0521010571	COUPLING SHAFT		004	004	004	004
10	0503030085	LOCK PIN		006	006	006	006
11	0521052754	SIDE EXTENDER 505/316	106	002	000	000	000
11.	0521051616	TURNBUCKLE SIDE 505/480	107	000	002	000	000
11..	0521050133	TURNBUCKLE SIDE 755/480	108	000	000	002	002
12	0571019951	JUNCTION SHAFT		003	003	003	003
13	0503010523	1/4" X 2" SPLIT PIN		004	004	004	004
14	0503034772	BOX		001	001	001	001
15	0521068652	TOOLS BOX SUPPORT		001	001	001	001
16	0501011643	3/8 X 1" BOLT		004	004	004	004
17	0503010025	3/8 SPRING WASHER		004	004	004	004
18	0503010026	3/8" NUT		004	004	004	004
19	0581017000	PLATE INTERMEDIARY		002	002	002	002
20	0503011334	BOLT 3/8" UNC X 3/4" CS G.5 ZN		004	004	004	004
21	0503010025	3/8 SPRING WASHER		004	004	004	004
22	0501010984	10,50 X 27 X 3,00 FLAT WASHER		004	004	004	004
23	0503014321	CABLE STEEL SHACKLE		002	002	002	002
24	0502010584	CARRYING-WHEELS SUPPORT FIXER		008	008	008	008
25	0503016485	BOLT 3/4		016	016	016	016


Item	Code	Description	See page	5750	5850	6850	7450
26	0501010322	20,50 X 46 X 4,00 ZN FLAT WASHER		032	032	032	032
27	0503010152	3/4" SELF LOCKING NUT		016	016	016	016
28	0521067716	FIXER TUBE		004	004	004	004
29	0511059237	3 POINT TURNBUCKLE	109	001	001	001	001
30	0571019950	COUPLING SHAFT		001	001	001	001
31	0521045756	HYDRAULIC CYLINDER	110	001	001	001	001
32	0521010779	31.75 X 95 COUPLING SHAFT		001	001	001	001
33	0521010581	0.9" X 4.9" COUPLING SHAFT		001	001	001	001
34	0531016049	FLAT WASHER 27 X 52 X 4,75 ZN		002	002	002	002
35	0503014820	BLACK WATER RESERVOIR		001	001	001	001
36	0521068651	SUPPORT BOX		001	001	001	001
37	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		000	000	001	001
38	0501212237	HITCH SLEEVE ARTICULATED 85 X 35 MM		001	001	001	001




Item	Code	Description	See page	QT
01	0501011301	1.1/2" UNC 6FPP 2.5/16" NUT		01
02	0503010010	SPLIT PIN 1/4" X 2.1/2"		01
03	0503010571	1/4" X 1.1/2" SPLIT PIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	LEFT COMPRESSION SPRING		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	SCREW ASSY		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0502011195	ADJUSTMENT NUT BODY		01
02	0521068096	EXTENSOR R.1.1 / 2 UNC RIGHT		01
03	0521068095	EXTENSOR R.1.1/2 UNC LEFT		01
04	0541018672	COUNTERNUT		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521068097	505 SIDE EXTENSOR FIXED POINT		01
02	0521066338	EXTERNAL ROTATING BRIDGE		01
03	0561019879	LOCK ATTACHMENT BAR		01
04	0521067393	EXTERNAL SIDE EAR		01
05	0571019949	JUNCTION SHAFT		01
06	0503030119	LOCK PIN		01
07	0503010002	1800 GREASE FITTING		03
08	0501078990	TURNBUCKLE AXLE		01




Item	Code	Description	See page	QT
01	0521068097	505 SIDE EXTENSOR FIXED POINT		01
02	0521066338	EXTERNAL ROTATING BRIDGE		01
03	0561019879	LOCK ATTACHMENT BAR		01
04	0521067393	EXTERNAL SIDE EAR		01
05	0571019949	JUNCTION SHAFT		01
06	0503030119	LOCK PIN		01
07	0503010002	1800 GREASE FITTING		03
08	0521065193	TURNBUCKLE AXLE		01




Item	Code	Description	See page	QT
01	0521065193	TURNBUCKLE AXLE		01
02	0521067392	FIXED BRACKET		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0521067393	EXTERNAL SIDE EAR		01
06	0571019949	JUNCTION SHAFT		01
07	0503030119	LOCK PIN		01
08	0503010002	1800 GREASE FITTING		03




Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0511061880	SIDE RIGHT RATCHET		01
03	0511061881	RATCHET FOLLOWER		01
04	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
05	0503011179	3/8" X 2-1/4" BOLT		05
06	0503010025	3/8 SPRING WASHER		05
07	0503010026	3/8" NUT		05
08	0503010002	1800 GREASE FITTING		02
09	0531010264	SIDE RATCHET		01
10	0521066919	3-POINT EXTENSOR RIGHT FUSE		01
11	0521066337	LEFT EXTENSOR 3 SPIKE		01




Item	Code	Description	See page	QT
01	0511057653	HYDRAULIC CYLINDER		01
02	0501053835	FEMALE QUICK COUPLER	101	02




Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		17
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		17
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01



Item	Code	Description	See page	QT
01	0501100045	WOODEN BOX		01
02	0511061022	ROW MARKER SUPPORT		02
03	0511066119	MARKER SUPP FIXER FASTENER		04
04	0502010175	HITCH CLAMP		08
05	0501010216	3/4 UNC X 4.1/2 C S G.5 ZN BOLT		16
06	0503010023	3/4" SPRING WASHER		16
07	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		16
08	0511060013	ROW MARKER ARM		02
09	0521013347	1.1/4" X 8.4" AXLE		02
10	0501019435	32 X 50 X 1.5 FLAT WASHER		16
11	0503010523	1/4" X 2" SPLIT PIN		16
12	0511060014	ROW MARKER ARM		02
13	0521011142	1.1/4" X 7.5" AXLE		04
14	0521011141	1.1/4" X 6.5" AXLE		02
15	0521061790	1750 TURNBUCKLE		02
16	0521055204	ROW MARKER DISC	114	02
17	0521012324	1/2" X 3.2" X 2.54" FASTENER		04
18	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
19	0503010019	1/2" SPRING WASHER		08
20	0503010060	1/2 UNC G.5 ZN HEX NUT		08
21	0503010004	1890 GREASE FITTING		02
22	0503010003	1845 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521069643	DISC AXLE MARKER ROW		01
02	0602023094	DR16X3 C36AFPAFR73+4FR+4FR D474 10R		01
03	0581019513	DEPTH WHEEL HUB		01
04	0503019342	ROLLER BEARING		01
05	0581019168	DUST CLOAK		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503013758	1/4" X 1-1/2" BOLT		03
11	0503010143	1/4" SPRING WASHER		03
12	0503010358	5/16" X 5/8" BOLT		04
13	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
14	0503010337	NUT 5/16 UNC G.5 ZN		04
15	0503034055	CLAMPING RING		01




Item	Code	Description	See page	QT
01	0521054739	FRONT ROW SHORT LEFT SEED WITH CARDAN WITHOUT LUBRICATION	116	01
02	0521054738	FRONT ROW SHORT RIGHT SEED WITH CARDAN WITHOUT LUBRICATION	117	01
03	0521054741	FRONT SEED ROW LONG LEFT WITH CARDAN WITHOUT LUBRICATION	118	01
04	0521054740	FRONT ROW LONG RIGHT SEED WITH CARDAN WITHOUT LUBRICATION	119	01
05	0521054737	FRONT SEMI-ASSEMBLED LONG LEFT SEED ROW	120	01
06	0521054736	FRONT SEMI-ASSEMBLED OF LONG RIGHT SEED ROW	121	01
07	0511059501	FRAME PRECISION PLANTING SEMI MOUNTED	127	01
08	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
09	0503010019	1/2" SPRING WASHER		01
10	0503010060	1/2 UNC G.5 ZN HEX NUT		01
11	0521054795	REAR LEFT SEED ROW P.P CSU 3 NAC	128	01
12	0521054794	REAR RIGHT SEED ROW P.P CSU 3 NAC	129	01
13	0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	139	01
14	0521054811	FERTILIZER SHORT ROW	150	01
15	0521054812	LONG FERTILIZER ROW	151	01
16	0521054769	LEFT DDD FERTILIZER WITH SUPPORT	157	01
17	0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	158	01
18	0503030520	SEED SOCKET		01
19	0511018662	SPACING PLATE		01
20	0521068982	DISC BLADE HUB KEY		01
21	0503030391	RIGHT FERTILIZER NOZZLE		01
22	0503030392	LEFT FERTILIZER NOZZLE		01
23	0503031050	CURVED CONDUCTOR		01
24	0503010246	CLAMP		01
25	0503031076	2" HOSE CLAMP		01
26	0503031145	2" X 2" X 20" HOSE		01

Item	Code	Description	See page	QT
27	0531059865	RIGHT SEED CONDUCTOR WITH PROTECTION		01
28	0531050237	3" RIGHT SEED CONDUCTOR FIXER	161	01
29	0531013600	PRESS ADJUSTMENT LEVER		01
30	0521053946	SCARING ROD	162	01
31	0511017969	0.1" SPACING PLATE		01
32	0521069127	BOTTOM NOZZLE FERTILIZER		01
33	0503030483	FERTILIZER SOCKET		01
34	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
35	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
36	0503010025	3/8 SPRING WASHER		01
37	0503010026	3/8" NUT		01
38	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
39	0503010905	1/2" X 2-1/4" BOLT		01
40	0503010019	1/2" SPRING WASHER		01
41	0503010060	1/2 UNC G.5 ZN HEX NUT		01
42	0581012756	HEX AXLE 5/8 X 360		01
43	0581010593	HEX AXLE 5/8 X 600		01
44	0521057957	FIXED ROD EXTENSION WITH FIXATION	163	01




Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0521065847	SHORT TIRE SEED ROW FRAME		01
03	0521055213	SEED ROW BEARING	122	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	NUT 5/16 UNC G.5 ZN		04
08	0521055223	SEED ROW TRANSMISSION HUB	123	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" SPLIT PIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" SPLIT PIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	124	01
17	0581018487	FIXER UPPER SPRING		01
18	0521055224	TRANSMISSION CARDAN ASSY	125	01
19	0502012782	17Z GEAR WITH HEX HOLE		01
20	0521064651	LEFT SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	126	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED ROW		01

Item	Code	Description	See page	QT
31	0581017624	SPACING SLEEVE		06
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0521065847	SHORT TIRE SEED ROW FRAME		01
03	0521055213	SEED ROW BEARING	122	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	NUT 5/16 UNC G.5 ZN		04
08	0521055223	SEED ROW TRANSMISSION HUB	123	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" SPLIT PIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" SPLIT PIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	124	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055224	TRANSMISSION CARDAN ASSY	125	01
20	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
21	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	126	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED ROW		01

Item	Code	Description	See page	QT
31	0581017624	SPACING SLEEVE		06
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0521065847	SHORT TIRE SEED ROW FRAME		01
03	0521055213	SEED ROW BEARING	122	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	NUT 5/16 UNC G.5 ZN		04
08	0521055223	SEED ROW TRANSMISSION HUB	123	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" SPLIT PIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" SPLIT PIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	124	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055224	TRANSMISSION CARDAN ASSY	125	01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	126	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED ROW		01

Item	Code	Description	See page	QT
31	0581017624	SPACING SLEEVE		06
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0521065847	SHORT TIRE SEED ROW FRAME		01
03	0521055213	SEED ROW BEARING	122	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	NUT 5/16 UNC G.5 ZN		04
08	0521055223	SEED ROW TRANSMISSION HUB	123	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" SPLIT PIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" SPLIT PIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	124	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0521055224	TRANSMISSION CARDAN ASSY	125	01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	126	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02
30	0502012911	TOP ARM SEED ROW		01

Item	Code	Description	See page	QT
31	0581017624	SPACING SLEEVE		06
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01
34	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
35	0503010045	O'RING		08




Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	SEED ROW BEARING	122	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	NUT 5/16 UNC G.5 ZN		04
08	0521055223	SEED ROW TRANSMISSION HUB	123	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" SPLIT PIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" SPLIT PIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	124	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064650	LEFT SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	126	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02

Item	Code	Description	See page	QT
30	0502012911	TOP ARM SEED ROW		01
31	0581017624	SPACING SLEEVE		06
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
02	0503010045	O'RING		08
03	0521055213	SEED ROW BEARING	122	02
04	0503011953	5/16" X 1" BOLT		04
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	NUT 5/16 UNC G.5 ZN		04
08	0521055223	SEED ROW TRANSMISSION HUB	123	01
09	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
10	0561019032	SEED FERTIL ROW LOCK		01
11	0503010071	3/16" X 1" SPLIT PIN		01
12	0503030168	HITCH PIN CLIP		01
13	0521010773	0.37" X 1.18" COUPLING SHAFT		01
14	0503010140	1/8" X 3/4" SPLIT PIN		01
15	0503012412	5/8" UNC SELF LOCKING NUT		04
16	0511055260	SEED ROW CHAIN TENSIONER	124	01
17	0581018487	FIXER UPPER SPRING		01
18	0502012782	17Z GEAR WITH HEX HOLE		01
19	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
20	0521064652	RH SEED ROW SUPPORT FRONT		01
21	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
22	0502012568	UPPER ROCKER ARM		01
23	0561014904	TRANSMISSION AXLE FRAME ROW		01
24	0501011388	COUPLING SHAFT		02
25	0521055219	BEARING WITH GEAR 17Z HEX 5/8	126	01
26	0502012789	FIXER SUPPORT FERTILIZER ROW		01
27	0503017857	BOLT 5/8 UNF 4		04
28	0503010811	5/8" UNF SELF ADJUSTING NUT		04
29	0503034580	TRACTION SPRING		02


Item	Code	Description	See page	QT
30	0502012911	TOP ARM SEED ROW		01
31	0581017624	SPACING SLEEVE		06
32	0503019273	AUTO LUBRICANT SLEEVE		08
33	0581017626	SPACER		01




Item	Code	Description	See page	QT
01	0502012718	ROW BEARING		01
02	0503019355	BEARING 6202 2RS1		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503019361	BEARING 6006 RS1		02
04	0503019363	BEARING 6005		01
05	0503011378	M6 X 1 X 16 C S 8.8 ZN BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503019362	BEARING 6005 RS1		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551017540	5/8" X 73 AXLE HEX		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0503011855	0.2" X 1.8" SPRING PIN		03
04	0503013958	1/4" X 1" BOLT		02
05	0551017559	BEARING AXLE BODY		01
06	0561014778	HEX UNIVERSAL JOINT		01
07	0571012412	HEX AXLE		01
08	0521055225	BEARING DOUBLE FRONT SEED ROW		01
09	0501056296	UNIVERSAL JOINT		01




Item	Code	Description	See page	QT
01	0502012819	17Z GEAR WITH HEX HOLE		01
02	0521055220	BEARING FRONT SEED ROW		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0521066539	CENTRAL SEED ROW FRAME		01
02	0521055224	TRANSMISSION CARDAN ASSY	125	01




Item	Code	Description	See page	QT
01	0521055873	LEFT DOUBLE DISC FAST EXCHANGE SEED 15X15	130	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0521055208	ASSEMBLY PRECISION PLANTING V-SET2 CSU 3	134	01
		CSU SUPREMA P.P		




Item	Code	Description	See page	QT
01	0521055872	RIGHT DOUBLE DISC FAST EXCHANGE SEED 138 15X15		01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0521055208	ASSEMBLY PRECISION PLANTING V-SET2 CSU 3 134 CSU SUPREMA P.P		01




Item	Code	Description	See page	QT
01	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0502012781	SUPPORT DDD LEFT		01
04	0503011402	0.2" X 0.8" SPRING PIN		01
05	0503013129	ELASTIC PIN		01
06	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
07	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 131 FERTILIZER / SEED		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 132 FERTILIZER / SEED		01
09	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
11	0503010025	3/8 SPRING WASHER		01
12	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0521055865	FERTILIZER/SEED LEFT HUB ASSY	133	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01



Item	Code	Description	See page	QT
01	0521055864	FERTILIZER/SEED RIGHT HUB ASSY		01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
02	0571017899	PIN LOCK		01
03	0503030190	0.5" X 1.6" X 0.05" SPRING		01
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
05	0521055210	LEFT P.P TRANSMISSION BOX	135	01
06	0571017894	PIN DRAG PRECISION PLANTING		01
07	0503013357	3/8 SELF-ADJUSTING NUT		01
08	0501013518	FLAT WASHER		02
09	0503015356	SPRING PIN		01
10	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
11	0571017895	PIN FIXER CONDUCTOR P.P		01
12	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		01
13	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
14	0503010293	CLAMP KNOB		02
15	0503010140	1/8" X 3/4" SPLIT PIN		02
16	0521066707	FEEDER		01
17	0503010025	3/8 SPRING WASHER		02
18	0571019491	SLUICE PNEUMATIC		01
19	0501011643	3/8 X 1" BOLT		01
20	0503010209	3/8" UNC BUTTERFLY NUT		01
21	0502012807	SUPPORT HOPPER PRECISION PLANTING		01
22	0571019489	CLAMP PRECISION PLANTING		01
23	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
24	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 136 DISC		01
25	0561014778	HEX UNIVERSAL JOINT		01
26	0503013958	1/4" X 1" BOLT		02
27	0503011855	0.2" X 1.8" SPRING PIN		01
28	0503012721	1/4" X 4" BOLT		01


Item	Code	Description	See page	QT
29	0503012880	1/4" UNC SELF ADJUSTING NUT		04
30	0571014024	FAST BOLT GUIDE AXLE		01
31	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
32	0503015110	M06 SPRING WASHER		02
33	0503818139	BOLT		03
34	0503037390	PACKING FOR PLANTING		01
35	0503015752	3/8" X 2" BOLT		01
36	0503034824	FIXATIVE		01
37	0581011226	FIXER CLOSING P. PLANTING CONTROL CPRA		01
38	0503010337	NUT 5/16 UNC G.5 ZN		04
39	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
40	0503011953	5/16" X 1" BOLT		03
41	0503012163	5/16" X 1-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION HOPPER PP		01
02	0502050053	RIGHT SIDE TRANSMISSION HOPPER PP		01
03	0503019356	BEARING 6005 2RS1		02
04	0503019367	BEARING 6203 2RS1 NAC		02
05	0503011184	502040 CLAMPING RING (FOR AXLE)		01
06	0571017655	FIXER SLEEVE		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
08	0503010144	1/4" NUT		03
09	0511057504	JOIN GEAR		01
09A	0571017898	BODY GEAR TRANSMISSION		01
09B	0503033975	24Z GEAR PNEUMATIC		01
09C	0503011769	M8 X 0.5" BOLT		01
10	0581011222	PINION AXLE 6Z PNEUMATIC		01
11	0503034340	PINION AXLE 6Z PNEUMATIC		01
12	3402510052	GREASE		0,07Kg




Item	Code	Description	See page	QT
01	0571019613	STRAW PRECISION PLANTING SHIELD		01
02	0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	137	01




Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01




Item	Code	Description	See page	QT
01	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0502012780	SUPPORT DDD RIGHT		01
04	0503011402	0.2" X 0.8" SPRING PIN		01
05	0503013129	ELASTIC PIN		01
06	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
07	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 131 FERTILIZER / SEED		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 132 FERTILIZER / SEED		01
09	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
11	0503010025	3/8 SPRING WASHER		01
12	0503010026	3/8" NUT		01







Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY	144	01
06	0503019398	AXLE RETAINER RING		01
07	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	145	01
08	0521055054	LEFT ARM WITH SLEEVE	146	01
09	0521055066	RIGHT ARM WITH SLEEVE	147	01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2 UNC G.5 ZN HEX NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED SLEEVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0521055055	HUB WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	148	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	NUT 5/16 UNC G.5 ZN		06




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	149	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	149	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" SPLIT PIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT SLEEVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" SPLIT PIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0581019523	LEFT ARM WHEEL DEPTH		01
02	0581019514	LUBRICANT SLEEVE		02
03	0503011109	O'RING 2-119 N 3006 9B		02




Item	Code	Description	See page	QT
01	0581019524	RIGHT ARM DEPTH		01
02	0581019514	LUBRICANT SLEEVE		02
03	0503011109	O'RING 2-119 N 3006 9B		02




Item	Code	Description	See page	QT
01	0581019522	CASE WHEEL DEPTH WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0503010143	1/4" SPRING WASHER		03
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019529	DEPTH REGULATOR SHAFT		01
11	0581019168	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0502012894	WHEEL HUB		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0501010066	3/4" X 9" BOLT		01
02	0511017232	FLAT WASHER		02
03	0503011255	3/4" LOCK NUT		01
04	0502012873	SUPPORT DC FERTILIZER ROW		01
05	0503019278	LUBRICANT SLEEVE		02
06	0581019195	SIDE GUIDE SLEEVE		02
07	0581019196	CENTRAL GUIDE SLEEVE		01
08	0503010410	RING		02
09	0502012876	CLAMP		01
10	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
11	0503010013	5/8" UNC G.5 ZN HEX NUT		02
12	0521054906	SPRING ASSY FERTILIZER	152	01
13	0521053231	DPL 20 SHORT ROW WITHOUT LUBRICATION CONICAL BEARING	153	01
14	0521066231	SHORT FERTILIZER ROW ARM		01
15	0503017857	BOLT 5/8 UNF 4		03
16	0503010811	5/8" UNF SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0501010066	3/4" X 9" BOLT		01
02	0511017232	FLAT WASHER		02
03	0503011255	3/4" LOCK NUT		01
04	0502012873	SUPPORT DC FERTILIZER ROW		01
05	0503019278	LUBRICANT SLEEVE		02
06	0581019195	SIDE GUIDE SLEEVE		02
07	0581019196	CENTRAL GUIDE SLEEVE		01
08	0503010410	RING		02
09	0502012876	CLAMP		01
10	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
11	0503010013	5/8" UNC G.5 ZN HEX NUT		02
12	0521054906	SPRING ASSY FERTILIZER	152	01
13	0521053232	DPL 20 LONG ROW WITHOUT LUBRICATION CONICAL BEARING	156	01
14	0521066230	LONG FERTILIZER ROW ARM		01
15	0503017857	BOLT 5/8 UNF 4		03
16	0503010811	5/8" UNF SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK		02
02	0502012184	FERTILIZER SPRING GUIDE		02
03	0503031910	1.7" X 22.8" X 0.3" SPRING		01
04	0502012510	SPRING ROD SUPPORT		01
05	0591018219	JUNCTION SHAFT 12.70 X 109 ZN		01
06	0501018535	1/2 X 1 BOLT		02
07	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		02
09	0502010891	SPRING ROD SUPPORT CHOCK		01
10	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		01
11	0521067619	FERTILIZER ROW TUBE		01
12	0503010257	1/8" X 1" SPLIT PIN		01
13	0501010937	13,50 X 28 X 3,00 FLAT WASHER		01




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	154	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	THRUST WASHER		01
08	0521068887	DC RIGHT ARM WITH SLEEVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		01
16	0521068892	LEFT DC ARM WITH SLEEVE		01
17	0503019272	LUBRICANT SLEEVE		02
18	0503010390	SEAL RING		02
19	0581017628	LID		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	DISC BLADE FIXED AXLE		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	DISC BLADE HUB	155	01




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4	01	01
02	0502040872	REGULATORY NUT	01	01
03	0503010370	502072 CLAMPING RING (FOR AXLE)	02	02
04	0503010590	00674-B SEAL	02	02
05	0503019285	RING	02	02
06	0503012170	30207 ROLLER BEARING	02	02
07	0502020641	BLADE DISC FLANGE	01	01
08	0502012862	DISC BLADE HUB	01	01
09	0502040873	DISC BLADE AXLE	01	01
10	0503017755	NUT	01	01
11	0503018825	5/16 UNC UNC BOLT	06	06
12	0501010694	FLAT WASHER 32,50 X 75 X 4,75	06	06
13	0503013816	5/16" LOCKNUT	06	06
14	0511017907	1/8" BSPT X 6 PLUG	02	02




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	154	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	THRUST WASHER		01
08	0521068887	DC RIGHT ARM WITH SLEEVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		01
16	0521068892	LEFT DC ARM WITH SLEEVE		01
17	0503019272	LUBRICANT SLEEVE		02
18	0503010390	SEAL RING		02
19	0581017628	LID		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	DISC BLADE FIXED AXLE		01




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC	159	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC	160	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 132 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 131 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503010025	3/8 SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 132 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 131 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0503013759	NUT		02
02	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
03	0502012979	CLAMP 3 RIGHT CSU		02
04	0503010421	5/16" X 1-1/2" BOLT		02



Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070085	FIXED ROD BEARING		01
03	0513010288	ELASTIC PIN 701211 10 X 24		02
04	0513010289	ELASTIC PIN 701211 10 X 24		02



Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

