

ROW CROP PLANTERS

USAP 3200 GF - FRAME 11040
USAP 3200 GF - CHASSI 11040

Code: 0501093814
Series: S-0523
Revision: 00
Revision Date: FEBRUARY/2024

PARTS CATALOGUE



MARCHESAN



PRODUCTS

Code	Working Width	Description
0112120009		USAP 3200 GF 57E170 ALP S-0523

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909097078	FRAME ASSY	1
0909097079	FRAME RIGHT SIDE ASSY	2
0909097080	ASSY CENTRAL FRAME	3
0909097081	LEFT SIDE FRAME ASSY	4
0541051031	DRAWBAR ASSY	5
0531059114	MAJOR DRAWBAR 3 POINT	6
0531059013	HOSE STABILIZER	7
0531059115	SEMI ASSEMBLED REST	8
0541051032	HEADER FRONT SEMI MOUNTED	9
0541050704	PANTOGRAPHIC HEADER	10
0531059875	CYLINDER HYDRAULIC	11
0531059876	CYLINDER HYDRAULIC	12
0541051033	REAR HEADER	13
0541050703	SIDE ARM LOCK SET	14
0541053029	ARTICULATED CONVEYOR ASSEMBLY 1145/1270	15
0541052820	ADJUSTABLE DUCT SUPPORT	16
0531059097	SIDE SUPPORT 4762	17
0531056740	ECU BOX WITH FIXING BASE	18
0521056857	ECU APT / TVT BOX WITH EXCHANGE	19
0541050145	GUIDE SET	20
0541050144	GUIDE SENSOR	21
0541052752	SHT DKO ASSY	22
0541050019	MULTIPLIER WITH PUMP	23
0541050014	HYDRAULIC PUMP	24
0541050010	SUPPORT WITH HEAT EXCHANGER	25
0541050009	TANK 180 LITER COMPLETE	26
0541050012	RADIATOR EQUIPMENT	27
0531059117	FULL HEAD HOSE STABILIZER	28
0541052747	COMMAND BLOCK	29
0541052751	HYDRAULIC CONTROL BLOCK	30
0541052753	SET FILTERS LINES	31
0541052748	RIGHT PASSAGE BLOCKS SET	32
0541052750	ASSY BLOCK LEFT PASSAGE	33
0541050020	DOUBLE ROTATING DIVIDER	34
0541053056	CONTROL BLOCK SET	35
0531059987	DRIVING BLOCK	36
0531059990	ROTATING DIVIDER	37
0531059985	BLOCK HYDRAULIC COMMAND	38
0531058252	LIGHTING/CONTROL SET 3F	39
0541053109	HYDRAULIC HOSE ASSEMBLY	40
0541053110	SWIVEL WHEELS HOSE GAME	41
0541053111	HOSE GAME APT	42
0541053112	HOSE GAME LIFT	43
0541053113	GAME HOSE JOINT LINES	44
0541053114	PANTOGRAPHIC OPEN/CLOSE HOSE GAME	45
0531056795	AXLE LOCK COMPLETE	46
0531059084	RIGHT SIDE SILOS CPL WITH 20 OUTLETS	47
0531059086	RIGHT SIDE SILO	48
0503032990	SEED DISTRIBUTOR HOPPER ASSY	49
0531059057	SEED COMPLETE BEARING	50
0531059056	DOSER FERTILIZER ALPHA II	51
0531055863	TRANSMISSION HUB ASSY	52
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	53
0531059139	COLLECTOR ASSY	54
0531055273	ALPHA FERTILIZER METERING CLAMP	55



MARCHESAN

INDEX


0531059058	DOUBLE GEAR BEARING SET	56
0531057912	DOUBLE SIDE BEARING	57
0531059088	PLATFORM RIGHT	58
0531059090	ARTICULATED PLATFORM	59
0511059383	INTERNAL HANDRAILING FIXER	60
0541050616	CYLINDER 101,55 X 618 X 353	61
0541051027	SUPPORT SIDE TRIGHT	62
0541050280	RIGHT SEED FERTILIZER DISTRIBUTOR ROW DDD 15X15 CPL	63
0531059053	SPRING WITH EARS	64
0541050281	SUPPORT RIGHT DDD 15X15 S/L CPL	65
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	66
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	67
0521055865	FERTILIZER/SEED LEFT HUB ASSY	68
0521055864	FERTILIZER/SEED RIGHT HUB ASSY	69
0531059909	GAUGE WHEEL DEPTH CONTROL	70
0501055187	DEPTH WHEEL	71
0531059911	DEPTH WHEEL SUPPORT	72
0531059910	SEMI-ASSEMBLED DEPTH CONTROL	73
0521056710	LEFT DEPTH CONTROL HUB	74
0521056711	RIGHT DEPTH CONTROL HUB	75
0531059081	ROW ARTICULATED FERTILIZER/SEED DISTRIBUTOR LEFT	76
0541050279	ROW DISTRIBUTOR RIGHT FERTILIZER/SEED	77
0511059653	SPRING	78
0541050956	SIDE ARTICULATION SUPPORT	79
0541051028	CENTER RIGHT JOINT SUPPORT	80
0541050962	HYDRAULIC CYLINDER LEFT	81
0541051162	SUPPORT HOSE	82
0541051654	RIGHT WHEELS	83
0531055358	COMPLETE SIDE CYLINDER BEARING	84
0531055357	LOCK PIN SET	85
0541050275	HYDRAULIC CYLINDER RIGHT 44.45X85.7X413	86
0541050292	MONO RIGHT WHEEL TIRE 500 X 50	87
0541050195	MOUNTED LEFT WHEEL	88
0541050294	FULL WHEEL BOX	89
0541052958	HYDRAULIC DUCT ASSY RIGHT	90
0531058719	ASSY ENGINE SEED	91
0531055688	DOUBLE BEARING 38Z	92
0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	93
0531058720	COVER CHAIN SEED MOTOR	94
0531058725	FERTILIZER MOTOR SET	95
0531058726	FERTILIZER PROTECTION COVER WITH RIP	96
0541051037	RIGHT SIDE FRAME DRIVER ASSEMBLY	97
0531059101	CONDUCTOR FERTILIZER/SEED LINES	98
0541050968	CONDUCTOR REAR LINES FERTILIZER/SEED	99
0541050969	CONDUCTOR FERTILIZER/SEED HOSE 310	100
0541051038	CONDUCTOR CURVED FERTILIZER/SEED SMALLER HOSE 210	101
0541051039	CONDUCTOR SMALLER CURVED FERTILIZER/SEED HOSE 310	102
0541051040	CONDUCTOR FERTILIZER/SEED HOSE 390	103
0541051041	CONDUCTOR SMALLER CURVED FERTILIZER/SEED HOSE 310	104
0541050967	CONDUCTOR FERTILIZER/SEED CURVED 430 HOSE 210	105
0541051042	CONDUCTOR FERTILIZER/SEED CURVED 312 HOSE 210	106
0531059054	SILOS CENTRAL CPL WITH 17 OUTLETS	107



MARCHESAN


INDEX

0531059055	CENTRAL SILOS	108
0531059064	COMPLETE CENTRAL PLATFORM	109
0541050276	CENTER LEFT TELESCOPIC WHEELS	110
0531054036	ASSY CENTER CYLINDER BEARING	111
0541050194	COMPLETE CENTRAL CUBE	112
0541050196	MOUNTED RIGHT WHEEL	113
0541050277	HYDRAULIC CYLINDER LEFT	114
0541050274	RIGHT CENTER TELESCOPIC WHEELS	115
0541050272	CENTRAL SUPPORT	116
0541050273	BRACKET MOUNTED CENTER	117
0541050278	ROW DISTRIBUTOR LEFT FERTILIZER/SEED	118
0541050283	SUPPORT DDD LEFT	119
0541050948	ARM ARTICULATION LEFT	120
0541050950	ARM ARTICULATION RIGHT	121
0541050949	LEFT DUCT SET	122
0541050951	DUCT SET RIGHT	123
0531059845	CYLINDER HYDRAULIC 50,80 X 127 X 965 X 534	124
0531055684	CENTRAL SEED MOTOR ASSY	125
0531058723	FERTILIZER ENGINE ASSY CENTRAL FRAME	126
0531055682	COVER CHAIN SEED MOTOR	127
0531058724	FERTILIZER PROTECTION COVER WITH BOLT	128
0531055693	SET ISO6 06 CHANNELS	129
0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	130
0511056972	FILTER HYDAC	131
0521054490	FLOW DIVIDING VALVE ASSY	132
0531059194	DECAL ASSY	133
0531052114	ASSY PORT MANUAL INSTRUCCION	134
0541050970	CENTRAL FRAME CONDUCTOR ASSY	135
0531059085	LEFT SIDE SILOS	136
0531059087	SIDE SILO LEFT	137
0531059089	COMPLETE LEFT PLATFORM	138
0541051029	LEFT SIDE SUPPORT	139
0541050282	ROW DISTRIBUTOR LEFT FERTILIZER/SEED	140
0541051232	LEFT CENTER JOINT SUPPORT	141
0541050954	HYDRAULIC CYLINDER RIGHT 50,80 X 101,60 X 353 X 56	142
0541051655	MONO WHEEL LEFT TIRE 500/50	143
0531057692	LEFT COMPLETE HOSE SUPPORT	144
0541050293	LEFT WHEEL TIRE 500 X 50	145
0541052957	LEFT HYDRAULIC DUCT ASSEMBLY	146
0531055690	SIDE SEED MOTOR ASSEMBLY	147
0531055689	SUPPORT ENGINE LEFT	148
0531058721	FERTILIZER MOTOR ASSEMBLY LEFT SIDE FRAME	149
0531058722	FERTILIZER PROTECTION COVER	150
0541051036	LEFT SIDE CHASSIS DRIVER ASSEMBLY	151




Item	Code	Description	See page	QT
01		FRAME RIGHT SIDE ASSY	2	
02		ASSY CENTRAL FRAME	3	
03		LEFT SIDE FRAME ASSY	4	
04	0541051031	DRAWBAR ASSY	5	01
05	0501311515	SENSOR LIFTING SUPPORT		01
06	0531059097	SIDE SUPPORT 4762	17	02
07	0531064881	FRONT AXLE		02
08	0531064880	FRONT AXLE		02
09	0501017779	FLAT WASHER 32 X 60 X 4,75		04
10	0503011052	1.1/4" X 0.77" CASTLE NUT		04
11	0503010038	3/16" X 2" SPLIT PIN		04
12	0531056819	TRANSPORT LOCK		04
12A	0531064879	TRANSPORT LOCK		04
12B	0531060392	PIN LOCK TRANSPORT		04
12C	0503030168	HITCH PIN CLIP		04
13	0501312548	SUPPORT 55 X 50 X 800		02
14	0503011334	3/8 UNC X 3/4 CS G.5 ZN BOLT		04
15	0503018775	MAGNETIC ACTUATOR LH7.4.000091		01
16	0503018774	MAGNETIC SENSOR		01
17	0531056740	ECU BOX WITH FIXING BASE	18	01
18	0541050145	GUIDE SET	20	01
19	0541050144	GUIDE SENSOR	21	01
20	0531066344	ACTUATOR RULER		01
21	0501311516	UPPER SHEET		01
22	0541052752	SHT DKO ASSY	22	01
23	0531058252	LIGHTING/CONTROL SET 3F	39	01
24	0513011769	EXTERNAL ADAPTER		02
25	0541053109	HYDRAULIC HOSE ASSEMBLY	40	01
26	0531056819	TRANSPORT LOCK		04
26A	0531064879	TRANSPORT LOCK		04

Item	Code	Description	See page	QT
26B	0531060392	PIN LOCK TRANSPORT		04
26C	0503030168	HITCH PIN CLIP		04
27	0503015321	3/8 UNC X 5/8 C S G.2 ZN BOLT		06
28	0501013518	FLAT WASHER		06
29	0503010025	3/8 SPRING WASHER		04
30	0513011183	TERMINAL CARDAN TRIANGULAR 20Z 1.3/4 SERIE 06		01




Item	Code	Description	See page	QT
01	0531065798	RIGHT SIDE FRAME		01
02	0591018042	FRICTION PLATE		02
03	0503010962	5/8" X 1-1/4" BOLT		06
04	0501010453	FLAT WASHER		06
05	0503010027	5/8 SPRING WASHER		07
06	0591015962	SEPARATOR GLOVE		04
07	0591018045	FRICTION TRACK		02
08	0531056795	AXLE LOCK COMPLETE	46	01
09	0591018044	WASHER 65 X 130 X 20		01
10	0591019522	SLEEVE WEAR		02
11	0503010232	5/8" X 1.3/4" BOLT		01
12	0511010721	FLAT WASHER		01
13	0591015374	HITCH AXIS		01
14	0501111058	ASSY FIXING GLOVE		02
15	0503011239	1/2" X 2" BOLT		06
16	0503011336	1/2" HEX SELF ADJUSTING NUT		06
17	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		09
18	0531059084	RIGHT SIDE SILOS CPL WITH 20 OUTLETS	47	01
19	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
20	0503010337	NUT 5/16 UNC G.5 ZN		02
21	0501013233	5/8" X 2-3/4" BOLT		09
22	0501210615	SIDE WHEEL JOINT AXLE		01
23	0591018043	BODY SUPPORT		02
24	0503035468	HOSE PROTECTION		01
25	0531059088	PLATFORM RIGHT	58	01
26	0503018738	HEADLIGHT		01
27	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		02
28	0503010391	501038 CLAMPING RING (FOR AXLE)		01
29	0531065831	SILO RIGHT SIDE SUPPORT		01
30	0503012412	5/8" UNC SELF LOCKING NUT		09

Item	Code	Description	See page	QT
31	0501310050	FIXER BUSHING		09
32	0531065833	SIDE SILO SUPPORT		02
33	0501216965	CYLINDER COVER		02
34	0541050616	CYLINDER 101,55 X 618 X 353	61	01
35	0501310141	LADDER FIXING SUPPORT		01
36	0503011333	COVER FIXER		01
37	0503010274	5/32" X 2" SPLIT PIN		01
38	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		01
39	0503013759	NUT		01
40	0541051027	SUPPORT SIDE TRIGHT	62	01
41	0541051654	RIGHT WHEELS	83	01
42	0541052958	HYDRAULIC DUCT ASSY RIGHT	90	01
43	0531058719	ASSY ENGINE SEED	91	01
44	0531058725	FERTILIZER MOTOR SET	95	01
45	0531058728	LADDER SENSOR		01
45A	0501219499	LADDER LIFT SUPPORT		01
45B	0503013356	RIVET POP 3,2 X 10,0		01
46	0501219498	LIFT ACTUATOR		01
47	0503010519	1/4" X 5/8" BOLT		02
48	0503010143	1/4" SPRING WASHER		02
49	0511017303	FLAT WASHER		02
50	0503019412	RIVET SCREW INTERNAL		02
51	0541051037	RIGHT SIDE FRAME DRIVER ASSEMBLY	97	01



Item	Code	Description	See page	QT
01	0531066280	CENTER FRAME		01
02	0531059054	SILOS CENTRAL CPL WITH 17 OUTLETS	107	01
03	0503010834	1/2 X 1 BOLT		02
04	0503010019	1/2" SPRING WASHER		02
05	0531059064	COMPLETE CENTRAL PLATFORM	109	01
06	0503018738	HEADLIGHT		01
07	0503010337	NUT 5/16 UNC G.5 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		06
10	0531052534	LED FLASHLIGHT WITH SUPPORT		02
10A	0503019579	LED LANTERN		01
10B	0501210333	LED FLASHLIGHT SUPPORT		01
11	0531064862	CYLINDER ARTICULATION AXLE		02
12	0531065795	CENTRAL SILO SIDE FIXING SUPPORT		02
13	0531065796	SILO CENTRAL FIXING SUPPORT		01
14	0503012412	5/8" UNC SELF LOCKING NUT		09
15	0501013233	5/8" X 2-3/4" BOLT		09
16	0501310050	FIXER BUSHING		09
17	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		09
18	0541050276	CENTER LEFT TELESCOPIC WHEELS	110	01
19	0501017065	FLAT WASHER		20
20	0503019522	HEX NUT		20
21	0503019521	SCREW 3/4 UNF 3 CSRP G.8 ZN		20
22	0511015994	FLAT WASHER		02
23	0503018754	NUT 1 - 8 UNC - 2B G8		02
24	0501010276	BOLT		02
25	0541050274	RIGHT CENTER TELESCOPIC WHEELS	115	01
26	0541050272	CENTRAL SUPPORT	116	01
27	0541050948	ARM ARTICULATION LEFT	120	01
28	0541050950	ARM ARTICULATION RIGHT	121	01

Item	Code	Description	See page	QT
29	0531059845	CYLINDER HYDRAULIC 50,80 X 127 X 965 X 534	124	02
30	0531055684	CENTRAL SEED MOTOR ASSY	125	01
31	0531058723	FERTILIZER ENGINE ASSY CENTRAL FRAME	126	01
32	0531055693	SET ISO6 06 CHANNELS	129	01
33	0531059194	DECAL ASSY	133	01
34	0531055518	WORM THREAD ASSEMBLED		57
34A	0531064265	WORM THREAD		01
34B	0503035859	SUPPORT SLEEVE		01
35	0531052114	ASSY PORT MANUAL INSTRUCCION	134	01
36	0501047887	40 ROD STOP		04
37	0541050970	CENTRAL FRAME CONDUCTOR ASSY	135	01




Item	Code	Description	See page	QT
01	0531065797	LEFT SIDE FRAME		01
02	0591019522	SLEEVE WEAR		02
03	0591018042	FRICTION PLATE		02
04	0503010962	5/8" X 1-1/4" BOLT		06
05	0501010453	FLAT WASHER		06
06	0503010027	5/8 SPRING WASHER		07
07	0591015962	SEPARATOR GLOVE		04
08	0503010232	5/8" X 1.3/4" BOLT		01
09	0511010721	FLAT WASHER		01
10	0531056795	AXLE LOCK COMPLETE	46	01
11	0591018044	WASHER 65 X 130 X 20		01
12	0501111058	ASSY FIXING GLOVE		02
13	0503011239	1/2" X 2" BOLT		06
14	0503011336	1/2" HEX SELF ADJUSTING NUT		06
15	0591018045	FRICTION TRACK		02
16	0591015374	HITCH AXIS		01
17	0501210615	SIDE WHEEL JOINT AXLE		01
18	0591018043	BODY SUPPORT		02
19	0531059085	LEFT SIDE SILOS	136	01
20	0531059089	COMPLETE LEFT PLATFORM	138	01
21	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
22	0503010337	NUT 5/16 UNC G.5 ZN		02
23	0501013233	5/8" X 2-3/4" BOLT		09
24	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		09
25	0503018738	HEADLIGHT		01
26	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		02
27	0503035468	HOSE PROTECTION		01
28	0503010391	501038 CLAMPING RING (FOR AXLE)		01
29	0531065833	SIDE SILO SUPPORT		02
30	0531065832	SILO SIDE SUPPORT		01


Item	Code	Description	See page	QT
31	0503012412	5/8" UNC SELF LOCKING NUT		09
32	0501310050	FIXER BUSHING		09
33	0501216965	CYLINDER COVER		02
34	0541051029	LEFT SIDE SUPPORT	139	01
35	0541050616	CYLINDER 101,55 X 618 X 353	61	01
36	0501310141	LADDER FIXING SUPPORT		01
37	0503011333	COVER FIXER		01
38	0503010274	5/32" X 2" SPLIT PIN		01
39	0503011762	SCREW 5/16UNC X 1.1/4 CAPQ G.2 ZN		01
40	0503013759	NUT		01
41	0541051655	MONO WHEEL LEFT TIRE 500/50	143	01
42	0541052957	LEFT HYDRAULIC DUCT ASSEMBLY	146	01
43	0531055690	SIDE SEED MOTOR ASSEMBLY	147	01
44	0531058721	FERTILIZER MOTOR ASSEMBLY LEFT SIDE FRAME	149	01
45	0531058728	LADDER SENSOR		01
45A	0501219499	LADDER LIFT SUPPORT		01
45B	0503013356	RIVET POP 3,2 X 10,0		01
46	0501219498	LIFT ACTUATOR		01
47	0503010519	1/4" X 5/8" BOLT		02
48	0503010143	1/4" SPRING WASHER		02
49	0511017303	FLAT WASHER		02
50	0503019412	RIVET SCREW INTERNAL		02
51	0541051036	LEFT SIDE CHASSIS DRIVER ASSEMBLY	151	01

DRAWBAR ASSY


0541051031




Item	Code	Description	See page	QT
01	0531059114	MAJOR DRAWBAR 3 POINT	6	01
02	0531059115	SEMI ASSEMBLED REST	8	01
03	0541051032	HEADER FRONT SEMI MOUNTED	9	01
04	0541051033	REAR HEADER	13	01
05	0541053029	ARTICULATED CONVEYOR ASSEMBLY 1145/1270	15	01
06	0513010755	STANDARD SIMPLE CLAMP		20
07	0513010746	STANDARD CLAMP SINGLE 10MM - BLACK		12
08	0513010752	SINGLE STANDARD CLAMP 12 MM - BLACK		68
09	0503010305	6,50 X 17 X 1,50 ZN FLAT WASHER		50
10	0503015110	M06 SPRING WASHER		30
11	0503014540	M6 NUT		30
12	0501311289	FIXER 2TB28		05
13	0501312225	CLAMP 179 X 30 X 6.30		10
14	0501312881	SIDE FIXER		04
15	0501312882	GUTTER		02
16	0503010144	1/4\" NUT		16
17	0503010143	1/4\" SPRING WASHER		16
18	0503013758	1/4\" X 1-1/2\" BOLT		16
19	0513011664	BOLT M6 X 1,00 X 80 - SXR6X80ZI		10
20	0501317922	GUTTER 1840 X 100 X 2,00		01
21	0503036790	HYDRAULIC TUBE PT10LX404X1908XPT10LX2632		01
22	0503036791	HYDRAULIC TUBE PT12LX402X1906XPT12LX2632		06
23	0503036788	HYDRAULIC TUBE PT28X392X2112XFG28X2862		01
24	0503036789	HYDRAULIC TUBE PT28X392X2157XFG28X2907		01
25	0513011668	BOLT M6		20
26	0541052820	ADJUSTABLE DUCT SUPPORT	16	01




Item	Code	Description	See page	QT
01	0501217466	TRACTION BAR GUIDE		02
02	0501010276	BOLT		04
03	0503010012	1" SPRING WASHER		04
04	0501010059	1.5/8 NUT		04
05	0503030119	LOCK PIN		01
06	0511069471	PLOUGH SUPPORT		02
07	0501011075	PIN		02
08	0503030285	HITCH PIN CLIP		02
09	0531065845	MAJOR DRAWBAR 3 POINT		01
10	0503030085	LOCK PIN		08
11	0521068018	UPPER AXLE		01
12	0521068015	UPPER AXLE		01
13	0521068013	UPPER AXLE		01
14	0503012809	2" CASTLE NUT		01
15	0503010833	10 X 90 SPRING PIN		01
16	0531063869	AXLE 50 X 245 MM WITH THREAD 2 UNS 10 FPP		01
17	0521068011	AXLE LOWER		02
18	0501217367	LEFT SUPPORT BOX		01
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
20	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		04
21	0501213695	EJE 1.1/4 X 380 MM		02
22	0501217366	RIGHT BOX SUPPORT		01
23	0501217467	3 POINT HEAD FIXING GUIDE GLOVE		04
24	0531057145	COMPLETE SAFETY LOCK AXIS		01
24A	0531064617	LOCK AXLE COUPLING		01
24B	0501217474	FLAT WASHER 38.50 X 70 X 6.30		02
24C	0513010701	LOCK PIN		01
25	0503019293	SCREW 1/2 UNC X 2 COVER G7 ZN		04
26	0531059013	HOSE STABILIZER	7	01



Item	Code	Description	See page	QT
01	0531065746	HOSE ARTICULATOR		01
02	0503010237	3/8" X 1" BOLT		01
03	0503010025	3/8 SPRING WASHER		01
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
05	0503010019	1/2" SPRING WASHER		01
06	0503012556	1/2" X 1" BOLT		01
07	0531061934	CONDUCTOR ARTICULATOR GUIDE		01
08	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
09	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		02
10	0501217329	BACK PLATE 70 X 228		01




Item	Code	Description	See page	QT
01	0503010571	1/4" X 1.1/2" SPLIT PIN		02
02	0521010784	COUPLING SHAFT		01
03	0531060758	AXLE JUNCTION 25.4 X 150 WITH HANDLE		01
04	0503030085	LOCK PIN		02
05	0531064648	DESCENDING		01
06	0521010580	COUPLING SHAFT		01
07	0521012533	COUPLING SHAFT		01
08	0501310199	TUBE 80 X 80 X 9,52 X 710		01
09	0531064647	REST SHOE		01




Item	Code	Description	See page	QT
01	0531065842	TELESCOPIC DRAWBAR		01
02	0541050704	PANTOGRAPHIC HEADER	10	01
03	0531051649	HEADER LARGEST PULLEY		01
03A	0591018923	LARGER BODY HEADER PULLEY		01
03B	0551014862	NYLON PULLEY		02
04	0551014871	FLAT WASHER		06
05	0503010002	1800 GREASE FITTING		06
06	0591018925	AXLE BIGGER PULLEY		01
07	0503011105	SEAL RING		03
08	0503018754	NUT 1 - 8 UNC - 2B G8		02
09	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
10	0511054270	TENSIONER SPRING		01
10A	0511069520	TELESC LOCK SPRING TENSIONER		01
10B	0503010013	5/8 UNC G.5 ZN HEX NUT		02
11	0501216070	HITCH LOCK		01
12	0521011132	FLAT WASHER		02
13	0503010131	3/16" X 1.1/2" SPLIT PIN		02
14	0521058345	SAFETY CHAIN WITH SHACKLE		03
14A	0503014120	CHAIN		01
14B	0503014321	CABLE STEEL SHACKLE		02
15	0531063995	AXIS 290 TELESCOPIC HEAD		01
16	0501211894	AXLE		01
17	0591018924	WHEEL BIGGEST SHAFT HEADER SIDE		02
18	0591018921	WASHER 63.5 X 39 X 6.30		04
19	0531051648	INTERNAL HEAD PULLEY		02
19A	0591018922	INTERNAL PULLEY BODY HEAD		01
19B	0551014862	NYLON PULLEY		02
20	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		01
21	0503010027	5/8 SPRING WASHER		02
22	0503010962	5/8" X 1-1/4" BOLT		01


Item	Code	Description	See page	QT
23	0503010044	SELF LOCKING NUT 1.1/4 UNF G.5 ZN		03
24	0591015450	LOCK BODY GLOVE		02
25	0531064951	SIDE LOCK AXIS 381		01
26	0503010290	SELF ADJUSTING 1.1/2" UNF NUT		01
27	0551012215	FLAT WASHER		01
28	0501216069	SUPPORT		01
29	0501010100	BOLT 5/8" UNC X 2 CS G.5 ZN		01
30	0501011299	FLAT WASHER		01
31	0503010013	5/8 UNC G.5 ZN HEX NUT		01
32	0531064952	AXIS 308 TELESCOPIC HEAD		02
33	0531064652	SUPPORT		01
34	0531059876	CYLINDER HYDRAULIC	12	01
35	0531066463	BODY LOCKS WITH PIN		01
36	0591018926	BODY LOCK BIGGER		01
37	0591015449	AXLE LOCK HEADER		01



Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		03
02	0531060746	AXIS 278 TELESCOPIC HEADER		02
03	0531060792	AXIS 200 TELESCOPIC HEADER		01
04	0531065027	AXLE FIXER		01
05	0503011052	1.1/4" X 0.77" CASTLE NUT		02
06	0503010038	3/16" X 2" SPLIT PIN		03
07	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		02
08	0531063829	SUPPORT WITH EAR PANTOGRAPHIC HEAD		01
09	0503010012	1" SPRING WASHER		08
10	0503012182	1" NUT		08
11	0531063828	HEAD HITCH		01
12	0501010171	BOLT 1 UNC X 3.1/2 C S G.5		08
13	0501219817	PROTECTION BODY PANTOGRAPHIC HEADER		01
14	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
15	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
16	0503010337	NUT 5/16 UNC G.5 ZN		01
17	0531059875	CYLINDER HYDRAULIC	11	01
18	0531064642	TOP ARM		01
19	0531064641	LOWER SUPPORT FOR PANTOGRAPHIC HEADER		01




Item	Code	Description	See page	QT
01	0531061424	PANTOGRAPHIC HEAD CYLINDER ROD		01
02	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
03	0503010345	2-218 N 3006-9B O'RING		01
04	0502010382	5" END CAP		01
05	0581010353	RING SUPPORT		01
06	0503018026	GASKET 1870-2000-375 B POLYMAX		01
07	0503011453	O'RING		02
08	0503018152	O'RING		02
09	0503018024	RING BS OD050805200171D-BR		01
10	0503018025	RING GUIDE W2-2250-750		01
11	0581010354	PISTON		01
12	0503018150	RING GUIDE W2-5000-984 (4528)		01
13	0503018151	RING BS		02
14	0503010039	D-2000 SCRAPER RING		01
15	0531066083	PANTOGRAPHIC HEADER CYLINDER CASE		01




Item	Code	Description	See page	QT
01	0531065723	MINOR CYLINDER GUIDE		01
02	0591013120	BODY STEM 38.10 X 280		01
03	0502012837	PISTON		01
04	0581010668	RING SUPPORT		01
05	0502010471	63,50 MOBILE CAP		01
06	0503018005	RING		01
07	0503011109	O'RING 2-119 N 3006 9B		01
08	0503018004	RING		01
09	0503018003	GASKET		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018163	BACK-UP RING		02
12	0503018162	O'RING		02
13	0531066084	CASE 63,50 X 285MM		01

REAR HEADER


0541051033



Item	Code	Description	See page	QT
01	0531065841	REAR HEADER BODY		01
02	0591015433	HEADER SUPPORT		04
03	0591015533	ADJUSTMENT SUPPORT		04
04	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		24
05	0503010019	1/2" SPRING WASHER		50
06	0503010002	1800 GREASE FITTING		08
07	0501010276	BOLT		12
08	0503010012	1" SPRING WASHER		14
09	0503012182	1" NUT		14
10	0591015435	NYLON ADJUSTMENT REGULATOR GUIDE		04
11	0591015431	HEADER ADJUSTMENT SUPPORT		04
12	0503011401	1/2" X 3/4" BOLT		24
13	0531062795	PULL ROD 1 UNC 8 FPP X 510		02
14	0501216087	SUPPORT		04
15	0501216086	NYLON ADJUSTMENT LID		04
16	0541050703	SIDE ARM LOCK SET	14	01
17	0501210625	SUPPORT GLOVE		02
18	0503013776	BOLT 1/2 UNC X 7/8 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0531064604	STABILIZER		01
02	0501211914	CYLINDER GUIDE SHAFT		01
03	0503019522	HEX NUT		04
04	0501010164	3/4" X 7 BOLT		02
05	0501010322	20,50 X 46 X 4,00 ZN FLAT WASHER		10
06	0503010880	501032 CLAMPING RING (FOR AXLE)		05
07	0501211910	GUIDE SHAFT SUPPORT WASHER		01
08	0511016281	3/4" X 8" BOLT		02
09	0531064605	UPPER PLATE		02
10	0501215908	SIDE FRAME LOCK		02
11	0501211911	BUSHING		04
12	0501211917	SUPPORT WASHER		02
13	0501211918	AXIS		02
14	0501211913	AXIS		03
15	0501211915	BUSHING		04
16	0531059877	CYLINDER HYDRAULIC 44,45 X 85,70 X 398 X 93		01
17	0531059946	BLOCK WITH RETENTION		01
18	0503036266	HYDRAULIC TUBE PT12L X 87 X FG12L X 50		01
19	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		02
20	0513011686	TERMINAL UNION FG TB12L X FG TB12L		02




Item	Code	Description	See page	QT
01	0501312861	FRONT SUPPORT MAT		02
02	0531066424	GUTTER SUPPORT BASE		01
03	0531059935	CABLE GUIDE HEADER		02
03A	0501311320	CABLE GUIDE HEADER		01
03B	0503010519	1/4" X 5/8" BOLT		02
03C	0503010144	1/4" NUT		02
03D	0501311321	LOCK GUIDE CABLES		01
04	0501310233	GUTTER FIXING PLATE		04
05	0501219500	SUPPORT 70 X 40 X 900		01
06	0501217333	ARTICULATOR AXLE 233		02
07	0501312865	AXIS LOCK SUPPORT GUTTER		01
08	0501312866	ARTICULATOR AXLE 25.40 X 56.50		02
09	0501010100	BOLT 5/8" UNC X 2 CS G.5 ZN		04
10	0503011952	5/16" X 3/4" BOLT		12
11	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		08
12	0501013519	FLAT WASHER		08
13	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
14	0501010694	FLAT WASHER 32,50 X 75 X 4,75		12
15	0503010019	1/2" SPRING WASHER		08
16	0503010027	5/8 SPRING WASHER		04
17	0503010013	5/8 UNC G.5 ZN HEX NUT		04
18	0503013759	NUT		12
19	0541053026	ARTICULATED CONVEYOR ASSEMBLY 1380/1500		01
19A	0531067728	SUPPORT FRONT 1145		01
19B	0531059091	MAT ROLLER 215MM		03
19BA	0501310150	AXIS FIXING HOSE GLOVE 280MM		01
19BB	0501310149	GLOVE 16,30 X 30 X 215MM		01
19BC	0503016739	SELF LOCKING HEX NUT WITH NYLON		02
19BD	0503010743	1/4" X 1-1/4" BOLT		02
20	0541053031	REAR SUPPORT 1270		01


Item	Code	Description	See page	QT
20A	0531067729	REAR SUPPORT 1270		01
20B	0531059091	MAT ROLLER 215MM		02
20BA	0501310150	AXIS FIXING HOSE GLOVE 280MM		01
20BB	0501310149	GLOVE 16,30 X 30 X 215MM		01
20BC	0503016739	SELF LOCKING HEX NUT WITH NYLON		02
20BD	0503010743	1/4" X 1-1/4" BOLT		02
21	0501219996	SUPPORT 70 X 40 X 800		01




Item	Code	Description	See page	QT
01	0501317267	DUCT SUPPORT		01
02	0501317268	DUCT SUPPORT		01
03	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
04	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		04
05	0521014188	FLAT WASHER		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2 UNC G.5 ZN HEX NUT		02
08	0503014378	1/2" X 1-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0531065840	SIDE SUPPORT 4351		01
02	0521057793	KNEECAP WITH RIGHT EXTENSION AXLE		01
03	0531061434	SIDE EXTENSOR EAR		01
04	0501310202	JUNCTION AXLE 34.90/35.00 X 97MM		01
05	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0521056857	ECU APT / TVT BOX WITH EXCHANGE	19	01
02	0501216631	MODULE BOX BASE		01
03	0503013357	3/8 SELF-ADJUSTING NUT		04
04	0501216628	FASTENER 3/8 UNC X 60 X 115		02
05	0591012160	7 X 23 X 2.00 ZN FLAT WASHER		04




Item	Code	Description	See page	QT
01	0503010257	1/8" X 1" SPLIT PIN		02
02	0503010026	3/8" NUT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010144	1/4" NUT		08
05	0503010143	1/4" SPRING WASHER		08
06	0503010237	3/8" X 1" BOLT		04
07	0521068017	BOX BODY APT/TVT		01
08	0571017090	ROD BOX		01
09	0521068016	BOX COVER		01
10	0503018171	FAST LOCK ASSY		02
11	0503010461	BOLT 1/4" UNC X 1" C S G.2 ZN		04
12	0503010282	1/4" X 3/4" BOLT		04




Item	Code	Description	See page	QT
01	0501311680	LEFT GUIDE TRIGGER		01
02	0501311682	NYLON GLOVE 70		02
03	0503010140	1/8" X 3/4" SPLIT PIN		02
04	0501311681	FIXING PIN		02




Item	Code	Description	See page	QT
01	0501311679	RIGHT TRIGGER GUIDE		01
02	0501311682	NYLON GLOVE 70		02
03	0501311681	FIXING PIN		02
04	0503010140	1/8" X 3/4" SPLIT PIN		02




Item	Code	Description	See page	QT
01	0503063819	CARDAN 21Z 1.3/8 X 20Z 1.3/4		01
02	0541050019	MULTIPLIER WITH PUMP	23	01
03	0541050010	SUPPORT WITH HEAT EXCHANGER	25	01
04	0501310425	GUTTER 55 X 50 X 460		01
05	0541052747	COMMAND BLOCK	29	01
06	0541052753	SET FILTERS LINES	31	01
07	0541052748	RIGHT PASSAGE BLOCKS SET	32	01
08	0541052750	ASSY BLOCK LEFT PASSAGE	33	01
09	0541050020	DOUBLE ROTATING DIVIDER	34	01
10	0541053056	CONTROL BLOCK SET	35	01




Item	Code	Description	See page	QT
01	0513010710	MULTIPLIER BOX		01
02	0501217531	REDUCTION BOX FLANGE		01
03	0503015140	M12 X 1,75 X 30 BOLT		08
04	0503015076	M12 SPRING WASHER		08
05	0521014188	FLAT WASHER		08
06	0501217530	GEARBOX CAP		01
07	0513011013	BOLT ALLEN M14 X 2 X 25MM CCSI		08
08	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		02
09	0503011828	FLAT WASHER 13 X 24 X 2,00 ZN		02
10	0503010019	1/2" SPRING WASHER		02
11	0541050014	HYDRAULIC PUMP	24	01




Item	Code	Description	See page	QT
01	0513010724	AXIAL PISTON HYDRAULIC PUMP 63CC - H		01
02	0513010832	ADAPTER TERMINAL MF R.1.5/16 UNF ORING X TB28		01
03	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		01
04	0513010826	KNEE TERMINAL 90G MF TB15 X FG TB15		01
05	0513011689	ADAPTER TERMINAL R.7/16 ORING X TB10L		01
06	0541051231	NIPLE WITH ROTATING DUCT		01




Item	Code	Description	See page	QT
01	0541050009	TANK 180 LITER COMPLETE	26	01
02	0541050012	RADIATOR EQUIPMENT	27	01
03	0501214600	LEFT SUPPORT 180L OIL RESERVOIR		01
04	0501214601	RIGHT SUPPORT 180L OIL RESERVOIR		01
05	0503010019	1/2" SPRING WASHER		07
06	0503011828	FLAT WASHER 13 X 24 X 2,00 ZN		15
07	0503010060	1/2 UNC G.5 ZN HEX NUT		08
08	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		08
09	0501010125	3/4" X 2-1/2" BOLT		08
10	0503011075	UNC NUT 3/4 UNC ALTA G.5 ZN		08
11	0501010322	20,50 X 46 X 4,00 ZN FLAT WASHER		08
12	0531059117	FULL HEAD HOSE STABILIZER	28	01




Item	Code	Description	See page	QT
01	0503063771	180 LITER TANK		01
02	0503015406	SUCTION FILTER		01
03	0513010698	RETURN FILTER IN TANK 310 LITERS		01
04	0513011030	FILLING NOZZLE WITH AIR FILTER AND PRESSURIZATION		01
05	0503063547	VISOR LEVEL		01
06	0513010029	BALL VALVE 2 NPT 11.5 FPP		01
07	0503063970	THREADED PLUG 1.5/16 UNF		01
08	0503063968	THREADED PLUG 3/4 UNF		01
09	0513011717	ADAPTER TERMINAL MF 2 BSP X TB42		01
10	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		02
11	0513011209	ORIGINAL ER.1.1/2 BSP ADAPTER TERMINAL		01
12	0503063773	SUPPLY NOZZLE		01
13	0513010344	SHOCK ABSORBER/VIBRATION CUSHION		04
14	0501217469	CAP 1.1/4 BSP - 11FPP		01
15	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
16	0571011721	FLAT WASHER 40 X 13.50 X 3.00		08
17	0503015076	M12 SPRING WASHER		08
18	0503011334	3/8 UNC X 3/4 CS G.5 ZN BOLT		03
19	0503010025	3/8 SPRING WASHER		03
20	0503010179	LOCK WASHER 5/16 ZN 1K01528		06




Item	Code	Description	See page	QT
01	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
02	0501013518	FLAT WASHER		16
03	0503010025	3/8 SPRING WASHER		10
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
05	0503019952	RUBBER BUSHING 14 X 40 X 40		06
06	0503011268	3/8" X 2-1/2" BOLT		06
07	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
08	0503010026	3/8" NUT		10
09	0571016789	PRISONER 3/8 UNC X 5/16 UNC X 65		04
10	0501218150	HEAT EXCHANGER SUPPORT		01
11	0591012708	CANVAS RADIATOR PROTECTION		01
12	0541050011	HEAT EXCHANGER		01
12A	0503063086	HEAT EXCHANGER		01
12B	0513010820	ADAPTER TERMINAL MF 1 BSP X TB35		01
12C	0513011688	ADAPTER TERMINAL MF 1 BSP X TB28		01




Item	Code	Description	See page	QT
01	0531061934	CONDUCTOR ARTICULATOR GUIDE		01
02	0531061935	CONDUCTOR ARTICULATOR		01
03	0503010237	3/8" X 1" BOLT		01
04	0503010025	3/8 SPRING WASHER		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503012556	1/2" X 1" BOLT		01




Item	Code	Description	See page	QT
01	0541052751	HYDRAULIC CONTROL BLOCK	30	01
02	0501313063	COMMAND BLOCK SUPPORT		01
03	0503010172	M10 X 1,5 X 25 BOLT		04
04	0503011196	3/4" X 2-1/4" BOLT		04
05	0501013518	FLAT WASHER		04
06	0511015255	FLAT WASHER		08
07	0503015075	M10 SPRING WASHER		04
08	0503010023	3/4" SPRING WASHER		04
09	0503012183	SNC 3/4" ZIN 1K03097 NUT		04




Item	Code	Description	See page	QT
01	0513010785	HYDRAULIC CONTROL BLOCK CYLINDERS 6AT		01
02	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		03
03	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		13




Item	Code	Description	See page	QT
01	0501317071	LINE FILTERS FIXER		01
02	0541050529	PDA FILTER		02
03	0501317070	FIXER TOP LINE FILTERS		01
04	0503019416	RIVET SCREW THREAD INTERNAL		02
05	0501013518	FLAT WASHER		02
06	0503010025	3/8 SPRING WASHER		04
07	0503011268	3/8" X 2-1/2" BOLT		02
08	0503010026	3/8" NUT		02
09	0503010849	3/8" X 1-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0501317069	BLOCK SUPPORT 04 WAY		01
02	0503011776	SELF-LOCKING HEX NUT		02
03	0513011659	M6 X 1,00 X 55 - SXR6X55ZI BOLT		02
04	0503010025	3/8 SPRING WASHER		03
05	0503010026	3/8" NUT		03
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		03
07	0541016892	10,50 X 22 X 2,00 FLAT WASHER		03
08	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		09
09	0513010674	DISTRIBUTOR BLOCK 4 WAYS		01
10	0513010841	ADAPTER TERMINAL MF R.3/4 UNF ORING X MF TB10L		03




Item	Code	Description	See page	QT
01	0501317069	BLOCK SUPPORT 04 WAY		01
02	0503011776	SELF-LOCKING HEX NUT		02
03	0513011659	M6 X 1,00 X 55 - SXR6X55ZI BOLT		02
04	0503010025	3/8 SPRING WASHER		03
05	0503010026	3/8" NUT		03
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		03
07	0541016892	10,50 X 22 X 2,00 FLAT WASHER		03
08	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		09
09	0513010674	DISTRIBUTOR BLOCK 4 WAYS		01
10	0503063968	THREADED PLUG 3/4 UNF		03




Item	Code	Description	See page	QT
01	0503019810	DOUBLE ROTATING DIVIDER		01
02	0503010237	3/8" X 1" BOLT		04
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
04	0503013357	3/8 SELF-ADJUSTING NUT		04
05	0513011034	ADAPTER TERMINAL MF R7/8 UNF ORING X MF TB12L		02
06	0513011687	ADAPTER TERMINAL MF R.1.1/16 UN ORING X MF TB12L		01




Item	Code	Description	See page	QT
01	0531059987	DRIVING BLOCK	36	01
02	0531059990	ROTATING DIVIDER	37	01
03	0513010828	TERMINAL KNEEL		03
04	0503015112	M10 X 1,5 X 30 BOLT		07
05	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0503010026	3/8" NUT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0501010984	10,50 X 27 X 3,00 FLAT WASHER		11
10	0503011828	FLAT WASHER 13 X 24 X 2,00 ZN		08
11	0503010025	3/8 SPRING WASHER		04
12	0503015075	M10 SPRING WASHER		07
13	0503010019	1/2" SPRING WASHER		04
14	0531059985	BLOCK HYDRAULIC COMMAND	38	01
15	0531066484	SUPPORT BLOCKS		01
16	0531066491	LIFTING DRIVE BLOCK SUPPORT		01
17	0503036405	HYDRAULIC TUBE FG28 X FG28 X 116		02
18	0503012183	SNC 3/4" ZIN 1K03097 NUT		04
19	0503010023	3/4" SPRING WASHER		04
20	0511017305	FLAT WASHER		08
21	0501010098	BOLT 3/4" UNC X 2 C S G.5 ZN		04




Item	Code	Description	See page	QT
01	0503063488	HYDRAULIC CONTROL BLOCK		01
02	0513011034	ADAPTER TERMINAL MF R7/8 UNF ORING X MF TB12L		12
03	0513010831	ADAPTER TERMINAL MF R.1.1/16		01




Item	Code	Description	See page	QT
01	0513010747	HYDRAULIC ROTATING DIVIDER		01
02	0513011034	ADAPTER TERMINAL MF R7/8 UNF ORING X MF TB12L		04
03	0513010832	ADAPTER TERMINAL MF R.1.5/16 UNF ORING X TB28		01




Item	Code	Description	See page	QT
01	0513010721	HYDRAULIC CONTROL BLOCK		01
02	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		02
03	0513010832	ADAPTER TERMINAL MF R.1.5/16 UNF ORING X TB28		04
04	0513010839	ADAPTER TERMINAL MF R.1/4 BSP ORING X MF TB10L		01
05	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		02
06	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		02




Item	Code	Description	See page	QT
01	0513011218	SHT BCE 5474.2 BLOCK CONTROL PANEL		01
02	0513010994	LIGHTHOUSE HARNESS LED LANTERN 12 METERS BCE 5403.1		01
03	0513010975	LIGHTHOUSE EXTENSION 3 HOLES ECB 5381.9		02
04	0503019926	BLOCK WHIP WITH ECB 4555.9		01
05	0503019291	SUPPORT SENSOR		02
06	0501217647	SHT PANEL FIXING PLATE		01
07	0503016234	FIXING VACUUM TRIMBLE 91357-AG		01
08	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
09	0503018829	NYLON CLAMP 7,8 X 1,8 X 390 MM		20
10	0503019902	NYLON CLAMP 7,8X1,8X225 MM		80
11	0503019924	BLOCK WHIP WITH ECB TREAT 4554.2		01
12	0513011205	HEAT EXCHANGER SWITCH PANEL		01
13	0513011204	TRACTOR POWER SWITCH CABLE 5463.5		01
14	0503019307	CABLE TRACTOR HEADLIGHT		01
15	0503062594	IMPLEMENT SWITCH CABLE (EXTENSION)		01
16	0503019305	WHIP		01
17	0513010191	BOLT		03
18	0503018774	MAGNETIC SENSOR		01
19	0503018775	MAGNETIC ACTUATOR LH7.4.000091		01




Item	Code	Description	See page	QT
01	0541053110	SWIVEL WHEELS HOSE GAME	41	01
02	0541053111	HOSE GAME APT	42	01
03	0541053112	HOSE GAME LIFT	43	01
04	0541053113	GAME HOSE JOINT LINES	44	01
05	0541053114	PANTOGRAPHIC OPEN/CLOSE HOSE GAME	45	01




Item	Code	Description	See page	QT
01	0501083256	HOSE 1/2 X 800 FG TB15 X FG C90 TB15		02
02	0501082899	HOSE 3/8 X 1100 FG TB12L X FG C90 TB12L		03
03	0501083006	HOSE 3/8 X 700 FG TB12L X FG C90 TB12L		03
04	0501083008	HOSE 3/8 X 600 FG TB12L X FG TB12L		06
05	0501082987	HOSE 3/8 X 1400 FG TB12L X FG C90 TB12L		02
06	0501083081	HOSE 3/8 X 800 FG TB12L X FG TB12L		02
07	0501083259	HOSE 1/4 X 1200 FG TB10L X FG C90 TB10L		01
08	0501083261	HOSE 1/4 X 600 FG TB10L X FG TB10L		02
09	0501083258	HOSE 1/4 X 700 FG TB10L X FG C90 TB10L		01
10	0501083259	HOSE 1/4 X 1200 FG TB10L X FG C90 TB10L		02
11	0501083260	HOSE 1/4 X 1000 FG TB10L X FG C90 TB10L		02
12	0501082945	HOSE 3/8 X 1200 FG TB12L X FG C90 TB12L		02
13	0501082881	HOSE 3/8 X 1000 FG TB12L X FG C90 TB12L		02
14	0501082945	HOSE 3/8 X 1200 FG TB12L X FG C90 TB12L		03
15	0501083257	HOSE 1/4 X 1100		01




Item	Code	Description	See page	QT
01	0501082982	HOSE 1.1/4 X 1100 FG TB35 X FG TB35		01
02	0501082913	HOSE 1/2 X 3900 FG TB15 X FG C90 TB15		01
03	0501082917	HOSE 2 X 1400		01
04	0501083102	HOSE1 X 7200 FG TB28 X FG TB28		01
05	0501083268	HOSE 1/4 X 7200 FG TB10L X FG C90 TB10L		01
06	0501082999	HOSE 1 X 6000 FG TB28 X FG TB28		01
07	0501082910	HOSE 1/4 X 500 FG TB10L X FG C90 TB10L		01
08	0501082976	HOSE 1/2 X 2550 FG TB15 X FG C90 TB15		02
09	0501082991	HOSE 1/2 X 1000 FG TB15 X FG C90 TB15		01
10	0501083124	HOSE 1/2 X 1200 FG TB15 X FG C90 TB15		01
11	0501082977	HOSE 1/2 X 2000 FG TB15 X FG C90 TB15		01
12	0501082633	HOSE 1/2 X 3300 FG TB15 X FG C90 TB15		01
13	0501083263	HOSE 1/2 X 600 FG TB15 X FG TB15		04
14	0501083266	HOSE 1/2 X 500 FG TB15 X FG C90 TB15		02
15	0501082936	HOSE 1/2 X 1300 FG TB15 X FG C90 TB15		02
16	0501083087	HOSE 1/2 X 1650 FG TB15 X FG C90 TB15		02
17	0501082877	HOSE 1/2 X 1700 FG TB15 X FG C90 TB15		01
18	0501082811	HYDRAULIC HOSE 1/2 X 2100		01




Item	Code	Description	See page	QT
01	0501082986	HOSE 3/8 X 1400 FG TB12L X FG TB12L		04
02	0501082947	HOSE 3/8 X 2300 FG TB12L X FG C90 TB12L		02
03	0501082892	HOSE 3/8 X 2700 FG TB12L X FG C90 TB12L		02
04	0501082987	HOSE 3/8 X 1400 FG TB12L X FG C90 TB12L		02
05	0501082948	HOSE 3/8 X 1100 FG TB12L X FG TB12L		02
06	0501082988	HOSE 3/8 X 550 FG TB12L X FG C90 TB12L		01
07	0501082983	HOSE 3/8 X 500 FG TB12L X FG C90 TB12L		01
08	0501082942	HOSE 3/8 X 450 FG TB12L X FG C90 TB12L		01
09	0501082897	HOSE 3/8 X 400 FG TB12L X FG C90 TB12L		01
10	0501083008	HOSE 3/8 X 600 FG TB12L X FG TB12L		04




Item	Code	Description	See page	QT
01	0501082983	HOSE 3/8 X 500 FG TB12L X FG C90 TB12L		01
02	0501082942	HOSE 3/8 X 450 FG TB12L X FG C90 TB12L		01
03	0501083000	HOSE 3/8 X 6100 FG TB12L X FG TB12L		02
04	0501082899	HOSE 3/8 X 1100 FG TB12L X FG C90 TB12L		04
05	0501082899	HOSE 3/8 X 1100 FG TB12L X FG C90 TB12L		02
06	0501082945	HOSE 3/8 X 1200 FG TB12L X FG C90 TB12L		02
07	0501083006	HOSE 3/8 X 700 FG TB12L X FG C90 TB12L		02
08	0501083008	HOSE 3/8 X 600 FG TB12L X FG TB12L		04
09	0501082956	HOSE 3/8 X 1700 FG TB12L X FG C90 TB12L		02
10	0501083121	HOSE 3/8 X 1800 FG TB12L X FG C90 TB12L		02




Item	Code	Description	See page	QT
01	0501082899	HOSE 3/8 X 1100 FG TB12L X FG C90 TB12L		02
02	0501082890	HOSE 3/8 X 1250 FG TB12L X FG C90 TB12L		02
03	0501082945	HOSE 3/8 X 1200 FG TB12L X FG C90 TB12L		02
04	0501082899	HOSE 3/8 X 1100 FG TB12L X FG C90 TB12L		02
05	0501083001	HOSE 3/8 X 5400 FG TB12L X FG TB12L		02



Item	Code	Description	See page	QT
01	0531064859	AXLE LOCK		01
02	0502040080	FLANGE NUT R.2.1/2" UN		01
03	0503010002	1800 GREASE FITTING		01
04	0503012213	1/4" X 4" SPLIT PIN		01




Item	Code	Description	See page	QT
01	0531059086	RIGHT SIDE SILO	48	01
02	0503010026	3/8" NUT		05
03	0503010025	3/8 SPRING WASHER		05
04	0503011087	3/8" X 1" BOLT		03
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
06	0501013518	FLAT WASHER		05
07	0503063477	SILO ASSY FERTILIZER WITH 10 OUTPUTS		02
08	0503063478	SEED SILO WITH 10 OUTLETS COMPLETE		02
09	0531065779	SILO LOCK		04
10	0503013389	5/8" SELF LOCKING NUT		08
11	0501219994	CORNER 1.1/2 X 1.1/2 X 3/16 X 946		04
12	0531065780	SILO LOCK		04
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		18
14	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		09
15	0503011082	C1/2" X 1.3/4" SCREW		09




Item	Code	Description	See page	QT
01	0531065814	RIGHT SIDE SILO SUPPORT		01
02	0571017643	AXLE FERTILIZER LOCK SLEEVE		03
03	0503017021	M8 X 0.5" BOLT		45
04	0502012325	SEED REGULATOR BEARING		01
05	0551019597	SEED REGULATION STEERING WHEEL		01
06	0571015340	AXIS		01
07	0503012882	BEARING		02
08	0503012104	501015 CLAMPING RING (FOR AXLE)		01
09	0503011945	503050 CLAMPING RING (FOR AXLE)		01
10	0511015098	FLAT WASHER		01
11	0503031035	HITCH PIN CLIP		01
12	0503032990	SEED DISTRIBUTOR HOPPER ASSY	49	20
13	0503011953	5/16" X 1" BOLT		80
14	0503010337	NUT 5/16 UNC G.5 ZN		80
15	0501010694	FLAT WASHER 32,50 X 75 X 4,75		80
16	0501210310	SQUARE SEED AXLE 15.88 X 3446 MM		01
17	0571017641	LARGER DOSER		01
18	0503030886	SCALE DOSER		01
19	0581010116	SUPPORT SCALE SEED		01
20	0503010001	RIVET 3,2 X 5,5		02
21	0501210311	SQUARE FERTILIZER SHAFT 3/4 X 3342		01
22	0503011099	GREASE FITTING		01
23	0503010010	SPLIT PIN 1/4" X 2.1/2"		01
24	0531059057	SEED COMPLETE BEARING	50	01
25	0531062737	REGULATOR BRACKET		01
26	0531059056	DOSER FERTILIZER ALPHA II	51	20
27	0503010237	3/8" X 1" BOLT		02
28	0503010026	3/8" NUT		02
29	0503010025	3/8 SPRING WASHER		02
30	0501310257	SQUARE LOCK GLOVE 5/8		40


Item	Code	Description	See page	QT
31	0531059058	DOUBLE GEAR BEARING SET	56	01
32	0531065778	38Z GEAR WITH 19.5 SQUARE HOLE		01
33	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		12
34	0503013357	3/8 SELF-ADJUSTING NUT		12
35	0511073136	SILO FIXING SUPPORT		06



Item	Code	Description	See page	QT
01	0503015222	BUSHING		01
02	0503014540	M6 NUT		01
03	0503015223	LARGER COVER		01
04	0503015224	DISTRIBUTOR		01
05	0503015225	SMALLER COVER		01
06	0503011397	M5 X 0.3" NUT		01
07	0503015226	REGULATOR FLOW		01
08	0503015227	GRAPHITIZED RING		01
09	0503015228	TOOTHED WASHER		01
10	0503015229	TOOTH LOCKWASHER COVER		01
11	0503015230	M5 BOLT		01
12	0503015231	ROTOR		01
13	0503015232	M 6 X 12 BOLT		01
14	0503015233	COVER		01



Item	Code	Description	See page	QT
01	0503010372	501050 CLAMPING RING (FOR AXLE)		01
02	0503010025	3/8 SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0503010003	1845 GREASE FITTING		01
05	0503030832	FLAT WASHER		01
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
07	0531065777	17 TOOTH GEAR		01
08	0501110359	OUTER BEARING ASSY		01




Item	Code	Description	See page	QT
01	0503035911	REAR COLLECTOR SEAL		01
02	0503035912	FRONT COLLECTOR SEAL		01
03	0503035797	FRONT COLLECTOR FIXER		02
04	0531055863	TRANSMISSION HUB ASSY	52	01
05	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	53	01
06	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
06A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
06B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
07	0501214337	FERTILIZER METERING BOX		01
08	0503036182	LOWER FLANGE		01
09	0531059139	COLLECTOR ASSY	54	01
10	0503036177	LID CORD		01
11	0501111197	FERTILIZER COATING		01
12	0531058988	P.16 ENDLESS THREAD WITH COATING		01
12A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
12B	0503035859	SUPPORT SLEEVE		01
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		04
14	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
15	0513011173	NUT 3/8 UNC X 1		04
16	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0513011171	1/4 NC HEX NUT		08
19	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
20	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
21	0503036206	FERTILIZER SYSTEM ADHESIVE LABEL ALPHA		01
22	0513011628	BOLT ALLEN 1/4 UNC X 1		04




USAP 3200 GF - FRAME 11040
DOSER FERTILIZER ALPHA II

Page 51
0531059056


Item	Code	Description	See page	QT
23	0501312601	FRONT COVER		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO DECAL		01
15	0503035316	LUBRICATED POINTS DECAL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT FERTILIZER METERING LID GUIDE		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	55	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0531057912	DOUBLE SIDE BEARING	57	01
02	0501219987	SIDE BEARING AXLE		01
03	0503010845	501035 CLAMPING RING (FOR AXLE)		01
04	0503010337	NUT 5/16 UNC G.5 ZN		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
07	0503010371	5/16" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0502013071	SIDE BEARING		01
02	0503016065	ROLLER BEARING		02
03	0503011800	SEAL RING		01




Item	Code	Description	See page	QT
01	0501013519	FLAT WASHER		12
02	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		08
03	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		06
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		07
05	0503013357	3/8 SELF-ADJUSTING NUT		14
06	0501013518	FLAT WASHER		20
07	0501011643	3/8 X 1"BOLT		08
08	0531065820	CENTER SUPPORT RIGHT PLATFORM RIGHT		01
09	0531065822	SUPPORT RIGHT PLATFORM		01
10	0501310124	SIDE PLATFORM 3492		01
11	0531065824	FRONT HANDRAILING		01
12	0531065825	SUPPORT RIGHT PLATFORM RIGHT SIDE		01
13	0531065827	MOBILE RIGHT STAIRCASE		01
14	0531065817	LADDER WITH 03 MOBILE STEPS		01
15	0531059090	ARTICULATED PLATFORM	59	01
16	0511059383	INTERNAL HANDRAILING FIXER	60	02
17	0501210097	HANDRAILING BODY		01
18	0503010734	1/2" X 2-1/2" BOLT		02
19	0503011333	COVER FIXER		02
20	0503010274	5/32" X 2" SPLIT PIN		02
21	0531065816	HANDRAILING SUPPORT		01
22	0503010849	3/8" X 1-1/2" BOLT		01
23	0503010025	3/8 SPRING WASHER		02
24	0503010026	3/8" NUT		02
25	0501310116	LADDER SUPPORT		01
26	0531065818	LADDER RIGHT SUPPORT		01
27	0503030285	HITCH PIN CLIP		01
28	0501310120	NYLON SLIDING GLOVE		02
29	0503010038	3/16" X 2" SPLIT PIN		02




Item	Code	Description	See page	QT
01	0501310112	PLATFORM ACCESS 460		01
02	0501210116	ARTICULATION BUCKING		02
03	0503013357	3/8 SELF-ADJUSTING NUT		02
04	0501210117	PLATE 700 X 130 X 10		01
05	0503015341	POP RIVET		04
06	0501210115	WASHER 4.20 X 11 X 2		04
07	0501214253	FLAT WASHER		02
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02




Item	Code	Description	See page	QT
01	0502012857	EXTERNAL FIXER HANDRAIL		01
02	0502012858	INTERNAL FIXER HANDRAIL		01
03	0503019083	7/16 UNC X 2.1/4 C S R P G.5 ZN BOLT		01
04	0503015490	SELF-LOCKING NUT 7/16		01




Item	Code	Description	See page	QT
01	0581010302	RING OF SUPPORT		01
02	0502012822	END CAP 4"		01
03	0503011061	8-342 BACK-UP RING		02
04	0503010338	2-342 N 3006-9B O'RING		02
05	0503017936	RING		01
06	0503017938	RING GUIDE		01
07	0503017937	GASKET		01
08	0503010761	D-1750 SCRAPER RING		01
09	0503018045	2-130 (AGEL) O'RING		04
10	0531064847	ROTATING CYLINDER ROD		01
11	0581010837	PISTON		01
12	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
13	0503015633	SELEMASTER SEALING		01
14	0503018029	O'RING 2-217 N 3006 90B		01
15	0503010002	1800 GREASE FITTING		01
16	0531066450	CILINDER CASE 101,60 X 497		01




Item	Code	Description	See page	QT
01	0531065808	TUBE FIXATION		01
02	0541050280	RIGHT SEED FERTILIZER DISTRIBUTOR ROW DDD 63 15X15 CPL	63	17
03	0531059081	ROW ARTICULATED FERTILIZER/SEED DISTRIBUTOR LEFT	76	02
04	0541050279	ROW DISTRIBUTOR RIGHT FERTILIZER/SEED	77	03
05	0541050956	SIDE ARTICULATION SUPPORT	79	02
06	0541051028	CENTER RIGHT JOINT SUPPORT	80	01
07	0541051162	SUPPORT HOSE	82	06




Item	Code	Description	See page	QT
01	0591019832	ARTICULATOR AXLE 30X150 WITH HOLES		01
02	0531065766	LOWER FRONT PANTOGRAPH		01
03	0531065767	FRONT UPPER PANTOGRAPH		01
04	0591019825	AXLE 25.40 X 150 WITH HOLE		01
05	0503013389	5/8" SELF LOCKING NUT		06
06	0503010131	3/16" X 1.1/2" SPLIT PIN		02
07	0503010577	3/16" X 1.1/4" SPLIT PIN		04
08	0503030520	SEED SOCKET		01
09	0503030483	FERTILIZER SOCKET		01
10	0501013519	FLAT WASHER		02
11	0503011336	1/2" HEX SELF ADJUSTING NUT		02
12	0531065768	PANTOGRAPH ARM		01
13	0591019821	AXIS 20.80 X 150		01
14	0503034469	NOZZLE SUPPORT		01
15	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
16	0591019820	SPACER BUSHING		08
17	0503019273	AUTO LUBRICANT SLEEVE		08
18	0501013867	BOLT 5/8" UNC X 6 CS G.5 ZN		04
19	0503010045	O'RING		08
20	0531065774	SUPPORT		01
21	0501010301	FLAT WASHER 16 X 29,50 X 3,00		02
22	0501213051	LOCK PIN		02
23	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
24	0502013063	LOCK FASTENER		01
25	0531059053	SPRING WITH EARS	64	02
26	0541050281	SUPPORT RIGHT DDD 15X15 S/L CPL	65	01
27	0531059909	GAUGE WHEEL DEPTH CONTROL	70	01
28	0503010734	1/2" X 2-1/2" BOLT		02
29	0513011693	R 2,5 X 40MM COTTER PIN		02




Item	Code	Description	See page	QT
01	0503034397	TRACTION SPRING E53,5 X 207 X 8		01
02	0531065775	SPRING HITCH EAR		02




Item	Code	Description	See page	QT
01	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 66 FERTILIZER / SEED		01
02	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 67 FERTILIZER / SEED		01
03	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
06	0503010025	3/8 SPRING WASHER		01
07	0503010026	3/8" NUT		01
08	0503010849	3/8" X 1-1/2" BOLT		01
09	0531065760	RIGHT DDD FRONT PROTECTOR		01
10	0503010011	5/16" X 1/2" BOLT		02
11	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
12	0502012895	RIGHT DDD SUPPORT 15 X 15		01
13	0511015098	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521055865	FERTILIZER/SEED LEFT HUB ASSY	68	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055864	FERTILIZER/SEED RIGHT HUB ASSY	69	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUBLE DISC AXLE		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O-RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0501055187	DEPTH WHEEL	71	02
02	0503013816	5/16" LOCKNUT		08
03	0503010358	5/16" X 5/8" BOLT		08
04	0531059911	DEPTH WHEEL SUPPORT	72	01
05	0531059910	SEMI-ASSEMBLED DEPTH CONTROL	73	01




Item	Code	Description	See page	QT
01	0503032005	RUBBER BAND		01
02	0541011628	DEPTH WHEEL RIM SEMI		02
03	0503010519	1/4" X 5/8" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0503013357	3/8 SELF-ADJUSTING NUT		04
02	0503010683	0,2" X 1,2" SPRING PIN		01
03	0503034830	REGULATION LATCH		01
04	0502013089	REGULATOR CRANK		01
05	0503019405	SLEEVE		01
06	0502013090	DEPTH WHEEL LEFT SUPPORT		01
07	0502013091	DEPTH WHEEL RIGHT SUPPORT		01
08	0501311276	SPINDLE WHEEL BEARING DEPTH		01
09	0503010849	3/8" X 1-1/2" BOLT		03
10	0503011179	3/8" X 2-1/4" BOLT		01
11	0501311277	HEIGHT REGULATOR SPINDLE		01
12	0501311278	GUIDE PIN		02
13	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521062602	LOCK DEPTH CONTROL		01
02	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
03	0541011627	FLAT WASHER		01
04	0503010140	1/8" X 3/4" SPLIT PIN		01
05	0521056710	LEFT DEPTH CONTROL HUB	74	01
06	0521056711	RIGHT DEPTH CONTROL HUB	75	01
07	0503011336	1/2" HEX SELF ADJUSTING NUT		01
08	0531060687	REGULATORY LEVER SHAFT		01
09	0591014936	DEPTH CONTROL REGULATOR SHAFT		01
10	0503035159	SCALE CONTROL DEPTH 0 TO 8		01
11	0503010001	RIVET 3,2 X 5,5		02
12	0531066113	DEPTH CONTROL INNER SUPPORT		01




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL HUB		01
02	0581019858	LEFT AXLE CHECK DEPTH		01
03	0503019342	ROLLER BEARING		01
04	0581019168	DUST CLOAK		01
05	0503034055	CLAMPING RING		01
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0521019178	PROTECTION LID		01
09	0503010143	1/4" SPRING WASHER		03
10	0503011105	SEAL RING		01
11	0503014729	1/4" UNF X 1/2" BOLT		03




Item	Code	Description	See page	QT
01	0581019513	DEPTH WHEEL HUB		01
02	0581019859	RIGHT AXLE CHECK DEPTH		01
03	0503019342	ROLLER BEARING		01
04	0581019168	DUST CLOAK		01
05	0503034055	CLAMPING RING		01
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0521019178	PROTECTION LID		01
09	0503010143	1/4" SPRING WASHER		03
10	0503011105	SEAL RING		01
11	0503014729	1/4" UNF X 1/2" BOLT		03




Item	Code	Description	See page	QT
01	0531065812	SUPPORT		01
02	0501310104	SUPPORT		02
03	0503010002	1800 GREASE FITTING		02
04	0503016110	BOLT 5/8 UNC X 4 C S G.7 ZN		02
05	0503010811	5/8" UNF SELF ADJUSTING NUT		02
06	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		02




Item	Code	Description	See page	QT
01	0591019832	ARTICULATOR AXLE 30X150 WITH HOLES		01
02	0531065766	LOWER FRONT PANTOGRAPH		01
03	0531065767	FRONT UPPER PANTOGRAPH		01
04	0591019825	AXLE 25.40 X 150 WITH HOLE		01
05	0503013389	5/8" SELF LOCKING NUT		04
06	0503010131	3/16" X 1.1/2" SPLIT PIN		02
07	0503010577	3/16" X 1.1/4" SPLIT PIN		04
08	0503030520	SEED SOCKET		01
09	0503030483	FERTILIZER SOCKET		01
10	0501013519	FLAT WASHER		02
11	0503011336	1/2" HEX SELF ADJUSTING NUT		02
12	0531065768	PANTOGRAPH ARM		01
13	0591019821	AXIS 20.80 X 150		01
14	0511059653	SPRING	78	02
15	0503034469	NOZZLE SUPPORT		01
16	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
17	0591019820	SPACER BUSHING		08
18	0503019273	AUTO LUBRICANT SLEEVE		08
19	0501013867	BOLT 5/8" UNC X 6 CS G.5 ZN		04
20	0503010045	O'RING		08
21	0531059909	GAUGE WHEEL DEPTH CONTROL	70	01
22	0503010734	1/2" X 2-1/2" BOLT		02
23	0501213051	LOCK PIN		02
24	0541050281	SUPPORT RIGHT DDD 15X15 S/L CPL	65	01
25	0513011693	R 2,5 X 40MM COTTER PIN		02




Item	Code	Description	See page	QT
01	0503034397	TRACTION SPRING E53,5 X 207 X 8		01
02	0521067185	EAR GEAR SPRING		02




Item	Code	Description	See page	QT
01	0503010019	1/2" SPRING WASHER		04
02	0503011075	UNC NUT 3/4 UNC ALTA G.5 ZN		06
03	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		06
04	0531062601	JUNCTION AXLE 30 X 170 WITH HANDLE		01
05	0503030085	LOCK PIN		01
06	0502013064	SUPPORT		01
07	0503063448	TELESCOPIC ACTUATOR		01
08	0502012789	FIXER SUPPORT FERTILIZER ROW		01
09	0503017857	BOLT 5/8 UNF 4		04
10	0503010811	5/8" UNF SELF ADJUSTING NUT		04
11	0501310098	LOCKING PIN		01
12	0531065810	SUPPORT		01
13	0503010880	501032 CLAMPING RING (FOR AXLE)		02
14	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		06
15	0531065811	FASTENING FLANGE		02
16	0503010834	1/2 X 1 BOLT		04
17	0501010098	BOLT 3/4" UNC X 2 C S G.5 ZN		06
18	0531066702	SIDE SUPPORT		01
19	0501313855	SUPPORT		06



Item	Code	Description	See page	QT
01	0502013023	SUPPORT		01
02	0503011075	UNC NUT 3/4 UNC ALTA G.5 ZN		06
03	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		06
04	0531062601	JUNCTION AXLE 30 X 170 WITH HANDLE		01
05	0501213053	HEADLESS PIN 1.1/4 X 170		01
06	0503010131	3/16" X 1.1/2" SPLIT PIN		02
07	0503030085	LOCK PIN		01
08	0503014182	SELF-ADJUSTING NUT		02
09	0531065802	SUPPORT		01
10	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		06
11	0501010098	BOLT 3/4" UNC X 2 C S G.5 ZN		06
12	0531065803	JOINT SHAFT 31,75		01
13	0503031035	HITCH PIN CLIP		01
14	0501310087	THREADED PIN 257		02
15	0503010002	1800 GREASE FITTING		02
16	0531059076	RIGHT JOINT SUPPORT		01
16A	0531065804	RIGHT JOINT SUPPORT		01
16B	0503010019	1/2" SPRING WASHER		04
16C	0503010479	BOLT		04
17	0531059079	LEFT JOINT SUPPORT		01
17A	0531065807	LEFT JOINT SUPPORT		01
17B	0503010019	1/2" SPRING WASHER		04
17C	0503010479	BOLT		04
18	0541050962	HYDRAULIC CYLINDER LEFT	81	01
19	0531066742	CENTER JOINT SUPPORT		01
20	0501313855	SUPPORT		06
21	0531066758	RIGHT REAR SUPPORT		01




Item	Code	Description	See page	QT
01	0531063669	EXTENDER 50.80X227.50 WITH BUSHING 32.50		01
02	0503010003	1845 GREASE FITTING		01
03	0581010678	50,80 X 101 RING SUPPORT		01
04	0503015636	SCRAPER SEAL		01
05	0503018025	RING GUIDE W2-2250-750		01
06	0503018026	GASKET 1870-2000-375 B POLYMAX		01
07	0503010338	2-342 N 3006-9B O-RING		02
08	0503011061	8-342 BACK-UP RING		02
09	0502012822	END CAP 4"		01
10	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
11	0503010345	2-218 N 3006-9B O-RING		01
12	0503015633	SELEMASTER SEALING		01
13	0502012842	50,80 X 101,60 PISTON		01
14	0531066586	LEFT CYLINDER BARREL 101,60 X 249		01



Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
02	0503010060	1/2 UNC G.5 ZN HEX NUT		02
03	0503010019	1/2" SPRING WASHER		02
04	0501313891	CONDUCTOR LOCK PIN		04
05	0531066711	HOSE SUPPORT		01
06	0503013759	NUT		04
07	0513011693	R 2,5 X 40MM COTTER PIN		04


RIGHT WHEELS

0541051654



Item	Code	Description	See page	QT
01	0531066958	RIGHT SIDE WHEEL CHASSIS		01
02	0501214463	SIDE WHEEL PULLEY		06
03	0503014559	ROLLER BEARING		02
04	0503010095	SEAL		01
05	0501213909	WHEELED HUB COVER		01
06	0502040080	FLANGE NUT R.2.1/2" UN		01
07	0503010002	1800 GREASE FITTING		13
08	0501213917	ADJUSTMENT WASHER		01
09	0503012213	1/4" X 4" SPLIT PIN		01
10	0531066281	SIDE WHEEL TOWER		01
11	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
13	0501214462	NYLON PULLEY BUSHING		12
14	0501214303	WHEEL CHAIN		06
15	0531064110	PULLEY LOCK AXLE		06
16	0503010834	1/2 X 1 BOLT		06
17	0503010019	1/2" SPRING WASHER		06
18	0591017921	BRONZE GLOVE 90.5 X 115 X 91		02
19	0501214460	AXLE 1.1/2 X 140MM		01
20	0503010390	SEAL RING		02
21	0531055358	COMPLETE SIDE CYLINDER BEARING	84	02
22	0531055357	LOCK PIN SET	85	01
23	0501214302	ADJUSTMENT COVER PLATE		06
24	0503034377	3/8 UNC X 3/4 BOLT		36
25	0503010025	3/8 SPRING WASHER		36
26	0501017065	FLAT WASHER		06
27	0503011255	3/4" LOCK NUT		06
28	0501216430	ADJUSTING COVER CALCO		06
29	0541050275	HYDRAULIC CYLINDER RIGHT 44.45X85.7X413	86	01
30	0503012623	3/8" X 1-1/2" BOLT		01


Item	Code	Description	See page	QT
31	0503010208	HEX NUT 3/8 UNF G.5 ZN		01
32	0501311048	BEATER AXLE 230		01
33	0541050292	MONO RIGHT WHEEL TIRE 500 X 50	87	01
34	0531062847	SPRING PRESSURE REGULATOR		01




Item	Code	Description	See page	QT
01	0501111135	BIGGER BEARING CYLINDER SUPPORT WITHOUT LUBRICATION		01
01A	0531064111	LARGER FIXING FLANGE HYDRAULIC CYLIND		01
01B	0503019408	IGLIDUR GSM-4550-30 AUTO LUBRICANT GLOVE		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
03	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		02

LOCK PIN SET


0531055357




Item	Code	Description	See page	QT
01	0591016056	LOCK AXLE SUPPORT		01
02	0531061626	38 X 308 JUNCTION AXLE WITH HANDLE		02
03	0503030119	LOCK PIN		02
04	0503010834	1/2 X 1 BOLT		01
05	0503010019	1/2" SPRING WASHER		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0531066275	CYLINDER CASE		01
02	0503010042	2-214 N 3006-9B O'RING		01
03	0503010063	1" SELF-ALIGNING NUT		01
04	0503010761	D-1750 SCRAPER RING		01
05	0571019710	1.7" X 3.4" PISTON		01
06	0503017935	RING		01
07	0503018144	RING		01
08	0571019711	RING SUPPORT		01
09	0571019709	DETACHABLE COVER		01
10	0503017936	RING		01
11	0503017938	RING GUIDE		01
12	0503017937	GASKET		01
13	0503017940	8-337 BACK-UP RING		02
14	0503017939	2-337 N 3006-9B O' RING		02
15	0503018045	2-130 (AGEL) O'RING		04
16	0531064313	ROD 1.3/4 X 826MM WITH SLEEVE		01




Item	Code	Description	See page	QT
01	0531064118	WHEEL RIGHT TIRE 500/50		01
02	0501213744	SINGLE ARM WHEEL AXLE		01
03	0503019246	BOLT		01
04	0503011075	UNC NUT 3/4 UNC ALTA G.5 ZN		01
05	0501213743	LOCK AXLE		01
06	0501213742	SUPPORT WASHER		01
07	0503010953	BOLT 1 UNC X 2 C S G.5 ZN		01
08	0503010012	1" SPRING WASHER		01
09	0541050195	MOUNTED LEFT WHEEL	88	01
10	0541050294	FULL WHEEL BOX	89	01




Item	Code	Description	See page	QT
01	0513010700	TIRE 500-50-17 FLOTATION T422 I1 18PR TECH SHEET		01
02	0503013999	VALVE 16MM AGR		01
03	0503036301	RIM 16 X 17		01




Item	Code	Description	See page	QT
01	0501213734	ROLLED EIXO		01
02	0541050193	WHEEL COMPLETE BOX		01
02A	0501111223	BOX ROUND WITH SCREW		01
02AA	0501213765	WHEEL BOX		01
02AB	0503014048	HEX NUT M22X1,5" CH32X33,5		08
02AC	0503810007	WHEEL BOLT		08
02B	0503010002	1800 GREASE FITTING		01
02C	0541013225	WHEEL HUB LID		01
02D	0503011444	SPRING WASHER 5/16"		06
02E	0503010240	BOLT		06
02F	0502040080	FLANGE NUT R.2.1/2" UN		01
02G	0503011345	1/4" X 3.1/2" SPLIT PIN		01
02H	1882970002	GREASE		01
02I	0503010050	SEAL 00085-B		01
02J	0503013633	BEARING 33287/33462		01
02K	0503013496	3982/3920 ROLLER BEARING		01




Item	Code	Description	See page	QT
01	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
02	0513010753	SINGLE STANDARD CLAMP		08
03	0513010752	SINGLE STANDARD CLAMP 12 MM - BLACK		36
04	0513010746	STANDARD CLAMP SINGLE 10MM - BLACK		04
05	0501314482	SUPPORT PLATE DUCT		01
06	0501314483	SMALLER SUPPORT PLATE		01
07	0501314484	DUCTS RIGHT SUPPORT		01
08	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		04
09	0501313324	UNION CLAMP 150 X 30 X 6,30		04
10	0501314485	CLAMP FIXER		02
11	0513011668	BOLT M6		04
12	0503014540	M6 NUT		08
13	0511017303	FLAT WASHER		12
14	0503010143	1/4" SPRING WASHER		08
15	0501314486	CLAMP FASTENER		02
16	0513011665	BOLT M6 X 1,00 X 90 - SXP6X90ZI		04
17	0503036764	HYDRAULIC TUBE PT12L X PT12L X 1230		03
18	0503036765	HYDRAULIC TUBE PT15 X PT15 X 1230		02
19	0503036766	HYDRAULIC TUBE PT10L X PT10L X 1230		01
20	0503036767	HYDRAULIC TUBE PT12L X PT12L X 2205		04
21	0501317813	SUPPORT 25 X 50 X 2150		01




Item	Code	Description	See page	QT
01	0531060544	15Z GEAR P		01
02	0531055688	DOUBLE BEARING 38Z	92	01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0531019479	AXLE CHAIN GEAR		01
07	0503030402	PULLEY		02
08	0503013369	40-1 X 62 CHAIN LINK + REDUCTION		01
09	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
10	0581012970	TIGHTENER AXLE		01
11	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
12	0503015162	M 8 X 1,25 X 20 BOLT		01
13	0501219494	GLOVE ENCODER		01
14	0531058720	COVER CHAIN SEED MOTOR	94	01




Item	Code	Description	See page	QT
01	0531064307	38Z SPROCKET		01
02	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	93	01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		02
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0503019412	RIVET SCREW INTERNAL		03
02	0503010143	1/4" SPRING WASHER		02
03	0503013813	1/4" UNC X 7/8" BOLT		02
04	0501212320	ENCODER LOCK SCREW		01
05	0501212912	CHAIN COVER		01




Item	Code	Description	See page	QT
01	0531055688	DOUBLE BEARING 38Z	92	01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0531019479	AXLE CHAIN GEAR		01
06	0503030402	PULLEY		02
07	0581012970	TIGHTENER AXLE		01
08	0503012515	40-1 X CHAIN 77 LINK+ MENDING		01
09	0503012142	40-1 CHAIN X 61 LINK + MENDING		01
10	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
11	0531058726	FERTILIZER PROTECTION COVER WITH RIP	96	01
12	0531060544	15Z GEAR P		01
13	0503015162	M 8 X 1,25 X 20 BOLT		01
14	0501219494	GLOVE ENCODER		01




Item	Code	Description	See page	QT
01	0501219507	COVER PROTECTION FERTILIZER		01
02	0503019412	RIVET SCREW INTERNAL		04
03	0503010143	1/4" SPRING WASHER		03
04	0503013813	1/4" UNC X 7/8" BOLT		03
05	0501212320	ENCODER LOCK SCREW		01




Item	Code	Description	See page	QT
01	0531059101	CONDUCTOR FERTILIZER/SEED LINES	98	14
02	0541050968	CONDUCTOR REAR LINES FERTILIZER/SEED	99	06
03	0541050969	CONDUCTOR FERTILIZER/SEED HOSE 310	100	12
04	0541051038	CONDUCTOR CURVED FERTILIZER/SEED SMALLER HOSE 210	101	01
05	0541051039	CONDUCTOR SMALLER CURVED FERTILIZER/SEED HOSE 310	102	02
06	0541051040	CONDUCTOR FERTILIZER/SEED HOSE 390	103	02
07	0541051041	CONDUCTOR SMALLER CURVED FERTILIZER/SEED HOSE 310	104	01
08	0541050967	CONDUCTOR FERTILIZER/SEED CURVED HOSE 210	430 105	01
09	0541051042	CONDUCTOR FERTILIZER/SEED CURVED HOSE 210	312 106	01




Item	Code	Description	See page	QT
01	0503010246	CLAMP		04
02	0503061799	TELESCOPIC		01
03	0503015268	BALANCING FERTILIZER / SEED		01
04	0501212537	TUBE		01
05	0503030195	2" X 2" X 12.2" HOSE		01
06	0503011266	CLAMP 2.1/4" A 3" 57-76		01




Item	Code	Description	See page	QT
01	0503010246	CLAMP		04
02	0503061799	TELESCOPIC		01
03	0503015268	BALANCING FERTILIZER / SEED		01
04	0581012347	CURVED CONDUCTOR		01
05	0503030195	2" X 2" X 12.2" HOSE		01
06	0503011266	CLAMP 2.1/4" A 3" 57-76		01




Item	Code	Description	See page	QT
01	0503010246	CLAMP		03
02	0503061799	TELESCOPIC		01
03	0503015268	BALANCING FERTILIZER / SEED		01
04	0503030195	2" X 2" X 12.2" HOSE		01
05	0503011266	CLAMP 2.1/4" A 3" 57-76		01




Item	Code	Description	See page	QT
01	0503010246	CLAMP		05
02	0503061799	TELESCOPIC		01
03	0503015268	BALANCING FERTILIZER / SEED		01
04	0503011266	CLAMP 2.1/4" A 3" 57-76		01
05	0503035361	HOSE		01
06	0503031050	CURVED CONDUCTOR		02




Item	Code	Description	See page	QT
01	0503010246	CLAMP		05
02	0503061799	TELESCOPIC		01
03	0503015268	BALANCING FERTILIZER / SEED		01
04	0503011266	CLAMP 2.1/4" A 3" 57-76		01
05	0503031050	CURVED CONDUCTOR		02
06	0503030195	2" X 2" X 12.2" HOSE		01




Item	Code	Description	See page	QT
01	0503010246	CLAMP		03
02	0503061799	TELESCOPIC		01
03	0503015268	BALANCING FERTILIZER / SEED		01
04	0503011266	CLAMP 2.1/4" A 3" 57-76		01
05	0503030408	2 X 2 X 390 HOSE		01




Item	Code	Description	See page	QT
01	0503010246	CLAMP		04
02	0503061799	TELESCOPIC		01
03	0503015268	BALANCING FERTILIZER / SEED		01
04	0503011266	CLAMP 2.1/4" A 3" 57-76		01
05	0503031050	CURVED CONDUCTOR		01
06	0503030195	2" X 2" X 12.2" HOSE		01




Item	Code	Description	See page	QT
01	0503010246	CLAMP		03
02	0503061799	TELESCOPIC		01
03	0503015268	BALANCING FERTILIZER / SEED		01
04	0503011266	CLAMP 2.1/4" A 3" 57-76		01
05	0503031826	CURVED CONDUCTOR		01
06	0503035361	HOSE		01



Item	Code	Description	See page	QT
01	0503010246	CLAMP		03
02	0503061799	TELESCOPIC		01
03	0503015268	BALANCING FERTILIZER / SEED		01
04	0503011266	CLAMP 2.1/4" A 3" 57-76		01
05	0503035361	HOSE		01
06	0581012347	CURVED CONDUCTOR		01




Item	Code	Description	See page	QT
01	0531059055	CENTRAL SILOS	108	01
02	0503063475	FERTILIZER SILO WITH 07 OUTLETS		01
03	0503010026	3/8" NUT		06
04	0503010025	3/8 SPRING WASHER		06
05	0503011087	3/8" X 1" BOLT		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
07	0501013518	FLAT WASHER		06
08	0503063477	SILO ASSY FERTILIZER WITH 10 OUTPUTS		01
09	0503063478	SEED SILO WITH 10 OUTLETS COMPLETE		01
10	0503063476	SILO FOR SEEDS WITH 7 OUTLETS		01
11	0531065779	SILO LOCK		04
12	0503013389	5/8" SELF LOCKING NUT		08
13	0501219994	CORNER 1.1/2 X 1.1/2 X 3/16 X 946		04
14	0531065780	SILO LOCK		04
15	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		18
16	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		09
17	0503011082	C1/2" X 1.3/4" SCREW		09




Item	Code	Description	See page	QT
01	0531065776	CENTRAL SILO SUPPORT		01
02	0571017643	AXLE FERTILIZER LOCK SLEVE		02
03	0503017021	M8 X 0.5" BOLT		38
04	0502012325	SEED REGULATOR BEARING		01
05	0551019597	SEED REGULATION STEERING WHEEL		01
06	0571015340	AXIS		01
07	0503012882	BEARING		02
08	0503012104	501015 CLAMPING RING (FOR AXLE)		01
09	0503011945	503050 CLAMPING RING (FOR AXLE)		01
10	0511015098	FLAT WASHER		01
11	0503031035	HITCH PIN CLIP		01
12	0503032990	SEED DISTRIBUTOR HOPPER ASSY	49	17
13	0503011953	5/16" X 1" BOLT		68
14	0503010337	NUT 5/16 UNC G.5 ZN		68
15	0501010694	FLAT WASHER 32,50 X 75 X 4,75		68
16	0591019975	SQUARE SEED AXIS 15.88 X 3050MM		01
17	0571017641	LARGER DOSER		01
18	0503030886	SCALE DOSER		01
19	0501219984	SEED SCALE SUPPORT		01
20	0503010001	RIVET 3,2 X 5,5		02
21	0591019976	SQUARE FERTILIZER SHAFT 3/4 X 2966		01
22	0503011099	GREASE FITTING		01
23	0503010010	SPLIT PIN 1/4" X 2.1/2"		01
24	0531059057	SEED COMPLETE BEARING	50	01
25	0531062737	REGULATOR BRACKET		01
26	0531065778	38Z GEAR WITH 19.5 SQUARE HOLE		01
27	0531059056	DOSER FERTILIZER ALPHA II	51	17
28	0531059058	DOUBLE GEAR BEARING SET	56	01
29	0503030119	LOCK PIN		01
30	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		12

Item	Code	Description	See page	QT
31	0503013357	3/8 SELF-ADJUSTING NUT		12
32	0511073136	SILO FIXING SUPPORT		06
33	0501219991	LOCK BUSHING		34




Item	Code	Description	See page	QT
01	0531065786	SUPPORT LEFT PLATFORM		01
02	0531065785	SUPPORT RIGHT PLATFORM		02
03	0531065787	CENTRAL HANDRAILING		01
04	0501013519	FLAT WASHER		12
05	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		06
06	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
07	0503013357	3/8 SELF-ADJUSTING NUT		10
08	0501013518	FLAT WASHER		04
09	0501011643	3/8 X 1" BOLT		04
10	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		04
11	0531065788	CENTER PLATFORM		01
12	0501310025	PLATE 70 X 366 X 10		02
13	0501210140	PLATE 70 X 108 X 10		02
14	0503010814	5/16 BOLT		24
15	0503010337	NUT 5/16 UNC G.5 ZN		24
16	0503010179	LOCK WASHER 5/16 ZN 1K01528		24
17	0503010237	3/8" X 1" BOLT		06




Item	Code	Description	See page	QT
01	0531065709	TELESCOPIC WHEEL SUPPORT		01
02	0531066279	TORRE RODEIRO		01
03	0531064106	CROSSHEAD WITH SUPPORT		01
04	0501210807	PLASTIPRENE LOWER SUPPORT		02
05	0501210806	PLASTIPRENE TOP SUPPORT		02
06	0501214452	DAMPER SPINDLE		02
07	0501214453	PLASTIPRENE EAR		01
08	0501214454	GLOVE ARTICULATION AXLE		02
09	0503010834	1/2 X 1 BOLT		05
10	0503010019	1/2" SPRING WASHER		09
11	0503011075	UNC NUT 3/4 UNC ALTA G.5 ZN		02
12	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		02
13	0501214303	WHEEL CHAIN		05
14	0531054036	ASSY CENTER CYLINDER BEARING	111	02
15	0503011052	1.1/4" X 0.77" CASTLE NUT		01
16	0503012182	1" NUT		02
17	0503010002	1800 GREASE FITTING		11
18	0503010038	3/16" X 2" SPLIT PIN		01
19	0591016434	PLASTIPRENE		02
20	0501214302	ADJUSTMENT COVER PLATE		05
21	0503034377	3/8 UNC X 3/4 BOLT		30
22	0503010025	3/8 SPRING WASHER		30
23	0501215027	CENTRAL WHEEL PULLEY		03
24	0501214462	NYLON PULLEY BUSHING		06
25	0501216430	ADJUSTING COVER CALCO		05
26	0531065712	CENTRAL PULLEY LOCK SHAFT		03
27	0561010960	FLAT WASHER		04
28	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
29	0501311051	BEATER SHAFT 200 WITH GROUP		01
30	0503012623	3/8" X 1-1/2" BOLT		01


Item	Code	Description	See page	QT
31	0503010208	HEX NUT 3/8 UNF G.5 ZN		01
32	0541050194	COMPLETE CENTRAL CUBE	112	02
33	0541050195	MOUNTED LEFT WHEEL	88	01
34	0541050196	MOUNTED RIGHT WHEEL	113	01
35	0531066277	CENTRAL CYLINDER AXIS		01
36	0531066276	ARTICULATOR SHAFT		01
37	0501312155	BACKREST WASHER		01
38	0513010043	BOLT 1/2 UNC X 1.3/4 CCSI 12.9		01
39	0531065710	MAJOR AXLE LOCK CENTRAL PULLEY		01
40	0501111193	FULL PULLEY		01
41	0541050277	HYDRAULIC CYLINDER LEFT	114	01




Item	Code	Description	See page	QT
01	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
03	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		02




Item	Code	Description	See page	QT
01	0501214451	CENTRAL WHEEL AXLE		01
02	0503010050	SEAL 00085-B		01
03	0503010002	1800 GREASE FITTING		01
04	0541013225	WHEEL HUB LID		01
05	0503011444	SPRING WASHER 5/16"		06
06	0503010240	BOLT		06
07	0502040080	FLANGE NUT R.2.1/2" UN		01
08	0503011345	1/4" X 3.1/2" SPLIT PIN		01
09	0501111223	BOX ROUND WITH SCREW		01
09A	0501213765	WHEEL BOX		01
09B	0503810007	WHEEL BOLT		08
09C	0503014048	HEX NUT M22X1,5" CH32X33,5		08
10	0503013633	BEARING 33287/33462		01
11	0503013496	3982/3920 ROLLER BEARING		01



Item	Code	Description	See page	QT
01	0513010700	TIRE 500-50-17 FLOTATION T422 I1 18PR TECH SHEET		01
02	0503013999	VALVE 16MM AGR		01
03	0503036301	RIM 16 X 17		01




Item	Code	Description	See page	QT
01	0531066278	CYLINDER CASE		01
02	0503010042	2-214 N 3006-9B O'RING		01
03	0503010063	1" SELF-ALIGNING NUT		01
04	0503010761	D-1750 SCRAPER RING		01
05	0571019710	1.7" X 3.4" PISTON		01
06	0503017935	RING		01
07	0503018144	RING		01
08	0571019711	RING SUPPORT		01
09	0571019709	DETACHABLE COVER		01
10	0503017936	RING		01
11	0503017938	RING GUIDE		01
12	0503017937	GASKET		01
13	0503017940	8-337 BACK-UP RING		02
14	0503017939	2-337 N 3006-9B O' RING		02
15	0503018045	2-130 (AGEL) O'RING		04
16	0531064313	ROD 1.3/4 X 826MM WITH SLEEVE		01




Item	Code	Description	See page	QT
01	0531065709	TELESCOPIC WHEEL SUPPORT		01
02	0531066279	TORRE RODEIRO		01
03	0531064106	CROSSHEAD WITH SUPPORT		01
04	0501210807	PLASTIPRENE LOWER SUPPORT		02
05	0501210806	PLASTIPRENE TOP SUPPORT		02
06	0501214452	DAMPER SPINDLE		02
07	0501214453	PLASTIPRENE EAR		01
08	0501214454	GLOVE ARTICULATION AXLE		02
09	0503010834	1/2 X 1 BOLT		05
10	0503010019	1/2" SPRING WASHER		09
11	0503011075	UNC NUT 3/4 UNC ALTA G.5 ZN		02
12	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		02
13	0501214303	WHEEL CHAIN		05
14	0531054036	ASSY CENTER CYLINDER BEARING	111	02
15	0503011052	1.1/4" X 0.77" CASTLE NUT		01
16	0503012182	1" NUT		02
17	0503010002	1800 GREASE FITTING		11
18	0503010038	3/16" X 2" SPLIT PIN		01
19	0591016434	PLASTIPRENE		02
20	0501214302	ADJUSTMENT COVER PLATE		05
21	0503034377	3/8 UNC X 3/4 BOLT		30
22	0503010025	3/8 SPRING WASHER		30
23	0501215027	CENTRAL WHEEL PULLEY		03
24	0501214462	NYLON PULLEY BUSHING		06
25	0501216430	ADJUSTING COVER CALCO		05
26	0531065712	CENTRAL PULLEY LOCK SHAFT		03
27	0561010960	FLAT WASHER		04
28	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
29	0501311051	BEATER SHAFT 200 WITH GROUP		01
30	0503012623	3/8" X 1-1/2" BOLT		01


Item	Code	Description	See page	QT
31	0503010208	HEX NUT 3/8 UNF G.5 ZN		01
32	0541050194	COMPLETE CENTRAL CUBE	112	02
33	0541050195	MOUNTED LEFT WHEEL	88	01
34	0541050196	MOUNTED RIGHT WHEEL	113	01
35	0531066277	CENTRAL CYLINDER AXIS		01
36	0531066276	ARTICULATOR SHAFT		01
37	0501312155	BACKREST WASHER		01
38	0513010043	BOLT 1/2 UNC X 1.3/4 CCSI 12.9		01
39	0531065710	MAJOR AXLE LOCK CENTRAL PULLEY		01
40	0501111193	FULL PULLEY		01
41	0541050275	HYDRAULIC CYLINDER RIGHT 44.45X85.7X413	86	01




Item	Code	Description	See page	QT
01	0531065763	TUBE FIXATION LINES 2517		01
02	0531065764	TUBE FIXATION LINES 2862		01
03	0541050273	BRACKET MOUNTED CENTER	117	02
04	0541050280	RIGHT SEED FERTILIZER DISTRIBUTOR ROW DDD 15X15 CPL	63	09
05	0541050278	ROW DISTRIBUTOR LEFT FERTILIZER/SEED	118	08




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0503017857	BOLT 5/8 UNF 4		04
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0503011075	UNC NUT 3/4 UNC ALTA G.5 ZN		06
05	0501011027	5/8" X 3-3/4" BOLT		04
06	0501010301	FLAT WASHER 16 X 29,50 X 3,00		04
07	0503013389	5/8" SELF LOCKING NUT		04
08	0501010098	BOLT 3/4" UNC X 2 C S G.5 ZN		06
09	0502013063	LOCK FASTENER		02
10	0531066274	FIXING SUPPORT ROWS		01




Item	Code	Description	See page	QT
01	0591019832	ARTICULATOR AXLE 30X150 WITH HOLES		01
02	0531065766	LOWER FRONT PANTOGRAPH		01
03	0531065767	FRONT UPPER PANTOGRAPH		01
04	0591019825	AXLE 25.40 X 150 WITH HOLE		01
05	0503013389	5/8" SELF LOCKING NUT		06
06	0503010131	3/16" X 1.1/2" SPLIT PIN		02
07	0503010577	3/16" X 1.1/4" SPLIT PIN		04
08	0503030520	SEED SOCKET		01
09	0503030483	FERTILIZER SOCKET		01
10	0501013519	FLAT WASHER		02
11	0503011336	1/2" HEX SELF ADJUSTING NUT		02
12	0531065768	PANTOGRAPH ARM		01
13	0591019821	AXIS 20.80 X 150		01
14	0503034469	NOZZLE SUPPORT		01
15	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
16	0591019820	SPACER BUSHING		08
17	0503019273	AUTO LUBRICANT SLEEVE		08
18	0501013867	BOLT 5/8" UNC X 6 CS G.5 ZN		04
19	0503010045	O'RING		08
20	0531065774	SUPPORT		01
21	0501010301	FLAT WASHER 16 X 29,50 X 3,00		02
22	0501213051	LOCK PIN		02
23	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		02
24	0502013063	LOCK FASTENER		01
25	0531059053	SPRING WITH EARS	64	02
26	0541050283	SUPPORT DDD LEFT	119	01
27	0531059909	GAUGE WHEEL DEPTH CONTROL	70	01
28	0503010734	1/2" X 2-1/2" BOLT		02
29	0513011693	R 2,5 X 40MM COTTER PIN		02



Item	Code	Description	See page	QT
01	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 66 FERTILIZER / SEED		01
02	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 67 FERTILIZER / SEED		01
03	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
06	0503010025	3/8 SPRING WASHER		01
07	0503010026	3/8" NUT		01
08	0503010849	3/8" X 1-1/2" BOLT		01
09	0503010011	5/16" X 1/2" BOLT		02
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
11	0531065759	LEFT DDD FRONT PROTECTOR		01
12	0502013095	SUPPORT DDD LEFT 15 X 15		01
13	0511015098	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0531064607	ARTICULATION AXLE		01
02	0571011767	125 X 88 X 4,76 FLAT WASHER		01
03	0503010408	7/8" SPRING WASHER		01
04	0503015322	BOLT 7/8		01
05	0503010814	5/16 BOLT		10
06	0503010002	1800 GREASE FITTING		02
07	0571011825	BUSHING		02
08	0591012948	700 X 130 X 10 PLATE		01
09	0531065783	ARM ARTICULATOR LEFT		01
10	0531064610	ARTICULATION AXLE		01
11	0503010834	1/2 X 1 BOLT		01
12	0503010019	1/2" SPRING WASHER		01
13	0503035505	HOSE PROTECTOR		01
14	0531065781	ARTICULATION AXLE		01
15	0501214491	CONIC GLOVE TIGHTENING		02
16	0501216766	FIXING WASHER		01
17	0502040080	FLANGE NUT R.2.1/2" UN		01
18	0503011345	1/4" X 3.1/2" SPLIT PIN		01
19	0541050949	LEFT DUCT SET	122	01




Item	Code	Description	See page	QT
01	0531064607	ARTICULATION AXLE		01
02	0571011767	125 X 88 X 4,76 FLAT WASHER		01
03	0503010408	7/8" SPRING WASHER		01
04	0503015322	BOLT 7/8		01
05	0503010814	5/16 BOLT		10
06	0503010002	1800 GREASE FITTING		02
07	0571011825	BUSHING		02
08	0531064610	ARTICULATION AXLE		01
09	0503010834	1/2 X 1 BOLT		01
10	0503010019	1/2" SPRING WASHER		01
11	0591012948	700 X 130 X 10 PLATE		01
12	0531065782	ARM ARTICULATOR RIGHT		01
13	0503035505	HOSE PROTECTOR		01
14	0531065781	ARTICULATION AXLE		01
15	0501214491	CONIC GLOVE TIGHTENING		02
16	0502040080	FLANGE NUT R.2.1/2" UN		01
17	0501216766	FIXING WASHER		01
18	0503011345	1/4" X 3.1/2" SPLIT PIN		01
19	0541050951	DUCT SET RIGHT	123	01

LEFT DUCT SET


0541050949




Item	Code	Description	See page	QT
01	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
02	0503013357	3/8 SELF-ADJUSTING NUT		06
03	0503010849	3/8" X 1-1/2" BOLT		02
04	0501310016	LEFT SUPPORT		01
05	0503010025	3/8 SPRING WASHER		01
06	0503010026	3/8" NUT		01
07	0503013029	3/8" X 3/4" BOLT		01
08	0503010256	3/8" X 3/4" BOLT		02
09	0501310018	SUPPORT		02
10	0501310019	SUPPORT 55 X 70 X 1000		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
12	0513010753	SINGLE STANDARD CLAMP		08
13	0503036245	HYDRAULIC TUBE		02
14	0503036265	HYDRAULIC TUBE		08
15	0513010752	SINGLE STANDARD CLAMP 12 MM - BLACK		32
16	0501314485	CLAMP FIXER		02
17	0513011668	BOLT M6		04
18	0503014540	M6 NUT		09
19	0511017303	FLAT WASHER		10
20	0503010143	1/4" SPRING WASHER		09
21	0501313325	4 TB12L FASTENER		04
22	0513011664	BOLT M6 X 1,00 X 80 - SXR6X80ZI		04
23	0501317072	SUPPORT LARGER DUCTS		01
24	0501317073	SUPPORT LARGER DUCTS		01
25	0513010720	M6 X 1 X 35 C S G.5 ZB BOLT		01




Item	Code	Description	See page	QT
01	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
02	0503013357	3/8 SELF-ADJUSTING NUT		06
03	0503010849	3/8" X 1-1/2" BOLT		02
04	0503010025	3/8 SPRING WASHER		01
05	0503010026	3/8" NUT		01
06	0503013029	3/8" X 3/4" BOLT		01
07	0503010256	3/8" X 3/4" BOLT		02
08	0501310017	RIGHT SUPPORT		01
09	0501310019	SUPPORT 55 X 70 X 1000		01
10	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
11	0503036265	HYDRAULIC TUBE		08
12	0513010752	SINGLE STANDARD CLAMP 12 MM - BLACK		32
13	0513010753	SINGLE STANDARD CLAMP		08
14	0503036245	HYDRAULIC TUBE		02
15	0501314485	CLAMP FIXER		02
16	0501317073	SUPPORT LARGER DUCTS		01
17	0501313325	4 TB12L FASTENER		04
18	0503014540	M6 NUT		09
19	0511017303	FLAT WASHER		10
20	0503010143	1/4" SPRING WASHER		09
21	0513011664	BOLT M6 X 1,00 X 80 - SXR6X80ZI		04
22	0513011668	BOLT M6		04
23	0501310018	SUPPORT		02
24	0513010720	M6 X 1 X 35 C S G.5 ZB BOLT		01
25	0501317072	SUPPORT LARGER DUCTS		01




Item	Code	Description	See page	QT
01	0581010353	RING SUPPORT		01
02	0502010382	5" END CAP		01
03	0581013698	PISTON 2" X 5" C/R. M36 X 1,5		01
04	0531062932	EXTENSION 50.80 X 898 MM		01
05	0503010003	1845 GREASE FITTING		02
06	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
07	0503018439	WIPER SEAL T-SEAL 1905127		01
08	0503018150	RING GUIDE W2-5000-984 (4528)		01
09	0503010173	2-220 N 3006-9B O-RING		01
10	0503018024	RING BS OD050805200171D-BR		01
11	0503018026	GASKET 1870-2000-375 B POLYMAX		01
12	0503010039	D-2000 SCRAPER RING		01
13	0503018152	O-RING		02
14	0503018025	RING GUIDE W2-2250-750		01
15	0503011453	O-RING		02
16	0531066066	CILINDER CASE 127 X 773MM		01




Item	Code	Description	See page	QT
01	0531060544	15Z GEAR P		01
02	0531055688	DOUBLE BEARING 38Z	92	01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0531019479	AXLE CHAIN GEAR		01
07	0503030402	PULLEY		02
08	0503013369	40-1 X 62 CHAIN LINK + REDUCTION		01
09	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
10	0581012970	TIGHTENER AXLE		01
11	0531055682	COVER CHAIN SEED MOTOR	127	01
12	0501214964	ENGINE COVER		01
13	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
14	0503015162	M 8 X 1,25 X 20 BOLT		01
15	0501219494	GLOVE ENCODER		01




Item	Code	Description	See page	QT
01	0531055688	DOUBLE BEARING 38Z	92	01
02	0501214964	ENGINE COVER		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0531019479	AXLE CHAIN GEAR		01
07	0503030402	PULLEY		02
08	0503013369	40-1 X 62 CHAIN LINK + REDUCTION		01
09	0503014911	40-1 X 63 CHAIN LINK + MENDING		01
10	0581012970	TIGHTENER AXLE		01
11	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
12	0531058724	FERTILIZER PROTECTION COVER WITH BOLT	128	01
13	0531060544	15Z GEAR P		01
14	0503015162	M 8 X 1,25 X 20 BOLT		01
15	0501219494	GLOVE ENCODER		01




Item	Code	Description	See page	QT
01	0501214962	ENGINE CHAIN COVER		01
02	0503019412	RIVET SCREW INTERNAL		03
03	0503010143	1/4" SPRING WASHER		02
04	0503013813	1/4" UNC X 7/8" BOLT		02
05	0501212320	ENCODER LOCK SCREW		01




Item	Code	Description	See page	QT
01	0501219496	FERTILIZER PROTECTION COVER		01
02	0503019412	RIVET SCREW INTERNAL		04
03	0503010143	1/4" SPRING WASHER		03
04	0503013813	1/4" UNC X 7/8" BOLT		03
05	0501212320	ENCODER LOCK SCREW		01




Item	Code	Description	See page	QT
01	0503063793	KIT ISO6 6C - 010082195		01
01A	0503019526	CONTROL MODULE ISO6 6CH ADV		01
01B	0503019384	CABLE CTRL MASTER MODULE		01
01C	0503015071	CONNECTOR		01
01D	0503016321	ISOBUS CONNECTION CABLE		01
01E	0503019386	MODULES "C"		01
01F	0503019385	WHIP ELETTRIC		01
01G	0503017443	ANTENNA GPS PM 400		01
01H	0503019979	EXTENSION CABLE EMD - 4,5MTS		02
01I	0503019617	EXTENSION CABLE		04
01J	0513010626	EXTENSION CABLE PWM 4,5M PN:020013678		02
01K	0503019616	EXTENSION CABLE		04
01L	0503019618	EXTENSION CABLE		01
02	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	130	06
03	0511056972	FILTER HYDAC	131	01
04	0503019291	SUPPORT SENSOR		01
05	0521054490	FLOW DIVIDING VALVE ASSY	132	01
06	0503013100	NYLON CLAMP 4,8 X 1,3 X 200 MM		85
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		255




Item	Code	Description	See page	QT
01	0513010049	MOTOR OMP X 80 EMD - 11185907		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02



Item	Code	Description	See page	QT
01	0503063151	PRESSURE FILTER MFM HYDAC 1319024BR		01
02	0503016336	PRESSURE GAUGE		01
03	0581011416	7/8"NF UNF NIPPLE		02
04	0503012341	7/8" T ADAPTER		01
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
08	0571016236	HIDRAULIC ADAPTER		01
09	0503014724	2-215 N 3006-9B O'RING		02



Item	Code	Description	See page	QT
01	0503016227	FLOW DIVIDING VALVE		01
02	0503013917	O`RING 2-224		03
03	0571013917	7/8\"NF X 1.1/16 UNF NIPPLE		03



0503033419



0503033421



0503031425



0503034078



0503038197



0503038198



0503031565




0503031087



0503038199



0503031428




0503035316




0503038200


Item	Code	Description	See page	QT
01	0503033419	NUMBER 5 DECAL		02
02	0503033421	NUMBER 7 DECAL		02
03	0503031565	CAUTION TRANSPORTATION DECAL		02
04	0503031428	READ MANUAL DECAL		01
05	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL		02
06	0503034078	LIFTING POINTS DECAL		02
07	0503031087	AUTO CONTROL APPROVED DECAL		01
08	0503035316	LUBRICATED POINTS DECAL		04
09	0503038197	OIL 140 ADHESIVE LABEL		02
10	0503038198	DECAL ASSY MARCHESAN USAP 3200 GF		03
11	0503038199	DECAL ASSY USAP 3200 GF		02
12	0503038200	DECAL ASSY USAP 3200 GF		01




Item	Code	Description	See page	QT
01	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
02	0503010267	NYLON CLAMP 3,60 X 1,3 X 155 MM		01
03	0503010337	NUT 5/16 UNC G.5 ZN		01
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
05	0503060100	SUPPORT INSTRUCTION MANUAL		01
06	0511034152	BAG WITH INSTRUCTION MANUAL		01



Item	Code	Description	See page	QT
01	0541050969	CONDUCTOR FERTILIZER/SEED HOSE 310	100	18
02	0531059101	CONDUCTOR FERTILIZER/SEED LINES	98	16




Item	Code	Description	See page	QT
01	0531059087	SIDE SILO LEFT	137	01
02	0503010026	3/8" NUT		05
03	0503010025	3/8 SPRING WASHER		05
04	0503011087	3/8" X 1" BOLT		03
05	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
06	0501013518	FLAT WASHER		05
07	0503063477	SILO ASSY FERTILIZER WITH 10 OUTPUTS		02
08	0503063478	SEED SILO WITH 10 OUTLETS COMPLETE		02
09	0531065779	SILO LOCK		04
10	0503013389	5/8" SELF LOCKING NUT		08
11	0501219994	CORNER 1.1/2 X 1.1/2 X 3/16 X 946		04
12	0531065780	SILO LOCK		04
13	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		18
14	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		09
15	0503011082	C1/2" X 1.3/4" SCREW		09




Item	Code	Description	See page	QT
01	0531065815	LEFT SIDE SILO SUPPORT		01
02	0571017643	AXLE FERTILIZER LOCK SLEVE		03
03	0503017021	M8 X 0.5" BOLT		45
04	0502012325	SEED REGULATOR BEARING		01
05	0551019597	SEED REGULATION STEERING WHEEL		01
06	0571015340	AXIS		01
07	0503012882	BEARING		02
08	0503012104	501015 CLAMPING RING (FOR AXLE)		01
09	0503011945	503050 CLAMPING RING (FOR AXLE)		01
10	0511015098	FLAT WASHER		01
11	0503031035	HITCH PIN CLIP		01
12	0503032990	SEED DISTRIBUTOR HOPPER ASSY	49	20
13	0503011953	5/16" X 1" BOLT		80
14	0503010337	NUT 5/16 UNC G.5 ZN		80
15	0501010694	FLAT WASHER 32,50 X 75 X 4,75		80
16	0501210318	SQUARE SEED AXLE 15.88 X 3560 MM		01
17	0571017641	LARGER DOSER		01
18	0503030886	SCALE DOSER		01
19	0581010116	SUPPORT SCALE SEED		01
20	0503010001	RIVET 3,2 X 5,5		02
21	0501210311	SQUARE FERTILIZER SHAFT 3/4 X 3342		01
22	0503011099	GREASE FITTING		01
23	0503010010	SPLIT PIN 1/4" X 2.1/2"		01
24	0531059057	SEED COMPLETE BEARING	50	01
25	0531062737	REGULATOR BRACKET		01
26	0531059056	DOSER FERTILIZER ALPHA II	51	20
27	0503010237	3/8" X 1" BOLT		02
28	0503010026	3/8" NUT		02
29	0503010025	3/8 SPRING WASHER		02
30	0501310257	SQUARE LOCK GLOVE 5/8		40


Item	Code	Description	See page	QT
31	0531059058	DOUBLE GEAR BEARING SET	56	01
32	0531065778	38Z GEAR WITH 19.5 SQUARE HOLE		01
33	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		12
34	0503013357	3/8 SELF-ADJUSTING NUT		12
35	0511073136	SILO FIXING SUPPORT		06




Item	Code	Description	See page	QT
01	0501013519	FLAT WASHER		12
02	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		08
03	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		06
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		07
05	0503013357	3/8 SELF-ADJUSTING NUT		14
06	0501013518	FLAT WASHER		20
07	0501011643	3/8 X 1" BOLT		08
08	0501310124	SIDE PLATFORM 3492		01
09	0531065824	FRONT HANDRAILING		01
10	0531059090	ARTICULATED PLATFORM	59	01
11	0511059383	INTERNAL HANDRAILING FIXER	60	02
12	0501210097	HANDRAILING BODY		01
13	0531065823	SUPPORT LEFT PLATFORM		01
14	0531065821	LEFT CENTRAL SUPPORT		01
15	0531065826	SIDE SUPPORT LEFT		01
16	0501310116	LADDER SUPPORT		01
17	0531065819	SUPPORT LADDER LEFT		01
18	0531065828	MOBILE LEFT LADDER		01
19	0531065817	LADDER WITH 03 MOBILE STEPS		01
20	0503010734	1/2" X 2-1/2" BOLT		02
21	0503011333	COVER FIXER		02
22	0503010274	5/32" X 2" SPLIT PIN		02
23	0503030285	HITCH PIN CLIP		01
24	0531065816	HANDRAILING SUPPORT		01
25	0503010849	3/8" X 1-1/2" BOLT		01
26	0503010025	3/8 SPRING WASHER		02
27	0503010026	3/8" NUT		02
28	0501310120	NYLON SLIDING GLOVE		02
29	0503010038	3/16" X 2" SPLIT PIN		02




Item	Code	Description	See page	QT
01	0531065808	TUBE FIXATION		01
02	0541050278	ROW DISTRIBUTOR LEFT FERTILIZER/SEED	118	17
03	0531059081	ROW ARTICULATED DISTRIBUTOR LEFT FERTILIZER/SEED	76	02
04	0541050282	ROW DISTRIBUTOR LEFT FERTILIZER/SEED	140	03
05	0541051232	LEFT CENTER JOINT SUPPORT	141	01
06	0541050956	SIDE ARTICULATION SUPPORT	79	02
07	0541051162	SUPPORT HOSE	82	06




Item	Code	Description	See page	QT
01	0591019832	ARTICULATOR AXLE 30X150 WITH HOLES		01
02	0531065766	LOWER FRONT PANTOGRAPH		01
03	0531065767	FRONT UPPER PANTOGRAPH		01
04	0591019825	AXLE 25.40 X 150 WITH HOLE		01
05	0503013389	5/8" SELF LOCKING NUT		04
06	0503010131	3/16" X 1.1/2" SPLIT PIN		02
07	0503010577	3/16" X 1.1/4" SPLIT PIN		04
08	0503030520	SEED SOCKET		01
09	0503030483	FERTILIZER SOCKET		01
10	0501013519	FLAT WASHER		02
11	0503011336	1/2" HEX SELF ADJUSTING NUT		02
12	0531065768	PANTOGRAPH ARM		01
13	0591019821	AXIS 20.80 X 150		01
14	0511059653	SPRING	78	02
15	0503034469	NOZZLE SUPPORT		01
16	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
17	0591019820	SPACER BUSHING		08
18	0503019273	AUTO LUBRICANT SLEEVE		08
19	0501013867	BOLT 5/8" UNC X 6 CS G.5 ZN		04
20	0503010045	O'RING		08
21	0531059909	GAUGE WHEEL DEPTH CONTROL	70	01
22	0503010734	1/2" X 2-1/2" BOLT		02
23	0501213051	LOCK PIN		02
24	0541050283	SUPPORT DDD LEFT	119	01
25	0513011693	R 2,5 X 40MM COTTER PIN		02



Item	Code	Description	See page	QT
01	0502013023	SUPPORT		01
02	0503011075	UNC NUT 3/4 UNC ALTA G.5 ZN		06
03	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		06
04	0531062601	JUNCTION AXLE 30 X 170 WITH HANDLE		01
05	0501213053	HEADLESS PIN 1.1/4 X 170		01
06	0503010131	3/16" X 1.1/2" SPLIT PIN		02
07	0503030085	LOCK PIN		01
08	0503014182	SELF-ADJUSTING NUT		02
09	0531065802	SUPPORT		01
10	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		06
11	0501010098	BOLT 3/4" UNC X 2 C S G.5 ZN		06
12	0531065803	JOINT SHAFT 31,75		01
13	0503031035	HITCH PIN CLIP		01
14	0501310087	THREADED PIN 257		02
15	0503010002	1800 GREASE FITTING		02
16	0531059077	LEFT JOINT SUPPORT		01
16A	0531065805	LEFT JOINT SUPPORT		01
16B	0503010019	1/2" SPRING WASHER		04
16C	0503010479	BOLT		04
17	0531059078	SUPPORT JOINT RIGHT		01
17A	0531065806	SUPPORT RIGHT RIGHT		01
17B	0503010019	1/2" SPRING WASHER		04
17C	0503010479	BOLT		04
18	0541050954	HYDRAULIC CYLINDER RIGHT 50,80 X 101,60 X 353 142 X 56		01
19	0531066742	CENTER JOINT SUPPORT		01
20	0501313855	SUPPORT		06
21	0531066759	REAR LEFT SUPPORT		01




Item	Code	Description	See page	QT
01	0531063669	EXTENDER 50.80X227.50 WITH BUSHING 32.50		01
02	0503010003	1845 GREASE FITTING		01
03	0581010678	50,80 X 101 RING SUPPORT		01
04	0503015636	SCRAPER SEAL		01
05	0503018025	RING GUIDE W2-2250-750		01
06	0503018026	GASKET 1870-2000-375 B POLYMAX		01
07	0503010338	2-342 N 3006-9B O-RING		02
08	0503011061	8-342 BACK-UP RING		02
09	0502012822	END CAP 4"		01
10	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
11	0503010345	2-218 N 3006-9B O-RING		01
12	0503015633	SELEMASTER SEALING		01
13	0502012842	50,80 X 101,60 PISTON		01
14	0531066585	CYLINDER BARREL 101,60 X 249		01




Item	Code	Description	See page	QT
01	0503014559	ROLLER BEARING		02
02	0503010095	SEAL		01
03	0501213909	WHEELED HUB COVER		01
04	0502040080	FLANGE NUT R.2.1/2" UN		01
05	0503010002	1800 GREASE FITTING		13
06	0501213917	ADJUSTMENT WASHER		01
07	0503012213	1/4" X 4" SPLIT PIN		01
08	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
10	0501214463	SIDE WHEEL PULLEY		06
11	0501214462	NYLON PULLEY BUSHING		12
12	0501214303	WHEEL CHAIN		06
13	0531064110	PULLEY LOCK AXLE		06
14	0503010834	1/2 X 1 BOLT		06
15	0503010019	1/2" SPRING WASHER		06
16	0591017921	BRONZE GLOVE 90.5 X 115 X 91		02
17	0501214460	AXLE 1.1/2 X 140MM		01
18	0503010390	SEAL RING		02
19	0531055358	COMPLETE SIDE CYLINDER BEARING	84	02
20	0531055357	LOCK PIN SET	85	01
21	0501214302	ADJUSTMENT COVER PLATE		06
22	0503034377	3/8 UNC X 3/4 BOLT		36
23	0503010025	3/8 SPRING WASHER		36
24	0501017065	FLAT WASHER		06
25	0503011255	3/4" LOCK NUT		06
26	0531057692	LEFT COMPLETE HOSE SUPPORT	144	01
27	0501216430	ADJUSTING COVER CALCO		06
28	0541050277	HYDRAULIC CYLINDER LEFT	114	01
29	0531066281	SIDE WHEEL TOWER		01
30	0541050293	LEFT WHEEL TIRE 500 X 50	145	01


Item	Code	Description	See page	QT
31	0531062847	SPRING PRESSURE REGULATOR		01
32	0503012623	3/8" X 1-1/2" BOLT		01
33	0503010208	HEX NUT 3/8 UNF G.5 ZN		01
34	0501311048	BEATER AXLE 230		01
35	0531066959	CHASSIS WHEEL LEFT SIDE		01




Item	Code	Description	See page	QT
01	0531065305	HOSE SUPPORT LEFT		01
02	0531065306	ARTICULATOR HOSE		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0503010025	3/8 SPRING WASHER		02
05	0503010237	3/8" X 1" BOLT		01
06	0503010026	3/8" NUT		01
07	0503010849	3/8" X 1-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0531064114	SINGLE LEFT WHEEL TIRE 500/50		01
02	0501213744	SINGLE ARM WHEEL AXLE		01
03	0503019246	BOLT		01
04	0503011075	UNC NUT 3/4 UNC ALTA G.5 ZN		01
05	0501213743	LOCK AXLE		01
06	0501213742	SUPPORT WASHER		01
07	0503010953	BOLT 1 UNC X 2 C S G.5 ZN		01
08	0503010012	1" SPRING WASHER		01
09	0541050196	MOUNTED RIGHT WHEEL	113	01
10	0541050294	FULL WHEEL BOX	89	01




Item	Code	Description	See page	QT
01	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
02	0513010753	SINGLE STANDARD CLAMP		08
03	0513010752	SINGLE STANDARD CLAMP 12 MM - BLACK		36
04	0513010746	STANDARD CLAMP SINGLE 10MM - BLACK		04
05	0501314482	SUPPORT PLATE DUCT		01
06	0501314483	SMALLER SUPPORT PLATE		01
07	0503010589	UNC SELF ADJUSTING NUT 1/2" UNC ALTA G.5 ZN		04
08	0501313324	UNION CLAMP 150 X 30 X 6,30		04
09	0501314485	CLAMP FIXER		02
10	0513011668	BOLT M6		04
11	0503014540	M6 NUT		09
12	0511017303	FLAT WASHER		12
13	0503010143	1/4" SPRING WASHER		09
14	0501314486	CLAMP FASTENER		02
15	0501314481	LEFT SUPPORT DUCTS		01
16	0513011665	BOLT M6 X 1,00 X 90 - SXR6X90ZI		04
17	0501317813	SUPPORT 25 X 50 X 2150		01
18	0503036766	HYDRAULIC TUBE PT10L X PT10L X 1230		01
19	0503036765	HYDRAULIC TUBE PT15 X PT15 X 1230		02
20	0503036764	HYDRAULIC TUBE PT12L X PT12L X 1230		03
21	0503036767	HYDRAULIC TUBE PT12L X PT12L X 2205		04




Item	Code	Description	See page	QT
01	0531060544	15Z GEAR P		01
02	0531055688	DOUBLE BEARING 38Z	92	01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0531019479	AXLE CHAIN GEAR		01
07	0503030402	PULLEY		02
08	0503013369	40-1 X 62 CHAIN LINK + REDUCTION		01
09	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
10	0581012970	TIGHTENER AXLE		01
11	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
12	0531055689	SUPPORT ENGINE LEFT	148	01
13	0503015162	M 8 X 1,25 X 20 BOLT		01
14	0501219494	GLOVE ENCODER		01




Item	Code	Description	See page	QT
01	0501214966	MOTOR CHAIN COVER		01
02	0503019412	RIVET SCREW INTERNAL		03
03	0503010143	1/4" SPRING WASHER		02
04	0503013813	1/4" UNC X 7/8" BOLT		02
05	0501212320	ENCODER LOCK SCREW		01




Item	Code	Description	See page	QT
01	0531055688	DOUBLE BEARING 38Z	92	01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0531019479	AXLE CHAIN GEAR		01
06	0503030402	PULLEY		02
07	0581012970	TIGHTENER AXLE		01
08	0503012515	40-1 X CHAIN 77 LINK+ MENDING		01
09	0503012142	40-1 CHAIN X 61 LINK + MENDING		01
10	0503010238	BOLT 1/2 UNC X 1.3/4 CS G.2 ZN		02
11	0531058722	FERTILIZER PROTECTION COVER	150	01



Item	Code	Description	See page	QT
01	0501219495	FERTILIZER PROTECTION COVER		01
02	0503019412	RIVET SCREW INTERNAL		04
03	0503010143	1/4" SPRING WASHER		03
04	0503013813	1/4" UNC X 7/8" BOLT		03
05	0501212320	ENCODER LOCK SCREW		01



Item	Code	Description	See page	QT
01	0531059101	CONDUCTOR FERTILIZER/SEED LINES	98	16
02	0541051038	CONDUCTOR CURVED FERTILIZER/SEED SMALLER HOSE 210	101	01
03	0541051039	CONDUCTOR SMALLER CURVED FERTILIZER/SEED HOSE 310	102	01
04	0541050969	CONDUCTOR FERTILIZER/SEED HOSE 310	100	10
05	0541051040	CONDUCTOR FERTILIZER/SEED HOSE 390	103	04
06	0541050967	CONDUCTOR FERTILIZER/SEED CURVED HOSE 210	430 105	01
07	0541051042	CONDUCTOR FERTILIZER/SEED CURVED HOSE 210	312 106	01
08	0541050968	CONDUCTOR REAR LINES FERTILIZER/SEED	99	06



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

