

ROW CROP PLANTERS

USAP 3200 SS SUPREMA - FRAME 11720 - UNI BOX
USAP 3200 SS SUPREMA - CHASSI 11720 - UNI BOX

Code: 0501093834
Series: S-0124
Revision: 00
Revision Date: FEBRUARY/2024

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Working Width	Description
0111600001		USAP 3200 SS UNI-BOX 11720/25E450 SUP S-0124

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.

INDEX

0909097100	ASSY FRAME	1
0909097101	FRAME RIGHT SIDE ASSY	2
0909097102	ASSY CENTRAL FRAME	3
0909097103	LEFT SIDE FRAME ASSY	4
0541053482	DRAWBAR ASSY 5103	5
0531057052	DRAWBAR ASSY	6
0531057067	DRAWBAR ESTABILIZER ASSY	7
0541051206	FRONT DRAWBAR	8
0521059886	SEMI-ASSEMBLED REST	9
0541053450	REAR DRAWBAR	10
0531059893	SIDE ARM LATCH ASSEMBLY	11
0531059877	CYLINDER HYDRAULIC 44,45 X 85,70 X 398 X 93	12
0541050977	CONVEYOR BELT ASSEMBLY	13
0541052820	ADJUSTABLE DUCT SUPPORT	14
0531057235	SIDE SUPPORT 5567	15
0531057236	SIDE SUPPORT 5567	16
0521057793	KNEECAP WITH RIGHT EXTENSION AXLE	17
0541053357	TANK TRACK	18
0541053400	HYDRAULIC CYLINDER 44,45X101,6X1162X565	19
0531058510	ASSY SENSOR FIXATION	20
0541053472	SHT SUPPORT SET VDRIVE	21
0541050497	COMMAND BLOCKS SET	22
0531059985	BLOCK HYDRAULIC COMMAND	23
0541050486	STABILIZER DRIVE BLOCK	24
0531059987	DRIVING BLOCK	25
0531059990	ROTATING DIVIDER	26
0541050081	SENSOR LIFTING SUPPORT	27
0541050145	GUIDE SET	28
0541050144	GUIDE SENSOR	29
0541050382	SUPPORT SENSOR ROW	30
0541053208	PDM SUPPORT WITH SCREW	31
0541051015	GUTTER 5S X 450 WITH SCREW	32
0541051638	GUTTER 5S X 450 WITH SCREW	33
0541051637	GUTTER 4S X 450 WITH SCREW	34
0541053483	HYDRAULIC HOSE ASSY	35
0541053484	SET HOSE TURBINE	36
0541053485	SET HOSE PANTOGRAPHIC	37
0541053486	HOSE LOCKS SET	38
0541053487	HOSE OPEN/CLOSE SET	39
0541053489	INOCULATING HOSE SET	40
0541053490	HOSE LIFT GAME	41
0541053491	ARTICULATED HOSE ASSEMBLY KIT	42
0531056065	STABILIZER	43
0531053738	STABILIZER EXTENDER	44
0531055314	MAJOR AXIS COMPLETE LOCK	45
0531059819	ARTICULATOR SUPPORT	46
0531059823	CYLINDER SIDE ARTICULATION	47
0531059915	HYDRAULIC CYLINDER 101,55X896	48
0531057693	HOSE SUPPORT	49
0541051653	RIGHT WHEELS	50
0531055358	COMPLETE SIDE CYLINDER BEARING	51
0531055357	LOCK PIN SET	52
0541050275	HYDRAULIC CYLINDER RIGHT 44.45X85.7X413	53
0541050292	MONO RIGHT WHEEL TIRE 500 X 50	54
0541050195	MOUNTED LEFT WHEEL	55
0541050294	FULL WHEEL BOX	56
0531059880	LARGER LOCK PIN ASSEMBLY	57
0541050845	HOSE STABILIZER	58
0541052202	HOSE GUIDE	59



MARCHESAN

INDEX

0541052199	LEFT SUPPORT	60
0541053452	FIXATION TUBE SEED LINES	61
0531059117	FULL HEAD HOSE STABILIZER	62
0521052549	CLAMP	63
0531058989	1 1/2 COMPLETE HANDCUFF CLAMP	64
0541053457	SET DUCTS RIGHT SIDE	65
0531050772	RIGHT CLAMP 4	66
0909097104	SEED LINE ASSY	67
0541052253	RIGHT SHORT SEED ROW	68
0541052254	ROW SEED LEFT LONG	69
0541052261	SEED ROW SLG LEFT SPICRR	70
0531054007	SHORT/LONG FRONT SEED ROW	71
0531051094	MOUNTED HOSE GUIDE ASSEMBLY	72
0541052255	RIGHT DDD REAR WITH	73
0521056640	PRECISION PLANTING CSC CABLE / TRANSMISSION ASSY	74
0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	75
0531059836	COMPACTOR WHEEL ASSEMBLY	76
0521054990	LEFT COMPACTOR WHEEL	77
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	78
0521055017	RIGHT COMPACTOR WHEEL	79
0531059837	SPA COMPACTING BODY WITHOUT BOLT	80
0541052256	RIGHT DDD REAR WITH SPICRR WITHOUT COMPACTOR WHEEL	81
0531059833	DEPTH REGULATOR	82
0521056631	MOUNTED LEFT ARM	83
0521056633	MOUNTED RIGHT ARM	84
0521055059	WHEEL RAYED ASSY SPA WITHOUT LUBRICATION	85
0521055073	ASSEMBLY DEPTH WHEEL HUB	86
0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	87
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	88
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	89
0521055864	FERTILIZER/SEED RIGHT HUB ASSY	90
0521055865	FERTILIZER/SEED LEFT HUB ASSY	91
0541050067	FRONT LONG SEED ROW	92
0541052257	LEFT DDD REAR WITH	93
0541052258	LEFT DDD REAR WITH SPICRR WITHOUT COMPACTOR WHEEL	94
0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	95
0531056775	FRONT SUPER LONG VDRIVE	96
0541050500	SHORT CUTTING DISC	97
0541050499	LONG CUTTING DISC	98
0541050502	SHORT LOWER SUPPORT	99
0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	100
0521053697	DISC BLADE HUB	101
0541050501	LONG LOWER SUPPORT	102
0531059845	CYLINDER HYDRAULIC 50,80 X 127 X 965 X 534	103
0541050276	CENTER LEFT TELESCOPIC WHEELS	104
0541050274	RIGHT CENTER TELESCOPIC WHEELS	105
0531054036	ASSY CENTER CYLINDER BEARING	106
0541050194	COMPLETE CENTRAL CUBE	107
0541050196	MOUNTED RIGHT WHEEL	108
0541050277	HYDRAULIC CYLINDER LEFT	109
0541053367	CENTRAL SEED BOX	110
0531054354	CENTRAL SEED BOX 2500 LITERS	111
0531054357	LOWER SYSTEM 28 PIPES	112
0531058201	HYDRAULIC TURBINE WITH SCREEN	113
0531056343	HYDRAULIC ENGINE	114
0521044613	480 X 50 FAN (HIDRAULIC)	115




MARCHESAN

INDEX

0531056344	COMMAND BLOCK	116
0541053366	CSC ASSEMBLY	117
0531054290	CENTRAL SEED BOX	118
0531054289	CENTRAL SEED BOX	119
0531054275	LOWER BOX SEED SYSTEM	120
0531058207	COMPLETE HYDRAULIC TURBINE	121
0541053331	CENTRAL ARTICULATOR SUPPORT	122
0541053333	CYLINDER SIDE ARTICULATION 44,45X85,70X213.5/563.5	123
0541053395	MOUNTED VACUUM METER SET	124
0541053378	LADDER	125
0541053396	COMPLETE 502 PLATFORM	126
0541053397	COMPLETE 718 PLATFORM	127
0541053404	COMPLETE LEFT SIDE HANDRAIL	128
0541053401	COMPLETE RIGHT SIDE HANDRAIL	129
0541053394	PLATFORM 2989 COMPLETE	130
0541053403	COMPLETE LEFT ARTICULATION ARM	131
0541053402	RIGHT ARTICULATION ARM	132
0541052180	STABILIZER HOSES	133
0541053383	LEFT FLASHLIGHT ASSEMBLY	134
0541053384	RIGHT FLASHLIGHT ASSEMBLY	135
0541053479	SEED ROWS FIXATION TUBE 3050 COMPLETE	136
0541053451	SUPPORT TURBINE COMPLETE	137
0541050844	TATU SUCTION TURBINE	138
0541050473	AIR DISTRIBUTOR T	139
0541053454	RIGHT SUPPORT T FIXATION	140
0541053453	LEFT SUPPORT T FIXATION	141
0521053672	LIGHTHOUSE ASSY	142
0541053455	VACUUM METER NEGATIVE ASSEMBLY MOUNTED	143
0541053494	REAR HEADLIGHT SUPPORT WITH FASTENING	144
0541050494	LIGHTING/CONTROL SET	145
0541053204	VDRIVE SET 25 LINES	146
0541051163	DECAL	147
0531059250	DOOR MANUAL	148
0531057692	LEFT COMPLETE HOSE SUPPORT	149
0541051652	LEFT MONO WHEELS TIRE 500/50	150
0541050293	LEFT WHEEL TIRE 500 X 50	151
0541053458	LEFT SIDE DUCT ASSEMBLY	152

ASSY FRAME

0909097100




Item	Code	Description	See page	QT
01		FRAME RIGHT SIDE ASSY	2	
02		ASSY CENTRAL FRAME	3	
03		LEFT SIDE FRAME ASSY	4	
04	0541053482	DRAWBAR ASSY 5103	5	01
05	0531057235	SIDE SUPPORT 5567	15	01
06	0531057236	SIDE SUPPORT 5567	16	01
07	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		02
08	0541053357	TANK TRACK	18	01
09	0541053400	HYDRAULIC CYLINDER 44,45X101,6X1162X565	19	02
10	0531058510	ASSY SENSOR FIXATION	20	01
11	0541053472	SHT SUPPORT SET VDRIVE	21	01
12	0513011981	NYLON BREATHER WITH AIR FILTER		02
13	0501318986	TERMINAL ADAPTER R.3/4 UNF		02
14	0501312548	SUPPORT 55 X 50 X 800		02
15	0503011334	3/8 UNC X 3/4 CS G.5 ZN BOLT		04
16	0503010025	3/8 SPRING WASHER		06
17	0541050081	SENSOR LIFTING SUPPORT	27	01
18	0531066344	ACTUATOR RULER		01
19	0503015321	3/8 UNC X 5/8 C S G.2 ZN BOLT		04
20	0501013518	FLAT WASHER		04
21	0541050145	GUIDE SET	28	01
22	0541050144	GUIDE SENSOR	29	01
23	0503011075	3/4 UNC LOCK NUT		02
24	0503013404	3/4" UNC X 1.3/4" BOLT		02
25	0501312550	GUTTER 55 X 50 X 300		01
26	0501312879	GLOVE 10.50 X 24 X 24		02
27	0501312549	GUTTER 100 X 30 X 450		01
28	0503010026	3/8" NUT		02
29	0501016103	FLAT WASHER		04
30	0501010096	3/8" X 2" BOLT		02
31	0503018774	MAGNETIC SENSOR		01
32	0503018775	MAGNETIC ACTUATOR LH7.4.000091		01

Item	Code	Description	See page	QT
33	0541050382	SUPPORT SENSOR ROW	30	02
34	0541053208	PDM SUPPORT WITH SCREW	31	01
35	0541051015	GUTTER 5S X 450 WITH SCREW	32	01
36	0541051638	GUTTER 5S X 450 WITH SCREW	33	02
37	0541051637	GUTTER 4S X 450 WITH SCREW	34	02
38	0541053483	HYDRAULIC HOSE ASSY	35	01
39	0541051416	ELECTRONIC HARNESS LOCK / LINE ASSEMBLY		01
40	0503064465	APPLICATION LINE KIT NEW PROINOC 7L - TC DRS - 6118		01
41	0503064467	APPLICATION LINE KIT NEW PROINOC 9L - TC DRS - 6120		02
42	0503064460	SPRAY KIT PROINOC TQ1000 CH-BPD 70L MTH DRS - 7235		01
43	0503063897	CARDAN 21Z 1.3/8 X 21Z 1.3/8 800MM		01
44	0513011183	TERMINAL CARDAN TRIANGULAR 20Z 1.3/4 SERIE 06		01
45	0521029660	BOX WITH 65 LITER MIXER KIT WITH PH		01
45A	0501100017	WOODEN BOX		01
45B	0503063744	KIT MIXER 65 LITROS FFUNDO CONICO DRS-1594		01
45C	0503063743	PH METER PORTABLE DIGITAL DRS-2425		01
45D	0511034819	PLASTIC COVER WITH INSTRUCTIONS MANUAL INOCULATING TANK		01
46	0531056065	STABILIZER	43	01

FRAME RIGHT SIDE ASSY

0909097101




Item	Code	Description	See page	QT
01	0591018045	FRICTION TRACK		02
02	0591018043	BODY SUPPORT		02
03	0503010962	5/8" X 1-1/4" BOLT		06
04	0503010027	5/8 SPRING WASHER		06
05	0501010453	FLAT WASHER		06
06	0531055314	MAJOR AXIS COMPLETE LOCK	45	01
07	0503012213	1/4" X 4" SPLIT PIN		01
08	0591018042	FRICTION PLATE		02
09	0591015962	SEPARATOR GLOVE		04
10	0531064368	AXLE 1.1/4 X 290 WITH LOCK		01
11	0501215131	SIDE WHEEL JOINT AXLE		01
12	0503010391	501038 CLAMPING RING (FOR AXLE)		01
13	0501215181	GLOVE 102 X 85.50 X 184		02
14	0503010834	1/2 X 1 BOLT		01
15	0503010019	1/2" SPRING WASHER		07
16	0591018044	WASHER 65 X 130 X 20		01
17	0531059819	ARTICULATOR SUPPORT	46	03
18	0531059915	HYDRAULIC CYLINDER 101,55X896	48	01
19	0531064361	CYLINDER AXLE 170.50MM		01
20	0503011052	1.1/4" X 0.77" CASTLE NUT		01
21	0503010038	3/16" X 2" SPLIT PIN		01
22	0531061755	NOZZLE Y SEED		04
23	0531057693	HOSE SUPPORT	49	02
24	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		10
25	0503010002	1800 GREASE FITTING		01
26	0541051653	RIGHT WHEELS	50	01
27	0541050845	HOSE STABILIZER	58	01
28	0541052202	HOSE GUIDE	59	02
29	0541052199	LEFT SUPPORT	60	04
30	0503019869	CLAMP		12
31	0501013519	FLAT WASHER		06
32	0503011401	1/2" X 3/4" BOLT		06

Item	Code	Description	See page	QT
33	0541053452	FIXATION TUBE SEED LINES	61	01
34	0531065126	FIXATION TUBE SEED LINES		01
35	0531067943	RIGHT SIDE FRAME		01
36	0531059117	FULL HEAD HOSE STABILIZER	62	02
37	0521052549	CLAMP	63	01
38	0503034867	AIR DISTRIBUTOR PUMP		01
39	0541050483	AIR TUBE CAP WITH CLAMP		01
39A	0503011372	102 TO 121 CLAMP		01
39B	0501012827	PIN LOCK		01
40	0531058989	1 1/2 COMPLETE HANDCUFF CLAMP	64	09
41	0541053457	SET DUCTS RIGHT SIDE	65	01
42	0531050772	RIGHT CLAMP 4	66	01
43	1164920015	BLACK SUCTION HOSE		05 mts
44	1164920014	BLACK LIGHT SUCTION HOSE		13 mts
45		SEED LINE ASSY	67	

ASSY CENTRAL FRAME

0909097102



Item	Code	Description	See page	QT
01	0503010019	1/2" SPRING WASHER		006
02	0531062245	233 CYLINDER JOINT AXIS		002
03	0503010834	1/2 X 1 BOLT		002
04	0503035505	HOSE PROTECTOR		002
05	0501212575	AIR CONDUCTOR PROTECTION		002
06	0531059845	CYLINDER HYDRAULIC 50,80 X 127 X 965 X 534	103	002
07	0541050276	CENTER LEFT TELESCOPIC WHEELS	104	001
08	0541050274	RIGHT CENTER TELESCOPIC WHEELS	105	001
09	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		012
10	0501017065	FLAT WASHER		021
11	0503019522	HEX NUT		020
12	0503019521	SCREW 3/4 UNF 3 CSRP G.8 ZN		020
13	0511015994	FLAT WASHER		002
14	0503018754	NUT 1 - 8 UNC - 2B G8		002
15	0501010276	BOLT		002
16	0531066439	LEFT HOSE SUPPORT		001
17	0531066442	RIGHT HOSE SUPPORT		001
18	0501010984	10,50 X 27 X 3,00 FLAT WASHER		002
19	0503010026	3/8" NUT		002
20	0503010025	3/8 SPRING WASHER		002
21	0501011532	3/8" X 1-3/4" BOLT		002
22	0541052081	ARTICULATOR SUPPORT WITH BUSHING		001
22A	0531067152	ARTICULATOR SUPPORT		001
22B	0513011646	SELF LUBRICANT GLOVE		002
22C	0503019273	AUTO LUBRICANT SLEEVE		002
23	0503013357	3/8 SELF-ADJUSTING NUT		008
24	0501010942	3/8" X 1-1/4" BOLT		004
25	0541053367	CENTRAL SEED BOX	110	001
26	0541053366	CSC ASSEMBLY	117	001
27	0531067874	CENTRAL FRAME		001
28	0501111258	BEARING WITH BUSHING		002
29	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		004

ASSY CENTRAL FRAME

0909097102

Item	Code	Description	See page	QT
30	0541053331	CENTRAL ARTICULATOR SUPPORT	122	002
31	0541053395	MOUNTED VACUUM METER SET	124	001
32	0541053378	LADDER	125	001
33	0541053396	COMPLETE 502 PLATFORM	126	001
34	0541053397	COMPLETE 718 PLATFORM	127	001
35	0541053404	COMPLETE LEFT SIDE HANDRAIL	128	001
36	0541053401	COMPLETE RIGHT SIDE HANDRAIL	129	001
37	0541053394	PLATFORM 2989 COMPLETE	130	001
38	0531067153	LOWER ARTICULATOR LOCK AXLE		001
39	0503011255	3/4" LOCK NUT		001
40	0541053403	COMPLETE LEFT ARTICULATION ARM	131	001
41	0541053402	RIGHT ARTICULATION ARM	132	001
42	0503034345	DISPENSER COVER		038
43	0541053383	LEFT FLASHLIGHT ASSEMBLY	134	001
44	0541053384	RIGHT FLASHLIGHT ASSEMBLY	135	001
45	0503011372	102 TO 121 CLAMP		003
46	0531060782	REAR CENTRAL TUBE FIXING SEED LINES		001
47	0541053479	SEED ROWS FIXATION TUBE 3050 COMPLETE	136	001
48	0541053451	SUPPORT TURBINE COMPLETE	137	002
49	0541050473	AIR DISTRIBUTOR T	139	001
50	0541053454	RIGHT SUPPORT T FIXATION	140	002
51	0541053453	LEFT SUPPORT T FIXATION	141	001
52	0531066387	SUPPORT RIGHT HOSE		001
53	0503010237	3/8" X 1" BOLT		004
54	0531066386	SUPPORT LEFT HOSE		001
55	0521053672	LIGHTHOUSE ASSY	142	002
56	0531050772	RIGHT CLAMP 4	66	008
57	0531059117	FULL HEAD HOSE STABILIZER	62	002
58	0501315935	HOSE GUIDE SUPPORT		002
59	0541053455	VACUUM METER NEGATIVE ASSEMBLY MOUNTED	143	001
60	0531058989	1 1/2 COMPLETE HANDCUFF CLAMP	64	007
61	0521052549	CLAMP	63	001
62	0503034867	AIR DISTRIBUTOR PUMP		001
63	0541050483	AIR TUBE CAP WITH CLAMP		001
63A	0501312827	AIR TUBE CAP		001
63B	0503011372	102 TO 121 CLAMP		001
64	1164920015	BLACK SUCTION HOSE		090 mts
65	1164920014	BLACK LIGHT SUCTION HOSE		011 mts
66	1163920004	BLACK LIGHT SUCTION HOSE		016 mts
67	0541053494	REAR HEADLIGHT SUPPORT WITH FASTENING	144	001
68	0541050494	LIGHTING/CONTROL SET	145	001
69	0541053204	VDRIVE SET 25 LINES	146	001
70	0541051163	DECAL	147	001
71	0541015451	WRENCH 2.3/8 X 2.3/4		001
72	0501047895	25 ROD STOP		004
73	0501047885	30 ROD STOP		008
74	0501047886	35 ROD STOP		004
75	0501047887	40 ROD STOP		008
76	0503010045	O'RING		001
77	0541010080	TERMINAL R.1 / 2 NPT		001
78	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		001
79	0581013729	NIPLE 1/2 NPT		001
80	0503011883	PLASTIC COVER		001
81	0503011628	FEMALE QUICK COUPLER		001
82	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		200
83	0503018829	NYLON CLAMP 7,8 X 1,8 X 390 MM		100
84	0531059250	DOOR MANUAL	148	001
85	0531055394	MOUNTED TRANSPORT LOCK 315MM		004
85A	0531064139	TRANSPORT LOCK 315MM		001
85B	0531060392	PIN LOCK TRANSPORT		001
85C	0503030168	HITCH PIN CLIP		001




USAP 3200 SS SUPREMA - FRAME 11720 - UNI BOX
ASSY CENTRAL FRAME

Page 3
0909097102

Item	Code	Description	See page	QT
86		SEED LINE ASSY	67	

LEFT SIDE FRAME ASSY

0909097103




Item	Code	Description	See page	QT
01	0501215181	GLOVE 102 X 85.50 X 184		02
02	0591018042	FRICTION PLATE		02
03	0503010962	5/8" X 1-1/4" BOLT		06
04	0501010453	FLAT WASHER		07
05	0503010027	5/8 SPRING WASHER		06
06	0591015962	SEPARATOR GLOVE		04
07	0531055314	MAJOR AXIS COMPLETE LOCK	45	01
08	0591018044	WASHER 65 X 130 X 20		01
09	0591018045	FRICTION TRACK		02
10	0591018043	BODY SUPPORT		02
11	0503012213	1/4" X 4" SPLIT PIN		01
12	0531064368	AXLE 1.1/4 X 290 WITH LOCK		01
13	0501215131	SIDE WHEEL JOINT AXLE		01
14	0503010391	501038 CLAMPING RING (FOR AXLE)		01
15	0503010834	1/2 X 1 BOLT		01
16	0503010019	1/2" SPRING WASHER		07
17	0531059915	HYDRAULIC CYLINDER 101,55X896	48	01
18	0531059819	ARTICULATOR SUPPORT	46	03
19	0531064361	CYLINDER AXLE 170.50MM		01
20	0503011052	1.1/4" X 0.77" CASTLE NUT		01
21	0503010038	3/16" X 2" SPLIT PIN		01
22	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		10
23	0503010002	1800 GREASE FITTING		01
24	0531057692	LEFT COMPLETE HOSE SUPPORT	149	02
25	0541051652	LEFT MONO WHEELS TIRE 500/50	150	01
26	0541052202	HOSE GUIDE	59	02
27	0541050845	HOSE STABILIZER	58	01
28	0541052199	LEFT SUPPORT	60	04
29	0531061755	NOZZLE Y SEED		04
30	0503019869	CLAMP		12
31	0501013519	FLAT WASHER		06
32	0503011401	1/2" X 3/4" BOLT		06

Item	Code	Description	See page	QT
33	0541053452	FIXATION TUBE SEED LINES	61	01
34	0531065126	FIXATION TUBE SEED LINES		01
35	0531067942	FRAME SIDE LEFT		01
36	0541050483	AIR TUBE CAP WITH CLAMP		01
36A	0503011372	102 TO 121 CLAMP		01
36B	0501012827	PIN LOCK		01
37	0531059117	FULL HEAD HOSE STABILIZER	62	02
38	0531058989	1 1/2 COMPLETE HANDCUFF CLAMP	64	09
39	0521052549	CLAMP	63	01
40	0503034867	AIR DISTRIBUTOR PUMP		01
41	0531050772	RIGHT CLAMP 4	66	01
42	0541053458	LEFT SIDE DUCT ASSEMBLY	152	01
43	1164920015	BLACK SUCTION HOSE		05 mts
44	1164920014	BLACK LIGHT SUCTION HOSE		13 mts
45		SEED LINE ASSY	67	

DRAWBAR ASSY 5103

0541053482




Item	Code	Description	See page	QT
01	0531064097	THREAD STRING 1 UNC 8 FPPX537 WITH NUT		02
02	0503010012	1" SPRING WASHER		02
03	0503012182	1" NUT		02
04	0531057052	DRAWBAR ASSY	6	01
05	0531058080	FRONT GUIDE		01
05A	0531065443	FRONT GUIDE		01
05B	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
05C	0503010589	1/2" UNC SELF ADJUSTING NUT		02
06	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		04
07	0541051206	FRONT DRAWBAR	8	01
08	0541053450	REAR DRAWBAR	10	01
09	0541050977	CONVEYOR BELT ASSEMBLY	13	01
10	0541052820	ADJUSTABLE DUCT SUPPORT	14	01
11	0513010752	SINGLE STANDARD CLAMP 12 MM - BLACK		56
12	0501312225	CLAMP 179 X 30 X 6.30		08
13	0503036577	TUBO HIDRÁULICO 404 PT12L X 2452 PT12L X 3180		07
14	0513010755	STANDARD SIMPLE CLAMP		16
15	0501312882	GUTTER		02
16	0501312881	SIDE FIXER		04
17	0503036580	HYDRAULIC TUBE 378 PT28 X 2746 FG28 X 3509		01
18	0503036579	HYDRAULIC TUBE 378 PT28 X 2789 FG28 X 3552		01
19	0513010746	STANDARD CLAMP SINGLE 10MM - BLACK		08
20	0503036578	HYDRAULIC TUBE 404 PT10L X 2456 PT10L X 3180		01
21	0501318970	UNIAO BRACADEIRAS 191 X 30 X 6,30		03
22	0513010753	SINGLE STANDARD CLAMP		12
23	0503010305	6,50 X 17 X 1,50 ZN FLAT WASHER		24
24	0503015110	M06 SPRING WASHER		16
25	0503014540	M6 NUT		16
26	0501215820	CLAMP FIXING COVER		06
27	0513011851	BOLT M6 X 1,00 X 175		06
28	0503036894	HYDRAULIC TUBE 403 PT15 X 1125 PT15 X 1860		02
29	0501314935	SUPPORT 100 X 33 X 2353		01



Item	Code	Description	See page	QT
30	0503010144	1/4" NUT		16
31	0503010143	1/4" SPRING WASHER		16
32	0503013758	1/4" X 1-1/2" BOLT		16
33	0513011671	M6 SCREW		10
34	0501312227	CLAMP FIXER		01

DRAWBAR ASSY


0531057052



Item	Code	Description	See page	QT
01	0501217466	TRACTION BAR GUIDE		02
02	0501010276	BOLT		04
03	0503010012	1" SPRING WASHER		04
04	0501010059	1.5/8 NUT		04
05	0503030119	LOCK PIN		01
06	0511069471	PLOUGH SUPPORT		02
07	0501011075	PIN		02
08	0503030285	HITCH PIN CLIP		02
09	0531065020	3 POINTS DRAWBAR ASSY		01
10	0503030085	LOCK PIN		08
11	0521068018	UPPER AXLE		01
12	0521068015	UPPER AXLE		01
13	0521068013	UPPER AXLE		01
14	0503012809	2" CASTLE NUT		01
15	0503010833	10 X 90 SPRING PIN		01
16	0501213695	EJE 1.1/4 X 380 MM		02
17	0531063869	AXLE 50 X 245 MM WITH THREAD 2 UNS 10 FPP		01
18	0521068011	AXLE LOWER		02
19	0531057067	DRAWBAR ESTABILIZER ASSY	7	01
20	0501217367	LEFT SUPPORT BOX		01
21	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
22	0503010589	1/2" UNC SELF ADJUSTING NUT		04
23	0501217366	RIGHT BOX SUPPORT		01
24	0503019293	SCREW 1/2 UNC X 2 COVER G7 ZN		04
25	0501217467	3 POINT HEAD FIXING GUIDE GLOVE		04
26	0531057145	COMPLETE SAFETY LOCK AXIS		01
26A	0531064617	LOCK AXLE COUPLING		01
26B	0501217474	FLAT WASHER 38.50 X 70 X 6.30		02
26C	0513010701	LOCK PIN		01

DRAWBAR ESTABILIZER ASSY


0531057067



Item	Code	Description	See page	QT
01	0531065026	HEAD HOSE STABILIZER		01
02	0531061935	CONDUCTOR ARTICULATOR		02
03	0503010237	3/8" X 1" BOLT		03
04	0503010025	3/8 SPRING WASHER		03
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		03
06	0503010019	1/2" SPRING WASHER		03
07	0503012556	1/2" X 1" BOLT		03
08	0531061934	CONDUCTOR ARTICULATOR GUIDE		03
09	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
10	0503010589	1/2" UNC SELF ADJUSTING NUT		02
11	0531065130	HYDRAULIC HOSE ARTICULATOR		01


FRONT DRAWBAR

0541051206



Item	Code	Description	See page	QT
01	0531059899	PANTOGRAPHIC DRAWBAR		01
02	0531059876	CYLINDER HYDRAULIC		01
03	0503010002	1800 GREASE FITTING		04
04	0591015449	AXLE LOCK HEADER		01
05	0503018754	NUT 1 - 8 UNC - 2B G8		02
06	0591015450	LOCK BODY GLOVE		02
07	0591018926	BODY LOCK BIGGER		01
08	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
09	0511054270	TENSIONER SPRING		01
09A	0511069520	TELESC LOCK SPRING TENSIONER		01
09B	0503010013	5/8 UNC G.5 ZN HEX NUT		02
10	0591015454	SPRING HITCH LOCK		01
11	0521011132	FLAT WASHER		02
12	0503010131	3/16" X 1.1/2" SPLIT PIN		02
13	0521058345	SAFETY CHAIN WITH SHACKLE		03
13A	0503014120	CHAIN		01
13B	0503014321	CABLE STEEL SHACKLE		02
14	0531064952	AXIS 308 TELESCOPIC HEAD		02
15	0591015457	CYLINDER GUIDE AXLE		01
16	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		01
17	0503010027	5/8 SPRING WASHER		02
18	0503010962	5/8" X 1-1/4" BOLT		01
19	0501011299	FLAT WASHER		01
20	0591018921	WASHER 63.5 X 39 X 6.30		04
21	0531060748	REST SUPPORT		01
22	0521059886	SEMI-ASSEMBLED REST	9	01
23	0501210174	SPRING SUPPORT		01
24	0503010233	5/8" X 2-1/2" BOLT		01
25	0503010013	5/8 UNC G.5 ZN HEX NUT		01
26	0531063995	AXIS 290 TELESCOPIC HEAD		01
27	0503010044	SELF LOCKING NUT 1.1/4 UNF G.5 ZN		03
28	0531064951	SIDE LOCK AXIS 381		01


Item	Code	Description	See page	QT
29	0503010290	SELF ADJUSTING 1.1/2" UNF NUT		01
30	0551012215	FLAT WASHER		01
31	0503014321	CABLE STEEL SHACKLE		01
32	0531065103	TELESCOPIC DRAWBAR 5285		01
33	0531066463	BODY LOCKS WITH PIN		01



Item	Code	Description	See page	QT
01	0503010571	1/4" X 1.1/2" SPLIT PIN		02
02	0521010784	COUPLING SHAFT		01
03	0531060758	AXLE JUNCTION 25.4 X 150 WITH HANDLE		01
04	0503030085	LOCK PIN		02
05	0531060667	REST		01
06	0521010580	COUPLING SHAFT		01
07	0521012533	COUPLING SHAFT		01
08	0591016111	TUBE 80 X 80 X 9,52 X 600MM		01
09	0531061640	REST		01

REAR DRAWBAR


0541053450




Item	Code	Description	See page	QT
01	0501010276	BOLT		14
02	0503010012	1" SPRING WASHER		14
03	0503012182	1" NUT		14
04	0501217064	SIDE FLANGE COVER		04
05	0503010002	1800 GREASE FITTING		08
06	0503010834	1/2 X 1 BOLT		32
07	0503010019	1/2" SPRING WASHER		56
08	0531059893	SIDE ARM LATCH ASSEMBLY	11	01
09	0501314046	HEADER CALCO		04
10	0501314072	GUIDE WEAR		04
11	0591015433	HEADER SUPPORT		04
12	0591015533	ADJUSTMENT SUPPORT		04
13	0591015434	NYLON ADJUSTABLE BACK HEAD		04
14	0503011401	1/2" X 3/4" BOLT		24
15	0531067944	REAR DRAWBAR 4343		01

SIDE ARM LATCH ASSEMBLY


0531059893



Item	Code	Description	See page	QT
01	0591015326	LATERAL FRAME LOCK		02
02	0531061411	STABILIZER ASSY LOCK ARM		01
03	0591015327	AXLE JUNCTION		02
04	0591015328	SPACING GLOVE		04
05	0591015329	CYLINDER GUIDE AXLE		01
06	0591015330	WASHER SUPPORT		02
07	0591015332	AXLE JUNCTION LOCK		03
08	0503019522	HEX NUT		04
09	0501010322	20,50 X 46 X 4,00 ZN FLAT WASHER		10
10	0503010880	501032 CLAMPING RING (FOR AXLE)		05
11	0531061445	TOP PLATE WITH GLOVE		02
12	0503010019	1/2" SPRING WASHER		02
13	0591015341	GLOVE SUPPORT		04
14	0591015340	WASHER SUPPORT GUIDE AXIS		01
15	0511016281	3/4" X 8" BOLT		02
16	0501210625	SUPPORT GLOVE		02
17	0503013776	BOLT 1/2 UNC X 7/8 C S G.5 ZN		02
18	0501013475	BOLT 3/4" UNC X 7.1/2" C S G.5 ZN		02
19	0531059877	CYLINDER HYDRAULIC 44,45 X 85,70 X 398 X 93	12	01



Item	Code	Description	See page	QT
01	0591015343	EXTENSOR 44,45 X 280MM		01
02	0503010063	1" SELF-ALIGNING NUT		01
03	0502010843	1.8" X 3.4" PISTON		01
04	0503010042	2-214 N 3006-9B O'RING		01
05	0503010170	PACKING 3120 2750		02
06	0503010948	W4-3346-590 PK RING G.E		01
07	0502040747	32.54 CLEVIS CLAMP		01
08	0503011094	BOLT 3/8" UNC X 2" C C S I 12.9		01
09	0503010025	3/8 SPRING WASHER		01
10	0503010026	3/8" NUT		01
11	0502010781	RING SUPPORT		01
12	0503010949	W2-2000-500 PK RING G.E		01
13	0503010990	GASKET		01
14	0503010761	D-1750 SCRAPER RING		01
15	0503010976	2-336 N 3006-9B O'RING		01
16	0503011060	8-336 BACK-UP RING		01
17	0502010993	MOBILE LID		01
18	0531066085	CILINDER CASE 85,70 X 272		01




Item	Code	Description	See page	QT
01	0541050980	SUPPORT REAR		01
01A	0531066589	SUPPORT REAR		01
01B	0531059091	MAT ROLLER 215MM		02
01BA	0501310150	AXIS FIXING HOSE GLOVE 280MM		01
01BB	0501310149	GLOVE 16,30 X 30 X 215MM		01
01BC	0503016739	SELF LOCKING HEX NUT WITH NYLON		02
01BD	0503010743	1/4" X 1-1/4" BOLT		02
02	0541050979	SUPPORT FRONT		01
02A	0531066588	SUPPORT FRONT 1530		01
02B	0531059091	MAT ROLLER 215MM		03
02BA	0501310150	AXIS FIXING HOSE GLOVE 280MM		01
02BB	0501310149	GLOVE 16,30 X 30 X 215MM		01
02BC	0503016739	SELF LOCKING HEX NUT WITH NYLON		02
02BD	0503010743	1/4" X 1-1/4" BOLT		02
03	0501312861	FRONT SUPPORT MAT		02
04	0531066424	GUTTER SUPPORT BASE		01
05	0531059935	CABLE GUIDE HEADER		02
05A	0501311320	CABLE GUIDE HEADER		01
05B	0503010519	1/4" X 5/8" BOLT		02
05C	0503010144	1/4" NUT		02
05D	0501311321	LOCK GUIDE CABLES		01
06	0501310233	GUTTER FIXING PLATE		04
07	0501219500	SUPPORT 70 X 40 X 900		02
08	0501217333	ARTICULATOR AXLE 233		02
09	0501312865	AXIS LOCK SUPPORT GUTTER		01
10	0501312866	ARTICULATOR AXLE 25.40 X 56.50		02
11	0501010100	BOLT 5/8" UNC X 2 CS G.5 ZN		04
12	0503011952	5/16" X 3/4" BOLT		12
13	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		08
14	0501013519	FLAT WASHER		08
15	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
16	0501010694	FLAT WASHER 32,50 X 75 X 4,75		12




USAP 3200 SS SUPREMA - FRAME 11720 - UNI BOX
CONVEYOR BELT ASSEMBLY

Page 13
0541050977


Item	Code	Description	See page	QT
17	0503010019	1/2" SPRING WASHER		08
18	0503010027	5/8 SPRING WASHER		04
19	0503010013	5/8 UNC G.5 ZN HEX NUT		04
20	0503013759	NUT		12




Item	Code	Description	See page	QT
01	0501317267	DUCT SUPPORT		01
02	0501317268	DUCT SUPPORT		01
03	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
04	0503010589	1/2" UNC SELF ADJUSTING NUT		04
05	0521014188	FLAT WASHER		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010060	1/2 UNC G.5 ZN HEX NUT		02
08	0503014378	1/2" X 1-1/2" BOLT		02




Item	Code	Description	See page	QT
01	0521057793	KNEECAP WITH RIGHT EXTENSION AXLE	17	01
02	0531065127	SIDE SUPPORT RIGHT 5167		01
03	0531064246	EAR BIGGER SIDE EXTENSOR		01
04	0571019949	JUNCTION SHAFT		01
05	0503030119	LOCK PIN		01
06	0503010038	3/16" X 2" SPLIT PIN		01
07	0503011052	1.1/4" X 0.77" CASTLE NUT		01
08	0531061650	FRONT SIDE SUPPORT AXIS		01
09	0501214789	FRONT AXLE BODY FRENCH HAND		01
10	0503010589	1/2" UNC SELF ADJUSTING NUT		01
11	0503010847	1/2" X 3.1/4" BOLT		01
12	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521057793	KNEECAP WITH RIGHT EXTENSION AXLE	17	01
02	0531065128	SIDE SUPPORT LEFT 5167		01
03	0531064246	EAR BIGGER SIDE EXTENSOR		01
04	0571019949	JUNCTION SHAFT		01
05	0503030119	LOCK PIN		01
06	0503010038	3/16" X 2" SPLIT PIN		01
07	0503011052	1.1/4" X 0.77" CASTLE NUT		01
08	0531061650	FRONT SIDE SUPPORT AXIS		01
09	0501214789	FRONT AXLE BODY FRENCH HAND		01
10	0503010589	1/2" UNC SELF ADJUSTING NUT		01
11	0503010847	1/2" X 3.1/4" BOLT		01
12	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0521062617	NUT FIXER		01
02	0531060778	EXTENSION AXLE 466 WITH DRAG		01
03	0561019879	LOCK ATTACHMENT BAR		01
04	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0531067918	TANK EASEL 1000 LITERS		01
02	0501011027	5/8" X 3-3/4" BOLT		08
03	0503013389	5/8" SELF LOCKING NUT		08
04	0503010752	1/2" X 3.1/2" BOLT		06
05	0503010589	1/2" UNC SELF ADJUSTING NUT		06
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06




Item	Code	Description	See page	QT
01	0503010338	2-342 N 3006-9B O'RING		02
02	0503017938	RING GUIDE		01
03	0503018029	O'RING 2-217 N 3006 90B		01
04	0503017936	RING		01
05	0503011061	8-342 BACK-UP RING		02
06	0503010761	D-1750 SCRAPER RING		01
07	0531067939	CYLINDER BARREL 101,55 X 764 X 491		01
08	0581010837	PISTON		01
09	0503017937	GASKET		01
10	0503010002	1800 GREASE FITTING		01
11	0531067951	ROD 1 3/4 X 745		01
12	0503018045	2-130 (AGEL) O'RING		04
13	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
14	0581010302	RING OF SUPPORT		01
15	0502012822	END CAP 4"		01
16	0503015633	SELEMASTER SEALING		01

ASSY SENSOR FIXATION


0531058510




Item	Code	Description	See page	QT
01	0501219250	SENSOR FIXATION		01
02	0503010722	3/16" X 5/8" BOLT		02
03	0503015013	3/16 SELF ADJUSTING NUT NC 1K02881		02
04	0501013518	FLAT WASHER		02
05	0503013357	3/8 SELF-ADJUSTING NUT		02
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0541050497	COMMAND BLOCKS SET	22	01
02	0541050020	DOUBLE ROTATING DIVIDER		01
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
04	0503014371	M8 SPRING WASHER		02
05	0503011295	M 8 X 1,25 X 25 BOLT		02
06	0503063819	CARDAN 21Z 1.3/8 X 20Z 1.3/4		01
07	0531059986	DRIVE COMMAND BLOCK		01
08	0503010172	M10 X 1,5 X 25 BOLT		02
09	0503015075	M10 SPRING WASHER		02
10	0501013518	FLAT WASHER		02
11	0501310425	GUTTER 55 X 50 X 460		01
12	0513010827	TERMINAL ADAPTER ORIGINAL R.7/16		01
13	0513010928	KNEE TERMINAL 90G		01
14	0513012510	UNION FEMALE MANOMETER		01
15	0503016888	MANOMETER 0-500		01
16	0541050504	HEAT EXCHANGER		01
17	0541050773	BLOCK COMMAND		01
18	0541053473	PASSAGE BLOCK SET		01
19	0541050526	DOUBLE PUMP MULTIPLIER		01




Item	Code	Description	See page	QT
01	0531066262	COMMAND BLOCK SUPPORT		01
02	0531066267	BLOCK SUPPORT		01
03	0501312858	FIXING PLATE		01
04	0531059985	BLOCK HYDRAULIC COMMAND	23	01
05	0541050486	STABILIZER DRIVE BLOCK	24	01
06	0531059987	DRIVING BLOCK	25	01
07	0531059990	ROTATING DIVIDER	26	01
08	0513010828	TERMINAL KNEEL		01
09	0513011277	TERMINAL		01
10	0513011854	TEE TERMINAL		02
11	0513011855	TEE TERMINAL		01
12	0513011852	TERMINAL ADAPTER 1.1/4 BSP X TB22		02
13	0503034478	HYDRAULIC TUBE		01
14	0503015112	M10 X 1,5 X 30 BOLT		07
15	0501010984	10,50 X 27 X 3,00 FLAT WASHER		17
16	0503015075	M10 SPRING WASHER		07
17	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
18	0503010025	3/8 SPRING WASHER		10
19	0503010026	3/8" NUT		10
20	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		06
21	0503011828	FLAT WASHER 13 X 24 X 2,00 ZN		06
22	0503010019	1/2" SPRING WASHER		06
23	0503010060	1/2 UNC G.5 ZN HEX NUT		06
24	0503011404	BOLT		06
25	0503011294	M 8 X 1,25 X 20 BOLT		03
26	0501010694	FLAT WASHER 32,50 X 75 X 4,75		03
27	0503014371	M8 SPRING WASHER		03




Item	Code	Description	See page	QT
01	0513010721	HYDRAULIC CONTROL BLOCK		01
02	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		02
03	0513010832	ADAPTER TERMINAL MF R.1.5/16 UNF ORING X TB28		04
04	0513010839	ADAPTER TERMINAL MF R.1/4 BSP ORING X MF TB10L		01
05	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		02
06	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		02




Item	Code	Description	See page	QT
01	0513011736	COMMAND BLOCK		01
02	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		04
03	0513011856	ADAPTER TERMINAL 9/16 UNF ORING X MF TB10L		01




Item	Code	Description	See page	QT
01	0503063488	HYDRAULIC CONTROL BLOCK		01
02	0513011034	ADAPTER TERMINAL MF R7/8 UNF ORING X MF TB12L		12
03	0513010831	ADAPTER TERMINAL MF R.1.1/16		01




Item	Code	Description	See page	QT
01	0513010747	HYDRAULIC ROTATING DIVIDER		01
02	0513011034	ADAPTER TERMINAL MF R7/8 UNF ORING X MF TB12L		04
03	0513010832	ADAPTER TERMINAL MF R.1.5/16 UNF ORING X TB28		01




Item	Code	Description	See page	QT
01	0501311516	UPPER SHEET		01
02	0501311515	SENSOR LIFTING SUPPORT		01
03	0503018775	MAGNETIC ACTUATOR LH7.4.000091		01
04	0503018774	MAGNETIC SENSOR		01
05	0503015321	3/8 UNC X 5/8 C S G.2 ZN BOLT		02
06	0501013518	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0501311680	LEFT GUIDE TRIGGER		01
02	0501311682	NYLON GLOVE 70		02
03	0503010140	1/8" X 3/4" SPLIT PIN		02
04	0501311681	FIXING PIN		02




Item	Code	Description	See page	QT
01	0501311679	RIGHT TRIGGER GUIDE		01
02	0501311682	NYLON GLOVE 70		02
03	0501311681	FIXING PIN		02
04	0503010140	1/8" X 3/4" SPLIT PIN		02




Item	Code	Description	See page	QT
01	0503011828	FLAT WASHER 13 X 24 X 2,00 ZN		02
02	0503010060	1/2 UNC G.5 ZN HEX NUT		02
03	0503010019	1/2" SPRING WASHER		02
04	0521014021	1/2" X 4.5" X 5.4" FASTENER		01
05	0501312553	SENSOR SUPPORT		01
06	0503015013	3/16 SELF ADJUSTING NUT NC 1K02881		02
07	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02




Item	Code	Description	See page	QT
01	0501318297	SUPPORT PDM		01
02	0503011776	SELF-LOCKING HEX NUT		04
03	0503014378	1/2" X 1-1/2" BOLT		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503011828	FLAT WASHER 13 X 24 X 2,00 ZN		04










Item	Code	Description	See page	QT
01	0501311926	CENTRAL GUTTER		01
02	0503013029	3/8" X 3/4" BOLT		05
03	0503013357	3/8 SELF-ADJUSTING NUT		05
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		05



Item	Code	Description	See page	QT
01	0501312250	SUPPORT 5S 50 X 30 X 2200		01
02	0503013029	3/8" X 3/4" BOLT		05
03	0503013357	3/8 SELF-ADJUSTING NUT		05
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		05




Item	Code	Description	See page	QT
01	0501314887	SUPPORT 4S 50 X 30 X 1750		01
02	0503013029	3/8" X 3/4" BOLT		04
03	0503013357	3/8 SELF-ADJUSTING NUT		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04




Item	Code	Description	See page	QT
01	0541053484	SET HOSE TURBINE	36	01
02	0541053485	SET HOSE PANTOGRAPHIC	37	01
03	0541053486	HOSE LOCKS SET	38	01
04	0541053487	HOSE OPEN/CLOSE SET	39	01
05	0541053489	INOCULATING HOSE SET	40	01
06	0541053490	HOSE LIFT GAME	41	01
07	0541053491	ARTICULATED HOSE ASSEMBLY KIT	42	01

SET HOSE TURBINE

0541053484




Item	Code	Description	See page	QT
01	0501082899	HOSE 3/8 X 1100 FG TB12L X FG C90 TB12L		06
02	0501082993	HOSE 3/8 X 600 FG TB12L X FG C90 TB12L		04
03	0501082971	HOSE 3/8 X 800 FG TB12L X FG C90 TB12L		02
04	0501082955	HOSE 3/8 X 1600 FG TB12L X FG C90 TB12L		02
05	0501083278	HOSE 3/8 X 3500 FG TB12L X FG C90 TB12L		01
06	0501082877	HOSE 1/2 X 1700 FG TB15 X FG C90 TB15		02
07	0501083028	HOSE 3/8 X 2000 FG TB12L X FG C90 TB12L		01
08	0501083068	HOSE 1/2 X 3000		02
09	0501083277	HOSE 1/2 X 3500 FG TB15 X FG C90 TB15		02
10	0501082893	HOSE 3/8 X 3000 FG TB12L X FG C90 TB12L		01
11	0501082918	HOSE 1/4 X 500 FG TB10L X FG TB10L		02
12	0501082919	HOSE 1/2 X 500 FG TB15 X FG TB15		04
13	0501082963	HOSE 1/4 X 530 FG TB10L X FG C90 TB10L		01
14	0501082971	HOSE 3/8 X 800 FG TB12L X FG C90 TB12L		01
15	0501082974	HOSE 1/4 X 430 FG TB10L X FG C90 TB10L		01
16	0501082900	HOSE 3/8 X 650 FG TB12L X FG C90 TB12L		01
17	0501083102	HOSE1 X 7200 FG TB28 X FG TB28		01
18	0501082917	HOSE 2 X 1400		01
19	0501082980	HOSE 1/2 X 3600 FG TB15 X FG C90		01
20	0501083103	HOSE 1 X 5700 FG TB28 X FG TB28		01
21	0501082970	HOSE 3/8 X 3400 FG TB12L X FG C90 TB12L		02
22	0501082982	HOSE 1.1/4 X 1100 FG TB35 X FG TB35		01
23	0501083282	HOSE 3/8 X 5200 FG TB12L X FG C90 TB12L		01
24	0501082717	HOSE 1/4 X 7300 TC-TC		01




Item	Code	Description	See page	QT
01	0501082957	HOSE 3/8 X 1300 FG TB12L X FG C90 TB12L		02
02	0501083105	HOSE 3/8 X 5100 FG TB12L X FG TB12L		02

HOSE LOCKS SET


0541053486




Item	Code	Description	See page	QT
01	0501082957	HOSE 3/8 X 1300 FG TB12L X FG C90 TB12L		03
02	0501082945	HOSE 3/8 X 1200 FG TB12L X FG C90 TB12L		01
03	0501082983	HOSE 3/8 X 500 FG TB12L X FG C90 TB12L		01
04	0501082942	HOSE 3/8 X 450 FG TB12L X FG C90 TB12L		01
05	0501083104	HOSE 3/8 X 5750 FG TB12L X FG TB12L		02




Item	Code	Description	See page	QT
01	0501082899	HOSE 3/8 X 1100 FG TB12L X FG C90 TB12L		03
02	0501082890	HOSE 3/8 X 1250 FG TB12L X FG C90 TB12L		01
03	0501082945	HOSE 3/8 X 1200 FG TB12L X FG C90 TB12L		02



Item	Code	Description	See page	QT
01	0501082923	HOSE 1/2 X 1900 FG TB15 X FG C90 TB15		01
02	0501082872	HOSE 3/4 X 2800 FG TB22 X FG TB22 WITH SPRING		01
03	0501082925	HOSE 1/2 X 2800 FG TB15 X FG TB15 WITH SPRING		01
04	0501082926	HOSE 1/2 X 4500 FG TB15 X FG C90 TB15		02
05	0501083074	HOSE 1/2 X 700 FG TB15 X FG C90 TB15		02




Item	Code	Description	See page	QT
01	0501082946	HOSE 3/8 X 2650 FG TB12L X FG TB12L		04
02	0501082947	HOSE 3/8 X 2300 FG TB12L X FG C90 TB12L		02
03	0501082892	HOSE 3/8 X 2700 FG TB12L X FG C90 TB12L		02
04	0501082887	HOSE 3/8 X 1350 FG TB12L X FG C90 TB12L		02
05	0501082948	HOSE 3/8 X 1100 FG TB12L X FG TB12L		02
06	0501082900	HOSE 3/8 X 650 FG TB12L X FG C90 TB12L		01
07	0501082949	HOSE 3/8 X 580 FG TB12L X FG C90 TB12L		01
08	0501082950	HOSE 3/8 X 530 FG TB12L X FG C90 TB12L		01
09	0501082883	HOSE 3/8 X 470 FG TB12L X FG C90 TB12L		01




Item	Code	Description	See page	QT
01	0501082901	HOSE 3/8 X 1150 FG TB12L X FG C90 TB12L		02
02	0501082952	HOSE 3/8 X 700 FG TB12L X FG C90 TB12L		12
03	0501082953	HOSE 3/8 X 3100 FG TB12L X FG C90 TB12L		04
04	0501082954	HOSE 3/8 X 3350 FG TB12L X FG C90 TB12L		04
05	0501082955	HOSE 3/8 X 1600 FG TB12L X FG C90 TB12L		03
06	0501082956	HOSE 3/8 X 1700 FG TB12L X FG C90 TB12L		01
07	0501082957	HOSE 3/8 X 1300 FG TB12L X FG C90 TB12L		02
08	0501082890	HOSE 3/8 X 1250 FG TB12L X FG C90 TB12L		02
09	0501082958	HOSE 1/2 X 1050 FG TB15 X FG C90 TB15		01
10	0501082959	HOSE 1/2 X 870 FG TB15 X FG C90 TB15		01
11	0501082972	HOSE 1/2 X 1250 FG TB15 X FG C90 TB15		01
12	0501083080	HOSE 3/8 X 700 FG TB12L X FG TB12L		02

STABILIZER


0531056065



Item	Code	Description	See page	QT
01	0531053738	STABILIZER EXTENDER	44	01
02	0531064461	PROLONGER		02
03	0501015348	1-1/4" X 3-3/4" BOLT		02
04	0503010070	SPRING WASHER		02
05	0503013026	1.1/4" CASTLE NUT		02




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0531063229	LABEL WITH LEFT EXTENDER		01
03	0531063230	LABEL WITH RIGHT EXTENDER		01
04	0501211865	LABEL FIXER		02
05	0503011052	1.1/4" X 0.77" CASTLE NUT		02
06	0501061056	1.1/2" RIGHT LOCK-NUT		01
07	0503010002	1800 GREASE FITTING		02
08	0503010571	1/4" X 1.1/2" SPLIT PIN		02




Item	Code	Description	See page	QT
01	0502040080	FLANGE NUT R.2.1/2" UN		01
02	0503010002	1800 GREASE FITTING		01
03	0531064074	MAJOR AXIS LOCK		01

ARTICULATOR SUPPORT


0531059819



Item	Code	Description	See page	QT
01	0531066049	SIDE SUPPORT		01
02	0531059823	CYLINDER SIDE ARTICULATION	47	01
03	0501111207	ARTICULATOR SUPPORT		01
04	0531061418	FIXING FLANGE HYDRAULIC CYLINDER WITHOUT LUBRICATION		02
05	0503010589	1/2" UNC SELF ADJUSTING NUT		04
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
07	0501211496	GLOVE 16 X 25 X 27 WITH HOLE		01
08	0591013172	31.75 X126 AXLE WITH 8 HOLE		01
09	0503012231	1/4" X 3" SPLIT PIN		01
10	0591017796	ARTICULATION AXIS 222 R.1.1 / 4 UNF		01
11	0591019305	FLAT WASHER 20 X 60 X 4.75 WITH CUT OUT		01
12	0501011544	3/4" X 1-1/2" BOLT		01
13	0503010023	3/4" SPRING WASHER		01
14	0591018408	PIN LOCK LINES		01
15	0503030085	LOCK PIN		01
16	0502012789	FIXER SUPPORT FERTILIZER ROW		02
17	0503017857	BOLT 5/8 UNF 4		08
18	0503010811	5/8" UNF SELF ADJUSTING NUT		08
19	0503011075	3/4 UNC LOCK NUT		06
20	0501010125	3/4" X 2-1/2" BOLT		06
21	0503019408	IGLIDUR GSM-4550-30 AUTO LUBRICANT GLOVE		02
22	0501314982	ARTICULATOR SHAFT		01
23	0503010301	0.3" X 1.8" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503010761	D-1750 SCRAPER RING		01
02	0571019711	RING SUPPORT		01
03	0571019709	DETACHABLE COVER		01
04	0503017936	RING		01
05	0503017938	RING GUIDE		01
06	0503017937	GASKET		01
07	0503017940	8-337 BACK-UP RING		02
08	0503017939	2-337 N 3006-9B O' RING		02
09	0503018045	2-130 (AGEL) O'RING		04
10	0511064408	FORK		01
11	0503010025	3/8 SPRING WASHER		01
12	0503011094	BOLT 3/8" UNC X 2" C C S I 12.9		01
13	0503010026	3/8" NUT		01
14	0503010042	2-214 N 3006-9B O'RING		01
15	0503010063	1" SELF-ALIGNING NUT		01
16	0571019710	1.7" X 3.4" PISTON		01
17	0503017935	RING		01
18	0503018144	RING		01
19	0501214514	EXTENDER 44.45 X 534		01
20	0531066046	CYLINDER CASE		01



Item	Code	Description	See page	QT
01	0581010302	RING OF SUPPORT		01
02	0502012822	END CAP 4"		01
03	0503011061	8-342 BACK-UP RING		02
04	0503010338	2-342 N 3006-9B O'RING		02
05	0503017936	RING		01
06	0503017938	RING GUIDE		01
07	0503017937	GASKET		01
08	0503010761	D-1750 SCRAPER RING		01
09	0531062936	SWIVEL CYLINDER STEM		01
10	0581010837	PISTON		01
11	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
12	0503015633	SELEMASTER SEALING		01
13	0503018029	O'RING 2-217 N 3006 90B		01
14	0503010002	1800 GREASE FITTING		02
15	0531066114	CYLINDER CASE		01

HOSE SUPPORT


0531057693



Item	Code	Description	See page	QT
01	0531065307	SUPPORT RIGHT HOSE		01
02	0531065306	ARTICULATOR HOSE		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0503010025	3/8 SPRING WASHER		02
05	0503010237	3/8" X 1" BOLT		01
06	0503010849	3/8" X 1-1/2" BOLT		01
07	0503010026	3/8" NUT		01

RIGHT WHEELS

0541051653




Item	Code	Description	See page	QT
01	0531066957	RIGHT SIDE WHEEL CHASSIS		01
02	0501214463	SIDE WHEEL PULLEY		06
03	0503014559	ROLLER BEARING		02
04	0503010095	SEAL		01
05	0501213909	WHEELED HUB COVER		01
06	0502040080	FLANGE NUT R.2.1/2" UN		01
07	0503010002	1800 GREASE FITTING		13
08	0501213917	ADJUSTMENT WASHER		01
09	0503012213	1/4" X 4" SPLIT PIN		01
10	0531066281	SIDE WHEEL TOWER		01
11	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
13	0501214462	NYLON PULLEY BUSHING		12
14	0501214303	WHEEL CHAIN		06
15	0531064110	PULLEY LOCK AXLE		06
16	0503010834	1/2 X 1 BOLT		06
17	0503010019	1/2" SPRING WASHER		06
18	0591017921	BRONZE GLOVE 90.5 X 115 X 91		02
19	0501214460	AXLE 1.1/2 X 140MM		01
20	0503010390	SEAL RING		02
21	0531055358	COMPLETE SIDE CYLINDER BEARING	51	02
22	0531055357	LOCK PIN SET	52	01
23	0501214302	ADJUSTMENT COVER PLATE		06
24	0503034377	3/8 UNC X 3/4 BOLT		36
25	0503010025	3/8 SPRING WASHER		36
26	0501017065	FLAT WASHER		06
27	0503011255	3/4" LOCK NUT		06
28	0501216430	ADJUSTING COVER CALCO		06
29	0541050275	HYDRAULIC CYLINDER RIGHT 44.45X85.7X413	53	01
30	0503012623	3/8" X 1-1/2" BOLT		01
31	0503010208	HEX NUT 3/8 UNF G.5 ZN		01
32	0501311048	BEATER AXLE 230		01



RIGHT WHEELS

0541051653


Item	Code	Description	See page	QT
33	0541050292	MONO RIGHT WHEEL TIRE 500 X 50	54	01
34	0531059880	LARGER LOCK PIN ASSEMBLY	57	01




Item	Code	Description	See page	QT
01	0501111135	BIGGER BEARING CYLINDER SUPPORT WITHOUT LUBRICATION		01
01A	0531064111	LARGER FIXING FLANGE HYDRAULIC CYLIND		01
01B	0503019408	IGLIDUR GSM-4550-30 AUTO LUBRICANT GLOVE		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
03	0503010589	1/2" UNC SELF ADJUSTING NUT		02

LOCK PIN SET


0531055357




Item	Code	Description	See page	QT
01	0591016056	LOCK AXLE SUPPORT		01
02	0531061626	38 X 308 JUNCTION AXLE WITH HANDLE		02
03	0503030119	LOCK PIN		02
04	0503010834	1/2 X 1 BOLT		01
05	0503010019	1/2" SPRING WASHER		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0531066275	CYLINDER CASE		01
02	0503010042	2-214 N 3006-9B O'RING		01
03	0503010063	1" SELF-ALIGNING NUT		01
04	0503010761	D-1750 SCRAPER RING		01
05	0571019710	1.7" X 3.4" PISTON		01
06	0503017935	RING		01
07	0503018144	RING		01
08	0571019711	RING SUPPORT		01
09	0571019709	DETACHABLE COVER		01
10	0503017936	RING		01
11	0503017938	RING GUIDE		01
12	0503017937	GASKET		01
13	0503017940	8-337 BACK-UP RING		02
14	0503017939	2-337 N 3006-9B O' RING		02
15	0503018045	2-130 (AGEL) O'RING		04
16	0531064313	ROD 1.3/4 X 826MM WITH SLEEVE		01




Item	Code	Description	See page	QT
01	0531064118	WHEEL RIGHT TIRE 500/50		01
02	0501213744	SINGLE ARM WHEEL AXLE		01
03	0503019246	BOLT		01
04	0503011075	3/4 UNC LOCK NUT		01
05	0501213743	LOCK AXLE		01
06	0501213742	SUPPORT WASHER		01
07	0503010953	BOLT 1 UNC X 2 C S G.5 ZN		01
08	0503010012	1" SPRING WASHER		01
09	0541050195	MOUNTED LEFT WHEEL	55	01
10	0541050294	FULL WHEEL BOX	56	01




Item	Code	Description	See page	QT
01	0513010700	TIRE 500-50-17 FLOTATION T422 I1 18PR TECH SHEET		01
02	0503013999	VALVE 16MM AGR		01
03	0503036301	RIM 16 X 17		01




Item	Code	Description	See page	QT
01	0501213734	ROLLED EIXO		01
02	0541050193	WHEEL COMPLETE BOX		01
02A	0501111223	BOX ROUND WITH SCREW		01
02AA	0501213765	WHEEL BOX		01
02AB	0503014048	HEX NUT M22X1,5" CH32X33,5		08
02AC	0503810007	WHEEL BOLT		08
02B	0503010002	1800 GREASE FITTING		01
02C	0541013225	WHEEL HUB LID		01
02D	0503011444	SPRING WASHER 5/16"		06
02E	0503010240	BOLT		06
02F	0502040080	FLANGE NUT R.2.1/2" UN		01
02G	0503011345	1/4" X 3.1/2" SPLIT PIN		01
02H	1882970002	GREASE		01
02I	0503010050	SEAL 00085-B		01
02J	0503013633	BEARING 33287/33462		01
02K	0503013496	3982/3920 ROLLER BEARING		01



Item	Code	Description	See page	QT
01	0591016056	LOCK AXLE SUPPORT		01
02	0503030119	LOCK PIN		01
03	0503010834	1/2 X 1 BOLT		01
04	0503010019	1/2" SPRING WASHER		01
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
06	0531064367	AXLE LOCK ARTICULATION WHEEL		01




Item	Code	Description	See page	QT
01	0531061934	CONDUCTOR ARTICULATOR GUIDE		01
02	0531061935	CONDUCTOR ARTICULATOR		01
03	0503010237	3/8" X 1" BOLT		01
04	0503010025	3/8 SPRING WASHER		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
08	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		01




Item	Code	Description	See page	QT
01	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
02	0503010025	3/8 SPRING WASHER		01
03	0503010237	3/8" X 1" BOLT		01
04	0531067189	HOSE GUIDE WITH BUSHING		01
05	0531061935	CONDUCTOR ARTICULATOR		01

LEFT SUPPORT


0541052199



Item	Code	Description	See page	QT
01	0531067188	LEFT HOSE GUIDE SUPPORT		01
02	0531065306	ARTICULATOR HOSE		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
04	0503010025	3/8 SPRING WASHER		03
05	0503010237	3/8" X 1" BOLT		01
06	0501010942	3/8" X 1-1/4" BOLT		02
07	0501013518	FLAT WASHER		02
08	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0503036366	SEALING AIR TUBE		02
02	0501312852	COVER AIR TUBE		02
03	0503010025	3/8 SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0503010237	3/8" X 1" BOLT		08
06	0531067947	FIXATION TUBE SEED LINES		01




Item	Code	Description	See page	QT
01	0531061934	CONDUCTOR ARTICULATOR GUIDE		01
02	0531061935	CONDUCTOR ARTICULATOR		01
03	0503010237	3/8" X 1" BOLT		01
04	0503010025	3/8 SPRING WASHER		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503012556	1/2" X 1" BOLT		01

CLAMP


0521052549



Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	SELF-LOCKING HEX NUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0503013759	NUT		01
02	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		01
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		01
04	0503063975	CLAMP SET 1 1/2		01
04A	0503036159	TOP CLAMP BODY		01
04B	0503036157	LOWER CLAMP BODY		01
04C	0503010585	0,24" X 1.18" SPRING PIN		01




Item	Code	Description	See page	QT
01	0503011075	3/4 UNC LOCK NUT	04	
02	0501010098	BOLT 3/4" UNC X 2 C S G.5 ZN	04	
03	0501312872	RIGHT SUPPORT PLATE HYDRAULIC DUCTS	02	
04	0513010752	SINGLE STANDARD CLAMP 12 MM - BLACK	48	
05	0503036429	HYDRAULIC TUBE PT PT12L X PT12L X 3000	04	
06	0501312870	DUCT SUPPORT	02	
07	0501311238	CLAMP UNION 112 X 30 X 6,30	04	
08	0501311237	FIXER	04	
09	0513011685	TEE TERMINAL MF X MF X FG TB12L	04	
10	0503036890	HYDRAULIC TUBE PT12L X FG12L X 1790	02	
11	0503036889	HYDRAULIC TUBE PT12L X PT12L X 1170	02	
12	0551010707	GLOVE	04	
13	0513011666	BOLT M6	04	
14	0591012160	7 X 23 X 2.00 ZN FLAT WASHER	04	
15	0503010305	6,50 X 17 X 1,50 ZN FLAT WASHER	16	
16	0503015110	M06 SPRING WASHER	16	
17	0503014540	M6 NUT	16	
18	0513011664	BOLT M6 X 1,00 X 80 - SGRP6X80ZI	12	
19	0501319122	SUPPORT 50 X 25 X 2965	01	

RIGHT CLAMP 4


0531050772




Item	Code	Description	See page	QT
01	0502012989	CLAMP BODY 4 RIGHT		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0541052253	RIGHT SHORT SEED ROW	68	01
02	0541052254	ROW SEED LEFT LONG	69	01
03	0541052261	SEED ROW SLG LEFT SPICRR	70	01
04	0541050500	SHORT CUTTING DISC	97	01
05	0541050499	LONG CUTTING DISC	98	01
06	0501215036	ROW ADJUSTMENT LEVER		01
07	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		01
08	0521068982	DISC BLADE HUB KEY		01
09	0561016889	STRIPED CAP WHEEL DEPTH		01




Item	Code	Description	See page	QT
01	0531054007	SHORT/LONG FRONT SEED ROW	71	01
02	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
03	0503010589	1/2" UNC SELF ADJUSTING NUT		04
04	0501216680	SRM MODULE COVER		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
06	0503013357	3/8 SELF-ADJUSTING NUT		01
07	0503010237	3/8" X 1" BOLT		01
08	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	72	01
09	0541052255	RIGHT DDD REAR WITH	73	01




Item	Code	Description	See page	QT
01	0541050067	FRONT LONG SEED ROW	92	01
02	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	72	01
03	0501216680	SRM MODULE COVER		01
04	0503011082	C1/2" X 1.3/4" SCREW		04
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
06	0503013357	3/8 SELF-ADJUSTING NUT		01
07	0503010237	3/8" X 1" BOLT		01
08	0503010589	1/2" UNC SELF ADJUSTING NUT		04
09	0541052257	LEFT DDD REAR WITH	93	01




Item	Code	Description	See page	QT
01	0531056775	FRONT SUPER LONG VDRIVE	96	01
02	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	72	01
03	0501216680	SRM MODULE COVER		01
04	0503010589	1/2" UNC SELF ADJUSTING NUT		04
05	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503013357	3/8 SELF-ADJUSTING NUT		01
08	0503010237	3/8" X 1" BOLT		01
09	0541052257	LEFT DDD REAR WITH	93	01




Item	Code	Description	See page	QT
01	0531060663	FRONT FRAME SEED LINE	01	01
02	0531061428	REAR LINE	01	01
03	0503030168	HITCH PIN CLIP	05	05
04	0571018883	PIN FIXER SPRING	04	04
05	0503034198	SPRING TRACTION 40 X 198 X 5,5	01	01
06	0502012789	FIXER SUPPORT FERTILIZER ROW	01	01
07	0502012812	SEED ROW ADJUSTMENT LEVER ASSY	01	01
08	0591011156	PIVOT ARM SEED ROW	02	02
09	0503017857	BOLT 5/8 UNF 4	04	04
10	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN	04	04
11	0503010811	5/8\" UNF SELF ADJUSTING NUT	04	04
12	0503019273	AUTO LUBRICANT SLEEVE	08	08
13	0503010045	O'RING	08	08
14	0591012829	SPACER LOWER SLEEVE	08	08
15	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	04
16	0503012412	5/8\" UNC SELF LOCKING NUT	04	04
17	0591012827	FRONT PENDULUM LINE	01	01
18	0591012828	LOCK PIN ROW ARTICULAT	01	01
19	0501219536	LINE GUTTER	01	01
20	0501310623	SPRING FIXING PIN	02	02




Item	Code	Description	See page	QT
01	0531062260	GUIDE HOSE L / TRANSMISSION		01
02	0571018883	PIN FIXER SPRING		01
03	0503010257	1/8" X 1" SPLIT PIN		01




Item	Code	Description	See page	QT
01	0521056640	PRECISION PLANTING CSC CABLE / 74	74	01
02	0531059836	TRANSMISSION ASSY	76	01
03	0571017895	COMPACTOR WHEEL ASSEMBLY		01
04	0503010140	PIN FIXER CONDUCTOR P.P		01
05	0541052256	1/8" X 3/4" SPLIT PIN		01
		RIGHT DDD REAR WITH SPICRR WITHOUT 81	81	01
		COMPACTOR WHEEL		




Item	Code	Description	See page	QT
01	0502012924	PRECISION PLANTING SUPPORT		01
02	0502012800	SUPPORT ARTICULATION PNEUMATIC		01
03	0503062406	SEED HOPPER		01
04	0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT 75 PROTECTION		01
05	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01
07	0503810009	BOLT		02
08	0571018649	SUPPORT FIXER		02
09	0503010243	CLAMP		01
10	0581017816	TERMINAL		01
11	0503034204	SEALING		01
12	0503010140	1/8" X 3/4" SPLIT PIN		01
13	0571014024	FAST BOLT GUIDE AXLE		01
14	0503034824	FIXATIVE		01
15	0503010293	CLAMP KNOB		01
16	0503010025	3/8 SPRING WASHER		05
17	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
18	0501110894	FIXER		01
19	0502012922	FIXING SUPPORT		01
20	0503011404	BOLT		01
21	0503013357	3/8 SELF-ADJUSTING NUT		01
22	0503010026	3/8" NUT		04
23	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04




Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01




Item	Code	Description	See page	QT
01	0521054990	LEFT COMPACTOR WHEEL	77	01
02	0521055017	RIGHT COMPACTOR WHEEL	79	01
03	0531059837	SPA COMPACTING BODY WITHOUT BOLT	80	01




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	78	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	WHEEL HUB		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02



Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	78	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT	02	
02	0503013816	5/16" LOCKNUT	04	
03	0581015855	SLEEVE	02	
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER	01	
05	0503030878	LEVER CRANK	01	
06	0581019520	AXIS	01	
07	0503010257	1/8" X 1" SPLIT PIN	01	
08	0581019511	COVER	01	
09	0503010848	5/16" X 3.1/2" BOLT	02	
10	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
11	0581019510	AXIS	01	
12	0581019512	PLATE TOP	01	
13	0503019351	LUBRICANT SLEEVE	02	
14	0571012442	COUPLING SHAFT	01	
15	0531062651	LEVER COMPACTOR	01	
16	0503034817	SPRING	01	
17	0531066053	SIDE LEFT	01	
18	0531066052	RIGHT SIDE	01	




Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0531059833	DEPTH REGULATOR	82	01
03	0591016905	DEPTH WHEEL JOINT AXLE		02
04	0591011309	ADJUSTMENT BUSHING		02
05	0591011310	ADJUSTMENT BAR		02
06	0503019275	SLEEVE LUBRICATION SYSTEM		01
07	0581019473	ARTICULATED SLEEVE		02
08	0503010045	O'RING		02
09	0503013357	3/8 SELF-ADJUSTING NUT		03
10	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
11	0591011326	LOCK PIN		01
12	0571015326	ARTICULATION SLEEVE HANDLE		01
13	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
14	0503010060	1/2 UNC G.5 ZN HEX NUT		02
15	0503010019	1/2" SPRING WASHER		04
16	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
17	0501011445	FLAT WASHER		04
18	0521056633	MOUNTED RIGHT ARM	84	01
19	0521056631	MOUNTED LEFT ARM	83	01
20	0503012556	1/2" X 1" BOLT		02
21	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
22	0591011306	ADJUSTMENT LOCK		02
23	0503010131	3/16" X 1.1/2" SPLIT PIN		02
24	0591016900	BEATING AXLE		01
25	0591016988	SPICER PROTECTOR		01
26	0591016907	SPACER SLEEVE		06
27	0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM 87 SPI		01
28	0503011140	1/2" X 3-3/4" BOLT		01
29	0503011336	1/2" HEX SELF ADJUSTING NUT		01
30	0501311083	AXIS 5/8 X 90MM		01
31	0503012342	CLAMPING PIN		01


Item	Code	Description	See page	QT
32	0502013084	SUPPORT REGULATOR		01
33	0531066051	FIXER SPRING		01
34	0503011404	BOLT		01
35	0502013083	ADJUSTMENT SHAFT DEPTH		01




Item	Code	Description	See page	QT
01	0501310947	BODY REGULATORY		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0503010581	RING		01
04	0502012892	DEPTH CONTROL HANDLE		01
05	0581019526	ARTICULATED AXLE LEVER DEPTH		01
06	0503010302	501019 SEAL RING		01
07	0581019519	FLAT WASHER		01
08	0501311082	NYLON GLOVE 17.20 X 20 X 25MM		01




Item	Code	Description	See page	QT
01	0502012927	LEFT ARM		01
02	0503011109	O'RING 2-119 N 3006 9B		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 85 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0502012926	RIGHT ARM		01
02	0503011109	O'RING 2-119 N 3006 9B		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055059	WHEEL RAYED ASSY SPA WITHOUT 85 LUBRICATION		01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503030891	RUBBER BAND		01
03	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
05	0503010337	NUT 5/16 UNC G.5 ZN		06
06	0521055073	ASSEMBLY DEPTH WHEEL HUB	86	01




Item	Code	Description	See page	QT
01	0581019528	WHEEL DEPTH SPA HUB WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	DUST CLOAK		01
11	0581019529	DEPTH REGULATOR SHAFT		01




Item	Code	Description	See page	QT
01	0502012929	BODY RIGHT		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 88 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 89 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055864	FERTILIZER/SEED RIGHT HUB ASSY	90	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055865	FERTILIZER/SEED LEFT HUB ASSY	91	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUBLE DISC AXLE		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01



Item	Code	Description	See page	QT
01	0531061428	REAR LINE	01	
02	0503030168	HITCH PIN CLIP	05	
03	0571018883	PIN FIXER SPRING	03	
04	0503034198	SPRING TRACTION 40 X 198 X 5,5	01	
05	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
06	0502012812	SEED ROW ADJUSTMENT LEVER ASSY	01	
07	0591011156	PIVOT ARM SEED ROW	02	
08	0503017857	BOLT 5/8 UNF 4	04	
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN	04	
10	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
11	0503019273	AUTO LUBRICANT SLEEVE	08	
12	0503010045	O'RING	08	
13	0591012829	SPACER LOWER SLEEVE	08	
14	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
15	0503012412	5/8" UNC SELF LOCKING NUT	04	
16	0591012827	FRONT PENDULUM LINE	01	
17	0591012828	LOCK PIN ROW ARTICULAT	01	
18	0501219536	LINE GUTTER	01	
19	0501310623	SPRING FIXING PIN	01	
20	0531066157	FRONT CHASSIS SEED LINE	01	
21	0503010233	5/8" X 2-1/2" BOLT	02	
22	0503010027	5/8 SPRING WASHER	02	
23	0503010013	5/8 UNC G.5 ZN HEX NUT	02	
24	0511015705	FLAT WASHER	02	




Item	Code	Description	See page	QT
01	0521056640	PRECISION PLANTING CSC CABLE / 74	74	01
02	0531059836	TRANSMISSION ASSY	76	01
03	0571017895	COMPACTOR WHEEL ASSEMBLY		01
04	0503010140	PIN FIXER CONDUCTOR P.P		01
05	0541052258	1/8" X 3/4" SPLIT PIN		01
		LEFT DDD REAR WITH SPICRR WITHOUT COMPACTOR WHEEL	94	01




Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0531059833	DEPTH REGULATOR	82	01
03	0591016905	DEPTH WHEEL JOINT AXLE		02
04	0591011309	ADJUSTMENT BUSHING		02
05	0591011310	ADJUSTMENT BAR		02
06	0503019275	SLEEVE LUBRICATION SYSTEM		01
07	0581019473	ARTICULATED SLEEVE		02
08	0503010045	O'RING		02
09	0503013357	3/8 SELF-ADJUSTING NUT		03
10	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
11	0591011326	LOCK PIN		01
12	0571015326	ARTICULATION SLEEVE HANDLE		01
13	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
14	0503010060	1/2 UNC G.5 ZN HEX NUT		02
15	0503010019	1/2" SPRING WASHER		04
16	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
17	0501011445	FLAT WASHER		04
18	0521056633	MOUNTED RIGHT ARM	84	01
19	0521056631	MOUNTED LEFT ARM	83	01
20	0503012556	1/2" X 1" BOLT		02
21	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
22	0591011306	ADJUSTMENT LOCK		02
23	0503010131	3/16" X 1.1/2" SPLIT PIN		02
24	0591016900	BEATING AXLE		01
25	0591016988	SPICER PROTECTOR		01
26	0591016907	SPACER SLEEVE		06
27	0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM 95 SPI		01
28	0503011140	1/2" X 3-3/4" BOLT		01
29	0503011336	1/2" HEX SELF ADJUSTING NUT		01
30	0501311083	AXIS 5/8 X 90MM		01
31	0503012342	CLAMPING PIN		01


Item	Code	Description	See page	QT
32	0502013084	SUPPORT REGULATOR		01
33	0531066051	FIXER SPRING		01
34	0503011404	BOLT		01
35	0502013083	ADJUSTMENT SHAFT DEPTH		01




Item	Code	Description	See page	QT
01	0502012928	LEFT EXTENSOR		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 89 FERTILIZER / SEED		01
11	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 88 FERTILIZER / SEED		01



Item	Code	Description	See page	QT
01	0531063425	FRONT FRAME SEED ROW		01
02	1902010175	HITCH CLAMP		02
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
06	0531061428	REAR LINE		01
07	0503030168	HITCH PIN CLIP		05
08	0571018883	PIN FIXER SPRING		04
09	0591012828	LOCK PIN ROW ARTICULAT		01
10	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
11	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
12	0591011156	PIVOT ARM SEED ROW		02
13	0591012829	SPACER LOWER SLEEVE		08
14	0503019273	AUTO LUBRICANT SLEEVE		08
15	0503010045	O'RING		08
16	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
17	0503012412	5/8" UNC SELF LOCKING NUT		04
18	0591012827	FRONT PENDULUM LINE		01




Item	Code	Description	See page	QT
01	0503017960	5/8" X 3-12" BOLT		04
02	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
03	0503010811	5/8" UNF SELF ADJUSTING NUT		04
04	0502012789	FIXER SUPPORT FERTILIZER ROW		01
05	0502013100	SUPPORT CUTTING DISC		01
06	0541050502	SHORT LOWER SUPPORT	99	01




Item	Code	Description	See page	QT
01	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		02
02	0503010811	5/8" UNF SELF ADJUSTING NUT		04
03	0503017960	5/8" X 3-12" BOLT		04
04	0502012789	FIXER SUPPORT FERTILIZER ROW		01
05	0502013100	SUPPORT CUTTING DISC		01
06	0541050501	LONG LOWER SUPPORT	102	01

SHORT LOWER SUPPORT

0541050502




Item	Code	Description	See page	QT
01	0503019277	SLEEVE LUBRICATION SYSTEM		03
02	0503019278	LUBRICANT SLEEVE		02
03	0581018679	SLEEVE		01
04	0501312876	MAJOR AXIS		01
05	0503010361	SPRING PIN		01
06	0551015883	SPRING GUIDES SLEEVE		02
07	0503031575	COMPRESSION SPRING		02
08	0521068189	SPRING REGULACION		02
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		02
10	0503010152	3/4" SELF LOCKING NUT		01
11	0503010806	5/8" X 3" BOLT		02
12	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT		01
13	0503011075	3/4 UNC LOCK NUT		02
14	0503010878	5/8" SELF ALIGNING NUT		02
15	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	100	01
16	0531066430	RIGHT ARM		01
17	0531066429	LEFT ARM		01
18	0503010410	RING		02
19	0502012898	BOTTOM BRACKET		01
20	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
21	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
22	0571012370	PROTECTION FRONT		01
23	0581018678	FLANGE WASHER		01
24	0503010756	0.2" X 2.4" SPRING PIN		01
25	0501214497	WASHER 35 X 55 X 4.75		01
26	0503030430	7/16 X 2" PIN LOCK		01



Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	DISC BLADE HUB	101	01

DISC BLADE HUB


0521053697




Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4		01
02	0502040872	REGULATORY NUT		01
03	0503010370	502072 CLAMPING RING (FOR AXLE)		02
04	0503010590	00674-B SEAL		02
05	0503019285	RING		02
06	0503012170	30207 ROLLER BEARING		02
07	0502020641	BLADE DISC FLANGE		01
08	0502012862	DISC BLADE HUB		01
09	0502040873	DISC BLADE AXLE		01
10	0503017755	NUT		01
11	0503018825	5/16 UNC UNC BOLT		06
12	0501010694	FLAT WASHER 32,50 X 75 X 4,75		06
13	0503013816	5/16" LOCKNUT		06
14	0511017907	1/8" BSPT X 6 PLUG		02

LONG LOWER SUPPORT


0541050501



Item	Code	Description	See page	QT
01	0503019277	SLEEVE LUBRICATION SYSTEM		03
02	0503019278	LUBRICANT SLEEVE		02
03	0581018679	SLEEVE		01
04	0501312876	MAJOR AXIS		01
05	0503010361	SPRING PIN		01
06	0551015883	SPRING GUIDES SLEEVE		02
07	0503031575	COMPRESSION SPRING		02
08	0521068189	SPRING REGULACION		02
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		02
10	0503010152	3/4" SELF LOCKING NUT		01
11	0503010806	5/8" X 3" BOLT		02
12	0503014744	3/4 UNF X 7.1/2 C S G.7 ZN BOLT		01
13	0503011075	3/4 UNC LOCK NUT		02
14	0503010878	5/8" SELF ALIGNING NUT		02
15	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	100	01
16	0531066430	RIGHT ARM		01
17	0531066429	LEFT ARM		01
18	0503010410	RING		02
19	0502012898	BOTTOM BRACKET		01
20	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		02
21	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
22	0571012370	PROTECTION FRONT		01
23	0581018678	FLANGE WASHER		01
24	0503010756	0.2" X 2.4" SPRING PIN		01
25	0501214497	WASHER 35 X 55 X 4.75		01
26	0503030430	7/16 X 2" PIN LOCK		01



Item	Code	Description	See page	QT
01	0581010353	RING SUPPORT		01
02	0502010382	5" END CAP		01
03	0581013698	PISTON 2" X 5" C/R. M36 X 1,5		01
04	0531062932	EXTENSION 50.80 X 898 MM		01
05	0503010003	1845 GREASE FITTING		02
06	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
07	0503018439	WIPER SEAL T-SEAL 1905127		01
08	0503018150	RING GUIDE W2-5000-984 (4528)		01
09	0503010173	2-220 N 3006-9B O'RING		01
10	0503018024	RING BS OD050805200171D-BR		01
11	0503018026	GASKET 1870-2000-375 B POLYMAX		01
12	0503010039	D-2000 SCRAPER RING		01
13	0503018152	O'RING		02
14	0503018025	RING GUIDE W2-2250-750		01
15	0503011453	O'RING		02
16	0531066066	CILINDER CASE 127 X 773MM		01




Item	Code	Description	See page	QT
01	0531065709	TELESCOPIC WHEEL SUPPORT		01
02	0531066279	TORRE RODEIRO		01
03	0531064106	CROSSHEAD WITH SUPPORT		01
04	0501210807	PLASTIPRENE LOWER SUPPORT		02
05	0501210806	PLASTIPRENE TOP SUPPORT		02
06	0501214452	DAMPER SPINDLE		02
07	0501214453	PLASTIPRENE EAR		01
08	0501214454	GLOVE ARTICULATION AXLE		02
09	0503010834	1/2 X 1 BOLT		05
10	0503010019	1/2" SPRING WASHER		09
11	0503011075	3/4 UNC LOCK NUT		02
12	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		02
13	0501214303	WHEEL CHAIN		05
14	0531054036	ASSY CENTER CYLINDER BEARING	106	02
15	0503011052	1.1/4" X 0.77" CASTLE NUT		01
16	0503012182	1" NUT		02
17	0503010002	1800 GREASE FITTING		11
18	0503010038	3/16" X 2" SPLIT PIN		01
19	0591016434	PLASTIPRENE		02
20	0501214302	ADJUSTMENT COVER PLATE		05
21	0503034377	3/8 UNC X 3/4 BOLT		30
22	0503010025	3/8 SPRING WASHER		30
23	0501215027	CENTRAL WHEEL PULLEY		03
24	0501214462	NYLON PULLEY BUSHING		06
25	0501216430	ADJUSTING COVER CALCO		05
26	0531065712	CENTRAL PULLEY LOCK SHAFT		03
27	0561010960	FLAT WASHER		04
28	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
29	0501311051	BEATER SHAFT 200 WITH GROUP		01
30	0503012623	3/8" X 1-1/2" BOLT		01
31	0503010208	HEX NUT 3/8 UNF G.5 ZN		01
32	0541050194	COMPLETE CENTRAL CUBE	107	02

CENTER LEFT TELESCOPIC WHEELS


0541050276

Item	Code	Description	See page	QT
33	0541050195	MOUNTED LEFT WHEEL	55	01
34	0541050196	MOUNTED RIGHT WHEEL	108	01
35	0531066277	CENTRAL CYLINDER AXIS		01
36	0531066276	ARTICULATOR SHAFT		01
37	0501312155	BACKREST WASHER		01
38	0513010043	BOLT 1/2 UNC X 1.3/4 CCSI 12.9		01
39	0531065710	MAJOR AXLE LOCK CENTRAL PULLEY		01
40	0501111193	FULL PULLEY		01
41	0541050277	HYDRAULIC CYLINDER LEFT	109	01




Item	Code	Description	See page	QT
01	0531065709	TELESCOPIC WHEEL SUPPORT		01
02	0531066279	TORRE RODEIRO		01
03	0531064106	CROSSHEAD WITH SUPPORT		01
04	0501210807	PLASTIPRENE LOWER SUPPORT		02
05	0501210806	PLASTIPRENE TOP SUPPORT		02
06	0501214452	DAMPER SPINDLE		02
07	0501214453	PLASTIPRENE EAR		01
08	0501214454	GLOVE ARTICULATION AXLE		02
09	0503010834	1/2 X 1 BOLT		05
10	0503010019	1/2" SPRING WASHER		09
11	0503011075	3/4 UNC LOCK NUT		02
12	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		02
13	0501214303	WHEEL CHAIN		05
14	0531054036	ASSY CENTER CYLINDER BEARING	106	02
15	0503011052	1.1/4" X 0.77" CASTLE NUT		01
16	0503012182	1" NUT		02
17	0503010002	1800 GREASE FITTING		11
18	0503010038	3/16" X 2" SPLIT PIN		01
19	0591016434	PLASTIPRENE		02
20	0501214302	ADJUSTMENT COVER PLATE		05
21	0503034377	3/8 UNC X 3/4 BOLT		30
22	0503010025	3/8 SPRING WASHER		30
23	0501215027	CENTRAL WHEEL PULLEY		03
24	0501214462	NYLON PULLEY BUSHING		06
25	0501216430	ADJUSTING COVER CALCO		05
26	0531065712	CENTRAL PULLEY LOCK SHAFT		03
27	0561010960	FLAT WASHER		04
28	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
29	0501311051	BEATER SHAFT 200 WITH GROUP		01
30	0503012623	3/8" X 1-1/2" BOLT		01
31	0503010208	HEX NUT 3/8 UNF G.5 ZN		01
32	0541050194	COMPLETE CENTRAL CUBE	107	02


Item	Code	Description	See page	QT
33	0541050195	MOUNTED LEFT WHEEL	55	01
34	0541050196	MOUNTED RIGHT WHEEL	108	01
35	0531066277	CENTRAL CYLINDER AXIS		01
36	0531066276	ARTICULATOR SHAFT		01
37	0501312155	BACKREST WASHER		01
38	0513010043	BOLT 1/2 UNC X 1.3/4 CCSI 12.9		01
39	0531065710	MAJOR AXLE LOCK CENTRAL PULLEY		01
40	0501111193	FULL PULLEY		01
41	0541050275	HYDRAULIC CYLINDER RIGHT 44.45X85.7X413	53	01




Item	Code	Description	See page	QT
01	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
03	0503010589	1/2" UNC SELF ADJUSTING NUT		02



Item	Code	Description	See page	QT
01	0501214451	CENTRAL WHEEL AXLE		01
02	0503010050	SEAL 00085-B		01
03	0503010002	1800 GREASE FITTING		01
04	0541013225	WHEEL HUB LID		01
05	0503011444	SPRING WASHER 5/16"		06
06	0503010240	BOLT		06
07	0502040080	FLANGE NUT R.2.1/2" UN		01
08	0503011345	1/4" X 3.1/2" SPLIT PIN		01
09	0501111223	BOX ROUND WITH SCREW		01
09A	0501213765	WHEEL BOX		01
09B	0503810007	WHEEL BOLT		08
09C	0503014048	HEX NUT M22X1,5" CH32X33,5		08
10	0503013633	BEARING 33287/33462		01
11	0503013496	3982/3920 ROLLER BEARING		01




Item	Code	Description	See page	QT
01	0513010700	TIRE 500-50-17 FLOTATION T422 I1 18PR TECH SHEET		01
02	0503013999	VALVE 16MM AGR		01
03	0503036301	RIM 16 X 17		01




Item	Code	Description	See page	QT
01	0531066278	CYLINDER CASE		01
02	0503010042	2-214 N 3006-9B O'RING		01
03	0503010063	1" SELF-ALIGNING NUT		01
04	0503010761	D-1750 SCRAPER RING		01
05	0571019710	1.7" X 3.4" PISTON		01
06	0503017935	RING		01
07	0503018144	RING		01
08	0571019711	RING SUPPORT		01
09	0571019709	DETACHABLE COVER		01
10	0503017936	RING		01
11	0503017938	RING GUIDE		01
12	0503017937	GASKET		01
13	0503017940	8-337 BACK-UP RING		02
14	0503017939	2-337 N 3006-9B O' RING		02
15	0503018045	2-130 (AGEL) O'RING		04
16	0531064313	ROD 1.3/4 X 826MM WITH SLEEVE		01

CENTRAL SEED BOX


0541053367




Item	Code	Description	See page	QT
01	0513010405	CLAMP		28
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		10
03	0503010019	1/2" SPRING WASHER		14
04	0503010025	3/8 SPRING WASHER		04
05	0531054354	CENTRAL SEED BOX 2500 LITERS	111	01
06	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		08
07	0503019293	SCREW 1/2 UNC X 2 COVER G7 ZN		06
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
09	0503010060	1/2 UNC G.5 ZN HEX NUT		10
10	0503010026	3/8" NUT		04
11	0531067924	SUPPORT CENTRAL SEED BOX		01
12	0521053176	COVER KAP		01
12A	0581017528	15 OUTPUT TUBE COVER		01
12B	0503011372	102 TO 121 CLAMP		01
13	0501217890	SILLO LOCK		02
14	0531058201	HYDRAULIC TURBINE WITH SCREEN	113	01




Item	Code	Description	See page	QT
01	0503063436	COMPLETE POSITIVE AIR DOUBLE SEED BOX		01
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		46
03	0531054357	LOWER SYSTEM 28 PIPES	112	01
04	0503013357	3/8 SELF-ADJUSTING NUT		46
05	0503010849	3/8" X 1-1/2" BOLT		12
06	0503010025	3/8 SPRING WASHER		12
07	0531063644	AIR TUBE 28 OUTLETS WITH FIXER		01
08	0513010632	RUBBER SMOOTH WASHER 28 X 10 X 2.00		46
09	0531063885	SYSTEM FIXING RULE		02
10	0531063624	SYSTEM FIXING RULE		14
11	0513010630	SCREW M6 X1 X 20 CCSI 10.9 SA		30




Item	Code	Description	See page	QT
01	0531063643	OUTLET BODY WITH DUCTS		01
02	0503015135	FLAT WASHER 10 X 18 X 2		10
03	0503011823	0.1" X 0.6" SPRING PIN		10
04	0521068978	CASH FUND COVER		05
05	0581017529	ROD 9,53		05
06	0503034692	FAST LOCK ASSY		10
07	0503030085	LOCK PIN		10
08	0503034573	SEALING		05
09	0503035773	BOTTOM SEAL BOX SYSTEM 28 OUTPUTS		01
10	0503063723	AIR TUBE SEAL 04 OUTLETS 290		07




Item	Code	Description	See page	QT
01	0531056343	HYDRAULIC ENGINE	114	01
02	0531063640	TURBINE SUPPORT		01
03	0521044613	480 X 50 FAN (HIDRAULIC)	115	01
04	0531061858	MECHANICAL SNAIL		01
05	0571018577	COVER SNAIL TURBINE		01
06	0571018578	TURBINE PROTECTIVE SCREEN		01
07	0521069167	FRONT PROTECTION		01
08	0531056344	COMMAND BLOCK	116	01
09	0503010025	3/8 SPRING WASHER		10
10	0503010026	3/8" NUT		08
11	0503010143	1/4" SPRING WASHER		01
12	0503010849	3/8" X 1-1/2" BOLT		02
13	0531018764	FLAT WASHER		01
14	0503011104	M6 X 1" BOLT		01
15	0503012722	0.16" X 0.4" BLIND RIVET		19
16	0503010237	3/8" X 1" BOLT		06
17	0503010206	3/8 X 1/2 BOLT		02
18	0541013274	LISA WASHER 10 X 38 X 4.75		02




Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0513010838	ADAPTER TERMINAL MF R.1/2 BSP ORING X MF TB15		02
03	0513010917	ADAPTER TERMINAL MF R.1/4 BSP ORING X MF TB15		01
04	0513010839	ADAPTER TERMINAL MF R.1/4 BSP ORING X MF TB10L		01




Item	Code	Description	See page	QT
01	0571016947	DISC FRONT TURBINE		01
02	0571016949	DISC REAR TURBINE		01
03	0521065171	HUB FLANGE		01
04	0571016950	DISC STRENGTHENING TURBINE		01
05	0571016951	FLIP TURBINE		10
06	0503012651	M6 X 1" BOLT		05
07	0503010143	1/4" SPRING WASHER		05
08	0503011776	SELF-LOCKING HEX NUT		05




Item	Code	Description	See page	QT
01	0503012291	BLOCK COMMAND		01
02	0513010841	ADAPTER TERMINAL MF R.3/4 UNF ORING X MF TB10L		01
03	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		04




Item	Code	Description	See page	QT
01	0531067922	FIXATION BASE		01
02	0501011643	3/8 X 1" BOLT		16
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		27
04	0503013357	3/8 SELF-ADJUSTING NUT		19
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
08	0521053176	COVER KAP		01
08A	0503011372	102 TO 121 CLAMP		01
08B	0581017528	15 OUTPUT TUBE COVER		01
09	0503011372	102 TO 121 CLAMP		01
10	0531064758	SUPPORT		01
11	0531064761	FASTENING CLAP		02
12	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		12
13	0503010811	5/8" UNF SELF ADJUSTING NUT		12
14	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
15	0503010232	5/8" X 1.3/4" BOLT		04
16	0501010942	3/8" X 1-1/4" BOLT		03
17	0503010233	5/8" X 2-1/2" BOLT		04
18	0513010405	CLAMP		17
19	0501216353	SUPPORT		04
20	0531064757	SUPPORT		01
21	0531054290	CENTRAL SEED BOX	118	01
22	0531058207	COMPLETE HYDRAULIC TURBINE	121	01




Item	Code	Description	See page	QT
01	0531062313	17-MOUTH AIR TUBE WITH FIXER		01
02	0503010025	3/8 SPRING WASHER		08
03	0503010849	3/8" X 1-1/2" BOLT		08
04	0531054289	CENTRAL SEED BOX	119	01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		30
06	0503013357	3/8 SELF-ADJUSTING NUT		26
07	0531054275	LOWER BOX SEED SYSTEM	120	01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04




Item	Code	Description	See page	QT
01	0513010632	RUBBER SMOOTH WASHER 28 X 10 X 2.00	26	
02	0503063688	COMPLETE POSITIVE AIR SEED BOX	01	
03	0531063623	LOWER BOX SYSTEM FIXING RULE	04	
04	0531063624	SYSTEM FIXING RULE	02	
05	0513010630	SCREW M6 X1 X 20 CCSI 10.9 SA	12	
06	0503019413	THREAD SCREW INTERNAL	04	




Item	Code	Description	See page	QT
01	0503063393	AIR PIPE SEAL 5 OUTPUTS		01
02	0503019290	BOLT		24
03	0503034692	FAST LOCK ASSY		06
04	0503034571	SEALING		01
05	0503030085	LOCK PIN		06
06	0503063392	AIR PIPE SEAL 6 OUTPUTS		02
07	0531063617	BOTTOM BOX SYSTEM 17 OUTPUTS		01
08	0503035462	COVER SEAL		03
09	0531063616	BOTTOM COVER BOX 418		03
10	0503015135	FLAT WASHER 10 X 18 X 2		06
11	0503011823	0.1" X 0.6" SPRING PIN		06
12	0581017529	ROD 9,53		03




Item	Code	Description	See page	QT
01	0531056343	HYDRAULIC ENGINE	114	01
02	0503010025	3/8 SPRING WASHER		12
03	0503010026	3/8" NUT		10
04	0521044613	480 X 50 FAN (HIDRAULIC)	115	01
05	0503010143	1/4" SPRING WASHER		01
06	0503010849	3/8" X 1-1/2" BOLT		02
07	0531018764	FLAT WASHER		01
08	0503011104	M6 X 1" BOLT		01
09	0503012722	0.16" X 0.4" BLIND RIVET		24
10	0521065857	CARACOL MECHANICAL TURBINE S MEC		01
11	0521065858	TURBIN SUPPORT		01
12	0531056344	COMMAND BLOCK	116	01
13	0561010634	VALVE SUPPORT ASSY		01
14	0503010237	3/8" X 1" BOLT		08
15	0503010206	3/8 X 1/2 BOLT		02
16	0571018577	COVER SNAIL TURBINE		01
17	0571018578	TURBINE PROTECTIVE SCREEN		01
18	0541013274	LISA WASHER 10 X 38 X 4.75		02
19	0521069167	FRONT PROTECTION		01
20	0503031087	AUTO CONTROL APPROVED DECAL		01
21	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01
22	0503033981	PRESSURE FREE RETAINER FOR TANK DECAL		01
23	0501080709	3/8" X 21.6" TR-TR HOSE		01
24	0501080091	1/2" X 550 TR-TR HOSE		02



Item	Code	Description	See page	QT
01	0501211496	GLOVE 16 X 25 X 27 WITH HOLE		01
02	0591013172	31.75 X126 AXLE WITH 8 HOLE		01
03	0503012231	1/4" X 3" SPLIT PIN		01
04	0591017796	ARTICULATION AXIS 222 R.1.1 / 4 UNF		01
05	0591019305	FLAT WASHER 20 X 60 X 4.75 WITH CUT OUT		01
06	0501011544	3/4" X 1-1/2" BOLT		01
07	0503010023	3/4" SPRING WASHER		01
08	0591018408	PIN LOCK LINES		01
09	0503030085	LOCK PIN		01
10	0502012789	FIXER SUPPORT FERTILIZER ROW		02
11	0503017857	BOLT 5/8 UNF 4		08
12	0503010811	5/8" UNF SELF ADJUSTING NUT		08
13	0531066045	CENTRAL SUPPORT		01
14	0501111295	CENTRAL SUPPORT ARTICULATOR		01
15	0541053333	CYLINDER SIDE ARTICULATION 123 44,45X85,70X213.5/563.5		01
16	0531061418	FIXING FLANGE HYDRAULIC CYLINDER WITHOUT LUBRICATION		02
17	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
18	0503010589	1/2" UNC SELF ADJUSTING NUT		04
19	0503011075	3/4 UNC LOCK NUT		06
20	0501010125	3/4" X 2-1/2" BOLT		06
21	0503019408	IGLIDUR GSM-4550-30 AUTO LUBRICANT GLOVE		02




Item	Code	Description	See page	QT
01	0503010761	D-1750 SCRAPER RING		01
02	0571019711	RING SUPPORT		01
03	0571019709	DETACHABLE COVER		01
04	0503017936	RING		01
05	0503017938	RING GUIDE		01
06	0503017937	GASKET		01
07	0503017940	8-337 BACK-UP RING		02
08	0503017939	2-337 N 3006-9B O' RING		02
09	0503018045	2-130 (AGEL) O'RING		04
10	0511064408	FORK		01
11	0503010025	3/8 SPRING WASHER		01
12	0503011094	BOLT 3/8" UNC X 2" C C S I 12.9		01
13	0503010026	3/8" NUT		01
14	0503010042	2-214 N 3006-9B O'RING		01
15	0503010063	1" SELF-ALIGNING NUT		01
16	0571019710	1.7" X 3.4" PISTON		01
17	0503017935	RING		01
18	0503018144	RING		01
19	0531067888	CYLINDER BARREL 85,7 X 322		01
20	0501318688	EXTENDER 44.45 X 479		01




Item	Code	Description	See page	QT
01	0503013584	VACUUM GAUGE		02
02	0501011643	3/8 X 1" BOLT		02
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0503013357	3/8 SELF-ADJUSTING NUT		02
05	0501318966	POSITIVE VACUUM METER SUPPORT		01

LADDER


0541053378




Item	Code	Description	See page	QT
01	0531067140	UPPER REAR LADDER		01
02	0531067144	STAIR HANDRAIL		02
03	0531067143	LOWER LADDER		01
04	0501313914	END CAP		04
05	0501318951	AXIS 25 X 163		01
06	0501318950	BUSHING 26 X 42 X 25		01
07	0503013357	3/8 SELF-ADJUSTING NUT		08
08	0503010237	3/8" X 1" BOLT		08
09	0503010547	1/2" X 4" BOLT		02
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
11	0503011336	1/2" HEX SELF ADJUSTING NUT		02
12	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		01
13	0503012880	1/4" UNC SELF ADJUSTING NUT		01
14	0501212578	LADDER LOCK BODY		01
15	0503010747	5/32" X 3/4" SPLIT PIN		01




Item	Code	Description	See page	QT
01	0531067932	502 PLATFORM		01
02	0501011643	3/8 X 1" BOLT		04
03	0503013357	3/8 SELF-ADJUSTING NUT		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04




Item	Code	Description	See page	QT
01	0501011643	3/8 X 1" BOLT		04
02	0503013357	3/8 SELF-ADJUSTING NUT		04
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
04	0531067933	718 PLATFORM		01



Item	Code	Description	See page	QT
01	0503010905	1/2" X 2-1/4" BOLT		04
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
03	0503010060	1/2 UNC G.5 ZN HEX NUT		04
04	0503010019	1/2" SPRING WASHER		04
05	0531067936	LEFT SIDE HANDRAIL		01




Item	Code	Description	See page	QT
01	0501011643	3/8 X 1" BOLT		04
02	0503013357	3/8 SELF-ADJUSTING NUT		04
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
04	0501313914	END CAP		01
05	0531067952	RIGHT HANDRAIL 700 X 1000		01
06	0503010905	1/2" X 2-1/4" BOLT		02
07	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
08	0503010060	1/2 UNC G.5 ZN HEX NUT		02
09	0503010019	1/2" SPRING WASHER		02



Item	Code	Description	See page	QT
01	0503013357	3/8 SELF-ADJUSTING NUT		04
02	0501011643	3/8 X 1" BOLT		04
03	0531067931	PLATFORM 2989		01
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04

COMPLETE LEFT ARTICULATION ARM


0541053403




Item	Code	Description	See page	QT
01	0503015322	BOLT 7/8		01
02	0503010408	7/8" SPRING WASHER		01
03	0503010002	1800 GREASE FITTING		02
04	0571011767	125 X 88 X 4,76 FLAT WASHER		01
05	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
06	0503010814	5/16 BOLT		10
07	0571011825	BUSHING		02
08	0591012948	700 X 130 X 10 PLATE		01
09	0531062168	CYLINDER JOINT AXIS		01
10	0503010834	1/2 X 1 BOLT		01
11	0503010019	1/2" SPRING WASHER		07
12	0503035505	HOSE PROTECTOR		01
13	0501214491	CONIC GLOVE TIGHTENING		02
14	0502040080	FLANGE NUT R.2.1/2" UN		01
15	0501214492	FIXING WASHER		01
16	0531064385	ARTICULATION AXLE 549		01
17	0503011345	1/4" X 3.1/2" SPLIT PIN		01
18	0531066369	HOSE SUPPORT		02
19	0503010060	1/2 UNC G.5 ZN HEX NUT		04
20	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		04
21	0503010589	1/2" UNC SELF ADJUSTING NUT		02
22	0501111160	CYLINDER SUPPORT BEARING		02
23	0503011082	C1/2" X 1.3/4" SCREW		04
24	0541052180	STABILIZER HOSES	133	02
25	0531067935	LEFT ARTICULATION ARM		01

RIGHT ARTICULATION ARM

0541053402




Item	Code	Description	See page	QT
01	0571011767	125 X 88 X 4,76 FLAT WASHER		01
02	0503010002	1800 GREASE FITTING		02
03	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
04	0503015322	BOLT 7/8		01
05	0503010408	7/8" SPRING WASHER		01
06	0503010814	5/16 BOLT		10
07	0591012948	700 X 130 X 10 PLATE		01
08	0571011825	BUSHING		02
09	0531062168	CYLINDER JOINT AXIS		01
10	0503010834	1/2 X 1 BOLT		01
11	0503010019	1/2" SPRING WASHER		07
12	0503035505	HOSE PROTECTOR		01
13	0501214491	CONIC GLOVE TIGHTENING		02
14	0502040080	FLANGE NUT R.2.1/2" UN		01
15	0501214492	FIXING WASHER		01
16	0503011345	1/4" X 3.1/2" SPLIT PIN		01
17	0531064385	ARTICULATION AXLE 549		01
18	0531066369	HOSE SUPPORT		02
19	0503010060	1/2 UNC G.5 ZN HEX NUT		04
20	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		04
21	0501111160	CYLINDER SUPPORT BEARING		02
22	0541052180	STABILIZER HOSES	133	02
23	0503011082	C1/2" X 1.3/4" SCREW		04
24	0503010589	1/2" UNC SELF ADJUSTING NUT		02
25	0531067934	RIGHT ARTICULATION ARM		01



Item	Code	Description	See page	QT
01	0531061934	CONDUCTOR ARTICULATOR GUIDE		01
02	0531061935	CONDUCTOR ARTICULATOR		01
03	0503010237	3/8" X 1" BOLT		01
04	0503010025	3/8 SPRING WASHER		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01

LEFT FLASHLIGHT ASSEMBLY


0541053383




Item	Code	Description	See page	QT
01	0503019579	LED LANTERN		01
02	0591018872	LANTERN COVER		01
03	0503019412	RIVET SCREW INTERNAL		02
04	0503013813	1/4" UNC X 7/8" BOLT		02
05	0503010143	1/4" SPRING WASHER		02
06	0503010305	6,50 X 17 X 1,50 ZN FLAT WASHER		02
07	0503010237	3/8" X 1" BOLT		02
08	0503010026	3/8" NUT		02
09	0503010025	3/8 SPRING WASHER		02
10	0501318958	LEFT FLASHLIGHT SUPPORT		01

RIGHT FLASHLIGHT ASSEMBLY


0541053384




Item	Code	Description	See page	QT
01	0503019579	LED LANTERN		01
02	0591018872	LANTERN COVER		01
03	0503019412	RIVET SCREW INTERNAL		02
04	0503013813	1/4" UNC X 7/8" BOLT		02
05	0503010143	1/4" SPRING WASHER		02
06	0503010305	6,50 X 17 X 1,50 ZN FLAT WASHER		02
07	0503010237	3/8" X 1" BOLT		02
08	0503010026	3/8" NUT		02
09	0503010025	3/8 SPRING WASHER		02
10	0501318959	RIGHT FLASHLIGHT SUPPORT		01




Item	Code	Description	See page	QT
01	0503036366	SEALING AIR TUBE		02
02	0501312852	COVER AIR TUBE		02
03	0503010025	3/8 SPRING WASHER		08
04	0503010026	3/8" NUT		08
05	0503010237	3/8" X 1" BOLT		08
06	0531067964	SEED LINES FIXATION TUBE		01




Item	Code	Description	See page	QT
01	0531066392	CLAMP FOR SQUARE TUBE 70MM		02
02	0503010027	5/8 SPRING WASHER		02
03	0503010013	5/8 UNC G.5 ZN HEX NUT		02
04	0503011267	BOLT 5/8" UNC X 1.1/2 C S G.5 ZN		02
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
06	0503010019	1/2" SPRING WASHER		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0503010547	1/2" X 4" BOLT		04
09	0541050844	TATU SUCTION TURBINE	138	01
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
11	0503010589	1/2" UNC SELF ADJUSTING NUT		02
12	0503010384	1/2" X 5" BOLT		02
13	0531067946	SUPPORT		01
14	0501217254	TURBINE SUPPORT BODY		01



Item	Code	Description	See page	QT
01	0591018230	FAN 428		01
02	0513010047	1/2 NC HEXAGONAL FLANGED NUT		01
03	0501219835	BOX TURBINE SUCTION		01
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		14
05	0503010358	5/16" X 5/8" BOLT		09
06	0503013357	3/8 SELF-ADJUSTING NUT		02
07	0503010025	3/8 SPRING WASHER		02
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
09	0503062560	TUBE FOR METER CLOCK 730142		01
10	0511017907	1/8" BSPT X 6 PLUG		01
11	0503035611	SUCTION DUCT SEAL		01
12	0503010143	1/4" SPRING WASHER		02
13	0503010294	1/4" X 7/8" BOLT		02
14	0503035455	HYDRAULIC TURBINE SUCTION DUCT		01
15	0503010397	5/16" X 1-3/4" BOLT		05
16	0541050591	COMPLETE PLM ENGINE		01
16A	0513010038	ENGINE		01
16B	0513011890	TERMINAL M22 X 1.50 MF ADAPTER		02
17	0513011686	TERMINAL UNION FG TB12L X FG TB12L		01
18	0531059913	ANTI CAVITATION VALVE SET		01
18A	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
18B	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		02
19	0531062277	TURBINE FRONT COVER		01
20	0501219837	PLATE COVER TURBINE		01




Item	Code	Description	See page	QT
01	0503012567	T-JOIN FOR TUBE 110		01
02	0521015543	110 X 55 AIR DUCT		03
03	0571018559	WHITE PVC TUBE		03




Item	Code	Description	See page	QT
01	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
02	0503010337	NUT 5/16 UNC G.5 ZN		02
03	0503010371	5/16" X 1" BOLT		02
04	0501312692	T CLAMP		01
05	0531067949	RIGHT SUPPORT T FIXATION		01
06	0531067950	LOWER FASTENING CLAP		01
07	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
08	0503010589	1/2" UNC SELF ADJUSTING NUT		02
09	0503010384	1/2" X 5" BOLT		02

LEFT SUPPORT T FIXATION


0541053453




Item	Code	Description	See page	QT
01	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
02	0503010337	NUT 5/16 UNC G.5 ZN		02
03	0503010371	5/16" X 1" BOLT		02
04	0501312692	T CLAMP		01
05	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
06	0531067948	LEFT SUPPORT T FIXATION		01
07	0531067950	LOWER FASTENING CLAP		01
08	0503010589	1/2" UNC SELF ADJUSTING NUT		02
09	0503010384	1/2" X 5" BOLT		02




Item	Code	Description	See page	QT
01	0581015856	REDLIGHT SUPPORT		01
02	0503018738	HEADLIGHT		01
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
04	0503010358	5/16" X 5/8" BOLT		02
05	0551019884	45 X 50 X 3/8 FASTENER		02
06	0503013357	3/8 SELF-ADJUSTING NUT		04
07	0503010337	NUT 5/16 UNC G.5 ZN		02
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		02




Item	Code	Description	See page	QT
01	0503013584	VACUUM GAUGE		02
02	0501011643	3/8 X 1" BOLT		02
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0503013357	3/8 SELF-ADJUSTING NUT		02
05	0501319062	VACUUM METER SUPPORT		01



Item	Code	Description	See page	QT
01	0501319197	SUPPORT REAR LIGHT		01
02	0503010025	3/8 SPRING WASHER		02
03	0503010026	3/8" NUT		02
04	0521010683	3/8 UNC FASTENER		01
05	0503018738	HEADLIGHT		01
06	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
07	0503010358	5/16" X 5/8" BOLT		02
08	0503010337	NUT 5/16 UNC G.5 ZN		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02



Item	Code	Description	See page	QT
01	0513010811	SUPREME BLOCK CONTROL PANEL BCE 5373.6		001
02	0513011850	HEADLIGHT WHIP / LED LANTERN IMPL18.5M BCE 5765.3		001
03	0513010975	LIGHTHOUSE EXTENSION 3 HOLES ECB 5381.9		002
04	0513011849	BLOCK WHIP		001
05	0513011232	LIMIT KEY		003
06	0501217647	SHT PANEL FIXING PLATE		001
07	0503016234	FIXING VACUUM TRIMBLE 91357-AG		001
08	0503016452	FIXING SUPPORT AG500 TRIMBLE		001
09	0503018829	NYLON CLAMP 7,8 X 1,8 X 390 MM		070
10	0503019902	NYLON CLAMP 7,8X1,8X225 MM		130
11	0503019924	BLOCK WHIP WITH ECB TREAT 4554.2		001
12	0513011205	HEAT EXCHANGER SWITCH PANEL		001
13	0513011204	TRACTOR POWER SWITCH CABLE 5463.5		001
14	0503019307	CABLE TRACTOR HEADLIGHT		001
15	0503062594	IMPLEMENT SWITCH CABLE (EXTENSION)		001
16	0503019305	WHIP		001
17	0513010191	BOLT		003
18	0503018774	MAGNETIC SENSOR		002
19	0503018775	MAGNETIC ACTUATOR LH7.4.000091		002
20	0513011238	CABLE PRESS		003




Item	Code	Description	See page	QT
01	0531057126	KIT CABIN SEEDSENSE GEN3		001
01A	0503063047	MONITOR KIT		001
01B	0503019536	MODULE		001
01C	0503063204	KIT BASE		001
01D	0503019759	WHIP		001
01E	0503017972	TRACTOR BATTERY WHIP		001
01F	0503017973	ENERGY DISTRIBUTOR MODULE		001
01G	0503016452	FIXING SUPPORT AG500 TRIMBLE		001
01H	0503016234	FIXING VACUUM TRIMBLE 91357-AG		001
01I	0503018653	ADAPTER WHIP		001
01J	0503018097	WHIP BATTERY		001
01K	0503019424	WHIP JD STARFIRE GPS		001
02	0503062458	TRACT CONNECTOR SET		001
03	0503018061	SRM MAIN WHIP - 7 LINES		001
04	0503018062	MAIN WHIP		002
05	0503018084	EXTENSION CABLE CAN SRM 729146 - 18,30MTS		001
06	0503018082	EXTENSION CABLE CAN SRM 729145 - 13,70MTS		001
07	0503018081	CAN EXTENSION CABLE SRM		001
08	0503018066	SRM MAIN HARNESS - 4 LINES 76/90 729444		002
09	0503017996	EXTENSION CABLE APEX 729151 - 4,50MTS		001
10	0513010031	EXTERNAL LIFTING CABLE PSS-X1005B CAN-5M		001
11	0503062431	ELECTRIC MOTOR		025
12	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		300
13	0503019776	SEED TUBE WITH WAVE VISION SENSOR		025
14	0503019755	UNIT MODULE		025
15	0503017975	WHIP		025
16	0513010275	PP725905 VACUUM SENSOR		030
17	0513011769	EXTERNAL ADAPTER		001
18	0503018774	MAGNETIC SENSOR		001
19	0503018775	MAGNETIC ACTUATOR LH7.4.000091		001
20	0503018055	WHIP ADAPTER		001
21	0513012252	PLUG ADAPTER DIN EUROPEIA 725719		001




USAP 3200 SS SUPREMA - FRAME 11720 - UNI BOX
VDRIVE SET 25 LINES

Page 146
0541053204

Item	Code	Description	See page	QT
22	0503017986	WHIP BATTERY FOR PLUG		001
23	0503018098	BATTERY HARNESS 3 ROUND PINS 725254		001
24	0513011194	TRIMBLE ADAPTER HARNESS GFX PP-727068		001




Item	Code	Description	See page	QT
01	0503034334	ADHESIVE LABEL CSC (REAR)		04
02	0503034335	ADHESIVE LABEL		04
03	0503034336	ADHESIVE LABEL CSC (FRONT)		04
04	0503034337	ADHESIVE LABEL		04
05	0503034338	ADHESIVE LABEL		08
06	0503034339	ADHESIVE LABEL		08
07	0503031565	CAUTION TRANSPORTATION DECAL		04
08	0503031827	LUBRICATE AND RETIGHTEN DAILY DECAL		05
09	0503033621	WARNING DO NOT TRANSIT DECAL		04
10	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL		04
11	0503033597	LIFTING PROHIBITED DECAL		02
12	0503031428	READ MANUAL DECAL		01
13	0503033416	NUMBER 2 DECAL		02
14	0503033419	NUMBER 5 DECAL		02
15	0503034534	ADHESIVE LABEL		01
16	0503033021	ADHESIVE LABEL ISOBUS INSIDE 200MM		02
17	0503033022	ADHESIVE LABEL ISOBUS INSIDE 400MM		02
18	0503033765	ADHESIVE LABEL APT MARCHESAN LARGER		04
19	0503033764	ADHESIVE LABEL APT MARCHESAN LOWER		01
20	0521056998	ALUMINUM IDENTIFICATION LABEL WITH RIVET		01
20A	0503034003	61 X 118 SERIAL NUMBER TAG		01
20B	0503010001	RIVET 3,2 X 5,5		04
21	0503032988	SEED DISTRIBUTOR CHART DECAL		02
22	0503032986	ADHESIVE LABEL		02
23	0503036078	ADHESIVE LABEL WARNING TANK SHT		01
24	0503038197	OIL 140 ADHESIVE LABEL		02




Item	Code	Description	See page	QT
01	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
02	0503010267	NYLON CLAMP 3,60 X 1,3 X 155 MM		01
03	0503010337	NUT 5/16 UNC G.5 ZN		01
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
05	0503060100	SUPPORT INSTRUCTION MANUAL		01
06	0511034540	BAG WITH INSTRUCTION MANUAL		01

LEFT COMPLETE HOSE SUPPORT

0531057692



Item	Code	Description	See page	QT
01	0531065305	HOSE SUPPORT LEFT		01
02	0531065306	ARTICULATOR HOSE		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0503010025	3/8 SPRING WASHER		02
05	0503010237	3/8" X 1" BOLT		01
06	0503010026	3/8" NUT		01
07	0503010849	3/8" X 1-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0503014559	ROLLER BEARING		02
02	0503010095	SEAL		01
03	0501213909	WHEELED HUB COVER		01
04	0502040080	FLANGE NUT R.2.1/2" UN		01
05	0503010002	1800 GREASE FITTING		13
06	0501213917	ADJUSTMENT WASHER		01
07	0503012213	1/4" X 4" SPLIT PIN		01
08	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
10	0501214463	SIDE WHEEL PULLEY		06
11	0501214462	NYLON PULLEY BUSHING		12
12	0501214303	WHEEL CHAIN		06
13	0531064110	PULLEY LOCK AXLE		06
14	0503010834	1/2 X 1 BOLT		06
15	0503010019	1/2" SPRING WASHER		06
16	0591017921	BRONZE GLOVE 90.5 X 115 X 91		02
17	0501214460	AXLE 1.1/2 X 140MM		01
18	0503010390	SEAL RING		02
19	0531055358	COMPLETE SIDE CYLINDER BEARING	51	02
20	0531055357	LOCK PIN SET	52	01
21	0501214302	ADJUSTMENT COVER PLATE		06
22	0503034377	3/8 UNC X 3/4 BOLT		36
23	0503010025	3/8 SPRING WASHER		36
24	0501017065	FLAT WASHER		06
25	0503011255	3/4" LOCK NUT		06
26	0501216430	ADJUSTING COVER CALCO		06
27	0531059880	LARGER LOCK PIN ASSEMBLY	57	01
28	0501311048	BEATER AXLE 230		01
29	0503012623	3/8" X 1-1/2" BOLT		01
30	0503010208	HEX NUT 3/8 UNF G.5 ZN		01
31	0541050293	LEFT WHEEL TIRE 500 X 50	151	01
32	0531066281	SIDE WHEEL TOWER		01



USAP 3200 SS SUPREMA - FRAME 11720 - UNI BOX
LEFT MONO WHEELS TIRE 500/50

Page 150
0541051652


Item	Code	Description	See page	QT
33	0541050277	HYDRAULIC CYLINDER LEFT	109	01
34	0531066956	LEFT SIDE WHEEL FRAME		01




Item	Code	Description	See page	QT
01	0531064114	SINGLE LEFT WHEEL TIRE 500/50		01
02	0501213744	SINGLE ARM WHEEL AXLE		01
03	0503019246	BOLT		01
04	0503011075	3/4 UNC LOCK NUT		01
05	0501213743	LOCK AXLE		01
06	0501213742	SUPPORT WASHER		01
07	0503010953	BOLT 1 UNC X 2 C S G.5 ZN		01
08	0503010012	1" SPRING WASHER		01
09	0541050196	MOUNTED RIGHT WHEEL	108	01
10	0541050294	FULL WHEEL BOX	56	01

LEFT SIDE DUCT ASSEMBLY

0541053458



Item	Code	Description	See page	QT
01	0503011075	3/4 UNC LOCK NUT		04
02	0501010098	BOLT 3/4" UNC X 2 C S G.5 ZN		04
03	0501312872	RIGHT SUPPORT PLATE HYDRAULIC DUCTS		02
04	0501312870	DUCT SUPPORT		02
05	0513010752	SINGLE STANDARD CLAMP 12 MM - BLACK		48
06	0501311238	CLAMP UNION 112 X 30 X 6,30		04
07	0501311237	FIXER		04
08	0513011685	TEE TERMINAL MF X MF X FG TB12L		04
09	0503036429	HYDRAULIC TUBE PT PT12L X PT12L X 3000		04
10	0551010707	GLOVE		04
11	0513011666	BOLT M6		04
12	0591012160	7 X 23 X 2.00 ZN FLAT WASHER		04
13	0503010305	6,50 X 17 X 1,50 ZN FLAT WASHER		16
14	0503015110	M06 SPRING WASHER		16
15	0503014540	M6 NUT		16
16	0513011664	BOLT M6 X 1,00 X 80 - SXR6X80ZI		12
17	0503036890	HYDRAULIC TUBE PT12L X FG12L X 1790		02
18	0503036889	HYDRAULIC TUBE PT12L X PT12L X 1170		02
19	0501319122	SUPPORT 50 X 25 X 2965		01



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

