

ROW CROP PLANTERS

USAP 3200 AP SUPREMA - FRAME 12820
USAP 3200 AP SUPREMA - CHASSI 12820

Code: 0501093868
Series: S-0523
Revision: 00
Revision Date: MARCH/2024

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Working Width	Description
0111510174		USAP 3200 AP 24E500 SUP ALP S-0523

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909097134	ASSY FRAME	1
0909097135	FRAME RIGHT SIDE ASSY	2
0909097136	ASSY CENTRAL FRAME	3
0909097137	LEFT SIDE FRAME ASSY	4
0541051002	DRAWBAR ASSY	5
0531057052	DRAWBAR ASSY	6
0531057067	DRAWBAR ESTABILIZER ASSY	7
0541050997	DRAWBAR ASSY	8
0521059886	SEMI-ASSEMBLED REST	9
0531059899	PANTOGRAPHIC DRAWBAR	10
0531059875	CYLINDER HYDRAULIC	11
0531059876	CYLINDER HYDRAULIC	12
0541050998	REAR DRAWBAR	13
0531059893	SIDE ARM LATCH ASSEMBLY	14
0531059877	CYLINDER HYDRAULIC 44,45 X 85,70 X 398 X 93	15
0541051192	CONVEYOR BELT ASSEMBLY 1200/1085	16
0541052597	SHT ASSY	17
0541050020	DOUBLE ROTATING DIVIDER	18
0541050680	DOUBLE PUMP MULTIPLIER	19
0541050014	HYDRAULIC PUMP	20
0541050681	HYDRAULIC PUMP	21
0541050774	DIVIDER VALVE	22
0541050762	SET OF COMMAND BLOCKS	23
0531059987	DRIVING BLOCK	24
0531059990	ROTATING DIVIDER	25
0531059985	BLOCK HYDRAULIC COMMAND	26
0541050775	CYLINDER COMMANDER BLOCK	27
0531059986	DRIVE COMMAND BLOCK	28
0541050773	BLOCK COMMAND	29
0541052598	PASSAGE BLOCK ASSY	30
0531059989	PASSAGE BLOCK	31
0541052594	4-WAY PASS BLOCK	32
0541052592	TANK HEAT EXCHANGER	33
0531059117	FULL HEAD HOSE STABILIZER	34
0541050012	RADIATOR EQUIPMENT	35
0541052593	COMPLETE 180L TANK	36
0531056312	ASSY FRENCH HAND	37
0521057793	KNEECAP WITH RIGHT EXTENSION AXLE	38
0531056065	STABILIZER	39
0531053738	STABILIZER EXTENDER	40
0541050066	SUPPORT 5S X 500	41
0541050666	CHUTE 4S X 500 WITH BOLT	42
0541050366	GUTTER 4S X 500 WITH CENTRAL BOLT	43
0541050552	BOX MODULES	44
0541050145	GUIDE SET	45
0541050144	GUIDE SENSOR	46
0531058510	ASSY SENSOR FIXATION	47
0541052755	LEFT ROW SENSOR ASSEMBLY	48
0541052754	RIGHT ROW SENSOR ASSEMBLY	49
0531057194	3F/AP LIGHTING/CONTROL ASSY	50
0541052112	HYDRAULIC HOSE SET	51
0541052105	HOSE SET DKO APT	52
0541052106	DKO LOCK HOSE SET	53
0541052107	DKO PANTOGRAPHIC HOSE SET	54
0541052108	HOSE SET DKO AB/FC	55
0541052109	LEVANTE HOSE SET DKO	56
0541052110	HOSE SET DKO ARTICULATION	57
0541052111	DKO TURBINE HOSE SET	58
0541051069	ASSY ISO 6C/24L/45/50 MSA	59



MARCHESAN

INDEX

0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	60
0521054490	FLOW DIVIDING VALVE ASSY	61
0531053111	SET LABEL ADHESIVE	62
0531059250	DOOR MANUAL	63
0531050901	ASSY STABILIZER	64
0521059948	ASSY LOCK AXLE	65
0531056303	RIGHT SIDE HOPPER 10 MOUTHS	66
0531056304	RIGHT SIDE HOPPER 10 10 MOUTHS ALPHA	67
0531051685	CENTRAL BEARING SHAFT	68
0531051684	SIDE AXLE	69
0531055292	ALPHA FERTILIZER METERING	70
0501053788	3/4" SQUARE AXLE FASTENER	71
0531055273	ALPHA FERTILIZER METERING CLAMP	72
0531055376	TRANSMISSION ALPHA FERTILIZER METERING HUB	73
0521051407	FERTILIZER HOPPER FIXER	74
0531050918	TOP SUPPORT MOUNTED LIFT EXTENSOR	75
0531052853	RIGHT LADDER SET	76
0531056308	HANDRAIL/PLATFORM ASSY	77
0521059839	ASSY REAR HEADLIGHT	78
0531053062	SUPPORT WITH VACUOMETER 18/25 LINES	79
0541050616	CYLINDER 101,55 X 618 X 353	80
0541050557	SIDE SUPPORT	81
0541050570	SIDE ARTICULATION CYLINDER 44,45X85,70X291X657 DKO	82
0541050590	TURBINE SUCTION	83
0531057693	HOSE SUPPORT	84
0541050990	AIR CONDUCTOR TUBE WITH 09 OUTLETS COMPLETE	85
0541051213	RIGHT SIDE DUCTS ASSEMBLY 24E500	86
0541051683	DOUBLE RIGHT WHEEL WHEELS SMALLER TIRE 500/50	87
0531055358	COMPLETE SIDE CYLINDER BEARING	88
0531055357	LOCK PIN SET	89
0531059818	HYDRAULIC RIGHT CYLINDER	90
0541050188	DOUBLE SIDE WHEELED TIRE	91
0541050193	WHEEL COMPLETE BOX	92
0541050195	MOUNTED LEFT WHEEL	93
0541050196	MOUNTED RIGHT WHEEL	94
0541052791	COMPLETE FERTILIZER SMALLER DUCT	95
0541052794	FLOW SENSOR ASSEMBLY WITH HOSE	96
0531050772	RIGHT CLAMP 4	97
0531058989	1 1/2 COMPLETE HANDCUFF CLAMP	98
0531059147	FERTILIZER ENGINE SUPPORT	99
0531056908	SUPPORT SEED ENGINE	100
0531056094	ASSY BEARING	101
0521055372	ROW SEED BEARING	102
0909097138	COMPLETE FERTILIZER ROW	103
0541050985	SHORT RIGHT SEED LINE SUP/TMC/SPICRRF/PPH	104
0541050984	LEFT LONG SEED LINE SUP/TMC/SPICRRF/PPH	105
0541050983	SUPER LONG LEFT SEED LINE SUP/TMC/SPICRRF/PPH	106
0531054007	SHORT/LONG FRONT SEED ROW	107
0541050987	RIGHT REAR WITH DDD SPICRRF	108
0531059830	REAR WITH RIGHT DDD WITHOUT FLAP WITHOUT FULL WHEEL	109
0531059833	DEPTH REGULATOR	110
0531059832	ASSEMBLED RIGHT ARM	111
0531059831	ASSEMBLED LEFT ARM	112
0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	113
0521055056	SPOKED WHEEL ASSY	114
0521055073	ASSEMBLY DEPTH WHEEL HUB	115
0521056640	PRECISION PLANTING CSC CABLE / TRANSMISSION ASSY	116



MARCHESAN

INDEX


0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION	117
0541050988	WHEEL COMPACTOR IRON SET	118
0531059837	SPA COMPACTING BODY WITHOUT BOLT	119
0521055018	WHEEL DRIVE WHEEL LEFT IN V	120
0521055019	IRON IN RIGHT WHEEL COMPACTOR V	121
0521054991	WHEEL DRIVE WHEEL RIGHT	122
0531051264	FULL SUPPORT FOR ENCAPSULATED CURRENT FIXATION	123
0541050062	P.P. TRANSMISSION GEAR BOX RIGHT	124
0541050079	SEED ROW UPPER TRANSMISSION GEAR BOX	125
0531051094	MOUNTED HOSE GUIDE ASSEMBLY	126
0541050067	FRONT LONG SEED ROW	127
0541050986	LEFT REAR WITH DDD SPICRRF	128
0531059835	REAR WITH LEFT DDD SPICRR WITHOUT FLAP WITHOUT FULL WHEEL	129
0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM SPI	130
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	131
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	132
0521055865	FERTILIZER/SEED LEFT HUB ASSY	133
0521055864	FERTILIZER/SEED RIGHT HUB ASSY	134
0541050048	SUPER LONG FRONT TCC	135
0511057159	TRANSMISSION HOPPER SEED ROW	136
0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	137
0501053566	ROW SEED BEARING	138
0531056104	SHORT FERTILIZER LINE DC20/DSAEB18 WITHOUT LUBRICATION	139
0531056103	SMALLER LONG FERTILIZER LINE DC20/DSAEB18	140
0521057679	ASSY CUTTING DISK 20	141
0521057681	BOX WITH DISC CUTTING 20 BEARING CONICO	142
0521057680	DISC CUTTING BOX	143
0531056105	MONO DC SINGLE STRETCHED FERTILIZER B - DSAEB	144
0531050800	HUB WITH SMOOTH STRIPED FLAT DISC B. 18	145
0531055165	20 COMPLETE CURVED CORRUGATED CUTTING DISC	146
0521053673	SCARIFIER ROD WITH NOZZLE	147
0531053737	MOUNTED SUPPORT	148
0531055349	CENTRAL HOPPER WITH 07 NOZZLES ALPHA/APT/AP	149
0531055350	CENTRAL SUPPORT WITH 07 NOZZLES	150
0531059144	FERTILIZER DOSER ALPHA II	151
0531055863	TRANSMISSION HUB ASSY	152
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	153
0531059138	COMPLETE COLLECTOR	154
0541050194	COMPLETE CENTRAL CUBE	154
0521054282	BEARING	155
0531059817	HYDRAULIC CYLINDER 44,45X85,70X326	155
0501056444	ROLLER BEARING	156
0531054036	ASSY CENTER CYLINDER BEARING	156
0531054350	DEPOSIT MOVEMENT SUPPORT	156
0531055368	ASSY RIGHT ARTICULATION ARM AP	156
0531055369	ASSY LEFT ARTICULATION ARM AP	156
0531059845	CYLINDER HYDRAULIC 50,80 X 127 X 965 X 534	156
0541050556	CENTRAL SUPPORT MOUNTED	156
0541050564	RIGHT TELESCOPIC WHEELSET	156
0541050565	LEFT TELESCOPIC WHEELSET	156
0541050555	SILLO ASSY CSC 2500L DKO	157
0531054354	CENTRAL SEED BOX 2500 LITERS	158
0531054357	LOWER SYSTEM 28 PIPES	159
0531058201	HYDRAULIC TURBINE WITH SCREEN	160
0531056343	HYDRAULIC ENGINE	161
0521044613	480 X 50 FAN (HIDRAULIC)	162

INDEX

0531056344	COMMAND BLOCK		163
0541050569	HYDRAULIC CYLINDER 38,10X63,50X225X375		164
0541050588	AIR CONDUCTOR TUBE 06 OUTLETS 02 COMPLETE NOZZLES		165
0521052549	CLAMP		166
0541050678	RIGHT LANTERN SET		167
0541050679	LEFT LANTERN SET		168
0531059634	ALPHA COMPONENTS KIT - 17 ROWS		169
0531052854	LEFT STAIRS SET		170
0531058139	LEFT SIDE HOPPER WITH 10 NOZZLES 175L ALPHA		171
0531058140	LEFT SIDE HOPPER WITH 10 NOZZLES ALPHA		172
0531057692	LEFT COMPLETE HOSE SUPPORT		173
0541051155	LEFT SIDE DUCT SET 24E500		174
0541051682	DOUBLE LEFT WHEEL SET SMALLER TIRE 500/50		175

ASSY FRAME

0909097134



Item	Code	Description	See page	QT
01		FRAME RIGHT SIDE ASSY	2	
02		ASSY CENTRAL FRAME	3	
03		LEFT SIDE FRAME ASSY	4	
04	0541051002	DRAWBAR ASSY	5	01
05	0541052597	SHT ASSY	17	01
06	0531056312	ASSY FRENCH HAND	37	02
07	0531056065	STABILIZER	39	01
08	0531055394	MOUNTED TRANSPORT LOCK 315MM		04
08A	0531064139	TRANSPORT LOCK 315MM		01
08B	0531060392	PIN LOCK TRANSPORT		01
08C	0503030168	HITCH PIN CLIP		01
09	0541050066	SUPPORT 5S X 500	41	02
10	0541050666	CHUTE 4S X 500 WITH BOLT	42	02
11	0541050366	GUTTER 4S X 500 WITH CENTRAL BOLT	43	01
12	0501311685	SUPPORT LIFTING STAIRS RIGHT		01
13	0501311686	STAIR LIFTING SUPPORT		01
14	0503010743	1/4" X 1-1/4" BOLT		02
15	0591012160	7 X 23 X 2.00 ZN FLAT WASHER		02
16	0503010143	1/4" SPRING WASHER		02
17	0503010144	1/4" NUT		02
18	0501311516	UPPER SHEET		01
19	0503015321	3/8 UNC X 5/8 C S G.2 ZN BOLT		06
20	0501013518	FLAT WASHER		06
21	0501311515	SENSOR LIFTING SUPPORT		01
22	0541050552	BOX MODULES	44	01
23	0501312548	SUPPORT 55 X 50 X 800		02
24	0501312917	GUTTER 55 X 50 X 450		02
25	0501312920	LEFT SIDE TROUGH		01
26	0501313013	LEFT ROW ARTICULATION GUIDE GUTTER		02
27	0501312919	GUTTER 55 X 50 X 200		01
28	0501312918	GUIDE GUTTER ARTICULATION RIGHT ROW		01
29	0503011334	3/8 UNC X 3/4 CS G.5 ZN BOLT		08


ASSY FRAME

0909097134

Item	Code	Description	See page	QT
30	0503010025	3/8 SPRING WASHER		10
31	0503011236	3/8" X 2" BOLT		02
32	0501016103	FLAT WASHER		02
33	0501312922	GLOVE 10.50 X 29 X 24		02
34	0503010026	3/8" NUT		02
35	0501010125	3/4" X 2-1/2" BOLT		02
36	0503011075	3/4 UNC LOCK NUT		02
37	0541050145	GUIDE SET	45	01
38	0541050144	GUIDE SENSOR	46	01
39	0531066193	RULER		01
40	0531058510	ASSY SENSOR FIXATION	47	01
41	0541052755	LEFT ROW SENSOR ASSEMBLY	48	01
42	0541052754	RIGHT ROW SENSOR ASSEMBLY	49	01
43	0531057194	3F/AP LIGHTING/CONTROL ASSY	50	01
44	0541052112	HYDRAULIC HOSE SET	51	01
45	0541051069	ASSY ISO 6C/24L/45/50 MSA	59	01
46	0531053111	SET LABEL ADHESIVE	62	01
47	0531055395	MOUNTED TRANSPORT BEAM 600MM		04
47A	0531064140	TRAVA FOR TRANSPORTATION 600MM		01
47B	0531060392	PIN LOCK TRANSPORT		01
47C	0503030168	HITCH PIN CLIP		01
48	0531059250	DOOR MANUAL	63	01
49	0521058345	SAFETY CHAIN WITH SHACKLE		01
49A	0503014120	CHAIN		01
49B	0503014321	CABLE STEEL SHACKLE		02
50	0503063897	CARDAN 21Z 1.3/8 X 21Z 1.3/8 800MM		01
51	0513011183	TERMINAL CARDAN TRIANGULAR 20Z 1.3/4 SERIE 06		01
52	0511034859	PLASTIC COVER WITH INSTRUCTIONS MANUAL ISO6		01

FRAME RIGHT SIDE ASSY

0909097135




Item	Code	Description	See page	QT
01	0531064575	RIGHT FRAME		01
02	0531050901	ASSY STABILIZER	64	03
03	0591018043	BODY SUPPORT		02
04	0503010962	5/8" X 1-1/4" BOLT		06
05	0501010453	FLAT WASHER		06
06	0503010027	5/8 SPRING WASHER		07
07	0521059948	ASSY LOCK AXLE	65	01
08	0591018044	WASHER 65 X 130 X 20		01
09	0503012213	1/4" X 4" SPLIT PIN		01
10	0591018042	FRICTION PLATE		02
11	0591015962	SEPARATOR GLOVE		04
12	0591018045	FRICTION TRACK		02
13	0591019522	SLEEVE WEAR		02
14	0591015374	HITCH AXIS		01
15	0503010232	5/8" X 1.3/4" BOLT		01
16	0511010721	FLAT WASHER		01
17	0501111058	ASSY FIXING GLOVE		02
18	0503011082	C1/2" X 1.3/4" SCREW		06
19	0503011336	1/2" HEX SELF ADJUSTING NUT		06
20	0591018541	SWIVEL CYLINDER COVER		02
21	0501210615	SIDE WHEEL JOINT AXLE		01
22	0503010391	501038 CLAMPING RING (FOR AXLE)		01
23	0531056303	RIGHT SIDE HOPPER 10 MOUTHS	66	01
24	0531062503	LOWER RIGHT SIDE COMPLETE		01
25	0531052853	RIGHT LADDER SET	76	01
26	0503013389	5/8" SELF LOCKING NUT		15
27	0591011409	FLAT WASHER 16,5 X 35 X 3,00		15
28	0503010233	5/8" X 2-1/2" BOLT		15
29	0531062505	LARGE SIDE LEFT		01
30	0501218752	LARGER FIXER GLOVE		08
31	0591018936	GLOVE		02
32	0503010002	1800 GREASE FITTING		02

Item	Code	Description	See page	QT
33	0503035468	HOSE PROTECTION		02
34	0531056308	HANDRAIL/PLATFORM ASSY	77	01
35	0521059839	ASSY REAR HEADLIGHT	78	01
36	0531053062	SUPPORT WITH VACUOMETER 18/25 LINES	79	01
37	0503010246	CLAMP		01
38	0531064602	TRANSMISSION SUPPORT		02
39	0531061069	FRONT SIDE SUPPORT AXIS		01
40	0503011052	1.1/4" X 0.77" CASTLE NUT		01
41	0503010038	3/16" X 2" SPLIT PIN		01
42	0501017779	FLAT WASHER 32 X 60 X 4,75		01
43	0591012027	31,75 X 150 X 20,00 SLEEVE		01
44	0503014876	NUT PARLOCK 1/4"		01
45	0503010733	1/4" X 1-3/4" BOLT		01
46	0591010703	HEX SHAFT 3/4 X 2347		01
47	0561016761	3/4 X 1900 HEX AXLE		01
48	0531060738	SEED/FERTILIZER LINE FIXATION TUBE		01
49	0541050616	CYLINDER 101,55 X 618 X 353	80	01
50	0541050557	SIDE SUPPORT	81	03
51	0541050590	TURBINE SUCTION	83	01
52	0531057693	HOSE SUPPORT	84	01
53	0541050990	AIR CONDUCTOR TUBE WITH 09 OUTLETS COMPLETE	85	01
54	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		10
55	0541051213	RIGHT SIDE DUCTS ASSEMBLY 24E500	86	01
56	0531059117	FULL HEAD HOSE STABILIZER	34	01
57	0541051683	DOUBLE RIGHT WHEEL WHEELS SMALLER TIRE 500/50	87	01
58	1164920015	BLACK SUCTION HOSE		52 mts
59	1164920014	BLACK LIGHT SUCTION HOSE		16 mts
60	1163920004	BLACK LIGHT SUCTION HOSE		04 mts
61	0501211086	FERTILIZER DRIVER CHUTE 24/25		01
62	0541052791	COMPLETE FERTILIZER SMALLER DUCT	95	09
63	0541052792	HOSE 60 X 60 X 245 WITH CLAMP		09
63A	0503035950	HOSE 60X 60 X 245		01
63B	0513012079	CLAMP		02
64	0541052794	FLOW SENSOR ASSEMBLY WITH HOSE	96	09
65	0541052793	POWER GUIDE WITH FIXATION		09
65A	0531062574	GUIDE		01
65B	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
65C	0503013357	3/8 SELF-ADJUSTING NUT		01
66	0531050772	RIGHT CLAMP 4	97	01
67	0541050483	AIR TUBE CAP WITH CLAMP		01
67A	0501312827	AIR TUBE CAP		01
67B	0503011372	102 TO 121 CLAMP		01
68	0531058989	1 1/2 COMPLETE HANDCUFF CLAMP	98	10
69	0503034867	AIR DISTRIBUTOR PUMP		01
70	0503019221	WIRE TYPE CLAMP 3,2MM X 35 X 41 MM AWAARC041		09
71	0531059147	FERTILIZER ENGINE SUPPORT	99	01
72	0531056908	SUPPORT SEED ENGINE	100	01
73	0531056094	ASSY BEARING	101	01
74		COMPLETE FERTILIZER ROW	103	

ASSY CENTRAL FRAME

0909097136



Item	Code	Description	See page	QT
01	0531064288	CENTRAL FRAME CSC 2500L		01
02	0531055349	CENTRAL HOPPER WITH 07 NOZZLES 149		01
03	0531064101	CENTRAL HOPPER SUPPORT		01
04	0531064081	RIGHT CENTRAL SILO SUPPORT		01
05	0531064100	LEFT CENTRAL SILO SUPPORT		01
06	0531055368	ASSY RIGHT ARTICULATION ARM AP	156	01
07	0531055369	ASSY LEFT ARTICULATION ARM AP	156	01
08	0521011100	FLAT WASHER		04
09	0531062245	233 CYLINDER JOINT AXIS		02
10	0503010834	1/2 X 1 BOLT		02
11	0503010019	1/2" SPRING WASHER		06
12	0503010060	1/2 UNC G.5 ZN HEX NUT		04
13	0503010027	5/8 SPRING WASHER		06
14	0503010013	5/8 UNC G.5 ZN HEX NUT		06
15	0501010100	BOLT 5/8" UNC X 2 CS G.5 ZN		06
16	0503010023	3/4" SPRING WASHER		02
17	0503010014	3/4" ZN G.5 (HEAVY) UNC HEX NUT		02
18	0501010098	BOLT 3/4" UNC X 2 C S G.5 ZN		02
19	0521059839	ASSY REAR HEADLIGHT	78	01
20	0531054350	DEPOSIT MOVEMENT SUPPORT	156	02
21	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
22	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
23	0531063645	CENTRAL PLATFORM FOR BOX 28 MOUTH		01
24	0503010589	1/2" UNC SELF ADJUSTING NUT		04
25	0503014378	1/2" X 1-1/2" BOLT		04
26	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
27	0501017065	FLAT WASHER		20
28	0503019522	HEX NUT		20
29	0503019521	SCREW 3/4 UNF 3 CSRP G.8 ZN		20
30	0511015994	FLAT WASHER		02


ASSY CENTRAL FRAME

0909097136

Item	Code	Description	See page	QT
31	0503018754	NUT 1 - 8 UNC - 2B G8		02
32	0501010276	BOLT		02
33	0531061847	FIXING TUBE SEED/FERTILIZER LINES		01
34	0581018254	HEX AXLE 3/4 X 2700 STM 29 USG		01
35	0531059845	CYLINDER HYDRAULIC 50,80 X 127 X 965 X 534	156	02
36	0541050565	LEFT TELESCOPIC WHEELSET	156	01
37	0541050564	RIGHT TELESCOPIC WHEELSET	156	01
38	0541050556	CENTRAL SUPPORT MOUNTED	156	02
39	0541050555	SILO ASSY CSC 2500L DKO	157	01
40	0541050569	HYDRAULIC CYLINDER 38,10X63,50X225X375	164	01
41	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		14
42	0521053176	COVER KAP		01
42A	0581017528	15 OUTPUT TUBE COVER		01
42B	0503011372	102 TO 121 CLAMP		01
43	0541050588	AIR CONDUCTOR TUBE 06 OUTLETS 02 165 COMPLETE NOZZLES		01
44	0541050678	RIGHT LANTERN SET	167	01
45	0541050679	LEFT LANTERN SET	168	01
46	1164920014	BLACK LIGHT SUCTION HOSE		10 mts
47	1163920004	BLACK LIGHT SUCTION HOSE		01 mt
48	1164920017	BLUE PVC FLAT HOSE		02 mts
49	0503034867	AIR DISTRIBUTOR PUMP		01
50	0503034345	DISPENSER COVER		04
51	0531050772	RIGHT CLAMP 4	97	02
52	0531058989	1 1/2 COMPLETE HANDCUFF CLAMP	98	07
53	0591019407	FERTILIZER CONDUCTOR GUTTER		01
54	0541052791	COMPLETE FERTILIZER SMALLER DUCT	95	06
55	0541052794	FLOW SENSOR ASSEMBLY WITH HOSE	96	06
56	0541052792	HOSE 60 X 60 X 245 WITH CLAMP		06
56A	0503035950	HOSE 60X 60 X 245		01
56B	0513012079	CLAMP		02
57	0503019221	WIRE TYPE CLAMP 3,2MM X 35 X 41 MM AWAARC041		06
58	0541052793	POWER GUIDE WITH FIXATION		06
58A	0531062574	GUIDE		01
58B	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
58C	0503013357	3/8 SELF-ADJUSTING NUT		01
59	0531059147	FERTILIZER ENGINE SUPPORT	99	01
60	0531056908	SUPPORT SEED ENGINE	100	01
61	0531056094	ASSY BEARING	101	01
62	0541015451	WRENCH 2.3/8 X 2.3/4		01
63	0501047895	25 ROD STOP		04
64	0501047885	30 ROD STOP		08
65	0501047886	35 ROD STOP		04
66	0501047887	40 ROD STOP		08
67	0503032624	FERTILIZER HOPPER GUTTER		06
68	0503011750	AMENDMENT WITH LOCK		06
69	0503011751	REDUCTION 40-1		06
70	0503019869	CLAMP		05
71	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		200
72	0503018829	NYLON CLAMP 7,8 X 1,8 X 390 MM		100
73	0503034345	DISPENSER COVER		04
74	0531059634	ALPHA COMPONENTS KIT - 17 ROWS	169	01
75	1164920015	BLACK SUCTION HOSE		25 mts
76		COMPLETE FERTILIZER ROW	103	

LEFT SIDE FRAME ASSY

0909097137



Item	Code	Description	See page	QT
01	0531064574	LEFT FRAME		01
02	0591019522	SLEEVE WEAR		02
03	0591018043	BODY SUPPORT		02
04	0503010962	5/8" X 1-1/4" BOLT		06
05	0501010453	FLAT WASHER		06
06	0503010027	5/8 SPRING WASHER		07
07	0521059948	ASSY LOCK AXLE	65	01
08	0591018044	WASHER 65 X 130 X 20		01
09	0503012213	1/4" X 4" SPLIT PIN		01
10	0591018042	FRICTION PLATE		02
11	0591015962	SEPARATOR GLOVE		04
12	0531050901	ASSY STABILIZER	64	03
13	0531062504	SIDE BIGGER RIGHT ASSY		01
14	0503013389	5/8" SELF LOCKING NUT		15
15	0591011409	FLAT WASHER 16,5 X 35 X 3,00		15
16	0503010233	5/8" X 2-1/2" BOLT		15
17	0531062502	ASSY LEFT LOWER SIDE		01
18	0531052854	LEFT STAIRS SET	170	01
19	0591018045	FRICTION TRACK		02
20	0591015374	HITCH AXIS		01
21	0503010232	5/8" X 1.3/4" BOLT		01
22	0511010721	FLAT WASHER		01
23	0501218752	LARGER FIXER GLOVE		08
24	0591018936	GLOVE		02
25	0503010002	1800 GREASE FITTING		02
26	0503035468	HOSE PROTECTION		02
27	0501111058	ASSY FIXING GLOVE		02
28	0503011082	C1/2" X 1.3/4" SCREW		06
29	0503011336	1/2" HEX SELF ADJUSTING NUT		06
30	0591018541	SWIVEL CYLINDER COVER		02
31	0501210615	SIDE WHEEL JOINT AXLE		01
32	0503010391	501038 CLAMPING RING (FOR AXLE)		01


LEFT SIDE FRAME ASSY

0909097137

Item	Code	Description	See page	QT
33	0531058139	LEFT SIDE HOPPER WITH 10 NOZZLES 175L 171		01
		ALPHA		
34	0531056308	HANDRAIL/PLATFORM ASSY	77	01
35	0521059839	ASSY REAR HEADLIGHT	78	01
36	0531053062	SUPPORT WITH VACUOMETER 18/25 LINES	79	01
37	0503010246	CLAMP		01
38	0531064602	TRANSMISSION SUPPORT		02
39	0531061069	FRONT SIDE SUPPORT AXIS		01
40	0503011052	1.1/4" X 0.77" CASTLE NUT		01
41	0503010038	3/16" X 2" SPLIT PIN		01
42	0501017779	FLAT WASHER 32 X 60 X 4,75		01
43	0591012027	31,75 X 150 X 20,00 SLEEVE		01
44	0503014876	NUT PARLOCK 1/4"		01
45	0503010733	1/4" X 1-3/4" BOLT		01
46	0591010703	HEX SHAFT 3/4 X 2347		01
47	0561016761	3/4 X 1900 HEX AXLE		01
48	0531060738	SEED/FERTILIZER LINE FIXATION TUBE		01
49	0531057692	LEFT COMPLETE HOSE SUPPORT	173	01
50	0541050590	TURBINE SUCTION	83	01
51	0541050557	SIDE SUPPORT	81	03
52	0541050616	CYLINDER 101,55 X 618 X 353	80	01
53	0541050990	AIR CONDUCTOR TUBE WITH 09 OUTLETS 85		01
		COMPLETE		
54	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		10
55	0541051155	LEFT SIDE DUCT SET 24E500	174	01
56	0531059117	FULL HEAD HOSE STABILIZER	34	01
57	0541051682	DOUBLE LEFT WHEEL SET SMALLER TIRE 500/50	175	01
58	1164920014	BLACK LIGHT SUCTION HOSE		16 mts
59	1164920015	BLACK SUCTION HOSE		52 mts
60	1163920004	BLACK LIGHT SUCTION HOSE		04 mts
61	0531050772	RIGHT CLAMP 4	97	01
62	0541050483	AIR TUBE CAP WITH CLAMP		01
62A	0503011372	102 TO 121 CLAMP		01
62B	0501012827	PIN LOCK		01
63	0531058989	1 1/2 COMPLETE HANDCUFF CLAMP	98	10
64	0503034867	AIR DISTRIBUTOR PUMP		01
65	0503019221	WIRE TYPE CLAMP 3,2MM X 35 X 41 MM		09
		AWAARC041		
66	0501211086	FERTILIZER DRIVER CHUTE 24/25		01
67	0541052791	COMPLETE FERTILIZER SMALLER DUCT	95	09
68	0541052794	FLOW SENSOR ASSEMBLY WITH HOSE	96	09
69	0541052793	POWER GUIDE WITH FIXATION		09
69A	0531062574	GUIDE		01
69B	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
69C	0503013357	3/8 SELF-ADJUSTING NUT		01
70	0541052792	HOSE 60 X 60 X 245 WITH CLAMP		09
70A	0503035950	HOSE 60X 60 X 245		01
70B	0513012079	CLAMP		02
71	0531056908	SUPPORT SEED ENGINE	100	01
72	0531059147	FERTILIZER ENGINE SUPPORT	99	01
73	0531056094	ASSY BEARING	101	01
74		COMPLETE FERTILIZER ROW	103	

DRAWBAR ASSY

0541051002



Item	Code	Description	See page	QT
01	0531061650	FRONT SIDE SUPPORT AXIS		02
02	0503011052	1.1/4" X 0.77" CASTLE NUT		02
03	0503010038	3/16" X 2" SPLIT PIN		02
04	0501017779	FLAT WASHER 32 X 60 X 4,75		02
05	0531057052	DRAWBAR ASSY	6	01
06	0521058345	SAFETY CHAIN WITH SHACKLE		01
06A	0503014120	CHAIN		01
06B	0503014321	CABLE STEEL SHACKLE		02
07	0541050997	DRAWBAR ASSY	8	01
08	0541050998	REAR DRAWBAR	13	01
09	0513010752	SINGLE STANDARD CLAMP 12 MM - BLACK		56
10	0513010755	STANDARD SIMPLE CLAMP		16
11	0503010305	6,50 X 17 X 1,50 ZN FLAT WASHER		32
12	0503015110	M06 SPRING WASHER		16
13	0503014540	M6 NUT		16
14	0501312225	CLAMP 179 X 30 X 6.30		08
15	0513010746	STANDARD CLAMP SINGLE 10MM - BLACK		08
16	0501312881	SIDE FIXER		04
17	0513011665	BOLT M6 X 1,00 X 90 - SXR6X90ZI		08
18	0513011851	BOLT M6 X 1,00 X 175		08
19	0503010144	1/4" NUT		16
20	0503010143	1/4" SPRING WASHER		16
21	0503013758	1/4" X 1-1/2" BOLT		16
22	0513010754	SINGLE STANDARD CLAMP 22 MM - BLACK		16
23	0503036445	HYDRAULIC TUBE 402 PT12L X 3081 PT12L X 3657		07
24	0503036444	HYDRAULIC TUBE 404 PT10L X 3083 PT10L X 3657		01
25	0503036443	HYDRAULIC TUBE 433 PT22 X 3081 PT15 X 3670		02
26	0503036442	HYDRAULIC TUBE 386 PT28 X 3300 FG28 X 3922		02
27	0501313380	SUPPORT 100 X 33 X 3003		01
28	0541051016	SUPPORT ASSEMBLED DUCTS		01
28A	0501313441	DUCT SUPPORT		01
28B	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04


DRAWBAR ASSY

0541051002


Item	Code	Description	See page	QT
28C	0503010589	1/2" UNC SELF ADJUSTING NUT		04
29	0501313435	GUTTER 70 X 33 X 407		01
30	0501313434	GUTTER 70 X 33 X 195		01
31	0501311289	FIXER 2TB28		04
32	0501313432	CLAMP 124 X 30 X 6,30		04
33	0541051192	CONVEYOR BELT ASSEMBLY 1200/1085	16	01

DRAWBAR ASSY

0531057052




Item	Code	Description	See page	QT
01	0501217466	TRACTION BAR GUIDE		02
02	0501010276	BOLT		04
03	0503010012	1" SPRING WASHER		04
04	0501010059	1.5/8 NUT		04
05	0503030119	LOCK PIN		01
06	0511069471	PLOUGH SUPPORT		02
07	0501011075	PIN		02
08	0503030285	HITCH PIN CLIP		02
09	0531065020	3 POINTS DRAWBAR ASSY		01
10	0503030085	LOCK PIN		08
11	0521068018	UPPER AXLE		01
12	0521068015	UPPER AXLE		01
13	0521068013	UPPER AXLE		01
14	0503012809	2" CASTLE NUT		01
15	0503010833	10 X 90 SPRING PIN		01
16	0501213695	EJE 1.1/4 X 380 MM		02
17	0531063869	AXLE 50 X 245 MM WITH THREAD 2 UNS 10 FPP		01
18	0521068011	AXLE LOWER		02
19	0531057067	DRAWBAR ESTABILIZER ASSY	7	01
20	0501217367	LEFT SUPPORT BOX		01
21	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
22	0503010589	1/2" UNC SELF ADJUSTING NUT		04
23	0501217366	RIGHT BOX SUPPORT		01
24	0503019293	SCREW 1/2 UNC X 2 COVER G7 ZN		04
25	0501217467	3 POINT HEAD FIXING GUIDE GLOVE		04
26	0531057145	COMPLETE SAFETY LOCK AXIS		01
26A	0531064617	LOCK AXLE COUPLING		01
26B	0501217474	FLAT WASHER 38.50 X 70 X 6.30		02
26C	0513010701	LOCK PIN		01



Item	Code	Description	See page	QT
01	0531065026	HEAD HOSE STABILIZER		01
02	0531061935	CONDUCTOR ARTICULATOR		02
03	0503010237	3/8" X 1" BOLT		03
04	0503010025	3/8 SPRING WASHER		03
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		03
06	0503010019	1/2" SPRING WASHER		03
07	0503012556	1/2" X 1" BOLT		03
08	0531061934	CONDUCTOR ARTICULATOR GUIDE		03
09	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
10	0503010589	1/2" UNC SELF ADJUSTING NUT		02
11	0531065130	HYDRAULIC HOSE ARTICULATOR		01

DRAWBAR ASSY

0541050997




Item	Code	Description	See page	QT
01	0531064571	TELESCOPIC HEADER 24/25		01
02	0531051649	HEADER LARGEST PULLEY		01
02A	0591018923	LARGER BODY HEADER PULLEY		01
02B	0551014862	NYLON PULLEY		02
03	0551014871	FLAT WASHER		06
04	0503010002	1800 GREASE FITTING		06
05	0591018925	AXLE BIGGER PULLEY		01
06	0503011105	SEAL RING		03
07	0591015449	AXLE LOCK HEADER		01
08	0503018754	NUT 1 - 8 UNC - 2B G8		02
09	0591015450	LOCK BODY GLOVE		02
10	0591018926	BODY LOCK BIGGER		01
11	0503031741	1.8" X 11.4" 0.3" TRACTION SPRING		01
12	0511054270	TENSIONER SPRING		01
12A	0511069520	TELESC LOCK SPRING TENSIONER		01
12B	0503010013	5/8 UNC G.5 ZN HEX NUT		02
13	0591015454	SPRING HITCH LOCK		01
14	0521011132	FLAT WASHER		02
15	0503010131	3/16" X 1.1/2" SPLIT PIN		02
16	0503011052	1.1/4" X 0.77" CASTLE NUT		03
17	0503010038	3/16" X 2" SPLIT PIN		03
18	0531060746	AXIS 278 TELESCOPIC HEADER		03
19	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		01
20	0591015457	CYLINDER GUIDE AXLE		01
21	0591018924	WHEEL BIGGEST SHAFT HEADER SIDE		02
22	0591018921	WASHER 63.5 X 39 X 6.30		04
23	0531051648	INTERNAL HEAD PULLEY		02
23A	0591018922	INTERNAL PULLEY BODY HEAD		01
23B	0551014862	NYLON PULLEY		02
24	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		02
25	0503010027	5/8 SPRING WASHER		03
26	0503010962	5/8" X 1-1/4" BOLT		01


DRAWBAR ASSY

0541050997


Item	Code	Description	See page	QT
27	0501210174	SPRING SUPPORT		01
28	0503010233	5/8" X 2-1/2" BOLT		01
29	0501011299	FLAT WASHER		01
30	0503010013	5/8 UNC G.5 ZN HEX NUT		01
31	0531060748	REST SUPPORT		01
32	0521059886	SEMI-ASSEMBLED REST	9	01
33	0531059899	PANTOGRAPHIC DRAWBAR	10	01
34	0531059876	CYLINDER HYDRAULIC	12	01
35	0531066463	BODY LOCKS WITH PIN		01
36	0531064951	SIDE LOCK AXIS 381		01
37	0503010290	SELF ADJUSTING 1.1/2" UNF NUT		01
38	0551012215	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0503010571	1/4" X 1.1/2" SPLIT PIN		02
02	0521010784	COUPLING SHAFT		01
03	0531060758	AXLE JUNCTION 25.4 X 150 WITH HANDLE		01
04	0503030085	LOCK PIN		02
05	0531060667	REST		01
06	0521010580	COUPLING SHAFT		01
07	0521012533	COUPLING SHAFT		01
08	0591016111	TUBE 80 X 80 X 9,52 X 600MM		01
09	0531061640	REST		01




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		03
02	0531060746	AXIS 278 TELESCOPIC HEADER		02
03	0531060792	AXIS 200 TELESCOPIC HEADER		01
04	0531065027	AXLE FIXER		01
05	0503011052	1.1/4" X 0.77" CASTLE NUT		02
06	0503010038	3/16" X 2" SPLIT PIN		03
07	0591013764	FLAT WASHER 39 X 65 X 8,00 ZN		02
08	0531063225	LOWER ARM PANTOGRAPHIC HEAD		01
09	0531063226	UPPER ARM PANTOGRAPHIC HEAD		01
10	0531063829	SUPPORT WITH EAR PANTOGRAPHIC HEAD		01
11	0503010012	1" SPRING WASHER		08
12	0503012182	1" NUT		08
13	0531063828	HEAD HITCH		01
14	0501010171	BOLT 1 UNC X 3.1/2 C S G.5		08
15	0501219817	PROTECTION BODY PANTOGRAPHIC HEADER		01
16	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
17	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
18	0503010337	NUT 5/16 UNC G.5 ZN		01
19	0531059875	CYLINDER HYDRAULIC	11	01



Item	Code	Description	See page	QT
01	0531061424	PANTOGRAPHIC HEAD CYLINDER ROD		01
02	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
03	0503010345	2-218 N 3006-9B O'RING		01
04	0502010382	5" END CAP		01
05	0581010353	RING SUPPORT		01
06	0503018026	GASKET 1870-2000-375 B POLYMAX		01
07	0503011453	O'RING		02
08	0503018152	O'RING		02
09	0503018024	RING BS OD050805200171D-BR		01
10	0503018025	RING GUIDE W2-2250-750		01
11	0581010354	PISTON		01
12	0503018150	RING GUIDE W2-5000-984 (4528)		01
13	0503018151	RING BS		02
14	0503010039	D-2000 SCRAPER RING		01
15	0531066083	PANTOGRAPHIC HEADER CYLINDER CASE		01




Item	Code	Description	See page	QT
01	0531065723	MINOR CYLINDER GUIDE		01
02	0591013120	BODY STEM 38.10 X 280		01
03	0502012837	PISTON		01
04	0581010668	RING SUPPORT		01
05	0502010471	63,50 MOBILE CAP		01
06	0503018005	RING		01
07	0503011109	O'RING 2-119 N 3006 9B		01
08	0503018004	RING		01
09	0503018003	GASKET		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018163	BACK-UP RING		02
12	0503018162	O'RING		02
13	0531066084	CASE 63,50 X 285MM		01




Item	Code	Description	See page	QT
01	0531066609	REAR DRAWBAR		01
02	0591015434	NYLON ADJUSTABLE BACK HEAD		04
03	0591015533	ADJUSTMENT SUPPORT		08
04	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		24
05	0503010019	1/2" SPRING WASHER		48
06	0503010002	1800 GREASE FITTING		08
07	0501010276	BOLT		12
08	0503010012	1" SPRING WASHER		14
09	0503012182	1" NUT		14
10	0591015435	NYLON ADJUSTMENT REGULATOR GUIDE		04
11	0591015432	HEAD ADJUSTMENT SUPPORT PLATE		04
12	0591015431	HEADER ADJUSTMENT SUPPORT		04
13	0503011401	1/2" X 3/4" BOLT		24
14	0531062795	PULL ROD 1 UNC 8 FPP X 510		02
15	0531059893	SIDE ARM LATCH ASSEMBLY	14	01
16	0501312901	LARGER CALCO HEADER		04

SIDE ARM LATCH ASSEMBLY


0531059893



Item	Code	Description	See page	QT
01	0591015326	LATERAL FRAME LOCK		02
02	0531061411	STABILIZER ASSY LOCK ARM		01
03	0591015327	AXLE JUNCTION		02
04	0591015328	SPACING GLOVE		04
05	0591015329	CYLINDER GUIDE AXLE		01
06	0591015330	WASHER SUPPORT		02
07	0591015332	AXLE JUNCTION LOCK		03
08	0503019522	HEX NUT		04
09	0501010322	20,50 X 46 X 4,00 ZN FLAT WASHER		10
10	0503010880	501032 CLAMPING RING (FOR AXLE)		05
11	0531061445	TOP PLATE WITH GLOVE		02
12	0503010019	1/2" SPRING WASHER		02
13	0591015341	GLOVE SUPPORT		04
14	0591015340	WASHER SUPPORT GUIDE AXIS		01
15	0511016281	3/4" X 8" BOLT		02
16	0501210625	SUPPORT GLOVE		02
17	0503013776	BOLT 1/2 UNC X 7/8 C S G.5 ZN		02
18	0501013475	BOLT 3/4" UNC X 7.1/2" C S G.5 ZN		02
19	0531059877	CYLINDER HYDRAULIC 44,45 X 85,70 X 398 X 93	15	01




Item	Code	Description	See page	QT
01	0591015343	EXTENSOR 44,45 X 280MM		01
02	0503010063	1" SELF-ALIGNING NUT		01
03	0502010843	1.8" X 3.4" PISTON		01
04	0503010042	2-214 N 3006-9B O'RING		01
05	0503010170	PACKING 3120 2750		02
06	0503010948	W4-3346-590 PK RING G.E		01
07	0502040747	32.54 CLEVIS CLAMP		01
08	0503011094	BOLT 3/8" UNC X 2" C C S I 12.9		01
09	0503010025	3/8 SPRING WASHER		01
10	0503010026	3/8" NUT		01
11	0502010781	RING SUPPORT		01
12	0503010949	W2-2000-500 PK RING G.E		01
13	0503010990	GASKET		01
14	0503010761	D-1750 SCRAPER RING		01
15	0503010976	2-336 N 3006-9B O'RING		01
16	0503011060	8-336 BACK-UP RING		01
17	0502010993	MOBILE LID		01
18	0531066085	CILINDER CASE 85,70 X 272		01




Item	Code	Description	See page	QT
01	0541051194	FRONT RAIL 1118 ASSY		01
01A	0531066749	SUPPORT FRONT 1085MM		01
01B	0531059091	MAT ROLLER 215MM		03
01BA	0501310150	AXIS FIXING HOSE GLOVE 280MM		01
01BB	0501310149	GLOVE 16,30 X 30 X 215MM		01
01BC	0503016739	SELF LOCKING HEX NUT WITH NYLON		02
01BD	0503010743	1/4" X 1-1/4" BOLT		02
02	0541051196	SUPPORT REAR 1223 ASSY		01
02A	0531066750	REAR SUPPORT 1200MM		01
02B	0531059091	MAT ROLLER 215MM		02
02BA	0501310150	AXIS FIXING HOSE GLOVE 280MM		01
02BB	0501310149	GLOVE 16,30 X 30 X 215MM		01
02BC	0503016739	SELF LOCKING HEX NUT WITH NYLON		02
02BD	0503010743	1/4" X 1-1/4" BOLT		02
03	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0501013519	FLAT WASHER		08
06	0501217333	ARTICULATOR AXLE 233		02
07	0531066424	GUTTER SUPPORT BASE		01
08	0501312866	ARTICULATOR AXLE 25.40 X 56.50		02
09	0531059935	CABLE GUIDE HEADER		02
09A	0501311320	CABLE GUIDE HEADER		01
09B	0503010519	1/4" X 5/8" BOLT		02
09C	0503010144	1/4" NUT		02
09D	0501311321	LOCK GUIDE CABLES		01
10	0501310233	GUTTER FIXING PLATE		04
11	0503011952	5/16" X 3/4" BOLT		12
12	0503013759	NUT		12
13	0501010694	FLAT WASHER 32,50 X 75 X 4,75		12
14	0501219996	SUPPORT 70 X 40 X 800		02
15	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
16	0503010027	5/8 SPRING WASHER		04


Item	Code	Description	See page	QT
17	0503010013	5/8 UNC G.5 ZN HEX NUT		04
18	0501010100	BOLT 5/8" UNC X 2 CS G.5 ZN		04
19	0501312861	FRONT SUPPORT MAT		02
20	0501312865	AXIS LOCK SUPPORT GUTTER		01



Item	Code	Description	See page	QT
01	0541050020	DOUBLE ROTATING DIVIDER	18	01
02	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
03	0503014371	M8 SPRING WASHER		02
04	0503011295	M 8 X 1,25 X 25 BOLT		02
05	0503063819	CARDAN 21Z 1.3/8 X 20Z 1.3/4		01
06	0541050680	DOUBLE PUMP MULTIPLIER	19	01
07	0541050774	DIVIDER VALVE	22	01
08	0541050762	SET OF COMMAND BLOCKS	23	01
09	0541050775	CYLINDER COMMANDER BLOCK	27	01
10	0541050773	BLOCK COMMAND	29	01
11	0501310425	GUTTER 55 X 50 X 460		01
12	0541052598	PASSAGE BLOCK ASSY	30	01
13	0541052592	TANK HEAT EXCHANGER	33	01




Item	Code	Description	See page	QT
01	0503019810	DOUBLE ROTATING DIVIDER		01
02	0503010237	3/8" X 1" BOLT		04
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
04	0503013357	3/8 SELF-ADJUSTING NUT		04
05	0513011034	ADAPTER TERMINAL MF R7/8 UNF ORING X MF TB12L		02
06	0513011687	ADAPTER TERMINAL MF R.1.1/16 UN ORING X MF TB12L		01




Item	Code	Description	See page	QT
01	0513010710	MULTIPLIER BOX		01
02	0501217531	REDUCTION BOX FLANGE		02
03	0503015140	M12 X 1,75 X 30 BOLT		08
04	0503015076	M12 SPRING WASHER		08
05	0521014188	FLAT WASHER		08
06	0513011013	BOLT ALLEN M14 X 2 X 25MM CCSI		08
07	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		04
08	0503011828	FLAT WASHER 13 X 24 X 2,00 ZN		04
09	0503010019	1/2" SPRING WASHER		04
10	0513010995	EXTERNAL GROOVED GLOVE 1.1/4 - Z14 X INTERNAL 7/8 Z13 X 42MM		01
11	0503010880	501032 CLAMPING RING (FOR AXLE)		01
12	0541050014	HYDRAULIC PUMP	20	01
13	0541050681	HYDRAULIC PUMP	21	01

HYDRAULIC PUMP

0541050014




Item	Code	Description	See page	QT
01	0513010724	AXIAL PISTON HYDRAULIC PUMP 63CC - H		01
02	0513010832	ADAPTER TERMINAL MF R.1.5/16 UNF ORING X TB28		01
03	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		01
04	0513010826	KNEE TERMINAL 90G MF TB15 X FG TB15		01
05	0513011689	ADAPTER TERMINAL R.7/16 ORING X TB10L		01
06	0541051231	NIPLE WITH ROTATING DUCT		01




Item	Code	Description	See page	QT
01	0513010739	GEAR HYDRAULIC PUMP 34CC - BD		01
02	0513011178	ADAPTER TERMINAL MF R.1.5/16 UNF ORING X TB22		01
03	0513010832	ADAPTER TERMINAL MF R.1.5/16 UNF ORING X TB28		01

DIVIDER VALVE


0541050774




Item	Code	Description	See page	QT
01	0503016227	FLOW DIVIDING VALVE		01
02	0513011035	ADAPTER TERMINAL MF R1.1/16 UNF		02
03	0513011916	TERMINAL ADAPTER R.3/4 BSP X MF TB22		01
04	0503010337	NUT 5/16 UNC G.5 ZN		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503011332	5/16" X 2-3/4" BOLT		02
07	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
08	0503019382	FILTER PDA 40 MICRA CASAPPA HHQ00530		01
09	0513011915	TERMINAL ADAPTER R. 1.1/16 ORING X FG TB22		02




Item	Code	Description	See page	QT
01	0531059987	DRIVING BLOCK	24	01
02	0531059990	ROTATING DIVIDER	25	01
03	0513010828	TERMINAL KNEEL		03
04	0503015112	M10 X 1,5 X 30 BOLT		07
05	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0503010026	3/8" NUT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0501010984	10,50 X 27 X 3,00 FLAT WASHER		11
10	0503011828	FLAT WASHER 13 X 24 X 2,00 ZN		08
11	0503010025	3/8 SPRING WASHER		04
12	0503015075	M10 SPRING WASHER		07
13	0503010019	1/2" SPRING WASHER		04
14	0531059985	BLOCK HYDRAULIC COMMAND	26	01
15	0531066484	SUPPORT BLOCKS		01
16	0531066491	LIFTING DRIVE BLOCK SUPPORT		01
17	0503036405	HYDRAULIC TUBE FG28 X FG28 X 116		02
18	0503012183	SNC 3/4" ZIN 1K03097 NUT		04
19	0503010023	3/4" SPRING WASHER		04
20	0511017305	FLAT WASHER		08
21	0501010098	BOLT 3/4" UNC X 2 C S G.5 ZN		04




Item	Code	Description	See page	QT
01	0503063488	HYDRAULIC CONTROL BLOCK		01
02	0513011034	ADAPTER TERMINAL MF R7/8 UNF ORING X MF TB12L		12
03	0513010831	ADAPTER TERMINAL MF R.1.1/16		01




Item	Code	Description	See page	QT
01	0513010747	HYDRAULIC ROTATING DIVIDER		01
02	0513011034	ADAPTER TERMINAL MF R7/8 UNF ORING X MF TB12L		04
03	0513010832	ADAPTER TERMINAL MF R.1.5/16 UNF ORING X TB28		01




Item	Code	Description	See page	QT
01	0513010721	HYDRAULIC CONTROL BLOCK		01
02	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		02
03	0513010832	ADAPTER TERMINAL MF R.1.5/16 UNF ORING X TB28		04
04	0513010839	ADAPTER TERMINAL MF R.1/4 BSP ORING X MF TB10L		01
05	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		02
06	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		02




Item	Code	Description	See page	QT
01	0531059986	DRIVE COMMAND BLOCK	28	01
02	0503010172	M10 X 1,5 X 25 BOLT		04
03	0503015075	M10 SPRING WASHER		04
04	0501013518	FLAT WASHER		04
05	0501313063	COMMAND BLOCK SUPPORT		01
06	0503010023	3/4" SPRING WASHER		04
07	0503012183	SNC 3/4" ZIN 1K03097 NUT		04
08	0511015255	FLAT WASHER		08
09	0503011196	3/4" X 2-1/4" BOLT		04




Item	Code	Description	See page	QT
01	0513010678	CYLINDER ACTIVATION CONTROL BLOCK		01
02	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		11
03	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		03
04	0513011034	ADAPTER TERMINAL MF R7/8 UNF ORING X MF TB12L		02




Item	Code	Description	See page	QT
01	0513010676	COMMAND BLOCK		01
02	0513011857	ADAPTER TERMINAL 7/8 UNF ORING X MF TB22		04




Item	Code	Description	See page	QT
01	0503010461	BOLT 1/4" UNC X 1" C S G.2 ZN		02
02	0503010143	1/4" SPRING WASHER		04
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0501312370	BLOCK SUPPORT		01
08	0503010144	1/4" NUT		02
09	0503011194	BOLT 1/4 UNC X 2.1/2 CS G.2 ZN		02
10	0531059989	PASSAGE BLOCK	31	01
11	0541052594	4-WAY PASS BLOCK	32	01




Item	Code	Description	See page	QT
01	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		16
02	0513011676	WALKWAY BLOCK 06 WAY		01
03	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		01
04	0503063968	THREADED PLUG 3/4 UNF		02




Item	Code	Description	See page	QT
01	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		09
02	0513010674	DISTRIBUTOR BLOCK 4 WAYS		01
03	0513012129	TERMINAL ADAPTER		01
04	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		02




Item	Code	Description	See page	QT
01	0501214601	RIGHT SUPPORT 180L OIL RESERVOIR		01
02	0503010019	1/2" SPRING WASHER		08
03	0503011828	FLAT WASHER 13 X 24 X 2,00 ZN		16
04	0501214600	LEFT SUPPORT 180L OIL RESERVOIR		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		08
07	0501010125	3/4" X 2-1/2" BOLT		08
08	0503011075	3/4 UNC LOCK NUT		08
09	0501010322	20,50 X 46 X 4,00 ZN FLAT WASHER		08
10	0531059117	FULL HEAD HOSE STABILIZER	34	01
11	0541050012	RADIATOR EQUIPMENT	35	01
12	0541052593	COMPLETE 180L TANK	36	01




Item	Code	Description	See page	QT
01	0531061934	CONDUCTOR ARTICULATOR GUIDE		01
02	0531061935	CONDUCTOR ARTICULATOR		01
03	0503010237	3/8" X 1" BOLT		01
04	0503010025	3/8 SPRING WASHER		01
05	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
06	0503010019	1/2" SPRING WASHER		01
07	0503012556	1/2" X 1" BOLT		01




Item	Code	Description	See page	QT
01	0501010694	FLAT WASHER 32,50 X 75 X 4,75		04
02	0501013518	FLAT WASHER		16
03	0503010025	3/8 SPRING WASHER		10
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
05	0503019952	RUBBER BUSHING 14 X 40 X 40		06
06	0503011268	3/8" X 2-1/2" BOLT		06
07	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		04
08	0503010026	3/8" NUT		10
09	0571016789	PRISONER 3/8 UNC X 5/16 UNC X 65		04
10	0501218150	HEAT EXCHANGER SUPPORT		01
11	0591012708	CANVAS RADIATOR PROTECTION		01
12	0541050011	HEAT EXCHANGER		01
12A	0503063086	HEAT EXCHANGER		01
12B	0513010820	ADAPTER TERMINAL MF 1 BSP X TB35		01
12C	0513011688	ADAPTER TERMINAL MF 1 BSP X TB28		01



Item	Code	Description	See page	QT
01	0503063771	180 LITER TANK		01
02	0513010698	RETURN FILTER IN TANK 310 LITERS		01
03	0503063547	VISOR LEVEL		01
04	0503063773	SUPPLY NOZZLE		01
05	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0513010029	BALL VALVE 2 NPT 11.5 FPP		01
08	0513010344	SHOCK ABSORBER/VIBRATION CUSHION		04
09	0571011721	FLAT WASHER 40 X 13.50 X 3.00		08
10	0503015076	M12 SPRING WASHER		08
11	0503011334	3/8 UNC X 3/4 CS G.5 ZN BOLT		03
12	0503010025	3/8 SPRING WASHER		03
13	0503015406	SUCTION FILTER		01
14	0503063968	THREADED PLUG 3/4 UNF		01
15	0513011209	ORIGINAL ER.1.1/2 BSP ADAPTER TERMINAL		01
16	0513010819	ADAPTER TERMINAL MF R.3/4 UNF		02
17	0513011030	FILLING NOZZLE WITH AIR FILTER AND PRESSURIZATION		01
18	0503014250	BALL REGISTRATION 1. 1/4		01
19	0513010741	SUCTION FILTER 90 LITERS		01
20	0501312422	CONNECTOR		01
21	0513011926	TERMINAL ADAPTER R.1.5/8 UNF ORING X MF TB15		01
22	0501315888	HOSE SPOT 1 X R.1.1/4 BSP		01




Item	Code	Description	See page	QT
01	0521057793	KNEECAP WITH RIGHT EXTENSION AXLE	38	01
02	0531061434	SIDE EXTENSOR EAR		01
03	0571019949	JUNCTION SHAFT		01
04	0503030119	LOCK PIN		01
05	0531064572	FRENCH HAND 24/25		01
06	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521062617	NUT FIXER		01
02	0531060778	EXTENSION AXLE 466 WITH DRAG		01
03	0561019879	LOCK ATTACHMENT BAR		01
04	0503010002	1800 GREASE FITTING		02

STABILIZER


0531056065




Item	Code	Description	See page	QT
01	0531053738	STABILIZER EXTENDER	40	01
02	0531064461	PROLONGER		02
03	0501015348	1-1/4" X 3-3/4" BOLT		02
04	0503010070	SPRING WASHER		02
05	0503013026	1.1/4" CASTLE NUT		02




Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0531063229	LABEL WITH LEFT EXTENDER		01
03	0531063230	LABEL WITH RIGHT EXTENDER		01
04	0501211865	LABEL FIXER		02
05	0503011052	1.1/4" X 0.77" CASTLE NUT		02
06	0501061056	1.1/2" RIGHT LOCK-NUT		01
07	0503010002	1800 GREASE FITTING		02
08	0503010571	1/4" X 1.1/2" SPLIT PIN		02



Item	Code	Description	See page	QT
01	0501311404	SUPPORT		01
02	0503013029	3/8" X 3/4" BOLT		05
03	0503013357	3/8 SELF-ADJUSTING NUT		05
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		05




Item	Code	Description	See page	QT
01	0501312936	CHUTE 4S X 50 X 30 X 1950		01
02	0503013029	3/8" X 3/4" BOLT		04
03	0503013357	3/8 SELF-ADJUSTING NUT		04
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04




Item	Code	Description	See page	QT
01	0503013029	3/8" X 3/4" BOLT		04
02	0503013357	3/8 SELF-ADJUSTING NUT		04
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
04	0501311956	GUTTER 4S 50 X 30 X 2250 CENTER		01

BOX MODULES


0541050552




Item	Code	Description	See page	QT
01	0503019412	RIVET SCREW INTERNAL		08
02	0503010143	1/4" SPRING WASHER		08
03	0503013813	1/4" UNC X 7/8" BOLT		04
04	0503010743	1/4" X 1-1/4" BOLT		04
05	0501312916	MODULE BOX BASE		01
06	0541050593	MODULE BOX COVER WITH BOLT		01




Item	Code	Description	See page	QT
01	0501311680	LEFT GUIDE TRIGGER		01
02	0501311682	NYLON GLOVE 70		02
03	0503010140	1/8" X 3/4" SPLIT PIN		02
04	0501311681	FIXING PIN		02




Item	Code	Description	See page	QT
01	0501311679	RIGHT TRIGGER GUIDE		01
02	0501311682	NYLON GLOVE 70		02
03	0501311681	FIXING PIN		02
04	0503010140	1/8" X 3/4" SPLIT PIN		02




Item	Code	Description	See page	QT
01	0501219250	SENSOR FIXATION		01
02	0503010722	3/16" X 5/8" BOLT		02
03	0503015013	3/16 SELF ADJUSTING NUT NC 1K02881		02
04	0501013518	FLAT WASHER		02
05	0503013357	3/8 SELF-ADJUSTING NUT		02
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0501317075	SENSOR SUPPORT		01
02	0503015013	3/16 SELF ADJUSTING NUT NC 1K02881		02
03	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02




Item	Code	Description	See page	QT
01	0501317074	SENSOR SUPPORT		01
02	0503015013	3/16 SELF ADJUSTING NUT NC 1K02881		02
03	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02




Item	Code	Description	See page	QT
01	0513010813	CONTROL PANEL BLOCK SHT BCE 5375.1		01
02	0513010994	LIGHTHOUSE HARNESS LED LANTERN 12 METERS BCE 5403.1		01
03	0513010975	LIGHTHOUSE EXTENSION 3 HOLES ECB 5381.9		02
04	0503019926	BLOCK WHIP WITH ECB 4555.9		01
05	0503019291	SUPPORT SENSOR		03
06	0501217647	SHT PANEL FIXING PLATE		01
07	0503016234	FIXING VACUUM TRIMBLE 91357-AG		01
08	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
09	0503018829	NYLON CLAMP 7,8 X 1,8 X 390 MM		20
10	0503019902	NYLON CLAMP 7,8X1,8X225 MM		80
11	0503019924	BLOCK WHIP WITH ECB TREAT 4554.2		01
12	0513011205	HEAT EXCHANGER SWITCH PANEL		01
13	0513011204	TRACTOR POWER SWITCH CABLE 5463.5		01
14	0503019307	CABLE TRACTOR HEADLIGHT		01
15	0503062594	IMPLEMENT SWITCH CABLE (EXTENSION)		01
16	0503019305	WHIP		01
17	0513010191	BOLT		03




01




02




03




04



05




06



07


Item	Code	Description	See page	QT
01	0541052105	HOSE SET DKO APT	52	01
02	0541052106	DKO LOCK HOSE SET	53	01
03	0541052107	DKO PANTOGRAPHIC HOSE SET	54	01
04	0541052108	HOSE SET DKO AB/FC	55	01
05	0541052109	LEVANTE HOSE SET DKO	56	01
06	0541052110	HOSE SET DKO ARTICULATION	57	01
07	0541052111	DKO TURBINE HOSE SET	58	01




Item	Code	Description	See page	QT
01	0501083069	HOSE 3/4 X 2100 FG TB22 X FG TB22 C90 TB22		01
02	0501083070	HOSE 1 X 3200 FG TB28		01
03	0501082872	HOSE 3/4 X 2800 FG TB22 X FG TB22 WITH SPRING		01
04	0501082873	HOSE 3/4 X 4500 FG TB22 X FG C90 TB22		02
05	0501082874	HOSE 3/4 X 1800 FG TB22 X FG TB22		01
06	0501082875	HOSE 3/4 X 2400 FG TB22 X FG C90 TB22		01
07	0501082876	HOSE 1/2 X 4100 FG TB15 X FG C90 TB15		02
08	0501082877	HOSE 1/2 X 1700 FG TB15 X FG C90 TB15		02
09	0501082878	HOSE 1/2 X 6700 FG TB15 X FG C90 TB15		01
10	0501082879	HOSE 1/2 X 6300 FG TB15 X FG C90 TB15		01
11	0501082880	HOSE 1/2 X 1800 FG TB15 X FG C90 TB15		02

DKO LOCK HOSE SET


0541052106




Item	Code	Description	See page	QT
01	0501082881	HOSE 3/8 X 1000 FG TB12L X FG C90 TB12L		03
02	0501082882	HOSE 3/8 X 900 FG TB12L X FG C90 TB12L		01
03	0501082883	HOSE 3/8 X 470 FG TB12L X FG C90 TB12L		01
04	0501082884	HOSE 3/8 X 430 FG TB12L X FG C90 TB12L		01
05	0501083064	HOSE 3/8 X 4500 FG TB12L X FG TB12L		02




Item	Code	Description	See page	QT
01	0501082881	HOSE 3/8 X 1000 FG TB12L X FG C90 TB12L		02
02	0501082915	HOSE 3/8 X 4500 FG TB12L X FG C90 TB12L		02




Item	Code	Description	See page	QT
01	0501082945	HOSE 3/8 X 1200 FG TB12L X FG C90 TB12L		03
02	0501082957	HOSE 3/8 X 1300 FG TB12L X FG C90 TB12L		01
03	0501082899	HOSE 3/8 X 1100 FG TB12L X FG C90 TB12L		02




Item	Code	Description	See page	QT
01	0501082891	HOSE 3/8 X 3100 FG TB12L X FG TB		02
02	0501082892	HOSE 3/8 X 2700 FG TB12L X FG C90 TB12L		02
03	0501082893	HOSE 3/8 X 3000 FG TB12L X FG C90 TB12L		02
04	0501082986	HOSE 3/8 X 1400 FG TB12L X FG TB12L		02
05	0501082987	HOSE 3/8 X 1400 FG TB12L X FG C90 TB12L		02
06	0501082895	HOSE 3/8 X 510 FG TB12L X FG C90 TB12L		01
07	0501082883	HOSE 3/8 X 470 FG TB12L X FG C90 TB12L		01
08	0501082896	HOSE 3/8 X 410 FG TB12L X FG C90 TB12L		01
09	0501082897	HOSE 3/8 X 400 FG TB12L X FG C90 TB12L		01
10	0501083084	HOSE 3/8 X 3000		02




Item	Code	Description	See page	QT
01	0501082882	HOSE 3/8 X 900 FG TB12L X FG C90 TB12L		01
02	0501082898	HOSE 3/8 X 3300 FG TB12L X FG C90 TB12L		08
03	0501082899	HOSE 3/8 X 1100 FG TB12L X FG C90 TB12L		12
04	0501082900	HOSE 3/8 X 650 FG TB12L X FG C90 TB12L		02
05	0501082987	HOSE 3/8 X 1400 FG TB12L X FG C90 TB12L		04
06	0501083072	HOSE 3/8 X 1200 FG TB12L X FG C90 LG TB12L		01
07	0501082945	HOSE 3/8 X 1200 FG TB12L X FG C90 TB12L		02
08	0501083073	HOSE 1/2 X 1350 FG TB15 X FG C90 TB15		01
09	0501082904	HOSE 1/2 X 900 FG TB15 X FG C90 TB15		01
10	0501083074	HOSE 1/2 X 700 FG TB15 X FG C90 TB15		01
11	0501082948	HOSE 3/8 X 1100 FG TB12L X FG TB12L		02
12	0501082986	HOSE 3/8 X 1400 FG TB12L X FG TB12L		01




Item	Code	Description	See page	QT
01	0501083079	HOSE 3/8 X 4000 FG TB12L X FG C90 TB12L		02
02	0501082907	HOSE 3/8 X 3800 FG TB12L X FG C90 TB12L		02
03	0501082908	HOSE 3/8 X 2200 FG TB12L X FG C90 TB12L		01
04	0501082909	HOSE 3/8 X 2100 FG TB12L X FG C90 TB12L		01
05	0501082910	HOSE 1/4 X 500 FG TB10L X FG C90 TB10L		01
06	0501083068	HOSE 1/2 X 3000		02
07	0501083075	HOSE 1/4 X 6500 FG TB10L X FG C90 TB10L		01
08	0501083085	HOSE 1 X 6400 FG TB28 X FG TB28		01
09	0501082912	HOSE 1 X 6000 FG TB28 X FG C90 TB28		01
10	0501082982	HOSE 1.1/4 X 1100 FG TB35 X FG TB35		01
11	0501082915	HOSE 3/8 X 4500 FG TB12L X FG C90 TB12L		01
12	0501083078	HOSE 1 X 5200 FG TB28 X FG TB28		01
13	0501082917	HOSE 2 X 1400		01
14	0501082918	HOSE 1/4 X 500 FG TB10L X FG TB10L		01
15	0501082919	HOSE 1/2 X 500 FG TB15 X FG TB15		02
16	0501082893	HOSE 3/8 X 3000 FG TB12L X FG C90 TB12L		01




Item	Code	Description	See page	QT
01	0503064488	KIT ISO 6C 24L 45/50		01
01A	0503019526	CONTROL MODULE ISO6 6CH ADV		01
01B	0503019384	CABLE CTRL MASTER MODULE		01
01C	0503015209	MODULES WSMB 18L ISOBUS 4679811100S1		02
01D	0503015210	WSMB ISOBUS 467981200 MODULE CABLE		02
01E	0503015071	CONNECTOR		01
01F	0503016323	CABLE ASSY		01
01G	0503017443	ANTENNA GPS PM 400		01
01H	0503015218	SENSOR FOTOELE PM 400		24
01I	0503018932	FLOW FERTILIZER SENSOR		24
01J	0503064503	CABLE ISO 6C 24L 45/50		01
01K	0503017031	CLEAN BRUSH		01
02	0521056496	MOTOR EMD 80 WITH BLOCK BLFP2618	60	06
03	0503018775	MAGNETIC ACTUATOR LH7.4.000091		01
04	0503018774	MAGNETIC SENSOR		01
05	0521054490	FLOW DIVIDING VALVE ASSY	61	01
06	0503013100	NYLON CLAMP 4,8 X 1,3 X 200 MM		120
07	0503016033	4.8 X 1.3 X 300 MM NYLON CLAMP		360
08	0581014681	SLEEVE		24
09	0503010246	CLAMP		48




Item	Code	Description	See page	QT
01	0513010049	MOTOR OMP X 80 EMD - 11185907		01
02	0503018769	MOTOR SPEED SENSOR		01
03	0503010045	O'RING		02
04	0503019320	VALVE		01
05	0501010590	NIPPLE		02




Item	Code	Description	See page	QT
01	0503016227	FLOW DIVIDING VALVE		01
02	0503013917	O`RING 2-224		03
03	0571013917	7/8\"NF X 1.1/16 UNF NIPPLE		03




Item	Code	Description	See page	QT
01	0503035133	ADHESIVE LABEL USAP 3200 (192 X 437)	08	
02	0503034782	LABEL ADHESIVE LOGO SMALLER TATU (03 MOUTHS)	08	
03	0503035135	ADHESIVE LABEL USAP 3200 (185 X 320)	04	
04	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)	04	
05	0503035134	ADHESIVE LABEL USAP 3200 (190 X 613)	02	
06	0503034983	LOGO TATU MARCHESAN ADHESIVE LABEL 190 X 613	08	
07	0503035136	ADHESIVE LABEL USAP 3200 (170 X 820)	03	
08	0503035137	ADHESIVE LABEL USAP 3200 (165 X 850)	03	
09	0503034970	LOGO TATU MARCHESAN (CSC) 155 X 1120	03	
10	0503034971	ADHESIVE LABEL LOGO TATU MARCHESAN (CSC) 150 X 1130	03	
11	0503034338	ADHESIVE LABEL	02	
12	0503035445	ADHESIVE LABEL LEVER BLUE HANDLE	01	
13	0503035443	ADHESIVE LABEL LEVER RED HANDLE	01	
14	0503035442	ADHESIVE LABEL FLOATING LEVER	01	
15	0503033416	NUMBER 2 DECAL	02	
16	0503033419	NUMBER 5 DECAL	02	
17	0503031565	CAUTION TRANSPORTATION DECAL	02	
18	0503031428	READ MANUAL DECAL	01	
19	0503031425	ATTENTION CARRYING-WHEEL LOCK DECAL	02	
20	0503034078	LIFTING POINTS DECAL	02	
21	0503031087	AUTO CONTROL APPROVED DECAL	01	
22	0503035316	LUBRICATED POINTS DECAL	04	
23	0503031546	P2 FERTILIZER CHART DECAL	02	
24	0503034249	PLANTERS TABLE DECAL	02	
25	0503035494	ADHESIVE LABEL LEVER BLACK HANDLE	01	
26	0503033981	PRESSURE FREE RETAINER FOR TANK DECAL	03	




Item	Code	Description	See page	QT
01	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
02	0503010267	NYLON CLAMP 3,60 X 1,3 X 155 MM		01
03	0503010337	NUT 5/16 UNC G.5 ZN		01
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
05	0503060100	SUPPORT INSTRUCTION MANUAL		01
06	0511034540	BAG WITH INSTRUCTION MANUAL		01




Item	Code	Description	See page	QT
01	0502011195	ADJUSTMENT NUT BODY		01
02	0503010002	1800 GREASE FITTING		02
03	0551013654	SPINDLE R.1.1 / 4 X R.1.1 / 2 RIGHT X 165		01
04	0502040747	32.54 CLEVIS CLAMP		01
05	0551013653	SPINDLE R.1.1 / 4 X LEFT X.1.1 / 2 X 165		01
06	0503011094	BOLT 3/8" UNC X 2" C C S I 12.9		01
07	0503010026	3/8" NUT		01
08	0503011443	SPRING WASHER 3/8"		01
09	0501061056	1.1/2" RIGHT LOCK-NUT		01
10	0531062137	SIDE FERTILIZER BOX EXTENSOR		01
11	0521010779	31.75 X 95 COUPLING SHAFT		01
12	0503010571	1/4" X 1.1/2" SPLIT PIN		01




Item	Code	Description	See page	QT
01	0502040080	FLANGE NUT R.2.1/2" UN		01
02	0503010002	1800 GREASE FITTING		01
03	0531061664	LOCK AXIS		01




Item	Code	Description	See page	QT
01	0531056304	RIGHT SIDE HOPPER 10 10 MOUTHS ALPHA	67	01
02	0521051407	FERTILIZER HOPPER FIXER	74	20
03	0531050918	TOP SUPPORT MOUNTED LIFT EXTENSOR	75	03
04	0503063509	COMPLETE SILO 05 MOUTH 900L		02




Item	Code	Description	See page	QT
01	0531064566	SILO SUPPORT 10 SIDE BUCKETS		01
02	0531051685	CENTRAL BEARING SHAFT	68	02
03	0531051684	SIDE AXLE	69	02
04	0591018936	GLOVE		02
05	0503010002	1800 GREASE FITTING		02
06	0531055292	ALPHA FERTILIZER METERING	70	10
07	0501053788	3/4" SQUARE AXLE FASTENER	71	04
08	0503031527	AGRICULTURAL BEARING		04
09	0501218575	SQUARE AXIS 3/4 X 730MM WITH RELIEVE		01
10	0501218487	3/4 X 390 AXLE		04
11	0531057908	SLEEVE 1/4 X 2		06
11A	0502013069	SLEEVE 21 X 38 X 50		01
11B	0503010523	1/4" X 2" SPLIT PIN		01
12	0501218573	SQUARE AXIS 3/4 X 865MM WITH RELIEVE		02




Item	Code	Description	See page	QT
01	0591018964	MINOR ARTICULATED AXLE		01
02	0503010329	LOCK WASHER		01
03	0503010330	KM 9 LOCKNUT		02
04	0591015365	RING		02
05	0503013462	6005 2RS1 ROLLER BEARING		01
06	0503011373	0.4" X 1.1" SPRING PIN		01
07	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0591018938	LOCK		01
02	0591018963	BIGGER ARTICULATED AXLE		01
03	0503010329	LOCK WASHER		01
04	0503010330	KM 9 LOCKNUT		02
05	0591015365	RING		02
06	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		02
07	0503010589	1/2" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0503010025	3/8 SPRING WASHER		04
02	0503010026	3/8" NUT		04
03	0513010742	RETAINER 47 X 30 X 10 BRG 5285		01
04	0501214879	HORIZONTAL SEAL LID ALPHA FERTILIZER METERING		01
05	0503035799	ALPHA FERTILIZER DOSAGE NOZZLE		01
06	0503035831	ALPHA FERTILIZER METERING COLLECTOR		01
07	0531055273	ALPHA FERTILIZER METERING CLAMP	72	01
08	0513010692	ALLEN SCREW 1/4 UNC X 7/8 C FLAT SI INOX		04
09	0501011643	3/8 X 1"BOLT		04
10	0503035796	REAR FIXER ALPHA FERTILIZER METERING COLLECTOR		02
11	0513010695	ALLEN SCREW 1/4 UNC X 7/8 CCSI INOX		04
12	0531055376	TRANSMISSION ALPHA FERTILIZER METERING 73 HUB		01
13	0502013049	ALPHA FERTILIZER DOSAGE HOPPER		01
14	0502013048	FLANGE FIXER BODY ALPHA FERTILIZER METERING		01
15	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
15A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
15B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
16	0503035829	ADHESIVE LABEL LOGO TATU 38 X 28 X 0.30 ALPHA FERTILIZER METERING		01
17	0531055518	WORM THREAD ASSEMBLED		01
17A	0531064265	WORM THREAD		01
17B	0503035859	SUPPORT SLEEVE		01
18	0501111143	COATING WITH GUIDE ASSY SUPPLEMENTATION FERTILIZER METERING		01
18A	0501214951	FERTILIZER DOSAGE COATING		01
18B	0531055519	GUIDE ASSY WITH SUPPLEMENTATION		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0502013050	TRANSMISSION ALPHA FERTILIZER METERING HOPPER		01
02	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
03	0503011800	SEAL RING		02
04	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
05	0503016065	ROLLER BEARING		02
06	0501214237	TRANSMISSION HOPPER ALPHA FERTILIZER METERING SLEEVE		01
07	0503019373	6006 2RS1 NATIONAL BEARING		02
08	0503012858	502075 CLAMPING RING (FOR HOLE)		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01
10	0501214501	ALPHA FERTILIZER METERING LID LOCK AXIS		01
11	0501214238	SHAFT LOCK SLEEVE HOPPER TRANSMISSION ALPHA FERTILIZER METERING		01
12	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01




Item	Code	Description	See page	QT
01	0503012531	3/8" INOX NUT		01
02	0503012535	3/8" SPRING WASHER		01
03	0571019051	FIXER HOPPER WASHER		01
04	0503013751	3/8 UNC X 1.1/4 BOLT		01




Item	Code	Description	See page	QT
01	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		08
02	0503010811	5/8" UNF SELF ADJUSTING NUT		04
03	0503018814	SCREW 5/8 UNF X 5" G.5 CS ZN		04
04	0531062173	LIFT EXTENSOR TOP SUPPORT		01
05	1902011170	FIXER		02




Item	Code	Description	See page	QT
01	0531061615	MOBILE LADDER		01
02	0531062924	RIGHT STAIR SUPPORT		01
03	0531062925	RIGHT LOCK LADDER		01
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
08	0503010589	1/2" UNC SELF ADJUSTING NUT		02
09	0503010752	1/2" X 3.1/2" BOLT		02
10	0503010140	1/8" X 3/4" SPLIT PIN		01




Item	Code	Description	See page	QT
01	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		08
02	0501010937	13,50 X 28 X 3,00 FLAT WASHER		16
03	0503011336	1/2" HEX SELF ADJUSTING NUT		08
04	0503011957	NYLON HANDLE		02
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
07	0503010337	NUT 5/16 UNC G.5 ZN		04
08	0531064569	LEFT SIDE HANDRAIL		01
09	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		08
10	0503013357	3/8 SELF-ADJUSTING NUT		08
11	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
12	0531064568	RIGHT SIDE HANDRAIL		01
13	0531064570	SIDE PLATFORM 24/25		02
14	0503013389	5/8" SELF LOCKING NUT		04
15	0591011409	FLAT WASHER 16,5 X 35 X 3,00		04
16	0503010899	5/8 UNC X 2.1/4 BOLT		04
17	0531064567	HANDRAIL SUPPORT		01
18	0503010371	5/16" X 1" BOLT		02
19	0503013759	NUT		02



Item	Code	Description	See page	QT
01	0591016055	REAR HEADLIGHT SUPPORT		01
02	0503018738	HEADLIGHT		01
03	0503010337	NUT 5/16 UNC G.5 ZN		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		02




Item	Code	Description	See page	QT
01	0503013584	VACUUM GAUGE		01
02	0501210978	VACUOMETER SUPPORT		01




Item	Code	Description	See page	QT
01	0581010302	RING OF SUPPORT		01
02	0502012822	END CAP 4"		01
03	0503011061	8-342 BACK-UP RING		02
04	0503010338	2-342 N 3006-9B O'RING		02
05	0503017936	RING		01
06	0503017938	RING GUIDE		01
07	0503017937	GASKET		01
08	0503010761	D-1750 SCRAPER RING		01
09	0503018045	2-130 (AGEL) O'RING		04
10	0531064847	ROTATING CYLINDER ROD		01
11	0581010837	PISTON		01
12	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
13	0503015633	SELEMASTER SEALING		01
14	0503018029	O'RING 2-217 N 3006 90B		01
15	0503010002	1800 GREASE FITTING		01
16	0531066450	CILINDER CASE 101,60 X 497		01

SIDE SUPPORT

0541050557




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW	02	
02	0503017857	BOLT 5/8 UNF 4	08	
03	0503010811	5/8" UNF SELF ADJUSTING NUT	08	
04	0591017796	ARTICULATION AXIS 222 R.1.1 / 4 UNF	01	
05	0531064321	UNIVERSAL SUPPORT	01	
06	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION	02	
06A	0531061418	FIXING FLANGE HYDRAULIC CYLINDER WITHOUT LUBRICATION	01	
06B	0503019408	IGLIDUR GSM-4550-30 AUTO LUBRICANT GLOVE	01	
07	0503010019	1/2" SPRING WASHER	04	
08	0501111070	SIDE SUPPORT ARTICULATOR	01	
09	0503011075	3/4 UNC LOCK NUT	06	
10	0501010125	3/4" X 2-1/2" BOLT	06	
11	0591013172	31.75 X126 AXLE WITH 8 HOLE	02	
12	0591013173	CYLINDER INTERMEDIATE BUSHING	01	
13	0503012231	1/4" X 3" SPLIT PIN	02	
14	0501011544	3/4" X 1-1/2" BOLT	01	
15	0503010023	3/4" SPRING WASHER	01	
16	0591018408	PIN LOCK LINES	01	
17	0503030085	LOCK PIN	01	
18	0591019305	FLAT WASHER 20 X 60 X 4.75 WITH CUT OUT	01	
19	0501211496	GLOVE 16 X 25 X 27 WITH HOLE	01	
20	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	04	
21	0503010060	1/2 UNC G.5 ZN HEX NUT	04	
22	0501010942	3/8" X 1-1/4" BOLT	02	
23	0503013357	3/8 SELF-ADJUSTING NUT	02	
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
25	0541050570	SIDE ARTICULATION CYLINDER 82	01	
		44,45X85,70X291X657 DKO		




Item	Code	Description	See page	QT
01	0503010761	D-1750 SCRAPER RING		01
02	0571019711	RING SUPPORT		01
03	0571019709	DETACHABLE COVER		01
04	0503017936	RING		01
05	0503017938	RING GUIDE		01
06	0503017937	GASKET		01
07	0503017940	8-337 BACK-UP RING		02
08	0503017939	2-337 N 3006-9B O' RING		02
09	0503018045	2-130 (AGEL) O'RING		04
10	0511064408	FORK		01
11	0503010025	3/8 SPRING WASHER		01
12	0503011094	BOLT 3/8" UNC X 2" C C S I 12.9		01
13	0503010026	3/8" NUT		01
14	0503010042	2-214 N 3006-9B O'RING		01
15	0503010063	1" SELF-ALIGNING NUT		01
16	0571019710	1.7" X 3.4" PISTON		01
17	0503017935	RING		01
18	0503018144	RING		01
19	0591017818	EXTENDER 44.45 X 550		01
20	0531066446	CILINDER CASE 85.70 X 499		01

TURBINE SUCTION


0541050590




Item	Code	Description	See page	QT
01	0591018230	FAN 428		01
02	0513010047	1/2 NC HEXAGONAL FLANGED NUT		01
03	0501219835	BOX TURBINE SUCTION		01
04	0531065747	FRONT COVER TURBINE		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		14
06	0503010358	5/16" X 5/8" BOLT		09
07	0503013357	3/8 SELF-ADJUSTING NUT		02
08	0503010025	3/8 SPRING WASHER		02
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
10	0503062560	TUBE FOR METER CLOCK 730142		01
11	0511017907	1/8" BSPT X 6 PLUG		01
12	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
13	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
14	0503035611	SUCTION DUCT SEAL		01
15	0501219837	PLATE COVER TURBINE		01
16	0503010143	1/4" SPRING WASHER		02
17	0503010294	1/4" X 7/8" BOLT		02
18	0503035455	HYDRAULIC TURBINE SUCTION DUCT		01
19	0503010397	5/16" X 1-3/4" BOLT		05
20	0541050591	COMPLETE PLM ENGINE		01
20A	0513010038	ENGINE		01
20B	0513011890	TERMINAL M22 X 1.50 MF ADAPTER		02
21	0513011686	TERMINAL UNION FG TB12L X FG TB12L		01
22	0531059913	ANTI CAVITATION VALVE SET		01
22A	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
22B	0513011678	ADAPTER TERMINAL 3/4 UNF ORING X MF TB12L		02




Item	Code	Description	See page	QT
01	0531065307	SUPPORT RIGHT HOSE		01
02	0531065306	ARTICULATOR HOSE		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0503010025	3/8 SPRING WASHER		02
05	0503010237	3/8" X 1" BOLT		01
06	0503010849	3/8" X 1-1/2" BOLT		01
07	0503010026	3/8" NUT		01



Item	Code	Description	See page	QT
01	0531066590	AIR TUBE 10 OUTLETS		01
02	0503036366	SEALING AIR TUBE		02
03	0501312852	COVER AIR TUBE		02
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0503010237	3/8" X 1" BOLT		08



Item	Code	Description	See page	QT
01	0501312939	RIGHT SIDE SUPPORT		01
02	0501312940	SUPPORT PLATE DUCT		02
03	0501313845	RIGHT VERTICAL SUPPORT		01
04	0501313846	LEFT VERTICAL SUPPORT		01
05	0501311238	CLAMP UNION 112 X 30 X 6,30		05
06	0501311237	FIXER		05
07	0513010752	SINGLE STANDARD CLAMP 12 MM - BLACK		60
08	0513011685	TEE TERMINAL MF X MF X FG TB12L		04
09	0503036455	HYDRAULIC TUBE PT12L X PT12L X 3150		04
10	0503036454	HYDRAULIC TUBE PT12L X PT12L X 1530		02
11	0503036453	HYDRAULIC TUBE PT12L X FG12L X 1580		02
12	0501313844	SUPPORT 50 X 30 X 3060		01
13	0513011664	BOLT M6 X 1,00 X 80 - SXR6X80ZI		08
14	0513011665	BOLT M6 X 1,00 X 90 - SXR6X90ZI		07
15	0503010305	6,50 X 17 X 1,50 ZN FLAT WASHER		15
16	0503015110	M06 SPRING WASHER		15
17	0503014540	M6 NUT		15
18	0501010098	BOLT 3/4" UNC X 2 C S G.5 ZN		04
19	0503011075	3/4 UNC LOCK NUT		04
20	0503013776	BOLT 1/2 UNC X 7/8 C S G.5 ZN		02
21	0503010019	1/2" SPRING WASHER		02
22	0501013519	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0531066963	RIGHT SIDE CARRYING-WHEEL FRAME		01
02	0501214463	SIDE WHEEL PULLEY		06
03	0503014559	ROLLER BEARING		02
04	0503010095	SEAL		01
05	0501213909	WHEELED HUB COVER		01
06	0502040080	FLANGE NUT R.2.1/2" UN		01
07	0503010002	1800 GREASE FITTING		13
08	0501213917	ADJUSTMENT WASHER		01
09	0503012213	1/4" X 4" SPLIT PIN		01
10	0531064113	SIDE WHEEL TOWER		01
11	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
13	0501214462	NYLON PULLEY BUSHING		12
14	0501214303	WHEEL CHAIN		06
15	0531064110	PULLEY LOCK AXLE		06
16	0503010834	1/2 X 1 BOLT		06
17	0503010019	1/2" SPRING WASHER		06
18	0591017921	BRONZE GLOVE 90.5 X 115 X 91		02
19	0501214460	AXLE 1.1/2 X 140MM		01
20	0503010390	SEAL RING		02
21	0531055358	COMPLETE SIDE CYLINDER BEARING	88	02
22	0531055357	LOCK PIN SET	89	02
23	0501214302	ADJUSTMENT COVER PLATE		06
24	0503034377	3/8 UNC X 3/4 BOLT		36
25	0503010025	3/8 SPRING WASHER		36
26	0501017065	FLAT WASHER		06
27	0503011255	3/4" LOCK NUT		06
28	0501216430	ADJUSTING COVER CALCO		06
29	0531059818	HYDRAULIC RIGHT CYLINDER	90	01
30	0541050188	DOUBLE SIDE WHEELED TIRE	91	01
31	0541050195	MOUNTED LEFT WHEEL	93	01
32	0541050196	MOUNTED RIGHT WHEEL	94	01



USAP 3200 AP SUPREMA - FRAME 12820
DOUBLE RIGHT WHEEL WHEELS SMALLER TIRE 500/50

Page 87
0541051683


Item	Code	Description	See page	QT
33	0503012623	3/8" X 1-1/2" BOLT		01
34	0503010208	HEX NUT 3/8 UNF G.5 ZN		01
35	0501311048	BEATER AXLE 230		01
36	0531057693	HOSE SUPPORT	84	01




Item	Code	Description	See page	QT
01	0501111135	BIGGER BEARING CYLINDER SUPPORT WITHOUT LUBRICATION		01
01A	0531064111	LARGER FIXING FLANGE HYDRAULIC CYLIND		01
01B	0503019408	IGLIDUR GSM-4550-30 AUTO LUBRICANT GLOVE		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
03	0503010589	1/2" UNC SELF ADJUSTING NUT		02

LOCK PIN SET


0531055357




Item	Code	Description	See page	QT
01	0591016056	LOCK AXLE SUPPORT		01
02	0531061626	38 X 308 JUNCTION AXLE WITH HANDLE		02
03	0503030119	LOCK PIN		02
04	0503010834	1/2 X 1 BOLT		01
05	0503010019	1/2" SPRING WASHER		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0503010042	2-214 N 3006-9B O'RING		01
02	0503010063	1" SELF-ALIGNING NUT		01
03	0503010761	D-1750 SCRAPER RING		01
04	0571019710	1.7" X 3.4" PISTON		01
05	0503017935	RING		01
06	0503018144	RING		01
07	0571019711	RING SUPPORT		01
08	0571019709	DETACHABLE COVER		01
09	0503017936	RING		01
10	0503017938	RING GUIDE		01
11	0503017937	GASKET		01
12	0503017940	8-337 BACK-UP RING		02
13	0503017939	2-337 N 3006-9B O' RING		02
14	0503018045	2-130 (AGEL) O'RING		04
15	0531064358	ROD 1.3/4 X 745MM		01
16	0531066041	RIGHT CYLINDER CASE		01




Item	Code	Description	See page	QT
01	0531064278	DOUBLE SIDE WHEEL SUPPORT		01
02	0503019246	BOLT		02
03	0503011075	3/4 UNC LOCK NUT		02
04	0531061575	BEARING		02
05	0501111142	MINOR MOUNTED CROSS		01
06	0503010019	1/2" SPRING WASHER		12
07	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		12
08	0501213743	LOCK AXLE		01
09	0501213742	SUPPORT WASHER		01
10	0503010953	BOLT 1 UNC X 2 C S G.5 ZN		01
11	0503010012	1" SPRING WASHER		01
12	0501213744	SINGLE ARM WHEEL AXLE		01
13	0501214898	DOUBLE SIDE WHEEL AXLE		01
14	0541050193	WHEEL COMPLETE BOX	92	02




Item	Code	Description	See page	QT
01	0503010050	SEAL 00085-B		01
02	0503010002	1800 GREASE FITTING		01
03	0541013225	WHEEL HUB LID		01
04	0503011444	SPRING WASHER 5/16"		06
05	0503010240	BOLT		06
06	0502040080	FLANGE NUT R.2.1/2" UN		01
07	0503011345	1/4" X 3.1/2" SPLIT PIN		01
08	1882970002	GREASE		01
09	0501111223	BOX ROUND WITH SCREW		01
09A	0501213765	WHEEL BOX		01
09AA	1902040522	WHEEL BOX		01
09B	0503014048	HEX NUT M22X1,5" CH32X33,5		08
09C	0503810007	WHEEL BOLT		08
10	0503013633	BEARING 33287/33462		01
11	0503013496	3982/3920 ROLLER BEARING		01




Item	Code	Description	See page	QT
01	0513010700	TIRE 500-50-17 FLOTATION T422 I1 18PR TECH SHEET		01
02	0503013999	VALVE 16MM AGR		01
03	0503036301	RIM 16 X 17		01




Item	Code	Description	See page	QT
01	0513010700	TIRE 500-50-17 FLOTATION T422 I1 18PR TECH SHEET		01
02	0503013999	VALVE 16MM AGR		01
03	0503036301	RIM 16 X 17		01




Item	Code	Description	See page	QT
01	0501216689	FIXER BODY		01
02	0501010942	3/8" X 1-1/4" BOLT		02
03	0503013357	3/8 SELF-ADJUSTING NUT		02
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
05	0501317157	FERTILIZER CONDUCTOR CLAMP		01
06	0501317158	FERTILIZER DISTRIBUTOR TUBE		01




Item	Code	Description	See page	QT
01	0503031076	2" HOSE CLAMP		01
02	0503036269	FERTILIZER SENSOR CONNECTION		01
03	0501317159	SLEEVE SENSOR CONNECTION		01
04	0501317160	SLEEVE SENSOR CONNECTION		01
05	0513012079	CLAMP		03
06	0503036193	HOSE 60 X 50 X 420		01




Item	Code	Description	See page	QT
01	0502012989	CLAMP BODY 4 RIGHT		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0503013759	NUT		01
02	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		01
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		01
04	0503063975	CLAMP SET 1 1/2		01
04A	0503036159	TOP CLAMP BODY		01
04B	0503036157	LOWER CLAMP BODY		01
04C	0503010585	0,24" X 1.18" SPRING PIN		01




Item	Code	Description	See page	QT
01	0501310283	RIGHT FERTILIZER MOTOR SUPPORT		01
02	0503062754	GEAR 34Z P.1/2 APT		01
03	0521069832	15Z GEAR		01
04	0503010282	1/4" X 3/4" BOLT		01
05	0503010143	1/4" SPRING WASHER		01
06	0531059149	FERTILIZER CURRENT PROTECTION RIGHT		01
06A	0501310284	FERTILIZER CURRENT PROTECTION RIGHT		01
06B	0503019412	RIVET SCREW INTERNAL		03
06C	0503010143	1/4" SPRING WASHER		02
06D	0503010305	6,50 X 17 X 1,50 ZN FLAT WASHER		02
06E	0503010461	BOLT 1/4" UNC X 1" C S G.2 ZN		02
06F	0501212320	ENCODER LOCK SCREW		01
07	0503010060	1/2 UNC G.5 ZN HEX NUT		03
08	0503010019	1/2" SPRING WASHER		03
09	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		02
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
11	0561013049	CHAIN TIGHTENER AXLE		01
12	0503010302	501019 SEAL RING		01
13	0503030402	PULLEY		01
14	0503015123	CHAIN 40-1 X 83		01
15	0501013518	FLAT WASHER		02
16	0503010026	3/8" NUT		02
17	0503010025	3/8 SPRING WASHER		02
18	0501011643	3/8 X 1"BOLT		02
19	0561011665	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0501216999	FIXING PLATE SEED ENGINE		01
02	0503010019	1/2" SPRING WASHER		03
03	0503010060	1/2 UNC G.5 ZN HEX NUT		03
04	0503030402	PULLEY		01
05	0531019479	AXLE CHAIN GEAR		01
06	0531064938	GEAR 15Z P12.70 ENGINE		01
07	0503010282	1/4" X 3/4" BOLT		01
08	0503010143	1/4" SPRING WASHER		01
09	0503012706	40-1 CHAIN X 47 LINK + MENDING		01
10	0503018701	SCREW 1/2 UNC X 1.3/4 CS G.5 ZN		02
11	0531064937	GEAR 25Z HEX 20		01
12	0511054314	TRANSMISSION AXLE LOCK SLEEVE		02
12A	0502012699	TRANSMISSION CASE LOCK SLEEVE		02
12B	0503010256	3/8" X 3/4" BOLT		02
13	0501214506	LINE ARTICULATION LOCK PIN		01
14	0501214505	GLOVE		01
15	0501217026	FLAT WASHER 13,50 X 32,50 X 3,00 ZN		02
16	0501217025	FLAT WASHER 8,70 X 28,50 X 2,00 ZN RCEM		01




Item	Code	Description	See page	QT
01	0521055372	ROW SEED BEARING	102	01
02	0531063569	ENCODER DRAG GLOVE		01
03	0501215449	ENCODER LOCK		01
04	0503010282	1/4" X 3/4" BOLT		01
05	0503014876	NUT PARLOCK 1/4"		01
06	0511017303	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0581017857	HOUSING BEARING		01
02	0503019361	BEARING 6006 RS1		01
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	NUT 5/16 UNC G.5 ZN		02
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0581019823	BEARING AXLE BODY WITHOUT LUBRICATION		01




Item	Code	Description	See page	QT
01	0541050985	SHORT RIGHT SEED LINE SUP/TMC/SPICRRF/PPH	104	01
02	0541050984	LEFT LONG SEED LINE SUP/TMC/SPICRRF/PPH	105	01
03	0541050983	SUPER LONG LEFT SEED LINE SUP/TMC/SPICRRF/PPH	106	01
04	0531056104	SHORT FERTILIZER LINE DC20/DSAEB18 WITHOUT LUBRICATION	139	01
05	0531056103	SMALLER LONG FERTILIZER LINE DC20/DSAEB18	140	01
06	0503030391	RIGHT FERTILIZER NOZZLE		01
07	0503030392	LEFT FERTILIZER NOZZLE		01
08	0531013600	PRESS ADJUSTMENT LEVER		01
09	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		24
10	0502012815	DOUBLE-DISC SPACING PLATE		48
11	0502070085	FIXED ROD BEARING		24
12	0503011402	0.2" X 0.8" SPRING PIN		48
13	0503016853	SPRING PIN		48
14	0503031050	CURVED CONDUCTOR		24
15	0503031826	CURVED CONDUCTOR		15
16	0521068982	DISC BLADE HUB KEY		02
17	0503010246	CLAMP		48
18	0503019222	BRACELET TYPE WIRE 3.2MM X 48 X 63 MM		05
19	0503036154	HOSE 2 X 2 X 505		12
20	0503030483	FERTILIZER SOCKET		24
21	0521053673	SCARIFIER ROD WITH NOZZLE	147	24
22	0531053737	MOUNTED SUPPORT	148	24
23	0511018662	SPACING PLATE		48
24	0571016118	FERTILIZER NOZZLE		24
25	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		48
26	0501010984	10,50 X 27 X 3,00 FLAT WASHER		96
27	0503010025	3/8 SPRING WASHER		48
28	0503010026	3/8" NUT		48
29	0503011266	CLAMP 2.1/4" A 3" 57-76		24




Item	Code	Description	See page	QT
01	0531054007	SHORT/LONG FRONT SEED ROW	107	01
02	0541050987	RIGHT REAR WITH DDD SPICRRF	108	01
03	0541050062	P.P. TRANSMISSION GEAR BOX RIGHT	124	01
04	0541050079	SEED ROW UPPER TRANSMISSION GEAR BOX	125	01
05	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	126	01
06	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
07	0503010589	1/2" UNC SELF ADJUSTING NUT		04
08	0503011855	0.2" X 1.8" SPRING PIN		02
09	0503064042	CARDAN T.S 16,00 X Q 15,90 X Q 22 X 577 FULL		01




Item	Code	Description	See page	QT
01	0541050067	FRONT LONG SEED ROW	127	01
02	0541050986	LEFT REAR WITH DDD SPICRRF	128	01
03	0541050079	SEED ROW UPPER TRANSMISSION GEAR BOX	125	01
04	0541050062	P.P. TRANSMISSION GEAR BOX RIGHT	124	01
05	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	126	01
06	0503011082	C1/2" X 1.3/4" SCREW		04
07	0503010589	1/2" UNC SELF ADJUSTING NUT		04
08	0503011855	0.2" X 1.8" SPRING PIN		02
09	0503064041	CARDAN T.S 16,00 X Q 15,90 X Q 22 X 697		01




Item	Code	Description	See page	QT
01	0541050048	SUPER LONG FRONT TCC	135	01
02	0541050986	LEFT REAR WITH DDD SPICRRF	128	01
03	0541050062	P.P. TRANSMISSION GEAR BOX RIGHT	124	01
04	0531051094	MOUNTED HOSE GUIDE ASSEMBLY	126	01
05	0503010589	1/2" UNC SELF ADJUSTING NUT		04
06	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
07	0503064042	CARDAN T.S 16,00 X Q 15,90 X Q 22 X 577 FULL		01
08	0503011855	0.2" X 1.8" SPRING PIN		02



Item	Code	Description	See page	QT
01	0531060663	FRONT FRAME SEED LINE	01	01
02	0531061428	REAR LINE	01	01
03	0503030168	HITCH PIN CLIP	05	05
04	0571018883	PIN FIXER SPRING	04	04
05	0503034198	SPRING TRACTION 40 X 198 X 5,5	01	01
06	0502012789	FIXER SUPPORT FERTILIZER ROW	01	01
07	0502012812	SEED ROW ADJUSTMENT LEVER ASSY	01	01
08	0591011156	PIVOT ARM SEED ROW	02	02
09	0503017857	BOLT 5/8 UNF 4	04	04
10	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN	04	04
11	0503010811	5/8" UNF SELF ADJUSTING NUT	04	04
12	0503019273	AUTO LUBRICANT SLEEVE	08	08
13	0503010045	O'RING	08	08
14	0591012829	SPACER LOWER SLEEVE	08	08
15	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	04
16	0503012412	5/8" UNC SELF LOCKING NUT	04	04
17	0591012827	FRONT PENDULUM LINE	01	01
18	0591012828	LOCK PIN ROW ARTICULAT	01	01
19	0501219536	LINE GUTTER	01	01
20	0501310623	SPRING FIXING PIN	02	02



Item	Code	Description	See page	QT
01	0531059830	REAR WITH RIGHT DDD WITHOUT FLAP WITHOUT FULL WHEEL	109	01
02	0521056640	PRECISION PLANTING CSC CABLE / TRANSMISSION ASSY	116	01
03	0541050988	WHEEL COMPACTOR IRON SET	118	01
04	0531051264	FULL SUPPORT FOR ENCAPSULATED CURRENT FIXATION	123	01
05	0503062403	TUBE SEED P.P		01
06	0571017895	PIN FIXER CONDUCTOR P.P		01
07	0503010140	1/8" X 3/4" SPLIT PIN		01




Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0531059833	DEPTH REGULATOR	110	01
03	0591016905	DEPTH WHEEL JOINT AXLE		02
04	0591011309	ADJUSTMENT BUSHING		02
05	0591011310	ADJUSTMENT BAR		02
06	0503019275	SLEEVE LUBRICATION SYSTEM		01
07	0581019473	ARTICULATED SLEEVE		02
08	0503010045	O'RING		02
09	0503013357	3/8 SELF-ADJUSTING NUT		03
10	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
11	0591011326	LOCK PIN		01
12	0571015326	ARTICULATION SLEEVE HANDLE		01
13	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
14	0503010060	1/2 UNC G.5 ZN HEX NUT		02
15	0503010019	1/2" SPRING WASHER		04
16	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
17	0501011445	FLAT WASHER		04
18	0531059832	ASSEMBLED RIGHT ARM	111	01
19	0531059831	ASSEMBLED LEFT ARM	112	01
20	0503012556	1/2" X 1" BOLT		02
21	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
22	0591011306	ADJUSTMENT LOCK		02
23	0503010131	3/16" X 1.1/2" SPLIT PIN		02
24	0591016900	BEATING AXLE		01
25	0591016988	SPICER PROTECTOR		01
26	0591016907	SPACER SLEEVE		06
27	0521056635	RIGHT ASSY DDD INTEGRATED DEPTH SYSTEM 113 SPI		01
28	0503011140	1/2" X 3-3/4" BOLT		01
29	0503011336	1/2" HEX SELF ADJUSTING NUT		01
30	0501311083	AXIS 5/8 X 90MM		01
31	0503012342	CLAMPING PIN		01


Item	Code	Description	See page	QT
32	0502013084	SUPPORT REGULATOR		01
33	0531066051	FIXER SPRING		01
34	0503011404	BOLT		01
35	0502013083	ADJUSTMENT SHAFT DEPTH		01

DEPTH REGULATOR


0531059833




Item	Code	Description	See page	QT
01	0501310947	BODY REGULATORY		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0503010581	RING		01
04	0502012892	DEPTH CONTROL HANDLE		01
05	0581019526	ARTICULATED AXLE LEVER DEPTH		01
06	0503010302	501019 SEAL RING		01
07	0581019519	FLAT WASHER		01
08	0501311082	NYLON GLOVE 17.20 X 20 X 25MM		01




Item	Code	Description	See page	QT
01	0502013082	RIGHT ARM		01
02	0503011109	O'RING 2-119 N 3006 9B		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055056	SPOKED WHEEL ASSY	114	01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01
07	0501311081	BEATER WHEEL CONTROL DEPTH		01
08	0503010420	BOLT		01
09	0511017303	FLAT WASHER		01
10	0503013814	1/4" NC LOCKNUT		01




Item	Code	Description	See page	QT
01	0502013081	LEFT ARM		01
02	0503011109	O'RING 2-119 N 3006 9B		02
03	0581019514	LUBRICANT SLEEVE		02
04	0521055056	SPOKED WHEEL ASSY	114	01
05	0503010741	1/2" X 2-3/4" BOLT		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01
07	0501311081	BEATER WHEEL CONTROL DEPTH		01
08	0503010420	BOLT		01
09	0511017303	FLAT WASHER		01
10	0503013814	1/4" NC LOCKNUT		01




Item	Code	Description	See page	QT
01	0502012929	BODY RIGHT		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 132 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 131 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0551019904	PRESS WHEEL RIM		02
02	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
04	0503010337	NUT 5/16 UNC G.5 ZN		06
05	0503032970	RUBBER BAND		01
06	0521055073	ASSEMBLY DEPTH WHEEL HUB	115	01




Item	Code	Description	See page	QT
01	0581019528	WHEEL DEPTH SPA HUB WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010143	1/4" SPRING WASHER		03
06	0503010878	5/8" SELF ALIGNING NUT		01
07	0503030757	2.9" X 2" X 0.02" JOINT		01
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019168	DUST CLOAK		01
11	0581019529	DEPTH REGULATOR SHAFT		01




Item	Code	Description	See page	QT
01	0502012924	PRECISION PLANTING SUPPORT		01
02	0502012800	SUPPORT ARTICULATION PNEUMATIC		01
03	0503062406	SEED HOPPER		01
04	0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT 117 PROTECTION		01
05	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
06	0503010589	1/2" UNC SELF ADJUSTING NUT		01
07	0503810009	BOLT		02
08	0571018649	SUPPORT FIXER		02
09	0503010243	CLAMP		01
10	0581017816	TERMINAL		01
11	0503034204	SEALING		01
12	0503010140	1/8" X 3/4" SPLIT PIN		01
13	0571014024	FAST BOLT GUIDE AXLE		01
14	0503034824	FIXATIVE		01
15	0503010293	CLAMP KNOB		01
16	0503010025	3/8 SPRING WASHER		05
17	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		01
18	0501110894	FIXER		01
19	0502012922	FIXING SUPPORT		01
20	0503011404	BOLT		01
21	0503013357	3/8 SELF-ADJUSTING NUT		01
22	0503010026	3/8" NUT		04
23	0503019529	SCREW 3/8 UNC X 1.1/2 CAPQ RI G.5 ZN		04




Item	Code	Description	See page	QT
01	0503062417	KIT CORN DISTRIBUTION		01
01A	0503018160	CORN PLASTIC DISC		01
01B	0503062472	SELECTOR SEED CORN		01
01C	0503062474	EJECTOR CORN SEED SET		01
02	0503062405	SEED DISTRIBUTOR		01
02A	0503062567	FIXED BASE SEEDS DISTRIBUTOR		01
02B	0503062974	MOBILE BASE WITHOUT SNORKEL		01
02C	0503062973	SNORKEL ASSY PP768718		01




Item	Code	Description	See page	QT
01	0531059837	SPA COMPACTING BODY WITHOUT BOLT	119	01
02	0521055018	WHEEL DRIVE WHEEL LEFT IN V	120	01
03	0521055019	IRON IN RIGHT WHEEL COMPACTOR V	121	01




Item	Code	Description	See page	QT
01	0501011753	5/16" X 1-3/4" BOLT	02	
02	0503013816	5/16" LOCKNUT	04	
03	0581015855	SLEEVE	02	
04	0502012877	PRESS WHEEL ADJUSTMENT LEVER	01	
05	0503030878	LEVER CRANK	01	
06	0581019520	AXIS	01	
07	0503010257	1/8" X 1" SPLIT PIN	01	
08	0581019511	COVER	01	
09	0503010848	5/16" X 3.1/2" BOLT	02	
10	0503030190	0.5" X 1.6" X 0.05" SPRING	01	
11	0581019510	AXIS	01	
12	0581019512	PLATE TOP	01	
13	0503019351	LUBRICANT SLEEVE	02	
14	0571012442	COUPLING SHAFT	01	
15	0531062651	LEVER COMPACTOR	01	
16	0503034817	SPRING	01	
17	0531066053	SIDE LEFT	01	
18	0531066052	RIGHT SIDE	01	




Item	Code	Description	See page	QT
01	0503013739	1/2" X 1" BOLT		01
02	0521014508	FLAT WASHER		04
03	0521054991	WHEEL DRIVE WHEEL RIGHT	122	01




Item	Code	Description	See page	QT
01	0503010752	1/2" X 3.1/2" BOLT		01
02	0521014508	FLAT WASHER		04
03	0521054991	WHEEL DRIVE WHEEL RIGHT	122	01




Item	Code	Description	See page	QT
01	0581019509	IRON WHEEL COMPACTOR		01
02	0503011105	SEAL RING		01
03	0503013848	5072-BR SEAL		02
04	0511011927	DUST CLOAK		02
05	0503019342	ROLLER BEARING		01
06	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0521068129	ENCAPSULATED CHAIN FIXATION SUPPORT		01
02	0591015755	CHAIN SUPPORT SLEEVE		02
03	0591016332	SUPPORT REAR SLEEVE		01
04	0501011753	5/16" X 1-3/4" BOLT		03
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75		01
06	0503019657	HEX LOCK NUT WITH NYLON 5/16		03
07	0591016334	FLAT WASHER 8,50 X 23 X 4,00		02




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION HOPPER PP		01
02	0502050053	RIGHT SIDE TRANSMISSION HOPPER PP		01
03	0503011410	ROLLER BEARING		02
04	0503033976	GEAR 6Z PNEUMATIC 2014		01
05	0503011182	6203 ROLLER BEARING		02
06	0571016187	PINION AXLE 6Z PNEUMATIC		01
07	0503011184	502040 CLAMPING RING (FOR AXLE)		01
08	0571017655	FIXER SLEEVE		01
09	0511057504	JOIN GEAR		01
09A	0571017898	BODY GEAR TRANSMISSION		01
09B	0503033975	24Z GEAR PNEUMATIC		01
09C	0503011769	M8 X 0.5" BOLT		01
10	3402510052	GREASE		01
11	0501311464	GEARBOX FLANGE		01
12	0503010733	1/4" X 1-3/4" BOLT		03
13	0503010143	1/4" SPRING WASHER		03
14	0503015356	SPRING PIN		01
15	0501311462	PIN DRAG 126		01
16	0503035749	LOCKING KNOB		01
17	0503036278	SPRING COMPRESSION		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6 X 1 X 16 C S 8.8 ZN BOLT		05
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0503011105	SEAL RING		01
11	0503011409	6005 Z BALL BEARING		01
12	0503017008	SEAL RING		01
13	0503017007	SEAL RING		02
14	0511017907	1/8" BSPT X 6 PLUG		01
15	0503010003	1845 GREASE FITTING		01
16	0503035316	LUBRICATED POINTS DECAL		01
17	0501311461	CONIC GEAR 14 TEETH		01
18	0531066150	WELDED DRIVE AXLE		01
19	0501311524	FIXER BOX TRANSMISSION		01
20	0503011953	5/16" X 1" BOLT		02
21	0503013759	NUT		02
22	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
23	0503015110	M06 SPRING WASHER		02




Item	Code	Description	See page	QT
01	0531062260	GUIDE HOSE L / TRANSMISSION		01
02	0571018883	PIN FIXER SPRING		01
03	0503010257	1/8" X 1" SPLIT PIN		01



Item	Code	Description	See page	QT
01	0531061428	REAR LINE	01	
02	0503030168	HITCH PIN CLIP	05	
03	0571018883	PIN FIXER SPRING	03	
04	0503034198	SPRING TRACTION 40 X 198 X 5,5	01	
05	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
06	0502012812	SEED ROW ADJUSTMENT LEVER ASSY	01	
07	0591011156	PIVOT ARM SEED ROW	02	
08	0503017857	BOLT 5/8 UNF 4	04	
09	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN	04	
10	0503010811	5/8\" UNF SELF ADJUSTING NUT	04	
11	0503019273	AUTO LUBRICANT SLEEVE	08	
12	0503010045	O'RING	08	
13	0591012829	SPACER LOWER SLEEVE	08	
14	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN	04	
15	0503012412	5/8\" UNC SELF LOCKING NUT	04	
16	0591012827	FRONT PENDULUM LINE	01	
17	0591012828	LOCK PIN ROW ARTICULAT	01	
18	0501219536	LINE GUTTER	01	
19	0501310623	SPRING FIXING PIN	01	
20	0531066157	FRONT CHASSIS SEED LINE	01	
21	0503010233	5/8\" X 2-1/2\" BOLT	02	
22	0503010027	5/8 SPRING WASHER	02	
23	0503010013	5/8 UNC G.5 ZN HEX NUT	02	
24	0511015705	FLAT WASHER	02	




Item	Code	Description	See page	QT
01	0531059835	REAR WITH LEFT DDD SPICRR WITHOUT FLAP WITHOUT FULL WHEEL	129	01
02	0541050988	WHEEL COMPACTOR IRON SET	118	01
03	0521056640	PRECISION PLANTING CSC CABLE / TRANSMISSION ASSY	116	01
04	0531051264	FULL SUPPORT FOR ENCAPSULATED CURRENT FIXATION	123	01
05	0503062403	TUBE SEED P.P		01
06	0571017895	PIN FIXER CONDUCTOR P.P		01
07	0503010140	1/8" X 3/4" SPLIT PIN		01




Item	Code	Description	See page	QT
01	0502012923	BEATER		01
02	0531059833	DEPTH REGULATOR	110	01
03	0591016905	DEPTH WHEEL JOINT AXLE		02
04	0591011309	ADJUSTMENT BUSHING		02
05	0591011310	ADJUSTMENT BAR		02
06	0503019275	SLEEVE LUBRICATION SYSTEM		01
07	0581019473	ARTICULATED SLEEVE		02
08	0503010045	O'RING		02
09	0503013357	3/8 SELF-ADJUSTING NUT		03
10	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
11	0591011326	LOCK PIN		01
12	0571015326	ARTICULATION SLEEVE HANDLE		01
13	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
14	0503010060	1/2 UNC G.5 ZN HEX NUT		02
15	0503010019	1/2" SPRING WASHER		04
16	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
17	0501011445	FLAT WASHER		04
18	0531059832	ASSEMBLED RIGHT ARM	111	01
19	0531059831	ASSEMBLED LEFT ARM	112	01
20	0503012556	1/2" X 1" BOLT		02
21	0503018882	3/8 UNC X 3.1/2 C S G.7 ZN SCREW		02
22	0591011306	ADJUSTMENT LOCK		02
23	0521056634	LEFT ASSY DDD INTEGRATED DEPTH SYSTEM 130 SPI		01
24	0503010131	3/16" X 1.1/2" SPLIT PIN		02
25	0591016900	BEATING AXLE		01
26	0591016988	SPICER PROTECTOR		01
27	0591016907	SPACER SLEEVE		06
28	0503011140	1/2" X 3-3/4" BOLT		01
29	0503011336	1/2" HEX SELF ADJUSTING NUT		01
30	0501311083	AXIS 5/8 X 90MM		01
31	0503012342	CLAMPING PIN		01


Item	Code	Description	See page	QT
32	0502013084	SUPPORT REGULATOR		01
33	0531066051	FIXER SPRING		01
34	0503011404	BOLT		01
35	0502013083	ADJUSTMENT SHAFT DEPTH		01




Item	Code	Description	See page	QT
01	0502012928	LEFT EXTENSOR		01
02	0503011402	0.2" X 0.8" SPRING PIN		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
05	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
06	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
07	0503010026	3/8" NUT		01
08	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
09	0503010025	3/8 SPRING WASHER		01
10	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 131 FERTILIZER / SEED		01
11	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 132 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055865	FERTILIZER/SEED LEFT HUB ASSY	133	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0521055864	FERTILIZER/SEED RIGHT HUB ASSY	134	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUBLE DISC AXLE		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0531063425	FRONT FRAME SEED ROW		01
02	1902010175	HITCH CLAMP		02
03	0503017857	BOLT 5/8 UNF 4		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04
05	0501012140	FLAT WASHER 16,50 X 40 X 4,00 ZN		04
06	0531061428	REAR LINE		01
07	0503030168	HITCH PIN CLIP		05
08	0571018883	PIN FIXER SPRING		04
09	0591012828	LOCK PIN ROW ARTICULAT		01
10	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
11	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
12	0591011156	PIVOT ARM SEED ROW		02
13	0591012829	SPACER LOWER SLEEVE		08
14	0503019273	AUTO LUBRICANT SLEEVE		08
15	0503010045	O'RING		08
16	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
17	0503012412	5/8" UNC SELF LOCKING NUT		04
18	0591012827	FRONT PENDULUM LINE		01
19	0511057159	TRANSMISSION HOPPER SEED ROW	136	02
20	0501057684	SIDE BEARING FRONT SUPPORT SEED ROW	137	03
21	0501212270	5/8 X 200 HEXAGONAL AXLE		01
22	0503010071	3/16" X 1" SPLIT PIN		02
23	0511054314	TRANSMISSION AXLE LOCK SLEEVE		02
23A	0502012699	TRANSMISSION CASE LOCK SLEEVE		01
23B	0503010256	3/8" X 3/4" BOLT		01
24	0501311487	HEXAGONAL SHAFT 3/4 X 320		01
25	0541050079	SEED ROW UPPER TRANSMISSION GEAR BOX	125	01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6 X 1 X 16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS DECAL		01




Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING	138	01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0502012030	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		01
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0521057679	ASSY CUTTING DISK 20	141	01
02	0531064025	LONG ARM MINOR FERTILIZER LINE		01
03	0503011255	3/4" LOCK NUT		02
04	0571019062	SLEEVE		01
05	0571019059	SUPPORT WASHER		01
06	0503010811	5/8" UNF SELF ADJUSTING NUT		04
07	0503011854	5/8" X 1-1/4" BOLT		02
08	0503017960	5/8" X 3-12" BOLT		04
09	0502012813	FLANGE WASHER SPRING		01
10	0503010417	7/8" NUT		02
11	0502012789	FIXER SUPPORT FERTILIZER ROW		01
12	0503019278	LUBRICANT SLEEVE		02
13	0591011147	SLEEVE ARM ROW		02
14	0503011109	O'RING 2-119 N 3006 9B		02
15	0503011254	7/8" HEX SELF ADJUSTING NUT		01
16	0521010066	3/4" X 8.12" BOLT		02
17	0591011146	LONG SUPPORT		01
18	0503034320	COMPRESSION SPRING		01
19	0531062203	REGULATOR SPRING LINE FERTILIZER		01
20	0531056105	MONO DC SINGLE STRETCHED FERTILIZER B - 144 DSAEB		01
21	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0531055165	20 COMPLETE CURVED CORRUGATED CUTTING DISC	146	01
02	0531064024	LONG ARM MINOR FERTILIZER LINE		01
03	0503011255	3/4" LOCK NUT		02
04	0571019062	SLEEVE		01
05	0571019059	SUPPORT WASHER		01
06	0503034320	COMPRESSION SPRING		01
07	0503010811	5/8" UNF SELF ADJUSTING NUT		04
08	0503011854	5/8" X 1-1/4" BOLT		02
09	0503017960	5/8" X 3-12" BOLT		04
10	0502012813	FLANGE WASHER SPRING		01
11	0531062203	REGULATOR SPRING LINE FERTILIZER		01
12	0503010417	7/8" NUT		02
13	0502012789	FIXER SUPPORT FERTILIZER ROW		01
14	0591011146	LONG SUPPORT		01
15	0591011147	SLEEVE ARM ROW		02
16	0503019278	LUBRICANT SLEEVE		02
17	0503011109	O'RING 2-119 N 3006 9B		02
18	0503011254	7/8" HEX SELF ADJUSTING NUT		01
19	0521010066	3/4" X 8.12" BOLT		02
20	0531056105	MONO DC SINGLE STRETCHED FERTILIZER B - 144 DSAEB		01
21	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
22	0503010019	1/2" SPRING WASHER		02
23	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0531060662	MONO ARM DISC CUTTING		01
02	0531060661	ARM SUPPORT		01
03	0571019034	FLANGE WASHER AXLE		01
04	0571019032	SUPPORT WASHER		01
05	0502012813	FLANGE WASHER SPRING		01
06	0591010619	DC SPRING SUPPORT		01
07	0503019274	WASHER		02
08	0581017628	LID		02
09	0503034320	COMPRESSION SPRING		01
10	0591010625	19,50 X 25 X 91,50/91,30 SLEEVE		01
11	0503010417	7/8" NUT		02
12	0503010390	SEAL RING		02
13	0503011198	BOLT 3/4" UNC X 6" CS G.5		01
14	0503011255	3/4" LOCK NUT		01
15	0503030430	7/16 X 2" PIN LOCK		01
16	0503019271	SELF LUBRICATING BUSHING		01
17	0503011254	7/8" HEX SELF ADJUSTING NUT		01
18	0531061481	MONO SPRING DISC CUTTING REGULATOR		01
19	0591011144	FIXATION AXLE		01
20	0591010628	SHAFT THRUST WASHER		01
21	0503019272	LUBRICANT SLEEVE		02
22	0521057681	BOX WITH DISC CUTTING 20 BEARING CONICO	142	01
23	0503012412	5/8" UNC SELF LOCKING NUT		01
24	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521057680	DISC CUTTING BOX	143	01




Item	Code	Description	See page	QT
01	0503010370	502072 CLAMPING RING (FOR AXLE)	02	
02	0502020641	BLADE DISC FLANGE	01	
03	0503018825	5/16 UNC UNC BOLT	06	
04	0503013816	5/16" LOCKNUT	06	
05	0501010694	FLAT WASHER 32,50 X 75 X 4,75	06	
06	0502012862	DISC BLADE HUB	01	
07	0511017907	1/8" BSPT X 6 PLUG	02	
08	0503019285	RING	02	
09	0503010590	00674-B SEAL	02	
10	0591012836	CUTTING DISC AXLE	01	
11	0502040872	REGULATORY NUT	01	
12	0503012170	30207 ROLLER BEARING	02	
13	0503010812	7/8" UNF SELF LOCKING NUT	01	
14	0501010067	22.5 X 56 X 4.75 FLAT WASHER	01	
15	0503019283	SCREW 7/8 UNF X 6.1/4	01	




Item	Code	Description	See page	QT
01	0531064488	SINGLE DISC ARM		01
02	0531050800	HUB WITH SMOOTH STRIPED FLAT DISC B. 18	145	01
03	0531064066	SINGLE DISC FERTILIZER CONDUCTOR		01
04	0521015376	DUST CLOAK		01
05	0503011404	BOLT		02
06	0503013357	3/8 SELF-ADJUSTING NUT		02
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503012417	SEAL		01
09	0503011800	SEAL RING		01
10	0503016063	ROLLER BEARING		01
11	0503030832	FLAT WASHER		01




Item	Code	Description	See page	QT
01	0503011800	SEAL RING		01
02	0503012417	SEAL		01
03	0503016063	ROLLER BEARING		01
04	0503030832	FLAT WASHER		01
05	0502020641	BLADE DISC FLANGE		01
06	0503010371	5/16" X 1" BOLT		06
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
08	0503010337	NUT 5/16 UNC G.5 ZN		06
09	0581019304	DISC HUB		01
10	0605025015	18" PLAIN COULTER BLADE		01







Item	Code	Description	See page	QT
01	0511061768	FERTILIZER SCARIFIER ROD		01
02	0503011402	0.2" X 0.8" SPRING PIN		02
03	0503016853	SPRING PIN		02
04	0502040869	FIXED ROD BEARING		01




Item	Code	Description	See page	QT
01	0531063324	LONG LINE COMPLEMENT SUPPORT		01
02	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0503010479	BOLT		02



Item	Code	Description	See page	QT
01	0531055350	CENTRAL SUPPORT WITH 07 NOZZLES	150	01
02	0503063507	COMPLETE SILO 03 MOUTHS 540L		01
03	0503063508	HOPPER ASSY (720 LITERS)		01
04	0521051407	FERTILIZER HOPPER FIXER	74	14
05	0503010589	1/2" UNC SELF ADJUSTING NUT		06
06	0503014378	1/2" X 1-1/2" BOLT		06
07	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06



Item	Code	Description	See page	QT
01	0531064103	CENTRAL SILO SUPPORT 07 MOUTHS		01
02	0531059144	FERTILIZER DOSER ALPHA II	151	07
03	0521054282	BEARING	155	02
04	0501053788	3/4" SQUARE AXLE FASTENER	71	04
05	0503031527	AGRICULTURAL BEARING		04
06	0501218575	SQUARE AXIS 3/4 X 730MM WITH RELIEVE		02
07	0501218487	3/4 X 390 AXLE		03
08	0531057908	SLEEVE 1/4 X 2		04
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010523	1/4" X 2" SPLIT PIN		01




Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	TRANSMISSION HUB ASSY	152	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	153	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0513011173	NUT 3/8 UNC X 1		04
12	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
13	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
14	0513011171	1/4 NC HEX NUT		08
15	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
16	0503036177	LID CORD		01
17	0531059138	COMPLETE COLLECTOR	154	01
18	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
19	0503035797	FRONT COLLECTOR FIXER		02
20	0501111195	GRANULATED FERTILIZER COATING		01
21	0513010692	ALLEN SCREW 1/4 UNC X 7/8 C FLAT SI INOX		04
22	0503036306	FERTILIZER DOSER SEAL		01
23	0501312601	FRONT COVER		01
24	0501312603	FRAME SEALING TAPE		01




USAP 3200 AP SUPREMA - FRAME 12820
FERTILIZER DOSER ALPHA II

Page 151
0531059144


Item	Code	Description	See page	QT
25	0503036206	FERTILIZER SYSTEM ADHESIVE LABEL ALPHA		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO DECAL		01
15	0503035316	LUBRICATED POINTS DECAL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT FERTILIZER METERING LID GUIDE		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	72	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036179	FERTILIZER DOSING NOZZLE		01
07	0503036202	LEFT TORSION SPRING SIDE COVER		02
08	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02




Item	Code	Description	See page	QT
01	0501214451	CENTRAL WHEEL AXLE		01
02	0503010050	SEAL 00085-B		01
03	0503010002	1800 GREASE FITTING		01
04	0541013225	WHEEL HUB LID		01
05	0503011444	SPRING WASHER 5/16"		06
06	0503010240	BOLT		06
07	0502040080	FLANGE NUT R.2.1/2" UN		01
08	0503011345	1/4" X 3.1/2" SPLIT PIN		01
09	0501111223	BOX ROUND WITH SCREW		01
09A	0501213765	WHEEL BOX		01
09B	0503810007	WHEEL BOLT		08
09C	0503014048	HEX NUT M22X1,5" CH32X33,5		08
10	0503013633	BEARING 33287/33462		01
11	0503013496	3982/3920 ROLLER BEARING		01




Item	Code	Description	See page	QT
01	0501056444	ROLLER BEARING	156	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER 32,50 X 75 X 4,75		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	NUT 5/16 UNC G.5 ZN		02




Item	Code	Description	See page	QT
01	0531064358	ROD 1.3/4 X 745MM		01
02	0503010042	2-214 N 3006-9B O'RING		01
03	0503010063	1" SELF-ALIGNING NUT		01
04	0503010761	D-1750 SCRAPER RING		01
05	0571019710	1.7" X 3.4" PISTON		01
06	0503017935	RING		01
07	0503018144	RING		01
08	0571019711	RING SUPPORT		01
09	0571019709	DETACHABLE COVER		01
10	0503017936	RING		01
11	0503017938	RING GUIDE		01
12	0503017937	GASKET		01
13	0503017940	8-337 BACK-UP RING		02
14	0503017939	2-337 N 3006-9B O' RING		02
15	0503018045	2-130 (AGEL) O'RING		04
16	0531066042	CYLINDER 85,70 X 253		01




Item	Code	Description	See page	QT
01	0502011697	GEARBOX SUPPORT		01
02	0503013462	6005 2RS1 ROLLER BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
03	0503010589	1/2" UNC SELF ADJUSTING NUT		02




Item	Code	Description	See page	QT
01	0501212948	DEPOSIT SUPPORT BODY		02
02	0503011075	3/4 UNC LOCK NUT		04
03	0501011545	3/4" X 6-1/2" BOLT		04




Item	Code	Description	See page	QT
01	0531064124	LEFT ARTICULATING ARM	01	
02	0521063778	RELATION AVEC AXE VERTICAL LATCH	01	
03	0571011767	125 X 88 X 4,76 FLAT WASHER	01	
04	0503010408	7/8" SPRING WASHER	01	
05	0503015322	BOLT 7/8	01	
06	0503010814	5/16 BOLT	10	
07	0503010002	1800 GREASE FITTING	02	
08	0571011825	BUSHING	02	
09	0503011345	1/4" X 3.1/2" SPLIT PIN	01	
10	0531062168	CYLINDER JOINT AXIS	01	
11	0503010834	1/2 X 1 BOLT	01	
12	0503010019	1/2" SPRING WASHER	05	
13	0503010060	1/2 UNC G.5 ZN HEX NUT	04	
14	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN	02	
15	0501013519	FLAT WASHER	04	
16	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT	02	
17	0591012948	700 X 130 X 10 PLATE	01	
18	0531063434	SUPPORT GUIDE HOSES SEED	02	
19	0591018508	24 X 50 X 1000 GUTTER	01	
20	0501013518	FLAT WASHER	02	
21	0503010025	3/8 SPRING WASHER	02	
22	0503010026	3/8" NUT	02	
23	0501011643	3/8 X 1"BOLT	02	
24	0503035505	HOSE PROTECTOR	01	
25	0501214491	CONIC GLOVE TIGHTENING	02	
26	0502040080	FLANGE NUT R.2.1/2" UN	01	
27	0501214492	FIXING WASHER	01	
28	0531064126	ARTICULATING AXLE	01	




Item	Code	Description	See page	QT
01	0521063778	RELATION AVEC AXE VERTICAL LATCH		01
02	0571011767	125 X 88 X 4,76 FLAT WASHER		01
03	0503010408	7/8" SPRING WASHER		01
04	0503015322	BOLT 7/8		01
05	0503010814	5/16 BOLT		10
06	0503010002	1800 GREASE FITTING		02
07	0571011825	BUSHING		02
08	0591012948	700 X 130 X 10 PLATE		01
09	0531064125	RIGHT ARTICULATING ARM		01
10	0531062168	CYLINDER JOINT AXIS		01
11	0503010834	1/2 X 1 BOLT		01
12	0503010019	1/2" SPRING WASHER		05
13	0501013519	FLAT WASHER		02
14	0503010060	1/2 UNC G.5 ZN HEX NUT		04
15	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0591018508	24 X 50 X 1000 GUTTER		01
18	0501013518	FLAT WASHER		02
19	0503010025	3/8 SPRING WASHER		02
20	0503010026	3/8" NUT		02
21	0501011643	3/8 X 1"BOLT		02
22	0503035505	HOSE PROTECTOR		01
23	0531063434	SUPPORT GUIDE HOSES SEED		02
24	0501214491	CONIC GLOVE TIGHTENING		02
25	0502040080	FLANGE NUT R.2.1/2" UN		01
26	0501214492	FIXING WASHER		01
27	0503011345	1/4" X 3.1/2" SPLIT PIN		01
28	0531064126	ARTICULATING AXLE		01



Item	Code	Description	See page	QT
01	0581010353	RING SUPPORT		01
02	0502010382	5" END CAP		01
03	0581013698	PISTON 2" X 5" C/R. M36 X 1,5		01
04	0531062932	EXTENSION 50.80 X 898 MM		01
05	0503010003	1845 GREASE FITTING		02
06	0503010817	SELF LOCKING NUT 1.1/4 UNF ALTA G.5 ZN		01
07	0503018439	WIPER SEAL T-SEAL 1905127		01
08	0503018150	RING GUIDE W2-5000-984 (4528)		01
09	0503010173	2-220 N 3006-9B O'RING		01
10	0503018024	RING BS OD050805200171D-BR		01
11	0503018026	GASKET 1870-2000-375 B POLYMAX		01
12	0503010039	D-2000 SCRAPER RING		01
13	0503018152	O'RING		02
14	0503018025	RING GUIDE W2-2250-750		01
15	0503011453	O'RING		02
16	0531066066	CILINDER CASE 127 X 773MM		01




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		02
02	0503017857	BOLT 5/8 UNF 4		08
03	0503010811	5/8" UNF SELF ADJUSTING NUT		08
04	0591017796	ARTICULATION AXIS 222 R.1.1 / 4 UNF		01
05	0531064321	UNIVERSAL SUPPORT		01
06	0501111056	BEARING SUPPORT CYLINDER WITHOUT LUBRICATION		02
07	0503010019	1/2" SPRING WASHER		04
08	0503011075	3/4 UNC LOCK NUT		06
09	0501010125	3/4" X 2-1/2" BOLT		06
10	0591013172	31.75 X126 AXLE WITH 8 HOLE		02
11	0591013173	CYLINDER INTERMEDIATE BUSHING		01
12	0503012231	1/4" X 3" SPLIT PIN		02
13	0501111072	SIDE SUPPORT ARTICULATOR		01
14	0501011544	3/4" X 1-1/2" BOLT		01
15	0503010023	3/4" SPRING WASHER		01
16	0591018408	PIN LOCK LINES		01
17	0503030085	LOCK PIN		01
18	0591019305	FLAT WASHER 20 X 60 X 4.75 WITH CUT OUT		01
19	0501211496	GLOVE 16 X 25 X 27 WITH HOLE		01
20	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
21	0503010060	1/2 UNC G.5 ZN HEX NUT		04
22	0501010942	3/8" X 1-1/4" BOLT		02
23	0503013357	3/8 SELF-ADJUSTING NUT		02
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
25	0541050570	SIDE ARTICULATION CYLINDER 82 44,45X85,70X291X657 DKO		01




Item	Code	Description	See page	QT
01	0531065709	TELESCOPIC WHEEL SUPPORT		01
02	0531064105	CENTRAL WHEEL TOWER		01
03	0531064106	CROSSHEAD WITH SUPPORT		01
04	0501210807	PLASTIPRENE LOWER SUPPORT		02
05	0501210806	PLASTIPRENE TOP SUPPORT		02
06	0501214452	DAMPER SPINDLE		02
07	0501214453	PLASTIPRENE EAR		01
08	0501214454	GLOVE ARTICULATION AXLE		02
09	0503010834	1/2 X 1 BOLT		05
10	0503010019	1/2" SPRING WASHER		09
11	0503011075	3/4 UNC LOCK NUT		02
12	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		02
13	0501214303	WHEEL CHAIN		05
14	0531054036	ASSY CENTER CYLINDER BEARING	156	02
15	0503011052	1.1/4" X 0.77" CASTLE NUT		01
16	0503012182	1" NUT		02
17	0503010002	1800 GREASE FITTING		11
18	0503010038	3/16" X 2" SPLIT PIN		01
19	0591016434	PLASTIPRENE		02
20	0501214302	ADJUSTMENT COVER PLATE		05
21	0503034377	3/8 UNC X 3/4 BOLT		30
22	0503010025	3/8 SPRING WASHER		30
23	0501215027	CENTRAL WHEEL PULLEY		03
24	0501214462	NYLON PULLEY BUSHING		06
25	0501216430	ADJUSTING COVER CALCO		05
26	0531065712	CENTRAL PULLEY LOCK SHAFT		03
27	0561010960	FLAT WASHER		04
28	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
29	0541050194	COMPLETE CENTRAL CUBE	154	02
30	0501111193	FULL PULLEY		01
31	0531065710	MAJOR AXLE LOCK CENTRAL PULLEY		01
32	0501311051	BEATER SHAFT 200 WITH GROUP		01

Item	Code	Description	See page	QT
33	0503012623	3/8" X 1-1/2" BOLT		01
34	0531064108	ARTICULATOR AXLE CENTRAL WHEEL		01
35	0591011057	WASHER		01
36	0503011250	1" X 2" BOLT		01
37	0531064361	CYLINDER AXLE 170.50MM		01
38	0541050195	MOUNTED LEFT WHEEL	93	01
39	0541050196	MOUNTED RIGHT WHEEL	94	01
40	0503010208	HEX NUT 3/8 UNF G.5 ZN		01
41	0531059818	HYDRAULIC RIGHT CYLINDER	90	01




Item	Code	Description	See page	QT
01	0531065709	TELESCOPIC WHEEL SUPPORT		01
02	0531064105	CENTRAL WHEEL TOWER		01
03	0531064106	CROSSHEAD WITH SUPPORT		01
04	0501210807	PLASTIPRENE LOWER SUPPORT		02
05	0501210806	PLASTIPRENE TOP SUPPORT		02
06	0501214452	DAMPER SPINDLE		02
07	0501214453	PLASTIPRENE EAR		01
08	0501214454	GLOVE ARTICULATION AXLE		02
09	0503010834	1/2 X 1 BOLT		05
10	0503010019	1/2" SPRING WASHER		09
11	0503011075	3/4 UNC LOCK NUT		02
12	0503013185	BOLT 3/4" UNC X 5.1/2 C S G.7 ZN		02
13	0501214303	WHEEL CHAIN		05
14	0531054036	ASSY CENTER CYLINDER BEARING	156	02
15	0503011052	1.1/4" X 0.77" CASTLE NUT		01
16	0503012182	1" NUT		02
17	0503010002	1800 GREASE FITTING		11
18	0503010038	3/16" X 2" SPLIT PIN		01
19	0591016434	PLASTIPRENE		02
20	0501214302	ADJUSTMENT COVER PLATE		05
21	0503034377	3/8 UNC X 3/4 BOLT		30
22	0503010025	3/8 SPRING WASHER		30
23	0501215027	CENTRAL WHEEL PULLEY		03
24	0501214462	NYLON PULLEY BUSHING		06
25	0501216430	ADJUSTING COVER CALCO		05
26	0531065712	CENTRAL PULLEY LOCK SHAFT		03
27	0561010960	FLAT WASHER		04
28	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		04
29	0541050194	COMPLETE CENTRAL CUBE	154	02
30	0501111193	FULL PULLEY		01
31	0531065710	MAJOR AXLE LOCK CENTRAL PULLEY		01
32	0531059817	HYDRAULIC CYLINDER 44,45X85,70X326	155	01


Item	Code	Description	See page	QT
33	0501311051	BEATER SHAFT 200 WITH GROUP		01
34	0503012623	3/8" X 1-1/2" BOLT		01
35	0531064108	ARTICULATOR AXLE CENTRAL WHEEL		01
36	0591011057	WASHER		01
37	0503011250	1" X 2" BOLT		01
38	0531064361	CYLINDER AXLE 170.50MM		01
39	0541050195	MOUNTED LEFT WHEEL	93	01
40	0541050196	MOUNTED RIGHT WHEEL	94	01
41	0503010208	HEX NUT 3/8 UNF G.5 ZN		01




Item	Code	Description	See page	QT
01	0531063641	CENTRAL SEED BOX SUPPORT 2500 LITERS		01
02	0531054352	AXLE 1.1/2 X 167 MM WITH WASHER		04
02A	0501212952	PASADOR 1.1/2 X 167 MM		01
02B	0501212953	FLAT WASHER 39 X 60 X 3		04
02C	0503010010	SPLIT PIN 1/4" X 2.1/2"		02
03	0531054355	SUPPORT WITH VACUOMETER 18 TO 25 LINES		01
03A	0503013584	VACUUM GAUGE		01
03B	0501212956	18/25 CENTRAL VACUUM SUPPORT		01
04	0531054354	CENTRAL SEED BOX 2500 LITERS	158	01
05	0531063639	CSC HANDRAIL 2500 LITERS		02
06	0503011372	102 TO 121 CLAMP		02
07	0501213035	SILO SUPPORT GLOVE CSC 2500L		04
08	0513010405	CLAMP		28
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
10	0503010019	1/2" SPRING WASHER		08
11	0503010060	1/2 UNC G.5 ZN HEX NUT		02
12	0503010547	1/2" X 4" BOLT		02
13	0501212957	SILO LOCK CSC 2500 LITERS		02
14	0503014007	BOLT 1/2 UNC X 1.1/4 C S G.5 ZN		06
15	0521018517	FLAT WASHER		02
16	0503010002	1800 GREASE FITTING		04
17	0521012538	1.2" X 3.5" COUPLING SHAFT		01
18	0503010010	SPLIT PIN 1/4" X 2.1/2"		01
19	0503014378	1/2" X 1-1/2" BOLT		06
20	0503010589	1/2" UNC SELF ADJUSTING NUT		06
21	0501213773	HOSE GUIDE SUPPORT		01
22	0503035468	HOSE PROTECTION		01
23	0531058201	HYDRAULIC TURBINE WITH SCREEN	160	01




Item	Code	Description	See page	QT
01	0503063436	COMPLETE POSITIVE AIR DOUBLE SEED BOX		01
02	0501010984	10,50 X 27 X 3,00 FLAT WASHER		46
03	0531054357	LOWER SYSTEM 28 PIPES	159	01
04	0503013357	3/8 SELF-ADJUSTING NUT		46
05	0503010849	3/8" X 1-1/2" BOLT		12
06	0503010025	3/8 SPRING WASHER		12
07	0531063644	AIR TUBE 28 OUTLETS WITH FIXER		01
08	0513010632	RUBBER SMOOTH WASHER 28 X 10 X 2.00		46
09	0531063885	SYSTEM FIXING RULE		02
10	0531063624	SYSTEM FIXING RULE		14
11	0513010630	SCREW M6 X1 X 20 CCSI 10.9 SA		30




Item	Code	Description	See page	QT
01	0531063643	OUTLET BODY WITH DUCTS		01
02	0503015135	FLAT WASHER 10 X 18 X 2		10
03	0503011823	0.1" X 0.6" SPRING PIN		10
04	0521068978	CASH FUND COVER		05
05	0581017529	ROD 9,53		05
06	0503034692	FAST LOCK ASSY		10
07	0503030085	LOCK PIN		10
08	0503034573	SEALING		05
09	0503035773	BOTTOM SEAL BOX SYSTEM 28 OUTPUTS		01
10	0503063723	AIR TUBE SEAL 04 OUTLETS 290		07



Item	Code	Description	See page	QT
01	0531056343	HYDRAULIC ENGINE	161	01
02	0531063640	TURBINE SUPPORT		01
03	0521044613	480 X 50 FAN (HIDRAULIC)	162	01
04	0531061858	MECHANICAL SNAIL		01
05	0571018577	COVER SNAIL TURBINE		01
06	0571018578	TURBINE PROTECTIVE SCREEN		01
07	0521069167	FRONT PROTECTION		01
08	0531056344	COMMAND BLOCK	163	01
09	0503010025	3/8 SPRING WASHER		10
10	0503010026	3/8" NUT		08
11	0503010143	1/4" SPRING WASHER		01
12	0503010849	3/8" X 1-1/2" BOLT		02
13	0531018764	FLAT WASHER		01
14	0503011104	M6 X 1" BOLT		01
15	0503012722	0.16" X 0.4" BLIND RIVET		19
16	0503010237	3/8" X 1" BOLT		06
17	0503010206	3/8 X 1/2 BOLT		02
18	0541013274	LISA WASHER 10 X 38 X 4.75		02




Item	Code	Description	See page	QT
01	0503012871	HYDRAULIC MOTOR		01
02	0513010838	ADAPTER TERMINAL MF R.1/2 BSP ORING X MF TB15		02
03	0513010917	ADAPTER TERMINAL MF R.1/4 BSP ORING X MF TB15		01
04	0513010839	ADAPTER TERMINAL MF R.1/4 BSP ORING X MF TB10L		01




Item	Code	Description	See page	QT
01	0571016947	DISC FRONT TURBINE		01
02	0571016949	DISC REAR TURBINE		01
03	0521065171	HUB FLANGE		01
04	0571016950	DISC STRENGTHENING TURBINE		01
05	0571016951	FLIP TURBINE		10
06	0503012651	M6 X 1" BOLT		05
07	0503010143	1/4" SPRING WASHER		05
08	0503011776	SELF-LOCKING HEX NUT		05

COMMAND BLOCK


0531056344



Item	Code	Description	See page	QT
01	0503012291	BLOCK COMMAND		01
02	0513010841	ADAPTER TERMINAL MF R.3/4 UNF ORING X MF TB10L		01
03	0513010818	ADAPTER TERMINAL MF R.7/8 UNF		04




Item	Code	Description	See page	QT
01	0531066440	CYLINDER CASE 63,50 X 345 DKO		01
02	0501212949	EXTENDER 38.10 X 38.05 X 380		01
03	0502010471	63,50 MOBILE CAP		01
04	0581010668	RING SUPPORT		01
05	0502012837	PISTON		01
06	0503018163	BACK-UP RING		02
07	0503018162	O'RING		02
08	0503018004	RING		01
09	0503018003	GASKET		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503011109	O'RING 2-119 N 3006 9B		01
12	0503018005	RING		01
13	0503018045	2-130 (AGEL) O'RING		04
14	0511064408	FORK		01
15	0503010025	3/8 SPRING WASHER		01
16	0503011094	BOLT 3/8" UNC X 2" C C S I 12.9		01
17	0503010026	3/8" NUT		01




Item	Code	Description	See page	QT
01	0531066447	AIR CONDUCTOR TUBE		01
02	0503036366	SEALING AIR TUBE		02
03	0501312852	COVER AIR TUBE		02
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0503010237	3/8" X 1" BOLT		08
07	0521052549	CLAMP	166	07
08	0531050772	RIGHT CLAMP 4	97	02
09	0503034867	AIR DISTRIBUTOR PUMP		01

CLAMP

0521052549




Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	SELF-LOCKING HEX NUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0503019579	LED LANTERN		01
02	0591018872	LANTERN COVER		01
03	0503019412	RIVET SCREW INTERNAL		02
04	0503013813	1/4" UNC X 7/8" BOLT		02
05	0503010143	1/4" SPRING WASHER		02
06	0503010305	6,50 X 17 X 1,50 ZN FLAT WASHER		02
07	0503010237	3/8" X 1" BOLT		02
08	0503010026	3/8" NUT		02
09	0503010025	3/8 SPRING WASHER		02
10	0501312954	SUPPORT RIGHT LIGHT		01

LEFT LANTERN SET


0541050679




Item	Code	Description	See page	QT
01	0501312955	LEFT LANTERN SUPPORT		01
02	0503019579	LED LANTERN		01
03	0591018872	LANTERN COVER		01
04	0503019412	RIVET SCREW INTERNAL		02
05	0503013813	1/4" UNC X 7/8" BOLT		02
06	0503010143	1/4" SPRING WASHER		02
07	0503010305	6,50 X 17 X 1,50 ZN FLAT WASHER		02
08	0503010237	3/8" X 1" BOLT		02
09	0503010026	3/8" NUT		02
10	0503010025	3/8 SPRING WASHER		02




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		24
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		24
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531061615	MOBILE LADDER		01
02	0531062927	LEFT SUPPORT STAIRCASE		01
03	0531062926	LEFT LOCK LADDER		01
04	0503010025	3/8 SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
07	0501010937	13,50 X 28 X 3,00 FLAT WASHER		04
08	0503010589	1/2" UNC SELF ADJUSTING NUT		02
09	0503010752	1/2" X 3.1/2" BOLT		02
10	0503010140	1/8" X 3/4" SPLIT PIN		01




Item	Code	Description	See page	QT
01	0531058140	LEFT SIDE HOPPER WITH 10 NOZZLES ALPHA	172	01
02	0521051407	FERTILIZER HOPPER FIXER	74	20
03	0531050918	TOP SUPPORT MOUNTED LIFT EXTENSOR	75	03
04	0503063509	COMPLETE SILO 05 MOUTH 900L		02




Item	Code	Description	See page	QT
01	0531064566	SILO SUPPORT 10 SIDE BUCKETS		01
02	0531051685	CENTRAL BEARING SHAFT	68	02
03	0531051684	SIDE AXLE	69	02
04	0591018936	GLOVE		02
05	0503010002	1800 GREASE FITTING		02
06	0531055292	ALPHA FERTILIZER METERING	70	10
07	0501053788	3/4" SQUARE AXLE FASTENER	71	04
08	0503031527	AGRICULTURAL BEARING		04
09	0501218487	3/4 X 390 AXLE		04
10	0531057908	SLEEVE 1/4 X 2		06
10A	0502013069	SLEEVE 21 X 38 X 50		01
10B	0503010523	1/4" X 2" SPLIT PIN		01
11	0501218573	SQUARE AXIS 3/4 X 865MM WITH RELIEVE		02
12	0501218575	SQUARE AXIS 3/4 X 730MM WITH RELIEVE		01



Item	Code	Description	See page	QT
01	0531065305	HOSE SUPPORT LEFT		01
02	0531065306	ARTICULATOR HOSE		01
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
04	0503010025	3/8 SPRING WASHER		02
05	0503010237	3/8" X 1" BOLT		01
06	0503010026	3/8" NUT		01
07	0503010849	3/8" X 1-1/2" BOLT		01




Item	Code	Description	See page	QT
01	0501312938	LEFT SIDE SUPPORT		01
02	0501312940	SUPPORT PLATE DUCT		02
03	0501313845	RIGHT VERTICAL SUPPORT		01
04	0501313846	LEFT VERTICAL SUPPORT		01
05	0501311238	CLAMP UNION 112 X 30 X 6,30		05
06	0501311237	FIXER		05
07	0513010752	SINGLE STANDARD CLAMP 12 MM - BLACK		60
08	0513011685	TEE TERMINAL MF X MF X FG TB12L		04
09	0503036455	HYDRAULIC TUBE PT12L X PT12L X 3150		04
10	0503036454	HYDRAULIC TUBE PT12L X PT12L X 1530		02
11	0503036453	HYDRAULIC TUBE PT12L X FG12L X 1580		02
12	0501313844	SUPPORT 50 X 30 X 3060		01
13	0513011664	BOLT M6 X 1,00 X 80 - SXR6X80ZI		10
14	0513011665	BOLT M6 X 1,00 X 90 - SXR6X90ZI		05
15	0503010305	6,50 X 17 X 1,50 ZN FLAT WASHER		15
16	0503015110	M06 SPRING WASHER		15
17	0503014540	M6 NUT		15
18	0501010098	BOLT 3/4" UNC X 2 C S G.5 ZN		04
19	0503011075	3/4 UNC LOCK NUT		04
20	0503013776	BOLT 1/2 UNC X 7/8 C S G.5 ZN		02
21	0503010019	1/2" SPRING WASHER		02
22	0501013519	FLAT WASHER		02



Item	Code	Description	See page	QT
01	0531064113	SIDE WHEEL TOWER		01
02	0503014559	ROLLER BEARING		02
03	0503010095	SEAL		01
04	0501213909	WHEELED HUB COVER		01
05	0502040080	FLANGE NUT R.2.1/2" UN		01
06	0503010002	1800 GREASE FITTING		13
07	0501213917	ADJUSTMENT WASHER		01
08	0503012213	1/4" X 4" SPLIT PIN		01
09	0503010295	SCREW 5/16 UNC X 5/8 CS G.2 ZN		06
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
11	0501214463	SIDE WHEEL PULLEY		06
12	0501214462	NYLON PULLEY BUSHING		12
13	0501214303	WHEEL CHAIN		06
14	0531064110	PULLEY LOCK AXLE		06
15	0503010834	1/2 X 1 BOLT		06
16	0503010019	1/2" SPRING WASHER		06
17	0591017921	BRONZE GLOVE 90.5 X 115 X 91		02
18	0501214460	AXLE 1.1/2 X 140MM		01
19	0503010390	SEAL RING		02
20	0531055358	COMPLETE SIDE CYLINDER BEARING	88	02
21	0531055357	LOCK PIN SET	89	01
22	0501214302	ADJUSTMENT COVER PLATE		06
23	0503034377	3/8 UNC X 3/4 BOLT		36
24	0503010025	3/8 SPRING WASHER		36
25	0501017065	FLAT WASHER		06
26	0503011255	3/4" LOCK NUT		06
27	0501216430	ADJUSTING COVER CALCO		06
28	0541050188	DOUBLE SIDE WHEELED TIRE	91	01
29	0531057692	LEFT COMPLETE HOSE SUPPORT	173	01
30	0541050195	MOUNTED LEFT WHEEL	93	01
31	0541050196	MOUNTED RIGHT WHEEL	94	01
32	0531059817	HYDRAULIC CYLINDER 44,45X85,70X326	155	01

Item	Code	Description	See page	QT
33	0503012623	3/8" X 1-1/2" BOLT		01
34	0503010208	HEX NUT 3/8 UNF G.5 ZN		01
35	0501311048	BEATER AXLE 230		01
36	0531066964	LEFT SIDE WHEEL CHASSIS		01



MARCHESAN

Technical Publications | Elaboration and Revision

LUIZ CANDIDO

www.marchesan.com.br

