

ROW CROP PLANTERS

PST DUO FLEX - FRAME 6350 - CSU (FROM 08/2022)

Code: 0501099007
Series: S-0119
Revision: 00
Date Revision: OUTUBRO/2022

PARTS CATALOGUE



MARCHESAN

PRODUCTS



Code	Description
0111240545	PST DUO FLEX 6350/13E500 ESPECIAL S-0119

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the consumer. The photos are only illustrative.



MARCHESAN

INDEX

0909096523	ASSY FRAME	1
0521054579	FRAME WITH ARTICULATION 6350	2
0521054574	RIGHT FRAME WITH WHEELED AXLE 6350	3
0521054575	FRAME LEFT WITH SHAFT WHEELED 6350	4
0511058667	SPRING FLOW ENSEMBLY	5
0521058402	WHEELED WITH 655 DRIFT SPRING WITH TRANSMISSION	6
0521058401	655 WHEELED SUPPORT WITH TRANSMISSION	7
0501058241	WHEEL SUPPORT CHAIN TENSIONER	8
0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH TRANSMISSION	9
0503063172	WHEEL	10
0521055233	WHEELED TRANSMISSION WITHOUT TIRE	11
0521055234	WHEELED FASTENER	12
0521055236	INTERMEDIARY CURRENT STRETCHER	13
0521055237	WHEEL FIXED CURRENT STRETCHER	14
0521055235	WHEEL MOBILE CURRENT STRETCHER	15
0521055238	BEARING TENSIONER CHAIN	16
0521054561	CYLINDER ASSEMBLY	17
0511058406	HYDRAULIC CYLINDER	18
0511056808	ASSY SYSTEM HYDRAULIC 6350	19
0501054694	FLOW DIVIDING VALVE ASSY	20
0501053834	MALE QUICK COUPLER	21
0909095186	DRAWBAR ASSY	22
0511055096	TRACTOR HITCH	23
0521053320	LEFT EXTENSION DRAWBAR 36.00 - 6350	24
0521053321	RIGHT EXTENSOR DRAWBAR 36,00 - 6350	25
0511052311	3 POINT TURNBUCKLE	26
0511056736	HOSE SUPPORT	27
0531056443	ALPHA FERTILIZER HOPPER SET	28
0531056570	LEFT HOPPER SUPPORT WITH FERTILIZER METERING	29
0531056571	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING	30
0501053788	3/4 SQUARE AXLE FASTENER	31
0531055292	ALPHA FERTILIZER METERING	32
0531055273	ALPHA FERTILIZER METERING CLAMP	33
0531055376	TRANSMISSION ALPHA FERTILIZER METERING HUB	34
0909095187	ASSEMBLY TRANSMISSION 4880/5340/5950/6350/6850	35
0501052560	MOTOR AXLE SIGNAL	36
0511051434	TRANSMISSION ACTUATOR	37
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	38
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	39
0521043316	RIGHT GEAR BOX ASSY	40
0501058212	SEMI MOUNTED RIGHT CHANGE	41
0521043317	LEFT GEAR BOX ASSY	42
0501058213	LH GEAR BOX	43
0511059266	CLOSED BEARING	44
0501056271	GEARBOX CLOSED BEARING	45
0501056443	GEAR HOUSING BEARING	46
0501056444	BEARING WITH ROLLER	47
0501048790	AXLE WITH RING	48
0501054655	CHAIN TENSIONER ASSY	49
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	50
0501055112	MICRO GRANULATED CHAIN TENSIONER	51
0521055217	LOWER CURRENT STRETCH	52
0501058254	UPPER SEED CHAIN TENSIONER	53
0521055216	BEARING WITH GEAR	54
0521055218	BEARING GEAR WITH DOUBLE	55



MARCHESAN

INDEX


0511054363	CHAIN TENSIONER	56
0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	57
0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	58
0521058394	WHEEL WITH PNEUME	59
0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	60
0521054565	PLATFORM ASSEMBLY 6350	61
0511056812	HANDRAIL ASSY 6350	62
0511054971	JACK ASSEMBLY	63
0511056536	LADDER ASSEMBLY	64
0511056809	SEMI MOUNTED HYDRAULIC MARKER 6350	65
0511058449	HYDRAULIC CYLINDER	66
0501054649	HBM SEQUENTIAL VALVE	67
0521055204	ROW MARKER DISC	68
0511058924	ASSEMBLY CSU C3 SEMI MOUNTED 6350	69
0511058802	2 HOPPERS WITH 13 CONDUCTORS ASSEMBLY	70
0511057690	3" ARTICULATED SEED CONDUCTOR	71
0521051927	TOWER SUPPORT HOPPER	72
0521054583	REAR LIGHTING ASSEMBLY	73
0521052792	MOUNTED REAR LIGHT	74
0521054585	MANUAL CANISTER ASSY	75
0521054181	TOOL BOX ASSEMBLY	76
0521054525	CONTAINER WATER TANK	77
0909095190	ASSY HEX AXLE	78
0521055214	BEARING GEAR WITH	79
0521055215	DOUBLE TRANSMISSION BEARING	80
0909096524	ASSY SEED/FERTILIZER ROW	81
0531055217	LEFT FRONT OF SHORT SEED ROW	82
0531055216	RIGHT FRONT OF SHORT SEED ROW	83
0531055213	LEFT FRONT OF LONG SEED ROW	84
0531055214	RIGHT FRONT OF LONG SEED ROW	85
0531055201	SEMI-ASSEMBLED RIGHT FRONT OF LONG SEED ROW	86
0521055213	SEED ROW BEARING	87
0511055260	SEED ROW CHAIN TENSIONER	88
0521055219	BEARING WITH GEAR 17Z HEX 5/8	89
0521055220	BEARING FRONT SEED ROW	90
0531055203	TRANSMISSION WITH AXLE	91
0531055206	298 TRANSMISSION HUB	92
0531055218	DRAGGER BEARING	93
0521055223	SEED ROW TRANSMISSION HUB	94
0531055205	BEARING WITH 168 AXLE	95
0531055199	SEMI-ASSEMBLED LONG FRAME	96
0531055340	BEARING WITH 408 AXLE	97
0531055555	LEFT REAR SEED ROW (QUICK CHANGING DISC)	98
0521055871	LEFT DOUBLE DISC SEED 15 X 15	99
0511052302	LH SUPPORT DDD GUIDE	100
0531055554	RIGHT REAR SEED ROW (QUICK CHANGING DISC)	101
0521055870	RIGHT DOUBLE DISC SEED 15 X 15	102
0511052301	SUPPORT DDD 15 RIGHT	103
0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	104
0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	105
0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 FERTILIZER / SEED	106
0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	107
0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	108
0521055065	ASSY DEPTH / COMPACTOR	109

INDEX

0501056769	DEPTH WHEELS REGULATOR ASSY	110
0521055033	SEMI-ASSEMBLED COMPACTOR BODY	111
0521055054	LEFT ARM WITH SLEEVE	112
0521055066	RIGHT ARM WITH SLEEVE	113
0521055068	RAYED WHEEL CENTER CLOSED	114
0521055055	HUB WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	115
0521054990	LEFT COMPACTOR WHEEL	116
0521055017	RIGHT COMPACTOR WHEEL	117
0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	118
0521054811	FERTILIZER SHORT ROW	119
0521053231	DPL 20 SHORT ROW WITHOUT LUBRICATION CONICAL BEARING	120
0521054812	LONG FERTILIZER ROW	121
0521053232	DPL 20 LONG ROW WITHOUT LUBRICATION CONICAL BEARING	122
0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	123
0521053697	DISC BLADE HUB	124
0521054906	SPRING ASSY FERTILIZER	125
0521054769	LEFT DDD FERTILIZER WITH SUPPORT	126
0521055869	LEFT DUAL FERTILIZER DISC	127
0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	128
0521055868	RIGHT DUAL FERTILIZER DISC	129
0531054901	SINGLE SEED HOPPER FRONT TRANSMISSION	130
0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	131
0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK LID	132
0531054895	FRONT TRANSMISSION SEED HOPPER SUPPORT	133
0531054795	FRONT TRANSMISSION ASSEMBLY	134
0521053947	AUTOMATIC DISARMING ROD	135
0521053951	STEM	136
0521053932	ROD WITH BEAK 0869	137
0503063785	SIGMA V2 CORN DISC SET	138
0503063786	SIGMA V2 SOY DISC SET	139
0521050525	FIXER FERTILIZER CONDUCTOR	140

ASSY FRAME

0909096523




Item	Code	Description	See page	QT
01	0521054579	FRAME WITH ARTICULATION 6350	2	01
02	0521064285	LOCK LOWER FRAME		01
03	0501010116	HEX NUT 1.5/8 7 FPP 2.3/8 ZN		01
04	0503010002	1800 GREASE FITTING		01
05	0503010003	1845 GREASE FITTING		05
06	0503010004	1890 GREASE FITTING		02
07	0511058667	SPRING FLOW ENSEMBLY	5	01
08	0521058402	WHEELED WITH 655 DRIFT SPRING WITH 6 TRANSMISSION	6	04
09	0521054561	CYLINDER ASSEMBLY	17	01
10	0511056808	ASSY SYSTEM HYDRAULIC 6350	19	01
11	0909095186	DRAWBAR ASSY	22	01
12	0511056736	HOSE SUPPORT	27	01
13	0531056443	ALPHA FERTILIZER HOPPER SET	28	01
14	0909095187	ASSEMBLY TRANSMISSION 4880/5340/5950/6350/6850	35	01
15	0521058404	WHEELED WITH 655 DRIFT SPRING WITHOUT TRANSMISSION	57	02
16	0521054565	PLATFORM ASSEMBLY 6350	61	01
17	0511056812	HANDRAIL ASSY 6350	62	01
18	0511054971	JACK ASSEMBLY	63	04
19	0511056536	LADDER ASSEMBLY	64	02
20	0511056809	SEMI MOUNTED HYDRAULIC MARKER 6350	65	01
21	0521055204	ROW MARKER DISC	68	02
22	0511058924	ASSEMBLY CSU C3 SEMI MOUNTED 6350	69	01
23	0521054583	REAR LIGHTING ASSEMBLY	73	01
24	0521054585	MANUAL CANISTER ASSY	75	01
25	0521013164	EXTENSOR		02
26	0501065677	STRUT		02
27	0541015451	FIXED KEY 2.3/8 X 2.3/4		01
28	0501047895	ROD STOP		02
29	0501047885	ROD STOP		02


ASSY FRAME

0909096523


Item	Code	Description	See page	QT
30	0501047886	ROD STOP		02
31	0501047887	ROD STOP		02
32	0521013022	TRANSPORT LOCK		02
33	0503030168	HITCH PIN CLIP		02
34	0501068994	8,30 X 78 LOCK PIN		02
35	0521054181	TOOL BOX ASSEMBLY	76	01
36	0521054525	CONTAINER WATER TANK	77	01
37	0503019262	SOAP DISH VACUUM		01
38	0503010780	N-2050 AMENDMENT		02
39	0503011750	AMENDMENT WITH LOCK		06
40	0503011751	REDUCTION		06
41	0503010951	REDUCTION		04
42	0909095190	ASSY HEX AXLE	78	01
43	0503010014	3/4" HEX NUT		02
44	0503010023	3/4" SPRING WASHER		02
45	0521065613	HOSE HOLDER		01
46	0503011953	5/16" X 1" BOLT		02
47	0503013816	5/16" LOCKNUT		02
48	0501011310	FIXER LOCK		08
49	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		08
50	0503010019	1/2" SPRING WASHER		08
51	0503010060	1/2 UNC G.5 ZN HEX NUT		08
52	0501214546	SPRING KEY		01
53	0909096524	ASSY SEED/FERTILIZER ROW	81	01




Item	Code	Description	See page	QT
01	0521054574	RIGHT FRAME WITH WHEELED AXLE 6350	3	01
02	0521054575	FRAME LEFT WITH SHAFT WHEELED 6350	4	01
03	0501110791	FRONT ARTICULATOR HUB WITH SLEEVES		01
04	0501110683	REAR HUB ARTICULATOR WITH SLEEVES		01
05	0501010098	3/4" UNC BOLT		09
06	0503011442	3/4" SPRING WASHER		09
07	0571010094	SLEEVE FLANGE		02
08	0521065616	ARTICULATION		01
09	0502012698	CLAMP		02
10	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
11	0503011444	SPRING WASHER		02
12	0571013510	LOCK AXLE		01
13	0503030085	LOCK PIN		01
14	0571010095	FLAT WASHER		01
15	0521063003	LOCK PIN		01
16	0571010969	LOCK SLEEVE FRAME		01
17	0503013627	1.1/2 SPRING WASHER		01
18	0501010110	1.1/2" NUT		01
19	0581018182	TROUGH 24 X 50 X 1750		02
20	0581018181	TROUGH 24 X 50 X 1250		02
21	0501011643	3/8 X 1" BOLT		08
22	0503010025	3/8" SPRING WASHER		08
23	0503010026	3/8" NUT		08
24	0501018059	3/4" X 2-1/4" BOLT		03
25	0503011255	3/4" LOCK NUT		03




Item	Code	Description	See page	QT
01	0521068948	RIGHT FRAME 6350		01
02	0521069432	RIGHT SIDE RIGHT ARTICULATED AXLE 6350		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0521068949	LEFT FRAME 6350		01
02	0521069433	LEFT ARTICULATED AXLE 6350		01
03	0521013199	LOWER BEARING SEMI		03
04	0503010899	5/8" X 2-1/4" BOLT		06
05	0501012140	FLAT WASHER		12
06	0531013922	0.6" X 0.8" X 1" SLEEVE		06
07	0503011445	SPRING WASHER		06
08	0503010013	5/8" NUT		06




Item	Code	Description	See page	QT
01	0511050681	TRACTION SPRING		06
01A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
01B	0561016062	SPRING HITCH		02
02	0503013030	5/8" X 3.1/4" BOLT		12
03	0501012140	FLAT WASHER		24




Item	Code	Description	See page	QT
01	0521058401	655 WHEELED SUPPORT WITH TRANSMISSION	7	01
02	0521055234	WHEELED FASTENER	12	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0501058241	WHEEL SUPPORT CHAIN TENSIONER	8	01
07	0521058393	WHEEL WITH PNEU 7.00X16 14L PR TT WITH 9 TRANSMISSION		01
08	0503018981	BOLT		02
09	0503010027	5/8" SPRING WASHER		04
10	0591010589	BODY LOCK WHEEL		01
11	0521069983	WHEEL COVER		01
12	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
13	0551017715	FLAT WASHER		02
14	0503013030	5/8" X 3.1/4" BOLT		01
15	0511050681	TRACTION SPRING		01
15A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
15B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	FERT CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503063172	WHEEL	10	01
02	0521055233	WHEELED TRANSMISSION WITHOUT TIRE	11	01




Item	Code	Description	See page	QT
01	0503019458	TIRE 7.00X16 14PR		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE	01	
02	0503010330	KM 9 LOCKNUT	01	
03	0503010329	LOCK WASHER	01	
04	0511015949	LOCK NUT	01	
05	0503010804	00547-B SEAL	02	
06	0503019364	BEARING 25590/25523	02	
07	0501110721	WHEEL HUB WITH SCREW / NUTS	01	
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION	01	
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR	06	
07C	0503016516	5/8 UNF CONIC NUT	06	
08	0502011339	15Z GEAR P 1.25"	01	
09	0503012550	5/16" X 3/4" BOLT	06	
10	0503010002	1800 GREASE FITTING	01	




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8" NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0521055236	INTERMEDIARY CURRENT STRETCHER	13	01
07	0521055237	WHEEL FIXED CURRENT STRETCHER	14	01
08	0521055235	WHEEL MOBILE CURRENT STRETCHER	15	01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN	16	01
02	0551018245	CHAIN TENSIONER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0551018239	SLEEVE 19 X 13,50 X 45		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN	16	01
02	0551018252	CHAIN TENSIONER AXLE		01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521055238	BEARING TENSIONER CHAIN	16	01
02	0551018244	CHAIN TENSIONER AXLE		01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503019355	BEARING 6202 2RS1		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01



Item	Code	Description	See page	QT
01	0511058406	HYDRAULIC CYLINDER	18	02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521015501	COUPLING SHAFT		02
04	0503010523	1/4" X 2" COTTERPIN		04
05	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		02
06	0531012565	SLEEVE 16,3X 30 X 88		02
07	0503010027	5/8" SPRING WASHER		02
08	0503010013	5/8" NUT		02




Item	Code	Description	See page	QT
01	0511064053	SLEEVE 2" X 14" TURNBUCLE		01
02	0511064052	4" X 12.1" CYLINDER CASE		01
03	0503010003	1845 GREASE FITTING		01
04	0503030385	CYLINDER PLUG N-002		02
05	0581010678	50,80 X 101 RING SUPPORT		01
06	0503015636	SCRAPER SEAL		01
07	0503018025	RING GUIDE		01
08	0503018026	1870-2000-375 B GASKET		01
09	0503010338	2-342 N 3006-9B O-RING		02
10	0503011061	8-342 BACK-UP RING		02
11	0502012822	101.60 END CAP		01
12	0503010817	1.1/4" SELF LOCKING NUT		01
13	0503010345	2-218 N 3006-9B O-RING		01
14	0503015633	SELEMASTER SEALING		01
15	0502012842	50,80 X 101,60 PISTON		01
16	0511032511	ASSY CYLINDER REPAIR KIT 50.8X101.6		01




Item	Code	Description	See page	QT
01	0571017027	VALVE SUPPORT		01
02	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		02
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0501054694	FLOW DIVIDING VALVE ASSY	20	01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0541012166	NIPPLE 3/4" UNF X 7/8"		01
11	0511018387	3/4" X 0,3 ADJUSTMENT VALVE NUT		01
12	0503011968	3/4" 8R6X-S T ADAPTER WITH SWIVEL NUT		01
13	0501053834	MALE QUICK COUPLER	21	02
14	0571011806	SPRING PROTECTION PLASTIC HOSE 3/4 X 600MM		02
15	0571017774	SPRING PROTECTION QUICK HOSE		01
16	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		03
17	0503010180	7/16" SPRING WASHER		03
18	0502012702	BODY SUPPORT CLAMP		03
19	0511057105	ASSY HYDRAULIC SYSTEM HOSE 6350		01
19A	0501080127	HOSE		01
19B	0501081998	HOSE 3/8 X 1300 TC-TC		01
19C	0501082001	TR-TC HOSE ASSY		01
19D	0501082000	TC-TC HOSE ASSY		01
20	0521052299	HOSE 1/2 X 4000 TR-TM BLACK / RED		01
20A	0501080185	HOSE 1/2 X 4000 TR-TM		01
20B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
20C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
20D	0503018952	PLASTIC BOLT		06
21	0521052300	HOSE 1/2 X 4000 TR-TM BLACK / BLUE		01
21A	0501080185	HOSE 1/2 X 4000 TR-TM		01
21B	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01

Item	Code	Description	See page	QT
21C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
21D	0503018952	PLASTIC BOLT		06
22	0503013100	NYLON CLAMP		02




Item	Code	Description	See page	QT
01	0503012481	FLOW DIVIDING VALVE		01
02	0503030923	3/4" UNF X 13/16UN OFS X 40 NIPPLE		03
03	0503010190	2-114 N 3006-9B O'RING		03



Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01

DRAWBAR ASSY

0909095186



Item	Code	Description	See page	4880	5340	5950	6350	6850
01	0521068561	LONG COUPLING DRAWBAR		001	001	001	001	001
02	0511055096	TRACTOR HITCH	23	001	001	001	001	001
03	0511053179	TRACTOR COUPLING SHAFT		001	001	001	001	001
03A	0521064036	TRACTOR HITCH AXLE		001	001	001	001	001
03B	0503030012	HITCH PIN CLIP		001	001	001	001	001
04	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		001	001	001	001	001
05	0503014120	CHAIN		001	001	001	001	001
06	0503014321	CABLE STEEL SHACKLE		002	002	002	002	002
07	0571010661	PIVOT SHAFT		001	001	001	001	001
08	0503010010	1/4" X 2.1/2" COTTERPIN		002	002	002	002	002
09	0521064203	EAR PIVOT DRAWBAR		001	001	001	001	001
10	0521053310	LEFT EXTENSION DRAWBAR 36.00 - 4880/5720/5950		001	000	001	000	000
10.	0531052545	LEFT EXTENSION DRAWBAR 36.00 - 4880/5950		001	000	000	000	000
10..	0521053313	LEFT EXTENSION DRAWBAR 36.00 - 5340		000	001	000	000	000
10...	0531052543	LEFT EXTENSION DRAWBAR 36.00 - 5340		000	001	000	000	000
10....	0521053320	LEFT EXTENSION DRAWBAR 36.00 - 6350	24	000	000	000	001	000
10.....	0531052540	DRAWBAR ASSY		000	000	000	001	000
10.....	0521053318	LEFT EXTENSION DRAWBAR 36.00 - 6850		000	000	000	000	001
11	0501010500	3/4"X3"BOLT		002	002	002	002	002
12	0503010023	3/4" SPRING WASHER		002	002	002	002	002
13	0503010014	3/4" HEX NUT		002	002	002	002	002
14	0571019949	JUNCTION SHAFT		002	002	002	002	002
15	0503030119	LOCK PIN		002	002	002	002	002
16	0521053311	RIGHT EXTENSOR DRAWBAR 36,00 - 4880/5720/5950		001	000	001	000	000
16.	0521053312	RIGHT EXTENSOR DRAWBAR 36,00 - 5340		000	001	000	000	000
16..	0521053321	RIGHT EXTENSOR DRAWBAR 36,00 - 6350	25	000	000	000	001	000
16...	0521053319	RIGHT EXTENSOR DRAWBAR 36,00 - 6850		000	000	000	000	001
17	0521010572	0.9" X 2.9" COUPLING SHAFT		001	001	001	001	001
18	0503030085	LOCK PIN		004	004	004	004	004
19	0521063528	EXTENDING FIXER		001	001	001	001	001


DRAWBAR ASSY

0909095186


Item	Code	Description	See page	4880	5340	5950	6350	6850
20	0501010171	BOLT 1 UNC X 3.1/2 C S G.5		003	003	003	003	003
21	0503010012	1" SPRING WASHER		003	003	003	003	003
22	0501010059	1.5/8 NUT		003	003	003	003	003
23	0521062916	LEFT FRENCH HAND		001	001	001	001	001
24	0521010585	0.9" X 5.9" COUPLING SHAFT		001	001	001	001	001
25	0511052311	3 POINT TURNBUCKLE	26	001	001	001	001	001
26	0521012532	0.9" X 3.9" COUPLING SHAFT		001	001	001	001	001
27	0521010582	COUPLING SHAFT		001	001	001	001	001
28	0521063529	LOCK AXLE		001	001	001	001	001
29	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		001	001	001	001	001
30	0501212237	HITCH SLEEVE ARTICULATED 85 X 35 MM		000	000	000	001	000

TRACTOR HITCH


0511055096



Item	Code	Description	See page	QT
01	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
02	0503010010	1/4" X 2.1/2" COTTERPIN		01
03	0503010571	1/4" X 1.1/2 COTTERPIN		01
04	0521010681	BUSHING COUPLING BODY		01
05	0521010639	COUPLING SHAFT		01
06	0503010002	1800 GREASE FITTING		01
07	0503016482	BOLT		02
08	0503033731	COMPRESSION SPRING LEFT		02
09	0503011331	3/8 BALL		02
10	0502040850	U TRACTOR COUPLING		01
11	0501110778	TRACTOR HITCH		01
11A	0502040853	HITCH JOINT		01
11B	0571014744	SLEEVE HITCH ARTICULATION 1.1/4		01
12	0503010396	501060 CLAMPING RING (FOR AXLE)		01
13	0581019654	ASSY BOLT		01




Item	Code	Description	See page	QT
01	0521064238	POINT FIXER EXTENDING LEFT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0521064237	POINT FIXER EXTENDING RIGHT		01
02	0501078990	TURNBUCLE AXLE		01
03	0521066338	EXTERNAL ROTATING BRIDGE		01
04	0561019879	LOCK ATTACHMENT BAR		01
05	0503010002	1800 GREASE FITTING		02

3 POINT TURNBUCKLE

0511052311




Item	Code	Description	See page	QT
01	0502012783	STABILIZER BODY GREATER		01
02	0571012279	JACK RIGHT		01
03	0571012280	JACK LEFT		01
04	0531010264	SIDE RATCHET		02
05	0521018500	SHAFT LEVER EXTENSOR		01
06	0511061881	RATCHET FOLLOWER		01
07	0521018920	0.4" X 0.5" X 0.2" SLEEVE		03
08	0503011179	3/8" X 2-1/4" BOLT		05
09	0503010025	3/8" SPRING WASHER		05
10	0503010026	3/8" NUT		05
11	0503010002	1800 GREASE FITTING		02



Item	Code	Description	See page	QT
01	0521065611	HOSE SUPPORT		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01

ALPHA FERTILIZER HOPPER SET

0531056443




Item	Code	Description	See page	QT
01	0531056570	LEFT HOPPER SUPPORT WITH FERTILIZER 29 METERING		01
02	0531056571	RIGHT HOPPER SUPPORT WITH FERTILIZER 30 METERING		01
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		24
04	0503010025	3/8" SPRING WASHER		12
05	0503010026	3/8" NUT		12
06	0503010849	3/8" X 1-1/2" BOLT		12
07	0571019051	FIXER HOPPER WASHER		20
08	0503013751	3/8 UNC X 1.1/4 BOLT		20
09	0503012535	3/8" SPRING WASHER		20
10	0503012531	3/8" INOX NUT		20
11	0503011957	NYLON LUG		02
12	0503010371	5/16" X 1" BOLT		04
13	0503010179	LOCK WASHER 5/16 ZN 1K01528		08
14	0503010337	5/16" NUT		08
15	0501010694	FLAT WASHER		04
16	0503011953	5/16" X 1" BOLT		04
17	0551019168	SLEEVE		02
18	0551019167	SLEEVE UNION		02
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		06
20	0503010479	BOLT		02
21	0503011336	1/2" HEX SELF ADJUSTING NUT		06
22	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		02
23	0503010019	1/2" SPRING WASHER		02
24	0503010060	1/2 UNC G.5 ZN HEX NUT		02
25	0501013518	FLAT WASHER		06
26	0503010140	1/8" X 3/4" COTTERPIN		06
27	0511069678	LH LOWER LEVER		02
28	0561016468	FASTENER		02
29	0521061741	INNTER LEVER		02
30	0551019159	LEVER FIXER BODY		02




ALPHA FERTILIZER HOPPER SET

0531056443


Item	Code	Description	See page	QT
31	0581012605	GEAR BOX LEVER LOCK		02
32	0503062362	FERTILIZER HOPPER		02
33	0503062927	FERTILIZER HOPPER		02
34	0501215701	ARM/DISARM LEVER		02




Item	Code	Description	See page	QT
01	0521014167	CONE LOCK		01
02	0511061759	22Z P12,70 FQ 3/4" GEAR		01
03	0501053788	3/4 SQUARE AXLE FASTENER	31	07
04	0501110392	HOPPER SUPPORT BEARING		01
05	0521012485	GEAR BOX BEARING AGRICUTURAL		01
06	0521011039	FLAT WASHER		02
07	0503010003	1845 GREASE FITTING		01
08	0531064696	LEFT FERTILIZER HOPPER SUPPORT		01
09	0503011953	5/16" X 1" BOLT		02
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
11	0503010337	5/16" NUT		02
12	0531055292	ALPHA FERTILIZER METERING	32	07
13	0501214267	3/4 X 855 SQUARE AXLE		01
14	0571017647	3/4 X 630 SQUARE AXLE		01
15	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		02
15A	0501214269	SQUARE SLEEVE		01
15B	0513010701	LOCK PIN		01
16	0503031527	AGRICULTURAL BEARING		06
17	0551015363	SQUARE AXLE		01



Item	Code	Description	See page	QT
01	0521014167	CONE LOCK		01
02	0511061759	22Z P12,70 FQ 3/4" GEAR		01
03	0501053788	3/4 SQUARE AXLE FASTENER	31	07
04	0501110392	HOPPER SUPPORT BEARING		01
05	0521012485	GEAR BOX BEARING AGRICUTURAL		01
06	0521011039	FLAT WASHER		02
07	0503010003	1845 GREASE FITTING		01
08	0531064697	RIGHT FERTILIZER HOPPER SUPPORT		01
09	0503011953	5/16" X 1" BOLT		02
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
11	0503010337	5/16" NUT		02
12	0531055292	ALPHA FERTILIZER METERING	32	07
13	0501214267	3/4 X 855 SQUARE AXLE		01
14	0571017647	3/4 X 630 SQUARE AXLE		01
15	0531055301	TRANSMISSION SLEEVE WITH LOCK PIN		02
15A	0501214269	SQUARE SLEEVE		01
15B	0513010701	LOCK PIN		01
16	0503031527	AGRICULTURAL BEARING		06
17	0551015363	SQUARE AXLE		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0503010025	3/8" SPRING WASHER		04
02	0503010026	3/8" NUT		04
03	0513010742	RETAINER 47 X 30 X 10 BRG 5285		01
04	0501214879	HORIZONTAL SEAL LID ALPHA FERTILIZER METERING		01
05	0503035799	ALPHA FERTILIZER DOSAGE NOZZLE		01
06	0503035831	ALPHA FERTILIZER METERING COLLECTOR		01
07	0531055273	ALPHA FERTILIZER METERING CLAMP	33	01
08	0513010692	ALLEN SCREW 1/4 UNC X 7/8 C FLAT SI INOX		04
09	0501011643	3/8 X 1" BOLT		04
10	0503035796	REAR FIXER ALPHA FERTILIZER METERING COLLECTOR		02
11	0513010695	ALLEN SCREW 1/4 UNC X 7/8 CCSI INOX		04
12	0531055376	TRANSMISSION ALPHA FERTILIZER METERING 34 HUB		01
13	0502013049	ALPHA FERTILIZER DOSAGE HOPPER		01
14	0502013048	FLANGE FIXER BODY ALPHA FERTILIZER METERING		01
15	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
15A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
15B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
16	0503035829	ADHESIVE LABEL LOGO TATU 38 X 28 X 0.30 ALPHA FERTILIZER METERING		01
17	0531055518	WORM THREAD ASSEMBLED		01
17A	0531064265	WORM THREAD		01
17B	0503035859	SUPPORT SLEEVE		01
18	0501111143	COATING WITH GUIDE ASSY SUPPLEMENTATION FERTILIZER METERING		01
18A	0501214951	FERTILIZER DOSAGE COATING		01
18B	0531055519	GUIDE ASSY WITH SUPPLEMENTATION		01

ALPHA FERTILIZER METERING CLAMP


0531055273



Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0502013050	TRANSMISSION ALPHA FERTILIZER METERING HOPPER		01
02	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
03	0503011800	SEAL RING		02
04	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
05	0503016065	ROLLER BEARING		02
06	0501214237	TRANSMISSION HOPPER ALPHA FERTILIZER METERING SLEEVE		01
07	0503019373	6006 2RS1 NATIONAL BEARING		02
08	0503012858	502075 CLAMPING RING (FOR HOLE)		01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01
10	0501214501	ALPHA FERTILIZER METERING LID LOCK AXIS		01
11	0501214238	SHAFT LOCK SLEEVE HOPPER TRANSMISSION ALPHA FERTILIZER METERING		01
12	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01




Item	Code	Description	See page	4880	5340	5950	6350	6850
00a	0511056751	RIGHT TRANSMISSION ASSY - 4880		001	000	000	000	000
00b	0511056752	LEFT TRANSMISSION ASSY - 4880		001	000	000	000	000
00c	0511056541	RIGHT TRANSMISSION ASSEMBLY 5340		000	001	000	000	000
00d	0511056542	LEFT TRANSMISSION ASSEMBLY 5340		000	001	000	000	000
00e	0511056818	RIGHT TRANSMISSION ASSY 5950		000	000	001	000	000
00f	0511056819	LEFT TRANSMISSION ASSY 5950		000	000	001	000	000
00g	0511056824	RIGHT TRANSMISSION ASSEMBLY 6350		000	000	000	001	000
00h	0511056825	LEFT TRANSMISSION ASSEMBLY 6350		000	000	000	001	000
00i	0511056830	RIGHT TRANSMISSION ASSEMBLY 6850		000	000	000	000	001
00j	0511056831	LEFT TRANSMISSION ASSEMBLY 6850		000	000	000	000	001
01	0501110639	BEARING		008	008	008	008	008
02	0503011099	GREASE FITTING		008	008	008	008	008
03	0503010300	5/32" X 1" COTTERPIN		008	008	008	008	008
04	0551019114	MOTOR BEARING AXLE SUPPORT		004	004	004	004	004
05	0521014021	1/2" X 4.5" X 5.4" FASTENER		004	004	004	004	004
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		008	008	008	008	008
07	0503010019	1/2" SPRING WASHER		008	008	008	008	008
08	0503010060	1/2 UNC G.5 ZN HEX NUT		008	008	008	008	008
09	0561016876	MOTOR SHAFT		002	000	000	000	000
09.	0571017428	MOTOR SHAFT		000	002	000	000	000
09..	0571011442	MOTOR SHAFT		000	000	002	000	000
09...	0571013750	MOTOR AXLE 3060		000	000	000	002	000
09....	0571017032	MOTOR SHAFT		000	000	000	000	002
10	0501018466	FLAT WASHER		004	004	004	004	004
11	0511015961	LOCK BUSHING		004	004	004	004	004
12	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		004	004	004	004	004
13	0503010060	1/2 UNC G.5 ZN HEX NUT		004	004	004	004	004
14	0501052560	MOTOR AXLE SIGNAL	36	002	002	002	002	002
15	0511051434	TRANSMISSION ACTUATOR	37	004	004	004	004	004
16	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	38	001	001	001	001	001
17	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	39	001	001	001	001	001

Item	Code	Description	See page	4880	5340	5950	6350	6850
18	0521043316	RIGHT GEAR BOX ASSY	40	001	001	001	001	001
19	0521043317	LEFT GEAR BOX ASSY	42	001	001	001	001	001
20	0503014734	BOLT		006	006	006	006	006
21	0503010920	1/2 UNC X 1.1/2 C S G.5 ZN BOLT		004	004	004	004	004
22	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		008	008	008	008	008
23	0503010019	1/2" SPRING WASHER		010	010	010	010	010
24	0503010060	1/2 UNC G.5 ZN HEX NUT		010	010	010	010	010
25	0521064448	GEAR		002	002	002	002	002
26	0501055112	MICRO GRANULATED CHAIN TENSIONER	51	002	002	002	002	002
27	0521055217	LOWER CURRENT STRETCH	52	002	002	002	002	002
28	0501058254	UPPER SEED CHAIN TENSIONER	53	002	002	002	002	002
29	0521055216	BEARING WITH GEAR	54	002	002	002	002	002
30	0521055218	BEARING GEAR WITH DOUBLE	55	002	002	002	002	002
31	0521055214	BEARING GEAR WITH	79	002	002	002	002	002
32	0503012204	40-1 CHAIN X 82 LINK + RED		002	002	002	002	002
33	0503012707	40-1 CHAIN X 96 LINK + REDUCTION		002	002	002	002	002
34	0503012718	40-1 CHAIN X 111 LINK + MENDING		002	002	002	002	002
35	0503014907	40-1 X 151 CHAIN LINK + MENDING		002	002	002	002	002
36	0503010256	3/8" X 3/4" BOLT		002	002	002	002	002
37	0503010025	3/8" SPRING WASHER		002	002	002	002	002
38	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		002	002	002	002	002
39	0501010637	FLAT WASHER		004	004	004	004	004
40	0503030275	AGRICULTURAL BEARING		002	002	002	002	002
41	0511054363	CHAIN TENSIONER	56	002	002	002	002	002




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01



Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02

RIGHT SIDE TRANSMISSION ACTUATOR


0511047069



Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

LEFT SIDE TRANSMISSION ACTUATOR


0511047070




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01

RIGHT GEAR BOX ASSY

0521043316




Item	Code	Description	See page	QT
01	0501058212	SEMI MOUNTED RIGHT CHANGE	41	01
02	0511059266	CLOSED BEARING	44	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	46	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	48	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	49	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	50	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069565	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01

LEFT GEAR BOX ASSY


0521043317



Item	Code	Description	See page	QT
01	0501058213	LH GEAR BOX	43	01
02	0511059266	CLOSED BEARING	44	05
03	0503030303	SUPPORT WASHER		05
04	0511067501	26Z GEAR		02
05	0521018630	1.4" X SQUARE 0.8" WASHER		04
06	0511060396	DRIVE/DRIVEN SHAFT		04
07	0503010834	1/2 X 1 BOLT		04
08	0503010060	1/2 UNC G.5 ZN HEX NUT		04
09	0503031512	0.4" X 0.1" X 2" X 0.6" SPRING		04
10	0503012389	1/2 BALL		04
11	0503012204	40-1 CHAIN X 82 LINK + RED		02
12	0501056443	GEAR HOUSING BEARING	46	02
13	0503010292	701164 6 X 40 SPRING PIN		08
14	0551018209	DRIVING AXLE		01
15	0503031805	11Z 1/2" GEAR		04
16	0503010302	501019 SEAL RING		04
17	0501048790	AXLE WITH RING	48	02
18	0503010002	1800 GREASE FITTING		02
19	0501054655	CHAIN TENSIONER ASSY	49	01
20	0521018259	DRIVEN AXLE		01
21	0551018210	DRIVEN AXLE		01
22	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	50	01
23	0503012713	40-1 CHAIN X 45 LINK + MEN		01
24	0511061830	17Z P 0.5" GEAR SQUARE HOL		02
25	0503010256	3/8" X 3/4" BOLT		01
26	0503010025	3/8" SPRING WASHER		01
27	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
28	0503030275	AGRICULTURAL BEARING		01
29	0551018211	INTERM SHAFT		01




Item	Code	Description	See page	QT
01	0511069566	LEFT GEAR BOX		01
02	0502011758	REAR TIGHTENER LEVER		02
03	0503010292	701164 6 X 40 SPRING PIN		02
04	0511061794	CHAIN TENSIONER		01
05	0503031367	SPRING		01
06	0511060392	CHAIN TENSIONER		01
07	0503031366	RIGHT TWISTED SPRING		01




Item	Code	Description	See page	QT
01	0501056271	GEARBOX CLOSED BEARING	45	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02

GEARBOX CLOSED BEARING


0501056271




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	47	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503010762	SCREW 5/8 UNC X 3.1/2 CS G.5 ZN		01
02	0501012140	FLAT WASHER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0531017086	50 AXLETIGHTENER		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503019356	BEARING 6005 2RS1		01
07	0503011105	SEAL RING		01
08	0503010027	5/8" SPRING WASHER		01
09	0503010013	5/8" NUT		01




Item	Code	Description	See page	QT
01	0521018933	FERT CHAIN TENSIONER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0501011234	5/8" X 3" BOLT		01
02	0531017086	50 AXLETIGHTENER		01
03	0521069698	GEAR 21Z P 1/2		01
04	0503019356	BEARING 6005 2RS1		01
05	0503011105	SEAL RING		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		01
07	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0503016460	5/8" X 4.1/2" BOLT		01
02	0551019175	DOUBLE GEAR AXLE		01
03	0503019356	BEARING 6005 2RS1		02
04	0511069680	20Z X 28Z DOBLE GEAR		01
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503012412	5/8 UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0521058403	655 WHEELED BRACKET WITHOUT TRANSMISSION	58	01
02	0502010584	CARRYING-WHEELS SUPPORT FIXER		02
03	0503011119	7/8" X 6" BOLT		04
04	0501014251	FLAT WASHER		04
05	0503011254	7/8" HEX SELF ADJUSTING NUT		04
06	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
07	0503010027	5/8" SPRING WASHER		02
08	0551017715	FLAT WASHER		02
09	0503013030	5/8" X 3.1/4" BOLT		01
10	0511050681	TRACTION SPRING		01
10A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
10B	0561016062	SPRING HITCH		02




Item	Code	Description	See page	QT
01	0531062422	WHEEL ARM		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" COTTERPIN		01
05	0503010003	1845 GREASE FITTING		01
06	0503018981	BOLT		02
07	0503010027	5/8" SPRING WASHER		02
08	0591010589	BODY LOCK WHEEL		02
09	0521058394	WHEEL WITH PNEUME	59	01




Item	Code	Description	See page	QT
01	0503063172	WHEEL	10	01
02	0521055244	WHEEL WITHOUT TRANSMISSION WITHOUT TIRE	60	01




Item	Code	Description	See page	QT
01	0521012185	TRANSMISSION WHEEL AXLE		01
02	0503010330	KM 9 LOCKNUT		01
03	0503010329	LOCK WASHER		01
04	0511015949	LOCK NUT		01
05	0503010804	00547-B SEAL		02
06	0503019364	BEARING 25590/25523		02
07	0501110721	WHEEL HUB WITH SCREW / NUTS		01
07A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
07B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
07C	0503016516	5/8 UNF CONIC NUT		06
08	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0521069419	RIGHT PLATFORM 6350		01
02	0521069424	LEFT PLATFORM 6350		01
03	0581015863	PLATFORM ENHANCEMENT PROTECTION		01
04	0501010942	3/8" X 1-1/4" BOLT		02
05	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		18
06	0503010025	3/8" SPRING WASHER		10
07	0503010026	3/8" NUT		10
08	0502012739	PLATFORM LEFT FIXER SUPPORT		01
09	0502012740	PLATFORM RIGHT FIXER SUPPORT		01
10	0503011333	COVER FIXER		02
11	0503010274	5/32"X 2" COTTERPIN		02
12	0521068316	JOINT SUPPORT		04
13	0503010741	1/2" X 2-3/4" BOLT		04
14	0503011336	1/2" HEX SELF ADJUSTING NUT		04
15	0521010549	COUPLING SHAFT		04
16	0503030168	HITCH PIN CLIP		04
17	0503010849	3/8" X 1-1/2" BOLT		08




Item	Code	Description	See page	QT
01	0521064028	HANDRAIL 6350		02
02	0503010395	1/2" X 1-1/4" BOLT		04
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08
06	0503034094	22 TWISTED CHAIN		02
07	0571017991	CHAIN FIXER HANDRAIL		04
08	0551019884	45 X 50 X 3/8 FASTENER		04
09	0503013357	3/8" SELF-ADJUSTING NUT		08



Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8 UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8" SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN	02	
08	0503013357	3/8" SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0511069622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		08
03	0503011070	BEATER		02
04	0503010019	1/2" SPRING WASHER		02
05	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
06	0551019213	FLAT WASHER		02
07	0511061811	ROW MARKER ARM		02
08	0521061655	BOLT 5/8 UNC X 320 MM		02
09	0521010479	SLEEVE ARTICULATION		04
10	0511058449	HYDRAULIC CYLINDER	66	02
11	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
12	0503010523	1/4" X 2" COTTERPIN		02
13	0511015779	1" X 4.2" AXLE		02
14	0503010523	1/4" X 2" COTTERPIN		02
15	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
16	0501068994	8,30 X 78 LOCK PIN		02
17	0503030168	HITCH PIN CLIP		02
18	0501066949	1235 TURNBUCKLE		02
19	0511016156	BOLT 5/8 UNC X1.1/2 CS PC G.5 ZN		04
20	0501054649	HBM SEQUENTIAL VALVE	67	01
21	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
22	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
23	0503010025	3/8" SPRING WASHER		02
24	0511057102	HOSE KIT MARKER HIDRAULICO 6350		01
24A	0501081794	TR-TC HOSE ASSY		01
24B	0501081999	3/8 X 4050 TR-TC HOSE ASSY		01
24C	0501080612	HOSE 3/8 X 4450 TR-TC		01
24D	0501082002	3/8 X 4650 TC-TC HOSE ASSY		01
25	0521052417	HOSE 3/8 X 4000 TR-TM PURPLE / RED		01
25A	0501080361	3/8" X 157" TR-TM HOSE		01
25B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01


Item	Code	Description	See page	QT
25C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
25D	0503018952	PLASTIC BOLT		06
26	0521052418	HOSE 3/8 X 4000 TR-TM PURPLE / BLUE		01
26A	0501080361	3/8" X 157" TR-TM HOSE		01
26B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26D	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	21	02
28	0571017773	SPRING PROTECTION PLASTIC HOSE 3/4		02
29	0502012702	BODY SUPPORT CLAMP		06
30	0531011180	UPPER BODY CLIP		04
31	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
32	0503011103	7/16" X 2-1/2" BOLT		02
33	0501012803	FLAT WASHER		02
34	0503010180	7/16" SPRING WASHER		06
35	0503010244	7/16" NUT		02
36	0503012412	5/8 UNC SELF LOCKING NUT		10
37	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0521069643	DISC AXLE MARKER ROW		01
02	0602023094	DR16X3 C36AFPAFR73+4FR+4FR D474 10R		01
03	0581019513	DEPTH WHEEL HUB		01
04	0503019342	ROLLER BEARING		01
05	0581019168	DUST CLOAK		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503013758	1/4" X 1-1/2" BOLT		03
11	0503010143	1/4" SPRING WASHER		03
12	0503010358	5/16" X 5/8" BOLT		04
13	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
14	0503010337	5/16" NUT		04
15	0503034055	CLAMPING RING		01




Item	Code	Description	See page	QT
01	0511058802	2 HOPPERS WITH 13 CONDUCTORS ASSEMBLY	70	01
02	0501010942	3/8" X 1-1/4" BOLT		08
03	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		08
04	0503010025	3/8" SPRING WASHER		08
05	0503010026	3/8" NUT		08
06	0521051927	TOWER SUPPORT HOPPER	72	04



Item	Code	Description	See page	QT
01	0521063401	SINGLE SEED HOPPER FIXING LOCK		04
02	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
03	0503010025	3/8" SPRING WASHER		60
04	0503010026	3/8" NUT		60
05	0511057690	3" ARTICULATED SEED CONDUCTOR	71	13
06	0571015773	SUPPORT SEED		01
07	0501011643	3/8 X 1"BOLT		04
08	0501010942	3/8" X 1-1/4" BOLT		52
09	0521064874	07 NOZZLES SINGLE SEED HOPPER SUPPORT		02
10	0503062165	HOPPER FERTILIZER 07 MOUTHS FRONT		02




Item	Code	Description	See page	QT
01	0571015779	COVER SUPPORT CONDUCTOR ARTICULATION		01
02	0501010942	3/8" X 1-1/4" BOLT		01
03	0503010025	3/8" SPRING WASHER		01
04	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		01
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0521066332	CONDUCTOR WITH FLANGE		01
07	0503010371	5/16" X 1" BOLT		02
08	0501010694	FLAT WASHER		02
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
10	0503010337	5/16" NUT		02
11	0502012767	FIXER CONDUCTOR SEED CSU SUPPORT		01




Item	Code	Description	See page	QT
01	0521066208	HOPPER SUPPORT TOWER		01
02	0502010175	HITCH CLAMP		01
03	0503011084	3/4" X 5" BOLT		02
04	0503011075	3/4" UNC NUT		02

REAR LIGHTING ASSEMBLY


0521054583




Item	Code	Description	See page	QT
01	0503014745	2 X 2,5 MM ELECTRIC CABLE		18mt
02	0503013151	ELECTRIC CONNECTION		01
03	0503015482	CONNECTOR		02
04	0503012903	T-80M CRAMP NYLON		50
05	0521052792	MOUNTED REAR LIGHT	74	02
06	3505151602	TUBE		0,3mt
07	0503017702	FIXER		14




Item	Code	Description	See page	QT
01	0503018738	LIGHTHOUSE		01
02	0581016999	REAR LIGHT SUPPORT		01
03	0551019884	45 X 50 X 3/8 FASTENER		02
04	0503010025	3/8" SPRING WASHER		04
05	0503010026	3/8" NUT		04
06	0503016506	5/16 UNC X 3/4 C S G.5 ZN BOLT		04
07	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
08	0503010337	5/16" NUT		04



Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01
07	0511033413	PACKAGING WITH MANUAL / CATALOG		01




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0521069295	SUPPORT TOOL CHEST		01
06	0581017000	PLATE INTERMEDIARY		02
07	0503034772	BOX		01
08	0501011643	3/8 X 1"BOLT		04
09	0503010025	3/8" SPRING WASHER		04
10	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0521014021	1/2" X 4.5" X 5.4" FASTENER		02
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
03	0503010019	1/2" SPRING WASHER		04
04	0503010060	1/2 UNC G.5 ZN HEX NUT		04
05	0521069405	WATER TANK SUPPORT		01
06	0503014820	BLACK WATER RESERVOIR		01

ASSY HEX AXLE


0909095190




Item	Code	Description	See page	4880	5340	5950	6350	6850
01	0531016944	RIGHT 5/8" X 96" HEX AXLE		001	000	000	000	000
01.	0561019199	5/8" X 2275 AXLE HEX		001	000	000	000	000
02	0571017427	5/8 X 2700 HEX AXLE		000	001	000	000	000
02.	0571017425	5/8 X 2530 HEX AXLE		000	001	000	000	000
03	0561018502	SHAFT AXIS 5/8 X 3000		000	000	001	001	000
03.	0571011980	5/8 X 2810 HEX AXLE		000	000	001	000	000
04	0531016949	LEFT 5/8" X 125" AXLE HEX		000	000	000	001	000
04.	0561018502	SHAFT AXIS 5/8 X 3000		000	000	000	001	000
05	0571017030	SHAFT AXLE 5 / 8X3450 14E500		000	000	000	000	001
05.	0571017029	5/8 X 3280 HEX AXLE		000	000	000	000	001
05..	0571017030	SHAFT AXLE 5 / 8X3450 14E500		000	000	000	000	001
05...	0571017029	5/8 X 3280 HEX AXLE		000	000	000	000	001
06	0561014215	BEARING COVER LOWER ROW FRAME		002	002	002	002	002
07	0521055214	BEARING GEAR WITH	79	002	002	002	002	002
08	0502040534	SPRING GUIDE BUSHING LOCK		004	004	004	004	004
09	0501018535	1/2 X 1 BOLT		004	004	004	004	004



Item	Code	Description	See page	QT
01	0511063106	20Z AXLE BEARING DOUBLE		01
02	0503010406	501025 CLAMPING RING (FOR AXLE)		02
03	0521055215	DOUBLE TRANSMISSION BEARING	80	01
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0502011987	DOUBLE HOUSING BEARING		01
02	0503019356	BEARING 6005 2RS1		02
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531055217	LEFT FRONT OF SHORT SEED ROW	82	01
02	0531055216	RIGHT FRONT OF SHORT SEED ROW	83	01
03	0531055213	LEFT FRONT OF LONG SEED ROW	84	01
04	0531055214	RIGHT FRONT OF LONG SEED ROW	85	01
05	0531055201	SEMI-ASSEMBLED RIGHT FRONT OF LONG SEED ROW	86	01
06	0531055199	SEMI-ASSEMBLED LONG FRAME	96	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		01
08	0503010019	1/2" SPRING WASHER		01
09	0503010060	1/2 UNC G.5 ZN HEX NUT		01
10	0531055555	LEFT REAR SEED ROW (QUICK CHANGING DISC)	98	01
11	0531055554	RIGHT REAR SEED ROW (QUICK CHANGING DISC)	101	01
12	0521055053	DEPTH/COMPACTOR SYSTEM - SPCRR	108	01
13	0521054811	FERTILIZER SHORT ROW	119	01
14	0521054812	LONG FERTILIZER ROW	121	01
15	0521054769	LEFT DDD FERTILIZER WITH SUPPORT	126	01
16	0521054768	RIGHT DDD FERTILIZER WITH SUPPORT	128	01
17	0531054901	SINGLE SEED HOPPER FRONT TRANSMISSION	130	01
18	0531055227	TRANSMISSION SLEEVE WITH LOCK PIN		01
18A	0501214219	TRANSMISSION TRACTION SLEEVE		01
18B	0513010701	LOCK PIN		01
19	0521053947	AUTOMATIC DISARMING ROD	135	01
20	0503031076	2" HOSE CLAMP		01
21	0503031145	2" X 2" X 20" HOSE		01
22	0581010082	FERTILIZER SOCKET RIGHT		01
23	0581010083	FERTILIZER SOCKET LEFT		01
24	0503063785	SIGMA V2 CORN DISC SET	138	01
25	0503063786	SIGMA V2 SOY DISC SET	139	01
26	0503035755	440 SEED NOZZLE		01
27	0521068982	DISC BLADE HUB KEY		01
28	0503010905	1/2" X 2-1/4" BOLT		01
29	0503010019	1/2" SPRING WASHER		01



ASSY SEED/FERTILIZER ROW

0909096524

Item	Code	Description	See page	QT
30	0503010060	1/2 UNC G.5 ZN HEX NUT		01
31	0531013600	PRESS ADJUSTMENT LEVER		01
32	0571011730	SEED CONDUCTOR 3" X 1500		01
33	0521050525	FIXER FERTILIZER CONDUCTOR	140	01
34	0503031050	CURVED CONDUCTOR		01
35	0503010246	CLAMP		01




Item	Code	Description	See page	QT
01	0521055213	SEED ROW BEARING	87	02
02	0503011953	5/16" X 1" BOLT		04
03	0501010694	FLAT WASHER		04
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
05	0503010337	5/16" NUT		04
06	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
07	0561019032	SEED FERTIL ROW LOCK		01
08	0503010071	3/16" X 1" COTTERPIN		01
09	0503030168	HITCH PIN CLIP		01
10	0521010773	0.37" X 1.18" COUPLING SHAFT		01
11	0503010140	1/8" X 3/4" COTTERPIN		01
12	0503012412	5/8 UNC SELF LOCKING NUT		04
13	0511055260	SEED ROW CHAIN TENSIONER	88	01
14	0502012782	17Z GEAR WITH HEX HOLE		01
15	0521064651	LEFT SEED ROW SUPPORT FRONT		01
16	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
17	0502012568	UPPER ROCKER ARM		01
18	0561014904	TRANSMISSION AXLE FRAME ROW		01
19	0501011388	COUPLING SHAFT		02
20	0521055219	BEARING WITH GEAR 17Z HEX 5/8	89	01
21	0502012789	FIXER SUPPORT FERTILIZER ROW		01
22	0503017857	BOLT 5/8 UNF 4		04
23	0503010811	5/8" UNF SELF ADJUSTING NUT		04
24	0503034580	TRACTION SPRING		02
25	0581017624	SPACING SLEEVE		06
26	0503019273	AUTO LUBRICANT SLEEVE		08
27	0581017626	SPACER		01
28	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
29	0503010045	O'RING		08
30	0581018487	FIXER UPPER SPRING		01
31	0502012911	TOP ARM SEED ROW		01



LEFT FRONT OF SHORT SEED ROW

0531055217


Item	Code	Description	See page	QT
32	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
33	0531064032	SEED ROW FRAME		01
34	0531055203	TRANSMISSION WITH AXLE	91	01



Item	Code	Description	See page	QT
01	0521055213	SEED ROW BEARING	87	02
02	0503011953	5/16" X 1" BOLT		04
03	0501010694	FLAT WASHER		04
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
05	0503010337	5/16" NUT		04
06	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
07	0561019032	SEED FERTIL ROW LOCK		01
08	0503010071	3/16" X 1" COTTERPIN		01
09	0503030168	HITCH PIN CLIP		01
10	0521010773	0.37" X 1.18" COUPLING SHAFT		01
11	0503010140	1/8" X 3/4" COTTERPIN		01
12	0503012412	5/8 UNC SELF LOCKING NUT		04
13	0511055260	SEED ROW CHAIN TENSIONER	88	01
14	0502012782	17Z GEAR WITH HEX HOLE		01
15	0521064653	RIGTH SEED ROW SUPPORT FRONT		01
16	0503016014	40-1 CHAIN X 92 LINK + REDUCTION		01
17	0502012568	UPPER ROCKER ARM		01
18	0561014904	TRANSMISSION AXLE FRAME ROW		01
19	0501011388	COUPLING SHAFT		02
20	0521055219	BEARING WITH GEAR 17Z HEX 5/8	89	01
21	0502012789	FIXER SUPPORT FERTILIZER ROW		01
22	0503017857	BOLT 5/8 UNF 4		04
23	0503010811	5/8" UNF SELF ADJUSTING NUT		04
24	0503034580	TRACTION SPRING		02
25	0581017624	SPACING SLEEVE		06
26	0503019273	AUTO LUBRICANT SLEEVE		08
27	0581017626	SPACER		01
28	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
29	0503010045	O'RING		08
30	0581018487	FIXER UPPER SPRING		01
31	0502012911	TOP ARM SEED ROW		01



Item	Code	Description	See page	QT
32	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
33	0531064032	SEED ROW FRAME		01
34	0531055203	TRANSMISSION WITH AXLE	91	01




Item	Code	Description	See page	QT
01	0521055213	SEED ROW BEARING	87	02
02	0503011953	5/16" X 1" BOLT		04
03	0501010694	FLAT WASHER		04
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
05	0503010337	5/16" NUT		04
06	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
07	0561019032	SEED FERTIL ROW LOCK		01
08	0503010071	3/16" X 1" COTTERPIN		01
09	0503030168	HITCH PIN CLIP		01
10	0521010773	0.37" X 1.18" COUPLING SHAFT		01
11	0503010140	1/8" X 3/4" COTTERPIN		01
12	0503012412	5/8 UNC SELF LOCKING NUT		04
13	0511055260	SEED ROW CHAIN TENSIONER	88	01
14	0502012782	17Z GEAR WITH HEX HOLE		01
15	0521064650	LEFT SEED ROW SUPPORT FRONT		01
16	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
17	0502012568	UPPER ROCKER ARM		01
18	0561014904	TRANSMISSION AXLE FRAME ROW		01
19	0501011388	COUPLING SHAFT		02
20	0521055219	BEARING WITH GEAR 17Z HEX 5/8	89	01
21	0502012789	FIXER SUPPORT FERTILIZER ROW		01
22	0503017857	BOLT 5/8 UNF 4		04
23	0503010811	5/8" UNF SELF ADJUSTING NUT		04
24	0503034580	TRACTION SPRING		02
25	0581017624	SPACING SLEEVE		06
26	0503019273	AUTO LUBRICANT SLEEVE		08
27	0581017626	SPACER		01
28	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
29	0503010045	O'RING		08
30	0581018487	FIXER UPPER SPRING		01
31	0502012911	TOP ARM SEED ROW		01



LEFT FRONT OF LONG SEED ROW

0531055213

Item	Code	Description	See page	QT
32	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
33	0531064032	SEED ROW FRAME		01
34	0531055203	TRANSMISSION WITH AXLE	91	01




Item	Code	Description	See page	QT
01	0521055213	SEED ROW BEARING	87	02
02	0503011953	5/16" X 1" BOLT		04
03	0501010694	FLAT WASHER		04
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
05	0503010337	5/16" NUT		04
06	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
07	0561019032	SEED FERTIL ROW LOCK		01
08	0503010071	3/16" X 1" COTTERPIN		01
09	0503030168	HITCH PIN CLIP		01
10	0521010773	0.37" X 1.18" COUPLING SHAFT		01
11	0503010140	1/8" X 3/4" COTTERPIN		01
12	0503012412	5/8 UNC SELF LOCKING NUT		04
13	0511055260	SEED ROW CHAIN TENSIONER	88	01
14	0502012782	17Z GEAR WITH HEX HOLE		01
15	0521064652	RH SEED ROW SUPPORT FRONT		01
16	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
17	0502012568	UPPER ROCKER ARM		01
18	0561014904	TRANSMISSION AXLE FRAME ROW		01
19	0501011388	COUPLING SHAFT		02
20	0521055219	BEARING WITH GEAR 17Z HEX 5/8	89	01
21	0502012789	FIXER SUPPORT FERTILIZER ROW		01
22	0503017857	BOLT 5/8 UNF 4		04
23	0503010811	5/8" UNF SELF ADJUSTING NUT		04
24	0503034580	TRACTION SPRING		02
25	0581017624	SPACING SLEEVE		06
26	0503019273	AUTO LUBRICANT SLEEVE		08
27	0581017626	SPACER		01
28	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
29	0503010045	O'RING		08
30	0581018487	FIXER UPPER SPRING		01
31	0502012911	TOP ARM SEED ROW		01



RIGHT FRONT OF LONG SEED ROW

0531055214


Item	Code	Description	See page	QT
32	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
33	0531064032	SEED ROW FRAME		01
34	0531055203	TRANSMISSION WITH AXLE	91	01




Item	Code	Description	See page	QT
01	0521055213	SEED ROW BEARING	87	02
02	0503011953	5/16" X 1" BOLT		04
03	0501010694	FLAT WASHER		04
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
05	0503010337	5/16" NUT		04
06	0501010422	BOLT 5/8 UNC X 6.1/2 CS G.5 ZN		04
07	0561019032	SEED FERTIL ROW LOCK		01
08	0503010071	3/16" X 1" COTTERPIN		01
09	0503030168	HITCH PIN CLIP		01
10	0521010773	0.37" X 1.18" COUPLING SHAFT		01
11	0503010140	1/8" X 3/4" COTTERPIN		01
12	0503012412	5/8 UNC SELF LOCKING NUT		04
13	0511055260	SEED ROW CHAIN TENSIONER	88	01
14	0502012782	17Z GEAR WITH HEX HOLE		01
15	0521064652	RH SEED ROW SUPPORT FRONT		01
16	0503012717	40-1 CHAIN X 101 LINK + MENDING		01
17	0502012568	UPPER ROCKER ARM		01
18	0561014904	TRANSMISSION AXLE FRAME ROW		01
19	0501011388	COUPLING SHAFT		02
20	0521055219	BEARING WITH GEAR 17Z HEX 5/8	89	01
21	0502012789	FIXER SUPPORT FERTILIZER ROW		01
22	0503017857	BOLT 5/8 UNF 4		04
23	0503010811	5/8" UNF SELF ADJUSTING NUT		04
24	0503034580	TRACTION SPRING		02
25	0581017624	SPACING SLEEVE		06
26	0503019273	AUTO LUBRICANT SLEEVE		08
27	0581017626	SPACER		01
28	0581017625	SMALLER SPACE SLEEVE LOWER ARM WITHOUT LUBRICATION		01
29	0503010045	O'RING		08
30	0581018487	FIXER UPPER SPRING		01
31	0502012911	TOP ARM SEED ROW		01




Item	Code	Description	See page	QT
32	0502012910	SEED ROW LOWER ARM WITHOUT LUBRICATION		01
33	0531055206	298 TRANSMISSION HUB	92	01




Item	Code	Description	See page	QT
01	0502012718	BEARIN BODY		01
02	0503019355	BEARING 6202 2RS1		01
03	0503017011	SEAL RING		01
04	0503011945	503050 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503030402	PULLEY		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0502012819	17Z GEAR WITH HEX HOLE		01
02	0521055220	BEARING FRONT SEED ROW	90	01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01



Item	Code	Description	See page	QT
01	0502011697	BEARING OF THE GEAR BOX		01
02	0503019356	BEARING 6005 2RS1		01
03	0503011105	SEAL RING		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0531055206	298 TRANSMISSION HUB	92	01
02	0531055205	BEARING WITH 168 AXLE	95	01




Item	Code	Description	See page	QT
01	0531055218	DRAGGER BEARING	93	01
02	0503015110	M06 SPRING WASHER		02
03	0503032984	HOOD HEX AXLE ROW		01
04	0503013100	NYLON CLAMP		01
05	0503011378	M6X1X16 C S 8.8 ZN BOLT		02
06	0521055223	SEED ROW TRANSMISSION HUB	94	01

DRAGGER BEARING


0531055218




Item	Code	Description	See page	QT
01	0521063532	BEARING FOLLOWER ROW ASSY		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0501214210	110 DRAGGER AXLE		01
05	0501214209	200 DRAGGER AXLE		01
06	0503010406	501025 CLAMPING RING (FOR AXLE)		02
07	0503015356	SPRING PIN		01
08	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503019361	BEARING 6006 RS1		02
04	0503019363	BEARING 6005		01
05	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
06	0503010143	1/4" SPRING WASHER		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503019362	BEARING 6005 RS1		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503010707	501030 CLAMPING RING (FOR AXLE)		01
02	0503012861	6006 2RS BALL BEARING		01
03	0502012030	HOUSING BEARING		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02
07	0501010694	FLAT WASHER		02
08	0501214207	BEARING AXLE BODY		01
09	0501214208	HEXAGONAL UNIVERSAL JOINT		01
10	0503011855	0.2" X 1.8" SPRING PIN		02
11	0503012858	502075 CLAMPING RING (FOR HOLE)		01
12	0501214211	5/8 X 195 HEXAGONAL AXLE		01
13	0501214204	3/4 X 168 HEXAGONAL AXLE		01




Item	Code	Description	See page	QT
01	0531064031	LONG SEED ROW FRAME		01
02	0531055340	BEARING WITH 408 AXLE	97	01




Item	Code	Description	See page	QT
01	0503010707	501030 CLAMPING RING (FOR AXLE)		01
02	0503012861	6006 2RS BALL BEARING		01
03	0502012030	HOUSING BEARING		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02
07	0501010694	FLAT WASHER		02
08	0501214207	BEARING AXLE BODY		01
09	0501214208	HEXAGONAL UNIVERSAL JOINT		01
10	0503011855	0.2" X 1.8" SPRING PIN		02
11	0503012858	502075 CLAMPING RING (FOR HOLE)		01
12	0501214211	5/8 X 195 HEXAGONAL AXLE		01
13	0501214202	3/4 X 408 HEXAGONAL AXLE		01




Item	Code	Description	See page	QT
01	0502013042	FIXING BASE		01
02	0521055871	LEFT DOUBLE DISC SEED 15 X 15	99	01
03	0531055215	FIXING SET		02
03A	0501214203	THREADED BODY		02
03B	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
03C	0503035749	LOCKING KNOB		02
03D	0511017303	FLAT WASHER		02
03E	0503015536	M6 X 1" SELF ADJUSTING NUT		02
04	0503010585	0,24" X 1.18" SPRING PIN		02
05	0503015920	3/8" UNC X 1.3/4" BOLT		04
06	0503010025	3/8" SPRING WASHER		04
07	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0511052302	LH SUPPORT DDD GUIDE	100	01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
05	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
06	0503010026	3/8" NUT		01
07	0503010025	3/8" SPRING WASHER		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 104 FERTILIZER / SEED		01
09	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 106 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0561015592	LEFT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502013042	FIXING BASE		01
02	0521055870	RIGHT DOUBLE DISC SEED 15 X 15	102	01
03	0531055215	FIXING SET		02
03A	0501214203	THREADED BODY		02
03B	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
03C	0503035749	LOCKING KNOB		02
03D	0511017303	FLAT WASHER		02
03E	0503015536	M6 X 1" SELF ADJUSTING NUT		02
04	0503010585	0,24" X 1.18" SPRING PIN		02
05	0503015920	3/8" UNC X 1.3/4" BOLT		04
06	0503010025	3/8" SPRING WASHER		04
07	0503010026	3/8" NUT		04




Item	Code	Description	See page	QT
01	0511052301	SUPPORT DDD 15 RIGHT	103	01
02	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
03	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
04	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
05	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
06	0503010026	3/8" NUT		01
07	0503010025	3/8" SPRING WASHER		01
08	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 104 FERTILIZER / SEED		01
09	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 106 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0561015591	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0571012491	SOCKET SEED GUIDE		01
03	0503010838	0.1" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0521055864	ASSY RIGHT HUB DDD FERTILIZER / SEED	105	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011150	RIGHT DOUB DISC - HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0521055865	ASSY LEFT HUB DDD FERTILIZER / SEED	107	01
02	0612023500	DPL CPR 15X4 C123 AFSFR72,00+6FR D568		01




Item	Code	Description	See page	QT
01	0571011151	LEFT DOUBLE DISC HUB		01
02	0502012896	SHORT CUBE FERTILIZER/SEED HUB		01
03	0503019342	ROLLER BEARING		01
04	0503034055	CLAMPING RING		01
05	0511011927	DUST CLOAK		01
06	0503014679	2-134 O'RING		01
07	0503019377	SCREW 5/16 UNC X 5/8 C S R I G.8 ZN		06
08	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
09	0591010493	WASHER DDD FERTILIZER / SEED		02
10	0503015081	502052 CLAMPING RING (FOR AXLE)		01
11	0571011152	DOUBLE DISC CAP		01




Item	Code	Description	See page	QT
01	0521055065	ASSY DEPTH / COMPACTOR	109	01
02	0521055068	RAYED WHEEL CENTER CLOSED	114	02
03	0521054990	LEFT COMPACTOR WHEEL	116	01
04	0521055017	RIGHT COMPACTOR WHEEL	117	01
05	0503016453	1/2" X 2.1/2 BOLT		02
06	0503010019	1/2" SPRING WASHER		02
07	0503010028	1/2" NUT		02




Item	Code	Description	See page	QT
01	0502012283	DEPTH CONTROL SUPPORT		01
02	0521019093	0.6" X 2.7" PIVOT SHAFT		01
03	0571013054	DEPTH CONTROL WHEEL AXLE		01
04	0502012663	EXTENSION		01
05	0501056769	DEPTH WHEELS REGULATOR ASSY	110	01
06	0503019398	AXLE RETAINER RING		01
07	0521055033	SEMI-ASSEMBLED COMPACTOR BODY	111	01
08	0521055054	LEFT ARM WITH SLEEVE	112	01
09	0521055066	RIGHT ARM WITH SLEEVE	113	01
10	0511015346	FLAT WASHER		04
11	0571015974	WASHER		02
12	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
13	0503010256	3/8" X 3/4" BOLT		01
14	0503010311	1/2" X 1-1/4" BOLT		02
15	0503010019	1/2" SPRING WASHER		04
16	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
17	0503010060	1/2 UNC G.5 ZN HEX NUT		02
18	0503019275	SLEEVE LUBRICATION SYSTEM		01
19	0581019473	ARTICULATED SLEEVE		02
20	0503010045	O'RING		02




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0502011688	DEPTH CONTROL LEVER		01
03	0503030975	0.9" X 1.5" X 0.1" SPRING		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511065582	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0521069585	LEFT SIDE		01
02	0581019475	RIGHT SIDE BODY		01
03	0581019511	COVER		01
04	0581019510	AXIS		01
05	0503019351	LUBRICANT SLEEVE		02
06	0581019520	AXIS		01
07	0503030190	0.5" X 1.6" X 0.05" SPRING		01
08	0502012877	PRESS WHEEL ADJUSTMENT LEVER		01
09	0503030878	LEVER CRANK		01
10	0521068661	LEVER		01
11	0571012442	COUPLING SHAFT		01
12	0503010257	1/8" X 1" COTTERPIN		01
13	0581019512	PLATE TOP		01
14	0503034817	SPRING		01
15	0503010752	1/2" X 3.1/2" BOLT		01
16	0503011336	1/2" HEX SELF ADJUSTING NUT		01
17	0501011753	5/16" X 1-3/4" BOLT		02
18	0581015855	SLEEVE		02
19	0503013816	5/16" LOCKNUT		04
20	0503010848	5/16" X 3.1/2" BOLT		02




Item	Code	Description	See page	QT
01	0581019523	LEFT ARM WHEEL DEPTH		01
02	0581019514	LUBRICANT SLEEVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0581019524	RIGHT ARM DEPTH		01
02	0581019514	LUBRICANT SLEEVE		02
03	0503011109	2-119 N 3006-9B O'RING		02




Item	Code	Description	See page	QT
01	0521055055	HUB WHEEL DEPTH COMPLETE WITHOUT LUBRICATION	115	01
02	0551019904	PRESS WHEEL RIM		02
03	0503032970	RUBBER BAND		01
04	0561016889	STRIPED CAP WHEEL DEPTH		01
05	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		06
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
07	0503010337	5/16" NUT		06




Item	Code	Description	See page	QT
01	0581019522	CASE WHEEL DEPTH WITHOUT LUBRICATION		01
02	0503011105	SEAL RING		01
03	0521019178	PROTECTION LID		01
04	0503014729	1/4" UNF X 1/2" BOLT		03
05	0503010878	5/8" SELF ALIGNING NUT		01
06	0503030757	2.9" X 2" X 0.02" JOINT		01
07	0503010143	1/4" SPRING WASHER		03
08	0503019342	ROLLER BEARING		01
09	0503034055	CLAMPING RING		01
10	0581019529	DEPTH REGULATOR SHAFT		01
11	0581019168	DUST CLOAK		01




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	118	01
02	0503013739	1/2" X 1" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0521054989	RUBBER WHEEL ASSEMBLY WITHOUT LUBRICATION	118	01
02	0503010752	1/2" X 3.1/2" BOLT		01
03	0521014508	FLAT WASHER		05




Item	Code	Description	See page	QT
01	0502012894	CUBE WHEELS		01
02	0521018928	PRESS WHEEL RIM		02
03	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
04	0503010358	5/16" X 5/8" BOLT		03
05	0503013816	5/16" LOCKNUT		09
06	0503010011	5/16" X 1/2" BOLT		06
07	0503019342	ROLLER BEARING		01
08	0503011105	SEAL RING		01
09	0511011927	DUST CLOAK		02
10	0503013848	5072-BR SEAL		02
11	0581019533	AXIS		02




Item	Code	Description	See page	QT
01	0501010066	3/4" X 9" BOLT		01
02	0511017232	FLAT WASHER		02
03	0503011255	3/4" LOCK NUT		01
04	0502012873	SUPPORT DC FERTILIZER ROW		01
05	0503019278	LUBRICANT SLEEVE		02
06	0581019195	SIDE GUIDE SLEEVE		02
07	0581019196	CENTRAL GUIDE SLEEVE		01
08	0503010410	RING		02
09	0502012876	CLAMP		01
10	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
11	0503010013	5/8" NUT		02
12	0521054906	SPRING ASSY FERTILIZER	125	01
13	0521053231	DPL 20 SHORT ROW WITHOUT LUBRICATION CONICAL BEARING	120	01
14	0521066231	SHORT FERTILIZER ROW ARM		01
15	0503017857	BOLT 5/8 UNF 4		03
16	0503010811	5/8" UNF SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	123	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	THRUST WASHER		01
08	0521068887	DC RIGHT ARM WITH SLEEVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH SLEEVE		01
17	0503019272	LUBRICANT SLEEVE		02
18	0503010390	SEAL RING		02
19	0581017628	LID		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012825	SHAFT FIXING SHAFT CUT SHORT ROW		01



Item	Code	Description	See page	QT
01	0501010066	3/4" X 9" BOLT		01
02	0511017232	FLAT WASHER		02
03	0503011255	3/4" LOCK NUT		01
04	0502012873	SUPPORT DC FERTILIZER ROW		01
05	0503019278	LUBRICANT SLEEVE		02
06	0581019195	SIDE GUIDE SLEEVE		02
07	0581019196	CENTRAL GUIDE SLEEVE		01
08	0503010410	RING		02
09	0502012876	CLAMP		01
10	0503019116	BOLT 5/8 UNC X 2.1/4 C S RT PC G.5 ZN		02
11	0503010013	5/8" NUT		02
12	0521054906	SPRING ASSY FERTILIZER	125	01
13	0521053232	DPL 20 LONG ROW WITHOUT LUBRICATION CONICAL BEARING	122	01
14	0521066230	LONG FERTILIZER ROW ARM		01
15	0503017857	BOLT 5/8 UNF 4		03
16	0503010811	5/8" UNF SELF ADJUSTING NUT		03




Item	Code	Description	See page	QT
01	0581017651	DISC LUBRICATION SUPPORT WITHOUT LUBRICATION		01
02	0571010188	13,50 X 19 X 86,30/86 SLEEVE		01
03	0521010452	SLEEVE		01
04	0501067323	SPRING REGULATOR		01
05	0521053248	20" DISC BLADE HUB WITH CONICAL BEARING	123	01
06	0503011255	3/4" LOCK NUT		02
07	0581011111	THRUST WASHER		01
08	0521068887	DC RIGHT ARM WITH SLEEVE		01
09	0503034319	LOCK PIN		01
10	0503010019	1/2" SPRING WASHER		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0503011411	1/2" X 5-1/2" BOLT		01
13	0503034498	SPRING		01
14	0502012878	WASHER		01
15	0503013185	3/4" X 5-1/2" BOLT		01
16	0521068892	LEFT DC ARM WITH SLEEVE		01
17	0503019272	LUBRICANT SLEEVE		02
18	0503010390	SEAL RING		02
19	0581017628	LID		02
20	0581017652	WASHER		01
21	0503019271	SELF LUBRICATING BUSHING		01
22	0503019274	WASHER		02
23	0502012824	FIXING SHAFT DISC CUT ROW		01




Item	Code	Description	See page	QT
01	0603027851	20" X 0.2" FLAT PLAIN DISC		01
02	0521053697	DISC BLADE HUB	124	01

DISC BLADE HUB


0521053697



Item	Code	Description	See page	QT
01	0503019283	SCREW 7/8 UNF X 6.1/4	01	
02	0502040872	REGULATORY NUT	01	
03	0503010370	502072 CLAMPING RING (FOR AXLE)	02	
04	0503010590	00674-B SEAL	02	
05	0503019285	RING	02	
06	0503012170	30207 ROLLER BEARING	02	
07	0502020641	BLADE DISC FLANGE	01	
08	0502012862	DISC BLADE HUB	01	
09	0502040873	DISC BLADE AXLE	01	
10	0503017755	NUT	01	
11	0503018825	5/16 UNC UNC BOLT	06	
12	0501010694	FLAT WASHER	06	
13	0503013816	5/16" LOCKNUT	06	
14	0511017907	1/8" BSPT X 6 PLUG	02	




Item	Code	Description	See page	QT
01	0502040534	SPRING GUIDE BUSHING LOCK	02	
02	0502012184	FERTILIZER SPRING GUIDE	02	
03	0503031910	1.7" X 22.8" X 0.3" SPRING	01	
04	0502012510	SPRING ROD SUPPORT	01	
05	0591018219	JUNCTION SHAFT 12.70 X 109 ZN	01	
06	0501018535	1/2 X 1 BOLT	02	
07	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN	02	
08	0503010060	1/2 UNC G.5 ZN HEX NUT	02	
09	0502010891	SPRING CHOCK SUPPORT VARON	01	
10	0503010014	3/4" HEX NUT	01	
11	0521067619	FERTILIZER ROW TUBE	01	
12	0503010257	1/8" X 1" COTTERPIN	01	
13	0501010937	13,50 X 28 X 3,00 FLAT WASHER	01	




Item	Code	Description	See page	QT
01	0521055869	LEFT DUAL FERTILIZER DISC	127	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04

LEFT DUAL FERTILIZER DISC


0521055869




Item	Code	Description	See page	QT
01	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
07	0503010025	3/8" SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 104 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 106 FERTILIZER / SEED		01




Item	Code	Description	See page	QT
01	0521055868	RIGHT DUAL FERTILIZER DISC	129	01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
05	0503010019	1/2" SPRING WASHER		04
06	0503010060	1/2 UNC G.5 ZN HEX NUT		04




Item	Code	Description	See page	QT
01	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
02	0501017542	LH DOUBLE DISC SCRAPER		01
03	0501017541	RIGHT DOUBLE DISC SCRAPER		01
04	0502070062	SCRAPER		01
05	0503011402	0.2" X 0.8" SPRING PIN		01
06	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
07	0503010025	3/8" SPRING WASHER		01
08	0503010026	3/8" NUT		01
09	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
10	0521055866	HUB RIGHT QUICK-CHANGE DPL 15 X 4.00 104 FERTILIZER / SEED		01
11	0521055867	HUB LEFT QUICK-CHANGE DPL 15 X 4.00 106 FERTILIZER / SEED		01



Item	Code	Description	See page	QT
01	0531054583	SEMI-ASSEMBLED SINGLE SEED HOPPER	131	01
02	0503014442	BOLT		05
03	0503012534	LOCK WASHER		05
04	0503012545	FLAT WASHER		05
05	0503010209	3/8" UNC BUTTERFLY NUT		01
06	0503010025	3/8" SPRING WASHER		01
07	0501013518	FLAT WASHER		02
08	0503034131	DEFLECTOR		01
09	0501213674	DEFLECTOR FIXING AXLE		01
10	0531054895	FRONT TRANSMISSION SEED HOPPER SUPPORT	133	01




Item	Code	Description	See page	QT
01	0503015536	M6 X 1" SELF ADJUSTING NUT		04
02	0581014295	FIXING SLEEVE		01
03	0501213431	SEED NOZZLE FIXING FLANGE		01
04	0501213520	SEED BREAKER BODY		01
05	0501213432	BREAKER SUPPORT BASE		01
06	0501213728	60 X 53 X 30 PVC TUBE		01
07	0513010720	M6 X 1 X 35 C S G.5 ZB BOLT		04
08	0503063760	SINGLE SEED HOPPER ASSEMBLED WITH LOCK LID	132	01



Item	Code	Description	See page	QT
01	0503035751	SIGMA SINGLE SEED HOPPER		01
02	0503035750	SEED HOPPER LID		01
03	0503035298	BAKELITE HANDLE WITH THREAD		01
04	0503015536	M6 X 1" SELF ADJUSTING NUT		01
05	0503035297	CURVED NOZZLE SEED HOPPER		01

FRONT TRANSMISSION SEED HOPPER SUPPORT


0531054895




Item	Code	Description	See page	QT
01	0503010337	5/16" NUT		01
02	0502013041	LOWER BASE SEED DISC		01
03	0513010140	SOCIDISCO SOY DISC 90 HOLES		01
04	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461		01
05	0503063778	SOY SEED DISTRIBUTOR CAP		01
06	0503017373	BOLT		06
07	0502013040	DISC DRAWER		01
08	0501213760	FRONT TRANSMISSION SEED HOPPER SUPPORT		01
09	0531054795	FRONT TRANSMISSION ASSEMBLY	134	01
10	0503010585	0,24" X 1.18" SPRING PIN		02
11	0503035789	SIGMA ALUMINUM ADHESIVE LABEL		01
12	0503013356	RIVET POP 3,2 X 10,0		04
13	0531055215	FIXING SET		02
13A	0501214203	THREADED BODY		02
13B	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		02
13C	0503035749	LOCKING KNOB		02
13D	0511017303	FLAT WASHER		02
13E	0503015536	M6 X 1" SELF ADJUSTING NUT		02
14	0513010671	5/6 UNC X 2 CCSI 12.9 BOLT		01
15	0513010672	M6 X 1 X 25 CCSI 12.9 BOLT		01

FRONT TRANSMISSION ASSEMBLY


0531054795




Item	Code	Description	See page	QT
01	0503019356	BEARING 6005 2RS1		02
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012930	CONICAL GEAR		01
04	0503010585	0,24" X 1.18" SPRING PIN		01
05	0503017022	RING		01
06	0501213588	40Z CONICAL CROWN LOWER TRANSMISSION		01
07	0503017373	BOLT		04
08	0502050058	UPPER TRANSMISSION BODY		01
09	0501213625	12 SPACER SLEEVE		01
10	0501213624	142 PINION AXLE		01
11	0501213586	LOWER BODY FRONT TRANSMISSION		01
12	0513010773	BEARING 6003 2RS1 NAC		02




Item	Code	Description	See page	QT
01	0521068567	BOX SPRING		01
02	0521053951	STEM	136	01
03	0503034106	80 X 230 X 16,50 COMPRESSSION SPRING		01
04	0581012094	SUPPORT WASHER		01
05	0503033624	35 X 215 X 7,14 COMPRES SPRING		01
06	0571019462	SUPPORT GUIDE PRING		01
07	0503012795	5/8" HEX SELF ADJUSTING NUT		01
08	0503010691	1/4" GREASE FITTING		01
09	0503010384	1/2" X 5" BOLT		02
10	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04
11	0503011336	1/2" HEX SELF ADJUSTING NUT		04
12	0503017874	BOLT 1/2 UNC		02
13	0571018541	BODY SOCKET FERTILIZER		01
14	0503010026	3/8" NUT		02
15	0503010025	3/8" SPRING WASHER		02
16	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
17	0501010984	FLAT WASHER 10,50 X 27 X 3,00 ZN		04
18	0503010417	7/8" NUT		01
19	0503017058	HEX 7/8 UNC X 3 CSRT PC G.5 ZN		01
20	0581012084	ARTICULATED SLEEVE		01
21	0581012082	SCREW		01
22	0581012081	ARTICULATED SLEEVE		01



Item	Code	Description	See page	QT
01	0521053932	ROD WITH BEAK 0869	137	01
02	0521067065	FLANGE WASHER SPRING		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		02
04	0581012092	AXLE FIXER		01
05	0521015818	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0521067523	STEM WITHOUT BEAK DISARM		01
02	0502040901	FIXED ROD NOZZLE		01
03	0503016853	SPRING PIN		02
04	0503011402	0.2" X 0.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0513010117	SOCIDISCO CORN DISC 28 HOLES 9,0 AMC9R-002130		01
02	0513010118	SOCIDISCO CORN DISC 28 HOLES 9,5 VLD9.5R-002115		01
03	0513010119	SOCIDISCO CORN DISC 28 HOLES 10 SAL10R-002619		01
04	0513010120	SOCIDISCO CORN DISC 28 HOLES 10,5 RSP10.5R-002133		01
05	0513010121	SOCIDISCO CORN DISC 28 HOLES 11 LRA11R-002134		01
06	0513010122	SOCIDISCO CORN DISC 28 HOLES 11,5 MAG11.5R-002620		01
07	0513010123	SOCIDISCO CORN DISC 28 HOLES 12 VDA12R-002621		01
08	0513010124	SOCIDISCO CORN DISC 28 HOLES 12,5 AMP12.5R-002131		01
09	0513010125	SOCIDISCO CORN DISC 28 HOLES 13 VMV13R-002132		01
10	0513010126	SOCIDISCO CORN DISC 28 HOLES 13,5 RXR13.5R-002136		01
11	0513010187	SOCIDISCO CORN DISC 28 HOLES 14,8 X 10 VM4-002581		01
12	0513010188	SOCIDISCO CORN DISC 28 HOLES 11 X 8 BR8.1-002589		01
13	0513010189	SOCIDISCO CORN DISC 28 HOLES 12,5 X 8,5 AZ8.2-002587		01
14	0513010164	SOCIDISCO FLAT RING FOR CORN AMFOSLISO-002127		01
15	0513010159	SOCIDISCO RING FOR CORN 0,8MM LRFOSSR08-002120		01
16	0513010160	SOCIDISCO RING FOR CORN 1,4MM VMFOSR1.4-002245		01
17	0513010163	SOCIDISCO RING FOR CORN 2,0MM VDFOSR2-002116		01




Item	Code	Description	See page	QT
18	0503063779	SOCIDISCO 2808 4Z CORN SEED DISTRIBUTOR CAP		01



Item	Code	Description	See page	QT
01	0513010136	SOCIDISCO SOY DISC 62 HOLES 7,5 LRA62.75-002357	01	01
02	0513010137	SOCIDISCO SOY DISC 62 HOLES 8,0 RSP62.80-002358	01	01
03	0513010138	SOCIDISCO SOY DISC 62 HOLES 8,5 RXR62.85-002359	01	01
04	0513010139	SOCIDISCO SOY DISC 62 HOLES 9,0 AZM62.90-002360	01	01
05	0513010141	SOCIDISCO SOY DISC 90 HOLES 8,0 RSP90.80-002287	01	01
06	0513010142	SOCIDISCO SOY DISC 90 HOLES 8,5 RXR90.85-002317	01	01
07	0513010143	SOCIDISCO SOY DISC 90 HOLES 9,0 AZM90.90-002288	01	01
08	0513010158	SOCIDISCO FLAT RING FOR SOY AZMSOJALISO-002243	01	01
09	0513010161	SOCIDISCO RING FOR SOY 0,8MM AZCSOJAR08-002461	01	01
10	0513010162	SOCIDISCO RING FOR SOY 1,5MM RSPSOJASR1,5-002244	01	01
11	0503063780	SOCIDISCO 2810 4Z SOY/BEAN SEED DISTRIBUTOR CAP	01	01



Item	Code	Description	See page	QT
01	1902012864	3 CLAMP		02
02	0503013759	NUT		02
03	0501010694	FLAT WASHER		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02



MARCHESAN

Technical Publications | Elaboration and Revision

LEONARDO JOSÉ DA SILVA SOUZA

www.marchesan.com.br

