

ROW CROP PLANTERS

**PST PLUS FLEX SUPREMA PP - FRAME
3245/3495/4045/4395/4845 (FROM 08/2022)**

Code: 0501099015
Series: S-0116
Revision: 00
Date Revision: JUNHO/2023

PARTS CATALOGUE



MARCHESAN

PRODUCTS

Code	Description
0111390062	PST PLUS FLEX SUP PP 3245/6E500 CI MH DC20 S-0116
0111390009	PST PLUS FLEX SUP PP 3245/7E450 MH MTH S-0116
0111390015	PST PLUS FLEX SUP PP 3495/7E500 ESPECIAL S-0116
0111390074	PST PLUS FLEX SUP PP 4045/6E650 ESPECIAL S-0116
0111390045	PST PLUS FLEX SUP PP 4045/8E500 ESPECIAL S-0116
0111390010	PST PLUS FLEX SUP PP 4395/9E500 ESPECIAL S-0116
0111390026	PST PLUS FLEX SUP PP 4845/10E500 ESPECIAL S-0116

ATTENTION: IMPORTANT

Marchesan S.A. reserves the right to improve and/or modify the technical features of its products, without obligation to do the same with those products already sold and without prior knowledge of the dealer or the customer. The photos are only illustrative.



MARCHESAN

INDEX

0909096438	ASSY FRAME - 3245/3495/4045/4395/4845	1
0511057196	FRAME WITH WHEEL AXLE - 3245	2
0511057371	FRAME WITH WHEEL AXLE - 3495	3
0511057303	FRAME WITH WHEEL AXLE - 4045	4
0511057361	FRAME WITH WHEEL AXLE - 4395	5
0511057336	FRAME WITH WHEEL AXLE - 4845	6
0511058655	CYLINDER SET - 3245/3495/4045/4395	7
0511058656	CYLINDER SET - 4845/5345/5745	8
0521045510	HYDRAULIC CYLINDER	9
0511058653	WHEELS WITH TRACTION SPRING	10
0511058654	WHEEL SUPPORT	11
0501058241	WHEEL SUPPORT CHAIN TENSIONER	12
0511052770	WHEEL WITH TIRE	13
0503062159	WHEEL WITH TIRE	14
0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	15
0501058240	WHEEL FASTENER WITH TENSIONER	16
0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	17
0501058244	WHEEL FIXED CHAIN TENSIONER	18
0501058242	WHEEL MOBILE CHAIN TENSIONER	19
0501058239	WHEEL CHAIN TENSIONER BEARING	20
0511059002	TRANSMISSION ASSY - 3245	21
0521050278	TRANSMISSION ASSY - 3495	22
0511058694	TRANSMISSION ASSY - 4045	23
0511059404	TRANSMISSION ASSY - 4395	24
0511059649	TRANSMISSION ASSY - 4845	25
0501052560	MOTOR AXLE SIGNAL	26
0511051434	TRANSMISSION ACTUATOR	27
0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	28
0511047070	LEFT SIDE TRANSMISSION ACTUATOR	29
0501053788	3/4" SQUARE AXLE FASTENER	30
0501056271	GEARBOX CLOSED BEARING	31
0511057265	TRANSMISSION CHAIN TENSIONER	32
0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	33
0511050652	CHAIN TENSIONER	34
0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	35
0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	36
0521055335	RIGHT GEAR HOUSING SET	37
0511058381	RIGHT GEAR HOUSING	38
0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	39
0501048790	AXLE WITH RING	40
0501056443	GEAR HOUSING BEARING	41
0501056444	BEARING WITH ROLLER	42
0511057258	TENSIONER WITH GEAR	43
0511054363	CHAIN TENSIONER	44
0521055337	LEFT GEAR HOUSING SET	45
0531055591	3245 ALPHA II FERTILIZER HOPPER SET	46
0531055584	HOPPER SUPPORT WITH FERTILIZER METERING - 3245	47
0531055922	3495 ALPHA II FERTILIZER HOPPER SET	48
0531055386	HOPPER SUPPORT WITH FERTILIZER METERING - 3495	49
0531059677	4045 ALPHA II FERTILIZER HOPPER SET	50
0531059676	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4045	51
0531059675	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4045	52
0531059578	4395 ALPHA II FERTILIZER HOPPER SET	53



MARCHESAN

INDEX

0531059579	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4395	54
0531059583	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4395	55
0531059596	4845 ALPHA II FERTILIZER HOPPER SET	56
0531059598	RIGHT HOPPER SUPPORT WITH FERTILIZER METERING - 4845	57
0531059597	LEFT HOPPER SUPPORT WITH FERTILIZER METERING - 4845	58
0531055319	ALPHA II FERTILIZER METERING	59
0531055863	ASSY TRANSMISSION HUB	60
0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	61
0531059139	ASSY COLLECTOR	62
0531055273	ALPHA FERTILIZER METERING CLAMP	63
0531057911	22Z GEAR SIDE BEARING ASSEMBLY	64
0531057901	GEAR	65
0503062362	FERTILIZER HOPPER	66
0503062391	FERTILIZER HOPPER	67
0511057266	HYDRAULIC SYSTEM ASSEMBLY - 3245/3495/4045/4395	68
0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	69
0511057846	ASSY HOSE KIT	70
0501053834	MALE QUICK COUPLER	71
0511057484	HANDRAIL ASSY - 3245	72
0521050279	HANDRAIL ASSY - 3495	73
0511057499	HANDRAIL ASSY - 4045	74
0511059403	HANDRAIL ASSY - 4395	75
0511057551	HANDRAIL ASSY - 4845	76
0511057205	PLATFORM ASSEMBLY - 3245	77
0511057370	PLATFORM ASSEMBLY - 3495	78
0511057307	PLATFORM ASSEMBLY - 4045	79
0511057358	PLATFORM ASSEMBLY - 4395	80
0511057331	PLATFORM ASSEMBLY - 4845	81
0511056536	LADDER ASSEMBLY	82
0511054971	JACK ASSEMBLY	83
0511057229	DRAWBAR ASSEMBLY - 3245	84
0511057333	DRAWBAR ASSEMBLY - 3495/4045/4395/4845/5345/5745	85
0531057445	ALPHA LABEL SET - 3245	86
0531057446	ALPHA LABEL SET - 3495	87
0531057447	ALPHA LABEL SET - 4045	88
0531057448	ALPHA LABEL SET - 4395	89
0531057449	ALPHA LABEL SET - 4845	90
0511059322	LIFTING SUPPORT ASSEMBLY	91
0511059323	SUPPORT PLATFORM TRANSPORT	92
0521051445	TURBINE ASSEMBLY MTH PP 3245	93
0511059005	SET TURBINE	94
0521050277	SET TURBINE	95
0521050274	SET TURBINE	96
0511059407	SET TURBINE	97
0521054059	SET TURBINE	98
0511057701	TURBINE WITH HIDRAULIC MOTOR	99
0511057349	DISTRIBUTOR VACUUM 4045/4395	100
0511059887	TURBINE PRECISION PLANTING	101
0521050154	PRECISION PLANTING TURBINE WITH HOLE	102
0511057348	DISTRIBUTOR VACUUM	103
0521044613	480 X 50 FAN (HIDRAULIC)	104
0521050985	AIR DISTRIBUTOR	105
0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	106




MARCHESAN

INDEX

0909099159	ASSY HEX AXLE	107
0909091038	HEX AXLE ASSEMBLY	108
0521055338	ROW SEED BEARING	109
0531053676	10 ROWS SEED MONITORING SET	110
0531053630	12 ROWS PLANTING MONITORING SET	111
0511057270	DRAWBAR EXTENDER	112
0511054601	HITCH ARTICULATED TRACTOR	113
0511053179	TRACTOR COUPLING SHAFT	114
0521056505	MANUAL CANISTER ASSY	115
0511057817	SUPPORT HOSE	116
0531059616	KIT WITH ALPHA COMPONENTS - 06 ROWS	117
0531059617	KIT WITH ALPHA COMPONENTS - 07 ROWS	118
0531059618	KIT WITH ALPHA COMPONENTS - 08 ROWS	119
0531059619	KIT WITH ALPHA COMPONENTS - 09 ROWS	120
0531059620	KIT WITH ALPHA COMPONENTS - 10 ROWS	121
0511057207	SEMI-ASSEMBLED HYDRAULIC MARKER - 3245	122
0511057368	SEMI-ASSEMBLED HYDRAULIC MARKER - 3495	123
0511057311	SEMI-ASSEMBLED HYDRAULIC MARKER - 4045	124
0511057355	SEMI-ASSEMBLED HYDRAULIC MARKER - 4395	125
0511057328	SEMI-ASSEMBLED HYDRAULIC MARKER - 4845	126
0511058449	HYDRAULIC CYLINDER	127
0501054649	HBM SEQUENTIAL VALVE	128
0511058119	VALVE SUPPORT ASSEMBLY	129
0501050633	ROW MARKER DISC ASSEMBLY	130
0511053904	ROW MARKER DISC	131
0521052549	CLAMP	132
0909090926	ASSY SEED/FERTILIZER ROW	133
0511057505	SEED ROW FRONT PNEUM PP SHORT WITH RIGHT REAR	134
0511057506	SEED ROW FRONT PNEUM PP LONG WITH RIGHT REAR	135
0511057276	TRANSMISSION SUPPORT RIGHT ASSY	136
0511058766	BEARING	137
0511057273	ASSEMBLY TRANSMISSION	138
0511057159	TRANSMISSION HOPPER SEED ROW	139
0511057269	CHAIN TENSIONER	140
0511058512	PROTECTION LID	141
0511059190	DOUBLE BEARING	142
0511059191	FRONT BEARING DOBLE	143
0511057209	ROW RIGHT REAR SEED	144
0511057210	ROW LEFT REAR SEED	145
0511057502	SET PRECISION PLANTING	146
0511057155	PRECISION PLANTING LEFT TRANSMISSION HOPPER	147
0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN DISC	148
0511057154	RIGHT DDD	149
0511053172	LEFT LOW HUB WITH 15 DISC	150
0511053173	RIGHT LOW HUB WITH 15 DISC	151
0511057153	DDD LEFT	152
0511058639	SHORT FERTILIZER ROW WITH DDD/DC20	153
0511058635	SHORT FERTILIZER ROW DDD 18" BLADE DISC	154
0511058636	LONG FERTILIZER ROW DDD 18" BLADE DISC	155
0511058640	LONG FERTILIZER ROW WITH DDD/DC20	156
0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	157
0511057272	LH SHORT ARM ROW FERTILIZER	158
0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	159
0511058630	20" DISC BLADE	160
0511058648	HUB WITH 20" DISC BLADE	161

INDEX


0511056909	DISC BLADE HUB WITHOUT DISC		162
0511058629	18" COULTER BLADE ASSY FOR SHORT ROW		163
0511056910	HUB WITH 18" DISC BLADE		164
0511058634	SUPPORT LONG		165
0511057271	RH LONG ARM ROW FERTILIZER		166
0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR		167
0511057509	SEED RESERVOIR PNEUMATIC ASSY		168
0521046122	DEPTH SYSTEM / COMPACTOR ASSY		169
0511058650	SEMI-MOUNTED DEPTH CONTROL		170
0511058652	LEFT DEPTH WHEEL ARM WITH HUB		171
0501052627	ASSY DEPTH WHEEL HUB		172
0511058651	RIGHT DEPTH WHEEL ARM WITH HUB		173
0501052297	DEPTH WHEELS REGULATOR ASSY		174
0501052538	DEPTH BAND WITH ARMS		175
0511054333	COMPACT WHEEL RIGHT WITH BEARING		176
0501052908	COMPACTOR WHEEL WITH BEARING		177
0511054334	COMPACT WHEEL LEFT WITH BEARING		178
0501110804	SCARIFIER ROD WITH POINT		179
0521057957	FIXED ROD EXTENSION WITH FIXATION		180




Item	Code	Description	See page	3245	3495	4045	4395	4845
01	0511057196	FRAME WITH WHEEL AXLE - 3245	2	01	00	00	00	00
01.	0511057371	FRAME WITH WHEEL AXLE - 3495	3	00	01	00	00	00
01..	0511057303	FRAME WITH WHEEL AXLE - 4045	4	00	00	01	00	00
01...	0511057361	FRAME WITH WHEEL AXLE - 4395	5	00	00	00	01	00
01....	0511057336	FRAME WITH WHEEL AXLE - 4845	6	00	00	00	00	01
02	0503010003	1845 GREASE FITTING		04	04	04	04	06
03	0511058655	CYLINDER SET - 3245/3495/4045/4395	7	01	01	01	01	00
03.	0511058656	CYLINDER SET - 4845/5345/5745	8	00	00	00	00	01
04	0511058653	WHEELS WITH TRACTION SPRING	10	02	04	04	04	04
05	0511059002	TRANSMISSION ASSY - 3245	21	01	00	00	00	00
05.	0521050278	TRANSMISSION ASSY - 3495	22	00	01	00	00	00
05..	0511058694	TRANSMISSION ASSY - 4045	23	00	00	01	00	00
05...	0511059404	TRANSMISSION ASSY - 4395	24	00	00	00	01	00
05....	0511059649	TRANSMISSION ASSY - 4845	25	00	00	00	00	01
06	0531055591	3245 ALPHA II FERTILIZER HOPPER SET	46	01	00	00	00	00
06.	0531055922	3495 ALPHA II FERTILIZER HOPPER SET	48	00	01	00	00	00
06..	0531059677	4045 ALPHA II FERTILIZER HOPPER SET	50	00	00	01	00	00
06...	0531059578	4395 ALPHA II FERTILIZER HOPPER SET	53	00	00	00	01	00
06....	0531059596	4845 ALPHA II FERTILIZER HOPPER SET	56	00	00	00	00	01
07	0511057266	HYDRAULIC SYSTEM ASSEMBLY - 3245/3495/4045/4395	68	01	01	01	01	00
07.	0511057329	HYDRAULIC SYSTEM ASSEMBLY - 4845/5345/5745	69	00	00	00	00	01
08	0511057484	HANDRAIL ASSY - 3245	72	01	00	00	00	00
08.	0521050279	HANDRAIL ASSY - 3495	73	00	01	00	00	00
08..	0511057499	HANDRAIL ASSY - 4045	74	00	00	01	00	00
08...	0511059403	HANDRAIL ASSY - 4395	75	00	00	00	01	00
08....	0511057551	HANDRAIL ASSY - 4845	76	00	00	00	00	01
09	0511057205	PLATFORM ASSEMBLY - 3245	77	01	00	00	00	00
09.	0511057370	PLATFORM ASSEMBLY - 3495	78	00	01	00	00	00
09..	0511057307	PLATFORM ASSEMBLY - 4045	79	00	00	01	00	00
09...	0511057358	PLATFORM ASSEMBLY - 4395	80	00	00	00	01	00
09....	0511057331	PLATFORM ASSEMBLY - 4845	81	00	00	00	00	01

Item	Code	Description	See page	3245	3495	4045	4395	4845
10	0511056536	LADDER ASSEMBLY	82	02	02	02	02	02
11	0511054971	JACK ASSEMBLY	83	02	02	02	02	02
12	0511057229	DRAWBAR ASSEMBLY - 3245	84	01	00	00	00	00
12.	0511057333	DRAWBAR ASSEMBLY 3495/4045/4395/4845/5345/5745	- 85	00	01	01	01	01
13	0531057445	ALPHA LABEL SET - 3245	86	01	00	00	00	00
13.	0531057446	ALPHA LABEL SET - 3495	87	00	01	00	00	00
13..	0531057447	ALPHA LABEL SET - 4045	88	00	00	01	00	00
13...	0531057448	ALPHA LABEL SET - 4395	89	00	00	00	01	00
13....	0531057449	ALPHA LABEL SET - 4845	90	00	00	00	00	01
14	0511059322	LIFTING SUPPORT ASSEMBLY	91	02	02	02	02	02
15	0511059323	SUPPORT PLATFORM TRANSPORT	92	04	04	04	04	04
16	0521051445	TURBINE ASSEMBLY MTH PP 3245	93	01	00	00	00	00
16.	0511059005	SET TURBINE	94	01	00	00	00	00
16..	0521050277	SET TURBINE	95	00	01	00	00	00
16...	0521050274	SET TURBINE	96	00	00	01	00	00
16....	0511059407	SET TURBINE	97	00	00	00	01	00
16.....	0521054059	SET TURBINE	98	00	00	00	00	01
16.....	0511057846	ASSY HOSE KIT	70	01	01	01	01	01
17	0571019315	BEARING SUPPORT AXLE HEX/SUPPORT PLATAFORM		02	02	02	02	04
18	0521014021	1/2" X 4.5" X 5.4" FASTENER		02	02	02	02	04
19	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		04	04	04	04	08
20	0503010019	1/2" SPRING WASHER		04	04	04	04	08
21	0503010060	1/2 UNC G.5 ZN HEX NUT		04	04	04	04	08
22	0909099159	ASSY HEX AXLE	107	01	01	01	01	00
22.	0909091038	HEX AXLE ASSEMBLY	108	00	00	00	00	01
23	0531053676	10 ROWS SEED MONITORING SET	110	00	00	01	00	00
23.	0531053630	12 ROWS PLANTING MONITORING SET	111	00	00	00	00	01
24	0501065677	STRUT		02	02	02	02	02
25	0511057270	DRAWBAR EXTENDER	112	01	01	01	01	01
26	0511054601	HITCH ARTICULATED TRACTOR	113	01	01	01	01	01
27	0571014769	SLEEVE HITCH ARTICULATION 1.1/2		01	01	01	01	01
28	0511053179	TRACTOR COUPLING SHAFT	114	01	01	01	01	01
29	0503034867	AIR DISTRIBUTOR PUMP		01	01	01	01	01
30	0503014120	CHAIN		01	01	01	01	01
31	0503014321	CABLE STEEL SHACKLE		02	02	02	02	02
32	0521056505	MANUAL CANISTER ASSY	115	01	01	01	01	01
33	0521013022	TRANSPORT LOCK		02	02	02	02	02
34	0503030168	HITCH PIN CLIP		02	02	02	02	02
35	0501068994	8,30 X 78 LOCK PIN		02	02	02	02	02
36	0511057817	SUPPORT HOSE	116	01	01	01	01	01
37	0501047895	25 ROD STOP		01	01	01	01	02
37.	0501047885	30 ROD STOP		01	01	01	01	02
37..	0501047886	35 ROD STOP		01	01	01	01	02
37...	0501047887	40 ROD STOP		01	01	01	01	02
38	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04	04	04	06	06
39	0503010025	3/8 SPRING WASHER		04	04	04	06	06
40	0503010026	3/8" NUT		04	04	04	06	06
41	0531059616	KIT WITH ALPHA COMPONENTS - 06 ROWS	117	01	00	01	00	00
41.	0531059617	KIT WITH ALPHA COMPONENTS - 07 ROWS	118	01	01	00	00	00
41..	0531059618	KIT WITH ALPHA COMPONENTS - 08 ROWS	119	00	00	01	00	00
41...	0531059619	KIT WITH ALPHA COMPONENTS - 09 ROWS	120	00	00	00	01	00
41....	0531059620	KIT WITH ALPHA COMPONENTS - 10 ROWS	121	00	00	00	00	01
42	0501053834	MALE QUICK COUPLER	71	01	01	01	01	01
43	0503010045	O'RING		01	01	01	01	01
44	0541010080	TERMINAL R.1 / 2 NPT		01	01	01	01	01
45	0571015343	NIPLE 1 / 2NPT X 3 / 4NPT		01	01	01	01	01
46	0581013729	NIPLE 1/2 NPT		01	01	01	01	01


Item	Code	Description	See page	3245	3495	4045	4395	4845
47	0503010246	CLAMP		14	14	14	14	14
48	0503010780	N-2050 AMENDMENT		02	02	02	02	02
49	0503010951	REDUCTION		04	04	04	04	04
50	0503011750	AMENDMENT WITH LOCK		06	06	06	06	06
51	0503011751	REDUCTION		06	06	06	06	06
52	0511057207	SEMI-ASSEMBLED HYDRAULIC MARKER - 3245	122	01	00	00	00	00
52.	0511057368	SEMI-ASSEMBLED HYDRAULIC MARKER - 3495	123	00	01	00	00	00
52..	0511057311	SEMI-ASSEMBLED HYDRAULIC MARKER - 4045	124	00	00	01	00	00
52...	0511057355	SEMI-ASSEMBLED HYDRAULIC MARKER - 4395	125	00	00	00	01	00
52....	0511057328	SEMI-ASSEMBLED HYDRAULIC MARKER - 4845	126	00	00	00	00	01
53	0501050633	ROW MARKER DISC ASSEMBLY	130	02	02	02	02	02
54	0521013164	EXTENDER		00	00	00	00	02
55	0501011310	FIXER LOCK		00	00	00	00	04
56	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		00	00	00	00	04
57	0503010019	1/2" SPRING WASHER		00	00	00	00	04
58	0503010060	1/2 UNC G.5 ZN HEX NUT		00	00	00	00	04
59	0511066652	400 TURNBUCKLE		02	02	02	02	00
60	0571019712	AIR CONDUCTOR		07	07	09	10	11
61	0521052549	CLAMP	132	14	14	18	20	22
62	0571013990	GUTTER		02	02	02	03	03
63	0571017368	SUPPORT GUTTER		04	04	04	06	06
64	0501011643	3/8 X 1"BOLT		04	04	04	06	06
65	0909090926	ASSY SEED/FERTILIZER ROW	133	01	01	01	01	01




Item	Code	Description	See page	QT
01	0521065917	FRAME - 3245		01
02	0521065926	CARRYING-WHEELS PIVOT SHAFT 3245		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0521065918	FRAME - 3495		01
02	0521065927	CARRYING-WHEELS PIVOT SHAFT 3495		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0521065919	FRAME - 4045		01
02	0521065928	CARRYING-WHEELS PIVOT SHAFT - 4045		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0521065920	FRAME - 4395		01
02	0521065929	CARRYING-WHEELS PIVOT SHAFT - 4395		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0521065921	FRAME - 4845		01
02	0521065930	PIVOT SHAFT WHEEL - 4845		01
03	0521013199	LOWER BEARING SEMI		04
04	0503810899	BOLT		08
05	0531013922	0.6" X 0.8" X 1" SLEEVE		08
06	0503011445	SPRING WASHER		08
07	0503810013	NUT 5/8 NC		08
08	0501812140	FLAT WASHER		16




Item	Code	Description	See page	QT
01	0521045510	HYDRAULIC CYLINDER	9	01
02	0551014099	COUPLING SHAFT 31,75 X 185		01
03	0521010547	1.2" X 6.5" COUPLING SHAFT		01
04	0503010523	1/4" X 2" SPLIT PIN		02
05	0501047888	45 ROD STOP		01




Item	Code	Description	See page	QT
01	0521054233	50,8 X 101,6 X 240,5 X 507,5 HYDRAULIC CYLINDER		02
02	0521012538	1.2" X 3.5" COUPLING SHAFT		02
03	0521010547	1.2" X 6.5" COUPLING SHAFT		02
04	0503010523	1/4" X 2" SPLIT PIN		04
05	0501047888	45 ROD STOP		02
06	0571019384	SPACING SLEEVE 16,30 X 30 X 104		02
07	0501013867	BOLT 5/8 UNC X 6 CS G.5 ZN		02
08	0503010027	5/8 SPRING WASHER		02
09	0503010013	5/8 NUT		02




Item	Code	Description	See page	QT
01	0521065976	127 X 438,5 TUBE		01
02	0581013698	PISTON		01
03	0521067585	EXTENDER 50.80 X 371.5 WITH BUSHING		01
04	0503010817	1.1/4" SELF LOCKING NUT		01
05	0503010003	1845 GREASE FITTING		01
06	0503030385	CYLINDER PLUG N-002		02
07	0503018439	WIPER SEAL		01
08	0503018150	RING GUIDE		01
09	0502010382	5" END CAP		01
10	0581010353	RING SUPPORT		01
11	0503018026	1870-2000-375 B GASKET		01
12	0503011453	O'RING		02
13	0503018152	O'RING		02
14	0503018024	RING BS		01
15	0503018025	RING GUIDE		01
16	0503010039	D-2000 SCRAPER RING		01
17	0503010173	2-220 N 3006-9B O'RING		01




Item	Code	Description	See page	QT
01	0511058654	WHEEL SUPPORT	11	01
02	0501058240	WHEEL FASTENER WITH TENSIONER	16	01
03	0502010584	CARRYING-WHEELS SUPPORT FIXER		01
04	0503011119	7/8" X 6" BOLT		04
05	0501014251	FLAT WASHER		04
06	0503011254	7/8" HEX SELF ADJUSTING NUT		04
07	0503012766	2050 CHAIN X 85 LINK + MENDING		01




Item	Code	Description	See page	QT
01	0521066716	WHEEL ARM ASSY		01
02	0521061567	CARRYING WHEEL SPRING TRACTION SUPPORT		01
03	0531016887	CARRYING WHEEL AXLE ARM		01
04	0503010523	1/4" X 2" SPLIT PIN		01
05	0503010003	1845 GREASE FITTING		01
06	0511050681	TRACTION SPRING		01
06A	0503031681	2.1" X 7.78" EXTENSION SPRING		01
06B	0561016062	SPRING HITCH		02
07	0501010100	SCREW 5/8 UNC X 2 CS G.5 ZN		01
08	0503010027	5/8 SPRING WASHER		01
09	0501058241	WHEEL SUPPORT CHAIN TENSIONER	12	01
10	0503013030	5/8" X 3.1/4" BOLT		01
11	0551017715	FLAT WASHER		02
12	0511052770	WHEEL WITH TIRE	13	01
13	0591010589	BODY LOCK WHEEL		01
14	0503010027	5/8 SPRING WASHER		02
15	0503011167	M16 X 2 X 30 BOLT		02




Item	Code	Description	See page	QT
01	0541016454	PULLEY		01
02	0521018933	CHAIN TENSIONER AXLE		01
03	0511015098	FLAT WASHER		01
04	0503010302	501019 SEAL RING		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503062159	WHEEL WITH TIRE	14	01
02	0511052769	WHEEL WITH TRANSMISSION WITHOUT TIRE	15	01




Item	Code	Description	See page	QT
01	0503012113	PLY TIRE		01
02	0503016517	WHEEL EI		01
03	0503010033	7.50 X 16 INNER TIRE		01




Item	Code	Description	See page	QT
01	0501110721	WHEEL HUB WITH SCREW / NUTS		01
01A	0571012990	CARRYING WHEEL HUB TRANSMISSION		01
01B	0501010186	WHEEL SCREW 5/8UNF X 2.1/8CR		06
01C	0503016516	5/8 UNF CONIC NUT		06
02	0503012550	5/16" X 3/4" BOLT		06
03	0502011339	15Z GEAR P 1.25"		01
04	0503010328	25590/25523 ROLLER BEARING		02
05	0503010804	00547-B SEAL		02
06	0521012185	TRANSMISSION WHEEL AXLE		01
07	0511015949	LOCK NUT		01
08	0503010329	LOCK WASHER		01
09	0503010330	KM 9 LOCKNUT		01
10	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0502012416	CARRYING-WHEELS SUPPORT FIXER		01
02	0501013491	5/8" TENSIONER SPRING		01
03	0503010013	5/8 NUT		02
04	0503030099	1.3" X 4.9" 0.2" TRACTION SPRING		01
05	0511069417	REAR TENSIONER		01
06	0501058243	INTERMEDIATE WHEEL CHAIN TENSIONER	17	01
07	0501058244	WHEEL FIXED CHAIN TENSIONER	18	01
08	0501058242	WHEEL MOBILE CHAIN TENSIONER	19	01




Item	Code	Description	See page	QT
01	0551018245	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	20	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0551018239	SLEEVE 19 X 13,50 X 45		01




Item	Code	Description	See page	QT
01	0551018252	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	20	01
03	0551018241	SLEEVE 16,30 X 30 X 8		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01



Item	Code	Description	See page	QT
01	0551018244	CHAIN TENSIONER AXLE		01
02	0501058239	WHEEL CHAIN TENSIONER BEARING	20	01
03	0591017923	15,30 X 30 X 32 SLEEVE		01
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0503012882	BEARING		01
02	0503011945	503050 CLAMPING RING (FOR AXLE)		01
03	0502012853	GEAR		01




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		02
02	0501110639	BEARING		06
03	0503011099	GREASE FITTING		06
04	0503010300	5/32" X 1" COTTERPIN		06
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
10	0503010019	1/2" SPRING WASHER		08
11	0503010060	1/2 UNC G.5 ZN HEX NUT		08
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	12	02
13	0571018904	AXLE MOTOR 1550		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	26	02
16	0511051434	TRANSMISSION ACTUATOR	27	02
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	28	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	29	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		02
20	0501053788	3/4" SQUARE AXLE FASTENER	30	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING	31	02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
25	0503010025	3/8 SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	32	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
30	0503010140	1/8" X 3/4" COTTERPIN		02
31	0571018846	DISASSEMBLE LEVER		02

Item	Code	Description	See page	QT
32	0503033942	COMPACTOR WHEEL REGULATOR LID		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
37	0503012412	5/8" UNC SELF LOCKING NUT		04
38	0511061759	22Z P12,70 FQ 3/4" GEAR		02
39	0501053788	3/4" SQUARE AXLE FASTENER	30	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING	31	02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
44	0503010025	3/8 SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	32	02
47	0511064536	28Z GEAR		02
48	0501053788	3/4" SQUARE AXLE FASTENER	30	02
49	0503030303	SUPPORT WASHER		02
50	0503010292	701164 6 X 40 SPRING PIN		02
51	0521018630	1.4" X SQUARE 0.8" WASHER		02
52	0501056271	GEARBOX CLOSED BEARING	31	02
53	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
54	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
55	0503010025	3/8 SPRING WASHER		04
56	0503010026	3/8" NUT		04
57	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	33	02
58	0511050652	CHAIN TENSIONER	34	04
59	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	35	02
60	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
61	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
62	0503013149	40-1 CHAIN X 157 LINK + MENDING + RED		02
63	0531062318	LEFT/RIGHT LOWER LEVER		02
64	0551019159	LEVER FIXER BODY		02
65	0561016468	FASTENER		02
66	0503011336	1/2" HEX SELF ADJUSTING NUT		04
67	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
68	0503010140	1/8" X 3/4" COTTERPIN		04
69	0521055335	RIGHT GEAR HOUSING SET	37	01
70	0521055337	LEFT GEAR HOUSING SET	45	01




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	12	04
13	0571018905	AXLE MOTOR 1675		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	26	02
16	0511051434	TRANSMISSION ACTUATOR	27	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	28	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	29	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		02
20	0501053788	3/4" SQUARE AXLE FASTENER	30	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING	31	02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
25	0503010025	3/8 SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	32	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
30	0503010140	1/8" X 3/4" COTTERPIN		02
31	0571018846	DISASSEMBLE LEVER		02

Item	Code	Description	See page	QT
32	0503033942	COMPACTOR WHEEL REGULATOR LID		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
37	0503012412	5/8" UNC SELF LOCKING NUT		04
38	0511061759	22Z P12,70 FQ 3/4" GEAR		02
39	0501053788	3/4" SQUARE AXLE FASTENER	30	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING	31	02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
44	0503010025	3/8 SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	32	02
47	0511064536	28Z GEAR		02
48	0501053788	3/4" SQUARE AXLE FASTENER	30	02
49	0503030303	SUPPORT WASHER		02
50	0503010292	701164 6 X 40 SPRING PIN		02
51	0521018630	1.4" X SQUARE 0.8" WASHER		02
52	0501056271	GEARBOX CLOSED BEARING	31	02
53	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
54	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
55	0503010025	3/8 SPRING WASHER		04
56	0503010026	3/8" NUT		04
57	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	33	02
58	0511050652	CHAIN TENSIONER	34	04
59	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	35	02
60	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
61	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
62	0503013149	40-1 CHAIN X 157 LINK + MENDING + RED		02
63	0531062318	LEFT/RIGHT LOWER LEVER		02
64	0551019159	LEVER FIXER BODY		02
65	0561016468	FASTENER		02
66	0503011336	1/2" HEX SELF ADJUSTING NUT		04
67	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
68	0503010140	1/8" X 3/4" COTTERPIN		04
69	0521055335	RIGHT GEAR HOUSING SET	37	01
70	0521055337	LEFT GEAR HOUSING SET	45	01




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	12	04
13	0571018906	AXLE MOTOR 1950		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	26	02
16	0511051434	TRANSMISSION ACTUATOR	27	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	28	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	29	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		02
20	0501053788	3/4" SQUARE AXLE FASTENER	30	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING	31	02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
25	0503010025	3/8 SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	32	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
30	0503010140	1/8" X 3/4" COTTERPIN		02
31	0571018846	DISASSEMBLE LEVER		02

Item	Code	Description	See page	QT
32	0503033942	COMPACTOR WHEEL REGULATOR LID		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
37	0503012412	5/8" UNC SELF LOCKING NUT		04
38	0511061759	22Z P12,70 FQ 3/4" GEAR		02
39	0501053788	3/4" SQUARE AXLE FASTENER	30	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING	31	02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
44	0503010025	3/8 SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	32	02
47	0511064536	28Z GEAR		02
48	0501053788	3/4" SQUARE AXLE FASTENER	30	02
49	0503030303	SUPPORT WASHER		02
50	0503010292	701164 6 X 40 SPRING PIN		02
51	0521018630	1.4" X SQUARE 0.8" WASHER		02
52	0501056271	GEARBOX CLOSED BEARING	31	02
53	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
54	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
55	0503010025	3/8 SPRING WASHER		04
56	0503010026	3/8" NUT		04
57	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	33	02
58	0511050652	CHAIN TENSIONER	34	04
59	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	35	02
60	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
61	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
62	0503013149	40-1 CHAIN X 157 LINK + MENDING + RED		02
63	0531062318	LEFT/RIGHT LOWER LEVER		02
64	0551019159	LEVER FIXER BODY		02
65	0561016468	FASTENER		02
66	0503011336	1/2" HEX SELF ADJUSTING NUT		04
67	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
68	0503010140	1/8" X 3/4" COTTERPIN		04
69	0521055335	RIGHT GEAR HOUSING SET	37	01
70	0521055337	LEFT GEAR HOUSING SET	45	01




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	12	04
13	0571018907	AXLE MOTOR 2125		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	26	02
16	0511051434	TRANSMISSION ACTUATOR	27	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	28	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	29	01
19	0511061759	22Z P12,70 FQ 3/4" GEAR		02
20	0501053788	3/4" SQUARE AXLE FASTENER	30	02
21	0503030303	SUPPORT WASHER		04
22	0501056271	GEARBOX CLOSED BEARING	31	02
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
25	0503010025	3/8 SPRING WASHER		04
26	0503010026	3/8" NUT		04
27	0511057265	TRANSMISSION CHAIN TENSIONER	32	02
28	0521010773	0.37" X 1.18" COUPLING SHAFT		02
29	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06
30	0503010140	1/8" X 3/4" COTTERPIN		02
31	0571018846	DISASSEMBLE LEVER		02

Item	Code	Description	See page	QT
32	0503033942	COMPACTOR WHEEL REGULATOR LID		02
33	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
34	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
35	0503030093	TRACTION SPRING		02
36	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
37	0503012412	5/8" UNC SELF LOCKING NUT		04
38	0511061759	22Z P12,70 FQ 3/4" GEAR		02
39	0501053788	3/4" SQUARE AXLE FASTENER	30	02
40	0503030275	AGRICULTURAL BEARING		02
41	0501056271	GEARBOX CLOSED BEARING	31	02
42	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
43	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
44	0503010025	3/8 SPRING WASHER		04
45	0503010026	3/8" NUT		04
46	0511057265	TRANSMISSION CHAIN TENSIONER	32	02
47	0511064536	28Z GEAR		02
48	0501053788	3/4" SQUARE AXLE FASTENER	30	02
49	0503030303	SUPPORT WASHER		02
50	0503010292	701164 6 X 40 SPRING PIN		02
51	0521018630	1.4" X SQUARE 0.8" WASHER		02
52	0501056271	GEARBOX CLOSED BEARING	31	02
53	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		04
54	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
55	0503010025	3/8 SPRING WASHER		04
56	0503010026	3/8" NUT		04
57	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	33	02
58	0511050652	CHAIN TENSIONER	34	04
59	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	35	02
60	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
61	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
62	0503013149	40-1 CHAIN X 157 LINK + MENDING + RED		02
63	0531062318	LEFT/RIGHT LOWER LEVER		02
64	0551019159	LEVER FIXER BODY		02
65	0561016468	FASTENER		02
66	0503011336	1/2" HEX SELF ADJUSTING NUT		04
67	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
68	0503010140	1/8" X 3/4" COTTERPIN		04
69	0521055335	RIGHT GEAR HOUSING SET	37	01
70	0521055337	LEFT GEAR HOUSING SET	45	01




Item	Code	Description	See page	QT
01	0521065954	SUPPORT BEARING AXLE MOTOR		04
02	0501110639	BEARING		08
03	0503011099	GREASE FITTING		08
04	0503010300	5/32" X 1" COTTERPIN		08
05	0511015961	LOCK BUSHING		04
06	0503030679	BOLT 1/2 UNC X 1.1/4 CSPC G.5 ZN		04
07	0503010060	1/2 UNC G.5 ZN HEX NUT		04
08	0521014021	1/2" X 4.5" X 5.4" FASTENER		08
09	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		16
10	0503010019	1/2" SPRING WASHER		16
11	0503010060	1/2 UNC G.5 ZN HEX NUT		16
12	0501058241	WHEEL SUPPORT CHAIN TENSIONER	12	04
13	0571018908	MOTOR SHAFT 2350		02
14	0501018466	FLAT WASHER		02
15	0501052560	MOTOR AXLE SIGNAL	26	02
16	0511051434	TRANSMISSION ACTUATOR	27	04
17	0511047069	RIGHT SIDE TRANSMISSION ACTUATOR	28	01
18	0511047070	LEFT SIDE TRANSMISSION ACTUATOR	29	01
19	0521055335	RIGHT GEAR HOUSING SET	37	01
20	0521055337	LEFT GEAR HOUSING SET	45	01
21	0511061759	22Z P12,70 FQ 3/4" GEAR		02
22	0501053788	3/4" SQUARE AXLE FASTENER	30	06
23	0503030303	SUPPORT WASHER		06
24	0501056271	GEARBOX CLOSED BEARING	31	06
25	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		12
26	0501010984	10,50 X 27 X 3,00 FLAT WASHER		28
27	0503010025	3/8 SPRING WASHER		12
28	0503010026	3/8" NUT		12
29	0511057265	TRANSMISSION CHAIN TENSIONER	32	04
30	0521010773	0.37" X 1.18" COUPLING SHAFT		02
31	0501010984	10,50 X 27 X 3,00 FLAT WASHER		06


Item	Code	Description	See page	QT
32	0503010140	1/8" X 3/4" COTTERPIN		02
33	0571018846	DISASSEMBLE LEVER		02
34	0503033942	COMPACTOR WHEEL REGULATOR LID		02
35	0571018844	SUPPORT RIGHT DISASSEMBLE LEVER		01
36	0571018845	SUPPORT LEFT DISASSEMBLE LEVER		01
37	0503030093	TRACTION SPRING		02
38	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
39	0503012412	5/8" UNC SELF LOCKING NUT		04
40	0511061759	22Z P12,70 FQ 3/4" GEAR		02
41	0503030275	AGRICULTURAL BEARING		02
42	0503010292	701164 6 X 40 SPRING PIN		02
43	0521018630	1.4" X SQUARE 0.8" WASHER		02
44	0501052810	TRANSMISSION CHAIN TENSIONER ASSEMBLY	33	02
45	0511050652	CHAIN TENSIONER	34	04
46	0501053653	BEARING WITH GEAR 20Z 3/4 HEX SHAFT	35	02
47	0503015637	40-1 X 56 CHAIN LINK + REDUCTION		02
48	0503014870	40-1 X 59 CHAIN LINK + MENDING		02
49	0503013149	40-1 CHAIN X 157 LINK + MENDING + RED		02
50	0511069678	LH LOWER LEVER		02
51	0551019159	LEVER FIXER BODY		02
52	0561016468	FASTENER		02
53	0503011336	1/2" HEX SELF ADJUSTING NUT		04
54	0503010140	1/8" X 3/4" COTTERPIN		04
55	0511064536	28Z GEAR		02




Item	Code	Description	See page	QT
01	0503031825	AXLE MOTOR SLOW-MOVING		02
02	0503010240	BOLT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010337	5/16" NUT		02
05	0503031584	ADHESIVE LABEL		01
06	0503031585	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012696	RIGHT RATCHET HANDLE BODY		01
02	0571010151	GRAGGER RATCHET BODY		01
03	0561019923	RATCHET PULLER GEAR		01
04	0551019100	LOCK RATCHET		02
05	0503030051	0.2" X 1" X 0.1" COMPRESSION SPRING		02
06	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		04
07	0503013816	5/16" LOCKNUT		04
08	0571010164	SEAT SIDE OF RATCHET		01
09	0503010004	1890 GREASE FITTING		01
10	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
11	0503010060	1/2 UNC G.5 ZN HEX NUT		01
12	0571010763	FLANGE WASHER		02




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502012009	DRIVING AXLE RIGHT FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010710	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012539	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0502011996	SLEEVE FIXER		01
02	0503030678	BOLT 1/2 UNC X 1.1/2 CSPC G.5 ZN		01
03	0503010060	1/2 UNC G.5 ZN HEX NUT		01
04	0521017590	GUIDE AXLE		01
05	0503030553	2.3"X 2.5"X 0.2"COMPRESSION SPRING		01
06	0502011995	LH DRIVING AXLE FOLLOWER		01
07	0501019734	FLAT WASHER		02
08	0502010720	RIGHT CAM, SMALLER		02
09	0503010003	1845 GREASE FITTING		02
10	0502012540	26Z P12,7 GEAR		01
11	0501019735	FLAT WASHER		01
12	0521017593	FLAT WASHER		01
13	0503010542	501045 CLAMPING RING (FOR AXLE)		01




Item	Code	Description	See page	QT
01	0521010691	AXLE FASTENER		01
02	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		01
03	0511017303	FLAT WASHER		01
04	0503010143	1/4" SPRING WASHER		01
05	0503010144	1/4" NUT		01




Item	Code	Description	See page	QT
01	0502012310	GEAR BOX CLOSE BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0531019479	AXLE CHAIN GEAR		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		03
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0541011713	TENSIONER CHAIN LOWER AXLE		01
02	0503031805	11Z 1/2" GEAR		01
03	0503010302	501019 SEAL RING		01
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
05	0503010019	1/2" SPRING WASHER		01
06	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0551019171	CHAIN TIGHTENER AXLE		01
02	0503011410	ROLLER BEARING		01
03	0511062169	21Z P 1/2" GEAR		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0503011105	SEAL RING		01
06	0501011027	5/8" X 3-3/4" BOLT		01
07	0571010265	16.5 X 40 X 3 FLAT WASHER		01
08	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	36	01
02	0511063185	20Z GEAR WITH HEX HOLE AXLE 20		01
03	0503010707	501030 CLAMPING RING (FOR AXLE)		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0501010694	FLAT WASHER		04
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02



Item	Code	Description	See page	QT
01	0502012031	HOUSING BEARING		01
02	0503012861	6006 2RS BALL BEARING		02
03	0503012858	502075 CLAMPING RING (FOR HOLE)		01




Item	Code	Description	See page	QT
01	0511058381	RIGHT GEAR HOUSING	38	01
02	0521065955	RIGHT GEARBOX LID		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0503010019	1/2" SPRING WASHER		01
07	0501010694	FLAT WASHER		06
08	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01




Item	Code	Description	See page	QT
01	0521065939	RIGHT GEAR BOX		01
02	0511060396	DRIVE/DRIVEN SHAFT		04
03	0503012389	1/2 BALL		04
04	0503031512	0.4" X 0.1"X 2" X 0.6" SPRING		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503010395	1/2" X 1-1/4" BOLT		04
07	0501056447	CENTRAL DOUBLE GEAR HOUSING BEARING	39	01
08	0503030303	SUPPORT WASHER		06
09	0503012204	40-1 CHAIN X 82 LINK + RED		02
10	0503012143	78 CHAIN X 40-1 LINK + REDUCTION		01
11	0501056271	GEARBOX CLOSED BEARING	31	03
12	0503011953	5/16" X 1" BOLT		06
13	0501010694	FLAT WASHER		06
14	0503010179	LOCK WASHER 5/16 ZN 1K01528		06
15	0503010337	5/16" NUT		06
16	0511061758	21Z GEAR		01
17	0502011758	REAR TIGHTENER LEVER		02
18	0503010002	1800 GREASE FITTING		02
19	0501048790	AXLE WITH RING	40	02
20	0503031366	RIGHT TWISTED SPRING		02
21	0503031805	11Z 1/2" GEAR		04
22	0503010302	501019 SEAL RING		04
23	0511061794	CHAIN TENSIONER		02
24	0571018903	AXLE INTERMEDIATE RECAMBIO		01
25	0511067501	26Z GEAR		01
26	0521010683	3/8 UNC FASTENER		02
27	0503010026	3/8" NUT		04
28	0571018902	GEAR BOX DRIVER AXLE		01
29	0571018900	SEED DRIVEN AXLE		01
30	0501056443	GEAR HOUSING BEARING	41	01
31	0503010292	701164 6 X 40 SPRING PIN		08


Item	Code	Description	See page	QT
32	0511057258	TENSIONER WITH GEAR	43	01
33	0511054363	CHAIN TENSIONER	44	01
34	0571018901	DRIVEN AXLE		01




Item	Code	Description	See page	QT
01	0502011978	HOUSING CENTRAL BEARING		01
02	0503013462	BEARING WITH BALL BEARING		02
03	0503011953	5/16" X 1" BOLT		02
04	0501010694	FLAT WASHER		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0521012476	GEAR BOX LEVER AXLE		01
02	0503031369	LINK		01




Item	Code	Description	See page	QT
01	0501056444	BEARING WITH ROLLER	42	01
02	0503011953	5/16" X 1" BOLT		02
03	0501010694	FLAT WASHER		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
05	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011697	GEARBOX BEARING		01
02	0503013462	BEARING WITH BALL BEARING		01
03	0503011105	SEAL RING		01




Item	Code	Description	See page	QT
01	0511062169	21Z P 1/2" GEAR		01
02	0503011410	ROLLER BEARING		01
03	0503011105	SEAL RING		01
04	0503010406	501025 CLAMPING RING (FOR AXLE)		01
05	0571019207	DEVIATION AXLE GEAR BOX		01
06	0503010899	5/8 UNC X 2.1/4 BOLT		01
07	0503012412	5/8" UNC SELF LOCKING NUT		01




Item	Code	Description	See page	QT
01	0531019398	AXLE TENSIONER CHAIN GEAR BOX		01
02	0503031805	11Z 1/2" GEAR		01
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		02
04	0503010019	1/2" SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511058382	LEFT GEAR HOUSING		01
02	0521065956	LEFT GEARBOX LID		01
03	0503010240	BOLT		02
04	0503013816	5/16" LOCKNUT		02
05	0503033682	KNOB 3P K3 60A M12 X 40		01
06	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
07	0503010019	1/2" SPRING WASHER		01
08	0501010694	FLAT WASHER		06




Item	Code	Description	See page	QT
01	0531055584	HOPPER SUPPORT WITH FERTILIZER METERING - 3245	47	01
02	0503062362	FERTILIZER HOPPER	66	02
03	0503013751	3/8 UNC X 1.1/4 BOLT		12
04	0571019051	FIXER HOPPER WASHER		12
05	0503012535	3/8" SPRING WASHER		12
06	0503012531	3/8" INOX NUT		12
07	0503011957	NYLON HANDLE		02
08	0503010371	5/16" X 1" BOLT		04
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
10	0503010337	5/16" NUT		04
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		20
13	0503010025	3/8 SPRING WASHER		10
14	0503010026	3/8" NUT		10




Item	Code	Description	See page	QT
01	0531064280	HOPPER SUPPORT - 3245		01
02	0501053788	3/4" SQUARE AXLE FASTENER	30	04
03	0503031527	AGRICULTURAL BEARING		04
04	0531055319	ALPHA II FERTILIZER METERING	59	08
05	0531057911	22Z GEAR SIDE BEARING ASSEMBLY	64	02
06	0501311131	3/4 X 450 AXLE WITH HOLE		02
07	0531057908	SLEEVE 1/4 X 2		06
07A	0502013069	SLEEVE 21 X 38 X 50		01
07B	0503010010	1/4" X 2.1/2" COTTERPIN		01
08	0501310661	3/4" X 15,35"/15,27" AXLE		06




Item	Code	Description	See page	QT
01	0531055386	HOPPER SUPPORT WITH FERTILIZER METERING - 3495	49	01
02	0503062362	FERTILIZER HOPPER	66	02
03	0503013751	3/8 UNC X 1.1/4 BOLT		12
04	0571019051	FIXER HOPPER WASHER		12
05	0503012535	3/8" SPRING WASHER		12
06	0503012531	3/8" INOX NUT		12
07	0503011957	NYLON HANDLE		02
08	0503010371	5/16" X 1" BOLT		04
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
10	0503010337	5/16" NUT		04
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		20
13	0503010025	3/8 SPRING WASHER		10
14	0503010026	3/8" NUT		10




Item	Code	Description	See page	QT
01	0531064089	HOPPER SUPPORT - 3495		01
02	0501053788	3/4" SQUARE AXLE FASTENER	30	06
03	0503031527	AGRICULTURAL BEARING		06
04	0531055319	ALPHA II FERTILIZER METERING	59	08
05	0531057913	DOUBLE BEARING ASSEMBLY		02
06	0531057908	SLEEVE 1/4 X 2		08
06A	0502013069	SLEEVE 21 X 38 X 50		01
06B	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0501218689	AXLE 3/4 X 190 WITH HOLE		02
08	0501218850	3/4 X 360/362 AXLE		02
09	0501218487	3/4 X 390 AXLE		06




Item	Code	Description	See page	QT
01	0531059676	RIGHT HOPPER SUPPORT WITH FERTILIZER 51 METERING - 4045		01
02	0531059675	LEFT HOPPER SUPPORT WITH FERTILIZER 52 METERING - 4045		01
03	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
04	0501010984	10,50 X 27 X 3,00 FLAT WASHER		20
05	0503010025	3/8 SPRING WASHER		10
06	0503010026	3/8" NUT		10
07	0503011957	NYLON HANDLE		02
08	0503018441	5/16" X 1-1/4" BOLT		04
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
10	0503010337	5/16" NUT		04
11	0503013751	3/8 UNC X 1.1/4 BOLT		16
12	0571019051	FIXER HOPPER WASHER		16
13	0503012535	3/8" SPRING WASHER		16
14	0503012531	3/8" INOX NUT		16
15	0503062391	FERTILIZER HOPPER	67	02




Item	Code	Description	See page	QT
01	0531065998	RIGHT HOPPER SUPPORT - 4045		01
02	0501053788	3/4" SQUARE AXLE FASTENER	30	02
03	0503030303	SUPPORT WASHER		02
04	0531057913	DOUBLE BEARING ASSEMBLY		01
05	0501310869	3/4 X 475 AXLE		01
06	0531055319	ALPHA II FERTILIZER METERING	59	05
07	0501218487	3/4 X 390 AXLE		03
08	0531057908	SLEEVE 1/4 X 2		04
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010010	1/4" X 2.1/2" COTTERPIN		01
09	0501310860	3/4 X 350/348 AXLE		01




Item	Code	Description	See page	QT
01	0531065999	LEFT HOPPER SUPPORT - 4045		01
02	0501053788	3/4" SQUARE AXLE FASTENER	30	02
03	0503030303	SUPPORT WASHER		02
04	0531057913	DOUBLE BEARING ASSEMBLY		01
05	0501310869	3/4 X 475 AXLE		01
06	0531055319	ALPHA II FERTILIZER METERING	59	05
07	0501218487	3/4 X 390 AXLE		03
08	0531057908	SLEEVE 1/4 X 2		04
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010010	1/4" X 2.1/2" COTTERPIN		01
09	0501310860	3/4 X 350/348 AXLE		01




Item	Code	Description	See page	QT
01	0531059583	LEFT HOPPER SUPPORT WITH FERTILIZER 55 METERING - 4395		01
02	0531059579	RIGHT HOPPER SUPPORT WITH FERTILIZER 54 METERING - 4395		01
03	0503011957	NYLON HANDLE		02
04	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
05	0503010337	5/16" NUT		04
06	0503018441	5/16" X 1-1/4" BOLT		04
07	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		10
08	0503010025	3/8 SPRING WASHER		10
09	0503010026	3/8" NUT		10
10	0501010984	10,50 X 27 X 3,00 FLAT WASHER		20
11	0503062391	FERTILIZER HOPPER	67	02
12	0503013751	3/8 UNC X 1.1/4 BOLT		16
13	0571019051	FIXER HOPPER WASHER		16
14	0503012535	3/8" SPRING WASHER		16
15	0503012531	3/8" INOX NUT		16




Item	Code	Description	See page	QT
01	0531065982	RIGHT HOPPER SUPPORT - 4395		01
02	0531055319	ALPHA II FERTILIZER METERING	59	05
03	0501218487	3/4 X 390 AXLE		03
04	0531057908	SLEEVE 1/4 X 2		04
04A	0502013069	SLEEVE 21 X 38 X 50		01
04B	0503010010	1/4" X 2.1/2" COTTERPIN		01
05	0501053788	3/4" SQUARE AXLE FASTENER	30	07
06	0503030303	SUPPORT WASHER		07
07	0531057913	DOUBLE BEARING ASSEMBLY		01
08	0501218689	AXLE 3/4 X 190 WITH HOLE		01
09	0501218577	3/4 X 790 AXLE WITH RELIEF		01




Item	Code	Description	See page	QT
01	0531065981	LEFT HOPPER SUPPORT - 4395		01
02	0531055319	ALPHA II FERTILIZER METERING	59	05
03	0501218487	3/4 X 390 AXLE		03
04	0531057908	SLEEVE 1/4 X 2		04
04A	0502013069	SLEEVE 21 X 38 X 50		01
04B	0503010010	1/4" X 2.1/2" COTTERPIN		01
05	0501053788	3/4" SQUARE AXLE FASTENER	30	07
06	0503030303	SUPPORT WASHER		07
07	0531057913	DOUBLE BEARING ASSEMBLY		01
08	0501218689	AXLE 3/4 X 190 WITH HOLE		01
09	0501218577	3/4 X 790 AXLE WITH RELIEF		01




Item	Code	Description	See page	QT
01	0531059598	RIGHT HOPPER SUPPORT WITH FERTILIZER 57 METERING - 4845		01
02	0531059597	LEFT HOPPER SUPPORT WITH FERTILIZER 58 METERING - 4845		01
03	0503013751	3/8 UNC X 1.1/4 BOLT		20
04	0571019051	FIXER HOPPER WASHER		20
05	0503012535	3/8" SPRING WASHER		20
06	0503012531	3/8" INOX NUT		20
07	0503011957	NYLON HANDLE		02
08	0503018441	5/16" X 1-1/4" BOLT		04
09	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
10	0503010337	5/16" NUT		04
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		14
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		28
13	0503010025	3/8 SPRING WASHER		14
14	0503010026	3/8" NUT		14
15	0503062362	FERTILIZER HOPPER	66	03




Item	Code	Description	See page	QT
01	0531065992	RIGHT HOPPER SUPPORT - 4845		01
02	0501053788	3/4" SQUARE AXLE FASTENER	30	07
03	0503030303	SUPPORT WASHER		07
04	0531057913	DOUBLE BEARING ASSEMBLY		01
05	0501218577	3/4 X 790 AXLE WITH RELIEF		01
06	0531055319	ALPHA II FERTILIZER METERING	59	06
07	0501218487	3/4 X 390 AXLE		03
08	0531057908	SLEEVE 1/4 X 2		04
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010010	1/4" X 2.1/2" COTTERPIN		01
09	0501310789	3/4 X 477 AXLE		01




Item	Code	Description	See page	QT
01	0531065991	LEFT HOPPER SUPPORT - 4845		01
02	0501053788	3/4" SQUARE AXLE FASTENER	30	07
03	0503030303	SUPPORT WASHER		07
04	0531057913	DOUBLE BEARING ASSEMBLY		01
05	0501218577	3/4 X 790 AXLE WITH RELIEF		01
06	0531055319	ALPHA II FERTILIZER METERING	59	06
07	0501218487	3/4 X 390 AXLE		03
08	0531057908	SLEEVE 1/4 X 2		04
08A	0502013069	SLEEVE 21 X 38 X 50		01
08B	0503010010	1/4" X 2.1/2" COTTERPIN		01
09	0501310789	3/4 X 477 AXLE		01




Item	Code	Description	See page	QT
01	0503035913	METERING BODY FIXING ADAPTER		01
02	0503035911	REAR COLLECTOR SEAL		01
03	0503035912	FRONT COLLECTOR SEAL		01
04	0531055518	WORM THREAD ASSEMBLED		01
04A	0531064265	WORM THREAD		01
04B	0503035859	SUPPORT SLEEVE		01
05	0531055863	ASSY TRANSMISSION HUB	60	01
06	0531055875	ALPHA II FERTILIZER FIXING GUIDE SET	61	01
07	0501111134	LID WITH ALPHA FERTILIZER METERING GUIDE SLEEVE		01
07A	0503063799	LID WITH FERTILIZER METERING WASHER ALPHA		01
07B	0503035822	GUIDE SLEEVE SPRING CONDUCTOR		01
08	0501214337	FERTILIZER METERING BOX		01
09	0513011169	ALLEN SCREW 1/4 UNC X 1 CCSI STAINLESS STEEL		04
10	0513011172	ALLEN SCREW 3/8 UNC X 1 CASI STAINLESS STEEL		04
11	0503035931	FERTILIZER METERING SEAL		01
12	0513011173	NUT 3/8 UNC X 1		04
13	0513011174	FLAT WASHER 10.50 X 20 X 2.00 STAINLESS STEEL		05
14	0513011167	FLAT WASHER 6.4 X 12 X 1.60 STAINLESS STEEL		04
15	0513011170	ALLEN SCREW 1/4 UNC X 7/8 CCSI STAINLESS STEEL		04
16	0513011171	1/4 NC HEX NUT		08
17	0503036181	30 X 47 X 6.50 SEAL SUPPLEMENT		01
18	0501310211	FRONT LID		01
19	0503036177	LID CORD		01
20	0531059139	ASSY COLLECTOR	62	01
21	0501310274	FLAT WASHER 46.10 X 32 X 0.80		01
22	0503035797	FRONT COLLECTOR FIXER		02
23	0501111195	GRANULATED FERTILIZER COATING		01




Item	Code	Description	See page	QT
01	0502013056	CONICAL PINION MOTOR 13Z ALPHA FERTILIZER METERING		01
02	0503011800	SEAL RING		02
03	0513010740	RETAINER 62 X 35 X 7 BRG 7159		02
04	0503016065	ROLLER BEARING		02
05	0503019373	6006 2RS1 NATIONAL BEARING		02
06	0503012858	502075 CLAMPING RING (FOR HOLE)		01
07	0503010707	501030 CLAMPING RING (FOR AXLE)		01
08	0501111141	GEAR WITH ALPHA FERTILIZER METERING CAP		01
09	0501215105	METERING TRANSMISSION HUB		01
10	0501215104	TRANSMISSION HUB SLEEVE		01
11	0513011272	SEAL 7435-BRG 30 X 55 X 8.00MM		01
12	0501219613	FIXER BREATHER COVER		01
13	0513011248	RING RING 62.00 X 1.50		01
14	0503036071	TATU LOGO ADHESIVE LABEL 41.5 X 29		01
15	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503035915	RIGHT GUIDE DOSING COVER		01
02	0503035916	LEFT GUIDE DISPENSER COVER		01
03	0501310245	ALPHA FERTILIZER DISPENSER COVER LATCH		01
04	0501310247	LEFT SAFETY LOCK SLEEVE		01
05	0513011249	ALLEN SCREW M4 X 20 CCSI STAINLESS STEEL		02
06	0501310246	RIGHT SAFETY LOCK SLEEVE		01
07	0513011507	FLANGED HEX SCREW AT 3.5 X 19 STAINLESS STEEL		08
08	0513011518	FLAT WASHER M4 STAINLESS STEEL AISI 304 4.3 X 12 X 1 MM		01




Item	Code	Description	See page	QT
01	0503036178	DISPENSER SIDE COVER COLLECTOR		01
02	0531055273	ALPHA FERTILIZER METERING CLAMP	63	01
03	0503036166	DISPENSER RIGHT SIDE COVER		01
04	0501219838	COLLECTOR SIDE LID AXLE		02
05	0503036167	DISPENSER LEFT SIDE COVER		01
06	0503036180	ALPHA FERTILIZER DOSING NOZZLE 50MM		01
07	0503036203	RIGHT TORSION SPRING DISPENSER SIDE COVER		02
08	0503036202	LEFT TORSION SPRING SIDE COVER		02




Item	Code	Description	See page	QT
01	0503035812	BODY CLAMP COLLECTOR FERTILIZER METERING ALPHA		02
02	0513010691	ALLEN SCREW 1/4 UNC X 1.1/2 CCSI INOX		02
03	0503012118	1/4" INOX NUT		02




Item	Code	Description	See page	QT
01	0531057910	SIDE BEARING WITH BEARING 6007		02
01A	0502013070	SIDE FERTILIZER HOPPER SUPPORT BEARING		01
01B	0503016065	ROLLER BEARING		01
01C	0503011800	SEAL RING		01
02	0503010337	5/16" NUT		02
03	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
04	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02
05	0502013067	SIDE BEARING AXLE FERTILIZER HOPPER SUPPORT		01
06	0531057901	GEAR	65	01
07	0503010845	501035 CLAMPING RING (FOR AXLE)		01
08	0503030119	LOCK PIN		01




Item	Code	Description	See page	QT
01	0531065402	GEAR		01
02	0503013958	1/4" X 1" BOLT		02




Item	Code	Description	See page	QT
01	0503034085	BEAN FERTILIZER ASSY		01
02	0503034086	HOPPER LID		01
03	0503034087	LID ARTICULATING TUBE		02
04	0503034088	WASHER		04
05	0503010131	3/16" X 1-1/2" COTTERPIN		04
06	0503034130	PLATE		01
07	0503032053	BOLT C.A.S.I		04
08	0503034220	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0503034127	FERTILIZER HOPPER		01
02	0503034129	LOWER HOPPER LID		01
03	0503034128	UPPER HOPPER LID		01
04	0503034130	PLATE		01
05	0503032053	BOLT C.A.S.I		04
06	0503034220	FLAT WASHER		04
07	0503034087	LID ARTICULATING TUBE		04
08	0503034088	WASHER		08
09	0503010131	3/16" X 1-1/2" COTTERPIN		08




Item	Code	Description	See page	QT
01	0511057267	HOSE KIT HYDRAULIC		01
01A	0501080722	3/8 X 3300 TC-TM HOSE ASSY		01
01B	0501082023	HOSE 3/8 X 3600 TC-TM		01
02	0501053834	MALE QUICK COUPLER	71	02
03	0503013100	NYLON CLAMP		02
04	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0511057335	HOSE KIT HYDRAULIC		01
01A	0501080025	3/8" X 55,11" TR-TC HOSE		04
01B	0521052285	TC-TM HOSE ASSY		01
01BA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01BB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01BD	0503018952	PLASTIC BOLT		06
01C	0521052330	HOSE 3/8 X 4000 TC-TM PRET/AZUL		01
01CA	0501080422	HOSE 3/8 X 4000 TC-TM		01
01CB	0503034492	HYDRAULIC HOSE GRIP (BLACK)		01
01CC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01CD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	71	02
03	0511058120	KIT VALVE SUPPORT		01
03A	0521066354	OIL DISTRIBUTOR BODY		02
03B	0502010477	HOSE CLAMP		04
03C	0503011268	3/8" X 2-1/2" BOLT		02
03D	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
03E	0503010025	3/8 SPRING WASHER		02
03F	0503010026	3/8" NUT		02
04	0503013100	NYLON CLAMP		02
05	0502012702	BODY SUPPORT CLAMP		04
06	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		04
07	0503010180	7/16" SPRING WASHER		04
08	0531011180	UPPER BODY CLIP		04
09	0571017774	SPRING PROTECTION QUICK HOSE		01




Item	Code	Description	See page	QT
01	0511057847	ASSY HOSE TURBINE		01
01A	0521052531	3/8 X 6108 TC-TM HOSE YELLOW / GREEN		01
01AA	0501080850	3/8" X 240" TC-TM HOSE		01
01AB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01AC	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
01AD	0503018952	PLASTIC BOLT		06
01B	0521052528	1/2 X 6200 TC-TM HOSE YELLOW / RED		01
01BA	0501081810	HOSE 1/2 X 6200 TC-TM		01
01BB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01BC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
01BD	0503018952	PLASTIC BOLT		06
01C	0521052529	1/2 X 6200 TC-TM HOSE YELLOW / BLUE		01
01CA	0501081810	HOSE 1/2 X 6200 TC-TM		01
01CB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
01CC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
01CD	0503018952	PLASTIC BOLT		06
02	0501053834	MALE QUICK COUPLER	71	02
03	0581012991	SPRING PROTECTION PLASTIC HOSE		01
04	0503033981	ADHESIVE LABEL		01
05	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	106	01




Item	Code	Description	See page	QT
01	0503011627	MALE QUICK COUPLER AGR 1/2 NPT		01
02	0503011882	MALE QUICK COUPLER CAP		01




Item	Code	Description	See page	QT
01	0521065948	FRAME HANDRAIL - 3245		02
02	0503010752	1/2" X 3.1/2" BOLT		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0521065949	FRAME HANDRAIL - 3495		02
02	0503010752	1/2" X 3.1/2" BOLT		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0521065950	FRAME HANDRAIL - 4045		02
02	0503010752	1/2" X 3.1/2" BOLT		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0521065951	FRAME HANDRAIL - 4395		02
02	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
03	0503010752	1/2" X 3.1/2" BOLT		04
04	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
05	0503010019	1/2" SPRING WASHER		08
06	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0521065952	FRAME HANDRAIL - 4845		02
02	0503010752	1/2" X 3.1/2" BOLT		08
03	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
04	0503010019	1/2" SPRING WASHER		08
05	0503010060	1/2 UNC G.5 ZN HEX NUT		08




Item	Code	Description	See page	QT
01	0571018864	PLATFORM - 3245		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0571018865	PLATFORM - 3495		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0571018866	PLATFORM - 4045		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0571018867	PLATFORM - 4395		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0571018868	PLATFORM - 4845		02
02	0503010237	3/8" X 1" BOLT		08
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		16
04	0503010025	3/8 SPRING WASHER		08
05	0503010026	3/8" NUT		08




Item	Code	Description	See page	QT
01	0502012742	FIXER SUPPORT LADDER	02	
02	0503010237	3/8" X 1" BOLT	04	
03	0503010025	3/8 SPRING WASHER	04	
04	0503010026	3/8" NUT	04	
05	0511069636	LADDER	01	
06	0503011179	3/8" X 2-1/4" BOLT	02	
07	0501010984	10,50 X 27 X 3,00 FLAT WASHER	02	
08	0503013357	3/8 SELF-ADJUSTING NUT	02	




Item	Code	Description	See page	QT
01	0501011543	5/8" X 4" BOLT		02
02	0511061835	PLOUGH SUPPORT		01
03	0503030012	HITCH PIN CLIP		01
04	0503012412	5/8" UNC SELF LOCKING NUT		02
05	0501011075	PIN		01
06	0502010175	HITCH CLAMP		01
07	0502011530	SUPPORT		01




Item	Code	Description	See page	QT
01	0502012806	SUPPORT REAR FIXER DRAWBAR	02	
02	0502012789	FIXER SUPPORT FERTILIZER ROW	02	
03	0503017960	5/8" X 3-12" BOLT	08	
04	0503010811	5/8" UNF SELF ADJUSTING NUT	08	
05	0501010191	1" X 6" BOLT	02	
06	0503010012	1" SPRING WASHER	02	
07	0501010059	1.5/8 NUT	02	
08	0502012805	SUPPORT FRONT FIXER DRAWBAR	02	
09	0502012789	FIXER SUPPORT FERTILIZER ROW	02	
10	0503017960	5/8" X 3-12" BOLT	08	
11	0503010811	5/8" UNF SELF ADJUSTING NUT	08	
12	0521065958	DRAWBAR	01	
13	0561019087	DRAWBAR TRANSPORT LOCK	01	
14	0551014099	COUPLING SHAFT 31,75 X 185	01	
15	0521010544	1.2" X 4.9" COUPLING SHAFT	01	
16	0503030085	LOCK PIN	02	
17	0503010002	1800 GREASE FITTING	01	




Item	Code	Description	See page	QT
01	0502012806	SUPPORT REAR FIXER DRAWBAR		04
02	0502012789	FIXER SUPPORT FERTILIZER ROW		04
03	0503017960	5/8" X 3-12" BOLT		16
04	0503010811	5/8" UNF SELF ADJUSTING NUT		16
05	0501010191	1" X 6" BOLT		04
06	0503010012	1" SPRING WASHER		04
07	0501010059	1.5/8 NUT		04
08	0502012805	SUPPORT FRONT FIXER DRAWBAR		04
09	0502012789	FIXER SUPPORT FERTILIZER ROW		04
10	0503017960	5/8" X 3-12" BOLT		16
11	0503010811	5/8" UNF SELF ADJUSTING NUT		16
12	0521065958	DRAWBAR		01
13	0561019087	DRAWBAR TRANSPORT LOCK		01
14	0551014099	COUPLING SHAFT 31,75 X 185		01
15	0521010544	1.2" X 4.9" COUPLING SHAFT		01
16	0503030085	LOCK PIN		02
17	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0503034116	ADHESIVE LABEL		02
02	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530		02
03	0503033416	ADHESIVE LABEL		02
04	0503033417	ADHESIVE LABEL		02
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
07	0503031428	READ MANUAL DECAL		01
08	0503031942	ADHESIVE LABEL		01
09	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
10	0503031565	ADHESIVE LABEL CARE		02
11	0503031566	ADHESIVE LABEL		02
12	0503034249	ADHESIVE LABEL TABLE PLANTS		02
13	0503031425	ADHESIVE LABEL ATTENTION		02
14	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
15	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
16	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
17	0503032930	ADHESIVE LABEL DANGER		04
18	0503031087	ADHESIVE LABEL		01
19	0503034003	SERIAL NUMBER TAG 61 X 118		01
20	0503010001	3.2 X 5.5 RIVET		04
21	0503032979	ADHESIVE LABEL LETTERS A B C D		02
22	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503034116	ADHESIVE LABEL		02
02	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530		02
03	0503033417	ADHESIVE LABEL		02
04	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		02
05	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
06	0503033423	LABEL ADHESIVE NUMBER 9		02
07	0503031428	READ MANUAL DECAL		01
08	0503031942	ADHESIVE LABEL		01
09	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
10	0503031565	ADHESIVE LABEL CARE		02
11	0503031566	ADHESIVE LABEL		02
12	0503034249	ADHESIVE LABEL TABLE PLANTS		02
13	0503031425	ADHESIVE LABEL ATTENTION		02
14	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
15	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
16	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
17	0503032930	ADHESIVE LABEL DANGER		04
18	0503031087	ADHESIVE LABEL		01
19	0503034003	SERIAL NUMBER TAG 61 X 118		01
20	0503010001	3.2 X 5.5 RIVET		04
21	0503032979	ADHESIVE LABEL LETTERS A B C D		02
22	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503034225	SUPREME ADHESIVE LABELS		02
02	0503034226	LABEL ADHESIVE		02
03	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)		04
04	0503033414	ADHESIVE LABEL 0 NUMBER FOR PLANTING		02
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
07	0503031428	READ MANUAL DECAL		01
08	0503031942	ADHESIVE LABEL		01
09	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
10	0503031565	ADHESIVE LABEL CARE		02
11	0503031566	ADHESIVE LABEL		02
12	0503034249	ADHESIVE LABEL TABLE PLANTS		02
13	0503031425	ADHESIVE LABEL ATTENTION		02
14	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
15	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
16	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
17	0503032930	ADHESIVE LABEL DANGER		05
18	0503031087	ADHESIVE LABEL		01
19	0503034003	SERIAL NUMBER TAG 61 X 118		01
20	0503010001	3.2 X 5.5 RIVET		04
21	0503032979	ADHESIVE LABEL LETTERS A B C D		02
22	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503034225	SUPREME ADHESIVE LABELS	02	
02	0503034226	LABEL ADHESIVE	02	
03	0503034229	ADHESIVE LABEL LOGO TATU LOWER (05 NOZZLES)	04	
04	0503033417	ADHESIVE LABEL	02	
05	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER	02	
06	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING	02	
07	0503033423	LABEL ADHESIVE NUMBER 9	02	
08	0503031428	READ MANUAL DECAL	01	
09	0503031942	ADHESIVE LABEL	01	
10	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27	02	
11	0503031565	ADHESIVE LABEL CARE	02	
12	0503031566	ADHESIVE LABEL	02	
13	0503034249	ADHESIVE LABEL TABLE PLANTS	02	
14	0503031425	ADHESIVE LABEL ATTENTION	02	
15	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER	02	
16	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
17	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT	01	
18	0503032930	ADHESIVE LABEL DANGER	05	
19	0503031087	ADHESIVE LABEL	01	
20	0503034003	SERIAL NUMBER TAG 61 X 118	01	
21	0503010001	3.2 X 5.5 RIVET	04	
22	0503032979	ADHESIVE LABEL LETTERS A B C D	02	
23	0503034500	ADHESIVE LABEL	01	




Item	Code	Description	See page	QT
01	0503034116	ADHESIVE LABEL		03
02	0503034114	ADHESIVE LABEL LOGO TATU HOPPER 190 X 530		03
03	0503033418	ADHESIVE LABEL 4 NUMBER FOR PLANTER		04
04	0503033419	ADHESIVE LABEL 5 NUMBER FOR PLANTING		02
05	0503033422	ADHESIVE LABEL		02
06	0503031428	READ MANUAL DECAL		01
07	0503031942	ADHESIVE LABEL		01
08	0503035927	ADHESIVE LABEL TABLE FERTILIZER P27		02
09	0503031565	ADHESIVE LABEL CARE		02
10	0503031566	ADHESIVE LABEL		02
11	0503034249	ADHESIVE LABEL TABLE PLANTS		02
12	0503031425	ADHESIVE LABEL ATTENTION		02
13	0503031424	ADHESIVE LABEL ATTENTION ROW HYDRAULIC MARKER		02
14	0503033012	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
15	0503033013	ADHESIVE LABEL RECAMBIO GEAR SEED / FERTILIZER LEFT		01
16	0503032930	ADHESIVE LABEL DANGER		06
17	0503031087	ADHESIVE LABEL		01
18	0503034003	SERIAL NUMBER TAG 61 X 118		01
19	0503010001	3.2 X 5.5 RIVET		04
20	0503032979	ADHESIVE LABEL LETTERS A B C D		02
21	0503034500	ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0502012789	FIXER SUPPORT FERTILIZER ROW		01
02	0521067033	FRAME LIFTING SUPPORT		01
03	0503017960	5/8" X 3-12" BOLT		04
04	0503010811	5/8" UNF SELF ADJUSTING NUT		04




Item	Code	Description	See page	QT
01	0581011989	SIDE BODY FIXER PLATFORM		01
02	0551019884	45 X 50 X 3/8 FASTENER		01
03	0503010025	3/8 SPRING WASHER		02
04	0503010026	3/8" NUT		02
05	0501011643	3/8 X 1"BOLT		02
06	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
07	0503013357	3/8 SELF-ADJUSTING NUT		02



Item	Code	Description	See page	QT
01	0581012097	RIGHT SUPPORT		01
02	0581012098	LEFT SUPPORT		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
07	0501010694	FLAT WASHER		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0581011439	AIR CONDUCTOR		02
11	0503011372	102 TO 121 CLAMP		02
12	0511057349	DISTRIBUTOR VACUUM 4045/4395	100	02
13	0503031436	AIR DISTRIBUTOR PUMP		02
14	0503010246	CLAMP		02
15	0571019403	STAPLE FIXER		04
16	0503010026	3/8" NUT		08
17	0503010025	3/8 SPRING WASHER		08
18	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
19	0581012095	AIR DISTRIBUTOR SUPPORT		04
20	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
21	0503010019	1/2" SPRING WASHER		08
22	0503010060	1/2 UNC G.5 ZN HEX NUT		08
23	0571013731	VACUUM GAUGE SUPPORT		01
24	0503013584	VACUUM GAUGE		01
25	0571019712	AIR CONDUCTOR		06
26	0571019716	ADAPTER		06
27	0511059887	TURBINE PRECISION PLANTING	101	01
28	0511057846	ASSY HOSE KIT	70	01
29	0521052549	CLAMP	132	12




Item	Code	Description	See page	QT
01	0511057701	TURBINE WITH HIDRAULIC MOTOR	99	01
02	0521066116	BOX PROTECTION HYDRAULIC CIRCUIT		01
03	0503011082	C1/2" X 1.3/4" SCREW		04
04	0501010937	13,50 X 28 X 3,00 FLAT WASHER		02
05	0503010019	1/2" SPRING WASHER		14
06	0503010060	1/2 UNC G.5 ZN HEX NUT		12
07	0571019399	SUPPORT FIXER RIGHT TURBINE		01
08	0571019398	SUPPORT FIXER LEFT TURBINE		01
09	0571019397	SUPPORT TUBE AR		04
10	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
11	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		08
12	0511057349	DISTRIBUTOR VACUUM 4045/4395	100	02
13	0571019403	STAPLE FIXER		04
14	0503010025	3/8 SPRING WASHER		08
15	0503010026	3/8" NUT		08
16	0571019552	SUPPORT VACUUM		01
17	0503013584	VACUUM GAUGE		01
18	0503015062	TUBE		03




Item	Code	Description	See page	QT
01	0581012097	RIGHT SUPPORT		01
02	0581012098	LEFT SUPPORT		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
07	0501010694	FLAT WASHER		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0581011439	AIR CONDUCTOR		02
11	0503011372	102 TO 121 CLAMP		02
12	0511057349	DISTRIBUTOR VACUUM 4045/4395	100	02
13	0503031436	AIR DISTRIBUTOR PUMP		01
14	0503010246	CLAMP		01
15	0571019403	STAPLE FIXER		04
16	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
17	0503010025	3/8 SPRING WASHER		08
18	0503010026	3/8" NUT		08
19	0581012095	AIR DISTRIBUTOR SUPPORT		04
20	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
21	0503010019	1/2" SPRING WASHER		08
22	0503010060	1/2 UNC G.5 ZN HEX NUT		08
23	0571013731	VACUUM GAUGE SUPPORT		01
24	0503013584	VACUUM GAUGE		01
25	0571019712	AIR CONDUCTOR		07
26	0571019716	ADAPTER		07
27	0511057846	ASSY HOSE KIT	70	01
27A	0501080850	3/8" X 240" TC-TM HOSE		01
27B	0501081810	HOSE 1/2 X 6200 TC-TM		02
27C	0501053834	MALE QUICK COUPLER	71	02
27D	0581012991	SPRING PROTECTION PLASTIC HOSE		01

Item	Code	Description	See page	QT
27E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	106	01
28	0511059887	TURBINE PRECISION PLANTING	101	01




Item	Code	Description	See page	QT
01	0581012097	RIGHT SUPPORT		01
02	0581012098	LEFT SUPPORT		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
07	0501010694	FLAT WASHER		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0581011439	AIR CONDUCTOR		02
11	0503011372	102 TO 121 CLAMP		02
12	0511057348	DISTRIBUTOR VACUUM	103	02
13	0503031436	AIR DISTRIBUTOR PUMP		02
14	0503010246	CLAMP		02
15	0571019403	STAPLE FIXER		04
16	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
17	0503010025	3/8 SPRING WASHER		08
18	0503010026	3/8" NUT		08
19	0581012095	AIR DISTRIBUTOR SUPPORT		04
20	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
21	0503010019	1/2" SPRING WASHER		08
22	0503010060	1/2 UNC G.5 ZN HEX NUT		08
23	0571013731	VACUUM GAUGE SUPPORT		01
24	0503013584	VACUUM GAUGE		01
25	0571019712	AIR CONDUCTOR		08
26	0571019716	ADAPTER		08
27	0511057846	ASSY HOSE KIT	70	01
27A	0501080850	3/8" X 240" TC-TM HOSE		01
27B	0501081810	HOSE 1/2 X 6200 TC-TM		02
27C	0501053834	MALE QUICK COUPLER	71	02
27D	0581012991	SPRING PROTECTION PLASTIC HOSE		01

Item	Code	Description	See page	QT
27E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	106	01
28	0511059887	TURBINE PRECISION PLANTING	101	01




Item	Code	Description	See page	QT
01	0581012097	RIGHT SUPPORT		01
02	0581012098	LEFT SUPPORT		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0581011439	AIR CONDUCTOR		02
07	0503011372	102 TO 121 CLAMP		02
08	0511057348	DISTRIBUTOR VACUUM	103	02
09	0503031436	AIR DISTRIBUTOR PUMP		01
10	0503010246	CLAMP		01
11	0571019403	STAPLE FIXER		04
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
13	0503010025	3/8 SPRING WASHER		08
14	0503010026	3/8" NUT		08
15	0581012095	AIR DISTRIBUTOR SUPPORT		04
16	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
17	0503010019	1/2" SPRING WASHER		08
18	0503010060	1/2 UNC G.5 ZN HEX NUT		08
19	0571013731	VACUUM GAUGE SUPPORT		01
20	0503013584	VACUUM GAUGE		01
21	0511057846	ASSY HOSE KIT	70	01
21A	0501080850	3/8" X 240" TC-TM HOSE		01
21B	0501081810	HOSE 1/2 X 6200 TC-TM		02
21C	0501053834	MALE QUICK COUPLER	71	02
21D	0581012991	SPRING PROTECTION PLASTIC HOSE		01
21E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	106	01
22	0511059887	TURBINE PRECISION PLANTING	101	01




Item	Code	Description	See page	QT
01	0581012097	RIGHT SUPPORT		01
02	0581012098	LEFT SUPPORT		01
03	0503011172	BOLT 1/2 UNC X 2.1/2 C S G.5 ZN		04
04	0503010019	1/2" SPRING WASHER		04
05	0503010060	1/2 UNC G.5 ZN HEX NUT		04
06	0503014491	SCREW 1/4 UNC X 2 CS G.5 ZN		02
07	0501010694	FLAT WASHER		02
08	0503010143	1/4" SPRING WASHER		02
09	0503010144	1/4" NUT		02
10	0581011439	AIR CONDUCTOR		02
11	0503011372	102 TO 121 CLAMP		02
12	0521050985	AIR DISTRIBUTOR	105	02
13	0503031436	AIR DISTRIBUTOR PUMP		02
14	0503010246	CLAMP		02
15	0571019403	STAPLE FIXER		04
16	0501010984	10,50 X 27 X 3,00 FLAT WASHER		08
17	0503010025	3/8 SPRING WASHER		08
18	0503010026	3/8" NUT		08
19	0581012095	AIR DISTRIBUTOR SUPPORT		04
20	0521014021	1/2" X 4.5" X 5.4" FASTENER		04
21	0503010019	1/2" SPRING WASHER		08
22	0503010060	1/2 UNC G.5 ZN HEX NUT		08
23	0571013731	VACUUM GAUGE SUPPORT		01
24	0503013584	VACUUM GAUGE		01
25	0571019712	AIR CONDUCTOR		10
26	0571019716	ADAPTER		10
27	0511059887	TURBINE PRECISION PLANTING	101	01
28	0511057846	ASSY HOSE KIT	70	01
28A	0511057847	ASSY HOSE TURBINE		01
28AA	0503033158	PLASTIC BAG		01
28AB	0521052531	3/8 X 6108 TC-TM HOSE YELLOW / GREEN		01

Item	Code	Description	See page	QT
28ABA	0501080850	3/8" X 240" TC-TM HOSE		01
28ABB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
28ABC	0503034497	HYDRAULIC HOSE GRIP (GREEN)		01
28ABD	0503018952	PLASTIC BOLT		06
28AC	0521052528	1/2 X 6200 TC-TM HOSE YELLOW / RED		01
28ACA	0501081810	HOSE 1/2 X 6200 TC-TM		01
28ACB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
28ACC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
28ACD	0503018952	PLASTIC BOLT		06
28AD	0521052529	1/2 X 6200 TC-TM HOSE YELLOW / BLUE		01
28ADA	0501081810	HOSE 1/2 X 6200 TC-TM		01
28ADB	0503034493	HYDRAULIC HOSE DEPTH (YELLOW)		01
28ADC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
28ADD	0503018952	PLASTIC BOLT		06
28B	0501053834	MALE QUICK COUPLER	71	02
28C	0581012991	SPRING PROTECTION PLASTIC HOSE		01
28D	0503033981	ADHESIVE LABEL		01
28E	0521050537	HITCH QUICK FEMALE WITH TURBINE HYDRAULIC DRAIN	106	01
29	0521052549	CLAMP	132	20




Item	Code	Description	See page	QT
01	0511057701	TURBINE WITH HIDRAULIC MOTOR	99	01
02	0501054983	NIPPLE HIDRAULIC MOTOR		01
02A	0503012871	HYDRAULIC MOTOR		01
02B	0531018770	R 3/4"UNF X R 1/4"BSP ELBOW		01
02C	0561016941	3/4" NUT		01
02D	0511014065	7/8" NF X R1/2NPT X 52 NIPPLE		02
02E	0541011065	3/4"UNF X R1/4BSP19FPP X43.5 NIPPLE		01
03	0503010025	3/8 SPRING WASHER		06
04	0503010026	3/8" NUT		04
05	0521044613	480 X 50 FAN (HIDRAULIC)	104	01
06	0503010143	1/4" SPRING WASHER		01
07	0503010849	3/8" X 1-1/2" BOLT		02
08	0531018764	FLAT WASHER		01
09	0503011104	M6 X 1" BOLT		01
10	0503012722	0.16" X 0.4" BLIND RIVET		20
11	0501054577	BLOCK COMMAND WITH NIPLES HYDRAULIC TURBINE		01
11A	0503012291	BLOCK COMMAND		01
11B	0501010590	NIPPLE		04
11C	0503010045	O'RING		04
11D	0541011066	3/4" UNF X 43.5 NIPPLE		01
11E	0503010190	2-114 N 3006-9B O'RING		01
12	0561010634	VALVE SUPPORT ASSY		01
13	0503010237	3/8" X 1" BOLT		02
14	0503010206	3/8 X 1/2 BOLT		02
15	0571018577	COVER SNAIL TURBINE		01
16	0521066237	SNAIL MECHANICAL TURBINE HIDRAULIC		01
17	0503010358	5/16" X 5/8" BOLT		02
18	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
19	0503010337	5/16" NUT		02
20	0501080125	HOSE 1/2 X 500 TR TR		02
21	0501080635	3/8" X 19" TR-TR HOSE		01


Item	Code	Description	See page	QT
22	0521018517	FLAT WASHER		02
23	0521066101	SUPPORT TURBINE		01
24	0503031649	CONECTOR CENTER		01




Item	Code	Description	See page	QT
01	0571019406	BODY DISTRIBUTOR VACUUM		01
02	0571017215	AIR DISTRIBUTOR SOCKET		01
03	0503012566	COVER KAP 110 YELLOW		01
04	0503031943	SOCKET		04
05	0503012856	POP RIVET		08




Item	Code	Description	See page	QT
01	0521050154	PRECISION PLANTING TURBINE WITH HOLE	102	01
02	0503015420	CV10208TN5 ANTI-CAVITATION VALVE		01
03	0501011460	7/8 NF REDUCTION NIPPLE		04
04	0503034385	NIPPLE 7/16 UNF X UNF JIC		01
05	0503010392	2-046 N 3006 9B O'RING		01
06	0503010190	2-114 N 3006-9B O'RING		04
07	0501080218	1/2 X 750 HOSE		01
08	0581012096	ROUND SLEEVE		02
09	0503031087	ADHESIVE LABEL		01
10	0503031426	ADHESIVE LABEL ATTENTION TURBINE		01




Item	Code	Description	See page	QT
01	0503062627	HYDRAULIC TURBINE ASSY		01




Item	Code	Description	See page	QT
01	0571017215	AIR DISTRIBUTOR SOCKET		01
02	0503012566	COVER KAP 110 YELLOW		01
03	0503031943	SOCKET		05
04	0503012856	POP RIVET		10
05	0571019405	BODY DISTRIBUTOR VACUUM 4845/5345		01




Item	Code	Description	See page	QT
01	0571016947	DISC FRONT TURBINE		01
02	0571016949	DISC REAR TURBINE		01
03	0521065171	HUB FLANGE		01
04	0571016950	DISC STRENGTHENING TURBINE		01
05	0571016951	FLIP TURBINE		10
06	0503012651	M6 X 1" BOLT		05
07	0503010143	1/4" SPRING WASHER		05
08	0503011776	M6 SELF ADJUSTINGNUT		05




Item	Code	Description	See page	QT
01	0581014326	BODY DISTRIBUTOR AR		01
02	0571017215	AIR DISTRIBUTOR SOCKET		01
03	0503012566	COVER KAP 110 YELLOW		01
04	0503031943	SOCKET		06
05	0503012856	POP RIVET		12




Item	Code	Description	See page	QT
01	0503018799	QUICK COUPLING		01
02	0503011883	QUICK CONNECTION COVER		01




Item	Code	Description	See page	QT
01	0521055338	ROW SEED BEARING	109	06
02	0511054314	TRANSMISSION AXLE LOCK SLEEVE		24
02A	0502012699	TRANSMISSION HUB LOCK SLEEVE		01
02B	0503010256	3/8" X 3/4" BOLT		01
03	0571018918	3/4 X 2305 AXLE HEX		01
04	0571018919	3/4 X 2490 AXLE HEX		01




Item	Code	Description	See page	3245	3495	4045	4395	4845	5345	5745
01	0571018910	3/4 X 1505 AXLE HEX		01	00	00	00	00	00	00
01.	0571018911	3/4 X 1690 AXLE HEX		01	00	00	00	00	00	00
02	0571018912	3/4 X 1630 AXLE HEX		00	01	00	00	00	00	00
02.	0571018913	3/4 X 1815 AXLE HEX		00	01	00	00	00	00	00
03	0571018914	3/4 X 1905 AXLE HEX		00	00	01	00	00	00	00
03.	0571018915	3/4 X 2090 AXLE HEX		00	00	01	00	00	00	00
04	0571018916	3/4 X 2080 AXLE HEX		00	00	00	01	00	00	00
04.	0571018917	3/4 X 2265 AXLE HEX		00	00	00	01	00	00	00
05	0571018918	3/4 X 2305 AXLE HEX		00	00	00	00	01	00	00
05.	0571018919	3/4 X 2490 AXLE HEX		00	00	00	00	01	00	00
06	0571018920	3/4 X 2555 AXLE HEX		00	00	00	00	00	01	00
06.	0571018921	3/4 X 2740 AXLE HEX		00	00	00	00	00	01	00
06..	0581012908	3/4 X 2755 AXLE HEX		00	00	00	00	00	00	01
06...	0581012909	3/4 X 2940 AXLE HEX		00	00	00	00	00	00	01
07	0501053654	3/4 SEED TRANSMISSION DOUBLE BEARING	36	01	01	01	01	01	01	01
07A	0502012031	HOUSING BEARING		01	01	01	01	01	01	01
07B	0503012861	6006 2RS BALL BEARING		02	02	02	02	02	02	02
07C	0503012858	502075 CLAMPING RING (FOR HOLE)		01	01	01	01	01	01	01
08	0511063185	20Z GEAR WITH HEX HOLE AXLE 20		01	01	01	01	01	01	01
09	0503010707	501030 CLAMPING RING (FOR AXLE)		01	01	01	01	01	01	01
10	0503010365	BOLT 5/16 UNC X 1.1/4 C S G.5 ZN		02	02	02	02	02	02	02
11	0501010694	FLAT WASHER		04	04	04	04	04	04	04
12	0503010179	LOCK WASHER 5/16 ZN 1K01528		02	02	02	02	02	02	02
13	0503010337	5/16" NUT		02	02	02	02	02	02	02
14	0581012949	BEARING COVER		01	01	01	01	01	01	01




Item	Code	Description	See page	QT
01	0551015804	BEARING AXLE BODY		01
02	0503010707	501030 CLAMPING RING (FOR AXLE)		01
03	0501053566	ROW SEED BEARING		01
03A	0502012030	HOUSING BEARING		01
03B	0503012861	6006 2RS BALL BEARING		01
03C	0503012858	502075 CLAMPING RING (FOR HOLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
06	0503010337	5/16" NUT		02
07	0501013518	FLAT WASHER		02
08	0501010694	FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503063631	KIT MONITORING SEED		01
01A	0503019725	CABLE		01
01B	0503019100	SENSOR		10
01C	0503017602	MONITOR PLANT PM400		01
01D	0503017443	ANTENNA GPS PM 400		01
01E	0503017031	CLEANING BRUSH		01
01F	0503019720	NYLON CLAMP		01
02	0503016234	TRIMBLE FIXING WINDOW		01
03	0503016452	FIXING SUPPORT AG500 TRIMBLE		01
04	0571012196	MOUNTING BRACKET PM 400		01
05	0503010803	SCREW 3/16 UNC X 3/4 CAF G.2 ZN		02
06	0503010669	FLAT WASHER		02
07	0503010668	3/16" SPRING WASHER		02
08	0503010667	3/16" NUT		02







Item	Code	Description	See page	QT
01	0501069529	653 TURNBUCKLE		01
02	0521065959	JACK R.1.1/2 UNC RIGHT X 240		01
03	0521065960	JACK R.1.1/2 UNC LEFT X 240		01
04	0501061056	RH LOCKNUT WITH HANDLER		01
05	0503010002	1800 GREASE FITTING		02




Item	Code	Description	See page	QT
01	0503010002	1800 GREASE FITTING		01
02	0503016482	BOLT		02
03	0502040846	U TRACTOR HITCH		01
04	0581019654	ASSY BOLT		01
05	0501011301	1.1/2 UNC 6FPP 2.5/16 NUT		01
06	0503010010	1/4" X 2.1/2" COTTERPIN		01
07	0521010681	BUSHING COUPLING BODY		01
08	0521010639	COUPLING SHAFT		01
09	0503010571	1/4" X 1.1/2 COTTERPIN		01
10	0503033731	LEFT COMPRESSION SPRING		02
11	0503010396	501060 CLAMPING RING (FOR AXLE)		01
12	0503011331	3/8 BALL		02
13	0501110778	TRACTOR HITCH		01




Item	Code	Description	See page	QT
01	0521064036	TRACTOR HITCH AXLE		01
02	0503030012	HITCH PIN CLIP		01




Item	Code	Description	See page	QT
01	0503060100	INSTRUCTIONS MANUAL CANISTER		01
02	0503010267	NYLON CLAMP		01
03	0503010363	BOLT 5/16 UNC X 1 C S G.2 ZN		01
04	0501010694	FLAT WASHER		01
05	0503010179	LOCK WASHER 5/16 ZN 1K01528		01
06	0503010337	5/16" NUT		01




Item	Code	Description	See page	QT
01	0521066302	HOSE HOLDER		01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		06
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		06
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		07
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		07
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		08
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		08
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01



Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		09
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		09
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0531058988	P.16 ENDLESS THREAD WITH COATING		10
01A	0531065012	ALPHA FERTILIZER METERING P.16MM WORM THREAD		01
01B	0503035859	SUPPORT SLEEVE		01
02	0531058992	PELLETIZED FERTILIZER KIT P.50 125 TO 650 KG/HA ALPHA		10
02A	0501111196	PELLETED FERTILIZER METERING COATING		01
02B	0531058987	ENDLESS THREAD WITH AXLE COVERING		01
03	0501214546	SPRING KEY		01
04	0503035928	ADHESIVE LABEL FERTILIZER TABLE ALPHA P16.5		01




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8" UNC SELF LOCKING NUT		06
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0511058449	HYDRAULIC CYLINDER	127	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" SPLIT PIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501069643	890 TURNBUCKLE		02
21	0503011854	5/8" X 1-1/4" BOLT		04
22	0501054649	HBM SEQUENTIAL VALVE	128	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
25	0503010025	3/8 SPRING WASHER		02
26	0511057208	HYDRAULIC MARKER HOSE KIT - 3245		01
26A	0501080452	3/8" X 98" TR-TR HOSE		02
26B	0501080414	3/8" X 110.2" TR-TC HOSE ASSY		02
26C	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
26CA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
26CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01

Item	Code	Description	See page	QT
26CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
26CD	0503018952	PLASTIC BOLT		06
26D	0521052850	3/8 X 4200 TC-TM PURPLE/BLUE HOSE		01
26DA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
26DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26DD	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	71	02
28	0502012702	BODY SUPPORT CLAMP		08
29	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		08
30	0503010180	7/16" SPRING WASHER		08
31	0503010244	7/16" NUT		02
32	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
33	0511058119	VALVE SUPPORT ASSEMBLY	129	01




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8" UNC SELF LOCKING NUT		04
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0511058449	HYDRAULIC CYLINDER	127	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" SPLIT PIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501069643	890 TURNBUCKLE		02
21	0503011854	5/8" X 1-1/4" BOLT		04
22	0501054649	HBM SEQUENTIAL VALVE	128	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
25	0503010025	3/8 SPRING WASHER		02
26	0511058119	VALVE SUPPORT ASSEMBLY	129	01
27	0501053834	MALE QUICK COUPLER	71	02
28	0502012702	BODY SUPPORT CLAMP		08
29	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		08
30	0503010180	7/16" SPRING WASHER		08
31	0503010244	7/16" NUT		02

Item	Code	Description	See page	QT
32	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
33	0511057367	HOSE KIT MARKER HYDRAULIC		01
33A	0501080296	3/8" X 106" TR-TR HOSE		02
33B	0501080397	3/8" X 120" TR-TC HOSE		02
34	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
34A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
34B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
34C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
34D	0503018952	PLASTIC BOLT		06
35	0521052850	3/8 X 4200 TC-TM PURPLE/BLEUE HOSE		01
35A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
35B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
35C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
35D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8" UNC SELF LOCKING NUT		04
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0511058449	HYDRAULIC CYLINDER	127	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" SPLIT PIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501069643	890 TURNBUCKLE		02
21	0503011854	5/8" X 1-1/4" BOLT		04
22	0501054649	HBM SEQUENTIAL VALVE	128	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
25	0503010025	3/8 SPRING WASHER		02
26	0511058119	VALVE SUPPORT ASSEMBLY	129	01
27	0501053834	MALE QUICK COUPLER	71	02
28	0502012702	BODY SUPPORT CLAMP		08
29	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		08
30	0503010180	7/16" SPRING WASHER		08
31	0503010244	7/16" NUT		02

Item	Code	Description	See page	QT
32	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
33	0511057312	HOSE KIT MARKER HYDRAULIC		
33A	0501081727	TR-TR HOSE ASSY		02
33B	0501080408	HOSE 3/8 X 3200 TR-TC		02
34	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
34A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
34B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
34C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
34D	0503018952	PLASTIC BOLT		06
35	0521052850	3/8 X 4200 TC-TM PURPLE/BUE HOSE		01
35A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
35B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
35C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
35D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8" UNC SELF LOCKING NUT		04
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0501012140	FLAT WASHER		04
12	0511058449	HYDRAULIC CYLINDER	127	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" SPLIT PIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501069643	890 TURNBUCKLE		02
21	0503011854	5/8" X 1-1/4" BOLT		04
22	0501054649	HBM SEQUENTIAL VALVE	128	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
25	0503010025	3/8 SPRING WASHER		02
26	0511058119	VALVE SUPPORT ASSEMBLY	129	01
27	0501053834	MALE QUICK COUPLER	71	02
28	0502012702	BODY SUPPORT CLAMP		08
29	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		08
30	0503010180	7/16" SPRING WASHER		08
31	0503010244	7/16" NUT		02

Item	Code	Description	See page	QT
32	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
33	0511057354	HYDRAULIC MARKER HOSE KIT - 4395		01
33A	0501081728	HOSE 3/8 X 3100 TR-TR		02
33B	0501080515	3/8" X 133" TR-TC HOSE		02
34	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
34A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
34B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
34C	0503034495	HYDRAULIC HOSE GRIP (RED)		01
34D	0503018952	PLASTIC BOLT		06
35	0521052850	3/8 X 4200 TC-TM PURPLE/BUE HOSE		01
35A	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
35B	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
35C	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
35D	0503018952	PLASTIC BOLT		06




Item	Code	Description	See page	QT
01	0521066622	ROW MARKER ARM SUPPORT		02
02	0503012699	BOLT 5/8NC X 2 CAPQ G.5 ZN 1K20548		04
03	0503012412	5/8" UNC SELF LOCKING NUT		04
04	0503011070	BEATER		02
05	0503010019	1/2" SPRING WASHER		02
06	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		02
07	0551019213	FLAT WASHER		02
08	0501069470	ROW MARKER ARM		02
09	0521061655	BOLT 5/8 UNC X 320 MM		02
10	0521010479	SLEEVE ARTICULATION		04
11	0503012412	5/8" UNC SELF LOCKING NUT		02
12	0511058449	HYDRAULIC CYLINDER	127	02
13	0521010575	C0.9" X 3.3" COUPLING SHAFT		02
14	0503010523	1/4" X 2" SPLIT PIN		02
15	0511015779	1" X 4.2" AXLE		02
16	0503010523	1/4" X 2" SPLIT PIN		02
17	0511017592	11.8" X 1.6" TRANSPORT LOCK		02
18	0501068994	8,30 X 78 LOCK PIN		02
19	0503030168	HITCH PIN CLIP		02
20	0501066949	1235 TURNBUCKLE		02
21	0503011854	5/8" X 1-1/4" BOLT		04
22	0501054649	HBM SEQUENTIAL VALVE	128	01
23	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
24	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
25	0503010025	3/8 SPRING WASHER		02
26	0511057334	HYDRAULIC MARKER HOSE KIT - 4845		01
26A	0501080343	TR-TR HOSE ASSY		02
26B	0501080435	3/8" X 141" TR-TC HOSE		02
26C	0521052849	3/8 X 4200 TC-TM PURPLE/RED HOSE		01
26CA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
26CB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01


Item	Code	Description	See page	QT
26CC	0503034495	HYDRAULIC HOSE GRIP (RED)		01
26CD	0503018952	PLASTIC BOLT		06
26D	0521052850	3/8 X 4200 TC-TM PURPLE/BUE HOSE		01
26DA	0501080878	3/8 X 4200 TC-TM HOSE ASSY		01
26DB	0503034491	HYDRAULIC HOSE GRIP (PURPLE)		01
26DC	0503034494	HYDRAULIC HOSE GRIP (BLUE)		01
26DD	0503018952	PLASTIC BOLT		06
27	0501053834	MALE QUICK COUPLER	71	02
28	0502012702	BODY SUPPORT CLAMP		06
29	0531011180	UPPER BODY CLIP		04
30	0503012555	SCREW 7/16 UNC X 2 CS RT G.7 ZN		06
31	0503010180	7/16" SPRING WASHER		06
32	0503010244	7/16" NUT		02
33	0571014419	PLASTIC PROTECTION SPRING HOSE 3/4 X 700MM		04
34	0501012140	FLAT WASHER		04
35	0581010011	VALVE FIXING SUPPORT		01




Item	Code	Description	See page	QT
01	0521066635	TURNBUCKLE		01
02	0511062810	2.5" X 15"CYLINDER CASE		01
03	0503030385	CYLINDER PLUG N-002		02
04	0502012837	PISTON		01
05	0503011109	2-119 N 3006-9B O'RING		01
06	0503018005	RING		01
07	0503018003	GASKET		01
08	0502010471	63,50 MOBILE CAP		01
09	0581010668	RING SUPPORT		01
10	0503010163	D-1500 SCRAPER RING		01
11	0503018004	RING		01
12	0503018163	BACK-UP RING		02
13	0503018162	O'RING		02
14	0511032280	ASSY REPAIR KIT 38,10 X 63,50 (0511058413)		01




Item	Code	Description	See page	QT
01	0503060132	VDFS-002 T SEQUENCCEL VALVE		01
02	0501010617	3/4" NIPPLE		02
03	0503010190	2-114 N 3006-9B O'RING		02
04	0501012109	3/4" X 9/16" NIPPLE FITTING		04
05	0503011036	2-111 N 3006-9B O'RING		06
06	0531019339	9/16" UNF X 12 PUMP		02




Item	Code	Description	See page	QT
01	0581010011	VALVE FIXING SUPPORT		01
02	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		02
03	0501010984	10,50 X 27 X 3,00 FLAT WASHER		04
04	0503010025	3/8 SPRING WASHER		02
05	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0511053904	ROW MARKER DISC	131	01
02	0503010023	3/4" SPRING WASHER		01
03	0503010014	3/4" HEX NUT		01



Item	Code	Description	See page	QT
01	0501066800	ROW MARKER DISC AXLE ASSY		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0602023110	DR16X3 NOTCHED DISC BLADE		01
04	0503010269	6204 BALL BEARING		02
05	0501013636	SPACING SLEEVE		01
06	0503010689	SEAL 00763-BR		01
07	0503011105	SEAL RING		01
08	0503030757	2.9" X 2" X 0.02" JOINT		01
09	0521019178	PROTECTION LID		01
10	0503011441	SPRING WASHER		03
11	0503014729	1/4" UNF X 1/2" BOLT		03
12	0503010878	5/8" SELF ALIGNING NUT		01
13	0503010691	1/4" GREASE FITTING		01
14	0503010358	5/16" X 5/8" BOLT		04
15	0503011444	SPRING WASHER		04
16	0503010337	5/16" NUT		04



Item	Code	Description	See page	QT
01	0503034660	CLAMP LOWER		01
02	0503034659	CLAMP UPPER		01
03	0503010686	0.2" X 0.7" SPRING PIN		01
04	0503011776	M6 SELF ADJUSTINGNUT		01
05	0503011813	M6 X 1.2" BOLT		01




Item	Code	Description	See page	QT
01	0511057505	SEED ROW FRONT PNEUM PP SHORT WITH RIGHT REAR	134	01
02	0511057506	SEED ROW FRONT PNEUM PP LONG WITH RIGHT REAR	135	01
03	0511057209	ROW RIGHT REAR SEED	144	01
04	0511057210	ROW LEFT REAR SEED	145	01
05	0511058639	SHORT FERTILIZER ROW WITH DDD/DC20	153	01
05.	0511058635	SHORT FERTILIZER ROW DDD 18" BLADE DISC	154	01
06	0511058640	LONG FERTILIZER ROW WITH DDD/DC20	156	01
06.	0511058636	LONG FERTILIZER ROW DDD 18" BLADE DISC	155	01
07	0511057509	SEED RESERVOIR PNEUMATIC ASSY	168	01
08	0521046122	DEPTH SYSTEM / COMPACTOR ASSY	169	01
09	0501110804	SCARIFIER ROD WITH POINT	179	10
10	0521069127	BOTTOM NOZZLE FERTILIZER		10
11	0503030391	RIGHT FERTILIZER NOZZLE		01
12	0503030392	LEFT FERTILIZER NOZZLE		01
13	0503031145	2" X 2" X 20" HOSE		01
14	0503031076	2" HOSE CLAMP		02
15	0531013600	PRESS ADJUSTMENT LEVER		01
16	0511017969	0.1" SPACING PLATE		20
17	0511018662	SPACING PLATE		20
18	0503062763	CONVERSION ASSY FOR DISTRIBUTOR SOY / BEANS		10
19	0503030520	SEED SOCKET		10
20	0521057957	FIXED ROD EXTENSION WITH FIXATION	180	05
21	0503031050	CURVED CONDUCTOR		10
22	0503010905	1/2" X 2-1/4" BOLT		02
23	0503010019	1/2" SPRING WASHER		06
24	0503010060	1/2 UNC G.5 ZN HEX NUT		06
25	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
26	0501010984	10,50 X 27 X 3,00 FLAT WASHER		01
27	0503010025	3/8 SPRING WASHER		01



PST PLUS FLEX SUPREMA PP - FRAME
ASSY SEED/FERTILIZER ROW

Page 133
0909090926

Item	Code	Description	See page	QT
28	0503010026	3/8" NUT		01
29	0511061769	RIGHT FERTILIZER CONDUCTOR WITH REGULATOR		01
30	0511061770	LEFT CONDUCTOR FERTILIZER WITH REGULATOR		01




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		02
03	0503017857	BOLT 5/8 UNF 4		04
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8" UNC SELF LOCKING NUT		04
08	0502012804	PIVOT ARM SEED ROW		02
09	0571018882	SEED ROW ARM SLEEVE		08
10	0503010002	1800 GREASE FITTING		04
11	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
12	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
13	0571018883	PIN FIXER SPRING		03
14	0571018884	LOCK PIN ROW ARTICULAT		01
15	0503030168	HITCH PIN CLIP		04
16	0511057276	TRANSMISSION SUPPORT RIGHT ASSY	136	01
17	0521065943	REAR FRAME LONG ROW SEED		01
18	0511057269	CHAIN TENSIONER	140	01
19	0511057507	TRANSMISSION LOWER FRONT		01
19A	0511059190	DOUBLE BEARING	142	01
19B	0581010976	5/8" HEX AXLE		01
19C	0503010300	5/32" X 1" COTTERPIN		01
19D	0501056296	UNIVERSAL JOINT		01
19E	0503011855	0.2" X 1.8" SPRING PIN		02
19F	0561014794	350 AXLE HEX		01
20	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
21	0581011694	PROTECTION REAR COVER SEED ROW		01
22	0503010765	3/8" X 3" BOLT		01
23	0503010025	3/8 SPRING WASHER		01
24	0503010026	3/8" NUT		01
25	0511058512	PROTECTION LID	141	01
26	0581011430	DRAWBAR ASSY		01



PST PLUS FLEX SUPREMA PP - FRAME
SEED ROW FRONT PNEUM PP SHORT WITH RIGHT REAR

Page 134
0511057505

Item	Code	Description	See page	QT
27	0521064369	HOSE HOLDER		01
28	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0521065941	FRAME SEED ROW FRONT		01
02	0502012789	FIXER SUPPORT FERTILIZER ROW		02
03	0503017960	5/8" X 3-12" BOLT		04
05	0503010811	5/8" UNF SELF ADJUSTING NUT		04
06	0503010967	SCREW 5/8 UNC X 5.1/2 CS G.5 ZN		04
07	0503012412	5/8" UNC SELF LOCKING NUT		04
08	0502012804	PIVOT ARM SEED ROW		02
09	0571018882	SEED ROW ARM SLEEVE		08
10	0503010002	1800 GREASE FITTING		04
11	0502012812	SEED ROW ADJUSTMENT LEVER ASSY		01
12	0503034198	SPRING TRACTION 40 X 198 X 5,5		01
13	0571018883	PIN FIXER SPRING		03
14	0571018884	LOCK PIN ROW ARTICULAT		01
15	0503030168	HITCH PIN CLIP		04
16	0511057276	TRANSMISSION SUPPORT RIGHT ASSY	136	01
17	0521066158	FRAME REAR LONG ROW SEED		01
18	0511057269	CHAIN TENSIONER	140	01
19	0511057508	TRANSMISSION LOWER FRONT		01
19A	0511059190	DOUBLE BEARING	142	01
19B	0581010976	5/8" HEX AXLE		01
19C	0503010300	5/32" X 1" COTTERPIN		02
19D	0501056296	UNIVERSAL JOINT		01
19E	0503011855	0.2" X 1.8" SPRING PIN		02
19F	0561014794	350 AXLE HEX		01
20	0503013215	40-1 CHAIN X 89 LINK + MENDING		01
21	0581011694	PROTECTION REAR COVER SEED ROW		01
22	0503010765	3/8" X 3" BOLT		01
23	0503010025	3/8 SPRING WASHER		01
24	0503010026	3/8" NUT		01
25	0511058512	PROTECTION LID	141	01
26	0581011430	DRAWBAR ASSY		01




PST PLUS FLEX SUPREMA PP - FRAME
SEED ROW FRONT PNEUM PP LONG WITH RIGHT REAR

Page 135
0511057506


Item	Code	Description	See page	QT
27	0521064369	HOSE HOLDER		01
28	0501012140	FLAT WASHER		04




Item	Code	Description	See page	QT
01	0511058766	BEARING	137	01
02	0511057273	ASSEMBLY TRANSMISSION	138	01
03	0503010300	5/32" X 1" COTTERPIN		01




Item	Code	Description	See page	QT
01	0502012852	ROW SEED UPPER BEARING		01
02	0503011105	SEAL RING		01
03	0502012851	17Z GEAR WITH HEX HOLE		01
04	0503011410	ROLLER BEARING		02
05	0503010406	501025 CLAMPING RING (FOR AXLE)		01
06	0503010237	3/8" X 1" BOLT		02
07	0503010025	3/8 SPRING WASHER		02
08	0503010026	3/8" NUT		02




Item	Code	Description	See page	QT
01	0511057159	TRANSMISSION HOPPER SEED ROW	139	01
02	0503032984	HOOD HEX AXLE ROW		01
03	0503013100	NYLON CLAMP		01
04	0571012492	5/8 X 330 AXLE HEX		01
05	0501056296	UNIVERSAL JOINT		01
06	0581010976	5/8" HEX AXLE		01
07	0503011855	0.2" X 1.8" SPRING PIN		02




Item	Code	Description	See page	QT
01	0502012465	TRANSMISSION HUB		01
02	0502012464	HOPPER TRANSMISSION LID		01
03	0503016995	6006 BALL BEARING		02
04	0503015895	6005 Z BALL BEARING		01
05	0503010143	1/4" SPRING WASHER		03
06	0503011378	M6X1X16 C S 8.8 ZN BOLT		03
07	0503010406	501025 CLAMPING RING (FOR AXLE)		01
08	0503010707	501030 CLAMPING RING (FOR AXLE)		02
09	0502040856	CONICAL GEAR		01
10	0571018870	14Z CONICAL GEAR		01
11	0503011105	SEAL RING		01
12	0503011409	6005 Z BALL BEARING		01
13	0503017008	SEAL RING		01
14	0503017007	SEAL RING		02
15	0511017907	1/8" BSPT X 6 PLUG		01
16	0503010003	1845 GREASE FITTING		01
17	0503035316	LUBRICATED POINTS ADHESIVE LABEL		01




Item	Code	Description	See page	QT
01	0503031805	11Z 1/2" GEAR		01
02	0511017302	FLAT WASHER 13,50 X 32,50 X 3,0 ZN		01
03	0503010019	1/2" SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0531019479	AXLE CHAIN GEAR		01




Item	Code	Description	See page	QT
01	0521066693	CAP BEARING		01
02	0503010834	1/2 X 1 BOLT		02
03	0503010019	1/2" SPRING WASHER		02




Item	Code	Description	See page	QT
01	0511059191	FRONT BEARING DOBLE	143	01
02	0502012851	17Z GEAR WITH HEX HOLE		01
03	0503010406	501025 CLAMPING RING (FOR AXLE)		01
04	0503011953	5/16" X 1" BOLT		02
05	0501010694	FLAT WASHER		02
06	0503010179	LOCK WASHER 5/16 ZN 1K01528		02
07	0503010337	5/16" NUT		02




Item	Code	Description	See page	QT
01	0502011971	HOUSING WITH DOUBLE BEARING		01
02	0503011410	ROLLER BEARING		02
03	0503011105	SEAL RING		01



Item	Code	Description	See page	QT
01	0511057502	SET PRECISION PLANTING	146	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057154	RIGHT DDD	149	01




Item	Code	Description	See page	QT
01	0511057502	SET PRECISION PLANTING	146	01
02	0503015920	3/8" UNC X 1.3/4" BOLT		04
03	0503010025	3/8 SPRING WASHER		04
04	0503010026	3/8" NUT		04
05	0503062403	TUBE SEED P.P		01
06	0511057153	DDD LEFT	152	01




Item	Code	Description	See page	QT
01	0502012807	SUPPORT HOPPER PRECISION PLANTING		01
01A	1902012807	SEED HOPPER SUPPORT		01
02	0502012776	SUPPORT ARTICULATION PNEUMATIC PP		01
03	0571017899	PIN LOCK		01
04	0503030190	0.5" X 1.6" X 0.05" SPRING		01
05	0571014024	FAST BOLT GUIDE AXLE		02
06	0571017897	AXLE ARTICULATION PRECISION PLANTING		01
07	0581011225	FIXER P PLANTING CONTR CPRA		01
08	0511057155	PRECISION PLANTING LEFT TRANSMISSION 147 HOPPER		01
09	0571017894	PIN DRAG PRECISION PLANTING		01
10	0503013357	3/8 SELF-ADJUSTING NUT		01
11	0503015752	3/8" X 2" BOLT		01
12	0501013518	FLAT WASHER		02
13	0503015356	SPRING PIN		01
14	0571017896	SLEEVE ARTICULATION PRECISION PLANTING		01
15	0571017895	PIN FIXER CONDUCTOR P.P		01
16	0503011776	M6 SELF ADJUSTINGNUT		03
17	0503032035	0.7" X 1.2" X 1" COMPRESSION SPRING		02
18	0503010293	CLAMP KNOB		01
19	0503010140	1/8" X 3/4" COTTERPIN		03
20	0503010131	3/16" X 1-1/2" COTTERPIN		01
21	0503010025	3/8 SPRING WASHER		01
22	0503037390	PACKING FOR PLANTING		01
23	0571019491	SLUICE PNEUMATIC		01
24	0501011643	3/8 X 1" BOLT		01
25	0503010209	3/8" UNC BUTTERFLY NUT		01
26	0503012721	1/4" X 4" BOLT		01
27	0503012880	1/4" UNC SELF ADJUSTING NUT		01
28	0581011226	FIXER CLOSING P. PLANTING CONTROL CPRA		01
29	0571019489	CLAMP PRECISION PLANTING		01


Item	Code	Description	See page	QT
30	0502012799	UPPER SUPPORT BASE PNEUMATIC PRECISION PLANTING		01
31	0511057491	P.P SEED ASSY SEED DISTRIBUTOR WITH CORN 148 DISC		01
31A	0503062405	SEED DISTRIBUTOR		01
31B	0503062407	SET SOYBEAN DISTRIBUTION		01
31B-01	0503062417	KIT CORN DISTRIBUTION		01
31B-02	0503062471	DISTRIBUTION ASSY (SORGHUM / MILLET)		01
31B-03	0503062577	DISTRIBUTION ASSY (LARGE CORN / SUNFLOWER)		01
31B-04	0503062578	DISTRIBUTION ASSY (LARGE CORN)		01
31B-05	0503062579	DISTRIBUTION ASSY (CORN / SUNFLOWER)		01
31B-06	0503062580	DISTRIBUTION ASSY (POPCORN / COTTON)		01
31B-07	0503062581	DISTRIBUTION ASSY (SMALL CORN / POP CORN)		01
31B-08	0503062573	CONVERSATION SET FOR DISTRIBUTION (LARGE BEAN)		01
31B-09	0503062574	CONVERSATION SET FOR DISTRIBUTION (SMALL BEET)		01
31B-10	0503062564	CONVERSATION SET FOR DISTRIBUTION (SOYBEAN / BEAN)		01
32	0561014778	HEX UNIVERSAL JOINT		01
33	0503013958	1/4" X 1" BOLT		02
34	0503818139	BOLT		03
35	0503011812	BOLT M6 X 1 X 12 CS 8.8 ZN		02
36	0503015110	M06 SPRING WASHER		02




Item	Code	Description	See page	QT
01	0502050052	LEFT SIDE TRANSMISSION HOPPER PP		01
02	0502050053	RIGHT SIDE TRANSMISSION HOPPER PP		01
03	0503011410	ROLLER BEARING		02
04	0503011182	6203 ROLLER BEARING		02
05	0503011184	502040 CLAMPING RING (FOR AXLE)		01
06	0571017655	FIXER SLEEVE		01
07	0503010373	SCREW 1/4 UNC X 2 CS G.2 ZN		03
08	0503010144	1/4" NUT		03
09	0511057504	JOIN GEAR		01
09A	0571017898	BODY GEAR TRANSMISSION		01
09B	0503011769	M8 X 0.5" BOLT		01
10	0581011222	PINION AXLE 6Z PNEUMATIC		01
11	0503034340	PINION AXLE 6Z PNEUMATIC		01




Item	Code	Description	See page	QT
01	0571019613	STRAW PRECISION PLANTING SHIELD		01
02	0521052131	VSET2 DISTRIBUTOR WITH CORN DISC WITHOUT PROTECTION		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	150	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	RIGHT LOW HUB WITH 15 DISC	151	01
04	0503810026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012780	SUPPORT DDD RIGHT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O'RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011151	LEFT DOUBLE DISC HUB		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0503063161	BEARING 5204 WITH SEALING RING		01
02	0571011150	RIGHT DOUBLE DISC AXLE		01
03	0603022042	13" X 0.12" PLAIN COULTER BLADE		01
04	0503010546	5/16" X 7/8" BOLT		06
05	0503010337	5/16" NUT		06
06	0502012736	HUB LOWER		01




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	150	01
02	1902012779	PROTECTION CONDUCTOR PNEUMATIC PRECISION		01
03	0511053173	RIGHT LOW HUB WITH 15 DISC	151	01
04	0503810026	3/8" NUT		01
05	0503011443	3/8" SPRING WASHER		01
06	0501810984	FLAT WASHER		02
07	0503810751	3/8 UNC X 1.1/4 C S G.5 - SCREW		01
08	0571017964	LEFT DOUBLE DISC SCRAPER		01
08.	0561010265	LH DOUBLE DISC SCRAPER - STARTING 04/18		01
09	0571017963	RIGHT DOUBLE DISC SCRAPER		01
09.	0561010264	RH DOUBLE DISC SCRAPER - STARTING 04/18		01
10	0502012781	SUPPORT DDD LEFT		01
11	0511815098	FLAT WASHER		04
12	0503011402	0.2" X 0.8" SPRING PIN		01
13	0503013129	ELASTIC PIN		01
14	0503015081	502052 CLAMPING RING (FOR AXLE)		02
15	0511011927	DUST CLOAK		02
16	0571011152	DOUBLE DISC CAP		02
17	0503014679	2-134 O-RING		02
18	0591014250	19 X 26 X 0,50 FLAT WASHER		02







Item	Code	Description	See page	QT
01	0511058633	FIXED SHORT SUPPORT FERTILIZER ROW	157	01
01A	0502012794	SHORT SUPPORT FERTILIZER ROW		01
02	0511058629	18" COULTER BLADE ASSY FOR SHORT ROW	163	01
03	0503011854	5/8" X 1-1/4" BOLT		02
04	0503010002	1800 GREASE FITTING		01
05	0502012789	FIXER SUPPORT FERTILIZER ROW		01
06	0503017960	5/8" X 3-12" BOLT		04
07	0503010811	5/8" UNF SELF ADJUSTING NUT		04
08	0521066744	FERTILIZER ROW ADJUSTMENT SPRING		01
09	0571019062	SLEEVE		01
10	0571019059	SUPPORT WASHER		01
12	0503034320	COMPRESSION SPRING		01
13	0502012813	FLANGE WASHER SPRING		01
14	0503010417	7/8" NUT		02
15	0511016281	3/4" X 8" BOLT		02
16	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
17	0503011255	3/4" LOCK NUT		02
18	0511057272	LH SHORT ARM ROW FERTILIZER	158	01
18A	0521065972	LH SHORT ARM ROW FERTILIZER		01
18B	0502012815	DOUBLE-DISC SPACING PLATE		02
18C	0503810479	BOLT		02
18D	0503011440	SPRING WASHER		04
18E	0503010060	1/2 UNC G.5 ZN HEX NUT		04
19	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	159	01
20	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	165	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057271	RH LONG ARM ROW FERTILIZER	166	01
06	0511058629	18" COULTER BLADE ASSY FOR SHORT ROW	163	01




Item	Code	Description	See page	QT
01	0511058634	SUPPORT LONG	165	01
02	0511016281	3/4" X 8" BOLT		02
03	0571019061	FERTILIZER ROW SUPPORT ARM SLEEVE		02
04	0503011255	3/4" LOCK NUT		02
05	0511057271	RH LONG ARM ROW FERTILIZER	166	01
06	0511058630	20" DISC BLADE	160	01




Item	Code	Description	See page	QT
01	0502012794	SHORT SUPPORT FERTILIZER ROW	01	
02	0503011854	5/8" X 1-1/4" BOLT	02	
03	0503010002	1800 GREASE FITTING	01	
04	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
05	0503017960	5/8" X 3-12" BOLT	04	
06	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
07	0521066744	FERTILIZER ROW ADJUSTMENT SPRING	01	
08	0571019062	SLEEVE	01	
09	0571019059	SUPPORT WASHER	01	
10	0503010417	7/8" NUT	04	
11	0503034320	COMPRESSION SPRING	01	
12	0502012813	FLANGE WASHER SPRING	01	




Item	Code	Description	See page	QT
01	0521065972	LH SHORT ARM ROW FERTILIZER		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0511053209	DDD FERTILIZER 15 X 15 LEFT MINOR	159	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0511053172	LEFT LOW HUB WITH 15 DISC	150	01
02	0511053173	RIGHT LOW HUB WITH 15 DISC	151	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011161	15"X15" LEFT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010026	3/8" NUT		01
14	0503010025	3/8 SPRING WASHER		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0571018989	LH BLADE DISC ARM		01
02	0502012790	LOCK NUT		01
03	0511058648	HUB WITH 20" DISC BLADE	161	01
04	0521065978	RIGHT ARM WITH WASHER LOCK		01
05	0571019035	SLEEVE SUPPORT ARM		01
06	0521010452	SLEEVE		01
07	0521066743	SPRING REGULATOR		01
08	0503010417	7/8" NUT		04
09	0571019033	FIXATION AXLE		01
10	0503034319	LOCK PIN		01
11	0502012813	FLANGE WASHER SPRING		01
12	0503034320	COMPRESSION SPRING		01
13	0571019032	SUPPORT WASHER		01
14	0571019034	FLANGE WASHER AXLE		02
15	0503010002	1800 GREASE FITTING		01
16	0503013185	3/4" X 5-1/2" BOLT		01
17	0503011255	3/4" LOCK NUT		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503011440	SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	162	01
02	0603027851	20" X 0.2" FLAT PLAIN DISC		01




Item	Code	Description	See page	QT
01	0502012793	DISC HUB		01
02	0571018047	DISC BLADE HUB AXLE		01
03	0503017755	NUT		01
04	0502020641	BLADE DISC FLANGE		01
05	0503013816	5/16" LOCKNUT		06
06	0571018048	BACKREST WASHER		02
07	0521065882	NILOS SEALING RING		02
08	0571018049	DUST CLOAK		02
09	0581010575	7/8" X 145 BOLT		01
10	0503018825	5/16 UNC UNC BOLT		06
11	0501010694	FLAT WASHER		06
12	0503016061	BEARING		02
13	0511017907	1/8" BSPT X 6 PLUG		01




Item	Code	Description	See page	QT
01	0571018989	LH BLADE DISC ARM		01
02	0502012790	LOCK NUT		01
03	0511056910	HUB WITH 18" DISC BLADE	164	01
04	0521065978	RIGHT ARM WITH WASHER LOCK		01
05	0571019035	SLEEVE SUPPORT ARM		01
06	0521010452	SLEEVE		01
07	0521066743	SPRING REGULATOR		01
08	0503010417	7/8" NUT		04
09	0571019033	FIXATION AXLE		01
10	0503034319	LOCK PIN		01
11	0502012813	FLANGE WASHER SPRING		01
12	0503034320	COMPRESSION SPRING		01
13	0571019032	SUPPORT WASHER		01
14	0571019034	FLANGE WASHER AXLE		02
15	0503010002	1800 GREASE FITTING		01
16	0503013185	3/4" X 5-1/2" BOLT		01
17	0503011255	3/4" LOCK NUT		01
18	0503011411	1/2" X 5-1/2" BOLT		01
19	0503010019	1/2" SPRING WASHER		01
20	0503010060	1/2 UNC G.5 ZN HEX NUT		01




Item	Code	Description	See page	QT
01	0511056909	DISC BLADE HUB WITHOUT DISC	162	01
02	0603026013	PLAIN COULTER BLADE		01




Item	Code	Description	See page	QT
01	0502012795	SUPPORT LONG	01	
02	0503011854	5/8" X 1-1/4" BOLT	02	
03	0503010002	1800 GREASE FITTING	01	
04	0502012789	FIXER SUPPORT FERTILIZER ROW	01	
05	0503017960	5/8" X 3-12" BOLT	04	
06	0503010811	5/8" UNF SELF ADJUSTING NUT	04	
07	0521066744	FERTILIZER ROW ADJUSTMENT SPRING	01	
08	0571019062	SLEEVE	01	
09	0571019059	SUPPORT WASHER	01	
10	0503010417	7/8" NUT	04	
11	0503034320	COMPRESSION SPRING	01	
12	0502012813	FLANGE WASHER SPRING	01	




Item	Code	Description	See page	QT
01	0521065973	RH LONG ARM ROW FERTILIZER		01
02	0502012815	DOUBLE-DISC SPACING PLATE		02
03	0503010479	BOLT		02
04	0503011440	SPRING WASHER		02
05	0503010060	1/2 UNC G.5 ZN HEX NUT		02
06	0511053208	DDD FERTILIZER 15 X 15 RIGHT MINOR	167	01
07	0503010706	BOLT 1/2 UNC X 4.1/2 C S G.5 ZN		02
08	0503011440	SPRING WASHER		02
09	0503010060	1/2 UNC G.5 ZN HEX NUT		02




Item	Code	Description	See page	QT
01	0511053173	RIGHT LOW HUB WITH 15 DISC	151	01
02	0511053172	LEFT LOW HUB WITH 15 DISC	150	01
03	0511011927	DUST CLOAK		02
04	0503014679	2-134 O'RING		02
05	0571011152	DOUBLE DISC CAP		02
06	0503015081	502052 CLAMPING RING (FOR AXLE)		02
07	0511815098	FLAT WASHER		02
08	0502011160	15"X15" RIGHT DOUBLE DISC SUPPORT		01
09	0501017542	LH DOUBLE DISC SCRAPER		01
10	0501017541	RIGHT DOUBLE DISC SCRAPER		01
11	0503010751	C3/8" X 1.1/4" HEX BOLT G.5		01
12	0501010984	10,50 X 27 X 3,00 FLAT WASHER		02
13	0503010025	3/8 SPRING WASHER		01
14	0503010026	3/8" NUT		01
15	0502070062	SCRAPER		01
16	0503011402	0.2" X 0.8" SPRING PIN		01
17	0591014250	19 X 26 X 0,50 FLAT WASHER		02




Item	Code	Description	See page	QT
01	0502012798	SUPPORT HOPPER SEED		01
02	0581012694	COMPACT PROTECTION		01
03	0503010849	3/8" X 1-1/2" BOLT		03
04	0501010096	3/8" X 2" BOLT		01
05	0503010025	3/8 SPRING WASHER		04
06	0503010026	3/8" NUT		04
07	0503031508	COVER GREEN BEAM SEED YELLOW		01
08	0503010358	5/16" X 5/8" BOLT		04
09	0501010694	FLAT WASHER		04
10	0503010179	LOCK WASHER 5/16 ZN 1K01528		04
11	0503010337	5/16" NUT		04




Item	Code	Description	See page	QT
01	0511058650	SEMI-MOUNTED DEPTH CONTROL	170	01
02	0501052538	DEPTH BAND WITH ARMS	175	02
03	0503010358	5/16" X 5/8" BOLT		08
04	0503013816	5/16" LOCKNUT		08
05	0511054333	COMPACT WHEEL RIGHT WITH BEARING	176	01
06	0511054334	COMPACT WHEEL LEFT WITH BEARING	178	01
07	0503033942	COMPACTOR WHEEL REGULATOR LID		01




Item	Code	Description	See page	QT
01	0502012282	DEPTH CONTROL SUPPORT		01
02	0581011100	DEPTH WHEEL AXLE		01
03	0521010480	1" X 1.2" X 0.4" ARTICULAT SLEEVE		02
04	0511015346	FLAT WASHER		02
05	0521064073	REGULACION WHEEL COMPACTOR		01
06	0511058652	LEFT DEPTH WHEEL ARM WITH HUB	171	01
07	0511058651	RIGHT DEPTH WHEEL ARM WITH HUB	173	01
08	0571017749	FLAT WASHER		02
09	0503011440	SPRING WASHER		02
10	0501052297	DEPTH WHEELS REGULATOR ASSY	174	01
11	0521019093	0.6" X 2.7" PIVOT SHAFT		01
12	0503010581	RING		01
13	1902012116	PRESS WHEEL ADJUSTER		01
14	0503010849	3/8" X 1-1/2" BOLT		02
15	0503011443	3/8" SPRING WASHER		02
16	0503010026	3/8" NUT		02
17	0541016906	PRESS WHEELS REGULATOR BODY		01
18	0521010539	0.3" X 1.2" COUPLING SHAFT		01
19	0503010140	1/8" X 3/4" COTTERPIN		01
20	0503030805	1.6" X 6" X 0.2 TRACTION SPRING		01
21	0503010311	1/2" X 1-1/4" BOLT		02
22	0503034377	3/8 UNC X 3/4 BOLT		01




Item	Code	Description	See page	QT
01	0501110834	LH ARM		01
02	0501052627	ASSY DEPTH WHEEL HUB	172	01
03	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
04	0503011440	SPRING WASHER		01
05	0503010060	1/2 UNC G.5 ZN HEX NUT		01
06	0503010002	1800 GREASE FITTING		01




Item	Code	Description	See page	QT
01	0511060927	DEPTH CONTROL AXLE WITH DUST CLOAK		01
02	0502011907	DEPTH CONTROL WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0501013636	SPACING SLEEVE		01
05	0503010689	SEAL 00763-BR		01
06	0503011105	SEAL RING		01
07	0503010878	5/8" SELF ALIGNING NUT		01
08	0521019178	PROTECTION LID		01
09	0503030757	2.9" X 2" X 0.02" JOINT		01
10	0503014729	1/4" UNF X 1/2" BOLT		03
11	0503011441	SPRING WASHER		03
12	0503010691	1/4" GREASE FITTING		01




Item	Code	Description	See page	QT
01	0501052627	ASSY DEPTH WHEEL HUB	172	01
02	0503010740	BOLT 1/2 UNC X 2 CS G.5 ZN		01
03	0503011440	SPRING WASHER		01
04	0503010060	1/2 UNC G.5 ZN HEX NUT		01
05	0503010002	1800 GREASE FITTING		01
06	0501110833	DEPTH CONTROL RIGHT ARM		01




Item	Code	Description	See page	QT
01	0502011689	1/8" DEPTH CONTROL LEVER		01
02	0503030975	0.9" X 1.5" X 0.1" SPRING		01
03	0502011688	DEPTH CONTROL LEVER		01
04	0581019519	FLAT WASHER		01
05	0503010071	3/16" X 1" COTTERPIN		01
06	0511060699	DEPTH WHEEL STOP		01
07	0503019398	AXLE RETAINER RING		01




Item	Code	Description	See page	QT
01	0503030551	DEPTH CONTROL WHEEL RUBBER BAND		01
02	0521010832	RIM FLANGE		02
03	0503010298	1/4" X 1/2" BOLT		05
04	0503010143	1/4" SPRING WASHER		05
05	0503010144	1/4" NUT		05




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	177	01
02	0503016449	1/2 X 4 BOLT		01
03	0521014508	FLAT WASHER		03
04	0503012136	NUT 1/2 NF		01




Item	Code	Description	See page	QT
01	0502011919	PRESS WHEEL HUB		01
02	0502011877	PRESS WHEEL HUB		01
03	0503010269	6204 BALL BEARING		02
04	0521018922	PRESS WHEEL PASSANG AXLE		02
05	0503012734	SEAL 01556 BR		02
06	0521018921	DUST CLOAK		02
07	0503010691	1/4" GREASE FITTING		01
08	0521018928	PRESS WHEEL RIM		02
09	0503031421	DEPTH CONTROL WHEEL RUBBER BAND		01
10	0503010011	5/16" X 1/2" BOLT		06
11	0503010358	5/16" X 5/8" BOLT		03
12	0503013816	5/16" LOCKNUT		03




Item	Code	Description	See page	QT
01	0501052908	COMPACTOR WHEEL WITH BEARING	177	01
02	0503016863	BOLT 1/2 UNF X 4 CS R/ LEFT		01
03	0521014508	FLAT WASHER		03
04	0503016864	LH 1/2" LOCK NUT		01



Item	Code	Description	See page	QT
01	0521065998	SCARIFIER SPINDLE		01
02	0502070061	POINT SUBSOILER		01
03	0503011373	0.4" X 1.1" SPRING PIN		01



Item	Code	Description	See page	QT
01	0521068467	FIXED ROD EXTENSION		01
02	0503010479	BOLT		02
03	0503010019	1/2" SPRING WASHER		02
04	0503010060	1/2 UNC G.5 ZN HEX NUT		02



MARCHESAN

Technical Publications | Elaboration and Revision

LEONARDO JOSÉ DA SILVA SOUZA

www.marchesan.com.br

